

# LEXUS NAVIGATION SYSTEM (RHD)

## SYSTEM OUTLINE

The LEXUS navigation system displays the operating status and instructions for the automatic air conditioner or radio and player, as well as trip information. Additionally, the navigation system precisely measures the current vehicle position, displays the map obtained from the map database on the screen, and informs the route to the destination shown on the map using voice guidance.

## SERVICE HINTS

### N6 (D) NAVIGATION ECU

- (D) 3-GROUND : Always approx. **12** volts
- (D) 9-GROUND : Approx. **12** volts with ignition SW at **ACC** or **ON** position
- (D) 6-GROUND : Always continuity

### M1 MULTI-DISPLAY

- 3-GROUND : Always approx. **12** volts

### R8 REMOTE CONTROL RECEIVER

- 5-GROUND : Approx. **12** volts with ignition at **ACC** or **ON** position
- 1-GROUND : Always continuity

## ○ : PARTS LOCATION

Code		See Page	Code		See Page	Code		See Page
B1	B	104 (RHD)	J6		107 (RHD)	N5	C	109 (RHD)
C3		104 (RHD)	J9		107 (RHD)	N6	D	109 (RHD)
C10		106 (RHD)	J11		107 (RHD)	R2	A	107 (RHD)
D4		106 (RHD)	J13		108 (RHD)	R3	B	107 (RHD)
F12		108 (RHD)	M1		107 (RHD)	R5	D	107 (RHD)
F14		108 (RHD)	N1	A	105 (RHD)	R8		107 (RHD)
J2	A	105 (RHD)	N3	A	109 (RHD)	S9		107 (RHD)
J3	B	105 (RHD)	N4	B	109 (RHD)			

## ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1D	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)
1E		
1H		
1I		
1L	88 (RHD)	Floor Wire and Driver Side J/B (Right Kick Panel)
2A	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)
2E		
2F		
2G	90 (RHD)	Engine Room Main Wire and Passenger Side J/B (Left Kick Panel)
2H	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)
2I	90 (RHD)	Floor No.2 Wire and Passenger Side J/B (Left Kick Panel)
2L	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)
2N	90 (RHD)	Engine Room Main Wire and Passenger Side J/B (Left Kick Panel)

## □ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IH1	126 (RHD)	Instrument Panel Wire and Floor Wire (Near the Driver Side J/B)
IH2		
IH3		
II1	126 (RHD)	Front Door RH Wire and Instrument Panel Wire (Left Kick Panel)

**: GROUND POINTS**

Code	See Page	Ground Points Location
BJ	128 (RHD)	Front Floor Panel LH
BL	128 (RHD)	Front Floor Panel RH