

Packet Tracer - Use Ping and Traceroute to Test Network Connectivity

Addressing Table

Device	Interface	IP Address / Prefix		Default Gateway
R1	G0/0	2001:db8:1:1::1/64		N/A
	G0/1	10.10.1.97	255.255.255.224	N/A
	S0/0/1	10.10.1.6	255.255.255.252	N/A
		2001:db8:1:2::2/64		
		fe80::1		
R2	S0/0/0	10.10.1.5	255.255.255.252	N/A
		2001:db8:1:2::1/64		
	S0/0/1	10.10.1.9	255.255.255.252	N/A
		2001:db8:1:3::1/64		
		fe80::2		
R3	G0/0	2001:db8:1:4::1/64		N/A
	G0/1	10.10.1.17	255.255.255.240	N/A
	S0/0/1	10.10.1.10	255.255.255.252	N/A
		2001:db8:1:3::2/64		
		fe80::3		
PC1	NIC	10.10.1.98	255.255.255.224	10.10.1.97
PC2	NIC	2001:DB8:1:1::2		FE80::1
PC3	NIC	10.10.1.18	255.255.255.240	10.10.1.17
PC4	NIC	2001:DB8:1:4::2		FE80::2

Objectives

Part 1: Test and Restore IPv4 Connectivity

Part 2: Test and Restore IPv6 Connectivity

Scenario

There are connectivity issues in this activity. In addition to gathering and documenting information about the network, you will locate the problems and implement acceptable solutions to restore connectivity.

Note: The user EXEC password is **cisco**. The privileged EXEC password is **class**.

Instructions

Part 1: Test and Restore IPv4 Connectivity

Step 1: Use ipconfig and ping to verify connectivity.

- Click **PC1** and open the **Command Prompt**.
- Enter the **ipconfig /all** command to collect the IPv4 information. Complete the **Addressing Table** with the IPv4 address, subnet mask, and default gateway.
- Click **PC3** and open the **Command Prompt**.
- Enter the **ipconfig /all** command to collect the IPv4 information. Complete the **Addressing Table** with the IPv4 address, subnet mask, and default gateway.
- Use the **ping** command to test connectivity between **PC1** and **PC3**. The ping should fail.

Step 2: Locate the source of connectivity failure.

- From **PC1**, enter the necessary command to trace the route to **PC3**.

What is the last successful IPv4 address that was reached?

10.10.1.97

- The trace will eventually end after 30 attempts. Enter **Ctrl+C** to stop the trace before 30 attempts.
- From **PC3**, enter the necessary command to trace the route to **PC1**.

What is the last successful IPv4 address that was reached?

10.10.1.17

- Enter **Ctrl+C** to stop the trace.
- Click **R1**. Press **ENTER** and log in to the router.
- Enter the **show ip interface brief** command to list the interfaces and their status. There are two IPv4 addresses on the router. One should have been recorded in Step 2a.

What is the other?

10.10.1.6

- Enter the **show ip route** command to list the networks to which the router is connected. Note that there are two networks connected to the **Serial0/0/1** interface.

What are they?

10.10.1.4/30 and 10.10.1.6/32

- Repeat steps 2e through 2g with **R3** and record your answers.

10.10.1.10

10.10.1.8/30, 10.10.1.10/32

- i. Click **R2**. Press **ENTER** and log into the router.
- j. Enter the **show ip interface brief** command and record your addresses.
- k. Run more tests if it helps visualize the problem. Simulation mode is available.

Step 3: Propose a solution to solve the problem.

Compare your answers in Step 2 to the documentation you have available for the network.

What is the error?

S0/0/0 ip number in R2 is assigned wrong

What solution would you propose to correct the problem?

By going to the config mode of R2, I need to reset the s0/0/0 's ip address to 10.10.1.5.

Step 4: Implement the plan.

First ping from both pc and try to from which end the packet is sending and receiving or not, if packet is losing the try to trace the route that till which hop the packet is going after that check that routes all config ip address and other things are ok not then just reset if any problem.

Step 5: Verify that connectivity is restored.

- a. From **PC1** test connectivity to **PC3**.
- b. From **PC3** test connectivity to **PC1**.

Yes

Step 6: Document the solution.

R2 -> configure terminal
R2 -> interface s0/0/0
R2 -> ip address 10.10.1.5 255.255.255.252
R2 -> no shutdown
R2 -> exit
PC1 -> ping 10.10.1.18
PC3 -> ping 10.10.1.98

Part 2: Test and Restore IPv6 Connectivity

Step 1: Use ipv6config and ping to verify connectivity.

- a. Click **PC2** and open the **Command Prompt**.

- b. Enter the **ipv6config /all** command to collect the IPv6 information. Complete the **Addressing Table** with the IPv6 address, subnet prefix, and default gateway.
- c. Click **PC4** and open the **Command Prompt**.
- d. Enter the **ipv6config /all** command to collect the IPv6 information. Complete the **Addressing Table** with the IPv6 address, subnet prefix, and default gateway.
- e. Test connectivity between **PC2** and **PC4**. The ping should fail.

Step 2: Locate the source of connectivity failure.

- a. From **PC2**, enter the necessary command to trace the route to **PC4**.

What is the last successful IPv6 address that was reached?

2001:DB8:1:3::2

- b. The trace will eventually end after 30 attempts. Enter **Ctrl+C** to stop the trace before 30 attempts.
- c. From **PC4**, enter the necessary command to trace the route to **PC2**.

What is the last successful IPv6 address that was reached?

No ipv6 address visited

- d. Enter **Ctrl+C** to stop the trace.
- e. Click **R3**. Press **ENTER** and log in to the router.
- f. Enter the **show ipv6 interface brief** command to list the interfaces and their status. There are two IPv6 addresses on the router. One should match the gateway address recorded in Step 1d.

Is there a discrepancy?

No

- g. Run more tests if it helps visualize the problem. Simulation mode is available.

Step 3: Propose a solution to solve the problem.

Compare your answers in Step 2 to the documentation you have available for the network.

What is the error?

The Default Gateway address of the PC4 was set wrong

What solution would you propose to correct the problem?

We just need to go to the ip configuration of PC4 and set it to *FE80::3 from FE80::2*.

Step 4: Implement the plan.

Implement the solution you proposed in Step 3b.

First ping from both pc and try to from which end the packet is sending and receiving or not, if packet is losing the try to trace the route that till which hop the packet is going after that check that routes all config ip address and other things are ok not then just reset if any problem.

Step 5: Verify that connectivity is restored.

- a. From **PC2** test connectivity to **PC4**.
- b. From **PC4** test connectivity to **PC2**.

Is the problem resolved?

Step 6: Document the solution.

R3 -> show ipv6 interface brief

Then just need to go to the ip configuration of PC4 and set it to *FE80::3*.