

The Mediatek logo consists of the word "MEDIATEK" in a bold, white, sans-serif font, centered within an orange parallelogram with a slight 3D effect.

**MEDIATEK**

# MT76 Test Mode Programming Guide

**Version:** 2.3  
**Release date:** 2024-12-03

Use of this document and any information contained therein is subject to the terms and conditions set forth in Exhibit 1. This document is subject to change without notice.

---

## Version History

Version	Date	Author	Description
1.0	2022-03-10	Shayne Chen	Official release
1.1	2022-08-15	StanleyYP Wang	Add pre-cal
1.2	2022-08-30	StanleyYP Wang	Add an iwpriv command mapping table and some description
1.3	2022-09-08	StanleyYP Wang	Add iBF
1.4	2022-10-07	StanleyYP Wang	Add bridge name config for ateni
1.5	2022-11-08	StanleyYP Wang	Add ZWDFS
1.6	2022-12-21	StanleyYP Wang	Add eBF certification & iBF calibration with golden
1.7	2023-02-23	Hugo Yang	Apply AIP format
1.8	2023-03-17	StanleyYP Wang	Add per-chip status
1.9	2023-05-10	StanleyYP Wang	Fix typo
1.10	2023-07-26	StanleyYP Wang	Add ateni eeprom iBF calibration sync command
1.11	2023-10-27	StanleyYP Wang	Add single sku enable command in testmode
1.12	2023-11-05	StanleyYP Wang	Add mt7981 support
2.0	2023-11-15	StanleyYP Wang	Add Wi-Fi 7 chipset (mt7996) support
2.1	2024-03-28	StanleyYP Wang	Modify <a href="#">3.7.1 DUT Command for Calibration with Instrument</a> to add missing command for iBF instrument calibration
2.2	2024-11-29	StanleyYP Wang	<ul style="list-style-type: none"> <li>Add Wi-Fi 7 chipset mt7992 support</li> <li>Modify <a href="#">2.2 MT76 Test</a> to add mt76-test interface add/delete commands and add single wiphy support</li> <li>Modify <a href="#">2.3.7 Write Back EEPROM Data to Flash</a> to add ateni eMMC write back support</li> </ul>
2.3	2024-12-03	StanleyYP Wang	<ul style="list-style-type: none"> <li>Add <a href="#">6.4 Abbreviations</a></li> <li>Modify <a href="#">2.3.7 Write Back EEPROM Data to Flash</a> to add eMMC write back example</li> </ul>

# Table of Contents

<b>Version History .....</b>	<b>2</b>
<b>Table of Contents .....</b>	<b>3</b>
<b>1 Introduction.....</b>	<b>6</b>
<b>2 Usage.....</b>	<b>8</b>
2.1 Pre-setting .....	8
2.1.1 Set Country Code .....	8
2.1.2 Check Firmware Mode (Mandatory for Wi-Fi 7) .....	8
2.1.3 Enter Test Mode Firmware Mode (Mandatory for Wi-Fi 7) .....	8
2.2 MT76 Test.....	10
2.2.1 Start Test Mode.....	10
2.2.2 Stop Test Mode .....	11
2.2.3 Start and Stop TX .....	11
2.2.4 Start and Stop RX .....	11
2.2.5 Start and Stop Continuous TX .....	12
2.2.6 Set Band Index .....	12
2.2.7 Set Channel and Bandwidth.....	12
2.2.8 Set TX Count.....	13
2.2.9 Set TX Length .....	13
2.2.10 Set Antenna.....	14
2.2.11 Set Spatial Extension Index .....	14
2.2.12 Set Guard Interval and Long Training Field .....	15
2.2.13 Set TX Rate Mode.....	16
2.2.14 Set TX Rate Index (MCS).....	17
2.2.15 Set Spatial Stream Number.....	17
2.2.16 Set LDPC .....	17
2.2.17 Set STBC .....	18
2.2.18 Set TX Power .....	18
2.2.19 Set Packet TX Time .....	18
2.2.20 Set Inter-packet Gap .....	19
2.2.21 Set Duty Cycle .....	19
2.2.22 Set TX Frequency Offset.....	20
2.2.23 Set MAC Address.....	20
2.2.24 Set AID for Virtual WTBL .....	20
2.2.25 Set RU Index .....	20
2.2.26 Set RU Allocation .....	21
2.2.27 Dump Settings.....	21
2.2.28 Dump Statistics .....	22
2.2.29 Group Pre-calibration.....	22
2.2.30 DPD/Flatness Pre-calibration .....	23
2.2.31 Implicit Beamforming (iBF) .....	24
2.2.31.1 Init Setting for iBF .....	24
2.2.31.2 Phase Compensation .....	25
2.2.31.3 BF Profile Configuration Read and Write .....	26

2.2.31.3.1 eBF/iBF Profile Configuration Update .....	26
2.2.31.3.2 Channel Profile Configuration Update .....	26
2.2.31.3.3 PFMU Tag Write .....	27
2.2.31.3.4 PFMU Tag Read .....	28
2.2.31.3.5 Set PFMU Tag Invalid Bit .....	28
2.2.31.3.6 BF Station Record Read .....	29
2.2.31.4 BF TX Setting .....	30
2.2.31.4.1 Apply TXBF to WTBL .....	30
2.2.31.4.2 BF TX Preparation .....	30
2.2.31.4.3 BF TXCMD Configuration .....	31
2.2.31.5 TXBF Trigger/Stop Sounding .....	31
2.2.31.6 iBF Calibration .....	32
2.2.31.7 iBF Save to EEPROM .....	33
2.2.32 Explicit Beamforming (eBF) .....	34
2.2.32.1 Init Setting for eBF .....	34
2.2.33 Zero Wait DFS (ZWDFS) .....	35
2.2.33.1 Set channel and bandwidth of background chain .....	35
2.2.33.2 Dump Channel and Bandwidth of Background Chain .....	36
2.2.33.3 Read Idle Power Indicator (IPI) Histogram of Background Chain .....	36
2.2.33.4 Reset Idle Power Indicator (IPI) Counter of Background Chain .....	38
2.2.34 Enable TX Power Single SKU .....	39
2.3 atenl .....	41
2.3.1 Start Daemon .....	41
2.3.2 Check EEPROM Mode .....	41
2.3.3 Clear EEPROM Data Temp File .....	42
2.3.4 Read EEPROM Data .....	42
2.3.5 Change Value to Specific Offset .....	42
2.3.6 Update Buffer Mode .....	42
2.3.7 Write Back EEPROM Data to Flash .....	43
2.3.8 Write Back EEPROM Data to eFuse .....	43
2.3.9 Write Back EEPROM Data to Bin File .....	44
2.3.10 Write Back Pre-cal Data to Flash .....	44
2.3.11 Clean Pre-cal Data in Flash .....	44
2.3.12 Sync iBF Cal Data from Driver .....	45
2.4 Wrapper .....	45
2.4.1 iwpriv Wrapper .....	45
2.4.2 ated Wrapper .....	46
<b>3 Example and Cross Reference .....</b>	<b>47</b>
3.1 TX VHT40 MCS9 ANT1 Band0 .....	47
3.2 TX HE80 MCS11 ANT8 Band1 .....	47
3.3 RX VHT20 ANT3 Band0 .....	48
3.4 Duplicate TX .....	48
3.5 Continuous TX .....	49
3.6 Pre-calibration .....	49
3.7 Implicit Beamforming .....	51

3.7.1	DUT Command for Calibration with Instrument .....	51
3.7.1.1	Calibration .....	51
3.7.1.2	Verification .....	56
3.7.2	DUT Command for Calibration with Golden .....	58
3.7.2.1	Calibration and Verification .....	58
3.7.3	iBF Calibration Channel Group .....	60
3.8	Explicit Beamforming .....	63
3.8.1	Certification .....	63
3.9	Zero Wait DFS .....	65
<b>4</b>	<b>iwpriv (mwctl) and ated Command Mapping Table .....</b>	<b>69</b>
4.1	Iwpriv (mwctl) .....	69
4.1.1	Set State .....	69
4.1.2	Set Configs .....	69
4.1.3	Statistic .....	71
4.1.4	MISC .....	71
4.2	ated .....	71
<b>5</b>	<b>Testmode Overall Status (Per-chip) .....</b>	<b>72</b>
<b>6</b>	<b>Appendix .....</b>	<b>73</b>
6.1	Spatial Extension Index Table .....	73
6.2	Beamforming Debug CR .....	74
6.3	Protected FT Field .....	75
6.4	Abbreviations .....	76
<b>Exhibit 1</b>	<b>Terms and Conditions .....</b>	<b>79</b>

# 1 Introduction

MT76 is a SoftMAC MediaTek open-source Wi-Fi driver developed based on the Linux kernel wireless subsystem.

The test mode part is implemented with NL80211\_CMD\_TESTMODE, a standard nl80211 command, which is different from the usage of the wireless extension in proprietary drivers.


User application tools are provided to control testmode and get statistics. In Wi-Fi 6 chipsets, the tools for the proprietary driver communicate to the kernel stack with ioctl, while those for mt76 use **generic netlink**. For convenience and transparency, **wrappers** are provided to adapt to the original manual and HQADLL commands.

**Note that the proprietary driver (logan) for Wi-Fi 7 chipsets also utilizes generic netlink (nl80211) instead of ioctl to communicate with the kernel stack.** The iwpriv daemon is replaced by the mwctl daemon to handle user commands; however, iwpriv commands are also supported by utilizing symbolic links to link iwpriv and mwctl commands. **For Wi-Fi 7 mt76, we support both mwctl and iwpriv commands via our iwpriv wrapper.**


**For QATool, please use the proprietary driver instead of MT76 upstream driver.**

Below is an architectural overview for the comparison of mt76 and the proprietary driver.

Wi-Fi 6 Chipset:



Wi-Fi 7 Chipset:



## 2 Usage

### 2.1 Pre-setting

#### 2.1.1 Set Country Code

If the test needs to bypass the DFS process or use some boundary channels, please switch to a customized regdomain before starting the test.

- Command

```
iw reg set VV
```

- Example

```
iw reg get
```

```
root@OpenWrt:/# iw reg set VV
root@OpenWrt:/# iw reg get
global
country VV: DFS-UNSET
(2402 - 2494 @ 40), (N/A, 30), (N/A)
(4910 - 4990 @ 80), (N/A, 30), (N/A)
(5150 - 5875 @ 160), (N/A, 30), (N/A)
```

#### 2.1.2 Check Firmware Mode (Mandatory for Wi-Fi 7)

In Wi-Fi 7 chipsets, due to the limitation of RAM size, we divide the WM firmware into two bins: the normal mode WM firmware bin and the test mode WM firmware bin. Therefore, before starting up, **please check that you are loading the test mode WM firmware bin via the following command or bootup log.**

- Command

```
cat /sys/kernel/debug/ieee80211/phy0/mt76/fw_version
```

- Example

(i) Debugfs command:

```
root@OpenWrt:/# cat /sys/kernel/debug/ieee80211/phy0/mt76/fw_version
Version: 3.3.10.0
Rom Patch Build Time: 20230516165403a
WM Patch Build Time: 20230516165518, Mode: Testmode
WA Patch Build Time: 20230516165241
DSP Patch Build Time: 20230516165216
```

(ii) Bootup log:

```
mt7996e 0000:01:00.0: WM_TM Firmware Version: ____000000, Build Time: 20230516165518
mt7996e 0000:01:00.0: DSP Firmware Version: ____000000, Build Time: 20230516165216
mt7996e 0000:01:00.0: WA Firmware Version: ____000000, Build Time: 20230516165241
```

#### 2.1.3 Enter Test Mode Firmware Mode (Mandatory for Wi-Fi 7)

For Wi-Fi 7 chipsets, the driver will determine which WM firmware bin to load during bootup based on your EEPROM mode (flash, eFuse, binfile or default bin mode), EEPROM fields, and input module parameters.

To check your current EEPROM mode, please enter the following commands:

```
cat /sys/kernel/debug/ieee80211/phy0/mt76/eeprom_mode
```



For more information about how to switch EEPROM modes, please refer to Section 6 of “MT76 Programming Guide.”


Please refer to the following descriptions or [flowchart](#) for the MT76 WM firmware loading flow.

- **Flash & binfile mode:**

For flash and binfile mode, MT76 driver first checks eeprom field 0x1af (eep[0x1af]) to determine which bin to load. If eep[0x1af] = 1, then MT76 driver directly loads testmode firmware. Otherwise, MT76 driver further checks module parameter “testmode\_enable” in /etc/module.d/mt7996e to decide which bin to load.

- **eFuse & default bin mode:**

For eFuse and default bin mode, MT76 driver only checks module parameter “testmode\_enable” in /etc/module.d/mt7996e to decide which bin to load.



There are two methods to **switch firmware mode at runtime**.

- **Command**

```

(i) Re-insert modules:
cat /sys/kernel/debug/ieee80211/phy0/mt76/eeprom_mode
// If eeprom mode == flash or binfile
atendl -i phy0 -c "eeprom set 0x1af=0x<val>"
atendl -i phy0 -c "eeprom precal sync"
atendl -i phy0 -c "sync eeprom all"

rmmod mt7996e
rmmod mt76-connac-lib
rmmod mt76
rmmod mac80211
rmmod cfg80211
rmmod compat
insmod compat
insmod cfg80211
insmod mac80211
insmod mt76
insmod mt76-connac-lib
insmod mt7996e testmode_enable=<val>
sleep 5
killall hostapd

```

```
killall netifd
```

- (ii) iwpriv wrapper commands (wraps the above commands) **[Recommended]** :
- ```
iwpriv ra0 switch <testmode/normal>
```

- Example

```
root@OpenWrt:~# iwpriv ra0 switch testmode
set offset 0x1af[ 126.979615] mt7996e 0000:01:00.0: Not pre-cal yet!
to 0x1
[ 126.984898] mt7996e 0000:01:00.0: Not pre-cal yet!
No Pre cal data or info!
No Pre cal data or info!
Unlocking Factory ...

Writing from /tmp/atenl-EEPROM-phy0 to Factory ...
[ 128.017576] Loading modules backported from Linux version v6.1.24-0-g0102425ac76b
[ 128.025064] Backport generated by backports.git v5.15.92-1-44-gd6ea70fafd36
[ 128.055082] mt7996e_hif 0001:01:00.0: assign IRQ: got 119
[ 128.060545] mt7996e_hif 0001:01:00.0: enabling bus mastering
[ 128.066297] mt7996e 0000:01:00.0: assign IRQ: got 120
[ 128.071359] mt7996e 0000:01:00.0: enabling bus mastering
[ 128.132470] mt7996e 0000:01:00.0: attaching wed device 0 version 3
[ 128.170487] platform 15010000.wed: W0 Firmware Version: 0000000, Build Time: 20230218204509
[ 128.225165] mt7996e_hif 0001:01:00.0: attaching wed device 1 version 3
[ 128.336273] mt7996e 0000:01:00.0: HW/SW Version: 0x8a108a10, Build Time: 20230516165403a
[ 128.336273]
[ 128.437691] mt7996e 0000:01:00.0: WM_TM Firmware Version: 0000000, Build Time: 20230516165518
[ 128.475555] mt7996e 0000:01:00.0: DSP Firmware Version: 0000000, Build Time: 20230516165216
[ 128.493237] mt7996e 0000:01:00.0: WA Firmware Version: 0000000, Build Time: 20230516165241
root@OpenWrt:~#
```

## 2.2 MT76 Test

mt76-test is a user application tool for test mode manual commands.

### 2.2.1 Start Test Mode

MT76 starts by adding a monitor interface.

Note that for **DBDC band1**, please change to **phy1/wlan1/phy1-ap0/mon1**.

#### Important Note:

- Please delete all the non-monitor interfaces before starting up the test mode monitor interface.
- iwpriv ra0 set ATE=ATESTART will handle all the interface deletion in the iwpriv wrapper.
- **mt76-test phyX add/del \${interface}** is a newly added command to support test mode interface addition/deletion for Wi-Fi 7 single Wiphy model. It can also be used in Wi-Fi 6 projects. For the sake of convenience, this command sets the country code to **VV**, activates the monitor interface, and sets the test mode state to idle. Therefore, users can start the test mode right after entering this command.

- Command

- (i) Use the **mt76-test** command **[Recommended for both non-single/single Wiphy]**

```
iw dev ${non-monitor interface name} del
mt76-test phy0 add mon0
```

- (ii) Use the **iw** command **[non-single Wiphy]**

```
iw phy phy0 interface add mon0 type monitor
iw dev ${non-monitor interface name} del
ifconfig mon0 up
```

- (iii) Use the **iw** command **[single Wiphy]**

```
iw phy phy0 interface add mon0 type monitor radios <radio_idx>
# <radio_idx> = 0, 1, 2 for band 0, 1, 2
iw dev ${non-monitor interface name} del
ifconfig mon0 up
```

- Example

```
root@OpenWrt:/# ifconfig mon0
mon0      Link encap:UNSPEC  HWaddr 00-0C-43-2A-57-A9-01-00-00-00-00-00
          UP BROADCAST RUNNING MULTICAST  MTU:1500  Metric:1
          RX packets:1768 errors:0 dropped:0 overruns:0 frame:0
          TX packets:0 errors:0 dropped:0 overruns:0 carrier:0
          collisions:0 txqueuelen:1000
          RX bytes:566960 (553.6 KiB)  TX bytes:0 (0.0 B)
```

## 2.2.2 Stop Test Mode

Remove monitor interface.

Note that the mt76-test command sets the testmode state to “off” before deleting the interface. This help to avoid SIOCSIFFLAGS errors.

- Command

- (i) Use the mt76-test command **[Recommended]**

```
mt76-test phy0 del mon0
```

- (ii) Use the iw command

```
mt76-test phy0 set state=off
iw dev mon0 del
iw phy phy0 interface add phy0-ap0 type managed
```

## 2.2.3 Start and Stop TX

- Command

- Start TX

```
mt76-test phy0 set state=tx_frames
```

- Stop TX

```
mt76-test phy0 set state=idle
```

- Example

```
root@OpenWrt:/# mt76-test phy0 dump | grep state
state=tx_frames
root@OpenWrt:/# mt76-test phy0 dump | grep state
state=idle
```

3.1 TX VHT40 MCS9 ANT1 Band0

3.2 TX HE80 MCS11 ANT8 Band1

3.4 Duplicate TX

## 2.2.4 Start and Stop RX

- Command

- Start RX

```
mt76-test phy0 set state=rx_frames
```

- Stop RX

```
mt76-test phy0 set state=idle
```

- Example

```
root@OpenWrt:~# mt76-test phy0 dump | grep state
state=rx_frames
root@OpenWrt:~# mt76-test phy0 dump | grep state
state=idle
```

### 3.3 RX VHT20 ANT3 Band0

## 2.2.5 Start and Stop Continuous TX

- Command

- Start continuous TX

```
mt76-test phy0 set state=tx_cont
```

- Stop continuous TX

```
mt76-test phy0 set state=idle
```

- Example

```
root@OpenWrt:~# mt76-test phy0 dump | grep state
state=tx_cont
```

### 3.5 Continuous TX

## 2.2.6 Set Band Index

MT76 uses phyX to control testmode on each band. For example:

```
# band 0
iw dev phy0-ap0 del
mt76-test phy0 add mon0
or
iw phy phy0 interface add mon0 type monitor
iw dev phy0-ap0 del
ifconfig mon0 up

# band 1
iw dev phy1-ap0 del
mt76-test phy1 add mon1
or
iw phy phy1 interface add mon1 type monitor
iw dev phy1-ap0 del
ifconfig mon1 up
```

## 2.2.7 Set Channel and Bandwidth

MT76 utilizes iw commands to configure channels and bandwidth. Note that setting the 6G channel (BW 320) is currently not supported in the iw command<sup>1</sup>. We suggest using the first **iw set frequency command** in every case. Iwpriv wrapper handles the 6G case correctly, so feel free to use the iwpriv command to set channel and BW.

**Note:**

---

<sup>1</sup> iw version: 5.19 for Wi-Fi 6, 6.9 for Wi-Fi 7

1. Currently only the first command supports 6G BW320.
2. In the first command, please specify the center frequency to select BW320-1 or BW320-2.
3. **For HE/EHT & bandwidth > 20, LPDC is a must for transmitting packets.** If LPDC is not set, the firmware will block the TX.

- Command

```
iw dev mon0 set freq <control freq> [5|10|20|40|80|80+80|160|320] [<center1_freq>
[<center2_freq>]]
iw dev mon0 set set freq <freq>
[NOHT|HT20|HT40+|HT40-|5MHz|10MHz|80MHz|160MHz|320MHz]
iw dev mon0 set channel <channel> [NOHT|HT20|HT40+|HT40-|5MHz|10MHz|80MHz|160MHz]
```

- Example

```
root@OpenWrt:/# iw dev mon0 set channel 7 HT20
root@OpenWrt:/# iw mon0 info
Interface mon0
    ifindex 19
    wdev 0x2
    addr 00:0c:43:2b:76:d7
    type monitor
    wiphy 0
    channel 7 (2442 MHz), width: 20 MHz, center1: 2442 MHz
    txpower 27.00 dBm
```

## 2.2.8 Set TX Count

Set the total number of TX packets.

| Input Argument | Description                        | Value         |
|----------------|------------------------------------|---------------|
| tx_count       | Set the total number of TX packets | [1, UINT_MAX] |

- Command

```
mt76-test phy0 set tx_count=10000000
```

- Example

```
root@OpenWrt:/# mt76-test phy0 dump | grep tx_count
tx_count=10000000
```

## 2.2.9 Set TX Length

Set the length of an MPDU. The maximum length is determined by the TX rate mode and the chip's capability.

| Input Argument | Description                | TX rate mode                           | Value                                               |
|----------------|----------------------------|----------------------------------------|-----------------------------------------------------|
| tx_length      | Set the length of the MPDU | CCK, OFDM                              | [30, 2352]                                          |
|                |                            | HT                                     | [30, 7935]                                          |
|                |                            | VHT, HE_SU, HE_EXT_SU,<br>HE_TB, HE_MU | [30, 7991] (for <b>mt7915</b> )                     |
|                |                            |                                        | [30, 11454]                                         |
|                |                            | EHT_SU, EHT_TB, EHT_MU                 | [30, <b>UINT_MAX</b> ]<br>(for <b>Wi-Fi 7</b> only) |

**Note:**

| Description                          | Value |
|--------------------------------------|-------|
| The length of the IEEE packet header | 30    |
| IEEE80211_MAX_FRAME_LEN              | 2352  |
| IEEE80211_MAX_MPDU_LEN_HT            | 7935  |

| Description                | Value             |
|----------------------------|-------------------|
| IEEE80211_MAX_MPDU_LEN_VHT | 7991 (for mt7915) |
|                            | 11454             |

- Command

```
mt76-test phy0 set tx_length=1024
```

- Example

```
root@OpenWrt:/# mt76-test phy0 dump | grep tx_length
tx_length=1024
```

## 2.2.10 Set Antenna

Set antenna mask (bitmap representation) for both the TX and RX paths.

**Note that bit 4 is used exclusively for the following chips.**

- mt7996 BE19000 6G band 4T5R
- mt7992 BE7200 eFEM 5G band 4T5R, mt7992 BE7200 2i5e 5G band 4T5R
- mt7992 BE7200 iFEM 5G band 5T5R

| Input Argument | Description                                                                                                                                                              | Value                                                                     |
|----------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------|
| tx_antenna     | Bit 0: enable TX/RX antenna 0<br>Bit 1: enable TX/RX antenna 1<br>Bit 2: enable TX/RX antenna 2<br>Bit 3: enable TX/RX antenna 3<br><b>Bit 4: enable TX/RX antenna 4</b> | $[0, 2^{nss} - 1]$<br>nss = the number of tx/rx streams written in eeprom |

- Command

```
# Enable antenna 1 & 2
mt76-test phy0 set tx_antenna=6
# Enable antenna 3 only
mt76-test phy0 set tx_antenna=8
```

- Example

```
root@OpenWrt:/# mt76-test phy0 dump | grep tx_antenna
tx_antenna=8
```

## 2.2.11 Set Spatial Extension Index

Set spatial extension index for TX. When not all antennas are enabled, the spatial extension index is used to prioritize which antenna to use for transmission. Please refer to the appendix [Spatial Extension Index Table](#) for more information.

| Input Argument | Description                            | Value   |
|----------------|----------------------------------------|---------|
| tx_spe_idx     | Determine the priority of each antenna | [0, 27] |

- Command

```
mt76-test phy0 set tx_spe_idx=24
```

- Example

```
root@OpenWrt:/# mt76-test phy0 dump | grep tx_spe_idx
tx_spe_idx=24
```

## 2.2.12 Set Guard Interval and Long Training Field

Set the Guard Interval (GI) and Long Training Filed (LTF) based on the current rate mode.

**Wi-Fi 6 chipset (mt7915, mt7916, mt7981, mt7986):**

| Input Argument | Description                                                                    | Value           |
|----------------|--------------------------------------------------------------------------------|-----------------|
| tx_rate_sgi    | Long GI/Short GI for HT/VHT<br>0.8 $\mu$ s, 1.6 $\mu$ s, 3.2 $\mu$ s GI for HE | 0, 1<br>0, 1, 2 |
| tx_ltf         | 1x, 2x, 4x LTF                                                                 | 0, 1, 2         |

**Wi-Fi 7 chipset (mt7996, mt7992):**

| Input Argument | Description                                                                                                                                                                         | Value  |
|----------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------|
| tx_rate_sgi    | In the Wi-Fi 7 chipset, tx_rate_sgi becomes an index to a specific GI & LTF combination based on your TX rate mode. Please refer to <a href="#">the table</a> for more information. | [0, 4] |
| tx_ltf         | Not used                                                                                                                                                                            | -      |

Please follow the standard shown in the table below to set the correct GI and LTF for different modes. Cases not listed in the following table are not supported.

Note that the input argument tx\_ltf is not used for the Wi-Fi 7 chipset, since testmode is offloaded to firmware. Therefore, please refer to the correct table based on your chip ID.

**Wi-Fi 6 chipset (mt7915, mt7916, mt7981, mt7986):**

| TX Rate Mode       | Type                    | Input Argument      | Value |
|--------------------|-------------------------|---------------------|-------|
| HT, VHT            | Long GI                 | tx_rate_sgi         | 0     |
|                    | Short GI                |                     | 1     |
| HE_SU<br>HE_EXT_SU | 1x LTF + 0.8 $\mu$ s GI | tx_ltf, tx_rate_sgi | 0, 0  |
|                    | 2x LTF + 0.8 $\mu$ s GI |                     | 1, 0  |
|                    | 4x LTF + 0.8 $\mu$ s GI |                     | 2, 0  |
|                    | 2x LTF + 1.6 $\mu$ s GI |                     | 1, 1  |
|                    | 4x LTF + 3.2 $\mu$ sGI  |                     | 2, 1  |
| HE_MU              | 2x LTF + 0.8 $\mu$ s GI |                     | 1, 0  |
|                    | 4x LTF + 0.8 $\mu$ s GI |                     | 2, 0  |
|                    | 2x LTF + 1.6 $\mu$ s GI |                     | 1, 1  |
|                    | 4x LTF + 3.2 $\mu$ s GI |                     | 2, 2  |
| HE_TB              | 1x LTF + 1.6 $\mu$ s GI |                     | 0, 1  |
|                    | 2x LTF + 1.6 $\mu$ s GI |                     | 1, 1  |
|                    | 4x LTF + 3.2 $\mu$ s GI |                     | 2, 2  |

**Wi-Fi 7 chipset (mt7996, mt7992):**

| Input Argument | TX Rate Mode       | Type                    | Value |
|----------------|--------------------|-------------------------|-------|
| tx_rate_sgi    | HT, VHT            | Long GI                 | 0     |
|                |                    | Short GI                | 1     |
|                | HE_SU<br>HE_EXT_SU | 1x LTF + 0.8 $\mu$ s GI | 0     |
|                |                    | 2x LTF + 0.8 $\mu$ s GI | 1     |
|                |                    | 2x LTF + 1.6 $\mu$ s GI | 2     |
|                |                    | 4x LTF + 3.2 $\mu$ sGI  | 3     |
|                |                    | 4x LTF + 0.8 $\mu$ s GI | 4     |

| Input Argument | TX Rate Mode     | Type                    | Value |
|----------------|------------------|-------------------------|-------|
|                | HE_MU            | 4x LTF + 0.8 $\mu$ s GI | 0     |
|                |                  | 2x LTF + 0.8 $\mu$ s GI | 1     |
|                |                  | 2x LTF + 1.6 $\mu$ s GI | 2     |
|                |                  | 4x LTF + 3.2 $\mu$ s GI | 3     |
|                | HE_TB            | 1x LTF + 1.6 $\mu$ s GI | 0     |
|                |                  | 2x LTF + 1.6 $\mu$ s GI | 1     |
|                |                  | 4x LTF + 3.2 $\mu$ s GI | 2     |
|                | EHT_SU<br>EHT_MU | 2x LTF + 0.8 $\mu$ s GI | 0     |
|                |                  | 2x LTF + 1.6 $\mu$ s GI | 1     |
|                |                  | 4x LTF + 0.8 $\mu$ s GI | 2     |
|                |                  | 4x LTF + 3.2 $\mu$ s GI | 3     |
|                | EHT_TB           | 1x LTF + 1.6 $\mu$ s GI | 0     |
|                |                  | 2x LTF + 1.6 $\mu$ s GI | 1     |
|                |                  | 4x LTF + 3.2 $\mu$ s GI | 2     |

- Command

```
# 2x LTF + 1.6 $\mu$ s GI for HE_SU
mt76-test phy0 set tx_rate_sgi=1 tx_ltf=1
```

- Example

```
root@OpenWrt:/# mt76-test phy0 dump | grep 'tx_ltf$|tx_rate_sgi'
tx_rate_sgi=1
tx_ltf=1
```

## 2.2.13 Set TX Rate Mode

Set the rate mode for packet TX.

| Input Argument | Description |                     | Value     |
|----------------|-------------|---------------------|-----------|
| tx_rate_mode   | 802.11b     |                     | cck       |
|                | 802.11g     |                     | ofdm      |
|                | 802.11b/g/n |                     | ht        |
|                | 802.11ac    |                     | vht       |
|                | 802.11ax    | Single User         | he_su     |
|                |             | Extended Range PPDU | he_ext_su |
|                |             | Multiple User       | he_tb     |
|                |             | Trigger-Based PPDU  | he_mu     |
|                | 802.11be    | Single User         | eht_su    |
|                |             | Multiple User       | eht_mu    |
|                |             | Trigger-Based PPDU  | eht_tb    |

**Note:**

- Green field is not supported in mt76

- Command

```
mt76-test phy0 set tx_rate_mode=he_su
```

- Example

```
root@OpenWrt:/# mt76-test phy0 dump | grep tx_rate_mode
tx_rate_mode=he_su
```



### 2.2.14 Set TX Rate Index (MCS)

Set the MCS value for packet TX.

**Note:**

- The data rate for VHT & HE is determined by NSS & MCS value

For more information, please refer to [MCS table](#).

| Input Argument | Description       | TX Rate Mode | Value            |
|----------------|-------------------|--------------|------------------|
| tx_rate_idx    | Set the MCS value | CCK, OFDM    | [0, 3], 1SS only |
|                |                   | OFDM         | [0, 7], 1SS only |
|                |                   | HT           | [0, 31], 1 ~ 4SS |
|                |                   | VHT          | [0, 9] ※         |
|                |                   | HE           | [0, 11] ※        |
|                |                   | EHT          | [0, 15]          |

- Command

```
mt76-test phy0 set tx_rate_idx=9
```

- Example

```
root@OpenWrt:/# mt76-test phy0 dump | grep tx_rate_idx
tx_rate_idx=9
```

### 2.2.15 Set Spatial Stream Number

Set the number of spatial streams for packet TX in VHT/HE mode.

| Input Argument | Description                       | Value  |
|----------------|-----------------------------------|--------|
| tx_rate_nss    | Set the number of spatial streams | [1, 4] |

- Command

```
mt76-test phy0 set tx_rate_nss=2
```

- Example

```
root@OpenWrt:/# mt76-test phy0 dump | grep tx_rate_nss
tx_rate_nss=2
```

### 2.2.16 Set LDPC

Use low density parity check (LDPC) code for packet TX. **Note that LDPC is mandatory on HE mode with BW larger than 20 MHz.**

| Input Argument | Description         | Value |
|----------------|---------------------|-------|
| tx_rate_ldpc   | Disable/Enable LDPC | 0/1   |

- Command

```
mt76-test phy0 set tx_rate_ldpc=1
```

- Example

```
root@OpenWrt:/# mt76-test phy0 dump | grep tx_rate_ldpc
tx_rate_ldpc=1
```

### 2.2.17 Set STBC

Use space time block coding (STBC) code for packet TX.

| Input Argument | Description         | Value |
|----------------|---------------------|-------|
| tx_rate_stbc   | Disable/Enable STBC | 0/1   |

- Command

```
mt76-test phy0 set tx_rate_stbc=1
```

- Example

```
root@OpenWrt:/# mt76-test phy0 dump | grep tx_rate_stbc
tx_rate_stbc=1
```

### 2.2.18 Set TX Power

Set TX power of a single antenna. Note that mt7915/mt7916/mt7981/mt7986 only support setting antenna 0, and **the TX power of antenna 1~3 will be the same as the one of antenna 0.**

The TX power can be checked by

1. cat /sys/kernel/debug/ieee80211/**phyX**/mt76/txpower\_sku, for Wi-Fi 6 & Wi-Fi 7 multi-Wiphy
2. cat /sys/kernel/debug/ieee80211/**phy0**/mt76/**bandX**/txpower\_sku, for Wi-Fi 7 single Wiphy

| Input Argument | Description                | Value (Unit: 0.5dB) |
|----------------|----------------------------|---------------------|
| tx_power       | Set the power of antenna 0 | [0, 63], decimal    |
|                | Set the power of antenna 1 |                     |
|                | Set the power of antenna 2 |                     |
|                | Set the power of antenna 3 |                     |

- Command

```
mt76-test phy0 set tx_power=38,0,0,0
```

- Example

```
root@OpenWrt:/# mt76-test phy0 dump | grep tx_power
tx_power=38,0,0,0
```

### 2.2.19 Set Packet TX Time

Set the expected packet TX time ( $\mu\text{sec}$ ). Note that if this value is set, **packet TX length will be recalculated** and ignore the original tx\_length value.

| Input Argument | Description                        | Value (Unit: $\mu\text{s}$ )                                      |
|----------------|------------------------------------|-------------------------------------------------------------------|
| tx_time        | Set the TX frame transmission time | The range decided by rate mode/data rate, and BW when in VHT mode |

- Command

```
mt76-test phy0 set tx_time=200
```

- Example

```
root@OpenWrt:/# mt76-test phy0 dump | grep tx_time
tx_time=200
```

## 2.2.20 Set Inter-packet Gap

Set the inter-packet gap of TX frame ( $\mu\text{sec}$ ). The minimum value of `tx_ipg` should be larger than the sum of default value of `SIG_EXT`, `SIFS`, and slot time listed in the table below. Otherwise, `tx_ipg` would be reset to 0.

| Terminology | Description                                                                                                                                                                                                                                        | Default Value (unit: μs)  |   |   |
|-------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------|---|---|
| SIG_EXT     | -                                                                                                                                                                                                                                                  | CCK                       | 0 |   |
|             |                                                                                                                                                                                                                                                    | Others                    | 6 |   |
| SIFS        | A short interframe space defined in CSMA/CA to avoid confliction                                                                                                                                                                                   | 10                        |   |   |
| Slot time   | The time that should elapse between a first electronic pulse being sent and a second one following it. In CSMA/CA, a slot time includes time for signal propagation in the air, clear channel assessment (CCA), and hardware to turn from RX to TX | Propagation               | 1 | 9 |
|             |                                                                                                                                                                                                                                                    | CCA                       | 4 |   |
|             |                                                                                                                                                                                                                                                    | RX/TX hardware turnaround | 4 |   |

| Input Argument      | Description                       | Value (unit: $\mu\text{s}$ ) |
|---------------------|-----------------------------------|------------------------------|
| <code>tx_ipg</code> | Set the TX frame inter-packet gap | [25, 590000]                 |

- Command  
`mt76-test phy0 set tx_ipg=50`
- Example

```
root@OpenWrt:/# mt76-test phy0 dump | grep tx_ipg
tx_ipg=50
```

## 2.2.21 Set Duty Cycle

Set the duty cycle of the TX frame, which can be calculated from `tx_time` and `tx_ipg`. Note that if both IPG and TX time are set, then the TX duty cycle will be determined.

$$tx\_duty\_cycle = \frac{tx\_time}{tx\_time + tx\_ipg}$$

Note that this command is not available in the Wi-Fi 7 chipset.

| Input Argument             | Description                    | Value               |
|----------------------------|--------------------------------|---------------------|
| <code>tx_duty_cycle</code> | Set the duty cycle of TX frame | [0, 99], percentage |

- Command  
`mt76-test phy0 set tx_duty_cycle=50`
- Example

```
root@OpenWrt:/# mt76-test phy0 dump | grep tx_duty_cycle
tx_duty_cycle=50
```

## 2.2.22 Set TX Frequency Offset

Set the RF frequency offset.

| Input Argument | Description                           | Value             |
|----------------|---------------------------------------|-------------------|
| freq_offset    | Set the offset of the TX RF frequency | [0, 127], decimal |

- Command

```
mt76-test phy0 set freq_offset=42
```

## 2.2.23 Set MAC Address

Set the MAC address of address 1, 2 and 3 in the MAC packet frame.

| Input Argument | Description                     | Value                   |
|----------------|---------------------------------|-------------------------|
| mac_addrs      | DA (1 <sup>st</sup> address)    | Destination MAC address |
|                | SA (2 <sup>nd</sup> address)    | Source MAC address      |
|                | BSSID (3 <sup>rd</sup> address) | BSSID MAC address       |

- Command

```
mt76-test phy0 set mac_addrs=00:11:22:33:44:55,11:22:33:44:55:66,22:33:44:55:66:77
```

- Example

```
root@OpenWrt:/# mt76-test phy0 dump | grep mac_addrs
mac_addrs=00:11:22:33:44:55,11:22:33:44:55:66,22:33:44:55:66:77
```

## 2.2.24 Set AID for Virtual WTBL

Set association ID (AID) for starting up virtual WTBL (Wireless Lan Table, storing capacity or information for the connected peer). For **mt7916**, **mt7981** and **mt7986**, WCID should not be 0 for TX. Otherwise, the packet would be dropped by WA firmware.

| Input Argument | Description            | Value   |
|----------------|------------------------|---------|
| aid            | Set the association ID | [0, 16] |

- Command

```
mt76-test phy0 set aid=1
```

- Example

```
root@OpenWrt:/# mt76-test phy0 dump | grep aid
aid=1
```

## 2.2.25 Set RU Index

Set the RU index. Please refer to [RU Index Table 9-29i](#) or Data and Pilot Subcarrier Indices [Table 27-7 to Table 27-9](#) for the indexing method. Note that the ru\_idx here is not the RU index listed in the table of the link above. It is the “B7-B1 of the RU Allocation subfield”, which ranges from 0 to 68, in the table. The difference between the RU index and “B7-B1 of the RU Allocation subfield” listed in the table of the link above is that “B7-B1 of the RU Allocation subfield” is the accumulated index of RU index for each bandwidth.

Note that this command is not available in the Wi-Fi 7 chipset.

| Input Argument | Description      | Value   |
|----------------|------------------|---------|
| ru_idx         | Set the RU index | [0, 68] |

- Command

```
mt76-test phy0 set ru_idx=1
```

- Example

```
root@OpenWrt:/# mt76-test phy0 dump | grep ru_idx
ru_idx=1
```

## 2.2.26 Set RU Allocation

Set the resource unit (RU) allocation subfield (8 bits) in HE-SIG-B (HE-MU PPDU for 802.11ax). The RU allocation subfield indicates the RU assignment, including the size of the RU(s) and their placement in the frequency domain.

Note that this command is not available in the Wi-Fi 7 chipset.

For more information, please refer to [RU allocation Table 27-26](#).

**Note:**

- ru\_idx is used to select a specific RU to TX/RX in 20/40/80 MHz bandwidth. Please refer to [2.2.25 Set RU Index](#) for the indexing method.
- ru\_alloc is used to specify the RU allocation in a 20 MHz bandwidth.

| Input Argument | Description                             | Value    |
|----------------|-----------------------------------------|----------|
| ru_alloc       | Set the RU allocation subfield (8 bits) | [0, 255] |

- Command

```
mt76-test phy0 set ru_alloc=1
```

- Example

```
root@OpenWrt:/# mt76-test phy0 dump | grep ru_alloc
ru_alloc=1
```

## 2.2.27 Dump Settings

Dump the current configured settings.

- Command

```
mt76-test phy0 dump
```

- Example

```

root@OpenWrt:/# mt76-test phy0 dump
state=off
tx_count=1
tx_length=1024
tx_rate_mode=ofdm
tx_rate_nss=1
tx_rate_idx=0
tx_rate_sgi=0
tx_rate_ldpc=0
tx_rate_stbc=1
tx_duty_cycle=50
tx_ipg=50
tx_time=200

```

### 2.2.28 Dump Statistics

Show current TX/RX status.

- Command

```
mt76-test phy0 dump stats
```

- Example

```

root@OpenWrt:/# mt76-test phy0 dump stats
tx_pending=972233
tx_queued=27767
tx_done=22936
rx_packets=152
rx_fcs_error=152
last_freq_offset=0
last_rcpi=0,0,0,0
last_ib_rssi=0,0,0,0
last_wb_rssi=0,0,0,0
last_snr=0
rx_per=100.00%

```

### 2.2.29 Group Pre-calibration

Do group pre-calibration (including RX DCOC, RSSI DCOC, TX TSSI DCOC, TX LPFG, TX FDIQ, TX DCIQ, RX FDIQ, RX FIIQ, ADCDCOC) and save the result in mt76 driver. To write back the result to flash, please use [atenl commands](#). For more information, please refer to [Pre-cal example](#).

Note:

4. Please make sure you are in **flash mode** or **bin file mode**.
5. `group_prek_clean` will only clean the pre-cal data stored in the mt76 driver. If you want to clean the pre-cal data in flash memory, please use [atenl commands](#).

- Command

```

mt76-test phy0 set state=group_prek
mt76-test phy0 set state=group_prek_dump
mt76-test phy0 set state=group_prek_clean

```

- Example

```

root@OpenWrt:/# iwpriv phy0 set ATE=ATESTART
root@OpenWrt:/# mt76-test phy0 set state=group_prek
root@OpenWrt:/# mt76-test phy0 set state=group_prek_dump
[ 1067.338707] mt7915e 0000:01:00:0: Group Pre-Cal:
[ 1067.343342] mt7915e 0000:01:00:0: [0x00000000] 0x 0 0x 1 0xfffffbfff 0x 10003ff
[ 1067.351598] mt7915e 0000:01:00:0: [0x00000010] 0x 300080 0x40023f90 0xfc000000 0xffffffff
[ 1067.359846] mt7915e 0000:01:00:0: [0x00000020] 0xf800000f 0x23f003ff 0x 3f9020 0xffffe05fd
[ 1067.368094] mt7915e 0000:01:00:0: [0x00000030] 0x 0 0x 3010100 0x408fe404 0xffbf8000
[ 1067.376344] mt7915e 0000:01:00:0: [0x00000040] 0x3fffc03f 0xc0c04000 0x 13fa80 0x ffff000
[ 1067.384592] mt7915e 0000:01:00:0: [0x00000050] 0x 10 0x40402010 0x 810fd40 0xfbfbc00
[ 1067.392840] mt7915e 0000:01:00:0: [0x00000060] 0x 3ff 0x 400 0xfffff3d8 0x 0
[ 1067.401088] mt7915e 0000:01:00:0: [0x00000070] 0x 0 0xff000000 0x3fff8ffe 0x 0
[ 1067.409338] mt7915e 0000:01:00:0: [0x00000080] 0x 0 0x 0 0x 400 0x 0
[ 1067.417585] mt7915e 0000:01:00:0: [0x00000090] 0x 0 0x 0 0x 0 0x 0
[ 1067.425834] mt7915e 0000:01:00:0: [0x000000a0] 0x 0 0x 0 0x 1 0xf0007ffe
[ 1067.434080] mt7915e 0000:01:00:0: [0x000000b0] 0x11fff3ff 0xffeffdc0 0x40173f93 0x13ff5008
[ 1067.442329] mt7915e 0000:01:00:0: [0x000000c0] 0xfe7fff00 0x13fc001f 0xec37f800 0xb4007df
[ 1067.450575] mt7915e 0000:01:00:0: [0x000000d0] 0x 3f40f 0x 20001fe 0xfb08fe00 0xc34fefff
[ 1067.458822] mt7915e 0000:01:00:0: [0x000000e0] 0xc000ff03 0x ff803e 0xfd83bf80 0x2103fbfe
[ 1067.467068] mt7915e 0000:01:00:0: [0x000000f0] 0xc0003f61 0x104ff01f 0x8f40efe0 0x4434fff3f
[ 1067.475314] mt7915e 0000:01:00:0: [0x00000100] 0xec0013d8 0x 827f80b 0xbba457f4 0x180f3ffb
[ 1067.483560] mt7915e 0000:01:00:0: [0x00000110] 0xfa0005ed 0x 207fe02 0xf3ed18fe 0x86048ff2
[ 1067.491806] mt7915e 0000:01:00:0: [0x00000120] 0xbec041fb 0x 0 0x 0 0x 400
[ 1067.500052] mt7915e 0000:01:00:0: [0x00000130] 0x 0 0x 0 0x 0 0x 0

```

### 3.6 Pre-calibration

#### 2.2.30 DPD/Flatness Pre-calibration

Do DPD/Flatness pre-calibration (including TX DPD, TX Flatness) and save the result in mt76 driver. To write back the result to flash, please use [atenl commands](#). For more information, please refer to [Pre-cal example](#).

##### Note:

1. Please make sure you are in **flash mode** or **bin file mode**.
2. dpd\_clean will only clean the pre-cal data stored in the mt76 driver. If you want to clean the pre-cal data in flash memory, please use [atenl commands](#).
3. For DBDC chips, please **select the corresponding phy index**. Otherwise, the command will be blocked. For example, in order to perform 5G/6G DPD pre-calibration in AX7800, please enter:

```

mt76-test phy3 set state=dpd_5g
mt76-test phy1 set state=dpd_6g

```

- Command

```

mt76-test phy0 set state=dpd_2g
mt76-test phy0 set state=dpd_5g
mt76-test phy0 set state=dpd_6g
mt76-test phy0 set state=dpd_dump
mt76-test phy0 set state=dpd_clean

```

- Example

```

root@OpenWrt:/# mt76-test phy1 set state=dpd_6g
root@OpenWrt:/# mt76-test phy1 set state=dpd_dump
[ 2476.679880] mt7915e 0000:01:00.0: DPD Pre-Cal:
[ 2476.684482] mt7915e 0000:01:00.0: [0x00017810] 0x 0 0x 0 0x 0
[ 2476.682734] mt7915e 0000:01:00.0: [0x00017820] 0x 0 0x 0 0x 0
[ 2476.700882] mt7915e 0000:01:00.0: [0x00017830] 0x 0 0x 0 0x 0
[ 2476.709232] mt7915e 0000:01:00.0: [0x00017840] 0x 0 0x 0 0x 0
[ 2476.717478] mt7915e 0000:01:00.0: [0x00017850] 0x 0 0x 0 0x 0
[ 2476.725728] mt7915e 0000:01:00.0: [0x00017860] 0x 0 0x 0 0x 0
[ 2476.733977] mt7915e 0000:01:00.0: [0x00017870] 0x 0 0x 0 0x 0
[ 2476.742228] mt7915e 0000:01:00.0: [0x00017880] 0x 0 0x 0 0x 0
[ 2476.750475] mt7915e 0000:01:00.0: [0x00017890] 0x 0 0x 0 0x 0
[ 2476.758739] mt7915e 0000:01:00.0: [0x000178a0] 0x 0 0x 0 0x 0
[ 2476.766996] mt7915e 0000:01:00.0: [0x000178b0] 0x 0 0x 0 0x 0
[ 2476.775262] mt7915e 0000:01:00.0: [0x000178c0] 0x 0 0x 0 0x 0
[ 2476.783510] mt7915e 0000:01:00.0: [0x000178d0] 0x 0 0x 0 0x 0
[ 2476.791758] mt7915e 0000:01:00.0: [0x000178e0] 0x 0 0x 0 0x 0
[ 2476.800007] mt7915e 0000:01:00.0: [0x000178f0] 0x 0 0x 0 0x 0
[ 2476.808256] mt7915e 0000:01:00.0: [0x00017900] 0x 0 0x 0 0x 0
[ 2476.816504] mt7915e 0000:01:00.0: [0x00017910] 0x 0 0x 0 0x 0
[ 2476.824752] mt7915e 0000:01:00.0: [0x00017920] 0x 0 0x 0 0x 0
[ 2476.833000] mt7915e 0000:01:00.0: [0x00017930] 0x 0 0x 0 0x 0
[ 2476.841248] mt7915e 0000:01:00.0: [0x00017940] 0x 0 0x 0 0x 0
[ 2476.849496] mt7915e 0000:01:00.0: [0x00017950] 0x 0 0x 0 0x 0
[ 2476.857743] mt7915e 0000:01:00.0: [0x00017960] 0x 0 0x 0 0x 0
[ 2476.865990] mt7915e 0000:01:00.0: [0x00017970] 0x 0 0x 0 0x 0
[ 2476.874238] mt7915e 0000:01:00.0: [0x00017980] 0x 0 0x 0 0x 0
[ 2476.882489] mt7915e 0000:01:00.0: [0x00017990] 0x 0 0x 0 0x 0
[ 2476.890758] mt7915e 0000:01:00.0: [0x000179a0] 0x 0 0x 0 0x 0
[ 2476.899004] mt7915e 0000:01:00.0: [0x000179b0] 0x 0 0x 0 0x 0
[ 2476.907252] mt7915e 0000:01:00.0: [0x000179c0] 0x 0 0x 0 0x 0
[ 2476.915499] mt7915e 0000:01:00.0: [0x000179d0] 0x 3030303 0x 3030000 0x 3030303 0x 3030000
[ 2476.923746] mt7915e 0000:01:00.0: [0x000179e0] 0x 9090909 0x 9090000 0x 7070707 0x 7070000
[ 2476.931993] mt7915e 0000:01:00.0: [0x000179f0] 0x 0 0x 0 0x 0
[ 2476.940240] mt7915e 0000:01:00.0: [0x00017a00] 0x 0 0x 1 0x 0
[ 2476.948487] mt7915e 0000:01:00.0: [0x00017a10] 0x 0 0x 0 0x 0
[ 2476.956735] mt7915e 0000:01:00.0: [0x00017a20] 0x 21a 0x 7ff 0x 7ff0001 0x 7fe07fc
[ 2476.964982] mt7915e 0000:01:00.0: [0x00017a30] 0x 120005 0x 0 0x 1 0x 23d
[ 2476.973230] mt7915e 0000:01:00.0: [0x00017a40] 0x 7ff0000 0x 7ff07ff 0x 7fe07f8 0x c0015

```

### 3.6 Pre-calibration

## 2.2.31 Implicit Beamforming (iBF)

This section covers the whole set of iBF commands, such as iBF setting initialization, iBF phase compensation, BF profile update, BF TX setting, iBF calibration, and saving calibrated iBF results to eeprom. Note that the argument of the iBF command must contain **txbf\_act** and **txbf\_param** at the same time. **txbf\_act** sets the action TXBF and **txbf\_param** sets the required parameters for the TXBF action. For more information, please refer to [iBF example](#).

### 2.2.31.1 Init Setting for iBF

Init the setting of DUT for iBF including

1. Set the MAC address configuration
2. Set the PHY mode, MCS rate, bandwidth, guard interval and IPG

| Input Argument | Description                          | Value                                                        |
|----------------|--------------------------------------|--------------------------------------------------------------|
| txbf_act       | Init the setting for iBF DUT         | init                                                         |
|                | Init the setting for iBF golden unit | <b>Not supported</b><br><b>Please use proprietary driver</b> |
| txbf_param     | Do nothing/Enable                    | 0/1                                                          |

- Command

```
mt76-test phy0 set state=idle
# init for DUT
mt76-test phy0 set txbf_act=init txbf_param=1
```
- Example

```

root@OpenWrt:/# mt76-test phy2 set txbf_act=init txbf_param=1
[317018.374833] ibf cal process: act = 0, val = 1, 0, 0, 0, 0

```

### 3.7 Implicit Beamforming



## 2.2.31.2 Phase Compensation

Enable the iBF phase compensation or clear the compensated TX/RX phases.

| Input Argument | Description                    |                 | Value      |
|----------------|--------------------------------|-----------------|------------|
| txbf_act       | Do phase compensation          |                 | phase_comp |
| txbf_param     | Set BW                         | 20 MHz (non-HT) | 0          |
|                |                                | 20 MHz          | 1          |
|                |                                | 40 MHz          | 2          |
|                |                                | 80 MHz          | 3          |
|                |                                | 80 + 80 MHz     | 4          |
|                |                                | 160 MHz         | 5          |
|                |                                | 5 MHz OFDM      | 6          |
|                |                                | 10 MHz OFNM     | 7          |
|                | Set band index                 |                 | 0/1        |
|                | Is JP band                     |                 | 0/1        |
|                | Enable reading from eeprom     |                 | 0/1        |
|                | Compensate TX/RX phases        |                 | 0          |
|                | Clear compensated TX/RX phases |                 | 1          |

- Command

```
mt76-test phy0 set txbf_act=phase_comp txbf_param=0,0,0,0,1 aid=1
```

- Note:

- If aid=1 is not entered before this command, it is required for adding virtual wtbl with wcid = aid. For more information, please refer to aid.

- Example

```
root@OpenWrt:/# mt76-test phy2 set txbf_act=phase_comp txbf_param=0,0,0,0,1 aid=1
[317110.517717] ibf cal process: act = 2, val = 0, 0, 0, 0, 1
[317111.546662] ibf cal process: phase comp info
[317111.551012] 0f 00 00 00 00 00 01 00 00 00 00 00 00 00 00 00
[317111.556661] 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
[317111.562306] 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
```

### 3.7 Implicit Beamforming

### 2.2.31.3 BF Profile Configuration Read and Write

#### 2.2.31.3.1 eBF/iBF Profile Configuration Update

Configure the profile management unit (PFMU) tag and BF station record of eBF/iBF for updating the channel profile.

| Input Argument | Description                                                                 | Value                              |
|----------------|-----------------------------------------------------------------------------|------------------------------------|
| txbf_act       | Configure the eBF/iBF profile                                               | ebf_prof_update<br>ibf_prof_update |
| txbf_param     | PFMU index                                                                  | [0, 63]                            |
|                | Not used                                                                    | -                                  |
|                | Nc<br>(The number of columns in the compressed beamforming feedback matrix) | Default = 0                        |

- Command

```
mt76-test phy0 set txbf_act=ebf_prof_update txbf_param=1,3,0
mt76-test phy0 set txbf_act=ibf_prof_update txbf_param=2,3,0
```

- Example

```
root@OpenWrt:/# mt76-test phy2 set txbf_act=ebf_prof_update txbf_param=1,3,0
[319904.570064] ibf cal process: act = 5, val = 1, 3, 0, 0, 0
root@OpenWrt:/# mt76-test phy2 set txbf_act=ibf_prof_update txbf_param=2,3,0
[319955.549101] ibf cal process: act = 4, val = 2, 3, 0, 0, 0
```

#### 3.7 Implicit Beamforming

#### 2.2.31.3.2 Channel Profile Configuration Update

Directly write the channel profile to the DUT.

| Input Argument | Description                                           | Value                     |
|----------------|-------------------------------------------------------|---------------------------|
| txbf_act       | Configure channel profile                             | prof_update_all           |
| txbf_param     | Start or stop to update                               |                           |
|                | PFMU index                                            | [0, 63]                   |
|                | Starting sequence                                     | f0                        |
|                | Ending sequence                                       | ff                        |
|                | Update data                                           |                           |
|                | Subcarrier index                                      | [00, 3F], hexadecimal     |
|                | Angle of H11                                          | [0000, 0400], hexadecimal |
|                | Angle of H21                                          | [0000, 0400], hexadecimal |
|                | Angle of H31                                          | [0000, 0400], hexadecimal |
|                | Angle of H41                                          | [0000, 0400], hexadecimal |
|                | Angle of H51<br>(Only for mt7992 BE7200 iFEM 5G 5T5R) | [0000, 0400], hexadecimal |
|                | ... (repeat the format above)                         | ...                       |

The angle of Hx1 originally ranges from  $-\pi$  to  $\pi$ . We map it to  $[-0.5, 0.5]$  and transform it through the formula listed below to hexadecimals.

$$y = \begin{cases} \text{round}((x + 2) \times 512), & \text{if } x < 0 \\ \text{round}(x \times 512), & \text{otherwise} \end{cases}, \quad \text{where } x \in [-0.5, 0.5]$$

- Command

```
// Start profile update
mt76-test phy0 set txbf_act=prof_update_all txbf_param=01,f0
mt76-test phy0 set txbf_act=prof_update_all txbf_param=
    00,0000,0000,0000,0000,0000,01,0000,0000,0000,0000,02,0000,0000,0000,0000,
    03,0000,0000,0000,0000,0000,04,003c,039f,0055,0375,05,001c,0380,0035,0356,
    06,03fd,0360,0015,0336,07,03de,0340,03f6,0317
mt76-test phy0 set txbf_act=prof_update_all txbf_param=
    08,03be,0321,03d7,00f7,09,039e,0301,03b7,00d8,0a,037f,00e2,0398,00b8,
    0b,0000,0000,0000,0000,0000,0c,0340,00a3,0359,0079,0d,0321,0084,033a,005a
    0e,0302,0064,031a,003a,0f,03de,0340,03f6,0317
    :
```

Note that you can input any length of data segment of a subcarrier (including subcarrier index, Ang<sub>H11</sub>, Ang<sub>H21</sub>, Ang<sub>H31</sub> and Ang<sub>H41</sub>) and even in any order since it buffers the data until the data of subcarrier index = 3F (63 in decimal) is sent.

- Example

```
root@OpenWrt:/# mt76-test phy2 set txbf_act=prof_update_all txbf_param=01,f0
root@OpenWrt:/# mt76-test phy2 set txbf_act=prof_update_all txbf_param=00,0000,0
000,0000,0000,01,0000,0000,0000,0000,02,0000,0000,0000,0000,03,0000,0000,0000,00
00,04,003c,039f,0055,0375,05,001c,0380,0035,0356,06,03fd,0360,0015,0336,07,03de,
0340,03f6,0317
[ 1203.109344] ibf cal process: act = 9, val = 1, 0, 0, 0, 0, 0
[ 1203.115051] ibf cal process: act = 9, val = 1, 1, 0, 0, 0, 0
[ 1203.120709] ibf cal process: act = 9, val = 1, 2, 0, 0, 0, 0
[ 1203.126357] ibf cal process: act = 9, val = 1, 3, 0, 0, 0, 0
[ 1203.132004] ibf cal process: act = 9, val = 1, 4, 60, 927, 85, 885
[ 1203.138172] ibf cal process: act = 9, val = 1, 5, 28, 896, 53, 854
[ 1203.144338] ibf cal process: act = 9, val = 1, 6, 1021, 864, 21, 822
[ 1203.150685] ibf cal process: act = 9, val = 1, 7, 990, 832, 1014, 791
root@OpenWrt:/# mt76-test phy2 set txbf_act=prof_update_all txbf_param=01,FF
```

### 3.7 Implicit Beamforming

## 2.2.31.3.3 PFMU Tag Write

Configure the profile management unit (PFMU) tag of eBF/iBF for updating the channel profile. This command would use the PFMU tag data stored in driver to update it. If the PFMU tag data is not allocated in driver, it would not take any action.

| Input Argument | Description                            | Value          |
|----------------|----------------------------------------|----------------|
| txbf_act       | Configure the eBF/iBF PFMU tag profile | pfmu_tag_write |
| txbf_param     | Select which PFMU index to update      | [0, 63]        |

- Command

```
mt76-test phy0 set txbf_act=pfmu_tag_write txbf_param=1
```

- Example

```
root@OpenWrt:/# mt76-test phy0 set txbf_act=pfmu_tag_write txbf_param=1
[ 640.411588] mt7915e 0000:01:00:0: ibf cal process: act = 17, val = 1, 0, 0, 0, 0, 0
```

### 3.7 Implicit Beamforming

## 2.2.31.3.4 PFMU Tag Read

Read the current settings of the profile management unit (PFMU) tag of eBF/iBF.

| Input Argument | Description                       | Value              |
|----------------|-----------------------------------|--------------------|
| txbf_act       | Read the eBF/iBF PFMU tag profile | pfmu_tag_read      |
| txbf_param     | Select which PFMU index to read   | [0, 63]            |
|                | Is beamformer or beamformee       | Bfer: 1<br>Bfee: 0 |

- Command

```
mt76-test phy0 set txbf_act=pfmu_tag_read txbf_param=1,1
```

- Example

```
root@OpenWrt:~# mt76-test phy0 set txbf_act=pfmu_tag_read txbf_param=2,1
[ 1109.886154] mt7915e 0000:01:00.0: ibf cal process: act = 16, val = 2, 1, 0, 0, 0, 0
[ 1109.893935] mt7915e 0000:01:00.0: ===== TXBf Profile Tag1 Info =====
[ 1109.902619] mt7915e 0000:01:00.0: DW0 = 0x60030002, DW1 = 0x01400100, DW2 = 0x01c00180
[ 1109.910524] mt7915e 0000:01:00.0: DW4 = 0x00000000, DW5 = 0x000000cc, DW6 = 0x00000000
[ 1109.910524]
[ 1109.919899] mt7915e 0000:01:00.0: PFMU ID = 2 Invalid status = 0
[ 1109.927022] mt7915e 0000:01:00.0: iBf/eBf = 0
[ 1109.927022]
[ 1109.932844] mt7915e 0000:01:00.0: DBW = 0
[ 1109.937020] mt7915e 0000:01:00.0: SU/MU = 0
[ 1109.941195] mt7915e 0000:01:00.0: RMSD = 3
[ 1109.945373] mt7915e 0000:01:00.0: nrow = 3, ncol = 0, ng = 0, LM = 0, CodeBook = 0 MobCalEn = 0
[ 1109.954055] mt7915e 0000:01:00.0: RU start = 0, RU end = 0
[ 1109.959531] mt7915e 0000:01:00.0: Mem Col1 = 0, Mem Row1 = 4, Mem Col2 = 0, Mem Row2 = 5
[ 1109.967607] mt7915e 0000:01:00.0: Mem Col3 = 0, Mem Row3 = 6, Mem Col4 = 0, Mem Row4 = 7
[ 1109.967607]
[ 1109.977158] mt7915e 0000:01:00.0: STS0_SNR = 0xcc, STS1_SNR = 0x00, STS2_SNR = 0x00, STS3_SNR = 0x00
[ 1109.986276] mt7915e 0000:01:00.0: STS4_SNR = 0x00, STS5_SNR = 0x00, STS6_SNR = 0x00, STS7_SNR = 0x00
[ 1109.995392] mt7915e 0000:01:00.0: =====
[ 1110.004075] mt7915e 0000:01:00.0: ===== TXBf Profile Tag2 Info =====
[ 1110.012758] mt7915e 0000:01:00.0: DW0 = 0x18000000, DW1 = 0x00000000, DW2 = 0x00600000
[ 1110.020661] mt7915e 0000:01:00.0: DW3 = 0x00000000, DW4 = 0x00000000, DW5 = 0xe0080000
[ 1110.020661]
[ 1110.030038] mt7915e 0000:01:00.0: Smart antenna ID = 0x0, SE index = 24
[ 1110.036727] mt7915e 0000:01:00.0: RMSD threshold = 0
[ 1110.041684] mt7915e 0000:01:00.0: Timeout = 0x0
[ 1110.046207] mt7915e 0000:01:00.0: Desired BW = 0, Desired Ncol = 0, Desired Nrow = 3
[ 1110.053935] mt7915e 0000:01:00.0: Desired RU Allocation = 0
[ 1110.059498] mt7915e 0000:01:00.0: Mobility DeltaT = 0, Mobility LQ = 0
[ 1110.066014] mt7915e 0000:01:00.0: =====
```

**Note:**

- Tag 1 info:

- Invalid status: 0 for already updated, 1 for not updated.
- iBf/eBf: 0 for iBF mode, 1 for eBF mode.
- DBW: the meaning of the number is same as the BW parameter in [phase compensation](#).
- SU/MU: 0 for SU, 1 for MU

- Tag 2 info:

- Timeout: 0xff for no timeout, 0 for already timeout.
- Desired Ncol: golden's antenna number – 1
- Desired Nrow: DUT's antenna number – 1

### 3.7 Implicit Beamforming

## 2.2.31.3.5 Set PFMU Tag Invalid Bit

Set the invalid bit of the PFMU tag. **Note that this command did not update the PFMU tag to firmware. If you want to validate or invalidate the PFMU tag, please use the PFMU tag write command above.**

| Input Argument | Description                         | Value                  |
|----------------|-------------------------------------|------------------------|
| txbf_act       | Set the invalid bit of the PFMU tag | set_invalid_prof       |
| txbf_param     | The value of the invalid bit        | Valid: 0<br>Invalid: 1 |

- Command

```
mt76-test phy0 set txbf_act=set_invalid_prof txbf_param=1
```

- Example

```
root@OpenWrt:/# mt76-test phy0 set txbf_act=set_invalid_prof txbf_param=1
[ 1390.217962] mt7915e 0000:01:00:0: ibf cal process: act = 18, val = 1, 0, 0, 0, 0, 0
```

## 2.2.31.3.6 BF Station Record Read

Read the current settings of the station record of eBF/iBF.

| Input Argument | Description                                                                                                                                   | Value        |
|----------------|-----------------------------------------------------------------------------------------------------------------------------------------------|--------------|
| txbf_act       | Read eBF/iBF station record                                                                                                                   | sta_rec_read |
| txbf_param     | Select which WLAN index to read<br><i>The WLAN index here is the wcid index set in Bfer's WTBL for the station you wish to send BF packet</i> | [0, 16]      |

- Command

```
mt76-test phy0 set txbf_act=sta_rec_read txbf_param=1
```

- Example

```
root@OpenWrt:/# mt76-test phy0 set txbf_act=sta_rec_read txbf_param=1
[ 1496.033028] mt7915e 0000:01:00:0: ibf cal process: act = 19, val = 1, 0, 0, 0, 0, 0
[ 1496.040816] mt7915e 0000:01:00:0: ===== BF Station Record =====
[ 1496.049498] mt7915e 0000:01:00:0: pfm_u      = 2
[ 1496.054455] mt7915e 0000:01:00:0: su_mu      = 0
[ 1496.059412] mt7915e 0000:01:00:0: bf_cap     = 0
[ 1496.064365] mt7915e 0000:01:00:0: sounding_phy = 1
[ 1496.069320] mt7915e 0000:01:00:0: ndpa_rate  = 0
[ 1496.074276] mt7915e 0000:01:00:0: ndp_rate   = 24
[ 1496.079317] mt7915e 0000:01:00:0: rept_poll_rate = 0
[ 1496.084274] mt7915e 0000:01:00:0: tx_mode    = 2
[ 1496.089229] mt7915e 0000:01:00:0: ncol       = 0
[ 1496.094183] mt7915e 0000:01:00:0: nrow       = 3
[ 1496.099139] mt7915e 0000:01:00:0: bw         = 0
[ 1496.104096] mt7915e 0000:01:00:0: mem_total  = 0
[ 1496.109051] mt7915e 0000:01:00:0: mem_20m    = 0
[ 1496.114007] mt7915e 0000:01:00:0: mem_row0   = 4
[ 1496.118962] mt7915e 0000:01:00:0: mem_col0   = 0
[ 1496.123918] mt7915e 0000:01:00:0: mem_row1   = 5
[ 1496.128873] mt7915e 0000:01:00:0: mem_col1   = 0
[ 1496.133828] mt7915e 0000:01:00:0: mem_row2   = 6
[ 1496.138784] mt7915e 0000:01:00:0: mem_col2   = 0
[ 1496.143740] mt7915e 0000:01:00:0: mem_row3   = 7
[ 1496.148695] mt7915e 0000:01:00:0: mem_col3   = 0
[ 1496.153651] mt7915e 0000:01:00:0: smart_ant  = 0x0
[ 1496.158780] mt7915e 0000:01:00:0: se_idx     = 24
[ 1496.163823] mt7915e 0000:01:00:0: auto_sounding = 0
[ 1496.168779] mt7915e 0000:01:00:0: ibf_timeout = 0xffff
[ 1496.173993] mt7915e 0000:01:00:0: ibf_dbw    = 0
[ 1496.178949] mt7915e 0000:01:00:0: ibf_ncol   = 0
[ 1496.183905] mt7915e 0000:01:00:0: ibf_nrow   = 0
[ 1496.188860] mt7915e 0000:01:00:0: nrow_gt_bw80 = 0
[ 1496.193816] mt7915e 0000:01:00:0: ncol_gt_bw80 = 0
[ 1496.198771] mt7915e 0000:01:00:0: ru_start_idx = 0
[ 1496.203727] mt7915e 0000:01:00:0: trigger_su  = 0
[ 1496.208682] mt7915e 0000:01:00:0: trigger_mu  = 0
[ 1496.213638] mt7915e 0000:01:00:0: ng16_su    = 0
[ 1496.218592] mt7915e 0000:01:00:0: ng16_mu    = 0
[ 1496.223548] mt7915e 0000:01:00:0: codebook42_su = 0
[ 1496.228503] mt7915e 0000:01:00:0: codebook75_mu = 0
[ 1496.233460] mt7915e 0000:01:00:0: he_ltf     = 0
[ 1496.238415] mt7915e 0000:01:00:0: =====
```

## 2.2.31.4 BF TX Setting

### 2.2.31.4.1 Apply TXBF to WTBL

Update the WTBL (Wireless Lan Table, storing capacity or information for the connected peer) for applying TXBF.

| Input Argument | Description                                                                                                                  | Value                            |
|----------------|------------------------------------------------------------------------------------------------------------------------------|----------------------------------|
| txbf_act       | Apply TXBF                                                                                                                   | apply_tx                         |
| txbf_param     | Set WLAN index<br><i>The WLAN index here is the wcid index set in Bfer's WTBL for the station you wish to send BF packet</i> | Decimal                          |
|                | Enable eBF TX                                                                                                                | 0/1                              |
|                | Enable iBF TX                                                                                                                | 0/1                              |
|                | Enable Mu BFTX                                                                                                               | 0<br>Enable is not supported yet |
|                | Phase Calibration                                                                                                            | 1                                |

- Command

```
mt76-test phy0 set txbf_act=apply_tx txbf_param=1,0,1,0,1
```

- Example

```
root@OpenWrt:/# mt76-test phy2 set txbf_act=apply_tx txbf_param=1,1,0,0,1
[320257.106366] ibf cal process: act = 6, val = 1, 1, 0, 0, 1
```

### 3.7 Implicit Beamforming

### 2.2.31.4.2 BF TX Preparation

Profile tag read/write for invalid iBF profile, set TXBF rate, TX length, TX count, and other TX settings.

| Input Argument | Description                                                                                                                  | Value   |
|----------------|------------------------------------------------------------------------------------------------------------------------------|---------|
| txbf_act       | Prepare to TX                                                                                                                | tx_prep |
| txbf_param     | Set BF on                                                                                                                    | 0/1     |
|                | Set AID                                                                                                                      | 1       |
|                | Set WLAN index<br><i>The WLAN index here is the wcid index set in Bfer's WTBL for the station you wish to send BF packet</i> | Decimal |
|                | Set update                                                                                                                   | 0/1     |

- Command

```
mt76-test phy0 set txbf_act=tx_prep txbf_param=0,1,1,0 aid=1 tx_count=10000000
tx_length=1024
mt76-test phy0 set state=tx_frames
```

**Note:**

- tx\_prep does not start TX in mt76, you must start it by setting state = tx\_frames.
- The TXBF parameter of setting AID and setting update (which triggers tx\_apply with fixed parameter) is used for HQADLL mode. To simplify the format of driver code, we reserve those parameters. For command mode, just input the value in the table above.
- tx\_count is set to a large number for simulating continuous TX.

- Example

```
root@OpenWrt:/# mt76-test phy2 set txbf_act=tx_prep txbf_param=0,1,1,0 aid=1 tx_
count=10000000 tx_length=1024
[320319.342425] ibf cal process: act = 3, val = 0, 1, 1, 0, 0
```

### 3.7 Implicit Beamforming

#### 2.2.31.4.3 BF TXCMD Configuration

Configure TXCMD BF bit manually.

Note that this command is available only in Wi-Fi 7 chipsets.

| Input Argument | Description                           |       | Value                 |
|----------------|---------------------------------------|-------|-----------------------|
| txbf_act       | Read/Write TXCMD BF bit configuration |       | txcmd                 |
| txbf_param     | Action                                | Read  | 0 (Not supported yet) |
|                |                                       | Write | 1                     |
|                | Enable TXCMD BF bit manual control    |       | 0/1                   |
|                | TXCMD BF bit                          |       | 0/1                   |

- Command

```
// Force TXCMD BF bit to 1 to TX BF
mt76-test phy0 set txbf_act=txcmd txbf_param=1,1,1
// Force TXCMD BF bit to 0 to disable TX BF
mt76-test phy0 set txbf_act=txcmd txbf_param=1,1,0
// Return to normal mode for TXCMD BF bit control
mt76-test phy0 set txbf_act=txcmd txbf_param=1,0,0
```

- Example

```
root@OpenWrt:/# mt76-test phy0 set txbf_act=txcmd txbf_param=1,1,1
[ 1127.294053] mt7996e 0000:01:00:0: ibf cal process: act = 20, val = 1, 1, 1, 0, 0, 0, 0, 0
```

### 3.7 Implicit Beamforming

#### 2.2.31.5 TXBF Trigger/Stop Sounding

Trigger the firmware to start or stop sending sounding packets (including null data packets (NDP) and null data packet announcement (NDPA)). This command is used for iBF calibration and eBF certification with the golden device only.

| Input Argument | Description                                                                                                                                                          | Value                             |   |
|----------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------|---|
| txbf_act       | Trigger sounding<br>Stop sounding                                                                                                                                    | trigger_sounding<br>stop_sounding |   |
| txbf_param     | Set sounding mode                                                                                                                                                    | SU sounding                       | 0 |
|                |                                                                                                                                                                      | MU sounding                       | 1 |
|                |                                                                                                                                                                      | SU periodic sounding              | 2 |
|                |                                                                                                                                                                      | MU periodic sounding              | 3 |
|                | Set the MU number (i.e. station number)                                                                                                                              | Decimal                           |   |
|                | Set the sounding interval for periodic sounding                                                                                                                      | Decimal<br>(Unit: 4 ms)           |   |
|                | Set WLAN index<br><i>The WLAN index here is the wcid index set in Bfer's WTBL for the station you wish to send sounding packet</i><br>(4 u8 data forming a u32 data) | Decimal                           |   |

- Command

```
// Starts sounding
mt76-test phy0 set txbf_act=trigger_sounding txbf_param=2,1,ff,1,0,0,0
// Stops sounding
mt76-test phy0 set txbf_act=stop_sounding txbf_param=0
```

- Example

```
root@OpenWrt:/# mt76-test phy0 set txbf_act=trigger_sounding txbf_param=2,1,ff,1,0,0,0
[ 1622.130808] mt7915e 0000:01:00.0: ibf cal process: act = 14, val = 2, 1, 255, 1, 0, 0
```

### 3.7 Implicit Beamforming

## 2.2.31.6 iBF Calibration

Do iBF calibration.

| Input Argument | Description                                                                                                                                   |                             |                | Value            |
|----------------|-----------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------|----------------|------------------|
| txbf_act       | Start iBF calibration                                                                                                                         |                             |                | phase_cal        |
| txbf_param     | Set group index                                                                                                                               |                             |                | [0, 8], decimal  |
|                | Set the L/M/H channel in group<br>(Use the lowest/middle/highest<br>channel in each <a href="#">channel group</a> to do<br>phase calibration) | L                           |                | 0                |
|                |                                                                                                                                               | M                           |                | 1                |
|                |                                                                                                                                               | H                           |                | 2                |
|                | Set SX2 (Band index)                                                                                                                          |                             |                | 0, for 2G band 0 |
|                |                                                                                                                                               |                             |                | 1, for 5G band 1 |
|                | Set calibration type                                                                                                                          | Do nothing                  |                | 0                |
|                |                                                                                                                                               | Calibration                 |                | 1                |
|                |                                                                                                                                               | Verification                |                | 2                |
|                |                                                                                                                                               | Calibration with instrument |                | 3                |
|                | Set the low noise amplifier (LNA)<br>gain level                                                                                               | 2G                          | Low            | 0                |
|                |                                                                                                                                               |                             | Middle         | 1                |
|                |                                                                                                                                               |                             | High           | 2                |
|                |                                                                                                                                               |                             | Ultra-high     | 3                |
|                |                                                                                                                                               | 5G                          | Low            | 0                |
|                |                                                                                                                                               |                             | Middle         | 1                |
|                |                                                                                                                                               |                             | Middle high    | 2                |
| High           |                                                                                                                                               |                             | 3              |                  |
|                |                                                                                                                                               |                             | 4              |                  |
| iBF Version    |                                                                                                                                               |                             | 0, for iBF 1.0 |                  |
|                |                                                                                                                                               |                             | 3, for iBF 2.0 |                  |

- Command

```
mt76-test phy0 set txbf_act=phase_cal txbf_param=1,1,1,3,1,0
```

- Example



```

root@OpenWrt:/# mt76-test phy0 set txbf_act=phase_cal txbf_param=2,1,0,1
[ 1908.048955] mt7915e 0000:01:00.0: ibf cal process: act = 10, val = 2, 1, 0, 1, 0, 0
[ 1908.083368] mt7915e 0000:01:00.0: Calibrated result = 1
[ 1908.088582] mt7915e 0000:01:00.0: Group 2 and Group M
[ 1908.093624] mt7915e 0000:01:00.0: m_t0_h = 243
[ 1908.098058] mt7915e 0000:01:00.0: m_t1_h = 173
[ 1908.102493] mt7915e 0000:01:00.0: m_t2_h = 74
[ 1908.106842] mt7915e 0000:01:00.0: r0_uh = 1
[ 1908.111015] mt7915e 0000:01:00.0: r0_h = 0
[ 1908.115103] mt7915e 0000:01:00.0: r0_m = 0
[ 1908.119190] mt7915e 0000:01:00.0: r0_l = 0
[ 1908.123279] mt7915e 0000:01:00.0: r1_uh = 0
[ 1908.127452] mt7915e 0000:01:00.0: r1_h = 0
[ 1908.131543] mt7915e 0000:01:00.0: r1_m = 0
[ 1908.135630] mt7915e 0000:01:00.0: r1_l = 0
[ 1908.139719] mt7915e 0000:01:00.0: r2_uh = 0
[ 1908.143893] mt7915e 0000:01:00.0: r2_h = 0
[ 1908.147979] mt7915e 0000:01:00.0: r2_m = 0
[ 1908.152067] mt7915e 0000:01:00.0: r2_l = 0
[ 1908.156153] mt7915e 0000:01:00.0: r3_uh = 0
[ 1908.160326] mt7915e 0000:01:00.0: r3_h = 0
[ 1908.164415] mt7915e 0000:01:00.0: r3_m = 0
[ 1908.168501] mt7915e 0000:01:00.0: r3_l = 4
[ 1908.172589] mt7915e 0000:01:00.0: r3_ul = 0
[ 1908.176764] mt7915e 0000:01:00.0: c0_h = 13, c1_h = 83, c2_h = 182
[ 1908.182934] mt7915e 0000:01:00.0: c0_m = 13, c1_m = 83, c2_m = 182
[ 1908.189101] mt7915e 0000:01:00.0: c0_l = 13, c1_l = 83, c2_l = 182
[ 1908.195269] mt7915e 0000:01:00.0: c3_m = 13, c3_h = 0
[ 3598.313781] mt7915e 0000:01:00.0: ibf cal process: act = 5, val = 1, 0, 2, 0, 0, 0
[ 3598.321380] mt7915e 0000:01:00.0: ibf cal process: phase comp info
[ 3598.325666] mt7915e 0000:01:00.0: 0f 00 01 00 00 00 00 00 01 00 00 00 00 00 00
[ 3598.331241] mt7915e 0000:01:00.0: 00 00 00 00 00 00 00 00 04 00 00 00 00 00
[ 3598.336813] mt7915e 0000:01:00.0: 00 00 00 00 00 00 f3 ad 4a 00 00 00 00 00 00
[ 3598.344574] mt7915e 0000:01:00.0: ibf cal process: act = 10, val = 2, 1, 0, 2, 1, 0
[ 3598.354783] mt7915e 0000:01:00.0: Verification result = 1
[ 3598.360172] mt7915e 0000:01:00.0: c0_h = 0, c1_h = 0, c2_h = 0
[ 3598.365996] mt7915e 0000:01:00.0: c0_m = 0, c1_m = 0, c2_m = 0
[ 3598.371818] mt7915e 0000:01:00.0: c0_l = 0, c1_l = 251, c2_l = 254
[ 3598.377985] mt7915e 0000:01:00.0: c3_m = 0, c3_h = 0

```

TX phase  
For saving memory,  
t3 is served as reference phase for 4x4  
RX0 phase at Ultra high, high,  
middle, and low LNA gain

Average phase (used for verification)

**Note:**

- If calibration is done successfully, it would return "Calibrated result = 1".
- This command will return the calibrated phase
  - TX phase: the phase of the largest TX path (e.g. T3 for 4 × 4) would be the reference phase. That is,
 
$$m_{tn\_h} = m_{tn\_h} - m_{tN\_h}, \text{ for } \begin{cases} N = \text{largest TX path} \\ n = 0 \text{ to } N - 1 \end{cases}$$
  - RX phase: Record the  $N^{th}$  RX phase of ultra-high, high, middle, and low LNA gain. No ultra-low gain since iBF normally would not be applied in this case.
- For verification:
  - If verified success, it would return "Verification result = 1".
  - Please do phase compensation before phase verification.
  - The verification here measures the degree of compensated phase. **The average phases must fall within the range of  $[-15^\circ, 15^\circ]$  to pass.**

**3.7 Implicit Beamforming****2.2.31.7 iBF Save to EEPROM**

Write the calibrated phase into eeprom **in the driver**.

To sync the iBF cal result to ateni tmp file, please refer to the [ateni eeprom ibf sync](#) command.

| Input Argument | Description                            | Value      |
|----------------|----------------------------------------|------------|
| txbf_act       | Write the calibrated phase into EEPROM | e2p_update |

| Input Argument | Description              |                                    | Value                                                                              |
|----------------|--------------------------|------------------------------------|------------------------------------------------------------------------------------|
| txbf_param     | Set the group index      |                                    | [0, 8], decimal<br><b>[0, 12], decimal</b><br><b>(for mt7992 BE7200 2i5i 5T5R)</b> |
|                | Set the update band type | Update all                         | 0                                                                                  |
|                |                          | Update BW 160                      | Not supported                                                                      |
|                |                          | Update 2G only                     |                                                                                    |
|                |                          | Update 5G only                     |                                                                                    |
|                | Set the update type      | Update one group                   | Not supported yet                                                                  |
|                |                          | Update all of the groups           | 1                                                                                  |
|                |                          | Erase all of the groups            | Not supported                                                                      |
|                |                          | Read calibrated phases from EEPROM |                                                                                    |

- Command

```
mt76-test phy0 set txbf_act=e2p_update txbf_param=0,0,1
```

- Example

```
root@OpenWrt:/# mt76-test phy2 set txbf_act=e2p_update txbf_param=0,0,1
[320977.074582] ibf cal process: act = 10, val = 0, 0, 1, 0, 0
```

### 3.7 Implicit Beamforming

## 2.2.32 Explicit Beamforming (eBF)

This section covers the eBF certification commands. Some commands used in the eBF certification is already listed in [IBF section](#). Note that the argument of the eBF command must contain **txbf\_act** and **txbf\_param** at the same time. **txbf\_act** sets the action TXBF and **txbf\_param** sets the required parameters for the TXBF action. For more information, please refer to [eBF example](#).

### 2.2.32.1 Init Setting for eBF

Initialize the settings of DUT for eBF including

1. Set the MAC address configuration
2. Create second interface (broadcast and multicast (BMC) entry) in WTBL for using TXCMD to transmit sounding packet (**BF data should still use TXD for mt7915/mt7916/mt7981/mt7986**)
3. Enable ETXBF capability for the DUT
4. Set the tx\_antenna\_mask and the spe\_idx

| Input Argument | Description                                | Value                                                          |
|----------------|--------------------------------------------|----------------------------------------------------------------|
| txbf_act       | Init the setting for the eBF DUT           | ebf_init                                                       |
|                | Init the setting for the eBF golden device | <b>Not supported</b><br><b>Please use Jedi/Logan as golden</b> |
| txbf_param     | Do nothing/Enable                          | 0/1                                                            |

- Command

```
mt76-test phy0 set state=idle
# init for DUT
mt76-test phy0 set txbf_act=ebf_init txbf_param=1
```

- Example

```
root@OpenWrt:~# mt76-test phy0 set txbf_act=ebf_init txbf_param=1
[ 308.826698] mt7915e 0000:01:00.0: ibf cal process: act = 3, val = 1, 0, 0, 0, 0
root@OpenWrt:~# mt76-test phy0 set txbf_act=ebf_golden_init txbf_param=1
[ 343.835718] mt7915e 0000:01:00.0: ibf cal process: act = 2, val = 1, 0, 0, 0, 0
[ 343.845190] mt7915e 0000:01:00.0: Set BBP RX CR = 5
```

### 3.8 Explicit Beamforming

## 2.2.33 Zero Wait DFS (ZWDFS)

These commands are used for testing the hardware functionality of background chain (i.e. check its Received Signal Strength Indication (RSSI) and Idle Power Indicator (IPI) counter (see 2.2.33.3 for IPI introduction)). Therefore, the channel selection could be non-DFS channels, and **the country code could remain at "VV"**.

### 2.2.33.1 Set channel and bandwidth of background chain

Enable and set the channel and bandwidth of the background chain (the RX chain used for ZWDFS) in test mode.

| Input Argument    | Description                                                                                                                                      | Value                         |
|-------------------|--------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------|
| offchan_ch        | Set the control channel of the background chain                                                                                                  | [36, 196]<br>Valid 5G channel |
| offchan_center_ch | Set the center channel of the background chain<br>(optional; if it is not set, the driver will calculate it based on the control channel and bw) | [36, 196]<br>Valid 5G channel |
| offchan_bw        | Set the bandwidth of the background chain                                                                                                        | NOHT                          |
|                   |                                                                                                                                                  | 20                            |
|                   |                                                                                                                                                  | 40                            |
|                   |                                                                                                                                                  | 80                            |
|                   |                                                                                                                                                  | 160                           |

- Command

```
mt76-test phy0 set state=idle
mt76-test phy0 set offchan_ch=100 offchan_bw=80
```

**Note:**

- The state should be set to idle before enabling background chain.
- The background chain is enabled only when offchan ch and offchan bw are set.

- Example

```
root@OpenWrt:~# mt76-test phy1 dump | grep offchan
offchan_ch=100
offchan_center_ch=106
offchan_bw=80
```

### 3.9 Zero Wait DFS

### 2.2.33.2 Dump Channel and Bandwidth of Background Chain

Dump the current center channel and bandwidth if the background chain is enabled.

- Command

```
mt76-test phy0 dump
```

- Example


```
root@OpenWrt:/# mt76-test phy1 dump
state=idle
tx_count=1
tx_length=1024
tx_rate_mode=ofdm
tx_rate_nss=1
tx_rate_idx=0
tx_rate_sgi=0
tx_rate_ldpc=0
tx_rate_stbc=0
aid=0
ru_alloc=0
ru_idx=0
offchan_ch=100
offchan_center_ch=0
offchan_bw=80
```

#### 3.9 Zero Wait DFS

### 2.2.33.3 Read Idle Power Indicator (IPI) Histogram of Background Chain

Read the IPI histogram of background chain. The IPI histogram shows the IPI count for each IPI index, where each index is defined as a specific power range as shown in the table below. Also, the IPI count of each IPI index could be read from the control register listed in the table below (via [this command](#)). Note that mt7986 has no dedicated RX, so there is no CR for IPI in mt7986.

The concept of IPI is shown in the following figure. The Idle Power Indicator, which is defined in 802.11K, is a counter used for idle power measurement. The IPI counter of the corresponding IPI index updates every 8  $\mu$ s until a packet is detected (Packet Detection (PD) Done), based on the current RSSI value. Therefore, this indicator could be used to test out the hardware ability of the dedicated RX (background chain for ZWDFS).



| IPI Index | Power Range [dBm] | CR Address of mt7915 | CR Address of mt7916 | CR Address of mt7996/mt7992 |
|-----------|-------------------|----------------------|----------------------|-----------------------------|
| 0         | $(-\infty, -92)$  | 0x830AF0A8           | 0x83121000           | 0x83041000                  |
| 1         | $(-92, -89)$      | 0x830AF0AC           | 0x83121004           | 0x83041004                  |
| 2         | $(-89, -86)$      | 0x830AF0B0           | 0x83121008           | 0x83041008                  |
| 3         | $(-86, -83)$      | 0x830AF0B4           | 0x8312100C           | 0x8304100C                  |
| 4         | $(-83, -80)$      | 0x830AF0B8           | 0x83121010           | 0x83041010                  |
| 5         | $(-80, -75]$      | 0x830AF0BC           | 0x83121014           | 0x83041014                  |
| 6         | $(-75, -70]$      | 0x830AF0C0           | 0x83121018           | 0x83041018                  |
| 7         | $(-70, -65]$      | 0x830AF0C4           | 0x8312101C           | 0x8304101C                  |
| 8         | $(-65, -60]$      | 0x830AF0C8           | 0x83121020           | 0x83041020                  |
| 9         | $(-60, -55]$      | 0x830AF0CC           | 0x83121024           | 0x83041024                  |
| 10        | $(-55, \infty)$   | 0x830AF0D0           | 0x83121028           | 0x83041028                  |

The format of the command is listed in the following table. This command also calculates the channel load, self-idle ratio, and IPI idle ratio according to the IPI threshold you set.

$$\begin{aligned}
 ipi\_hist\_count_i &= ipi \text{ count for } ipi\_index = i \\
 ipi\_hist\_count\_th &= \sum_{i=th}^{10} ipi\_hist\_count_i, \text{ where } 0 \leq th \leq 10 \\
 ipi\_free\_count &= \sum_{i=0}^{10} ipi\_hist\_count_i \\
 ipi\_idle\_ratio &= \frac{ipi\_free\_count - ipi\_hist\_count\_th}{ipi\_free\_count} \times 100\% \\
 self\_idle\_ratio &= \frac{ipi\_period - tx\_assert\_time}{ipi\_period} \times 100\% \\
 channel\_load &= \begin{cases} \frac{self\_idle\_ratio - ipi\_idle\_ratio}{self\_idle\_ratio} \times 100\%, & self\_idle\_ratio \geq ipi\_idle\_ratio \\ 0, & otherwise \end{cases}
 \end{aligned}$$

Note that `ipi_antenna_idx` is not available in the Wi-Fi 7 chipset.

| Input Argument               | Description                                                                                                                                                                                                                      | Value                                          |
|------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------|
| <code>ipi_threshold</code>   | Set the IPI index threshold for calculating the channel load and idle ratio<br><i>When IPI threshold is set to K, then the total IPI count of IPI index <math>\geq K</math> is used to calculate channel load and idle ratio</i> | [0, 10], decimal<br>The range of the IPI index |
| <code>ipi_period</code>      | Set the period for accumulating the IPI counter                                                                                                                                                                                  | [0, 10000], msec                               |
| <code>ipi_antenna_idx</code> | Specify to read the IPI histogram of which antenna                                                                                                                                                                               | Antenna 0                                      |
|                              |                                                                                                                                                                                                                                  | Antenna 1                                      |
|                              |                                                                                                                                                                                                                                  | Antenna 2                                      |
|                              |                                                                                                                                                                                                                                  | Antenna 3                                      |
|                              |                                                                                                                                                                                                                                  | Use all antennas<br>4<br>(Default value)       |

- Command

```
mt76-test phy0 set ipi_threshold=8 ipi_period=100 ipi_antenna_idx=2
```

**Note:**

- The state should be set to idle and background chain should be enabled before reading IPI histogram.
- This command prints out all the IPI histogram of all the antenna if ipi\_antenna\_idx is not specified.
- This command automatically resets all the IPI counters to zero, and then it returns the accumulated IPI counter during the set IPI period.

## • Example

```
root@OpenWrt:/# mt76-test phy1 set ipi_threshold=0 ipi_period=100 ipi_antenna_idx
x=2
root@OpenWrt:/# [ 770.249322] mt7915e 0000:01:00.0: Antenna index: 6
[ 770.254118] mt7915e 0000:01:00.0: IPI 0 (power range: (-inf, -92] dBm): ipi count = 1456480
[ 770.262459] mt7915e 0000:01:00.0: IPI 1 (power range: (-92, -89] dBm): ipi count = 5803663
[ 770.270712] mt7915e 0000:01:00.0: IPI 2 (power range: (-89, -86] dBm): ipi count = 3166532
[ 770.278964] mt7915e 0000:01:00.0: IPI 3 (power range: (-86, -83] dBm): ipi count = 3398024
[ 770.287217] mt7915e 0000:01:00.0: IPI 4 (power range: (-83, -80] dBm): ipi count = 2707706
[ 770.295468] mt7915e 0000:01:00.0: IPI 5 (power range: (-80, -75] dBm): ipi count = 1325184
[ 770.303718] mt7915e 0000:01:00.0: IPI 6 (power range: (-75, -70] dBm): ipi count = 1172129
[ 770.311970] mt7915e 0000:01:00.0: IPI 7 (power range: (-70, -65] dBm): ipi count = 696205
[ 770.320134] mt7915e 0000:01:00.0: IPI 8 (power range: (-65, -60] dBm): ipi count = 716684
[ 770.328299] mt7915e 0000:01:00.0: IPI 9 (power range: (-60, -55] dBm): ipi count = 574800
[ 770.336464] mt7915e 0000:01:00.0: IPI 10 (power range: (-55, inf] dBm): ipi count = 4944143
[ 770.344800] mt7915e 0000:01:00.0: IPI threshold 0: ipi_hist_count_th = 25961550, ipi_free_count = 25961550
[ 770.354435] mt7915e 0000:01:00.0: TX assert time = 0 [ms]
[ 770.359915] mt7915e 0000:01:00.0: band[1]: chan load = 100%, self idle ratio = 100%, idle ratio = 0%
```

Note that the "Antenna index: 6" in the above figure is because the antenna index starts from 4 for band index 1 of a DBDC chip. The IPI counter of each IPI index has a large number because of the noise in the environment I used. If the DUT is set in shielding box/room and the signal is transmitted via cable, then only the IPI counter of the IPI index would increase.

**3.9 Zero Wait DFS****2.2.33.4 Reset Idle Power Indicator (IPI) Counter of Background Chain**

Reset all the IPI counters to zero.

| Input Argument | Description                               | Value |
|----------------|-------------------------------------------|-------|
| ipi_reset      | Reset the IPI counter of the dedicated RX | 1     |

You could also utilize the IPI reset CR to reset the IPI counter if the mt76 IPI reset command is not working.

| Chip             | IPI Reset CR Address | IPI Reset Method                                                                                                                                                      |
|------------------|----------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| mt7915           | 0x830AF070           | Set the bit 27 of the CR to 1                                                                                                                                         |
| mt7916           | 0x831A3008           | Set the bit 2 of the CR to 1<br><i>Note that the CR automatically resets bit 2 to 0 after setting it to 1.<br/>Don't worry if the value of bit 2 of CR remains 0.</i> |
| mt7981<br>mt7986 |                      | No dedicated RX                                                                                                                                                       |
| mt7996<br>mt7992 | 0x830A5DFC           | Set the bit 28 of the CR to 1                                                                                                                                         |

## • Command

```
mt76-test phy0 set ipi_reset=1
or
echo 0x831a3008 > /sys/kernel/debug/ieee80211/phy0/mt76/regidx/
echo 4 > /sys/kernel/debug/ieee80211/phy0/mt76/regval/
```

- Example

```
root@OpenWrt:/# iwpriv phy0 mac 830AF0B0
phy0      mac:[0x830AF0B0]:004e87f1
root@OpenWrt:/# mt76-test phy0 set ipi_reset=1
root@OpenWrt:/# iwpriv phy0 mac 830AF0B0
phy0      mac:[0x830AF0B0]:00001f9d
```

### 3.9 Zero Wait DFS

## 2.2.34 Enable TX Power Single SKU

Enable the single SKU table for verifying TX power in testmode.

| Input Argument | Description                            | Value |
|----------------|----------------------------------------|-------|
| sku_en         | Enable/Disable single SKU in test mode | 1/0   |

- Command

```
mt76-test phy0 set sku_en=1
```

**Note:**

- Please follow **MT76 Programming Guide Section 9** to add your single sku power limit table in the DTS file
- Please **set your country to "VV"** since our country would be set to VV in test mode.

```
&slot0 {
    mt7996@0,0 {
        reg = <0x0000 0 0 0 0>;
        device_type = "pci";
        mediatek,mt76-eeeprom = <&factory 0x0>;
        power-limits {
            r0 {
                country = "VV";
                txpower-2g {
                    r0 {
                        channels = <1 1>;
                        txs_delta = <0 0 0>;
                        rates-ckk = <22 25 27 24>;
                        rates-ofdm = <27 22 21 29 28 24 35 29>;
                        rates-mcs =
                        <1 22 26 20 22 32 30 30 30 28 30>,
                        <1 26 30 34 30 20 22 40 22 32 28>,
                        <2 126 126 126 126 126 126 126 126 126 126>;
                    };
                };
            };
        };
    };
};
```

- Please **do not use tx\_power** command when sku\_en is on.

- Example

(i) sku\_en is off: TX power is decided by eeprom txpower field & tx\_power

```
root@OpenWrt:/# mt76-test phy0 dump | grep sku_en
sku_en=0
root@OpenWrt:/# cat /sys/kernel/debug/ieee80211/phy0/mt76/txpower_sku

Phy 0 TX Power Table (Channel 1)
: 1m 2m 5m 11m
CCK (TMAC) : 48 48 48 48
OFDM (TMAC) : 48 48 48 48 48 48 48 48
HT20 (TMAC) : 48 48 48 48 48 48 48 48 48 48 48 48
HT40 (TMAC) : 48 48 48 48 48 48 48 48 48 48 48 48 48 48
VHT20 (TMAC) : 48 48 48 48 48 48 48 48 48 48 48 48 48 48 48 48
VHT40 (TMAC) : 48 48 48 48 48 48 48 48 48 48 48 48 48 48 48 48
VHT80 (TMAC) : 48 48 48 48 48 48 48 48 48 48 48 48 48 48 48 48
VHT160 (TMAC) : 48 48 48 48 48 48 48 48 48 48 48 48 48 48 48 48
HE26 (TMAC) : 48 48 48 48 48 48 48 48 48 48 48 48 48 48 48 48
HE52 (TMAC) : 48 48 48 48 48 48 48 48 48 48 48 48 48 48 48 48
HE106 (TMAC) : 48 48 48 48 48 48 48 48 48 48 48 48 48 48 48 48
HE242 (TMAC) : 48 48 48 48 48 48 48 48 48 48 48 48 48 48 48 48
HE484 (TMAC) : 48 48 48 48 48 48 48 48 48 48 48 48 48 48 48 48
HE936 (TMAC) : 48 48 48 48 48 48 48 48 48 48 48 48 48 48 48 48
HE2x936 (TMAC) : 48 48 48 48 48 48 48 48 48 48 48 48 48 48 48 48
: mcs0 mcs1 mcs2 mcs3 mcs4 mcs5 mcs6 mcs7 mcs8 mcs9 mcs10 mcs11
EHT26 (TMAC) : 48 48 48 48 48 48 48 48 48 48 48 48 48 48 48 48
EHT52 (TMAC) : 48 48 48 48 48 48 48 48 48 48 48 48 48 48 48 48
EHT106 (TMAC) : 48 48 48 48 48 48 48 48 48 48 48 48 48 48 48 48
EHT242 (TMAC) : 48 48 48 48 48 48 48 48 48 48 48 48 48 48 48 48
EHT484 (TMAC) : 48 48 48 48 48 48 48 48 48 48 48 48 48 48 48 48
EHT936 (TMAC) : 48 48 48 48 48 48 48 48 48 48 48 48 48 48 48 48
EHT2x936 (TMAC) : 48 48 48 48 48 48 48 48 48 48 48 48 48 48 48 48
EHT4x936 (TMAC) : 48 48 48 48 48 48 48 48 48 48 48 48 48 48 48 48
EHT26_52 (TMAC) : 48 48 48 48 48 48 48 48 48 48 48 48 48 48 48 48
EHT26_106 (TMAC) : 48 48 48 48 48 48 48 48 48 48 48 48 48 48 48 48
EHT484_242 (TMAC) : 48 48 48 48 48 48 48 48 48 48 48 48 48 48 48 48
EHT936_484 (TMAC) : 48 48 48 48 48 48 48 48 48 48 48 48 48 48 48 48
EHT936_484_242 (TMAC) : 48 48 48 48 48 48 48 48 48 48 48 48 48 48 48 48
EHT2x936_484 (TMAC) : 48 48 48 48 48 48 48 48 48 48 48 48 48 48 48 48
EHT3x936 (TMAC) : 48 48 48 48 48 48 48 48 48 48 48 48 48 48 48 48
EHT3x936_484 (TMAC) : 48 48 48 48 48 48 48 48 48 48 48 48 48 48 48 48
```

- (ii) sku\_en is on: TX power is decided by the single SKU table

[illegible]



## 2.3 atenl

atenl is a daemon for the communication between HQADLL command and driver. Moreover, it has command mode used for e2p operations. For specific e2p commands (for example, `atenl -i phy0 -c "..."`), the daemon bypasses HQADLL mode and terminates after the e2p command is done. atenl would run in the background in HQADLL mode.

### Note:

- For the **DBDC/TBTC** device, please use **the first phy index** for the following commands.
- In HQADLL mode, **do not** start two atenl daemons with different interfaces. Please use "killall atenl" before starting another atenl process in HQADLL mode. If you use ated instead of atenl, you can skip this note because the ated wrapper handles the case correctly.
- In atenl, it will detect the SDK you use to assign the default bridge name. Currently, it supports OpenWrt (default bridge name = br-lan) and RDK-B (default bridge name = brlan0). For the other 3<sup>rd</sup> party SDK or using a non-default bridge, please specify the bridge name via the argument "-b" listed in the following table.
- To support writing back to flash memory without entering flash mode, please use -p to specify the partition name and offset. atenl supports MTD and eMMC flash write-back.

| Argument | Description                                              |
|----------|----------------------------------------------------------|
| -i       | Specify interface                                        |
| -u       | Use unicast to send the response                         |
| -b       | Specify bridge name                                      |
| -c       | Specific e2p command                                     |
| -p       | Specify flash partition name and offset for writing back |
| -h       | Help                                                     |

### 2.3.1 Start Daemon

Enter HQADLL mode

- Command  

```
atenl -i phyX -u
```

### 2.3.2 Check EEPROM Mode

This command is used to:

- Check the path of the temp EEPROM data for atenl
- Indicate eFuse mode or flash mode (**here flash mode includes flash, binfile and default bin mode**)

- Command  

```
atenl -i phy0 -c "eeprom file"
```

- Example

```
root@OpenWrt:/usr/sbin# atenl -i phy0 -c "eeprom file"
/tmp/atenl-eeprom
Flash mode: 1
```

### 2.3.3 Clear EEPROM Data Temp File

- Command  
`atenl -i phy0 -c "eeprom reset"`
- Example

```
root@OpenWrt:/usr/sbin# ls /tmp | grep atenl
atenl-eeprom
root@OpenWrt:/usr/sbin# atenl -i phy0 -c "eeprom reset"
root@OpenWrt:/usr/sbin# ls /tmp | grep atenl
root@OpenWrt:/usr/sbin#
```

### 2.3.4 Read EEPROM Data

- Command  
 # Read all  
`hexdump -C /tmp/atenl-eeprom`  
 # Read specific offset  
`atenl -i phy0 -c "eeprom read 0x<offset>"`
- Example

```
root@OpenWrt:/usr/sbin# hexdump -C /tmp/atenl-eeprom
00000000  ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff |.....|
*
00005000  15 79 00 00 00 0c 43 2a 59 9f 00 0c 43 2a 59 a0 |.y...C*Y...C*Y.|
00005010  15 79 c3 14 00 80 02 00 15 79 c3 14 ed 9c 01 00 |.y.....y.....|
00005020  16 79 c3 14 00 80 02 00 16 79 c3 14 00 00 01 00 |.y.....y.....|
00005030  00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 |.....|
00005040  00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 |.....|
00005050  01 00 94 00 00 00 00 00 00 00 00 00 00 00 00 00 |.....|
00005060  00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 |.....|
00005070  30 1c 0f 00 00 00 07 b0 82 00 00 00 00 00 00 00 |0.....|
00005080  00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 |.....|
*
000050a0  00 00 00 00 00 00 00 00 ee 3c 0b d1 96 72 de d2 |.....<...r..|
000050b0  00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 |.....|
*
00005190  24 24 08 00 28 00 00 15 00 00 00 00 00 00 00 00 |$....(.....|
000051a0  00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 |.....|
```

### 2.3.5 Change Value to Specific Offset

This command only updates EEPROM data in the temp file. Writing back to flash or eFuse is required for the changes to take effect.

- Command  
`atenl -i phy0 -c "eeprom set 0x<offset>=0x<val>"`
- Example

```
root@OpenWrt:/usr/sbin# atenl -i phy0 -c "eeprom set 0x670=0x10"
set offset 0x670 to 0x10
```

- Check

```
*
00005670  10 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 |.....|
00005680  06 09 00 00 00 08 0a 00 02 00 07 0a 00 00 00 00 |.....|
```

### 2.3.6 Update Buffer Mode

This command will send an MCU command to trigger the buffer mode update.  
 This is same as jedi's "iwpriv ra0 set bufferMode=2".

- Command

```
atenl -i phy0 -c "eeprom update buffermode"
```

### 2.3.7 Write Back EEPROM Data to Flash

Write back values of EEPROM data (/tmp/atenl-eeprom) to flash (mtd/eMMC factory).

- Command

```
atenl -i phy0 -c "eeprom write flash"
```

or

```
atenl -i phy0 -c "sync eeprom all"
```

or

```
atenl -i phy0 -c "sync eeprom all" -p <partition name>:<offset>
```

- Example: If the driver is not in flash mode or cannot enter flash mode, the user should provide the **flash partition name** and **offset** to write back the EEPROM data to flash memory.

(i) For MTD

```
# Check MTD partition name (case insensitive)
```

```
# Usually, the eeprom data is stored in the factory partition
```

```
cat /proc/mtd
```

```
root@OpenWrt:~# cat /proc/mtd
dev:      size  erasesize  name
mtd0: 08000000 00020000 "spi0.0"
mtd1: 00100000 00020000 "BL2"
mtd2: 00080000 00020000 "u-boot-env"
mtd3: 00400000 00020000 "Factory"
mtd4: 00200000 00020000 "FIP"
mtd5: 07080000 00020000 "ubi"
```

```
# Write back
```

```
atenl -i phy0 -c "sync eeprom all" -p Factory:0x0
```

(ii) eMMC

```
# Check MTD partition name (case insensitive)
```

```
# Usually, the eeprom data is stored in the factory partition
```

```
blkid
```

```
root@OpenWrt:~# blkid
/dev/mmcblk0p1: PARTLABEL="u-boot-env" PARTUUID="54e99ba2-aa8d-11ef-b58e-0242c0a80002"
/dev/mmcblk0p2: PARTLABEL="factory" PARTUUID="54e9c334-aa8d-11ef-b58e-0242c0a80002"
/dev/mmcblk0p3: PARTLABEL="fip" PARTUUID="54e9e468-aa8d-11ef-b58e-0242c0a80002"
/dev/mmcblk0p4: PARTLABEL="kernel" PARTUUID="54ea04b6-aa8d-11ef-b58e-0242c0a80002"
/dev/mmcblk0p5: TYPE="squashfs" PARTLABEL="rootfs" PARTUUID="54ea2112-aa8d-11ef-b58e-0242c0a80002"
```

```
# Write back
```

```
atenl -i phy0 -c "sync eeprom all" -p factory:0x0
```

### 2.3.8 Write Back EEPROM Data to eFuse

Write back values of EEPROM data (/tmp/atenl-eeprom) to eFuse. **Please check the correctness of EEPROM data before executing this command.**

To protect the FT calibrated values stored in eFuse, the MT76 driver restricts the offset that can be updated. For more information about the protected eFuse field, please refer to [this table](#).

- Command

```
atenl -i phy0 -c "eeprom write to efuse"
```

## 2.3.9 Write Back EEPROM Data to Bin File

Write back values of EEPROM data (/tmp/atenl-eeprom) to bin file mode bin.

- Command

```
dd if=/tmp/atenl-eeprom-phy0 of=/your/bin/file
```

```
root@OpenWrt:~# dd -h
BusyBox v1.33.2 (2023-03-04 12:09:12 UTC) multi-call binary.

Usage: dd [if=FILE] [of=FILE] [ibs=N obs=N/bs=N] [count=N] [skip=N] [seek=N]
       [conv=notrunc|noerror|sync|fsync]
       [iflag=skip_bytes|count_bytes|fullblock|direct] [oflag=seek_bytes|append|direct]

Copy a file with converting and formatting

  if=FILE          Read from FILE instead of stdin
  of=FILE          Write to FILE instead of stdout
  bs=N            Read and write N bytes at a time
  ibs=N           Read N bytes at a time
  obs=N           Write N bytes at a time
  count=N         Copy only N input blocks
  skip=N          Skip N input blocks
  seek=N          Skip N output blocks
  conv=notrunc     Don't truncate output file
  conv=noerror    Continue after read errors
  conv=sync       Pad blocks with zeros
  conv=fsync      Physically write data out before finishing
  conv=swab       Swap every pair of bytes
  iflag=skip_bytes      skip=N is in bytes
  iflag=count_bytes     count=N is in bytes
  oflag=seek_bytes      seek=N is in bytes
  iflag=direct          O_DIRECT input
  oflag=direct          O_DIRECT output
  iflag=fullblock       Read full blocks
  oflag=append          Open output in append mode

N may be suffixed by c (1), w (2), b (512), kB (1000), k (1024), MB, M, GB, G
```

## 2.3.10 Write Back Pre-cal Data to Flash

Write back values of pre-cal data (stored in the driver) to flash (mtd factory).

**Note:**

- The first command gets the pre-cal data from the driver and writes the result to "/tmp/atenl-eeprom".
- Therefore, we need the second command to write back the result to flash.

- Command

```
atenl -i phy0 -c "eeprom precal sync"
atenl -i phy0 -c "sync eeprom all"
```

## 2.3.11 Clean Pre-cal Data in Flash

Cleaning the values of pre-cal data stored in flash (mtd factory).

**Note:**

1. The first and second commands clean the Group and DPD pre-cal data in "/tmp/atenl-eeprom", respectively. Therefore, we need the third command to write back the result to flash.
2. To clean the pre-cal data stored in the mt76 driver, please refer to [Group pre-calibration](#) and [DPD pre-calibration](#).

- Command

```
atenl -i phy0 -c "eeprom precal group clean"
atenl -i phy0 -c "eeprom precal dpd clean"
atenl -i phy0 -c "sync eeprom all"
```

### 2.3.12 Sync iBF Cal Data from Driver

Sync iBF cal data in driver eeprom array to eeprom data (/tmp/atenl-eeprom).

**Note:**

1. This command is required when using mt76 command mode to perform iBF cal. mt76-test txbf [e2p\\_update](#) command **only copies iBF cal data from pfm\_data to eeprom array in driver**. Therefore, atenl eeprom data (/tmp/atenl-eeprom) will not have iBF cal result after entering mt76-test txbf e2p\_update command.
2. For mt76 HQADLL mode, this command is **not necessary**. HQA iBF phase eeprom update command would sync iBF cal data in driver eeprom array to atenl eeprom data (/tmp/atenl-eeprom). Therefore, just enter atenl -i phy0 -c "sync eeprom all" to write back to flash is fine.

- Command

```
atenl -i phy0 -c "eeprom ibf sync"
```

## 2.4 Wrapper

### 2.4.1 iwpriv Wrapper

The wrapper is a shell script placed in /usr/sbin/iwpriv. It is used to convert frequently used iwpriv ATE commands to mt76-test (or atenl for some cases). For more information, please refer to [iwpriv mapping table](#).

Note that the iwpriv wrapper supports interface name conversion for AX8400, AX7800, AX6000, AX3000, BE19000 (mt7988a + mt7996), BE14000 (mt7988d + mt7996 2 adie TBTC), BE7200 (mt7988d + mt7992), and BE5040 (mt7988d + mt7992). Therefore, you can simply enter jedi's or logan's commands.

**For Wi-Fi 7 chipsets, the iwpriv wrapper also supports translating mwctl commands to mt76-test commands.**

For debugging purposes, iwpriv wrapper provides the following command to switch the work mode of the iwpriv wrapper.

- Command

```
iwpriv ra0 set WORKMODE=<RUN/PRINT/DEBUG>
```

**Note:**

1. The value is all caps.
2. This command is "iwpriv wrapper" specific, not jedi's iwpriv command.
3. The work mode is chip specific. That is, for example AX8400, if we only set the work mode of mt7986 to "DEBUG", then mt7915 would not be in DEBUG mode.

| Argument | Description                                     | Value |
|----------|-------------------------------------------------|-------|
| WORKMODE | Default mode                                    | RUN   |
|          | Directly run the translated mt76-test commands  |       |
|          | Only print the translated mt76-test commands    | PRINT |
|          | Run and print the translated mt76-test commands | DEBUG |

### 2.4.2 ated Wrapper

The wrapper is a shell script placed in /usr/sbin/ated. It is similar to setting a symbolic link, with interface name conversion (ra0 → phy0, rax0 → phy1) and additional clean up command. For more information, please refer to [ated mapping table](#).

### 3 Example and Cross Reference

In this section, some testing examples and corresponding commands for our proprietary driver are provided.

#### 3.1 TX VHT40 MCS9 ANT1 Band0

| MT76                                                                                                                                                                                                                                                                                                                                                                                                                                                                                | Jedi/Logan                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <pre># Start testmode by enabling monitor interface iw dev phy0-ap0 del mt76-test phy0 add mon0  iw dev mon0 set channel 36 HT40+  mt76-test phy0 set tx_ipg=50 tx_rate_mode=vht tx_rate_idx=9 tx_rate_sgi=0 tx_rate_ldpc=1 tx_length=1024 tx_antenna=1 tx_count=10000000 freq_offset=42 tx_power=40,0,0,0  # (optional) check parameters mt76-test phy0 dump  # Start tx mt76-test phy0 set state=tx_frames  # Dump tx status (tx_queued, tx_done) mt76-test phy0 dump stats</pre> | <pre>iwpriv ra0 set ATE=ATESTART iwpriv ra0 set ATECTRLBANDIDX=0 iwpriv ra0 set ATEIPG=50 iwpriv ra0 set ATETXMODE=4 iwpriv ra0 set ATETXMCS=9 iwpriv ra0 set ATETXBW=1:1 iwpriv ra0 set ATETXGI=0 iwpriv ra0 set ATETXLDPC=1 iwpriv ra0 set ATETXLEN=1024 iwpriv ra0 set ATETXANT=1 iwpriv ra0 set ATERXANT=1 iwpriv ra0 set ATETXCNT=10000000 iwpriv ra0 set ATETXFREQOFFSET=42 iwpriv ra0 set ATECHANNEL=36:1 iwpriv ra0 set ATETXPOW0=40 iwpriv ra0 set ATE=TXCOMMIT iwpriv ra0 set ATE=TXFRAME</pre> |

#### 3.2 TX HE80 MCS11 ANT8 Band1

| MT76                                                                                                                                                                                                                                                                                                                                         | Jedi/Logan                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <pre>iw dev phy1-ap0 del mt76-test phy1 add mon1  iw dev mon1 set channel 40 80MHz  mt76-test phy1 set tx_ipg=50 tx_rate_mode=he_su tx_rate_idx=11 tx_rate_sgi=0 tx_ltf=1 tx_rate_ldpc=1 tx_length=4096 tx_antenna=8 tx_count=10000000 freq_offset=42 tx_power=38,0,0,0  mt76-test phy1 set state=tx_frames  mt76-test phy1 dump stats</pre> | <pre>iwpriv ra0 set ATE=ATESTART iwpriv ra0 set ATECTRLBANDIDX=1 iwpriv ra0 set ATEIPG=50 iwpriv ra0 set ATETXMODE=8 iwpriv ra0 set ATETXMCS=11 iwpriv ra0 set ATETXBW=2:2 iwpriv ra0 set ATETXGI=1 iwpriv ra0 set ATETXLDPC=1 iwpriv ra0 set ATETXLEN=4096 iwpriv ra0 set ATETXANT=8 iwpriv ra0 set ATERXANT=8 iwpriv ra0 set ATETXCNT=10000000 iwpriv ra0 set ATETXFREQOFFSET=42 iwpriv ra0 set ATECHANNEL=40:1 iwpriv ra0 set ATETXPOW0=38 iwpriv ra0 set ATE=TXCOMMIT iwpriv ra0 set ATE=TXFRAME</pre> |

### 3.3 RX VHT20 ANT3 Band0

| MT76                                                                                                                                                                                                                                                                            | Jedi/Logan                                                                                                                                                                                                                                                                                                                      |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <pre>iw dev phy0-ap0 del mt76-test phy0 add mon0  iw dev mon0 set channel 36 HT20  mt76-test phy0 set tx_rate_mode=vht tx_antenna=3 tx_rate_idx=0  # This command will also clean counters mt76-test phy0 set state=rx_frames  # Dump RX status mt76-test phy0 dump stats</pre> | <pre>iwpriv ra0 set ATE=ATESTART iwpriv ra0 set ATECTRLBANDIDX=0 iwpriv ra0 set ATETXBW=0:0 iwpriv ra0 set ATETXANT=3 iwpriv ra0 set ATERXANT=3 iwpriv ra0 set ATETXMODE=4 iwpriv ra0 set ATETXMCS=0 iwpriv ra0 set ATECHANNEL=36:1 iwpriv ra0 set ATE=RXFRAME iwpriv ra0 set ATERXSTATRESET=0 iwpriv ra0 set ATERXSTAT=0</pre> |

### 3.4 Duplicate TX

| MT76                                                                                                                                                                                                                                                                                                                                         | Jedi/Logan                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <pre>iw dev phy0-ap0 del mt76-test phy0 add mon0  iw dev mon0 set channel 36 80MHz  mt76-test phy0 set tx_ipg=50 tx_rate_mode=vht tx_rate_idx=8 tx_rate_sgi=1 tx_rate_ldpc=1 tx_rate_nss=2 tx_antenna=3 tx_length=4096 tx_count=1000000 tx_power=40,0,0,0 tx_spe_idx=24  mt76-test phy0 set state=tx_frames  mt76-test phy0 dump stats</pre> | <pre>iwpriv ra0 set ATE=ATESTART iwpriv ra0 set ATECTRLBANDIDX=0 iwpriv ra0 set ATEIPG=50 iwpriv ra0 set ATETXMODE=4 iwpriv ra0 set ATETXMCS=8 iwpriv ra0 set ATETXBW=2:2 iwpriv ra0 set ATETXGI=1 iwpriv ra0 set ATETXLDPC=1 iwpriv ra0 set ATEVHTNSS=2 iwpriv ra0 set ATETXANT=3 iwpriv ra0 set ATERXANT=3 iwpriv ra0 set ATETXLEN=4096 iwpriv ra0 set ATETXCNT=1000000 iwpriv ra0 set ATETXFREQOFFSET=42 iwpriv ra0 set ATECHANNEL=36 iwpriv ra0 set ATETXPOW0=40 iwpriv ra0 set ATETXANT=1:24 iwpriv ra0 set ATE=TXCOMMIT iwpriv ra0 set ATE=TXFRAME</pre> |



### 3.5 Continuous TX

This mode will **NOT** send normal packets, only has signal waveforms.

To leave continuous TX mode to send some normal packets again, we need to stop and start test mode.

| MT76                                                                                                                                                                                                                                                                                                                                                                                                           | Jedi/Logan                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <pre>iw dev phy0-ap0 del mt76-test phy0 add mon0  iw dev mon0 set channel 6 HT20  mt76-test phy0 set tx_rate_mode=ofdm tx_rate_idx=7 tx_count=0 tx_power=40,0,0,0 tx_antenna=1  # For mt7916, mt7981, and mt7986 mt76-test phy0 set aid=1  mt76-test phy0 set state=tx_cont  mt76-test phy0 set state=idle  mt76-test phy0 del mon0 iw phy phy0 interface add phy0-ap0 type managed ifconfig phy0-ap0 up</pre> | <pre>iwpriv ra0 set ATE=ATESTART iwpriv ra0 set ATECTRLBANDIDX=0 iwpriv ra0 set RBIST_SwitchMode=1 iwpriv ra0 set ATETXMODE=1 iwpriv ra0 set ATETXMCS=7 iwpriv ra0 set ATETXBW=0 iwpriv ra0 set ATETXCNT=0 iwpriv ra0 set ATETXPOW0=40 iwpriv ra0 set ATETXANT=1 iwpriv ra0 set ATECHANNEL=6:0 iwpriv ra0 set ATE=TXCONT iwpriv ra0 set ATE=TXCONTSTOP iwpriv ra0 set ATE=TXFRAME iwpriv ra0 set RBIST_SwitchMode=0 iwpriv ra0 set ATE=ATESTOP</pre> |

### 3.6 Pre-calibration

Take **AX8400** for example. Assume both mt7915 & mt7986 are in flash mode.

Note that `atenl -i phy1 -c "eeprom precal sync" & atenl -i phy1 -c "sync eeprom all"` could be skipped since the buffer file in atenl would be the same for dbdc chip.

| MT76                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | Jedi                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <pre># mt7915: 5G iw dev phy0-ap0 del mt76-test phy0 add mon0  mt76-test phy0 set state=group_prek mt76-test phy0 set state=dpd_5g  atenl -i phy0 -c "eeprom precal sync" atenl -i phy0 -c "sync eeprom all"  mt76-test phy0 del mon0 iw phy phy0 interface add phy0-ap0 type managed ifconfig phy0-ap0 up  # mt7986: 2G iw dev phy1-ap0 del mt76-test phy1 add mon1  mt76-test phy1 set state=group_prek mt76-test phy1 set state=dpd_6g  # Optional atenl -i phy1 -c "eeprom precal sync" atenl -i phy1 -c "sync eeprom all"</pre> | <pre># mt7915: 5G iwpriv rai0 set ATE=ATESTART iwpriv rai0 set ATE=GROUPPREK iwpriv rai0 set ATE=DPD5G ated -i rai0 -c "sync eeprom all" iwpriv rai0 set ATE=ATESTOP  # mt7986: 2G iwpriv ra0 set ATE=ATESTART iwpriv ra0 set ATE=GROUPPREK iwpriv ra0 set ATE=DPD2G ated -i ra0 -c "sync eeprom all" iwpriv ra0 set ATE=ATESTOP  # mt7986: 6G iwpriv rax0 set ATE=ATESTART iwpriv rax0 set ATE=DPD6G ated -i rax0 -c "sync eeprom all" iwpriv rax0 set ATE=ATESTOP</pre> |

| MT76                                                                                                                                                                                                                                                                                                                                                                         | Jedi |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------|
| <pre> mt76-test phy1 del mon1 iw phy phy1 interface add phy1-ap0 type managed ifconfig phy1-ap0 up  # mt7986: 6G iw dev phy2-ap0 del mt76-test phy2 add mon2  mt76-test phy2 set state=dpd_6g  aten1 -i phy2 -c "eeprom precal sync" aten1 -i phy2 -c "sync eeprom all"  mt76-test phy2 del mon2 iw phy phy2 interface add phy2-ap0 type managed ifconfig phy2-ap0 up </pre> |      |

Take BE19000 (mt7996) for **Wi-Fi 7** chipset as an example. Assume it is in flash mode. **In Wi-Fi 7, we recommend setting up all the test mode monitor interfaces before taking any actions.**

| MT76                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | Logan                                                                                                                                                                                                                                                                                                                                                            |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <pre> # Testmode interface setup iw dev phy0-ap0 del iw dev phy1-ap0 del iw dev phy2-ap0 del  ## mt7996: 2G mt76-test phy0 add mon0  ## mt7996: 5G mt76-test phy1 add mon1  ## mt7996: 6G mt76-test phy2 add mon2  # Start calibration mt76-test phy0 set state=group_prek mt76-test <b>phy0</b> set state=dpd_2g mt76-test <b>phy1</b> set state=dpd_5g mt76-test <b>phy2</b> set state=dpd_6g  # Save calibration result to flash aten1 -i phy0 -c "eeprom precal sync" aten1 -i phy0 -c "sync eeprom all"  # Testmode interface delete mt76-test phy0 del mon0 mt76-test phy1 del mon1 mt76-test phy2 del mon2 </pre> | <pre> # Testmode interface setup ## mt7996: 2G, 5G &amp; 6G at once iwpriv ra0 set ATE=ATESTART  # Start calibration iwpriv ra0 set ATE=GROUPPREK iwpriv ra0 set ATE=DPD2G iwpriv ra0 set ATE=DPD5G iwpriv ra0 set ATE=DPD6G  # Save calibration result to flash ated -i ra0 -c "sync eeprom all"  # Testmode interface delete iwpriv ra0 set ATE=ATESTOP </pre> |


## 3.7 Implicit Beamforming

The testing environment is shown below. The iBF calibration and verification can be done by the golden device or instrument such as IQxel.

There are some prerequisites that should be satisfied.

- The RX target power should be **-50dBm** with 3dBm variation only. If it is not satisfied, then calibration would fail.
  - As shown in the figure, the combiner has 6dBm loss and each cable loss is 2dBm. The TX power of instrument is fixed at -40dBm.
  - Check the DUT's RX power by [RX statistic dump](#).
  - If the RX target power is too large or too small, please add an attenuator or adjust the TX power of golden.
  - You could also check the TX power of the golden device via the following command.
 


```
cat /sys/kernel/debug/ieee80211/phyX/mt76/txpower_sku, for Wi-Fi 6, Wi-Fi 7 multi-Wiphy
cat /sys/kernel/debug/ieee80211/phy0/mt76/bandX/txpower_sku, for Wi-Fi 7 single Wiphy
```
- iBF DUT and Golden **MUST** be done within separate shielding boxes.
- Conductive calibration is necessary. Over-the-air (OTA) is not recommended.



### 3.7.1 DUT Command for Calibration with Instrument

#### 3.7.1.1 Calibration

Perform iBF calibration using the test instrument. The procedure is illustrated in the following figure.



**For TX antenna  $\leq 4$ :** (Wi-Fi 6 chipsets, mt7996, mt7992 (except BE7200 iFEM 5G))

| Step | MT76                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               | Jedi/Logan                                                                                                                                                                                                                              |
|------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 0    | <pre># Start the first channel group's group M iBF calibration &amp; verification ## For saving testing time, we only do calibration &amp; verification on group M &lt;group&gt;={     0, for 2G     1 ~ 8, for 5G     1 ~ 12, for mt7992 5G } &lt;band_idx&gt;={0, for 2G             1, for 5G } &lt;channel&gt;=group_to_chan(&lt;group&gt;) &lt;MCS&gt;={15 + 8 * (n<sub>ss</sub> - 2), 1 &lt; n<sub>ss</sub> ≤ 4        31, otherwise } &lt;wlan_idx&gt;={1, otherwise             2, mt7996 / mt7992 5G } &lt;ver&gt;={0, otherwise iBF 1.0        3, mt7992 iBF 2.0 }</pre> |                                                                                                                                                                                                                                         |
| 1    | <pre># Start iBF TX Calibration iw dev phy0-ap0 del mt76-test phy0 add mon0 mt76-test phy0 set txbf_act=init txbf_param=1</pre>                                                                                                                                                                                                                                                                                                                                                                                                                                                    | <pre># Start iBF TX Calibration iwpriv ra0 set ATE=ATESTART ## Skip it for Wi-Fi 7 iwpriv ra0 set ATECTRLBANDIDX=&lt;band_idx&gt; iwpriv ra0 set ATETxBfInit=&lt;band_idx&gt;</pre>                                                     |
| 2    | <pre># Group 0 ~ 8 iw dev mon0 set channel &lt;channel&gt; # Group 9 ~ 12 (only for iBF 2.0) ## Use CBW 160 DBW 20 mt76-test phy1 set tx_pkt_bw=20 tx_pri_sel=4 iw dev mon1 set channel &lt;channel&gt; 160MHz</pre>                                                                                                                                                                                                                                                                                                                                                               | <pre># Group 0 ~ 8 iwpriv ra0 set ATECHANNEL=&lt;channel&gt;:&lt;band_idx&gt; # Group 9 ~ 12 (only for iBF 2.0) ## Use CBW 160 DBW 20 iwpriv rai0 set ATETXBW=5:0 iwpriv rai0 set ATECHANNEL=&lt;channel&gt;:&lt;band_idx&gt;:4:0</pre> |
| 3    | <pre># Clear compensated TX/RX phases mt76-test phy0 set txbf_act=phase_comp txbf_param=0,&lt;band_idx&gt;,&lt;group&gt;,0,1 aid=1</pre>                                                                                                                                                                                                                                                                                                                                                                                                                                           | <pre># Clear compensated TX/RX phases iwpriv ra0 set ATEIBFPhaseComp=00:&lt;band_idx&gt;:&lt;group&gt;:00:01</pre>                                                                                                                      |

| Step | MT76                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       | Jedi/Logan                                                                                                                                                                                                                                                                                                                                                    |
|------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 4    | <pre># Configure eBF PFMU profile for channel update mt76-test phy0 set txbf_act=ebf_prof_update txbf_param=1,3,0 # Prepare for TX mt76-test phy0 set tx_rate_idx=&lt;MCS&gt; mt76-test phy0 set txbf_act=apply_tx txbf_param=&lt;wlan_idx&gt;,1,0,0,1 # Configure BF TXCMD (only Wi-Fi 7 required) mt76-test phy0 set txbf_act=txcmd txbf_param=1,1,1 mt76-test phy0 set txbf_act=tx_prep txbf_param=0,1,&lt;wlan_idx&gt;,0 mt76-test phy0 set aid=1 tx_count=10000000 tx_length=1024 # Start TX mt76-test phy0 set state=tx_frames</pre> | <pre># Configure eBF PFMU profile for channel update iwpriv ra0 set ATEEBfProfileConfig=01:03:00 # Prepare and start TX iwpriv ra0 set ATETXMCS=&lt;MCS&gt; iwpriv ra0 set TxBfTxApply=&lt;wlan_idx&gt;:01:00:00:01 # Configure BF TXCMD (only Wi-Fi 7 required) iwpriv ra0 set TxBfTxCmd=1:1:1 iwpriv ra0 set ATETxPacketWithBf=00:&lt;wlan_idx&gt;:00</pre> |
| 5    | # Instrument start to calculate channel profile                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |                                                                                                                                                                                                                                                                                                                                                               |
| 6    | <pre># Stop TX mt76-test phy0 set state=idle</pre>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         | <pre># Stop TX iwpriv ra0 set ATETxPacketWithBf=00:&lt;wlan_idx&gt;:01</pre>                                                                                                                                                                                                                                                                                  |
| 7    | <pre># Instrument writes channel profile to DUT mt76-test phy0 set txbf_act=prof_update_all txbf_param=01,f0 mt76-test phy0 set txbf_act=prof_update_all txbf_param=00,0000,0000,0000,0000,... mt76-test phy0 set txbf_act=prof_update_all txbf_param=01,ff</pre>                                                                                                                                                                                                                                                                          | <pre># Instrument writes channel profile to DUT iwpriv ra0 set TxBfProfileData20MAllWrite=01:F0 iwpriv ra0 set TxBfProfileData20MAllWrite= 00:0000:0000:0000:0000: 01:0000:0000:0000:0000... iwpriv ra0 set TxBfProfileData20MAllWrite= 08:035f:0322:0031:00f2:09:0337:0312:007c:00af... ... iwpriv ra0 set TxBfProfileData20MAllWrite=01:FF</pre>            |
| 8    | <pre># Configure iBF PFMU profile for channel update mt76-test phy0 set txbf_act=ibf_prof_update txbf_param=2,3,0</pre>                                                                                                                                                                                                                                                                                                                                                                                                                    | <pre># Configure iBF PFMU profile for channel update iwpriv ra0 set ATEIBfProfileConfig=02:03:00</pre>                                                                                                                                                                                                                                                        |
| 9    | <pre># Enable DUT's RX mt76-test phy0 set state=rx_frames</pre>                                                                                                                                                                                                                                                                                                                                                                                                                                                                            | <pre># Enable DUT's RX iwpriv ra0 set ATE=RXFRAME</pre>                                                                                                                                                                                                                                                                                                       |
|      | # Instrument start to TX packet to DUT (OFDM 54M)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |                                                                                                                                                                                                                                                                                                                                                               |
| 10   | <pre># Enable iBF RX mt76-test phy0 set txbf_act=apply_tx txbf_param=&lt;wlan_idx&gt;,0,1,0,1 # Start to do the iBF phase calibration mt76-test phy0 set txbf_act=phase_cal txbf_param=&lt;group&gt;,1,&lt;band_idx&gt;,3,1,&lt;ver&gt;</pre>                                                                                                                                                                                                                                                                                              | <pre># Enable iBF RX iwpriv ra0 set TxBfTxApply=&lt;wlan_idx&gt;:00:01:00:01 # Start to do the iBF phase calibration iwpriv ra0 set ATEIBfInstCal=&lt;group&gt;:01:&lt;band_idx&gt;:03:01:&lt;ver&gt;</pre>                                                                                                                                                   |

**For 5T5R 4SS (mt7992 BE7200 iFEM 5G band):**


To support 5T5R iBF, the DUT is required to transmit a 5x5 iBF profile to the instrument for calibration. However, the chip only supports 4 spatial streams (SS), so the packet needs to be transmitted twice with different TX antenna settings to enable the instrument to combine these two 4x4 iBF profiles into a 5x5 iBF profile. As a result, the **iBF commands for chips supporting 5T5R 4SS differ from those for other chips.**

| Step | MT76                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              | Logan                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 0    | <pre># Start the first channel group's group M iBF calibration &amp; verification ## For saving testing time, we only do calibration &amp; verification on group M &lt;group&gt;=1 ~ 12 &lt;band_idx&gt;=1 &lt;channel&gt;=<a href="#">group to chan</a>(&lt;group&gt;) &lt;wlan_idx&gt;=2 &lt;ver&gt;=3</pre>                                                                                                                                                                                                                    |                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| 1    | <pre># Start iBF TX Calibration iw dev phy1-ap0 del mt76-test phy1 add mon1 mt76-test phy1 set txbf_act=init txbf_param=1</pre>                                                                                                                                                                                                                                                                                                                                                                                                   | <pre># Start iBF TX Calibration iwpriv rai0 set ATE=ATESTART iwpriv rai0 set ATETxBfInit=&lt;band_idx&gt;</pre>                                                                                                                                                                                                                                                                                                                                |
| 2    | <pre>mt76-test phy1 set tx_antenna=31 tx_rate_nss=4 # For group 1 ~ 8 iw dev mon1 set channel &lt;channel&gt; # For group 9 ~ 12 ## Use CBW 160 DBW 20 mt76-test phy1 set tx_pkt_bw=20 tx_pri_sel=4 iw dev mon1 set channel &lt;channel&gt; 160MHz</pre>                                                                                                                                                                                                                                                                          | <pre>iwpriv rai0 set ATETXNSS=4 iwpriv rai0 set ATETXANT=31 # For group 1 ~ 8 iwpriv rai0 set ATECHANNEL=&lt;channel&gt;:&lt;band_idx&gt; # For group 9 ~ 12 ## Use CBW 160 DBW 20 iwpriv rai0 set ATETXBW=5:0 iwpriv rai0 set ATECHANNEL=&lt;channel&gt;:&lt;band_idx&gt;:4:0</pre>                                                                                                                                                           |
| 3    | <pre># Unstable Tx power caused by GT switching can be avoided by fixing pre-GT (only required for 7977 Adie) echo 0x8318FD30 &gt; /sys/kernel/debug/ieee80211/phy0/mt76/regidx echo 0 &gt; /sys/kernel/debug/ieee80211/phy0/mt76/regval # Clear compensated TX/RX phases mt76-test phy1 set txbf_act=phase_comp txbf_param=0,&lt;band_idx&gt;,&lt;group&gt;,0,1 aid=1</pre>                                                                                                                                                      | <pre># Unstable Tx power caused by GT switching can be avoided by fixing pre-GT (only required for 7977 Adie) mwctl phy phy0 mac 8318FD30=0 # Clear compensated TX/RX phases iwpriv rai0 set ATEIBFPhaseComp=00:&lt;band_idx&gt;:&lt;group&gt;:00:01</pre>                                                                                                                                                                                     |
| 4    | <pre># Configure eBF PFMU profile for channel update mt76-test phy1 set txbf_act=ebf_prof_update txbf_param=1,4,0  # Prepare for the first TX mt76-test phy1 set tx_antenna=23 tx_rate_nss=4 mt76-test phy1 set txbf_act=apply_tx txbf_param=&lt;wlan_idx&gt;,1,0,0,1 # Configure BF TXCMD mt76-test phy1 set txbf_act=txcmd txbf_param=1,1,1 mt76-test phy1 set txbf_act=tx_prep txbf_param=0,1,&lt;wlan_idx&gt;,0 mt76-test phy1 set aid=1 tx_count=10000000 tx_length=1024 # Start TX mt76-test phy1 set state=tx_frames</pre> | <pre># Configure eBF PFMU profile for channel update iwpriv rai0 set ATEEBfProfileConfig=01:04:00  # Prepare and start the first TX iwpriv rai0 set ATETXNSS=4 iwpriv rai0 set ATETXANT=23 ## Start TX commit, not necessary mwctl rai0 set HQA=SetTestEng=0x1,18 iwpriv rai0 set TxBfTxApply=&lt;wlan_idx&gt;:01:00:00:01 # Configure BF TXCMD iwpriv rai0 set TxBfTxCmd=1:1:1 iwpriv rai0 set ATETxPacketWithBf=00:&lt;wlan_idx&gt;:00</pre> |

| Step | MT76                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                | Logan                                                                                                                                                                                                                                                                                                                                                                                                                             |
|------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 5    | <pre># Unstable Tx power caused by GT switching can be avoided by fixing pre-GT (only required for 7977 Adie) echo 0x8318FD30 &gt; /sys/kernel/debug/ieee80211/phy0/mt76/regidx echo 0 &gt; /sys/kernel/debug/ieee80211/phy0/mt76/regval # Prepare for the second TX mt76-test phy1 set tx_antenna=27 tx_rate_nss=4 mt76-test phy1 set txbf_act=apply_tx txbf_param=&lt;wlan_idx&gt;,1,0,0,1 mt76-test phy1 set txbf_act=txcmd txbf_param=1,1,1 mt76-test phy1 set txbf_act=tx_prep txbf_param=0,1,&lt;wlan_idx&gt;,0 mt76-test phy1 set aid=1 tx_count=10000000 tx_length=1024 # Start TX mt76-test phy1 set state=tx_frames</pre> | <pre># Unstable Tx power caused by GT switching can be avoided by fixing pre-GT (only required for 7977 Adie) mwctl phy phy0 mac 8318FD30=0 # Prepare for the second TX iwpriv rai0 set ATETXNSS=4 iwpriv rai0 set ATETXANT=27 # Start the second TX iwpriv rai0 set TxBFTxApply=&lt;wlan_idx&gt;:01:00:00:01 # Configure BF TXCMD iwpriv rai0 set TxBFTxCmd=1:1:1 iwpriv rai0 set ATETxPacketWithBf=00:&lt;wlan_idx&gt;:00</pre> |
| 6    | # Instrument start to calculate channel profile                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| 7    | <pre># Stop TX mt76-test phy1 set state=idle</pre>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | <pre># Stop TX iwpriv rai0 set ATETxPacketWithBf=00:&lt;wlan_idx&gt;:01</pre>                                                                                                                                                                                                                                                                                                                                                     |
| 8    | <pre># Instrument writes channel profile to DUT ## 5 angle tuple for each subcarrier mt76-test phy1 set txbf_act=prof_update_all txbf_param=01,f0 mt76-test phy1 set txbf_act=prof_update_all txbf_param=00,0000,0000,0000,0000,0000,01,... mt76-test phy1 set txbf_act=prof_update_all txbf_param=01,ff</pre>                                                                                                                                                                                                                                                                                                                      | <pre># Instrument writes channel profile to DUT ## 5 angle tuple for each subcarrier iwpriv rai0 set TxBfProfileData20MAllWrite=01:F0 iwpriv rai0 set TxBfProfileData20MAllWrite= 00:0000:0000:0000:0000:0000:01:0000:0000:0000:0000... iwpriv rai0 set TxBfProfileData20MAllWrite= 08:00ac:03b0:00a5:068b:033d:09:0094:0397:008d:0272:0324... iwpriv rai0 set TxBfProfileData20MAllWrite=01:FF</pre>                             |
| 9    | <pre># Enable DUT's RX mt76-test phy1 set tx_antenna=31 mt76-test phy1 set state=rx_frames</pre>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    | <pre># Enable DUT's RX iwpriv rai0 set ATETXANT=31 iwpriv rai0 set ATE=RXFRAME</pre>                                                                                                                                                                                                                                                                                                                                              |
| 10   | <pre># Configure iBF PFMU profile for channel update mt76-test phy1 set txbf_act=ibf_prof_update txbf_param=2,4,0</pre>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | <pre># Configure iBF PFMU profile for channel update iwpriv rai0 set ATEIBfProfileConfig=02:04:00</pre>                                                                                                                                                                                                                                                                                                                           |
|      | # Instrument start to TX packet to DUT                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| 11   | <pre># Enable iBF RX mt76-test phy1 set txbf_act=apply_tx txbf_param=&lt;wlan_idx&gt;,0,1,0,1 # Start to do the iBF phase calibration mt76-test phy1 set txbf_act=phase_cal txbf_param=&lt;group&gt;,1,&lt;band_idx&gt;,3,1,&lt;ver&gt;</pre>                                                                                                                                                                                                                                                                                                                                                                                       | <pre># Enable iBF RX iwpriv rai0 set TxBFTxApply=&lt;wlan_idx&gt;:00:01:00:01 # Start to do the iBF phase calibration iwpriv rai0 set ATEIBfInstCal=&lt;group&gt;:01:&lt;band_idx&gt;:03:01:&lt;ver&gt;</pre>                                                                                                                                                                                                                     |

### 3.7.1.2 Verification

Verify the calibrated iBF data through iBF gain with the test instrument, and the procedure is shown in the following figure. Note that the verification result is unaffected by the order of non-BF TX and BF-TX.



**For TX antenna ≤ 4:** (Wi-Fi 6 chipsets, mt7996, mt7992 (except BE7200 iFEM 5G))

| Step | MT76                                                                                                                                                                                                                     | Jedi/Logan                                                                                                                                                                              |
|------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1    | # Start iBF TX Verification<br># Compensate TX / RX phase<br># <bf_on>={0, for group 0 ~ 8<br>3, for group 9 ~ 12<br>mt76-test phy0 set txbf_act=phase_comp<br>txbf_param=<bf_on>,<band_idx>,<group>,0,0 aid=1           | # Start iBF TX Verification<br># Compensate TX / RX phase<br># <bf_on>={0, for group 0 ~ 8<br>3, for group 9 ~ 12<br>iwpriv ra0 set<br>ATEIBFPhaseComp=<bf_on>:<band_idx>:<group>:00:00 |
| 2    | # Enable DUT's RX<br>mt76-test phy0 set state=rx_frames<br># Instrument start to TX packet (OFDM 54M)                                                                                                                    | # Enable DUT's RX<br>iwpriv ra0 set ATE=RXFRAME<br># Instrument start to TX packet (OFDM 54M)                                                                                           |
| 3    | # Set MCS rate<br>mt76-test phy0 set tx_rate_idx=4<br># Start BF TX<br>mt76-test phy0 set txbf_act=tx_prep<br>txbf_param=1,1,<wlan_idx>,0 aid=1<br>tx_count=1000000 tx_length=1024<br>mt76-test phy0 set state=tx_frames | # Set MCS rate<br>iwpriv ra0 set ATETXMCS=4<br># Start BF TX<br>iwpriv ra0 set ATETxPacketWithBf=01:<wlan_idx>:00                                                                       |
| 4    | # Instrument start to measure the averaged power of BF TX (P <sub>BF</sub> )                                                                                                                                             |                                                                                                                                                                                         |
| 5    | # Start non-BF TX<br>mt76-test phy0 set txbf_act=tx_prep<br>txbf_param=0,1,<wlan_idx>,0 aid=1<br>tx_count=1000000 tx_length=1024<br>mt76-test phy0 set state=tx_frames                                                   | # Start non-BF TX<br>iwpriv ra0 set ATETxPacketWithBf=00:<wlan_idx>:00                                                                                                                  |



| Step | MT76                                                                                                                                                                                                                         | Jedi/Logan                                                                                                                                                              |
|------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 6    | # Instrument start to measure the averaged power of non-BF TX (P_NBF)                                                                                                                                                        |                                                                                                                                                                         |
| 7    | # Stop DUT's TX<br>mt76-test phy0 set state=idle<br><br># Instrument calculates iBF gain via P_BF - P_NBF, it should be > 10 dB for 4x4 AP to 1x1 STA                                                                        | # Stop DUT's TX<br>iwpriv ra0 set ATE=TXSTOP                                                                                                                            |
| 8    | # Write the calibrated phases of groups into eeprom<br>mt76-test phy0 set txbf_act=e2p_update<br>txbf_param=0,0,1<br>atenl -i phy0 -c "eeprom ibf sync"<br># Write the result to flash<br>atenl -i phy0 -c "sync eeprom all" | # Write the calibrated phases of groups into eeprom<br>iwpriv ra0 set ATEIBFPhaseE2pUpdate=00:00:01<br># Write the result to flash<br>ated -i phy0 -c "sync eeprom all" |

#### For 5T5R 4SS (mt7992 BE7200 iFEM 5G band):


| Step | MT76                                                                                                                                                                                                                                                                                                                                                                                                        | Jedi/Logan                                                                                                                                                                                                                    |
|------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1    | # Start iBF TX Verification<br># Compensate TX / RX phase<br># <bf_on>={0, for group 0 ~ 8<br>{3, for group 9 ~ 12<br>mt76-test phy1 set txbf_act=phase_comp<br>txbf_param=<bf_on>,<band_idx>,<group>,0,0 aid=1                                                                                                                                                                                             | # Start iBF TX Verification<br># Compensate TX / RX phase<br># <bf_on>={0, for group 0 ~ 8<br>{3, for group 9 ~ 12<br>iwpriv rai0 set<br>ATEIBFPhaseComp=<bf_on>:<band_idx>:<group>:00:00                                     |
| 2    | # Enable DUT's RX<br>mt76-test phy1 set state=rx_frames<br># Instrument start to TX packet (OFDM 54M)                                                                                                                                                                                                                                                                                                       | # Enable DUT's RX<br>iwpriv rai0 set ATE=RXFRAME<br># Instrument start to TX packet (OFDM 54M)                                                                                                                                |
| 3    | # Set MCS rate & NSS<br>mt76-test phy1 set tx_rate_idx=4 tx_rate_nss=1<br># Start BF TX<br>mt76-test phy1 set txbf_act=tx_prep<br>txbf_param=1,1,<wlan_idx>,0 aid=1<br>tx_count=1000000 tx_length=1024<br>mt76-test phy1 set state=tx_frames<br># Stop BF TX<br>mt76-test phy1 set txbf_act=tx_prep<br>txbf_param=1,1,<wlan_idx>,0 aid=1 tx_count=1<br>tx_length=1024<br>mt76-test phy1 set state=tx_frames | # Set MCS rate & NSS<br>iwpriv rai0 set ATETXMCS=4<br>iwpriv rai0 set ATETXNSS=1<br># Start BF TX<br>iwpriv rai0 set ATETxPacketWithBf=01:<wlan_idx>:00<br># Stop BF TX<br>iwpriv rai0 set ATETxPacketWithBf=00:<wlan_idx>:01 |
| 4    | # Instrument start to measure the averaged power of BF TX (P_BF)                                                                                                                                                                                                                                                                                                                                            |                                                                                                                                                                                                                               |
| 5    | # Start non-BF TX<br>mt76-test phy1 set tx_antenna=1<br>mt76-test phy1 set txbf_act=tx_prep<br>txbf_param=0,1,<wlan_idx>,0 aid=1<br>tx_count=1000000 tx_length=1024<br>mt76-test phy1 set state=tx_frames<br># Stop non-BF TX<br>mt76-test phy1 set txbf_act=tx_prep<br>txbf_param=0,1,<wlan_idx>,0 aid=1 tx_count=1<br>tx_length=1024<br>mt76-test phy1 set state=tx_frames                                | # Start non-BF TX<br>iwpriv rai0 set ATETXANT=1<br>iwpriv rai0 set ATETxPacketWithBf=00:<wlan_idx>:00<br># Stop non-BF TX<br>iwpriv rai0 set ATETxPacketWithBf=00:<wlan_idx>:01                                               |
| 6    | # Instrument start to measure the averaged power of non-BF TX (P_NBF)                                                                                                                                                                                                                                                                                                                                       |                                                                                                                                                                                                                               |
| 7    | # Stop DUT's TX<br>mt76-test phy1 set state=idle<br><br># Instrument calculates iBF gain via P_BF - P_NBF, it should be > 10 dB for 4x4 AP to 1x1 STA                                                                                                                                                                                                                                                       | # Stop DUT's TX<br>iwpriv rai0 set ATE=TXSTOP                                                                                                                                                                                 |

| Step | MT76                                                                                                                                                                                                                     | Jedi/Logan                                                                                                                                                                 |
|------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 8    | <pre># Write the calibrated phases of groups into eeprom mt76-test phy1 set txbf_act=e2p_update txbf_param=0,0,1 atenl -i phy0 -c "eeprom ibf sync" # Write the result to flash atenl -i phy0 -c "sync eeprom all"</pre> | <pre># Write the calibrated phases of groups into eeprom iwpriv rai0 set ATEIBFPhaseE2pUpdate=00:00:01 # Write the result to flash ated -i phy0 -c "sync eeprom all"</pre> |

### 3.7.2 DUT Command for Calibration with Golden

#### 3.7.2.1 Calibration and Verification

Do iBF calibration with the golden device, and the procedure is shown in the following figure (orange for Golden, blue for DUT, and white for common). This test procedure is a template suitable for different channel bands and chips. **Note that please use the proprietary driver for the golden device.**



| Step | MT76                                                                                                                                                                                                                                                                                                                                                                             | Jedi/Logan |
|------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------|
| 0    | <pre># Start the first channel group's group M iBF calibration &amp; verification ## For saving testing time, we only do calibration &amp; verification on group M &lt;group&gt;={ 0, for 2G           1 ~ 8, for 5G &lt;band_idx&gt;={0, for 2G             1, for 5G &lt;channel&gt;=group to chan(&lt;group&gt;) &lt;wlan_idx&gt;={1, otherwise             2, Eagle 5G</pre> |            |

| Step                                       | MT76                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               | Jedi/Logan                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|--------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1                                          | <pre># DUT init iw dev phy0-ap0 del mt76-test phy0 add mon0 mt76-test phy0 set txbf_act=init txbf_param=1 mt76-test phy0 set aid=1 ## Set channel iw dev mon0 set channel &lt;channel&gt; HT20</pre>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               | <pre># DUT init iwpriv ra0 set ATE=ATESTART ## This CR is chip dependent, we handle it in mt76 and iwpriv wrapper. Not required in mt76 anymore. iwpriv ra0 mac 820E3030=301 ## DUT init iwpriv ra0 set ATETxBfInit=&lt;band_idx&gt; ## Set channel iwpriv ra0 set ATECHANNEL=&lt;channel&gt;:&lt;band_idx&gt;</pre>                                                                                                                                                                                                                                                                                                                                                                                   |
| 2                                          | <pre># Please use proprietary driver</pre>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         | <pre># Golden device init iwpriv ra0 set ATE=ATESTART iwpriv ra0 set ATETxBfGdInit=&lt;band_idx&gt; ## Set channel iwpriv ra0 set ATECHANNEL=&lt;channel&gt;:&lt;band&gt; iwpriv ra0 set ATE=RXFRAME ## Not required in mt76 iwpriv ra0 ATETXCNT=1 iwpriv ra0 set ATE=TXFRAME</pre>                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 3                                          | <pre># Clear compensated TX/RX phases mt76-test phy0 set txbf_act=phase_comp txbf_param=0,&lt;band_idx&gt;,&lt;group&gt;,0,1 # Enable DUT's RX mt76-test phy0 set state=rx_frames # eBF profile configuration mt76-test phy0 set txbf_act=ebf_prof_update txbf_param=1,3,0 # Apply eBF profile mt76-test phy0 set txbf_act=apply_tx txbf_param=&lt;wlan_idx&gt;,1,0,0,1 # Configure BF TXCMD (only Wi-Fi 7 is required) mt76-test phy0 set txbf_act=txcmd txbf_param=1,1,1 # Trigger sounding mt76-test phy0 set txbf_act=trigger_sounding txbf_param=2,1,0c,&lt;wlan_idx&gt;,0,0,0 # Stop sounding after 1 sec mt76-test phy0 set txbf_act=stop_sounding txbf_param=0 # iBF profile configuration mt76-test phy0 set txbf_act=ibf_prof_update txbf_param=2,3,0 # Apply iBF profile mt76-test phy0 set txbf_act=apply_tx txbf_param=&lt;wlan_idx&gt;,0,1,0,1</pre> | <pre># Clear compensated TX/RX phases iwpriv ra0 set ATEIBFPhaseComp=00:&lt;band_idx&gt;:&lt;group&gt;:00:01 # Enable DUT's RX iwpriv ra0 set ATE=RXFRAME # eBF profile configuration iwpriv ra0 set ATEEBfProfileConfig=01:03:00 # Apply eBF profile iwpriv ra0 set TxBfTxApply=&lt;wlan_idx&gt;:01:00:00:01 # Configure BF TXCMD (only Wi-Fi 7 is required) iwpriv ra0 set TxBfTxCmd=1:1:1 # Trigger sounding iwpriv ra0 set TriggerSounding=02:01:0C: &lt;wlan_idx&gt;:00:00:00 # Stop sounding after 1 sec iwpriv ra0 set StopSounding=1 # iBF profile configuration iwpriv ra0 set ATEIBfProfileConfig=02:03:00 # Apply iBF profile iwpriv ra0 set TxBfTxApply=&lt;wlan_idx&gt;:00:01:00:01</pre> |
| 3-1<br>Sounding<br>golden<br>debug<br>step | <pre># Please use proprietary driver</pre>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         | <pre># Check Bfee RX NDP &amp; trigger BFRP (for debugging) iwpriv ra0 mac \${BFEE_RX_NDP_ADDR} # Check Bfee RX NDPA &amp; TX feedback report (for debugging) iwpriv ra0 mac \${BFEE_RX_NDPA_ADDR}</pre>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| 3-2<br>Sounding<br>DUT<br>debug<br>step    | <pre># Check Bfer RX feedback report counter (for debugging) echo \${BFER_RX_FBK_ADDR} &gt; /sys/kernel/debug/ieee80211/phy0/mt76/regidx cat /sys/kernel/debug/ieee80211/phy0/mt76/regval # Check eBF profile if not receiving feedback mt76-test phy0 set txbf_act=pfm_tag_read txbf_param=1,1</pre>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              | <pre># Check Bfer RX feedback report counter (for debugging) iwpriv ra0 mac \${BFER_RX_FBK_ADDR} # Check eBF profile if not receiving feedback iwpriv ra0 set TxBfProfileTagRead=01:01 # Check iBF profile if not receiving feedback iwpriv ra0 set TxBfProfileTagRead=02:01 # Check BF station record if not receiving feedback</pre>                                                                                                                                                                                                                                                                                                                                                                 |

| Step                 | MT76                                                                                                                                                                                                                                                        | Jedi/Logan                                                                                                                                                                                                 |
|----------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                      | <pre># Check iBF profile if not receiving feedback mt76-test phy0 set txbf_act=pfmu_tag_read txbf_param=2,1 # Check BF station record if not receiving feedback mt76-test phy0 set txbf_act=sta_rec_read txbf_param=1</pre>                                 | <pre>iwpriv ra0 set StaRecBfRead=01</pre>                                                                                                                                                                  |
| 4                    | <pre># Please use proprietary driver</pre>                                                                                                                                                                                                                  | <pre># Golden start continuous TX ## Set TX count to a large number iwpriv ra0 set ATETXCNT=0 ## Set golden's TX power if required (iwpriv ra0 set ATETXP0W0=&lt;val&gt;) iwpriv ra0 set ATE=TXFRAME</pre> |
| 4-1<br>debug<br>step | <pre># Check Bfer TX packet applied iBF counter echo <a href="#">\${BF_APP_CNT_ADDR}</a> &gt; /sys/kernel/debug/ieee80211/phy0/mt76/regidx cat /sys/kernel/debug/ieee80211/phy0/mt76/regval # If counter is counting, then try \${BF_NOT_APP_REASON}</pre>  | <pre># Check Bfer TX packet applied iBF counter iwpriv ra0 mac <a href="#">\${BF_APP_CNT_ADDR}</a> # If counter is counting, then try \${BF_NOT_APP_REASON}</pre>                                          |
| 5                    | <pre># Phase calibration mt76-test phy0 set txbf_act=phase_cal txbf_param=&lt;group&gt;,1,&lt;band_idx&gt;,1</pre>                                                                                                                                          | <pre># Phase calibration iwpriv ra0 set ATEIBfGdCal=&lt;group&gt;:01:&lt;band_idx&gt;:01</pre>                                                                                                             |
| 6                    | <pre># Phase verification ## Phase compensation mt76-test phy0 set txbf_act=phase_comp txbf_param=1,&lt;band_idx&gt;,&lt;group&gt;,0,0 ## Phase verification mt76-test phy0 set txbf_act=phase_cal txbf_param=&lt;group&gt;,1,&lt;band_idx&gt;,2,1</pre>    | <pre># Phase verification iwpriv ra0 set ATEIBFPhaseVerify=&lt;group&gt;:01:&lt;band_idx&gt;:02:01:00</pre>                                                                                                |
| 7                    | <pre># Please use proprietary driver</pre>                                                                                                                                                                                                                  | <pre># Stop golden's TX iwpriv ra0 set ATE=TXSTOP</pre>                                                                                                                                                    |
| 8                    | <pre># Move on to the iBF calibration for the next group or stop the procedure if all groups are done &lt;group&gt;=&lt;group&gt;+1 &lt;channel&gt;=<a href="#">group_to_chan</a>(&lt;group&gt;) # Back to the channel setting part in step 1 &amp; 2</pre> |                                                                                                                                                                                                            |
| 9                    | <pre># Write the calibrated phases of groups into eeprom mt76-test phy0 set txbf_act=e2p_update txbf_param=0,0,1 atenl -i phy0 -c "eeprom ibf sync" # Write the result to flash atenl -i phy0 -c "sync eeprom all"</pre>                                    | <pre># Write the calibrated phases of groups into eeprom iwpriv ra0 set ATEIBFPhaseE2pUpdate=00:00:01 # Write the result to flash ated -i phy0 -c "sync eeprom all"</pre>                                  |

### 3.7.3 iBF Calibration Channel Group

In the iBF calibration and verification test, we would not calibrate and verify all channels due to testing time and cost constraints. Instead, we classify the channel into several channel groups and select the **median channel** (this can be changed by setting the group L, M, and H in phase calibration) to represent the entire group. According to the RF test, the BF gain loss of the boundary channel in each channel group is no more than 0.5 dBm.

**Note that the 5G channel group differs for Wi-Fi 6 and Wi-Fi 7 chipsets.**

**Wi-Fi 6 chipset (mt7915, mt7916, mt7981, mt7986):**

| Channel Group |   | Group Range                                             | Calibrated Channel | Frequency (Unit: MHz) | EEPROM Address             |                |
|---------------|---|---------------------------------------------------------|--------------------|-----------------------|----------------------------|----------------|
| 2G            | 0 | Channel: [1, 14]<br>Frequency: [2412, 2484]             | 8                  | 2447                  | iPA + iLNA<br>(Adie: 7975) | [0x651, 0x678] |
|               |   |                                                         |                    |                       | ePA + eLNA<br>(Adie: 7976) | [0x60A, 0x631] |
| 5G            | 1 | Channel: [184, 196] & [8,16]<br>Frequency: [4920, 5080] | 196                | 4980                  | iPA + iLNA<br>(Adie: 7975) | [0x679, 0x6A0] |
|               |   |                                                         |                    |                       | ePA + eLNA<br>(Adie: 7976) | [0x632, 0x659] |
|               | 2 | Channel: [36, 48]<br>Frequency: [5180, 5240]            | 44                 | 5220                  | iPA + iLNA<br>(Adie: 7975) | [0x6A1, 0x6C8] |
|               |   |                                                         |                    |                       | ePA + eLNA<br>(Adie: 7976) | [0x65A, 0x681] |
|               | 3 | Channel: [52, 68]<br>Frequency: [5260, 5340]            | 60                 | 5300                  | iPA + iLNA<br>(Adie: 7975) | [0x6C9, 0x6F0] |
|               |   |                                                         |                    |                       | ePA + eLNA<br>(Adie: 7976) | [0x682, 0x6A9] |
|               | 4 | Channel: [72, 92]<br>Frequency: [5360, 5460]            | 84                 | 5420                  | iPA + iLNA<br>(Adie: 7975) | [0x6F1, 0x718] |
|               |   |                                                         |                    |                       | ePA + eLNA<br>(Adie: 7976) | [0x6AA, 0x6D1] |
|               | 5 | Channel: [96, 112]<br>Frequency: [5480, 5560]           | 104                | 5520                  | iPA + iLNA<br>(Adie: 7975) | [0x719, 0x740] |
|               |   |                                                         |                    |                       | ePA + eLNA<br>(Adie: 7976) | [0x6D2, 0x6F9] |
|               | 6 | Channel: [116, 136]<br>Frequency: [5580, 5680]          | 124                | 5620                  | iPA + iLNA<br>(Adie: 7975) | [0x741, 0x768] |
|               |   |                                                         |                    |                       | ePA + eLNA<br>(Adie: 7976) | [0x6FA, 0x721] |
|               | 7 | Channel: [140, 157]<br>Frequency: [5700, 5785]          | 149                | 5745                  | iPA + iLNA<br>(Adie: 7975) | [0x769, 0x790] |
|               |   |                                                         |                    |                       | ePA + eLNA<br>(Adie: 7976) | [0x722, 0x749] |
|               | 8 | Channel: [161, 181]<br>Frequency: [5805, 5905]          | 173                | 5865                  | iPA + iLNA<br>(Adie: 7975) | [0x791, 0x7B8] |
|               |   |                                                         |                    |                       | ePA + eLNA<br>(Adie: 7976) | [0x74A, 0x771] |

**Wi-Fi 7 iBF 1.0 (mt7996):**

| Channel Group |   | Group Range                                  | Calibrated Channel | Frequency (Unit: MHz) | EEPROM Address |
|---------------|---|----------------------------------------------|--------------------|-----------------------|----------------|
| 2G            | 0 | Channel: [1, 14]<br>Frequency: [2412, 2484]  | 8                  | 2447                  | [0xC00, 0xC2D] |
| 5G            | 1 | Channel: [36, 48]<br>Frequency: [5180, 5240] | 44                 | 5220                  | [0xC2E, 0xC5B] |
|               | 2 | Channel: [52, 64]<br>Frequency: [5260, 5320] | 60                 | 5300                  | [0xC5C, 0xC89] |
|               | 3 | Channel: [68, 96]                            | 84                 | 5420                  | [0xC8A, 0xCB7] |

| Channel Group |   | Group Range                                    | Calibrated Channel | Frequency (Unit: MHz) | EEPROM Address |
|---------------|---|------------------------------------------------|--------------------|-----------------------|----------------|
|               |   | Frequency: [5340, 5480]                        |                    |                       |                |
|               | 4 | Channel: [100, 112]<br>Frequency: [5500, 5560] | 104                | 5520                  | [0xCB8, 0xCE5] |
|               | 5 | Channel: [116, 128]<br>Frequency: [5580, 5640] | 124                | 5620                  | [0xCE6, 0xD13] |
|               | 6 | Channel: [132, 144]<br>Frequency: [5660, 5720] | 136                | 5680                  | [0xD14, 0xD41] |
|               | 7 | Channel: [149, 161]<br>Frequency: [5745, 5805] | 153                | 5765                  | [0xD42, 0xD6F] |
|               | 8 | Channel: [165, 181]<br>Frequency: [5825, 5905] | 173                | 5865                  | [0xD70, 0xD9D] |

**Wi-Fi 7 iBF 2.0 (mt7992):**

| Channel Group |    | Group Range                                                                        | Calibrated Channel | Frequency (Unit: MHz) | EEPROM Address |
|---------------|----|------------------------------------------------------------------------------------|--------------------|-----------------------|----------------|
| 2G            | 0  | Channel: [1, 14]<br>Frequency: [2412, 2484]                                        | 8                  | 2447                  | [0xC00, 0xC1C] |
| 5G            | 1  | Channel: [36, 48]<br>Frequency: [5180, 5240]                                       | 44                 | 5220                  | [0xC1D, 0xC3E] |
|               | 2  | Channel: [52, 64]<br>Frequency: [5260, 5320]                                       | 60                 | 5300                  | [0xC3F, 0xC60] |
|               | 3  | Channel: [68, 96]<br>Frequency: [5340, 5480]                                       | 84                 | 5420                  | [0xC61, 0xC82] |
|               | 4  | Channel: [100, 112]<br>Frequency: [5500, 5560]                                     | 104                | 5520                  | [0xC83, 0xCA4] |
|               | 5  | Channel: [116, 128]<br>Frequency: [5580, 5640]                                     | 124                | 5620                  | [0xCA5, 0xCC6] |
|               | 6  | Channel: [132, 144]<br>Frequency: [5660, 5720]                                     | 136                | 5680                  | [0xCC7, 0xCE8] |
|               | 7  | Channel: [149, 161]<br>Frequency: [5745, 5805]                                     | 153                | 5765                  | [0xCE9, 0xD0A] |
|               | 8  | Channel: [165, 181]<br>Frequency: [5825, 5905]                                     | 173                | 5865                  | [0xD0B, 0xD2C] |
|               | 9  | Channel: [36, 64]<br>Frequency: [5180, 5240]<br><b>CBW: 160 MHz, DBW: 20 MHz</b>   | 52                 | 5260                  | [0xD2D, 0xD4E] |
|               | 10 | Channel: [68, 96]<br>Frequency: [5340, 5480]<br><b>CBW: 160 MHz, DBW: 20 MHz</b>   | 84                 | 5420                  | [0xD4F, 0xD70] |
|               | 11 | Channel: [100, 128]<br>Frequency: [5500, 5640]<br><b>CBW: 160 MHz, DBW: 20 MHz</b> | 116                | 5580                  | [0xD71, 0xD92] |
|               | 12 | Channel: [149, 181]<br>Frequency: [5745, 5905]<br><b>CBW: 160 MHz, DBW: 20 MHz</b> | 165                | 5825                  | [0xD93, 0xDB4] |


## 3.8 Explicit Beamforming

### 3.8.1 Certification

As we all know, beamforming mechanism will get power gain due to in-phase signal by different TX antenna. When applying eBF in normal mode TX, we need to compensate the BF power gain to meet the power constraint. As a result, the goal of this certification is to create the eBF power gain table based on the measured power gain, also known as the TXBF power backoff table, and to test the functionality of eBF.

*There are some certification criteria, such as continuous TX, duty cycle > 98%, and manually controlled BF on/off. We simulate the continuous TX by setting a large TX count number, and BF on/off could be triggered by the command listed below. The eBF certification laboratory's duty cycle > 98% criterion for measuring TX power is out of date. They can now accept package mode and measure power gain without the requirement of duty cycle > 98%.*

This eBF test needs a "DUT" and a "Golden Unit" to realize gain boosting, where the DUT and the Golden Unit play the roles of beamformer and beamformee, respectively. The testing environment is shown in the figure below. **For DBDC mt7915, the beamformer (DUT) would be 2T instead of 4T, as shown in the following figure.**



The following is an example of eBF certification for **mt7986 2G HT20 (AX6000)**. For other testcases, please modify the interface (phy0), channel, BW, and TX rate mode. The commands of DUT and golden need to **be entered in sequence** during the test (orange for Golden, blue for DUT, and white for common). **Note that please use the proprietary driver for the golden device.**

| Step | MT76                                                                                                                                                                                                                                                                                            | Jedi                                                                                           |
|------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------|
| 1    | <pre># Start eBF certification ## Do nothing</pre>                                                                                                                                                                                                                                              | <pre># Start eBF certification iwpriv ra0 set ATEEBFCE=1 iwpriv ra0 set ATECTRLBANDIDX=0</pre> |
| 2    | <pre># Please use proprietary driver</pre>                                                                                                                                                                                                                                                      | <pre># Golden device init iwpriv ra0 set ATEConTxETxBfGdProc=02:00:00:006:000:0</pre>          |
| 3    | <pre># DUT init ## Start testmode for DUT iw dev phy0-ap0 del mt76-test phy0 add mon0 ## Switch channel iw dev mon0 set channel 6 HT20 ## Set TX parameters (tx_count: use a large num to simulate cont. TX) mt76-test phy0 set tx_rate_mode=ht tx_rate_idx=0 tx_rate_nss=1 tx_rate_sgi=0</pre> | <pre># DUT init iwpriv ra0 set ATEConTxETxBfInitProc=02:00:00:01:04:18:006:000:0:04000</pre>   |

| Step                                     | MT76                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | Jedi                                                                                                                                                                                                     |
|------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                          | <pre>tx_rate_ldpc=1 tx_power=18,0,0,0 tx_count=1000000 tx_length=4000 tx_ipg=4 ## eBF DUT init mt76-test phy0 set txbf_act=ebf_init txbf_param=1 ## Create virtual WTBL entry mt76-test phy0 set aid=1 ## Stop auto sounding mt76-test phy0 set txbf_act=stop_sounding txbf_param=1 ## Update channel information mt76-test phy0 set txbf_act=update_ch txbf_param=1 ## Update eBF profile (PFMU tag &amp; STA record) mt76-test phy0 set txbf_act=ebf_prof_update txbf_param=0,0,0 ## Apply eBF TX settings (PFMU tag &amp; STA record) mt76-test phy0 set txbf_act=apply_tx txbf_param=1,1,0,0,0 ## Trigger one-shot sounding packet mt76-test phy0 set txbf_act=trigger_sounding txbf_param=0,1,0,1,0,0,0 ## Trigger periodic sounding packet mt76-test phy0 set txbf_act=trigger_sounding txbf_param=2,1,ff,1,0,0,0 ## Start RX (for receiving BF sounding feedback packet) mt76-test phy0 set state=rx_frames</pre> |                                                                                                                                                                                                          |
| 4<br>Sounding<br>golden<br>debug<br>step | # Please use proprietary driver                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          | <pre># Check Bfee RX NDP &amp; trigger BFRP (for debugging) iwpriv ra0 mac \${BFEE_RX_NDP_ADDR} # Check Bfee RX NDPA &amp; TX feedback report (for debugging) iwpriv ra0 mac \${BFEE_RX_NDPA_ADDR}</pre> |
| 5<br>Sounding<br>DUT<br>debug<br>step    | <pre># Check Bfer RX feedback report counter (for debugging) echo \${BFER_RX_FBK_ADDR} &gt; /sys/kernel/debug/ieee80211/phy0/mt76/regidx cat /sys/kernel/debug/ieee80211/phy0/mt76/regval</pre>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          | <pre># Check Bfer RX feedback report counter (for debugging) iwpriv ra0 mac \${BFER_RX_FBK_ADDR}</pre>                                                                                                   |
| 6                                        | <pre># Start BF TX mt76-test phy0 set state=tx_frames</pre>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              | <pre># Start BF TX iwpriv ra0 set ATE=TXFRAME</pre>                                                                                                                                                      |
| 7                                        | <pre># Check Bfer TX packet applied eBF counter echo \${BF_APP_CNT_ADDR} &gt; /sys/kernel/debug/ieee80211/phy0/mt76/regidx cat /sys/kernel/debug/ieee80211/phy0/mt76/regval # If counter is counting, then try \${BF_NOT_APP_REASON}</pre>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               | <pre># Check Bfer TX packet applied eBF counter iwpriv ra0 mac \${BF_APP_CNT_ADDR} # If counter is counting, then try \${BF_NOT_APP_REASON}</pre>                                                        |
| 8                                        | # Use the instrument IQxel to check BF ON waveform                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |                                                                                                                                                                                                          |
| 9                                        | <pre># Changing TX power ## This step could be skipped if it is not required # Stop TX first</pre>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       | <pre># Changing TX power ## This step could be skipped if it is not required # Stop TX first iwpriv ra0 set ATE=TXSTOP</pre>                                                                             |




| Step | MT76                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | Jedi                                                                                                                                                                                                                                                                                                                                                                           |
|------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | mt76-test phy0 set state=idle<br># Re-configure TX power<br>mt76-test phy0 set tx_power=30,0,0,0<br>Go back to step 6 to re-trigger continuous TX                                                                                                                                                                                                                                                                                                                        | # Re-configure TX power<br>iwpriv ra0 set ATETXP0W0=30<br>Go back to step 6 to re-trigger continuous TX                                                                                                                                                                                                                                                                        |
| 10   | # Turn off BF<br>## Stop sounding<br>## BF Off and it takes a few seconds to take effect<br>mt76-test phy0 set txbf_act=stop_sounding<br>txbf_param=1<br>## Set PFMU tag invalid bit to true<br>mt76-test phy0 set txbf_act=set_invalid_prof<br>txbf_param=1<br>## Update PFMU tag<br>mt76-test phy0 set txbf_act=pfm_tag_write<br>txbf_param=0<br>## Read PFMU tag to check if it is updated successfully<br>mt76-test phy0 set txbf_act=pfm_tag_read<br>txbf_param=0,1 | # Turn off BF<br>## Stop sounding<br>## BF Off and it takes a few seconds to take effect<br>iwpriv ra0 set StopSounding=1<br>## Set PFMU tag invalid bit to true<br>iwpriv ra0 set TxBfProfileTagInvalid=1<br>## Update PFMU tag<br>iwpriv ra0 set TxBfProfileTagWrite=0<br>## Read PFMU tag to check if it is updated successfully<br>iwpriv ra0 set TxBfProfileTagRead=00:01 |
| 11   | # Check Bfer TX packet applied eBF counter<br>## It should be 0 after turning off eBF<br>echo <u><a href="#">\${BF_APP_CNT_ADDR}</a></u> ><br>/sys/kernel/debug/ieee80211/phy0/mt76/regidx<br>cat<br>/sys/kernel/debug/ieee80211/phy0/mt76/regval                                                                                                                                                                                                                        | # Check Bfer TX packet applied eBF counter<br>## It should be 0 after turning off eBF<br>iwpriv ra0 mac <u><a href="#">\${BF_APP_CNT_ADDR}</a></u>                                                                                                                                                                                                                             |
| 12   | # Use the instrument IQxel to check BF OFF waveform                                                                                                                                                                                                                                                                                                                                                                                                                      |                                                                                                                                                                                                                                                                                                                                                                                |
| 13   | # Resume BF On<br>## The way of MT76 resume BF on is different from jedi<br><b>MT76 should go back to step 3 &amp; 6 to resume BF on</b><br>## Therefore, if you are using iwpriv commands in MT76 (based on iwpriv wrapper), you should enter the ATEConTxETxBfInitProc and TXFRAME command instead of TriggerSounding listed in the right table                                                                                                                        | # Resume BF On<br>iwpriv ra0 set TriggerSounding=02:01:FF:01:00:00:00                                                                                                                                                                                                                                                                                                          |


### 3.9 Zero Wait DFS

Verify the hardware capability of the dedicated RX via LitePoint instrument (IQXEL). The testing procedure is illustrated in the following figure.

The test method here is to utilize a simple Continuous Wave (CW) tone to trigger the update of the IPI counter (see [here](#) for the introduction of IPI). Since CW tone is a signal with stable power and is also not a packet (no PD done), only the IPI counter within the power range of CW tone would increase endlessly. We use this indicator to check if the hardware of the dedicated RX could receive the signal correctly.



1. Enable the dedicated RX of DUT via [this command](#).
2. Set the VSG pattern and power of IQXEL. Please follow the steps to configure your instrument.
  - (1) Set the center frequency you want to test.  
**Note that, due to physical reasons, the frequency should have 5 MHz offset to avoid the DC tone. If CW hits on the DC tone, then the instrument cannot detect the signal properly.**
  - (2) Set the power level you want to test. The recommended test range is -62dBm.
  - (3) Select CW tone.
  - (4) Click the “RF(on)” button.



3. Get the RSSI value via reading control register (CR). The address of the CR of RSSI is listed in the following table. **If the read RSSI value has a 1~2dBm offset due to cable loss, then it is acceptable. Otherwise, the test failed. The IPI counter would not be correct anyway.**

| Chip             | RSSI CR Address | RSSI Reading Method [dBm]                                                                                                               |
|------------------|-----------------|-----------------------------------------------------------------------------------------------------------------------------------------|
| mt7915           | 0x830AF0E0      | ADC RSSI = CR[15:8] – 256 (in decimal)<br>IB RSSI = CR[7:0] – 256 (in decimal)<br><b>IB RSSI is the RSSI in which we are interested</b> |
| mt7916           | 0x831203E0      | RSSI = CR[31:24] – 256 (in decimal)                                                                                                     |
| mt7981<br>mt7986 | -               | -                                                                                                                                       |
| mt7996<br>mt7992 | 0x830403E0      | RSSI = CR[31:24] – 256 (in decimal)                                                                                                     |

4. Check the IPI status via reading [IPI CR](#) or [IPI show histogram command](#). The IPI counter of the corresponding IPI index should increase faster than the other IPI indexes.
5. If you are going to test another power range or channel, please [reset the IPI counter](#). And then, go back to step 1 or 2 according to your test requirements. Otherwise, the test is done.

**Wi-Fi 6 chipset (mt7915, mt7916):**

| Step | MT76                                                                                                                                                                                                                                                                                            | Jedi                                                                                                                                                                                |
|------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1    | <pre># Start ZWDFS Verification iw dev phy0-ap0 del mt76-test phy0 add mon0 # Enable the dedicated RX mt76-test phy0 set offchan_ch=100 offchan_bw=80</pre>                                                                                                                                     | <pre># Start ZWDFS Verification iwpriv ra0 set ATE=ATESTART # Enable the dedicated RX iwpriv ra0 set DfsRxCtrl=100:2</pre>                                                          |
| 2    | # Setup Instrument                                                                                                                                                                                                                                                                              |                                                                                                                                                                                     |
| 3    | <pre># Read RSSI CR echo \${RSSI_ADDR} &gt; /sys/kernel/debug/ieee80211/phy0/mt76/regidx cat /sys/kernel/debug/ieee80211/phy0/mt76/regval # Calculate RSSI = CR[31:24] - 256</pre>                                                                                                              | <pre># Read RSSI CR iwpriv ra0 mac \${RSSI_ADDR} # Calculate RSSI = CR[31:24] - 256</pre>                                                                                           |
| 4    | <pre># Read IPI status (e.g. IPI index 8) # Method 1: IPI histogram show command mt76-test phy0 set ipi_threshold=8 ipi_period=100 # Method 2: read IPI histogram CR echo \${IPI_ADDR} &gt; /sys/kernel/debug/ieee80211/phy0/mt76/regidx cat /sys/kernel/debug/ieee80211/phy0/mt76/regval</pre> | <pre># Read IPI status (e.g. IPI index 8) # Method 1: IPI histogram show command iwpriv ra0 set DfsRxHist=8:100 # Method 2: read IPI histogram CR iwpriv ra0 mac \${IPI_ADDR}</pre> |
| 5    | <pre># Reset the IPI counter or finish test mt76-test phy0 set ipi_reset=1 or echo \${IPI_RESET_ADDR} &gt; /sys/kernel/debug/ieee80211/phy0/mt76/regidx echo \${RESET_VALUE} &gt; /sys/kernel/debug/ieee80211/phy0/mt76/regval # Back to step 1 or 2</pre>                                      | <pre># Reset the IPI counter or finish test iwpriv ra0 mac \${IPI_RESET_ADDR}=\${RESET_VALUE} # Back to step 1 or 2</pre>                                                           |

**Wi-Fi 7 chipset (mt7996, mt7992):**

For the Wi-Fi 7 chipset, the HW module of the dedicated RX (ZWDFS) lies in band 0, so band 0 should also be enabled while using ZWDFS.

| Step | MT76                                                                                                                                                                                                                    | Logan                                                                                                                                                                                                    |
|------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1    | <pre># Start ZWDFS Verification mt76-test phy0 add mon0 mt76-test phy1 add mon1  # Enable band 0 RX mt76-test phy0 set state=rx_frames  # Enable the dedicated RX mt76-test phy1 set offchan_ch=100 offchan_bw=80</pre> | <pre># Start ZWDFS Verification iwpriv ra0 set ATE=ATESTART iwpriv rai0 set ATE=ATESTART  # Enable band 0 RX iwpriv ra0 set ATE=RXFRAME  # Enable the dedicated RX iwpriv rai0 set DfsRxCtrl=100:2</pre> |
| 2    | # Setup Instrument                                                                                                                                                                                                      |                                                                                                                                                                                                          |
| 3    | <pre># Read RSSI CR echo \${RSSI_ADDR} &gt; /sys/kernel/debug/ieee80211/phy0/mt76/regidx cat /sys/kernel/debug/ieee80211/phy0/mt76/regval # Calculate RSSI = CR[31:24] - 256</pre>                                      | <pre># Read RSSI CR iwpriv ra0 mac \${RSSI_ADDR} # Calculate RSSI = CR[31:24] - 256</pre>                                                                                                                |

| Step | MT76                                                                                                                                                                                                                                                                                                  | Logan                                                                                                                                                                                     |
|------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 4    | <pre># Read IPI status (e.g. IPI index 8) # Method 1: IPI histogram show command mt76-test phy0 set ipi_threshold=8 ipi_period=100 # Method 2: read IPI histogram CR echo <u>#{IPI ADDR}</u> &gt; /sys/kernel/debug/ieee80211/phy0/mt76/regidx cat /sys/kernel/debug/ieee80211/phy0/mt76/regval</pre> | <pre># Read IPI status (e.g. IPI index 8) # Method 1: IPI histogram show command iwpriv ra0 set DfsRxHist=8:100 # Method 2: read IPI histogram CR iwpriv ra0 mac <u>#{IPI ADDR}</u></pre> |
| 5    | <pre># Reset the IPI counter or finish test mt76-test phy0 set ipi_reset=1 or echo <u>#{IPI RESET ADDR}</u> &gt; /sys/kernel/debug/ieee80211/phy0/mt76/regidx echo <u>#{RESET VALUE}</u> &gt; /sys/kernel/debug/ieee80211/phy0/mt76/regval # Back to step 1 or 2</pre>                                | <pre># Reset the IPI counter or finish test iwpriv ra0 mac <u>#{IPI RESET ADDR}={RESET VALUE}</u> # Back to step 1 or 2</pre>                                                             |

## 4 iwpriv (mwctl) and ated Command Mapping Table

The mapping between iwpriv/ated commands and mt76-test/atenl commands is shown in the table below. **It should be noted that iwpriv/ated commands that are not listed here are not currently supported by MT76.** To check how the iwpriv commands are mapped by the mt76-test commands, please enable iwpriv wrapper [debug mode](#).

### 4.1 Iwpriv (mwctl)

#### 4.1.1 Set State

| Jedi/Logan                        | MT76                                                 |
|-----------------------------------|------------------------------------------------------|
| Basic commands                    |                                                      |
| iwpriv ra0 set ATE=ATESTART       | Enter monitor mode                                   |
| iwpriv ra0 set ATE=ATESTOP        | state=off and leave monitor mode                     |
| iwpriv ra0 set ATE=TXFRAME        | state=tx_frames                                      |
| iwpriv ra0 set ATE=TXSTOP         | state=idle                                           |
| iwpriv ra0 set ATE=TXCOMMIT       | aid=1                                                |
| iwpriv ra0 set ATE=TXREVERT       | aid=0                                                |
| iwpriv ra0 set ATE= RXFRAME       | state=rx_frames                                      |
| iwpriv ra0 set ATE=RXSTOP         | state=idle                                           |
| iwpriv ra0 set ATE=TXCONT         | state=tx_cont                                        |
| Pre-cal commands                  |                                                      |
| iwpriv ra0 set ATE=GROUPPREK      | state=group_prek<br>Write Back Pre-cal Data to Flash |
| iwpriv ra0 set ATE=GROUPPREKDUMP  | state=group_prek_dump                                |
| iwpriv ra0 set ATE=GROUPPREKClean | state=group_prek_clean                               |
| iwpriv ra0 set ATE=DPD2G          | state=dpd_2g<br>Write Back Pre-cal Data to Flash     |
| iwpriv ra0 set ATE=DPD5G          | state=dpd_5g<br>Write Back Pre-cal Data to Flash     |
| iwpriv ra0 set ATE=DPD6G          | state=dpd_6g<br>Write Back Pre-cal Data to Flash     |
| iwpriv ra0 set ATE=DPDDUMP        | state=dpd_dump                                       |
| iwpriv ra0 set ATE=DPDClean       | state=dpd_clean                                      |

#### 4.1.2 Set Configs

| Jedi/Logan                                                                       | MT76                      |
|----------------------------------------------------------------------------------|---------------------------|
| Basic commands                                                                   |                           |
| iwpriv ra0 set ATECTRLBANDIDX=<val>                                              | Use phyX to control       |
| iwpriv ra0 set ATETXBW=<val>(<val>)<br>iwpriv ra0 set ATECHANNEL=<val>(<val>...) | iw set channel            |
| iwpriv ra0 set ATETXCNT=<val>                                                    | tx_count                  |
| iwpriv ra0 set ATETXLEN=<val>                                                    | tx_length                 |
| iwpriv ra0 set ATETXANT=<val>                                                    | tx_antenna and tx_spe_idx |

| Jedi/Logan                                                                                                                           | MT76                                                                                     |                      |
|--------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------|----------------------|
| iwpriv ra0 set ATERXANT=<val>                                                                                                        |                                                                                          |                      |
| iwpriv ra0 set ATETXGI=<val>                                                                                                         | tx_rate_sgi & tx_ltf                                                                     |                      |
| iwpriv ra0 set ATETXMODE=<val>                                                                                                       | tx_rate_mode                                                                             |                      |
| iwpriv ra0 set ATETXMCS=<val>                                                                                                        | tx_rate_idx                                                                              |                      |
| iwpriv ra0 set ATEVHTNSS=<val><br>iwpriv ra0 set ATETXNSS=<val>                                                                      | tx_rate_nss                                                                              |                      |
| iwpriv ra0 set ATETXLDPC=<val>                                                                                                       | tx_rate_ldpc                                                                             |                      |
| iwpriv ra0 set ATETXSTBC=<val>                                                                                                       | tx_rate_stbc                                                                             |                      |
| iwpriv ra0 set ATETXPOW0=<val><br>iwpriv ra0 set ATETXPOW1=<val><br>iwpriv ra0 set ATETXPOW2=<val><br>iwpriv ra0 set ATETXPOW3=<val> | tx_power                                                                                 |                      |
| iwpriv ra0 set ATEPKTTXTIME =<val>                                                                                                   | tx_time                                                                                  |                      |
| iwpriv ra0 set ATEIPG=<val>                                                                                                          | tx_ipg                                                                                   |                      |
| iwpriv ra0 set ATEDUTYCYCLE=<val>                                                                                                    | tx_duty_cycle                                                                            |                      |
| iwpriv ra0 set ATETXFREQOFFSET=<val>                                                                                                 | freq_offset                                                                              |                      |
| iwpriv ra0 set ATEDA=xx:xx:xx:xx:xx:xx<br>iwpriv ra0 set ATESA= xx:xx:xx:xx:xx:xx<br>iwpriv ra0 set ATEBSSID= xx:xx:xx:xx:xx:xx      | mac_addr                                                                                 |                      |
| iBF commands                                                                                                                         |                                                                                          |                      |
| iwpriv ra0 set ATETxBfInit=<val>                                                                                                     | txbf_act=init                                                                            | txbf_param=<val>     |
| iwpriv ra0 set ATETxBfGdInit=<val>                                                                                                   | txbf_act=init                                                                            | txbf_param=<val>     |
| iwpriv ra0 set ATEIBFPhaseComp=<val>:<val>:..                                                                                        | txbf_act=phase_comp                                                                      | txbf_param=<val>,... |
| iwpriv ra0 set ATEEBfProfileConfig=<val>:<val>:..                                                                                    | txbf_act=ebf_prof_update                                                                 | txbf_param=<val>,... |
| iwpriv ra0 set ATEIBfProfileConfig=<val>:<val>:..                                                                                    | txbf_act=ibf_prof_update                                                                 | txbf_param=<val>,... |
| iwpriv ra0 set TxBFTxApply=<val>:<val>:..                                                                                            | txbf_act=apply_tx                                                                        | txbf_param=<val>,... |
| iwpriv ra0 set ATETxPacketWithBf=<val>:<val>:..                                                                                      | txbf_act=tx_prep                                                                         | txbf_param=<val>,... |
| iwpriv ra0 set TxBFTxCmd=<val>:<val>:..                                                                                              | txbf_act=txcmd                                                                           | txbf_param=<val>,... |
| iwpriv ra0 set TxBFProfileData20MAllWrite=<val>:<val>:..                                                                             | txbf_act=prof_update_all                                                                 | txbf_param=<val>,... |
| iwpriv ra0 set ATEIBfInstCal=<val>:<val>:..                                                                                          | txbf_act=phase_cal                                                                       | txbf_param=<val>,... |
| iwpriv ra0 set ATEIBfGdCal=<val>:<val>:..                                                                                            |                                                                                          |                      |
| iwpriv ra0 set ATEIBFPhaseVerify=<val>:<val>:...                                                                                     | txbf_act=phase_comp<br>txbf_act=phase_cal                                                | txbf_param=<val>,... |
| iwpriv ra0 set ATEIBFPhaseE2pUpdate=<val>:<val>:..                                                                                   | txbf_act=e2p_update<br>atenl "eeprom ibf sync"                                           | txbf_param=<val>,... |
| iwpriv ra0 set TriggerSounding=<val>:<val>:...                                                                                       | txbf_act=trigger_sounding                                                                | txbf_param=<val>,... |
| iwpriv ra0 set StopSounding=<val>                                                                                                    | txbf_act=stop_sounding                                                                   | txbf_param=<val>,... |
| iwpriv ra0 set TxBFProfileTagWrite=<val>                                                                                             | txbf_act=pfmu_tag_write                                                                  | txbf_param=<val>,... |
| iwpriv ra0 set TxBFProfileTagRead=<val>:<val>                                                                                        | txbf_act=pfmu_tag_read                                                                   | txbf_param=<val>,... |
| iwpriv ra0 set TxBFProfileTagInValid=<val>                                                                                           | txbf_act=set_invalid_prof                                                                | txbf_param=<val>,... |
| iwpriv ra0 set StaRecBfRead=<val>                                                                                                    | txbf_act=sta_rec_read                                                                    | txbf_param=<val>,... |
| eBF commands                                                                                                                         |                                                                                          |                      |
| iwpriv ra0 set ATEConTxETxBfGdProc=<val>:...                                                                                         | This command is translated to a lot of mt76's command. See <a href="#">eBF example</a> . |                      |
| iwpriv ra0 set ATEConTxETxBfInitProc=<val>:...                                                                                       | This command is translated to a lot of mt76's command. See <a href="#">eBF example</a> . |                      |
| ZWDFS commands                                                                                                                       |                                                                                          |                      |
| iwpriv ra0 set DfsRxCtrl=<chan>:<bw>                                                                                                 | offchan_ch=<chan><br>offchan_bw=<bw>                                                     |                      |

| Jedi/Logan                                                      | MT76                                                                               |
|-----------------------------------------------------------------|------------------------------------------------------------------------------------|
| iwpriv ra0 set<br>DfsRxHist=<threshold>:<period>(<antenna_idx>) | ipi_threshold=<threshold><br>ipi_period=<period><br>ipi_antenna_idx=< antenna_idx> |

### 4.1.3 Statistic

| Jedi/Logan                          | MT76                                                                                                                       |
|-------------------------------------|----------------------------------------------------------------------------------------------------------------------------|
| iwpriv ra0 set ATESHOW=1            | dump<br>dump stats                                                                                                         |
| iwpriv ra0 set ATERXSTAT=<val>      |                                                                                                                            |
| iwpriv ra0 set ResetCounter=1       | Auto reset on tx_frame or rx_frame                                                                                         |
| iwpriv ra0 set ATERXSTATRESET=<val> |                                                                                                                            |
| iwpriv ra0 show wtbl=<wlan_idx>     | echo <wlan_idx> ><br>/sys/kernel/debug/ieee80211/phy0/mt76/wlan_idx<br>cat /sys/kernel/debug/ieee80211/phy0/mt76/wtbl_info |

### 4.1.4 MISC

| Jedi/Logan                                                | MT76                                                                   |
|-----------------------------------------------------------|------------------------------------------------------------------------|
| Read/Write EEPROM                                         |                                                                        |
| iwpriv ra0 e2p <offset>                                   | Read EEPROM Data                                                       |
| iwpriv ra0 e2p <offset>=<val>                             | Change Value to Specific offset                                        |
| Read/Write Control Register                               |                                                                        |
| iwpriv ra0 mac <offset>                                   | Section 7.7 Set/Dump Control Register<br>in the MT76 Programming Guide |
| iwpriv ra0 mac <offset>=<val>                             |                                                                        |
| Buffer Mode                                               |                                                                        |
| iwpriv ra0 set bufferMode=2<br>※only support bufferMode=2 | Update buffer mode                                                     |

## 4.2 ated

| Jedi/Logan                       | MT76        |
|----------------------------------|-------------|
| ated -i ra0 -c "sync eeprom all" | sync eeprom |

## 5 Testmode Overall Status (Per-chip)

| Chip     |                                                           | Test Item   | Command Mode<br>(iwpriv/mt76-test) | ATENL/HQADLL<br>(Litepoint) |
|----------|-----------------------------------------------------------|-------------|------------------------------------|-----------------------------|
| MT7915 A |                                                           | Basic TX/RX | Support                            | Support                     |
|          |                                                           | iBF         |                                    |                             |
| MT7916   | 2/5G<br>2T2R + 1R                                         | Basic TX/RX | No RFB                             |                             |
|          |                                                           | iBF         |                                    |                             |
|          | 2/5G<br>3T3R                                              | Basic TX/RX | Support                            | Support                     |
|          |                                                           | iBF         |                                    |                             |
|          | 2/6G<br>2T2R + 1R                                         | Basic TX/RX | -                                  | -                           |
|          |                                                           | iBF         |                                    |                             |
|          | 2/6G<br>3T3R                                              | Basic TX/RX | Support                            | Support                     |
|          |                                                           | iBF         | Fail                               |                             |
| MT7981   | 2/5G<br>3T3R                                              | Basic TX/RX | Support                            | Support                     |
|          |                                                           | iBF         |                                    |                             |
| MT7986   | MT7975                                                    | Basic TX/RX | Support                            | Support                     |
|          |                                                           | iBF         |                                    |                             |
|          | MT7976<br>2/5G                                            | Basic TX/RX | Support                            | Support                     |
|          |                                                           | iBF         |                                    |                             |
|          | MT7976<br>2/5G                                            | Basic TX/RX | Support                            | Support                     |
|          |                                                           | iBF         |                                    |                             |
| MT7996   | MT7976+MT7977+MT7977<br>BE19000 eFEM                      | Basic TX/RX | Support                            | T.B.D                       |
|          |                                                           | iBF         |                                    |                             |
|          | MT7975+MT7977+MT7977<br>BE19000 iFEM                      | Basic TX/RX | Support                            | T.B.D                       |
|          |                                                           | iBF         |                                    |                             |
|          | MT7976DA+MT7977<br>BE14000 eFEM                           | Basic TX/RX | Support                            | T.B.D                       |
|          |                                                           | iBF         |                                    |                             |
|          | MT7976C+MT7977<br>BE14000 iFEM                            | Basic TX/RX | Support                            | T.B.D                       |
|          |                                                           | iBF         |                                    |                             |
| MT7992   | MT7976G+MT7977<br>(2G 4T4R+ZWDFS, 5G 4T5R)<br>BE7200 eFEM | Basic TX/RX | Support                            | T.B.D                       |
|          |                                                           | iBF         |                                    |                             |
|          | MT7975+MT7977<br>(2G 4T4R+ZWDFS, 5G 4T5R)<br>BE7200 2i5e  | Basic TX/RX | Support                            | T.B.D                       |
|          |                                                           | iBF         |                                    |                             |
|          | MT7975+MT7979<br>(2G 4T4R+ZWDFS, 5G 5T5R)<br>BE7200 iFEM  | Basic TX/RX | Support                            | T.B.D                       |
|          |                                                           | iBF         |                                    |                             |
|          | MT7976C+MT7977<br>(2G 2T2R, 5G 3T3R)<br>BE5040 eFEM       | Basic TX/RX | Support                            | T.B.D                       |
|          |                                                           | iBF         |                                    |                             |
|          | MT7976C+MT7977<br>(2G 2T2R, 5G 3T3R)<br>BE5040 iFEM       | Basic TX/RX | Support                            | T.B.D                       |
|          |                                                           | iBF         |                                    |                             |



## 6 Appendix

### 6.1 Spatial Extension Index Table

|           |                 | Antenna Indexing |            |            |            | SW Valid Settings |    |    |    |
|-----------|-----------------|------------------|------------|------------|------------|-------------------|----|----|----|
| SPE index | Class           | priority 1       | priority 2 | priority 3 | priority 4 | 4T                | 3T | 2T | 1T |
| 0         | default         | 0                | 1          | 2          | 3          | O                 | O  | O  | O  |
| 1         | default         | 1                | 0          | 2          | 3          | O                 | O  | O  | X  |
| 2         | default         | 0                | 2          | 1          | 3          | O                 | O  | X  | X  |
| 3         | default         | 2                | 0          | 1          | 3          | O                 | O  | X  | X  |
| 4         | default         | 1                | 2          | 0          | 3          | O                 | O  | X  | X  |
| 5         | default         | 2                | 1          | 0          | 3          | O                 | O  | X  | X  |
| 6         | default         | 1                | 3          | 0          | 2          | O                 | X  | X  | X  |
| 7         | default         | 3                | 1          | 0          | 2          | O                 | X  | X  | X  |
| 8         | default         | 0                | 3          | 1          | 2          | O                 | X  | X  | X  |
| 9         | default         | 3                | 0          | 1          | 2          | O                 | X  | X  | X  |
| 10        | default         | 0                | 1          | 3          | 2          | O                 | X  | X  | X  |
| 11        | default         | 1                | 0          | 3          | 2          | O                 | X  | X  | X  |
| 12        | default         | 0                | 2          | 3          | 1          | O                 | X  | X  | X  |
| 13        | default         | 2                | 0          | 3          | 1          | O                 | X  | X  | X  |
| 14        | default         | 0                | 3          | 2          | 1          | O                 | X  | X  | X  |
| 15        | default         | 3                | 0          | 2          | 1          | O                 | X  | X  | X  |
| 16        | default         | 2                | 3          | 0          | 1          | O                 | X  | X  | X  |
| 17        | default         | 3                | 2          | 0          | 1          | O                 | X  | X  | X  |
| 18        | default         | 1                | 2          | 3          | 0          | O                 | X  | X  | X  |
| 19        | default         | 2                | 1          | 3          | 0          | O                 | X  | X  | X  |
| 20        | default         | 1                | 3          | 2          | 0          | O                 | X  | X  | X  |
| 21        | default         | 3                | 1          | 2          | 0          | O                 | X  | X  | X  |
| 22        | default         | 2                | 3          | 1          | 0          | O                 | X  | X  | X  |
| 23        | default         | 3                | 2          | 1          | 0          | O                 | X  | X  | X  |
| 24        | SE_SET1 from CR | *                | *          | *          | *          | O                 | O  | O  | X  |
| 25        | SE_SET2 from CR | *                | *          | *          | *          | O                 | O  | O  | X  |
| 26        | SE_SET3 from CR | *                | *          | *          | *          | O                 | O  | O  | X  |
| 27        | SE_SET4 from CR | *                | *          | *          | *          | O                 | O  | O  | X  |
| 28        | Reserved        | *                | *          | *          | *          | X                 | X  | X  | X  |
| 29        | Reserved        | *                | *          | *          | *          | X                 | X  | X  | X  |
| 30        | Reserved        | *                | *          | *          | *          | X                 | X  | X  | X  |
| 31        | Reserved        | *                | *          | *          | *          | X                 | X  | X  | X  |

## 6.2 Beamforming Debug CR

The following tables record the most used CR for debugging or checking BF. Note that the CR presented here is mostly **read clear**.

| Chip   |        | Bfee RX NDP Count CR Address | Description (Unit: MPDU)                                                                                                                                                                                                 |
|--------|--------|------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| mt7915 | Band 0 | 0x820EA044                   | [31:24] Number of TXBF feedback CQI Report count<br>[23:16] Number of TXBF feedback aborted due to WTBL response control<br>[15:8] Number of HE Trigger Frame BRP packet received<br>[7:0] Number of NDP packet received |
|        | Band 1 | 0x820FA044                   |                                                                                                                                                                                                                          |
| mt7916 | Band 0 | 0x820ED7BC                   | [31:16] Number of TXBF feedback CQI report count<br>[15:0] Number of NDP packet received                                                                                                                                 |
| mt7981 | Band 1 | 0x820FD7BC                   |                                                                                                                                                                                                                          |
| mt7986 |        |                              |                                                                                                                                                                                                                          |
| mt7996 | Band 0 | 0x820ED9F0                   | [31:0] Number of NDP packet received                                                                                                                                                                                     |
|        | Band 1 | 0x820FD9F0                   |                                                                                                                                                                                                                          |
|        | Band 2 | 0x830ED9F0                   |                                                                                                                                                                                                                          |
| mt7992 | Band 0 | 0x820EDAEC                   |                                                                                                                                                                                                                          |
|        | Band 1 | 0x820FDAEC                   |                                                                                                                                                                                                                          |

| Chip   |        | Bfee RX NDPA Count & TX Feedback Report CR Address | Description (Unit: MPDU)                                                                                          |
|--------|--------|----------------------------------------------------|-------------------------------------------------------------------------------------------------------------------|
| mt7915 | Band 0 | 0x820EA040                                         | [31:16] Number of successfully transmitted TXBF feedback<br>[15:0] Number of TXBF feedback triggered (NDPA Count) |
|        | Band 1 | 0x820FA040                                         |                                                                                                                   |
| mt7916 | Band 0 | 0x820ED7B8                                         | [31:16] Number of HE Trigger Frame BRP packet received<br>[15:0] Number of TXBF feedback triggered (NDPA Count)   |
| mt7981 | Band 1 | 0x820FD7B8                                         |                                                                                                                   |
| mt7986 |        |                                                    |                                                                                                                   |
| mt7996 | Band 0 | 0x820ED9E8                                         | [31:0] Number of TXBF feedback triggered (NDPA Count)                                                             |
|        | Band 1 | 0x820FD9E8                                         |                                                                                                                   |
|        | Band 2 | 0x830ED9E8                                         |                                                                                                                   |
| mt7992 | Band 0 | 0x820EDAE4                                         |                                                                                                                   |
|        | Band 1 | 0x820FDAE4                                         |                                                                                                                   |

| Chip   |        | Bfer RX Feedback Count CR Address   | Description (Unit: MPDU)                                                                                                                                                                                                              |
|--------|--------|-------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| mt7915 | Band 0 | 0x820EA0F8                          | [31:24] Number of Bfer received feedback for <b>Total</b><br>[23:16] Number of Bfer received feedback for <b>HE</b><br>[15:8] Number of Bfer received feedback for <b>VHT</b><br>[7:0] Number of Bfer received feedback for <b>HT</b> |
|        | Band 1 | 0x820FA0F8                          |                                                                                                                                                                                                                                       |
| mt7916 | Band 0 | 0x820ED7B0, for <b>HT &amp; VHT</b> | [31:16] Number of Bfer received feedback for <b>VHT</b><br>[15:0] Number of Bfer received feedback for <b>HT</b>                                                                                                                      |
| mt7981 | Band 1 | 0x820FD7B0, for <b>HT &amp; VHT</b> |                                                                                                                                                                                                                                       |
| mt7986 | Band 0 | 0x820ED7B4, for <b>HE</b>           | [15:0] Number of Bfer received feedback for <b>HE</b>                                                                                                                                                                                 |
|        | Band 1 | 0x820FD7B4, for <b>HE</b>           |                                                                                                                                                                                                                                       |
| mt7996 | Band 0 | 0x820ED9D8 + <offs>                 | [31:0] Number of Bfer received feedback<br>$\text{<offs>} = \begin{cases} 0x0, & \text{HT} \\ 0x4, & \text{VHT} \\ 0x8, & \text{HE} \\ 0xC, & \text{EHT} \end{cases}$                                                                 |
|        | Band 1 | 0x820FD9D8 + <offs>                 |                                                                                                                                                                                                                                       |
|        | Band 2 | 0x830ED9D8 + <offs>                 |                                                                                                                                                                                                                                       |
| mt7992 | Band 0 | 0x820EDAD4 + <offs>                 |                                                                                                                                                                                                                                       |
|        | Band 1 | 0x820FDAD4 + <offs>                 |                                                                                                                                                                                                                                       |

| Chip   |        | Bfer TXBF Applied Count CR Address | Description (Unit: PPDU)                      |
|--------|--------|------------------------------------|-----------------------------------------------|
| mt7915 | Band 0 | 0x820EA0F0                         | [31:16] Number of TX <b>iBF</b> applied count |
|        | Band 1 | 0x820FA0F0                         | [15:0] Number of TX <b>eBF</b> applied count  |
| mt7916 | Band 0 | 0x820ED7A8                         | [31:16] Number of TX <b>iBF</b> applied count |
| mt7981 | Band 1 | 0x820FD7A8                         | [15:0] Number of TX <b>eBF</b> applied count  |
| mt7986 |        |                                    |                                               |
| mt7996 | Band 0 | 0x820ED9CC                         | [31:0] Number of TX <b>eBF</b> applied count  |
|        | Band 1 | 0x820FD9CC                         |                                               |
|        | Band 2 | 0x830ED9CC                         |                                               |
|        | Band 0 | 0x820ED9D0                         | [31:0] Number of TX <b>iBF</b> applied count  |
|        | Band 1 | 0x820FD9D0                         |                                               |
|        | Band 2 | 0x830ED9D0                         |                                               |
| mt7992 | Band 0 | 0x820EDAC8                         | [31:0] Number of TX <b>eBF</b> applied count  |
|        | Band 1 | 0x820FDAC8                         |                                               |
|        | Band 0 | 0x820EDACC                         | [31:0] Number of TX <b>iBF</b> applied count  |
|        | Band 1 | 0x820FDACC                         |                                               |

### 6.3 Protected FT Field

The following table lists the protected FT fields in eFuse for each chip variant. The offsets listed below means their value **CANNOT** be overwritten.

| Chip                                      | eFuse Protected Region                     |                                                                                             |
|-------------------------------------------|--------------------------------------------|---------------------------------------------------------------------------------------------|
| mt7996 BE19000 eFEM<br>(7976, 7977, 7977) | <b>Ddie</b><br>[0x0, 0x3FF]                | [0x10, 0x18F]<br>[0x1B0, 0x2BF]<br>[0x2C6, 0x2FF]<br>[0x300, 0x30F]<br>[0x311, 0x3FF]       |
|                                           | <b>Adie 0 (MT7976)</b><br>[0x400, 0x11FF]  | [0x400, 0x47f]<br>[0xB90, 0xB98]<br>[0xB9A, 0xB9F]<br>0xBA6, 0xBA8, 0xBAA<br>[0xBB0, 0xBBF] |
|                                           | <b>Adie 1 (MT7977)</b><br>[0x1E00, 0x2A00] | [0x1E00, 0x1E6E]<br>[0x1E70, 0x1E7C]<br>[0x1E7E, 0x1F0F]                                    |
|                                           | <b>Adie 2 (MT7977)</b><br>[0x1200, 0x1E00] | [0x1200, 0x126E]<br>[0x1270, 0x127C]<br>[0x127E, 0x130F]                                    |

| Chip                                              | eFuse Protected Region                     |                                                                    |
|---------------------------------------------------|--------------------------------------------|--------------------------------------------------------------------|
| mt7996 BE19000 iFEM<br>(7975, 7977, 7977)         | <b>Ddie</b><br>[0x0, 0x3FF]                | Same as mt7996 BE19000 eFEM Ddie                                   |
|                                                   | <b>Adie 0 (MT7976)</b><br>[0x400, 0x11FF]  | [0x9C0, 0xA2F]<br>[0xAC0, 0xAFF]<br>0xBA1, 0xBA9<br>[0xBB0, 0xBBF] |
|                                                   | <b>Adie 1 (MT7977)</b><br>[0x1E00, 0x2A00] | Same as mt7996 BE19000 eFEM Adie1                                  |
|                                                   | <b>Adie 2 (MT7977)</b><br>[0x1200, 0x1E00] | Same as mt7996 BE19000 eFEM Adie 2                                 |
| mt7996 BE14000 2adie<br>eFEM/iFEM<br>(7976, 7977) | <b>Ddie</b><br>[0x0, 0x3FF]                | Same as mt7996 BE19000 eFEM Ddie                                   |
|                                                   | <b>Adie 0 (MT7976)</b><br>[0x400, 0x11FF]  | Same as mt7996 BE19000 eFEM Adie 0                                 |
|                                                   | <b>Adie 1 (MT7977)</b><br>[0x1200, 0x1E00] | Same as mt7996 BE19000 eFEM Adie 2                                 |
| mt7992                                            | <b>Ddie</b><br>[0x0, 0x3FF]                | [0x10, 0x18f]<br>[0x1b0, 0x1e00]                                   |
|                                                   | <b>Adie 0, 1</b>                           | <b>All protected</b>                                               |

## 6.4 Abbreviations

| Abbreviation | Full Form                                                    |
|--------------|--------------------------------------------------------------|
| ADC          | Analog-to-Digital Converter                                  |
| ADCDCCOC     | Analog-to-Digital Converter Direct Current Offset Correction |
| Adie         | Analog Die                                                   |
| AID          | Association Identifier                                       |
| ANT          | Antenna                                                      |
| AP           | Access Point                                                 |
| ATE          | Automated Test Equipment                                     |
| BF           | Beamforming                                                  |
| Bfee         | Beamformee                                                   |
| Bfer         | Beamformer                                                   |
| BMC          | Broadcast and Multicast                                      |
| BRP          | Beam Refinement Process                                      |
| BSSID        | Basic Service Set Identifier                                 |
| BW           | Bandwidth                                                    |
| Cal          | Calibration                                                  |
| CBW          | Channel Bandwidth                                            |
| CCA          | Clear Channel Assessment                                     |
| CCK          | Complementary Code Keying                                    |
| CQI          | Channel Quality Indicator                                    |
| CR           | Control Register                                             |
| CSMA/CA      | Carrier Sense Multiple Access with Collision Avoidance       |
| CW           | Continuous Wave                                              |
| DA           | Destination Address                                          |
| dB           | Decibel                                                      |

| Abbreviation | Full Form                                                          |
|--------------|--------------------------------------------------------------------|
| DBDC         | Dual Band Dual Concurrent                                          |
| DBW          | Data Bandwidth                                                     |
| DC           | Direct Current                                                     |
| DCIQ         | Direct Current In-phase and Quadrature                             |
| DCOC         | Direct Current Offset Correction                                   |
| Ddie         | Digital Die                                                        |
| DFS          | Dynamic Frequency Selection                                        |
| DPD          | Digital Pre-Distortion                                             |
| DTS          | Device Tree Source                                                 |
| DUT          | Device Under Test                                                  |
| eBF          | Explicit Beamforming                                               |
| EEPROM/E2P   | Electrically Erasable Programmable Read-Only Memory                |
| eFEM         | External Front-End Module                                          |
| eFuse        | Electronic Fuse                                                    |
| EHT          | Extremely High Throughput                                          |
| eLNA         | External Low Noise Amplifier                                       |
| eMMC         | Embedded Multimedia Card                                           |
| ePA          | External Power Amplifier                                           |
| FDIQ         | Frequency Domain In-phase and Quadrature                           |
| FIIQ         | Frequency Independent In-phase and Quadrature                      |
| FT           | Final Test                                                         |
| FW           | Firmware                                                           |
| GI           | Guard Interval                                                     |
| GT           | Gain Table                                                         |
| HE           | High Efficiency                                                    |
| HQADLL       | Hardware Quality Assurance Dynamic-link Library                    |
| HT           | High Throughput                                                    |
| IB RSSI      | Intermediate Frequency/Baseband Received Signal Strength Indicator |
| iBF          | Implicit Beamforming                                               |
| ID           | Identifier                                                         |
| IEEE         | Institute of Electrical and Electronics Engineers                  |
| iFEM         | Internal Front-End Module                                          |
| iLNA         | Internal Low Noise Amplifier                                       |
| iPA          | Internal Power Amplifier                                           |
| IPG          | Inter-Packet Gap                                                   |
| IPI          | Idle Power Indicator                                               |
| JP           | Japan                                                              |
| LDPC         | Low-Density Parity-Check                                           |
| LNA          | Low Noise Amplifier                                                |
| LPFG         | Low-Pass Filter Gain                                               |
| LTF          | Long Training Field                                                |
| MAC          | Media Access Control                                               |
| MCS          | Modulation and Coding Scheme                                       |
| MHz          | Megahertz                                                          |
| MPDU         | MAC Protocol Data Unit                                             |
| MTD          | Memory Technology Device                                           |
| MU           | Multi-User                                                         |

| Abbreviation | Full Form                                  |
|--------------|--------------------------------------------|
| NDP          | Null Data Packet                           |
| NDPA         | Null Data Packet Announcement              |
| NSS          | Number of Spatial Streams                  |
| OFDM         | Orthogonal Frequency Division Multiplexing |
| OTA          | Over-The-Air                               |
| PD           | Packet Detection                           |
| PFMU         | Profile Management Unit                    |
| PHY          | Physical Layer                             |
| PPDU         | Physical Protocol Data Unit                |
| Pre-cal      | Pre-calibration                            |
| RAM          | Random Access Memory                       |
| RF           | Radio Frequency                            |
| RSSI         | Received Signal Strength Indicator         |
| RU           | Resource Unit                              |
| RX           | Receiver/Receive                           |
| SA           | Source Address                             |
| SDK          | Software Development Kit                   |
| SIFS         | Short Interframe Space                     |
| SKU          | Stock Keeping Unit                         |
| SPE          | Spatial Extension                          |
| SS           | Spatial Streams                            |
| STA          | Station                                    |
| STBC         | Space-Time Block Coding                    |
| SU           | Single User                                |
| SW           | Software                                   |
| Sync         | Synchronization/Synchronize                |
| TB           | Trigger-based                              |
| TBTC         | Triple-Band Triple Concurrent              |
| TSSI         | Transmit Signal Strength Indicator         |
| TX           | Transmitter/Transmit                       |
| TXBF         | Transmit Beamforming                       |
| TXCMD        | TX command                                 |
| TXD          | Transmit Descriptor                        |
| VHT          | Very High Throughput                       |
| WA (-CPU)    | Wi-Fi Acceleration/Application CPU         |
| WCID         | Wireless Client Identifier                 |
| Wi-Fi        | Wireless Fidelity                          |
| Wiphy        | Wireless Physical Layer                    |
| WLAN         | Wireless Local Area Network                |
| WM (-CPU)    | Wi-Fi MAC CPU                              |
| WTBL         | Wireless Lan Table                         |
| ZWDFS        | Zero Wait Dynamic Frequency Selection      |

## Exhibit 1 Terms and Conditions

Your access to and use of this document and the information contained herein (collectively this “Document”) is subject to your (including the corporation or other legal entity you represent, collectively “You”) acceptance of the terms and conditions set forth below (“T&C”). By using, accessing or downloading this Document, You are accepting the T&C and agree to be bound by the T&C. If You don’t agree to the T&C, You may not use this Document and shall immediately destroy any copy thereof.

This Document contains information that is confidential and proprietary to MediaTek Inc. and/or its affiliates (collectively “MediaTek”) or its licensors and is provided solely for Your internal use with MediaTek’s chipset(s) described in this Document and shall not be used for any other purposes (including but not limited to identifying or providing evidence to support any potential patent infringement claim against MediaTek or any of MediaTek’s suppliers and/or direct or indirect customers). Unauthorized use or disclosure of the information contained herein is prohibited. You agree to indemnify MediaTek for any loss or damages suffered by MediaTek for Your unauthorized use or disclosure of this Document, in whole or in part.

MediaTek and its licensors retain titles and all ownership rights in and to this Document and no license (express or implied, by estoppels or otherwise) to any intellectual propriety rights is granted hereunder. This Document is subject to change without further notification. MediaTek does not assume any responsibility arising out of or in connection with any use of, or reliance on, this Document, and specifically disclaims any and all liability, including, without limitation, consequential or incidental damages.

THIS DOCUMENT AND ANY OTHER MATERIALS OR TECHNICAL SUPPORT PROVIDED BY MEDIATEK IN CONNECTION WITH THIS DOCUMENT, IF ANY, ARE PROVIDED “AS IS” WITHOUT WARRANTY OF ANY KIND, WHETHER EXPRESS, IMPLIED, STATUTORY, OR OTHERWISE. MEDIATEK SPECIFICALLY DISCLAIMS ALL WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT, FITNESS FOR A PARTICULAR PURPOSE, COMPLETENESS OR ACCURACY AND ALL WARRANTIES ARISING OUT OF TRADE USAGE OR OUT OF A COURSE OF DEALING OR COURSE OF PERFORMANCE. MEDIATEK SHALL NOT BE RESPONSIBLE FOR ANY MEDIATEK DELIVERABLES MADE TO MEET YOUR SPECIFICATIONS OR TO CONFORM TO A PARTICULAR STANDARD OR OPEN FORUM.

Without limiting the generality of the foregoing, MediaTek makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does MediaTek assume any liability arising out of the application or use of any product, circuit or software. You agree that You are solely responsible for the designing, validating and testing Your product incorporating MediaTek’s product and ensure such product meets applicable standards and any safety, security or other requirements.

The above T&C and all acts in connection with the T&C or this Document shall be governed, construed and interpreted in accordance with the laws of Taiwan, without giving effect to the principles of conflicts of law.