

EVBSFM10R User Manual

Rev.7

WiSOL

Jan. 09, 2017

Contents

| | |
|---|----|
| Hardware | 3 |
| Test Program | 6 |
| AT command complete set | 11 |
| Specific recommendation for each module | 16 |

| Model | F/W |
|------------------|-----|
| EVBSFM10R1AT, AP | - |
| EVBSFM10R2AT, AP | - |
| EVBSFM10R3AT, AP | - |
| EVBSFM10R4AT, AP | - |


Confidential Only for UTS
February 27, 2017

Hard Ware

Evaluation Kit Component



Antenna



EVBSFM10R(Rev.3)

[Fig. Evaluation Kit Component]

EVBSFM10R Evaluation Kit Component

- 1) EVBSFM10R(Rev.3): 1EA
- 2) SMA Antenna: 1EA
- 3) Micro USB cable: 1EA



Connector PIN Description


| Connector | Pin No. | Pin name | Module Pin No. | Fucntion |
|-----------|---------|-----------------|----------------|---|
| J3 | 1 | SYSCLK | 5 | - |
| | 2 | GPIO8 | 6 | General purpose IO |
| | 3 | GPIO7 | 7 | General purpose IO Selectable SPI functionality (MISO) |
| | 4 | GPIO6 | 8 | General purpose IO Selectable SPI functionality (MOSI) |
| | 5 | GPIO5 | 9 | General purpose IO Selectable SPI functionality (SCK) |
| | 6 | GPIO4 | 10 | General purpose IO Selectable $\Sigma\Delta$ DAC functionality Selectable dock functionality |
| | 7 | CPU_LED | 11 | CPU activity indicator |
| | 8 | RADIO_LED | 12 | Radio activity indicator |
| | 9 | GPIO9 | 13 | General purpose IO Wakeup from deep sleep |
| | 10 | UARTTX | 14 | UART transmit |
| | 11 | UARTRX | 15 | UART receive |
| | 12 | RXLED/ DBG_DATA | 16 | Receive activity indicator |
| | 13 | TXLED/ DBG_CLK | 17 | Transmit activity indicator |
| | 14 | DBG_EN | 18 | - |
| | 15 | RST_N | 19 | Optional reset pin |
| | 16 | GPIO0 | 23 | General purpose IO Selectable ADC functionality Selectable $\Sigma\Delta$ DAC functionality Selectable clock functionality |
| | 17 | GPIO1 | 24 | General purpose IO Selectable ADC functionality |
| | 18 | GPIO2 | 25 | General purpose IO Selectable ADC functionality |
| | 19 | GPIO3 | 26 | General purpose IO Selectable ADC functionality |
| | 20 | GND | - | Ground |

*The GPIO2 and GPIO3 pin should not be used for RCZ2 and RCZ4 module and left "Not Connected".

Test Program

Evaluation board Connection

1. EVBSFM10R connect to Window PC by USB cable.




- (1) EVBSFM10
- (2) Micro USB cable
- (3) Windows PC

[Fig. EVBSFM10R connection]

Program execution


1. EVBSFM10R connected serial port in Windows PC, and then check the COM-port number in device manager.

- USB Serial Port(COM9)



[Fig. EVBSFM10R serial port]


2. Run serial communication program "SFM10R_AT_TEST.exe"
3. Write serial port Number in 'DUTCOM' BOX, and then 'connect' click.



[Fig. EVBSFM10R serial port number]


Install USB driver

1. Execute "CDM21216_Setup.exe" file.




[Fig. USB driver set-up file]

2. Setting device manager in Windows.



[Fig. Setting device manager]

Test program Description



[Fig. Screen of execute Test program(v13)]

- Serial Communication
 - (1) DUTCOM: Input serial port number of USB
 - (2) Connect : Serial port open
 - (3) Close: Serial port close
- Quick commands
 - (1) AT: Just returns 'OK' and does nothing else. Can be used to check communication.
 - (2) Get DEVID: Read Device ID [AT\$I=10]
 - (3) Get PAC: Read Device PAC [AT\$I=11]
 - (4) S/W Reset : Software reset [AT\$P=0]
 - (5) CW_EU_ON: To run Continuous Wave emission tests for RCZ1 module.
[AT\$CW=868130000,1,15]
 - (6) CW_EU_OFF: RCZ1 continuous wave Off [AT\$CW=868130000,0,15]
 - (7) CW_US_ON: To run Continuous Wave emission tests for RCZ2 module.
[AT\$CW=902200000,1,24]

- (8) CW_US_OFF: RCZ2 continuous wave Off [AT\$CW=902200000,0,24]
- (9) CW_RCZ4_ON: To run Continuous Wave emission tests for RCZ4 module.
[AT\$CW=920800000,1,24]
- (10) CW_RCZ4_OFF: RCZ4 continuous wave Off [AT\$CW=920800000,0,24]
- (11) MOD_EU_ON: Modulation wave ON for EU
AT\$IF=868130000
ATS302=15 // set output power to maximum power level.*
AT\$CB=-1,1
- (12) MOD_US_ON: Modulation wave ON for US
AT\$IF=902200000
AT\$CB=-1,1
- (13) MOD_RCZ4_ON: Modulation wave ON for RCZ4
AT\$IF=920800000
AT\$CB=-1,1
- (14) MOD_EU(US/RCZ4)_OFF: Modulation wave Off [AT\$CB=-1,0]
- (15) Frame Data: Send a SIGFOX message for EU
ATS302=15 // set output power to maximum power level.*
AT\$SF= xxxxxxxxxxxx
- (16) Frame Data: Send a SIGFOX message for US Tx only
AT\$GI? → return X,Y
If X=0 or Y<3
AT\$RC
AT\$SF= xxxxxxxxxxxx
- (17) Frame Data: Send a SIGFOX message for RCZ4 Tx only
AT\$GI? → return X,Y
If X=0 or Y<3
AT\$RC
AT\$SF= xxxxxxxxxxxx

* Execute S/W reset to ensure Tx frequency on payload data sending with Send(XX) button because Tx frequency can be changed when RF TEST buttons executed.

* By default, register 302 is set to 14 level which leads to an output power of 12.5dBm. Use the command ATS302=15 to set the output power to the maximum power level. This register is only accessible for RCZ1 module.

- Key switch
 - (1) Public: switch to public key [ATS410=1]
 - (2) Private: switch to private key [ATS410=0]

AT command complete set

A typical serial terminal emulator can also be used to control the EVK instead of the proposed test SW. In that case the following parameters should be used:


- Speed : 9600 bauds
- Data bits: 8
- Stop bits: 1
- Parity: None

Confidential Only for UTS
February 27, 2017

The following table gather all AT command available:

| Command | Name | Description | | | | | | | | | | | | |
|----------------------------|-----------------------------------|--|------|-------|-------------|-----------|------------------------|--|------|------|--------------------------------------|-------|------|-----------------------------|
| AT | Dummy Command | Just returns 'OK' and does nothing else. Can be used to check communication. | | | | | | | | | | | | |
| AT\$SB=bit[,bit] | Send Bit | Send a bit status (0 or 1). Optional bit flag indicates if AX-SFEU should receive a downlink frame. | | | | | | | | | | | | |
| AT\$SF=frame[,bit] | Send Frame | Send payload data, 1 to 12 bytes. Optional bit flag indicates if AX-SFEU should receive a downlink frame. | | | | | | | | | | | | |
| AT\$SO | Manually send out of band message | Send the out-of-band message. | | | | | | | | | | | | |
| AT\$TR? | Get the transmit repeat | Returns the number of transmit repeats. Default: 2 | | | | | | | | | | | | |
| AT\$TR=? | Get transmit range | Returns the allowed range of transmit repeats. | | | | | | | | | | | | |
| AT\$TR=uint | Get transmit repeat | Sets the transmit repeat. | | | | | | | | | | | | |
| AT\$uint? | Get Register | Query a specific configuration register's value. See chapter "Registers" for a list of registers. | | | | | | | | | | | | |
| AT\$uint=uint | Set Register | Change a configuration register. | | | | | | | | | | | | |
| AT\$uint=? | Get Register Range | Returns the allowed range of transmit repeats. | | | | | | | | | | | | |
| AT\$IF=uint | Set TX Frequency | Set the output carrier macro channel for Sigfox frames. | | | | | | | | | | | | |
| AT\$IF? | Get TX Frequency | Get the currently chosen TX frequency. | | | | | | | | | | | | |
| AT\$DR=uint | Set RX Frequency | Set the reception carrier macro channel for Sigfox frames. | | | | | | | | | | | | |
| AT\$DR? | Get RX Frequency | Get the currently chosen RX frequency. | | | | | | | | | | | | |
| AT\$CW=uint,bit[,uint_opt] | Continuous Wave | <p>To run emission tests for Sigfox certification it is necessary to send a continuous wave, i.e. just the base frequency without any modulation. Parameters:</p> <table> <tr> <th>Name</th><th>Range</th><th>Description</th></tr> <tr> <td>Frequency</td><td>800000000–999999999, 0</td><td>Continuous wave frequency in Hz. Use 868130000 for Sigfox or 0 to keep previous frequency.</td></tr> <tr> <td>Mode</td><td>0, 1</td><td>Enable or disable carrier wave.</td></tr> <tr> <td>Power</td><td>0–14</td><td>dBm of signal Default: 14</td></tr> </table> | Name | Range | Description | Frequency | 800000000–999999999, 0 | Continuous wave frequency in Hz. Use 868130000 for Sigfox or 0 to keep previous frequency. | Mode | 0, 1 | Enable or disable carrier wave. | Power | 0–14 | dBm of signal Default: 14 |
| Name | Range | Description | | | | | | | | | | | | |
| Frequency | 800000000–999999999, 0 | Continuous wave frequency in Hz. Use 868130000 for Sigfox or 0 to keep previous frequency. | | | | | | | | | | | | |
| Mode | 0, 1 | Enable or disable carrier wave. | | | | | | | | | | | | |
| Power | 0–14 | dBm of signal Default: 14 | | | | | | | | | | | | |
| AT\$CB=uint_opt,bit | Test Mode: TX constant byte | <p>For emission testing it is useful to send a specific bit pattern. The first parameter specifies the byte to send. Use '-1' for a (pseudo-)random pattern. Parameters:</p> <table> <tr> <th>Name</th><th>Range</th><th>Description</th></tr> <tr> <td>Pattern</td><td>0–255, -1</td><td>Byte to send. Use '-1' for a (pseudo-)random pattern.</td></tr> <tr> <td>Mode</td><td>0, 1</td><td>Enable or disable pattern test mode.</td></tr> </table> | Name | Range | Description | Pattern | 0–255, -1 | Byte to send. Use '-1' for a (pseudo-)random pattern. | Mode | 0, 1 | Enable or disable pattern test mode. | | | |
| Name | Range | Description | | | | | | | | | | | | |
| Pattern | 0–255, -1 | Byte to send. Use '-1' for a (pseudo-)random pattern. | | | | | | | | | | | | |
| Mode | 0, 1 | Enable or disable pattern test mode. | | | | | | | | | | | | |
| AT\$T? | Get Temperature | Measure internal temperature and return it in 1/10 th of a degree Celsius. | | | | | | | | | | | | |
| AT\$V? | Get Voltages | Return current voltage and voltage measured during the last transmission in mV. | | | | | | | | | | | | |

| Command | Name | Description | | | | | | | | | | | | | | | | | | | | | | |
|------------|---|---|------|-------------|----|------------------|----|-----------------|----|-----------------------------|----|---------------------------|----|---|----|---|----|------------|----|------------|----|------------|----|------------|
| AT\$I=uint | Information | Display various product information: 0: Software Name & Version Example Response: AX-SFEU 1.0.6-ETSI 1: Contact Details Example Response: support@axsem.com 2: Silicon revision lower byte Example Response: 8F 3: Silicon revision upper byte Example Response: 00 4: Major Firmware Version Example Response: 1 5: Minor Firmware Version Example Response: 0 7: Firmware Variant (Frequency Band etc. (EU/US)) Example Response: ETSI 8: Firmware VCS Version Example Response: v1.0.2-36 9: SIGFOX Library Version Example Response: DL0-1.4 10: Device ID Example Response: 00012345 11: PAC Example Response: 0123456789ABCDEF | | | | | | | | | | | | | | | | | | | | | | |
| AT\$P=uint | Set Power Mode | To conserve power, the AX-SFEU can be put to sleep manually. Depending on power mode, you will be responsible for waking up the AX-SFEU again. 0: software reset (settings will be reset to values in flash) 1: sleep (send a break to wake up) 2: deep sleep (toggle GPIOs or RESET_N pin to wake up; the AX-SFEU is not running and all settings will be reset!) | | | | | | | | | | | | | | | | | | | | | | |
| AT\$WR | Save Config | Write all settings to flash (RX/TX frequencies, registers) so they survive reset/deep sleep or loss of power. Use AT\$P=0 to reset the AX-SFEU and load settings from flash. | | | | | | | | | | | | | | | | | | | | | | |
| AT:Pn? | Get GPIO Pin | Return the setting of the GPIO Pin <i>n</i> ; <i>n</i> can range from 0 to 9. A character string is returned describing the mode of the pin, followed by the actual value. If the pin is configured as analog pin, then the voltage (range 0...1 V) is returned. The mode characters have the following meaning: <table><tr><th>Mode</th><th>Description</th></tr><tr><td>0</td><td>Pin drives low</td></tr><tr><td>1</td><td>Pin drives high</td></tr><tr><td>Z</td><td>Pin is high impedance input</td></tr><tr><td>U</td><td>Pin is input with pull-up</td></tr><tr><td>A</td><td>Pin is analog input (GPIO pin 0...3 only)</td></tr><tr><td>T</td><td>Pin is driven by clock or DAC (GPIO pin 0 and 4 only)</td></tr></table> The default mode after exiting reset is U on all GPIO pins. | Mode | Description | 0 | Pin drives low | 1 | Pin drives high | Z | Pin is high impedance input | U | Pin is input with pull-up | A | Pin is analog input (GPIO pin 0...3 only) | T | Pin is driven by clock or DAC (GPIO pin 0 and 4 only) | | | | | | | | |
| Mode | Description | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | Pin drives low | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | Pin drives high | | | | | | | | | | | | | | | | | | | | | | | |
| Z | Pin is high impedance input | | | | | | | | | | | | | | | | | | | | | | | |
| U | Pin is input with pull-up | | | | | | | | | | | | | | | | | | | | | | | |
| A | Pin is analog input (GPIO pin 0...3 only) | | | | | | | | | | | | | | | | | | | | | | | |
| T | Pin is driven by clock or DAC (GPIO pin 0 and 4 only) | | | | | | | | | | | | | | | | | | | | | | | |
| AT:Pn=? | Get GPIO Pin Range | Print a list of possible modes for a pin. The table below lists the response. <table><tr><th>Pin</th><th>Modes</th></tr><tr><td>P0</td><td>0, 1, Z, U, A, T</td></tr><tr><td>P1</td><td>0, 1, Z, U, A</td></tr><tr><td>P2</td><td>0, 1, Z, U, A</td></tr><tr><td>P3</td><td>0, 1, Z, U, A</td></tr><tr><td>P4</td><td>0, 1, Z, U, T</td></tr><tr><td>P5</td><td>0, 1, Z, U</td></tr><tr><td>P6</td><td>0, 1, Z, U</td></tr><tr><td>P7</td><td>0, 1, Z, U</td></tr><tr><td>P8</td><td>0, 1, Z, U</td></tr><tr><td>P9</td><td>0, 1, Z, U</td></tr></table> | Pin | Modes | P0 | 0, 1, Z, U, A, T | P1 | 0, 1, Z, U, A | P2 | 0, 1, Z, U, A | P3 | 0, 1, Z, U, A | P4 | 0, 1, Z, U, T | P5 | 0, 1, Z, U | P6 | 0, 1, Z, U | P7 | 0, 1, Z, U | P8 | 0, 1, Z, U | P9 | 0, 1, Z, U |
| Pin | Modes | | | | | | | | | | | | | | | | | | | | | | | |
| P0 | 0, 1, Z, U, A, T | | | | | | | | | | | | | | | | | | | | | | | |
| P1 | 0, 1, Z, U, A | | | | | | | | | | | | | | | | | | | | | | | |
| P2 | 0, 1, Z, U, A | | | | | | | | | | | | | | | | | | | | | | | |
| P3 | 0, 1, Z, U, A | | | | | | | | | | | | | | | | | | | | | | | |
| P4 | 0, 1, Z, U, T | | | | | | | | | | | | | | | | | | | | | | | |
| P5 | 0, 1, Z, U | | | | | | | | | | | | | | | | | | | | | | | |
| P6 | 0, 1, Z, U | | | | | | | | | | | | | | | | | | | | | | | |
| P7 | 0, 1, Z, U | | | | | | | | | | | | | | | | | | | | | | | |
| P8 | 0, 1, Z, U | | | | | | | | | | | | | | | | | | | | | | | |
| P9 | 0, 1, Z, U | | | | | | | | | | | | | | | | | | | | | | | |
| AT:Pn=mode | Set GPIO Pin | Set the GPIO pin mode. For a list of the modes see the command AT:Pn? | | | | | | | | | | | | | | | | | | | | | | |

| Command | Name | Description | | | | | | | | | | | | | | | |
|---------------------------|-----------------------------|--|------|-----------------|-------------|---|--------|--------|---|--------|-----------|---|----------|--------|---|----------|-----------|
| AT:ADC Pn[-Pn[(1V 10V)]]? | Get GPIO Pin Analog Voltage | Measure the voltage applied to a GPIO pin. The command also allows measurement of the voltage difference across two GPIO pins. In differential mode, the full scale range may also be specified as 1 V or 10 V. Note however that the pin input voltages must not exceed the range 0..VDD_IO. The command returns the result as fraction of the full scale range (1 V if none is specified). The GPIO pins referenced should be initialized to analog mode before issuing this command. | | | | | | | | | | | | | | | |
| AT:SPI[(A B C D)]=bytes | SPI Transaction | <p>This command clocks out bytes on the SPI port. The clock frequency is 312.5 kHz. The command returns the bytes read on MISO during output. Optionally the clocking mode may be specified (default is A):</p> <table> <thead> <tr> <th>Mode</th><th>Clock Inversion</th><th>Clock Phase</th></tr> </thead> <tbody> <tr> <td>A</td><td>normal</td><td>normal</td></tr> <tr> <td>B</td><td>normal</td><td>alternate</td></tr> <tr> <td>C</td><td>inverted</td><td>normal</td></tr> <tr> <td>D</td><td>inverted</td><td>alternate</td></tr> </tbody> </table>  <p>Note that SEL, if needed, is not generated by this command, and must instead be driven using standard GPIO commands (AT:Pn=0 1).</p> | Mode | Clock Inversion | Clock Phase | A | normal | normal | B | normal | alternate | C | inverted | normal | D | inverted | alternate |
| Mode | Clock Inversion | Clock Phase | | | | | | | | | | | | | | | |
| A | normal | normal | | | | | | | | | | | | | | | |
| B | normal | alternate | | | | | | | | | | | | | | | |
| C | inverted | normal | | | | | | | | | | | | | | | |
| D | inverted | alternate | | | | | | | | | | | | | | | |
| AT:CLK=freq,reffreq | Set Clock Generator | Output a square wave on the pin(s) set to T mode. The frequency of the square wave is $(\text{freq} / 2^{16}) \times \text{reffreq}$. Possible values for reffreq are 20000000, 10000000, 5000000, 2500000, 1250000, 625000, 312500, 156250. Possible values if freq are 0...65535. | | | | | | | | | | | | | | | |
| AT:CLK=OFF | Turn off Clock Generator | Switch off the clock generator | | | | | | | | | | | | | | | |
| AT:CLK? | Get Clock Generator | Return the settings of the clock generator. Two numbers are returned, freq and reffreq. | | | | | | | | | | | | | | | |
| AT:DAC=value | Set $\Sigma\Delta$ DAC | Output a $\Sigma\Delta$ DAC value on the pin(s) set to T mode. Parameter value may be in the range -32768...32767. The average output voltage is $(1/2 + \text{value} / 2^{17}) \times \text{VDD}$. An external low pass filter is needed to get smooth output voltages. The modulation frequency is 20 MHz. A possible low pass filter choice is a simple RC low pass filter with $R = 10 \text{ k}\Omega$ and $C = 1 \mu\text{F}$. | | | | | | | | | | | | | | | |
| AT:DAC=OFF | Turn off $\Sigma\Delta$ DAC | Switch off the DAC | | | | | | | | | | | | | | | |
| AT:DAC? | Get $\Sigma\Delta$ DAC | Return the DAC value | | | | | | | | | | | | | | | |

| Command | Name | Description |
|--------------------|----------------------------------|--|
| AT\$TM=mode,config | Activates the Sigfox Testmode | <p>Available test modes:</p> <ol style="list-style-type: none"> 0. TX BPSK Send only BPSK with Synchro Bit + Synchro frame + PN sequence: No hopping centered on the TX_frequency. Config bits 0 to 6 define the number of repetitions. Bit 7 of config defines if a delay is applied or not in the loop 1. TX Protocol: Tx mode with full protocol with Sigfox key: Send Sigfox protocol frames with initiate downlink flag = True. Config defines the number of repetitions. 2. RX Protocol: This mode tests the complete downlink protocol in Downlink only. Config defines the number of repetitions. 3. RX GFSK: RX mode with known pattern with SB + SF + Pattern on RX_frequency (internal comparison with received frame ⇔ known pattern = AA AA B2 27 1F 20 41 84 32 68 C5 BA AE 79 E7 F6 DD 9B. Config defines the number of repetitions. Config defines the number of repetitions. 4. RX Sensitivity: Does uplink + downlink frame with Sigfox key and specific timings. This test is specific to SIGFOX's test equipments & softwares. 5. TX Synthesis: Does one uplink frame on each Sigfox channel to measure frequency synthesis step |
| AT\$SE | Starts AT\$TM-3,255 indefinitely | Convenience command for sensitivity tests |
| AT\$SL[=frame] | Send local loop | Sends a local loop frame with optional payload of 1 to 12 bytes. Default payload: 0x84, 0x32, 0x68, 0xC5, 0xBA, 0x53, 0xAE, 0x79, 0xE7, 0xF6, 0xDD, 0x9B. |
| AT\$RL | Receive local loop | Starts listening for a local loop. |

Specific recommendation for each module

RCZ1 module (SFM10R1)

- Default output power is set to 12.5dBm.
To set the output power to 14dBm, use <ATS302=15> before sending a SIGFOX frame.

RCZ2 module (SFM10R2)

- The output power is set to 22dBm and cannot be adjusted.
- To send a frame the following procedure should be followed:

AT\$GI? → return X,Y

If X=0 or Y<3

AT\$RC

AT\$SF= xxxxxxxxxxxx

This procedure will force the module to send the frame within the macro channel listened by SIGFOX network.

- To send a frame with a downlink request, the following procedure should be followed:

AT\$RC

AT\$SF= xxxxxxxxxxxx,1

RCZ4 module (SFM10R4)

- The output power is set to 22dBm and cannot be adjusted.
- To send a frame the following procedure should be followed

AT\$GI? → return X,Y

If X=0 or Y<3

AT\$RC

AT\$SF= xxxxxxxxxxxx

This procedure will force the module to send the frame within the macro channel listened by SIGFOX network.

- To send a frame with a downlink request, the following procedure should be followed:

AT\$RC

AT\$SF= xxxxxxxxxxxx,1