


Creating a parameter file for Translator

1. Copy star.param file from Builder/translator directory to work area
2. Open star.param
 - 2.1 Edit Star.cel, Star.vrt, and Star.usr to show where they are located
 - 2.2 Change scalarname lines to respective scalars
 - 2.3 For StarCD, "writeoption" should be Option 1
 - 2.4 Enter one of the following on the scale index line:

Enter: For scale factor of:

- | | |
|---|--|
| 0 | No scale, corresponding to a scale factor of 1.0 |
| 1 | Custom scale, indicating that the SCALEFACTOR tag will be used to specify a scale factor |
| 2 | Meters to feet, corresponding to a scale factor of 3.28 |
| 3 | Millimeters to feet, corresponding to a scale factor of 3.28e-3 |
| 4 | Inches to feet, corresponding to a scale factor of 1.0/12.0 |
| 5 | Meters (1:12) scale to feet, corresponding to a scale factor of 12.0*3.28 |

2.5 VR space is always in feet, so the scale factor tag must be in feet.



```
File Edit Search Preferences Shell Macro Windows Help
VES_test/Untitled byte 1315, col 0, 1315 bytes

1 STARCEL=/home/user_directory/star.cel // a *.cel file is required
2 STARVRT=/home/user_directory/star.vrt // a *.vrt file is required
3 STARUSR=/home/user_directory/star.usr // a *.usr file is required
4 VECTORNAME=velocity // the columns of the *.usr file must be labeled
5 SCALARNAME=scalar1 // the columns of the *.usr file must be labeled
6 SCALARNAME=scalar2 // the columns of the *.usr file must be labeled
7 SCALARNAME=scalar3 // the columns of the *.usr file must be labeled
8 ROTATEX=0 // optional: the x-rotation component (default = 0 degrees)
9 ROTATEY=0 // optional: the y-rotation component (default = 0 degrees)
10 ROTATEZ=0 // optional: the z-rotation component (default = 0 degrees)
11 TRANSLATEX=0 // optional: the x-translation component (default = 0 feet)
12 TRANSLATEY=0 // optional: the y-translation component (default = 0 feet)
13 TRANSLATEZ=0 // optional: the z-translation component (default = 0 feet)
14 SCALEINDEX=1 // optional: uses integer indices defined in translateToVtk.cpp to set scale factor
15 SCALEFACTOR=.083333333 // optional: the scale factor (default = 1, unless SCALEINDEX > 1)
16 WRITEOPTION=1 // optional: 0=let vtk write the file(default), 1=directly write ascii to disk
17 OUTPUTFILENAME=flowdata.vtk // optional: specify the output file name
18
```

3. Save and close
4. Enter "vedemo"
5. Enter "translateToVtk" in your shell
6. Select data type to convert
7. Name the file
8. Enter "mergeVertices"
- 8.1 Enter file name for input
- 8.2 Enter file name for output

Note: After the mergeVertices step, you may get the following error message: "vtkDebugLeaks has detected LEAKS!" This is normal.

Note: take note of orientation (size, etc.) and correct in VE-Xplorer parameter file if necessary*

9. Run meshViewer for visual verification of the location of the converted data

10. Run WhatIsScalarRange for information on data set type, bounding box, and scalar and vector**

10.1 Enter file name for input

10.2 Input shrink factor

11. Enter the integer corresponding to the scalar you want to activate

12. Pick an option for displaying cells

13. Manipulate the display views with the mouse:

--left: rotate

--right: zoom out

--middle: translate

14. Keyboard shortcuts:

--T: toggles mouse between joystick and trackball modes

--E: exit

*optional

**optional but recommended

[Preprocessor](#)