

Smart Call Center Phone Fix

THIS IS NOT AN OFFICIAL TECHNICAL PUBLICATION. THIS KNOWLEDGEBASE ENTRY IS THE PROPERTY OF CANON U.S.A. AND IS CONFIDENTIAL INFORMATION TO BE RETAINED FOR REFERENCE PURPOSES BY THE AUTHORIZED DEALER WITH WHOM SERVICE AGREEMENTS HAVE BEEN ENTERED INTO. USER AGREES TO INDEMNIFY CANON U.S.A., INC. AND TO HOLD IT HARMLESS AGAINST ANY CLAIM ARISING BY REASON OF THE POSSESSION OR USE THEREOF ITS UNAUTHORIZED USE IS PROHIBITED.


Product:
imageRUNNER ADVANCE C5000 Series

Title:
Replacing the Waste Toner Container


Problem:
Replacing the Waste Toner Container

Solution:


- 1 Open the front cover, holding both sides.



- 2 Lower the locking lever.




3 Pull out the waste toner container.




! CAUTION

When removing the waste toner container, be careful not to tilt it, as the toner may spill and get onto your hands or clothing. If toner gets onto your hands or clothing, wash them immediately with cold water. Washing them with warm water will set the toner, and make it impossible to remove the toner stains.


4 Insert the new waste toner container.



5 Return the locking lever to its original position.



6 Close the front cover of the main unit.



! CAUTION

When closing the front cover, be careful not to get your fingers caught, as this may result in personal injury.