



TDS330-01 Atmospheric Temperature, Humidity & Pressure Sensor

Thanh Dong Invest & Trading Co., LTD

Add: No.22/A22 Geleximco, Le Trong Tan, An Khanh, Hoai Duc, Ha Noi

T: +84-911 379 588

E: info@thanhdongcorp.com

W: www.thadosensor.com

Atmospheric Temperature, Humidity & Pressure Sensor is a professional measurement of air temperature, relative humidity & barometric pressure. Sensors are built-in the water-proof and anti-UV shelter. It is widely used in agriculture, forestry, meteorology as well as a climate chamber, warehousing and other places.

FEATURES

- High Sensitivity
- Fast response time
- Long service life
- Low consumption
- Good stability of output

Parts:

1. Sensor:1
2. Radiation shield and bracket(optional):1
3. Clamp(optional):1

SPECIFICATIONS

Item	Technical Specification		
	Temperature	Humidity	Pressure
Range	-40-60°C	0-100%RH	10-110kPa(100-1100mbar)
Resolution	0.01°C	0.05%RH	0.1mbar
Accuracy	±0.5°C	±3%RH	±1mbar
Long term stability	<0.1°C/year	<0.5%RH/year	<0.1mbar/year
Supply	Mark on the label		
Output Signal	4-20mA, 0-5V, RS485 MODBUS(RTU)①		
Current Consumption	<40mA(current output)		
Operating Temperature	-40°C~+80°C		
Ingress Protection	IP65		
Storage	10-60°C@20%-90%RH		
Weight(unpacked)	700g		
Shelter material	Anti-UV engineering plastics		

①If choose three parameter sensor output, output can only be RS485.

3

OUTPUT CHARACTERISTICS

● Current

$T = (I - 4) / 16 * 100 - 40$, (where T = temperature(°C), I = output current(mA))

$H = (I - 4) / 16 * 100\%$, ((where H = humidity(RH), I = output current(mA)))

● Voltage

$T = V / V_{full\ scale} * 100 - 40$, (where T = temperature(°C), V= output voltage(V), $V_{full\ scale}$ = 5V or 10V)

$H = V / V_{full\ scale} * 100\%$, (where H = humidity(RH), V= output voltage(V), $V_{full\ scale}$ = 5V or 10V)

● RS485

If the transmission distance is over 100m, please add a 120Ω terminal matching resistances on the front end and back end of bus interface respectively. Attach communication protocol.

MOUNTING

- Install the product in stable environment area, avoid direct sunlight, away from windows air-conditioning, heating and other equipment. Otherwise it will cause measurement inaccuracies.
- Fixing rail is optional.

ELECTRICAL CONNECTIONS

Cable	Voltage/Current	Cable	RS485
Red	V+	Red	V+
Blue	T-Signal	Yellow	RS485A
Black	V-	Black/Blue	V-
White	H-Signal	Green	RS485B

Note: This product has been tested and complies with European CE requirements for EMC directive.

WARRANTY

This product is warranted to be free of defects in materials and construction for a period of 12 months from date of lead time.
Liability is limited to repair or replacement of defective item.

Communication Protocol (MODBUS)

Transmission mode: MODBUS-RTU,Baud rate: 9600bps,Data bits:8,Stop bit:1,Check bit:no

Slave address:the factory default is01H (set according to the need,00H to FFH)

- The 03H Function Code Example: Read The Atmospheric Temperature, Humidity & Pressure

Host Scan Order(Slave addr:0x01):

01 03 00 00 00 03 05CB

Slave Response:

01 03 06 01 21 0164 2728 C76E

Temperature:(0121)H=(298)D,289/10=28.9(℃)

Humidity:(0164)H=356(D), 356/10=35.6%

Pressure:(2728)H=10024(D),10024/10=1002.4(mbar)

- The 03H Function Code Example: Read The Atmospheric Temperature & Humidity

Host Scan Order(Slave addr:0x01):

01 03 00 00 00 02 0C0B

Slave Response:

01 03 04 1114 0164 BF70

Temperature:(0114)H=(276)D,276/10=27.6(℃)

If the data ≥ 0x8000, for example:0xFF05,according to the following method to calculate:
0xFF05-0xFFFF-0x01=(65285)D-(65535)D-(1)D=(-251)D,-251/10=-25.1(℃)

Humidity:(0164)H=356(D),356/10=35.6(%)

- The 03H Function Code Example: Read The Atmospheric Temperature

Host Scan Order(Slave addr:0x01):

01 03 00 00 00 01 840A

Slave Response:

01 03 02 1114 B41B

Temperature:(1114)H=(276)D,276/10=27.6(℃)

- The 06H Function Code Example: Modify the slave address(fixed command,ensure that no other devices on the bus)

Host Scan Order (Changed 01H to 02H):

01 06 00 00 00 02 08 0B

Slave Response:

01 06 02 00 02 39 49

If you forget the original address, you should use the broadcast address(FEH) (ensure that no other devices on the bus at this time).

Note:

- All underlined is fixed bit;
- The last two bytes is CRC check command.

CE Complies with applicable CE directives.

Manual subject to change without notice. Version 2.0

Copyright © 2019 Thanh Dong Invest & Trading Co., LTD