



# **Build application templates for your organization**

## **Cloud Manager**

Tom Onacki  
August 03, 2021

# Table of Contents

- Build application templates for your organization. . . . . 1
  - Quick start . . . . . 1
  - Requirements . . . . . 1
  - Examples of creating resources using templates. . . . . 2
  - Examples of enabling services using templates . . . . . 16
  - What to do after you have created the template . . . . . 20
  - Edit or delete a template . . . . . 20

# Build application templates for your organization

Select one or more of the NetApp-provided "actions" and quickly build an application template that your organization can use to start optimizing the creation of resources.

## Quick start

Get started quickly by following these steps, or scroll down to the remaining sections for full details.



### Verify required prerequisites

- Before users can create a volume for a Cloud Volumes ONTAP, on-premises ONTAP, or Azure NetApp Files system using a template, make sure they have access to an appropriate working environment where the volume will be deployed.
- If you plan to add a Cloud service "action" to your template, such as [Cloud Backup](#) or [Cloud Data Sense](#), ensure that the service is active and licensed in your environment.



### Launch the Application Templates service

Select the **AppTemplate** service, click the **Editor** tab, and select the template.



### Build the template by selecting "actions" and defining parameters

Follow the creation steps and define the actions that will be performed by the template.

## Requirements

Read the following requirements to make sure that you have a supported configuration.

- If you don't already have a Connector, [see how to create Connectors](#) for AWS, Azure, and GCP.
- When creating a Cloud Volumes ONTAP volume template, make sure you have a Cloud Volumes ONTAP working environment available for your users. See how to launch a Cloud Volumes ONTAP system in [AWS](#), [Azure](#), or in [GCP](#).
- When creating an on-premises ONTAP volume template, make sure you have an on-premises ONTAP working environment available for your users. See how to [discover an on-premises ONTAP system](#) in Cloud Manager.
- When creating an Azure NetApp Files volume template, make sure you have an Azure NetApp Files working environment available for your users. See how to [create an Azure NetApp Files working environment](#) in Cloud Manager.
- If you plan to enable Cloud Backup in the template, ensure that your environment has an active and licensed Cloud Backup service.
- If you plan to enable Cloud Data Sense in the template, ensure that your environment has an active and licensed Cloud Data Sense service.

- If you plan to enable Replication in the template, and the template is for an on-premises ONTAP volume, the ONTAP cluster must have an active SnapMirror license.

## Examples of creating resources using templates

Resource templates enable you to create new volumes or a new Cloud Volumes ONTAP working environment.

### Create a template for a Cloud Volumes ONTAP volume

See [how to provision Cloud Volumes ONTAP volumes](#) for details about all the parameters you need to complete in the Cloud Volumes ONTAP volume template.

For this example we'll create a template named "CVO volume for databases" and include the following 2 actions:

- Create Cloud Volumes ONTAP Volume

Make the volume for the AWS environment, configure it with 100 GB of storage, set the Snapshot Policy to "default", and enable Storage Efficiency.


- Enable Cloud Backup

Create daily backups with a retention value of 30 copies.

#### Steps

1. Select the **AppTemplate** service, click the **Templates** tab, and click **Add New Template**.

The *Select\_a Template* page is displayed.



2. Select **Volume for Cloud Volumes ONTAP + Backup** as the type of resource you want to create, and click **Get Started**.

The *Create Volume in Cloud Volumes ONTAP Action Definition* page is displayed.

The screenshot shows the 'Create Volume in Cloud Volumes ONTAP Action Definition' page. The left pane displays a workflow diagram with two steps: 'Create Volume in Cloud Volumes ONTAP (#1da)' and 'Enable Cloud Backup (#a09)'. The right pane contains configuration options for the action, including Volume Name, Volume Size (GB), Tags, Protection, and Usage Profile.

3. **Action Name:** Optionally, enter a customized action name instead of the default value.
4. **Details:** Enter the volume name and size.

Field	Description
Volume Name	Click in the field and select one of the 5 options. You can let the admin enter any name by selecting <b>Free Text</b> , or you can specify that the volume name must have a certain prefix or suffix, that it <i>contains</i> certain characters, or that it follows rules from a regular expression (regex) you enter.  For example, you could specify that "db" be a required prefix, suffix, or contains; requiring the user to add volume names like "db_vol1", "vol1_db", or "vol_db_1".
Volume Size	You can specify a range of allowable values, or you can specify a fixed size. This value is in GB. For our example we can add a fixed value <b>100</b> .
Tags	Enter a name and value pair for a tag that you want to associate with this volume. For example, you could add "Cost Center" as the tag name and the cost center code "6655829" as the value. You can associate more than one tag with a volume by adding more tag name and value pairs.

5. **Protection:** Choose whether this volume will have Snapshot copies created by selecting "Default" or some other policy, or choose "None" if you do not want to create Snapshot copies.
6. **Usage Profile:** Choose whether or not NetApp storage efficiency features are applied to the volume. This includes Thin Provisioning, Deduplication, and Compression. For our example, keep storage efficiency enabled.

7. **Disk Type:** Choose the cloud storage provider and the type of disk. For some disk selections you can also select a minimum and maximum IOPS or Throughput (MB/s) value; basically defining a certain Quality of Service (QoS).
8. **Protocol Options:** Select **NFS** or **SMB** to set the protocol of the volume. And then the provide the protocol details.

NFS Fields	Description
Access Control	Choose whether access controls are needed to access the volume.
Export Policy	Create an export policy to define the clients in the subnet that can access the volume.
NFS Version	Select the NFS version for the volume: either <i>NFSv3</i> or <i>NFSv4</i> , or you can select both.

SMB Fields	Description
Share Name	Click in the field and select one of the 5 options. You can let the admin enter any name (Free Text) or you can specify that the share name must have a certain prefix or suffix, that it <i>contains</i> certain characters, or that it follows rules from a regular expression (regex) you enter.
Permissions	Select the level of access to a share for users and groups (also called access control lists, or ACLs).
Users / Groups	Specify local or domain Windows users or groups, or UNIX users or groups. If you specify a domain Windows user name, you must include the user's domain using the format domain\username.

9. **Tiering:** Choose the tiering policy that you would like applied to the volume, or set this to "None" if you do not want to tier cold data from this volume to object storage.

See [volume tiering policies](#) for an overview, and see [Tiering inactive data to object storage](#) to make sure your environment is set up for tiering.

10. **Context:** Enter the Cloud Volumes ONTAP working environment context; if required.

When users launch the template from an existing working environment, this information gets filled in automatically.

When users launch the template from the Templates Dashboard (not in a working environment context), then they need to select the working environment and the SVM where the volume will be created. That's why these fields are marked as "Editable".

11. Click **Apply** after you have defined the parameters needed for this action.

If the template values are correctly completed, a green checkmark is added to the "Create Volume in Cloud Volumes ONTAP" box.

12. Click the **Enable Cloud Backup** box and the *Enable Cloud Backup Action Definition* dialog is displayed so you can fill in the Cloud Backup details.

**Enable Cloud Backup (#a09)**

Action Definition

**Policy - Retention & Schedule**

Backup Every ☐ Editable ☐ Drift  
 Day

Number of backups to retain ☐ Editable ☐ Drift

Minimum Maximum  
☐ Enter minimum Enter maximum

Fixed value  
☒ 30

**Context**

Working Environment ☒ Editable ☐ Drift  
 Select Working Environment

Storage VM ☒ Editable ☐ Drift  
 Select Storage VM

Volume Name ☐ Editable ☐ Drift

Get input value from action  
 Create Volume in Cloud Volumes ONTAP (#1da)  
 Volume Name

Apply Cancel

13. Define the backup policy to create daily backups with a 30-day retention value.
14. Below the Volume Name field there are three fields you use to indicate which volume will have backup enabled. See [how to complete these fields](#).
15. Click **Apply** and the Cloud Backup dialog is saved.
16. Enter the template name **CVO volume for databases** (for this example) in the top left.
17. Click **Settings & Drift** to provide a more detailed description so that this template can be distinguished from other similar templates, and so you can enable Drift for the overall template, and then click **Apply**.

Drift allows Cloud Manager to monitor the hard-coded values you entered for parameters when creating this template.

18. Click **Save Template**.

## Result

The template is created and you are returned to the Templates Dashboard where your new template appears.

See [what you should tell your users about templates](#).

## Create a template for an Azure NetApp Files volume


Creating a template for an Azure NetApp Files volume is done in the same manner as creating a template for a Cloud Volumes ONTAP volume.

See [how to provision Azure NetApp Files volumes](#) for details about all the parameters you need to complete in the ANF volume template.

### Steps

1. Select the **AppTemplate** service, click the **Templates** tab, and click **Add New Template**.

The *Select\_a Template* page is displayed.



2. Select **Volume for Azure NetApp Files** as the type of resource you want to create, and click **Get Started**.

The *Create Volume in Azure NetApp Files Action Definition* page is displayed.



Enter a name for this template

Reset Zoom

Create Volume in Azure NetApp Files (#23c)

Create Volume in Azure NetApp Files (#23c)

Volume Name ? ☐ Editable ☐ Drift

Select...

Volume Size (GB) ☐ Editable ☐ Drift

Minimum Maximum

☐ Enter minimum Enter maximum

Fixed value

☒ Enter volume size in GB

Tags ☒ Editable ☐ Drift

+ Add Tags

Protocol

Protocol ☐ Editable ☐ Drift

☒ NFSv3 ☐ NFSv4.1 ☐ SMB

Volume Path ? ☐ Editable ☐ Drift

Select...

Apply Cancel

3. **Action Name:** Optionally, enter a customized action name instead of the default value.
4. **Volume Details:** Enter a volume name and size, and optionally specify tags for the volume.

Field	Description
Volume Name	<p>Click in the field and select one of the 5 options. You can let the admin enter any name by selecting <b>Free Text</b>, or you can specify that the volume name must have a certain prefix or suffix, that it <i>contains</i> certain characters, or that it follows rules from a regular expression (regex) you enter.</p> <p>For example, you could specify that "db" be a required prefix, suffix, or contains; requiring the user to add volume names like "db_vol1", "vol1_db", or "vol_db_1".</p>
Volume Size	You can specify a range of allowable values, or you can specify a fixed size. This value is in GB.
Tags	Enter a name and value pair for a tag that you want to associate with this volume. For example, you could add "Cost Center" as the tag name and the cost center code "6655829" as the value. You can associate more than one tag with a volume by adding more tag name and value pairs.

5. **Protocol:** Select **NFSv3**, **NFSv4.1**, or **SMB** to set the protocol of the volume. And then the provide the protocol details.

NFS Fields	Description
Volume Path	Select one of the 5 options. You can let the admin enter any path by selecting <b>Free Text</b> , or you can specify that the path name must have a certain prefix or suffix, that it <i>contains</i> certain characters, or that it follows rules from a regular expression (regex) you enter.

NFS Fields	Description
Export Policy Rules	Create an export policy to define the clients in the subnet that can access the volume.

SMB Fields	Description
Volume Path	Select one of the 5 options. You can let the admin enter any path by selecting <b>Free Text</b> , or you can specify that the path name must have a certain prefix or suffix, that it <i>contains</i> certain characters, or that it follows rules from a regular expression (regex) you enter.

6. **Context:** Enter the Azure NetApp Files working environment, details for a new or an existing Azure NetApp Files account, and other details.

Field	Description
Working Environment	When storage admin users launch the template from an existing working environment, this information gets filled in automatically.  When users launch the template from the Templates Dashboard (not in a working environment context), then they need to select the working environment where the volume will be created.
NetApp Account Name	Enter the name you want to use for the account.
Azure Subscription ID	Enter the Azure Subscription ID. This is the full ID in a format similar to "2b04f26-7de6-42eb-9234-e2903d7s327".
Region	Enter the region using the <a href="#">internal region name</a> .
Resource Group Name	Enter the name of the Resource Group you want to use.
Capacity Pool Name	Enter the name of an existing capacity pool.
Subnet	Enter the VNet and subnet. This value includes the full path, in a format similar to "/subscriptions/<subscription_id>/resourceGroups/<resource_group>/providers/Microsoft.Network/virtualNetworks/<vpc_name>/subnets/<subhet_name>".

7. **Snapshot Copy:** Enter the Snapshot ID for an existing volume Snapshot if you want this new volume to be created using characteristics from an existing volume.
8. Click **Apply** after you have defined the parameters needed for this action.
9. Enter the name you want to use for the template in the top left.
10. Click **Settings & Drift** to provide a more detailed description so that this template can be distinguished from other similar templates, and so you can enable Drift for the overall template, and then click **Apply**.

Drift allows Cloud Manager to monitor the hard-coded values you entered for parameters when creating this template.

11. Click **Save Template**.

## Result

The template is created and you are returned to the Templates Dashboard where your new template appears.

See [what you should tell your users about templates](#).

## Create a template for an on-premises ONTAP volume

See [how to provision on-premises ONTAP volumes](#) for details about all the parameters you need to complete in the on-premises ONTAP volume template.

### Steps

1. Select the **AppTemplate** service, click the **Templates** tab, and click **Add New Template**.

The *Select\_a Template* page is displayed.

### Select a Template to Get Started

Choose a template for the type of resource you want to create and then customize the parameters for what's required in your environment.

For even greater flexibility, choose the "blank" template to mix and match configurations and to apply additional Cloud Manager services.

Start with a template of:

☒ Blank template

☐ Volume for Cloud Volumes ONTAP + Backup

☐ Volume for Cloud Volumes ONTAP + Backup + Compliance

☐ Volume for Azure NetApp files + Compliance

Get StartedCancel

2. Select **Blank template** and click **Get Started**.

The *Add New Action* page is displayed.

Add New Action

Q

Search for actions

ACTIONS - RESOURCES

Create Volume in Azure NetApp Files

Create Volume in Cloud Volumes ONTAP

Create Volume in On-Premises ONTAP

Create Working Environment in AWS (single node)

ACTIONS - SERVICES

Activate Cloud Data Sense on Volume

Apply

Cancel

3. Select **Create Volume in On-Premises ONTAP** as the type of resource you want to create, and click **Apply**.

The *Create Volume in On-Premises ONTAP Action Definition* page is displayed.

Enter a name for this template

Reset Zoom

Create Volume in On-Premises ONTAP (#7b6)

+

Create Volume in On-Premises ONTAP (#7b6)

Action Definition

Details

Volume Name

Select...

☐ Editable
 ☐ Drift

Volume Size (GB)

☐ Minimum
 ☐ Maximum

Enter minimum

Enter maximum

Fixed value

☒ Enter volume size

Tags

☒ Editable
 ☐ Drift

+

Add Tags

Protection

Snapshot Policy

Select snapshot policy

☐ Editable
 ☐ Drift

Usage Profile

Apply

Cancel

10

4. **Action Name:** Optionally, enter a customized action name instead of the default value.

5. **Details:** Enter the volume name and size.

Field	Description
Volume Name	<p>Click in the field and select one of the 5 options. You can let the admin enter any name by selecting <b>Free Text</b>, or you can specify that the volume name must have a certain prefix or suffix, that it <i>contains</i> certain characters, or that it follows rules from a regular expression (regex) you enter.</p> <p>For example, you could specify that "db" be a required prefix, suffix, or contains; requiring the user to add volume names like "db_vol1", "vol1_db", or "vol_db_1".</p>
Volume Size	<p>You can specify a range of allowable values, or you can specify a fixed size. This value is in GB. For our example we can add a fixed value <b>100</b>.</p>
Tags	<p>Enter a name and value pair for a tag that you want to associate with this volume. For example, you could add "Cost Center" as the tag name and the cost center code "6655829" as the value. You can associate more than one tag with a volume by adding more tag name and value pairs.</p>

6. **Protection:** Choose whether this volume will have Snapshot copies created by selecting "Default" or some other policy, or choose "None" if you do not want to create Snapshot copies.

7. **Usage Profile:** Choose whether or not NetApp storage efficiency features are applied to the volume. This includes Thin Provisioning, Deduplication, and Compression.

8. **Protocol Options:** Select **NFS** or **SMB** to set the protocol of the volume. And then the provide the protocol details.

NFS Fields	Description
Access Control	Choose whether access controls are needed to access the volume.
Export Policy	Create an export policy to define the clients in the subnet that can access the volume.
NFS Version	Select the NFS version for the volume: either <i>NFSv3</i> or <i>NFSv4</i> , or you can select both.

SMB Fields	Description
Share Name	Click in the field and select one of the 5 options. You can let the admin enter any name (Free Text) or you can specify that the share name must have a certain prefix or suffix, that it <i>contains</i> certain characters, or that it follows rules from a regular expression (regex) you enter.
Permissions	Select the level of access to a share for users and groups (also called access control lists, or ACLs).
Users / Groups	Specify local or domain Windows users or groups, or UNIX users or groups. If you specify a domain Windows user name, you must include the user's domain using the format domain\username.

9. **Context:** Enter the on-premises ONTAP working environment context; if required.

When users launch the template from an existing working environment, this information gets filled in automatically.

When users launch the template from the Templates Dashboard (not in a working environment context), then they need to select the working environment, the SVM, and the aggregate where the volume will be created.

10. Click **Apply** after you have defined the parameters needed for this action.

If the template values are correctly completed, a green checkmark is added to the "Create Volume in On-Premises ONTAP" box.

11. Enter the template name in the top left.

12. Click **Settings & Drift** to provide a more detailed description so that this template can be distinguished from other similar templates, and so you can enable Drift for the overall template, and then click **Apply**.

Drift allows Cloud Manager to monitor the hard-coded values you entered for parameters when creating this template.

13. Click **Save Template**.

### Result

The template is created and you are returned to the Template Dashboard where your new template appears.

See [what you should tell your users about templates](#).

## Create a template for a Cloud Volumes ONTAP working environment

You can create a Cloud Volumes ONTAP working environment using templates.



- This support is provided only for AWS environments at this time, and only for single-node clusters.
- This template doesn't create the first volume in the working environment. You must add a "Create Volume in Cloud Volumes ONTAP" action in the template to create the volume.

See [how to launch a single-node Cloud Volumes ONTAP system in AWS](#) for the prerequisites that must be in place, and for details about all the parameters you need to complete in this template.

### Steps


1. Select the **AppTemplate** service, click the **Templates** tab, and click **Add New Template**.

The *Select\_a Template* page is displayed.

## Select a Template to Get Started

Choose a template for the type of resource you want to create and then customize the parameters for what's required in your environment.

For even greater flexibility, choose the "blank" template to mix and match configurations and to apply additional Cloud Manager services.



Start with a template of:

Blank template

Volume for Cloud Volumes  
ONTAP + Backup

Volume for Cloud Volumes  
ONTAP + Backup + Compliance

Volume for Azure NetApp files +  
Compliance

Get Started

Cancel

2. Select **Blank template** and click **Get Started**.

The *Add New Action* page is displayed.

Add New Action

Search for actions

ACTIONS - RESOURCES

Create Volume in Azure NetApp Files

Create Volume in Cloud Volumes ONTAP

Create Volume in On-Premises ONTAP

Create Working Environment in AWS (single node)

ACTIONS - SERVICES

Activate Cloud Data Sense on Volume

Apply

Cancel

3. Select **Create Working Environment in AWS (single node)** as the type of resource you want to create, and click **Apply**.

The *Create Working Environment in AWS (single node)* page is displayed.

**Create Working Environment in AWS (single node) (#a22)**

Action Definition

Action Name ⓘ

Create Working Environment in AWS (single node) (#a22)

**Details and Credentials**

Credentials ☐ Editable ☐ Drift

Working Environment Name ⓘ ☐ Editable ☐ Drift

Tags ☒ Editable ☐ Drift

+ Add Tags

4. **Action Name:** Optionally, enter a customized action name instead of the default value.
5. **Details and Credentials:** Select the AWS credentials to use, enter a working environment name, and add tags, if needed.

Some of the fields in this page are self-explanatory. The following table describes fields for which you might need guidance:

Field	Description
Credentials	These are the credentials for the Cloud Volumes ONTAP cluster admin account. You can use these credentials to connect to Cloud Volumes ONTAP through ONTAP System Manager or its CLI.
Working Environment Name	Cloud Manager uses the working environment name to name both the Cloud Volumes ONTAP system and the Amazon EC2 instance. It also uses the name as the prefix for the predefined security group, if you select that option.  Click in the field and select one of the 5 options. You can let the admin enter any name by selecting <b>Free Text</b> , or you can specify that the working environment name must have a certain prefix or suffix, that it <i>contains</i> certain characters, or that it follows rules from a regular expression (regex) you enter.



Field	Description
Tags	<p>AWS tags are metadata for your AWS resources. Cloud Manager adds the tags to the Cloud Volumes ONTAP instance and each AWS resource associated with the instance.</p> <p>For information about tags, refer to <a href="#">AWS Documentation: Tagging your Amazon EC2 Resources</a>.</p>

6. **Location & Connectivity:** Enter the network information that you recorded in the [AWS worksheet](#). This includes the AWS Region, VPC, Subnet, and Security Group.

If you have an AWS Outpost, you can deploy a single node Cloud Volumes ONTAP system in that Outpost by selecting the Outpost VPC. The experience is the same as any other VPC that resides in AWS.

7. **Authentication Method:** Select the SSH authentication method you want to use; either a password or a key pair.
8. **Data Encryption:** Choose no data encryption or AWS-managed encryption.

For AWS-managed encryption, you can choose a different Customer Master Key (CMK) from your account or another AWS account.


[Learn how to set up the AWS KMS for Cloud Volumes ONTAP.](#)

9. **Charging Method:** Specify which charging option would you like to use with this system.

[Learn about these charging methods.](#)

10. **NSS Account:** Select a NetApp Support Site account.
11. **Preconfigured Packages:** Select one of the four preconfigured packages that will determine several factors for volumes created in the working environment.
12. **SMB Configuration:** If you plan to deploy volumes using SMB on this working environment, you can set up a CIFS server and related configuration elements.
13. Click **Apply** after you have defined the parameters needed for this action.

If the template values are correctly completed, a green checkmark is added to the "Create Working Environment in AWS (single node)" box.

14. You may want to add another action in this template to create a volume for this working environment. If so, click  and add that action. See how to [Create a template for a Cloud Volumes ONTAP volume](#) for details.
15. Enter the template name in the top left.
16. Click **Settings & Drift** to provide a more detailed description so that this template can be distinguished from other similar templates, and so you can enable Drift for the overall template, and then click **Apply**.

Drift allows Cloud Manager to monitor the hard-coded values you entered for parameters when creating this template.

17. Click **Save Template**.

## Result

The template is created and you are returned to the Template Dashboard where your new template appears.

See [what you should tell your users about templates](#).

## Examples of enabling services using templates

Service templates enable you to activate Cloud Backup, Cloud Data Sense, or Replication (SnapMirror) services on a newly created volume.

### Add Backup functionality to a volume

When creating a volume template, you can add in the template that you want to create backups of the volume periodically using the [Cloud Backup](#) service. This action is not applicable for Azure NetApp Files volumes.

### Enable Cloud Backup

Action Definition

#### Context

Working Environment ☒ Editable ☐ Drift

Select Working Environment

Storage VM ☒ Editable ☐ Drift

Select Storage VM

#### Policy - Retention & Schedule

Backup Every ☐ Editable ☐ Drift

Week X

Number of backups to retain ☐ Editable ☐ Drift

Minimum

☐ Enter minimum

Maximum

☐ Enter maximum

Fixed value

☒ 52

Volume Name ⓘ ☐ Editable ☐ Drift

Select

Apply

Cancel

1. **Context:** You can enter a working environment Name and storage VM name if you are using this action in a template without first creating a volume. Otherwise, leave these fields as "Editable."
2. **Policy:** Define the backup policy to create daily, weekly, or monthly backups with a specific number of backup copies to retain.

3. **Volume Name:** Typically the volume is the one created prior to the backup action in the same template. In this case, see how to [complete the fields](#) within the volume name to indicate that volume.
4. Click **Apply** to save your changes.

## Add Data Sense functionality to a volume

When creating a volume template, you can add in the template that you want to scan the volume for compliance and classification using the [Cloud Data Sense](#) service.

### Activate Cloud Data Sense on Volume

Action Definition

**Context**

Working Environment ☒ Editable ☐ Drift

Select Working Environment

Volume Name ⓘ ☐ Editable ☐ Drift

Select

Volume UUID ⓘ ☐ Editable ☐ Drift

Select

Volume Path ⓘ ☐ Editable ☐ Drift

Select

Protocol ⓘ ☐ Editable ☐ Drift

Select

Apply

Cancel

1. **Working Environment:** You can enter a working environment Name if you are using this action in a template without first creating a volume. Otherwise, leave this field as "Editable."
2. **Volume Name:** Typically the volume is the one created prior to the Data Sense action in the same template. In this case, see how to [complete the fields](#) within the volume name to indicate that volume.
3. **Volume UUID:** Data Sense needs the UUID of the volume before it can scan the volume. See how to [complete the three fields](#) below the volume name to indicate that volume.
4. **Volume Path:** Typically this is the mount point from the volume you are creating in the template. So you can get the "mountpoint" value from the output of that volume.
5. **Protocol:** Data Sense needs to know the protocol so it can scan the data. So you can get the "Protocol" value from the output of that volume.
6. Click **Apply** to save your changes.

## Add Replication functionality to a volume

When creating a volume template, you can add in the template that you want to replicate the data in the volume to another volume using the [Replication](#) service. You can replicate data to a Cloud Volumes ONTAP cluster or to an on-prem ONTAP cluster.



This action is not applicable for Azure NetApp Files volumes.

Replication functionality consists of three parts: selecting the source volume, selecting the destination volume, and defining the replication settings. Each section is described below.

1. **Source Details:** Enter the details about the source volume you want to replicate:

**Source Details** ⓘ

Source Working Environment ☐ Editable ☐ Drift

Select source Working Environment ▼

Source Storage VM ☐ Editable ☐ Drift

Select source Storage VM ▼

Source Volume Name ⓘ ☐ Editable ☐ Drift

Select ▼

Source intercluster LIF IPs ⓘ ☒ Editable ☐ Drift

Intercluster LIF IP (1)

Add Source intercluster LIF IPs

- a. Select the working environment where the volume resides.
- b. Select the storage VM on which the volume resides.
- c. Typically the volume is the one created prior to the replication action in the same template. In this case, see how to [complete the fields](#) within the Source Volume Name field to indicate that volume.
- d. Replication requires that the source and destination working environments are connected through their intercluster LIFs. Enter the intercluster LIF IP address for the source working environment.

To get this information: double-click the working environment, click the menu icon, and click Information.

2. **Destination Details:** Enter the details about the destination volume that will be created by the replication operation:

**Destination Details** ⓘ

Destination Working Environment
☐ Editable
☐ Drift

Select destination Working Environment

Destination Storage VM
☐ Editable
☐ Drift

Select destination Storage VM

Destination Aggregate Name
☐ Editable
☐ Drift

Select destination Aggregate

Destination Volume name ⓘ
☐ Editable
☐ Drift

Select...

Destination intercluster LIF IPs ⓘ
☒ Editable
☐ Drift

Intercluster LIF IP (1)

+ Add Destination intercluster LIF IPs

Destination Provider
☐ Editable
☐ Drift

AWS

Destination Disk Type
☐ Editable
☐ Drift

GP2 - General Purpose SSD

- Select the working environment where the volume will be created.
  - Select the storage VM on which the volume will reside.
  - Select the aggregate on which the volume will reside.
  - For the destination volume, click in the field and select one of the 5 options. You can let the admin enter any name by selecting **Free Text**, or you can specify that the volume name must have a certain prefix or suffix, that it *contains* certain characters, or that it follows rules from a regular expression (regex) you enter.
  - Replication requires that the source and destination working environments are connected through their intercluster LIFs. Enter the intercluster LIF IP address for the destination working environment.
  - When replicating a volume to a Cloud Volumes ONTAP cluster (not to an on-prem ONTAP cluster), you need to specify the Destination Provider (AWS, Azure, or GCP) and the type of disk that will be used for the new volume.
3. **Replication Details:** Enter the details about the type and frequency of the replication operation:

Replication Details ⓘ

Replication Policy ⓘ

☐ Editable
☐ Drift

Schedule

☐ Editable
☐ Drift

☐ Enable replication health monitoring

☐ Editable
☐ Drift

Enable Transfer Rate Limit

☐ Editable
☐ Drift

☒ Limit transfer rate
☐ Unlimited (recommended for DR only machines)

Transfer Rate Limit (KB/s) ⓘ

☐ Editable
☐ Drift

Minimum

Maximum

☐

Enter minimum

Enter maximum

Fixed value

☒

Enter a value for transfer rate limit

- a. Select the [replication policy](#) that you want to use.
- b. Choose a one-time copy or a recurring replication schedule.
- c. Enable replication health monitoring if you want the drift report to include the replication health of the SnapMirror relationship along with the lag time, status, and last transfer time. [See what this looks like in the drift report.](#)
- d. Select whether you want to set a transfer rate limit, and then enter the maximum rate (in kilobytes per second) at which data can be transferred. You can enter a fixed value, or you can provide a minimum and maximum and let the storage admin select a value in that range.

4. Click **Apply** to save your changes.

## What to do after you have created the template

After you have created a template, you should inform your storage administrators to use the template when creating new working environments and volumes.

You can point them to [Creating resources using templates](#) for details.

## Edit or delete a template

You can modify a template if you need to change any of the parameters. After you save your changes, all future resources created from the template will use the new parameter values.

You can also delete a template if you no longer need it. Deleting a template does not affect any of the

resources that were created with the template. However, no Drift compliance checking can be done after the template is deleted.

1 Templates

Q

Add new template

Template Name	Template Description	Created by	Last Modified	Parameters	Resources created	
CVO volume for databases	Volume for Oracle databases requiring large and fast disks.	Tom Onacki	Apr 05 2021, 3:32:14 pm	<a href="#">View</a>	0	<div><div>Run Drift</div><div>Run Template</div><div>Edit Template</div><div>Delete Template</div></div>

## Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system-without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

## Trademark Information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.