

i.MX8 HSM API Rev 4.2

NXP Copyright

Generated by Doxygen 1.8.17

1 HSM API	1
2 Revision History	1
3 General concepts related to the API	4
3.1 Session	4
3.2 Service flow	4
3.3 Example	5
3.4 Key store	5
3.4.1 Key management	5
3.4.2 NVM writing	5
3.5 Implementation specificities	6
4 Module Index	6
4.1 Modules	6
5 Data Structure Index	8
5.1 Data Structures	8
6 Module Documentation	8
6.1 Session	8
6.1.1 Detailed Description	9
6.1.2 Data Structure Documentation	9
6.1.3 Function Documentation	10
6.2 Key management	12
6.2.1 Detailed Description	15
6.2.2 Data Structure Documentation	15
6.2.3 Macro Definition Documentation	18
6.2.4 Function Documentation	19
6.3 Ciphering	23
6.3.1 Detailed Description	23
6.3.2 Data Structure Documentation	23
6.3.3 Function Documentation	24
6.4 Signature generation	28
6.4.1 Detailed Description	29
6.4.2 Data Structure Documentation	29
6.4.3 Macro Definition Documentation	30
6.4.4 Function Documentation	31
6.5 Signature verification	34
6.5.1 Detailed Description	34
6.5.2 Data Structure Documentation	34
6.5.3 Function Documentation	35
6.6 Random number generation	38
6.6.1 Detailed Description	38

6.6.2 Data Structure Documentation	38
6.6.3 Function Documentation	38
6.7 Hashing	41
6.7.1 Detailed Description	41
6.7.2 Data Structure Documentation	41
6.7.3 Macro Definition Documentation	42
6.7.4 Function Documentation	42
6.8 Data storage	45
6.8.1 Detailed Description	45
6.8.2 Data Structure Documentation	45
6.8.3 Function Documentation	46
6.9 Authenticated Encryption	48
6.9.1 Detailed Description	48
6.9.2 Function Documentation	48
6.10 Mac	49
6.10.1 Detailed Description	49
6.10.2 Data Structure Documentation	49
6.10.3 Function Documentation	50
6.11 Public key reconstruction	53
6.11.1 Detailed Description	53
6.11.2 Data Structure Documentation	53
6.11.3 Function Documentation	53
6.12 Public key decompression	55
6.12.1 Detailed Description	55
6.12.2 Data Structure Documentation	55
6.12.3 Function Documentation	55
6.13 ECIES encryption	57
6.13.1 Detailed Description	57
6.13.2 Data Structure Documentation	57
6.13.3 Function Documentation	58
6.14 Root KEK export	59
6.14.1 Detailed Description	59
6.14.2 Data Structure Documentation	59
6.14.3 Function Documentation	59
6.15 SM2 Get Z	62
6.15.1 Detailed Description	62
6.15.2 Data Structure Documentation	62
6.15.3 Function Documentation	62
6.16 SM2 ECES decryption	64
6.16.1 Detailed Description	64
6.16.2 Data Structure Documentation	64
6.16.3 Function Documentation	65

6.17 SM2 ECES encryption	67
6.17.1 Detailed Description	67
6.17.2 Data Structure Documentation	67
6.17.3 Function Documentation	67
6.18 Key exchange	69
6.18.1 Detailed Description	70
6.18.2 Data Structure Documentation	70
6.18.3 Function Documentation	71
6.19 Standalone butterfly key expansion	75
6.19.1 Detailed Description	75
6.19.2 Data Structure Documentation	75
6.19.3 Function Documentation	76
6.20 Key generic crypto service	78
6.20.1 Detailed Description	78
6.20.2 Data Structure Documentation	78
6.20.3 Function Documentation	79
6.21 Dump Firmware Log	81
6.21.1 Detailed Description	81
6.21.2 Data Structure Documentation	81
6.22 Dev attest	82
6.22.1 Detailed Description	82
6.22.2 Data Structure Documentation	82
6.22.3 Function Documentation	82
6.23 Dev Info	84
6.23.1 Detailed Description	84
6.23.2 Data Structure Documentation	84
6.23.3 Function Documentation	84
6.24 Generic Crypto: Asymmetric Crypto	86
6.24.1 Detailed Description	87
6.24.2 Data Structure Documentation	87
6.24.3 Function Documentation	88
6.25 Generic Crypto Asymmetric Key Generate	89
6.25.1 Detailed Description	89
6.25.2 Data Structure Documentation	89
6.25.3 Function Documentation	89
6.26 Get Info	91
6.26.1 Detailed Description	91
6.26.2 Data Structure Documentation	91
6.26.3 Function Documentation	91
6.27 Public key recovery	93
6.27.1 Detailed Description	93
6.27.2 Data Structure Documentation	93

6.27.3 Function Documentation	93
6.28 Key store	95
6.28.1 Detailed Description	95
6.28.2 Data Structure Documentation	95
6.28.3 Function Documentation	96
6.29 LC update	98
6.29.1 Detailed Description	98
6.29.2 Data Structure Documentation	98
6.30 Error codes	99
6.30.1 Detailed Description	99
6.30.2 Enumeration Type Documentation	99
6.31 i.MX8QXP specificities	101
6.32 i.MX8DXL specificities	105
7 Data Structure Documentation	108
7.1 op_but_key_exp_args_t Struct Reference	108
7.1.1 Field Documentation	108
7.2 op_ecies_dec_args_t Struct Reference	110
7.2.1 Field Documentation	111
7.3 op_import_public_key_args_t Struct Reference	112
7.3.1 Field Documentation	112
7.4 op_manage_key_group_args_t Struct Reference	113
7.4.1 Field Documentation	113
Index	115

1 HSM API

This document is a software reference description of the API provided by the i.MX8 HSM solutions.


2 Revision History

Revision	date	description
0.1	Mar 29 2019	Preliminary draft
0.8	May 24 2019	It adds the following API: -signature generation -signature verification -rng -hash -butterfly key expansion -ECIES enc/dec -public key reconstruction -public key decompression
0.9	May 28 2019	Explicit addresses are replaced by pointers.

Revision	date	description
1.0	May 29 2019	<ul style="list-style-type: none"> - bug/typos fix. - Change HSM_SVC_KEY_STORE_FLAGS definition
1.1	July 31 2019	<ul style="list-style-type: none"> - hsm_butterfly_key_expansion argument definition: dest_key_identifier is now a pointer. - add error code definition. - improve argument comments clarity
1.5	Sept 13 2019	<ul style="list-style-type: none"> - manage key argument: fix padding size - butterfly key expansion: change argument definition - introduce public key recovery API
1.6	Oct 14 2019	<ul style="list-style-type: none"> - add Key store section in chapter 3 - change key_info and flags definition, substitute key_type_ext with group_id - hsm_generate_key, hsm_manage_key, hsm_butterfly_key_expansion: change argument definition - hsm_manage_key: change argument definition - add hsm_manage_key_group API
1.7	Dec 20 2019	<ul style="list-style-type: none"> - add generic data storage API - add GCM and CMAC support - add support for AES 192/256 key size for all cipher algorithms - add root KEK export API - add key import functionality - add get info API
2.0	Feb 21 2020	<ul style="list-style-type: none"> - fix HSM_KEY_INFO_TRANSIENT definition: delete erroneous "not supported" comment - add Key Encryption Key (HSM_KEY_INFO_KEK) support - key store open service API: adding signed message support for key store reprovisioning - naming consistency: remove "hsm_" prefix from <ul style="list-style-type: none"> hsm_op_ecies_dec_args_t hsm_op_pub_key_rec_args_t hsm_op_pub_key_dec_args_t hsm_op_ecies_enc_args_t hsm_op_pub_key_recovery_args_t hsm_op_get_info_args_t
2.1	Apr 16 2020	<ul style="list-style-type: none"> - Preliminary version: Add the support of the chinese algorithms and update for i.MX8DXL
2.2	Apr 30 2020	<ul style="list-style-type: none"> - fix erroneous number of supported key groups (correct number is 1000 while 1024 was indicated) - add missing status code definition - remove hsm_open_key_store_service unused flags: HSM_SVC_KEY_STORE_FLAGS_UPDATE, HSM_SVC_KEY_STORE_FLAGS_DELETE
2.3	June 30 2020	<ul style="list-style-type: none"> - hsm_get_info fips mode definition: now specifying "FIPS mode of operation" and "FIPS certified part" bits. - Update i.MX8QXP specificities section specifying operations disabled when in FIPS approved mode. - Update comments related to cipher_one_go and SM2 ECES APIs for i.MX8DXL
2.4	July 9 2020	<ul style="list-style-type: none"> - clarify support of hsm_import_public key API.
2.5	July 28 2020	<ul style="list-style-type: none"> - add section in "i.MX8QXP specificities" chapter indicating the maximum number of keys per group.
2.6	Jul 29 2020	<ul style="list-style-type: none"> - Key Exchange: add the definition of ECDH_P384 and TLS KDFs - mac_one_go: add definition of HMAC SHA256/384.
2.7	Sep 25 2020	<ul style="list-style-type: none"> - Key Exchange: additional TLS KDFs support, CMAC KDF replaced by SHA-256 KDF - mac_one_go: add support of HMAC SHA224/523.

Revision	date	description
2.8	Sep 30 2020	- Key Exchange: add details related to the SM2 key exchange.
2.9	Oct 14 2020	- key_store_open: add STRICT_OPERATION flag. This flag allows to export the key store in the external NVM at the key store creation.
3.0	Nov 16 2020	hsm_open_key_store_service: add min_mac_length argument. hsm_mac_one_go - verification: add HSM_OP_MAC_ONE_GO_FLAG↔ S_MAC_LENGTH_IN_BITS to represent mac_length in bit. hsm_key_exchange: - enforce new constraints on KEK and TLS key generations - add signed message arguments for KEK generation. - rename HSM_KDF_ALG_SHA_256 in HSM_KDF_ONE_STEP_SHA_↔ 256. - rename HSM_OP_KEY_EXCHANGE_FLAGS_USE_EPHEMERAL in HSM_OP_KEY_EXCHANGE_FLAGS_GENERATE_EPHEMERAL
3.1	Nov 20 2020	Enable support of key_exchange and HMAC on QXP
3.2	Dec 1 2020	hsm_generate_key, hsm_manage_key: fix key_group argument wrong description. User must specify the key group for CREATE/UPDATE/DELETE operations.
3.2 Amendement	Feb 3 2021	Clarify Key_exchange and HMAC support on QXP - both are not supported.
3.3	Jan 11 2021	Add hsm_tls_finish API. Update hsm_key_exchange description: - The TLS master_secret is now stored into the key store and accesible by the hsm_tls_finish API - TLS KDF: add support of extended master secret hsm_auth_enc API - GCM encryption (not backward compatible): the IV cannot be fully provided by the user anymore, it must be generated by the HSM instead.
3.4	Jan 13 2021	Add support of per-key min mac length using extension commands for key create and key manage.
3.5	Feb 5 2021	Clarify hsm_tls_finish support on QXP - not supported.
3.6	Feb 12 2021	Key exchange for KEK negotiation supported on QXP, usage of IV flags for auth_enc clarified.
3.7	Mar 19 2021	Add HSM_FATAL_FAILURE error code definition
3.8	April 30 2021	- hsm_open_key_store_service, hsm_generate_key_ext, hsm_manage↔ _key_ext: min_mac_len cannot be set to values < 32 bits when in FIPS approved mode. - Update hsm_key_exchange kdf_input_size argument description in case of TLS Key generation.
3.9	May 12 2021	- Butterfly key expansion: add the support of SM2 on DXL - Public key reconstruction: add the support of SM2 on DXL - Introduce standalone Butterfly key expansion API on DXL. - Butterfly key expansion, Public key reconstruction, ECIES enc/dec: remove the support of BR256T1 on DXL. - hsm_prepare_signature: specify max number of stored pre-calculated values. key exchange: add the support of BR256T1 on DXL.
4.0	Aug 05 2021	- Authenticated encryption: add the support of SM4 CCM on DXL. - Add key generic cryptographic service API on DXL.

3 General concepts related to the API



3.1 Session

The API must be initialized by a potential requestor by opening a session.

The session establishes a route (MU, DomainID...) between the requestor and the HSM. When a session is opened, the HSM returns a handle identifying the session to the requestor.

3.2 Service flow

For a given category of services, the requestor is expected to open a service flow by invoking the appropriate HSM API.

The session handle, as well as the control data needed for the service flow, are provided as parameters of the call. Upon reception of the open request, the HSM allocates a context in which the session handle, as well as the provided control parameters are stored and return a handle identifying the service flow.

The context is preserved until the service flow, or the session, are closed by the user and it is used by the HSM to proceed with the sub-sequent operations requested by the user on the service flow.

3.3 Example

```

/* Open a session: create a route between the user and the HSM */
hsm_open_session(&open_session_args, &session_hdl);

/* Open a key store - user is authenticated */
hsm_open_key_store_service(session_hdl, &open_svc_key_store_args, &key_store_hdl);
/* Open hash service - it grants access to hashing operations */
hsm_open_hash_service (session_hdl, &open_svc_hash_args, &hash_hdl);
/* Open cipher service - it grants access to ciphering operations */
hsm_open_cipher_service(key_store_hdl, &open_svc_cipher_args, &cipher_hdl);

/* Perform AES ECB, CCB ... */
hsm_cipher_one_go (cipher_hdl, &op_cipher_one_go_args);
/* Perform authenticate and encryption algos: e.g AES GCM */
hsm_auth_enc (cipher_hdl, &op_auth_enc_args);
/* Perform hashing operations: e.g SHA */
hsm_hash_one_go (hash_hdl, &op_hash_one_go_args);

/* Close the session and all the related services */
hsm_close_session(session_hdl);

```

3.4 Key store

A key store can be created by specifying the CREATE flag in the hsm_open_key_store_service API. Please note that the created key store will be not stored in the NVM till a key is generated/imported specifying the "STRICT OPERATION" flag.

Only symmetric and private keys are stored into the key store. Public keys can be exported during the key pair generation operation or recalculated through the hsm_pub_key_recovery API.

Secret keys cannot be exported under any circumstances, while they can be imported in encrypted form.

3.4.1 Key management

Keys are divided in groups, keys belonging to the same group are written/read from the NVM as a monolithic block. Up to 3 key groups can be handled in the HSM local memory (those immediately available to perform crypto operations), while up to 1000 key groups can be handled in the external NVM and imported in the local memory as needed.

If the local memory is full (3 key groups already reside in the HSM local memory) and a new key group is needed by an incoming user request, the HSM swaps one of the local key group with the one needed by the user request. The user can control which key group must be kept in the local memory (cached) through the manage_key_group API lock/unlock mechanism.

As general concept, frequently used keys should be kept, when possible, in the same key group and locked in the local memory for performance optimization.

3.4.2 NVM writing

All the APIs creating a key store (open key store API) or modifying its content (key generation, key management, key derivation functions) provide a "STRICT OPERATION" flag. If the flag is set, the HSM exports the relevant key store blocks into the external NVM and increments (blows one bit) the OTP monotonic counter used as roll back protection. In case of key generation/derivation/update the "STRICT OPERATION" has effect only on the target key

group.

Any update to the key store must be considered as effective only after an operation specifying the flag "STRICT OPERATION" is acknowledged by the HSM. All the operations not specifying the "STRICT OPERATION" flags impact the HSM local memory only and will be lost in case of system reset

Due to the limited monotonic counter size (QXPB0 up to 1620 update available by default), the user should, when possible, perform multiple updates before setting the "STRICT OPERATION" flag (i.e. keys to be updated should be kept in the same key group).

Once the monotonic counter is completely blown a warning is returned on each key store export to the NVM to inform the user that the new updates are not roll-back protected.

3.5 Implementation specificities

HSM API is supported on different versions of the i.MX8 family. The API description below is the same for all of them but some features may not be available on some chips. The details of the supported features per chip can be found here:

- for i.MX8QXP: [i.MX8QXP specificities](#)
- for i.MX8DXL: [i.MX8DXL specificities](#)

4 Module Index

4.1 Modules

Here is a list of all modules:

Session	8
i.MX8QXP specificities	101
i.MX8DXL specificities	105
Key management	12
Ciphering	23
i.MX8QXP specificities	101
i.MX8DXL specificities	105
Signature generation	28
i.MX8QXP specificities	101
i.MX8DXL specificities	105
Signature verification	34
i.MX8QXP specificities	101
i.MX8DXL specificities	105
Random number generation	38
Hashing	41

i.MX8QXP specificities	101
Data storage	45
Authenticated Encryption	48
Mac	49
i.MX8QXP specificities	101
i.MX8DXL specificities	105
Public key reconstruction	53
i.MX8QXP specificities	101
i.MX8DXL specificities	105
Public key decompression	55
i.MX8QXP specificities	101
ECIES encryption	57
i.MX8QXP specificities	101
i.MX8DXL specificities	105
Root KEK export	59
SM2 Get Z	62
i.MX8QXP specificities	101
SM2 ECES decryption	64
i.MX8QXP specificities	101
i.MX8DXL specificities	105
SM2 ECES encryption	67
i.MX8QXP specificities	101
i.MX8DXL specificities	105
Key exchange	69
i.MX8QXP specificities	101
i.MX8DXL specificities	105
Standalone butterfly key expansion	75
i.MX8QXP specificities	101
i.MX8DXL specificities	105
Key generic crypto service	78
i.MX8QXP specificities	101
Dump Firmware Log	81

Dev attest	82
Dev Info	84
Generic Crypto: Asymmetric Crypto	86
Generic Crypto Asymmetric Key Generate	89
Get Info	91
Public key recovery	93
Key store	95
LC update	98
Error codes	99

5 Data Structure Index

5.1 Data Structures

Here are the data structures with brief descriptions:

op_butb_key_exp_args_t	108
op_ecies_dec_args_t	110
op_import_public_key_args_t	112
op_manage_key_group_args_t	113

6 Module Documentation

6.1 Session

The API must be initialized by a potential requestor by opening a session.
Once a session is closed all the associated service flows are closed by the HSM.

Modules

- [i.MX8QXP specificities](#)
- [i.MX8DXL specificities](#)

Data Structures

- struct [hsm_session_hdl_s](#)
- struct [hsm_service_hdl_s](#)
- struct [open_session_args_t](#)

Macros

- `#define HSM_MAX_SESSIONS` (8u)
- `#define HSM_MAX_SERVICES` (32u)
- `#define HSM_OPEN_SESSION_PRIORITY_LOW` (0x00U)
Low priority. default setting on platforms that doesn't support sessions priorities.
- `#define HSM_OPEN_SESSION_PRIORITY_HIGH` (0x01U)
High Priority session.
- `#define HSM_OPEN_SESSION_FIPS_MODE_MASK` (1u << 0)
Only FIPS certified operations authorized in this session.
- `#define HSM_OPEN_SESSION_EXCLUSIVE_MASK` (1u << 1)
No other HSM session will be authorized on the same security enclave.
- `#define HSM_OPEN_SESSION_LOW_LATENCY_MASK` (1u << 3)
Use a low latency HSM implementation.
- `#define HSM_OPEN_SESSION_NO_KEY_STORE_MASK` (1u << 4)
No key store will be attached to this session. May provide better performances on some operation depending on the implementation. Usage of the session will be restricted to operations that doesn't involve secret keys (e.g. hash, signature verification, random generation).
- `#define HSM_OPEN_SESSION_RESERVED_MASK` ((1u << 2) | (1u << 5) | (1u << 6) | (1u << 7))
Bits reserved for future use. Should be set to 0.

Typedefs

- `typedef uint32_t hsm_hdl_t`

Functions

- `hsm_err_t hsm_open_session` (`open_session_args_t` *args, `hsm_hdl_t` *session_hdl)
- `hsm_err_t hsm_close_session` (`hsm_hdl_t` session_hdl)
- `struct hsm_session_hdl_s * session_hdl_to_ptr` (`uint32_t` hdl)
- `struct hsm_service_hdl_s * service_hdl_to_ptr` (`uint32_t` hdl)
- `void delete_session` (`struct hsm_session_hdl_s` *s_ptr)
- `void delete_service` (`struct hsm_service_hdl_s` *s_ptr)
- `struct hsm_session_hdl_s * add_session` (`void`)
- `struct hsm_service_hdl_s * add_service` (`struct hsm_session_hdl_s` *session)

6.1.1 Detailed Description

The API must be initialized by a potential requestor by opening a session. Once a session is closed all the associated service flows are closed by the HSM.

6.1.2 Data Structure Documentation

Data Fields

<code>struct plat_os_abs_hdl *</code>	<code>phdl</code>	Pointer to OS device node.
<code>uint32_t</code>	<code>session_hdl</code>	Session handle.
<code>uint32_t</code>	<code>mu_type</code>	Session MU type.

6.1.2.1 struct hsm_session_hdl_s

Data Fields

struct hsm_session_hdl_s *	session	Pointer to session handle.
uint32_t	service_hdl	Service handle.

6.1.2.2 struct hsm_service_hdl_s

Data Fields

uint32_t	session_hdl	Session handle.
uint8_t	session_priority	Priority of the operations performed in this session.
uint8_t	operating_mode	Options for the session to be opened (bitfield).
uint8_t	interrupt_idx	Interrupt number of the MU used to indicate data availability.
uint8_t	mu_id	index of the MU as per PLAT point of view.
uint8_t	tz	indicate if current partition has TZ enabled.
uint8_t	did	DID of the calling partition.

6.1.2.3 struct open_session_args_t

6.1.3 Function Documentation

6.1.3.1 hsm_open_session() `hsm_err_t hsm_open_session (`
 `open_session_args_t * args,`
 `hsm_hdl_t * session_hdl)`

Parameters

<i>args</i>	pointer to the structure containing the function arguments.
<i>session_hdl</i>	pointer to where the session handle must be written.

Returns

error_code error code.

6.1.3.2 hsm_close_session() `hsm_err_t hsm_close_session (`
 `hsm_hdl_t session_hdl)`

Terminate a previously opened session. All the services opened under this session are closed as well

Parameters

<code>session_hdl</code>	pointer to the handle identifying the session to be closed.
--------------------------	---

Returns

`error_code` error code.

6.2 Key management

Data Structures

- struct [op_delete_key_args_t](#)
- struct [op_get_key_attr_args_t](#)
- struct [op_import_key_args_t](#)
- struct [kek_enc_key_hdr_t](#)
- struct [op_generate_key_ext_args_t](#)
- struct [op_generate_key_args_t](#)
- struct [open_svc_key_management_args_t](#)
- struct [op_manage_key_args_t](#)
- struct [op_manage_key_ext_args_t](#)

Macros

- #define **HSM_OP_DEL_KEY_FLAGS_STRICT_OPERATION** ((hsm_op_import_key_flags_t)(1u << 7))
- #define **HSM_OP_IMPORT_KEY_INPUT_E2GO_TLV** ((hsm_op_import_key_flags_t)(1u << 0))
- #define **HSM_OP_IMPORT_KEY_INPUT_SIGNED_MSG** ((hsm_op_import_key_flags_t)(0u << 0))
- *Bit 1-6: Reserved.*
- #define **HSM_OP_IMPORT_KEY_FLAGS_STRICT_OPERATION** ((hsm_op_import_key_flags_t)(1u << 7))
- #define **HSM_KEY_USAGE_EXPORT** ((hsm_key_usage_t) (1u << 0))
- #define **HSM_KEY_USAGE_ENCRYPT** ((hsm_key_usage_t) (1u << 8))
- #define **HSM_KEY_USAGE_DECRYPT** ((hsm_key_usage_t) (1u << 9))
- #define **HSM_KEY_USAGE_SIGN_MSG** ((hsm_key_usage_t) (1u << 10))
- #define **HSM_KEY_USAGE_VERIFY_MSG** ((hsm_key_usage_t) (1u << 11))
- #define **HSM_KEY_USAGE_SIGN_HASH** ((hsm_key_usage_t) (1u << 12))
- #define **HSM_KEY_USAGE_VERIFY_HASH** ((hsm_key_usage_t) (1u << 13))
- #define **HSM_KEY_USAGE_DERIVE** ((hsm_key_usage_t) (1u << 14))
- #define **HSM_KEY_INFO_PERSISTENT** ((hsm_key_info_t)(0u << 1))
- *< Persistent keys are stored in the external NVM.*
- #define **HSM_KEY_INFO_PERMANENT** ((hsm_key_info_t)(1u << 0))
- *Transient keys are deleted when the corresponding key store service flow is.*
- #define **HSM_KEY_INFO_TRANSIENT** ((hsm_key_info_t)(1u << 1))
- *When set, the key is considered as a master key.*
- #define **HSM_KEY_INFO_MASTER** ((hsm_key_info_t)(1u << 2))
- *When set, the key is considered as a key encryption key. KEK keys can only.*
- #define **HSM_KEY_INFO_KEK** ((hsm_key_info_t)(1u << 3))
- #define **FLAG_0** 0
- #define **HSM_OP_KEY_GENERATION_FLAGS_UPDATE** ((hsm_op_key_gen_flags_t)(1u << 0))
- *< User can replace an existing key only by generating a key with*
- #define **HSM_OP_KEY_GENERATION_FLAGS_CREATE** ((hsm_op_key_gen_flags_t)(1u << 1))
- #define **HSM_OP_KEY_GENERATION_FLAGS_STRICT_OPERATION** ((hsm_op_key_gen_flags_t)(1u << 7))
- #define **HSM_OP_MANAGE_KEY_FLAGS_IMPORT_UPDATE** ((hsm_op_manage_key_flags_t)(1u << 0))
- *Import a key and create a new identifier.*
- #define **HSM_OP_MANAGE_KEY_FLAGS_IMPORT_CREATE** ((hsm_op_manage_key_flags_t)(1u << 1))
- *Delete an existing key.*
- #define **HSM_OP_MANAGE_KEY_FLAGS_DELETE** ((hsm_op_manage_key_flags_t)(1u << 2))
- *The key to be imported is encrypted using the part-unique root kek.*

- `#define HSM_OP_MANAGE_KEY_FLAGS_PART_UNIQUE_ROOT_KEY ((hsm_op_manage_key_flags_t)(1u << 3))`
The key to be imported is encrypted using the common root kek.
- `#define HSM_OP_MANAGE_KEY_FLAGS_COMMON_ROOT_KEY ((hsm_op_manage_key_flags_t)(1u << 4))`
The request is completed only when the new key has been written in the NVM.
- `#define HSM_OP_MANAGE_KEY_FLAGS_STRICT_OPERATION ((hsm_op_manage_key_flags_t)(1u << 7))`

Typedefs

- `typedef uint8_t hsm_op_delete_key_flags_t`
- `typedef uint8_t hsm_op_import_key_flags_t`
Bit 0: Defines input configuration.
- `typedef uint32_t hsm_key_usage_t`
- `typedef uint16_t hsm_key_group_t`
- `typedef uint16_t hsm_key_info_t`
- `typedef uint8_t hsm_op_key_gen_flags_t`
- `typedef uint8_t hsm_svc_key_management_flags_t`
- `typedef uint8_t hsm_op_manage_key_flags_t`
- `typedef uint8_t hsm_op_manage_key_ext_flags_t`

Enumerations

- `enum hsm_storage_loc_t { HSM_SE_KEY_STORAGE = 0x00000000 }`
Indicating the key location indicator.
- `enum hsm_storage_persist_lvl_t {
HSM_VOLATILE_STORAGE = 0x0,
HSM_PERSISTENT_STORAGE = 0x1,
HSM_PERMANENT_STORAGE = 0xFF }`
Indicating the key persistent level indicator.
- `enum hsm_key_lifetime_t {
HSM_SE_KEY_STORAGE_VOLATILE = HSM_SE_KEY_STORAGE | HSM_VOLATILE_STORAGE,
HSM_SE_KEY_STORAGE_PERSISTENT = HSM_SE_KEY_STORAGE | HSM_PERSISTENT_STORAGE,
HSM_SE_KEY_STORAGE_PERS_PERM = HSM_SE_KEY_STORAGE | HSM_PERMANENT_STORAGE
}`
Indicating the key lifetime.
- `enum hsm_pubkey_type_t {
HSM_PUBKEY_TYPE_RSA = 0x4001,
HSM_PUBKEY_TYPE_ECC_BP_R1 = 0x4130,
HSM_PUBKEY_TYPE_ECC_NIST = 0x4112,
HSM_PUBKEY_TYPE_ECC_BP_T1 = 0xC180 }`
Indicating the public key type.
- `enum hsm_key_type_t {
HSM_KEY_TYPE_ECDSA_NIST_P224 = 0x01,
HSM_KEY_TYPE_ECDSA_NIST_P256 = 0x02,
HSM_KEY_TYPE_ECDSA_NIST_P384 = 0x03,
HSM_KEY_TYPE_ECDSA_NIST_P521 = 0x04,
HSM_KEY_TYPE_ECDSA_BRAINPOOL_R1_224 = 0x12,
HSM_KEY_TYPE_ECDSA_BRAINPOOL_R1_256 = 0x13,
HSM_KEY_TYPE_ECDSA_BRAINPOOL_R1_320 = 0x14,
HSM_KEY_TYPE_ECDSA_BRAINPOOL_R1_384 = 0x15,
HSM_KEY_TYPE_ECDSA_BRAINPOOL_R1_512 = 0x16,`

```

HSM_KEY_TYPE_ECDSA_BRAINPOOL_T1_224 = 0x22,
HSM_KEY_TYPE_ECDSA_BRAINPOOL_T1_256 = 0x23,
HSM_KEY_TYPE_ECDSA_BRAINPOOL_T1_320 = 0x24,
HSM_KEY_TYPE_ECDSA_BRAINPOOL_T1_384 = 0x25,
HSM_KEY_TYPE_ECDSA_BRAINPOOL_T1_512 = 0x26,
HSM_KEY_TYPE_AES_128 = 0x30,
HSM_KEY_TYPE_AES_192 = 0x31,
HSM_KEY_TYPE_AES_256 = 0x32,
HSM_KEY_TYPE_DSA_SM2_FP_256 = 0x42,
HSM_KEY_TYPE_SM4_128 = 0x50,
HSM_KEY_TYPE_HMAC_224 = 0x60,
HSM_KEY_TYPE_HMAC_256 = 0x61,
HSM_KEY_TYPE_HMAC_384 = 0x62,
HSM_KEY_TYPE_HMAC_512 = 0x63,
HSM_KEY_TYPE_RSA_2048 = 0x71,
HSM_KEY_TYPE_RSA_4096 = 0x73 }

```

Indicating the key type.

- enum `hsm_bit_key_sz_t` {


```

HSM_KEY_SIZE_HMAC_224 = 224,
HSM_KEY_SIZE_HMAC_256 = 256,
HSM_KEY_SIZE_HMAC_384 = 384,
HSM_KEY_SIZE_HMAC_512 = 512,
HSM_KEY_SIZE_AES_128 = 128,
HSM_KEY_SIZE_AES_192 = 192,
HSM_KEY_SIZE_AES_256 = 256,
HSM_KEY_SIZE_SM4_128 = 128,
HSM_KEY_SIZE_RSA_2048 = 2048,
HSM_KEY_SIZE_RSA_3072 = 3072,
HSM_KEY_SIZE_RSA_4096 = 4096,
HSM_KEY_SIZE_ECC_BP_R1_224 = 224,
HSM_KEY_SIZE_ECC_BP_R1_256 = 256,
HSM_KEY_SIZE_ECC_BP_R1_320 = 320,
HSM_KEY_SIZE_ECC_BP_R1_384 = 384,
HSM_KEY_SIZE_ECC_BP_R1_512 = 512,
HSM_KEY_SIZE_ECC_NIST_224 = 224,
HSM_KEY_SIZE_ECC_NIST_256 = 256,
HSM_KEY_SIZE_ECC_NIST_384 = 384,
HSM_KEY_SIZE_ECC_NIST_521 = 521,
HSM_KEY_SIZE_ECC_BP_T1_224 = 224,
HSM_KEY_SIZE_ECC_BP_T1_256 = 256,
HSM_KEY_SIZE_ECC_BP_T1_320 = 320,
HSM_KEY_SIZE_ECC_BP_T1_384 = 384 }

```

Indicating the key security size in bits.

- enum `hsm_permitted_algo_t` {


```

PERMITTED_ALGO_SHA224 = ALGO_HASH_SHA224,
PERMITTED_ALGO_SHA256 = ALGO_HASH_SHA256,
PERMITTED_ALGO_SHA384 = ALGO_HASH_SHA384,
PERMITTED_ALGO_SHA512 = ALGO_HASH_SHA512,
PERMITTED_ALGO_SM3 = ALGO_HASH_SM3,
PERMITTED_ALGO_HMAC_SHA256 = ALGO_HMAC_SHA256,
PERMITTED_ALGO_HMAC_SHA384 = ALGO_HMAC_SHA384,
PERMITTED_ALGO_CMAC = ALGO_CMAC,
PERMITTED_ALGO_CTR = ALGO_CIPHER_CTR,
PERMITTED_ALGO_CFB = ALGO_CIPHER_CFB,
PERMITTED_ALGO_OFB = ALGO_CIPHER_OFB,
PERMITTED_ALGO_ECB_NO_PADDING = ALGO_CIPHER_ECB_NO_PAD,
PERMITTED_ALGO_CBC_NO_PADDING = ALGO_CIPHER_CBC_NO_PAD,
PERMITTED_ALGO_CCM = ALGO_CCM,

```

```

PERMITTED_ALGO_GCM = ALGO_GCM,
PERMITTED_ALGO_RSA_PKCS1_V15_SHA224 = ALGO_RSA_PKCS1_V15_SHA224,
PERMITTED_ALGO_RSA_PKCS1_V15_SHA256 = ALGO_RSA_PKCS1_V15_SHA256,
PERMITTED_ALGO_RSA_PKCS1_V15_SHA384 = ALGO_RSA_PKCS1_V15_SHA384,
PERMITTED_ALGO_RSA_PKCS1_V15_SHA512 = ALGO_RSA_PKCS1_V15_SHA512,
PERMITTED_ALGO_RSA_PKCS1_PSS_MGF1_SHA224 = ALGO_RSA_PKCS1_PSS_MGF1_SHA224,
PERMITTED_ALGO_RSA_PKCS1_PSS_MGF1_SHA256 = ALGO_RSA_PKCS1_PSS_MGF1_SHA256,
PERMITTED_ALGO_RSA_PKCS1_PSS_MGF1_SHA384 = ALGO_RSA_PKCS1_PSS_MGF1_SHA384,
PERMITTED_ALGO_RSA_PKCS1_PSS_MGF1_SHA512 = ALGO_RSA_PKCS1_PSS_MGF1_SHA512,
PERMITTED_ALGO_ECDSA_SHA224 = ALGO_ECDSA_SHA224,
PERMITTED_ALGO_ECDSA_SHA256 = ALGO_ECDSA_SHA256,
PERMITTED_ALGO_ECDSA_SHA384 = ALGO_ECDSA_SHA384,
PERMITTED_ALGO_ECDSA_SHA512 = ALGO_ECDSA_SHA512,
PERMITTED_ALGO_HMAC_KDF_SHA256 = ALGO_HMAC_KDF_SHA256,
PERMITTED_ALGO_ALL_CIPHER = ALGO_CIPHER_ALL,
PERMITTED_ALGO_ALL_AEAD = ALGO_ALL_AEAD,
PERMITTED_ALGO_OTH_KEK_CBC = ALGO_CIPHER_KEK_CBC }
• enum hsm_key_lifecycle_t {
    HSM_KEY_LIFECYCLE_OPEN = 0x1,
    HSM_KEY_LIFECYCLE_CLOSED = 0x2,
    HSM_KEY_LIFECYCLE_CLOSED_LOCKED = 0x4 }

```

Functions

- [hsm_err_t hsm_delete_key](#) (hsm_hdl_t key_management_hdl, [op_delete_key_args_t](#) *args)
 - [hsm_err_t hsm_get_key_attr](#) (hsm_hdl_t key_management_hdl, [op_get_key_attr_args_t](#) *args)
 - [hsm_err_t hsm_import_key](#) (hsm_hdl_t key_management_hdl, [op_import_key_args_t](#) *args)
 - [hsm_err_t hsm_generate_key_ext](#) (hsm_hdl_t key_management_hdl, [op_generate_key_ext_args_t](#) *args)
 - [hsm_err_t hsm_generate_key](#) (hsm_hdl_t key_management_hdl, [op_generate_key_args_t](#) *args)
 - [hsm_err_t hsm_open_key_management_service](#) (hsm_hdl_t key_store_hdl, [open_svc_key_management_args_t](#) *args, hsm_hdl_t *key_management_hdl)
 - [hsm_err_t hsm_close_key_management_service](#) (hsm_hdl_t key_management_hdl)
 - [hsm_err_t hsm_manage_key](#) (hsm_hdl_t key_management_hdl, [op_manage_key_args_t](#) *args)
- User can replace an existing key only by importing a key with.*
- [hsm_err_t hsm_manage_key_ext](#) (hsm_hdl_t key_management_hdl, [op_manage_key_ext_args_t](#) *args)

6.2.1 Detailed Description

6.2.2 Data Structure Documentation

Data Fields

uint32_t	key_identifier	identifier of the key to be used for the operation.
hsm_op_delete_key_flags_t	flags	bitmap specifying the operation properties.

6.2.2.1 struct op_delete_key_args_t

Data Fields

uint32_t	key_identifier	identifier of the key to be used for the operation.
hsm_key_type_t	key_type	indicates which type of key must be generated.

Data Fields

hsm_bit_key_sz_t	bit_key_sz	
hsm_key_lifetime_t	key_lifetime	
hsm_key_usage_t	key_usage	
hsm_permitted_algo_t	permitted_algo	
hsm_key_lifecycle_t	lifecycle	

6.2.2.2 struct op_get_key_attr_args_t

Data Fields

uint32_t	key_identifier	Identifier of the KEK used to encrypt the key to be imported (Ignored if KEK is not used as set as part of "flags" field).
uint8_t *	input_lsb_addr	Address in the requester space where: <ul style="list-style-type: none"> • EdgeLock 2GO TLV can be found. • Ignore this field if not E2GO_TLV.
uint32_t	input_size	Size in bytes of: <ul style="list-style-type: none"> • EdgeLock 2GO TLV can be found. • Ignore this field if not E2GO_TLV.
hsm_op_import_key_flags_t	flags	bitmap specifying the operation properties.

6.2.2.3 struct op_import_key_args_t

Data Fields

uint8_t	iv[IV_LENGTH]	
uint8_t *	key	
uint32_t	tag	

6.2.2.4 struct kek_enc_key_hdr_t

Data Fields

uint32_t *	key_identifier	pointer to the identifier of the key to be used for the operation In case of create operation the new key identifier will be stored in this location
uint16_t	out_size	length in bytes of the generated key It must be 0 in case of symmetric keys
hsm_op_key_gen_flags_t	flags	bitmap specifying the operation properties
hsm_key_type_t	key_type	indicates which type of key must be generated
hsm_key_group_t	key_group	Key group of the generated key. It must be a value in the range 0-1023. Keys belonging to the same group can be cached in the HSM local memory through the hsm_manage_key_group API

Data Fields

hsm_key_info_t	key_info	bitmap specifying the properties of the key
uint8_t *	out_key	pointer to the output area where the generated public key must be written.
uint8_t	min_mac_len	min mac length in bits to be set for this key, value 0 indicates use default (see op_mac_one_go_args_t for more details). Only accepted for keys that can be used for mac operations, must not be larger than maximum mac size that can be performed with the key. When in FIPS approved mode values < 32 bits are not allowed.
uint8_t	reserved[3]	It must be 0.

6.2.2.5 struct op_generate_key_ext_args_t

Data Fields

uint32_t *	key_identifier	pointer to the identifier of the key to be used for the operation. In case of create operation the new key identifier will be stored in this location.
uint16_t	out_size	length in bytes of the generated key. It must be 0 in case of symmetric keys.
hsm_op_key_gen_flags_t	flags	bitmap specifying the operation properties.
hsm_key_type_t	key_type	indicates which type of key must be generated.
hsm_key_group_t	key_group	Key group of the generated key. It must be a value in the range 0-1023. Keys belonging to the same group can be cached in the HSM local memory through the hsm_manage_key_group API.
uint8_t *	out_key	pointer to the output area where the generated public key must be written.
hsm_key_info_t	key_info	bitmap specifying the properties of the key.

6.2.2.6 struct op_generate_key_args_t

Data Fields

hsm_hdl_t	key_management_hdl	handle identifying the key management service flow
hsm_svc_key_management_flags_t	flags	bitmap specifying the services properties.

6.2.2.7 struct open_svc_key_management_args_t

Data Fields

uint32_t *	key_identifier	< pointer to the identifier of the key to be used for the operation. identifier of the key to be used to decrypt the key to be
uint32_t	kek_identifier	length in bytes of the input key area. It must be equal to
uint16_t	input_size	bitmap specifying the operation properties.
hsm_op_manage_key_flags_t	flags	indicates the type of the key to be managed.

Data Fields

hsm_key_type_t	key_type	key group of the imported key. It must be a value in
hsm_key_group_t	key_group	bitmap specifying the properties of the key,
hsm_key_info_t	key_info	pointer to the input buffer. The input buffer is the concatenation
uint8_t *	input_data	

6.2.2.8 struct op_manage_key_args_t

Data Fields

uint32_t *	key_identifier	< pointer to the identifier of the key to be used for the operation. identifier of the key to be used to decrypt the key to be imported
uint32_t	kek_identifier	length in bytes of the input key area. It must be equal to
uint16_t	input_size	bitmap specifying the operation properties.
hsm_op_manage_key_flags_t	flags	indicates the type of the key to be managed.
hsm_key_type_t	key_type	key group of the imported key. It must be a value in
hsm_key_group_t	key_group	bitmap specifying the properties of the key,
hsm_key_info_t	key_info	pointer to the input buffer. The input buffer is the concatenation
uint8_t *	input_data	min mac length in bits to be set for this key, value 0 indicates
uint8_t	min_mac_len	It must be 0.
uint8_t	reserved[3]	

6.2.2.9 struct op_manage_key_ext_args_t

6.2.3 Macro Definition Documentation

6.2.3.1 HSM_OP_IMPORT_KEY_INPUT_SIGNED_MSG `#define HSM_OP_IMPORT_KEY_INPUT_SIGNED_M←
SG ((hsm_op_import_key_flags_t) (0u << 0))`

Bit 1-6: Reserved.

Bit 7: Strict: Request completed - New key written to NVM with updated MC.

6.2.3.2 HSM_KEY_INFO_PERSISTENT `#define HSM_KEY_INFO_PERSISTENT ((hsm_key_info_t) (0u << 1))`

< Persistent keys are stored in the external NVM.

When set, the key is permanent (write locked). Once created, it will not

6.2.3.3 FLAG `#define FLAG 0`

structure defining

6.2.3.4 HSM_OP_KEY_GENERATION_FLAGS_UPDATE `#define HSM_OP_KEY_GENERATION_FLAGS_UPDATE ((hsm_op_key_gen_flags_t)(1u << 0))`

< User can replace an existing key only by generating a key with

Create a new key.

6.2.3.5 HSM_OP_KEY_GENERATION_FLAGS_STRICT_OPERATION `#define HSM_OP_KEY_GENERATION_FLAGS_STRICT_OPERATION ((hsm_op_key_gen_flags_t)(1u << 7))`

< The request is completed only when the new key has been written in the NVM. This applicable for persistent key only.

6.2.4 Function Documentation**6.2.4.1 hsm_delete_key()** `hsm_err_t hsm_delete_key (hsm_hdl_t key_management_hdl, op_delete_key_args_t * args)`

This command is designed to perform the following operations:

- delete an existing key

Parameters

<i>key_importment_hdl</i>	handle identifying the key management service flow.
<i>args</i>	pointer to the structure containing the function arguments.

Returns

error code Bit 0-6: Reserved. Bit 7: Strict: Request completed - New key written to NVM with updated MC.

6.2.4.2 hsm_get_key_attr() `hsm_err_t hsm_get_key_attr (hsm_hdl_t key_management_hdl, op_get_key_attr_args_t * args)`

This command is designed to perform the following operations:

- get attributes of an existing key

Parameters

<i>key_importment_hdl</i>	handle identifying the key management service flow.
<i>args</i>	pointer to the structure containing the function arguments.

Returns

error code

6.2.4.3 hsm_generate_key_ext() `hsm_err_t hsm_generate_key_ext (`
`hsm_hdl_t key_management_hdl,`
`op_generate_key_ext_args_t * args)`

Generate a key or a key pair with extended settings. Basic operation is identical to `hsm_generate_key`, but accepts additional settings. Currently the `min_mac_len` is the only additional setting accepted.

Parameters

<i>key_management_hdl</i>	handle identifying the key management service flow.
<i>args</i>	pointer to the structure containing the function arguments.

Returns

error code

6.2.4.4 hsm_generate_key() `hsm_err_t hsm_generate_key (`
`hsm_hdl_t key_management_hdl,`
`op_generate_key_args_t * args)`

Generate a key or a key pair. Only the confidential keys (symmetric and private keys) are stored in the internal key store, while the non-confidential keys (public key) are exported.

The generated key can be stored using a new or existing key identifier with the restriction that an existing key can be replaced only by a key of the same type.

Parameters

<i>key_management_hdl</i>	handle identifying the key management service flow.
<i>args</i>	pointer to the structure containing the function arguments.

Returns

error code

6.2.4.5 hsm_open_key_management_service() `hsm_err_t hsm_open_key_management_service (`
`hsm_hdl_t key_store_hdl,`
`open_svc_key_management_args_t * args,`
`hsm_hdl_t * key_management_hdl)`

Open a key management service flow

User must open this service flow in order to perform operation on the key store keys (generate, update, delete)

Parameters

<i>key_store_hdl</i>	handle identifying the key store service flow.
<i>args</i>	pointer to the structure containing the function arguments.
<i>key_management_hdl</i>	pointer to where the key management service flow handle must be written.

Returns

`error_code` error code.

6.2.4.6 hsm_close_key_management_service() `hsm_err_t hsm_close_key_management_service (`
`hsm_hdl_t key_management_hdl)`

Terminate a previously opened key management service flow

Parameters

<i>key_management_hdl</i>	handle identifying the key management service flow.
---------------------------	---

Returns

error code

6.2.4.7 hsm_manage_key() `hsm_err_t hsm_manage_key (`
`hsm_hdl_t key_management_hdl,`
`op_manage_key_args_t * args)`

User can replace an existing key only by importing a key with.

This command is designed to perform the following operations:

- import a key creating a new key identifier (import and create)
- import a key using an existing key identifier (import and update)
- delete an existing key

The key encryption key (KEK) can be previously pre-shared or stored in the key store.

The key to be imported must be encrypted by using the KEK as following:

- Algorithm: AES GCM
- Key: root KEK
- AAD = 0
- IV = 12 bytes. When encrypting with a given key, the same IV MUST NOT be repeated. Refer to SP 800-38D for recommendations.
- Tag = 16 bytes
- Plaintext: key to be imported

The `hsm_manage_key_ext` function (described separately) allows additional settings when importing keys. When using the `hsm_manage_key` function to import a key, all additional settings are set to their default values

User can call this function only after having opened a key management service flow

Parameters

<i>key_management_hdl</i>	handle identifying the key management service flow.
<i>args</i>	pointer to the structure containing the function arguments.

Returns

error code

```
6.2.4.8 hsm_manage_key_ext() hsm_err_t hsm_manage_key_ext (  
    hsm_hdl_t key_management_hdl,  
    op_manage_key_ext_args_t * args )
```

Manage a key or a key pair with extended settings. Basic operation is identical to `hsm_manage_key`, but accepts additional settings.

Currently the `min_mac_len` is the only additional setting accepted.

Parameters

<i>key_management_hdl</i>	handle identifying the key management service flow.
<i>args</i>	pointer to the structure containing the function arguments.

Returns

error code

6.3 Ciphering

Modules

- [i.MX8QXP specificities](#)
- [i.MX8DXL specificities](#)

Data Structures

- struct [op_auth_enc_args_t](#)
- struct [open_svc_cipher_args_t](#)
- struct [op_cipher_one_go_args_t](#)

Macros

- #define [HSM_AUTH_ENC_ALGO_AES_GCM](#) ((hsm_op_auth_enc_algo_t)(0x00u))
Perform SM4 CCM with following constraints:
- #define [HSM_AUTH_ENC_ALGO_SM4_CCM](#) ((hsm_op_auth_enc_algo_t)(0x10u))
- #define [HSM_AUTH_ENC_FLAGS_DECRYPT](#) ((hsm_op_auth_enc_flags_t)(0u << 0))
- #define [HSM_AUTH_ENC_FLAGS_ENCRYPT](#) ((hsm_op_auth_enc_flags_t)(1u << 0))
Full IV is internally generated (only relevant for encryption)
- #define [HSM_AUTH_ENC_FLAGS_GENERATE_FULL_IV](#) ((hsm_op_auth_enc_flags_t)(1u << 1))
User supplies 4 bytes of the IV (fixed part), the other bytes are.
- #define [HSM_AUTH_ENC_FLAGS_GENERATE_COUNTER_IV](#) ((hsm_op_auth_enc_flags_t)(1u << 2))
- #define [HSM_CIPHER_ONE_GO_ALGO_AES_ECB](#) ((hsm_op_cipher_one_go_algo_t)(0x00u))
- #define [HSM_CIPHER_ONE_GO_ALGO_AES_CBC](#) ((hsm_op_cipher_one_go_algo_t)(0x01u))
Perform AES CCM with following constraints:
- #define [HSM_CIPHER_ONE_GO_ALGO_AES_CCM](#) ((hsm_op_cipher_one_go_algo_t)(0x04u))
- #define [HSM_CIPHER_ONE_GO_ALGO_SM4_ECB](#) ((hsm_op_cipher_one_go_algo_t)(0x10u))
- #define [HSM_CIPHER_ONE_GO_ALGO_SM4_CBC](#) ((hsm_op_cipher_one_go_algo_t)(0x11u))
- #define [HSM_CIPHER_ONE_GO_FLAGS_DECRYPT](#) ((hsm_op_cipher_one_go_flags_t)(0u << 0))
- #define [HSM_CIPHER_ONE_GO_FLAGS_ENCRYPT](#) ((hsm_op_cipher_one_go_flags_t)(1u << 0))

Typedefs

- typedef uint8_t [hsm_op_auth_enc_algo_t](#)
Perform AES GCM with following constraints:
- typedef uint8_t [hsm_op_auth_enc_flags_t](#)
- typedef uint8_t [hsm_svc_cipher_flags_t](#)
- typedef uint8_t [hsm_op_cipher_one_go_algo_t](#)
- typedef uint8_t [hsm_op_cipher_one_go_flags_t](#)

Functions

- [hsm_err_t hsm_do_cipher](#) (hsm_hdl_t cipher_hdl, [op_cipher_one_go_args_t](#) *cipher_one_go)
- [hsm_err_t hsm_auth_enc](#) (hsm_hdl_t cipher_hdl, [op_auth_enc_args_t](#) *args)
- [hsm_err_t hsm_open_cipher_service](#) (hsm_hdl_t key_store_hdl, [open_svc_cipher_args_t](#) *args, hsm_hdl_t *cipher_hdl)
- [hsm_err_t hsm_cipher_one_go](#) (hsm_hdl_t cipher_hdl, [op_cipher_one_go_args_t](#) *args)
- [hsm_err_t hsm_close_cipher_service](#) (hsm_hdl_t cipher_hdl)

6.3.1 Detailed Description

6.3.2 Data Structure Documentation

Data Fields

uint32_t	key_identifier	< identifier of the key to be used for the operation pointer to the user supplied part of initialization vector or nonce,
uint8_t *	iv	length in bytes of the fixed part of the initialization vector for
uint16_t	iv_size	pointer to the additional authentication data
uint8_t *	aad	length in bytes of the additional authentication data
uint16_t	aad_size	algorithm to be used for the operation
hsm_op_auth_enc_algo_t	ae_algo	bitmap specifying the operation attributes
hsm_op_auth_enc_flags_t	flags	pointer to the input area plaintext for encryption
uint8_t *	input	pointer to the output area Ciphertext + Tag (16 bytes)
uint8_t *	output	length in bytes of the input
uint32_t	input_size	length in bytes of the output
uint32_t	output_size	

6.3.2.1 struct op_auth_enc_args_t

Data Fields

hsm_hdl_t	cipher_hdl	handle identifying the cipher service flow
hsm_svc_cipher_flags_t	flags	bitmap specifying the services properties
uint8_t	reserved[3]	

6.3.2.2 struct open_svc_cipher_args_t

Data Fields

uint32_t	key_identifier	< identifier of the key to be used for the operation pointer to the initialization vector (nonce in case of AES CCM)
uint8_t *	iv	length in bytes of the initialization vector.
uint16_t	iv_size	bitmap specifying the services properties.
hsm_svc_cipher_flags_t	svc_flags	bitmap specifying the operation attributes
hsm_op_cipher_one_go_flags_t	flags	algorithm to be used for the operation
hsm_op_cipher_one_go_algo_t	cipher_algo	pointer to the input area:
uint8_t *	input	pointer to the output area:
uint8_t *	output	length in bytes of the input.
uint32_t	input_size	length in bytes of the output
uint32_t	output_size	

6.3.2.3 struct op_cipher_one_go_args_t

6.3.3 Function Documentation

```

6.3.3.1 hsm_do_cipher() hsm_err_t hsm_do_cipher (
    hsm_hdl_t cipher_hdl,
    op_cipher_one_go_args_t * cipher_one_go )

```

Secondary API to perform ciphering operation
This API does the following:

1. Open an Cipher Service Flow
2. Perform ciphering operation
3. Terminate a previously opened cipher service flow
User can call this function only after having opened a cipher service flow.

Parameters

<i>key_store_hdl</i>	handle identifying the cipher service flow.
<i>args</i>	pointer to the structure containing the function arguments.

Returns

error code

```

6.3.3.2 hsm_auth_enc() hsm_err_t hsm_auth_enc (
    hsm_hdl_t cipher_hdl,
    op_auth_enc_args_t * args )

```

Perform authenticated encryption operation

User can call this function only after having opened a cipher service flow

For decryption operations, the full IV is supplied by the caller via the iv and iv_size parameters. HSM_AUTH_ENC_FLAGS_GENERATE_FULL_IV and HSM_AUTH_ENC_FLAGS_GENERATE_COUNTER_IV flags are ignored. For encryption operations, either HSM_AUTH_ENC_FLAGS_GENERATE_FULL_IV or HSM_AUTH_ENC_FLAGS_GENERATE_COUNTER_IV must be set when calling this function:

- When HSM_AUTH_ENC_FLAGS_GENERATE_FULL_IV is set, the full IV is internally generated, iv and iv_size must be set to 0
- When HSM_AUTH_ENC_FLAGS_GENERATE_COUNTER_IV is set, the user supplies a 4 byte fixed part of the IV. The other IV bytes are internally generated

Parameters

<i>cipher_hdl</i>	handle identifying the cipher service flow.
<i>args</i>	pointer to the structure containing the function arguments.

Returns

error code

6.3.3.3 hsm_open_cipher_service() `hsm_err_t hsm_open_cipher_service (`
 `hsm_hdl_t key_store_hdl,`
 `open_svc_cipher_args_t * args,`
 `hsm_hdl_t * cipher_hdl)`

- Open a cipher service flow.
- User can call this function only after having opened a key-store service flow.
- User must open this service in order to perform cipher operation.

Parameters

<i>key_store_hdl</i>	handle identifying the key store service flow.
<i>args</i>	pointer to the structure containing the function arguments.
<i>cipher_hdl</i>	pointer to where the cipher service flow handle must be written.

Returns

error code

6.3.3.4 hsm_cipher_one_go() `hsm_err_t hsm_cipher_one_go (`
 `hsm_hdl_t cipher_hdl,`
 `op_cipher_one_go_args_t * args)`

Perform ciphering operation

User can call this function only after having opened a cipher service flow

Parameters

<i>cipher_hdl</i>	handle identifying the cipher service flow.
<i>args</i>	pointer to the structure containing the function arguments.

Returns

error code

6.3.3.5 hsm_close_cipher_service() `hsm_err_t hsm_close_cipher_service (`
 `hsm_hdl_t cipher_hdl)`

Terminate a previously opened cipher service flow

Parameters

<i>cipher_hdl</i>	pointer to handle identifying the cipher service flow to be closed.
-------------------	---

Returns

error code

6.4 Signature generation

Modules

- [i.MX8QXP specificities](#)
- [i.MX8DXL specificities](#)

Data Structures

- struct [open_svc_sign_gen_args_t](#)
- struct [op_generate_sign_args_t](#)
- struct [op_prepare_sign_args_t](#)

Macros

- `#define HSM_OP_GENERATE_SIGN_FLAGS_INPUT_DIGEST ((hsm_op_generate_sign_flags_t)(0u << 0))`
- `#define HSM_OP_GENERATE_SIGN_FLAGS_INPUT_MESSAGE ((hsm_op_generate_sign_flags_t)(1u << 0))`
- `#define HSM_OP_GENERATE_SIGN_FLAGS_LOW_LATENCY_SIGNATURE ((hsm_op_generate_sign_flags_t)(1u << 2))`
- `#define HSM_SIGNATURE_SCHEME_ECDSA_NIST_P256_SHA_256 ((hsm_signature_scheme_id_t)0x02u)`
- `#define HSM_SIGNATURE_SCHEME_ECDSA_NIST_P384_SHA_384 ((hsm_signature_scheme_id_t)0x03u)`
- `#define HSM_SIGNATURE_SCHEME_ECDSA_NIST_P521_SHA_512 ((hsm_signature_scheme_id_t)0x04u)`
- `#define HSM_SIGNATURE_SCHEME_ECDSA_BRAINPOOL_R1_256_SHA_256 ((hsm_signature_scheme_id_t)0x13u)`
- `#define HSM_SIGNATURE_SCHEME_ECDSA_BRAINPOOL_R1_320_SHA_384 ((hsm_signature_scheme_id_t)0x14u)`
- `#define HSM_SIGNATURE_SCHEME_ECDSA_BRAINPOOL_R1_384_SHA_384 ((hsm_signature_scheme_id_t)0x15u)`
- `#define HSM_SIGNATURE_SCHEME_ECDSA_BRAINPOOL_R1_512_SHA_512 ((hsm_signature_scheme_id_t)0x16u)`
- `#define HSM_SIGNATURE_SCHEME_ECDSA_BRAINPOOL_T1_256_SHA_256 ((hsm_signature_scheme_id_t)0x23u)`
- `#define HSM_SIGNATURE_SCHEME_ECDSA_BRAINPOOL_T1_320_SHA_384 ((hsm_signature_scheme_id_t)0x24u)`
- `#define HSM_SIGNATURE_SCHEME_ECDSA_BRAINPOOL_T1_384_SHA_384 ((hsm_signature_scheme_id_t)0x25u)`
- `#define HSM_SIGNATURE_SCHEME_ECDSA_BRAINPOOL_T1_512_SHA_512 ((hsm_signature_scheme_id_t)0x26u)`
- `#define HSM_SIGNATURE_SCHEME_DSA_SM2_FP_256_SM3 ((hsm_signature_scheme_id_t)0x43u)`
- `#define HSM_OP_PREPARE_SIGN_INPUT_DIGEST ((hsm_op_prepare_signature_flags_t)(0u << 0))`
- `#define HSM_OP_PREPARE_SIGN_INPUT_MESSAGE ((hsm_op_prepare_signature_flags_t)(1u << 0))`
- `#define HSM_OP_PREPARE_SIGN_COMPRESSED_POINT ((hsm_op_prepare_signature_flags_t)(1u << 1))`

Typedefs

- `typedef uint8_t hsm_svc_signature_generation_flags_t`
- `typedef uint8_t hsm_op_generate_sign_flags_t`
- `typedef uint8_t hsm_signature_scheme_id_t`
Bit 3 to 7: Reserved.
- `typedef uint8_t hsm_op_prepare_signature_flags_t`

Functions

- `hsm_err_t hsm_do_sign (hsm_hdl_t key_store_hdl, op_generate_sign_args_t *args)`
- `hsm_err_t hsm_open_signature_generation_service (hsm_hdl_t key_store_hdl, open_svc_sign_gen_args_t *args, hsm_hdl_t *signature_gen_hdl)`
- `hsm_err_t hsm_close_signature_generation_service (hsm_hdl_t signature_gen_hdl)`
- `hsm_err_t hsm_generate_signature (hsm_hdl_t signature_gen_hdl, op_generate_sign_args_t *args)`
- `hsm_err_t hsm_prepare_signature (hsm_hdl_t signature_gen_hdl, op_prepare_sign_args_t *args)`

6.4.1 Detailed Description**6.4.2 Data Structure Documentation**

Data Fields

hsm_hdl_t	signature_gen_hdl	bitmap specifying the services properties.
hsm_svc_signature_generation_flags_t	flags	

6.4.2.1 struct open_svc_sign_gen_args_t

Data Fields

uint32_t	key_identifier	< identifier of the key to be used for the operation pointer to the input (message or message digest) to be signed
uint8_t *	message	pointer to the output area where the signature must be stored.
uint8_t *	signature	length in bytes of the output. After signature generation operation,
uint16_t	signature_size	length in bytes of the input
uint32_t	message_size	identifier of the digital signature scheme to be used
hsm_signature_scheme_id_t	scheme_id	bitmap specifying the svc flow attributes
hsm_svc_signature_generation_flags_t	svc_flags	bitmap specifying the operation attributes
hsm_op_generate_sign_flags_t	flags	

6.4.2.2 struct op_generate_sign_args_t

Data Fields

hsm_signature_scheme_id_t	scheme_id	< identifier of the digital signature scheme to be used bitmap specifying the operation attributes
hsm_op_prepare_signature_flags_t	flags	

6.4.2.3 struct op_prepare_sign_args_t

6.4.3 Macro Definition Documentation

6.4.3.1 HSM_OP_GENERATE_SIGN_FLAGS_INPUT_DIGEST `#define HSM_OP_GENERATE_SIGN_FLAGS_I↵
NPUT_DIGEST ((hsm_op_generate_sign_flags_t) (0u << 0))`

Bit field indicating the requested operations: Bit 0:

- 0: Input is the message digest.
- 1: Input is the actual message.

6.4.3.2 HSM_OP_GENERATE_SIGN_FLAGS_LOW_LATENCY_SIGNATURE #define HSM_OP_GENERATE_SIGN_FLAGS_LOW_LATENCY_SIGNATURE ((hsm_op_generate_sign_flags_t) (1u << 2))

Bit 2: HSM finalizes the signature by using the artifacts of the previously executed hsm_prepare_signature API. The API fails if no artifacts related to the requested scheme id are available.

6.4.4 Function Documentation

6.4.4.1 hsm_do_sign() hsm_err_t hsm_do_sign (hsm_hdl_t key_store_hdl, op_generate_sign_args_t * args)

Secondary API to generate signature on the given message.
This API does the following:

1. Open a service flow for signature generation.
2. Based on the flag to identify the type of message: Digest or actual message, generate the signature using the key corresponding to the key id.
3. Post performing the operation, terminate the previously opened signature-generation service flow.
User can call this function only after having opened a key-store.

Parameters

<i>key_store_hdl</i>	handle identifying the current key-store.
<i>args</i>	pointer to the structure containing the function arguments.

Returns

error code

6.4.4.2 hsm_open_signature_generation_service() hsm_err_t hsm_open_signature_generation_service (hsm_hdl_t key_store_hdl, open_svc_sign_gen_args_t * args, hsm_hdl_t * signature_gen_hdl)

Open a signature generation service flow
User can call this function only after having opened a key store service flow.

User must open this service in order to perform signature generation operations.

Parameters

<i>key_store_hdl</i>	handle identifying the key store service flow.
<i>args</i>	pointer to the structure containing the function arguments.
<i>signature_gen_hdl</i>	pointer to where the signature generation service flow handle must be written.

Returns

error code

6.4.4.3 hsm_close_signature_generation_service() `hsm_err_t hsm_close_signature_generation_↵
service (`
`hsm_hdl_t signature_gen_hdl)`

Terminate a previously opened signature generation service flow

Parameters

<code>signature_gen_hdl</code>	handle identifying the signature generation service flow to be closed.
--------------------------------	--

Returns

error code

6.4.4.4 hsm_generate_signature() `hsm_err_t hsm_generate_signature (`
`hsm_hdl_t signature_gen_hdl,`
`op_generate_sign_args_t * args)`

Generate a digital signature according to the signature scheme User can call this function only after having opened a signature generation service flow.

The signature $S=(r,s)$ is stored in the format $r||s||R_y$ where:

- R_y is an additional byte containing the lsb of y . R_y has to be considered valid only if the `HSM_OP_GENERATE_SIGN_FLAGS_COMPRESSED_POINT` is set.

In case of `HSM_SIGNATURE_SCHEME_DSA_SM2_FP_256_SM3`, message of `op_generate_sign_args_t` should be (as specified in GB/T 32918):

- equal to $Z||M$ in case of `HSM_OP_GENERATE_SIGN_FLAGS_INPUT_MESSAGE`
- equal to $SM3(Z||M)$ in case of `HSM_OP_GENERATE_SIGN_FLAGS_INPUT_DIGEST`

Parameters

<code>signature_gen_hdl</code>	handle identifying the signature generation service flow.
<code>args</code>	pointer to the structure containing the function arguments.

Returns

error code

6.4.4.5 hsm_prepare_signature() `hsm_err_t hsm_prepare_signature (`
 `hsm_hdl_t signature_gen_hdl,`
 `op_prepare_sign_args_t * args)`

Prepare the creation of a signature by pre-calculating the operations having not dependencies on the input message.

The pre-calculated value will be stored internally and used once call `hsm_generate_signature`. Up to 20 pre-calculated values can be stored, additional preparation operations will have no effects.

User can call this function only after having opened a signature generation service flow.

The signature $S=(r,s)$ is stored in the format $r||s||Ry$ where:

- Ry is an additional byte containing the lsb of y , Ry has to be considered valid only if the `HSM_OP_PREPARE_SIGN_COMPRESSED_POINT` is set.

Parameters

<i>signature_gen_hdl</i>	handle identifying the signature generation service flow
<i>args</i>	pointer to the structure containing the function arguments.

Returns

error code

6.5 Signature verification

Modules

- [i.MX8QXP specificities](#)
- [i.MX8DXL specificities](#)

Data Structures

- struct [open_svc_sign_ver_args_t](#)
- struct [op_verify_sign_args_t](#)

Macros

- `#define HSM_OP_VERIFY_SIGN_FLAGS_INPUT_DIGEST ((hsm_op_verify_sign_flags_t)(0u << 0))`
- `#define HSM_OP_VERIFY_SIGN_FLAGS_INPUT_MESSAGE ((hsm_op_verify_sign_flags_t)(1u << 0))`
- `#define HSM_OP_VERIFY_SIGN_FLAGS_COMPRESSED_POINT ((hsm_op_verify_sign_flags_t)(1u << 1))`
when set the value passed by the key argument is considered as the internal
- `#define HSM_OP_VERIFY_SIGN_FLAGS_KEY_INTERNAL ((hsm_op_verify_sign_flags_t)(1u << 2))`
- `#define HSM_VERIFICATION_STATUS_SUCCESS ((hsm_verification_status_t)(0x5A3CC3A5u))`
- `#define HSM_VERIFICATION_STATUS_FAILURE ((hsm_verification_status_t)(0x2B4DD4B2u))`

Typedefs

- `typedef uint8_t hsm_svc_signature_verification_flags_t`
- `typedef uint32_t hsm_verification_status_t`
- `typedef uint8_t hsm_op_verify_sign_flags_t`

Functions

- `hsm_err_t hsm_verify_sign (hsm_hdl_t session_hdl, op_verify_sign_args_t *args, hsm_verification_status_t *verification_status)`
- `hsm_err_t hsm_open_signature_verification_service (hsm_hdl_t session_hdl, open_svc_sign_ver_args_t *args, hsm_hdl_t *signature_ver_hdl)`
- `hsm_err_t hsm_close_signature_verification_service (hsm_hdl_t signature_ver_hdl)`
- `hsm_err_t hsm_verify_signature (hsm_hdl_t signature_ver_hdl, op_verify_sign_args_t *args, hsm_verification_status_t *status)`

6.5.1 Detailed Description

6.5.2 Data Structure Documentation

Data Fields

hsm_svc_signature_verification_flags_t	flags	< bitmap indicating the service flow properties
hsm_hdl_t	sig_ver_hdl	

6.5.2.1 struct open_svc_sign_ver_args_t

Data Fields

uint8_t *	key	< pointer to the public key to be used for the verification. pointer to the input (message or message digest)
uint8_t *	message	pointer to the input signature. The signature S=(r,s) is expected
uint8_t *	signature	length in bytes of the input key
uint16_t	key_size	length in bytes of the output - it must contain one additional
uint16_t	signature_size	length in bytes of the input message
uint32_t	message_size	
hsm_verification_status_t	verification_status	identifier of the digital signature scheme to be used
hsm_signature_scheme_id_t	scheme_id	bitmap specifying the operation attributes
hsm_op_verify_sign_flags_t	flags	bitmap specifying the svc flow attributes
hsm_svc_signature_verification_flags_t	svc_flags	

6.5.2.2 struct op_verify_sign_args_t

6.5.3 Function Documentation

6.5.3.1 hsm_verify_sign() `hsm_err_t hsm_verify_sign (`
`hsm_hdl_t session_hdl,`
`op_verify_sign_args_t * args,`
`hsm_verification_status_t * verification_status)`

Secondary API to verify a message signature.

This API does the following:

1. Open a flow for verification of the signature.
2. Based on the flag to identify the type of message: Digest or actual message, verification of the signature is done using the public key.
3. Post performing the operation, terminate the previously opened signature-verification service flow.
User can call this function only after having opened a session.

Parameters

<i>key_store_hdl</i>	handle identifying the current key-store.
<i>args</i>	pointer to the structure containing the function arguments.

Returns

error code

6.5.3.2 hsm_open_signature_verification_service() `hsm_err_t hsm_open_signature_verification_↔`
`service (`
`hsm_hdl_t session_hdl,`
`open_svc_sign_ver_args_t * args,`
`hsm_hdl_t * signature_ver_hdl)`

User must open this service in order to perform signature verification operations. User can call this function only after having opened a session.

Parameters

<i>session_hdl</i>	handle identifying the current session.
<i>args</i>	pointer to the structure containing the function arguments.
<i>signature_ver_hdl</i>	pointer to where the signature verification service flow handle must be written.

Returns

error code

6.5.3.3 hsm_close_signature_verification_service() `hsm_err_t hsm_close_signature_verification_↔`
`service (`
`hsm_hdl_t signature_ver_hdl)`

Terminate a previously opened signature verification service flow

Parameters

<i>signature_ver_hdl</i>	handle identifying the signature verification service flow to be closed.
--------------------------	--

Returns

error code

6.5.3.4 hsm_verify_signature() `hsm_err_t hsm_verify_signature (`
`hsm_hdl_t signature_ver_hdl,`
`op_verify_sign_args_t * args,`
`hsm_verification_status_t * status)`

Verify a digital signature according to the signature scheme User can call this function only after having opened a signature verification service flow.

The signature S=(r,s) is expected to be in format r||s||Ry where:

- Ry is an additional byte containing the lsb of y. Ry will be considered as valid only, if the HSM_OP_VERIFY_Y_SIGN_FLAGS_COMPRESSED_POINT is set.

Only not-compressed keys (x,y) can be used by this command. Compressed keys can be decompressed by using the dedicated API.

In case of HSM_SIGNATURE_SCHEME_DSA_SM2_FP_256_SM3, message of [op_verify_sign_args_t](#) should be (as specified in GB/T 32918):

- equal to $Z||M$ in case of HSM_OP_VERIFY_SIGN_FLAGS_INPUT_MESSAGE
- equal to $SM3(Z||M)$ in case of HSM_OP_VERIFY_SIGN_FLAGS_INPUT_DIGEST

Parameters

<i>signature_ver_hdl</i>	handle identifying the signature verification service flow.
<i>args</i>	pointer to the structure containing the function arguments.
<i>status</i>	pointer to where the verification status must be stored if the verification succeed the value HSM_VERIFICATION_STATUS_SUCCESS is returned.

Returns

error code

6.6 Random number generation

Data Structures

- struct [open_svc_rng_args_t](#)
- struct [op_get_random_args_t](#)

Typedefs

- typedef uint8_t [hsm_svc_rng_flags_t](#)

Functions

- [hsm_err_t hsm_do_rng](#) (hsm_hdl_t session_hdl, [op_get_random_args_t](#) *args)
- [hsm_err_t hsm_open_rng_service](#) (hsm_hdl_t session_hdl, [open_svc_rng_args_t](#) *args, hsm_hdl_t *rng_hdl)
- [hsm_err_t hsm_close_rng_service](#) (hsm_hdl_t rng_hdl)
- [hsm_err_t hsm_get_random](#) (hsm_hdl_t rng_hdl, [op_get_random_args_t](#) *args)

6.6.1 Detailed Description

6.6.2 Data Structure Documentation

Data Fields

hsm_svc_rng_flags_t	flags	< bitmap indicating the service flow properties
uint8_t	reserved[3]	
hsm_hdl_t	rng_hdl	

6.6.2.1 struct [open_svc_rng_args_t](#)

Data Fields

uint8_t *	output	pointer to the output area where the random number must be written
uint32_t	random_size	length in bytes of the random number to be provided. bitmap indicating the service flow properties
hsm_svc_rng_flags_t	svc_flags	
uint8_t	reserved[3]	

6.6.2.2 struct [op_get_random_args_t](#)

6.6.3 Function Documentation

6.6.3.1 hsm_do_rng() `hsm_err_t hsm_do_rng (`
 `hsm_hdl_t session_hdl,`
 `op_get_random_args_t * args)`

Secondary API to fetch the Random Number

This API does the following:

1. Opens Random Number Generation Service Flow
 2. Get a freshly generated random number
 3. Terminate a previously opened rng service flow
- User can call this function only after having opened a session.

Parameters

<i>session_hdl</i>	handle identifying the current session.
<i>args</i>	pointer to the structure containing the function arguments.

Returns

error code

6.6.3.2 hsm_open_rng_service() `hsm_err_t hsm_open_rng_service (`
 `hsm_hdl_t session_hdl,`
 `open_svc_rng_args_t * args,`
 `hsm_hdl_t * rng_hdl)`

Open a random number generation service flow

User can call this function only after having opened a session.

User must open this service in order to perform rng operations.

Parameters

<i>session_hdl</i>	handle identifying the current session.
<i>args</i>	pointer to the structure containing the function arguments.
<i>rng_hdl</i>	pointer to where the rng service flow handle must be written.

Returns

error code

6.6.3.3 hsm_close_rng_service() `hsm_err_t hsm_close_rng_service (`
 `hsm_hdl_t rng_hdl)`

Terminate a previously opened rng service flow

Parameters

<i>rng_hdl</i>	handle identifying the rng service flow to be closed.
----------------	---

Returns

error code

6.6.3.4 hsm_get_random() `hsm_err_t hsm_get_random (`
 `hsm_hdl_t rng_hdl,`
 `op_get_random_args_t * args)`

Get a freshly generated random number

User can call this function only after having opened a rng service flow

Parameters

<i>rng_hdl</i>	handle identifying the rng service flow.
<i>args</i>	pointer to the structure containing the function arguments.

Returns

error code

6.7 Hashing

Modules

- [i.MX8QXP specificities](#)

Data Structures

- struct [open_svc_hash_args_t](#)
- struct [op_hash_one_go_args_t](#)

Macros

- `#define HSM_HASH_ALGO_SHA_224 ((hsm_hash_algo_t)(0x0u))`
- `#define HSM_HASH_ALGO_SHA_256 ((hsm_hash_algo_t)(0x1u))`
- `#define HSM_HASH_ALGO_SHA_384 ((hsm_hash_algo_t)(0x2u))`
- `#define HSM_HASH_ALGO_SHA_512 ((hsm_hash_algo_t)(0x3u))`
- `#define HSM_HASH_ALGO_SM3_256 ((hsm_hash_algo_t)(0x11u))`
- `#define HSM_HASH_FLAG_ALLOWED`

Typedefs

- `typedef uint8_t hsm_hash_algo_t`

Enumerations

- `enum hsm_hash_svc_flags_t {
HSM_HASH_FLAG_ONE_SHOT = 0x1,
HSM_HASH_FLAG_INIT = 0x2,
HSM_HASH_FLAG_UPDATE = 0x4,
HSM_HASH_FLAG_FINAL = 0x8,
HSM_HASH_FLAG_GET_CONTEXT = 0x80 }`

Functions

- `hsm_err_t hsm_do_hash (hsm_hdl_t session_hdl, op_hash_one_go_args_t *args)`
- `hsm_err_t hsm_open_hash_service (hsm_hdl_t session_hdl, open_svc_hash_args_t *args, hsm_hdl_t *hash_hdl)`
- `hsm_err_t hsm_close_hash_service (hsm_hdl_t hash_hdl)`
- `hsm_err_t hsm_hash_one_go (hsm_hdl_t hash_hdl, op_hash_one_go_args_t *args)`

6.7.1 Detailed Description

6.7.2 Data Structure Documentation

Data Fields

<code>hsm_hdl_t</code>	<code>hash_hdl</code>	
------------------------	-----------------------	--

6.7.2.1 struct open_svc_hash_args_t

Data Fields

uint8_t *	input	< pointer to the input data to be hashed pointer to the output area where the resulting digest must be written
uint8_t *	output	length in bytes of the input
uint32_t	input_size	length in bytes of the output
uint32_t	output_size	hash algorithm to be used for the operation
hsm_hash_algo_t	algo	flags identifying the operation init() update(), final() or one shot
hsm_hash_svc_flags_t	svc_flags	

6.7.2.2 struct op_hash_one_go_args_t

6.7.3 Macro Definition Documentation

6.7.3.1 HSM_HASH_FLAG_ALLOWED #define HSM_HASH_FLAG_ALLOWED

Value:

```
(HSM_HASH_FLAG_ONE_SHOT | HSM_HASH_FLAG_INIT \
 | HSM_HASH_FLAG_UPDATE | HSM_HASH_FLAG_FINAL \
 | HSM_HASH_FLAG_GET_CONTEXT)
```

6.7.4 Function Documentation

6.7.4.1 hsm_do_hash() `hsm_err_t hsm_do_hash (` `hsm_hdl_t session_hdl,` `op_hash_one_go_args_t * args)`

Secondary API to digest a message.

This API does the following:

1. Open an Hash Service Flow
2. Perform hash
3. Terminate a previously opened hash service flow
User can call this function only after having opened a session.

Parameters

<i>session_hdl</i>	handle identifying the current session.
<i>args</i>	pointer to the structure containing the function arguments.

Returns

error code

6.7.4.2 hsm_open_hash_service() `hsm_err_t hsm_open_hash_service (`
 `hsm_hdl_t session_hdl,`
 `open_svc_hash_args_t * args,`
 `hsm_hdl_t * hash_hdl)`

Open an hash service flow

User can call this function only after having opened a session.

User must open this service in order to perform hash operations.

Parameters

<i>session_hdl</i>	handle identifying the current session.
<i>args</i>	pointer to the structure containing the function arguments.
<i>hash_hdl</i>	pointer to where the hash service flow handle must be written.

Returns

error code

6.7.4.3 hsm_close_hash_service() `hsm_err_t hsm_close_hash_service (`
 `hsm_hdl_t hash_hdl)`

Terminate a previously opened hash service flow

Parameters

<i>hash_hdl</i>	handle identifying the hash service flow to be closed.
-----------------	--

Returns

error code

6.7.4.4 hsm_hash_one_go() `hsm_err_t hsm_hash_one_go (`
 `hsm_hdl_t hash_hdl,`
 `op_hash_one_go_args_t * args)`

Perform the hash operation on a given input

User can call this function only after having opened a hash service flow

Parameters

<i>hash_hdl</i>	handle identifying the hash service flow.
<i>args</i>	pointer to the structure containing the function arguments.

Returns

error code

6.8 Data storage

Data Structures

- struct [open_svc_data_storage_args_t](#)
- struct [op_data_storage_args_t](#)

Macros

- #define [HSM_OP_DATA_STORAGE_FLAGS_STORE](#) ((hsm_op_data_storage_flags_t)(1u << 0))
Store data.
- #define [HSM_OP_DATA_STORAGE_FLAGS_RETRIEVE](#) ((hsm_op_data_storage_flags_t)(0u << 0))
Retrieve data.

Typedefs

- typedef uint8_t [hsm_svc_data_storage_flags_t](#)
- typedef uint8_t [hsm_op_data_storage_flags_t](#)

Functions

- [hsm_err_t hsm_data_ops](#) (hsm_hdl_t key_store_hdl, [op_data_storage_args_t](#) *args)
- [hsm_err_t hsm_open_data_storage_service](#) (hsm_hdl_t key_store_hdl, [open_svc_data_storage_args_t](#) *args, hsm_hdl_t *data_storage_hdl)
- [hsm_err_t hsm_data_storage](#) (hsm_hdl_t data_storage_hdl, [op_data_storage_args_t](#) *args)
- [hsm_err_t hsm_close_data_storage_service](#) (hsm_hdl_t data_storage_hdl)

6.8.1 Detailed Description

6.8.2 Data Structure Documentation

Data Fields

hsm_hdl_t	data_storage_handle	
hsm_svc_data_storage_flags_t	flags	bitmap specifying the services properties.
uint8_t	reserved[3]	

6.8.2.1 struct open_svc_data_storage_args_t

Data Fields

uint8_t *	data	< pointer to the data. In case of store request, length in bytes of the data
uint32_t	data_size	id of the data
uint16_t	data_id	bitmap specifying the services properties.
hsm_svc_data_storage_flags_t	flags	flags bitmap specifying the operation attributes.
hsm_op_data_storage_flags_t	svc_flags	

6.8.2.2 struct op_data_storage_args_t

6.8.3 Function Documentation

6.8.3.1 hsm_data_ops() `hsm_err_t hsm_data_ops (`
`hsm_hdl_t key_store_hdl,`
`op_data_storage_args_t * args)`

Secondary API to store and restore data from the linux filesystem managed by EdgeLock Enclave Firmware.

This API does the following:

1. Open an data storage service Flow
2. Based on the flag for operation attribute: Store or Re-store,
 - Store the data
 - Re-store the data, from the non-volatile storage.
3. Post performing the operation, terminate the previously opened data-storage service flow.
 User can call this function only after having opened a key-store.

Parameters

<i>key_store_hdl</i>	handle identifying the current key-store.
<i>args</i>	pointer to the structure containing the function arguments.

Returns

error code

6.8.3.2 hsm_open_data_storage_service() `hsm_err_t hsm_open_data_storage_service (`
`hsm_hdl_t key_store_hdl,`
`open_svc_data_storage_args_t * args,`
`hsm_hdl_t * data_storage_hdl)`

Open a data storage service flow

User must open this service flow in order to store/retrieve generic data in/from the HSM.

Parameters

<i>key_store_hdl</i>	handle identifying the key store service flow.
<i>args</i>	pointer to the structure containing the function arguments.
<i>data_storage_hdl</i>	pointer to where the data storage service flow handle must be written.

Returns

error_code error code.

6.8.3.3 hsm_data_storage() `hsm_err_t hsm_data_storage (`
 `hsm_hdl_t data_storage_hdl,`
 `op_data_storage_args_t * args)`

Store or retrieve generic data identified by a data_id.

Parameters

<i>data_storage_hdl</i>	handle identifying the data storage service flow.
<i>args</i>	pointer to the structure containing the function arguments.

Returns

error code

6.8.3.4 hsm_close_data_storage_service() `hsm_err_t hsm_close_data_storage_service (`
 `hsm_hdl_t data_storage_hdl)`

Terminate a previously opened data storage service flow

Parameters

<i>data_storage_hdl</i>	handle identifying the data storage service flow.
-------------------------	---

Returns

error code

6.9 Authenticated Encryption

Functions

- [hsm_err_t hsm_do_auth_enc](#) (hsm_hdl_t key_store_hdl, [op_auth_enc_args_t](#) *auth_enc_args)

6.9.1 Detailed Description

6.9.2 Function Documentation

6.9.2.1 hsm_do_auth_enc() [hsm_err_t](#) hsm_do_auth_enc (
hsm_hdl_t key_store_hdl,
[op_auth_enc_args_t](#) * auth_enc_args)

Secondary API to perform Authenticated Encryption
This API does the following:

1. Opens Cipher Service Flow
2. Perform Authenticated Encryption operation
3. Terminates the previously opened Cipher service flow
User can call this function only after having opened a key store service flow.

Parameters

<i>key_store_hdl</i>	handle identifying the key store service flow.
<i>args</i>	pointer to the structure containing the function arguments.

Returns

error code

6.10 Mac

Modules

- [i.MX8QXP specificities](#)
- [i.MX8DXL specificities](#)

Data Structures

- struct [open_svc_mac_args_t](#)
- struct [op_mac_one_go_args_t](#)

Macros

- `#define HSM_OP_MAC_ONE_GO_FLAGS_MAC_VERIFICATION ((hsm_op_mac_one_go_flags_t)(0u << 0))`
- `#define HSM_OP_MAC_ONE_GO_FLAGS_MAC_GENERATION ((hsm_op_mac_one_go_flags_t)(1u << 0))`
- `#define HSM_OP_MAC_ONE_GO_FLAGS_MAC_LENGTH_IN_BITS ((hsm_op_mac_one_go_flags_t)(1u << 1))`
- `#define HSM_OP_MAC_ONE_GO_ALGO_AES_CMAC ((hsm_op_mac_one_go_algo_t)(0x01u))`
- `#define HSM_OP_MAC_ONE_GO_ALGO_HMAC_SHA_224 ((hsm_op_mac_one_go_algo_t)(0x05u))`
- `#define HSM_OP_MAC_ONE_GO_ALGO_HMAC_SHA_256 ((hsm_op_mac_one_go_algo_t)(0x06u))`
- `#define HSM_OP_MAC_ONE_GO_ALGO_HMAC_SHA_384 ((hsm_op_mac_one_go_algo_t)(0x07u))`
- `#define HSM_OP_MAC_ONE_GO_ALGO_HMAC_SHA_512 ((hsm_op_mac_one_go_algo_t)(0x08u))`
- `#define HSM_MAC_VERIFICATION_STATUS_SUCCESS ((hsm_mac_verification_status_t)(0x6C1AA1↵C6u))`

Typedefs

- `typedef uint8_t hsm_svc_mac_flags_t`
- `typedef uint8_t hsm_op_mac_one_go_flags_t`
- `typedef uint32_t hsm_mac_verification_status_t`
- `typedef uint8_t hsm_op_mac_one_go_algo_t`

Functions

- `hsm_err_t hsm_do_mac (hsm_hdl_t key_store_hdl, op_mac_one_go_args_t *mac_one_go)`
- `hsm_err_t hsm_open_mac_service (hsm_hdl_t key_store_hdl, open_svc_mac_args_t *args, hsm_hdl_t ↵ *mac_hdl)`
- `hsm_err_t hsm_mac_one_go (hsm_hdl_t mac_hdl, op_mac_one_go_args_t *args, hsm_mac_verification↵_status_t *status)`
- `hsm_err_t hsm_close_mac_service (hsm_hdl_t mac_hdl)`

6.10.1 Detailed Description

6.10.2 Data Structure Documentation

Data Fields

hsm_svc_mac_flags_t	flags	< bitmap specifying the services properties.
hsm_hdl_t	mac_serv_hdl	

6.10.2.1 struct open_svc_mac_args_t

Data Fields

uint32_t	key_identifier	< identifier of the key to be used for the operation algorithm to be used for the operation
hsm_op_mac_one_go_algo_t	algorithm	bitmap specifying the operation attributes
hsm_op_mac_one_go_flags_t	flags	pointer to the payload area
uint8_t *	payload	pointer to the tag area
uint8_t *	mac	length in bytes of the payload
uint32_t	payload_size	length of the tag.
uint16_t	mac_size	expected mac size for output, returned by FW in case the mac size
uint16_t	expected_mac_size	
hsm_mac_verification_status_t	verification_status	bitmap specifying the services properties.
hsm_svc_mac_flags_t	svc_flags	

6.10.2.2 struct op_mac_one_go_args_t

6.10.3 Function Documentation

6.10.3.1 hsm_do_mac() `hsm_err_t hsm_do_mac (`
`hsm_hdl_t key_store_hdl,`
`op_mac_one_go_args_t * mac_one_go)`

Secondary API to perform mac operation

This API does the following:

1. Open an MAC Service Flow
2. Perform mac operation
3. Terminate a previously opened mac service flow
User can call this function only after having opened a key store service flow.

Parameters

<i>key_store_hdl</i>	handle identifying the key store service flow.
<i>args</i>	pointer to the structure containing the function arguments.

Returns

error code

6.10.3.2 hsm_open_mac_service() `hsm_err_t hsm_open_mac_service (`
`hsm_hdl_t key_store_hdl,`
`open_svc_mac_args_t * args,`
`hsm_hdl_t * mac_hdl)`

Open a mac service flow

User can call this function only after having opened a key store service flow.
 User must open this service in order to perform mac operation

Parameters

<i>key_store_hdl</i>	handle identifying the key store service flow.
<i>args</i>	pointer to the structure containing the function arguments.
<i>mac_hdl</i>	pointer to where the mac service flow handle must be written.

Returns

error code

6.10.3.3 hsm_mac_one_go() `hsm_err_t hsm_mac_one_go (`
`hsm_hdl_t mac_hdl,`
`op_mac_one_go_args_t * args,`
`hsm_mac_verification_status_t * status)`

Perform mac operation

User can call this function only after having opened a mac service flow

For CMAC algorithm, a key of type HSM_KEY_TYPE_AES_XXX must be used

For HMAC algorithm, a key of type HSM_KEY_TYPE_HMAC_XXX must be used

For mac verification operations, the verified mac length can be specified in:

- Bits by setting the HSM_OP_MAC_ONE_GO_FLAGS_MAC_LENGTH_IN_BITS flag,
- if this flag is clear then the mac_length is specified in bytes.

For mac generation operations:

- mac length must be set in bytes, and
- HSM_OP_MAC_ONE_GO_FLAGS_MAC_LENGTH_IN_BITS flag must be 0

Parameters

<i>mac_hdl</i>	handle identifying the mac service flow.
<i>args</i>	pointer to the structure containing the function arguments.

Returns

error code

6.10.3.4 hsm_close_mac_service() `hsm_err_t hsm_close_mac_service (`
`hsm_hdl_t mac_hdl)`

Terminate a previously opened mac service flow

Parameters

<i>mac_hdl</i>	pointer to handle identifying the mac service flow to be closed.
----------------	--

Returns

error code

6.11 Public key reconstruction

Modules

- [i.MX8QXP specificities](#)
- [i.MX8DXL specificities](#)

Data Structures

- struct [op_pub_key_rec_args_t](#)

Typedefs

- typedef uint8_t [hsm_op_pub_key_rec_flags_t](#)

Functions

- [hsm_err_t hsm_pub_key_reconstruction](#) (hsm_hdl_t session_hdl, [op_pub_key_rec_args_t](#) *args)

6.11.1 Detailed Description

6.11.2 Data Structure Documentation

Data Fields

uint8_t *	pub_rec	< pointer to the public reconstruction value extracted from the pointer to the input hash value. In the butterfly scheme it
uint8_t *	hash	pointer to the CA public key
uint8_t *	ca_key	pointer to the output area where the reconstructed public key must
uint8_t *	out_key	length in bytes of the public reconstruction value
uint16_t	pub_rec_size	length in bytes of the input hash
uint16_t	hash_size	length in bytes of the input CA public key
uint16_t	ca_key_size	length in bytes of the output key
uint16_t	out_key_size	indicates the type of the managed key.
hsm_key_type_t	key_type	flags bitmap specifying the operation attributes.
hsm_op_pub_key_rec_flags_t	flags	
uint16_t	reserved	

6.11.2.1 struct op_pub_key_rec_args_t

6.11.3 Function Documentation

6.11.3.1 hsm_pub_key_reconstruction() `hsm_err_t hsm_pub_key_reconstruction (`
`hsm_hdl_t session_hdl,`
`op_pub_key_rec_args_t * args)`

Reconstruct an ECC public key provided by an implicit certificate

User can call this function only after having opened a session

This API implements the following formula:

$\text{out_key} = (\text{pub_rec} * \text{hash}) + \text{ca_key}$

Parameters

<i>session_hdl</i>	handle identifying the current session.
<i>args</i>	pointer to the structure containing the function arguments.

Returns

error code

6.12 Public key decompression

Modules

- [i.MX8QXP specificities](#)

Data Structures

- struct [op_pub_key_dec_args_t](#)

Typedefs

- typedef uint8_t [hsm_op_pub_key_dec_flags_t](#)

Functions

- [hsm_err_t hsm_pub_key_decompression](#) (hsm_hdl_t session_hdl, [op_pub_key_dec_args_t](#) *args)

6.12.1 Detailed Description

6.12.2 Data Structure Documentation

Data Fields

uint8_t *	key	< pointer to the compressed ECC public key. pointer to the output area where the decompressed public key must be written.
uint8_t *	out_key	length in bytes of the input compressed public key
uint16_t	key_size	length in bytes of the resulting public key
uint16_t	out_key_size	indicates the type of the manged keys.
hsm_key_type_t	key_type	bitmap specifying the operation attributes.
hsm_op_pub_key_dec_flags_t	flags	
uint16_t	reserved	

6.12.2.1 struct op_pub_key_dec_args_t

6.12.3 Function Documentation

6.12.3.1 hsm_pub_key_decompression() [hsm_err_t hsm_pub_key_decompression](#) (
[hsm_hdl_t session_hdl](#),
[op_pub_key_dec_args_t](#) * args)

Decompress an ECC public key

The expected key format is x||lsb_y where lsb_y is 1 byte having value: 1 if the least-significant bit of the original (uncompressed) y coordinate is set. 0 otherwise. User can call this function only after having opened a session

Parameters

<i>session_hdl</i>	handle identifying the current session.
<i>args</i>	pointer to the structure containing the function arguments.

Returns

error code

6.13 ECIES encryption

Modules

- [i.MX8QXP specificities](#)
- [i.MX8DXL specificities](#)

Data Structures

- struct [op_ecies_enc_args_t](#)

Typedefs

- typedef uint8_t [hsm_op_ecies_enc_flags_t](#)

Functions

- [hsm_err_t hsm_ecies_encryption](#) (hsm_hdl_t session_hdl, [op_ecies_enc_args_t](#) *args)

6.13.1 Detailed Description

6.13.2 Data Structure Documentation

Data Fields

uint8_t *	input	< pointer to the input plaintext pointer to the input recipient public key
uint8_t *	pub_key	pointer to the KDF P1 input parameter
uint8_t *	p1	pointer to the MAC P2 input parameter should be NULL
uint8_t *	p2	pointer to the output area where the VCT must be written
uint8_t *	output	length in bytes of the input plaintext should be equal to 16 bytes
uint32_t	input_size	length in bytes of the KDF P1 parameter should be equal to 32 bytes
uint16_t	p1_size	length in bytes of the MAC P2 parameter should be zero reserved for
uint16_t	p2_size	length in bytes of the recipient public key should be equal to 64 bytes
uint16_t	pub_key_size	length in bytes of the requested message authentication code should
uint16_t	mac_size	length in bytes of the output VCT should be equal to 96 bytes
uint32_t	out_size	indicates the type of the recipient public key
hsm_key_type_t	key_type	bitmap specifying the operation attributes.
hsm_op_ecies_enc_flags_t	flags	
uint16_t	reserved	

6.13.2.1 struct op_ecies_enc_args_t

6.13.3 Function Documentation

6.13.3.1 hsm_ecies_encryption() `hsm_err_t hsm_ecies_encryption (`
 `hsm_hdl_t session_hdl,`
 `op_ecies_enc_args_t * args)`

Encrypt data usign ECIES

User can call this function only after having opened a session.

ECIES is supported with the constraints specified in 1609.2-2016.

Parameters

<i>session_hdl</i>	handle identifying the current session.
<i>args</i>	pointer to the structure containing the function arguments.

Returns

error code

6.14 Root KEK export

Data Structures

- struct [op_export_root_kek_args_t](#)

Macros

- #define **HSM_OP_EXPORT_ROOT_KEK_FLAGS_COMMON_KEK** ((hsm_op_export_root_kek_flags_t)(1u << 0))
- #define **HSM_OP_EXPORT_ROOT_KEK_FLAGS_UNIQUE_KEK** ((hsm_op_export_root_kek_flags_t)(0u << 0))

Typedefs

- typedef uint8_t **hsm_op_export_root_kek_flags_t**

Functions

- [hsm_err_t](#) [hsm_export_root_key_encryption_key](#) ([hsm_hdl_t](#) session_hdl, [op_export_root_kek_args_t](#) *args)

6.14.1 Detailed Description

6.14.2 Data Structure Documentation

Data Fields

uint8_t *	signed_message	< pointer to signed_message authorizing the operation pointer to the output area where the derived root kek
uint8_t *	out_root_kek	size of the signed_message authorizing the operation
uint16_t	signed_msg_size	length in bytes of the root kek. Must be 32 bytes.
uint8_t	root_kek_size	flags bitmap specifying the operation attributes.
hsm_op_export_root_kek_flags_t	flags	
uint8_t	reserved[2]	

6.14.2.1 struct op_export_root_kek_args_t

6.14.3 Function Documentation

- ##### 6.14.3.1 hsm_export_root_key_encryption_key()
- ```
hsm_err_t hsm_export_root_key_encryption_key (
 hsm_hdl_t session_hdl,
 op_export_root_kek_args_t * args)
```

Export the root key encryption key. This key is derived on chip. It can be common or chip unique. This key will be used to import key in the key store through the manage key API.



**Parameters**

|                    |                                                             |
|--------------------|-------------------------------------------------------------|
| <i>session_hdl</i> | handle identifying the current session.                     |
| <i>args</i>        | pointer to the structure containing the function arguments. |

**Returns**

error code

## 6.15 SM2 Get Z

### Modules

- [i.MX8QXP specificities](#)

### Data Structures

- struct [op\\_sm2\\_get\\_z\\_args\\_t](#)

### Typedefs

- typedef uint8\_t [hsm\\_op\\_sm2\\_get\\_z\\_flags\\_t](#)

### Functions

- [hsm\\_err\\_t hsm\\_sm2\\_get\\_z](#) ([hsm\\_hdl\\_t session\\_hdl](#), [op\\_sm2\\_get\\_z\\_args\\_t \\*args](#))

#### 6.15.1 Detailed Description

#### 6.15.2 Data Structure Documentation

##### Data Fields

|                                          |                 |                                                                      |
|------------------------------------------|-----------------|----------------------------------------------------------------------|
| uint8_t *                                | public_key      | < pointer to the sender public key pointer to the sender identifier  |
| uint8_t *                                | identifier      | pointer to the output area where the Z value must be written         |
| uint8_t *                                | z_value         | length in bytes of the sender public key should be equal to 64 bytes |
| uint16_t                                 | public_key_size | length in bytes of the identifier                                    |
| uint8_t                                  | id_size         | length in bytes of Z should be at least 32 bytes                     |
| uint8_t                                  | z_size          | indicates the type of the sender public key.                         |
| <a href="#">hsm_key_type_t</a>           | key_type        | bitmap specifying the operation attributes.                          |
| <a href="#">hsm_op_sm2_get_z_flags_t</a> | flags           |                                                                      |
| uint8_t                                  | reserved[2]     |                                                                      |

##### 6.15.2.1 struct op\_sm2\_get\_z\_args\_t

#### 6.15.3 Function Documentation

##### 6.15.3.1 [hsm\\_sm2\\_get\\_z\(\)](#) [hsm\\_err\\_t hsm\\_sm2\\_get\\_z](#) ( [hsm\\_hdl\\_t session\\_hdl](#), [op\\_sm2\\_get\\_z\\_args\\_t \\*args](#) )

This command is designed to compute:  $Z = SM3(Entl || ID || a || b || xG || yG || xpubk || ypubk)$  where,

- ID, Entl: user distinguishing identifier and length,
- a, b, xG and yG : curve parameters,
- xpubk , ypubk : public key

This value is used for SM2 public key cryptography algorithms, as specified in GB/T 32918. User can call this function only after having opened a session.

#### Parameters

|                    |                                                             |
|--------------------|-------------------------------------------------------------|
| <i>session_hdl</i> | handle identifying the current session.                     |
| <i>args</i>        | pointer to the structure containing the function arguments. |

#### Returns

error code

## 6.16 SM2 ECES decryption

### Modules

- [i.MX8QXP specificities](#)
- [i.MX8DXL specificities](#)

### Data Structures

- struct [open\\_svc\\_sm2\\_eces\\_args\\_t](#)
- struct [op\\_sm2\\_eces\\_dec\\_args\\_t](#)

### Typedefs

- typedef uint8\_t [hsm\\_svc\\_sm2\\_eces\\_flags\\_t](#)
- typedef uint8\_t [hsm\\_op\\_sm2\\_eces\\_dec\\_flags\\_t](#)

### Functions

- [hsm\\_err\\_t hsm\\_open\\_sm2\\_eces\\_service](#) (hsm\_hdl\_t key\_store\_hdl, [open\\_svc\\_sm2\\_eces\\_args\\_t](#) \*args, hsm\_hdl\_t \*sm2\_eces\_hdl)
- [hsm\\_err\\_t hsm\\_close\\_sm2\\_eces\\_service](#) (hsm\_hdl\_t sm2\_eces\_hdl)
- [hsm\\_err\\_t hsm\\_sm2\\_eces\\_decryption](#) (hsm\_hdl\_t sm2\_eces\_hdl, [op\\_sm2\\_eces\\_dec\\_args\\_t](#) \*args)

#### 6.16.1 Detailed Description

#### 6.16.2 Data Structure Documentation

##### Data Fields

|                                          |             |                                                 |
|------------------------------------------|-------------|-------------------------------------------------|
| <a href="#">hsm_svc_sm2_eces_flags_t</a> | flags       | < bitmap indicating the service flow properties |
| uint8_t                                  | reserved[3] |                                                 |

##### 6.16.2.1 struct [open\\_svc\\_sm2\\_eces\\_args\\_t](#)

##### Data Fields

|                                             |                |                                                                                                 |
|---------------------------------------------|----------------|-------------------------------------------------------------------------------------------------|
| uint32_t                                    | key_identifier | < identifier of the private key to be used for the operation<br>pointer to the input ciphertext |
| uint8_t *                                   | input          | pointer to the output area where the plaintext must be<br>written                               |
| uint8_t *                                   | output         | length in bytes of the input ciphertext.                                                        |
| uint32_t                                    | input_size     | length in bytes of the output plaintext                                                         |
| uint32_t                                    | output_size    | Indicates the type of the used key.                                                             |
| <a href="#">hsm_key_type_t</a>              | key_type       | bitmap specifying the operation attributes.                                                     |
| <a href="#">hsm_op_sm2_eces_dec_flags_t</a> | flags          |                                                                                                 |
| uint16_t                                    | reserved       |                                                                                                 |

### 6.16.2.2 struct op\_sm2\_eces\_dec\_args\_t

## 6.16.3 Function Documentation

**6.16.3.1 hsm\_open\_sm2\_eces\_service()** `hsm_err_t hsm_open_sm2_eces_service (`  
`hsm_hdl_t key_store_hdl,`  
`open_svc_sm2_eces_args_t * args,`  
`hsm_hdl_t * sm2_eces_hdl )`

Open a SM2 ECES decryption service flow

User can call this function only after having opened a key store.

User must open this service in order to perform SM2 decryption.

#### Parameters

|                     |                                                                    |
|---------------------|--------------------------------------------------------------------|
| <i>session_hdl</i>  | handle identifying the current session.                            |
| <i>args</i>         | pointer to the structure containing the function arguments.        |
| <i>sm2_eces_hdl</i> | pointer to where the sm2 eces service flow handle must be written. |

#### Returns

error code

**6.16.3.2 hsm\_close\_sm2\_eces\_service()** `hsm_err_t hsm_close_sm2_eces_service (`  
`hsm_hdl_t sm2_eces_hdl )`

Terminate a previously opened SM2 ECES service flow

#### Parameters

|                     |                                                            |
|---------------------|------------------------------------------------------------|
| <i>sm2_eces_hdl</i> | handle identifying the SM2 ECES service flow to be closed. |
|---------------------|------------------------------------------------------------|

#### Returns

error code

**6.16.3.3 hsm\_sm2\_eces\_decryption()** `hsm_err_t hsm_sm2_eces_decryption (`  
`hsm_hdl_t sm2_eces_hdl,`  
`op_sm2_eces_dec_args_t * args )`

Decrypt data usign SM2 ECES

User can call this function only after having opened a SM2 ECES service flow.

SM2 ECES is supported with the requirements specified in the GB/T 32918.4.

**Parameters**

|                     |                                                             |
|---------------------|-------------------------------------------------------------|
| <i>sm2_eces_hdl</i> | handle identifying the SM2 ECES                             |
| <i>args</i>         | pointer to the structure containing the function arguments. |

**Returns**

error code

## 6.17 SM2 ECES encryption

### Modules

- [i.MX8QXP specificities](#)
- [i.MX8DXL specificities](#)

### Data Structures

- struct [op\\_sm2\\_eces\\_enc\\_args\\_t](#)

### Typedefs

- typedef uint8\_t [hsm\\_op\\_sm2\\_eces\\_enc\\_flags\\_t](#)

### Functions

- [hsm\\_err\\_t hsm\\_sm2\\_eces\\_encryption](#) (hsm\_hdl\_t session\_hdl, [op\\_sm2\\_eces\\_enc\\_args\\_t](#) \*args)

#### 6.17.1 Detailed Description

#### 6.17.2 Data Structure Documentation

##### Data Fields

|                                             |              |                                                                                                  |
|---------------------------------------------|--------------|--------------------------------------------------------------------------------------------------|
| uint8_t *                                   | input        | < pointer to the input plaintext pointer to the output area where the ciphertext must be written |
| uint8_t *                                   | output       | pointer to the input recipient public key                                                        |
| uint8_t *                                   | pub_key      | length in bytes of the input plaintext                                                           |
| uint32_t                                    | input_size   | Length in bytes of the output ciphertext.                                                        |
| uint32_t                                    | output_size  | length in bytes of the recipient public key should be equal to 64 bytes                          |
| uint16_t                                    | pub_key_size | Indicates the type of the recipient public key.                                                  |
| <a href="#">hsm_key_type_t</a>              | key_type     | bitmap specifying the operation attributes.                                                      |
| <a href="#">hsm_op_sm2_eces_enc_flags_t</a> | flags        |                                                                                                  |

##### 6.17.2.1 struct op\_sm2\_eces\_enc\_args\_t

#### 6.17.3 Function Documentation

##### 6.17.3.1 hsm\_sm2\_eces\_encryption()

```
hsm_err_t hsm_sm2_eces_encryption (
 hsm_hdl_t session_hdl,
 op_sm2_eces_enc_args_t * args)
```

Encrypt data using SM2 ECES

User can call this function only after having opened a session.

SM2 ECES is supported with the requirements specified in the GB/T 32918.4.

The output (i.e. ciphertext) is stored in the format  $C = C1 || C2 || C3$ . Where,  $C1 = PC || x1 || y1$  where  $PC=04$  and  $(x1,y1)$  are the coordinates of an elliptic curve point

$C2 = M \text{ xor } t$  where  $t = \text{KDF}(x2 || y2, \text{input\_size})$  and  $(x2,y2)$  are the coordinates of an elliptic curve point

$C3 = \text{SM3}(x2 || M || y2)$

#### Parameters

|                    |                                                             |
|--------------------|-------------------------------------------------------------|
| <i>session_hdl</i> | handle identifying the current session.                     |
| <i>args</i>        | pointer to the structure containing the function arguments. |

#### Returns

error code



## 6.18 Key exchange

### Modules

- [i.MX8QXP specificities](#)
- [i.MX8DXL specificities](#)

### Data Structures

- struct [op\\_key\\_exchange\\_args\\_t](#)
- struct [op\\_tls\\_finish\\_args\\_t](#)

### Macros

- `#define HSM_KDF_ALG_FOR_SM2 ((hsm_kdf_algo_id_t)0x10u)`  
*TLS PRF based on HMAC with SHA-256, the resulting mac\_key\_length is 0 bytes,.*
- `#define HSM_KDF_HMAC_SHA_256_TLS_0_16_4 ((hsm_kdf_algo_id_t)0x20u)`  
*TLS PRF based on HMAC with SHA-384, the resulting mac\_key\_length is 0 bytes,.*
- `#define HSM_KDF_HMAC_SHA_384_TLS_0_32_4 ((hsm_kdf_algo_id_t)0x21u)`  
*TLS PRF based on HMAC with SHA-256, the resulting mac\_key\_length is 0 bytes,.*
- `#define HSM_KDF_HMAC_SHA_256_TLS_0_32_4 ((hsm_kdf_algo_id_t)0x22u)`  
*TLS PRF based on HMAC with SHA-256, the resulting mac\_key\_length is 32 bytes,.*
- `#define HSM_KDF_HMAC_SHA_256_TLS_32_16_4 ((hsm_kdf_algo_id_t)0x23u)`  
*TLS PRF based on HMAC with SHA-384, the resulting mac\_key\_length is 48 bytes,.*
- `#define HSM_KDF_HMAC_SHA_384_TLS_48_32_4 ((hsm_kdf_algo_id_t)0x24u)`  
*One-Step Key Derivation using SHA256 as per NIST SP80056C. It can only be used,.*
- `#define HSM_KDF_ONE_STEP_SHA_256 ((hsm_kdf_algo_id_t)0x31u)`
- `#define HSM_KEY_SCHEME_ECDH_NIST_P256 ((hsm_key_exchange_scheme_id_t)0x02u)`
- `#define HSM_KEY_SCHEME_ECDH_NIST_P384 ((hsm_key_exchange_scheme_id_t)0x03u)`
- `#define HSM_KEY_SCHEME_ECDH_BRAINPOOL_R1_256 ((hsm_key_exchange_scheme_id_t)0x13u)`
- `#define HSM_KEY_SCHEME_ECDH_BRAINPOOL_R1_384 ((hsm_key_exchange_scheme_id_t)0x15u)`
- `#define HSM_KEY_SCHEME_ECDH_BRAINPOOL_T1_256 ((hsm_key_exchange_scheme_id_t)0x23u)`
- `#define HSM_KEY_SCHEME_SM2_FP_256 ((hsm_key_exchange_scheme_id_t)0x42u)`  
*User can replace an existing key only by the derived key which should have.*
- `#define HSM_OP_KEY_EXCHANGE_FLAGS_UPDATE ((hsm_op_key_exchange_flags_t)(1u << 0))`  
*Create a new key.*
- `#define HSM_OP_KEY_EXCHANGE_FLAGS_CREATE ((hsm_op_key_exchange_flags_t)(1u << 1))`  
*Use an ephemeral key (freshly generated key)*
- `#define HSM_OP_KEY_EXCHANGE_FLAGS_GENERATE_EPHEMERAL ((hsm_op_key_exchange_flags_t)(1u << 2))`  
*Enable key confirmation (valid only in case of HSM\_KEY\_SCHEME\_SM2\_FP\_256)*
- `#define HSM_OP_KEY_EXCHANGE_FLAGS_KEY_CONF_EN ((hsm_op_key_exchange_flags_t)(1u << 3))`  
*Use extended master secret for TLS KDFs.*
- `#define HSM_OP_KEY_EXCHANGE_FLAGS_USE_TLS_EMS ((hsm_op_key_exchange_flags_t)(1u << 4))`  
*The request is completed only when the new key has been written in the NVM.*
- `#define HSM_OP_KEY_EXCHANGE_FLAGS_STRICT_OPERATION ((hsm_op_key_exchange_flags_t)(1u << 7))`
- `#define HSM_OP_TLS_FINISH_HASH_ALGO_SHA256 (0x06)`
- `#define HSM_OP_TLS_FINISH_HASH_ALGO_SHA384 (0x07)`  
*Use "client finished" label for PRF.*
- `#define HSM_OP_TLS_FINISH_FLAGS_CLIENT BIT(0)`  
*Use "server finished" label for PRF.*
- `#define HSM_OP_TLS_FINISH_FLAGS_SERVER BIT(1)`

## Typedefs

- typedef uint8\_t **hsm\_kdf\_algo\_id\_t**
- typedef uint8\_t **hsm\_key\_exchange\_scheme\_id\_t**
- typedef uint8\_t **hsm\_op\_key\_exchange\_flags\_t**
- typedef uint8\_t **hsm\_op\_tls\_finish\_algo\_id\_t**
- typedef uint8\_t **hsm\_op\_tls\_finish\_flags\_t**

## Functions

- [hsm\\_err\\_t hsm\\_key\\_exchange](#) (hsm\_hdl\_t key\_management\_hdl, [op\\_key\\_exchange\\_args\\_t](#) \*args)
- [hsm\\_err\\_t hsm\\_tls\\_finish](#) (hsm\_hdl\_t key\_management\_hdl, [op\\_tls\\_finish\\_args\\_t](#) \*args)

### 6.18.1 Detailed Description

### 6.18.2 Data Structure Documentation

#### Data Fields

|                                |                                  |                                                                                                                |
|--------------------------------|----------------------------------|----------------------------------------------------------------------------------------------------------------|
| uint32_t                       | key_identifier                   | < Identifier of the key used for derivation. pointer to the identifiers of the derived keys. In case of create |
| uint8_t *                      | shared_key_identifier_array      | pointer to the initiator input data related to the key exchange function.                                      |
| uint8_t *                      | ke_input                         | pointer to the output area where the data related to the key                                                   |
| uint8_t *                      | ke_output                        | pointer to the input data of the KDF.                                                                          |
| uint8_t *                      | kdf_input                        | pointer to the output area where the non sensitive output data                                                 |
| uint8_t *                      | kdf_output                       | It specifies the group where the derived keys will be stored.                                                  |
| hsm_key_group_t                | shared_key_group                 | bitmap specifying the properties of the derived keys, it will be                                               |
| hsm_key_info_t                 | shared_key_info                  | indicates the type of the derived key.                                                                         |
| <a href="#">hsm_key_type_t</a> | shared_key_type                  | Indicates the public data type specified by the initiator,.                                                    |
| <a href="#">hsm_key_type_t</a> | initiator_public_data_type       | indicates the key exchange scheme                                                                              |
| hsm_key_exchange_scheme_id_t   | key_exchange_scheme              | indicates the KDF algorithm                                                                                    |
| hsm_kdf_algo_id_t              | kdf_algorithm                    | length in bytes of the input data of the key exchange function.                                                |
| uint16_t                       | ke_input_size                    | length in bytes of the output data of the key exchange function                                                |
| uint16_t                       | ke_output_size                   | length in byte of the area containing the shared key identifiers                                               |
| uint8_t                        | shared_key_identifier_array_size | length in bytes of the input data of the KDF.                                                                  |

## Data Fields

|                             |                 |                                                                      |
|-----------------------------|-----------------|----------------------------------------------------------------------|
| uint8_t                     | kdf_input_size  | length in bytes of the non sensitive output data related to the KDF. |
| uint8_t                     | kdf_output_size | bitmap specifying the operation properties                           |
| hsm_op_key_exchange_flags_t | flags           | pointer to the signed_message authorizing the operation.             |
| uint8_t *                   | signed_message  | size of the signed_message authorizing the operation.                |
| uint16_t                    | signed_msg_size | It must be 0.                                                        |
| uint8_t                     | reserved[2]     |                                                                      |

## 6.18.2.1 struct op\_key\_exchange\_args\_t

## Data Fields

|                             |                           |                                                                                                                                  |
|-----------------------------|---------------------------|----------------------------------------------------------------------------------------------------------------------------------|
| uint32_t                    | key_identifier            | < identifier of the master_secret key used for the PRF. pointer to the input area containing the hash of the handshake messages. |
| uint8_t *                   | handshake_hash_input      | pointer to the output area where the verify_data contents will be written.                                                       |
| uint8_t *                   | verify_data_output        | size of the hash of the handshake messages                                                                                       |
| uint16_t                    | handshake_hash_input_size | size of the required verify_data output                                                                                          |
| uint16_t                    | verify_data_output_size   | bitmap specifying the operation properties                                                                                       |
| hsm_op_tls_finish_flags_t   | flags                     | hash algorithm to be used for the PRF                                                                                            |
| hsm_op_tls_finish_algo_id_t | hash_algorithm            | It must be 0.                                                                                                                    |
| uint8_t                     | reserved[2]               |                                                                                                                                  |

## 6.18.2.2 struct op\_tls\_finish\_args\_t

## 6.18.3 Function Documentation

**6.18.3.1 hsm\_key\_exchange()** `hsm_err_t hsm_key_exchange (`  
`hsm_hdl_t key_management_hdl,`  
`op_key_exchange_args_t * args )`

This command is designed to compute secret keys through a key exchange protocol and the use of a key derivation function. The resulting secret keys are stored into the key store as new keys or as an update of existing keys. A freshly generated key or an existing key can be used as input of the shared secret calculation. User can call this function only after having opened a key management service flow.

This API support three use cases:

- Key Encryption Key generation:

- shared\_key\_identifier\_array: it must corresponds to the KEK key id.
  - The kdf\_input must be 0
  - The kdf\_output must be 0
  - The shared\_key\_info must have the HSM\_KEY\_INFO\_KEK bit set. (only Key Encryption Keys can be generated).
  - The shared\_key\_type must be HSM\_KEY\_TYPE\_AES\_256
  - The initiator\_public\_data\_type must be: – HSM\_KEY\_TYPE\_ECDSA\_NIST\_P256 or – HSM\_KEY\_TYPE\_ECDSA\_BRAINPOOL\_R1\_256 or – HSM\_KEY\_TYPE\_ECDSA\_BRAINPOOL\_T1\_256.
  - The key\_exchange\_scheme must be: – HSM\_KEY\_SCHEME\_ECDH\_NIST\_P256 or – HSM\_KEY\_SCHEME\_ECDH\_BRAINPOOL\_R1\_256 or – HSM\_KEY\_SCHEME\_ECDH\_BRAINPOOL\_T1\_256.
  - The kdf\_algorithm must be HSM\_KDF\_ONE\_STEP\_SHA\_256. As per as per SP800-56C rev2, the KEK is generated using the formula:  $\Rightarrow \text{SHA}_{256}(\text{counter} || Z || \text{FixedInput})$ , where: – counter is the value 1 expressed in 32 bit and in big endian format – Z is the shared secret generated by the DH key-establishment scheme – FixedInput is the literal 'NXP HSM USER KEY DERIVATION' (27 bytes, no null termination).
  - The kdf\_input\_size must be 0.
  - The kdf\_output\_size must be 0.
  - Flags: Use of the flag HSM\_OP\_KEY\_EXCHANGE\_FLAGS\_GENERATE\_EPHEMERAL, is mandatory. (Only freshly generated keys can be used as input of the Z derivation.)
  - signed\_message: mandatory in OEM CLOSED life cycle.
- TLS Key generation:
    - Only an ephemeral key pair is supported as input of the TLS key\_exchange negotiation. This can be:
      - \* either a TRANSIENT private key already stored into the key store. – Indicated by its key identifier. – To prevent any misuse non-transient key will be rejected. – Additionally the private key will be deleted from the key store as part of this command handling.
      - \* either a key pair freshly generated by the use of flag: – HSM\_OP\_KEY\_EXCHANGE\_FLAGS\_GENERATE\_EPHEMERAL.
    - shared\_key\_identifier\_array: It must correspond to the concatenation of: – client\_write\_MAC\_key id (4 bytes, if any), – server\_write\_MAC\_key id (4 bytes, if any), – client\_write\_key id (4 bytes), – the server\_write\_key id (4 bytes), and – the master\_secret key id (4 bytes).
    - The kdf\_input format depends on the HSM\_OP\_KEY\_EXCHANGE\_FLAGS\_USE\_TLS\_EMS flag:
      - \* for HSM\_OP\_KEY\_EXCHANGE\_FLAGS\_USE\_TLS\_EMS not set, the kdf\_input must correspond to the concatenation of: – clientHello\_random (32 bytes), – serverHello\_random (32 bytes), – server\_random (32 bytes) and – client\_random (32 bytes).
      - \* for HSM\_OP\_KEY\_EXCHANGE\_FLAGS\_USE\_TLS\_EMS set, the kdf\_input must correspond to the concatenation of: – message\_hash, – server\_random (32 bytes) and – client\_random (32 bytes). The length of the message\_hash must be: – 32 bytes for SHA256 based KDFs, or – 48 bytes for SHA384 based KDFs.
    - kdf\_output: the concatenation of: – client\_write\_iv (4 bytes) and – server\_write\_iv (4 bytes) will be stored at this address.
    - The shared\_key\_info must have: – the HSM\_KEY\_INFO\_TRANSIENT bit set (only transient keys can be generated), – the HSM\_KEY\_INFO\_KEK bit is not allowed.
    - The shared\_key\_type is not applicable and must be left to 0.
    - The initiator\_public\_data\_type must be: – HSM\_KEY\_TYPE\_ECDSA\_NIST\_P256/384, or – HSM\_KEY\_TYPE\_ECDSA\_BRAINPOOL\_R1\_256/384.
    - The key\_exchange\_scheme must be: – HSM\_KEY\_SCHEME\_ECDH\_NIST\_P256/384, or – HSM\_KEY\_SCHEME\_ECDH\_BRAINPOOL\_R1\_256/384.
    - The kdf\_algorithm must be HSM\_KDF\_HMAC\_SHA\_xxx\_TLS\_xxx. – The generated MAC keys will have type ALG\_HMAC\_XXX, where, — XXX corresponds to the key length in bit of generated MAC key. – The generated encryption keys will have type HSM\_KEY\_TYPE\_AES\_XXX, where, — XXX corresponds to the key length in bit of the generated AES key. – The master\_secret key can only be used for: — the hsm\_tls\_finish function, or — be deleted using the hsm\_manage\_key function.

- `kdf_input_size`:
  - \* for `HSM_OP_KEY_EXCHANGE_FLAGS_USE_TLS_EMS` not set, it must be 128 bytes.
  - \* for `HSM_OP_KEY_EXCHANGE_FLAGS_USE_TLS_EMS` set, it must be: – 96 (SHA256), or – 112 (SHA384) bytes.
- `kdf_output_size`: It must be 8 bytes
- `signed_message`: it must be NULL
- SM2 key generation (as specified in GB/T 32918):
  - Only the receiver role is supported.
  - `ke_input` =  $(x||y) || (xephemeral||yephemeral)$  of the 2 public keys of initiator
  - `ke_out` =  $(x||y) || (xephemeral||yephemeral)$  of the 2 public keys the receiver
  - `kdf_input` =  $(Z_{initiator}||Z_{initiator}||V1)$  if: – `HSM_OP_KEY_EXCHANGE_FLAGS_KEY_CONF_EN` enabled. Where, V1 is the verification value calculated on the initiator side.
  - `kdf_output` = –  $(VA||VB)$ , if `HSM_OP_KEY_EXCHANGE_FLAGS_KEY_CONF_EN` enabled, – 0 otherwise.
  - `shared_key_info`: the `HSM_KEY_INFO_KEK` bit is not allowed.
  - The `shared_key_type` must be `HSM_KEY_TYPE_SM4_128` or `HSM_KEY_TYPE_DSA_SM2_FP_256`
  - The `initiator_public_data_type` must be `HSM_KEY_TYPE_DSA_SM2_FP_256`
  - The `key_exchange_scheme` must be `HSM_KEY_SCHEME_SM2_FP_256`.
  - The `kdf_algorithm` must be `HSM_KDF_ALG_FOR_SM2`.
  - Flags: the `HSM_OP_KEY_EXCHANGE_FLAGS_GENERATE_EPHEMERAL` flag is not supported
  - `signed_message`: it must be NULL

#### Parameters

|                           |                                                             |
|---------------------------|-------------------------------------------------------------|
| <i>key_management_hdl</i> | handle identifying the key store management service flow.   |
| <i>args</i>               | pointer to the structure containing the function arguments. |

#### Returns

error code

**6.18.3.2 hsm\_tls\_finish()** `hsm_err_t hsm_tls_finish (`  
     `hsm_hdl_t key_management_hdl,`  
     `op_tls_finish_args_t * args )`

This command is designed to compute the `verify_data` block required for the Finished message in the TLS handshake.

The input key must be a `master_secret` key generated by a previous `hsm_key_exchange` call using a TLS KDF. User can call this function only after having opened a key management service flow.

#### Parameters

|                           |                                                             |
|---------------------------|-------------------------------------------------------------|
| <i>key_management_hdl</i> | handle identifying the key store management service flow.   |
| <i>args</i>               | pointer to the structure containing the function arguments. |

**Returns**

error code

## 6.19 Standalone butterfly key expansion

### Modules

- [i.MX8QXP specificities](#)
- [i.MX8DXL specificities](#)

### Data Structures

- struct [op\\_st\\_butt\\_key\\_exp\\_args\\_t](#)

### Macros

- `#define HSM_OP_ST_BUTTERFLY_KEY_FLAGS_UPDATE ((hsm_op_st_but_key_exp_flags_t)(1u << 0))`  
*Create a new key.*
- `#define HSM_OP_ST_BUTTERFLY_KEY_FLAGS_CREATE ((hsm_op_st_but_key_exp_flags_t)(1u << 1))`  
*standalone butterfly key expansion using implicit certificate.*
- `#define HSM_OP_ST_BUTTERFLY_KEY_FLAGS_IMPLICIT_CERTIF ((hsm_op_st_but_key_exp_flags_t)(0u << 2))`  
*standalone butterfly key expansion using explicit certificate.*
- `#define HSM_OP_ST_BUTTERFLY_KEY_FLAGS_EXPLICIT_CERTIF ((hsm_op_st_but_key_exp_flags_t)(1u << 2))`  
*The request is completed only when the new key has been written in the NVM.*
- `#define HSM_OP_ST_BUTTERFLY_KEY_FLAGS_STRICT_OPERATION ((hsm_op_st_but_key_exp_flags_t)(1u << 7))`

### Typedefs

- typedef uint8\_t [hsm\\_op\\_st\\_but\\_key\\_exp\\_flags\\_t](#)

### Functions

- [hsm\\_err\\_t hsm\\_standalone\\_butterfly\\_key\\_expansion](#) (hsm\_hdl\_t key\_management\_hdl, [op\\_st\\_butt\\_key\\_exp\\_args\\_t](#) \*args)  
*User can replace an existing key only by generating a key with the same.*

#### 6.19.1 Detailed Description

#### 6.19.2 Data Structure Documentation

##### Data Fields

|           |                              |                                                                                                                      |
|-----------|------------------------------|----------------------------------------------------------------------------------------------------------------------|
| uint32_t  | key_identifier               | < identifier of the key to be expanded.<br>identifier of the key to be use for the<br>expansion function computation |
| uint32_t  | expansion_fct_key_identifier | pointer to the input used to compute the<br>expansion function                                                       |
| uint8_t * | expansion_fct_input          | pointer to the hash value input.<br>In case of explicit certificate,                                                 |

## Data Fields

|                               |                              |                                                                        |
|-------------------------------|------------------------------|------------------------------------------------------------------------|
| uint8_t *                     | hash_value                   | pointer to the private reconstruction value input.                     |
| uint8_t *                     | pr_reconstruction_value      | length in bytes of the expansion function input.                       |
| uint8_t                       | expansion_fct_input_size     | length in bytes of the hash value input.                               |
| uint8_t                       | hash_value_size              | length in bytes of the private reconstruction value input.             |
| uint8_t                       | pr_reconstruction_value_size | bitmap specifying the operation properties                             |
| hsm_op_st_but_key_exp_flags_t | flags                        | pointer to identifier of the derived key to be used for the operation. |
| uint32_t *                    | dest_key_identifier          | pointer to the output area where the public key must be written.       |
| uint8_t *                     | output                       | length in bytes of the generated key, if the size is 0, no key is      |
| uint16_t                      | output_size                  | indicates the type of the key to be derived.                           |
| hsm_key_type_t                | key_type                     | cipher algorithm to be used for the expansion function computation     |
| uint8_t                       | expansion_fct_algo           | it must be a value in the range 0-1023. Keys belonging to the same     |
| hsm_key_group_t               | key_group                    | bitmap specifying the properties of the derived key.                   |
| hsm_key_info_t                | key_info                     |                                                                        |

## 6.19.2.1 struct op\_st\_but\_key\_exp\_args\_t

## 6.19.3 Function Documentation

**6.19.3.1 hsm\_standalone\_butterfly\_key\_expansion()** `hsm_err_t hsm_standalone_butterfly_key_expansion (`  
`hsm_hdl_t key_management_hdl,`  
`op_st_but_key_exp_args_t * args )`

User can replace an existing key only by generating a key with the same.

This command is designed to perform a standalone butterfly key expansion operation on an ECC private key in case of implicit and explicit certificates. Optionally the resulting public key is exported. The standalone butterfly key expansion computes the expansion function in addition to the butterfly key expansion

The expansion function is defined as:  $f_k = (\text{cipher}(k, x+1) \text{ xor } (x+1)) \parallel (\text{cipher}(k, x+2) \text{ xor } (x+2)) \parallel (\text{cipher}(k, x+3) \text{ xor } (x+3)) \bmod I$  where,

- Cipher = AES 128 ECB or SM4 128 ECB



- K: the expansion function key
- X: is expansion function the input
- l: the order of the group of points on the curve.  
User can call this function only after having opened a key management service flow.

Explicit certificates:

$f\_k$  = expansion function value

$out\_key = Key + f\_k$

Implicit certificates:

- $f\_k$  = expansion function value,
- hash = hash value used in the derivation of the pseudonym ECC key,
- $pr\_v$  = private reconstruction value

$out\_key = (Key + f\_k) * hash + pr\_v$

#### Parameters

|                           |                                                             |
|---------------------------|-------------------------------------------------------------|
| <i>key_management_hdl</i> | handle identifying the key store management service flow.   |
| <i>args</i>               | pointer to the structure containing the function arguments. |

#### Returns

error code

## 6.20 Key generic crypto service

### Modules

- [i.MX8QXP specificities](#)

### Data Structures

- struct [open\\_svc\\_key\\_generic\\_crypto\\_args\\_t](#)
- struct [op\\_key\\_generic\\_crypto\\_args\\_t](#)

### Macros

- #define **HSM\_KEY\_GENERIC\_ALGO\_SM4\_CCM** ((hsm\_op\_key\_generic\_crypto\_algo\_t)(0x10u))
- #define **HSM\_KEY\_GENERIC\_FLAGS\_DECRYPT** ((hsm\_op\_key\_generic\_crypto\_flags\_t)(0u << 0))
- #define **HSM\_KEY\_GENERIC\_FLAGS\_ENCRYPT** ((hsm\_op\_key\_generic\_crypto\_flags\_t)(1u << 0))

### Typedefs

- typedef uint8\_t **hsm\_svc\_key\_generic\_crypto\_flags\_t**
- typedef uint8\_t **hsm\_op\_key\_generic\_crypto\_algo\_t**
- typedef uint8\_t **hsm\_op\_key\_generic\_crypto\_flags\_t**

### Functions

- [hsm\\_err\\_t hsm\\_open\\_key\\_generic\\_crypto\\_service](#) (hsm\_hdl\_t session\_hdl, [open\\_svc\\_key\\_generic\\_crypto\\_args\\_t](#) \*args, hsm\_hdl\_t \*key\_generic\_crypto\_hdl)
- [hsm\\_err\\_t hsm\\_close\\_key\\_generic\\_crypto\\_service](#) (hsm\_hdl\_t key\_generic\_crypto\_hdl)
- [hsm\\_err\\_t hsm\\_key\\_generic\\_crypto](#) (hsm\_hdl\_t key\_generic\_crypto\_hdl, [op\\_key\\_generic\\_crypto\\_args\\_t](#) \*args)

*Perform SM4 CCM with following characteristics:*

#### 6.20.1 Detailed Description

#### 6.20.2 Data Structure Documentation

##### Data Fields

|                                    |             |                                                 |
|------------------------------------|-------------|-------------------------------------------------|
| hsm_svc_key_generic_crypto_flags_t | flags       | < bitmap indicating the service flow properties |
| uint8_t                            | reserved[3] |                                                 |

##### 6.20.2.1 struct open\_svc\_key\_generic\_crypto\_args\_t

## Data Fields

|                                   |             |                                                                                               |
|-----------------------------------|-------------|-----------------------------------------------------------------------------------------------|
| uint8_t *                         | key         | < pointer to the key to be used for the cryptographic operation<br>length in bytes of the key |
| uint8_t                           | key_size    | pointer to the initialization vector                                                          |
| uint8_t *                         | iv          | length in bytes of the initialization vector                                                  |
| uint16_t                          | iv_size     | pointer to the additional authentication data                                                 |
| uint8_t *                         | aad         | length in bytes of the additional authentication data                                         |
| uint16_t                          | aad_size    | length in bytes of the tag                                                                    |
| uint8_t                           | tag_size    | algorithm to be used for the cryptographic operation                                          |
| hsm_op_key_generic_crypto_algo_t  | crypto_algo | bitmap specifying the cryptographic operation attributes                                      |
| hsm_op_key_generic_crypto_flags_t | flags       | pointer to the input area<br>plaintext for encryption                                         |
| uint8_t *                         | input       | pointer to the output area<br>ciphertext + tag for encryption                                 |
| uint8_t *                         | output      | length in bytes of the input                                                                  |
| uint32_t                          | input_size  | length in bytes of the output                                                                 |
| uint32_t                          | output_size |                                                                                               |
| uint32_t                          | reserved    |                                                                                               |

## 6.20.2.2 struct op\_key\_generic\_crypto\_args\_t

## 6.20.3 Function Documentation

**6.20.3.1 hsm\_open\_key\_generic\_crypto\_service()** `hsm_err_t hsm_open_key_generic_crypto_service (`  
`hsm_hdl_t session_hdl,`  
`open_svc_key_generic_crypto_args_t * args,`  
`hsm_hdl_t * key_generic_crypto_hdl )`

Open a generic crypto service flow.

User can call this function only after having opened a session.

User must open this service in order to perform key generic cryptographic operations.

## Parameters

|                               |                                                                              |
|-------------------------------|------------------------------------------------------------------------------|
| <i>session_hdl</i>            | handle identifying the current session.                                      |
| <i>args</i>                   | pointer to the structure containing the function arguments.                  |
| <i>key_generic_crypto_hdl</i> | pointer to where the key generic crypto service flow handle must be written. |

## Returns

error code

**6.20.3.2 hsm\_close\_key\_generic\_crypto\_service()** `hsm_err_t hsm_close_key_generic_crypto_service`  
(  
     )

Terminate a previously opened key generic service flow.

**Parameters**

|                                     |                                                               |
|-------------------------------------|---------------------------------------------------------------|
| <code>key_generic_crypto_hdl</code> | handle identifying the key generic service flow to be closed. |
|-------------------------------------|---------------------------------------------------------------|

**Returns**

error code

**6.20.3.3 hsm\_key\_generic\_crypto()** `hsm_err_t hsm_key_generic_crypto` (  
    ,  
    `op_key_generic_crypto_args_t * args` )

Perform SM4 CCM with following characteristics:

Perform key generic crypto service operations

User can call this function only after having opened a key generic crypto service flow

**Parameters**

|                                     |                                                             |
|-------------------------------------|-------------------------------------------------------------|
| <code>key_generic_crypto_hdl</code> | handle identifying the key generic crypto service flow.     |
| <code>args</code>                   | pointer to the structure containing the function arguments. |

**Returns**

error code

## 6.21 Dump Firmware Log

### Data Structures

- struct [op\\_debug\\_dump\\_args\\_t](#)

### Functions

- [hsm\\_err\\_t](#) **dump\_firmware\_log** (hsm\_hdl\_t session\_hdl)

#### 6.21.1 Detailed Description

#### 6.21.2 Data Structure Documentation

##### Data Fields

|          |                        |  |
|----------|------------------------|--|
| bool     | is_dump_pending        |  |
| uint32_t | dump_buf_len           |  |
| uint32_t | dump_buf[MAC_BUFF_LEN] |  |

##### 6.21.2.1 struct op\_debug\_dump\_args\_t

## 6.22 Dev attest

### Data Structures

- struct [op\\_dev\\_attest\\_args\\_t](#)

### Functions

- [hsm\\_err\\_t hsm\\_dev\\_attest](#) (hsm\_hdl\_t sess\_hdl, [op\\_dev\\_attest\\_args\\_t](#) \*args)

#### 6.22.1 Detailed Description

#### 6.22.2 Data Structure Documentation

##### Data Fields

|           |                  |  |
|-----------|------------------|--|
| uint16_t  | soc_id           |  |
| uint16_t  | soc_rev          |  |
| uint16_t  | lmda_val         |  |
| uint8_t   | ssm_state        |  |
| uint8_t   | uid_sz           |  |
| uint8_t * | uid              |  |
| uint16_t  | rom_patch_sha_sz |  |
| uint16_t  | sha_fw_sz        |  |
| uint8_t * | sha_rom_patch    |  |
| uint8_t * | sha_fw           |  |
| uint32_t  | nounce           |  |
| uint32_t  | rsp_nounce       |  |
| uint8_t   | attest_result    |  |
| uint8_t   | reserved         |  |
| uint16_t  | sign_sz          |  |
| uint8_t * | signature        |  |

##### 6.22.2.1 struct op\_dev\_attest\_args\_t

#### 6.22.3 Function Documentation

**6.22.3.1 hsm\_dev\_attest()** [hsm\\_err\\_t](#) hsm\_dev\_attest (   
     [hsm\\_hdl\\_t](#) sess\_hdl,   
     [op\\_dev\\_attest\\_args\\_t](#) \* args )

Perform device attestation operation

User can call this function only after having opened the session.

**Parameters**

|                 |                                                             |
|-----------------|-------------------------------------------------------------|
| <i>sess_hdl</i> | handle identifying the active session.                      |
| <i>args</i>     | pointer to the structure containing the function arguments. |

**Returns**

error code

## 6.23 Dev Info

### Data Structures

- struct [op\\_dev\\_getinfo\\_args\\_t](#)

### Functions

- [hsm\\_err\\_t hsm\\_dev\\_getinfo](#) (hsm\_hdl\_t sess\_hdl, [op\\_dev\\_getinfo\\_args\\_t](#) \*args)

#### 6.23.1 Detailed Description

#### 6.23.2 Data Structure Documentation

##### Data Fields

|           |                  |  |
|-----------|------------------|--|
| uint16_t  | soc_id           |  |
| uint16_t  | soc_rev          |  |
| uint16_t  | lmda_val         |  |
| uint8_t   | ssm_state        |  |
| uint8_t   | uid_sz           |  |
| uint8_t * | uid              |  |
| uint16_t  | rom_patch_sha_sz |  |
| uint16_t  | sha_fw_sz        |  |
| uint8_t * | sha_rom_patch    |  |
| uint8_t * | sha_fw           |  |
| uint16_t  | oem_srkh_sz      |  |
| uint8_t * | oem_srkh         |  |
| uint8_t   | imem_state       |  |
| uint8_t   | csal_state       |  |
| uint8_t   | trng_state       |  |

##### 6.23.2.1 struct op\_dev\_getinfo\_args\_t

#### 6.23.3 Function Documentation

**6.23.3.1 hsm\_dev\_getinfo()** [hsm\\_err\\_t](#) hsm\_dev\_getinfo (   
     hsm\_hdl\_t sess\_hdl,   
     [op\\_dev\\_getinfo\\_args\\_t](#) \* args )

Perform device attestation operation

User can call this function only after having opened the session.

##### Parameters

|                 |                                                             |
|-----------------|-------------------------------------------------------------|
| <i>sess_hdl</i> | handle identifying the active session.                      |
| <i>args</i>     | pointer to the structure containing the function arguments. |



#### Returns

error code

## 6.24 Generic Crypto: Asymmetric Crypto

### Data Structures

- struct [op\\_gc\\_acrypto\\_args\\_t](#)

### Macros

- #define **HSM\_OP\_GC\_ACRYPTO\_FLAGS\_INPUT\_MESSAGE** ((hsm\_op\_gc\_acrypto\_flags\_t)(1u << 0))
- #define **HSM\_GC\_ACRYPTO\_VERIFICATION\_SUCCESS** ((hsm\_gc\_acrypto\_verification\_status\_t)(0x5↵A3CC3A5u))
- #define **HSM\_GC\_ACRYPTO\_VERIFICATION\_FAILURE** ((hsm\_gc\_acrypto\_verification\_status\_t)(0x2↵B4DD4B2u))

### Typedefs

- typedef uint8\_t **hsm\_op\_gc\_acrypto\_flags\_t**
- typedef uint32\_t **hsm\_gc\_acrypto\_verification\_status\_t**

### Enumerations

- enum [hsm\\_op\\_gc\\_acrypto\\_algo\\_t](#) {  
**HSM\_GC\_ACRYPTO\_ALGO\_ECDSA\_SHA224** = ALGO\_ECDSA\_SHA224,  
**HSM\_GC\_ACRYPTO\_ALGO\_ECDSA\_SHA256** = ALGO\_ECDSA\_SHA256,  
**HSM\_GC\_ACRYPTO\_ALGO\_ECDSA\_SHA384** = ALGO\_ECDSA\_SHA384,  
**HSM\_GC\_ACRYPTO\_ALGO\_ECDSA\_SHA512** = ALGO\_ECDSA\_SHA512,  
**HSM\_GC\_ACRYPTO\_ALGO\_RSA\_PKCS1\_V15\_SHA224** = ALGO\_RSA\_PKCS1\_V15\_SHA224,  
**HSM\_GC\_ACRYPTO\_ALGO\_RSA\_PKCS1\_V15\_SHA256** = ALGO\_RSA\_PKCS1\_V15\_SHA256,  
**HSM\_GC\_ACRYPTO\_ALGO\_RSA\_PKCS1\_V15\_SHA384** = ALGO\_RSA\_PKCS1\_V15\_SHA384,  
**HSM\_GC\_ACRYPTO\_ALGO\_RSA\_PKCS1\_V15\_SHA512** = ALGO\_RSA\_PKCS1\_V15\_SHA512,  
**HSM\_GC\_ACRYPTO\_ALGO\_RSA\_PKCS1\_PSS\_MGF1\_SHA224** = ALGO\_RSA\_PKCS1\_PSS\_MGF1\_↵  
SHA224,  
**HSM\_GC\_ACRYPTO\_ALGO\_RSA\_PKCS1\_PSS\_MGF1\_SHA256** = ALGO\_RSA\_PKCS1\_PSS\_MGF1\_↵  
SHA256,  
**HSM\_GC\_ACRYPTO\_ALGO\_RSA\_PKCS1\_PSS\_MGF1\_SHA384** = ALGO\_RSA\_PKCS1\_PSS\_MGF1\_↵  
SHA384,  
**HSM\_GC\_ACRYPTO\_ALGO\_RSA\_PKCS1\_PSS\_MGF1\_SHA512** = ALGO\_RSA\_PKCS1\_PSS\_MGF1\_↵  
SHA512,  
**HSM\_GC\_ACRYPTO\_ALGO\_RSA\_PKCS1\_V15\_CRYPT** = ALGO\_RSA\_PKCS1\_V15\_CRYPT,  
**HSM\_GC\_ACRYPTO\_ALGO\_RSA\_PKCS1\_OAEP\_SHA1** = ALGO\_RSA\_PKCS1\_OAEP\_SHA1,  
**HSM\_GC\_ACRYPTO\_ALGO\_RSA\_PKCS1\_OAEP\_SHA224** = ALGO\_RSA\_PKCS1\_OAEP\_SHA224,  
**HSM\_GC\_ACRYPTO\_ALGO\_RSA\_PKCS1\_OAEP\_SHA256** = ALGO\_RSA\_PKCS1\_OAEP\_SHA256,  
**HSM\_GC\_ACRYPTO\_ALGO\_RSA\_PKCS1\_OAEP\_SHA384** = ALGO\_RSA\_PKCS1\_OAEP\_SHA384,  
**HSM\_GC\_ACRYPTO\_ALGO\_RSA\_PKCS1\_OAEP\_SHA512** = ALGO\_RSA\_PKCS1\_OAEP\_SHA512 }  
*< Algorithms to be used for the operations*
- enum **hsm\_gc\_acrypto\_op\_mode\_t** {  
**HSM\_GC\_ACRYPTO\_OP\_MODE\_ENCRYPT** = 0x01,  
**HSM\_GC\_ACRYPTO\_OP\_MODE\_DECRYPT** = 0x02,  
**HSM\_GC\_ACRYPTO\_OP\_MODE\_SIGN\_GEN** = 0x03,  
**HSM\_GC\_ACRYPTO\_OP\_MODE\_SIGN\_VER** = 0x04 }

### Functions

- [hsm\\_err\\_t hsm\\_gc\\_acrypto](#) (hsm\_hdl\_t session\_hdl, [op\\_gc\\_acrypto\\_args\\_t](#) \*args)

6.24.1 Detailed Description

6.24.2 Data Structure Documentation

## Data Fields

|                                                   |                     |                                                                   |
|---------------------------------------------------|---------------------|-------------------------------------------------------------------|
| <code>hsm_op_gc_acrypto_algo_t</code>             | algorithm           | < algorithm to use for the operation indicates the operation mode |
| <code>hsm_gc_acrypto_op_mode_t</code>             | op_mode             | indicates operation flags                                         |
| <code>hsm_op_gc_acrypto_flags_t</code>            | flags               | key size in bits                                                  |
| <code>hsm_bit_key_sz_t</code>                     | bit_key_sz          | pointer to the data buffer 1:                                     |
| <code>uint8_t *</code>                            | data_buff1          | pointer to the data buffer 2:                                     |
| <code>uint8_t *</code>                            | data_buff2          | size in bytes of data buffer 1                                    |
| <code>uint32_t</code>                             | data_buff1_size     | size in bytes of data buffer 2                                    |
| <code>uint32_t</code>                             | data_buff2_size     | pointer to the key modulus buffer                                 |
| <code>uint8_t *</code>                            | key_buff1           | pointer the key exponent, either private or public                |
| <code>uint8_t *</code>                            | key_buff2           | size in bytes of the key buffer 1                                 |
| <code>uint16_t</code>                             | key_buff1_size      | size in bytes of the key buffer 2                                 |
| <code>uint16_t</code>                             | key_buff2_size      | RSA label address.                                                |
| <code>uint8_t *</code>                            | rsa_label           | RSA label size in bytes.                                          |
| <code>uint16_t</code>                             | rsa_label_size      | RSA salt length in bytes.                                         |
| <code>uint16_t</code>                             | rsa_salt_len        | expected plaintext length in bytes, returned by FW in case of     |
| <code>uint32_t</code>                             | exp_plaintext_len   | signature verification status                                     |
| <code>hsm_gc_acrypto_verification_status_t</code> | verification_status |                                                                   |

## 6.24.2.1 struct op\_gc\_acrypto\_args\_t

## 6.24.3 Function Documentation

**6.24.3.1 hsm\_gc\_acrypto()** `hsm_err_t hsm_gc_acrypto (`  
`hsm_hdl_t session_hdl,`  
`op_gc_acrypto_args_t * args )`

This command is designed to perform the following operations: -Asymmetric crypto -encryption/decryption - signature generation/verification

## Parameters

|                          |                                                             |
|--------------------------|-------------------------------------------------------------|
| <code>session_hdl</code> | handle identifying the current session.                     |
| <code>args</code>        | pointer to the structure containing the function arguments. |

## Returns

error code

## 6.25 Generic Crypto Asymmetric Key Generate

### Data Structures

- struct [op\\_gc\\_akey\\_gen\\_args\\_t](#)

### Functions

- [hsm\\_err\\_t hsm\\_gc\\_akey\\_gen](#) (hsm\_hdl\_t session\_hdl, [op\\_gc\\_akey\\_gen\\_args\\_t](#) \*args)

#### 6.25.1 Detailed Description

#### 6.25.2 Data Structure Documentation

##### Data Fields

|                                  |                |                                                                                                    |
|----------------------------------|----------------|----------------------------------------------------------------------------------------------------|
| <a href="#">uint8_t *</a>        | modulus        | < pointer to the output buffer of key modulus pointer to the output buffer of key private exponent |
| <a href="#">uint8_t *</a>        | priv_buff      | pointer to the input buffer containing key public exponent                                         |
| <a href="#">uint8_t *</a>        | pub_buff       | size in bytes of the modulus buffer                                                                |
| <a href="#">uint16_t</a>         | modulus_size   | size in bytes of the private exponent buffer                                                       |
| <a href="#">uint16_t</a>         | priv_buff_size | size in bytes of the public exponent buffer                                                        |
| <a href="#">uint16_t</a>         | pub_buff_size  | indicates which type of keypair must be generated                                                  |
| <a href="#">hsm_key_type_t</a>   | key_type       | size in bits of the keypair to be generated                                                        |
| <a href="#">hsm_bit_key_sz_t</a> | bit_key_sz     |                                                                                                    |

##### 6.25.2.1 struct op\_gc\_akey\_gen\_args\_t

#### 6.25.3 Function Documentation

**6.25.3.1 hsm\_gc\_akey\_gen()** [hsm\\_err\\_t](#) hsm\_gc\_akey\_gen (   
[hsm\\_hdl\\_t](#) session\_hdl,   
[op\\_gc\\_akey\\_gen\\_args\\_t](#) \* args )

This command is designed to perform the following operations: -Generate asymmetric keys, without using FW keystore

##### Parameters

|                    |                                                             |
|--------------------|-------------------------------------------------------------|
| <i>session_hdl</i> | handle identifying the current session.                     |
| <i>args</i>        | pointer to the structure containing the function arguments. |

**Returns**

error code

## 6.26 Get Info

### Data Structures

- struct [op\\_get\\_info\\_args\\_t](#)

### Functions

- [hsm\\_err\\_t hsm\\_get\\_info](#) (hsm\_hdl\_t sess\_hdl, [op\\_get\\_info\\_args\\_t](#) \*args)

#### 6.26.1 Detailed Description

#### 6.26.2 Data Structure Documentation

##### Data Fields

|           |                        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|-----------|------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| uint32_t  | user_sab_id            | < Stores User identifier (32bits) Stores the chip unique identifier                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| uint8_t * | chip_unique_id         | Size of the chip unique identifier in bytes.                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| uint16_t  | chip_unq_id_sz         | Stores the chip monotonic counter value (16bits)                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| uint16_t  | chip_monotonic_counter | Stores the chip current life cycle bitfield (16bits)                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| uint16_t  | chip_life_cycle        | Stores the module version (32bits)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| uint32_t  | version                | Stores the module extended version (32bits)                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| uint32_t  | version_ext            | Stores the FIPS mode bitfield (8bits). Bitmask definition:<br>bit0 - FIPS mode of operation: <ul style="list-style-type: none"> <li>• value 0 - part is running in FIPS non-approved mode.</li> <li>• value 1 - part is running in FIPS approved mode.</li> </ul> bit1 - FIPS certified part: <ul style="list-style-type: none"> <li>• value 0 - part is not FIPS certified.</li> <li>• value 1 - part is FIPS certified.</li> </ul> bit2-7: reserved <ul style="list-style-type: none"> <li>• value 0.</li> </ul> |
| uint8_t   | fips_mode              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |

##### 6.26.2.1 struct op\_get\_info\_args\_t

#### 6.26.3 Function Documentation

**6.26.3.1 hsm\_get\_info()** `hsm_err_t hsm_get_info (`  
    `hsm_hdl_t sess_hdl,`  
    `op_get_info_args_t * args )`

Perform device attestation operation

User can call this function only after having opened the session.

**Parameters**

|                 |                                                             |
|-----------------|-------------------------------------------------------------|
| <i>sess_hdl</i> | handle identifying the active session.                      |
| <i>args</i>     | pointer to the structure containing the function arguments. |

**Returns**

error code



## 6.27 Public key recovery

Public Key Recovery is now also known as Public Key Exportation, in PSA compliant APIs. The naming here has been kept unchanged, for backward compatibility and Non-PSA compliant APIs.

### Data Structures

- struct [op\\_pub\\_key\\_recovery\\_args\\_t](#)

### Typedefs

- typedef uint8\_t [hsm\\_op\\_pub\\_key\\_recovery\\_flags\\_t](#)

### Functions

- [hsm\\_err\\_t hsm\\_pub\\_key\\_recovery](#) (hsm\_hdl\_t key\_store\_hdl, [op\\_pub\\_key\\_recovery\\_args\\_t](#) \*args)

#### 6.27.1 Detailed Description

Public Key Recovery is now also known as Public Key Exportation, in PSA compliant APIs. The naming here has been kept unchanged, for backward compatibility and Non-PSA compliant APIs.

#### 6.27.2 Data Structure Documentation

##### Data Fields

|                                                 |                |                                                                                                                                               |
|-------------------------------------------------|----------------|-----------------------------------------------------------------------------------------------------------------------------------------------|
| uint32_t                                        | key_identifier | < pointer to the identifier of the key to be used for the operation pointer to the output area where the generated public key must be written |
| uint8_t *                                       | out_key        | length in bytes of the output key                                                                                                             |
| uint16_t                                        | out_key_size   | indicates the type of the key to be recovered                                                                                                 |
| <a href="#">hsm_key_type_t</a>                  | key_type       | bitmap specifying the operation attributes, mandatory for non-PSA compliant platforms                                                         |
| <a href="#">hsm_op_pub_key_recovery_flags_t</a> | flags          |                                                                                                                                               |

##### 6.27.2.1 struct op\_pub\_key\_recovery\_args\_t

#### 6.27.3 Function Documentation

**6.27.3.1 hsm\_pub\_key\_recovery()** `hsm_err_t hsm_pub_key_recovery (`  
`hsm_hdl_t key_store_hdl,`  
`op_pub_key_recovery_args_t * args )`

Recover Public key from private key present in key store  
User can call this function only after having opened a key store.

#### Parameters

|                      |                                                             |
|----------------------|-------------------------------------------------------------|
| <i>key_store_hdl</i> | handle identifying the current key store.                   |
| <i>args</i>          | pointer to the structure containing the function arguments. |

#### Returns

error code

## 6.28 Key store

User must open a key store service flow in order to perform the following operations:

### Data Structures

- struct [open\\_svc\\_key\\_store\\_args\\_t](#)

### Macros

- #define [HSM\\_SVC\\_KEY\\_STORE\\_FLAGS\\_LOAD](#) ((hsm\_svc\_key\_store\_flags\_t)(0u << 0))  
*It must be specified to create a new key store. The key store will be.*
- #define [HSM\\_SVC\\_KEY\\_STORE\\_FLAGS\\_CREATE](#) ((hsm\_svc\_key\_store\_flags\_t)(1u << 0))  
*If set, minimum mac length specified in min\_mac\_length field will be.*
- #define [HSM\\_SVC\\_KEY\\_STORE\\_FLAGS\\_SET\\_MAC\\_LEN](#) ((hsm\_svc\_key\_store\_flags\_t)(1u << 3))  
*The request is completed only when the new key store has been written in.*
- #define [HSM\\_SVC\\_KEY\\_STORE\\_FLAGS\\_STRICT\\_OPERATION](#) ((hsm\_svc\_key\_store\_flags\_t)(1u << 7))

### Typedefs

- typedef uint8\_t [hsm\\_svc\\_key\\_store\\_flags\\_t](#)  
*It must be specified to load a previously created key store.*

### Functions

- [hsm\\_err\\_t hsm\\_open\\_key\\_store\\_service](#) (hsm\_hdl\_t session\_hdl, [open\\_svc\\_key\\_store\\_args\\_t](#) \*args, hsm\_hdl\_t \*key\_store\_hdl)
- [hsm\\_err\\_t hsm\\_close\\_key\\_store\\_service](#) (hsm\_hdl\_t key\_store\_hdl)

#### 6.28.1 Detailed Description

User must open a key store service flow in order to perform the following operations:

- create a new key store
- perform operations involving keys stored in the key store (ciphering, signature generation...)
- perform a key store reprovisioning using a signed message. A key store re-provisioning results in erasing all the key stores handled by the HSM.

To grant access to the key store, the caller is authenticated against the domain ID (DID) and Messaging Unit used at the keystore creation, additionally an authentication nonce can be provided.

#### 6.28.2 Data Structure Documentation

## Data Fields

|                           |                      |                                                                                            |
|---------------------------|----------------------|--------------------------------------------------------------------------------------------|
| hsm_hdl_t                 | key_store_hdl        | < handle identifying the key store service flow user defined id identifying the key store. |
| uint32_t                  | key_store_identifier | user defined nonce used as authentication proof for accessing the                          |
| uint32_t                  | authentication_nonce | maximum number of updates authorized for the key store.                                    |
| uint16_t                  | max_updates_number   | bitmap specifying the services properties.                                                 |
| hsm_svc_key_store_flags_t | flags                | it corresponds to the minimum mac length (in bits) accepted by                             |
| uint8_t                   | min_mac_length       | pointer to signed_message to be sent only in case of                                       |
| uint8_t *                 | signed_message       | size of the signed_message to be sent only in case of                                      |
| uint16_t                  | signed_msg_size      |                                                                                            |

## 6.28.2.1 struct open\_svc\_key\_store\_args\_t

## 6.28.3 Function Documentation

**6.28.3.1 hsm\_open\_key\_store\_service()** `hsm_err_t hsm_open_key_store_service (`  
`hsm_hdl_t session_hdl,`  
`open_svc_key_store_args_t * args,`  
`hsm_hdl_t * key_store_hdl )`

Open a service flow on the specified key store. Only one key store service can be opened on a given key store.

## Parameters

|                      |                                                                     |
|----------------------|---------------------------------------------------------------------|
| <i>session_hdl</i>   | pointer to the handle identifying the current session.              |
| <i>args</i>          | pointer to the structure containing the function arguments.         |
| <i>key_store_hdl</i> | pointer to where the key store service flow handle must be written. |

## Returns

`error_code` error code.

**6.28.3.2 hsm\_close\_key\_store\_service()** `hsm_err_t hsm_close_key_store_service (`  
`hsm_hdl_t key_store_hdl )`

Close a previously opened key store service flow. The key store is deleted from the HSM local memory, any update not written in the NVM is lost

**Parameters**

|               |                                                      |
|---------------|------------------------------------------------------|
| <i>handle</i> | identifying the key store service flow to be closed. |
|---------------|------------------------------------------------------|

**Returns**

`error_code` error code.

## 6.29 LC update

### Data Structures

- struct [op\\_lc\\_update\\_msg\\_args\\_t](#)

### Enumerations

- enum **hsm\_lc\_new\_state\_t** {  
  **HSM\_NXP\_PROVISIONED\_STATE** = (1u << 0),  
  **HSM\_OEM\_OPEN\_STATE** = (1u << 1),  
  **HSM\_OEM\_CLOSE\_STATE** = (1u << 3),  
  **HSM\_OEM\_FIELD\_RET\_STATE** = (1u << 4),  
  **HSM\_NXP\_FIELD\_RET\_STATE** = (1u << 5),  
  **HSM\_OEM\_LOCKED\_STATE** = (1u << 7) }

### Functions

- [hsm\\_err\\_t](#) **hsm\_lc\_update** (hsm\_hdl\_t session\_hdl, [op\\_lc\\_update\\_msg\\_args\\_t](#) \*args)

#### 6.29.1 Detailed Description

#### 6.29.2 Data Structure Documentation

##### Data Fields

|                                    |                              |  |
|------------------------------------|------------------------------|--|
| <a href="#">hsm_lc_new_state_t</a> | <a href="#">new_lc_state</a> |  |
|------------------------------------|------------------------------|--|

##### 6.29.2.1 struct [op\\_lc\\_update\\_msg\\_args\\_t](#)

## 6.30 Error codes

### Enumerations

```

• enum hsm_err_t {
 HSM_NO_ERROR = 0x0,
 HSM_INVALID_MESSAGE = 0x1,
 HSM_INVALID_ADDRESS = 0x2,
 HSM_UNKNOWN_ID = 0x3,
 HSM_INVALID_PARAM = 0x4,
 HSM_NVM_ERROR = 0x5,
 HSM_OUT_OF_MEMORY = 0x6,
 HSM_UNKNOWN_HANDLE = 0x7,
 HSM_UNKNOWN_KEY_STORE = 0x8,
 HSM_KEY_STORE_AUTH = 0x9,
 HSM_KEY_STORE_ERROR = 0xA,
 HSM_ID_CONFLICT = 0xB,
 HSM_RNG_NOT_STARTED = 0xC,
 HSM_CMD_NOT_SUPPORTED = 0xD,
 HSM_INVALID_LIFECYCLE = 0xE,
 HSM_KEY_STORE_CONFLICT = 0xF,
 HSM_KEY_STORE_COUNTER = 0x10,
 HSM_FEATURE_NOT_SUPPORTED = 0x11,
 HSM_SELF_TEST_FAILURE = 0x12,
 HSM_NOT_READY_RATING = 0x13,
 HSM_FEATURE_DISABLED = 0x14,
 HSM_KEY_GROUP_FULL = 0x19,
 HSM_CANNOT_RETRIEVE_KEY_GROUP = 0x1A,
 HSM_KEY_NOT_SUPPORTED = 0x1B,
 HSM_CANNOT_DELETE_PERMANENT_KEY = 0x1C,
 HSM_OUT_TOO_SMALL = 0x1D,
 HSM_CRC_CHECK_ERR = 0xB9,
 HSM_OEM_CLOSED_LC_SIGNED_MSG_VERIFICATION_FAIL = 0xF0,
 HSM_OEM_OPEN_LC_SIGNED_MSG_VERIFICATION_FAIL = 0xF0,
 HSM_FATAL_FAILURE = 0x29,
 HSM_SERVICES_DISABLED = 0xF4,
 HSM_UNKNOWN_WARNING = 0xFC,
 HSM_SIGNATURE_INVALID = 0xFD,
 HSM_UNKNOWN_ERROR = 0xFE,
 HSM_GENERAL_ERROR = 0xFF }

```

#### 6.30.1 Detailed Description

#### 6.30.2 Enumeration Type Documentation

##### 6.30.2.1 hsm\_err\_t enum hsm\_err\_t

Error codes returned by HSM functions.

##### Enumerator

|              |                                                      |
|--------------|------------------------------------------------------|
| HSM_NO_ERROR | Success. The received message is invalid or unknown. |
|--------------|------------------------------------------------------|

## Enumerator

|                                                |                                                                                                                                               |
|------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------|
| HSM_INVALID_MESSAGE                            | The provided address is invalid or doesn't respect the API requirements.                                                                      |
| HSM_INVALID_ADDRESS                            | The provided identifier is not known.                                                                                                         |
| HSM_UNKNOWN_ID                                 | One of the parameter provided in the command is invalid.                                                                                      |
| HSM_INVALID_PARAM                              | NVM generic issue.                                                                                                                            |
| HSM_NVM_ERROR                                  | There is not enough memory to handle the requested operation.                                                                                 |
| HSM_OUT_OF_MEMORY                              | Unknown session/service handle.                                                                                                               |
| HSM_UNKNOWN_HANDLE                             | The key store identified by the provided "key store Id" doesn't exist and the "create" flag is not set.                                       |
| HSM_UNKNOWN_KEY_STORE                          | Key store authentication fails.                                                                                                               |
| HSM_KEY_STORE_AUTH                             | An error occurred in the key store internal processing.                                                                                       |
| HSM_KEY_STORE_ERROR                            | An element (key store, key. . . ) with the provided ID already exists.                                                                        |
| HSM_ID_CONFLICT                                | The internal RNG is not started.                                                                                                              |
| HSM_RNG_NOT_STARTED                            | The functionality is not supported for the current session/service/key store configuration.                                                   |
| HSM_CMD_NOT_SUPPORTED                          | Invalid lifecycle for requested operation.                                                                                                    |
| HSM_INVALID_LIFECYCLE                          | A key store with the same attributes already exists.                                                                                          |
| HSM_KEY_STORE_CONFLICT                         | The current key store reaches the max number of monotonic counter updates, updates are still allowed but monotonic counter will not be blown. |
| HSM_KEY_STORE_COUNTER                          | The requested feature is not supported by the firmware.                                                                                       |
| HSM_FEATURE_NOT_SUPPORTED                      | Self tests report an issue                                                                                                                    |
| HSM_SELF_TEST_FAILURE                          | The HSM is not ready to handle the current request                                                                                            |
| HSM_NOT_READY_RATING                           | The required service/operation is disabled                                                                                                    |
| HSM_FEATURE_DISABLED                           | Not enough space to store the key in the key group                                                                                            |
| HSM_KEY_GROUP_FULL                             | Impossible to retrieve key group                                                                                                              |
| HSM_CANNOT_RETRIEVE_KEY_GROUP                  | Key not supported                                                                                                                             |
| HSM_KEY_NOT_SUPPORTED                          | Trying to delete a permanent key                                                                                                              |
| HSM_CANNOT_DELETE_PERMANENT_KEY                | Output buffer size is too small                                                                                                               |
| HSM_OUT_TOO_SMALL                              | Command CRC check error                                                                                                                       |
| HSM_CRC_CHECK_ERR                              | In OEM closed lifecycle, Signed message signature verification failure                                                                        |
| HSM_OEM_CLOSED_LC_SIGNED_MSG_VERIFICATION_FAIL | Warning: In OEM open lifecycles, Signed message signature verification failure                                                                |
| HSM_OEM_OPEN_LC_SIGNED_MSG_VERIFICATION_FAIL   | A fatal failure occurred, the HSM goes in unrecoverable error state not replying to further requests                                          |
| HSM_FATAL_FAILURE                              | Message neither handled by ROM nor FW                                                                                                         |
| HSM_SERVICES_DISABLED                          | Unknown warnings                                                                                                                              |
| HSM_UNKNOWN_WARNING                            | Failure in verification status of operations such as MAC verification, Signature verification.                                                |
| HSM_SIGNATURE_INVALID                          | Unknown errors                                                                                                                                |
| HSM_UNKNOWN_ERROR                              | Error in case General Error is received                                                                                                       |



## 6.31 i.MX8QXP specificities

### Session

i.MX8QXP HSM is implemented only on SECO core which doesn't offer priority management neither low latencies.

- `HSM_OPEN_SESSION_FIPS_MODE_MASK` not supported and ignored
- `HSM_OPEN_SESSION_EXCLUSIVE_MASK` not supported and ignored
- `session_priority` field of `open_session_args_t` is ignored.
- `HSM_OPEN_SESSION_LOW_LATENCY_MASK` not supported and ignored.

### Signature verification

- `HSM_OP_VERIFY_SIGN_FLAGS_KEY_INTERNAL` is not supported
- `hsm_import_public_key`: This API is not supported

### Key management

- `HSM_OP_MANAGE_KEY_GROUP_FLAGS_DELETE` is not supported.
- `HSM_KEY_TYPE_ECDSA_NIST_P521` is not supported.
- `HSM_KEY_TYPE_ECDSA_BRAINPOOL_R1_320` is not supported.
- `HSM_KEY_TYPE_ECDSA_BRAINPOOL_R1_512` is not supported.
- `HSM_KEY_TYPE_ECDSA_BRAINPOOL_T1_256` is not supported.
- `HSM_KEY_TYPE_ECDSA_BRAINPOOL_T1_320` is not supported.
- `HSM_KEY_TYPE_ECDSA_BRAINPOOL_T1_384` is not supported.
- `HSM_KEY_TYPE_ECDSA_BRAINPOOL_T1_512` is not supported.
- `HSM_KEY_TYPE_DSA_SM2_FP_256` is not supported.
- `HSM_KEY_TYPE_SM4_128` is not supported.
- `HSM_KEY_TYPE_HMAC_224` is not supported.
- `HSM_KEY_TYPE_HMAC_256` is not supported.
- `HSM_KEY_TYPE_HMAC_384` is not supported.
- `HSM_KEY_TYPE_HMAC_512` is not supported.
- `hsm_butterfly_key_expansion`: This feature is disabled when part is running in FIPS approved mode. Any call to this API will results in a `HSM_FEATURE_DISABLED` error.
- `hsm_key_type_t` of `op_butt_key_exp_args_t`: Only following are supported: `HSM_KEY_TYPE_ECDSA_NIST_P256`, and `HSM_KEY_TYPE_ECDSA_BRAINPOOL_R1_256`

### Public key reconstruction

- This feature is disabled when part is running in FIPS approved mode. Any call to this API will results in a `HSM_FEATURE_DISABLED` error.

- [hsm\\_key\\_type\\_t](#) of [op\\_pub\\_key\\_rec\\_args\\_t](#): Only following are supported: HSM\_KEY\_TYPE\_ECDSA\_NIST\_P256, and HSM\_KEY\_TYPE\_ECDSA\_BRAINPOOL\_R1\_256

#### Public key decompression

- This feature is disabled when part is running in FIPS approved mode. Any call to this API will results in a HSM\_FEATURE\_DISABLED error.

#### ECIES encryption

- [hsm\\_ecies\\_encryption](#): This feature is disabled when part is running in FIPS approved mode. Any call to this API will results in a HSM\_FEATURE\_DISABLED error.
- [hsm\\_key\\_type\\_t](#) of [op\\_ecies\\_enc\\_args\\_t](#): Only followinga are supported: HSM\_KEY\_TYPE\_ECDSA\_NIST\_P256, and HSM\_KEY\_TYPE\_ECDSA\_BRAINPOOL\_R1\_256.

#### SM2 Get Z

- This API is not supported.

#### SM2 ECES decryption

- All the APIs related the SM2 ECES decryption are not supported.

#### SM2 ECES encryption

- This API is not supported.

#### Key exchange

- [HSM\\_KDF\\_HMAC\\_SHA\\_256\\_TLS\\_0\\_16\\_4](#) is not supported.
- [HSM\\_KDF\\_HMAC\\_SHA\\_384\\_TLS\\_0\\_32\\_4](#) is not supported.
- [HSM\\_KDF\\_HMAC\\_SHA\\_256\\_TLS\\_0\\_32\\_4](#) is not supported.
- [HSM\\_KDF\\_HMAC\\_SHA\\_256\\_TLS\\_32\\_16\\_4](#) is not supported.
- [HSM\\_KDF\\_HMAC\\_SHA\\_384\\_TLS\\_48\\_32\\_4](#) is not supported.
- [hsm\\_tls\\_finish](#) API is not supported.
- [HSM\\_OP\\_TLS\\_FINISH\\_HASH\\_ALGO\\_SHA256](#) is not supported.
- [HSM\\_OP\\_TLS\\_FINISH\\_HASH\\_ALGO\\_SHA384](#) is not supported.
- [HSM\\_OP\\_TLS\\_FINISH\\_FLAGS\\_CLIENT](#) is not supported.
- [HSM\\_OP\\_TLS\\_FINISH\\_FLAGS\\_SERVER](#) is not supported.
- [HSM\\_KE\\_SCHEME\\_ECDH\\_BRAINPOOL\\_T1\\_256](#) is not supported.

#### Standalone butterfly key expansion

- This API is not supported.

#### Key generic crypto service

- This API is not supported.

#### Ciphering

- HSM\_CIPHER\_ONE\_GO\_ALGO\_SM4\_ECB is not supported.
- HSM\_CIPHER\_ONE\_GO\_ALGO\_SM4\_CBC is not supported.
- HSM\_AUTH\_ENC\_ALGO\_SM4\_CCM is not supported.
- hsm\_ecies\_decryption: This feature is disabled when part is running in FIPS approved mode. Any call to this API will results in a HSM\_FEATURE\_DISABLED error.
- hsm\_key\_type\_t of op\_ecies\_dec\_args\_t: Only HSM\_KEY\_TYPE\_ECDSA\_NIST\_P256 and HSM\_KEY\_TYPE\_ECDSA\_BRAINPOOL\_R1\_256 are supported.

#### Signature generation

- HSM\_HASH\_ALGO\_SM3\_256 is not supported.

#### Mac

- HSM\_OP\_MAC\_ONE\_GO\_ALGO\_HMAC\_SHA\_224 is not supported.
- HSM\_OP\_MAC\_ONE\_GO\_ALGO\_HMAC\_SHA\_256 is not supported.
- HSM\_OP\_MAC\_ONE\_GO\_ALGO\_HMAC\_SHA\_384 is not supported.
- HSM\_OP\_MAC\_ONE\_GO\_ALGO\_HMAC\_SHA\_512 is not supported.

#### Signature generation

- HSM\_SIGNATURE\_SCHEME\_ECDSA\_NIST\_P521\_SHA\_512 is not supported.
- HSM\_SIGNATURE\_SCHEME\_ECDSA\_BRAINPOOL\_R1\_320\_SHA\_384 is not supported.
- HSM\_SIGNATURE\_SCHEME\_ECDSA\_BRAINPOOL\_R1\_512\_SHA\_512 is not supported.
- HSM\_SIGNATURE\_SCHEME\_ECDSA\_BRAINPOOL\_T1\_256\_SHA\_256 is not supported.
- HSM\_SIGNATURE\_SCHEME\_ECDSA\_BRAINPOOL\_T1\_320\_SHA\_384 is not supported.
- HSM\_SIGNATURE\_SCHEME\_ECDSA\_BRAINPOOL\_T1\_384\_SHA\_384 is not supported.
- HSM\_SIGNATURE\_SCHEME\_ECDSA\_BRAINPOOL\_T1\_512\_SHA\_512 is not supported.
- HSM\_SIGNATURE\_SCHEME\_DSA\_SM2\_FP\_256\_SM3 is not supported.

#### Key store

The table below summarizes the maximum number of keys per group in the QXP implementation:

| Key size (bits) | Number of keys per group |
|-----------------|--------------------------|
| 128             | 169                      |
| 192             | 126                      |
| 224             | 101                      |
| 256             | 101                      |
| 384             | 72                       |
| 512             | 56                       |

## 6.32 i.MX8DXL specificities

### Session

i.MX8DXL has 2 separate implementations of HSM on SECO and on V2X cores.

- `HSM_OPEN_SESSION_FIPS_MODE_MASK` not supported and ignored
- `HSM_OPEN_SESSION_EXCLUSIVE_MASK` not supported and ignored
- If `HSM_OPEN_SESSION_LOW_LATENCY_MASK` is unset then SECO implementation will be used. In this case `session_priority` field of `open_session_args_t` is ignored.
- If `HSM_OPEN_SESSION_LOW_LATENCY_MASK` is set then V2X implementation is used. `session_priority` field of `open_session_args_t` and `HSM_OPEN_SESSION_NO_KEY_STORE_MASK` are considered.

### Signature verification

- `HSM_OP_VERIFY_SIGN_FLAGS_COMPRESSED_POINT` is not supported, in case of `HSM_SIGNATURE_SCHEME_DSA_SM2_FP_256_SM3`.
- `HSM_OP_VERIFY_SIGN_FLAGS_KEY_INTERNAL` is not supported
- `hsm_import_public_key`: This API is a preliminary version

### Key management

- `HSM_OP_MANAGE_KEY_GROUP_FLAGS_DELETE` is not supported.
- `HSM_KEY_TYPE_HMAC_224` is not supported.
- `HSM_KEY_TYPE_HMAC_256` is not supported.
- `HSM_KEY_TYPE_HMAC_384` is not supported.
- `HSM_KEY_TYPE_HMAC_512` is not supported.
- `hsm_key_type_t` of `op_but_key_exp_args_t`: Only following are supported: `HSM_KEY_TYPE_ECDSA_NIST_P256`, `HSM_KEY_TYPE_ECDSA_BRAINPOOL_R1_256` and `HSM_KEY_TYPE_DSA_SM2_FP_256` are supported.

### Public key reconstruction

- `hsm_key_type_t` of `op_pub_key_rec_args_t`: Only following are supported: `HSM_KEY_TYPE_ECDSA_NIST_P256`, `HSM_KEY_TYPE_ECDSA_BRAINPOOL_R1_256`, and `HSM_KEY_TYPE_DSA_SM2_FP_256`

### ECIES encryption

- `hsm_key_type_t` of `op_ecies_enc_args_t`: Only following are supported: `HSM_KEY_TYPE_ECDSA_NIST_P256`, and `HSM_KEY_TYPE_ECDSA_BRAINPOOL_R1_256`.

### SM2 ECES decryption

- The `output_size` should be a multiple of 4 bytes.

### SM2 ECES encryption

- The output\_size should be a multiple of 4 bytes.

### Key exchange

- `HSM_KDF_HMAC_SHA_256_TLS_0_16_4` is not supported.
- `HSM_KDF_HMAC_SHA_384_TLS_0_32_4` is not supported.
- `HSM_KDF_HMAC_SHA_256_TLS_0_32_4` is not supported.
- `HSM_KDF_HMAC_SHA_256_TLS_32_16_4` is not supported.
- `HSM_KDF_HMAC_SHA_384_TLS_48_32_4` is not supported.
- `hsm_tls_finish` API is not supported.
- `HSM_OP_TLS_FINISH_HASH_ALGO_SHA256` is not supported.
- `HSM_OP_TLS_FINISH_HASH_ALGO_SHA384` is not supported.
- `HSM_OP_TLS_FINISH_FLAGS_CLIENT` is not supported.
- `HSM_OP_TLS_FINISH_FLAGS_SERVER` is not supported.

### Standalone butterfly key expansion

`hsm_key_type_t` of `op_butt_key_exp_args_t`: Only following are supported:

- `HSM_KEY_TYPE_ECDSA_NIST_P256`,
- `HSM_KEY_TYPE_ECDSA_BRAINPOOL_R1_256` and
- `HSM_KEY_TYPE_DSA_SM2_FP_256`.

### Ciphering

- `hsm_key_type_t` of `op_ecies_dec_args_t`: Only `HSM_KEY_TYPE_ECDSA_NIST_P256` and `HSM_KEY_TYPE_ECDSA_BRAINPOOL_R1_256` are supported.

### Mac

- `HSM_OP_MAC_ONE_GO_ALGO_HMAC_SHA_224` is not supported.
- `HSM_OP_MAC_ONE_GO_ALGO_HMAC_SHA_256` is not supported.
- `HSM_OP_MAC_ONE_GO_ALGO_HMAC_SHA_384` is not supported.
- `HSM_OP_MAC_ONE_GO_ALGO_HMAC_SHA_512` is not supported.

### Signature generation

- `HSM_OP_GENERATE_SIGN_FLAGS_COMPRESSED_POINT` is not supported, in case of `HSM_SIGNATURE_SCHEME_DSA_SM2_FP_256_SM3`.

### Key store

The table below summarizes the maximum number of keys per group in the DXL implementation:

sessions using V2X implementation (`HSM_OPEN_SESSION_LOW_LATENCY_MASK`) :

| Key size (bits) | Number of keys per group |
|-----------------|--------------------------|
| 128             | 166                      |
| 192             | 125                      |
| 224             | 111                      |
| 256             | 100                      |
| 384             | 71                       |
| 512             | 52                       |

session using SECO implementation : same number as QXP applies

## 7 Data Structure Documentation

### 7.1 op\_but\_key\_exp\_args\_t Struct Reference

#### Data Fields

- uint32\_t [key\\_identifier](#)  
*< identifier of the key to be expanded.*
- uint8\_t \* [expansion\\_function\\_value](#)  
*pointer to the hash value input.  
In case of explicit certificate,*
- uint8\_t \* [hash\\_value](#)  
*pointer to the private reconstruction value input.*
- uint8\_t \* [pr\\_reconstruction\\_value](#)  
*length in bytes of the expansion function input*
- uint8\_t [expansion\\_function\\_value\\_size](#)  
*length in bytes of the hash value input.*
- uint8\_t [hash\\_value\\_size](#)  
*length in bytes of the private reconstruction value input.*
- uint8\_t [pr\\_reconstruction\\_value\\_size](#)  
*bitmap specifying the operation properties*
- hsm\_op\_but\_key\_exp\_flags\_t [flags](#)  
*pointer to identifier of the derived key to be used for the operation.*
- uint32\_t \* [dest\\_key\\_identifier](#)  
*pointer to the output area where the public key must be written.*
- uint8\_t \* [output](#)  
*length in bytes of the generated key, if the size is 0, no key is*
- uint16\_t [output\\_size](#)  
*indicates the type of the key to be derived.*
- [hsm\\_key\\_type\\_t](#) [key\\_type](#)
- uint8\_t [reserved](#)  
*it must be a value in the range 0-1023. Keys belonging to the same*
- hsm\_key\_group\_t [key\\_group](#)  
*bitmap specifying the properties of the derived key.*
- hsm\_key\_info\_t [key\\_info](#)

#### 7.1.1 Field Documentation

##### 7.1.1.1 [key\\_identifier](#) uint32\_t op\_but\_key\_exp\_args\_t::key\_identifier

< identifier of the key to be expanded.

pointer to the expansion function value input



**7.1.1.2 expansion\_function\_value** uint8\_t\* op\_but\_key\_exp\_args\_t::expansion\_function\_value

pointer to the hash value input.  
In case of explicit certificate,

**7.1.1.3 hash\_value** uint8\_t\* op\_but\_key\_exp\_args\_t::hash\_value

pointer to the private reconstruction value input.

**7.1.1.4 pr\_reconstruction\_value** uint8\_t\* op\_but\_key\_exp\_args\_t::pr\_reconstruction\_value

length in bytes of the expansion function input

**7.1.1.5 expansion\_function\_value\_size** uint8\_t op\_but\_key\_exp\_args\_t::expansion\_function\_value\_size

length in bytes of the hash value input.

**7.1.1.6 hash\_value\_size** uint8\_t op\_but\_key\_exp\_args\_t::hash\_value\_size

length in bytes of the private reconstruction value input.

**7.1.1.7 pr\_reconstruction\_value\_size** uint8\_t op\_but\_key\_exp\_args\_t::pr\_reconstruction\_value\_size

bitmap specifying the operation properties

**7.1.1.8 flags** hsm\_op\_but\_key\_exp\_flags\_t op\_but\_key\_exp\_args\_t::flags

pointer to identifier of the derived key to be used for the operation.

**7.1.1.9 dest\_key\_identifier** uint32\_t\* op\_but\_key\_exp\_args\_t::dest\_key\_identifier

pointer to the output area where the public key must be written.

**7.1.1.10 output** `uint8_t* op_butt_key_exp_args_t::output`

length in bytes of the generated key, if the size is 0, no key is

**7.1.1.11 output\_size** `uint16_t op_butt_key_exp_args_t::output_size`

indicates the type of the key to be derived.

**7.1.1.12 key\_type** `hsm_key_type_t op_butt_key_exp_args_t::key_type`

**7.1.1.13 reserved** `uint8_t op_butt_key_exp_args_t::reserved`

it must be a value in the range 0-1023. Keys belonging to the same

**7.1.1.14 key\_group** `hsm_key_group_t op_butt_key_exp_args_t::key_group`

bitmap specifying the properties of the derived key.

**7.1.1.15 key\_info** `hsm_key_info_t op_butt_key_exp_args_t::key_info`

## 7.2 op\_ecies\_dec\_args\_t Struct Reference

### Data Fields

- `uint32_t key_identifier`  
*< identifier of the private key to be used for the operation*
- `uint8_t* input`  
*pointer to the KDF P1 input parameter*
- `uint8_t* p1`  
*pointer to the MAC P2 input parameter should be NULL*
- `uint8_t* p2`  
*pointer to the output area where the plaintext must be written*
- `uint8_t* output`  
*length in bytes of the input VCT should be equal to 96 bytes*
- `uint32_t input_size`  
*length in bytes of the output plaintext should be equal to 16 bytes*
- `uint32_t output_size`  
*length in bytes of the KDF P1 parameter should be equal to 32 bytes*
- `uint16_t p1_size`  
*length in bytes of the MAC P2 parameter should be zero reserved for*
- `uint16_t p2_size`  
*length in bytes of the requested message authentication code should*
- `uint16_t mac_size`  
*indicates the type of the used key*
- `hsm_key_type_t key_type`  
*bitmap specifying the operation attributes.*
- `hsm_op_ecies_dec_flags_t flags`

### 7.2.1 Field Documentation

**7.2.1.1 key\_identifier** `uint32_t op_ecies_dec_args_t::key_identifier`

< identifier of the private key to be used for the operation

pointer to the VCT input

**7.2.1.2 input** `uint8_t* op_ecies_dec_args_t::input`

pointer to the KDF P1 input parameter

**7.2.1.3 p1** `uint8_t* op_ecies_dec_args_t::p1`

pointer to the MAC P2 input parameter should be NULL

**7.2.1.4 p2** `uint8_t* op_ecies_dec_args_t::p2`

pointer to the output area where the plaintext must be written

**7.2.1.5 output** `uint8_t* op_ecies_dec_args_t::output`

length in bytes of the input VCT should be equal to 96 bytes

**7.2.1.6 input\_size** `uint32_t op_ecies_dec_args_t::input_size`

length in bytes of the output plaintext should be equal to 16 bytes

**7.2.1.7 output\_size** `uint32_t op_ecies_dec_args_t::output_size`

length in bytes of the KDF P1 parameter should be equal to 32 bytes

**7.2.1.8 p1\_size** `uint16_t op_ecies_dec_args_t::p1_size`

length in bytes of the MAC P2 parameter should be zero reserved for

**7.2.1.9 p2\_size** `uint16_t op_ecies_dec_args_t::p2_size`

length in bytes of the requested message authentication code should

**7.2.1.10 mac\_size** `uint16_t op_ecies_dec_args_t::mac_size`

indicates the type of the used key

**7.2.1.11 key\_type** `hsm_key_type_t op_ecies_dec_args_t::key_type`

bitmap specifying the operation attributes.

**7.2.1.12 flags** `hsm_op_ecies_dec_flags_t op_ecies_dec_args_t::flags`

## 7.3 op\_import\_public\_key\_args\_t Struct Reference

### Data Fields

- `uint8_t * key`  
*< pointer to the public key to be imported*
- `uint16_t key_size`  
*indicates the type of the key to be imported.*
- `hsm_key_type_t key_type`  
*bitmap specifying the operation attributes*
- `hsm_op_import_public_key_flags_t flags`

### 7.3.1 Field Documentation

**7.3.1.1 key** `uint8_t* op_import_public_key_args_t::key`

< pointer to the public key to be imported

length in bytes of the input key

**7.3.1.2 key\_size** uint16\_t op\_import\_public\_key\_args\_t::key\_size

indicates the type of the key to be imported.

**7.3.1.3 key\_type** hsm\_key\_type\_t op\_import\_public\_key\_args\_t::key\_type

bitmap specifying the operation attributes

**7.3.1.4 flags** hsm\_op\_import\_public\_key\_flags\_t op\_import\_public\_key\_args\_t::flags

## 7.4 op\_manage\_key\_group\_args\_t Struct Reference

### Data Fields

- hsm\_key\_group\_t [key\\_group](#)  
< it must be a value in the range 0-1023.
- hsm\_op\_manage\_key\_group\_flags\_t **flags**
- uint8\_t **reserved**

### 7.4.1 Field Documentation

**7.4.1.1 key\_group** hsm\_key\_group\_t op\_manage\_key\_group\_args\_t::key\_group

< it must be a value in the range 0-1023.

bitmap specifying the operation properties.

**7.4.1.2 flags** hsm\_op\_manage\_key\_group\_flags\_t op\_manage\_key\_group\_args\_t::flags

**7.4.1.3 reserved** uint8\_t op\_manage\_key\_group\_args\_t::reserved



## Index

- Authenticated Encryption, 48
  - hsm\_do\_auth\_enc, 48
- Ciphering, 23
  - hsm\_auth\_enc, 25
  - hsm\_cipher\_one\_go, 26
  - hsm\_close\_cipher\_service, 26
  - hsm\_do\_cipher, 24
  - hsm\_open\_cipher\_service, 26
- Data storage, 45
  - hsm\_close\_data\_storage\_service, 47
  - hsm\_data\_ops, 46
  - hsm\_data\_storage, 47
  - hsm\_open\_data\_storage\_service, 46
- dest\_key\_identifier
  - op\_but\_key\_exp\_args\_t, 109
- Dev attest, 82
  - hsm\_dev\_attest, 82
- Dev Info, 84
  - hsm\_dev\_getinfo, 84
- Dump Firmware Log, 81
- ECIES encryption, 57
  - hsm\_ecies\_encryption, 58
- Error codes, 99
  - HSM\_CANNOT\_DELETE\_PERMANENT\_KEY, 100
  - HSM\_CANNOT\_RETRIEVE\_KEY\_GROUP, 100
  - HSM\_CMD\_NOT\_SUPPORTED, 100
  - HSM\_CRC\_CHECK\_ERR, 100
  - hsm\_err\_t, 99
  - HSM\_FATAL\_FAILURE, 100
  - HSM\_FEATURE\_DISABLED, 100
  - HSM\_FEATURE\_NOT\_SUPPORTED, 100
  - HSM\_ID\_CONFLICT, 100
  - HSM\_INVALID\_ADDRESS, 100
  - HSM\_INVALID\_LIFECYCLE, 100
  - HSM\_INVALID\_MESSAGE, 100
  - HSM\_INVALID\_PARAM, 100
  - HSM\_KEY\_GROUP\_FULL, 100
  - HSM\_KEY\_NOT\_SUPPORTED, 100
  - HSM\_KEY\_STORE\_AUTH, 100
  - HSM\_KEY\_STORE\_CONFLICT, 100
  - HSM\_KEY\_STORE\_COUNTER, 100
  - HSM\_KEY\_STORE\_ERROR, 100
  - HSM\_NO\_ERROR, 99
  - HSM\_NOT\_READY\_RATING, 100
  - HSM\_NVM\_ERROR, 100
  - HSM\_OEM\_CLOSED\_LC\_SIGNED\_MSG\_VERIFICATION\_FAILURE, 100
  - HSM\_OEM\_OPEN\_LC\_SIGNED\_MSG\_VERIFICATION\_FAILURE, 100
  - HSM\_OUT\_OF\_MEMORY, 100
  - HSM\_OUT\_TOO\_SMALL, 100
  - HSM\_RNG\_NOT\_STARTED, 100
  - HSM\_SELF\_TEST\_FAILURE, 100
  - HSM\_SERVICES\_DISABLED, 100
  - HSM\_SIGNATURE\_INVALID, 100
  - HSM\_UNKNOWN\_ERROR, 100
  - HSM\_UNKNOWN\_HANDLE, 100
  - HSM\_UNKNOWN\_ID, 100
  - HSM\_UNKNOWN\_KEY\_STORE, 100
  - HSM\_UNKNOWN\_WARNING, 100
- expansion\_function\_value
  - op\_but\_key\_exp\_args\_t, 108
- expansion\_function\_value\_size
  - op\_but\_key\_exp\_args\_t, 109
- FLAG
  - Key management, 18
- flags
  - op\_but\_key\_exp\_args\_t, 109
  - op\_ecies\_dec\_args\_t, 112
  - op\_import\_public\_key\_args\_t, 113
  - op\_manage\_key\_group\_args\_t, 113
- Generic Crypto Asymmetric Key Generate, 89
  - hsm\_gc\_akey\_gen, 89
- Generic Crypto: Asymmetric Crypto, 86
  - hsm\_gc\_acrypto, 88
- Get Info, 91
  - hsm\_get\_info, 91
- hash\_value
  - op\_but\_key\_exp\_args\_t, 109
- hash\_value\_size
  - op\_but\_key\_exp\_args\_t, 109
- Hashing, 41
  - hsm\_close\_hash\_service, 43
  - hsm\_do\_hash, 42
  - HSM\_HASH\_FLAG\_ALLOWED, 42
  - hsm\_hash\_one\_go, 43
  - hsm\_open\_hash\_service, 43
- hsm\_auth\_enc
  - Ciphering, 25
- HSM\_CANNOT\_DELETE\_PERMANENT\_KEY
  - Error codes, 100
- HSM\_CANNOT\_RETRIEVE\_KEY\_GROUP
  - Error codes, 100
- hsm\_cipher\_one\_go
  - Ciphering, 26
- hsm\_close\_cipher\_service
  - Ciphering, 26
- hsm\_close\_data\_storage\_service
  - Data storage, 47
- hsm\_close\_hash\_service
  - Hashing, 43
- hsm\_close\_key\_generic\_crypto\_service
  - Key generic crypto service, 79
- hsm\_close\_key\_management\_service
  - Key management, 21

- hsm\_close\_key\_store\_service
  - Key store, [96](#)
- hsm\_close\_mac\_service
  - Mac, [52](#)
- hsm\_close\_rng\_service
  - Random number generation, [39](#)
- hsm\_close\_session
  - Session, [10](#)
- hsm\_close\_signature\_generation\_service
  - Signature generation, [32](#)
- hsm\_close\_signature\_verification\_service
  - Signature verification, [36](#)
- hsm\_close\_sm2\_eces\_service
  - SM2 ECES decryption, [65](#)
- HSM\_CMD\_NOT\_SUPPORTED
  - Error codes, [100](#)
- HSM\_CRC\_CHECK\_ERR
  - Error codes, [100](#)
- hsm\_data\_ops
  - Data storage, [46](#)
- hsm\_data\_storage
  - Data storage, [47](#)
- hsm\_delete\_key
  - Key management, [19](#)
- hsm\_dev\_attest
  - Dev attest, [82](#)
- hsm\_dev\_getinfo
  - Dev Info, [84](#)
- hsm\_do\_auth\_enc
  - Authenticated Encryption, [48](#)
- hsm\_do\_cipher
  - Ciphering, [24](#)
- hsm\_do\_hash
  - Hashing, [42](#)
- hsm\_do\_mac
  - Mac, [50](#)
- hsm\_do\_rng
  - Random number generation, [38](#)
- hsm\_do\_sign
  - Signature generation, [31](#)
- hsm\_ecies\_encryption
  - ECIES encryption, [58](#)
- hsm\_err\_t
  - Error codes, [99](#)
- hsm\_export\_root\_key\_encryption\_key
  - Root KEK export, [59](#)
- HSM\_FATAL\_FAILURE
  - Error codes, [100](#)
- HSM\_FEATURE\_DISABLED
  - Error codes, [100](#)
- HSM\_FEATURE\_NOT\_SUPPORTED
  - Error codes, [100](#)
- hsm\_gc\_acrypto
  - Generic Crypto: Asymmetric Crypto, [88](#)
- hsm\_gc\_akey\_gen
  - Generic Crypto Asymmetric Key Generate, [89](#)
- hsm\_generate\_key
  - Key management, [20](#)
- hsm\_generate\_key\_ext
  - Key management, [20](#)
- hsm\_generate\_signature
  - Signature generation, [32](#)
- hsm\_get\_info
  - Get Info, [91](#)
- hsm\_get\_key\_attr
  - Key management, [19](#)
- hsm\_get\_random
  - Random number generation, [40](#)
- HSM\_HASH\_FLAG\_ALLOWED
  - Hashing, [42](#)
- hsm\_hash\_one\_go
  - Hashing, [43](#)
- HSM\_ID\_CONFLICT
  - Error codes, [100](#)
- HSM\_INVALID\_ADDRESS
  - Error codes, [100](#)
- HSM\_INVALID\_LIFECYCLE
  - Error codes, [100](#)
- HSM\_INVALID\_MESSAGE
  - Error codes, [100](#)
- HSM\_INVALID\_PARAM
  - Error codes, [100](#)
- hsm\_key\_exchange
  - Key exchange, [71](#)
- hsm\_key\_generic\_crypto
  - Key generic crypto service, [80](#)
- HSM\_KEY\_GROUP\_FULL
  - Error codes, [100](#)
- HSM\_KEY\_INFO\_PERSISTENT
  - Key management, [18](#)
- HSM\_KEY\_NOT\_SUPPORTED
  - Error codes, [100](#)
- HSM\_KEY\_STORE\_AUTH
  - Error codes, [100](#)
- HSM\_KEY\_STORE\_CONFLICT
  - Error codes, [100](#)
- HSM\_KEY\_STORE\_COUNTER
  - Error codes, [100](#)
- HSM\_KEY\_STORE\_ERROR
  - Error codes, [100](#)
- hsm\_mac\_one\_go
  - Mac, [51](#)
- hsm\_manage\_key
  - Key management, [21](#)
- hsm\_manage\_key\_ext
  - Key management, [22](#)
- HSM\_NO\_ERROR
  - Error codes, [99](#)
- HSM\_NOT\_READY\_RATING
  - Error codes, [100](#)
- HSM\_NVM\_ERROR
  - Error codes, [100](#)
- HSM\_OEM\_CLOSED\_LC\_SIGNED\_MSG\_VERIFICATION\_FAIL
  - Error codes, [100](#)
- HSM\_OEM\_OPEN\_LC\_SIGNED\_MSG\_VERIFICATION\_FAIL
  - Error codes, [100](#)



- HSM\_OP\_GENERATE\_SIGN\_FLAGS\_INPUT\_DIGEST
  - Signature generation, [30](#)
- HSM\_OP\_GENERATE\_SIGN\_FLAGS\_LOW\_LATENCY\_SIGNATURE
  - Signature generation, [30](#)
- HSM\_OP\_IMPORT\_KEY\_INPUT\_SIGNED\_MSG
  - Key management, [18](#)
- HSM\_OP\_KEY\_GENERATION\_FLAGS\_STRICT\_OPERATION
  - Key management, [19](#)
- HSM\_OP\_KEY\_GENERATION\_FLAGS\_UPDATE
  - Key management, [19](#)
- hsm\_open\_cipher\_service
  - Ciphering, [26](#)
- hsm\_open\_data\_storage\_service
  - Data storage, [46](#)
- hsm\_open\_hash\_service
  - Hashing, [43](#)
- hsm\_open\_key\_generic\_crypto\_service
  - Key generic crypto service, [79](#)
- hsm\_open\_key\_management\_service
  - Key management, [20](#)
- hsm\_open\_key\_store\_service
  - Key store, [96](#)
- hsm\_open\_mac\_service
  - Mac, [51](#)
- hsm\_open\_rng\_service
  - Random number generation, [39](#)
- hsm\_open\_session
  - Session, [10](#)
- hsm\_open\_signature\_generation\_service
  - Signature generation, [31](#)
- hsm\_open\_signature\_verification\_service
  - Signature verification, [36](#)
- hsm\_open\_sm2\_eces\_service
  - SM2 ECES decryption, [65](#)
- HSM\_OUT\_OF\_MEMORY
  - Error codes, [100](#)
- HSM\_OUT\_TOO\_SMALL
  - Error codes, [100](#)
- hsm\_prepare\_signature
  - Signature generation, [33](#)
- hsm\_pub\_key\_decompression
  - Public key decompression, [55](#)
- hsm\_pub\_key\_reconstruction
  - Public key reconstruction, [53](#)
- hsm\_pub\_key\_recovery
  - Public key recovery, [93](#)
- HSM\_RNG\_NOT\_STARTED
  - Error codes, [100](#)
- HSM\_SELF\_TEST\_FAILURE
  - Error codes, [100](#)
- hsm\_service\_hdl\_s, [10](#)
- HSM\_SERVICES\_DISABLED
  - Error codes, [100](#)
- hsm\_session\_hdl\_s, [9](#)
- HSM\_SIGNATURE\_INVALID
  - Error codes, [100](#)
- hsm\_sm2\_eces\_decryption
  - SM2 ECES decryption, [65](#)
- hsm\_sm2\_eces\_encryption
  - SM2 ECES encryption, [67](#)
- hsm\_store\_get\_z
  - SM2 Get Z, [62](#)
- hsm\_standalone\_butterfly\_key\_expansion
  - Standalone butterfly key expansion, [76](#)
- hsm\_tls\_finish
  - Key exchange, [73](#)
- HSM\_UNKNOWN\_ERROR
  - Error codes, [100](#)
- HSM\_UNKNOWN\_HANDLE
  - Error codes, [100](#)
- HSM\_UNKNOWN\_ID
  - Error codes, [100](#)
- HSM\_UNKNOWN\_KEY\_STORE
  - Error codes, [100](#)
- HSM\_UNKNOWN\_WARNING
  - Error codes, [100](#)
- hsm\_verify\_sign
  - Signature verification, [35](#)
- hsm\_verify\_signature
  - Signature verification, [36](#)
- i.MX8DXL specificities, [105](#)
- i.MX8QXP specificities, [101](#)
- input
  - op\_ecies\_dec\_args\_t, [111](#)
- input\_size
  - op\_ecies\_dec\_args\_t, [111](#)
- kek\_enc\_key\_hdr\_t, [16](#)
- key
  - op\_import\_public\_key\_args\_t, [112](#)
- Key exchange, [69](#)
  - hsm\_key\_exchange, [71](#)
  - hsm\_tls\_finish, [73](#)
- Key generic crypto service, [78](#)
  - hsm\_close\_key\_generic\_crypto\_service, [79](#)
  - hsm\_key\_generic\_crypto, [80](#)
  - hsm\_open\_key\_generic\_crypto\_service, [79](#)
- Key management, [12](#)
  - FLAG, [18](#)
  - hsm\_close\_key\_management\_service, [21](#)
  - hsm\_delete\_key, [19](#)
  - hsm\_generate\_key, [20](#)
  - hsm\_generate\_key\_ext, [20](#)
  - hsm\_get\_key\_attr, [19](#)
  - HSM\_KEY\_INFO\_PERSISTENT, [18](#)
  - hsm\_manage\_key, [21](#)
  - hsm\_manage\_key\_ext, [22](#)
  - HSM\_OP\_IMPORT\_KEY\_INPUT\_SIGNED\_MSG, [18](#)
  - HSM\_OP\_KEY\_GENERATION\_FLAGS\_STRICT\_OPERATION, [19](#)
  - HSM\_OP\_KEY\_GENERATION\_FLAGS\_UPDATE, [19](#)
  - hsm\_open\_key\_management\_service, [20](#)
- Key store, [95](#)
  - hsm\_close\_key\_store\_service, [96](#)

- hsm\_open\_key\_store\_service, 96
- key\_group
  - op\_but\_key\_exp\_args\_t, 110
  - op\_manage\_key\_group\_args\_t, 113
- key\_identifier
  - op\_but\_key\_exp\_args\_t, 108
  - op\_ecies\_dec\_args\_t, 111
- key\_info
  - op\_but\_key\_exp\_args\_t, 110
- key\_size
  - op\_import\_public\_key\_args\_t, 112
- key\_type
  - op\_but\_key\_exp\_args\_t, 110
  - op\_ecies\_dec\_args\_t, 112
  - op\_import\_public\_key\_args\_t, 113
- LC update, 98
- Mac, 49
  - hsm\_close\_mac\_service, 52
  - hsm\_do\_mac, 50
  - hsm\_mac\_one\_go, 51
  - hsm\_open\_mac\_service, 51
- mac\_size
  - op\_ecies\_dec\_args\_t, 112
- op\_auth\_enc\_args\_t, 23
- op\_but\_key\_exp\_args\_t, 108
  - dest\_key\_identifier, 109
  - expansion\_function\_value, 108
  - expansion\_function\_value\_size, 109
  - flags, 109
  - hash\_value, 109
  - hash\_value\_size, 109
  - key\_group, 110
  - key\_identifier, 108
  - key\_info, 110
  - key\_type, 110
  - output, 109
  - output\_size, 110
  - pr\_reconstruction\_value, 109
  - pr\_reconstruction\_value\_size, 109
  - reserved, 110
- op\_cipher\_one\_go\_args\_t, 24
- op\_data\_storage\_args\_t, 45
- op\_debug\_dump\_args\_t, 81
- op\_delete\_key\_args\_t, 15
- op\_dev\_attest\_args\_t, 82
- op\_dev\_getinfo\_args\_t, 84
- op\_ecies\_dec\_args\_t, 110
  - flags, 112
  - input, 111
  - input\_size, 111
  - key\_identifier, 111
  - key\_type, 112
  - mac\_size, 112
  - output, 111
  - output\_size, 111
  - p1, 111
  - p1\_size, 111
  - p2, 111
  - p2\_size, 112
- op\_ecies\_enc\_args\_t, 57
- op\_export\_root\_kek\_args\_t, 59
- op\_gc\_acrypto\_args\_t, 87
- op\_gc\_akey\_gen\_args\_t, 89
- op\_generate\_key\_args\_t, 17
- op\_generate\_key\_ext\_args\_t, 16
- op\_generate\_sign\_args\_t, 30
- op\_get\_info\_args\_t, 91
- op\_get\_key\_attr\_args\_t, 15
- op\_get\_random\_args\_t, 38
- op\_hash\_one\_go\_args\_t, 42
- op\_import\_key\_args\_t, 16
- op\_import\_public\_key\_args\_t, 112
  - flags, 113
  - key, 112
  - key\_size, 112
  - key\_type, 113
- op\_key\_exchange\_args\_t, 70
- op\_key\_generic\_crypto\_args\_t, 78
- op\_lc\_update\_msg\_args\_t, 98
- op\_mac\_one\_go\_args\_t, 50
- op\_manage\_key\_args\_t, 17
- op\_manage\_key\_ext\_args\_t, 18
- op\_manage\_key\_group\_args\_t, 113
  - flags, 113
  - key\_group, 113
  - reserved, 113
- op\_prepare\_sign\_args\_t, 30
- op\_pub\_key\_dec\_args\_t, 55
- op\_pub\_key\_rec\_args\_t, 53
- op\_pub\_key\_recovery\_args\_t, 93
- op\_sm2\_eces\_dec\_args\_t, 64
- op\_sm2\_eces\_enc\_args\_t, 67
- op\_sm2\_get\_z\_args\_t, 62
- op\_st\_but\_key\_exp\_args\_t, 75
- op\_tls\_finish\_args\_t, 71
- op\_verify\_sign\_args\_t, 35
- open\_session\_args\_t, 10
- open\_svc\_cipher\_args\_t, 24
- open\_svc\_data\_storage\_args\_t, 45
- open\_svc\_hash\_args\_t, 41
- open\_svc\_key\_generic\_crypto\_args\_t, 78
- open\_svc\_key\_management\_args\_t, 17
- open\_svc\_key\_store\_args\_t, 95
- open\_svc\_mac\_args\_t, 49
- open\_svc\_rng\_args\_t, 38
- open\_svc\_sign\_gen\_args\_t, 29
- open\_svc\_sign\_ver\_args\_t, 34
- open\_svc\_sm2\_eces\_args\_t, 64
- output
  - op\_but\_key\_exp\_args\_t, 109
  - op\_ecies\_dec\_args\_t, 111
- output\_size
  - op\_but\_key\_exp\_args\_t, 110
  - op\_ecies\_dec\_args\_t, 111

- p1
  - op\_ecies\_dec\_args\_t, [111](#)
- p1\_size
  - op\_ecies\_dec\_args\_t, [111](#)
- p2
  - op\_ecies\_dec\_args\_t, [111](#)
- p2\_size
  - op\_ecies\_dec\_args\_t, [112](#)
- pr\_reconstruction\_value
  - op\_but\_key\_exp\_args\_t, [109](#)
- pr\_reconstruction\_value\_size
  - op\_but\_key\_exp\_args\_t, [109](#)
- Public key decompression, [55](#)
  - hsm\_pub\_key\_decompression, [55](#)
- Public key reconstruction, [53](#)
  - hsm\_pub\_key\_reconstruction, [53](#)
- Public key recovery, [93](#)
  - hsm\_pub\_key\_recovery, [93](#)
- Random number generation, [38](#)
  - hsm\_close\_rng\_service, [39](#)
  - hsm\_do\_rng, [38](#)
  - hsm\_get\_random, [40](#)
  - hsm\_open\_rng\_service, [39](#)
- reserved
  - op\_but\_key\_exp\_args\_t, [110](#)
  - op\_manage\_key\_group\_args\_t, [113](#)
- Root KEK export, [59](#)
  - hsm\_export\_root\_key\_encryption\_key, [59](#)
- Session, [8](#)
  - hsm\_close\_session, [10](#)
  - hsm\_open\_session, [10](#)
- Signature generation, [28](#)
  - hsm\_close\_signature\_generation\_service, [32](#)
  - hsm\_do\_sign, [31](#)
  - hsm\_generate\_signature, [32](#)
  - HSM\_OP\_GENERATE\_SIGN\_FLAGS\_INPUT\_DIGEST, [30](#)
  - HSM\_OP\_GENERATE\_SIGN\_FLAGS\_LOW\_LATENCY\_SIGNATURE, [30](#)
  - hsm\_open\_signature\_generation\_service, [31](#)
  - hsm\_prepare\_signature, [33](#)
- Signature verification, [34](#)
  - hsm\_close\_signature\_verification\_service, [36](#)
  - hsm\_open\_signature\_verification\_service, [36](#)
  - hsm\_verify\_sign, [35](#)
  - hsm\_verify\_signature, [36](#)
- SM2 ECES decryption, [64](#)
  - hsm\_close\_sm2\_eces\_service, [65](#)
  - hsm\_open\_sm2\_eces\_service, [65](#)
  - hsm\_sm2\_eces\_decryption, [65](#)
- SM2 ECES encryption, [67](#)
  - hsm\_sm2\_eces\_encryption, [67](#)
- SM2 Get Z, [62](#)
  - hsm\_sm2\_get\_z, [62](#)
- Standalone butterfly key expansion, [75](#)
  - hsm\_standalone\_butterfly\_key\_expansion, [76](#)