

## NOISE OCCURS

### INSPECTION PROCEDURE

#### 1 CHECK SPEAKER INSTALLATION

- (a) Check the speaker installation condition.  
 (1) Check that each speaker is securely installed.

**OK: Malfunction disappears.**

**HINT:**

The radio is equipped with a noise prevention system that blocks excessively loud noise. If such noise occurs, check that all wiring is proper and that the antenna installation part ground and noise-prevention equipment are installed.

Conditions under which noise occurs	Noise type
Noise increases when the accelerator pedal is depressed, but stops when the engine is stopped.	Generator noise
Noise occurs during A/C or heater operation.	Blower motor noise
Noise occurs when the vehicle accelerates rapidly on an unpaved road or after the ignition switch is turned on.	Fuel pump noise
Noise occurs when the horn switch is pressed and released or when pressed and held.	Horn noise
Quiet noise occurs while the engine is running, but stops when the engine is stopped.	Ignition noise
Noise occurs synchronously with the blink of the turn signal.	Flasher noise
Noise occurs during window washer operation.	Washer noise
Noise occurs while the engine is running, and continues even after the engine is stopped.	Water temperature sensor noise
Noise occurs during wiper operation.	Wiper noise
Noise occurs when the brake pedal is depressed.	Stop light switch noise
Others	Static electricity stored on the vehicle

**HINT:**

- Identify the conditions under which the noise occurs, and check the noise filter on the relevant part.
- First ensure that the noise is not coming from the outside. Failure to do so makes noise source detection difficult and may lead to a misdiagnosis.
- Noise should be removed in descending order of loudness.

**NG**

**INSTALL IT PROPERLY**

**OK**

### IDENTIFICATION OF NOISE SOURCE