

PROBLEM SYMPTOMS TABLE

HINT:

If a normal code is displayed during the diagnostic trouble code check although the trouble still occurs, check the electrical circuits for each symptom in the order given in the charts on the following pages and proceed to the page given for troubleshooting.

The Matrix Chart is divided into 2 chapters.

1. Chapter 1: Electronic Circuit Matrix Chart

- Refer to the table below when the trouble cause is considered to be electrical.
- If the instruction "Proceed to next circuit inspection shown on matrix chart" is given in the flow chart of each circuit, proceed to the circuit with the next highest number in the table to continue the check.
- If the trouble still occurs even though there are no abnormalities in any of the other circuits, check and replace the ECM.

HINT:

*1: When the circuit on which mark *1 is attached is defective, DTC could be output (see page [05-1152](#)).

Symptom	Suspected Area	See page
No down-shift (A particular gear, from 1st to 4th gear, is not down-shifted)	1. Shift solenoid valve (SL1) circuit *1 2. Shift solenoid valve (SL2) circuit *1 3. Shift solenoid valve (SL3) circuit *1 4. Shift solenoid valve (SR) circuit *1 5. ECM	05-1180 05-1197 05-1209 05-1192 01-32
No down-shift (5th → 4th)	1. Transmission control switch (O/D OFF) circuit 2. Shift solenoid valve (S4) circuit *1 3. ECM	05-1230 05-1187 01-32
No up-shift (A particular gear, from 1st to 4th gear, is not up-shifted)	1. Shift solenoid valve (SL1) circuit *1 2. Shift solenoid valve (SL2) circuit *1 3. ECM	05-1180 05-1197 01-32
No up-shift (4th → 5th)	1. Transmission control switch (O/D OFF) circuit 2. Shift solenoid valve (S4) circuit *1 3. ECM	05-1230 05-1187 01-32
No lock-up	1. Shift solenoid valve (DSL) circuit *1 2. Stop light switch circuit *1 3. Engine coolant temp. sensor circuit *1 4. ECM	05-1175 05-1172 05-51 05-390 01-32
No lock-up off	1. Shift solenoid valve (DSL) circuit *1 2. ECM	05-1175 01-32
Shift point too high or too low	1. Throttle position sensor circuit *1 2. Shift solenoid valve (SLT) circuit *1 3. ECM	05-51 05-390 05-1223 01-32
Up-shift to 5th from 4th while shift lever is D (O/D OFF) position	1. Transmission control switch (O/D OFF) circuit 2. ECM	05-1230 01-32
Up-shift to 5th from 4th while engine is cold	1. Engine coolant temp. sensor circuit *1 2. ECM	05-51 05-390 01-32
Up-shift to 2nd from 1st while shift lever is L position	1. Transmission control switch (2 ⇔ L position) circuit *1 2. ECM	05-1154 01-32
Harsh engagement (N → D)	1. Shift solenoid valve (SL1) circuit *1 2. ECM	05-1180 01-32
Harsh engagement (Lock-up)	1. Shift solenoid valve (SL2) circuit *1 2. ECM	05-1197 01-32

Harsh engagement (Any driving position)	1. Shift solenoid valve (SLT) circuit *1 2. ECM	05-1223 01-32
Poor acceleration	1. Shift solenoid valve (SLT) circuit *1 2. ECM	05-1223 01-32
No kick-down	ECM	01-32
Engine stalls when starting off or stopping	1. Shift solenoid valve (DSL) circuit *1 2. ECM	05-1175 01-32
Malfunction in shifting	1. Park/neutral position switch circuit *1 2. Transmission control switch (O/D OFF) circuit 3. ECM	05-1154 05-1230 01-32

2. Chapter 2: On-Vehicle Repair and Off-Vehicle Repair

(★: U250E AUTOMATIC TRANSAXLE Repair Manual Pub. No. RM1123U)

Symptom	Suspected Area	See page
Vehicle does not move in forward position and in reverse position	1. Valve body assy 2. U/D brake (B ₃) 3. Torque converter clutch	40-42 ★ 40-27
Vehicle does not move in R position	1. Valve body assy 2. Reverse clutch (C ₂) 3. 1st & reverse brake (B ₂)	40-42 ★ ★
No up-shift (1st → 2nd)	1. Valve body assy 2. 2nd & O/D brake (B ₁)	40-42 ★
No up-shift (2nd → 3rd)	1. Valve body assy 2. Direct and O/D clutch (C ₀)	40-42 ★
No up-shift (3rd → 4th)	1. Valve body assy 2. 2nd & O/D brake (B ₁)	40-42 ★
No up-shift (4th → 5th)	1. Valve body assy 2. U/D clutch (C ₃)	40-42 ★
No down-shift (5th → 4th)	Valve body assy	40-42
No down-shift (4th → 3rd)	Valve body assy	40-42
No down-shift (3rd → 2nd)	Valve body assy	40-42
No down-shift (2nd → 1st)	Valve body assy	40-42
No lock-up or No lock-up off	1. Valve body assy 2. Torque converter clutch	40-42 40-27
Harsh engagement (N → D)	1. Valve body assy 2. C ₁ accumulator 3. Forward clutch (C ₁) 4. One-way clutch No.1 (F ₁) 5. U/D one-way clutch (F ₂)	40-42 ★ ★ ★ ★
Harsh engagement (Lock-up)	1. Valve body assy 2. Torque converter clutch	40-42 40-27
Harsh engagement (N → R)	1. Valve body assy 2. C ₂ accumulator 3. Reverse clutch (C ₂) 4. 1st & reverse brake (B ₂)	40-42 ★ ★ ★
Harsh engagement (1st → 2nd → 3rd → 4th → 5th)	Valve body assy	40-42
Harsh engagement (1st → 2nd)	1. Valve body assy 2. 2nd & O/D brake (B ₁)	40-42 ★
Harsh engagement (2nd → 3rd)	1. Valve body assy 2. C ₀ accumulator 3. Direct and O/D clutch (C ₀)	40-42 ★ ★
Harsh engagement (3rd → 4th)	1. Valve body assy 2. 2nd & O/D brake (B ₁)	40-42 ★
Harsh engagement (4th → 5th)	1. Valve body assy 2. C ₃ accumulator 3. U/D clutch (C ₃)	40-42 ★ ★
Harsh engagement (5th → 4th)	1. Valve body assy 2. B ₃ accumulator	40-42 ★

Slip or shudder (Forward and reverse: After warm-up)	1. Valve body assy	40-42
	2. Oil strainer	40-42
	3. Direct and O/D clutch (C ₀)	★
	4. Forward clutch (C ₁)	★
	5. U/D clutch (C ₃)	★
	6. 2nd & O/D brake (B ₁)	★
	7. U/D brake (B ₃)	★
	8. One-way clutch No.1 (F ₁)	★
	9. U/D one-way clutch (F ₂)	★
	10. Torque converter clutch	40-27
Slip or shudder (Particular position: Just after engine starts)	Torque converter clutch	40-27
Slip or shudder (R position)	1. Reverse clutch (C ₂)	★
	2. 1st & reverse brake (B ₂)	★
Slip or shudder (1st)	1. Forward clutch (C ₁)	★
	2. One-way clutch No.1 (F ₁)	★
	3. U/D one-way clutch (F ₂)	★
Slip or shudder (2nd)	2nd & O/D brake (B ₁)	★
Slip or shudder (3rd)	Direct and O/D clutch (C ₀)	★
Slip or shudder (4th)	2nd & O/D brake (B ₁)	★
Slip or shudder (5th)	U/D clutch (C ₃)	★
No engine braking (1st – 4th: D position)	U/D brake (B ₃)	★
No engine braking (1st: L (1) position)	1. Valve body assy	40-42
	2. 1st & reverse brake (B ₂)	★
No engine braking (2nd: 2 position)	1. Valve body assy	40-42
	2. 2nd & O/D brake (B ₁)	★
No engine braking (3rd: 3 position)	U/D brake (B ₃)	★
Poor acceleration (All positions)	Torque converter clutch	40-27
Poor acceleration (5th)	1. U/D clutch (C ₃)	★
	2. U/D planetary gear unit	★
Engine stalls when starting off or stopping	Torque converter clutch	40-27
No kick-down	Valve body assy	40-42