


NORNS UI:

The user interface has 4 pages: **SEQUENCE**, **DELAY**, **SYNTH** and **COMMAND REFERENCE**. Use **ENC1** to scroll through the pages. Scroll through the command references (see page 4) with **ENC2**.


SEQUENCE PAGE:

- ▶ Navigate to the desired step with **ENC2**. The currently selected step is highlighted. Scroll through the commands with **ENC3**. While **KEY1** is held all commands except **#** and **?** are ignored.
- ▶ Hold **KEY1** and use **ENC2** to change the note of the selected step.
- ▶ Press **KEY2** to start/stop the sequencer. Hold **KEY1** and press **KEY2** to reset to the first step.
- ▶ Press **KEY3** to randomize the command sequence. Hold **KEY1** and press **KEY3** to reset the command sequence.
- ▶ Hold **KEY3** for longer than 1s to randomize the note pattern and reset the command sequence.

DELAY PAGE:

- ▶ **level: (0 - 1)** delay level
- ▶ **rate: (division)** delay rate (syncd to internal clock)
- ▶ **feedback: (0 - 1)** feedback amount
- ▶ **adjust rate: ($\pm 10\%$)** shorten or lengthen delay time to deviate from the synced rate.


Use **K2** to toggle between the top and bottom row of parameters (active row is highlighted) and use **ENC2** and **ENC3** to change the corresponding parameter values.

SYNTH PAGE:

- ▶ **wave shape: (0 - 10)** adjust waveform
- ▶ **wave folds: (0 - 10)** intensity of wave folding
- ▶ **cutoff freq: (0 - 10kHz)** cutoff of the lpg
- ▶ **decay: (0.01 - 8s)** decay of the lpg

Use **K2** to toggle between the top and bottom row of parameters (active row is highlighted) and use **ENC2** and **ENC3** to change the corresponding parameter values.

GRID LAYOUT:



KEY PRESSES:

- Press **START/STOP** to start or stop the sequencer.
- Hold a **COMMAND KEY** and press the desired step within the sequence row to assign the command to the selected step.
- Hold **ALT** and a step to make the playhead jump to the pressed step.
- **DIRECTION** selects the playback direction.
- **BASE CLOCK MULT** sets the multiplication of the internal clock source. At factor 1 a step corresponds to a quarter note.
- Select a note pattern by pressing the according **NOTE PATTERN PRESET** slot. To copy the selected note pattern to another slot hold **ALT** and press desired slot. The note pattern of that slot will be overwritten with the pattern data of the currently active (highlighted) note pattern slot. All changes are automatically stored.
- **COMMAND PATTERN PRESETS** are selected/copied the same way as note pattern presets.
- Select the sequence **LENGTH** by pressing and holding the according start-point and end-point keys. The length is set on key-release.

PARAMETER MENU:

DUNES PARAMETERS:

DUNES	
output settings >	
midi settings >	
scale settings >	
save & load >	

- ▶ **output settings** > turn the passersby engine on/off. Select an external output (off, midi, crow 1+2, crow ii JF)
- ▶ **midi settings** > see midi parameters
- ▶ **scale settings** > select scale, root note and note display (on/off)
- ▶ **save & load** > save or load a note pattern and/or command sequence. The data is read from / written to the currently selected preset slot(s). **Important:** Scale and root note are saved and recalled with note patterns, so your current settings might get overwritten.

MIDI PARAMETERS:

midi device	1: OP-2
midi channel	1
midi transport	off
velocity mode	fixed
velocity value	100
velocity range ±	20

- ▶ **midi device: (1 - 16)** select midi device slot.
- ▶ **midi channel: (1 - 16)** select midi channel on which note data is sent.
- ▶ **midi transport: (off, send, receive)** send or receive midi start/ stop messages.
- ▶ **velocity mode: (fixed, random)** fixed velocity value is set via "velocity value", when set to random the velocity value is randomized within the range: "velocity value" ± velocity range.
- ▶ **velocity value (1 - 127)** set base velocity value.
- ▶ **velocity range: (± 1 - 127)** set velocity range.

SOUND PARAMETERS:

sound	
delay >	
synth >	

- ▶ **delay: (softcut delay parameters)**
- ▶ **synth: (passersby engine parameters)**

CROW PARAMETERS:

crow	
out 1: v/oct type	1 v/oct
out 2: envelope >	
out 3: rnd v-range	5.0 v
out 4: envelope >	

- ▶ **out 1: (1 / 1.2 v/oct)** set v/oct standard
- ▶ **out 2: (AD env)** set amplitude, attack and decay
- ▶ **out 3: (1 - 5v)** set random voltage range
- ▶ **out 4: (AD env)** set amplitude, attack and decay

Saving/recalling sessions:

All parameter settings, note pattern presets and command sequence presets are saved/recalled via the built-in norms pset manager. Note that currently there is no callback function to automatically remove data from deleted pset. This needs to be done manually.

COMMAND REFERENCE:

There are 33 commands in total, which affect the **SEQUENCE**, the **SYNTH** engine, the softcut **DELAY** and **CROW** outputs 3 and 4.

COMMAND DESCRIPTION:

- < Octave down (clamped at -1 octave)
- > Octave up (clamped at +1 octave)
- O Random octave (either +1, 0 or -1 octave)
- Half tempo (clamped at base rate / 4)
- + Double tempo (clamped at base rate * 4)
- = Reset tempo to base clock rate
- M Add rest (at step)
- N New note (at step)
- P New pattern (randomized note pattern)
- # Reset position to first step if direction fwd or to last step if direction rev
- ? Jump to random step
- } Forward direction
- { Reverse direction

- G Random glide at step
- d Decrements the currently set decay value
- D Increments the currently set decay value
- s Decrements the currently set wave shape value
- S Increments the currently set wave shape value
- f Decrements the currently set wave fold value
- F Increments the currently set wave fold value
- v Decrements the passersby reverb mix (clamped at 0.05)
- V Increments the passersby reverb mix (clamped at 0.5)

- R Set random voltage: crow output 3 (set range in params)
- E Trigger AD envelope: crow output 4 (set slopes in params)

- X Randomly set the pan position (-1 - 1) of the softcut delay
- 1 Reset the delay rate to the set value (softcut playback speed = 1)
- 2 Multiply the delay rate by 2 (clamped at 2), play forward
- 3 Multiply delay rate by 2 (clamped at, 2), play reverse
- 4 Divide delay rate by 2 (clamped at 0.5), play forward
- 5 Divide delay rate by 2 (clamped at 0.5), play reverse
- Z Freeze the delay buffer (loops recorded material)
- z Unfreeze delay buffer

- ! Insert a random command at a random step (not selectable via grid)