


OMEN PIA / issue 1

Technical Documentation





INTRODUCTION

=====

The OMEN PIA kit is a peripheral circuit for the OMEN series computers. It features:

- Motorola MC68B21 PIA
- Two 8bit parallel ports
- four control signals
- Power supply /optional/


ASSEMBLY INSTRUCTIONS

=====

1. Solder sockets for the integrated circuits
2. Test all soldered connections
 - a. Test if all pins are well connected
 - b. Check if GND is not short connected to Vcc
 - c. Check if each IC has properly connected GND and Vcc
3. Solder all passive parts
4. Solder voltage regulator, if necessary
5. Solder RESET inverter for OMEN Alpha
6. Set switches to the proper configuration

THE BOARD

=====



Jumpers and pin headers

IO1-IO7: Selects the IO enable signal. OMEN computers has seven free /IO select signals, so you can chose the right one for you.

RES: All OMEN computers /Bravo, Kilo, .../ has /RESET active in log. 0. Only Alpha has a positive RESET, active in log. 1. For Bravo or Kilo just connect pins 1 and 2 - left and middle, marked as “+/-” For Alpha connect middle and right, marked “/-” and solder the SMD invertor 74AHCLG04, or just connect the middle pin to the VCC.

JP3, JP4: Only if you are planning to use the external power supply. Use two jumpers and connect them into the “VIN” position if voltage input is 5 V

OMEN PIA =====



exactly. In the case you have non*regulated power supply 7 - 12 V, you have to connect both switches to the “LDO” position. You have to solder a 7805 voltage regulator and two polarized capacitors.

CAUTION =====


In the case you are using the PIA power supply, please do not connect the OMEN CPU board power supply together.

In the case you do not want to use PIA power supply circuit, just leave the JP3, JP4, C1, C2 and 7805 not connected.

OMEN ALPHA =====

When connecting the OMEN PIA to the OMEN Alpha computer, you HAVE TO:

- solder the inverter 74AHC1G04 and connect the RES pins 2 and 3, marked as “slash - minus”
- OR
- connect the PIA pin 34 with the PIA pin 20 and leave RES unconnected. Use the resistor 10k. The resistance is not critical. You can use the simple wire connection too.





SYSTEM APPLICATION CONNECTOR

=====

This connector is on the right edge of board. Pin 1 is on the upper side, next to the SYSTEM label.

Pins:

1 /WR

2 D0

3 D1

4 D2

5 D3

6 D4

7 D5

8 D6

9 D7

10 A0

11 A1

12 A2

13 /RD

14 IO1

15 IO2

16 IO3

17 IO4

18 IO5

19 IO6

20 IO7

21 Vcc

22 GND

23 IRQ

24 PHI2

25 /RESET --- see the comment above

26 /WAIT

27 /BUSRQ

28 /BUSACK

	Bravo, Kilo		Alpha
14 IO1	--- 9000h - 93FFh	---	20h - 27h
15 IO2	--- 8800h - 8BFFh	---	10h - 17h
16 IO3	--- 9800h - 9BFFh	---	30h - 37h
17 IO4	--- 8400h - 87FFh	---	00h - 0Fh
18 IO5	--- 9400h - 97FFh	---	20h - 2Fh
19 IO6	--- 8C00h - 8FFFh	---	10h - 1Fh
20 IO7	--- 9C00h - 9FFFh	---	30h - 3Fh

