

WEPS Sensors

Procedure for Installation, Operation and
Maintenance of Subsea Sensors

00003075 - Rev AL

Siemens Energy AS
Ternetangen 65
N-5420 Rubbestadneset
NORWAY







Revision List

Rev	Date	Description	Author	Reviewed	Approved
Y	01.09.2016	Updated references Added info about 20K PSI Updated ch. 7	EV	IMB	AE
Z	29.03.2017	Added flange type to section 6.2	AE	EV	BH
AA	03.11.2017	Updated section for analogue sensors. Added ref. [38]	EV	IMB	AE
AB	02.01.2018	Updated references Updated ch. 7.1	EV	JIF	IMB
AC	23.07.2018	Improved wording section 6.2, page 10	AE	CS	JV
AD	05.02.2019	Revised wording section 4 and 8 – storage temp requirements	AE	JIF	EV
AE	26.02.2019	Section 8 – Improved wording for onsite testing	AE	TKG	EV
AF	12.05.2020	Section 5 – Updated wording to describe correct lifting technical for sensors supplied with dedicated lifting points. Added new section 7/8/9 for instructions regarding IR testing, welding and painting. Updated section 3 with correct revision. Section 6.2 – Added flange	AE	TKG	EV
AG	12.08.2020	Fixed typo in ch. 10.1 Changed company name to Siemens Energy (former Siemens) Updated logo on front page and header. Updated references.	EV	JIF	AE
AH	24.08.2020	Fixed wrong chapter reference to SIL sensors in ch. 10.1	EV	JIF	AE
AI	28.09.2020	Added pictures to chapter 8	EV	SKL	AE
AJ	26.11.2020	Added pictures to chapter 8	SKL	EV	AE
AK	31.05.2021	Added WEPS-300 information + SE logos	AE	EV	SKL
AL	14.10.2021	Corrected reference to 6A + improved wording	SKL	EV	AE

TABLE OF CONTENTS

1	CAUTIONS.....	4
2	ABBREVIATIONS.....	5
3	REFERENCES.....	6
4	PACKING AND TRANSPORTATION	7
5	HEALTH AND SAFETY STATEMENTS	8
6	INSTALLATION	9
6.1	INSTALLATION INSTRUCTIONS	9
6.2	MECHANICAL INTERFACE	9
7	INSULATION RESISTANCE TESTING	11
8	WELDING	12
8.1	NO FLYING LEADS.....	12
8.2	HOW TO GROUND FLYING LEADS	13
8.3	SENSORS WITH FLYING LEADS	17
8.4	SENSOR SUPPLIED WITH CONNECTOR	17
8.5	SENSOR HARNESS	18
9	PAINTING ON STRUCTURE	19
10	OPERATING INSTRUCTIONS.....	19
10.1	ANALOGUE SENSORS	19
10.2	DIGITAL SENSORS	20
10.3	SIL RATED SENSORS.....	24
11	MAINTENANCE.....	25

1 CAUTIONS

	PLEASE READ THE COMPLETE INSTALLATION, OPERATION AND MAINTENANCE MANUAL BEFORE ANY WORK START.
	<p>Avoid manual handling !</p> <p>Manual Handling by an individual at this weight should be avoided at all times.</p> <p>Suitable mechanical lifting aids should be identified, and used for the movement of Sensors, avoiding Musculoskeletal damage to the operator. The weight of the sensor will be found on the Weight Certificate for each individual type of sensor.</p>
	<p>Unless the sensor is within its transport case, it shall only be handled by personnel authorised by the client.</p> <p>Installation shall only be undertaken by personnel authorised by the client.</p>
	<p>Never use air tools when fixing the remote seal- and main body bolts.</p> <p>Avoid other types of shock and vibration impacts</p>
	<p>At any time during any type of welding operations in vicinity of the sensor, all cables shall be grounded.</p> <p>Twist all leads of the sensor and ensure that they are properly connected to the sensor housing.</p>
	<p>Membrane system must be handled with extreme care, do not:</p> <ul style="list-style-type: none"> • Touch or come near the membrane surface by hand or any object. <p>Note that the membrane is very thin and fragile, even the slightest contact with a sharp object may permanently damage the complete sensor.</p>

2 ABBREVIATIONS

Abbreviation	Description
API	American Petroleum Institute
CAN	Controller Area Network
CANopen	CAN Standard based on EN50325
CiA	CAN in Automation
CRC	Cyclic Redundancy Check
FAT	Factory Acceptance Test
FT	Fault Tolerant
HS	High Speed
NMT	Network Management, CAN Application Layer
PDO	Process Data Object
PFD	Probability of Failure on Demand
PPE	Personal Protective Equipment
RTU	Remote Terminal Unit
SFF	Safe Failure Function
SIF	Safety Instrumented Function
SIL	Safety Integrity Level
SIS	Safety Instrumented System
SRS	Safety Requirement Specification
SYNC	Synchronous Transmission

3 REFERENCES

Ref	Doc. No.	Version	Title
[1]	CiA-443	1.0, 2.0 or 3.0	CANopen Device Profile for SIIS level-2 devices
[2]	CiA-401	3.0	CANopen Device Profile for Generic I/O Modules
[3]	CiA-301	4.2.0	CANopen application layer and communication profile
[4]	API 6A	2019	Specification for Wellhead and Christmas Tree Equipment
[5]	00002015	B	Safety Manual WEPS-100 Series 4-20 mA SIL
[6]	00003816	M	Procedure for Packing, Preservation, Handling and Shipping of Subsea Pressure and Temperature Sensors
[7]	00004614	C	Specification for Subsea Instrumentation with CiA-401 Interface
[8]	00004615	D	Specification for WEPS-6153 SIL3 CiA-401 Interface
[9]	00004616	G	Specification for WEPS-100 Series Modbus Interface
[10]	00004617	D	Specification for WEPS-100 Series RS485 KOS Interface
[11]	00004621	D	Specification for WEPS-6122 and WEPS-6152 SIL2 CiA-401 Interface
[12]	00004622	D	Specification for WEPS-642 and WEPS-645 Modbus Interface
[13]	00004623	N	Specification Weeps-100 Series CANopen Interface
[14]	00004627	B	Specification for WADS CiA-443 v2.0 Interface
[15]	00004798	D	Specification WEPS-25 CiA-443 v2.0 Interface
[16]	00004799	C	Specification for WEPS-100 Series 4-20 mA SIL Interface
[17]	00004805	F	Specification WEPS-25 CiA-443 v1.0 Interface
[18]	00004833	C	Specification for WEPS RS485 KOS Interface
[19]	00004836	F	Specification for WEPS-612 and WEPS-615 CiA-443 v.2.0 Interface
[20]	00004848	C	Specification for WEPS-6121 and WEPS-6151 SIL1 CiA-401 Interface
[21]	00004850	C	Specification for WEPS-95 CiA-443 Interface
[22]	00007067	C	Specification WEPS-2 and WEPS-25 Profibus Interface
[23]	00007070	B	Specification WEPS-3 Profibus Interface
[24]	00010690	A	Specification for WEPS-3 CiA-443 v2.0 Interface
[25]	00014628	A	Specification for WEPS-612 and WEPS-615 CiA-401 Interface
[26]	00020420	A	Safety Requirement Specification SRS SIL1 WEPS-612 and WEPS-615 CANopen FT
[27]	00020423	A	Safety Requirement Specification SRS SIL2 WEPS-6122 & 6152 CANopen HS
[28]	00020428	A	Safety Requirement Specification SRS SIL2 WEPS-5 FR 4-20 mA
[29]	00020431	A	Safety Requirement Specification SRS SIL3 WEPS-6153 CANopen FT
[30]	00032571	E	Software Manual for WEPS-900 HT Series CANopen CiA-443 SIL3 Interface
[31]	10000657	B	Specification for WEPS-100 Series 4-20 mA PT Interface
[32]	10000659	B	Specification for WEPS-100 Series 4-20 mA TT Interface
[33]	10001535	D	Safety Manual WEPS-900 Series HT CANopen SIL3
[34]	10024259	B	Software Manual for WEPS-900 HT Series CANopen CiA-443 Interface
[35]	10033064	D	Software Manual for WEPS-900 HP Series CANopen CiA-443 SIL3 Interface
[36]	10033065	B	Software Manual for WEPS-900 HP Series CANopen CiA-443 Interface
[37]	10033584	C	Safety Manual WEPS-900 Series HP CANopen SIL3
[38]	SIIS_RP	01	Subsea Instrumentation Interface Standardisation (SIIS) Recommended Practice
[39]	10229667	01	Software Manual WEPS-300 Series CANopen CiA-443

4 PACKING AND TRANSPORTATION

Avoid excessive shock and vibrations during transport and handling, even though the equipment itself is resistant towards shock and vibration, this is only true when the units are properly fixed and secured.

A special transport case is prepared for packing, storing and transport of the subsea sensor. We strongly advise that the unit is kept secured in this box until the final installation destination is reached.

The transportation case must be in its upright position at all times (see marking on the case).

The weight of the subsea sensor makes a dangerous combination if the transportation cases is handled roughly (dropped, turned from upright positions etc).

Storage temperature limits are defined as -40 to +70°C, however it is recommended to store the subsea sensors at room temperature if possible. Humidity control is not required.

Note: For further information regarding packing, handling and storage specifications, see ref. [6].

5 HEALTH AND SAFETY STATEMENTS

It is recommended that the client performs a risk Assessment for all aspects of the sensor Installation from initial delivery to final dispatch, to identify the hazards associated with the work.

Each Sensor unit weighs between 10 to 55 Kgs. Those staff preparing to move a sensor unit from the delivery box must ensure that they assess the identified hazards for each movement of the sensor.

Sensors with large flanges such as 3 1/16" 15K or 2 1/16" 20K are provided with dedicated threaded holes on the flange edge for eyebolts. Eyebolts are not Siemens Energy scope of supply, however Siemens Energy insist that only suitably rated and approved eyebolts are used.

Manual handling by an individual at this weight should be avoided at all times. Suitable mechanical lifting aids should be used to avoid musculoskeletal damage to the operator.



Personal Protective Equipment in the form of:

- Safety Shoes/ Boots
- Protective Gloves

Is highly recommended for the protection of staff whilst working with Sensors. Additional PPE may be required for the working environment / Client Safety Rules

The sensors do not contain any chemicals or compositions that could be hazardous upon exposure.

During soldering operations it is recommended that fumes are removed from the immediate working area to avoid inhalation by the operator.

	<p>Any soldering shall not take place unless the soldering procedure and/or soldering company have the appropriate skills and are approved by Siemens Energy.</p>
	<p>Care in the selection of the correct tools for the final "Torque Setting of the API Bolts" is important to avoid accidents through damaged/poorly maintained tooling.</p> <p>See API 6A ref. [4]</p>

6 INSTALLATION


6.1 INSTALLATION INSTRUCTIONS

CAUTION: **UNLESS THE SUBSEA SENSOR IS WITHIN ITS
TRANSPORT CASES/CRADLE IT SHALL
ONLY BE HANDLED BY PERSONNEL
AUTHORISED BY THE CLIENT.**

**INSTALLATION SHALL ONLY BE
UNDERTAKEN BY PERSONNEL
AUTHORISED BY THE CLIENT.**

**HANDLE THE SUBSEA SENSOR WITH CARE -
HEAVY SHOCK AND/OR VIBRATIONS, HIGH
TEMPERATURES MAY DAMAGE THE UNIT.**

6.2 MECHANICAL INTERFACE



Never use air tools when fixing the remote seal- and main body bolts.
Also avoid other types of shock and vibration impact.

The Subsea Sensor shall be installed with BX Ring in accordance with the respective mechanical interface drawing for the Subsea Sensor.

Available flanges according to API 6A, ref. [4]:

- 2 1/16", 5k PSI, BX-152, 8 bolt.
- 2 1/16", 10k PSI, BX-152, 8 bolt.
- 1 13/16", 5k PSI, BX-151, 8 bolt.
- 1 13/16", 10k PSI, BX-151, 8 bolt.
- 2 1/16", 15k PSI, BX-152, 8 bolt.
- 3 1/16", 10k PSI, BX-154, 8 bolt.

In addition following flange alternatives:

- 1 11/16", 10k PSI, BX-150, 4 bolt.
- 1 11/16", 15k PSI, BX-150, 6 bolt.
- 2 1/16", 15k PSI, BX-152, 10 bolt.
- 2 1/16", 20k PSI, BX-152, 10 bolt.

Nuts and bolts used for installation : According to clients specifications.

Material : According to clients specifications.


Torque Settings : According to Clients specifications.

No requirements regarding orientation.

All surfaces shall be cleaned and inspected for damage before installation.


Nuts, bolts and gaskets are not part of Siemens Energy delivery, however sensors are designed to be used with nuts, bolts and gaskets according to API 6A ref. [4].

7 INSULATION RESISTANCE TESTING

	<p>Insulation Resistance Test: Test voltage shall never exceed 50 VDC.</p>
-----------------------------------------------------------------------------------	---------------------------------------------------------------------------------

If there is a need to conduct insulation resistance testing of the sensor on site, the following best practice routine is to be followed.


1. Hook up the EUT as per the sketch below.



2. Connect the insulation tester with the negative terminal to the metallic body of the sensor. Connect all pins to the insulation tester positive terminal.
3. Measure the insulation resistance at 50VDC @ dry conditions for 1 minute.
4. If the insulation resistance value is below the acceptance criteria, contact Siemens Energy for further assistance.

Acceptance Criteria: $IR \geq 1\text{Gohm}$

8 WELDING




Always ensure sensor is removed from the structure or grounded before commencing any welding.

At any time during any type of welding operations in the vicinity of the sensor, the sensor needs to be removed from the structure being welded entirely or grounded.

Best practice for grounding the sensor is:

8.1 NO FLYING LEADS

For sensors supplied with no flying leads the sensor is grounded by spring between the pins and the sensor housing. This spring is supplied and mounted by Siemens Energy before shipping. The picture below shows a spring mounted onto a four pin penetrator with no flying leads. The same spring can be used for sensors supplied with 8-pin penetrators.



8.2 HOW TO GROUND FLYING LEADS

Remove the isolation from the end of the leads, as demonstrated in picture below. About 1cm should be sufficient.



Figure 1: Example of flying leads with isolation removed at ends.

Wind a steel wire around (max) four flying leads at a time. The steel wire mounted onto the flying leads and supplied by Siemens Energy before shipping can be used for this.



Figure 2: Steel wire ready to be winded around set of four flying leads.




Figure 3: Example of steel wire wound around a set of four flying leads.

Use the same steel wire to ground several sets of four (or less) flying leads. This is demonstrated in picture below.




Figure 4: Example of steel wire wound around several sets of four flying leads.

Note: It is also possible to use phoenix connectors to ground flying leads. The leads are then assembled to the phoenix connector. A steel wire is used to connect all leads inside the connector and then connected to metal part of sensor as demonstrated below.




Figure 5: Example of grounding using phoenix connector.

The sensor is grounded when all the flying leads are in contact with a steel part of the sensor. Best practise is to use a clamping tool as demonstrated in the picture below. The steel wire which is in contact with all flying leads is wound around the clamp to ensure contact with steel part of sensor.



Figure 6: Example of how to ensure flying lead contact with steel part of sensor. Steel wire clamped to housing.




Figure 7: Example of how to ensure flying lead contact with steel part of sensor. Steel wire clamped to flange.

Test connectors with flying leads are grounded in the same manner.



Figure 8: Example of test connector – grounded using phoenix connectors

8.3 SENSORS WITH FLYING LEADS

All flying leads must be grounded before welding can start. Please refer to chapter 8.2 for information on how to ground flying leads.




Figure 9: Sketch demonstrating grounding of all pins.

8.4 SENSOR SUPPLIED WITH CONNECTOR

For sensors supplied with connector best practice is to use a test connector with flying leads. The flying leads are then grounded. Please refer to chapter 8.2 for information on how to ground flying leads.





Figure 10: Sketch demonstrating grounding of sensor using test connector.

8.5 SENSOR HARNESS



Sensor harness, both 1 leg and multiple leg harness must be grounded using test connectors. Please refer to chapter 8.2 for information on how to ground flying leads and test connector.




Figure 11: Sketch demonstrating grounding of sensor 1 leg jumper harness using test connector.





Figure 12: Sketch demonstrating grounding of sensor multiple leg jumper harness using test connectors.

9 PAINTING ON STRUCTURE



Always ensure sensor is removed from the structure or grounded before commencing any blasting.

If the sensor is supplied un-painted, the sensor can be prepared and painted along with the host structure. During surface preparation, e.g. blasting, Pin Hole Tests or other test methods that utilising an electrical method, the sensor needs to be grounded as described in section 8.

Special consideration should be taken towards masking of the electrical connector.

10 OPERATING INSTRUCTIONS

After installation, check the Subsea Sensor(s) at ambient pressure and/or temperature to verify that the sensor is still functioning properly.

10.1 ANALOGUE SENSORS

The output can be measured by the use of a loop tester. The loop tester should be according to SIIS RP, ref. [38], capable of providing 24 Volt for minimum of 40mA during start up.

Recommended loop tester: Drück UPS III

Note: The Fluke 707 instrument has a current limitation lower than SIIS RP and could prevent the sensor from starting up correctly and cannot be used as an instrument to read this sensor.

The pressure output(s) shall give a mA output according to the calibrated range and the ambient pressure. The temperature output(s) shall give a mA-value corresponding to the calibrated range and the ambient temperature.

The pressure output(s) are calibrated from: MinCalibPress to MaxCalibPress. This is the calibrated sensor range for pressure. See sensor marking.

The temperature output(s) are calibrated from: MinCalibTemp to MaxCalibTemp. This is the calibrated sensor range for temperature. See sensor marking.

The conversion from mA to engineering units such as Bara and deg C is as follows:

Pressure = $\{(m\text{Value} - 4) * ((\text{MaxCalibPress} - \text{MinCalibPress}/16))\} + \text{MinCalibPress}$.

Temp. = $\{(m\text{Value} - 4) * ((\text{MaxCalibTemp} - \text{MinCalibTemp})/16)\} + \text{MinCalibTemp}$.

For more details regarding the 4-20 mA interface for WEPS-100 Series of sensors please see the following interface specifications:

- WEPS-100 Series PT: Ref. [31].
- WEPS-100 Series TT: Ref. [32].
- WEPS-100 Series SIL: Ref.[16].
- WEPS-5 FR SIL: Ref. [28].

NOTE:

Regarding SIL rated analogue sensors please see also ch. 10.3 and ch. 11.

10.2 DIGITAL SENSORS

The Subsea sensors will communicate with the supply/receiver circuitry through RS485 (KOS/Modbus/Profibus) protocol or on CANopen.

The sensor signal is transmitted in engineering units. Most often this is in Bara/°C, but sensors can also be delivered with PSI /Fahrenheit on request.

After installation subsea, the signal from the subsea sensor will form a part of the client's main system, and all operational instructions should be according to the client's procedures.

10.2.1 RS485 Modbus

The master unit can start communication with the sensor 5 seconds after power up. The master needs to send request to the sensor, then it will transmit messages with sensor data in return.

The electrical interface between the master and the sensor is based on the RS485 standard.

The format of each byte in RTU mode is:

Interface	:	RS485 (two-wire)
Baud rate	:	default 1200 (2400, 4800, 9600, 19200 and 38400 is available)
Coding system	:	8-bit binary
Number of start bits	:	1
Data bits	:	8
Parity	:	No
Stop bits	:	1 (2 stop bit is available on request)
Error checking	:	CRC

For more details regarding the Modbus interface, please see the corresponding interface specification:

- WEPS-100 Series Modbus: Ref. [9].
- WEPS-600 Series Modbus: Ref. [12].

10.2.2 RS485 PROFIBUS

The electrical interface between the master and the sensor is based on the Profibus DP standard, EN 50170.

Interface	:	RS485 (two-wire)
Baud rate	:	Auto (9600 or 19200)
Address	:	2 to 125

For more details regarding the Profibus interface, please see the corresponding interface specifications:

- Weps-2 and Weps-25 Profibus : Ref.[22].
- Weps-3 Profibus : Ref.[23].

10.2.3 RS485 KOS

After power up, the sensor starts transmitting messages within 5 seconds. The protocol is unidirectional.

Messages are sent from the sensor when new measurements are ready, twice a second.

The electrical interface between the master and the sensor is based on the RS485 standard, optional RS422.

Interface	:	RS485 (two-wire)
Baud rate	:	1200
Coding system	:	8-bit binary
Number of start bits	:	1
Data bits	:	8
Parity	:	No
Stop bits	:	1
Error checking	:	Checksum

For more details regarding the KOS interface, please see the corresponding interface specifications:

- WEPS-100 Series RS485 KOS : Ref. [10].
- Other Sensors with RS485 KOS : Ref. [18].

10.2.4 CANopen

The sensor can be configured before delivery to support two different device profiles: CiA-401 or CiA-443.

Device Profile 401

If the sensor is configured for device profile 401, ref.[2], the sensor enters the application and NMT pre-operational mode after power-on. In pre-operational mode, the sensor application starts to read and calculate process values (typically pressure and temperature). When the sensor receives the “NMT start command” it will enter NMT state operational (if no failures detected). After the start command is received the sensor will start to transmit process data according to the transmission type and configuration.

Process measurements are transmitted periodically (according to configuration) by the means of PDO, using transmission type 254. It is possible to use SYNC transmission 1-240. See CiA-301, ref.[3].

For more details regarding the sensor interface, please see the corresponding interface specifications:

- WEPS-100 Series with CiA-401 : Ref. [13].
- WEPS-6153 CiA-401 : Ref. [8].
- WEPS-6122 CiA-401 : Ref. [11].
- WEPS-6152 CiA-401 : Ref. [11].
- WEPS-612 CiA-401 : Ref. [25].
- WEPS-615 CiA-401 : Ref. [25].
- WEPS-6121 CiA-401 : Ref. [20].
- WEPS-6151 CiA-401 : Ref. [20].
- Other sensors with CiA-401 : Ref. [7].

Device Profile 443

If the sensor is configured for device profile 443, ref.[1], the sensor stays in boot loader program and enters NMT pre-operational mode after power-on.

In the boot loader program only the LSS layer and some dictionary objects are implemented. Process measurements and PDO are not implemented; hence setting the boot loader program in NMT operational mode makes no sense.

The application is started by using the dictionary object 1F51h Program Control, writing 1 to sub-index 1.

The application will then start up in NMT pre-operational mode and the sensor starts to read and calculate process values (typically pressure and temperature). When the sensor receives the NMT start command it will enter NMT operational mode (if no failures detected).

After the start command is received the sensor will start to transmit process data according to the transmission type and configuration.

Process measurements are transmitted continuously (according to configuration) by the means of PDO using transmission type 255. It is possible to use SYNC transmission 1-240, or transmission type 254.

Interface	:	CANopen (two-wire)
Baud rate	:	CANopen FT: 50 (default) and 125kbit CANopen HS: 10, 20, 50 (default) 125 and 250kbit

For more details regarding the sensor interface, please see the corresponding interface specifications or user manual:

- WEPS-300 Series with CiA-443 : Ref. [13].
- WEPS-100 Series with CiA-443 : Ref. [13].
- WADS with CiA-443 : Ref. [14].
- WEPS-25 with CiA-443 v.1 : Ref. [17].
- WEPS-25 with CiA-443 v.2 : Ref. [15].
- WEPS-3 with CiA-443 : Ref. [24].
- WEPS-95 with CiA-443 : Ref. [21].
- WEPS-612 CiA-443 : Ref. [19].
- WEPS-615 CiA-443 : Ref. [19].
- WEPS-900 HT Series : Ref. [34].
- WEPS-900 HP Series : Ref. [36].

NOTE:

Regarding SIL rated digital sensors please see ch.10.3 and ch.11.

10.3 SIL RATED SENSORS

SIL is a measure of safety system performance, or probability of failure on demand (PFD) for a SIF or SIS. The higher the SIL level, the lower the probability of failure on demand for the safety system and the better the system performance.

SIEMENS ENERGY SIL 1, SIL 2 and SIL 3 rated sensors are suitable for application in SIL 1, SIL 2 and SIL 3 Safety Instrumented System respectively.

All SIEMENS ENERGY SIL rated sensor are independently certified and approved by certification authority.

Type of communication protocol that is suitable for SIL rated sensor is dependent on type of platform for which sensors have been developed, for example 4-20mA, CAN bus etc.

Please refer to independent sensor's interface specification, software manual or safety manual for SIL rated sensor. This documentation will provide information about communication protocol being used, safe state indication, PFD and SFF etc.

- WEPS-6121 and WEPS-6151 SIL1 : See ref. [26], SRS for details.
- WEPS-6122 and WEPS-6152 SIL2 : See ref. [27], SRS for details.
- WEPS 6153 SIL3 : See ref. [29], SRS for details.
- WEPS-5 Fast Response SIL2 : See ref. [28], SRS for details.
- WEPS-100 Series 4-20 mA SIL3 : See ref. [5], Safety Manual for details.
- WEPS-900 Series HT SIL3 : See ref. [33], Safety Manual for details.
- WEPS-900 Series HP SIL3 : See ref. [37], Safety Manual for details.

11 MAINTENANCE

Before installation, confirm if the Subsea Sensor(s) have been stored for more than six - 6 - months, if so, a test of the sensor signal at ambient pressure and temperature should be carried out. Use of calibrated reference instruments is required to ensure correct test results.

If the result from the test shows any discrepancy ($\geq 1\text{Bar}$ / $\geq 1^\circ\text{C}$) in the sensor signal contact Siemens Energy for further assistance. If required the sensors could be returned to the manufacturer for adjustment or a note should be made of the difference and adjusted on the Company's topside system after installation subsea.

After installation subsea, it will not be possible to carry out any maintenance of the sensor. However, if possible, a periodical test of the sensors should be carried out. At known pressure the signal from the pressure outputs should correspond to the reference pressure. If it is possible to have a known temperature reference, a similar test should be carried out for the temperature outputs. In case of any drift, the sensor signal should be corrected on the topside system. The top side system has to have the facility of an offset adjustment of the sensors to be able to carry out this test.

SIL rated sensors should have proof test on regular basis, ref. Safety Requirement Specification (SRS) or Safety Manual for the specific sensor.

If the structure for any reason should be retrieved after installation, the sensor should be controlled as in section 10, (Operating Instructions) above or returned to the manufacturer for a complete check/recalibration.

Published by

Siemens Energy Global GmbH & Co. KG

Transformation of Industry

Siemenspromenade 9

91058 Erlangen

Germany

For the US Published by

Siemens Energy, Inc.

Transformation of Industry

4400 N Alafaya Trail

Orlando, FL 32826

USA

E-mail: subsea@siemens-energy.com

For more information, please visit our website:

www.siemens-energy.com/subsea

Subject to changes and errors. The information given in this document only contains general descriptions and/or performance features which may not always specifically reflect those described, or which may undergo modification in the course of future development of the products. The requested performance features are binding only when they are expressly agreed upon in the concluded contract.

Siemens Energy is a trademark licensed by Siemens AG