

ChassisSim Lite Quick Start

Introduction.....	3
The Purpose of race car simulation.....	3
Directory organization and ChassisSim files	3
Setting up your Model for the first time.	6
<i>Step 1 – Select an appropriate template and save the car model.</i>	<i>7</i>
<i>Step -2: Selecting Springs.</i>	<i>8</i>
<i>Step-3: Selecting Roll bars</i>	<i>10</i>
<i>Step-4: Entering mass, wb, track and Inertia Characteristics</i>	<i>11</i>
<i>Step-5: Suspension Geometry.....</i>	<i>13</i>
<i>Step 6 – Entering Aero characteristics</i>	<i>14</i>
<i>Step 7 – Entering tyre information.....</i>	<i>16</i>
<i>Step 8 – Entering the engine properties.....</i>	<i>17</i>
<i>Step 9: Entering the gear ratios.....</i>	<i>18</i>
<i>Step 10: Entering motion ratios.....</i>	<i>19</i>
Running your first Simulation.	19

Introduction

Congratulations on your purchase of ChassisSim lite. ChassisSim lite will become an indispensable tool as you seek to understand your race car and deduce the best possible setup for your race car.

The purpose of this manual is to show you what to do to get up and going with ChassisSim lite. This manual will show you how to get going with ChassisSim from a blank piece of paper to a fully functional car model. It is a step by step process that the reader can work through at their own pace. However it is presented in sequential order and the reader is advised to keep this order in place.

After working through this guide the user should have a model they can readily use to start evaluating setups.

The Purpose of race car simulation

Before starting on race car simulation it would be appropriate to discuss what we are trying to do with our race car simulator.

Our goal in race car simulation is to create a representative environment that we can run virtual test sessions with our car. What ChassisSim will return is the perfect simulated lap as if the perfect race driver has been piloting your car. The results can be viewed in either the ChassisSim viewer or they can be exported to a logger of your choice and compared against actual data or reviewed as a virtual test session in its own right.

Your goal when creating a simulation is to ensure everything the car does on the track is replicated on the simulator. Initially this may mean a sacrifice of some accuracy in the corners. This is perfectly ok and a natural part of the process. As you gain more experience in using ChassisSim and the vehicle modeling process this will sort itself out in time.

Also remember that ChassisSim is a tool and not a magic wand. Always review simulated data critically and view it as testing. Don't just take things at face value. If you use ChassisSim this way it will become an indispensable element of your race engineering toolbox.

Directory organization and ChassisSim files

The first step in starting to use ChassisSim is to understand what the various ChassisSim files are and what they actually do. To this end the following summary is presented in Table 1,

Table – 1 – ChassisSim files

File Type	File extension	Description
ChassisSim car file	*.car	This stores your setup, and all the car modeling parameters such as tyres, aero and suspension geometry
ChassisSim template	*.ini	This stores the selection of springs and bars that relate to your car.
Curvature file	*.txt	This is the curvature file or the path the car takes around the circuit. This is typically prefixed by tr_mycircuitname.txt
Bump Profile	*.dat	This is the bump profile that represents all the road undulations for all 4 corners of the car. This is typically prefixed by the following convention bump_profile_mycircuitname.dat

The two major file types I want to touch on is the ChassisSim car file and template files.

The ChassisSim car file stores your specific setup. Think of a ChassisSim car file as a word processing document. A ChassisSim car file contains the specific setup you are working on and the model it pertains to. Consequently to save a setup and you go to File->Save As and save it as a car file. This stores your specific setup.

To store your car files I would recommend the following directory structure as Illustrated in Fig-1,




Fig-1 – Suggested Directory structure

Typically the suggested convention is,
C:\ChassisSim Technologies\Models\My Car Name\Circuit Name.

While this may seem long winded we have found this to be a reliable and almost fool proof method of storing your models.

The ChassisSim template is an ini file that is located in the ChassisSim version directory. When you select a ChassisSim template by going to the right hand side of the screen and selecting the car drop down box it does the following,

- Loads a car file that pertains to a particular car.
- Loads all the spring, bar, geometry and aero options that relate to that car.

For those of you who have had your modeling down for you, you just select the name of your car. You are then in a position of selecting your setup from the drop down menu items when you change a particular aspect of the setup. When you have selected all aspects of your setup to save it you simply go to File->Save As and save it in the appropriate directory as illustrated in Fig-1.

So how do you retrieve a setup you have just been working on? You perform the following tasks,

1. Open ChassisSim (obviously if ChassisSim is open you skip this bit).
2. Select the relevant template that most closely resembles your race car.

3. Go to File->Open, navigate to the appropriate directory (as shown in Fig-1) and select your car file.

It's as straight forward as that!


Setting up your Model for the first time.

To start your model for the first time this is what we will be doing,

- Selecting the most appropriate template that most resembles your car.
- Save the car file in an appropriate location as illustrated in Fig-1.
- We modify each element and save as we go.

For the purpose of illustration we are going to setup a F3 car. In particular it will be a Dallara F310 car. Don't worry if this is not your car. The techniques that will be discussed here will be identical to what you'll use for your car.

The other thing I would advise you to do is to setup the units you want to save the car model parameters in. This is accessed in View -> Select Units to use. This will display the following dialog and you simply select the units you desire.




The image shows a 'Unit Selection Dialog' window with a list of parameters and their corresponding units in dropdown menus. The parameters and units are as follows:

Parameter	Unit
Spring Rate:	Pounds force per inch (lbf/in)
Spring/Damper/Bump rubber Length:	Millimetre (mm)
Spring/Damper/Bump rubber Force:	Newtons (N)
Suspension geometry length	MilliMetres (mm)
Ride Height Length:	MilliMetres (mm)
Mass/Corner Weight:	Kilogram (kg)
Track/wheelbase/cg height:	Metre (m)
Tyre Temperature:	Celsius (deg C)
Tyre radius:	Metre (m)
Tyre Pressure:	Pounds per square inch (Psi)
Tyre Load/Force:	Kilogram/kgf (kg/kgf)
Aero Force:	Pounds/lbf (lb/lbf)

At the bottom of the dialog are two buttons: 'OK' and 'Cancel'.

Step 1 – Select an appropriate template and save the car model.

This is done by going to the right hand side of the ChassisSim screen and clicking on the car menu. This will present a list of cars you can choose from. This process is illustrated in Fig-2.



This will bring up this Dialog




Fig-2 – Selecting a car template

When this is selected the Car drop down box will show Dallara F310. When this has been selected we'll now save the model. To do this, go to File->Save As and we'll save this in the same directory as we created in Fig – 1. This process is illustrated in Fig-3,




Fig-3 – Saving the base car file.

Step -2: Selecting Springs.

The next step is to select the springs. To do this click on the front spring on the car picture or the Front spring drop down box on the front of the car. This will display the following dialog,




Fig – 4 – Spring Dialog.

To enter the spring rate the user has two options. They can select from the list of springs on the left hand side. Alternatively the user can type in the spring rate they desire on the edit control next to spring rate. The pre load on the spring is entered in the edit control next to the spring rate. Note the units for both of these can be changed by going into the view menu and selecting View->Select Units to use.

To enter damper data the user has a number of options,

- Click on the damper control and edit the numbers manually. Please ensure the slider controls tab is switched off as illustrated.
- Import an ascii file with damper information. This is detailed in the ChassisSim help.
- Click on the slider control and specify the bypass between low and high speed. The changes will be reflected in the control.

If you are using bump rubbers click on the bump rubber tab. The following dialog will be shown,




Fig-5 – Bump rubber dialog.

You will notice that the packer gaps are specified as an air gap. If your setup sheet has this specified as a ground gap, click on the tab that says click on here to enter as Ground gap. You enter the ground gap here and click on OK.

You have two options for entering the bump rubber. The first as illustrated in Fig-5 is to enter the numbers as a lookup table. Please note an origin of 0,0 is assumed. These can be exported out to file, or re imported back in. The format for this can be found in the ChassisSim help. Alternatively the Lookup table tab can be unclicked and a single spring rate is specified.

Once you have done this click OK on the bump rubber dialog and click OK to apply the spring settings. When you are done Go to File->Save and this will save the changes.

Step-3: Selecting Roll bars

To select Roll bar either click on the front roll bar image on the left hand side or on the right hand side of the screen select the front roll bar drop down box on the right hand side. This will display the following dialog,




Fig-6: Roll bar input dialog.

You have two options. If your particular car template is loaded you can just choose from the available list of bars.

If the your roll bar rate is not there click on the tab that says "Click here to enter bar rate directly" This will display the following dialog,




Fig-7: Directly entering spring rates.

You enter your bar rate in either N/m, N/mm or lbf/in depending on the units you selected. Press OK on both dialogs and choose File->Save.

Step-4: Entering mass, wb, track and Inertia Characteristics

To enter the mass, wheelbase, track and Inertial characteristics you either click on the cockpit (open wheeler picture) or roof of the car (Touring car picture) or the mass drop down box on the right hand side. This will display the following dialog,

Parameter	Value
mt	550
umf	44
umr	50
wb	2.73
tf	1.585
tr	1.535
Ix	50
Iy	250
Iz	550
height	0.3
Front rh	18
Rear rh	31
wdf	0.41
wd left	0.5

Fig-8 – Inertial dialog

As can be seen from Fig 8 all you need to do is enter the relevant entries. The units these are entered in are selected in View->Select units to use. The inertias I_x , I_y and I_z are entered in kgm^2 .

Most of the entries are very straightforward. The main ones to focus on are,

- mt – total car mass
- umf and umr – Total unsprung weight for the front and rear respectively.
- wb – wheelbase, tf and tr – Front and rear track respectively.
- wdf – Total weight distribution on the front axle.
- Height – This is the total c.g height and Front rh and Rear rh is the front and rear ride height of the setup this centre of gravity height corresponds to.

The entries that take create the most confusion is the c.g height and moments of inertia. A rough guide to c.g height is presented below,

Table-1 – Approximate c.g heights

Car Type	c.g height
Open Wheeler/Sports prototype	0.3m
GT car	0.35 – 0.45m
Touring car	0.5m
Road car	0.55 – 0.6m

A rough guide to inertias are presented in Table 2,

Table-2 – Approximate Inertias

Car	I_x (kgm ²)	I_y (kgm ²)	I_z (kgm ²)
Formula Ford	100	300	500
F3	150	400	600
GP2/IRL	200	800	1200
V8 Supercar/NASCAR	400	1300	2500

Step-5: Suspension Geometry

To adjust the suspension geometry click on either the front or rear wishbone/ or live rear axle picture. This will bring up the following dialog,




Fig-9: Lite suspension dialog.

If the template pertains to your car you simply select from the list and press OK. If the geometry is not covered in the list press Edit Config tab. This brings up the following dialog,

Suspension Interface

Rear geometry

Suspension Type: Double Wishbone Suspension end: Rear

	x (m)	y (m)	z (m)
Point 1	2.319	0.1525	0.214
Point 2	2.612	0.129	0.19
Point 3	2.648	0.676	0.202
Point 4	2.482	0.124	0.328
Point 5	2.889	0.09	0.324
Point 6	2.707	0.6165	0.405

Results:

- Roll Centre: 0.052 m
- Anti Dive: 64.0% anti-dive
- Anti squat: 10.9% anti-squat

Diagram: DATUM: Front axle of car on centreline.

Ride Height geometry is measured at: 0.0350000

Pitch centre (anti-dive): 0.1918700

Pitch centre (anti-squat): 0.0327019

Fixed Roll centre properties:

Roll centre flag (0-free, 1-fixed): 0 Fixed Roll centre value: 0.0693359

Buttons: Analyse configuration, Apply Calc, OK, Cancel, Export Settings, Import Settings

Fig-10 – Geometry input

The user manually edits the points and the operation of this dialog is covered in the online help. The user selects OK presses OK on the main dialog and goes File->Save. Note if the geometry hasn't been measured up and you know the roll centre location, as a temporary fix – The roll centre flag can be set to 1.

Step 6 – Entering Aero characteristics

To enter the aero characteristics of the car click on either the front or rear wing or the Wing drop down box on the right hand side. This will bring up the following dialog,




Fig-11 – Entering Wing settings

If the template directly relates to your car all you need to do is choose from the drop down list.

If your wing setting isn't in the drop down list, click on the tab that says Click here to edit Aero values directly. This will bring up the following dialog,




Fig-12: Downforce, drag and aero balance calculator

There are two sections to fill in. The first is you enter a reference condition this can pertain to your current wing configuration or some other reference. Downforce and drag are entered as forces for a given front and rear ride height and a reference speed. Aero balance is entered as a percentage at the reference condition. Then in the delta's you put the delta front downforce, delta rear downforce and delta drag forces that pertain to your wing setting. In this case we have put the reference as our current configuration because all the deltas are zero.

Step 7 – Entering tyre information.

To enter the tyre information either click on the tyres or click on the drop down box on the right hand side that says Front or rear tyres. This will bring up the following dialog,

The screenshot shows the 'Tyre Properties v3' dialog box. It features a dropdown menu at the top set to 'Front tyre'. The main area contains several input fields and buttons. The 'Tyre Settings' section has 'Neg Camber' (3), 'Castor' (9), and 'Toe (deg)' (0.2845828). The 'Tyre Global grip factors' section has 'Tyre Force Grip factor' (0.9). Below these are three buttons: 'Click here if you want to enter toe in mm', 'Click here for Tyre Model Quick Edit/Start', and 'Import v3 ascii tyre file/opt tyre results'. The 'Friction and rolling radius' section has 'Friction Drag' (0) and 'Tyre radius' (0.2865000). The 'Initial Tyre Settings' section has 'Tyre Press' (20.000289) and 'Tyre Temp' (19.999991). At the bottom are 'OK' and 'Cancel' buttons.

Fig-13: Tyre Properties dialog.

Cambers and castors are entered in deg. Note Negative camber is set as positive. Toe is entered as degrees. If you want to enter toe in mm, click on the tab that says "Click here if you want to enter toe in mm."

Tyre radius is entered in the appropriate edit control. Note this is the rolling tyre radius.

The tyre pressure and baseline tyre temperature is entered in the relevant tab. Note the baseline Tyre temp represents the tyre temperature as measured when coming into the pits. If in doubt, leave at the default settings.

Apply your changes and press on OK and save the car file.

Step 8 – Entering the engine properties.

To enter the engine parameters click on the engine graphic on the car. This will bring up the following dialog,




Fig-14: Engine Property dialog.

The critical thing to note is the engine curve and max RPM or redline.

The horsepower curve is the 100% throttle curve of power in kW vs RPM. This is entered by clicking on the control and using the left and right arrow keys to move the curve around. If in doubt the Engine brake parameters should be left at zero.

Modify this to your needs press OK and go to File->Save.

Step 9: Entering the gear ratios.

To enter gear ratios either click on the bell crank (open wheeler picture) or the gearbox graphic on the open wheeler picture. This will bring up the following graphic,

Gearbox Parameters

G/Box Properties

Torque split (0 RWD, 1 FWD)

Front diff type No of ratios

Rear diff type

Gear Ratios

1st	<input type="text" value="8.264"/>	6th	<input type="text" value="3.131"/>
2nd	<input type="text" value="6.422"/>	7th	<input type="text" value="0"/>
3rd	<input type="text" value="5.099"/>	8th	<input type="text" value="0"/>
4th	<input type="text" value="4.167"/>	9th	<input type="text" value="0"/>
5th	<input type="text" value="3.5417"/>	10th	<input type="text" value="0"/>

NOTE: Gear ratios are entered as RPM/w/speed
For further details refer to the manual.

☐ Use up and down shift points for each gear.

☐ Use upshift and downshift time delays.


Fig-15 Gear ratio graphic

Gear ratios are entered as the ratio of Engine speed/wheel speed. Effectively it is a torque multiplier. It is effectively the inverse of the current ratio multiplied by the final drive ratio.

The documentation for all of the gearbox controls can be found in the ChassisSim online help within the software.

Step 10: Entering motion ratios

If the currently selected template matches your car then this step can be omitted. If it hasn't all you need to do is click on the bell crank of the car picture. This will bring up the following dialog,




The image shows a 'Motion Ratio' dialog box with a title bar containing a close button (X). Inside the dialog, there is a tab labeled 'Front MR'. At the top right are 'OK' and 'Cancel' buttons. The dialog is divided into three columns: 'Main spring', 'Third spring', and 'Roll bar'. Each column contains five input fields labeled '1st order' through '5th order'. The values entered are: Main spring (1st: 0.8842, 2nd: 0, 3rd: 0, 4th: 0, 5th: 0), Third spring (1st: 0.868, 2nd: 0, 3rd: 0, 4th: 0, 5th: 0), and Roll bar (1st: 1, 2nd: 0, 3rd: 0, 4th: 0, 5th: 0).

Component	1st order	2nd order	3rd order	4th order	5th order
Main spring	0.8842	0	0	0	0
Third spring	0.868	0	0	0	0
Roll bar	1	0	0	0	0

Motion ratios are plotted as Damper Movement/wheel movement. Please note most race car manuals have it the other way around so take the inverse of it. Also to start off with stick with a linear ratio as illustrated above.

Running your first Simulation.

To run your first simulation Select a circuit from the available drop down list on the right hand side of the screen. This is illustrated in Fig 16



This will display the following dialog




Fig-16 – Selecting a circuit from the Drop down menu.

As illustrated select Eastern Creek.

The next step is to record this to data. Go to Simulate->Data logging options this will display the following over leaf. As you can see for the purposes of illustration we are logging the file to Motec Interpreter. As you can see we specify the car and circuit name and the comment we wish to log this too.

You can also see we have specified a file location for the log file. This can be specified in any direction the user wishes by clicking on the tab that says Data File output name. This brings up a windows file save dialog where you can specify where you want the data file.

Data Logging Options

Data logging switch
Log data for this run (1-Yes, 0-No)

Output Platform
PI (1) / Matlab (2) / Data Viewer (3) / Motec (4) / Bosch (5) / Pi Toolbox (6) / Magnetti Marelli - ZTX (7) / Atlas csv format (9)
☒ Use Motec Interpreter format

Data file output options
Car Name
Circuit
Short comment
Long comment

Data File Output Name

Setup Channel Names (Marelli, Bosch and Pi Toolbox)

Data Output options

OK
Cancel

Fig 17: Data logging options

Once this is completed you are ready to run your first simulation. To do this you go to Simulate->Simulate or click on the Start button on the main screen. This will bring up the simulation window. To commence the simulation you click on the Start simulation tab. This will start the simulation. When it is completed you will see the lap time reflected. Congratulations you have just run your first simulation!

Now that we have this our next steps from here will be the following,

- Creating the monster file. This is covered in CSim_creating_monster_file.pdf.
- We then match the baseline model to your data. This is covered in CSim_modelling_in_minutes.pdf.
- Lastly we will show you how to create a track map – This is covered in CSim_track_creation_lite.pdf.