

# Usbgeneralpage



## Linux USB Configuration


Linux PSP

### USB Driver

## Introduction

### Linux USB Stack Architecture

Linux usb stack is an layered architecture in which musb controller hardware is at the lowest layer. The musb controller driver abstract the musb controller hardware to linux usb stack.



This page being common across all TI platforms describes the configuration of USB in linux menuconfig. Specific sections will be used for different platform to mention the differences with other platform.

## Driver configuration

The MUSB OTG controller can be used in Host only, Peripheral(Gadget) only or OTG (both host and device) modes. The following section shows the configuration options for USB and its associated class drivers.

### To configure the USB Driver Features through menuconfig

Use menuconfig to configure the USB driver features supported in kernel.

```
make ARCH=arm CROSS_COMPILE=arm-none-linux-gnueabi- menuconfig
```

Goto Menuconfig->Device Drivers

```
Device Drivers --->
....
[ ] HID Devices --->
[*] USB support --->
....
```

#### TI81XX/AM38XX/TI811X EVM default configuration

By default the usb host mode configuration is selected in default evm defconfig is available for DM816X and DM814X. The user can chose default evm defconfig by running

for TI816X

```
# make ARCH=arm CROSS_COMPILE=arm-none-linux-gnueabi- ti8168_evm_defconfig
```

for TI814X

```
# make ARCH=arm CROSS_COMPILE=arm-none-linux-gnueabi- ti8148_evm_defconfig
```

for TI811X

```
# make ARCH=arm CROSS_COMPILE=arm-none-linux-gnueabi- ti811x_evm_defconfig
```

### USB phy selection for MUSB OTG port

Please select NOP USB transceiver for MUSB support on all platform except Beagle or Beagle-XM which uses USB phy on TPS65950 (aka TWL4030).

```
Device Drivers --->
USB support --->
*** OTG and related infrastructure ***
[ ] GPIO based peripheral-only VBUS sensing 'transceiver'
[ ] Philips ISP1301 with OMAP OTG
[ ] TWL4030 USB Transceiver Driver
[*] NOP USB Transceiver Driver
```

## USB controller in host mode

### TI81XX/TI811X

In host only mode configuration, by default both ports usb0/usb1 are configured for host mode.

#### MUSB OTG Host Configuration

```
Device Drivers --->
USB support --->
<*> Support for Host-side USB
    *** Miscellaneous USB options ***
[*] USB device filesystem
[*] USB device class-devices (DEPRECATED)
    *** USB Host Controller Drivers ***
<*>   Inventra Highspeed Dual Role Controller (TI, ADI, ...)
    *** Platform Glue Layer ***
    < >   TUSB6010
    < >   OMAP2430 and onwards
    < >   AM35x
    <*>   TI81XX
        TI816X usb connector's ID pin control (from software setting) --->
        Driver Mode (USB Host) --->
    [ ]   Disable DMA (always use PIO)
    [*]   Enable debugging messages
```

- To enable musb driver in PIO mode, select

```
[*] Disable DMA (always use PIO)
```

- To enable musb driver in DMA mode, unselect

```
[ ] Disable DMA (always use PIO)
```

Note: for DM816X you need to select usb-id pin configuration as mentioned in usb-id configuration section <sup>[1]</sup>.

#### USB-ID pin configuration selection for TI81XX

The DM816X silicon includes the USB-ID configuration changes, where USB-ID can be controlled only through

1. software controlled

To select software controlled USB-ID configuration (applicable for TI816X and TI814x PG1.x revision only)

```
Menuconfig->Device Drivers->USB Support
.....
<*>   Inventra Highspeed Dual Role Controller (TI, ADI, ...)
        *** Platform Glue Layer ***
    < >   TUSB6010
    < >   OMAP2430 and onwards
    < >   AM35x
    <*>   TI81XX
        TI816X usb connector's ID pin control (from software setting) --->
```

To select USB-ID configuration from external connector (**applicable for TI814X PG2.x/TI811X**)

```

Menuconfig->Device Drivers->USB Support

.....
<*>  Inventra Highspeed Dual Role Controller (TI, ADI, ...)
      *** Platform Glue Layer ***
< >   TUSB6010
< >   OMAP2430 and onwards
< >   AM35x
<*>   TI81XX
      TI816X usb connector's ID pin control (from usb connector)  --->

```

## OMAP35x/AM35x/AM37x/AM45x

### MUSB OTG Host Configuration

```

Device Drivers --->
USB support --->
<*> Support for Host-side USB
      *** Miscellaneous USB options ***
[*] USB device filesystem
[*] USB device class-devices (DEPRECATED)
      *** USB Host Controller Drivers ***
<*> Inventra Highspeed Dual Role Controller (TI, ADI, ...)
      *** Platform Glue Layer ***
<>   TUSB6010
<*>   OMAP2430 and onwards
<>   AM35x
      Driver Mode (USB Host) --->
[ ] Disable DMA (always use PIO)
[*] Use System DMA for Mentor DMA workaround
[*] Enable debugging messages

```

- Please enable "Use System DMA for Mentor DMA workaround" on OMAP35x/AM37x as a workaround to Mentor DMA issues.
- Select AM35x for AM35x based platforms

```

[ ] TUSB6010
[ ] OMAP2430 and onwards
[*] AM35x

```

- To enable musb driver in PIO mode, select

```

[*] Disable DMA (always use PIO)

```

- To enable musb driver in DMA mode, unselect

```

[ ] Disable DMA (always use PIO)

```

### EHCI Configuration (Not supported for TI81XX/TI811X)

```
Device Drivers --->
USB support --->
<*> Support for Host-side USB
    *** Miscellaneous USB options ***
[*] USB device filesystem
[*] USB device class-devices (DEPRECATED)
<*> EHCI HCD (USB2.0) Support
[ ] Root hub transaction translators
[*] Improved Transaction Translator scheduling
    *** USB Host Controller Drivers ***
```

## MUSB controller in gadget mode

### TI81XX/TI811X

In USB Gadget only configuration, only the usb0 port of TI816x/TI814x/TI813x/TI811x is configured for USB Gadget/Device Mode, usb1 port is unused. To enable each port as device/host mode, then you need to chose OTG configuration please refer here <sup>[2]</sup>.

Note: For TI816X you need to select usb-id pin configuration as mentioned in usb-id configuration section <sup>[1]</sup>.

### Configuration

```
Device Drivers --->
USB support --->
    < > Support for Host-side USB
    <*> Inventra Highspeed Dual Role Controller (TI, ADI, ...)
        *** Platform Glue Layer ***
    < > TUSB6010
    < > OMAP2430 and onwards
    < > AM35x
    <*> TI81XX
        Driver Mode (USB Peripheral (gadget stack)) --->
        [ ] Disable DMA (always use PIO)
        [*] Enable debugging messages
            *** NOTE: USB_STORAGE depends on SCSI but BLK_DEV_SD may ***
    <*> USB Gadget Support --->
        *** OTG and related infrastructure ***
    < > GPIO based peripheral-only VBUS sensing 'transceiver'
    [ ] Generic ULPI Transceiver Driver
    -* - NOP USB Transceiver Driver
```

Note: When Inventra HDRC is selected as USB peripheral controller, then must select the Inventra HDRC in "USB Gadget support page" as show below.

```
--- USB Gadget Support
    [ ] Debugging messages (DEVELOPMENT) (NEW)
    [ ] Debugging information files (DEVELOPMENT) (NEW)
    [ ] Debugging information files in debugfs (DEVELOPMENT) (NEW)
```

```
(2) Maximum VBUS Power usage (2-500 mA) (NEW)
USB Peripheral Controller (Inventra HDRC USB Peripheral (TI, ADI, ...)) --->
```

#### For Gadget RNDIS Mode configuration

```
--- USB Gadget Support
USB Peripheral Controller (Inventra HDRC USB Peripheral (TI, ADI, ...)) --->
<*> USB Gadget Drivers (Ethernet Gadget (with CDC Ethernet support)) --->
Ethernet Gadget (with CDC Ethernet support) (NEW)
[*] RNDIS support (NEW)
```

#### For Gadget FileStorage configuration

```
--- USB Gadget Support
USB Peripheral Controller (Inventra HDRC USB Peripheral (TI, ADI, ...)) --->
<M> USB Gadget Drivers
<M> File-backed Storage Gadget
[*] File-backed Storage Gadget testing version
```

Note: when the gadget driver built as modules, the usb gadget driver module are available at /drivers/usb/gadget directory and you need to insert the gadget driver after kernel is booted.

Please make sure that Inventra HDRC is selected as USB peripheral controller which will appear only when "USB Peripheral (gadget stack)" is selected in driver mode as shown below so after selecting Gadget Support go back to driver mode option to select "USB Peripheral (gadget stack)" and then come back again to select Inventra HDRC as USB peripheral controller.

```
--- USB Gadget Support
[ ] Debugging messages (DEVELOPMENT)
[ ] Debugging information files (DEVELOPMENT)
[ ] Debugging information files in debugfs (DEVELOPMENT)
(2) Maximum VBUS Power usage (2-500 mA)
USB Peripheral Controller (Inventra HDRC USB Peripheral (TI, ADI, ...)) --->
<M> USB Gadget Drivers
<M> Gadget Zero (DEVELOPMENT)
[*] HNP Test Device
< > Audio Gadget (EXPERIMENTAL)
<M> Ethernet Gadget (with CDC Ethernet support)
[*] RNDIS support
```

### OMAP35x/AM35x/AM37x/AM45x

Please do not disable support for host side usb as this will disable EHCI host interface also. Gadget option in driver mode will appear only when gadget support is also selected. Please enable gadget support as given below.

```
Device Drivers --->
USB support --->
<*> USB Gadget Support --->
[ ] Debugging messages (DEVELOPMENT)
[ ] Debugging information files (DEVELOPMENT)
[ ] Debugging information files in debugfs (DEVELOPMENT)
(2) Maximum VBUS power usage (2-500mA) NEW
```

```

USB Peripheral Controller (Inventra HDRC Peripheral (TI, ADI, ...)) --->
<M> USB Gadget Drivers
<M> File-backed Storage Gadget

```

Please make sure that Inventra HDRC is selected as USB peripheral controller which will appear only when "USB Peripheral (gadget stack)" is selected in driver mode as shown below so after selecting Gadget Support go back to driver mode option to select "USB Peripheral (gadget stack)" and then come back again to select Inventra HDRC as USB peripheral controller.

```

Device Drivers --->
USB support --->
<*> Support for Host-side USB
    *** Miscellaneous USB options ***
[*] USB device filesystem
[*] USB device class-devices (DEPRECATED)
    *** USB Host Controller Drivers ***
<*> Inventra Highspeed Dual Role Controller (TI, ADI, ...)
    **** Platform Glue Layer ***
<>     TUSB6010
<*>     OMAP2430 and onwards
<>     AM35x
        Driver Mode (USB Peripheral (gadget stack)) --->
[ ] Disable DMA (always use PIO)
[*] Use System DMA for Mentor DMA workaround
[*] Enable debugging messages

```

## MUSB OTG controller in OTG mode

### TI81XX/TI811X

OTG not supported.

### OMAP35x/AM35x/AM37x/AM45x

#### OTG Configuration

Both Host and Gadget driver should be selected for OTG support. If gadget driver is built as module then the host side module will be initialized only after gadget module is inserted after bootup.

If "Rely on targeted peripheral list" is also selected then make sure to update `drivers/usb/core/otg_whitelist.h` with the desired supported device class identification ids.

OTG option in driver mode will appear only when gadget support is also selected. Please enable gadget support as given below.

```

Device Drivers --->
USB support --->
<*> USB Gadget Support --->
    [ ] Debugging messages (DEVELOPMENT)
    [ ] Debugging information files (DEVELOPMENT)
    [ ] Debugging information files in debugfs (DEVELOPMENT)
    (2) Maximum VBUS power usage (2-500mA) NEW

```

```
USB Peripheral Controller (Inventra HDRC Peripheral(TI,ADI, ...)) --->
<M> USB Gadget Drivers
<M> File-backed Storage Gadget
```

Please make sure that Inventra HDRC is selected as USB peripheral controller which will appear only when OTG is selected as below.


```
Device Drivers --->
USB support --->
<*> Support for Host-side USB
    *** Miscellaneous USB options ***
[*] USB device filesystem
[*] USB device class-devices (DEPRECATED)
    *** USB Host Controller Drivers ***
<*> Inventra Highspeed Dual Role Controller (TI, ADI, ...)
    **** Platform Glue Layer ***
<>     TUSB6010
<*>     OMAP2430 and onwards
<>     AM35x
        Driver Mode (Both Host and peripheral : USB OTG (On The Go) Device) --->
[ ] Disable DMA (always use PIO)
[*] Use System DMA for Mentor DMA workaround
[*] Enable debugging messages
```



## Host mode applications

### Mass Storage Driver

This figure illustrates the stack diagram of the system with USB Mass Storage class.



### Configuration

```


Device Drivers --->
SCSI device support --->
<*> SCSI device support
[*] legacy /proc/scsi/support
--- SCSI support type (disk, tape, CD-ROM)
<*> SCSI disk support
USB support --->
<*> Support for Host-side USB
[...]
--- USB Device Class drivers
<*> USB Mass Storage support
  
```

### Device nodes

The SCSI sub system creates /dev/sd\* devices with help of mdev. For example when USB stick or HDD is inserted /dev/sda1 will be created. Use fdisk utility to create a partition, mkfs.<vfat/ext2> to format the device with vfat/ext2 file system, use mount command for mounting the usb mass storage device.

### USB HID Class

USB Mouse and Keyboards that conform to the USB HID specifications are supported.



### Configuration

```


Device Drivers --->
HID Devices --->
  <*> Generic HID Support
    *** USB Input Devices ***
  <*> USB Human Interface Device(full HID) support
  
```

## Device nodes

The event sub system creates `/dev/input/event*` devices with the help of `mdev`. When mouse or keyboard is connected the device nodes with `/dev/input/event[0/1/2..]` will be created. The HID events can be captured with application. Usage: `./evtest /dev/input/event*`

## USB Audio

The image below shows the USB stack architecture with USB Audio/Video class.



## Configuration

```

Device Drivers --->
Sound card support--->
<*> Sound card support
  Advanced Linux Sound Architecture --->
  <*> Advanced Linux Sound Architecture
    [*] USB sound devices --->
    <*> USB Audio/MIDI driver
  
```

## Resources

For testing USB Audio support we need any ALSA compliant audio player/capture application. Kindly read the Audio driver section to get more inputs on this.

arecord and aplay tools can be used for record and playing audio stream to/from usb audio devices.

To list the audio output (speaker) devices available use

```
#aplay -l
```

For playing audio on usb audio speaker.

```
#aplay -D "hw:0,0" -f S16_LE -r 11025 <samplefile.wav>
```

To list the audio input (mike) devices available use

```
#arecord -l
```

For recording audio from usb audio input/mike device.

```
#arecord -D "hw:0,0" -f S16_LE -r 16000 <samplefile.wav>
```

Note: use the appropriate device number "hw:0,0" or "hw:1,0" or "hw:2,0", use "aplay -l" or "arecord -l" to get list of available audio devices/

## USB Video

### Configuration

```
Device Drivers --->
Multimedia support --->
    *** Multimedia core support ***
    <*> Video for Linux
    [*] Enable Video For Linux API 1 (DEPRECATED)
    [*] V4L2 sub-device userspace API (EXPERIMENTAL)
    *** Multimedia Drivers ***
    [*] Video capture adapters --->
        [*] V4L USB devices --->
            <*> USB Video Class (UVC)
                [*] UVC input events device support
```

## Resources

For testing USB Video support we need a user level application like "mplayer" to stream video from an USB camera. If you are using mplayer as the capture application, then you must export the DISPLAY to a X server. Then, execute the following command:

```
$ mplayer tv:// -tv driver=v4l2:width=320:height=240
```

You can use the capture tool to stream video from USB camera.

```
$ ./capture -d /dev/video0 -i z1.yuv -w 320 -l 240
```

## USB CDC-HOST

The CDC-Host configuration will enable the CDC-ACM host class driver, which support network communication devices like USB modems.

### Configuration

Select usb host configuration through menuconfig as explained in host configuration section <sup>[3]</sup> and select CDC ACM support as mentioned below.

```
Device Drivers --->
USB support --->
  <*>   Support for Host-side USB
  ....
  *** USB Device Class drivers ***
    <*> USB Modem (CDC ACM) support
    < > USB Printer support
    < > USB Wireless Device Management support
    < > USB Test and Measurement Class support
```

```
Device Drivers --->
Network device supports --->
  USB Network Adapters --->
    <*> Multi-purpose USB Networking Framework
    < >   ASIX AX88xxx Based USB 2.0 Ethernet Adapters
    <*>   CDC Ethernet support (smart devices such as cable modems)
    < >   CDC EEM support
```

### Resources

The test setup includes connecting the two EVMs, EVM-1 is configured in host mode (enabling CDC-host configuration as explained above) and EVM-2 is configured in CDC-device mode configuration (refer cdc-configuration <sup>[4]</sup>). Connect EVM-2 (CDC-device act as CDC-modem) to EVM-1 (CDC-Host), the EVM-1 CDC-Host will recognize the EVM-2 as usb-modem and creates the new **usbx** network interface.

on EVM-2 (CDC-Device)

```
#ifconfig usb0 192.168.0.3 up
```


on EVM-1 (CDC-Host): A new interface say usb0 or usb1 will be created.

```
#ifconfig usbx 192.168.0.5 up
```

perform the ping from EVM-1 to EVM-2 (vice-versa).

## Gadget Mode Applications

### Mass Storage Gadget



### Configuration

#### 1. Select USB Gadget support

```

Device Drivers --->
USB support --->
< >   Support for Host-side USB
    *** Enable Host or Gadget support to see Inventra options ***
    *** NOTE: USB_STORAGE depends on SCSI but BLK_DEV_SD may ***
<*>   USB Gadget Support   --->
    *** OTG and related infrastructure ***
  
```

#### 2. Select device/gadget controller support

```

< >   Support for Host-side USB
<*>   Inventra Highspeed Dual Role Controller (TI, ADI, ...)
    *** Platform Glue Layer ***
< >   TUSB6010
< >   OMAP2430 and onwards
< >   AM35x
<*>   TI81XX
TI81XX usb connector's ID pin control (from software setting) --->
  
```

```

    Driver Mode (USB Peripheral (gadget stack)) --->
[ ]   Disable DMA (always use PIO)
[*]   Enable debugging messages
    *** NOTE: USB_STORAGE depends on SCSI but BLK_DEV_SD may ***
<*>   USB Gadget Support --->
    *** OTG and related infrastructure ***

```

### 3. Select gadget driver, also select USB Peripheral controller

```

Device Drivers --->
USB support --->
USB Gadget Support --->
[ ]   Debugging messages (DEVELOPMENT)
[ ]   Debugging information files (DEVELOPMENT)
[ ]   Debugging information files in debugfs (DEVELOPMENT)
(2)   Maximum VBUS Power usage (2-500 mA)
USB Peripheral Controller (Inventra HDRC USB Peripheral (TI, ADI, ...)) --->
< >   GPIO based peripheral-only VBUS sensing 'transceiver'
[ ]   Generic ULPI Transceiver Driver
    *-   NOP USB Transceiver Driver
<M>   USB Gadget Drivers
< >   Gadget Zero (DEVELOPMENT)
< >   Audio Gadget (EXPERIMENTAL)
< >   Ethernet Gadget (with CDC Ethernet support)
< >   Gadget Filesystem (EXPERIMENTAL)
< >   Function Filesystem (EXPERIMENTAL)
<M>   File-backed Storage Gadget
[*]   File-backed Storage Gadget testing version
<M>   Mass Storage Gadget

```

#### Installation of File Storage Gadget Driver

Let us assume that we are interested in exposing /dev/mmcblk0 block device to the file storage gadget device to host (windows/linux). To that effect we need to issue the following command to load the file storage gadget driver. The module parameter **buflen** can be used set buffersize of the gadget driver for better performance, please refer to /driver/usb/gadget/file\_storage.c for more information on module parameters.

```

example
#insmod <g_file_storage.ko> file=/dev/sda1 buflen=65536 stall=0 removable=1
#insmod <g_file_storage.ko> file=/dev/mmcblk0 stall=0 removable=1


```

## CDC/RNDIS gadget

The CDC/RNDIS gadget driver that is used to send standard Ethernet frames using USB.

**For OMAP35x** : Please enable "Use System DMA for Rx endpoints" to fix the flood ping hang issue with packet size of more than 16KB on OMAP35x due to Mentor DMA lockup issue.

The image below shows the USB stack architecture with CDC/RNDIS gadget.



### Configuration for USB controller and CDC/RNDIS Gadget

#### 1. Select USB Gadget support

```

Device Drivers --->
USB support --->
< >   Support for Host-side USB
    *** Enable Host or Gadget support to see Inventra options ***
    *** NOTE: USB_STORAGE depends on SCSI but BLK_DEV_SD may ***
<*>   USB Gadget Support  --->
    *** OTG and related infrastructure ***
  
```

#### 2. Select device/gadget controller support

```

< >   Support for Host-side USB
<*>   Inventra Highspeed Dual Role Controller (TI, ADI, ...)
    *** Platform Glue Layer ***
< >   TUSB6010
< >   OMAP2430 and onwards
  
```



```

< >      AM35x
<*>      TI81XX
TI81XX usb connector's ID pin control (from software setting) --->
        Driver Mode (USB Peripheral (gadget stack)) --->
[ ]      Disable DMA (always use PIO)
[*]      Enable debugging messages
*** NOTE: USB_STORAGE depends on SCSI but BLK_DEV_SD may ***
<*>      USB Gadget Support --->
        *** OTG and related infrastructure ***

```

3. Select cdc/rndis gadget driver, select 'M' to build gadget as module and '\*' for builtin. Also select USB Peripheral controller.

```

Device Drivers --->
USB support --->
USB Gadget Support --->
[ ]      Debugging messages (DEVELOPMENT)
[ ]      Debugging information files (DEVELOPMENT)
[ ]      Debugging information files in debugfs (DEVELOPMENT)
(2)      Maximum VBUS Power usage (2-500 mA)
USB Peripheral Controller (Inventra HDRC USB Peripheral (TI, ADI, ...)) --->
<M>      USB Gadget Drivers (Ethernet Gadget (with CDC Ethernet support)) --->
        Ethernet Gadget (with CDC Ethernet support)
[*]      RNDIS support
[ ]      Ethernet Emulation Model (EEM) support

```

Please do not select RNDIS support for testing ethernet gadget with Linux 2.4, IXIA and MACOS host machine.

### Installation of CDC/RNDIS Gadget Driver

Inserting the CDC/RNDIS gadget driver as module is as follows:

```
$ insmod <path to g_ether.ko>
```

### Setting up USBNet

The CDC/RNDIS Gadget driver will create a Ethernet device by the name usb0. You need to assign an IP address to the device and bring up the device. The typical command for that would be:

```
$ ifconfig usb0 <IP_ADDR> netmask 255.255.255.0 up
```

## Modular testing on MUSB

Mentor USB (MUSB) linux driver has been reorganized in v2.6.37 to support multi platform config. Modular structure has also changed due to this and thus now onward there will be below modules on MUSB

1. musb\_hdrc.ko: The core controller module.
2. cppi30dma.ko, cppi41dma.ko or musbhsdma.ko: The dma controller module.
3. ti81xx.ko, am35x.ko or omap2430.ko: The platform glue module.
4. g\_file\_storage.ko or g\_ether.ko: The gadget controller module.

All the above four modules need to be inserted sequentially for an OTG (both host and device) configured or gadget only configured kernel. Fourth module (gadget controller) would not be needed in a host only config.

## One port as host and other port as Gadget (for TI81XX/TI813X)

The TI816X/TI814X/TI813X/TI811X has two mentor usb controller and hence each port usb0/usb1 can be configured in host or gadget mode. This feature will provide the user to configure the each port in host/gadget mode.

To configure the usb0/usb1 port to host/gadget mode, do the following steps

### 1) Select host and gadget support

```
Menuconfig->Device Drviers->USB Support
<*>   Support for Host-side USB
[ ]    USB verbose debug messages
[*]    USB announce new devices
*** Miscellaneous USB options ***
.....
<*>   USB Gadget Support  --->
```

### 2) Select USB OTG support (for TI814X/TI813X/TI811X)

```
Menuconfig->Device Drviers->USB Support
<*>   Inventra Highspeed Dual Role Controller (TI, ADI, ...)
      *** Platform Glue Layer ***
< >   TUSB6010
< >   OMAP2430 and onwards
< >   AM35x
<*>   TI81XX
      TI816X usb connector's ID pin control (from usb connector)  --->
      Driver Mode (Both host and peripheral:  USB OTG (On The Go) Device)  --->
[ ]    Disable DMA (always use PIO)
[*]    Enable debugging messages
```

### 3) Select USB OTG support (for TI816X)

For DM816X, you need to chose the USB-ID configuration through 1) software settings or 2)external connector. In case of software setting for each port usb0 or usb1 you need to configure the mode (Host or Device). You can chose 1) both port as host or 2)one port as host or other as device.

```
Menuconfig->Device Drviers->USB Support
<*>   Inventra Highspeed Dual Role Controller (TI, ADI, ...)
      *** Platform Glue Layer ***
< >   TUSB6010
< >   OMAP2430 and onwards
< >   AM35x
<*>   TI81XX
      TI816X usb connector's ID pin control (from software setting)  --->
      Force TI816X USB0 to  (Host mode)  --->
      Force TI816X USB1 to  (Host mode)  --->
      Driver Mode (Both host and peripheral:  USB OTG (On The Go) Device)  --->
[ ]    Disable DMA (always use PIO)
[*]    Enable debugging messages
```

### 4) Select Gadget device controller and gadget driver as modules

```

Menuconfig->Device Drivers->USB Support

<*>  USB Gadget Support  --->
    --- USB Gadget Support
    [ ]  Debugging messages (DEVELOPMENT) (NEW)
    [ ]  Debugging information files (DEVELOPMENT) (NEW)
    [ ]  Debugging information files in debugfs (DEVELOPMENT) (NEW)
    (2)  Maximum VBUS Power usage (2-500 mA) (NEW)

    USB Peripheral Controller (Inventra HDRC USB Peripheral (TI, ADI, ...)) --->

<M>  USB Gadget Drivers
<M>    Gadget Zero (DEVELOPMENT)
[ ]    HNP Test Device (NEW)
< >    Audio Gadget (EXPERIMENTAL) (NEW)
<M>    Ethernet Gadget (with CDC Ethernet support)
[*]      RNDIS support (NEW)
[ ]      Ethernet Emulation Model (EEM) support (NEW)
< >    Gadget Filesystem (EXPERIMENTAL) (NEW)
< >    Function Filesystem (EXPERIMENTAL) (NEW)
<M>    File-backed Storage Gadget
[*]      File-backed Storage Gadget testing version

```

### 5) Unselect the OTG Targeted Peripherals list

```

Menuconfig->Device Drivers->USB Support

<*>  Support for Host-side USB
    ....
    [*] USB runtime power management (autosuspend) and wakeup
    -* OTG support
    [ ]  Rely on OTG Targeted Peripherals List
    [ ]  Disable external hubs

```

### 6) Build uImage and usb gadget modules

Build the kernel image and the two usb gadget as modules (like g\_ether.ko, g\_file\_storage.ko, g\_mass\_storage.ko or g\_zero.ko ..etc).

### 7) Setup for TI81XX/TI814X

If the board has mini-AB or micro-AB receptacle for usb0/usb1 port then

- To configure usb0/usb1 as host mode, connect mini/micro-A to A receptacle to usb0/usb1 port.
- To configure usb0/usb1 as device mode, connect mini/micro-B to standard A cable.

If the board has standard-A receptacle

- To configured usb0/usb1 as host mode , connect device directly or through HUB.
- To configured usb0/usb1 as device mode , connect **Standard A to A USB cable**.

### 8) Insert the two gadget modules

Load the kernel image and Make sure above setup is done before insert the modules. Insert the gadget modules for usb0 port.

```
# insmod <module>.ko      (eg: #insert g_ether.ko)
```

Insert the gadget module for usb1 port.

```
# insmod <module>.ko      (eg: #insert g_file_storage.ko file=<file path> stall=0 buflen=65536)
```

**Note: Please note that the usb port will be enabled only after inserting usb gadget module for port0/port1, depending on the cable type connected to each port, the first inserted gadget module will enable usb0 port for to host/device mode, the second inserted gadget module will enable the usb1 port to host/device mode.**

In scenario where usb0 as mass-storage gadget mode and usb1 as host mode, and the use-case is to expose the usb flash drive or USB-HDD connected to usb1 port as mass-storage media through usb0 gadget port to windows/linux host. The workaround for this use-case could be

1. insmod g\_ether.ko (usb0 port will be enabled as cdc/rndis gadget)
2. insmod g\_zero.ko (usb1 port will enabled as host mode and all devices (eg.USB-HDD/flash drive etc) connected to this port will be enumerated)
3. rmmod g\_ether.ko (remove the gadget driver from usb0 port)
4. insmod g\_file\_storage.ko file=/dev/sda stall=0 buflen=65536 (or use g\_mass\_storage.ko)

Now the usb0 port can be connected to window/linux host as mass storage gadget with USB-HDD (/dev/sda) as storage media.

## USB EHCI Electrical testing (Not applicable for TI81XX/TI811X)

USB EHCI electrical test is supported in software. Please use below command to perform various electrical tests.

```
$ echo 'Options' > sys/devices/platform/ehci-omap.0/portN
Where 'options' can be,
reset    --> Reset Device
t-j      --> Send TEST_J on suspended port
t-k      --> Send TEST_K on suspended port
t-pkt    --> Send TEST_PACKET[53] on suspended port
t-force  --> Send TEST_FORCE_ENABLE on suspended port
t-se0    --> Send TEST_SE0_NAK on suspended port
```

## USB OTG (HNP/SRP) testing (Not applicable for TI81XX/TI811X)

Please choose the configuration as described in driver configuration section for OTG and follow the steps below for testing.

- 1. Boot the OTG build image on two OMAP35x EVM.
- 2. If gadget driver is built as module then insert it to complete USB initialization.
- 3. Connect mini-A side of the OTG cable to one of the EVM (say EVM-1) and mini-B side on the other (say EVM-2).

In this scenario EVM-1 will become initial host or A-device and EVM-2 will become initial device or B-device. A-device will provide bus power throughout the bus communication even if it becomes peripheral using HNP.

There will not be any connect event at this point of time as Vbus power is not yet switched-on. Vbus power can be switched-on from A-device or from B-device using SRP.

- 4. Request to switch-on the Vbus power using below command on any EVM.

```
$ echo "F" > /proc/driver/musb_hdrc
```

If this command is executed on B-device then SRP protocol will be used to request A-device to switch-on the Vbus power.

- 5. Now the connect event occurs, enumeration will complete and gadget driver on B-device will be ready to use if this driver is in "Targeted Peripheral List (TPL)" of A-device.

If TPL is disabled on A-device then gadget driver will be ready to use soon after enumeration.

If TPL is enabled and gadget driver of B-device is not in TPL list of A-device then there will be an automatic trial of HNP from usb core by suspending the bus. This will cause a role switch and B-device will enumerate A-device. Now the gadget driver of A-device will be configured if it is on the TPL list of B-device.

Currently this is the only way possible for HNP testing but we have added a suspend proc entry to start HNP in other than this scenario.

- 6. Complete all the communication between A-device and B-device.
- 7. Start HNP by executing below command on host side.

```
$ echo "S" > /proc/driver/musb_hdrc
```

It will suspend the bus and role-switch will follow after that.

- 8. Repeat step 4, 5, 6 and 7 for further testing.

## Software Interface

The USB driver exposes its state/control through the sysfs and the procfs interfaces. The following sections talks about these.

### sysfs

sysfs attribute	Description
mode	The entry <code>/sys/devices/platform/musb_hdrc.0/mode</code> is a read-only entry. It will show the state of the OTG (though this feature is not supported) state machine. This will be true even if the driver has been compiled without OTG support. Only the states like A_HOST, B_PERIPHERAL, that makes sense for non-OTG will show up.
vbus	The entry <code>/sys/devices/platform/musb_hdrc.0/vbus</code> is a write-only entry. It is used to set the VBUS timeout value during OTG. If the current OTG state is <code>a_wait_bcon</code> then urb submission is disabled.

### procfs

The procfs entry `/proc/driver/musb_hdrc` is used to control the driver behaviour as well as check the status of the driver.

In case of TI81XX/TI811X two nodes will be created for each controller `/proc/driver/musb_hdrc.0` and `/proc/driver/musb_hdrc.1` respectively.

- 1. The following command will show the usage of this proc entry

```
# echo "?" > /proc/driver/musb_hdrc.x
```

- 2. Specifically the most important usage of this entry would be to start an USB session(host mode) by issuing the following command:

```
# echo "F" > /proc/driver/musb_hdrc.x
```

- 3. To enable DEBUG message from musb driver, issue the following command:

```
# echo "D<num>" > /proc/driver/musb_hdrc : <num> can be 1 to 8.
Use dmesg to get dump of musb driver debug output
# dmesg
```

```
example (for two instances of musb controller)
# echo D8 > /proc/driver/musb_hdrc.0 //set debug_level 8 for musb controller-0
# echo D8 > /proc/driver/musb_hdrc.1 //set debug_level 8 for musb controller-1
# dmesg //dump the debug prints on console
```

## **musb driver debugfs**

To use the debugfs feature of kernel and musb, you need to enable the kernel debugfs option through menuconfig, as shown below

```
Menuconfig->kernel hacking -->
    [ ] Enable unused/obsolete exported symbols
    [*] Debug Filesystem
    [ ] Run 'make headers_check' when building vmlinux
    [*] Kernel debugging
```

## **mount the debug file system (debugfs)**

```
#mount -t debugfs none /sys/kernel/debug/
```

## **musb driver TEST-MODE debugfs support**

Issue the following command

### **To force musb to host mode**

```
#echo "force host" > /sys/kernel/debug/testmode
```

### **To force musb to full-speed**

```
#echo "force full-speed" > /sys/kernel/debug/testmode
```

### **To force musb to high-speed**

```
#echo "force high-speed" > /sys/kernel/debug/testmode
```

### **To send test packet**

```
#echo "test packet" > /sys/kernel/debug/testmode
```

### **To generate test K pattern**

```
#echo "test K" > /sys/kernel/debug/testmode
```

### **To generate test J pattern**

```
#echo "test K" > /sys/kernel/debug/testmode
```

### **To generate test SE0 NAK pattern**

```
#echo "test SE0 NAK" > /sys/kernel/debug/testmode
```

## **References**

- [1] [http://processors.wiki.ti.com/index.php/Usbgeneralpage#USB-ID\\_pin\\_configuration\\_selection\\_for\\_DM816X](http://processors.wiki.ti.com/index.php/Usbgeneralpage#USB-ID_pin_configuration_selection_for_DM816X)
- [2] [http://processors.wiki.ti.com/index.php/Usbgeneralpage#One\\_port\\_as\\_host\\_and\\_other\\_port\\_as\\_Gadget\\_.28for\\_DM81XX.29](http://processors.wiki.ti.com/index.php/Usbgeneralpage#One_port_as_host_and_other_port_as_Gadget_.28for_DM81XX.29)
- [3] [http://processors.wiki.ti.com/index.php/Usbgeneralpage#USB\\_controller\\_in\\_host\\_mode](http://processors.wiki.ti.com/index.php/Usbgeneralpage#USB_controller_in_host_mode)
- [4] [http://processors.wiki.ti.com/index.php/Usbgeneralpage#CDC.2FRNDIS\\_gadget](http://processors.wiki.ti.com/index.php/Usbgeneralpage#CDC.2FRNDIS_gadget)

# Article Sources and Contributors

Usbgeneralpage Source: http://processors.wiki.ti.com/index.php?oldid=124142 Contributors: AJ, AjayGupta, Ravibabu31

# Image Sources, Licenses and Contributors

Image:TIBanner.png Source: http://processors.wiki.ti.com/index.php?title=File:TIBanner.png License: unknown Contributors: Nsnehaprabha  
File:Linuxusbarch3.JPG Source: http://processors.wiki.ti.com/index.php?title=File:Linuxusbarch3.JPG License: unknown Contributors: Ravibabu31  
Image:usb-msc.png Source: http://processors.wiki.ti.com/index.php?title=File:Usb-msc.png License: unknown Contributors: AjayGupta, SanjeevPremi  
Image:usb-hid.png Source: http://processors.wiki.ti.com/index.php?title=File:Usb-hid.png License: unknown Contributors: AjayGupta, SanjeevPremi  
Image:usb-iso.png Source: http://processors.wiki.ti.com/index.php?title=File:Usb-iso.png License: unknown Contributors: AjayGupta, SanjeevPremi  
Image:usb-gadget.png Source: http://processors.wiki.ti.com/index.php?title=File:Usb-gadget.png License: unknown Contributors: Hvaibhav  
Image:usb-cdc.png Source: http://processors.wiki.ti.com/index.php?title=File:Usb-cdc.png License: unknown Contributors: Hvaibhav

# License

THE WORK (AS DEFINED BELOW) IS PROVIDED UNDER THE TERMS OF THIS CREATIVE COMMONS PUBLIC LICENSE ("CCPL" OR "LICENSE"). THE WORK IS PROTECTED BY COPYRIGHT AND/OR OTHER APPLICABLE LAW. ANY USE OF THE WORK OTHER THAN AS AUTHORIZED UNDER THIS LICENSE OR COPYRIGHT LAW IS PROHIBITED. BY EXERCISING ANY RIGHTS TO THE WORK PROVIDED HERE, YOU ACCEPT AND AGREE TO BE BOUND BY THE TERMS OF THIS LICENSE. TO THE EXTENT THIS LICENSE MAY BE CONSIDERED TO BE A CONTRACT, THE LICENSOR GRANTS YOU THE RIGHTS CONTAINED HERE IN CONSIDERATION OF YOUR ACCEPTANCE OF SUCH TERMS AND CONDITIONS.

## License

### 1. Definitions

- a. **"Adaptation"** means a work based upon the Work, or upon the Work and other pre-existing works, such as a translation, adaptation, derivative work, arrangement of music or other alterations of a literary or artistic work, or phonogram or performance and includes cinematographic adaptations or any other form in which the Work may be recast, transformed, or adapted including in any form recognizably derived from the original, except that a work that constitutes a Collection will not be considered an Adaptation for the purpose of this License. For the avoidance of doubt, where the Work is a musical work, performance or phonogram, the synchronization of the Work in timed-relation with a moving image ("synching") will be considered an Adaptation for the purpose of this License.
- b. **"Collection"** means a collection of literary or artistic works, such as encyclopedias and anthologies, or performances, phonograms or broadcasts, or other works or subject matter other than works listed in Section 1(f) below, which, by reason of the selection and arrangement of their contents, constitute intellectual creations, in which the Work is included in its entirety in unmodified form along with one or more other contributions, each constituting separate and independent works in themselves, which together are assembled into a collective whole. A work that constitutes a Collection will not be considered an Adaptation (as defined below) for the purposes of this License.
- c. **"Creative Commons Compatible License"** means a license that is listed at <http://creativecommons.org/compatlicenses> that has been approved by Creative Commons as being essentially equivalent to this License, including, at a minimum, because that license: (i) contains terms that have the same purpose, meaning and effect as the License Elements of this License; and, (ii) explicitly permits the relicensing of adaptations of works made available under that license under this License or a Creative Commons jurisdiction license with the same License Elements as this License.
- d. **"Distribute"** means to make available to the public the original and copies of the Work or Adaptation, as appropriate, through sale or other transfer of ownership.
- e. **"License Elements"** means the following high-level license attributes as selected by Licensor and indicated in the title of this License: Attribution, ShareAlike.
- f. **"Licensor"** means the individual, individuals, entity or entities that offer(s) the Work under the terms of this License.
- g. **"Original Author"** means, in the case of a literary or artistic work, the individual, individuals, entity or entities who created the Work or if no individual or entity can be identified, the publisher; and in addition (i) in the case of a performance the actors, singers, musicians, dancers, and other persons who act, sing, deliver, declaim, play in, interpret or otherwise perform literary or artistic works or expressions of folklore; (ii) in the case of a phonogram the producer being the person or legal entity who first fixes the sounds of a performance or other sounds; and, (iii) in the case of broadcasts, the organization that transmits the broadcast.
- h. **"Work"** means the literary and/or artistic work offered under the terms of this License including without limitation any production in the literary, scientific and artistic domain, whatever may be the mode or form of its expression including digital form, such as a book, pamphlet and other writing; a lecture, address, sermon or other work of the same nature; a dramatic or dramatico-musical work; a choreographic work or entertainment in dumb show; a musical composition with or without words; a cinematographic work to which are assimilated works expressed by a process analogous to cinematography; a work of drawing, painting, architecture, sculpture, engraving or lithography; a photographic work to which are assimilated works expressed by a process analogous to photography; a work of applied art; an illustration, map, plan, sketch or three-dimensional work relative to geography, topography, architecture or science; a performance; a broadcast; a phonogram; a compilation of data to the extent it is protected as a copyrightable work; or a work performed by a variety or circus performer to the extent it is not otherwise considered a literary or artistic work.
- i. **"You"** means an individual or entity exercising rights under this License who has not previously violated the terms of this License with respect to the Work, or who has received express permission from the Licensor to exercise rights under this License despite a previous violation.
- j. **"Publicly Perform"** means to recite, perform, play, or to communicate to the public those public recitations, by any means or process, including by wire or wireless means or public digital performances; to make available to the public Works in such a way that members of the public may access these Works from a place and at a place individually chosen by them; to perform the Work to the public by any means or process and the communication to the public of the performances of the Work, including by public digital performance; to broadcast and rebroadcast the Work by any means including signs, sounds or images.
- k. **"Reproduce"** means to make copies of the Work by any means including without limitation by sound or visual recordings and the right of fixation and reproducing fixations of the Work, including storage of a protected performance or phonogram in digital form or other electronic medium.

### 2. Fair Dealing Rights

Nothing in this License is intended to reduce, limit, or restrict any uses free from copyright or rights arising from limitations or exceptions that are provided for in connection with the copyright protection under copyright law or other applicable laws.

### 3. License Grant

Subject to the terms and conditions of this License, Licensor hereby grants You a worldwide, royalty-free, non-exclusive, perpetual (for the duration of the applicable copyright) license to exercise the rights in the Work as stated below:

- a. to reproduce the Work, to incorporate the Work into one or more Collections, and to Reproduce the Work as incorporated in the Collections;
- b. to Create and Reproduce Adaptations provided that any such Adaptation, including any translation in any medium, takes reasonable steps to clearly label, demarcate or otherwise identify that changes were made to the original Work. For example, a translation could be marked "The original work was translated from English to Spanish," or a modification could indicate "The original work has been modified.";
- c. to Distribute and Publicly Perform the Work including as incorporated in Collections; and,
- d. to Distribute and Publicly Perform Adaptations.
- e. For the avoidance of doubt:
  - i. **Non-waivable Compulsory License Schemes.** In those jurisdictions in which the right to collect royalties through any statutory or compulsory licensing scheme cannot be waived, the Licensor reserves the exclusive right to collect such royalties for any exercise by You of the rights granted under this License;
  - ii. **Waivable Compulsory License Schemes.** In those jurisdictions in which the right to collect royalties through any statutory or compulsory licensing scheme can be waived, the Licensor waives the exclusive right to collect such royalties for any exercise by You of the rights granted under this License; and,
  - iii. **Voluntary License Schemes.** The Licensor waives the right to collect royalties, whether individually or, in the event that the Licensor is a member of a collecting society that administers voluntary licensing schemes, via that society, from any exercise by You of the rights granted under this License.

The above rights may be exercised in all media and formats whether now known or hereafter devised. The above rights include the right to make such modifications as are technically necessary to exercise the rights in other media and formats. Subject to Section 8(f), all rights not expressly granted by Licensor are hereby reserved.

### 4. Restrictions

The license granted in Section 3 above is expressly made subject to and limited by the following restrictions:

- a. You may Distribute or Publicly Perform the Work only under the terms of this License. You must include a copy of, or the Uniform Resource Identifier (URI) for, this License with every copy of the Work You Distribute or Publicly Perform. You may not offer or impose any terms on the Work that restrict the terms of this License or the ability of the recipient of the Work to exercise the rights granted to that recipient under the terms of the License. You may not sublicense the Work. You must keep intact all notices that refer to this License and to the disclaimer of warranties with every copy of the Work You Distribute or Publicly Perform. When You Distribute or Publicly Perform the Work, You may not impose any effective technological measures on the Work that restrict the ability of a recipient of the Work from You to exercise the rights granted to that recipient under the terms of the License. This Section 4(a) applies to the Work as incorporated in a Collection, but this does not require the Collection apart from the Work itself to be made subject to the terms of this License. If You create a Collection, upon notice from any Licensor You must, to the extent practicable, remove from the Collection any credit as required by Section 4(c), as requested. If You create an Adaptation, upon notice from any Licensor You must, to the extent practicable, remove from the Adaptation any credit as required by Section 4(c), as requested.
- b. You may Distribute or Publicly Perform an Adaptation only under the terms of: (i) this License; (ii) a later version of this License with the same License Elements as this License; (iii) a Creative Commons jurisdiction license (either this or a later license version) that contains the same License Elements as this License (e.g., Attribution-ShareAlike 3.0 US); (iv) a Creative Commons Compatible License. If you license the Adaptation under one of the licenses mentioned in (iv), you must comply with the terms of that license. If you license the Adaptation under the terms of any of the licenses mentioned in (i), (ii) or (iii) (the "Applicable License"), you must comply with the terms of the Applicable License generally and the following provisions: (I) You must include a copy of, or the URI for, the Applicable License with every copy of each Adaptation You Distribute or Publicly Perform; (II) You may not offer or impose any terms on the Adaptation that restrict the terms of the Applicable License or the ability of the recipient of the Adaptation to exercise the rights granted to that recipient under the terms of the Applicable License; (III) You must keep intact all notices that refer to the Applicable License and to the disclaimer of warranties with every copy of the Work as included in the Adaptation You Distribute or Publicly Perform; (IV) when You Distribute or Publicly Perform the Adaptation, You may not impose any effective technological measures on the Adaptation that restrict the ability of a recipient of the Adaptation from You to exercise the rights granted to that recipient under the terms of the Applicable License. This Section 4(b) applies to the Adaptation as incorporated in a Collection, but this does not require the Collection apart from the Adaptation itself to be made subject to the terms of the Applicable License.
- c. If You Distribute, or Publicly Perform the Work or any Adaptations or Collections, You must, unless a request has been made pursuant to Section 4(a), keep intact all copyright notices for the Work and provide, reasonable to the medium or means You are utilizing: (i) the name of the Original Author (or pseudonym, if applicable) if supplied, and/or if the Original Author and/or Licensor designate another party or parties (e.g., a sponsor institute, publishing entity, journal) for attribution ("Attribution Parties") in Licensor's copyright notice, terms of service or by other reasonable means, the name of such party or parties; (ii) the title of the Work if supplied; (iii) to the extent reasonably practicable, the URI, if any, that Licensor specifies to be associated with the Work, unless such URI does not refer to the copyright notice or licensing information for the Work; and (iv), consistent with Section 3(b), in the case of an Adaptation, a credit identifying the use of the Work in the Adaptation (e.g., "French translation of the Work by Original Author," or "Screenplay based on original Work by Original Author"). The credit required by this Section 4(c) may be implemented in any reasonable manner; provided, however, that in the case of a Adaptation or Collection, at a minimum such credit will appear, if a credit for all contributing authors of the Adaptation or Collection appears, then as part of these credits and in a manner at least as prominent as the credits for the other contributing authors. For the avoidance of doubt, You may only use the credit required by this Section for the purpose of attribution in the manner set out above and, by exercising Your rights under this License, You may not implicitly or explicitly assert or imply any connection with, sponsorship or endorsement by the Original Author, Licensor and/or Attribution Parties, as appropriate, of You or Your use of the Work, without the separate, express prior written permission of the Original Author, Licensor and/or Attribution Parties.
- d. Except as otherwise agreed in writing by the Licensor or as may be otherwise permitted by applicable law, if You Reproduce, Distribute or Publicly Perform the Work either by itself or as part of any Adaptations or Collections, You must not distort, mutilate, modify or take other derogatory action in relation to the Work which would be prejudicial to the Original Author's honor or reputation. Licensor agrees that in those jurisdictions (e.g. Japan), in which any exercise of the right granted in Section 3(b) of this License (the right to make Adaptations) would be deemed to be a distortion, mutilation, modification or other derogatory action prejudicial to the Original Author's honor and reputation, the Licensor will waive or not assert, as appropriate, this Section, to the fullest extent permitted by the applicable national law, to enable You to reasonably exercise Your right under Section 3(b) of this License (right to make Adaptations) but not otherwise.

### 5. Representations, Warranties and Disclaimer

UNLESS OTHERWISE MUTUALLY AGREED TO BY THE PARTIES IN WRITING, LICENSOR OFFERS THE WORK AS-IS AND MAKES NO REPRESENTATIONS OR WARRANTIES OF ANY KIND CONCERNING THE WORK, EXPRESS, IMPLIED, STATUTORY OR OTHERWISE, INCLUDING, WITHOUT LIMITATION, WARRANTIES OF TITLE, MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, NONINFRINGEMENT, OR THE ABSENCE OF LATENT OR OTHER DEFECTS, ACCURACY, OR THE PRESENCE OF ABSENCE OF ERRORS, WHETHER OR NOT DISCOVERABLE. SOME JURISDICTIONS DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES, SO SUCH EXCLUSION MAY NOT APPLY TO YOU.

**6. Limitation on Liability**

EXCEPT TO THE EXTENT REQUIRED BY APPLICABLE LAW, IN NO EVENT WILL LICENSOR BE LIABLE TO YOU ON ANY LEGAL THEORY FOR ANY SPECIAL, INCIDENTAL, CONSEQUENTIAL, PUNITIVE OR EXEMPLARY DAMAGES ARISING OUT OF THIS LICENSE OR THE USE OF THE WORK, EVEN IF LICENSOR HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

**7. Termination**

- a. This License and the rights granted hereunder will terminate automatically upon any breach by You of the terms of this License. Individuals or entities who have received Adaptations or Collections from You under this License, however, will not have their licenses terminated provided such individuals or entities remain in full compliance with those licenses. Sections 1, 2, 5, 6, 7, and 8 will survive any termination of this License.
- b. Subject to the above terms and conditions, the license granted here is perpetual (for the duration of the applicable copyright in the Work). Notwithstanding the above, Licensor reserves the right to release the Work under different license terms or to stop distributing the Work at any time; provided, however that any such election will not serve to withdraw this License (or any other license that has been, or is required to be, granted under the terms of this License), and this License will continue in full force and effect unless terminated as stated above.

**8. Miscellaneous**

- a. Each time You Distribute or Publicly Perform the Work or a Collection, the Licensor offers to the recipient a license to the Work on the same terms and conditions as the license granted to You under this License.
- b. Each time You Distribute or Publicly Perform an Adaptation, Licensor offers to the recipient a license to the original Work on the same terms and conditions as the license granted to You under this License.
- c. If any provision of this License is invalid or unenforceable under applicable law, it shall not affect the validity or enforceability of the remainder of the terms of this License, and without further action by the parties to this agreement, such provision shall be reformed to the minimum extent necessary to make such provision valid and enforceable.
- d. No term or provision of this License shall be deemed waived and no breach consented to unless such waiver or consent shall be in writing and signed by the party to be charged with such waiver or consent.
- e. This License constitutes the entire agreement between the parties with respect to the Work licensed here. There are no understandings, agreements or representations with respect to the Work not specified here. Licensor shall not be bound by any additional provisions that may appear in any communication from You. This License may not be modified without the mutual written agreement of the Licensor and You.
- f. The rights granted under, and the subject matter referenced, in this License were drafted utilizing the terminology of the Berne Convention for the Protection of Literary and Artistic Works (as amended on September 28, 1979), the Rome Convention of 1961, the WIPO Copyright Treaty of 1996, the WIPO Performances and Phonograms Treaty of 1996 and the Universal Copyright Convention (as revised on July 24, 1971). These rights and subject matter take effect in the relevant jurisdiction in which the License terms are sought to be enforced according to the corresponding provisions of the implementation of those treaty provisions in the applicable national law. If the standard suite of rights granted under applicable copyright law includes additional rights not granted under this License, such additional rights are deemed to be included in the License; this License is not intended to restrict the license of any rights under applicable law.