

PS Vita™ Open SDK Specification

Yifan Lu

May 28, 2015

Contents

1	Introduction	3
1.1	Goals	3
1.2	Legal	3
1.3	Overview	3
2	SCE ELF Format	4
2.1	ELF Header	4
2.2	ELF Sections	4
2.2.1	SCE Relocations	4
2.2.2	Relocation Operations	6
2.3	SCE Dynamic Section	6
2.3.1	NIDs	7
2.3.2	Library Information	7
2.3.3	Library Exports	8
2.3.4	Library Imports	9
2.3.5	Diagram	12
2.4	ELF Segments	13
2.4.1	Library Information Location	13
3	Open SDK Format	14
3.1	JSON NID Database	14
3.2	Header Files	15
3.3	Library Files	15
4	Toolchain	16
4.1	vita-libs-gen	16
4.2	vita-elf-create	17

1 Introduction

The documents outlines the requirements and implementation advice for an open source software development library and toolchain for creating object code for the PS Vita™ device.

1.1 Goals

The main goal for this project is to create an ecosystem of amateur produced software and games (*homebrew*) on the PS Vita™ device for non-commercial purposes. The inspiration for this document comes from observed failures of open toolchains on other gaming platforms. The goal is to define precisely the requirements and implementation of an open source toolchain and SDK for the PS Vita™. Collaboration from the community is expected and desired in the creation of this ecosystem. Comments and suggestions for this document should be sent directly to the author.

1.2 Legal

PS Vita™ is a trademark of Sony Computer Entertainment America LLC. This document is written independently of and is not approved by SCEA. Please don't sue us.

1.3 Overview

The PS Vita™ carries an ARM Cortex A9 MPCore as the main CPU processor in a custom SoC. The processor implements the ARMv7-R architecture (with full Thumb2 support). Additionally, it supports the MPE, NEONv1, and VFPv3 extensions.

The software infrastructure is handed by a proprietary operating system; the details of which is outside the scope of this document. What this document will define is the executable format, which is an extension of the ELF version 1 standards. Thorough knowledge of the ELF specifications[1] is assumed and the SCE extensions will be described in detail. The simplified specifications[2] and ARM extensions to ELF[3] will be referenced throughout this document.

The first part of this document will describe the format of SCE ELF executables including details on SCE extension segment and sections. The second part will detail a proposed SDK format for writing the include files and symbol-NID mapping database. The third part will specify a tool which can convert a standard Linux EABI ELF into a SCE ELF.

2 SCE ELF Format

2.1 ELF Header

The header is a standard ARM ELF[3] header. For the `e_type` field, there are some additional options.

Name	Value	Meaning
ET_SCE_EXEC	0xFE00	SCE Executable file
ET_SCE_REEXEC	0xFE04	SCE Relocatable file
ET_SCE_STUBLIB	0xFE0C	SCE SDK Stubs
ET_SCE_DYNAMIC	0xFE18	Unused
ET_SCE_PSPREEXEC	0xFFA0	Unused (PSP ELF only)
ET_SCE_PPUREEXEC	0xFFA4	Unused (SPU ELF only)
ET_SCE_UNK	0xFFA5	Unknown

Figure 1: SCE specific ELF type values

The difference between executable files and relocatable files is that executables have a set base address. Relocatable ELF's were used before FW 2.50 only for PRX, however in the latest versions, any application with ASLR support is relocatable. The open toolchain is required to support ET_SCE_REEXEC. All others are optional.

2.2 ELF Sections

SCE ELF's define additional section types for the `sh_type` field.

Name	Value	Meaning
SHT_SCE_RELA	0x60000000	SCE Relocations
SHT_SCENID	0x61000001	Unused (PSP ELF only)
SHT_SCE_PSPRELA	0x700000A0	Unused (PSP ELF only)
SHT_SCE_ARMRELA	0x700000A4	Unused (SPU ELF only)

Figure 2: SCE specific ELF section types

The toolchain is required to support SHT_SCE_RELA, which is how relocations are implemented in SCE ELF's. The details are described in the following subsection.

2.2.1 SCE Relocations

SCE ELF's use a different relocation format from standard ELF's. The relocation entries are in two different format, either an 8 byte “short” entry or a 12 byte “long” entry. You

are allowed to mix and match “short” and “long” entries, but that is not recommended for alignment reasons. The entire relocation segment is just a packed array of these entries.

```
// assuming LSB of bitfield is listed first
union {
    Elf32_Word r_short : 4;
    struct {
        Elf32_Word r_short : 4;
        Elf32_Word r_symseg : 4;
        Elf32_Word r_code : 8;
        Elf32_Word r_datseg : 4;
        Elf32_Word r_offset_lo : 12;
        Elf32_Word r_offset_hi : 20;
        Elf32_Word r_addend : 12;
    } r_short_entry;
    struct {
        Elf32_Word r_short : 4;
        Elf32_Word r_symseg : 4;
        Elf32_Word r_code : 8;
        Elf32_Word r_datseg : 4;
        Elf32_Word r_code2 : 8;
        Elf32_Word r_dist2 : 4;
        Elf32_Word r_addend;
        Elf32_Word r_offset;
    } r_long_entry;
} SCE_Rel;
```

Figure 3: SCE relocation entry

In the short entry, the offset is stored partially in the first word and partially in the second word. It also has a 12-bit addend. In the long entry, there is support for two relocations on the same data. The open toolchain does not have to implement this. Long entries have 32-bit addends.

- **r_short** determines if the entry is short (non-zero) or not (zero).
- **r_symseg** is the index of the *program segment* containing the data to point to. If this value is 0xF, then 0x0 is used as the base address.
- **r_code** is the relocation code defined in ARM ELF[3]
- **r_datseg** is the index of the *program segment* containing the pointer that is to be relocated.

- `r_offset` is the offset into the segment indexed by `r_datseg`. This is the pointer to relocate.
- `r_addend` is the offset into the segment indexed by `r_symseg`. This is what is written to the relocated pointer.

2.2.2 Relocation Operations

Only the following ARM relocation types are supported on the PS Vita™:

Code	Name	Operation
0	R_ARM_NONE	
2	R_ARM_ABS32	$S + A$
3	R_ARM_REL32	$S + A - P$
10	R_ARM_THM_CALL	$S + A - P$
28	R_ARM_CALL	$S + A - P$
29	R_ARM_JUMP24	$S + A - P$
38	R_ARM_TARGET1 (same as R_ARM_ABS32)	$S + A$
40	R_ARM_V4BX (same as R_ARM_NONE)	
41	R_ARM_TARGET2 (same as R_ARM_REL32)	$S + A - P$
42	R_ARM_PREL31	$S + A - P$
43	R_ARM_MOVW_ABS_NC	$S + A$
44	R_ARM_MOVT_ABS	$S + A$
47	R_ARM_THM_MOVW_ABS_NC	$S + A$
48	R_ARM_THM_MOVT_ABS	$S + A$

Figure 4: SCE specific ELF section types

The toolchain is required to only output relocations of these types. Refer to that ARM ELF[3] manual for information on how the value is formed. The definitions of the variables for relocation is as follows.

Segment start = Base address of segment indexed at `r_datseg`

Symbol start = Base address of segment indexed at `r_symseg`

P = segment start + `r_offset`

S = `r_symseg` == 15 ? 0 : symbol start

A = `r_addend`

2.3 SCE Dynamic Section

ELF Dynamic sections are not used (a change from PSP). Instead all dynamic linking information is stored as part of the export and import sections, which are `SHT_PROGBITS` sections.

2.3.1 NIDs

Instead of using symbols, SCE ELF linking depends on NIDs. These are just 32-bit integers created from hashing the symbol name. The formula for generating them does not matter as long as they match up. For our purposes, we will make sure our open SDK recognizes NIDs for imported functions and when NIDs are created, they can be done so in an implementation defined way.

2.3.2 Library Information

The first SCE specific section `.sceModuleInfo.rodata` is located in the same program segment as `.text`. It contains metadata on the library.

```
struct {
    u16_t    attributes;
    u16_t    version;
    char     name[27];
    u8_t     type;
    void     *gp_value;
    u32_t    export_top;
    u32_t    export_end;
    u32_t    import_top;
    u32_t    import_end;
    u32_t    library_nid;
    u32_t    field_38;
    u32_t    field_3C;
    u32_t    field_40;
    u32_t    module_start;
    u32_t    module_stop;
    u32_t    exidx_top;
    u32_t    exidx_end;
    u32_t    extab_top;
    u32_t    extab_end;
} sce_module_info;
```

Figure 5: SCE library information

Some fields here are optional and can be set to zero. The other fields determine how this library is loaded and linked. All “pointers” used here are relative offsets from the start of the segment containing it.

- **version:** Set to 0x0101
- **name:** Name of the library

- `type`: 0x0 for executable, 0x6 for PRX
- `export_top`: Offset to start of export table.
- `export_end`: Offset to end of export table.
- `import_top`: Offset to start of import table.
- `import_end`: Offset to start of import table.
- `library_nid`: NID of this library. Can be a random unique integer.
- `module_start`: Offset to function to run when library is started. Set to 0 to disable.
- `module_stop`: Offset to function to run when library is exiting. Set to 0 to disable.
- `exidx_top`: Offset to start of ARM EXIDX (optional)
- `exidx_end`: Offset to end of ARM EXIDX (optional)
- `extab_top`: Offset to start of ARM EXTAB (optional)
- `extab_end`: Offset to end of ARM EXTAB (optional)

2.3.3 Library Exports

Each library can export one or more *modules*¹. To get the start of the export table, we add `export_top` to the base of the segment address. To iterate through the export tables, we read the size field of each entry and increment by the size until we reach `export_end`.

- `size`: Set to 0x20. There are other sized export tables that follow different formats. We will not support them for now.
- `version`: Set to 0x1 for a normal export or 0x0 for the main module export.
- `flags`: Set to 0x1 for a normal export or 0x8000 for the main module export. Other values are also valid but will not be covered in this document.
- `num_syms_funcs`: Number of function exports.
- `num_syms_vars`: Number of variable exports.
- `module_nid`: NID of this module. Can be a random unique integer.
- `module_name`: Pointer to name of this exported module.

¹People (including SCE) often mention “module” when they mean “library”. We will also (incorrectly) use “module” when referring to system calls and structures that define it that way. However, the correct usage is “library” for the executable file and “module” for a set of functions exported by the library.


```

struct {
    u16_t    size;
    u16_t    version;
    u16_t    flags;
    u16_t    num_syms_funcs;
    u32_t    num_syms_vars;
    u32_t    num_syms_unk;
    u32_t    module_nid;
    char    *module_name;
    u32_t    *nid_table;
    void    **entry_table;
} sce_module_exports;

```

Figure 6: SCE library export

- **nid_table**: Pointer to an array of 32-bit NIDs to export.
- **entry_table**: Pointer to an array of data pointers corresponding to each exported NID (of the same index).

Note that since pointers are used, the `.sceLib.ent` section containing the export tables can be relocated. The data pointed to (name string, NID array, and data array) are usually stored in a section `.sceExport.rodata`. The order in the arrays (NID and data) is: function exports followed by data exports followed by the unknown exports (the open toolchain should define no such entries). The `.sceExport.rodata` section can also be relocated.

For all executables, a module with NID `0x00000000` and attributes `0x8000` exports the `module_start` and `module_stop` functions along with a pointer to the module information structure as a function export. The NIDs for these exports are as follows:

Name	Type	NID
<code>module_stop</code>	Function	<code>0x79F8E492</code>
<code>module_exit</code>	Function	<code>0x913482A9</code>
<code>module_start</code>	Function	<code>0x935CD196</code>
<code>module_info</code>	Variable	<code>0x6C2224BA</code>

Figure 7: Required module export

2.3.4 Library Imports

Each library also has a list of imported modules. The format of the import table is very similar to the format of the export table.

```

struct {
    u16_t    size;
    u16_t    version;
    u16_t    flags;
    u16_t    num_syms_funcs;
    u16_t    num_syms_vars;
    u16_t    num_syms_unk;
    u32_t    reserved1;
    u32_t    module_nid;
    char    *module_name;
    u32_t    reserved2;
    u32_t    *func_nid_table;
    void    **func_entry_table;
    u32_t    *var_nid_table;
    void    **var_entry_table;
    u32_t    *unk_nid_table;
    void    **unk_entry_table;
} sce_module_imports;

```

Figure 8: SCE library import

- **size**: Set to 0x34. There are other sized import tables that follow different formats. We will not support them for now.
- **version**: Set to 0x1.
- **flags**: Set to 0x0.
- **num_syms_funcs**: Number of function imports.
- **num_syms_vars**: Number of variable imports.
- **module_nid**: NID of module to import. This is used to find what module to import from and is the same NID as the **module_nid** of module from the exporting library.
- **module_name**: Pointer to name of the imported module. Only used for debugging.
- **func_nid_table**: Pointer to an array of function NIDs to import.
- **func_entry_table**: Pointer to an array of stub functions to fill.
- **var_nid_table**: Pointer to an array of variable NIDs to import.
- **var_entry_table**: Pointer to an array of data pointers to write to.

The import tables are stored in the same way as export tables in a section `.sceLib.stubs` which can be relocated. The data pointed to are usually found in `.sceImport.rodata`. The function NIDs to import (for all imported modules) is usually stored in section `.sceFNID.rodata` and the corresponding stub functions are in `.sceFStub.rodata`. The stub functions are found in `.text` and can be any function that is 12 bytes long (however, functions are usually aligned to 16 bytes, which is fine too). Upon dynamic linking, the stub function is either replaced with a jump to the user library or a syscall to an imported kernel module. The suggested stub function is:

```
mvn r0, #0x0  
bx lr  
mov r0, r0
```

Figure 9: Stub function code

Imported variable NIDs can be stored in section `.sceVNID.rodata` and the data table in `.sceVNID.rodata`.

2.3.5 Diagram




Figure 10: Visual representation of all the parts in the SCE sections. Credits to Anissian and xerpi.

2.4 ELF Segments

SCE ELF's define additional program segment types for the `p_type` field.

Name	Value	Meaning
PT_SCE_RELA	0x60000000	SCE Relocations
PT_SCE_COMMENT	0x6FFFFFF0	Unused
PT_SCE_VERSION	0x6FFFFFF1	Unused
PT_SCE_UNK	0x70000001	Unknown
PT_SCE_PSPRELA	0x700000A0	Unused (PSP ELF only)
PT_SCE_PPURELA	0x700000A4	Unused (SPU ELF only)

Figure 11: SCE specific ELF program segment types

The toolchain is only required to support `PT_SCE_RELA`. This program segment is essentially just a composition of all `SHT_SCE_RELA` sections.

2.4.1 Library Information Location

For `ET_SCE_EXEC` executables, the library information is stored in the first segment (where the code is loaded). The location of the `sce_module_info` structure is at `p_paddr` offset from the start of the ELF file. Once the ELF is loaded into memory, the location is segment base address + `p_paddr` - `p_offset`.

For `ET_SCE_RELEXEC` executables, the segment containing `sce_module_info` is indexed by the upper two bits of `e_entry` of the ELF header. The structure is stored at the base of the segment plus the offset defined by the bottom 30 bits of `e_entry`.

3 Open SDK Format

We will first specify a format for defining a database of NIDs to symbol name mappings in JSON. The motivation behind this is that most ELF tools deal with Linux APIs and symbols. We should not have to write our own linker but instead have a tool that converts a linked executable to the SCE ELF format. This database will be built by reverse engineers who will extract NIDs and figure out how the APIs work.

3.1 JSON NID Database

Let's start with a motivating example for what a typical API export would look like.

```
[
  {
    "name": "SceLibKernel",
    "nid": 1237592384,
    "modules": [
      {
        "name": "SceLibKernel",
        "nid": 3404311782,
        "kernel": false,
        "functions": [
          {"sceKernelPuts": 37661282},
          {"sceKernelGetThreadId": 263811833},
          {"sceIoDevctl": 78843058},
          ...
        ],
        "variables": [
          {"SceKernelStackGuard": 1146666227},
          ...
        ]
      },
      {
        "name": "SceLibGcc",
        "nid": 1450899878,
        "kernel": false,
        "functions": [
          ...
        ],
        "variables": [
          ...
        ]
      }
    ]
  },
  ...
]
```

```

    ...
  ],
  {
    "name": "SceIoFilemgr",
    "nid": 1042566167,
    "modules": [
      ...
    ]
  },
  ...
]

```

We start out with an array of library definitions. Each library has an associated library NID (value from `library_nid` field of `sce_module_info` structure) and an array of module exports. Each module has a module NID (value from `module_nid` field of each export table). If the module can only be accessed in kernel (no syscalls are exported), then “kernel” is set to true, otherwise if the module is in userspace or has syscall exports, it is set to false. Each module has an array of functions and an array of variables which maps the symbol name to an NID.

3.2 Header Files

The header files written should be commented with Doxygen syntax. API documentation will be generated by Doxygen.

3.3 Library Files

Library stub files for static linking will be generated by the `vita-libs-gen` tool which uses the JSON API database to create temporary libraries to statically link to.

4 Toolchain

We will try to use as much of the existing publicly available and open source ARM cross-compile build system as possible. We only need to build two tools: a library stubs generator and a ELF to SCE ELF converter. That way, the build system is agnostic of compiler (GCC, clang, etc) and host platform. The tools can also be integrated into a Makefile build process by including vita-elf-create as the last step in producing a PS Vita™ executable. The only requirement for these tools is that they work across Linux, OSX, and Windows.

4.1 vita-libs-gen

For each library as defined by the JSON NID database, we will generate a static object archive with the name of the SCE library. For example, “SceLibKernel” was defined in our JSON database so we produce “libSceLibKernel.a”.

The contents of each library is a collection of object files, one for each exporting module. These object files are assembled from assembly code generated by this tool. For example, the entry for “SceLibGcc” will generate “SceLibGcc.S” which gets assembled into “SceLibGcc.o”.

The assembly code for each exported module contains an exported symbol for each exported function or variable. The functions/variables will be placed into a section defined as `.vitalink.fstubs` (for functions) or `.vitalink.vstubs` (for variables) so the vita-elf-create tool can find it. For each symbol that is exported, we store three integers: the library NID, the module NID, and the function/variable NID in place of any actual code.

Below is an example of the assembly code generated for “SceLibKernel.S”

```
.arch armv7-a
@ export functions
.section .vitalink.fstubs,"ax",%progbits
.align 2
@ export sceKernelPuts
.global sceKernelPuts
.type sceKernelPuts, %function
sceKernelPuts:
.word 0x49C42940
.word 0xCAE9ACE6
.word 0x023EAA62
.align 4
@ export sceKernelGetThreadId
.global sceKernelGetThreadId
.type sceKernelGetThreadId, %function
sceKernelGetThreadId:
.word 0x49C42940
.word 0xCAE9ACE6
.word 0x0FB972F9
```



```

    .align 4
@ export sceIoDevctl
    .global sceIoDevctl
    .type sceIoDevctl, %function
sceIoDevctl:
    .word 0x49C42940
    .word 0xCAE9ACE6
    .word 0x04B30CB2
    .align 4
@ ... export all other functions
@ export variables
    .section .vitalink.vstubs,"awx",%progbits
    .align 2
@ export SceKernelStackGuard
    .global SceKernelStackGuard
    .type SceKernelStackGuard, %object
SceKernelStackGuard:
    .word 0x49C42940
    .word 0xCAE9ACE6
    .word 0x4458BCF3
    .align 4
@ ... export all other variables

```

4.2 vita-elf-create

The purpose of this tool is to convert an executable ELF linked with the static libraries generated by vita-libs-gen and produce a SCE ELF.

1. Read the `.vitalink.fstubs` and `.vitalink.vstubs` sections of the input ELF. Build a list of imports from each module required.
2. Create the `.sceModuleInfo.rodata` section by generating a library info for the input ELF.
3. Create the export tables and import tables with the list from step 1 and the NID JSON database.
4. Convert all non-supported relocations to a supported type (optionally, if the linker was patched to only produce supported relocation types, we can skip this)
5. Open a new ELF with type `ET_SCE_EXEC` or `ET_SCE_RELEXEC` for writing.
6. Build the output SCE ELF by copying over the first loadable program segment and then writing all the library info, export, and import data to the end of the segment,

extending the size of the segment. Make sure the offsets and pointers in the SCE sections are updated to match its new location.

7. Update `p_paddr` of the first segment to point to the library info (for `ET_SCE_EXEC` types) or `e_entry` to point to the library info (for `ET_SCE_RELEXEC` types).
8. Write import stubs over the temporary entries in `.vitalink.fstubs` and `.vitalink.vstubs`.
9. Next copy over the other program segments (if needed).
10. Finally create a new program segment of type `PT_SCE_RELA` and create SCE relocation entries based on the ELF relocation entries of the input ELF.

References

- [1] *Tool Interface Standard (TIS) Executable and Linking Format (ELF) Specification Version 1.2* <https://refspecs.linuxbase.org/elf/elf.pdf>
- [2] *Executable and Linkable Format (ELF)* http://flint.cs.yale.edu/cs422/doc/ELF_Format.pdf
- [3] *ARM IHI 0044E: ELF for the ARM Architecture* http://infocenter.arm.com/help/topic/com.arm.doc.ihl0044e/IHI0044E_aaelf.pdf