

ST87MXX UM AT commands description

Introduction

This document gives details of the AT Command Set supported by the ST87MXX NB-IoT module.

| |
|-----------------|
| Document status |
| Official |

1 General information

1.1 Acronyms and terms

Table 1. Definitions of terms

| ADC | Analog to Digital Converter |
|--------|---|
| DNS | Domain Name System |
| EPS | Evolved Packet Switch |
| ESM | EPS Session Management |
| GBR | Guaranteed Bit rate |
| GPIO | General Purpose Input / Output |
| GW | GateWay |
| I2C | Inter-Integrated Circuit |
| IP | Internet Protocol |
| JTAG | Joint Test Action Group |
| MBR | Maximum Bit Rate |
| NCP | Network Control Protocol |
| NVM | Non Volatile Memory |
| P-CSCF | Proxy - Call Session Control Function |
| PDP | Packet Data Protocol |
| PPP | Point-to-Point Protocol |
| QCI | QoS Class Identifier |
| QoS | Quality of service |
| SDK | Software Development Kit |
| SNDCP | Sub Network Dependent Convergence Protocol |
| SPI | Serial Peripheral Interface |
| SV | Space Vehicle |
| TA | Terminal Adaptor, e.g. a GSM data card (equal to DCE; Data Circuit terminating Equipment) |
| TE | Terminal Equipment, e.g. a computer (equal to DTE; Data Terminal Equipment) |
| TFT | Traffic Flow Template |
| TRNG | True Random Number Generator |
| UART | Universal Asynchronous Receiver Transmitter |
| UE | User Equipment |
| URC | Unsolicited Result Code |
| URI | Universal Resource Identifier |

1.2 Reference documents

The documents listed in [Table 2](#) provide further information.

Table 2. Document references

| Reference | Document |
|-----------|-------------------------|
| [1] | 3GPP TS 24.301 V15.8.0 |
| [2] | 3GPP TS 24.008 V15.9.0 |
| [3] | 3GPP TS 23.682 V15.10.0 |
| [4] | 3GPP TS 23.401 V15.12.0 |
| [5] | 3GPP TS 23.682 V15.10.0 |
| [6] | 3GPP TS 36.133 V15.15.0 |
| [7] | 3GPP TS 31.101 V15.3.0 |
| [8] | 3GPP TS 36.106 V12.1.0 |
| [9] | 3GPP TS 27.060 V15.0.0 |
| [10] | 3GPP TS 29.061 V15.7.0 |
| [11] | 3GPP TS 23.203 V15.4.0 |
| [12] | 3GPP TS 27.007 V15.3.0 |
| [13] | 3GPP TS 23.060 V15.4.0 |
| [14] | 3GPP TC 27.005 V10.0.0 |

Table 3. Document revision history

| Date | Version | Changes |
|------------|---------|---|
| 2022-04-01 | V0.1 | First release after review |
| 2022-06-02 | V0.2 | Added some new Custom System commands |
| 2022-07-08 | V0.3 | MQTT Typo corrections |
| 2022-08-02 | V0.4 | Added GNSS commands |
| 2023-02-03 | V0.5 | <ul style="list-style-type: none"> - Add ADC GPIOs services - Update URCs - Several corrections and typo |
| 2023-06-05 | V0.6 | <ul style="list-style-type: none"> - Added Modem Start/Stop command - Added ADCGETRAW command - Several correction and typo |
| 2023-09-11 | V0.7 | <ul style="list-style-type: none"> - Added watchdog mode command - Added assert command - IPPARAMS Correction - URC list updated |
| 2023-10-23 | V0.8 | <ul style="list-style-type: none"> - Added ADCGETUSER command - RESET command updated - IPCFG command correction - GPIOCFG command updated - IPSENDUDP command updated - Added GPIOSPICFG command |
| 2023-12-04 | V1.0 | <ul style="list-style-type: none"> - Added RFTXCW and RFRSSI commands. - General review of the document for look and feel harmonization. - Added CGEV URCs in URC list. <ul style="list-style-type: none"> - First official version. |

1.4 Table of contents

| | |
|---|----|
| Introduction | 1 |
| 1 General information | 2 |
| 1.1 Acronyms and terms | 2 |
| 1.2 Reference documents | 3 |
| 1.3 Revision history | 4 |
| 1.4 Table of contents | 5 |
| 1.5 List of tables | 8 |
| 2 Introduction | 9 |
| 2.1 AT command syntax | 9 |
| 3 Generic System commands | 10 |
| 3.1 ATE – Set Command Echo Mode | 10 |
| 3.2 ATI – Display product identification information | 11 |
| 3.3 AT+CCLK – Set and get current date and time | 12 |
| 3.4 AT+CFUN – Set modem functionality | 13 |
| 3.5 AT+CGMI – Request manufacturer identification | 14 |
| 3.6 AT+CGMM – Request model identification | 15 |
| 3.7 AT+CGMR – Request revision identification | 16 |
| 3.8 AT+CGSN – Request product serial number identification | 17 |
| 3.9 AT+CIMI – Request international mobile subscriber identity | 18 |
| 3.10 AT+CMEE – Report Mobile Termination Error | 19 |
| 3.11 AT+CMUX – Multiplexing mode | 20 |
| 3.12 AT+CRC – Cellular result codes | 22 |
| 3.13 AT+IPR – Set device UART baudrate | 23 |
| 3.14 AT#SIMST – Report SIM status | 24 |
| 4 Custom System commands | 25 |
| 4.1 AT#BANDSEL – Enable or Disable RF bands | 25 |
| 4.2 AT#BANDCFG – Supported RF bands | 27 |
| 4.3 AT#GETTEMP – Read the internal temperature | 29 |
| 4.4 AT#GETVBAT – Read the voltage battery supply | 30 |
| 4.5 AT#ADCGETRAW – Read the ADC raw value from an ADC Channel | 31 |
| 4.6 AT#ADCGETUSER – Read the user ADC channel in ADC steps or in mV | 32 |
| 4.7 AT#GPIOCFG – Set or Get the GPIO Mode of a GPIO | 33 |
| 4.8 AT#GPIORD – Read the level of a GPIO | 34 |
| 4.9 AT#GPIOWR – Writes the level of a GPIO | 35 |
| 4.10 AT#GPIOJTAGCFG – Configure the GPIO in JTAG mode | 36 |
| 4.11 AT#GPIOI2CCFG – Configure the GPIO in I2C mode | 37 |
| 4.12 AT#GPiOSPICFG – Configure the GPIO in SPI mode | 38 |
| 4.13 AT#GPIOUART1CFG – Configure the GPIO in UART1 mode | 39 |
| 4.14 AT#GPIOADCCFG – Configure the GPIO in ADC mode | 40 |
| 4.15 AT#LEDCFG – Enable or disable LED status | 41 |
| 4.16 AT#LOCKFREQ – Lock to a specific frequency | 42 |
| 4.17 AT#PWROFF – Powers module off | 43 |
| 4.18 AT#RESET – Module reset | 44 |
| 4.19 AT#RFACTORY – Reboot with a factory configuration | 45 |
| 4.20 AT#SLEEPIND – Enable or disable the URC messages related to sleep mode | 46 |
| 4.21 AT#SLEEPMODE – Enable, disable the sleep mode | 47 |
| 4.22 AT#STRACECFG – Set or get the trace configuration | 48 |
| 4.23 AT#TEMPLIMIT – Temperature thresholds low and high | 49 |
| 4.24 AT#VBATLIMIT – Handling of battery level thresholds | 51 |
| 4.25 AT#CAP – Enables or disables the Customer Application mode | 52 |
| 4.26 AT#WAKEUPEVENT – Handling of the wake up event and associated pins | 53 |
| 4.27 AT#PWMINIT – Initialize GPIO for PWM mode | 54 |
| 4.28 AT#PWMSET – Enable PWM with given period and duty cycle | 55 |

| | | |
|------|---|-----|
| 4.29 | AT#PWMSTOP – Stop PWM with given period and duty cycle..... | 56 |
| 4.30 | AT#MODEMSTOP – Stop NBIOT MODEM | 57 |
| 4.31 | AT#MODEMSTART – Start NBIOT MODEM | 58 |
| 4.32 | AT#SCAN – Cells scan parameters..... | 59 |
| 4.33 | AT#WDGMode – Configure the watchdog | 61 |
| 4.34 | AT#ASSERT – Gives the assert information for the different cores..... | 62 |
| 4.35 | AT#RINGPIN – Configure the Ring pin..... | 63 |
| 4.36 | AT#REGVEXT – Configuration of the regulator VEXT..... | 64 |
| 4.37 | AT#RFTXCW – RF TX Continuous Wave..... | 65 |
| 4.38 | AT#RFRSSI – RF RSSI measurement | 66 |
| 5 | PS commands | 67 |
| 5.1 | AT+CGACT – PDP context activate or deactivate..... | 67 |
| 5.2 | AT+CGAPNRC – APN rate control..... | 69 |
| 5.3 | AT+CGATT – PS attach or detach..... | 71 |
| 5.4 | AT+CGCMOD – PDP context modify..... | 72 |
| 5.5 | AT+CGCONTRDP – Read PDP context dynamic parameters..... | 73 |
| 5.6 | AT+CGDATA – Enter data state..... | 76 |
| 5.7 | AT+CGDCONT – Define PDP context..... | 78 |
| 5.8 | AT+ CGDSCONT – Define secondary PDP context..... | 82 |
| 5.9 | AT+CGEQOS – Defines EPS Quality of Service..... | 84 |
| 5.10 | AT+CGEQOSRDP – EPS quality of service read dynamic parameters..... | 86 |
| 5.11 | AT+CGEREP – Packet domain event reporting | 88 |
| 5.12 | AT+CGPADDR – Show PDP address(es) | 91 |
| 5.13 | AT+CGPIAF – Printing IP address format..... | 93 |
| 5.14 | AT+ CGTFT – Traffic flow template | 95 |
| 5.15 | AT+CRTDCP – Reporting of terminating data via the control plane | 98 |
| 5.16 | AT+CSCON – Signalling connection status | 99 |
| 5.17 | AT+CSODCP – Sending of originating data via the control plane | 101 |
| 6 | Network services commands..... | 103 |
| 6.1 | AT+CCIoTOPT – CIoT optimization configuration | 103 |
| 6.2 | AT+CEDRXS – eDRX settings..... | 105 |
| 6.3 | AT#PTW – eDRX Paging Time Window | 107 |
| 6.4 | AT+CEDRXRDP – eDRX Read dynamic parameters..... | 108 |
| 6.5 | AT+CEREG – EPS network registration status..... | 109 |
| 6.6 | AT+CESQ – Extended signal quality | 112 |
| 6.7 | AT+CLCK – Facility lock | 113 |
| 6.8 | AT+COPS – PLMN selection..... | 114 |
| 6.9 | AT+CPIN – Enter PIN | 116 |
| 6.10 | AT+CPSMS – Power saving mode setting..... | 118 |
| 6.11 | AT+CPWD – Change password..... | 120 |
| 6.12 | AT+CTZR – Time Zone Reporting..... | 121 |
| 7 | SMS commands | 123 |
| 7.1 | AT+CMGF – Message Format | 123 |
| 7.2 | AT+CMGS – Send Message..... | 124 |
| 7.3 | AT+CNMA – New Message Acknowledgement | 126 |
| 7.4 | AT+CNMI – New Message Indication | 127 |
| 7.5 | AT+CSCA – Service Center Address..... | 129 |
| 7.6 | AT+CSMS – Select SMS Message Service | 130 |
| 8 | USIM commands..... | 131 |
| 8.1 | AT+CCHC – Close logical channel..... | 131 |
| 8.2 | AT+CCHO – Open logical channel..... | 132 |
| 8.3 | AT+CGLA – Generic UICC logical channel access | 133 |
| 8.4 | AT+CRSM – Restricted SIM access..... | 134 |
| 8.5 | AT+CSIM – Generic SIM access..... | 136 |
| 8.6 | AT+ICCID – Request Integrated Circuit Card IDentifier..... | 137 |

| | | |
|-------|---|-----|
| 9 | TCP-IP commands..... | 138 |
| 9.1 | AT#IPCFG – IPv4 or IPv6 configuration..... | 138 |
| 9.2 | AT#IPDEL – Delete IP configuration..... | 140 |
| 9.3 | AT#IPPARAMS – IP stack configuration..... | 141 |
| 9.4 | AT#IPPING – ICMPv4/v6 request (ping)..... | 142 |
| 9.5 | AT#IPREAD – Read data available in TCP or UDP receiving buffer | 144 |
| 9.6 | AT#IPSENDTCP – Send data over an established socket using TCP protocol | 145 |
| 9.7 | AT#IPSENDUDP – Send data using UDP protocol..... | 146 |
| 9.8 | AT#SOCKETCLOSE – Close a socket identify by the context number | 147 |
| 9.9 | AT#SOCKETCREATE – Create a new socket on top of an existing IPv4/v6 link..... | 148 |
| 9.10 | AT#TCPCONNECT – Establish a TCP link using a configured IP socket..... | 150 |
| 10 | HTTP commands..... | 151 |
| 10.1 | AT#HTTPMETHOD – Send a method on an established HTTP session..... | 151 |
| 10.2 | AT#HTTPSTART – Start the HTTP protocol stack | 152 |
| 10.3 | AT#HTTPSTOP – Stop the HTTP protocol stack | 153 |
| 11 | MQTT commands | 154 |
| 11.1 | AT#MQTTCFG – Configure the MQTT protocol stack..... | 154 |
| 11.2 | AT#MQTTCONNECT – connect to a MQTT server..... | 155 |
| 11.3 | AT#MQTTDISC – Disconnect from a MQTT server..... | 156 |
| 11.4 | AT#MQTTPUB – Publish a message for the specified topic | 157 |
| 11.5 | AT#MQTTSUB – Subscribe to specified topic..... | 158 |
| 11.6 | AT#MQTTUNSUB – UnSubscribe from the specified topic..... | 159 |
| 12 | CoAP commands..... | 160 |
| 12.1 | AT#COAPCFG – Configure the CoAP service | 160 |
| 12.2 | AT#COAPCMD – Send a CoAP command to the CoAP server | 161 |
| 12.3 | AT#COAPCONNECT – Connect to CoAP server..... | 162 |
| 12.4 | AT#COAPDISCONNECT – Disconnect from a CoAP server..... | 163 |
| 12.5 | AT#COAPSTART – Start COAP service..... | 164 |
| 12.6 | AT#COAPSTOP – Stop the COAP service | 165 |
| 13 | LwM2M commands..... | 166 |
| 13.1 | AT#LWADDOBJ – Add a LwM2M object | 166 |
| 13.2 | AT#LWCFG – LwM2M configuration | 167 |
| 13.3 | AT#LWCHGRSCVAL– Change a LwM2M resource value..... | 169 |
| 13.4 | AT#LWDUMPOBJ – Dump the content of a LwM2M object..... | 170 |
| 13.5 | AT#LWLSTOBJ – List LwM2M objects..... | 171 |
| 13.6 | AT#LWLSTSERV – List LwM2M servers..... | 172 |
| 13.7 | AT#LWREADRSCVAL– HOST reads LwM2M resource value | 173 |
| 13.8 | AT#LWNTYTO – LwM2M Custom object response time out for Service Notification | 174 |
| 13.9 | AT#LWNTYXEEOBJ – LwM2M Custom object response for Execution Notification..... | 175 |
| 13.10 | AT#LWNTYRDOBJ – LwM2M Custom object response for Read Notification | 176 |
| 13.11 | AT#LWNTYWROBJ – LwM2M Custom object response for Write Notification..... | 178 |
| 13.12 | AT#LWREG – Register to LwM2M server | 179 |
| 13.13 | AT#LWRMOBJ – Remove a LwM2M object..... | 180 |
| 13.14 | AT#LWSTART – Start LwM2M client service..... | 181 |
| 13.15 | AT#LWSTOP – Stop the LwM2M client..... | 182 |
| 14 | TLS commands..... | 183 |
| 14.1 | AT#TLCERTADD - Add X.509 DER certificate or PSK identity..... | 183 |
| 14.2 | AT#TLCERTDEL - Remove certificate in a security profile..... | 184 |
| 14.3 | AT#TLCERTLIST - List stored certificates/PSK identities..... | 185 |
| 14.4 | AT#TLCERTSIGN - Sign a Certificate Signing Request form (CSR)..... | 186 |
| 14.5 | AT#TLSKEYADD – Store a secret key and bind it to a security profile..... | 187 |
| 14.6 | AT#TLSKEYDEL - Remove the secret key in a security profile..... | 188 |
| 14.7 | AT#TLSKEYLIST - List stored keys..... | 189 |
| 15 | GNSS commands | 190 |
| 15.1 | AT#GNSSINIT – GNSS Init..... | 190 |

| | | |
|------|--|-----|
| 15.2 | AT#GNSSDEINIT – GNSS service un-initialize and stop..... | 192 |
| 15.3 | AT#GNSSFIX – GNSS Start or Stop Fix..... | 193 |
| 15.4 | AT#GNSSSV – GNSS Space Vehicles URC configuration..... | 195 |
| 16 | FOTA commands..... | 196 |
| 16.1 | AT#FOTACFG – Configure the FOTA services..... | 196 |
| 16.2 | AT#FOTADL – Download FOTA image | 197 |
| 16.3 | AT#FOTALNCHUP – Update FOTA image..... | 199 |
| 17 | Unsolicited Response Code (URC)..... | 201 |
| 17.1 | URC List..... | 201 |
| 18 | Error codes..... | 204 |
| 18.1 | Modem generic error code | 204 |
| 18.2 | Modem custom error code..... | 207 |
| 18.3 | Secure core error code | 208 |
| 18.4 | Application core error code..... | 210 |

1.5 List of tables

| | | |
|----------|---------------------------------|---|
| Table 1. | Definitions of terms..... | 2 |
| Table 2. | Document references | 3 |
| Table 3. | Document revision history | 4 |
| Table 4. | AT command format..... | 9 |

2 Introduction

2.1 AT command syntax

All the commands start with the "AT" prefix and ends with a carriage return character <CR>.

Responses start with a carriage return and a line feedback character and end with a carriage return and a line feedback character <CR><LF><response><CR><LF>

Throughout the document the <CR> and <LF> characters are omitted for the sake of readability.

The AT Command set implemented in the ST87MXX is a combination of 3GPP TS 27.005, 3GPP TS 27.007 and ITU-T recommendation V.25ter and the AT proprietary commands developed by ST. The proprietary ST commands are formatted as follow: AT#CMD.

Each AT command is described using the following format:

Table 4. AT command format

| Command type | Syntax | Description |
|-------------------|---------------------------------|---|
| Test command | AT+CMD=? | Gives information about the type, value, or range of its parameter. |
| Read command | AT+CMD? | Checks the current parameter value |
| Write Command | AT+CMD=<param1>[,<param2>,...]] | Sets parameter value. |
| Execution command | AT+CMD | Performs a specific action. |

For a given AT command, if a command type is not described in the document this means that it doesn't exist.

3 Generic System commands

3.1 ATE – Set Command Echo Mode

This setting determines whether the TA echoes characters received from TE during command state.

| ATE – Set Command Echo Mode | |
|-----------------------------|--|
| Execution Command | ATE<value> |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameter | <value> |
| <value> | Integer type 0: Echo mode off 1: Echo mode on |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | SAVED to NVM using AT#RESET=1 Takes effect immediately. |
| Reference | ITU-T V.250 |

Note: if parameter is omitted, the ATE command behaves the same way as ATE1.

3.2 ATI – Display product identification information

This Execution Command returns product information including hardware and software versions.

| ATI – Display product identification information | |
|--|--|
| Execution Command | ATI |
| Response | STMICROELECTRONICS ST87M01 <software_version> OK |
| Parameters | <software_version> |
| <software_version> | String type The format is "A:maj.min.rc-M:maj.min.rc-S:maj.min.rc-G:maj.min.rc", where "maj" characters indicate major version, "min" characters indicate minor version, "rc" characters indicate Release Candidate version |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | ITU-T V.250 |

3.3 AT+CCLK – Set and get current date and time

The write command sets the real-time clock. RTC is automatically synchronized once UE has received EMM INFORMATION signalling. The read command returns the current setting of the clock.

| AT+CCLK – Set and get current date and time | |
|---|---|
| Test Command | AT+CCLK=? |
| Response | +CCLK: "yy/mm/dd,hh:mm:ss+zz" OK |
| Read Command | AT+CCLK? |
| Response | +CCLK: <date_and_time> OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Set Command | AT+CCLK=<date_and_time> |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <date_and_time> |
| <date_and_time> | String type The format is "YY/MM/DD,hh:mm:ss±zz", where characters indicate year (two last digits), month, day, hour, minute, second and time zone (indicates the difference, expressed in quarters of an hour, between the local time and GMT; the range is -96 to +96). For instance, "6th of May 2014, 22:10:00 GMT+2" equals "14/05/06,22:10:00+08" |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | SAVED in NVM. Takes effect immediately. |
| Reference | 3GPP TS 27.007 |

3.4 AT+CFUN – Set modem functionality

The set command selects the level of functionality in the UE.

| AT+CFUN – Set modem functionality | |
|-----------------------------------|--|
| Test Command | AT+CFUN=? |
| Response | +CFUN: (list of supported <fun>),(list of supported <rst>) OK |
| Read Command | AT+CFUN? |
| Response | +CFUN: <fun> OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Set Command | AT+CFUN=<fun> |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <fun>,<rst> |
| <fun> | Integer type When <fun> is '0', "minimum functionality" is selected. Transmit and receive RF circuits are disabled. When <fun> is '1', "full functionality" is selected. Transmit and receive RF circuits are enabled for all the supported radio access technologies. |
| <rst> | <rst> defines the functionality level at reset. The functionality level at reset cannot be modified and is set as "full functionality" by default. This explains why the list of supported values for <rst> that is returned by the test command "AT+CFUN=?" is empty. |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | 3GPP TS 27.007 |

3.5 AT+CGMI – Request manufacturer identification

AT+CGMI command execution causes the UE to return the manufacturer identification of the UE it is connected to.

| AT+CGMI – Request manufacturer identification | |
|---|---|
| Test Command | AT+CGMI=? |
| Response | +CGMI: <manufacturer id> OK |
| Execution Command | AT+CGMI |
| Response | <manufacturer_id> OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <manufacturer id> |
| <manufacturer_id> | String without double quote that is manufacturer id of the UE |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | 3GPP TS 27.007 |

Informative example:

To get the manufacturer id of the UE:

```
AT+CGMI
001010123456063
OK
```

3.6 AT+CGMM – Request model identification

AT+CGMM command execution causes the UE to return the model identification of the UE it is connected to (e.g. name of the product).

| AT+CGMM – Request model identification | |
|--|--|
| Test Command | AT+CGMM=? |
| Response | +CGMM: <model_id> OK |
| Execution Command | AT+CGMM |
| Response | <model_id> OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <model_id> |
| <model_id> | String without double quote that is model id of the UE |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | 3GPP TS 27.007 |

Informative example:

To get the model id of the UE:

```
AT+CGMM
ST87M01
OK
```

3.7 AT+CGMR – Request revision identification

AT+CGMR command execution causes the UE to return the revision identification of the UE it is connected to.

| AT+CGMR – Request revision identification | |
|---|---|
| Test Command | AT+CGMR=? |
| Response | +CGMR: <revision_id> OK |
| Execution Command | AT+CGMR |
| Response | <revision_id> OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <revision_id> |
| <revision_id> | String without double quote that is revision id of the UE |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | 3GPP TS 27.007 |

Informative example:

To get the revision id of the UE:

AT+CGMR

A:1.1.4-M:1.0-S:1.1.4

OK

3.8 AT+CGSN – Request product serial number identification

This command returns one of the User Equipment identifiers.

| AT+CGSN – Request product serial number identification | |
|--|--|
| Test Command | AT+CGSN=? |
| Response | +CGSN: (list of supported <snt>) OK |
| Execution Command | AT+CGSN[=<snt>] |
| Response | +CGSN: [<sn>] OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <snt>,<sn>,<imei>,<imeisv>,<svn> |
| <snt> | Integer type Serial Number Type: 0-3 |
| <sn> | When <snt> is omitted or is '0', <sn> is equal to <imei>. When <snt> is '1', <sn> is equal to <imei> When <snt> is '2', <sn> is equal to <imeisv> When <snt> is '3', <sn> is equal to <svn> |
| <imei> | String with 14 digits, in decimal format, composed of the Type Allocation Code (TAC - 8 digits), Serial Number (SNR – 6 digits) and Check Digit (CD – 1 digit). |
| <imeisv> | String with 16 digits, in decimal format, indicating the IMEISV that is the concatenation of the Type Allocation Code (TAC - 8 digits), Serial Number (SNR – 6 digits) and the Software Version Number (SVN - 2 digits). |
| <svn> | String with 2 digits, in decimal format, indicating the Software Version Number (SVN - 2 digits). |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | 3GPP TS 27.007 |

Informative examples:

To get <sn> which returns IMEI of the UE:

```
AT+CGSN
"455201033543990"
OK
```

To get <imei> which returns IMEI of the UE:

```
AT+CGSN=1
+CGSN: "455201033543990"
OK
```

To get <imeisv> which returns IMEI without DC and SVN of the UE:

```
AT+CGSN=2
+CGSN: "4552010335439970"
OK
```

3.9 AT+CIMI – Request international mobile subscriber identity

AT+CIMI command execution causes the UE to return the International Mobile Subscriber Identity that is intended to identify the individual SIM card or active application in the UICC which is attached to UE.

| AT+CIMI – Request international mobile subscriber identity | |
|--|--|
| Test Command | AT+CIMI=? |
| Response | +CIMI: <imsi> OK |
| Execution Command | AT+CIMI |
| Response | [<imsi>] OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <imsi> |
| <imsi> | String without double quote that is International Mobile Subscriber Identity |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | 3GPP TS 27.007 |

Informative example:

To get <imsi> of the UE:

AT+CIMI

001010123456063

OK

3.10 AT+CMEE – Report Mobile Termination Error

This command disables or enables the use of the final result code +CME ERROR: <err> as an indication of an error relating to the functionality of MT.

| AT+CMEE – Report Mobile Termination Error | |
|---|---|
| Test Command | AT+CMEE=? |
| Response | +CMEE: <supported range> OK |
| Read Command | AT+CMEE? |
| Response | +CMEE: <n> OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Set Command | AT+CMEE=<n> |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <n> |
| <n> | Integer type Enable/disable the use of result code +CME ERROR: <err>. 0: disables result code 1: enables result code and use numeric values 2: enables result code and use verbose values |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | SAVED in NVM using AT#RESET=1 Takes effect immediately. |
| Reference | 3GPP TS 27.005 / 3GPP TS 27.007 |

3.11 AT+CMUX – Multiplexing mode

In mobile networks, in a user equipment (UE), the terminal adapter (TA) is used by the terminal equipment (TE) to access the mobile termination (MT) using AT commands. The +CMUX AT command helps configure the link between the TE and the TA.

This command is used to enable/disable the 3GPP TS 27.010 multiplexing protocol control channel. The AT command sets parameters for the Control Channel. If the parameters are left out, the default value is used.

Read command returns the current settings.

Test command returns the supported parameter values.

It is recommended that the MT/TA/TE should autobaud to the +CMUX command up to and including an interface speed of 9600 bits/s.

The OK or +CME ERROR: <err> response is returned at the speed of the +CMUX command prior to entering <transparency>.

It is recommended that whenever the multiplexer control channel is released the MT/TA/TE should assume an interface rate of up to and including 9600 bits/s for auto-baud purposes irrespective of any previous higher speed having been selected.

If a +CMUX command is issued whilst in any multiplexer mode, then that +CMUX command is ignored, and the MT/TA shall return a +CME ERROR: <err> response.

| AT+CMUX – Multiplexing mode | |
|-----------------------------|--|
| Test Command | AT+CMUX=? |
| Response | +CMUX: (list of supported <transparency>),(list of supported <subset>),(list of supported <port speed>),(list of supported <N1>),(list of supported <T1>),(list of supported <N2>),(list of supported <T2>),(list of supported <T3>),(list of supported <k>) OK |
| Read Command | AT+CMUX? |
| Response | +CMUX: <transparency>,<subset>,<port speed>,<N1>,<T1>,<N2>,<T2>,<T3>,<k> OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Set Command | AT+CMUX=<transparency>[,<subset>[,<port_speed>[,<N1>[,<T1>[,<N2>[,<T2>[,<T3>[,<k>]]]]]]] |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <transparency>,<subset>,<port_speed>,<N1>,<T1>,<N2>,<T2>,<T3>,<k> |
| <transparency> | Integer type Multiplexer Transparency Mechanism |

| | |
|-----------------------|--|
| | When <transparency> is '0', basic option is selected. When <transparency> is '1', advanced option is selected. |
| <subset> | Integer type Defines the way in which the multiplexer control channel is set up. A virtual channel may subsequently be set up differently but in the absence of any negotiation for the settings of a virtual channel, the virtual channel shall be set up according to the control channel <subset> setting. When '0', UIH frames used only When '1', UI frames used only When '2', I frames used only |
| <port_speed> | Integer type Transmission rate 1: 9 600 bit/s 2: 19 200 bit/s 3: 38 400 bit/s 4: 57 600 bit/s 5: 115 200 bit/s 6: 230 400 bits/s |
| <N1> | Integer type Maximum frame size (1-32768): where 31 is the default value for Basic option and 64 is the default value for Advanced option (see <transparency>) |
| <T1> | Integer type Acknowledgement timer in units of ten milliseconds (1-255): where 10 is the default value (100 ms) |
| <N2> | Integer type Maximum number of re-transmissions (0-100): where 3 is the default value |
| <T2> | Integer type Response timer for the multiplexer control channel in units of ten milliseconds (2-255): where 30 is the default value (300 ms) Note:T2 must be longer than T1 |
| <T3> | Integer type Wake up response timer in seconds) (1-255): where 10 is the default value |
| <k> | Integer type Window size, for Advanced option with Error-Recovery Mode (1-7): where 2 is the default value |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | 3GPP TS 27.007 |

3.12 AT+CRC – Cellular result codes

Sets command controls whether the extended format of network request for PDP context activation is used or not.

| AT+CRC – Cellular result codes | |
|--------------------------------|--|
| Test Command | AT+CRC=? |
| Response | +CRC: (list of supported <mode>) OK |
| Read Command | AT+CRC? |
| Response | +CRC: <mode> OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Set Command | AT+CRC=<mode> |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <mode>,<type>,<priority>,<subaddr>,<satype> |
| <mode> | Integer type 0: extended format is disabled 1: extended format is enabled |
| <type> | ASYN [,<priority>,<subaddr>,<satype>]: asynchronous transparent SYNC [,<priority>,<subaddr>,<satype>]: synchronous transparent REL ASYN [,<priority>,<subaddr>,<satype>]: asynchronous non-transparent REL SYNC [,<priority>,<subaddr>,<satype>]: synchronous non-transparent |
| <priority> | Indicates the eMLPP priority level of the notification or setup message. The priority level values are as defined in eMLPP specification 3GPP TS 22.067. |
| <subaddr> | String type sub-address of format specified by <satype> |
| <satype> | Type of <subaddr> octet in integer format (refer 3GPP TS 24.008 subclause 10.5.4.8) or RFC 4715 appendix A. |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA. |
| Reference | 3GPP TS 27.007, 3GPP TS 24.008, 3GPP TS 22.067, TIA IS-99 and TIA IS-135 |

3.13 AT+IPR – Set device UART baudrate

| AT+IPR – Set device UART baudrate | |
|-----------------------------------|---|
| Test Command | AT+IPR=? |
| Response | +IPR: (list of supported <rate>) OK |
| Read Command | AT+IPR? |
| Response | +IPR: <rate> |
| Set Command | AT+IPR=<rate> |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameter | <rate> |
| <rate> | Integer type Baudrate: 9600, 19200, 38400, 57600, 15200, 230400, 460800. Default value is 460800. |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | SAVED to NVM using AT#RESET=1 Takes effect immediately. |
| Reference | ITU-T V.250 |

Note:

When set command is used, the 'OK' response is sent using the new baudrate, otherwise, it is sent with the original baudrate.

3.14 AT#SIMST – Report SIM status

This Read Command reports the current SIM status.

| AT#SIMST – SIM status | |
|-----------------------|--------------------------------|
| Read Command | AT#SIMST? |
| Response | #SIMST: <status> OK |
| Parameters | <status> |
| <status> | 0: SIM invalid 1: SIM valid |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | 3GPP TS 27.007 |

4 Custom System commands

4.1 AT#BANDSEL – Enable or Disable RF bands

| AT#BANDSEL – Enable or disable RF Bands | |
|---|--|
| Test Command | AT#BANDSEL=? |
| Response | #BANDSEL: <supported_bands> OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Read Command | AT#BANDSEL? |
| Response | #BANDSEL: <active_bands> OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Set Command | AT#BANDSEL=<band>[,<band>[,...]] |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <supported_bands>,<active_bands>,<band> |
| <supported_bands> | List of integers List of band number(s), separated by commas, that are supported by the module. |
| <active_bands> | List of integers List of band number(s), separated by commas, for the band(s) that is(are) enabled. Active band(s) is(are) part of supported band(s). |
| <band> | Integer type Band number(s) for the band(s) to enable or disable |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | SAVED to NVM using AT#RESET=1 Takes effect after module reboot |
| Reference | Custom |

Informative examples:

The AT command AT#BANDSEL can be used to get or set the NB-IoT RF bands where the UE is allowed to scan and connect.

Response to AT command 'AT#BANDSEL=?' returns the list of supported RF bands. For example:

```
AT#BANDSEL=?
#BANDSEL:1,3,8,71
OK
```

The list of active bands is returned from the following command:

```
AT#BANDSEL?  
#BANDSEL:3,8  
OK
```

The following AT command enables bands B3 and B8:
AT#BANDSEL=3,8

4.2 AT#BANDCFG – Supported RF bands

AT#BANDCFG set command configures the band usage and the band split among the network mobile operators (NMO).

| AT#BANDCFG – Configure band usage | |
|-----------------------------------|---|
| Test Command | AT#BANDCFG=? |
| Response | #BANDCFG: <id>,<0>,<band>,<option>,<start100k> #BANDCFG: <id>,<nmo>,<pref>,<guard>,<in>,<bw100k>,<offset100k> OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Read Command | AT#BANDCFG? |
| Response | #BANDCFG0: Band=0, Option=0, StartFreq=0 Pref=0, Guard=0, In=0, BW=0, OffsetFreq=0 Pref=0, Guard=0, In=0, BW=0, OffsetFreq=0 Pref=0, Guard=0, In=0, BW=0, OffsetFreq=0 Pref=0, Guard=0, In=0, BW=0, OffsetFreq=0 Pref=0, Guard=0, In=0, BW=0, OffsetFreq=0 ... #BANDCFG4: Band=0, Option=0, StartFreq=0 Pref=0, Guard=0, In=0, BW=0, OffsetFreq=0 Pref=0, Guard=0, In=0, BW=0, OffsetFreq=0 Pref=0, Guard=0, In=0, BW=0, OffsetFreq=0 Pref=0, Guard=0, In=0, BW=0, OffsetFreq=0 Pref=0, Guard=0, In=0, BW=0, OffsetFreq=0 OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Set Command | AT#BANDCFG=<id>,<0>,<band>,<option>,<start100k> or AT#BANDCFG=<id>,<nmo>,<pref>,<guard>,<in>,<bw100k>,<offset100k> |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <id>,<band>,<option>,<start100k>,<nmo>,<pref>,<guard>,<in>,<bw100k>,<offset100k> |
| <id> | Integer type BAND_NMO_CONFIG entry identifier in NVM Valid values are from 0 to 4. |
| <band> | Integer type Band number for the band to configure. |
| <option> | Integer type Bitmap to select option. |
| <start100k> | Integer type Start Frequency of the band to configure (left edge of the band). Unit is |

| | |
|-----------------------|---|
| | 100kHz. |
| <nmo> | Integer type NMO id. Valid values are from 1 to 5. |
| <pref> | Boolean type Indicates that the corresponding NMO is the preferred NMO |
| <guard> | Integer type Indicates that NBIOT is deployed in the NMO band using guard band and provides its priority for the initial cell search. Valid values are from 0 to 2. |
| <in> | Integer type Indicates that NBIOT is deployed in the NMO band using in band and provides its priority for the initial cell search. Valid values are from 0 to 2. |
| <bw100k> | Integer type This is the NMO bandwidth. Unit is 100 kHz |
| <offset100k> | Integer type This is the frequency offset versus band left edge. Unit is 100 kHz |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | SAVED to NVM using AT#RESET=1 Takes effect after module reboot |
| Reference | Custom |

Note:

The AT command AT#BANDCFG can be used to get or set the NVM parameters that configure the band usage and split between various NMO. These parameters are used by modem software to prioritize the initial cell search, leading to shorter attach time.

Response to AT command 'AT#BANDCFG?' returns the current configuration in NVM.

4.3 AT#GETTEMP – Read the internal temperature

| AT#GETTEMP – Get the internal temperature of the module | |
|---|---|
| Test Command | AT#GETTEMP=? |
| Response | #GETTEMP OK |
| Read Command | AT#GETTEMP? |
| Response | #GETTEMP: <temp> OK |
| Parameter | <temp> |
| <temp> | Value of Temperature in Celsius degrees |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | Custom |

4.4 AT#GETVBAT – Read the voltage battery supply

| AT#GETVBAT – Read the voltage battery supply | |
|--|---------------------------------|
| Test Command | AT#GETVBAT=? |
| Response | #GETVBAT OK |
| Read Command | AT#GETVBAT? |
| Response | #GETVBAT: <vbat> OK |
| Parameters | <vbat> |
| <vbat> | Voltage of battery supply in mV |
| Parameter Saving Mode | NA |
| Reference | Custom |

4.5 AT#ADCGETRAW – Read the ADC raw value from an ADC Channel

AT#ADCGETRAW reads the raw data from an ADC channel.

| AT#ADCGETRAW – Read the raw data from an ADC channel | |
|--|---|
| Test Command | AT#ADCGETRAW=? |
| Response | #ADCGETRAW: <channel>,<divider> OK |
| Set Command | AT#ADCGETRAW=<channel>,<divider> |
| Response | #ADCGETRAW: <channel>,<result> OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <channel>,<divider>,<result> |
| <channel> | Integer type 1: user1 2: user2 3: internal temperature channel P 4: internal temperature channel N 7: vbat |
| <divider> | Integer type 0: No Divider 1: Divider enabled with ratio 3.3V/1.1V 2: Divider enabled with ratio 1.8V/1.1V |
| <result> | Result of the conversion in ADC code |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | Custom |

4.6 AT#ADCGETUSER – Read the user ADC channel in ADC steps or in mV

| AT#ADCGETUSER – Read the ADC user channels in ADC steps or in mV | |
|--|---|
| Test Command | AT#ADCGETUSER=? |
| Response | #ADCGETUSER: <channel>,<divider>,<format> OK |
| Set Command | AT#ADCGETUSER=<channel>,<divider>,<format> |
| Response | #ADCGETUSER: <channel>,<adc_value> OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <channel>, <divider>, <format>, <adc_value> |
| <channel> | Integer type 1: User1 2: User2 |
| <divider> | Integer type 0: No Divider 1: Divider enabled with ratio 3.3V/1.1V 2: Divider enabled with ratio 1.8V/1.1V |
| <format> | Integer type 0: Data in ADC steps 1: Data in mV |
| <adc_value> | ADC value |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | Custom |

4.7 AT#GPIOCFG – Set or Get the GPIO Mode of a GPIO

AT#GPIOCFG command is used to set the GPIO Mode or to get the GPIO mode when GPIO Id is provided as unique parameter.

| AT#GPIOCFG – Set or Get the GPIO Mode of a GPIO | |
|---|---|
| Test Command | AT#GPIOCFG=? |
| Response | #GPIOCFG: <gpio_id>[,<gpio_mode>[,<format>]] OK |
| Set Command | AT#GPIOCFG=<gpio_id>[,<gpio_mode>[,<format>]] |
| Response | #GPIOCFG: <gpio_id>,<gpio_mode>,<format> OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <gpio_id>,<gpio_mode>,<format> |
| <gpio_id> | Integer type ID (between 16 and 31) |
| <gpio_mode> | Integer type 0: GPIO Input Mode 1: GPIO Output Mode, Push-Pull Mode 2: GPIO Input Mode, Pull-Up enable 3: GPIO Input Mode, Pull-Down enable 4: GPIO Output Mode, Open Drain Mode 5: GPIO Output Mode, Open Drain Mode, Pull-up enable 6: GPIO Output Mode, Open Drain Mode, Pull-down enable |
| <format> | Integer type If GPIO in input mode, <format> selects the interrupt configuration: 0: IT Disable (default) 1: IT triggered on falling edge 2: IT triggered on raising edge 3: IT triggered on both edges If GPIO in output mode, <format> selects the initialization level: 0: low level (default) 1: high level |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | SAVED in NVM after AT#RESET=1 Takes effect immediately |
| Reference | Custom |

4.8 AT#GPIORD – Read the level of a GPIO

| AT#GPIORD – Read the level of a GPIO | |
|--------------------------------------|---|
| Test Command | AT#GPIORD=? |
| Response | #GPIORD: <gpio_id> OK |
| Set Command | AT#GPIORD=<gpio_id> |
| Response | #GPIORD: <gpio_id>,<gpio_level> OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <gpio_id>,<gpio_level> |
| <gpio_id> | Integer type ID between 16 and 31 |
| <gpio_level> | Integer type 0: Low level 1: high level |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | Custom |

4.9 AT#GPIOWR – Writes the level of a GPIO

AT#GPIOWR command is used to write a low level or a high level on a GPIO.

| AT#GPIOWR – Writes the level of a GPIO | |
|--|--|
| Test Command | AT#GPIOWR=? |
| Response | #GPIOWR: <gpio id>,<gpio level> OK |
| Set Command | AT#GPIOWR=<gpio_id>,<gpio_level> |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <gpio id>,<gpio level> |
| <gpio_id> | Integer type ID between 16 and 31 |
| <gpio_level> | Integer type 0: Low level 1: High level. |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | Custom |

4.10 AT#GPIOJTAGCFG – Configure the GPIO in JTAG mode

| AT#GPIOJTAGCFG – Configure the GPIO in JTAG mode | |
|--|--|
| Test Command | AT#GPIOJTAGCFG=? |
| Response | #GPIOJTAGCFG: <core>,<enable> OK |
| Set Command | AT#GPIOJTAGCFG=<core>,<enable> |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <core>,<enable> |
| <core> | Integer type ID (between 0 and 2) of whose JTAG is associated to. 0: APP 1: MODEM 2: SECURE. |
| <enable> | Integer type 0 (disable) or 1 (enable). |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | SAVED to NVM using AT#RESET=1 Takes effect after module reboot |
| Reference | Custom |

4.11 AT#GPIOI2CCFG – Configure the GPIO in I2C mode

| AT#GPIOI2CCFG – Configure the GPIO in I2C mode | |
|--|--|
| Test Command | AT#GPIOI2CCFG=? |
| Response | #GPIOI2CCFG: <port_number>,<enable> OK |
| Set Command | AT#GPIOI2CCFG=<port_number>,<enable> |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <port_number>,<enable> |
| <port_number> | Integer type Indicates the I2C port number. 0: I2C0 1: I2C1 |
| <enable> | Integer type 0: disable 1: enable |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | SAVED to NVM using AT#RESET=1 Takes effect after module reboot |
| Reference | Custom |

4.12 AT#GPIOSPICFG – Configure the GPIO in SPI mode

AT#GPIOSPICFG command is used to configure the GPIO in SPI mode. The management of the CS pin is performed in software by utilizing the AT#GPIOWR AT command, which can be applied to any pin set in output mode.

| AT#GPIOSPICFG – Configure the GPIO in SPI mode | |
|--|--|
| Test Command | AT#GPIOSPICFG=? |
| Response | #GPIOSPICFG: <config_number>,<enable> OK |
| Set Command | AT#GPIOSPICFG=<config_number>,<enable> |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <config_number>,<enable> |
| <config_number> | Integer type ID indicating the SPI config number. 0: SPI on GPIO12, GPIO13 and GPIO14 1: SPI on GPIO27, GPIO29 and GPIO30 |
| <enable> | 0 (disable) or 1 (enable). |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | SAVED to NVM using AT#RESET=1 Takes effect after module reboot |
| Reference | Custom |

4.13 AT#GPIUART1CFG – Configure the GPIO in UART1 mode

AT#GPIUART1CFG command is used to configure the GPIO in UART1 mode.

| AT#GPIUART1CFG – Configure the GPIO in UART1 mode | |
|---|--|
| Test Command | AT#GPIUART1CFG=? |
| Response | #GPIUART1CFG: <config_number>,<enable> OK |
| Set Command | AT#GPIUART1CFG=<config_number>,<enable> |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <config_number>,<enable> |
| <config_number> | Integer type ID (between 0 and 1) indicating the UART1 config number. 0: UART1 on GPIO15 and GPIO16 1: UART1 on GPIO21 and GPIO22 |
| <enable> | Integer type 0: disable 1: enable |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | SAVED to NVM using AT#RESET=1 Takes effect after module reboot |
| Reference | Custom |

4.14 AT#GPIOADCCFG – Configure the GPIO in ADC mode

| AT#GPIOADCCFG – Configure the GPIOs in ADC mode | |
|---|---|
| Test Command | AT#GPIOADCCFG=? |
| Response | #GPIOADCCFG: <adc_bitmap> OK |
| Read Command | AT#GPIOADCCFG? |
| Response | <adc_bitmap> OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Set Command | AT#GPIOADCCFG=<adc_bitmap> |
| Response | OK |
| Response If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <adc_bitmap> |
| <adc_bitmap> | Integer type 0: ADC0 and ADC1 are disabled 1: ADC0 is enabled and ADC1 is disabled 2: ADC0 is disabled and ADC1 is enabled 3: ADC0 and ADC1 are enabled |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | SAVED to NVM using AT#RESET=1 Takes effect after module reboot |
| Reference | Custom |

4.15 AT#LEDCFG – Enable or disable LED status

AT#LEDCFG is used to configure the LED status (enable or disable)

| AT#LEDCFG – Enable or disable LED status | |
|--|---|
| Test Command | AT#LEDCFG=? |
| Response | #LEDCFG: <status> OK |
| Read Command | AT#LEDCFG? |
| Response | #LEDCFG: <status> OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Set Command | AT#LEDCFG=<status> |
| Response | OK |
| Response If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <status> |
| <status> | 0: LED0 and LED1 are disabled 1: LED0 is enabled and LED1 is disabled 2: LED0 is disabled and LED1 is enabled 3: LED0 and LED1 are enabled |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | SAVED to NVM using AT#RESET=1 Takes effect after module reboot |
| Reference | Custom |

4.16 AT#LOCKFREQ – Lock to a specific frequency

| AT#LOCKFREQ – Lock the Modem to a specific frequency | |
|--|---|
| Test Command | AT#LOCKFREQ=? |
| Response | #LOCKFREQ: <enable>,<earfcn> OK |
| Read Command | AT#LOCKFREQ? |
| Response | #LOCKFREQ: <enable>[,<earfcn>] OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Set Command | AT#LOCKFREQ=<enable>[,<earfcn>] |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <enable>,<earfcn> |
| <enable> | Integer type 0: disable frequency locking 1: enable frequency locking, need to provide <earfcn> parameter |
| <earfcn> | Integer type EARCN as defined in ETSI TS 136 521-1 |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | 3GPP TS 36.106, ETSI TS 136 521-1, Custom |

4.17 AT#PWROFF – Powers module off

AT#PWROFF sets the module in “power off” mode. The only way to power the module back on is to wake it up by using power on key or UART character. At module power off, the NVM parameters are saved.

| AT#PWROFF – Powers module off | |
|-------------------------------|---------------------------------|
| Test Command | AT#PWROFF=? |
| Response | #PWROFF OK |
| Execution Command | AT#PWROFF |
| Response | OK #SHUTDOWN |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | Custom |

4.18 AT#RESET – Module reset

| AT#RESET – Module reset | |
|-------------------------|---|
| Test Command | AT#RESET=? |
| Response | #RESET: <type> OK |
| Set Command | AT#RESET=<type> |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Execution Command | AT#RESET |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <type> |
| <type> | Integer type 0: Reset without saving the latest custom command updates 1: Reset and saves the latest custom command updates 2: Reset and make a FOTA validation of the image 3: Reset and make a FOTA roll back |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | Custom |

4.19 AT#RFACTORY – Reboot with a factory configuration

AT#RFACTORY sets the user parameters with their default values and saves them to NVM. The module reboots with these default parameters.

| AT#RFACTORY – Reboot with a factory configuration | |
|---|---|
| Test Command | AT#RFACTORY=? |
| Response | #RFACTORY:[<app_filter>,<modem_filter>,<secure_filter>] OK |
| Set Command | AT#RFACTORY[=<app_filter>,<modem_filter>,<secure_filter>] |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <app_filter>,<modem_filter>,<secure_filter> |
| <app_filter> | Integer type Reset factory filter for the application core: 0: no action 1: user parameters reset to default values |
| <modem_filter> | Integer type. Bitmap value: Bit 0: reset list of candidate frequencies in NVM to none. Bit 1: reset SIM parameters in NVM. Bit 2: reset list of candidate PLMNs in NVM to none. Bit 4: reset list of static candidate frequencies in NVM to none. Bit 15: reset PS customer parameters to default values. When <modem_filter> == 0x0: no action is performed When <modem_filter> == 0x8000: PS parameters in NVM are reset to default values. This is exclusive to any other action: setting bits 0, 1, 2 or 4 together with bit 15 would have no effect except resetting PS parameters in NVM to default values. |
| <secure_filter> | Integer type Reset factory filter for the secure core: 0: no action 1: user parameters reset to default values |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | Custom |

4.20 AT#SLEEPIND – Enable or disable the URC messages related to sleep mode

| AT#SLEEPIND – Enable or disable the URC messages related to sleep mode | |
|--|---|
| Test Command | AT#SLEEPIND=? |
| Response | #SLEEPIND: <msg_ind> OK |
| Read Command | AT#SLEEPIND? |
| Response | #SLEEPIND: <msg_ind> OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Set Command | AT#SLEEPIND=<msg_ind> |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <msg_ind> |
| <msg_ind> | Bitmap when bit set, the event display a #WAKEUP and a #SLEEP URC b0: DRX event is displayed b1: EDRX event is displayed b2: PSM event is displayed b3: OOS event is displayed b4: Verbosity is set (event type and duration of the sleep period). This is displayed only if one of the previous fields is set b5: Lib information from Modem NBIOT at BOOT |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | SAVED to NVM using AT#RESET=1 Takes effect after module reboot |
| Reference | Custom |

4.21 AT#SLEEPMODE – Enable, disable the sleep mode

AT#SLEEPMODE disables or enables the sleep mode. It also sets the minimum time between the last AT command and the sleep mode entry.

| AT#SLEEPMODE – Enable, disable the sleep mode | |
|---|--|
| Test Command | AT#SLEEPMODE=? |
| Response | #SLEEPMODE: <enable>,<hold time>,<awake time> OK |
| Read Command | AT#SLEEPMODE? |
| Response | #SLEEPMODE: <enable>,<hold time>,<awake time> OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Set Command | AT#SLEEPMODE=<enable>[,<hold_time>[,<awake_time>]] |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <enable>,<hold time>,<awake time> |
| <enable> | Integer type 0: Disable the sleep mode 1: Enable the sleep mode |
| <hold_time> | Integer type Time in seconds between the last AT command and the sleep mode entry |
| <awake_time> | Integer type Define the timeout in seconds that the module is awake at each wake up (telecom activity,AT command activity..). If the <awake_time> is reached, the module is reset |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | SAVED to NVM using AT#RESET=1 Takes effect after module reboot |
| Reference | Custom |

4.22 AT#STRACECFG – Set or get the trace configuration

AT#STRACECFG sets the trace configuration with the mapping on the GPIOs.

| AT#STRACECFG – Set or get the trace configuration | |
|---|---|
| Test Command | AT#STRACECFG=? |
| Response | #STRACECFG: <trace_cfg> |
| Read Command | AT#STRACECFG? |
| Response | #STRACECFG: <trace_cfg> |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Set Command | AT#STRACECFG=<trace_cfg> |
| Response | OK |
| Response If there is any error | ERROR Or +CME ERROR:<err> |
| Execution Command | 1 sec |
| Parameters | <trace_cfg> |
| <trace_cfg> | Integer type Set the trace configuration 0: Trace is off 1: Trace is on 1 line and the GPIO configuration is GPIO27 and GPIO28 2: Trace is on 1 line and the GPIO configuration is GPIO23 and GPIO24 3: Trace is on 1 line and the GPIO configuration is GPIO17 and GPIO18 4: Trace is on 4 lines and GPIO configuration is GPIO27.. GPIO31 |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | SAVED to NVM using AT#RESET=1 Takes effect immediately |
| Reference | Custom |

4.23 AT#TEMPLIMIT – Temperature thresholds low and high

AT#TEMPLIMIT sets the low and high temperature thresholds.
In case the temperature level reaches one of these thresholds, a message can be sent to the user and a shutdown can be triggered.

| AT#TEMPLIMIT – Temperature thresholds low and high | |
|--|---|
| Test Command | AT#TEMPLIMIT=? |
| Response | #TEMPLIMIT: <low_temp>,<high_temp>,<low_temp_shutdown>,<high_temp_shutdown>,<shutdown>,<display> OK |
| Read Command | AT#TEMPLIMIT? |
| Response | #TEMPLIMIT: <low_temp>,<high_temp>,<low_temp_shutdown>,<high_temp_shutdown>,<shutdown>,<display> OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Set Command | AT#TEMPLIMIT=<low_temp>,<high_temp>,<low_temp_shutdown>,<high_temp_shutdown>,<shutdown>,<display> |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <low_temp>,<high_temp>,<low_temp_shutdown>,<high_temp_shutdown>,<shutdown>,<display> |
| <low_temp> | Signed integer type Temperature low threshold in Celsius degree for warning display |
| <high_temp> | Signed integer type Temperature high threshold in Celsius degree for warning display |
| <low_temp_shutdown> | Signed integer type Temperature low threshold in Celsius degree for shutdown display and shutdown |
| <high_temp_shutdown> | Signed integer type Temperature high threshold in Celsius degree for shutdown display and shutdown |
| <shutdown> | Integer type 0: Disable shutdown if the shutdown threshold is reached 1: Enable shutdown if the shutdown threshold is reached |
| <display> | Integer type 0: Disable the display if the threshold is reached 1: Enable the display if the threshold is reached |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | SAVED to NVM using AT#RESET=1 Takes effect after module reboot |



| | |
|-----------|--------|
| Reference | Custom |
|-----------|--------|

4.24 AT#VBATLIMIT – Handling of battery level thresholds

AT#VBATLIMIT sets the low and high battery level thresholds.

In case the battery level reaches one of these thresholds, a message can be sent to the user and a shutdown can be triggered.

| AT#VBATLIMIT – Handling of battery level thresholds | |
|---|---|
| Test Command | AT#VBATLIMIT=? |
| Response | #VBATLIMIT: <low_vbat>,<high_vbat>,<low_vbat_shutdown>,<high_vbat_shutdown>,<shutdown>,<display> OK |
| Read Command | AT#VBATLIMIT? |
| Response | #VBATLIMIT: <low_vbat>,<high_vbat>,<low_vbat_shutdown>,<high_vbat_shutdown>,<shutdown>,<display> OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Set Command | AT#VBATLIMIT=<low_vbat>,<high_vbat>,<low_vbat_shutdown>,<high_vbat_shutdown>,<shutdown>,<display> |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <low_vbat>,<high_vbat>,<low_vbat_shutdown>,<high_vbat_shutdown>,<shutdown>,<display> |
| <low_vbat> | Integer type Low battery threshold in mV for display warning |
| <high_vbat> | Integer type High battery threshold in mV for display warning |
| <low_vbat_shutdown> | Integer type Low battery threshold in mV for shutdown display and shutdown |
| <high_vbat_shutdown> | Integer type High battery threshold in mV for shutdown display and shutdown |
| <shutdown> | Integer type 0: Disable shutdown if the shutdown threshold is reached 1: Enable shutdown if the shutdown threshold is reached |
| <display> | Integer type 0: Disable the display if the threshold is reached 1: Enable the display if the threshold is reached |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | SAVED to NVM using AT#RESET=1 Takes effect after module reboot |
| Reference | Custom |

4.25 AT#CAP – Enables or disables the Customer Application mode

| AT#CAP – Enables or disables the Customer Application mode | |
|--|---|
| Test Command | AT#CAP=? |
| Response | #CAP: <enable> OK |
| Read Command | AT#CAP? |
| Response | #CAP: <enable> OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Set Command | AT#CAP=<enable> |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <enable> |
| <enable> | Integer type 0: disables the Customer Application mode 1: enables the Customer Application mode |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | SAVED to NVM using AT#RESET=1 Takes effect after module reboot |
| Reference | Custom |

4.26 AT#WAKEUPEVENT – Handling of the wake up event and associated pins

AT#WAKEUPEVENT enables the wake up of the module through a UART command or the wake up pin. This command also configures the polarity and pull up capabilities of the associated pins.

| AT#WAKEUPEVENT – Handling of the wake up event and associated pins | |
|--|---|
| Test Command | AT#WAKEUPEVENT=? |
| Response | #WAKEUPEVENT: <pwrkey_evt>,<uart_evt> OK |
| Read Command | AT#WAKEUPEVENT? |
| Response | #WAKEUPEVENT: <pwrkey_evt>,<uart_evt> OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Set Command | AT#WAKEUPEVENT=<pwrkey_evt>,<uart_evt> |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <pwrkey_evt>,<uart_evt> |
| <pwrkey_evt> | Integer type See note below |
| <uart_evt> | Integer type See note below |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | SAVED to NVM using AT#RESET=1 Takes effect after module reboot |
| Reference | Custom |

Note: <pwrkey_evt> and <uart_evt> are bit maps with following bit definitions:

| bit3 (Pull type) | bit2 (Pull) | bit1(Polarity) | bit0 (Enable) |
|--|-------------------------|--|-------------------------|
| 0: Pull-down logic is selected 1: Pull-up logic is selected | 0: Disable 1: Enable | 0: Logic LOW level selected 1: Logic HIGH level is selected | 0: Disable 1: Enable |

4.27 AT#PWMINIT – Initialize GPIO for PWM mode

| AT#PWMINIT – Initialize GPIO for PWM mode | |
|---|--|
| Test Command | AT#PWMINIT=? |
| Response | #PWMINIT: <pwm_gpio_id> OK |
| Set Command | AT#PWMINIT=<pwm_gpio_id> |
| Response | OK |
| If there is any error | +CME ERROR:<err> |
| Parameters | <pwm_gpio_id> |
| <pwm_gpio_id> | Integer type 0: PWM0 on GPIO8 1: PWM1 on GPIO9 2: PWM0 on GPIO10 Note: PWM0 connection is exclusive (either GPIO8 or GPIO10) |
| <err> | See ATC_ERR_SEC_PWM error codes in Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | Custom |

4.28 AT#PWMSET – Enable PWM with given period and duty cycle

AT#PWMSET command enables PWM signal with user period and duty cycle on selected PWM peripheral (initially configured to output on a given GPIO using PWMINIT AT command). This AT command can be used each time a new period and/or duty cycle is set for PWM signal (“on-the-fly” update).

| AT#PWMSET – Enable PWM signal with given period and duty cycle | |
|--|---|
| Test Command | AT#PWMSET=? |
| Response | #PWMSET: < pwm_id >,< period >,< duty_cycle > OK |
| Set Command | AT#PWMSET=< pwm_id >,< period >,< duty_cycle > |
| Response | OK |
| If there is any error | +CME ERROR:< err > |
| Parameters | < pwm_id >,< period >,< duty_cycle > |
| < pwm_id > | Integer type PWM peripheral number: 0: PWM0 (connected to GPIO8 or 10) 1: PWM1 (connected to GPIO9) |
| < period > | Integer type PWM signal period value in microsecond. Minimum value is 2μs, maximum is 10s. |
| < duty_cycle > | Integer type PWM signal duty cycle value in tenth of percent (e.g 489 for 48.9%). Minimum value is 10 (1.0%), maximum is 990 (99.0%). |
| < err > | See ATC_ERR_SEC_PWM error codes in Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | Custom |

4.29 AT#PWMSTOP – Stop PWM with given period and duty cycle

AT#PWMSTOP command disables PWM signal on selected PWM peripheral (initially configured to output on a given GPIO using PWMINIT AT command).

| AT#PWMSTOP – Stop PWM with given period and duty cycle | |
|--|--|
| Test Command | AT#PWMSTOP=? |
| Response | #PWMSTOP: < pwm id > OK |
| Set Command | AT#PWMSTOP=< pwm_id > |
| Response | OK |
| If there is any error | +CME ERROR:< err > |
| Parameters | < pwm id > |
| < pwm_id > | Integer type PWM peripheral number: 0: PWM0 (connected to GPIO8 or GPIO10) 1: PWM1 (connected to GPIO9) |
| < err > | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | Custom |

4.30 AT#MODEMSTOP – Stop NBIOT MODEM

| AT#MODEMSTOP – Stop the NBIOT Modem | |
|-------------------------------------|------------------|
| Test Command | AT#MODEMSTOP=? |
| Response | #MODEMSTOP OK |
| Execution Command | AT#MODEMSTOP |
| Response | OK |
| If there is any error | +CME ERROR:<err> |
| Parameters | |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | Custom |

4.31 AT#MODEMSTART – Start NBIOT MODEM

| AT#MODEMSTART – Start the NBIOT Modem | |
|---------------------------------------|-------------------|
| Test Command | AT#MODEMSTART=? |
| Response | #MODEMSTART OK |
| Set Command | AT#MODEMSTART |
| Response | OK |
| If there is any error | |
| Parameters | |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | Custom |

4.32 AT#SCAN – Cells scan parameters

The set command controls the cells scan parameters. Parameter `<enable>` defines if extended coverage (EC) scan is enabled.

If it is set to 0, EC scan is disabled and only cells with a level greater than `<level_dbm>` are scanned. If it is set to 1, cells with a level greater than `<level_dbm>` are scanned first then in a second time, cells below this threshold are scanned.

Once all scans have been performed and if no PLMN is found, the UE enters in OOS mode (Out of Service) where it sleeps for `<oos_timer_min_in_10s>` if EC scan is disabled, or for `<oos_ec_timer_min_in_10s>` if it is enabled.

At wakeup, a new scan is performed. Once again, if no PLMN is found, the UE enters sleep for twice the previous time. The sequence is repeated.

The sleep time is clamped to a maximum value which is `<oos_timer_max_in_10s>` for EC scan disabled or `<oos_ec_timer_max_in_10s>` if enabled.

| AT#SCAN – Cell scan parameters | |
|--|---|
| Test Command | AT#SCAN=? |
| Response | #SCAN: <code><enable></code> :0-1>,[<code><level_dbm></code>],[<code><oos_timer_min_in_10s></code>],[<code><oos_timer_max_in_10s></code>],[<code><oos_ec_timer_min_in_10s></code>],[<code><oos_ec_timer_max_in_10s></code>] OK |
| Read Command | AT#SCAN? |
| Response | #SCAN: <code><enable></code>],[<code><level_dbm></code>],[<code><oos_timer_min_in_10s></code>],[<code><oos_timer_max_in_10s></code>],[<code><oos_ec_timer_min_in_10s></code>],[<code><oos_ec_timer_max_in_10s></code> OK |
| If there is any error | ERROR Or +CME ERROR: <code><err></code> |
| Set Command | AT#SCAN= <code><enable></code>],[<code><level_dbm></code>],[<code><oos_timer_min_in_10s></code>],[<code><oos_timer_max_in_10s></code>],[<code><oos_ec_timer_min_in_10s></code>],[<code><oos_ec_timer_max_in_10s></code>] OK |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR: <code><err></code> |
| Parameters | <code><enable></code>],[<code><level_dbm></code>],[<code><oos_timer_min_in_10s></code>],[<code><oos_timer_max_in_10s></code>],[<code><oos_ec_timer_min_in_10s></code>],[<code><oos_ec_timer_max_in_10s></code> |
| <code><enable></code> | Integer type 0: disable EC scan 1: enable EC scan |
| <code><level_dbm></code> | Integer type Threshold in dBm of the EC scan |
| <code><oos_timer_min_in_10s></code> | Integer type Minimum sleep time in EC scan mode disabled. Unit is 10s |
| <code><oos_timer_max_in_10s></code> | Integer type Maximum sleep time in EC scan mode disabled. Unit is 10s |
| <code><oos_ec_timer_min_in_10s></code> | Integer type |

| | |
|--|---|
| <code>in_in_10s></code> | Minimum sleep time in EC scan mode enabled. Unit is 10s |
| <code><oos ec timer max_in_10s></code> | Maximum sleep time in EC scan mode enabled. Unit is 10s |
| <code><err></code> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | SAVED to NVM using AT#RESET=1 Takes effect after module reboot |
| Reference | Custom |

4.33 AT#WDGMODE – Configure the watchdog

| AT#WDGMODE – Configure the watchdog | |
|-------------------------------------|---|
| Test Command | AT#WDGMODE=? |
| Response | #WDGMODE: <wdgmode> OK |
| Read Command | AT#WDGMODE? |
| Response | #WDGMODE: <wdgmode> OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Set Command | AT#WDGMODE=<wdgmode> |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <wdgmode> |
| <wdgmode> | Integer type 0: The watchdog is disabled 1: The watchdog is enabled and when it occurs, it triggers a reboot 2: The watchdog is enabled and when it occurs, it triggers a power off then power on sequence |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | SAVED to NVM using AT#RESET=1 Takes effect immediately |
| Reference | Custom |

4.34 AT#ASSERT – Gives the assert information for the different cores

AT#ASSERT command gives or resets the different core's assert information.

| AT#ASSERT – Gives the assert information for the different cores. | |
|---|--|
| Test Command | AT#ASSERT=? |
| Response | #ASSERT: <core> OK |
| Set Command | AT#ASSERT=<core> |
| Response | Assert information for core <core> if any OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <core> |
| <core> | Integer type 0: gives the assert information related to APP core 1: gives the assert information related to Modem core 2: gives the assert information related to Secure core 3: reset information for all cores |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | Custom |

4.35 AT#RINGPIN – Configure the Ring pin

AT#RINGPIN command configure the ring pin used to wakeup an external host before sending any URC message.

| AT#RINGPIN – Configure the Ring pin | |
|-------------------------------------|--|
| Test Command | AT#RINGPIN=? |
| Response | #RINGPIN: <enable>,<gpio>,<level>,<delay> OK |
| Read Command | AT#RINGPIN? |
| Response | #RINGPIN: <enable>,<gpio>,<level>,<delay> OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Set Command | AT#RINGPIN=<enable>,<gpio>,<level>,<delay> |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <enable>,<gpio>,<level>,<delay> |
| <enable> | Integer type 0: disable the ring pin 1: enable the ring pin to toggle |
| <gpio> | Integer type The GPIO number between 8 and 31 |
| <level> | Integer type 0: active low level 1: active high level |
| <delay> | Integer type The <delay> is the time in ms when the ring pin is active. The min value is 10ms and the max is 300ms by 10ms steps |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | SAVED to NVM using AT#RESET=1 Takes effect after module reboot |
| Reference | Custom |

4.36 AT#REGVEXT – Configuration of the regulator VEXT

| AT#REGVEXT – Configuration of the regulator VEXT | |
|--|--|
| Test Command | AT#REGVEXT=? |
| Response | #REGVEXT: <enable>,<voltage_sel> OK |
| Read Command | AT#REGVEXT? |
| Response | #REGVEXT: <enable>,<voltage_sel> OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Set Command | AT#REGVEXT=<enable>,<voltage_sel> |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <enable>,<voltage_sel> |
| <enable> | Integer type 0: disable the regulator 1: enable the regulator |
| <voltage_sel> | Integer type 0: select the output to 1.8V 1: select the output to 3.0V |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | Custom |

4.37 AT#RFTXCW – RF TX Continuous Wave

This command is used in test mode to generate a CW in TX.

| AT#RFTXCW – RF TX Continuous Wave | |
|-----------------------------------|---|
| Test Command | AT#RFTXCW=? |
| Response | #RFTXCW:<rf_freq100k>[,<rf_power>[,<on_time>,<off_time>[,<tone_freq>,<tone_gain>]]] start_stop CW on TX OK |
| Set Command | To start a CW AT#RFTXCW=<rf_freq100k>[,<rf_power>[,<on_time>,<off_time>[,<tone_freq>,<tone_gain>]]] To stop a CW AT#RFTXCW=0 |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <rf_freq100k>,<rf_power>,<on_time>,<off_time>,<tone_freq>,<tone_gain> |
| <rf_freq100k> | Integer type RF TX frequency in 100 kHz unit |
| <rf_power> | Integer type RF TW power in dBm |
| <on_time> | Integer type TX ON time duration in ms Default value is 60000 when not set |
| <off_time> | Integer type TX OFF time duration in ms Default value is 3 when not set |
| <tone_freq> | Integer type CW frequency in Hz Default value is 0 when not set |
| <tone_gain> | Integer type CW linear gain from 0 to 63 Default value is 20 when not set |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | Private |

Note:

This command must be executed in test mode, i.e., after AT+CFUN=0

4.38 AT#RFRSSI – RF RSSI measurement

This command is used in test mode to control the RF TX window.

| AT#RFRSSI – RF RSSI measurement | |
|---------------------------------|--|
| Test Command | AT#RFRSSI=? |
| Response | #RFRSSI:<rf_freq100k>,<rf_level> OK |
| Set Command | AT#RFRSSI=<rf_freq100k>,<rf_level> |
| Response | RFRSSI:<value> dBm OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <rf_freq100k>,<rf_level>,<value> |
| <rf_freq100k> | Integer type RF RX frequency in 100kHz unit |
| <rf_level> | Integer type RF RX expected level in dBm |
| <value> | Integer type RSSI measurement in dBm |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | Private |

Note:

This command must be executed in test mode, i.e., after AT+CFUN=0.

5 PS commands

5.1 AT+CGACT – PDP context activate or deactivate

The execution command is used to activate or deactivate the specified PDP context. After the command has completed, the MT remains in V.250 command state. If any PDP context is already in the requested state, the state for that context remains unchanged. If the MT is not PS attached when the activation form of the command is executed, the MT first performs a PS attach and then attempts to activate the specified contexts. If the attach fails then the MT responds with an error message. For EPS, if an attempt is made to disconnect the last PDN connection, then the MT responds with an error.

For EPS, the activation request for an EPS bearer resource will be answered by the network by either an EPS dedicated bearer activation or EPS bearer modification request. The request must be accepted by the MT before the PDP context can be set in to established state.

If no <cid>s are specified the activation form of the command activates all defined non-emergency contexts.

If no <cid>s are specified the deactivation form of the command deactivates all active contexts.

The read command returns the current activation states for all the defined PDP contexts.

The test command is used for requesting information on the supported PDP context activation states.

| AT+CGACT – PDP context activate or deactivate | |
|---|--|
| Test Command | AT+CGACT=? |
| Response | +CGACT: (list of supported <state>s) OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Read Command | AT+CGACT? |
| Response | [+CGACT: <cid>,<state>] [<CR><LF>+CGACT: <cid>,<state> [...]] OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Set Command | AT+CGACT=[<state>[,<cid>[,<cid>[,...]]]] |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| If there is any error | <state>,<cid> |
| <state> | Integer type Indicates the state of PDP context activation. The default value is manufacturer specific. 0: deactivated 1: activated |
| <cid> | Integer type Specifies a particular PDP context definition (see the +CGDCONT and +CGDSCONT commands). |
| <err> | See Error List |

| | |
|-----------------------|----------------|
| Max Response Time | 5 sec |
| Parameter Saving Mode | NA |
| Reference | 3GPP TS 27.007 |

Note:

If the initial PDP context is supported, the context with <cid>=5 is automatically defined at startup.

5.2 AT+CGAPNRC – APN rate control

This execution command returns the APN rate control parameters (see 3GPP TS 24.008) associated to the provided context identifier `<cid>`.

If the parameter `<cid>` is omitted, the APN rate control parameters for all active PDP contexts are returned.

The test command returns a list of `<cid>`s associated with secondary and non-secondary active PDP contexts.

| AT+CGAPNRC – APN rate control | |
|---|---|
| Test Command | AT+CGAPNRC=? |
| Response | +CGAPNRC: (list of <code><cid></code> s associated with active contexts) OK |
| If there is any error | ERROR Or +CME ERROR: <code><err></code> |
| Set Command | AT+CGAPNRC= <code><cid></code> |
| Response | [+CGAPNRC: <code><cid></code> , <code><additional_exception_reports></code> [, <code><uplink_time_unit></code> [, <code><maximum_uplink_rate></code>]]] [<CR><LF>+CGAPNRC: <code><cid></code> , <code><additional_exception_reports></code> [, <code><uplink_time_unit></code> [, <code><maximum_uplink_rate></code>]]] [...]]] OK |
| If there is any error | ERROR Or +CME ERROR: <code><err></code> |
| Execution Command | AT+CGAPNRC |
| Response | [+CGAPNRC: <code><cid></code> , <code><additional_exception_reports></code> [, <code><uplink_time_unit></code> [, <code><maximum_uplink_rate></code>]]] [<CR><LF>+CGAPNRC: <code><cid></code> , <code><additional_exception_reports></code> [, <code><uplink_time_unit></code> [, <code><maximum_uplink_rate></code>]]] [...]]] OK |
| If there is any error | ERROR Or +CME ERROR: <code><err></code> |
| Parameters | <code><cid></code> , <code><additional_exception_reports></code> , <code><uplink_time_unit></code> , <code><maximum_uplink_rate></code> |
| <code><cid></code> | Integer type Specifies a particular PDP context definition (see the +CGDCONT and +CGDSCONT commands). |
| <code><additional_exception_reports></code> | Integer type Indicates whether or not additional exception reports are allowed to be sent when the maximum uplink rate is reached. This refers to bit 4 of octet 1 of the APN rate control parameters IE as specified in 3GPP TS 24.008 subclause 10.5.6.3.2. 0: <code><additional_exception_reports></code> at maximum rate reached are not allowed to be sent. |

| | |
|-----------------------|--|
| | 1: <additional exception reports> at maximum rate reached are allowed to be sent. |
| <uplink_time_unit> | Integer type Specifies the time unit to be used for the maximum uplink rate. This refers to bits 1 to 3 of octet 1 of the APN rate control parameters IE as specified in 3GPP TS 24.008 subclause 10.5.6.3.2. 0: unrestricted 1: minute 2: hour 3: day 4: week |
| <maximum_uplink_rate> | Integer type Specifies the maximum number of messages the UE is restricted to send per uplink time unit. This refers to octet 2 to 4 of the APN rate control parameters IE as specified in 3GPP TS 24.008 subclause 10.5.6.3.2. |
| <err> | See Error List |
| Max Response Time | 5 sec |
| Parameter Saving Mode | NA |
| Reference | 3GPP TS 27.007 |

5.3 AT+CGATT – PS attach or detach

The execution command is used to attach the MT to, or detach the MT from, the Packet Domain service. After the command has completed, the MT remains in V.250 command state. If the MT is already in the requested state, the command is ignored and the OK response is returned. If the requested state cannot be achieved, an error is reported.

| AT+CGATT – PS attach or detach | |
|--------------------------------|---|
| Test Command | AT+CGATT=? |
| Response | +CGATT: (list of supported <state>) OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Read Command | AT+CGATT? |
| Response | +CGATT:<state> OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Set Command | AT+CGATT=<state> |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <state> |
| <state> | Integer type Indicates the state of PS attachment. 0: detached 1: attached |
| <err> | See Error List |
| Max Response Time | 5 min |
| Parameter Saving Mode | NA |
| Reference | 3GPP TS 27.007 |

Note1:

If the initial PDP context is supported, the context with <cid>=0 is automatically defined at startup. Any active PDP contexts will be automatically deactivated when the attachment state changes to detached.

The read command returns the current Packet Domain service state.

The test command is used for requesting information on the supported PacketDomain service states.

Note2:

This command has the characteristics of both the V.250 action and parameter commands. Hence it has the read form in addition to the execution/set and test forms.

5.4 AT+CGCMOD – PDP context modify

The execution command is used to modify the specified PDP context (s) with respect to QoS profiles and TFTs. After the command has completed, the MT returns to V.250 online data state. If the requested modification for any specified context cannot be achieved, an error is returned. For EPS, the modification request for an EPS bearer resource will be answered by the network by an EPS bearer modification request. The request must be accepted by the MT before the PDP context is effectively changed.

If no <cid>s are specified, the activation form of the command modifies all active contexts. The test command returns a list of <cid>s associated with active contexts.

| AT+CGCMOD – PDP context modify | |
|--------------------------------|--|
| Test Command | AT+CGCMOD=? |
| Response | +CGCMOD: (list of <cid>s associated with active contexts) OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Set Command | AT+CGCMOD[=<cid>[,<cid>[,...]]] |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Execution Command | AT+CGCMOD |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <cid> |
| <cid> | Integer type Specifies a particular PDP context definition (see the +CGDCONT and +CGDSCONT commands). |
| <err> | See Error List |
| Max Response Time | 5 sec |
| Parameter Saving Mode | NA |
| Reference | 3GPP TS 27.007 |

Note:

The syntax of the AT Set Command is corrected to be according to ITU T Recommendation V.250. Older versions of the specification specify incorrect syntax +CGCMOD=[<cid>[,<cid>[,...]]].

5.5 AT+CGCONTRDP – Read PDP context dynamic parameters

The execution command returns the relevant information <bearer_id>, <apn>, <local_addr_and_subnet_mask>, <gw_addr>, <DNS_prim_addr>, <DNS_sec_addr>, <P-CSCF_prim_addr>, <P-CSCF_sec_addr>, <IM_CN_Signalling_Flag>, <LIPA_indication>, <IPv4_MTU>, <WLAN_Offload>, <Non-IP_MTU> and <Serving_PLMN_rate_control_value> for an active non secondary PDP context with the context identifier <cid>.

If the MT indicates more than two IP addresses of P-CSCF servers or more than two IP addresses of DNS servers, multiple lines of information per <cid> will be returned.

If the MT has dual stack capabilities, at least one pair of lines with information is returned per <cid>. First one line with the IPv4 parameters followed by one line with the IPv6 parameters. If this MT with dual stack capabilities indicates more than two IP addresses of P-CSCF servers or more than two IP addresses of DNS servers, multiple of such pairs of lines are returned.

If the parameter <cid> is omitted, the relevant information for all active non secondary PDP contexts is returned.

The test command returns a list of <cid>s associated with active non secondary contexts.

| AT+CGCONTRDP – Read PDP context dynamic parameters | |
|--|--|
| Test Command | AT+CGCONTRDP=? |
| Response | +CGCONTRDP: (list of <cid>s associated with active contexts) OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Set Command | AT+CGCONTRDP=<cid> |
| Response | [+CGCONTRDP: <cid>,<bearer_id>,<apn> [,<local_addr_and_subnet_mask>[,<gw_addr>[,<DNS_prim_addr> [,<DNS_sec_addr>[,<P-CSCF_prim_addr>[,<P-CSCF_sec_addr> [,<IM_CN_Signalling_Flag>[,<LIPA_indication>[,<IPv4_MTU> [,<WLAN_Offload>[,<Local_Addr_Ind>[,<Non-IP_MTU> [,<Serving_PLMN_rate_control_value>]]]]]]]]]]] [<CR><LF>+CGCONTRDP: <cid>,<bearer_id>,<apn> [,<local_addr_and_subnet_mask>[,<gw_addr>[,<DNS_prim_addr> [,<DNS_sec_addr>[,<P-CSCF_prim_addr> [,<P-CSCF_sec_addr>[,<IM_CN_Signalling_Flag> [,<LIPA_indication>[,<IPv4_MTU>[,<WLAN_Offload> [,<Local_Addr_Ind>[,<Non-IP_MTU> [,<Serving_PLMN_rate_control_value>]]]]]]]]]]][...]] OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Execution Command | AT+CGCONTRDP |
| Response | [+CGCONTRDP: <cid>,<bearer_id>,<apn> [,<local_addr_and_subnet_mask>[,<gw_addr>[,<DNS_prim_addr> [,<DNS_sec_addr>[,<P-CSCF_prim_addr>[,<P-CSCF_sec_addr> [,<IM_CN_Signalling_Flag>[,<LIPA_indication>[,<IPv4_MTU> [,<WLAN_Offload>[,<Local_Addr_Ind>[,<NonIP_MTU> [,<Serving_PLMN_rate_control_value>]]]]]]]]]]] |

| | |
|------------------------------|---|
| If there is any error | [<CR><LF>+CGCONTRDP: <cid>,<bearer_id>,<apn> [,<local_addr_and_subnet_mask>[,<gw_addr>[,<DNS_prim_addr> [,<DNS_sec_addr>[,<P-CSCF_prim_addr> [,<P-CSCF_sec_addr>[,<IM_CN_Signalling_Flag> [,<LIPA_indication>[,<IPv4_MTU>[,<WLAN_Offload> [,<Local_Addr_Ind>[,<Non-IP_MTU> [,<Serving_PLMN_rate_control_value>]]]]]]]]]]...]] OK |
| | ERROR Or +CME ERROR:<err> |
| Parameters | <cid>,<bearer_id>,<apn> [,<local_addr_and_subnet_mask>[,<gw_addr>[,<DNS_prim_addr> [,<DNS_sec_addr>[,<P-CSCF_prim_addr>[,<P-CSCF_sec_addr> [,<IM_CN_Signalling_Flag>[,<LIPA_indication>[,<IPv4_MTU> [,<WLAN_Offload>[,<Local_Addr_Ind>[,<Non-IP_MTU> [,<Serving_PLMN_rate_control_value>]]]]]]]]]]]] |
| <cid> | Integer type Specifies a particular non secondary PDP context definition. The parameter is local to the TE-MT interface and is used in other PDP context-related commands (see the +CGDCONT and +CGDSCONT commands). |
| <bearer_id> | Integer type Identifies the bearer, e.g., the EPS bearer in EPS and the NSAPI in UMTS/GPRS. |
| <apn> | String type Logical name that was used to select the GGSN or the external packet data network. |
| <local_addr_and_subnet_mask> | String type Shows the IP address and subnet mask of the MT. The string is given as dot-separated numeric (0-255) parameters on the form: "a1.a2.a3.a4.m1.m2.m3.m4" for IPv4 or "a1.a2.a3.a4.a5.a6.a7.a8.a9.a10.a11.a12.a13.a14.a15.a16.m1.m2.m3.m4.m5.m6.m7.m8.m9.m10.m11.m12.m13.m14.m15.m16" for IPv6. When +CGPIAF is supported, its settings can influence the format of this parameter returned with the execute form of +CGCONTRDP. |
| <gw_addr> | String type Shows the Gateway Address of the MT. The string is given as dot-separated numeric (0-255) parameters. When +CGPIAF is supported, its settings can influence the format of this parameter returned with the execute form of +CGCONTRDP. |
| <DNS_prim_addr> | String type Shows the IP address of the primary DNS server. When +CGPIAF is supported, its settings can influence the format of this parameter returned with the execute form of +CGCONTRDP. |
| <DNS_sec_addr> | String type Shows the IP address of the secondary DNS server. When +CGPIAF is supported, its settings can influence the format of this parameter returned with the execute form of +CGCONTRDP. |
| <P-CSCF_prim_addr> | String type Shows the IP address of the secondary P-CSCF server. When +CGPIAF is supported, its settings can influence the format of this parameter returned with the execute form of +CGCONTRDP. |
| <P-CSCF_sec_addr> | String type Shows the IP address of the secondary P-CSCF server. |

| | |
|-----------------------------------|---|
| | When +CGPIAF is supported, its settings can influence the format of this parameter returned with the execute form of +CGCONTRDP. |
| <IM_CN_Signalling_Flag> | Integer type Shows whether the PDP context is for IM CN subsystem-related signalling only or not. 0: PDP context is not for IM CN subsystem-related signalling only 1: PDP context is for IM CN subsystem-related signalling only |
| <LIPA_indication> | Integer type Indicates that the PDP context provides connectivity using a LIPA PDN connection. This parameter cannot be set by the TE. 0: indication not received that the PDP context provides connectivity using a LIPA PDN connection 1: indication received that the PDP context provides connectivity using a LIPA PDN connection |
| <IPv4_MTU> | Integer type Shows the IPv4 MTU size in octets. |
| <WLAN_Offload> | Integer type Indicates whether traffic can be offloaded using the specified PDN connection via a WLAN or not. This refers to bits 1 and 2 of the WLAN offload acceptability IE as specified in 3GPP TS 24.008 subclause 10.5.6.20. 0: offloading the traffic of the PDN connection via a WLAN when in S1 mode or when in lu mode is not acceptable. 1: offloading the traffic of the PDN connection via a WLAN when in S1 mode is acceptable, but not acceptable in lu mode. 2: offloading the traffic of the PDN connection via a WLAN when in lu mode is acceptable, but not acceptable in S1 mode. 3: offloading the traffic of the PDN connection via a WLAN when in S1 mode or when in lu mode is acceptable. |
| <Local_Addr_Ind> | Integer type Indicates whether or not the MS and the network support local IP address in TFTs (see 3GPP TS 24.301 and 3GPP TS 24.008 subclause 10.5.6.3). 0: indicates that the MS or the network or both do not support local IP address in TFTs 1: indicates that the MS and the network support local IP address in TFTs |
| <Non-IP_MTU> | Integer type Shows the Non-IP MTU size in octets. |
| <Serving_PLMN_rate_control_value> | Integer type Indicates the maximum number of uplink messages the UE is allowed to send in a 6-minute interval. This refers to octet 3 to 4 of the Serving PLMN rate control IE as specified in 3GPP TS 24.301 subclause 9.9.4.28. |
| <err> | See Error List |
| Max Response Time | 5 sec |
| Parameter Saving Mode | NA |
| Reference | 3GPP TS 27.007 |

Note: if the MT does not have all the IP addresses to be included in a line, e.g., in case the UE received four IP addresses of DNS servers and two IP addresses of P-CSCF servers, the parameter value representing an IP address that cannot be populated is set to an empty string.

5.6 AT+CGDATA – Enter data state

The execution command causes the MT to perform whatever actions are necessary to establish communication between the TE and the network using one or more Packet Domain PDP types. This may include performing a PS attach and one or more PDP context activations. If the **<L2P>** parameter value is unacceptable to the MT, the MT shall return an error. Otherwise, the MT issues the intermediate result code CONNECT and enters V.250 online data state.

Commands following +CGDATA command in the AT command line shall not be processed by the MT.

The detailed behaviour after the online data state has been entered is dependent on the PDP type. It is described briefly in 3GPP TS 27.060 and in more detail in 3GPP TS 29.061 and the specifications for the relevant PDPs. PS attachment and PDP context activation procedures may take place prior to or during the PDP startup if they have not already been performed using the +CGATT and +CGACT commands.

If context activation takes place during the PDP startup, one or more **<cid>**s may be specified in order to provide the information needed for the context activation request(s).

During each PDP startup procedure the MT may have access to some or all of the following information.

The MT may have a priori knowledge, for example, it may implement only one PDP type.

The command may have provided an **<L2P>** parameter value.

The TE may provide a PDP type and/or PDP address to the MT during the PDP startup procedure.

If any of this information is in conflict, the command will fail.

Any PDP type and/or PDP address present in the above information shall be compared with the PDP type and/or PDP address in any context definitions specified in the command in the order in which their **<cid>**s appear. For a context definition to match:

The PDP type must match exactly.

The PDP addresses are considered to match if they are identical or if either or both addresses are unspecified. For example, a PPP NCP request specifying PDP type = IP and no PDP address would cause the MT to search through the specified context definitions for one with PDP type = IP and any PDP address.

The context shall be activated using the matched value for PDP type and a static PDP address if available, together with the other information found in the PDP context definition. If a static PDP address is not available then a dynamic address is requested.

If no **<cid>** is given or if there is no matching context definition, the MT shall attempt to activate the context with whatever information is available to the MT. The other context parameters shall be set to their default values.

If the activation is successful, data transfer may proceed.

After data transfer is complete, and the layer 2 protocol termination procedure has completed successfully, the V.250 command state is re-entered and the MT returns the final result code OK.

In the event of an erroneous termination or a failure to start up, the V.250 command state is re-entered and the MT returns the final result code NO CARRIER or, if enabled, +CME ERROR.

The test command is used for requesting information on the supported layer 2 protocols.

This command may be used in both normal and modem compatibility modes.

| AT+CGDATA – Enter data state | |
|------------------------------|---|
| Test Command | AT+CGDATA=? |
| Response | +CGDATA: (list of supported <L2P> s) OK |

| | |
|-----------------------|--|
| If there is any error | ERROR Or +CME ERROR:<err> |
| Set Command | AT+CGDATA=<l2P>[,<cid>[,<cid>[,...]]] |
| Response | CONNECT |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Execution Command | AT+CGDATA |
| Response | CONNECT |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <l2P> ,<cid> |
| <l2P> | String type Indicates the layer 2 protocol to be used between the TE and MT NULL: none, for PDP type OSP:IHOSS (Obsolete) PPP: Point-to-point protocol for a PDP such as IP PAD: character stream for X.25 character (triple X PAD) mode (Obsolete) X25: X.25 L2 (LAPB) for X.25 packet mode (Obsolete) M-xxxx: manufacturer-specific protocol (xxxx is an alphanumeric string) If the value is omitted, the layer 2 protocol is unspecified. Other values are reserved and will result in an ERROR response. |
| <cid> | Integer type Specifies a particular PDP context definition (see the +CGDCONT and +CGDSCONT commands). |
| <err> | See Error List |
| Max Response Time | 5 min |
| Parameter Saving Mode | NA |
| Reference | 3GPP TS 27.007 |

Note1: If the initial PDP context is supported, the context with <cid>=5 is automatically defined at startup.

Note2: The syntax of the AT Set Command is corrected to be according to ITU T Recommendation V.250. Older versions of the specification specify incorrect syntax
+CGDATA=[<l2P>[,<cid>[,<cid>[,...]]]].

5.7 AT+CGDCONT – Define PDP context

The set command specifies PDP context parameter values for a PDP context identified by the (local) context identification parameter, <cid> and also allows the TE to specify whether security protected transmission of ESM information is requested, because the PCO can include information that requires ciphering. There can be other reasons for the UE to use security protected transmission of ESM information, e.g. if the UE needs to transfer an APN. The number of PDP contexts that may be in a defined state at the same time is given by the range returned by the test command.

For EPS the PDN connection and its associated EPS default bearer is identified herewith. A special form of the set command, +CGDCONT=<cid> causes the values for context number <cid> to become undefined.

If the initial PDP context is supported, the context with <cid>=0 is automatically defined at startup. As all other contexts, the parameters for <cid>=0 can be modified with +CGDCONT. If the initial PDP context is supported, +CGDCONT=0 resets context number 0 to its particular default settings.

The read command returns the current settings for each defined context.

The test command returns values supported as compound values. If the MT supports several PDP types, <PDP_type>, the parameter value ranges for each <PDP_type> are returned on a separate line.

| AT+CGDCONT – Define PDP context | |
|---------------------------------|---|
| Test Command | AT+CGDCONT=? |
| Response | +CGDCONT: (range of supported <cid>s),<PDP_type>,,(list of supported <d_comp>s),(list of supported <h_comp>s),(list of supported <IPv4AddrAlloc>s), (list of supported <request_type>s),(list of supported <P-CSCF_discovery>s), (list of supported <IM_CN_Signalling_Flag_Ind>s),(list of supported <NSLPI>s), (list of supported <securePCO>s),(list of supported <IPv4_MTU_discovery>s), (list of supported <Local_Addr_Ind>s),(list of supported <Non-IPMTUdiscovery>s) [<CR><LF>+CGDCONT: (range of supported <cid>s),<PDP_type>,,(list of supported <d_comp>s),(list of supported <h_comp>s),(list of supported <IPv4AddrAlloc>s), (list of supported <request_type>s),(list of supported <P-CSCF_discovery>s), (list of supported <IM_CN_Signalling_Flag_Ind>s),(list of supported <NSLPI>s), (list of supported <securePCO>s),(list of supported <IPv4_MTU_discovery>s), (list of supported <Local_Addr_Ind>s),(list of supported <Non-IPMTUdiscovery>s)[...]] OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Read Command | AT+CGDCONT? |
| Response | [+CGDCONT: <cid>,<PDP_type>,<APN>,<PDP_addr>,<d_comp>,<h_comp> [,<IM_CN_Signalling_Flag_Ind>[,<NSLPI>[,<securePCO>[,<IPv4_MTU_discovery> > [,<Local_Addr_Ind>[,<Non-IP_MTU_discovery>]]]]]]] [<CR><LF>+CGDCONT: <cid>,<PDP_type>,<APN>,<PDP_addr>,<d_comp>,<h_comp> [,<IM_CN_Signalling_Flag_Ind>[,<NSLPI> [,<securePCO>[,<IPv4_MTU_discovery>[,<Local_Addr_Ind> [,<Non-IP_MTU_discovery>]]]]]]] [...]] OK |

| | |
|-----------------------|---|
| If there is any error | ERROR Or +CME ERROR:<err> |
| Set Command | AT+CGDCONT=[<cid>,<pdp_type>,<apn>,<pdp_addr>,<d_comp>,<h_comp>,<IPv4AddrAlloc>,<request_type>,<PCSCF_discovery>,<IM_CN_Signalling_Flag_Ind>,<NSLPI>,<securePCO>,<IPv4_MTU_discovery>][,<Local_Addr_Ind>][,<Non-P_MTU_discovery>] [111111111111] |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameter | <cid>,<pdp_type>,<apn>,<pdp_addr>,<d_comp>,<h_comp>,<IPv4AddrAlloc>,<request_type>,<PCSCF_discovery>,<IM_CN_Signalling_Flag_Ind>,<NSLPI>,<securePCO>,<IPv4_MTU_discovery>,<Local_Addr_Ind>,<Non-IP_MTU_discovery> |
| <cid> | Integer type Specifies a particular PDP context definition. The parameter is local to the TE-MT interface and is used in other PDP context-related commands. The range of permitted values (minimum value = 1 or if the initial PDP context is supported (see subclause 10.1.0), minimum value = 0) is returned by the test form of the command. Note1:The <cid>s for network-initiated PDP contexts will have values outside the ranges indicated for the <cid> in the test form of the commands +CGDCONT and +CGDSCONT. |
| <pdp_type> | String type Specifies the type of packet data protocol. The default value is manufacturer specific. <ul style="list-style-type: none"> • X.25: ITU-T/CCITT X.25 layer 3 (Obsolete) • IP: Internet Protocol (IETF STD 5) • IPV6 : Internet Protocol, version 6 (see RFC 2460) • IPV4V6 : Virtual <PDP_type> introduced to handle dual IP stack UE capability. (See 3GPP TS 24.301) • OSPIH: Internet Hosted Octect Stream Protocol (Obsolete) • PPP: Point to Point Protocol (IETF STD 51) • Non-IP: Transfer of Non-IP data to external packet data network (see 3GPP TS 23.401) Note2: Only IP, IPV6, IPV4V6 and Non-IP values are supported for EPS services. |
| <apn> | String type Logical name that is used to select the GGSN or the external packet data network. If the value is null or omitted, then the subscription value will be requested. |
| <pdp_addr> | String type Identifies the MT in the address space applicable to the PDP. When +CGPIAF is supported, its settings can influence the format of this parameter returned with the read form of +CGDCONT. Note3:The value of this parameter is ignored with the set command. The parameter is included in the set command for backwards compatibility reasons only. |
| <d_comp> | Integer type Controls PDP data compression (applicable for SNDCP only) (refer 3GPP TS 44.065) <ul style="list-style-type: none"> • 0: off • 1: on (manufacturer preferred compression) • 2: V.42bis • 3: V.44 |
| <h_comp> | Integer type |

| | |
|-----------------------------|--|
| | <p>Controls PDP header compression (refer 3GPP TS 44.065 and 3GPP TS 25.323)</p> <ul style="list-style-type: none"> 0: off 1: on (manufacturer preferred compression) 2: RFC 1144 (applicable for SDCP only) 3: RFC 2507 4: RFC 3095 (applicable for PDCP only) |
| <IPv4AddrAlloc> | <p>Integer type</p> <p>Controls how the MT/TA requests to get the IPv4 address information</p> <ul style="list-style-type: none"> 0: IPv4 address allocation through NAS signalling 1: IPv4 address allocated through DHCP |
| <request_type> | <p>Integer type</p> <p>Indicates the type of PDP context activation request for the PDP context, see 3GPPTS 24.301 (subclause 6.5.1.2) and 3GPPTS 24.008 (subclause 10.5.6.17). If the initial PDP context is supported (see subclause 10.1.0) it is not allowed to assign <cid>=0 for emergency bearer services. According to 3GPP TS 24.008 (subclause 4.2.4.2.2 and subclause 4.2.5.1.4) and 3GPP TS 24.301 (subclause 5.2.2.3.3 and subclause 5.2.3.2.2), a separate PDP context must be established for emergency bearer services.</p> <p>Note4: If the PDP context for emergency bearer services is the only activated context, only emergency calls are allowed, see 3GPP TS 23.401 subclause 4.3.12.9.</p> <ul style="list-style-type: none"> 0: PDP context is for new PDP context establishment or for handover from a non-3GPP access network (how the MT decides whether the PDP context is for new PDP context establishment or for handover is implementation specific) 1: PDP context is for emergency bearer services 2: PDP context is for new PDP context establishment 3: PDP context is for handover from a non-3GPP access network 4: PDP context is for handover of emergency bearer services from a non-3GPP access network <p>Note5: A PDP context established for handover of emergency bearer services from a non-3GPP access network has the same status as a PDP context for emergency bearer services.</p> |
| <P-CSCF_discovery> | <p>Integer type</p> <p>Influences how the MT/TA requests to get the P-CSCF address, see 3GPP TS 24.229 annex B and annex L.</p> <ul style="list-style-type: none"> 0: Preference of P-CSCF address discovery not influenced by +CGDCONT 1: Preference of P-CSCF address discovery through NAS signalling 2: Preference of P-CSCF address discovery through DHCP |
| <IM_CN_Signalling_Flag_Ind> | <p>Integer type</p> <p>Indicates to the network whether the PDP context is for IM CN subsystem-related signalling only or not.</p> <ul style="list-style-type: none"> 0: UE indicates that the PDP context is not for IM CN subsystem-related signalling only 1: UE indicates that the PDP context is for IM CN subsystem-related signalling only |
| <NSLPI> | <p>Integer type</p> <p>Indicates the NAS signalling priority requested for this PDP context:</p> <ul style="list-style-type: none"> 0: indicates that this PDP context is to be activated with the value for the low priority indicator configured in the MT. 1: indicates that this PDP context is to be activated with the value for the low priority indicator set to "MS is not configured for NAS signalling low priority". <p>Note6: The MT utilises the provide NSLPI information as specified in 3GPP TS 24.301 and 3GPP TS 24.008.</p> |

| | |
|------------------------|--|
| <securePCO> | Integer type Specifies if security protected transmission of PCO is requested or not (applicable for EPS only, see 3GPP TS 23.401 subclause 6.5.1.2). <ul style="list-style-type: none">0: Security protected transmission of PCO is not requested1: Security protected transmission of PCO is requested |
| <IPv4_MTU_discovery> | Integer type Influences how the MT/TA requests to get the IPv4 MTU size, see 3GPP TS 24.008 subclause 10.5.6.3. <ul style="list-style-type: none">0: Preference of IPv4 MTU size discovery not influenced by +CGDCONT1: Preference of IPv4 MTU size discovery through NAS signalling |
| <Local_Addr_Ind> | Integer type Indicates to the network whether or not the MS supports local IP address in TFTs (see 3GPP TS 24.301 and 3GPP TS 24.008 subclause 10.5.6.3). <ul style="list-style-type: none">0: indicates that the MS does not support local IP address in TFTs1: indicates that the MS supports local IP address in TFTs |
| <Non-IP_MTU_discovery> | Integer type Influences how the MT/TA requests to get the Non-IP MTU size, see 3GPP TS 24.008 subclause 10.5.6.3. <ul style="list-style-type: none">0: Preference of Non-IP MTU size discovery not influenced by +CGDCONT1: Preference of Non-IP MTU size discovery through NAS signalling |
| <err> | See Error List |
| Max Response Time | 5 sec |
| Parameter Saving Mode | NA |
| Reference | 3GPP TS 27.007 |

Note:

<cid> values of 0-10 are supported

5.8 AT+ CGDSCONT – Define secondary PDP context

The set command specifies PDP context parameter values for a secondary PDP context identified by the (local) context identification parameter, <cid>. The number of PDP contexts that may be in a defined state at the same time is given by the range returned by the test command.

In EPS the command is used to define traffic flows.

A special form of the set command, +CGDSCONT=<cid> causes the values for context number <cid> to become undefined.

The read command returns the current settings for each defined context.

The test command returns values supported as compound values.

| AT+CGDSCONT – Define secondary PDP context | |
|--|--|
| Test Command | AT+CGDSCONT=? |
| Response | +CGDSCONT: (range of supported <cid>),(list of <p cid> for active primary contexts),(list of supported <d comp>),(list of supported <h comp>), (list of supported <IM CN Signalling Flag Ind>) OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Read Command | AT+CGDSCONT? |
| Response | [+CGDSCONT: <cid>,<p cid>,<d comp>,<h comp>,<IM CN Signalling Flag Ind>] [<CR><LF>+CGDSCONT: <cid>,<p cid>,<d comp>,<h comp>,<IM CN Signalling Flag Ind> [...]] OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Set Command | +CGDSCONT=[<cid>,<p cid>,<d comp>,<h comp> [,<IM CN Signalling Flag Ind>]]] |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <cid>,<p cid>,<d comp>,<h comp>,<IM CN Signalling Flag Ind> |
| <cid> | Integer type Specifies a particular PDP context definition. The parameter is local to the TE-MT interface and is used in other PDP context-related commands. The range of permitted values (minimum value = 1) is returned by the test form of the command. |
| <p cid> | Integer type Specifies a particular PDP context definition which has been specified by use of the +CGDSCONT command. The parameter is local to the TE-MT interface. The list of permitted values is returned by the test form of the command. |
| <d comp> | Integer type Controls PDP data compression (applicable for SNDCP only) (refer 3GPP TS 44.065) 0: off 1: on (manufacturer preferred compression) |

| | |
|-----------------------------|---|
| | 2: V.42bis 3: V.44 |
| <h_comp> | Integer type Controls PDP header compression (refer 3GPP TS 44.065 and 3GPP TS 25.323) 0: off 1: on (manufacturer preferred compression) 2: RFC 1144 (applicable for SNDCCP only) 3: RFC 2507 4: RFC 3095 (applicable for PDCP only) |
| <IM_CN_Signalling_Flag_Ind> | Integer type Indicates to the network whether the PDP context is for IM CN subsystem-related signalling only or not. 0: UE indicates that the PDP context is not for IM CN subsystem-related signalling only 1: UE indicates that the PDP context is for IM CN subsystem-related signalling only |
| <err> | See Error List |
| Max Response Time | 5 sec |
| Parameter Saving Mode | NA |
| Reference | 3GPP TS 27.007 |

Note1: If the initial PDP context is supported, the context with <cid>=0 is automatically defined at startup.

Note2: The <cid> for network-initiated PDP contexts will have values outside the ranges indicated for the <cid> in the test form of the commands +CGDCONT and +CGDSCONT.

5.9 AT+CGEQOS – Defines EPS Quality of Service

The set command allows the TE to specify the EPS Quality of Service parameters <cid>, <QCI>, [<DL_GBR> and <UL_GBR>] and [<DL_MBR> and <UL_MBR>] for a PDP context or Traffic Flows (see 3GPP TS 24.301 and 3GPP TS 23.203).

A special form of the set command, +CGEQOS=<cid> causes the values for context number <cid> to become undefined.

The read command returns the current settings for each defined QoS.

The test command returns the ranges of the supported parameters as compound values.

| AT+CGEQOS – Defines EPS Quality of Service | |
|--|---|
| Test Command | AT+CGEQOS=? |
| Response | +CGEQOS: (range of supported <cid>),(ranges of supported <QCI>), (range of supported <DL_GBR>),(range of supported <UL_GBR>), (range of supported <DL_MBR>),(range of supported <UL_MBR>) OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Read Command | AT+CGEQOS? |
| Response | [+CGEQOS: <cid>,<QCI>,<DL_GBR>,<UL_GBR>],[<DL_MBR>,<UL_MBR>]] [<CR><LF>+CGEQOS: <cid>,<QCI>,<DL_GBR>,<UL_GBR>],[<DL_MBR>,<UL_MBR>] [...]] OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Set Command | AT+CGEQOS=[<cid>,<QCI>,<DL_GBR>,<UL_GBR>,<DL_MBR>,<UL_MBR>] |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <cid>,<QCI>,<DL_GBR>,<UL_GBR>,<DL_MBR>,<UL_MBR> |
| <cid> | Integer type Specifies a particular EPS Traffic Flows definition in EPS (see the +CGDCONT and +CGDSCONT commands). |
| <QCI> | Integer type Specifies a class of EPS QoS (see 3GPP TS 23.203 and 3GPP TS 24.301): 0: QCI is selected by network [1 – 4]: value range for guaranteed bit rate Traffic Flows 75: value for guaranteed bit rate Traffic Flows [5 – 9]: value range for non-guaranteed bit rate Traffic Flows 79: value for non-guaranteed bit rate Traffic Flows [128 – 254]: value range for Operator-specific QCIs The QCI values 65, 66, 69 and 70 are not allowed to be requested by the UE. If the TE requests a QCI parameter 65, 66, 69 or 70, the MT responds with result code +CME ERROR: 181 (unsupported QCI value). |
| <DL_GBR> | Integer type Indicates DL GBR in case of GBR QCI. The value is in kbit/s. This parameter is omitted for a non-GBR QCI (see 3GPP TS 24.301). |

| | |
|-----------------------|--|
| <UL_GBR> | Integer type Indicates UL GBR in case of GBR QCI. The value is in kbit/s. This parameter is omitted for a non-GBR QCI (see 3GPP TS 24.301). |
| <DL_MBR> | Integer type Indicates DL MBR in case of GBR QCI. The value is in kbit/s. This parameter is omitted for a non-GBR QCI (see 3GPP TS 24.301). |
| <UL_MBR> | Integer type Indicates UL MBR in case of GBR QCI. The value is in kbit/s. This parameter is omitted for a non-GBR QCI (see 3GPP TS 24.301). |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | 3GPP TS 27.007 |

5.10 AT+CGEQOSRDP – EPS quality of service read dynamic parameters

The execution command returns the Quality of Service parameters <QCI>, [<DL_GBR>and <UL_GBR>]and [<DL_MBR>and <UL_MBR>] of the active secondary or non secondary PDP context associated to the provided context identifier <cid>.

If the parameter <cid>is omitted, the Quality of Service parameters for all secondary and non secondary active PDP contexts are returned.

The test command returns a list of <cid>s associated with secondary or non secondary active PDP contexts.

Parameters of both network and MT/TA initiated PDP contexts will be returned.

| AT+CGEQOSRDP – EPS quality of service read dynamic parameters | |
|---|---|
| Test Command | AT+CGEQOSRDP=? |
| Response | +CGEQOSRDP: (list of <cid>s associated with active contexts) OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Set Command | AT+CGEQOSRDP[=<cid>] |
| Response | [+CGEQOSRDP: <cid>,<QCI>,<DL_GBR>,<UL_GBR>] ,<DL_MBR>,<UL_MBR>][,<DL_AMBR>,<UL_AMBR>]] [<CR><LF>+CGEQOSRDP: <cid>,<QCI>,<DL_GBR>,<UL_GBR>] ,<DL_MBR>,<UL_MBR>][,<DL_AMBR>,<UL_AMBR>][...]] OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Execution Command | AT+CGEQOSRDP |
| Response | [+CGEQOSRDP: <cid>,<QCI>,<DL_GBR>,<UL_GBR>] ,<DL_MBR>,<UL_MBR>][,<DL_AMBR>,<UL_AMBR>]] [<CR><LF>+CGEQOSRDP: <cid>,<QCI>,<DL_GBR>,<UL_GBR>] ,<DL_MBR>,<UL_MBR>][,<DL_AMBR>,<UL_AMBR>][...]] OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <cid>,<QCI>,<DL_GBR>,<UL_GBR>,<DL_MBR>,<UL_MBR>,<DL_AMBR>,<UL_AMBR> |
| <cid> | Integer type Specifies a particular Traffic Flows definition in EPS (see the +CGDCONTand +CGDSCONTcommands). |
| <QCI> | Integer type Specifies a class of EPS QoS (see 3GPP TS 23.203 and 3GPP TS 24.301). 0 QCI is selected by network [1 – 4] value range for guaranteed bit rate Traffic Flows 65, 66, 75 values for guaranteed bit rate Traffic Flows [5 – 9] value range for non-guaranteed bit rate Traffic Flows 69, 70, 79 values for non-guaranteed bit rate Traffic Flows |

| | |
|-----------------------|--|
| | [128 – 254] value range for Operator-specific QCI |
| <DL_GBR> | Integer type Indicates DL GBR in case of GBR QCI. The value is in kbit/s. This parameter is omitted for a non-GBR QCI (see 3GPP TS 24.301). |
| <UL_GBR> | Integer type Indicates UL GBR in case of GBR QCI. The value is in kbit/s. This parameter is omitted for a non-GBR QCI (see 3GPP TS 24.301). |
| <DL_MBR> | Integer type Indicates DL MBR in case of GBR QCI. The value is in kbit/s. This parameter is omitted for a non-GBR QCI (see 3GPP TS 24.301). |
| <UL_MBR> | Integer type Indicates UL MBR in case of GBR QCI. The value is in kbit/s. This parameter is omitted for a non-GBR QCI (see 3GPP TS 24.301). |
| <DL_AMBR> | Integer type Indicates DL APN aggregate MBR (see 3GPP TS 24.301). The value is in kbit/s. |
| <UL_AMBR> | Integer type Indicates UL APN aggregate MBR (see 3GPP TS 24.301). The value is in kbit/s. |
| <err> | See Error List |
| Max Response Time | 5 sec |
| Parameter Saving Mode | NA |
| Reference | 3GPP TS 27.007 |

Note1:

The syntax of the AT Set Command is corrected to be according to ITU-T Recommendation V.250. Older versions of the specification specify incorrect syntax +CGEQOSRDP=[<cid>]

Note2:

If multiple lines in a response belong to the same PDN connection they contain the same <dl_ambr><ul_ambr>values.

5.11 AT+CGEREP – Packet domain event reporting

Set command enables or disables sending of unsolicited result codes, +CGEV: XXX from MT to TE in the case of certain events occurring in the Packet Domain MT or the network. Parameter <mode> controls the processing of unsolicited result codes specified within this command. If a setting is not supported by the MT, an error is returned.

Read command returns the current mode.

Test command returns the modes by the MT as compound values.

| AT+CGEREP – Packet domain event reporting | |
|---|--|
| Test Command | AT+CGEREP=? |
| Response | +CGEREP: (list of supported <mode>s) OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Read Command | AT+CGEREP? |
| Response | +CGEREP: <mode> OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Set Command | AT+CGEREP=[<mode>] |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <mode> |
| <mode> | Integer type 0: disables sending of unsolicited result codes 1: discards unsolicited result codes when MT-TE link is reserved (e.g. in on-line data mode); otherwise forward them directly to the TE |
| <err> | See Error List |
| Max Response Time | 5 sec |
| Parameter Saving Mode | SAVED to NVM using AT#RESET=1 Takes effect immediately |
| Reference | 3GPP TS 27.007 |

Note1:

The defined events are valid for GPRS/UMTS and LTE unless explicitly mentioned.

For network attachment, the following unsolicited result codes and the corresponding events are defined:

+CGEV: NW DETACH

The network has forced a PS detach. This implies that all active contexts have been deactivated. These are not reported separately.

+CGEV: ME DETACH

The mobile termination has forced a PS detach. This implies that all active contexts have been deactivated. These are not reported separately.

For PDP context activation, the following unsolicited result codes and the corresponding events are defined:

+CGEV: ME PDN ACT <cid>[,<reason>[,<cid_other>]]

The mobile termination has activated a context. The context represents a PDN connection in LTE or a Primary PDP context in GSM/UMTS. The <cid> for this context is provided to the TE. This event is sent either in result of explicit context activation request (+CGACT), or in result of implicit context activation request associated to attach request (+CGATT=1). The format of the parameters <cid> and <cid_other> are found in command +CGDCONT.

<reason>: integer type; indicates the reason why the context activation request for PDP type IPv4v6 was not granted. This parameter is only included if the requested PDP type associated with <cid> is IPv4v6, and the PDP type assigned by the network for <cid> is either IPv4 or IPv6.

- 0: IPv4 only allowed.
- 1: IPv6 only allowed.
- 2: single address bearers only allowed.
- 3: single address bearers only allowed and MT initiated context activation for a second address type bearer was not successful.

<cid_other>: integer type; indicates the context identifier allocated by MT for an MT initiated context of a second address type. MT shall only include this parameter if <reason> parameter indicates single address bearers only allowed, and MT supports MT initiated context activation of a second address type without additional commands from TE, and MT has activated the PDN connection or PDP context associated with <cid_other>.

Note2: For legacy TEs supporting MT initiated context activation without TE requests, there is also a subsequent event +CGEV: ME PDN ACT <cid_other> returned to TE.

+CGEV: NW ACT <p_cid>, <cid>, <event_type>

The network has activated a context. The <cid> for this context is provided to the TE in addition to the associated primary <p_cid>. The format of the parameters <p_cid> and <cid> are found in command +CGDCONT.

<event_type>: integer type; indicates whether this is an informational event or whether the TE has to acknowledge it.

- 0: Informational event
- 1: Information request: Acknowledgement required. The acknowledgement can be accept or reject, see +CGANS.

+CGEV: ME ACT <p_cid>, <cid>, <event_type>

The network has responded to an ME initiated context activation. The <cid> for this context is provided to the TE in addition to the associated primary <p_cid>. The format of the parameters <p_cid> and <cid> are found in command +CGDCONT. The format of the parameters <event_type> are defined above.

For PDP context deactivation, the following unsolicited result codes and the corresponding events are defined:

+CGEV: NW PDN DEACT <cid>

The network has deactivated a context. The context represents a PDN connection in LTE or a Primary PDP context in GSM/UMTS. The associated <cid> for this context is provided to the TE. The format of the parameter <cid> is found in command +CGDCONT.

+CGEV: ME PDN DEACT <cid>

The mobile termination has deactivated a context. The context represents a PDN connection in LTE or a Primary PDP context in GSM/UMTS. The <cid> for this context is provided to the TE. The format of the parameter <cid> is found in command +CGDCONT.

Note3: Occurrence of this event replaces usage of the event

+CGEV: ME DEACT <PDP_type>, <PDP_addr>, [<cid>].
+CGEV: NW DEACT <p_cid>, <cid>, <event_type>

The network has deactivated a context. The <cid> for this context is provided to the TE in addition to the associated primary <p_cid>. The format of the parameters <p_cid> and <cid> are found in command +CGDSCONT. The format of the parameters <event_type> are defined above.

Note4: Occurrence of this event replaces usage of the event

+CGEV: NW DEACT <PDP_type>, <PDP_addr>, [<cid>].
+CGEV: ME DEACT <p_cid>, <cid>, <event_type>

The network has responded to an ME initiated context deactivation request. The associated <cid> is provided to the TE in addition to the associated primary <p_cid>. The format of the parameters <p_cid> and <cid> are found in command +CGDSCONT. The format of the parameter <event_type> is defined above.

For PDP context modification, the following unsolicited result codes and the corresponding events are defined:

+CGEV: NW MODIFY <cid>, <change_reason>, <event_type>

The network has modified a context. The associated <cid> is provided to the TE in addition to the <change_reason> and <event_type>. The format of the parameter <cid> is found in command +CGDCONT or +CGDSCONT. The format of the parameters <change_reason>, <event_type>, and <WLAN_Offload> are defined above.

<change_reason>: integer type; a bitmap that indicates what kind of change occurred. The <change_reason> value is determined by summing all the applicable bits.

- Bit 1: TFT changed
- Bit 2: Qos changed

+CGEV: ME MODIFY <cid>, <change_reason>, <event_type>

The mobile termination has modified a context. The associated <cid> is provided to the TE in addition to the <change_reason> and <event_type>. The format of the parameter <cid> is found in command +CGDCONT or +CGDSCONT. The format of the parameters <change_reason> and <event_type> are defined above.

5.12 AT+CGPADDR – Show PDP address(es)

The execution command returns a list of PDP addresses for the specified context identifiers. If no `<cid>` is specified, the addresses for all defined contexts are returned.
The test command returns a list of defined `<cid>`.

| AT+CGPADDR – Show PDP address(es) | |
|-----------------------------------|--|
| Test Command | AT+CGPADDR=? |
| Response | +CGPADDR: list of defined <code><cid></code> OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Set Command | AT+CGPADDR[=<cid>[,<cid>[,...]]] |
| Response | [+CGPADDR: <cid>[,<PDP_addr_1>[,<PDP_addr_2>]]] [<CR><LF>+CGPADDR: <cid>[,<PDP_addr_1>[,<PDP_addr_2>]] [...]] OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Execution Command | AT+CGPADDR |
| Response | [+CGPADDR: <cid>[,<PDP_addr_1>[,<PDP_addr_2>]]] [<CR><LF>+CGPADDR: <cid>[,<PDP_addr_1>[,<PDP_addr_2>]] [...]] OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <cid>,<PDP_addr_1>,<PDP_addr_2> |
| <cid> | Integer type Specifies a particular PDP context definition (see the +CGDCONT and +CGDSCONT commands). |
| <PDP_addr_1> <PDP_addr_2> | String type Identifies the MT in the address space applicable to the PDP. The address may be static or dynamic. For a static address, it will be the one set by the +CGDCONT and +CGDSCONT commands when the context was defined. For a dynamic address it will be the one assigned during the last PDP context activation that used the context definition referred to by <cid>. Both <PDP_addr_1> and <PDP_addr_2> are omitted if none is available. Both <PDP_addr_1> and <PDP_addr_2> are included when both IPv4 and IPv6 addresses are assigned, with <PDP_addr_1> containing the IPv4 address and <PDP_addr_2> containing the IPv6 address. The string is given as dot-separated numeric (0-255) parameter of the form: a1.a2.a3.a4 for IPv4 and a1.a2.a3.a4.a5.a6.a7.a8.a9.a10.a11.a12.a13.a14.a15.a16 for IPv6. When +CGPIAF is supported, its settings can influence the format of the IPv6 address in parameter <PDP_addr_1> or <PDP_addr_2> returned with the execute form of +CGPADDR. |
| <err> | See Error List |

| | |
|-----------------------|----------------|
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | 3GPP TS 27.007 |

Note1:

The syntax of the AT Set Command is corrected to be according to ITU T Recommendation V.250. Older versions of the specification specify incorrect syntax +CGPADDR=[,<cid>[,<cid>[,...]]].

Note2:

In dual-stack terminals (<PDP_type> IPV4V6), the IPv6 address will be provided in <PDP_addr_2>. For terminals with a single IPv6 stack (<PDP_type> IPV6) or due to backwards compatibility, the IPv6 address can be provided in parameter <PDP_addr_1>.

5.13 AT+CGPIAF – Printing IP address format

Set command decides what format to print IPV6 address parameters of other AT commands. See RFC 4291 for details of the IPv6 address format.

The +CGPIAF parameters <IPv6_AddressFormat>, <IPv6_SubnetNotation>, <IPv6_LeadingZeros> and <IPv6_CompressedZeros> affect the following commands and parameters:

- a) in +CGTFT and +CGTFTRDP, the <remote_address_and_subnet_mask>;
- b) in +CGDCONT, the <PDP_addr>;
- c) in +CGPADDR, the <PDP_addr_1> and <PDP_addr_2>;
- d) in +CGCONTRDP, the <local address and subnet mask>, <DNS_prim_addr>, <DNS_sec_addr>, <P_CSCF_prim_addr> and <P_CSCF_sec_addr>; and
- e) in +CRC, the <PDP_addr> of unsolicited result code GPRS <PDP_type>, <PDP_addr>[, <L2P>][,<APN>]].

Read command returns the current command parameter settings.

Test command returns values supported as compound values.

| AT+CGPIAF – Printing IP address format | |
|--|--|
| Test Command | AT+CGPIAF=? |
| Response | +CGPIAF: (list of supported <IPv6_AddressFormat>s),(list of supported <IPv6_SubnetNotation>s),(list of supported <IPv6_LeadingZeros>s),(list of supported <IPv6_CompressZeros>s) OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Read Command | AT+CGPIAF? |
| Response | +CGPIAF: <IPv6_AddressFormat>,<IPv6_SubnetNotation>,<IPv6_LeadingZeros>,<IPv6_CompressZeros> OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Set Command | AT+CGPIAF=[<IPv6_AddressFormat>[,<IPv6_SubnetNotation>[,<IPv6_LeadingZeros>[,<IPv6_CompressZeros>]]]] |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <IPv6_AddressFormat>,<IPv6_SubnetNotation>,<IPv6_LeadingZeros>,<IPv6_CompressZeros> |
| <IPv6_AddressFormat> | Integer type Decides the IPv6 address format. Relevant for all AT command parameters that can hold an IPv6 address. 0: Use IPv4-like dot-notation. IP address, and subnetwork mask if applicable, are dot-separated. Example: For <remote_address_and_subnet_mask>: "32.1.13.184.0.0.205.48.0.0.0.0.0.0.0.255.255.255.255.255.255.240.0.0.0.0.0.0.0.0.0" For other IP address parameters: "32.1.13.184.0.0.205.48.0.0.0.0.0.0.0.0" |

| | |
|-----------------------|---|
| | <p>1: Use IPv6-like colon-notation. IP address, and subnetwork mask if applicable and when given explicitly, are separated by a space. Example:For <remote address and subnet mask>: "2001:0DB8:0000:CD30:0000:0000:0000:0000 FFFF:FFFF:FFFF:FFF0:0000:0000:0000:0000" For other IP address parameters: "2001:0DB8:0000:CD30:0000:0000:0000:0000"</p> |
| <IPv6 SubnetNotation> | <p>Integer type Decides the subnet-notation for <remote_address_and_subnet_mask>. Setting does not apply if <IPv6 AddressFormat> = 0.</p> <p>0: Both IP Address and subnet mask are stated explicitly, separated by a space. Example:"2001:0DB8:0000:CD30:0000:0000:0000:0000 FFFF:FFFF:FFFF:FFF0:0000:0000:0000:0000"</p> <p>1: The printout format is applying / (forward slash) subnet-prefix Classless Inter-Domain Routing (CIDR) notation. Example:"2001:0DB8:0000:CD30:0000:0000:0000:0000/60"</p> |
| <IPv6 LeadingZeros> | <p>Integer type Decides whether leading zeros are omitted or not. Setting does not apply if <IPv6_AddressFormat> = 0.</p> <p>0: Leading zeros are omitted. Example:"2001:DB8:0:CD30:0:0:0:0"</p> <p>1: Leading zeros are included. Example:"2001:0DB8:0000:CD30:0000:0000:0000:0000"</p> |
| <IPv6 CompressZeros> | <p>Integer type Decides whether 1-n instances of 16-bit zero-values are replaced by only '::'. This applies only once. Setting does not apply if <IPv6_AddressFormat> = 0.</p> <p>0: No zero compression. Example:"2001:DB8:0:CD30:0:0:0:0"</p> <p>1: Use zero compression. Example:"2001:DB8:0:CD30::"</p> |
| <err> | See Error List |
| Max Response Time | 5 sec |
| Parameter Saving Mode | SAVED to NVM using AT#RESET=1 Takes effect immediately |
| Reference | 3GPP TS 27.007 |

5.14 AT+ CGTFT – Traffic flow template

This command allows the TE to specify a Packet Filter - PF for a Traffic Flow Template - TFT that is used in the Packet GW in EPS for routing of packets onto different QoS flows towards the TE. The concept is further described in the 3GPP TS 23.060. A TFT consists of from one and up to 16 Packet Filters, each identified by a unique `<packet_filter_identifier>`. A Packet Filter also has an `<evaluation_precedence_index>` that is unique within all TFTs associated with all PDP contexts that are associated with the same PDP address.

The set command specifies a Packet Filter that is to be added to the TFT stored in the MT and used for the context identified by the (local) context identification parameter, `<cid>`. The specified TFT will be stored in the Packet GW in EPS only at activation or MS-initiated modification of the related context. Since this is the same parameter that is used in the +CGDCONT and +CGDSCONT commands, the +CGTFT command is effectively an extension to these commands. The Packet Filters consist of a number of parameters, each of which may be set to a separate value.

A special form of the set command, +CGTFT=`<cid>` causes all of the Packet Filters in the TFT for context number `<cid>` to become undefined. At any time, there may exist only one PDP context with no associated TFT amongst all PDP contexts associated to one PDP address. At an attempt to delete a TFT, which would violate this rule, an error is reported.

The read command returns the current settings for all Packet Filters for each defined context.

The test command returns values supported as compound values. If the MT supports several PDP types, the parameter value ranges for each PDP type are returned on a separate line. TFTs shall be used for PDP-type IP and PPP only. For PDP-type PPP a TFT is applicable only when IP traffic is carried over PPP. If PPP carries header-compressed IP packets, then a TFT cannot be used.

| AT+ CGTFT – Traffic flow template | |
|-----------------------------------|---|
| Test Command | AT+CGTFT=? |
| Response | +CGTFT: <code><PDP_type></code> , (list of supported <code><packet filter identifier></code> s), (list of supported <code><evaluation precedence index></code> s), (list of supported <code><remote address and subnet mask></code> s), (list of supported <code><protocol number (ipv4) / next header (ipv6)></code> s), (list of supported <code><local port range></code> s), (list of supported <code><remote port range></code> s), (list of supported <code><ipsec security parameter index (spi)></code> s), (list of supported <code><type of service (tos) (ipv4) and mask / traffic class (ipv6) and mask></code> s), (list of supported <code><flow label (ipv6)></code> s), (list of supported <code><direction></code> s), (list of supported <code><local address and subnet mask></code> s) [<CR><LF> +CGTFT: <code><PDP_type></code> , (list of supported <code><packet filter identifier></code> s), (list of supported <code><evaluation precedence index></code> s), (list of supported <code><remote address and subnet mask></code> s), (list of supported <code><protocol number (ipv4) / next header (ipv6)></code> s), (list of supported <code><local port range></code> s), (list of supported <code><remote port range></code> s), (list of supported <code><ipsec security parameter index (spi)></code> s), (list of supported <code><type of service (tos) (ipv4) and mask / traffic class (ipv6) and mask></code> s), (list of supported <code><flow label (ipv6)></code> s), (list of supported <code><direction></code> s), (list of supported <code><local address and subnet mask></code> s) [...] OK |

| | |
|---|---|
| <local_port_range> | String type The string is given as dot-separated numeric (0-65535) parameters on the form "f.t". |
| <remote_port_range> | String type The string is given as dot-separated numeric (0-65535) parameters on the form "f.t". |
| <ipsec security parameter index (spi)> | Numeric value in hexadecimal format. The value range is from 00000000 to FFFFFFFF. |
| <type of service (tos) (ipv4) and mask / traffic class (ipv6) and mask> | String type The string is given as dot-separated numeric (0-255) parameters on the form "t.m". |
| <flow label (ipv6)> | Numeric value in hexadecimal format. The value range is from 00000 to FFFFF. Valid for IPv6 only. |
| <direction> | Integer type Specifies the transmission direction in which the packet filter shall be applied. 0: Pre-Release 7 TFT filter (see 3GPP TS 24.008, table 10.5.162) 1: Uplink 2: Downlink 3: Birectional (Up & Downlink) |
| <local address and subnet mask> | String type The string is given as dot-separated numeric (0-255) parameters on the form: "a1.a2.a3.a4.m1.m2.m3.m4" for IPv4 or "a1.a2.a3.a4.a5.a6.a7.a8.a9.a10.a11.a12.a13.a14.a15.a16.m1.m2.m3.m4.m5.m6.m7.m8.m9.m10.m11.m12.m13.m14.m15.m16", for IPv6. When +CGPIAF is supported, its settings can influence the format of this parameter returned with the read form of +CGTFT. |
| <err> | See Error List |
| Max Response Time | 5 sec |
| Parameter Saving Mode | NA |
| Reference | 3GPP TS 27.007 |

Note: some of the above listed attributes may coexist in a Packet Filter while others mutually exclude each other, the possible combinations are shown in 3GPP TS 23.060.

5.15 AT+CRTDCP – Reporting of terminating data via the control plane

The set command is used to enable and disable reporting of data from the network to the MT that is transmitted via the control plane in downlink direction. If reporting is enabled, the MT returns the unsolicited result code +CMTDCP: <cpdata_length>,<cpdata> when data is received from the network.

Read command returns the current settings.

Test command returns supported values as compound values.

| AT+CRTDCP – Reporting of terminating data via the control plane | |
|---|--|
| Test Command | AT+CRTDCP=? |
| Response | +CMTDCP: (list of supported <reporting>), (range of supported <cid>), (maximum number of octets of user data indicated by <cpdata_length>) OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Read Command | AT+CRTDCP? |
| Response | +CMTDCP: [<reporting>] OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Set Command | AT+CMTDCP=[<reporting>] |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <reporting>,<cpdata_length>,<cpdata> |
| <reporting> | Integer type Reporting of mobile terminated control plane data events 0: Disable reporting of MT control plane data. 1: Enable reporting of MT control plane data by the unsolicited result code +CMTDCP. |
| <cpdata_length> | Integer type Indicates the number of bytes of the <cpdata> information element. When there is no data to transmit, the value shall be set to zero. |
| <cpdata> | String type Contains the User data container contents (refer 3GPPTS 24.301 subclause 9.9.4.24). When there is no data to transmit, the <cpdata> shall be an empty string (""). The length of <cpdata> is implementation specific. |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | SAVED to NVM using AT#RESET=1 Takes effect immediately |
| Reference | 3GPP TS 27.007 |

5.16 AT+CSCON – Signalling connection status

The set command controls the presentation of an unsolicited result code +CSCON. If `<n>=1`, +CSCON: `<mode>` is sent from the MT when the connection mode of the MT is changed. If `<n>=2` and there is a state within the current mode, +CSCON: `<mode>`[,`<state>`] is sent from the MT. If `<n>=3`, +CSCON: `<mode>`[,`<state>`][,`<access>`] is sent from the MT. If setting fails, an MT error, +CME ERROR: `<err>` is returned.

When the MT is E-UTRAN, the mode of the MT refers to idle when no PS signalling connection and to connected mode when a PS signalling connection between UE and network is setup.

The read command returns the status of result code presentation and an integer `<mode>` which shows whether the MT is currently in idle mode or connected mode. State information `<state>` is returned only when `<n>=2`. Radio access type information `<access>` is returned only when `<n>=3`.

Test command returns supported values as a compound value.

| AT+CSCON – Signaling connection status | |
|--|--|
| Test Command | AT+CSCON=? |
| Response | +CSCON: (list of supported <code><supported range></code>) OK |
| If there is any error | ERROR Or +CME ERROR: <code><err></code> |
| Read Command | AT+CSCON? |
| Response | +CSCON: <code><n></code> [, <code><mode></code>] [, <code><state></code>] [, <code><access></code>] OK |
| If there is any error | ERROR Or +CME ERROR: <code><err></code> |
| Set Command | AT+CSCON=[<code><n></code>] |
| Response | +CSCON=[<code><n></code>] OK |
| If there is any error | ERROR Or +CME ERROR: <code><err></code> |
| Parameters | <code><n></code> [, <code><mode></code>] [, <code><state></code>] [, <code><access></code>] |
| <code><n></code> | Integer type 0: disable unsolicited result code 1: enable unsolicited result code +CSCON: <code><mode></code> 2: enable unsolicited result code +CSCON: <code><mode></code> [, <code><state></code>] 3: enable unsolicited result code +CSCON: <code><mode></code> [, <code><state></code>] [, <code><access></code>] |
| <code><mode></code> | Integer type Indicates the signalling connection status 0: idle 1: connected |
| <code><state></code> | Integer type Indicates the CS or PS state while in GERAN and the RRC state information if the MT is in connected Mode while in UTRAN and E-UTRAN. 7: E-UTRAN connected state (only support) |

| | |
|-----------------------|---|
| <access> | Integer type Indicates the current radio access type. 4: Indicates usage of radio access of type E-UTRAN FDD, see 3GPP TS 36.300 (only support) |
| <err> | See Error List |
| Max Response Time | 1 |
| Parameter Saving Mode | SAVED to NVM using AT#RESET=1 Takes effect immediately |
| Reference | 3GPP TS 27.007 |

5.17 AT+CSODCP – Sending of originating data via the control plane

The set command is used by the TE to transmit data over control plane to network via MT. Context identifier <cid> is used to link the data to particular context.

This command optionally indicates that the application on the MT expects that the exchange of data will be completed with this uplink data transfer; or will be completed with the next received downlink data.

This command also optionally indicates whether or not the data to be transmitted is an exception data.

This command causes transmission of an ESM DATA TRANSPORT message, as defined in 3GPP TS 24.301.

Test command returns range of supported <cid>, the maximum number of bytes of user data indicated by <cpdata_length>, supported <RAI> and supported <type_of_user_data> as compound values.

| AT+CSODCP – Sending of originating data via the control plane | |
|---|---|
| Test Command | AT+CSODCP=? |
| Response | +CSODCP: (range of supported <cid>), (maximum number of octets of user data indicated by <cpdata_length>), (list of supported <RAI>),(list of supported <type_of_user_data>) OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Set Command | AT+CSODCP=<cid>,<cpdata_length>,<cpdata>[,<RAI>[,<type_of_user_data>]] |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <cid>,<cpdata_length>,<cpdata>,<RAI>,<type_of_user_data> |
| <cid> | Integer type Numeric parameter which specifies a particular PDP context or EPS bearer context definition. The <cid> parameter is local to the TE-MT interface and identifies the PDP or EPS bearer contexts which have been setup via AT command (see the +CGDCONT and +CGDSCONT commands). |
| <cpdata_length> | Integer type Indicates the number of octets of the <cpdata> information element. When there is no data to transmit, the value shall be set to zero. |
| <cpdata> | String of octets Contains the user data container contents (refer 3GPP TS 24.301 subclause 9.9.4.24). When there is no data to transmit, the <cpdata> shall be an empty string (""). This parameter shall not be subject to conventional character conversion as per +CSCS. The coding format of the user data container and the maximum length of <cpdata> are implementation specific. |
| <RAI> | Integer type Indicates the value of the release assistance indication, refer 3GPP TS 24.301 subclause 9.9.4.25. 0: No information available. 1: The MT expects that exchange of data will be completed with the transmission of the ESM DATA TRANSPORT message. 2: The MT expects that exchange of data will be completed with the receipt of an ESM DATA TRANSPORT message. |

| | |
|-----------------------|--|
| <type_of_user_data> | Integer type Indicates whether the user data that is transmitted is regular or exceptional. 0: Regular data. 1: Exception data. |
| <err> | See Error List |
| Max Response Time | 5 sec |
| Parameter Saving Mode | NA |
| Reference | 3GPP TS 27.007 |

Note1: There is a maximum data length of 589 bytes.

Note2: Only one message will be buffered at a time.

6 Network services commands

6.1 AT+CCIOTOPT – CloT optimization configuration

The set command controls which CloT EPS optimizations the UE indicates as supported and preferred in the “Attach Request” and “Tracking Area Update Request” messages. The command also allows reporting of the CloT EPS optimizations that are supported by the network.

A UE supporting CloT functionality may support control plane CloT EPS optimization or user plane CloT EPS optimization or both (see 3GPP TS 24.301, subclause 9.9.3.34). Based on the application characteristics the UE may prefer to be registered for control plane CloT EPS optimization or for user plane CloT EPS optimization (see 3GPP TS 24.301, subclause 9.9.3.0B).

Further, the network may support control plane CloT EPS optimization or user plane CloT EPS optimization or both (see 3GPP TS 24.301, subclause 9.9.3.12A).

The set command is also used to control the unsolicited result code +CCIOTOPTI. An unsolicited result code +CCIOTOPTI: <supported_network_opt> is used to indicate the supported CloT EPS optimizations by the network.

The read command returns the current settings for supported and preferred CloT EPS optimizations and the current status of unsolicited result code +CCIOTOPTI.

The test command returns values supported as compound values.

| AT+CCIOTOPT – CloT optimization configuration | |
|---|--|
| Test Command | AT+CCIOTOPT=? |
| Response | +CCIOTOPT: (list of supported <n>), (list of supported <supported_UE_opt>), (list of supported <preferred_UE_opt>) OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Read Command | AT+ CCIOTOPT? |
| Response | +CCIOTOPT: <n>,<supported_UE_opt>,<preferred_UE_opt> OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Set Command | AT+CCIOTOPT=<n>,[<supported_UE_opt>[,<preferred_UE_opt>]] |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <n>,<supported_UE_opt>,<preferred_UE_opt>,<supported_network_opt> |
| <n> | Integer type Enables or disables reporting of unsolicited result code +CCIOTOPTI: 0: disable reporting 1: enable reporting 3: disable reporting and reset the parameters for CloT EPS optimization to the default values |

| | |
|-------------------------|---|
| <supported_UE_opt> | Integer type Indicates the UE's support for CloT EPS optimizations: 0: no support 1: support for control plane CloT EPS optimization 2: support for user plane CloT EPS optimization 3: support for both control plane CloT EPS optimization and user plane CloT EPS optimization |
| <preferred_UE_opt> | Integer type Indicates the UE's preference for CloT EPS optimizations: 0: no preference 1: preference for control plane CloT EPS optimization 2: preference for user plane CloT EPS optimization |
| <supported_network_opt> | Integer type Indicates the Network support for CloT EPS optimizations: 0: no support 1: support for control plane CloT EPS optimization 2: support for user plane CloT EPS optimization 3: support for both control plane CloT EPS optimization and user plane CloT EPS optimization |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | SAVED to NVM using AT#RESET=1 Takes effect immediately |
| Reference | 3GPP TS 27.007 |

6.2 AT+CEDRXS – eDRX settings

The set command controls the setting of the UEs eDRX parameters. The command controls whether the UE wants to apply eDRX or not, as well as the requested eDRX value for each specified type of access technology.

The set command also controls the presentation of an unsolicited result code +CEDRXP: <AcT-type>[,<Requested_eDRX_value>[,<NW-provided_eDRX_value>[,<Paging_time_window>]]] when <n>=2 and there is a change in the eDRX parameters provided by the network.

A special form of the command can be given as +CEDRXS=3. In this form, eDRX will be disabled and data for all parameters in the command +CEDRXS will be removed or, if available, set to the manufacturer specific default values.

The read command returns the current settings for each defined value of <AcT-type>.

The test command returns the supported <mode>s and the value ranges for the access technology and the requested eDRX value as compound values.

| AT+CEDRXS – eDRX settings | |
|---------------------------|---|
| Test Command | AT+CEDRXS=? |
| Response | +CEDRXS: (list of supported <mode>s), (list of supported <AcT-type>s), (list of supported <Requested_eDRX_value>s) OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Read Command | AT+CEDRXS? |
| Response | [+CEDRXS: <AcT-type>,<Requested_eDRX_value> [<CR><LF>+CEDRXS: <AcT-type>,<Requested_eDRX_value> [...]]] OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Set Command | AT+CEDRXS=[<mode>[,<AcT-type>[,<Requested_eDRX_value>]]] |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <mode>,<AcT-type>,<Requested_eDRX_value>,<NW-provided_eDRX_value>,<Paging_time_window> |
| <mode> | Integer type Indicates to disable or enable the use of eDRX in the UE. This parameter is applicable to all specified types of access technology, i.e. the most recent setting of <mode> will take effect for all specified values of <AcT>. 0: Disable the use of eDRX 1: Enable the use of eDRX 2: Enable the use of eDRX and enable the unsolicited result code +CEDRXP: <AcT-type>[,<Requested_eDRX_value>[,<NW-provided_eDRX_value>[,<Paging_time_window>]]] 3: Disable the use of eDRX and discard all parameters |

| | |
|--------------------------|---|
| <AcT-type> | Integer type Indicates the type of access technology. This AT-command is used to specify the relationship between the type of access technology and the requested eDRX value. 0: Access technology is not using eDRX. This parameter value is only used in the unsolicited result code. 5: E-UTRAN (NB-S1 mode) |
| <Requested_eDRX_value> | String type Half a byte in a 4 bit format. The eDRX value refers to bit 4 to 1 of octet 3 of the Extended DRX parameters information element (see subclause 10.5.5.32 of 3GPP TS 24.008). For the coding and the value range, see Extended DRX parameters information element in 3GPP TS 24.008 Table 10.5.5.32. Does not support values: 0,1,4,6,7,8. |
| <NW-provided_eDRX_value> | String type Half a byte in a 4 bit format. The eDRX value refers to bit 4 to 1 of octet 3 of the Extended DRX parameters information element (see subclause 10.5.5.32 of 3GPP TS 24.008). For the coding and the value range, see Extended DRX parameters information element in 3GPP TS 24.008 Table 10.5.5.32. |
| <Paging_time_window> | String type Half a byte in a 4 bit format. The paging time window refers to bit 8 to 5 of octet 3 of the Extended DRX parameters information element (see subclause 10.5.5.32 of 3GPP TS 24.008). For the coding and the value range, see the Extended DRX parameters information element in 3GPP TS 24.008 Table 10.5.5.32. |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | SAVED to NVM using AT#RESET=1 Takes effect immediately |
| Reference | 3GPP TS 27.007 |

6.3 AT#PTW – eDRX Paging Time Window

The set command controls the setting of the UEs Paging Time Window (PTW) which is requested to the network for eDRX configuration.

The read command returns the current settings of this requested UEs PTW.

The test command returns the supported range of `<requested_paging_time_window>` in 4-bit format.

| AT#PTW – eDRX Paging Time Window | |
|---|---|
| Test Command | AT#PTW=? |
| Response | #PTW: Range of <code><requested_paging_time_window></code> OK |
| Read Command | AT#PTW? |
| Response | #PTW: <code><requested_paging_time_window></code> |
| If there is any error | ERROR Or +CME ERROR: <code><err></code> |
| Set Command | AT#PTW= <code><requested_paging_time_window></code> OK |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR: <code><err></code> |
| Parameters | <code><requested_paging_time_window></code> |
| <code><requested_paging_time_window></code> | String type Half a byte in a 4-bit format. The PTW refers to bit 8 to 5 of octet 3 of the Extended DRX parameters information element (see subclause 10.5.5.32 of 3GPP TS 24.008). For the coding and the value range, see the Extended DRX parameters information element in 3GPP TS 24.008 Table 10.5.5.32. |
| <code><err></code> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | SAVED to NVM using AT#RESET=1 Takes effect after reboot |
| Reference | Custom |

6.4 AT+CEDRXRDP – eDRX Read dynamic parameters

The execution command returns `<act-type>` and `<requested_edrx_value>`, `<nwprovided_edrx_value>` and `<paging_time_window>` if eDRX is used for the cell that the MS is currently registered to. If the cell that the MS is currently registered to is not using eDRX, `<act-type>=0` is returned.

| AT+CEDRXRDP – eDRX Read dynamic parameters | |
|---|--|
| Test Command | AT+CEDRXRDP=? |
| Response | OK |
| Execution Command | AT+CEDRXRDP |
| Response | <code><act_type>[,<requested_edrx_value>,<nwprovided_edrx_value>[,<paging_time_window>]]</code> OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <code><act_type></code> , <code><requested_edrx_value></code> , <code><nw-provided_edrx_value></code> , <code><paging_time_window></code> |
| <code><act_type></code> | Integer type Indicates the type of access technology. This AT-command is used to specify the relationship between the type of access technology and the requested eDRX value. 0: Access technology is not using eDRX 5: E-UTRAN (NB-S1 mode) |
| <code><requested_edrx_value></code> | String type Half a byte in a 4-bit format. The eDRX value refers to bit 4 to 1 of octet 3 of the Extended DRX parameters information element (see subclause 10.5.5.32 of 3GPP TS 24.008). For the coding and the value range, see Extended DRX parameters information element in 3GPP TS 24.008 Table 10.5.5.32. |
| <code><nw_provided_edrx_value></code> | String type Half a byte in a 4-bit format. The eDRX value refers to bit 4 to 1 of octet 3 of the Extended DRX parameters information element (see subclause 10.5.5.32 of 3GPP TS 24.008). For the coding and the value range, see Extended DRX parameters information element in 3GPP TS 24.008 Table 10.5.5.32. |
| <code><paging_time_window></code> | String type Half a byte in a 4-bit format. The paging time window refers to bit 8 to 5 of octet 3 of the Extended DRX parameters information element (see subclause 10.5.5.32 of 3GPP TS 24.008). For the coding and the value range, see the Extended DRX parameters information element in 3GPP TS 24.008 Table 10.5.5.32. |
| <code><err></code> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | 3GPP TS 27.007 |

6.5 AT+CEREG – EPS network registration status

The set command controls the presentation of an unsolicited result code +CEREG: <stat> .

- When <n>=1 and there is a change in the MT's EPS network registration status in E-UTRAN, or unsolicited result code +CEREG: <stat>[,<tac>],<ci>[,<AcT>]]
- When <n>=2 and there is a change of the network cell in E-UTRAN. The parameters <AcT>, <tac> and <ci> are provided only if available
- The value <n>=3 further extends the unsolicited result code with [<cause_type>,<reject_cause>], when available, when the value of <stat> changes.

If the UE wants to apply PSM for reducing its power consumption, see +CPSMS command and 3GPP TS 23.682, the set command controls the presentation of an unsolicited result code +CEREG: <stat>[,<tac>],<ci>[,<AcT>],<cause_type>[,<reject_cause>],<Active-Time>[,<Periodic-TAU>]]].

- When <n>=4 the unsolicited result code will provide the UE with additional information for the Active Time value and the extended periodic TAU value if there is a change of the network cell in E-UTRAN.
- The value <n>=5 further enhances the unsolicited result code with <cause_type> and <reject_cause> when the value of <stat> changes. The parameters <AcT>, <tac>, <ci>, <cause_type>, <reject_cause>, <Active-Time> and <Periodic-TAU> are provided only if available.

The read command returns the status of result code presentation and an integer <stat> which shows whether the network has currently indicated the registration of the MT. Location information elements <tac>, <ci> and <AcT>, if available, are returned only when <n>=2 and MT is registered in the network. The parameters [<cause_type>,<reject_cause>], if available, are returned when <n>=3.

| AT+CEREG – EPS network registration status | |
|--|--|
| Test Command | AT+CEREG=? |
| Response | +CEREG:(< list of supported <n>) OK |
| Read Command | AT+CEREG? |
| Response | when <n>=0, 1, 2 or 3 and command successful: +CEREG: <n>,<stat>[,<tac>],<ci>[,<AcT>,<cause_type>,<reject_cause>]]] OK when <n>=4 or 5 and command successful: +CEREG: <n>,<stat>[,<tac>],<ci>[,<AcT>],<cause_type>,<reject_cause>[,<Active-Time>],<Periodic-TAU>]]] OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Set Command | AT+CEREG=<n> |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <n>,<stat>,<tac>,<ci>,<act>,<cause_type>,<reject_cause>,<Active-Time>,<Periodic-TAU>,<err> |
| <n> | Integer type |

| | |
|-----------------------------------|--|
| | <p>0: Disable network registration unsolicited result code</p> <p>1: Enable network registration unsolicited result code +CEREG: <code><stat></code></p> <p>2: Enable network registration and location information unsolicited result code +CEREG: <code><stat>[,<tac>,<ci>,<AcT>]</code></p> <p>3: Enable network registration, location information and EMM cause value information unsolicited result code +CEREG: <code><stat>[,<tac>,<ci>,<AcT>][,<cause_type>,<reject_cause>]</code></p> <p>4: For a UE that wants to apply PSM, enable network registration and location information unsolicited result code +CEREG: <code><stat>[,<tac>,<ci>,<AcT>][,[,<Active-Time>,<Periodic-TAU>]]]</code></p> <p>5: For a UE that wants to apply PSM, enable network registration, location information and EMM cause value information unsolicited result code +CEREG: <code><stat>[,<tac>,<ci>,<AcT>][,<cause_type>,<reject_cause>][,<Active-Time>,<Periodic-TAU>]]]</code></p> |
| <code><stat></code> | <p>Integer type</p> <p>Indicates the EPS registration status:</p> <p>0: not registered, MT is not currently searching an operator to register to</p> <p>1: registered, home network</p> <p>2: not registered, but MT is currently trying to attach or searching an operator to register to</p> <p>3: registration denied</p> <p>4: unknown (e.g. out of E-UTRAN coverage)</p> <p>5: registered, roaming</p> <p>8: attached for emergency bearer services only (see Note 1)</p> <p>Note 1: 3GPPTS 24.008 and 3GPPTS 24.301 specify the condition when the MS is considered as attached for emergency bearer services.</p> |
| <code><tac></code> | <p>String type</p> <p>Two tracking bytes are coded in hexadecimal format (e.g. "00B5" equals 181 in decimal)</p> |
| <code><ci></code> | <p>String type</p> <p>Four-byte E-UTRAN cell ID in hexadecimal format</p> |
| <code><act></code> | <p>Integer type</p> <p>Indicates the access technology of the serving cell:</p> <p>9E-UTRAN (NB-S1 mode)</p> |
| <code><cause_type></code> | <p>Integer type</p> <p>Indicates the type of <code><reject_cause></code>:</p> <p>0: Indicates that <code><reject_cause></code> contains an EMM cause value, see 3GPP TS 24.301 Annex A.</p> <p>1: Indicates that <code><reject_cause></code> contains a manufacturer-specific cause.</p> |
| <code><reject_cause></code> | <p>Integer type</p> <p>Cause of the failed registration. The value is of type as defined by <code><cause_type></code>.</p> |
| <code><Active-Time></code> | <p>String type</p> <p>One byte in an 8 bit format. It indicates the Active Time value (T3324) allocated to the UE in E-UTRAN. The Active Time value is coded as one byte (octet 3) of the GPRS Timer 2 information element coded as bit format (e.g. "00100100" equals 4 minutes). For the coding and the value range, see the GPRS Timer 2 IE in 3GPP TS 24.008 Table 10.5.163. See also 3GPP TS 23.682 and 3GPP TS 23.401.</p> |
| <code><Periodic-TAU></code> | <p>String type</p> <p>One byte in an 8 bit format. It indicates the extended periodic TAU value (T3412) allocated to the UE in E-UTRAN. The extended periodic TAU value is coded as one byte (octet 3) of the GPRS Timer 3 information element coded as bit format (e.g. "01000111" equals 70 hours). For the coding and the value range, see the GPRS Timer 3 IE in 3GPP TS 24.008 Table 10.5.163a. See also 3GPP TS 23.682 and 3GPP TS 23.401.</p> |

| | |
|-----------------------|---|
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | Saved to NVM using AT#RESET=1 Takes effect immediately |
| Reference | 3GPP TS 27.007 |

6.6 AT+CESQ – Extended signal quality

Execution command returns received signal quality parameters.

| AT+CESQ – Extended Signal Quality | |
|-----------------------------------|---|
| Test Command | AT+CESQ=? |
| Response | +CESQ: (list of supported <rxlev>s),(list of supported <ber>s),(list of supported <rsrp>s),(list of supported <ecno>s),(list of supported <rsrq>s),(list of supported <rsrp>s) |
| Execution Command | AT+CESQ |
| Response | +CESQ: <rxlev>,<ber>,<rsrp>,<ecno>,<rsrq>,<rsrp> OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <rxlev>,<ber>,<rsrp>,<ecno>,<rsrq>,<rsrp> |
| <rxlev> | 99 as the serving cell is not a GERAN cell |
| <ber> | 99 as the serving cell is not a GERAN cell |
| <rsrp> | 255 as the serving cell is not a UTRA cell |
| <ecno> | 255 as the serving cell is not a UTRA cell |
| <rsrq> | Integer type Reference signal received quality (see 3GPP TS 36.133 subclause 9.1.7). 0: rsrq < -19.5 dB 1: -19.5 dB ≤ rsrq < -19 dB 2: -19 dB ≤ rsrq < -18.5 dB ... 32: -4 dB ≤ rsrq < -3.5 dB 33: -3.5 dB ≤ rsrq < -3 dB 34: -3 dB ≤ rsrq 255: Not known or not detectable |
| <rsrp> | Integer type Reference signal received power (see 3GPP TS 36.133 subclause 9.1.4). 0: rsrp < -140 dBm 1: -140 dBm ≤ rsrp < -139 dBm 2: -139 dBm ≤ rsrp < -138 dBm ... 95: -46 dBm ≤ rsrp < -45 dBm 96: -45 dBm ≤ rsrp < -44 dBm 97: -44 dBm ≤ rsrp 255 Not known or not detectable |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | 3GPP TS 27.007 |

6.7 AT+CLCK – Facility lock

Execute command is used to lock, unlock or interrogate a UE or a network facility <fac>. Password is normally needed to do such actions. When querying the status of a network service (<mode>=2) the response line for 'not active' case (<status>=0) should be returned only if service is not active for any <class>. This command is abortable when network facilities are set or interrogated.

Call barring facilities are based on GSM/UMTS supplementary services (refer 3GPP TS 22.088). The interaction of these with other commands based on other GSM/UMTS supplementary services is described in the GSM/UMTS standard.

Test command returns facility values supported as a compound value.

| AT+CLCK – Facility lock | |
|-------------------------|---|
| Test Command | AT+CLCK=? |
| Response | +CLCK:(<list of supported <fac>) OK |
| Set Command | AT+CLCK=<fac>,<mode>,<passwd>] |
| Response | If <mode>=2 and command successful: +CLCK: <status>[,<class1> [<CR><LF>+CLCK: <status>,<class2> [...]] OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <fac>,<mode>,<status>,<passwd> |
| <fac> | String type Only value "SC" is supported: SIM (lock SIM/UICC card installed in the currently selected card slot) (SIM/UICC asks password in UE power-up and when this lock command issued) |
| <mode> | Integer type 0: unlock 1: lock 2: query status |
| <status> | Integer type 0: not active 1: active |
| <passwd> | String type Shall be the same as password specified for the facility from the UE user interface or with command Change Password +CPWD |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | SAVED to NVM using AT#RESET=1 Takes effect after reboot |
| Reference | 3GPP TS 27.007 |

6.8 AT+COPS – PLMN selection

Set command forces an attempt to select and register the EPS network operator using the SIM/USIM card installed in the currently selected card slot.

<mode> is used to select whether the selection is done automatically by the MT or is forced by this command to operator <oper> (it shall be given in format <format>) to a certain access technology, indicated in <Act>.

If the selected operator is not available, no other operator shall be selected except in case of <mode>=4.

The selected operator name format shall apply to further read commands (+COPS?) also. <mode>=2 forces an attempt to deregister from the network. The selected mode affects to all further network registration (e.g. after <mode>=2, MT shall be unregistered until <mode>=0 or 1 is selected). This command should be abortable when registration/deregistration attempt is made.

Read command returns the current mode, the currently selected operator and the current Access Technology. If no operator is selected, <format>, <oper> and <Act> are omitted.

Test command returns a set of five parameters, each representing an operator present in the network.

A set consists of:

- an integer indicating the availability of the operator <stat>
- long alphanumeric format of the name of the operator
- short alphanumeric format of the name of the operator
- numeric format representation of the operator
- access technology.

Any of the formats may be unavailable and should then be an empty field.

The list of operators is in order: HPLMN selector, User controlled PLMN selector, Operator controlled PLMN selector and PLMN selector (in the SIM or GSM application), and other networks.

| AT+COPS – PLMN selection | |
|--------------------------|---|
| Test Command | AT+COPS=? |
| Response | +COPS: [list of supported (<stat>,long alphanumeric <oper>,short alphanumeric <oper>,numeric <oper>[,<Act>])s][,,(list of supported <mode>s),(list of supported <format>s)] OK |
| Read Command | AT+COPS? |
| Response | +CMD:<mode>[,<format>,<oper>[,<Act>]] OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Set Command | AT+COPS=[<mode>[,<format>[,<oper>[,<Act>]]]] |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <mode>,<format>,<oper>,<stat>,<Act> |
| <mode> | Integer type Selection mode: 0: automatic (<oper> field is ignored) 1: manual (<oper> field shall be present, and <Act> optionally) |

| | |
|-----------------------------|---|
| | <p>2: deregister from network</p> <p>3: set only <code><format></code> (for read command +COPS?), do not attempt registration/deregistration (<code><oper></code> and <code><Act></code> fields are ignored); this value is not applicable in read command response</p> <p>4: manual/automatic (<code><oper></code> field shall be present); if manual selection fails, automatic mode (<code><mode>=0</code>) is entered</p> |
| <code><format></code> | <p>Integer type</p> <p>Specified the format of parameter <code><oper></code></p> <p>0: long format alphanumeric <code><oper></code></p> <p>1: short format alphanumeric <code><oper></code></p> <p>2: numeric <code><oper></code></p> |
| <code><oper></code> | <p>String type</p> <p>Operator</p> <p>In case of long alphanumeric format, <code><oper></code> can be up to 16 characters long.</p> <p>In case of short alphanumeric format, <code><oper></code> can be up to 8 characters long.</p> <p>In case of a numeric format, <code><oper></code> is the GSM Location Area Identification number (refer 3GPP TS 24.008 subclause 10.5.1.3) which consists of a three BCD digit country code coded as in ITU-T Recommendation E.212 Annex A, plus a two BCD digit network code, which is administration specific; Returned <code><oper></code> is not in BCD format, but in IRA characters converted from BCD . Hence the number has structure: country code digit 3, country code digit 2, country code digit 1, network code digit 3, network code digit 2, network code digit 1.</p> |
| <code><stat></code> | <p>Integer type</p> <p>Indicates the operator availability:</p> <p>0: unknown</p> <p>1: available</p> <p>2: current</p> <p>3: forbidden</p> |
| <code><Act></code> | <p>Integer type</p> <p>Access technology selected</p> <p>9: E-UTRAN (NB-S1 mode)</p> |
| <code><err></code> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | <p>SAVED to NVM using AT#RESET=1</p> <p>Takes effect immediately</p> |
| Reference | 3GPP TS 27.007 |

6.9 AT+CPIN – Enter PIN

The set command sends to the UE a password which is necessary before it can be operated (SIM PIN, SIM PUK, PH-SIM PIN, etc.). If the PIN is to be entered twice, the TA shall automatically repeat the PIN. If no PIN request is pending, no action is taken towards UE and an error message, +CME ERROR, is returned to TE.

If the PIN required is SIM PUK or SIM PUK2, the second pin is required. This second PIN, <newpin>, is used to replace the old PIN in the SIM.

The read command returns an alphanumeric string indicating whether a password is required or not.

| AT+CPIN – Enter PIN | |
|-----------------------|---|
| Test Command | AT+CPIN=? |
| Response | OK |
| Read Command | AT+CPIN? |
| Response | +CPIN:<code> OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Set Command | AT+CPIN=<pin>[,<newpin>] |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <pin>,<newpin>,<code> |
| <pin> | String type Pin value |
| <newpin> | String type New PIN value |
| <code> | Values listed below: <ul style="list-style-type: none"> • READY: UE is not pending for any password • SIM PIN: UE is waiting SIM PIN to be given • SIM PUK: UE is waiting SIM PUK to be given • PH-SIM PIN: UE is waiting phone-to-SIM card password to be given • PH-FSIM PIN: UE is waiting phone-to-very first SIM card password to be given • PH-FSIM PUK: UE is waiting phone-to-very first SIM card unblocking password to be given • SIM PIN2: UE is waiting SIM PIN2 to be given (this <code>is recommended to be returned only when the last executed command resulted in PIN2 authentication failure (i.e. +CME ERROR: 17); if PIN2 is not entered right after the failure, it is recommended that MT does not block its operation) • SIM PUK2: UE is waiting SIM PUK2 to be given (this <code>is recommended to be returned only when the last executed command resulted in PUK2 authentication failure (i.e. +CME ERROR: 18); if PUK2 and new PIN2 are not entered right after the failure, it is recommended that MT does not block its operation) • PH-NETPIN: UE is waiting network personalization password to be given • PH-NET PUK: UE is waiting network personalization unblocking password to be given |

| | |
|-----------------------|---|
| | <ul style="list-style-type: none"> • PH-NETSUB PIN: UE is waiting network subset personalization password to be given • PH-NETSUB PUK: UE is waiting network subset personalization unblocking password to be given • PH-SP PIN: UE is waiting service provider personalization password to be given • PH-SP PUK: UE is waiting service provider personalization unblocking password to be given • PH-CORP PIN: UE is waiting corporate personalization password to be given • PH-CORP PUK: UE is waiting corporate personalization unblocking password to be given |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | SAVED in SIM (NOT SAVED in NVM) Takes effect immediately. |
| Reference | 3GPP TS 27.007 |

Note:

SIM PIN, SIM PUK, PH-SIM PIN, PH-FSIM PIN, PH-FSIM PUK, SIM PIN2 and SIM PUK2 refer to the PIN of the selected application on the UICC. For example, in an E-UTRAN context, the selected application on the currently selected UICC should be a USIM and the SIM PIN then represents the PIN of the selected USIM. See 3GPP TS 31.101 for further details on application selection on the UICC.

6.10 AT+CPSMS – Power saving mode setting

The set command controls the setting of the UEs power saving mode (PSM) parameters. The command controls whether the UE wants to apply PSM or not, as well as the requested extended periodic RAU value, the requested extended periodic TAU value in E-UTRAN and the requested Active Time value.

To get the Active Time value and the extended periodic TAU value that are allocated to the UE by the network, use the command AT+CEREG.

A special form of the command can be given as +CPSMS=2. In this form, the use of PSM will be disabled and data for all parameters in the command +CPSMS will be removed or, if available, set to the manufacturer specific default values.

The read command returns the current parameter values.

The test command returns the supported <mode> and the value ranges for the requested extended periodic RAU value, the requested extended periodic TAU value in E-UTRAN and the requested Active Time value as compound values.

| AT+CPSMS – Power saving mode setting | |
|--------------------------------------|---|
| Test Command | AT+CPSMS=? |
| Response | +CPSMS: (list of supported <mode>), (list of supported <requested periodic RAU>), (list of supported <requested GPRS_READY_timer>), (list of supported <requested periodic TAU>), (list of supported <requested active time>) OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Read Command | AT+CPSMS? |
| Response | +CPSMS: (list of supported <mode>), (list of supported <requested periodic RAU>), (list of supported <requested GPRS_READY_timer>), (list of supported <requested periodic TAU>), (list of supported <requested active time>) OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Set Command | AT+CPSMS=[<mode>,<requested periodic RAU>,<requested GPRS_READY_timer>,<requested periodic TAU>,<requested active time>] |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <mode>,<requested periodic RAU>,<requested GPRS_READY_timer>,<requested periodic TAU>,<requested active time> |
| <mode> | Integer type Indication to disable or enable the use of PSM in the UE: 0: disables the use of PSM 1: enables the use of PSM |

| | |
|----------------------------------|---|
| | 2: disables the use of PSM and discard all parameters for PSM or, if available, reset to the manufacturer specific default values. The read command AT+CPSMS? could only get mode value 0 and 1. |
| <requested periodic_RAU> | String type One byte in an 8-bit format. This field is not supported in NB-IOT. No value will be output, and any input will be ignored. |
| <requested GPRS _READY_timer> | String type One byte in an 8-bit format. This field is not supported in NB-IOT. No value will be output, and any input will be ignored. |
| <requested periodic_TAU> | String type One byte in an 8-bit format. Requested extended periodic TAU value (T3412) to be allocated to the UE in E-UTRAN. The requested extended periodic TAU value is coded as one byte (octet 3) of the GPRS Timer 3 information element coded as bit format (e.g. "01000111" equals 70 hours). For the coding and the value range, see the GPRS Timer 3 IE in 3GPP TS 24.008 Table 10.5.163a/3GPP TS 24.008. See also 3GPP TS 23.682 and 3GPP TS 23.401. The unit (first 3 bit value) does not support 7. (see 3GPP TS 24.008 10.5.7.4a.) |
| <requested_active _time> | String type One byte in an 8-bit format. Requested active time value (T3324) to be allocated to the UE. The requested active time value is coded as one byte (octet 3) of the GPRS Timer 2 information element coded as bit format (e.g. "00100100" equals 4 minutes). For the coding and the value range, see the GPRS Timer 2 IE in 3GPP TS 24.008 Table 10.5.163/3GPP TS 24.008. See also 3GPP TS 23.682, 3GPP TS 23.060 and 3GPP TS 23.401. The unit (first 3 bit value) does not support 3,4,5,6. (see 3GPP TS 24.008 10.5.7.3.) |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | SAVED to NVM using AT#RESET=1 Takes effect immediately |
| Reference | 3GPP TS 27.007 |

6.11 AT+CPWD – Change password

The set command defines a new password for the facility lock function handled by command Facility Lock +CLCK.

The test command returns a list of pairs which presents the available facilities and the maximum length of their password.

| AT+CPWD – Change password | |
|---------------------------|--|
| Test Command | AT+CPWD=? |
| Response | +CPWD: list of supported (<fac>,<pwdlength>)s OK |
| Set Command | AT+CPWD=<fac>,<oldpwd>,<newpwd > |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <fac>,<pwdlength>,<oldpwd>,<newpwd > |
| <fac> | String type Only value "SC" is supported |
| <pwdlength> | Integer type Maximum length of the password for the facility |
| <oldpwd> | String type Old Password, should be the same as password specified for the facility with previous command +CPWD |
| <newpwd> | String type New password |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | SAVED to NVM using AT#RESET=1 Takes effect immediately |
| Reference | 3GPP TS 27.007 |

6.12 AT+CTZR – Time Zone Reporting

The set command controls the time zone change event reporting. If reporting is enabled, the UE returns the unsolicited result code +CTZV: <tz>, +CTZE: <tz>,<dst>,<time>], or +CTZEU: <tz>,<dst>,<utime>] whenever the time zone is changed.

The UE also provides the time zone upon network registration if provided by the network.

The read command returns the current reporting settings in the UE.

The test command returns supported <reporting> values as a compound value.

| AT+CTZR – Time Zone Reporting | |
|-------------------------------|--|
| Test Command | AT+CTZR=? |
| Response | +CTZR: (list of supported <reporting>s) OK |
| Read Command | AT+CTZR? |
| Response | +CTZR:<reporting> OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Set Command | AT+CTZR=[<reporting>] |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <reporting>,<tz>,<dst>,<time>,<utime> |
| <reporting> | Integer type Reporting value: 0: disable time zone change event reporting. 1: enable time zone change event reporting by unsolicited result code +CTZV: <tz>. 2: enable extended time zone and local time reporting by unsolicited result code: +CTZE: <tz>,<dst>,<time>]. 3: enable extended time zone and universal time reporting by unsolicited result code: +CTZEU: <tz>,<dst>,<utime>]. |
| <tz> | String type Sum of the local time zone (difference between the local time and GMT expressed in quarters of an hour) plus daylight saving time. The format is "+zz", expressed as a fixed width, two-digit integer with the range -48 ... +56. To maintain a fixed width, numbers in the range -9 ... +9 are expressed with a leading zero, e.g. "-09", "+00" and "+09". |
| <dst> | Integer type Value indicating whether <tz> includes daylight savings adjustment: 0: <tz> includes no adjustment for Daylight Saving Time 1: <tz> includes +1 hour (equals 4 quarters in <tz>) adjustment for daylight saving time 2: <tz> includes +2 hours (equals 8 quarters in <tz>) adjustment for daylight saving time |
| <time> | String type Local time. The format is "YYYY/MM/DD,hh:mm:ss", expressed as integers representing year (YYYY), month (MM), date (DD), hour (hh), minute (mm) and second (ss). The local time can be derived by the UE from information provided by the |

| | |
|-----------------------|--|
| | network at the time of delivering time zone information and will be present in the unsolicited result code for extended time zone and local time reporting if the universal time is provided by the network. |
| <utime> | String type Universal time. The format is "YYYY/MM/DD,hh:mm:ss", expressed as integers representing year (YYYY), month (MM), date(DD), hour (hh), minute (mm) and second (ss). The universal time can be provided by the network at the time of delivering time zone information and will be present in the unsolicited result code for extended time zone and universal time reporting if provided by the network. |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | 3GPP TS 27.007 |

7 SMS commands

7.1 AT+CMGF – Message Format

This command indicates input and output format for SMS messages.

| AT+CMGF – SMS Message Format | |
|------------------------------|---|
| Test Command | AT+CMGF=? |
| Response | +CMGF: (list of supported <mode>) OK |
| Read Command | AT+CMGF? |
| Response | +CMGF:<mode> OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Set Command | AT+CMGF=<mode> |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameter | <mode> |
| <mode> | Integer type 0: PDU mode |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | 3GPP TS 27.005 |

Note:

Only PDU mode is supported.

7.2 AT+CMGS – Send Message

Execution command sends SMS message from TE to the network (SMS-SUBMIT).

Only PDU mode is supported (AT+CMGF=0).

Message reference value `<mr>` is returned to the TE on successful message delivery. Optionally (when +CSMS `<service>` value is 1 and network supports) `<ackpdu>` is returned. Values can be used to identify message upon unsolicited delivery status report result code.

If sending fails in a network or an ME error, final result code +CMS ERROR: `<err>` is returned.

This command should be abortable.

| AT+CMGS – Send Message | |
|------------------------|---|
| Test Command | AT+CMGS=? |
| Response | OK |
| Set Command | AT+CMGS=<length><CR> ><PDU><ctrl-Z/ESC> |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <length>,<PDU> |
| <length> | Integer type Length is the number of bytes of the PDU (SMSC address bytes are excluded) |
| <PDU> | PDU given in one line in hexadecimal format after the > prompt character The <ctrl-Z> character must be used to indicate the ending of PDU The sending can be cancelled by giving <ESC> character See examples below |
| <err> | See Error List |
| Max Response Time | 5 min |
| Parameter Saving Mode | NA |
| Reference | 3GPP TS 27.005 |

Example 1:

This example shows how to send a message in PDU mode - 7 bit format

- Message is text message 'SMS message': This text message composed of 7-bit ASCII characters are packed into 8-bit bytes to be inserted in PDU
- SMSC address is '764332637249279'
- Destination address is '764332637249270'

```
AT+CMGS=26<CR>
```

```
>
```

```
098167342336279472F911000F8167342336279472F00000AA0BD3E614D42ECFE7E17319<ctrl-Z>
```

0x09 is the number of bytes for the SMSC format and address

0x81 (=129) is the SMSC format

67342336279472F9 is the SMSC address

swapped digit by digit

F added as number is odd

0x11 TPDU
0x00 is the message reference number
0x0F is the length of the destination address
0x81 is the destination address format
67342336279472F0 is the destination address
0x00 is the protocol identifier
0x00 to select 7-bit mode
0xAA
0x0B is the length of the 7-bit message
D3E614D42ECFE7E17319 is the message

Example 2:

This example shows how to send a message in PDU mode 8 bit format

- Message is '010203040506070809'
- SMSC address is '764332637249279'
- Destination address is '764332637249270'

AT+CMGS=25<CR>

>

098167342336279472F911000F8167342336279472F00004AA09010203040506070809<ctrl-Z>

0x09 is the number of bytes for the SMSC format and address
0x81 (=129) is the SMSC format
67342336279472F9 is the SMSC address
swapped digit by digit
F added as number is odd

0x11 TPDU
0x00 is the message reference number
0x0F is the length of the destination address
0x81 is the destination address format
67342336279472F0 is the destination address
0x00 is the protocol identifier
0x04to select 8-bit mode
0xAA
0x09 is the length of the message in bytes
010203040506070809 is the message

7.3 AT+CNMA – New Message Acknowledgement

This command confirms reception of a new message (SMS-DELIVER or SMS-STATUS-REPORT) which is routed directly to the TE (refer command +CNMI). This acknowledgement command shall be used when +CSMS parameter [<service>](#) equals 1.

In PDU mode, it is possible to send either positive (RPACK) or negative (RP-ERROR) acknowledgement to the network. Parameter [<n>](#) defines which one will be sent.

Optionally (when [<length>](#) is greater than zero) an acknowledgement TPDU (SMS-DELIVER-REPORT for RPACK or RP-ERROR) may be sent to the network. The entering of PDU is done similarly as specified in command Send Message +CMGS, except that the format of [<ackpdu>](#) is used instead of [<PDU>](#) (i.e. SMSC address field is not present). PDU shall not be bounded by double quotes. TA shall not send another +CMT or +CDS result code to TE before previous one is acknowledged.

If ME does not get acknowledgement within required time (network timeout), ME should respond as specified in 3GPP TS 24.011 [6] to the network. ME/TA shall automatically disable routing to TE by setting both [<mt>](#) and [<ds>](#) values of +CNMI to zero.

If command is executed, but no acknowledgement is expected, or some other ME related error occurs, final result code +CMS ERROR: [<err>](#) is returned.

| AT+CNMA – New Message Acknowledgement | |
|---------------------------------------|---|
| Test Command | AT+CNMA=? |
| Response | +CNMA:(list of supported <n>s) OK |
| Set Command | AT+CNMA [= <n> [, <length> [<CR> <PDU> <CTRL-Z/ESC>]]] |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR: <err> |
| Parameters | <n> , <length> , <PDU> |
| <n> | Integer type 0: command operates similarly as defined for the text mode 1: send RP-ACK (or buffered result code received correctly) 2: send RP-ERROR (if PDU is not given, ME/TA shall send SMS-DELIVER-REPORT with 3GPP TS 23.040 [3] TP-FCS value set to 'FF' (unspecified error cause)) |
| <length> | String type 1 to 3 characters Number of bytes in the PDU |
| <PDU> | Hexadecimal format See AT+CMGS chapter for details. |
| <err> | See Error List |
| Max Response Time | 5 sec |
| Parameter Saving Mode | NA |
| Reference | 3GPP TS 27.005 |

7.4 AT+CNMI – New Message Indication

This command selects the procedure, how receiving of new messages from the network is indicated to the TE.

| AT+CNMI – New Message Indication | |
|----------------------------------|---|
| Test Command | AT+CNMI=? |
| Response | +CNMI: (list of supported <mode>), (list of supported <mt>), (list of supported <bm>), (list of supported <ds>), (list of supported <bfr>) OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Read Command | AT+CNMI? |
| Response | +CNMI:<mode>,<mt>,<bm>,<ds>,<bfr> OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Set Command | AT+CNMI=[<mode>,<mt>,<bm>,<ds>,<bfr>]]]] |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <mode>,<mt>,<bm>,<ds>,<bfr> |
| <mode> | Integer type 1: Discard indication and reject new received message unsolicited result codes when TA-TE link is reserved (e.g. in on-line data mode). Other value: forward them directly to the TE. |
| <mt> | Integer type 2: SMS-DELIVER are routed directly to the TE using unsolicited result code: +CMT: [<alpha>,<length><CR><LF><pdu> (PDU mode enabled) |
| <bm> | Integer type Not used |
| <ds> | Integer type 0: No SMS-STATUS-REPORTs are routed to the TE. 1: SMS-STATUS-REPORTs are routed to the TE using unsolicited result code: +CDS: <length><CR><LF><pdu> (PDU mode enabled) |
| <bfr> | Integer type 0: TA buffer of unsolicited result codes defined within this command is flushed to the TE when <mode> 1...3 is entered (OK response shall be given before flushing the codes). 1: TA buffer of unsolicited result codes defined within this command is cleared when <mode> 1...3 is entered. |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving | NA |



| | |
|-----------|----------------|
| Mode | |
| Reference | 3GPP TS 27.005 |

7.5 AT+CSCA – Service Center Address

This command sets the SMS center address through which mobile originated SMS are transmitted. In PDU mode, this is used only when the length of the SMSC address coded in the PDU equals zero.

| AT+CSCA – Service Center Address | |
|----------------------------------|---|
| Test Command | AT+CSCA=? |
| Response | OK |
| Read Command | AT+CSCA? |
| Response | +CSCA:<sca>,<tosca> OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Set Command | AT+CSCA =<sca>[,<tosca>] |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <sca>,<tosca>,<err> |
| <sca> | String format between “ “ Service Center Address value field BCD numbers (or GSM default alphabet characters) are converted to characters of the currently selected TE character set (specified by +CSCS in 3GPP TS 27.007); type of address given by <tosca> |
| <tosca> | Integer type Service Center Address format |
| <err> | See Error List |
| Max Response Time | 5 sec |
| Parameter Saving Mode | NA |
| Reference | 3GPP TS 27.005 |

7.6 AT+CSMS – Select SMS Message Service

This command selects messaging service **<service>**. It returns the types of messages supported by the ME: **<mt>** for mobile terminated messages, **<mo>** for mobile originated messages and **<bm>** for broadcast type messages.

If chosen service is not supported by the ME (but is supported by the TA), final result code +CMS ERROR: **<err>** shall be returned.

| AT+CSMS – Select SMS Message Service | |
|--------------------------------------|--|
| Test Command | AT+CSMS=? |
| Response | +CSMS:(<mt> , <mo>) OK |
| Read Command | AT+CSMS? |
| Response | +CSMS: <service> , <mt> , <mo> , <bm> OK |
| If there is any error | ERROR Or +CME ERROR: <err> |
| Set Command | AT+CSMS= <service> |
| Response | +CSMS: <mt> , <mo> , <bm> OK |
| If there is any error | ERROR Or +CME ERROR: <err> |
| Parameter | <service> , <mt> , <mo> , <bm> |
| <service> | Integer type 0: refer to 3GPP TS 23.040 and 3GPP TS 23.041 1: refer to 3GPP TS 23.040 and 3GPP TS 23.041 2 to 127: reserved |
| <mt> | Mobile Terminated 0: type not supported 1: type supported |
| <mo> | Mobile Originated 0: type not supported 1: type supported |
| <bm> | Broadcast Messages 0: type not supported 1: type supported |
| <err> | See Error List |
| Max Response Time | 5 sec |
| Parameter Saving Mode | NA |
| Reference | 3GPP TS 27.005 |

8 USIM commands

8.1 AT+CCHC – Close logical channel

This command requests the ME to close a communication session with the UICC the UE is attached to.

The ME shall close the previously opened logical channel. The TE will no longer be able to send commands on this logical channel. The UICC will close the logical channel when receiving this command.

| AT+CCHC – Close logical channel | |
|---------------------------------|---|
| Test Command | AT+CCHC=? |
| Response | OK |
| Set Command | AT+CCHC=<sessionid> |
| Response | +CCHC OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <sessionid> |
| <sessionid> | Integer type Session identifier to be used in order to target a specific application on the UICC using logical channels mechanism. |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | 3GPP TS 31.101, 3GPP TS 27.007 |

8.2 AT+CCHO – Open logical channel

The set command starts the allocation and establishment of a session with the UICC the UE is attached to.

The currently selected UICC will open a new logical channel; select the application identified by the `<dfname>` received with this command and return a session Id `<sessionid>` as the response.

The ME shall restrict the communication between the TE and the UICC to this logical channel.

| AT+CCHO – Open logical channel | |
|--------------------------------|---|
| Test Command | AT+CCHO=? |
| Response | OK |
| Set Command | AT+CCHO=<dfname> |
| Response | <sessionid> OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <dfname>, <sessionid> |
| <dfname> | String type All selectable applications in the UICC are referenced by a DF name coded on 1 to 16 bytes |
| <sessionid> | Integer type Session Id to be used in order to target a specific application on the UICC using logical channels mechanism. |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | 3GPP TS 31.101, 3GPP TS 27.007 |

Note:

The logical channel number is contained in the CLASS byte of an APDU command, thus implicitly contained in all APDU commands sent to a UICC. In this case it will be up to the MT to manage the logical channel part of the APDU CLASS byte and to ensure that the chosen logical channel is relevant to the `<sessionid>` indicated in the AT command.

See 3GPP TS 31.101 for further information on logical channels in APDU commands protocol.

8.3 AT+CGLA – Generic UICC logical channel access

In mobile networks, in a user equipment (UE), the terminal adapter (TA) is used by the terminal equipment (TE) to access the mobile termination (MT) using AT commands.

The +CGLA command helps sending to the TA some commands that shall be forwarded to the UICC that is attached to the TA.

This command allows direct control of the currently selected UICC by a distant application on the TE. The TE shall then take care of processing UICC information within the frame specified by the network.

See the references below for more details about the command usage.

| AT+CGLA – Generic UICC logical channel access | |
|---|---|
| Test Command | AT+CGLA=? |
| Response | OK |
| Set Command | AT+CGLA=<sessionid>,<length>,<command> |
| Response | +CGLA:<length>,<response> OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <sessionid>,<length>,<command>,<response> |
| <sessionid> | Integer type Session identifier to be used in order to send the APDU commands to the UICC. It is mandatory in order to send commands to the UICC when targeting applications on the smart card using a logical channel other than the default channel (channel "0"). |
| <length> | Integer type Length of the characters that are sent to TE in <command> or <response> (two times the actual length of the command or response) |
| <command> | command passed on by the MT to the UICC in the format as described in 3GPP TS 31.101 (hexadecimal character format) |
| <response> | Hexadecimal character format response to the command passed on by the UICC to the MT in the format as described in 3GPP TS 31.101 |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | 3GPP TS 31.101, 3GPP TS 31.102, 3GPP TS 27.007 |

Note: compared to Restricted UICC Access command +CRLA, the definition of +CGLA allows TE to take more control over the UICC-MT interface. The locking and unlocking of the interface may be done by a special <command> value or automatically by TA/MT (by interpreting <command> parameter). In case that TE application does not use the unlock command (or does not send a <command> causing automatic unlock) in a certain timeout value, MT may release the locking.

8.4 AT+CRSM – Restricted SIM access

By using this command instead of the generic SIM Access +CSIM, TE application has easier but more limited access to the SIM database.

Set command transmits to the MT the SIM [command](#) and its required parameters. If a SIM is installed in the currently selected card slot, the MT handles internally all SIM-MT interface locking and file selection routines. As response to the command, MT sends the actual SIM information parameters and response data. MT error result code +CME ERROR may be returned when the command cannot be passed to the SIM, but failure in the execution of the command in the SIM is reported in [sw1](#) and [sw2](#) parameters.

See references below for more details about the command usage.

| AT+CRSM – Restricted SIM access | |
|---|--|
| Test Command | AT+CRSM=? |
| Response | OK |
| Set Command | AT+CRSM=< command >[,< fileid >[,< P1 >,< P2 >,< P3 >[,< data >[,< pathid >]]]] |
| Response | +CRSM: < sw1 >,< sw2 >[,< response >] OK |
| If there is any error | ERROR Or +CME ERROR:< err > |
| Parameters | < command >,< fileid >,< P1 >,< P2 >,< P3 >,< data >,< pathid >,< sw1 >,< sw2 >,< response > |
| < command > | String type Command passed on by the MT to the SIM. Refer to 3GPP TS 51.011 '176': READ BINARY '178': READ RECORD '192': GET RESPONSE '214': UPDATE BINARY '220': UPDATE RECORD '242': STATUS '203': RETRIEVE DATA '219': SET DATA all other values are reserved See Note 1 |
| < fileid > | Integer type Identifier of an elementary datafile on SIM. Mandatory for every command except STATUS. See Note 2. |
| < P1 >, < P2 >,< P3 > | Integer type Parameters passed on by the MT to the SIM. These parameters are mandatory for every command, except GET RESPONSE and STATUS. The values are described in 3GPP TS 51.011 . |
| < data > | Hexadecimal character format Information which shall be written to the SIM . |
| < pathid > | String type Contains the path of an elementary file on the SIM/UICC in hexadecimal format as defined in ETSI TS 102 221 (e.g. "7F205F70" in SIM and UICC case). The < pathid > shall only be used in the mode "select by path from MF" as defined in ETSI TS 102 221. See Note 3. |
| < sw1 >, < sw2 > | Integer type Information from the SIM about the execution of the actual command. These |

| | |
|-----------------------|---|
| | parameters are delivered to the TE in both cases, on successful or failed execution of the command. |
| <response> | Response of a successful completion of the command previously issued (hexadecimal character format). STATUS and GET RESPONSE return data, which gives information about the current elementary data field. This information includes the type of file and its size (refer 3GPP TS 51.011). After READ BINARY, READ RECORD or RETRIEVE DATA command the requested data will be returned. <response> is not returned after a successful UPDATE BINARY, UPDATE RECORD or SET DATA command. |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | 3GPP TS 27.007, 3GPP TS 51.011, ETSI TS 102 221 |

Note1: The MT internally executes all commands necessary for selecting the desired file, before performing the actual command.

Note2: The range of valid file identifiers depends on the actual SIM and is defined in 3GPP TS 51.011. Optional files may not be present at all.

Note3: Since valid elementary file identifiers may not be unique over all valid dedicated file identifiers, the <pathid> indicates the targeted UICC/SIM directory path in case of ambiguous file identifiers.

8.5 AT+CSIM – Generic SIM access

The set command transmits to the MT the <command> it then shall send as it is to the SIM. In the same manner, the SIM <response> shall be sent back by the MT to the TA as it is.

This command allows direct control of the SIM that is installed in the currently selected card slot, by a distant application on the TE. The TE shall then take care of processing SIM information within the frame specified by the network.

| AT+CSIM – Generic SIM access | |
|------------------------------|---|
| Test Command | AT+CSIM=? |
| Response | OK |
| Set Command | AT+CSIM=<length>,<command> |
| Response | +CSIM: <length>,<response> OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <length>,<command>,<response> |
| <length> | Integer type Length of the characters that are sent to TE in <command> or <response> (two times the actual length of the command or response) |
| <command> | Hexadecimal character format Command passed on by the MT to the SIM in the format as described in 3GPP TS 51.011 |
| <response> | Hexadecimal character format Response to the command passed on by the SIM to the MT in the format as described in 3GPP TS 51.011 |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA. |
| Reference | 3GPP TS 27.007, 3GPP TS 51.011 |

Note:

Compared to Restricted SIM Access command +CRSM, the definition of +CSIM allows the TE to take more control over the SIM-MT interface. The locking and unlocking of the interface may be done by a special <command> value or automatically by TA/MT (by interpreting <command> parameter). In case that the TE application does not use the unlock command (or does not send a <command> causing automatic unlock) in a certain timeout value, MT may release the locking.

8.6 AT+ICCID – Request Integrated Circuit Card Identifier

AT+ICCID command execution allows the UE to return the Integrated Circuit Card Identifier number of the SIM card.

| AT+ICCID – Request Integrated Circuit Card Identifier | |
|---|---|
| Test Command | AT+ICCID=? |
| Response | OK |
| Execution Command | AT+ICCID |
| Response | [<iccid>] OK |
| If there is any error | ERROR Or +CME ERROR: <err> |
| Parameters | <iccid> |
| <iccid> | String without double quote Integrated Circuit Card Identifier |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |

Informative example:

To get <iccid> of the UE:
AT+ICCID
988812910100001424F9
OK

9 TCP-IP commands

9.1 AT#IPCFG – IPv4 or IPv6 configuration

This command is used to configure and activate the IPv4 or IPv6 protocol stack on top of an already established PDP context.

3 ways are possible to setup a new IP address:

- Create a static (manual) IP address. The entered IP address is analysed to determine the IP version (v4 or v6).
 - In case of IPv4 address, only the IP address is specified.
 - In case of IPv6 address, the IP address or prefix, and the prefix length shall be specified.
- Use the IPv6 autoconfiguration mechanism. Only available for IPv6.

| AT#IPCFG – IPv4 or IPv6 configuration | |
|--|--|
| Test Command | AT#IPCFG=? |
| Response | #IPCFG: <context_id>,<ip_mode>,<ip_address>[,<ipv6_prefix_length>] OK |
| Read Command | AT#IPCFG? |
| Response | #IPCFG: <context id>,<ip status>[,<ipv4 address>[,<ipv6 address>]] OK |
| Set Command | AT#IPCFG=<context id>,<ip mode>,<ip address>[,<ipv6 prefix length>] |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameter | <context_id>,<ip_mode>,<ip_status>,<ip_address>,<ipv4_address>,<ipv6_address>,<ipv6_prefix_length> |
| <context_id> | Integer type Context number established on modem side. |
| <ip_mode> | Integer type 0: Static/Manual IP configuration. Used when the IP address is provided by the network. This address can be read using the AT command AT+CGPADDR 1: DHCP mode. Address is obtained from a DHCP server. This mode is not supported in this version of firmware. 2: IPv6 auto configuration mode. Only available for IPv6. |
| <ip_status> | Integer type 0: The IP address is down due to the deactivation of PDP context 1: The IP address is active and its related PDP context is also active 2: The IP address is deleted because a new PDP context with different address is active |
| <ip_address> <ipv4_address> <ipv6_address> | String type. IPv4 or IPv6 address provided by the network: IPv4 example: 192.168.10.30 IPv6 example: cafe:baba::01 |
| <ipv6_prefix_length> | Integer type Length, in number of bit, of the prefix. Only used in case of IPv6. |
| <err> | See Error List |
| Max Response Time | 1 sec |

| | |
|-----------------------|--------|
| Parameter Saving Mode | NA |
| Reference | Custom |

9.2 AT#IPDEL – Delete IP configuration

| AT#IPDEL – Delete IP configuration | |
|------------------------------------|---|
| Test Command | AT#IPDEL=? |
| Response | #IPDEL: <context_id> OK |
| Set Command | AT#IPDEL: <context_id> |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameter | <context_id> |
| <context_id> | Integer type Context number established on modem side. |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | Custom |

9.3 AT#IPPARAMS – IP stack configuration

This command is used to configure the IP stack parameters before using it.

| AT#IPPARAMS – IP stack configuration | |
|--------------------------------------|--|
| Test Command | AT#IPPARAMS=? |
| Response | #IPPARAMS: <auto_ip>,<preferred_ip_version>,<max_ipstack_periodicity>,<auto_ip_timeout> OK |
| Read Command | AT#IPPARAMS? |
| Response | #IPPARAMS: <auto_ip>,<preferred_ip_version>,<max_ipstack_periodicity>,<auto_ip_timeout> OK |
| Set Command | AT#IPPARAMS=<auto_ip>,<preferred_ip_version>,<max_ipstack_periodicity>,<auto_ip_timeout> |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameter | <auto_ip>,<preferred_ip_version>,<max_ipstack_periodicity>,<auto_ip_timeout> |
| <auto_ip> | Integer type 0: Automatic configuration of IP link not activated. 1: Automatic configuration of IP link activated. When activated, the stack will, by itself, configure the IPv4 and IPv6 addresses and parameters with the information provided by the network. |
| <preferred_ip_version> | Integer type 0: IPv4 is the preferred stack 1: IPv6 is the preferred stack. The preferred stack will be used by default in case the parameter provided by the user cannot help to decide. |
| <max_ipstack_periodicity> | Integer type Max Timer in second for the IP stack periodicity. By default, it is set to 0xFFFF (no periodic wake-up is supported unless except it is managed in the Customer Application mode) |
| <auto_ip_timeout> | Integer type Timer in second between the module startup and attached PS attachment state for entering in sleep |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | SAVED to NVM using AT#RESET=1 Takes effect after module reboot. |
| Reference | Custom |

9.4 AT#IPING – ICMPv4/v6 request (ping)

This command is used to send IPv4 or IPv6 ping to a remote device, using an already established IP context.

| AT#IPING – ICMPv4/v6 request (ping) | |
|-------------------------------------|--|
| Test Command | AT#IPING=? |
| Response | #IPING: <context_id>,<ip_address> [,<timeout>,<number_of_bytes>,<number_of_ping>] OK |
| Set Command | AT#IPING=<context_id>,<ip_address>[,<timeout>,<number_of_bytes>,<number_of_ping>]] |
| Response | 1,<result>,<nb_bytes_transmitted>,<transmission_time> 2,<result>,<nb_bytes_transmitted>,<transmission_time> ... <number_of_ping>,<result>,<nb_bytes_transmitted>,<transmission_time> #IPING:<nb_ping_sent>,<nb_ping_received>,<nb_ping_lost>,<min_transmission_time>,<max_transmission_time>,<average_transmission_time> OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameter | <context_id>,<ip_address>,<timeout>,<number_of_bytes>,<number_of_ping>,<result>,<nb_bytes_transmitted>,<transmission_time>,<nb_ping_sent>,<nb_ping_received>,<nb_ping_lost>,<min_transmission_time>,<max_transmission_time>,<average_transmission_time> |
| <context_id> | Integer type Context number established on modem side. |
| <ip_address> | String type IPv4 or IPv6 address of the remote target to ping. |
| <timeout> | Integer type Timeout value waiting for the ICMP answer (1 to 120 seconds) This parameter is optional. By default it is set to 60 seconds |
| <number_of_bytes> | Integer type Number of bytes in the ICMP request. The minimum value is 1 and the maximum is 450. This parameter is optional. By default it is set to 10. |
| <number_of_ping> | Integer type Number of ping to transmit. Minimum number is 1 and maximum is 20. This parameter is optional. By default it is set to 1. |
| <result> | Integer type Result of the transmission of an ICMP message. Can take the values: 0: Ping OK 1: Ping KO – No answer to ICMP request received before timeout. 2: Bad sequence number received. 3: ICMP transmission failed |
| <nb_bytes_transmitted> | Integer type Number of data correctly transmitted in the ICMP packet |
| <transmission_time> | Integer type Transmission time in milliseconds. In case the ICMP answer is not received before timeout, the returned transmission time is 999999 |

| | |
|-----------------------------|---|
| <nb_ping_sent> | Integer type Final status - Number of ping transmitted by the module |
| <nb_ping_received> | Integer type Final status - Number of ICMP answer received by the module |
| <nb_ping_lost> | Integer type Final status - Number of ping transmitted without answer received |
| <min_transmission_time> | Integer type Final status – Minimum transmission time in milliseconds |
| <max_transmission_time> | Integer type Final status – Maximum transmission time in milliseconds |
| <average_transmission_time> | Integer type Final status – Average transmission time in milliseconds |
| <err> | See Error List |
| Max Response Time | <timeout> seconds |
| Parameter Saving Mode | NA |
| Reference | Custom |

9.5 AT#IPREAD – Read data available in TCP or UDP receiving buffer

| AT#IPREAD – Read data available in TCP or UDP receiving buffer | |
|--|---|
| Test Command | AT#IPREAD=? |
| Response | #IPREAD: <context_id>,<socket_id> OK |
| Set Command | AT#IPREAD=<context_id>,<socket_id> |
| Response | <data> OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameter | <context_id>,<socket_id> |
| <context_id> | Integer type Context number established on modem side. The IP stack has been configured for this context with the AT#IPCFG command. |
| <socket_id> | Integer type Socket number created on this context with the AT#SOCKETCREATE command. |
| <err> | See Error List |
| Max Response Time | 30 sec |
| Parameter Saving Mode | NA |
| Reference | Custom |

9.6 AT#IPSENDTCP – Send data over an established socket using TCP protocol

This command is used to send data in TCP mode using a previously established IP socket.

| AT#IPSENDTCP – Send data over an established socket using TCP protocol | |
|--|--|
| Test Command | AT#IPSENDTCP=? |
| Response | #IPSENDTCP: <context_id>,<socket_id>,<data_type>,[<data_length>],[<data>] OK |
| Set Command | AT#IPSENDTCP=<context_id>,<socket_id>,<data_type>,[<data_length>],[<data>] |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameter | <context_id>,<socket_id>,<data_type>,<data_length>,<data> |
| <context_id> | Integer type Context number established on modem side. The IP stack has been configured for this context with the AT#IPCFG command. |
| <socket_id> | Integer type Socket number created on this context with the AT#SOCKETCREATE command for a TCP connection. The TCP link shall be established before calling this command. |
| <data_type> | Integer type Type of data to transmit: 0: ASCII String as next parameter 1: Binary data. Next parameter is the data length followed by <CR><LF> Data in binary format is entered just after. 2: Hex data in text mode: 01A34B... = 0x01 0xA3 0x4B |
| <data_length> | Integer type Number of data. Only present for binary mode. Can take value from 1 to 512. |
| <data> | String or Hex or Binary type Maximum size is 512 bytes. |
| <err> | See Error List |
| Max Response Time | 10 sec |
| Parameter Saving Mode | NA |
| Reference | Custom |

9.7 AT#IPSENDUDP – Send data using UDP protocol.

This command is used to send data in UDP mode using a previously established IP link.

| AT#IPSENDUDP – Send data using UDP protocol. | |
|--|--|
| Test Command | AT#IPSENDUDP=? |
| Response | #IPSENDUDP: <context_id>,<socket_id>,<ip_address>,<port>,<rai>,<data_type>,<data_length>,<data> OK |
| Set Command | AT#IPSENDUDP=<context_id>,<socket_id>,<ip_address>,<port>,<rai>,<data_type>,<data_length>,<data> |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameter | <context_id>,<socket_id>,<ip_address>,<port>,<rai>,<data_type>,<data_length>,<data> |
| <context_id> | Integer type Context number established on modem side. The IP stack has been configured for this context with the AT#IPCFG command. |
| <socket_id> | Integer type Socket number created on this context with the AT#SOCKETCREATE command for an UDP communication. |
| <ip_address> | String type IPv4 or IPv6 address of the remote target. |
| <port> | Integer type Port number |
| <rai> | Integer type Specifies release assistance information: 0: No information available (or none of the other options apply) 1: TE will send only 1 UL packet and no DL packets expected 2: TE will send only 1 UL packet and only 1 DL packet expected |
| <data_type> | Integer type Type of data to transmit: 0: ASCII String as next parameter 1: Binary data. Next parameter is the data length follow by <CR><LF> Data in binary format is entered just after. 2: Hex data in text mode: 01A34B... = 0x01 0xA3 0x4B |
| <data_length> | Integer type Number of data. Only present for binary mode. Can takes value from 1 to 512 |
| <data> | String or Hex or Binary type Maximum size if 512 bytes. |
| <err> | See Error List |
| Max Response Time | 10 sec |
| Parameter Saving Mode | NA |
| Reference | Custom |

9.8 AT#SOCKETCLOSE – Close a socket identify by the context number

| AT#SOCKETCLOSE – Close a socket identify by the context number | |
|--|---|
| Test Command | AT#SOCKETCLOSE=? |
| Response | #SOCKETCLOSE: <context_id>,<socket_id> OK |
| Set Command | AT#SOCKETCLOSE=<context_id>,<socket_id> |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameter | <context_id>,<socket_id> |
| <context_id> | Integer type Context number established on modem side. The IP stack has been configured for this context with the AT#IPCFG command. |
| <socket_id> | Integer type Socket number created on this context with the AT#SOCKETCREATE command. If a TCP link is connected on this socket, it will be automatically closed. |
| <err> | See Error List |
| Max Response Time | 60 sec |
| Parameter Saving Mode | NA |
| Reference | Custom |

9.9 AT#SOCKETCREATE – Create a new socket on top of an existing IPv4/v6 link

This command is used to configure and activate the IPv4 or IPv6 protocol stack on top of an already established PDP context.

| AT#SOCKETCREATE – Create a new socket on top of an existing IPv4/v6 link | |
|--|---|
| Test Command | AT#SOCKETCREATE=? |
| Response | #SOCKETCREATE:<context_id>,<ip_version>,<socket_type>,[<udp_port>],<send_timeout>,<receive_timeout>[,<frame_received_urc>,<security_profile_id>] OK |
| Read Command | AT#SOCKETCREATE? |
| Response | #SOCKETCREATE: <context_id>,<socket_id>,<socket_status>,<socket_type>,<udp_port>,<send_timeout>,<receive_timeout>,<frame_received_urc>,<security_profile_id> ... <context_id>,<socket_id>,<socket_status>,<socket_type>,<udp_port>,<send_timeout>,<receive_timeout>,<frame_received_urc>,<security_profile_id> OK |
| Set Command | AT#SOCKETCREATE=<context_id>,<ip_version>,<socket_type>,[<udp_port>],<send_timeout>,<receive_timeout>[,<frame_received_urc>,<security_profile_id>] |
| Response | #SOCKETCREATE:<socket_id> OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameter | <context_id>,<socket_id>,<ip_version>,<socket_status>,<socket_type>,<udp_port>,<send_timeout>,<receive_timeout>,<frame_received_urc>,<security_profile_id> |
| <socket_status> | Integer type 0: socket not assigned 1: socket not activated 2: activating socket 3: socket activated 4: UDP socket created 5: raw link 6: TCP socket not connected 7: TCP socket connected |
| <context_id> | Integer type Context number established on modem side. The IP stack has been configured for this context with the AT#IPCFG command. |
| <socket_id> | Integer type ID of the new created socket. This number starts with 0 and is incremented each time a new socket is created. The maximum number of sockets supported by the system is 3: one TCP socket and two UDP sockets. This <socket_id> shall be indicated when using the socket for data transmission or to close the socket. |
| <ip_version> | Integer type The IP version to use for the socket: 0: IPv4 |

| | |
|-----------------------|---|
| | 1: IPv6 This parameter shall be in line with the IP link configuration. If IPv4 version is requested and the IP address of the link is IPv6, or if IPv6 is requested for IPv4 link, an error will be reported. |
| <socket_type> | String type The type of socket to create: "TCP": TCP communication "UDP": UDP communication "RAW": Data RAW communication |
| <udp_port> | Integer type The port number to open for UDP reception. This parameter is present only in case of UDP protocol. |
| <send_timeout> | Integer type Maximum time needed for transmission of packet over the air and reception of acknowledgement. |
| <receive_timeout> | Integer type Maximum time needed for transmission of packet over the air. |
| <frame_received_urc> | Integer value (0 or 1) Indicates if an URC (#IPRECV) shall be generated when TCP or UDP data are available and can be read with AT#IPREAD command. |
| <security_profile_id> | Integer type Optional parameter If specified and if the security profile exists, a TLS link will be used for the socket. |
| <err> | See Error List |
| Max Response Time | 2 sec |
| Parameter Saving Mode | NA |
| Reference | Custom |

9.10 AT#TCPCONNECT – Establish a TCP link using a configured IP socket

This command is used to establish a TCP connection using a previously established IP socket. The socket is identified by its context number.

| AT#TCPCONNECT – Establish a TCP link using a configured IP socket | |
|---|---|
| Test Command | AT#TCPCONNECT=? |
| Response | #TCPCONNECT: <context_id>,<socket_id>,<ip_address>,<port_number> OK |
| Read Command | AT#TCPCONNECT? |
| Response | # TCPCONNECT: <context_id>,<socket_id>,<status> OK |
| Set Command | AT#TCPCONNECT=<context_id>,<socket_id>,<ip_address>,<port_number> |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameter | <context_id>,<socket_id>,<ip_address>,<port_number> |
| <context_id> | Integer type Context number established on modem side. The IP stack has been configured for this context with the AT#IPCFG command. |
| <socket_id> | Integer type Socket number created on this context with the AT#SOCKETCREATE command. |
| <ip_address> | String type IPv4 or IPv6 address of the remote target. |
| <port_number> | Integer type Port number |
| <status> | Integer type Status of the TCP link: 3: TCP not connected 4: TCP connecting 5: TCP connected |
| <err> | See Error List |
| Max Response Time | 10 sec |
| Parameter Saving Mode | NA |
| Reference | Custom |

10 HTTP commands

10.1 AT#HTTPMETHOD – Send a method on an established HTTP session

This command is used to send a HTTP method (GET, POST, HEAD or PUT) to a remote server. TCP/IP socket shall already be established and connected to the server.

| AT#HTTPMETHOD – Send a method on an established HTTP session | |
|--|--|
| Test Command | AT#HTTPMETHOD=? |
| Response | #HTTPMETHOD: <method>,<method_path> OK |
| Set Command | #HTTPMETHOD=<method>,<method_path> |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameter | <method>,<method_path> |
| <method> | String type Method to send on the HTTP link (opened TCP link). Method shall be one of the following text: GET, POST, HEAD or PUT |
| <method_path> | String type Contains the method request. Result is sent to the caller directly. |
| <err> | See Error List |
| Max Response Time | 10 sec |
| Parameter Saving Mode | NA |
| Reference | Custom RFC 7231 |

10.2 AT#HTTPSTART – Start the HTTP protocol stack

This command is used to start the HTTP protocol stack.

| AT#HTTPSTART – Start the HTTP protocol stack | |
|--|---|
| Test Command | AT#HTTPSTART=? |
| Response | #HTTPSTART: <context_id>,<socket_id> OK |
| Read Command | AT#HTTPSTART? |
| Response | If connected to a remote server: #HTTPSTART: 1, <context_id>,<socket_id> OK Or If not connected: #HTTPSTART: 0 OK |
| Set Command | AT#HTTPSTART=<context_id>,<socket_id> |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameter | <context_id>,<socket_id> |
| <context_id> | Integer type Context number established on modem side. The IP stack has been configured for this context with the AT#IPCFG command. |
| <socket_id> | Integer type Socket number created on this context with the AT#SOCKETCREATE command. |
| <err> | See Error List |
| Max Response Time | 10 sec |
| Parameter Saving Mode | NA |
| Reference | Custom |

10.3 AT#HTTPSTOP – Stop the HTTP protocol stack

| AT#HTTPSTOP – Stop the HTTP protocol stack | |
|--|---------------------------------|
| Test Command | AT#HTTPSTOP=? |
| Response | OK |
| Execution Command | AT#HTTPSTOP |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | |
| <err> | See Error List |
| Max Response Time | 10 sec |
| Parameter Saving Mode | NA |
| Reference | Custom |

11 MQTT commands

11.1 AT#MQTTCFG – Configure the MQTT protocol stack

This command is used to configure the MQTT protocol stack before using it.
If this command is not called, the parameters saved in NVM are used.

| AT#MQTTCFG – Configure the MQTT protocol stack | |
|--|---|
| Test Command | AT#MQTTCFG=? |
| Response | #MQTTCFG: [<client_name>],[<connexion_timeout>],[<protocol_timeout>],[<publish_retry>],[<keep_alive_pub_msg>] OK |
| Read Command | AT#MQTTCFG? |
| Response | #MQTTCFG: <client_name>,<connexion_timeout>,<protocol_timeout>,<publish_retry>,<keep_alive_pub_msg> OK |
| Set Command | AT#MQTTCFG=[<client_name>],[<connexion_timeout>],[<protocol_timeout>],[<publish_retry>],[<keep_alive_pub_msg>] |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <client_name>,<connexion_timeout>,<protocol_timeout>,<publish_retry>,<keep_alive_pub_msg> |
| <client_name> | UTF-8 encoded string Maximum size is 25 characters. Name of the MQTT client that is provided to the broker. |
| <connexion_timeout> | Integer type Connexion to the broker timeout in seconds. |
| <protocol_timeout> | Integer type Transmission timeout, in seconds, of MQTT protocol messages. |
| <publish_retry> | Integer type Number of time a publish message is sent to the broker in case of transmission issue. |
| <keep_alive_pub_msg> | Integer type If no data flow over the open TCP is observed after the keep alive period (in seconds), the stack will generate a ping request and expect reception of a ping response from the broker. |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | SAVED in NVM after AT#RESET=1 Takes effect immediately. |
| Reference | Custom MQTT Version 3.1.1 Plus Errata 01 |

11.2 AT#MQTTCONNECT – connect to a MQTT server

| AT#MQTTCONNECT – connect to a MQTT server | |
|---|--|
| Test Command | AT#MQTTCONNECT=? |
| Response | #MQTTCONNECT: <context_id>,<socket_id>,<broker_address>,<broker_port>[,<username>,<passwd>]] OK |
| Read Command | AT#MQTTCONNECT? |
| Response | If MQTT stack is connected to a Broker: #MQTTCONNECT: 1,<context id>,<socket id>,<broker address>,<broker port>,<username> OK Or If MQTT stack is NOT connected to a Broker: #MQTTCONNECT: 0 OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Set Command | AT#MQTTCONNECT=<context_id>,<socket_id>,<broker_address>,<broker_port>[,<username>,<passwd>]] |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <context_id>,<socket_id>,<broker_address>,<broker_port>,<username>,<passwd> |
| <context_id> | Integer type ID of an established TCP context |
| <socket_id> | Integer type Socket number created on this context with the AT#SOCKETCREATE command. |
| <broker_address> | UTF-8 encoded string IPv4 or IPv6 address of the remote Broker. |
| <broker_port> | Integer type Port number of the remote Broker. |
| <username> | UTF-8 encoded string User name can be used by the Server for authentication and authorization. Maximum length is 25. |
| <passwd> | UTF-8 encoded string. Password associated to the indicated username. Its maximum length is 50. |
| <err> | See Error List |
| Max Response Time | 20 sec |
| Parameter Saving Mode | NA |
| Reference | Custom MQTT Version 3.1.1 Plus Errata 01 |

11.3 AT#MQTTDISC – Disconnect from a MQTT server

This command requests a disconnection from the MQTT server (broker).

| AT#MQTTDISC – Disconnect from a MQTT server | |
|---|---|
| Test Command | AT#MQTTDISC=? |
| Response | #MQTTDISC: OK |
| Execution Command | AT#MQTTDISC |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | |
| <err> | See Error List |
| Max Response Time | 20 sec |
| Parameter Saving Mode | NA |
| Reference | Custom MQTT Version 3.1.1 Plus Errata 01 |

11.4 AT#MQTTPUB – Publish a message for the specified topic

The Publish command sends from a client to a server or from server to a client an application message for a given topic.

| AT#MQTTPUB – Publish a message for the specified topic | |
|--|--|
| Test Command | AT#MQTTPUB=? |
| Response | #MQTTPUB: <topic>,<message>[,<retry_number>][,<qos>] OK |
| Set Command | AT#MQTTPUB=<topic>,<message>[,<retry_number>][,<qos>] |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <topic>,<message>,<retry_number>,<qos> |
| <topic> | UTF-8 encoded string Is the topic name. It shall not include any wildcard characters. Maximum length is 50. |
| <message> | UTF-8 encoded string Is the payload containing the application message that is being published. The content and format of the data is application specific. Maximum length is 50. |
| <retry_number> | Integer type Number of allowed retries for the message sending. Maximum number is 20. |
| <qos> | Integer type QoS value used when publishing topic: 0: at most once 1: at least once 2: exactly once |
| <err> | See Error List |
| Max Response Time | 20 sec |
| Parameter Saving Mode | NA |
| Reference | Custom MQTT Version 3.1.1 Plus Errata 01 |

11.5 AT#MQTTSUB – Subscribe to specified topic

The Subscribe command is sent from the Client to the Server to create one or more Subscriptions. Each Subscription registers a Client's interest in one or more topics. When subscribing to a topic, when a change occurs for this topic, the result is sent to the caller.

| AT#MQTTSUB – Subscribe to specified topic | |
|---|--|
| Test Command | AT#MQTTSUB=? |
| Response | #MQTTSUB: <topic1>,<qos1>[,<topic2>,<qos2>,...] OK |
| Read Command | AT#MQTTSUB? |
| Response | #MQTTSUB: <topic1>,<qos1> <topic2>,<qos2> ... OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Set Command | AT#MQTTSUB=<topic1>,<qos1>[,<topic2>,<qos2>[,...]] |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <topic1>,<qos1>,<topic2>,<qos2>,...<topicN>,<qosN> |
| <topic1>,<topic2>,...,<topicN> | UTF-8 encoded string. Topic Filter: indicates an interest in one or more topics. A topic filter can include wildcard characters. Maximum length for each topic is 50 characters (without considering AT command's maximum allowed char) |
| <qos1>,<qos2>,...,<qosN> | Integer type Maximum QoS level (0, 1 or 2) for corresponding topic at which the Server can send application messages to the client. QoS 0: the message is delivered according to the capabilities of the underlying network. No response is sent by the receiver and no retry is performed by the sender. The message arrives at the receiver either once or not at all. QoS 1: This quality of service ensures that the message arrives at the receiver at least once. QoS 2: This is the highest quality of service, for use when neither loss nor duplication of messages are acceptable. There is an increased overhead associated with this quality of service. |
| <err> | See Error List |
| Max Response Time | 10 sec |
| Parameter Saving Mode | NA |
| Reference | Custom MQTT Version 3.1.1 Plus Errata 01 |

11.6 AT#MQTTUNSUB – UnSubscribe from the specified topic

This command is sent by the Client to the Server to unsubscribe from topics.

| AT#MQTTUNSUB – UnSubscribe from the specified topic | |
|---|--|
| Test Command | AT#MQTTUNSUB=? |
| Response | #MQTTUNSUB: <topic1>[,<topic2>,....] OK |
| Set Command | #MQTTUNSUB=<topic1>[,<topic2>[,....]] |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | < topic1>,<topic2>,....,< topicN> |
| <topic1>, <topic2>,...., <topicN> | UTF-8 encoded string Topic Filter: indicates an interest in one or more topics. A topic filter can include wildcard characters. |
| <err> | See Error List |
| Max Response Time | 10 sec |
| Parameter Saving Mode | NA |
| Reference | Custom MQTT Version 3.1.1 Plus Errata 01 |

12 CoAP commands

12.1 AT#COAPCFG – Configure the CoAP service

This command configures the CoAP service and shall be used after AT#COAPSTART command execution.

| AT#COAPCFG – Configure the CoAP service | |
|---|--|
| Test Command | AT#COAPCFG=? |
| Response | #COAPCFG:<context_id>,<socket_id>,<server_address>,<server_port> OK |
| Read Command | AT#COAPCFG? |
| Response | #COAPCFG:<context_id>,<socket_id>,<server_address>,<server_port> OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Set Command | AT#COAPCFG=<context_id>,<socket_id>,<server_address>,<server_port> |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <context_id>,<socket_id>,<server_address>,<server_port> |
| <context_id> | Integer type Context number established on modem side. |
| <socket_id> | Integer type Socket number created on this context with the AT#SOCKETCREATE command. |
| <server_address> | String type Address of the CoAP server (IPv4 or [IPv6]) - IPv6 shall be enclosed in '[' and ']' characters. |
| <server_port> | Integer type Port number of the CoAP server. |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | Custom |

12.2 AT#COAPCMD – Send a CoAP command to the CoAP server

This command is used to send a CoAP request to a CoAP server. The response is indicated with the URC #COAPCMD

| AT#COAPCMD – Send a CoAP request to the CoAP server | |
|---|---|
| Test Command | AT#COAPCMD=? |
| Response | #COAPCMD: <message_type>,<method>,<path>[,<payload>] OK |
| Set Command | AT#COAPCMD=<message_type>,<method>,<path>,<payload> |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR: <err> |
| Parameters | <message_type>,<method>,<path>,<payload> |
| <message_type> | Integer type CoAP Message Type 0: Confirmable 1: Non-confirmable 2: Acknowledgement 3: Reset |
| <method> | Integer type CoAP Method Type 1: GET 2: POST 3: PUT 4: DELETE |
| <path> | String Type URI path (ends with “?” for a query). Maximum length is 50 characters. UTF-8 encoded string |
| <payload> | String Type Data payload in string format. Maximum length is 128 characters. UTF-8 encoded string |
| <err> | See Error List |
| Max Response Time | 10 sec |
| Parameter Saving Mode | NA |
| Reference | Custom |

12.3 AT#COAPCONNECT – Connect to CoAP server

| AT#COAPCONNECT – Connect to CoAP server | |
|---|--|
| Test Command | AT#COAPCONNECT=? |
| Response | #COAPCONNECT OK |
| Read Command | AT#COAPCONNECT? |
| Response | #COAPCONNECT: <status> OK |
| If there is any error | ERROR Or +CME ERROR: <err> |
| Execution Command | AT#COAPCONNECT |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <status> |
| <status> | 0: CoAP service is not started 1: CoAP service is started 2: CoAP service is configured 3: CoAP client is connected |
| <err> | See Error List |
| Max Response Time | 10 sec |
| Parameter Saving Mode | NA |
| Reference | Custom |

12.4 AT#COAPDISCONNECT – Disconnect from a CoAP server

| AT#COAPDISCONNECT – Disconnect from a CoAP server | |
|---|---------------------------------|
| Test Command | AT#COAPDISCONNECT=? |
| Response | #COAPDISCONNECT OK |
| Execution Command | AT#COAPDISCONNECT |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | |
| <err> | See Error List |
| Max Response Time | 10 sec |
| Parameter Saving Mode | NA |
| Reference | Custom |

Note:

This command changes CoAP service state to 1 (CoAP Service is started), thus the service has to be reconfigured with AT#LWCFG command.

12.5 AT#COAPSTART – Start CoAP service

| AT#COAPSTART – Start CoAP service | |
|-----------------------------------|--|
| Test Command | AT#COAPSTART=? |
| Response | #COAPSTART OK |
| Read Command | AT#COAPSTART? |
| Response | #COAPSTART: <status> OK |
| Execution Command | AT#COAPSTART |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR: <err> |
| Parameters | <status> |
| <status> | Integer type 0: CoAP service is not started 1: CoAP service is started 2: CoAP service is configured 3: CoAP client is connected |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | Custom |

12.6 AT#COAPSTOP – Stop the COAP service

| AT#COAPSTOP – Stop the CoAP service | |
|-------------------------------------|----------------------------------|
| Test Command | AT#COAPSTOP=? |
| Response | #COAPSTOP OK |
| Execution Command | AT#COAPSTOP |
| Response | OK |
| If there is any error | Error Or +CME ERROR: <err> |
| Parameters | |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | Custom |

Note:

This command closes the socket assigned by CoAP service

13 LwM2M commands

13.1 AT#LWADDOBJ – Add a LwM2M object

| AT# LWADDOBJ – Add a LwM2M object | |
|-----------------------------------|--|
| Test Command | AT#LWADDOBJ=? |
| Response | #LWADDOBJ:<object_id>,<instance_id>,<resource_count>,<resource_id> [,<resource_id>[,<resource_id>[,...]]] OK |
| Set Command | AT#LWADDOBJ=<object_id>,<instance_id>,<resource_count>,<resource_id> [,<resource_id>[,<resource_id>[,...]]] |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <object_id>,<instance_id>,<resource_count>,<resource_id> |
| <object_id> | Integer type ID of the object to be added |
| <instance_id> | Integer type ID of the instance to be added |
| <resource_count> | Integer type Number of resources to create |
| <resource_id> | Integer type Resource ID to create |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | Custom |

13.2 AT#LWCFG – LwM2M configuration

This command is used to set the LwM2M configuration both for client and server. LwM2M service must be start first with AT#LWSTART.

| AT#LWCFG – LwM2M configuration | |
|--------------------------------|--|
| Test Command | AT#LWCFG=? |
| Response | #LWCFG: <context_id>,<socket_id>,<client_name>,<server_address>,<server_port>,<server_id>,<server_type>,<binding_mode>,<lifetime>[,<storing>] OK |
| Read Command | AT#LWCFG? |
| Response | #LWCFG: <context_id>,<socket_id>,<client_name>,<server_address>,<server_port>,<server_id>,<server_type>,<binding_mode>,<lifetime>,<storing> OK |
| Set Command | AT#LWCFG=<context_id>,<socket_id>,<client_name>,<server_address>,<server_port>,<server_id>,<server_type>,<binding_mode>,<lifetime>[,<storing>] OK |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR: <err> |
| Parameters | <context_id>,<socket_id>,<client_name>,<server_address>,<server_port>,<server_id>,<server_type>,<binding_mode>,<lifetime>,<storing> |
| <context_id> | Integer type Context number established on modem side. |
| <socket_id> | Integer type Socket number created on this context with the AT#SOCKETCREATE command. |
| <client_name> | String type LwM2M client name |
| <server_address> | String type IPv4 or IPv6 address of the LwM2M server |
| <server_port> | Integer type LwM2M server port number |
| <server_id> | Integer type LwM2M server id |
| <server_type> | Integer type 0: Bootstrap 1: Normal |
| <binding_mode> | String type U: UDP T: TCP S: SMS N: NonIP |
| <lifetime> | Integer type Lifetime in seconds |
| <storing> | Integer type Notify storing option 0: deactivated (default) 1: activated (not supported) |

| | |
|-----------------------|----------------|
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | Custom |

13.3 AT#LWCHGRSCVAL– Change a LwM2M resource value

| AT# LWCHGRSCVAL – Change a LwM2M resource value | |
|---|--|
| Test Command | AT#LWCHGRSCVAL=? |
| Response | #LWCHGRSCVAL: <uri>,<data> OK |
| Set Command | AT#LWCHGRSCVAL=<uri>,<data> |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR: <err> |
| Parameter | <uri>,<data> |
| <uri> | String type. uri of the LwM2M resource to change such as /3/0/2 |
| <data> | String type. LwM2M resource data to change. |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | Custom |

13.4 AT#LWDUMPOBJ – Dump the content of a LwM2M object

This command is used to dump the content of a specific instance of a LwM2M client.

| AT#LWDUMPOBJ – Dump LwM2M object | |
|----------------------------------|---|
| Test Command | AT#LWDUMPOBJ=? |
| Response | #LWDUMPOBJ:<uri> OK |
| Set Command | AT#LWDUMPOBJ=<uri> |
| Response | #LWDUMPOBJ: <uri>[,<data_type>][,<data>] OK |
| If there is any error | ERROR Or +CME ERROR: <err> |
| Parameter | <uri>,<data_type>,<data> |
| <uri> | String type. URI of the LwM2M instance |
| <data_type> | Integer type. LwM2M resource data type 0: Undefined 1: Object 2: Object instance 3: Multiple resource 4: String 5: Opaque 6: Integer 7: Unsigned integer 8: Float 9: Boolean 10: Object link 11: Core link |
| <data> | String type. LwM2M resource data |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | Custom |

13.5 AT#LWLISTOBJ – List LwM2M objects

This command is used to list the LwM2M objects.

| AT# LWLISTOBJ – List the LwM2M objects | |
|--|--|
| Test Command | AT#LWLISTOBJ=? |
| Response | #LWLISTOBJ OK |
| Execution Command | AT#LWLISTOBJ |
| Response | #LWLISTOBJ: <uri> OK |
| If there is any error | ERROR Or +CME ERROR: <err> |
| Parameter | <uri> |
| <uri> | String type URI of the LwM2M instance |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | Custom |

13.6 AT#LWLISTSERV – List LwM2M servers

| AT#LWLISTSERV – List LwM2M servers | |
|------------------------------------|--|
| Test Command | AT#LWLISTSERV=? |
| Response | #LWLISTSERV OK |
| Execution Command | AT#LWLISTSERV |
| Response | #LWLISTSERV: <server_type>,<registration_status>,<server_id>[,<location>][,<lifetime>] OK |
| If there is any error | ERROR Or +CME ERROR: <err> |
| Parameter | <server_type>,<registration_status>,<server_id>,<location>,<lifetime> |
| <server_type> | Integer type 0: bootstrap 1: normal |
| <registration_status> | Integer type 0: Deregistered 1: Registration hold off 2: Registration pending 3: Registered 4: Registration failed 6: Registration update pending 7: Registration update needed 8: Deregistration pending 9: Bootstrap hold off 10: Bootstrap initiated 11: Bootstrap pending 12: Bootstrap finishing 13: Bootstrap finished 14: Bootstrap failing 15: Bootstrap failed |
| <server_id> | Integer type LwM2M Server Id |
| <location> | String type Registration Location in LwM2M Server |
| <lifetime> | Integer type. Lifetime in seconds |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | Custom |

13.7 AT#LWREADRSCVAL – HOST reads LwM2M resource value

This command is used when the HOST wants to read the value of a LwM2M resource.

| AT#LWREADRSCVAL – Read LwM2M resource value | |
|---|--|
| Test Command | AT#LWREADRSCVAL=? |
| Response | #LWREADRSCVAL:<uri> OK |
| Set Command | AT#LWREADRSCVAL=<uri> |
| Response | #LWREADRSCVAL:<data> OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameter | <uri>,<data> |
| <uri> | String type URI of the LwM2M instance |
| <data> | String type Resource data value |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | Custom |

13.8 AT#LWNTYTO – LwM2M Custom object response time out for Service Notification

This command is used to configure LwM2M Custom Object's Notify-response timeout.

| AT# LWNTYTO – LwM2M Custom Object Notify-Response Timeout | |
|---|---|
| Test Command | AT#LWNTYTO=? |
| Response | #LWNTYTO: <timeout> OK |
| Read Command | AT#LWNTYTO? |
| Response | #LWNTYTO: <timeout> OK |
| If there is any error | ERROR Or +CME ERROR: <err> |
| Set Command | AT#LWNTYTO=<timeout> |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameter | <timeout> |
| <timeout> | Integer type Timeout value in milliseconds |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | Custom |

13.9 AT#LWNTYEXEOBJ – LwM2M Custom object response for Execution Notification

| AT# LWNTYEXEOBJ – LwM2M Custom object response for Execution Notification | |
|---|--|
| Test Command | AT#LWNTYEXEOBJ=? |
| Response | #LWNTYEXEOBJ: <server_id>,<object_id>,<instance_id>,<resource_count>,<resource_id>[,<resource_id>[,<resource_id>[,...]]] OK |
| Set Command | AT#LWNTYEXEOBJ=<server_id>,<object_id>,<instance_id>,<resource_count>,<resource_id>[,<resource_id>[,<resource_id>[,...]]] |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR: <err> |
| Parameter | <server_id>,<object_id>,<instance_id>,<resource_count>,<resource_id> |
| <server_id> | Integer type. ID of the LwM2M Server |
| <object_id> | Integer type ID of the object to be added |
| <instance_id> | Integer type ID of the instance to be added |
| <resource_count> | Integer type Number of Resources to create |
| <resource_id> | Integer type Resource ID to create |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | Custom |

13.10 AT#LWNTYRDOBJ – LwM2M Custom object response for Read Notification

This command is used to respond to LwM2M Custom object's Read Notification.

| AT#LWNTYRDOBJ – LwM2M Custom object response for Read Notification | |
|--|---|
| Test Command | AT#LWNTYRDOBJ=? |
| Response | #LWNTYRDOBJ:<server_id>,<object_id>,<instance_id>,<resource_count>,<resource_id>,<resource_type>,<resource_length>,<resource_value>[,<resource_id>,<resource_type>,<resource_length>,<resource_value>[,<resource_id>,<resource_type>,<resource_length>,<resource_value>[,...]]] OK |
| Set Command | AT#LWNTYRDOBJ=<server_id>,<object_id>,<instance_id>,<resource_count>,<resource_id>,<resource_type>,<resource_length>,<resource_value>[,<resource_id>,<resource_type>,<resource_length>,<resource_value>[,<resource_id>,<resource_type>,<resource_length>,<resource_value>[,...]]] |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameter | <server_id>,<object_id>,<instance_id>,<resource_count>,<resource_id>,<resource_type>,<resource_length>,<resource_value> |
| <server_id> | Integer type ID of the LwM2M Server |
| <object_id> | Integer type ID of the object to be added |
| <instance_id> | Integer type ID of the instance to be added |
| <resource_count> | Integer type Number of resources to create |
| <resource_id> | Integer type Resource ID to create |
| <resource_type> | String Type S: Data type String D: Data type Opaque I: Data type Signed Integer U: Data type Unsigned Integer F: Data type Float B: Data type Boolean L: Data type Object Link C: Data type Core Link |
| <resource_length> | Integer type Number of bytes of resource data |
| <resource_value> | String type Resource data value |
| <err> | See Error List |
| Max Response Time | 1 sec |

| | |
|-----------------------|--------|
| Parameter Saving Mode | NA |
| Reference | Custom |

13.11 AT#LWNTYWROBJ – LwM2M Custom object response for Write Notification

This command is used to response to LwM2M custom object's write notification.

| AT# LWNTYWROBJ – LwM2M Custom Object Execution Notification response | |
|--|---|
| Test Command | AT#LWNTYWROBJ=? |
| Response | #LWNTYWROBJ: <server_id>,<object_id>,<instance_id>,<resource_count>,<resource_id>[,<resource_id>[,<resource_id>[,...]]] OK |
| Set Command | AT#LWNTYWROBJ=<server_id>,<object_id>,<instance_id>,<resource_count>,<resource_id>[,<resource_id>[,<resource_id>[,...]]] |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR: <err> |
| Parameter | <server_id>,<object_id>,<instance_id>,<resource_count>,<resource_id> |
| <server_id> | Integer type ID of the LwM2M Server |
| <object_id> | Integer type ID of the object to be added |
| <instance_id> | Integer type ID of the instance to be added |
| <resource_count> | Integer type Number of Resources to create |
| <resource_id> | Integer type Resource ID to create |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | Custom |

13.12 AT#LWREG – Register to LwM2M server

| AT#LWREG – Register to LwM2M server | |
|-------------------------------------|--|
| Test Command | AT#LWREG=? |
| Response | #LWREG: <server_id>,<opt> OK |
| Set Command | AT#LWREG=<server_id>,<opt> |
| Response | If <opt> is 3 (retrieve registration status) #LWREG: <reg_status> OK Else OK |
| If there is any error | ERROR Or +CME ERROR: <err> |
| Parameter | <server_id>,<opt>,<reg_status> |
| <server_id> | Integer type LwM2M server id to register. Currently, only <server_id>=0 is supported. |
| <opt> | Integer type LwM2M Server registration options 0: Deregister 1: Register 2: Update registration 3: Retrieve registration status |
| <reg_status> | Integer type LwM2M registration status 2: registration pending 3: registered 4: registration failed |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | Custom |

13.13 AT#LWRMOBJ – Remove a LwM2M object

| AT# LWRMOBJ – Remove a LwM2M object | |
|-------------------------------------|---|
| Test Command | AT#LWRMOBJ=? |
| Response | #LWRMOBJ:<object_id> OK |
| Set Command | AT#LWRMOBJ=<object_id> |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameter | <object_id> |
| <object_id> | Integer type ID of the object to be removed. |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | Custom |

13.14 AT#LWSTART – Start LwM2M client service

This command is used to start the LwM2M client service.

| AT#LWSTART – LwM2M client start command | |
|---|--|
| Test Command | AT#LWSTART=? |
| Response | #LWSTART OK |
| Read Command | AT#LWSTART? |
| Response | #LWSTART: <state> OK |
| If there is any error | ERROR Or +CME ERROR: <err> |
| Execution Command | AT#LWSTART |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR: <err> |
| Parameter | <state> |
| <status> | Integer type LwM2M Service State 0: LwM2M Stack not started 1: LwM2M Stack started 2: LwM2M Stack configured 3: LwM2M Stack activated |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | Custom |

13.15 AT#LWSTOP – Stop the LwM2M client

| AT#LWSTOP – Stop the LwM2M client | |
|-----------------------------------|----------------------------------|
| Test Command | AT#LWSTOP=? |
| Response | #LWSTOP OK |
| Execution Command | AT#LWSTOP |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR: <err> |
| Parameter | |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | Custom |

14 TLS commands

14.1 AT#TSLCERTADD - Add X.509 DER certificate or PSK identity

AT#TSLCERTADD command is used to store an X.509 certificate or a PSK identity to a security profile. It is also used to read a stored certificate or PSK identity.

| AT#TSLCERTADD – Add X.509 DER certificate or PSK identity | |
|---|--|
| Test Command | AT#TSLCERTADD? |
| Response | #TSLCERTADD=<sec_id>,<type>,<data_len> OK |
| Set Command | AT#TSLCERTADD=<sec_id>,<type>,<data_len> |
| Response | If <data_len>=0: <Certificate content in DER format> or <PSK identity> OK Else: OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <sec_id>,<type>,<data_len> |
| <sec_id> | Integer type Security profile ID linked to certificate/PSK identity |
| <type> | Integer type 0: device cert 1: CA root cert 2: PSK identity |
| <data_len> | Integer type Length of following data. If 0, PSK identity/certificate content is returned. |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | SAVED to NVM using AT#RESET=1 Takes effect immediately |
| Reference | Custom |

Note:

This command is the starting point of the data transaction. After this, the data are sent in a binary flow. The certificate MUST be in DER format.

14.2 AT#TSLCERTDEL - Remove certificate in a security profile

AT#TSLCERTDEL command is used to remove stored certificate/PSK identity.

| AT#TSLCERTDEL – Remove certificate/PSK identity from secure storage | |
|---|--|
| Test Command | AT#TSLCERTDEL? |
| Response | #TSLCERTDEL=<sec_id>[,<type>] OK |
| Set Command | AT#TSLCERTDEL=<sec_id>[,<type>] |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <sec_id>,<type> |
| <sec_id> | Integer type Security profile ID |
| <type> | Integer type 0: device cert 1: CA root cert 2: PSK identity If not specified, all the certificates for the specified security ID will be erased. |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | SAVED to NVM using AT#RESET=1 Takes effect after reboot |
| Reference | Custom |

14.3 AT#TSLSCERTLIST - List stored certificates/PSK identities

| AT#TSLSCERTLIST – List stored X.509 certificates/PSK identities | |
|---|---|
| Test Command | AT#TSLSCERTLIST? |
| Response | #TSLSCERTLIST[: <sec_id>] OK |
| Set Command | AT#TSLSCERTLIST[=<sec_id>] |
| Response | SP <sec_id> CA Certificate size <size> bytes, expiry: <date> Device Certificate, size <size>bytes, expiry: <date> Or PSK ID, string size <size> OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <sec_id>,<size>,<date> |
| <sec_id> | Integer type Security profile ID If not specified, all the stored certificates will be listed. |
| <size> | Integer type Size of the certificate or of the PSK ID |
| <date> | String type Format is yymmdd |
| <err> | See Error List |
| Max Response Time | 5 sec |
| Parameter Saving Mode | NA |
| Reference | Custom |

Note:

Expiry date is shown as stored in X.509 certificate as yymmdd

14.4 AT#TSLCERSIGN - Sign a Certificate Signing Request form (CSR)

AT#TSLCERSIGN command is used to sign a CSR in DER format with a stored private key.

| AT#TSLCERSIGN – Sign a Certificate Signing Request form (CSR) | |
|---|---|
| Test Command | AT#TSLCERSIGN? |
| Response | #TSLCERSIGN=<sec_id>,<csr_len> OK |
| Set Command | AT#TSLCERSIGN=<sec_id>,<csr_len> |
| Response | <Signed CSR in DER format> OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <sec_id>,<csr_len> |
| <sec_id> | Integer type Security profile ID of the private key to use for signature |
| <csr_len> | Integer type Size of certificate in bytes Maximum value allowed: 1024 |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | Custom |

Note:

This command is the starting point of the data transaction. After this, the data are sent in a binary flow. The CSR MUST be in DER format, including the signature.

14.5 AT#TLSKEYADD – Store a secret key and bind it to a security profile

AT#TLSKEYADD command is used to store a secret key.

| AT#TLSKEYADD – Store a secret key and bind it to a security profile | |
|---|--|
| Test Command | AT#TLSKEYADD? |
| Response | #TLSKEYADD:<sec_id>,<type>,<storage>,<size>,<data_flag> OK |
| Set Command | AT#TLSKEYADD=<sec_id>,<type>,<storage>,<size>,<data_flag> |
| Response | If <data_flag> bit1 = 1: <public key bytes> OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <sec_id>,<type>,<storage>,<size>,<data_flag> |
| <sec_id> | Integer type Security profile ID linked to key |
| <type> | Integer type Bitmap value: Bit0: 0: asymmetric, 1: symmetric Bit1: 0: private, 1: public Bit2: 0: ECC curve NIST P, 1: ECC curve Brainpoolr1 |
| <storage> | Integer type Secure storage partition: 1: OTP 2: Flash 3: Retention RAM 4: RAM |
| <size> | Integer type Size in bytes of the key (32 or 48) |
| <data_flag> | Integer type Bitmap value: Bit0: 0: key content follows, 1: key content is created Bit1: 0: no content returned, 1: return public key Bit2: 0: DER format, 1: raw binary Bit3: 0: key data in clear |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | SAVED to NVM using AT#RESET=1 Takes effect immediately |
| Reference | Custom |

Note:

If <data_flag> bit0 = 0, this command is the starting point of the data transaction. After this, the data are sent in a binary flow.

If storage partition is OTP, factory provisioned key in OTP is taken.

14.6 AT#TLSKEYDEL - Remove the secret key in a security profile

| AT#TLSKEYDEL – Remove a secret key in a security profile | |
|--|--|
| Test Command | AT#TLSKEYDEL? |
| Response | #TLSKEYDEL: <sec_id> OK |
| Set Command | AT#TLSKEYDEL=<sec_id> |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <sec_id> |
| <sec_id> | Integer type Security profile ID |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | SAVED to NVM using AT#RESET=1 Takes effect after reboot |
| Reference | Custom |

14.7 AT#TLSKEYLIST - List stored keys

| AT#TLSKEYLIST – List stored keys | |
|----------------------------------|--|
| Test Command | AT#TLSKEYLIST? |
| Response | #TLSKEYLIST[=<sec_id>] OK |
| Set Command | AT#TLSKEYLIST[=<sec_id>] |
| Response | SP <sec_id>: key type: private ECC SECP_R1 size: <i>nn</i> bits Or key type: PSK size: <i>nn</i> bits OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <sec_id> |
| <sec_id> | Integer type Security profile ID |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | Custom |

15 GNSS commands

15.1 AT#GNSSINIT – GNSS Init

This command is used to Initialize GNSS service and get its status.
User shall wait for #GNSSINIT URC before sending other GNSS AT commands (except AT#GNSSDEINIT).

| AT#GNSSINIT – GNSS Init | |
|-------------------------|---|
| Test Command | AT#GNSSINIT=? |
| Response | #GNSSINIT: <assistance_gnss>,<constellation_id>[,<context_id>,<supl_server_ip>,<supl_server_port>[,<supl_session_timeout>[,<security_profile_id>]]] OK |
| Read Command | AT#GNSSINIT? |
| Response | #GNSSINIT:[<status>] OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Set Command | AT#GNSSINIT=<assistance_gnss>,<constellation_id> [,<context_id>,<supl_server_ip>,<supl_server_port> [,<supl_session_timeout>[,<security_profile_id>]]] |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <status>,<assistance_gnss>,<constellation_id>,<context_id>,<supl_server_ip>,<supl_server_port>,<supl_session_timeout>,<security_profile_id> |
| <status> | Integer type 0: GNSS service not started 1: GNSS service startup: service startup ongoing 2: GNSS service ready: service ready to accept request 3: GNSS download from SUPL: assistance data download ongoing 4: GNSS download fail: error during assistance data download. Retry downloading or perform a cold start. 5: GNSS system failure: severe fault during startup. Service may not be available. |
| <assistance_gnss> | Integer type 0: Assistance data download disabled (cold start) 1: Auto: use assistance data only if already available and still valid, but do not download it from SUPL server. 2: Assistance data download enabled --> use assistance data already available if valid. Otherwise, force download (hot start). |
| <constellation_id> | Integer type 0: GPS 1: GALLILEO 2: GPS+GALLILEO |

| | |
|------------------------|---|
| <context_id> | Integer type Context number established on modem side. The IP stack has been configured for this context with the AT#IPCFG command. |
| <supl_server_ip> | String type IPv4 or IPV6 GNSS Supplier Server address IPv4 Example: 74.125.140.192 (note this is a Google public SUPL server that could be used) IPv6 Example: cafe:baba::01 |
| <supl_server_port> | Integer type GNSS Supplier Server Port Example: 7276 |
| <supl_session_timeout> | Integer type [seconds] – Optional parameter SUPL server connection and session timeout (default 30 seconds) |
| <security_profile_id> | Integer type – Optional parameter If specified and if the security profile exist, a TLS link will be used for the socket. |
| Max Response Time | 10 sec |
| Parameter Saving Mode | NA |
| Reference | Custom |

15.2 AT#GNSSDEINIT – GNSS service un-initialize and stop

| AT#GNSSDEINIT – GNSS service un-initialize and stop | |
|---|---------------------------------|
| Test Command | AT#GNSSDEINIT=? |
| Response | #GNSSDEINIT: OK |
| Set Command | AT#GNSSDEINIT |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | |
| <err> | See Error List |
| Max Response Time | 10 sec |
| Parameter Saving Mode | NA |
| Reference | Custom |

15.3 AT#GNSSFIX – GNSS Start or Stop Fix

This command can only be used when GNSS service is in ready state.

| AT#GNSSFIX – GNSS Fix | |
|-----------------------|---|
| Test Command | AT#GNSSFIX=? |
| Response | #GNSSFIX: <start_stop>,<event_enable>,<format_type>,<format_argument>[,<period>] OK |
| Read Command | AT#GNSSFIX? |
| Response | <p>If <format_type>==AT: #GNSSFIX=<week_number>,<time_of_week>,<latitude>,<longitude>,<altitude>,<accuracy>[,<std_dev_latitude>,<std_dev_longitude>,<std_dev_altitude>,<hdop>,<gdop>,<pdop>][,<number_of_satellites>,<satellite1_id>,<satellite1_residual>,...,<satelliten_id>,<satelliten_residual>][,<orientation_degree>,<semi_major>,<semi_minor>] OK</p> <p>If <format_type>==NMEA: Refer to NMEA standard for the following subsets: \$GPGGA \$GPGSA \$GPGSV \$GPGLL \$GPRMC \$GPVTG OK</p> |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Set command | AT#GNSSFIX=<start_stop>,<event_enable>,<format_type>,<format_argument>[,<period>] |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <start_stop>,<event_enable>,<format_type>,<format_argument>,<period>,<week_number>,<time_of_week>,<latitude>,<longitude>,<altitude>,<accuracy>,<std_dev_latitude>,<std_dev_longitude>,<std_dev_altitude>,<hdop>,<gdop>,<pdop>,<number_of_satellites>,<satellite_id>,<satellite_residual>,<orientation_degree>,<semi_major>,<semi_minor> |
| <start_stop> | Integer type 0: Stop fix position 1: Start fix position |
| <event_enable> | Integer type 0: GNSS fix event disabled 1: GNSS fix event enabled: an event will be sent to the HOST every time there is a new fix available |
| <format_type> | Integer type Answer format selection 0: AT 1: NMEA |

| | |
|------------------------|--|
| <format_argument> | <p>if <format_type> == AT: 1000: position data 0100: accuracy data 0010: satellites (used for computing position) info 0001: orientation info</p> <p>if <format_type> == NMEA: 100000: \$GPGGA 010000: \$GPGSA 001000: \$GPGSV 000100: \$GPGLL 000010: \$GPRMC 000001: \$GPVTG</p> |
| <period> | Integer type GNSS activation period in second: delay between Position Sample acquisition and next GNSS activation |
| <week_number> | Number of weeks since 5-6 January 1980 |
| <time_of_week> | Elapsed number of milliseconds within the week |
| <latitude> | Latitude in degrees (positive for North, negative for South) |
| <longitude> | Longitude in degrees (positive for East, negative for West) |
| <altitude> | Altitude in meters |
| <accuracy> | The accuracy of the position in meters |
| <std_dev_latitude> | The standard deviation of latitude error in degrees |
| <std_dev_longitude> | The standard deviation of longitude error in degrees |
| <std_dev_altitude> | The standard deviation of altitude error in meters |
| <hdop> | Horizontal dilution of precision |
| <gdop> | Geometric dilution of precision |
| <pdop> | Position (3D) dilution of precision |
| <number_of_satellites> | The number of SVs used to calculate the location |
| <satellite_id> | ID of SV |
| <satellite_residual> | Range residuals in meters of SV |
| <orientation_degree> | The orientation of the semi-major axis in degrees |
| <semi_major> | The standard deviation of semi major axis in meters |
| <semi_minor> | The standard deviation of semi minor axis in meters |
| <err> | See Error List |
| Max Response Time | 10 sec |
| Parameter Saving Mode | NA |
| Reference | Custom |

15.4 AT#GNSSSV – GNSS Space Vehicles URC configuration

This command is used to enable/disable #GNSSSV URC that reports the status of Space Vehicles currently in view.

| AT#GNSSSV – GNSS Space Vehicles URC configuration | |
|---|---|
| Test Command | AT#GNSSSV=? |
| Response | #GNSSSV: <urc_mode> OK |
| Read Command | AT#GNSSSV? |
| Response | #GNSSSV: <urc_mode> OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Set Command | AT#GNSSSV=<urc_mode> |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <urc_mode> |
| <urc_mode> | Integer type 0: URC disabled 1: URC enabled with basic format: #GNSSSV: <tot number of visible SVs>,<SV id>,<SV quality> 2: URC enabled with verbose format: #GNSSSV: <tot number of visible SVs>,<SV id>,<SV quality> <code phase measurement chip>,<doppler [Hz]>, <Carrier to noise ratio [dB]>,<Time of week at transmission [ms]> |
| <err> | See Error List |
| Max Response Time | 10 sec |
| Parameter Saving Mode | NA |
| Reference | Custom |

16 FOTA commands

16.1 AT#FOTACFG – Configure the FOTA services

| AT#FOTACFG – Configure the FOTA services | |
|--|---|
| Test Command | AT#FOTACFG=? |
| Response | #FOTACFG: [<method>],[<protocol>],[<urc>],[<security_profile_id>] OK |
| Read Command | AT#FOTACFG? |
| Response | #FOTACFG: <method>,<protocol>,<urc>,<security_profile_id> OK |
| If there is any error | ERROR Or +CME ERROR: <err> |
| Set Command | AT#FOTACFG=[<method>],[<protocol>],[<urc>],[<security_profile_id>] |
| Response | OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <method>,<protocol>,<urc>,<security_profile_id> |
| <method> | Integer type. Supported method in bitmap Bit0: PULL |
| <protocol> | Integer type Supported protocol in bitmap Bit0: CoAP |
| <urc> | Integer type FOTA Service URC Option 0: None 1: Normal 2: Verbose |
| <security_profile_id> | Integer type If specified and if the security profile exist, a TLS link will be used for the socket. |
| <err> | See Error List |
| Max Response Time | 1 s |
| Parameter Saving Mode | NA |
| Reference | Private |

16.2 AT#FOTADL – Download FOTA image

This command is used to manage the FOTA image download through the FOTA services.

| AT#FOTADL – Download FOTA image | |
|---------------------------------|--|
| Test Command | AT#FOTADL=? |
| Response | #FOTADL:<opt>,<url>[,<auto_update>] OK |
| Set Command | AT#FOTADL=<opt>,<url>[,<auto_update>] |
| Response | If <opt>==0 or <opt>==1: OK Else if <opt>==2: #FOTADL:<fota_state>,<fota_result>,<fota_error>,<auto_update> OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <opt>,<url>,<auto_update>,<fota_state>,<fota_result>,<fota_error> |
| <opt> | Integer type. Download service option: 0: Abort Download 1: Start Download 2: Retrieve Download status |
| <url> | String type URL of FW image file to download |
| <auto_update> | Integer type Automatic update enable. Once download is successful, update procedure is automatically launched. 0: Disabled 1: Enabled |
| <fota_state> | Integer Type 0: IDLE 1: DOWNLOAD ON GOING 2: DOWNLOAD DONE 3: DOWNLOAD FAILED 4: UPDATING DEFERRED 5: UPDATING ON GOING 6: UPDATE DONE 7: UPDATE FAILED |
| <fota_result> | Integer Type 0: INITIAL 1: SUCCESS UPDATE 2: FAIL FLASH 3: FAIL RAM 4: FAIL CONNECTION 5: FAIL INTEGRITY 6: FAIL PACKAGE TYPE 7: FAIL URI 8: CANCELLED 9: DEFERRED |

| | |
|-----------------------|---|
| <fota_error> | Integer type 0: NO ERROR 1: INVALID BOOT STATE 2: FAILED TO ERASE FLASH 3: FAILED TO PROGRAM FLASH 4: INVALID CRC FLASH 5: INVALID PKG URI 6: FAILED TO CREATE SESSION 7: FAILED TO GET MESSAGE 8: FAILED TO LAUNCH UPDATE 9: GENERAL ERROR |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | Private |

16.3 AT#FOTALNCHUP – Update FOTA image

Once a new FOTA image has been downloaded Over The Air, this command is used to manage the image update process.

| AT#FOTALNCHUP – Manage the image update process | |
|---|--|
| Test Command | AT#FOTALNCHUP=? |
| Response | #FOTALNCHUP: <opt>[,<defer>] OK |
| Set Command | AT#FOTALNCHUP=<opt> |
| Response | If <opt>==0 or <opt>==1 OK Else If <opt>==2 #FOTALNCHUP: <fota_state>,<fota_result>,<fota_error>,<time_to_update> OK |
| If there is any error | ERROR Or +CME ERROR:<err> |
| Parameters | <opt>,<defer>,<fota_state>,<fota_result>,<fota_error>,<time_to_update> |
| <defer> | Integer type Time to defer for launching update in seconds. |
| <opt> | Integer type Update service option: 0: Cancel Update 1: Launch Update 2: Retrieve Update status |
| <fota_state> | Integer Type 0: IDLE 1: DOWNLOAD ON GOING 2: DOWNLOAD DONE 3: DOWNLOAD FAILED 4: UPDATING DEFERRED 5: UPDATING ON GOING 6: UPDATE DONE 7: UPDATE FAILED |
| <fota_result> | Integer Type 0: INITIAL 1: SUCCESS UPDATE 2: FAIL FLASH 3: FAIL RAM 4: FAIL CONNECTION 5: FAIL INTEGRITY 6: FAIL PACKAGE TYPE 7: FAIL URI 8: CANCELLED 9: DEFERRED |
| <fota_error> | Integer type 0: NO ERROR 1: INVALID BOOT STATE 2: FAILED TO ERASE FLASH 3: FAILED TO PROGRAM FLASH 4: INVALID CRC FLASH 5: INVALID PKG URI |

| | |
|-----------------------|---|
| | 6: FAILED TO CREATE SESSION 7: FAILED TO GET MESSAGE 8: FAILED TO LAUNCH UPDATE 9: GENERAL ERROR |
| <time_to_update> | Integer type Remaining time to launch the image update in seconds. |
| <err> | See Error List |
| Max Response Time | 1 sec |
| Parameter Saving Mode | NA |
| Reference | Private |

17 Unsolicited Response Code (URC)

17.1 URC List

Additional to standard URC define by 3GPP, the ST87MXX module may send additional URC to the HOST.

| URC | Comment |
|--|---|
| #SIMST | To indicate SIM status |
| #URC : sleep | To indicate that the module is entering SLEEP mode |
| #URC : wakeup | To indicate that the module has just woken up |
| #GNSSFIX: <week_number>,<time_of_week>,<latitude>,<longitude>,<altitude>,<accuracy>[,<std_dev_latitude>,<std_dev_longitude>,<std_dev_altitude>,<hdop>,<gdop>,<pdop>][,<number_of_satellites>,<satellite1_id>,<satellite1_residual>,...,<satelliten_id>,<satelliten_residual>][,<orientation_degree>,<semi_major>,<semi_minor>] | To indicate a new fix position is available |
| #GNSS: 2 | GNSS Service ready |
| #GNSS: 4 | Failure during Assistance data download |
| #GNSS: 5 | Failure during GNSS Service startup |
| #IPCFG: <context_id>,<ip_mode>,<ip_status> | Indicates that a PDP context has been established and that an IP address has been assigned to the UE : <context_id>: the modem context ID <ip_mode>: 0 = IPv4; 1 = IPv6 <ip_status>: 0 = IP stack down; 1 = IP stack up To get the assigned IP address, AT command AT#IPCFG? shall be used (see §9.1) Rem: In case IPv4 and IPv6 address are assigned to the UE, two #IPCFG URC will be displayed. |
| #IPRECV:<context_id>,<socket_id> | Indicates that an UDP or TCP packet has been received. To read the received packet, the AT command AT#IPREAD shall be used (see §9.5) |
| #MQTTRECV: <topicName>,<Payload> | Display the payload received for a subscribed topic |
| #COAPCMD: <resp>,<message type>[,<payload length>,<block2 more>][<payload>] | COAP Request Result <resp> : CoAP Response code Response code. 0 : Response not received(Timeout) 65 : CREATED_2_01 66 : DELETED_2_02 67 : VALID_2_03 68 : CHANGED_2_04 69 : CONTENT_2_05 128 : BAD_REQUEST_4_00 129 : UNAUTHORIZED_4_01 130 : BAD_OPTION_4_02 131 : FORBIDDEN_4_03 132 : NOT_FOUND_4_04 133 : METHOD_NOT_ALLOWED_4_05 134 : NOT_ACCEPTABLE_4_06 |

| | |
|---|--|
| | 140 : PRECONDITION_FAILED_4_12 141 : REQUEST_ENTITY_TOO_LARGE_4_13 143 : UNSUPPORTED_MEDIA_TYPE_4_15 160 : INTERNAL_SERVER_ERROR_5_00 161 : NOT_IMPLEMENTED_5_01 162 : BAD_GATEWAY_5_02 163 : SERVICE_UNAVAILABLE_5_03 164 : GATEWAY_TIMEOUT_5_04 165 : PROXYING_NOT_SUPPORTED_5_05 Refer to definition from RFC7252, RFC2612 <payload_length> : Received payload length <block2 more>: CoAP Block2 option 0: End of data 1: More Data to get Refer to definition from RFC7959 <payload> : Received payload content |
| #LWCLIENTST: <client_status> | LwM2M client's status change <client_status> LwM2M client status 0: initial 1: bootstrap required 2: bootstrapping 3: registered required 4: registering 5: ready |
| #LWNTYEXEOBJ: <server_id>,<object_id>,<instance_id>,<resource_id> | LwM2M Customer Object Execution Notify |
| #LWNTYRDOBJ: <server_id>,<object_id>,<instance_id>,<resource_count>,<resource_id>[,<resource_id>[,<resource_id>[,...]]] | LwM2M Customer Object Read Notify |
| #LWNTYWROBJ: <server_id>,<object_id>,<instance_id>,<resource_count>,<resource_id>,<resource_type>,<resource_length>,<resource_value>[,<resource_id>,<resource_type>,<resource_length>,<resource_value>[,<resource_id>,<resource_type>,<resource_length>,<resource_value>[, ...]]] | LwM2M Customer Object Write Notify |
| #GNSSSV: <number_of_visible_sv>,<sv_id>,<sv_quality>[,<code_phase_measurement_chip>,<doppler[Hz]>,<carrier_to_noise_ratio[dB]>,<time of week at transmission[ms]>] | GNSS Space Vehicle status notification. SV quality range from 0 (detected) to 5 (ephemeris decoded). |
| #FOTA: state,<fota_state>,<fota_result>,<fota_error> | FOTA Service state change <fota_state> Integer Type 0: IDLE 1: DOWNLOAD ON GOING 2: DOWNLOAD DONE 3: DOWNLOAD FAILED 4: UPDATING DEFERRED 5: UPDATING ON GOING 6: UPDATE DONE 7: UPDATE FAILED <fota_result> |
| +CGEV: NW DETACH | Refer to 5.11 |

| | |
|--|---------------|
| +CGEV: ME DETACH | Refer to 5.11 |
| +CGEV: ME PDN ACT <cid>[,<reason>[,<cid_other>]] | Refer to 5.11 |
| +CGEV: NW ACT <p_cid>, <cid>, <event_type> | Refer to 5.11 |
| +CGEV: ME ACT <p_cid>, <cid>, <event_type> | Refer to 5.11 |
| +CGEV: NW PDN DEACT <cid> | Refer to 5.11 |
| +CGEV: ME PDN DEACT <cid> | Refer to 5.11 |
| +CGEV: ME DEACT <PDP_type>, <PDP_addr>, [<cid>]. | Refer to 5.11 |
| +CGEV: NW DEACT <p_cid>, <cid>, <event_type> | Refer to 5.11 |
| +CGEV: NW MODIFY <cid>,<change_reason>,<event_type> | Refer to 5.11 |
| +CGEV: ME MODIFY <cid>,<change_reason>,<event_type> | Refer to 5.11 |

18 Error codes

18.1 Modem generic error code

| Code | Comment |
|------|---|
| 1 | no connection to phone |
| 2 | phone-adaptor link reserved |
| 3 | operation not allowed |
| 4 | operation not supported |
| 5 | PH-SIM PIN required |
| 6 | PH-FSIM PIN required |
| 7 | PH-FSIM PUK required |
| 10 | SIM not inserted |
| 11 | SIM PIN required |
| 12 | SIM PUK required |
| 13 | SIM failure |
| 14 | SIM busy |
| 15 | SIM wrong |
| 16 | incorrect password |
| 17 | SIM PIN2 required |
| 18 | SIM PUK2 required |
| 20 | memory full |
| 21 | invalid index |
| 22 | not found |
| 23 | memory failure |
| 24 | text string too long |
| 25 | invalid characters in text string |
| 26 | dial string too long |
| 27 | invalid characters in dial string |
| 30 | no network service |
| 31 | network timeout |
| 32 | network not allowed - emergency calls only |
| 40 | network personalisation PIN required |
| 41 | network personalisation PUK required |
| 42 | network subset personalisation PIN required |
| 43 | network subset personalisation PUK required |
| 44 | service provider personalisation PIN required |
| 45 | service provider personalisation PUK required |
| 46 | corporate personalisation PIN required |
| 47 | corporate personalisation PUK required |
| 48 | hidden key required |
| 49 | EAP method not supported |
| 50 | Incorrect parameters |

| | |
|-----|---|
| 51 | command implemented but currently disabled |
| 52 | command aborted by user |
| 53 | not attached to network due to MT functionality restrictions |
| 54 | modem not allowed - MT restricted to emergency calls only |
| 55 | operation not allowed because of MT functionality restrictions |
| 56 | fixed dial number only allowed - called number is not a fixed dial number |
| 57 | temporarily out of service due to other MT usage |
| 58 | language/alphabet not supported |
| 59 | unexpected data value |
| 60 | system failure |
| 61 | data missing |
| 62 | call barred |
| 63 | message waiting indication subscription failure |
| 64 | unknown |
| 103 | Illegal MS (#3) |
| 106 | Illegal ME (#6) |
| 107 | GPRS services not allowed (#7) |
| 108 | GPRS services and non-GPRS services not allowed (#8) |
| 111 | PLMN not allowed (#11) |
| 112 | Location area not allowed (#12) |
| 113 | Roaming not allowed in this location area (#13) |
| 114 | GPRS services not allowed in this PLMN (#14) |
| 115 | No Suitable Cells In Location Area (#15) |
| 122 | Congestion (#22)) |
| 125 | Not authorized for this CSG (#25) |
| 126 | insufficient resources (#26) |
| 127 | missing or unknown APN (#27) |
| 128 | unknown PDP address or PDP type (#28) |
| 129 | user authentication failed (#29) |
| 130 | activation rejected by GGSN Serving GW or PDN GW (#30) |
| 131 | activation rejected unspecified (#31) |
| 132 | service option not supported (#32) |
| 133 | requested service option not subscribed (#33) |
| 134 | service option temporarily out of order (#34) |
| 140 | feature not supported (#40) |
| 141 | semantic error in the TFT operation (#41) |
| 142 | syntactical error in the TFT operation (#42) |
| 143 | unknown PDP context (#43) |
| 144 | semantic errors in packet filter(s) (#44) |
| 145 | syntactical errors in packet filter(s) (#45) |
| 146 | PDP context without TFT already activated (#46) |
| 149 | PDP authentication failure |
| 171 | Last PDN disconnection not allowed (#49) |
| 172 | Semantically incorrect message (#95) |
| 173 | Mandatory information element error (#96) |

| | |
|-----|---|
| 174 | Information element non-existent or not implemented (#97) |
| 175 | Conditional IE error (#99) |
| 176 | Protocol error unspecified (#111) |
| 177 | Operator Determined Barring (#8) |
| 178 | maximum number of PDP contexts reached (#65) |
| 179 | requested APN not supported in current RAT and PLMN combination (#66) |
| 180 | request rejected Bearer Control Mode violation (#48) |
| 181 | unsupported QCI value (#83) |

18.2 Modem custom error code

| Code | Comment |
|------|-----------------------------|
| 500 | Command not available |
| 501 | Number of param not correct |
| 502 | Exceed parameter number |
| 503 | Not enough parameter |
| 504 | Command unknown |
| 505 | Generic error |

18.3 Secure core error code

| Code | Comment |
|------|---|
| 1000 | Generic Error |
| 1001 | String too long |
| 1002 | Command analyzing error |
| 1003 | Execution error |
| 1004 | Bad number of parameter |
| 1005 | Error in parameter conversion |
| 1020 | EFLASH MCU write error |
| 1021 | EFLASH MCU erase, error |
| 1022 | NVM read error |
| 1023 | NVM write error |
| 1024 | NVM save error |
| 1025 | NVM erase error |
| 1040 | WRITE access error |
| 1041 | READ access error |
| 1050 | Ring pin error |
| 1051 | Ring pin setting |
| 1052 | Ring pin delay |
| 1060 | GPIO pin number error |
| 1061 | GPIO mode error |
| 1062 | GPIO value error |
| 1063 | GPIO bank error |
| 1064 | GPIO pin error |
| 1065 | GPIO mux error |
| 1066 | GPIO not available |
| 1070 | Date entry error |
| 1071 | Time entry error |
| 1072 | GMT entry error |
| 1080 | Regulator error |
| 1090 | Watchdog setting error |
| 1100 | Sleep error |
| 1101 | Clock error |
| 1102 | Calclock 32khz error |
| 1103 | Ccalklock rosc error |
| 1104 | Calclock don't exist |
| 1105 | Ram test error |
| 1106 | Flash test error |
| 1107 | Watchdog test error |
| 1120 | AT command forward to APP error |
| 1121 | AT command forward to Modem error |
| 1140 | Storage init error |
| 1180 | PWM init error |
| 1181 | PWM set error |
| 1182 | PWM stop error |
| 1183 | PWM parameters out of bounds error |
| 1184 | PWM parameters bad state transition error |
| 1200 | Assert fault |
| 1205 | Load acces fault |

| | |
|------|---------------------------|
| 1206 | Store acces fault |
| 1300 | Invalid PSA argument |
| 1301 | PSA allready exists |
| 1302 | PSA does not exist |
| 1303 | Insufficient PSA memory |
| 1304 | PSA generic error |
| 1305 | PSA not permitted |
| 1306 | PSA storage failure |
| 1307 | PSA invalid signature |
| 1308 | PSA storage cert ID error |
| 1309 | PSA invalid handle |
| 1400 | GNSS Lib not started |

18.4 Application core error code

| Code | Comment |
|------|--|
| 2000 | system memory issue |
| 2001 | system queue send issue |
| 2008 | adc invalid parameter : channel |
| 2009 | adc : no answer |
| 2010 | system invalid parameter : time for PSM |
| 2011 | system invalid parameter : auto IP success timeout |
| 2012 | Invalid AT command |
| 2100 | tcpip invalid parameter : context id |
| 2101 | tcpip invalid parameter : ip mode |
| 2102 | tcpip invalid parameter : ip version |
| 2103 | tcpip invalid parameter : ip address |
| 2104 | tcpip invalid parameter : socket id |
| 2105 | tcpip : no more context available |
| 2106 | tcpip : network is down |
| 2110 | tcpip invalid parameter : ipv4 address |
| 2111 | tcpip invalid parameter : dhcp not supported |
| 2120 | tcpip invalid parameter : ipv6 address |
| 2121 | tcpip invalid parameter : ipv6 prefix |
| 2122 | tcpip invalid parameter : ipv6 prefix length |
| 2123 | tcpip invalid parameter : ipv6 dns |
| 2124 | tcpip invalid parameter : dhcp6 not supported |
| 2130 | tcpip ping not possible |
| 2131 | tcpip invalid parameter : nbr of bytes |
| 2132 | tcpip invalid parameter : nbr of ping |
| 2133 | tcpip invalid parameter : timeout |
| 2140 | tcpip invalid parameter : tcp udp |
| 2141 | tcpip invalid parameter : port number |
| 2142 | tcpip invalid parameter : data |
| 2143 | tcpip ip address missing |
| 2144 | tcpip invalid parameter : display number of data |
| 2145 | tcpip invalid parameter : data type |
| 2146 | tcpip invalid parameter : data length |
| 2147 | tcpip invalid parameter : RAI |
| 2150 | tcpip socket creation error |
| 2151 | tcpip socket already bound to different port |
| 2152 | tcpip socket error while connecting |
| 2153 | tcpip socket not opened |
| 2154 | tcpip socket issue during data transfer |
| 2155 | tcpip socket bind error |
| 2156 | tcpip socket invalid context |
| 2157 | tcpip socket already connected |
| 2158 | tcpip socket received error |
| 2160 | tcpip invalid parameter : tls algo type |
| 2161 | tcpip invalid parameter : security profile id |
| 2162 | tcpip error while setting tls credentials |
| 2200 | mqtt init failed |

| | |
|------|---|
| 2201 | mqtt protocol stack not initialized |
| 2202 | mqtt invalid parameter : client name |
| 2203 | mqtt invalid parameter : connexion timeout |
| 2204 | mqtt invalid parameter : protocol timeout |
| 2205 | mqtt invalid parameter : publish retry |
| 2206 | mqtt invalid parameter : keep alive pub msg |
| 2207 | mqtt invalid parameter : user |
| 2208 | mqtt invalid parameter : passwd |
| 2209 | mqtt invalid parameter : topic |
| 2210 | mqtt invalid parameter : message |
| 2211 | mqtt invalid parameter : subscribe |
| 2212 | mqtt invalid parameter : retry number |
| 2213 | mqtt invalid parameter : QoS |
| 2214 | mqtt connexion failed |
| 2215 | mqtt publish failed |
| 2216 | mqtt subscribe failed |
| 2217 | mqtt unsubscribe failed |
| 2218 | mqtt not connected |
| 2219 | mqtt disconnexion failed |
| 2220 | mqtt protocol stack already connected |
| 2221 | mqtt not configured |
| 2300 | http init issue |
| 2301 | http protocol stack not initialized |
| 2302 | http protocol stack already initialized |
| 2303 | http invalid parameter : method |
| 2304 | http invalid parameter : method path |
| 2305 | http request initialization failed |
| 2306 | http request send failed |
| 2400 | coap invalid parameter: client name |
| 2401 | coap invalid parameter: server address |
| 2402 | coap invalid parameter: message type |
| 2403 | coap invalid parameter: method |
| 2404 | coap invalid parameter: uri path |
| 2405 | coap invalid parameter: payload |
| 2406 | coap invalid parameter: command string |
| 2410 | coap invalid status: not configured |
| 2411 | coap invalid status: not started |
| 2412 | coap invalid status: not connected |
| 2500 | lwm2m invalid parameter: client name |
| 2501 | lwm2m invalid parameter: server address |
| 2502 | lwm2m invalid parameter: server port |
| 2503 | lwm2m invalid parameter: server id |
| 2504 | lwm2m invalid parameter: server type |
| 2505 | lwm2m invalid parameter: binding mode |
| 2506 | lwm2m invalid parameter: lifetime |
| 2507 | lwm2m invalid parameter: storing |
| 2508 | lwm2m invalid parameter: object id |
| 2509 | lwm2m invalid parameter: uri |
| 2510 | lwm2m invalid parameter: data |
| 2511 | lwm2m invalid parameter: command type |
| 2512 | lwm2m invalid parameter: command string |
| 2513 | lwm2m invalid parameter: register option |
| 2514 | lwm2m invalid stack status |

| | |
|------|--|
| 2515 | lwm2m failed to create device object |
| 2516 | lwm2m failed to create security object |
| 2517 | lwm2m failed to create server object |
| 2518 | lwm2m failed to create firmware object |
| 2519 | lwm2m failed to init protocol |
| 2520 | lwm2m general failure |
| 2521 | lwm2m failed to create custom object |
| 2522 | lwm2m max object num |
| 2523 | lwm2m failed to remove custom object |
| 2524 | lwm2m invalid resource |
| 2525 | lwm2m notify not initialized |
| 2526 | lwm2m invalid notify |
| 2527 | lwm2m notify timed out |
| 2528 | lwm2m notify mismatch |
| 2600 | fota invalid option |
| 2601 | fota invalid uri |
| 2602 | fota failed to download |
| 2603 | fota failed to abort download |
| 2604 | fota failed to update |
| 2605 | fota failed to cancel update |
| 2700 | gnss invalid mode |
| 2701 | gnss invalid const |
| 2702 | gnss invalid IP |
| 2703 | gnss invalid port |
| 2704 | gnss invalid timeout |
| 2705 | gnss invalid sate |
| 2706 | gnss invalid data |
| 2707 | gnss error start |
| 2708 | gnss invalid event |
| 2709 | gnss invalid format |
| 2710 | gnss invalid period |
| 2711 | gnss sv status fail |
| 2712 | gnss busy |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

IMPORTANT NOTICE – PLEASE READ CAREFULLY

STMicroelectronics NV and its subsidiaries (“ST”) reserve the right to make changes, corrections, enhancements, modifications, and improvements to ST products and/or to this document at any time without notice. Purchasers should obtain the latest relevant information on ST products before placing orders. ST products are sold pursuant to ST’s terms and conditions of sale in place at the time of order acknowledgement.

Purchasers are solely responsible for the choice, selection, and use of ST products and ST assumes no liability for application assistance or the design of Purchasers’ products.

No license, express or implied, to any intellectual property right is granted by ST herein.

Resale of ST products with provisions different from the information set forth herein shall void any warranty granted by ST for such product.

ST and the ST logo are trademarks of ST. For additional information about ST trademarks, please refer to www.st.com/trademarks. All other product or service names are the property of their respective owners. Information in this document supersedes and replaces information previously supplied in any prior versions of this document.

© 2023 STMicroelectronics – All rights reserved