



WICED Studio



Running Iperf on WICED-SDK Console Application

Doc. No.: 002-20870 Rev. **

Cypress Semiconductor
198 Champion Court
San Jose, CA 95134-1709
www.cypress.com

Contents

1	Running Iperf on WICED-SDK Console Application.....	3
1.1	IoT Resources and Technical Support	3
1.2	Joining a Wi-Fi AP as WICED STA	3
1.3	Starting WICED SoftAP	3
1.4	Standard Iperf Commands	4
1.5	Restrictions & Known Issues	8
	Document Revision History	9
	Worldwide Sales and Design Support.....	10
	Products	10
	PSoC® Solutions.....	10
	Cypress Developer Community	10
	Technical Support.....	10

1 Running Iperf on WICED-SDK Console Application

Iperf is available in the WICED SDK console test application. Load the console application onto a WICED evaluation board, then connect with a terminal program (eg. PuTTY) with parameters 115200 8N1.

Once the console application boots, standard IPerf commands are available through the console. Before running IPerf, the application needs to join to a Wi-Fi Access Point (AP) as a Wi-Fi client (WICED STA) or start a Wi-Fi AP (WICED SoftAP). Some useful examples follow.

1.1 IoT Resources and Technical Support

Cypress provides a wealth of data at <http://www.cypress.com/internet-things-iot> to help you to select the right IoT device for your design, and quickly and effectively integrate the device into your design. Cypress provides customer access to a wide range of information, including technical documentation, schematic diagrams, product bill of materials, PCB layout information, and software updates. Customers can acquire technical documentation and software from the Cypress Support Community website (<http://community.cypress.com/>).

1.2 Joining a Wi-Fi AP as WICED STA

The STA needs to join a Wi-Fi AP and either assign an IP address statically or use DHCP. The following is an example of joining an open Wi-Fi

AP and assigning a fixed IP address:

```
> join your_ssid open 0102 192.168.1.108 255.255.255.0 192.168.1.1
Joining : your_ssid
Successfully joined : your_ssid
Network ready IP: 192.168.1.108
Network mask: 255.255.255.0
Gateway IP: 192.168.1.1
> ping 192.168.1.1
Pinging: 192.168.1.1
Ping Reply 9ms
```

1.3 Starting WICED SoftAP

To start a SoftAP:

```
start_ap <ssid> <open|wpa2|wpa2_aes> <key> <channel> <wps>
```

Notes and known issues:

- Starting a Soft AP in open mode (no encryption) requires a dummy argument for <key>
- SoftAP may be stopped by using the stop_ap command.

Examples:

Start an AP using WPA2-AES:

```
> start_ap YOUR_AP_SSID wpa2_aes 12345678 6
```

Start an AP using WPA2/WPA mixed mode:

```
> start_ap YOUR_AP_SSID wpa2 12345678 6
```

Start an AP using open mode (no encryption):

```
> start_ap YOUR_AP_SSID open DUMMY_KEY
```

1.4 Standard Iperf Commands

To run Iperf in a thread so that other Iperf instances can also be run, see the `thread_spawn` commands further below. The number of Iperf threads that can run depends on the available memory on the WICED module. The BCM943362WCD4 module can generally support two Iperf threads.

Start a TCP server:

```
> iperf -s
```

Start a UDP server:

```
> iperf -s -u
```

Start a UDP Multicast server bound to 224.1.1.1:

```
> iperf -s -u -B 224.1.1.1
```

Start a TCP client:

```
> iperf -c 192.168.1.136
```

Start a UDP client and send at voice priority (using the -S option), for 90 seconds at 10 Mbps, followed by the same command at video, best effort and background levels of priority:

```
> iperf -c 192.168.1.136 -u -S 0xE0 -t 90 -b 10M
-----
Client connecting to 192.168.1.136, UDP port 5001
Sending 1470 byte datagrams
UDP buffer size: 8.00 KByte (default)
-----
[ ID] Interval      Transfer      Bandwidth
[  0] 0.0-90.0 sec 95.3 MBytes  8.88 Mbits/sec
[  0] Sent 67995 datagrams
[  0] Server Report:
[  0] 0.0-90.0 sec 95.2 MBytes  8.87 Mbits/sec    1.383 ms    106/67996 (0.16%)

> iperf -c 192.168.1.136 -u -S 0xA0 -t 90 -b 10M
-----
Client connecting to 192.168.1.136, UDP port 5001
Sending 1470 byte datagrams
UDP buffer size: 8.00 KByte (default)
-----
[ ID] Interval      Transfer      Bandwidth
[  0] 0.0-90.0 sec 93.7 MBytes  8.73 Mbits/sec
[  0] Sent 66817 datagrams
[  0] Server Report:
[  0] 0.0-90.0 sec 93.7 MBytes  8.73 Mbits/sec    1.210 ms    9/66818 (0.013%)

> iperf -c 192.168.1.136 -u -S 0x00 -t 90 -b 10M
-----
Client connecting to 192.168.1.136, UDP port 5001
Sending 1470 byte datagrams
UDP buffer size: 8.00 KByte (default)
-----
[  0] 0.0-90.0 sec 90.6 MBytes 8.44 Mbits/sec
[  0] Sent 64607 datagrams
[  0] Server Report:
[  0] 0.0-90.0 sec 90.6 MBytes 8.44 Mbits/sec    1.449 ms    2/64608 (0.0031%)

> iperf -c 192.168.1.136 -u -S 0x40 -t 90 -b 10M
-----
Client connecting to 192.168.1.136, UDP port 5001
Sending 1470 byte datagrams
UDP buffer size: 8.00 KByte (default)
-----
[  0] 0.0-90.0 sec 42.1 MBytes  3.92 Mbits/sec
[  0] Sent 30037 datagrams
[  0] Server Report:
[  0] 0.0-90.0 sec 42.1 MBytes  3.92 Mbits/sec    3.077 ms    30/30038 (0.1%)
```

Start a UDP Multicast client:

```
> iperf -c 224.1.1.1 -u
-----
Client connecting to 224.1.1.1, UDP port 5001
Sending 1470 byte datagrams
Setting multicast TTL to 1
UDP buffer size: 8.00 KByte (default)
-----
[ ID] Interval      Transfer    Bandwidth
[  0]  0.0-10.1 sec 1002 KBytes  816 Kbits/sec
[  0] Sent 698 datagrams
```

Starting Iperf UDP server and client in separate threads (ThreadX NetX example):

```
> thread_spawn 7 iperf -s -u -i 10 -p 6000
Started thread 0x200130a8 ("iperf") Spawning a listener.
-----
Server listening on UDP port 6000
Receiving 1470 byte datagrams
UDP buffer size: 8.00 KByte (default)
-----
> thread_spawn 7 iperf -c 192.168.1.139 -u -i 10 -t 90
Started thread 0x200149c8 ("iperf")
-----
Client connecting to 192.168.1.139, UDP port 5001
Sending 1470 byte datagrams
UDP buffer size: 8.00 KByte (default)
-----
[ 1] local 0.0.0.0 port 5001 connected with 192.168.1.139 port 5001
> Spawning a server.
[ ID] Interval      Transfer      Bandwidth
[ 1] 0.0-10.0 sec 1.25 MBytes 1.05 Mbits/sec
[ 0] 0.0-10.0 sec 1.25 MBytes 1.05 Mbits/sec      3.894 ms      0/      891 (0%)
[ 1] 10.0-20.0 sec 1.25 MBytes 1.05 Mbits/sec
[ 0] 10.0-20.0 sec 1.25 MBytes 1.05 Mbits/sec      3.709 ms      0/      892 (0%)
[ 1] 20.0-30.0 sec 1.25 MBytes 1.05 Mbits/sec
[ 0] 20.0-30.0 sec 1.25 MBytes 1.05 Mbits/sec      4.050 ms      0/      891 (0%)
[ 1] 30.0-40.0 sec 1.25 MBytes 1.05 Mbits/sec
[ 0] 30.0-40.0 sec 1.25 MBytes 1.05 Mbits/sec      6.100 ms      0/      891 (0%)
[ 1] 40.0-50.0 sec 1.25 MBytes 1.05 Mbits/sec
[ 0] 40.0-50.0 sec 1.25 MBytes 1.05 Mbits/sec      6.219 ms      0/      892 (0%)
[ 1] 50.0-60.0 sec 1.25 MBytes 1.05 Mbits/sec
[ 0] 50.0-60.0 sec 1.25 MBytes 1.05 Mbits/sec      9.140 ms      0/      892 (0%)
[ 0] 0.0-60.0 sec 7.50 MBytes 1.05 Mbits/sec      8.462 ms      0/     5351 (0%)
[ 1] 60.0-70.0 sec 1.25 MBytes 1.05 Mbits/sec
[ 1] 70.0-80.0 sec 1.25 MBytes 1.05 Mbits/sec
[ 1] 80.0-90.0 sec 1.25 MBytes 1.05 Mbits/sec
[ 1] 0.0-90.0 sec 11.3 MBytes 1.05 Mbits/sec
[ 1] Sent 8026 datagrams
[ 1] Server Report:
[ 1] 0.0-90.0 sec 11.2 MBytes 1.05 Mbits/sec      5.338 ms      3/     8027 (0.037%)
Thread 0x200149c8 (iperf) exited with return value 0
>
```

1.5 Restrictions & Known Issues

- If Iperf is run without first associating and getting an IP address WICED will reset.
- If Iperf is started in client mode and cannot connect with the server then WICED will lock up.
- Joining an open WLAN and using a fixed IP address requires inputting a dummy key because the join command is designed to also cater for security.
- Many Iperf parameters cannot be changed, for example TCP window size and max segment size.
- Using the Iperf -i command to print statistics at small time intervals, e.g. 1 second intervals, will degrade throughput performance. The -S option for setting the Type of Service (TOS) did not properly set the DSCP (Differentiated Services Code Point) bits in the IP header in SDK 2.4.0 and earlier SDKs. This problem is fixed in SDK 2.4.1 and later SDKs. In these SDKs an example TOS value for Voice traffic is 0xE0, for Video traffic is 0xA0, for Best Effort traffic is 0x00, and for Background traffic is 0x40.

Document Revision History

Document Title: Running Iperf on WICED-SDK Console Application

Document Number: 002-20870

Revision	ECN	Issue Date	Description of Change
**	5860455	08/22/2017	Initial release

Worldwide Sales and Design Support

Cypress maintains a worldwide network of offices, solution centers, manufacturer's representatives, and distributors. To find the office closest to you, visit us at [Cypress Locations](#).

Products

ARM® Cortex® Microcontrollers	cypress.com/arm
Automotive	cypress.com/automotive
Clocks & Buffers	cypress.com/clocks
Interface	cypress.com/interface
Internet of Things	cypress.com/iot
Memory	cypress.com/memory
Microcontrollers	cypress.com/mcu
PSoC	cypress.com/psoc
Power Management ICs	cypress.com/pmic
Touch Sensing	cypress.com/touch
USB Controllers	cypress.com/usb
Wireless Connectivity	cypress.com/wireless

PSoC® Solutions

[PSoC 1](#) | [PSoC 3](#) | [PSoC 4](#) | [PSoC 5LP](#) | [PSoC 6](#)

Cypress Developer Community

[Forums](#) | [WICED IOT Forums](#) | [Projects](#) | [Videos](#) | [Blogs](#)
| [Training](#) | [Components](#)

Technical Support

cypress.com/support



Cypress Semiconductor
198 Champion Court
San Jose, CA 95134-1709

© Cypress Semiconductor Corporation, 2017. This document is the property of Cypress Semiconductor Corporation and its subsidiaries, including Spansion LLC ("Cypress"). This document, including any software or firmware included or referenced in this document ("Software"), is owned by Cypress under the intellectual property laws and treaties of the United States and other countries worldwide. Cypress reserves all rights under such laws and treaties and does not, except as specifically stated in this paragraph, grant any license under its patents, copyrights, trademarks, or other intellectual property rights. If the Software is not accompanied by a license agreement and you do not otherwise have a written agreement with Cypress governing the use of the Software, then Cypress hereby grants you a personal, non-exclusive, nontransferable license (without the right to sublicense) (1) under its copyright rights in the Software (a) for Software provided in source code form, to modify and reproduce the Software solely for use with Cypress hardware products, only internally within your organization, and (b) to distribute the Software in binary code form externally to end users (either directly or indirectly through resellers and distributors), solely for use on Cypress hardware product units, and (2) under those claims of Cypress's patents that are infringed by the Software (as provided by Cypress, unmodified) to make, use, distribute, and import the Software solely for use with Cypress hardware products. Any other use, reproduction, modification, translation, or compilation of the Software is prohibited.

TO THE EXTENT PERMITTED BY APPLICABLE LAW, CYPRESS MAKES NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS DOCUMENT OR ANY SOFTWARE OR ACCOMPANYING HARDWARE, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. To the extent permitted by applicable law, Cypress reserves the right to make changes to this document without further notice. Cypress does not assume any liability arising out of the application or use of any product or circuit described in this document. Any information provided in this document, including any sample design information or programming code, is provided only for reference purposes. It is the responsibility of the user of this document to properly design, program, and test the functionality and safety of any application made of this information and any resulting product. Cypress products are not designed, intended, or authorized for use as critical components in systems designed or intended for the operation of weapons, weapons systems, nuclear installations, life-support devices or systems, other medical devices or systems (including resuscitation equipment and surgical implants), pollution control or hazardous substances management, or other uses where the failure of the device or system could cause personal injury, death, or property damage ("Unintended Uses"). A critical component is any component of a device or system whose failure to perform can be reasonably expected to cause the failure of the device or system, or to affect its safety or effectiveness. Cypress is not liable, in whole or in part, and you shall and hereby do release Cypress from any claim, damage, or other liability arising from or related to all Unintended Uses of Cypress products. You shall indemnify and hold Cypress harmless from and against all claims, costs, damages, and other liabilities, including claims for personal injury or death, arising from or related to any Unintended Uses of Cypress products.

Cypress, the Cypress logo, Spansion, the Spansion logo, and combinations thereof, WICED, PSoC, CapSense, EZ-USB, F-RAM, and Traveo are trademarks or registered trademarks of Cypress in the United States and other countries. For a more complete list of Cypress trademarks, visit cypress.com. Other names and brands may be claimed as property of their respective owners.