



## **Trivial File Transfer Protocol (TFTP) for NetX Duo**

# **User Guide**

**Express Logic, Inc.**

858.613.6640  
Toll Free 888.THREADX  
FAX 858.521.4259

[www.expresslogic.com](http://www.expresslogic.com)

**©2002-2017 by Express Logic, Inc.**

All rights reserved. This document and the associated NetX software are the sole property of Express Logic, Inc. Each contains proprietary information of Express Logic, Inc. Reproduction or duplication by any means of any portion of this document without the prior written consent of Express Logic, Inc. is expressly forbidden. Express Logic, Inc. reserves the right to make changes to the specifications described herein at any time and without notice in order to improve design or reliability of NetX. The information in this document has been carefully checked for accuracy; however, Express Logic, Inc. makes no warranty pertaining to the correctness of this document.

**Trademarks**

NetX, Piconet, and UDP Fast Path are trademarks of Express Logic, Inc. ThreadX is a registered trademark of Express Logic, Inc.

All other product and company names are trademarks or registered trademarks of their respective holders.

**Warranty Limitations**

Express Logic, Inc. makes no warranty of any kind that the NetX products will meet the USER's requirements, or will operate in the manner specified by the USER, or that the operation of the NetX products will operate uninterrupted or error free, or that any defects that may exist in the NetX products will be corrected after the warranty period. Express Logic, Inc. makes no warranties of any kind, either expressed or implied, including but not limited to the implied warranties of merchantability and fitness for a particular purpose, with respect to the NetX products. No oral or written information or advice given by Express Logic, Inc., its dealers, distributors, agents, or employees shall create any other warranty or in any way increase the scope of this warranty, and licensee may not rely on any such information or advice.

Part Number: 000-1052

Revision 5.10

# Contents

---

Chapter 1 Introduction to NetX Duo TFTP .....	4
NetX Duo TFTP Requirements.....	4
TFTP File Names .....	4
TFTP Messages .....	5
TFTP Communication .....	6
TFTP Server Session Timer .....	6
TFTP Multi-Thread Support.....	7
TFTP RFCs .....	7
Chapter 2 Installation and Use of NetX Duo TFTP .....	8
Product Distribution .....	8
NetX Duo TFTP Installation.....	8
Using NetX Duo TFTP.....	8
Small Example System .....	9
Configuration Options.....	17
Chapter 3 Description of TFTP Services.....	20
nxd_tftp_client_create .....	22
nxd_tftp_client_delete .....	24
nxd_tftp_client_error_info_get.....	25
nxd_tftp_client_file_close .....	26
nx_tftp_client_file_open.....	27
nxd_tftp_client_file_open.....	29
nxd_tftp_client_file_read .....	31
nxd_tftp_client_file_write .....	33
nxd_tftp_client_packet_allocate .....	35
nxd_tftp_client_set_interface.....	37
nxd_tftp_server_create.....	38
nxd_tftp_server_delete.....	40
nxd_tftp_server_start.....	41
nxd_tftp_server_stop.....	42

# Chapter 1

## Introduction to NetX Duo TFTP

The Trivial File Transfer Protocol (TFTP) is a lightweight protocol designed for file transfers. Unlike more robust protocols, TFTP does not perform extensive error checking and can also have limited performance because it is a stop-and-wait protocol. After a TFTP data packet is sent, the sender waits for an ACK to be returned by the recipient. Although this is simple, it does limit the overall TFTP throughput. The TFTP package enables hosts to use the TFTP protocol over IP networks.

## NetX Duo TFTP Requirements

In order to function properly, the TFTP Clients portion of the NetX Duo TFTP package requires that an IP instance has already been created. In addition, UDP must be enabled on that same IP instance. The Client portion of the NetX Duo TFTP package has no further requirements.

The TFTP Server portion of the NetX Duo TFTP package has several additional requirements. First, it requires complete access to the UDP *well known port 69* for handling all client TFTP requests. The TFTP Server is also designed for use with the FileX embedded file system. If FileX is not available, the user may port the portions of FileX used to their own environment. This is discussed in later sections of this guide.

## TFTP File Names

TFTP file names should be in the format of the target file system. They should be NULL terminated ASCII strings, with full path information if necessary. There is no specified limit in the size of TFTP file names in the NetX Duo TFTP implementation.

## TFTP Messages

The TFTP has a very simple mechanism for opening, reading, writing, and closing files. There are basically 2-4 bytes of TFTP header underneath the UDP header. The definition of the TFTP file open messages has the following format:

**abcdf...f0OCTET0**

Where:

**abcd**                      2-byte Opcode field

                            0x0001 -> Open for read  
                            0x0002 -> Open for write

**f...f**                      n-byte Filename field

**0**                          1-byte NULL termination character

**OCTET**                    ASCII "OCTET" to specify binary transfer

**0**                          1-byte NULL termination character

The definition of the TFTP write, ACK, and error messages are slightly different and are defined as follows:

**abcdwxyzn...n**

Where:

**abcd**                      2-byte Opcode field

                            0x0003 -> Data packet  
                            0x0004 -> ACK for last read  
                            0x0005 -> Error condition

**wxyz**                      2-byte Block Number field (1-n)

**n...n**                      n-byte Data field

Opcode	Filename	NULL	Mode	NULL
0x0001 (read)	File Name	0	OCTET	0
0x0002 (write)	File Name	0	OCTET	0

## TFTP Communication

TFTP Servers utilize the well-known UDP port 69 to listen for Client requests. TFTP Client sockets may bind to any available UDP port. Data packet payload containing the file to upload or download is sent in 512 byte chunks, until the last packet containing < 512 bytes. Therefore a packet containing fewer than 512 bytes signals the end of file. The general sequence of events is as follows:

TFTP Read File Requests:

1. The Client issues an “Open For Read” request with the file name and waits for a reply from the Server.
2. The Server sends the first 512 bytes of the file or less if the file size is less than 512 bytes.
3. The Client receives data, sends an ACK, and waits for the next packet from the Server for files containing more than 512 bytes.
4. The sequence ends when the Client receives a packet containing fewer than 512 bytes.

TFTP Write Requests:

1. The Client issues an “Open for Write” request with the file name and waits for an ACK with a block number of 0 from the Server.
2. When the Server is ready to write the file, it sends an ACK with a block number of zero.
3. The Client sends the first 512 bytes of the file (or less for files less than 512 bytes) to the Server and waits for an ACK back.
4. The Server sends an ACK after the bytes are written.
5. The sequence ends when the Client completes writing a packet containing fewer than 512 bytes.
- 6.

## TFTP Server Session Timer

The TFTP Server has a limited number of client request slots. If a client session appears to be dropped, that slot cannot be available for re-use. However if the NX\_TFTP\_SERVER\_RETRANSMIT\_ENABLE option is enabled, the NetX Duo TFTP Server creates a session timer that monitors the timeout on each of its client sessions. When a session

timeout expires it is terminated and any open files are closed. Thus the 'slot' becomes available for another TFTP Client request.

To set the timeout, adjust the configuration option `NX_TFTP_SERVER_RETRANSMIT_TIMEOUT` which by default is 200 timer ticks. The interval between which session timeouts are checked is set by the `NX_TFTP_SERVER_TIMEOUT_PERIOD` which is 20 timer ticks by default.

## **TFTP Multi-Thread Support**

The NetX Duo TFTP Client services can be called from multiple threads simultaneously. However, read or write requests for a particular TFTP Client instance should be done in sequence from the same thread.

## **TFTP RFCs**

NetX Duo TFTP is compliant with RFC1350 and related RFCs.

## Chapter 2

# Installation and Use of NetX Duo TFTP

This chapter contains a description of various issues related to installation, setup, and usage of the NetX Duo TFTP component.

## Product Distribution

NetX Duo TFTP is shipped on a single CD-ROM compatible disk. The package includes two source files and a PDF file that contains this document, as follows:

<b><code>nxd_tftp_client.h</code></b>	Header file for NetX Duo TFTP Client
<b><code>nxd_tftp_client.c</code></b>	C Source file for NetX Duo TFTP Client
<b><code>nxd_tftp_server.h</code></b>	Header file for NetX Duo TFTP Server
<b><code>nxd_tftp_server.c</code></b>	C Source file for NetX Duo TFTP Server
<b><code>filex_stub.h</code></b>	Stub file if FileX is not present
<b><code>nxd_tftp.pdf</code></b>	PDF description of NetX Duo TFTP
<b><code>demo_netxduo_tftp.c</code></b>	NetX Duo TFTP demonstration

## NetX Duo TFTP Installation

To use NetX Duo TFTP, the entire distribution mentioned previously may be copied to the same directory where NetX Duo is installed. For example, if NetX Duo is installed in the directory “*\threadx\arm7\green*” then the *nxd\_tftp\_client.h*, *nxd\_tftp\_client.c*, *nxd\_tftp\_server.h* and *nxd\_tftp\_server.c* files could be copied into this directory.

## Using NetX Duo TFTP

To run a TFTP application, the application code must include *nxd\_tftp\_client.h* and/or *nxd\_tftp\_server.h* after it includes *tx\_api.h*, *fx\_api.h*, and *nx\_api.h*, in order to use ThreadX, FileX, and NetX Duo, respectively. The application project must also include *nxd\_tftp\_client.c* and/or *nxd\_tftp\_server.c* in the build process. These files must be compiled in the same manner as other application files and its object form must be linked along with the files of the application. This is all that is required to use NetX Duo TFTP. Once the header file(s) is included, the application code is then able to use TFTP services.



Note that since TFTP utilizes NetX Duo UDP services, UDP must be enabled with the *nx\_udp\_enable* call prior to using TFTP.

## Small Example System

An example of how easy it is to use NetX Duo TFTP is described in Figure 1.1 that appears below. In this example, the TFTP include file *nxd\_tftp\_client.h* and *nxd\_tftp\_server.h* are brought in at line 19 and 20. Next, the TFTP Server is created in “*tx\_application\_define*” at line 179. Note that the TFTP Server control block “*server*” was defined as a global variable at line 45 previously. This demo chooses to use IPv4 for its TFTP communication in line 14. After successful creation, the TFTP Server is started at line 303. At line 397 the TFTP Client is created. And finally, the Client writes the file at line 436 and reads the file back at line 471.

Note that this example uses FileX for the TFTP Server handling of receiving and downloading TFTP Client file requests. However, if *NX\_TFTP\_NO\_FILEX* is defined, the application can include *file\_stub.h* instead of *fx\_api.h*.

Also note that existing NetX TFTP client and server applications will work with NetX Duo TFTP. However, the application developer is encouraged to port their Netx TFTP applications to NetX Duo. The equivalent NetX TFTP services are:

```
nxd_tftp_server_start
nxd_tftp_server_stop
nxd_tftp_client_file_read
nxd_tftp_client_file_write
nxd_tftp_client_file_open
```

```
1 /* This is a small demo of TFTP on the high-performance NetX TCP/IP stack.
This demo
2   relies on ThreadX and NetX , to show a simple file transfer from the client
3   and then back to the server. */
4
5 /* Indicate if using a NetX TFTP services. To port a NetX TFTP application to
NetX TFTP
6   undefine this term. */
7
8
9 #define USE_DUO
10
11 /* If the host application is using NetX Duo, determine which IP version to
use.
12   Make sure IPv6 in NetX Duo is enabled if planning to use TFTP over IPv6 */
13 #ifdef USE_DUO
14 #define IP_TYPE 6
15 #endif /* USE_DUO */
16
17 #include "tx_api.h"
18 #include "nx_api.h"
19 #include "nxd_tftp_client.h"
```

```

20 #include      "nxd_tftp_server.h"
21 #ifndef      NX_TFTP_NO_FILEX
22 #include      "fx_api.h"
23 #endif
24
25
26 #define      DEMO_STACK_SIZE      4096
27
28 /* To use another file storage utility define this symbol:
29 #define NX_TFTP_NO_FILEX
30 */
31
32 /* Define the ThreadX, NetX, and FileX object control blocks... */
33
34 TX_THREAD      server_thread;
35 TX_THREAD      client_thread;
36 NX_PACKET_POOL server_pool;
37 NX_IP          server_ip;
38 NX_PACKET_POOL client_pool;
39 NX_IP          client_ip;
40 FX_MEDIA       ram_disk;
41
42 /* Define the NetX TFTP object control blocks. */
43
44 NX_TFTP_CLIENT client;
45 NX_TFTP_SERVER server;
46
47 /* Define the application global variables */
48
49 #define      CLIENT_ADDRESS      IP_ADDRESS(1, 2, 3, 5)
50 #define      SERVER_ADDRESS      IP_ADDRESS(1, 2, 3, 4)
51
52 NXD_ADDRESS      server_ip_address;
53 NXD_ADDRESS      client_ip_address;
54
55 UINT          error_counter = 0;
56
57 /* Define buffer used in the demo application. */
58 UCHAR          buffer[255];
59 ULONG          data_length;
60
61
62 /* Define the memory area for the FileX RAM disk. */
63 #ifndef NX_TFTP_NO_FILEX
64 UCHAR          ram_disk_memory[32000];
65 UCHAR          ram_disk_sector_cache[512];
66 #endif
67
68
69 /* Define function prototypes. */
70
71 VOID          _fx_ram_driver(FX_MEDIA *media_ptr);
72 VOID          _nx_ram_network_driver(NX_IP_DRIVER *driver_req_ptr);
73 void          client_thread_entry(ULONG thread_input);
74 void          server_thread_entry(ULONG thread_input);
75
76
77 /* Define main entry point. */
78
79 int main()
80 {
81     /* Enter the ThreadX kernel. */
82     tx_kernel_enter();
83 }
84
85
86
87 /* Define what the initial system looks like. */
88
89 void          tx_application_define(void *first_unused_memory)
90 {
91     UINT      status;
92     UCHAR      *pointer;
93
94     /* Setup the working pointer. */
95     pointer = (UCHAR *) first_unused_memory;
96
97     /* Create the main TFTP server thread. */

```

```

101     status = tx_thread_create(&server_thread, "TFTP Server Thread",
server_thread_entry, 0,
102                               pointer, DEMO_STACK_SIZE,
103                               4, 4, TX_NO_TIME_SLICE, TX_AUTO_START);
104
105     pointer += DEMO_STACK_SIZE ;
106
107     /* Check for errors. */
108     if (status)
109         error_counter++;
110
111
112     /* Create the main TFTP client thread at a slightly lower priority. */
113     status = tx_thread_create(&client_thread, "TFTP Client Thread",
client_thread_entry, 0,
114                               pointer, DEMO_STACK_SIZE,
115                               5, 5, TX_NO_TIME_SLICE, TX_DONT_START);
116
117     pointer += DEMO_STACK_SIZE ;
118
119     /* Check for errors. */
120     if (status)
121         error_counter++;
122
123     /* Initialize the NetX system. */
124     nx_system_initialize();
125
126     /* Note: The data portion of a packet is exactly 512 bytes, but the packet
payload size must
127     be at least 580 bytes. The remaining bytes are used for the UDP, IP,
and Ethernet
128     headers and byte alignment requirements. */
129
130     status = nx_packet_pool_create(&server_pool, "TFTP Server Packet Pool",
NX_TFTP_PACKET_SIZE, pointer, 8192);
131     pointer = pointer + 8192;
132
133     /* Check for errors. */
134     if (status)
135         error_counter++;
136
137     /* Create the IP instance for the TFTP Server. */
138     status = nx_ip_create(&server_ip, "NetX Server IP Instance",
SERVER_ADDRESS, 0xFFFFFFFFUL,
139                               &server_pool, _nx_ram_network_driver,
pointer, 2048, 1);
140     pointer = pointer + 2048;
141
142     /* Check for errors. */
143     if (status)
144         error_counter++;
145
146     /* Enable ARP and supply ARP cache memory for IP Instance 0. */
147     status = nx_arp_enable(&server_ip, (void *) pointer, 1024);
148     pointer = pointer + 1024;
149
150     /* Check for errors. */
151     if (status)
152         error_counter++;
153
154     /* Enable UDP. */
155     status = nx_udp_enable(&server_ip);
156
157     /* Check for errors. */
158     if (status)
159         error_counter++;
160
161
162     /* Create the TFTP server. */
163     #ifdef USE_DUO
164     #if (IP_TYPE == 6)
165     #ifdef FEATURE_NX_IPV6
166     /* Specify the tftp server global address. */
167     server_ip_address.nxd_ip_version = NX_IP_VERSION_V6;
168     server_ip_address.nxd_ip_address.v6[0] = 0x20010db1;
169     server_ip_address.nxd_ip_address.v6[1] = 0xf101;
170     server_ip_address.nxd_ip_address.v6[2] = 0;
171     server_ip_address.nxd_ip_address.v6[3] = 0x102;
172     #endif
173     #else
174     server_ip_address.nxd_ip_version = NX_IP_VERSION_V4;

```

```

175     server_ip_address.nxd_ip_address.v4 = SERVER_ADDRESS;
176
177 #endif
178
179     status = nxd_tftp_server_create(&server, "TFTP Server Instance",
&server_ip, &ram_disk,
180                                     pointer, DEMO_STACK_SIZE, &server_pool);
181 #else
182     status = nx_tftp_server_create(&server, "TFTP Server Instance",
&server_ip, &ram_disk,
183                                     pointer, DEMO_STACK_SIZE, &server_pool);
184 #endif
185
186     pointer = pointer + DEMO_STACK_SIZE;
187
188     /* Check for errors for the server. */
189     if (status)
190         error_counter++;
191
192     /* Create a packet pool for the TFTP client. */
193
194     /* Note: The data portion of a packet is exactly 512 bytes, but the packet
payload size must
195     be at least 580 bytes. The remaining bytes are used for the UDP, IP,
and Ethernet
196     headers and byte alignment requirements. */
197
198     status = nx_packet_pool_create(&client_pool, "TFTP Client Packet Pool",
NX_TFTP_PACKET_SIZE, pointer, 8192);
199     pointer = pointer + 8192;
200
201     /* Create an IP instance for the TFTP client. */
202     status = nx_ip_create(&client_ip, "TFTP Client IP Instance",
CLIENT_ADDRESS, 0xFFFFFFFFUL,
203                                     &client_pool,
_nx_ram_network_driver, pointer, 2048, 1);
204     pointer = pointer + 2048;
205
206     /* Enable ARP and supply ARP cache memory for IP Instance 1. */
207     status = nx_arp_enable(&client_ip, (void *) pointer, 1024);
208     pointer = pointer + 1024;
209
210     /* Enable UDP for client IP instance. */
211     status |= nx_udp_enable(&client_ip);
212     status |= nx_icmp_enable(&client_ip);
213
214     tx_thread_resume(&client_thread);
215 }
216
217 void server_thread_entry(ULONG thread_input)
218 {
219
220     UINT          status, running;
221     #if (IP_TYPE == 6)
222     #ifdef FEATURE_NX_IPV6
223     UINT          address_index;
224     UINT          iface_index;
225     #endif
226     #endif
227
228
229     /* Allow time for the network driver and NetX to get initialized. */
230     tx_thread_sleep(100);
231
232     #ifndef NX_TFTP_NO_FILEX
233
234     /* Format the RAM disk - the memory for the RAM disk was defined above.
*/
235     status = fx_media_format(&ram_disk,
236                             _fx_ram_driver,          /* Driver entry
*/
237                             ram_disk_memory,         /* RAM disk
memory pointer */
238                             ram_disk_sector_cache,   /* Media buffer
pointer */
239                             sizeof(ram_disk_sector_cache), /* Media buffer
size */
240                             "MY_RAM_DISK",           /* Volume Name
*/
241                             1,                       /* Number of FATs
*/

```

```

242      Entries      */          32,          /* Directory
243      */          0,          /* Hidden sectors
244      */          256,        /* Total sectors
245      */          128,        /* Sector size
246      cluster      */          1,          /* Sectors per
247      */          1,          /* Heads
248      track        */          1);         /* Sectors per
249
250      /* Check for errors. */
251      if (status != FX_SUCCESS)
252      {
253          return;
254      }
255
256      /* Open the RAM disk. */
257      status = fx_media_open(&ram_disk, "RAM DISK", _fx_ram_driver,
ram_disk_memory, ram_disk_sector_cache, sizeof(ram_disk_sector_cache));
258
259      /* Check for errors. */
260      if (status != FX_SUCCESS)
261      {
262          return;
263      }
264
265 #endif /* NX_TFTP_NO_FILEX */
266
267 #if (IP_TYPE == 6)
268 #ifdef FEATURE_NX_IPV6
269
270      /* Enable ICMPv6 services. */
271      status |= nxd_icmp_enable(&server_ip);
272      if (status != NX_SUCCESS)
273      {
274          return;
275      }
276
277      /* Enable IPv6 services for the server. */
278      status = nxd_ipv6_enable(&server_ip);
279      if (status != NX_SUCCESS)
280      {
281          return;
282      }
283
284      /* This assumes the primary interface. See the NetX Duo
285      User Guide for more information on address configuration. */
286      iface_index = 0;
287      status = nxd_ipv6_address_set(&server_ip, iface_index, NX_NULL, 10,
&address_index);
288      status += nxd_ipv6_address_set(&server_ip, iface_index, &server_ip_address,
64, &address_index);
289
290      if (status != NX_SUCCESS)
291      {
292          return;
293      }
294
295      /* wait for DAD to validate the address. */
296      tx_thread_sleep(500);
297 #endif
298
299 #endif /* IP_TYPE == 6 */
300
301      /* Start the NetX TFTP server. */
302 #ifdef USE_DUO
303      status = nxd_tftp_server_start(&server);
304 #else
305      status = nx_tftp_server_start(&server);
306 #endif
307
308      /* Check for errors. */
309      if (status)
310      {
311          error_counter++;
312          return;

```

```

313     }
314
315     /* Run for a while */
316     running = NX_TRUE;
317     while(running)
318         tx_thread_sleep(200);
319
320 #ifdef USE_DUO
321     nxd_tftp_server_delete(&server);
322 #else
323     nx_tftp_server_delete(&server);
324 #endif
325
326 }
327
328 /* Define the TFTP client thread. */
329 void client_thread_entry(ULONG thread_input)
330 {
331     NX_PACKET *my_packet;
332     UINT status;
333     all_done = NX_FALSE;
334     #if (IP_TYPE == 6)
335     #ifdef FEATURE_NX_IPV6
336         address_index;
337         iface_index;
338     #endif
339     #endif
340
341     /* Allow time for the network driver and NetX to get initialized. */
342     tx_thread_sleep(100);
343
344     #if (IP_TYPE == 6)
345     #ifdef FEATURE_NX_IPV6
346         /* Enable ICMPv6 services for the client. */
347         status = nxd_icmp_enable(&client_ip);
348         if (status != NX_SUCCESS)
349         {
350             return;
351         }
352
353         /* Enable IPv6 services for the client. */
354         status = nxd_ipv6_enable(&client_ip);
355         if (status != NX_SUCCESS)
356         {
357             return;
358         }
359
360         /* Set the Client IPv6 address */
361         client_ip_address.nxd_ip_version = NX_IP_VERSION_V6;
362         client_ip_address.nxd_ip_address.v6[0] = 0x20010db1;
363         client_ip_address.nxd_ip_address.v6[1] = 0xf101;
364         client_ip_address.nxd_ip_address.v6[2] = 0;
365         client_ip_address.nxd_ip_address.v6[3] = 0x101;
366
367         /* This assumes the primary interface. See the NetX Duo
368            User Guide for more information on address configuration. */
369         iface_index = 0;
370         status = nxd_ipv6_address_set(&client_ip, iface_index, NX_NULL, 10,
371 &address_index);
372         status += nxd_ipv6_address_set(&client_ip, iface_index, &client_ip_address,
373 64, &address_index);
374         if (status != NX_SUCCESS)
375         {
376             return;
377         }
378
379         /* wait for the link local and global addresses to be validated. */
380         tx_thread_sleep(500);
381     #endif
382     #endif /*(IP_TYPE == 6) */
383
384     /* The TFTP services used below include the NetX equivalent service which
385        will work with

```

```

390         NetX Duo TFTP. However, it is recommended for developers to port their
391         applications to the newer services that take the NXD_ADDRESS type and support both
392         IPv4 and IPv6 communication.
393     */
394
395     /* Create a TFTP client. */
396     #ifdef USE_DUO
397         status = nxd_tftp_client_create(&client, "TFTP Client", &client_ip,
&client_pool, IP_TYPE);
398     #else
399         status = nx_tftp_client_create(&client, "TFTP Client", &client_ip,
&client_pool);
400     #endif
401
402     /* Check status. */
403     if (status)
404         return;
405
406     /* Open a TFTP file for writing. */
407     #ifdef USE_DUO
408         status = nxd_tftp_client_file_open(&client, "test.txt",
&server_ip_address, NX_TFTP_OPEN_FOR_WRITE, 100, IP_TYPE);
409     #else
410         status = nx_tftp_client_file_open(&client, "test.txt", SERVER_ADDRESS,
NX_TFTP_OPEN_FOR_WRITE, 100);
411     #endif
412
413     /* Check status. */
414     if (status)
415         return;
416
417     /* Allocate a TFTP packet. */
418     #ifdef USE_DUO
419         status = nxd_tftp_client_packet_allocate(&client_pool, &my_packet, 100,
IP_TYPE);
420     #else
421         status = nx_tftp_client_packet_allocate(&client_pool, &my_packet, 100);
422     #endif
423     /* Check status. */
424     if (status)
425         error_counter++;
426
427     /* write ABCs into the packet payload! */
428     memcpy(my_packet -> nx_packet_prepend_ptr, "ABCDEFGHJKLMNOPQRSTUVWXYZ ",
28);
429
430     /* Adjust the write pointer. */
431     my_packet -> nx_packet_length = 28;
432     my_packet -> nx_packet_append_ptr = my_packet -> nx_packet_prepend_ptr +
28;
433
434     /* write this packet to the file via TFTP. */
435     #ifdef USE_DUO
436         status = nxd_tftp_client_file_write(&client, my_packet, 100, IP_TYPE);
437     #else
438         status = nx_tftp_client_file_write(&client, my_packet, 100);
439     #endif
440
441     /* Check status. */
442     if (status)
443         error_counter++;
444
445     /* Close this file. */
446     #ifdef USE_DUO
447         status = nxd_tftp_client_file_close(&client, IP_TYPE);
448     #else
449         status = nx_tftp_client_file_close(&client);
450     #endif
451
452     /* Check status. */
453     if (status)
454         error_counter++;
455
456     /* Open the same file for reading. */
457     #ifdef USE_DUO
458         status = nxd_tftp_client_file_open(&client, "test.txt",
&server_ip_address, NX_TFTP_OPEN_FOR_READ, 100, IP_TYPE);
459     #else

```

```

460     status = nx_tftp_client_file_open(&client, "test.txt", SERVER_ADDRESS,
NX_TFTP_OPEN_FOR_READ, 100);
461 #endif
462
463     /* Check status. */
464     if (status)
465         error_counter++;
466     do
467     {
468
469         /* Read the file back. */
470 #ifdef USE_DUO
471         status = nxd_tftp_client_file_read(&client, &my_packet, 100, IP_TYPE);
472 #else
473         status = nx_tftp_client_file_read(&client, &my_packet, 100);
474 #endif
475         /* Check for retransmission/dropped packet error. Benign. Try again...
*/
476         if (status == NX_TFTP_INVALID_BLOCK_NUMBER)
477         {
478
479             continue;
480         }
481         else if (status == NX_TFTP_END_OF_FILE)
482         {
483
484             /* All done. */
485             all_done = NX_TRUE;
486         }
487         else if (status != NX_SUCCESS)
488         {
489
490             /* Internal error, invalid packet or error on read. */
491             break;
492         }
493
494
495         /* Do something with the packet data and release when done. */
496         nx_packet_data_retrieve(my_packet, buffer, &data_length);
497         buffer[data_length] = 0;
498         printf("Receive data: %s\n", buffer);
499
500         printf("release packet in demo.\n");
501
502         nx_packet_release(my_packet);
503
504     } while (all_done == NX_FALSE);
505
506     /* close the file again. */
507 #ifdef USE_DUO
508     status = nxd_tftp_client_file_close(&client, IP_TYPE);
509 #else
510     status = nx_tftp_client_file_close(&client);
511 #endif
512
513     /* Check status. */
514     if (status)
515         error_counter++;
516
517     /* Delete the client. */
518 #ifdef USE_DUO
519     status = nxd_tftp_client_delete(&client);
520 #else
521     status = nx_tftp_client_delete(&client);
522 #endif
523
524     /* Check status. */
525     if (status)
526         error_counter++;
527
528     return;
529 }

```

Figure 1.1 Example of TFTP use with NetX Duo



# Configuration Options

There are several configuration options for building NetX Duo TFTP. The following list describes each in detail. Unless otherwise specified, these options are found in *nxd\_tftp\_client.h* and *nxd\_tftp\_server.h*.

Define	Meaning
<b>NX_DISABLE_ERROR_CHECKING</b>	Defined, this option removes the basic TFTP error checking. It is typically used after the application has been debugged.
<b>NX_TFTP_SERVER_PRIORITY</b>	The priority of the TFTP server thread. By default, this value is defined as 16 to specify priority 16.
<b>NX_TFTP_SERVER_TIME_SLICE</b>	The time slice for the TFTP Server to run before yielding to other threads of the same priority. The default value is 2.
<b>NX_TFTP_MAX_CLIENTS</b>	The maximum number of clients the server can handle at one time. By default, this value is 10 to support 10 clients at once.
<b>NX_TFTP_ERROR_STRING_MAX</b>	The maximum number of characters in the error string. By default, this value is 64.
<b>NX_TFTP_NO_FILEX</b>	Defined, this option provides a stub for FileX dependencies. The TFTP Client will function without any change if this option is defined. The TFTP Server will need to either be modified or the user will have to create a handful of FileX services in order to function properly.
<b>NX_TFTP_TYPE_OF_SERVICE</b>	Type of service required for the TFTP UDP requests. By default, this value is defined as

NX\_IP\_NORMAL to indicate normal IP packet service.

#### **NX\_TFTP\_FRAGMENT\_OPTION**

Fragment enable for TFTP UDP requests. By default, this value is NX\_DONT\_FRAGMENT to disable TFTP UDP fragmenting.

#### **NX\_TFTP\_TIME\_TO\_LIVE**

Specifies the number of routers this packet can pass before it is discarded. The default value is set to 0x80.

#### **NX\_TFTP\_SOURCE\_PORT**

This option allows a TFTP Client application to specify the TFTP Client UDP socket port. It is defaulted to NX\_ANY\_PORT.

#### **NX\_TFTP\_SERVER\_RETRANSMIT\_ENABLE**

Enables the TFTP server's timer to check each TFTP client session with for recent activity (either an ACK or data packet). When the session timeout expires after the maximum number of times, it is assumed the connection was lost. The Server clears the Client request, closes any open files and makes the connection request available for the next Client. The default setting is disabled.

#### **NX\_TFTP\_SERVER\_TIMEOUT\_PERIOD**

Specifies the interval when the TFTP server timer entry function checks Client connections for receiving any packets. The default value is 20 (timer ticks).

#### **NX\_TFTP\_SERVER\_RETRANSMIT\_TIMEOUT**

This is the timeout for receiving a valid ACK or data packet from

the Client. The default value is 200 (timer ticks).

**NX\_TFTP\_SERVER\_MAX\_RETRIES** Specifies the maximum number of times the Client session retransmit timeout is renewed. Thereafter, the session is closed by the Server.

**NX\_TFTP\_MAX\_CLIENT\_RETRANSMITS** Specifies the maximum number of times the Server receives a duplicate ACK or data packet from the Client (which it drops) without sending an error message to the Client and closing the session. Has no effect if **NX\_TFTP\_SERVER\_RETRANSMIT\_ENABLE** is defined.

## Chapter 3

# Description of TFTP Services

This chapter contains a description of all NetX Duo TFTP services (listed below) in alphabetic order. Unless otherwise specified, all services support IPv6 and IPv4 communications.

In the “Return Values” section in the following API descriptions, values in **BOLD** are not affected by the **NX\_DISABLE\_ERROR\_CHECKING** define that is used to disable API error checking, while non-bold values are completely disabled.

nxd\_tftp\_client\_file\_open  
*Open TFTP client file*

nxd\_tftp\_client\_create  
*Create a TFTP client instance*

nxd\_tftp\_client\_delete  
*Delete a TFTP client instance*

nxd\_tftp\_client\_error\_info\_get  
*Get client error information*

nxd\_tftp\_client\_file\_close  
*Close client file*

nxd\_tftp\_client\_file\_open  
*Open client file*

nxd\_tftp\_client\_file\_read  
*Read a block from client file*

nxd\_tftp\_client\_file\_write  
*Write block to client file*

nxd\_tftp\_client\_packet\_allocate  
*Allocate packet for client file write*

nxd\_tftp\_client\_set\_interface  
*Set the physical interface for TFTP requests*

`nxd_tftp_server_create`  
*Create TFTP server*

`nxd_tftp_server_delete`  
*Delete TFTP server*

`nxd_tftp_server_start`  
*Start TFTP server*

`nxd_tftp_server_stop`  
*Stop TFTP server*

Note: The IPv4 equivalents of all the services listed above are available in NetX Duo TFTP Client and Server e.g. `nx_tftp_server_create` and `nx_tftp_client_file_open`. Only the 'Duo' API descriptions, e.g. services beginning with `nxd_`, are provided in the following pages. Where an `NXD_ADDRESS *` input is specified, the IPv4 equivalent API calls for `ULONG` input. Otherwise there is no difference in using the API.

## **nxd\_tftp\_client\_create**

Create a TFTP Client instance

### **Prototype**

```
UINT nxd_tftp_client_create(NX_TFTP_CLIENT *tftp_client_ptr,
    CHAR *tftp_client_name, NX_IP *ip_ptr, NX_PACKET_POOL *pool_ptr);
```

### **Description**

This service creates a TFTP Client instance for the previously created IP instance.

**Important Note:** The application must make certain the supplied IP and packet pool are already created. In addition, UDP must be enabled for the IP instance prior to calling this service.

### **Input Parameters**

<b>tftp_client_ptr</b>	Pointer to TFTP Client control block.
<b>tftp_client_name</b>	Name of this TFTP Client instance
<b>ip_ptr</b>	Pointer to previously created IP instance.
<b>pool_ptr</b>	Pointer to packet pool TFTP Client instance.

### **Return Values**

<b>NX_SUCCESS</b>	<b>(0x00)</b>	<b>Successful TFTP create.</b>
<b>NX_TFTP_INVALID_IP_VERSION</b>	<b>(0x0C)</b>	<b>Invalid or unsupported IP version</b>
<b>NX_TFTP_INVALID_SERVER_ADDRESS</b>	<b>(0x08)</b>	<b>Invalid Server IP address received</b>
<b>NX_TFTP_NO_ACK_RECEIVED</b>	<b>(0x09)</b>	<b>Server ACK not received</b>
<b>NX_PTR_ERROR</b>	<b>(0x16)</b>	<b>Invalid IP, pool, or TFTP pointer.</b>
<b>NX_INVALID_PARAMETERS</b>	<b>(0x4D)</b>	<b>Invalid non pointer input</b>
<b>NX_CALLER_ERROR</b>	<b>(0x11)</b>	<b>Invalid caller of this service.</b>

### **Allowed From**

## Initialization and Threads

### Example

```
/* Create a TFTP Client instance. */
status = nxd_tftp_client_create(&my_tftp_client, "My TFTP Client",
                                &my_ip, &pool_ptr);

/* If status is NX_SUCCESS a TFTP Client instance was successfully
   created. */
```

## **nxd\_tftp\_client\_delete**

---

Delete a TFTP Client instance

### **Prototype**

```
UINT nxd_tftp_client_delete(NX_TFTP_CLIENT *tftp_client_ptr);
```

### **Description**

This service deletes a previously created TFTP Client instance.

### **Input Parameters**

<b>tftp_client_ptr</b>	Pointer to previously created TFTP client instance.
------------------------	---

### **Return Values**

<b>NX_SUCCESS</b>	(0x00)	Successful TFTP Client delete.
<b>NX_PTR_ERROR</b>	(0x16)	Invalid pointer input.
<b>NX_CALLER_ERROR</b>	(0x11)	Invalid caller of this service.

### **Allowed From**

Threads

### **Example**

```
/* Delete a TFTP Client instance. */  
status = nxd_tftp_client_delete(&my_tftp_client);  
  
/* If status is NX_SUCCESS the TFTP Client instance was successfully  
   deleted. */
```



## **nxd\_tftp\_client\_error\_info\_get**

Get client error information

### **Prototype**

```
UINT nxd_tftp_client_error_info_get(NX_TFTP_CLIENT *tftp_client_ptr,
                                     UINT *error_code, CHAR **error_string);
```

### **Description**

This service returns the last error code received and sets the pointer to the client's internal error string. In error conditions, the user can view the last error sent by the server. A null error string indicates no error is present.

### **Input Parameters**

<b>tftp_client_ptr</b>	Pointer to previously created TFTP Client instance.
<b>error_code</b>	Pointer to destination area for error code
<b>error_string</b>	Pointer to destination for error string

### **Return Values**

<b>NX_SUCCESS</b>	(0x00)	Successful TFTP error info get.
<b>NX_PTR_ERROR</b>	(0x16)	Invalid TFTP Client pointer.
<b>NX_CALLER_ERROR</b>	(0x11)	Invalid caller of this service.

### **Allowed From**

Threads

### **Example**

```
/* Get error information for client. */
status = nxd_tftp_client_error_info_get(&my_tftp_client, &error_code,
                                         &error_string_ptr);

/* If status is NX_SUCCESS the error code and error string are available. */
```

## **nxd\_tftp\_client\_file\_close**

---

Close client file

### **Prototype**

```
UINT nxd_tftp_client_file_close(NX_TFTP_CLIENT *tftp_client_ptr,
                               UINT ip_type);
```

### **Description**

This service closes the previously opened file by this TFTP Client instance. A TFTP Client instance is allowed to have only one file open at a time.

### **Input Parameters**

<b>tftp_client_ptr</b>	Pointer to previously created TFTP Client instance.
<b>ip_type</b>	Indicate which IP protocol to use. Valid options are IPv4 (4) or IPv6 (6).

### **Return Values**

<b>NX_SUCCESS</b>	(0x00)	Successful TFTP file close.
<b>NX_PTR_ERROR</b>	(0x16)	Invalid pointer input.
<b>NX_CALLER_ERROR</b>	(0x11)	Invalid caller of this service.
<b>NX_INVALID_PARAMETERS</b>	(0x4D)	Invalid non pointer input

### **Allowed From**

Threads

### **Example**

```
/* Close the previously opened file associated with "my_client". */
status = nxd_tftp_client_file_close(&my_tftp_client);
/* If status is NX_SUCCESS the TFTP file is closed. */
```

## **nx\_tftp\_client\_file\_open**

Open TFTP client file

### **Prototype**

```
UINT nx_tftp_client_file_open(NX_TFTP_CLIENT *tftp_client_ptr,
                              CHAR *file_name, NXD_ADDRESS *server_ip_address, UINT
                              open_type, ULONG wait_option);
```

### **Description**

This service attempts to open the specified file on the TFTP Server at the specified IP address. The file will be opened for either reading or writing. Note this is limited to IPv4 packets only, and is intended for supporting NetX TFTP applications. Developers are encouraged to port their applications to using equivalent “duo” service *nxd\_tftp\_client\_file\_open*.

### **Input Parameters**

**tftp\_client\_ptr**      Pointer to TFTP control block.

**file\_name**            ASCII file name, NULL-terminated and with appropriate path information.

**server\_ip\_address**   Server TFTP address.

**open\_type**            Type of open request, either:

**NX\_TFTP\_OPEN\_FOR\_READ**   (0x01)

**NX\_TFTP\_OPEN\_FOR\_WRITE** (0x02)

**wait\_option**          Defines how long the service will wait for the TFTP Client file open. The wait options are defined as follows:

**timeout value**        (0x00000001 through 0xFFFFFFFF)

**TX\_WAIT\_FOREVER** (0xFFFFFFFF)

Selecting TX\_WAIT\_FOREVER causes the calling thread to suspend indefinitely until a TFTP Server responds to the request.

Selecting a numeric value (1-0xFFFFFFFF) specifies the maximum number of timer-ticks to stay suspended while waiting for the TFTP server response.

**ip\_type**                      Indicate which IP protocol to use. Valid options are IPv4 (4) or IPv6 (6).

## Return Values

<b>NX_SUCCESS</b>	(0x00)	Successful Client file open
<b>NX_TFTP_NOT_CLOSED</b>	(0xC3)	Client already has file open
<b>NX_INVALID_TFTP_SERVER_ADDRESS</b>	(0x08)	Invalid server address received
<b>NX_TFTP_NO_ACK_RECEIVED</b>	(0x09)	No ACK received from server
<b>NX_TFTP_INVALID_SERVER_ADDRESS</b>	(0x08)	<b>Invalid Server IP received</b>
<b>NX_TFTP_CODE_ERROR</b>	(0x05)	<b>Received error code</b>
<b>NX_PTR_ERROR</b>	(0x16)	Invalid pointer input.
<b>NX_CALLER_ERROR</b>	(0x11)	Invalid caller of this service
<b>NX_IP_ADDRESS_ERROR</b>	(0x21)	Invalid Server IP address
<b>NX_OPTION_ERROR</b>	(0x0A)	Invalid open type

## Allowed From

Threads

## Example

```
/* Define the TFTP server address. */
NXD_ADDRESS server_ip_address;

server_ip_address.nxd_ip_version = NX_IP_VERSION_V6;
server_ip_address.nxd_ip_address.v6[0] = 0x20010db8;
server_ip_address.nxd_ip_address.v6[1] = 0xf101;
server_ip_address.nxd_ip_address.v6[2] = 0;
server_ip_address.nxd_ip_address.v6[3] = 0x101;

/* Open file "test.txt" for reading on the TFTP Server. */
status = nxd_tftp_client_file_open(&my_tftp_client, "test.txt",
                                   &server_ip_address, NX_TFTP_OPEN_FOR_READ, 200);

/* If status is NX_SUCCESS the "test.txt" file is now open for reading. */
```

---

## **nxd\_tftp\_client\_file\_open**

Open TFTP client file

### **Prototype**

```
UINT nxd_tftp_client_file_open(NX_TFTP_CLIENT *tftp_client_ptr,
                               CHAR *file_name, NXD_ADDRESS *server_ip_address, UINT
                               open_type, ULONG wait_option, UINT ip_type);
```

### **Description**

This service attempts to open the specified file on the TFTP Server at the specified IPv6 address. The file will be opened for either reading or writing.

### **Input Parameters**

**tftp\_client\_ptr** Pointer to TFTP control block.

**file\_name** ASCII file name, NULL-terminated and with appropriate path information.

**server\_ip\_address** Server TFTP address.

**open\_type** Type of open request, either:

**NX\_TFTP\_OPEN\_FOR\_READ** (0x01)  
**NX\_TFTP\_OPEN\_FOR\_WRITE** (0x02)

**wait\_option** Defines how long the service will wait for the TFTP Client file open. The wait options are defined as follows:

**timeout value** (0x00000001 through 0xFFFFFFFF)  
**TX\_WAIT\_FOREVER** (0xFFFFFFFF)

Selecting TX\_WAIT\_FOREVER causes the calling thread to suspend indefinitely until a TFTP Server responds to the request.

Selecting a numeric value (1-0xFFFFFFFF) specifies the maximum number of timer-ticks to stay suspended while waiting for the TFTP server response.

**ip\_type** Indicate which IP protocol to use. Valid options

are IPv4 (4) or IPv6 (6).

## Return Values

<b>NX_SUCCESS</b>	(0x00)	Successful Client file open
<b>NX_TFTP_NOT_CLOSED</b>	(0xC3)	Client already has file open
<b>NX_INVALID_TFTP_SERVER_ADDRESS</b>	(0x08)	Invalid server address received
<b>NX_TFTP_NO_ACK_RECEIVED</b>	(0x09)	No ACK received from server
<b>NX_TFTP_INVALID_IP_VERSION</b>	(0x0C)	Invalid IP version
<b>NX_TFTP_INVALID_SERVER_ADDRESS</b>	(0x08)	Invalid Server IP received
<b>NX_TFTP_CODE_ERROR</b>	(0x05)	Received error code
<b>NX_PTR_ERROR</b>	(0x16)	Invalid pointer input.
<b>NX_CALLER_ERROR</b>	(0x11)	Invalid caller of this service
<b>NX_IP_ADDRESS_ERROR</b>	(0x21)	Invalid Server IP address
<b>NX_OPTION_ERROR</b>	(0x0A)	Invalid open type
<b>NX_INVALID_PARAMETERS</b>	(0x4D)	Invalid non pointer input

## Allowed From

Threads

## Example

```
/* Define the TFTP server address. */
NXD_ADDRESS server_ip_address;

server_ip_address.nxd_ip_version = NX_IP_VERSION_V6;
server_ip_address.nxd_ip_address.v6[0] = 0x20010db8;
server_ip_address.nxd_ip_address.v6[1] = 0xf101;
server_ip_address.nxd_ip_address.v6[2] = 0;
server_ip_address.nxd_ip_address.v6[3] = 0x101;

/* Open file "test.txt" for reading on the TFTP Server. */
status = nxd_tftp_client_file_open(&my_tftp_client, "test.txt",
    & server_ip_address, NX_TFTP_OPEN_FOR_READ, 200);

/* If status is NX_SUCCESS the "test.txt" file is now open for reading. */
```

## **nxd\_tftp\_client\_file\_read**

Read a block from client file

### **Prototype**

```
UINT nxd_tftp_client_file_read(NX_TFTP_CLIENT *tftp_client_ptr,
                               NX_PACKET **packet_ptr, ULONG wait_option,
                               UINT ip_type);
```

### **Description**

This service reads a 512-byte block from the previously opened TFTP Client file. A block containing fewer than 512 bytes signals the end of the file.

### **Input Parameters**

<b>tftp_client_ptr</b>	Pointer to TFTP Client control block.
<b>packet_ptr</b>	Destination for packet containing the block read from the file.
<b>wait_option</b>	Defines how long the service will wait for the read to complete. The wait options are defined as follows:  <b>timeout value</b> (0x00000001 through 0xFFFFFFFF) <b>TX_WAIT_FOREVER</b> (0xFFFFFFFF)  Selecting TX_WAIT_FOREVER causes the calling thread to suspend indefinitely until the TFTP Server responds to the request.  Selecting a numeric value (1-0xFFFFFFFF) specifies the maximum number of timer-ticks to stay suspended while waiting for the TFTP server to send a block of the file.
<b>ip_type</b>	Indicate which IP protocol to use. Valid options are IPv4 (4) or IPv6 (6).

### **Return Values**

<b>NX_SUCCESS</b>	(0x00)	Successful Client block read
-------------------	--------	------------------------------

<b>NX_TFTP_NOT_OPEN</b>	(0xC3)	Specified Client file is not open for reading
<b>NX_NO_PACKET</b>	(0x01)	No Packet received from Server.
<b>NX_INVALID_TFTP_SERVER_ADDRESS</b>	(0x08)	Invalid server address received
<b>NX_TFTP_NO_ACK_RECEIVED</b>	(0x09)	No ACK received from Server
<b>NX_TFTP_END_OF_FILE</b>	(0xC5)	End of file detected (not an error).
<b>NX_TFTP_INVALID_IP_VERSION</b>	(0x0C)	Invalid IP version
<b>NX_TFTP_CODE_ERROR</b>	(0x05)	Received error code
<b>NX_TFTP_FAILED</b>	(0xC2)	Unknown TFTP code received
<b>NX_TFTP_INVALID_BLOCK_NUMBER</b>	(0x0A)	Invalid block number received
<b>NX_PTR_ERROR</b>	(0x16)	Invalid pointer input.
<b>NX_CALLER_ERROR</b>	(0x11)	Invalid caller of this service
<b>NX_INVALID_PARAMETERS</b>	(0x4D)	Invalid non pointer input

### Allowed From

Threads

### Example

```
/* Read a block from a previously opened file of "my_client". */
status = nxd_tftp_client_file_read(&my_tftp_client, &return_packet_ptr, 200);

/* If status is NX_SUCCESS a block of the TFTP file is in the payload of
   "return_packet_ptr". */
```



## **nxd\_tftp\_client\_file\_write**

Write a block to Client file

### **Prototype**

```
UINT nxd_tftp_client_file_write(NX_TFTP_CLIENT *tftp_client_ptr,
                                NX_PACKET *packet_ptr, ULONG wait_option, UINT ip_type);
```

### **Description**

This service writes a 512-byte block to the previously opened TFTP Client file. Specifying a block containing fewer than 512 bytes signals the end of the file.

### **Input Parameters**

<b>tftp_client_ptr</b>	Pointer to TFTP Client control block.
<b>packet_ptr</b>	Packet containing the block to write to the file.
<b>wait_option</b>	Defines how long the service will wait for the write to complete. The wait options are defined as follows:  <b>timeout value</b> (0x00000001 through 0xFFFFFFFF) <b>TX_WAIT_FOREVER</b> (0xFFFFFFFF)  Selecting TX_WAIT_FOREVER causes the calling thread to suspend indefinitely until the TFTP Server responds to the request.  Selecting a numeric value (1-0xFFFFFFFF) specifies the maximum number of timer-ticks to stay suspended while waiting for the TFTP server to send an ACK for the write request.
<b>ip_type</b>	Indicate which IP protocol to use. Valid options are IPv4 (4) or IPv6 (6).

### **Return Values**

<b>NX_SUCCESS</b>	(0x00)	Successful Client block write
<b>NX_TFTP_NOT_OPEN</b>	(0xC3)	Specified Client file is not open for writing

<b>NX_TFTP_TIMEOUT</b>	(0xC1)	Timeout waiting for Server ACK
<b>NX_INVALID_TFTP_SERVER_ADDRESS</b>	(0x08)	Invalid server address received
<b>NX_TFTP_NO_ACK_RECEIVED</b>	(0x09)	No ACK received from server
<b>NX_TFTP_INVALID_IP_VERSION</b>	(0x0C)	Invalid IP version
<b>NX_INVALID_TFTP_SERVER_ADDRESS</b>	(0x08)	Invalid server address received
<b>NX_TFTP_CODE_ERROR</b>	(0x05)	Received error code
<b>NX_PTR_ERROR</b>	(0x16)	Invalid pointer input.
<b>NX_CALLER_ERROR</b>	(0x11)	Invalid caller of this service
<b>NX_INVALID_PARAMETERS</b>	(0x4D)	Invalid non pointer input

### Allowed From

Threads

### Example

```
/* write a block to the previously opened file of "my_client". */
status = nxd_tftp_client_file_write(&my_tftp_client, packet_ptr, 200);
/* If status is NX_SUCCESS the block in the payload of "packet_ptr" was
   written to the TFTP file opened by "my_client". */
```

## **nxd\_tftp\_client\_packet\_allocate**

Allocate packet for Client file write

### **Prototype**

```
UINT nxd_tftp_client_packet_allocate(NX_PACKET_POOL *pool_ptr,
                                     NX_PACKET **packet_ptr, ULONG wait_option,
                                     UINT ip_type)
```

### **Description**

This service allocates a UDP packet from the specified packet pool and makes room for the 4-byte TFTP header before the packet is returned to the caller. The caller can then build a buffer for writing to a client file.

### **Input Parameters**

<b>pool_ptr</b>	Pointer to packet pool.
<b>packet_ptr</b>	Destination for pointer to allocated packet.
<b>wait_option</b>	Defines how long the service will wait for the packet allocate to complete. The wait options are defined as follows:  <div style="margin-left: 40px;"> <b>timeout value</b>      (0x00000001 through 0xFFFFFFFF)  <b>TX_WAIT_FOREVER</b> (0xFFFFFFFF)         </div> Selecting TX_WAIT_FOREVER causes the calling thread to suspend indefinitely until the allocation completes.  Selecting a numeric value (1-0xFFFFFFFF) specifies the maximum number of timer-ticks to stay suspended while waiting for the packet allocation.
<b>ip_type</b>	Indicate which IP protocol to use. Valid options are IPv4 (4) or IPv6 (6).

### **Return Values**

<b>NX_SUCCESS</b>	(0x00)	Successful packet allocate
-------------------	--------	----------------------------

NX_PTR_ERROR	(0x16)	Invalid pointer input.
NX_CALLER_ERROR	(0x11)	Invalid caller of this service
NX_INVALID_PARAMETERS	(0x4D)	Invalid non pointer input

## Allowed From

Threads

## Example

```
/* Allocate a packet for TFTP file write. */  
status = nxd_tftp_client_packet_allocate(&my_pool, &packet_ptr, 200);  
/* If status is NX_SUCCESS "packet_ptr" contains the new packet. */
```

## **nxd\_tftp\_client\_set\_interface**

Set physical interface for TFTP requests

### **Prototype**

```
UINT nxd_tftp_client_set_interface(NX_TFTP_CLIENT *tftp_client_ptr,
                                   UINT if_index)
```

### **Description**

This service uses the input interface index to set the physical interface for the TFTP Client to send and receive TFTP packets. The default value is zero, for the primary interface. Note that NetX Duo must support multihome addressing (v5.6 or later) to use this service.

### **Input Parameters**

<b>tftp_client_ptr</b>	Pointer to TFTP Client instance
<b>if_index</b>	Index of physical interface to use

### **Return Values**

<b>NX_SUCCESS</b>	(0x00)	Successfully set interface
	(0x0B)	Invalid interface input
<b>NX_PTR_ERROR</b>	(0x16)	Invalid pointer input.
<b>NX_CALLER_ERROR</b>	(0x11)	Invalid caller of this service
<b>NX_TFTP_INVALID_INTERFACE</b>	(0x0B)	Invalid interface input

### **Allowed From**

Threads

### **Example**

```
/* Specify the primary interface for TFTP requests. */
status = nxd_tftp_client_set_interface(&client, 0);

/* If status is NX_SUCCESS the primary interface will be use for TFTP
communications. */
```

# nxd\_tftp\_server\_create

Create TFTP server

## Prototype

```
UINT nxd_tftp_server_create(NX_TFTP_SERVER *tftp_server_ptr,
    CHAR *tftp_server_name, NX_IP *ip_ptr, FX_MEDIA *media_ptr,
    VOID *stack_ptr, ULONG stack_size,
    NX_PACKET_POOL *pool_ptr);
```

## Description

This service creates a TFTP Server that responds to TFTP Client requests on port 69. The Server must be started by a subsequent call to *nxd\_tftp\_server\_start*.

**Important Note:** The application must make certain the supplied IP instance, packet pool, and FileX media instance are already created. In addition, UDP must be enabled for the IP instance prior to calling this service.

## Input Parameters

<b>tftp_server_ptr</b>	Pointer to TFTP Server control block.
<b>tftp_server_name</b>	Name of this TFTP Server instance
<b>ip_ptr</b>	Pointer to previously created IP instance.
<b>media_ptr</b>	Pointer to FileX media instance.
<b>stack_ptr</b>	Pointer to TFTP Server stack area.
<b>stack_size</b>	Number of bytes in the TFTP Server stack.
<b>pool_ptr</b>	Pointer to TFTP packet pool. Note that the supplied pool must have packet payloads at least 580 bytes in size. <sup>1</sup>

## Return Values

<b>NX_SUCCESS</b>	(0x00)	Successful Server create
-------------------	--------	--------------------------

<sup>1</sup> The data portion of a packet is exactly 512 bytes, but the packet payload size must be at least 572 bytes. The remaining bytes are used for the UDP, IPv6, and Ethernet headers and potential trailing bytes required by the driver for alignment.

<b>NX_TFTP_POOL_ERROR</b>	(0xC6)	Packet pool has packet size of less than 560 bytes
<b>NX_PTR_ERROR</b>	(0x16)	Invalid pointer input.

### Allowed From

Initialization, Threads

### Example

```
/* Create a TFTP Server called "my_server". */
status = nxd_tftp_server_create(&my_server, "My TFTP Server", &server_ip,
                                &ram_disk, stack_ptr, 2048, pool_ptr);

/* If status is NX_SUCCESS the TFTP Server is created. */
```

## **nxd\_tftp\_server\_delete**

---

Delete TFTP Server

### **Prototype**

```
UINT nxd_tftp_server_delete(NX_TFTP_SERVER *tftp_server_ptr);
```

### **Description**

This service deletes a previously created TFTP Server.

### **Input Parameters**

<b>tftp_server_ptr</b>	Pointer to TFTP Server control block.
------------------------	---------------------------------------

### **Return Values**

<b>NX_SUCCESS</b>	(0x00)	Successful Server delete
<b>NX_PTR_ERROR</b>	(0x16)	Invalid pointer input.
<b>NX_CALLER_ERROR</b>	(0x11)	Invalid caller of this service

### **Allowed From**

Threads

### **Example**

```
/* Delete the TFTP Server called "my_server". */
status = nxd_tftp_server_delete(&my_server);

/* If status is NX_SUCCESS the TFTP Server is deleted. */
```



## **nxd\_tftp\_server\_start**

---

Start TFTP server

### **Prototype**

```
UINT nxd_tftp_server_start(NX_TFTP_SERVER *tftp_server_ptr);
```

### **Description**

This service starts the previously created TFTP Server.

### **Input Parameters**

<b>tftp_server_ptr</b>	Pointer to TFTP Server control block.
------------------------	---------------------------------------

### **Return Values**

<b>NX_SUCCESS</b>	(0x00)	Successful Server start
<b>NX_PTR_ERROR</b>	(0x16)	Invalid pointer input

### **Allowed From**

Initialization, threads

### **Example**

```
/* Start the TFTP Server called "my_server". */
status = nxd_tftp_server_start(&my_server);

/* If status is NX_SUCCESS the TFTP Server is started. */
```

## **nxd\_tftp\_server\_stop**

---

Stop TFTP Server

### **Prototype**

```
UINT nxd_tftp_server_stop(NX_TFTP_SERVER *tftp_server_ptr);
```

### **Description**

This service stops the previously created TFTP Server.

### **Input Parameters**

<b>tftp_server_ptr</b>	Pointer to TFTP Server control block.
------------------------	---------------------------------------

### **Return Values**

<b>NX_SUCCESS</b>	(0x00)	Successful Server stop
<b>NX_PTR_ERROR</b>	(0x16)	Invalid pointer input.
<b>NX_CALLER_ERROR</b>	(0x11)	Invalid caller of this service

### **Allowed From**

Threads

### **Example**

```
/* Stop the TFTP Server called "my_server". */  
status = nxd_tftp_server_stop(&my_server);  
  
/* If status is NX_SUCCESS the TFTP Server is stopped. */
```