



Palm OS® Programmer's Companion

Volume II Communications

CONTRIBUTORS

Written by Christopher Bey, Elly Freeman, Gary Hillerson, Jean Ostrem, Ruben Rodriguez, and Greg Wilson

Production by <dot>PS Document Production Services

Engineering contributions by Ludovic Ferrandis, Gilles Fabre, David Fedor, Roger Flores, Steve Lemke, Bob Ebert, Ken Krugler, Paul Plaquette, Bruce Thompson, Jesse Donaldson, Tim Wiegman, Gavin Peacock, Ryan Robertson, and Waddah Kudaimi

Copyright © 1996 - 2001, Palm, Inc. All rights reserved. This documentation may be printed and copied solely for use in developing products for Palm OS software. In addition, two (2) copies of this documentation may be made for archival and backup purposes. Except for the foregoing, no part of this documentation may be reproduced or transmitted in any form or by any means or used to make any derivative work (such as translation, transformation or adaptation) without express written consent from Palm, Inc.

Palm, Inc. reserves the right to revise this documentation and to make changes in content from time to time without obligation on the part of Palm, Inc. to provide notification of such revision or changes. PALM, INC. MAKES NO REPRESENTATIONS OR WARRANTIES THAT THE DOCUMENTATION IS FREE OF ERRORS OR THAT THE DOCUMENTATION IS SUITABLE FOR YOUR USE. THE DOCUMENTATION IS PROVIDED ON AN "AS IS" BASIS. PALM, INC. MAKES NO WARRANTIES, TERMS OR CONDITIONS, EXPRESS OR IMPLIED, EITHER IN FACT OR BY OPERATION OF LAW, STATUTORY OR OTHERWISE, INCLUDING WARRANTIES, TERMS, OR CONDITIONS OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, AND SATISFACTORY QUALITY.

TO THE FULL EXTENT ALLOWED BY LAW, PALM, INC. ALSO EXCLUDES FOR ITSELF AND ITS SUPPLIERS ANY LIABILITY, WHETHER BASED IN CONTRACT OR TORT (INCLUDING NEGLIGENCE), FOR DIRECT, INCIDENTAL, CONSEQUENTIAL, INDIRECT, SPECIAL, OR PUNITIVE DAMAGES OF ANY KIND, OR FOR LOSS OF REVENUE OR PROFITS, LOSS OF BUSINESS, LOSS OF INFORMATION OR DATA, OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THIS DOCUMENTATION, EVEN IF PALM, INC. HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Palm Computing, Palm OS, Graffiti, HotSync, and Palm Modem are registered trademarks, and Palm III, Palm IIle, Palm IIlx, Palm V, Palm Vx, Palm VII, Palm, Palm Powered, More connected., Simply Palm, the Palm logo, Palm Computing platform logo, Palm III logo, Palm IIlx logo, Palm V logo, and HotSync logo are trademarks of Palm, Inc. or its subsidiaries. All other product and brand names may be trademarks or registered trademarks of their respective owners.

IF THIS DOCUMENTATION IS PROVIDED ON A COMPACT DISC, THE OTHER SOFTWARE AND DOCUMENTATION ON THE COMPACT DISC ARE SUBJECT TO THE LICENSE AGREEMENT ACCOMPANYING THE COMPACT DISC.

Palm OS Programmer's Companion, Volume II: Communications
Document Number 3005-002

July 23, 2001

For the latest version of this document, visit

<http://www.palmos.com/dev/tech/docs/>.

Palm, Inc.
5470 Great America Pkwy.
Santa Clara, CA 95052
USA

www.palmos.com

Table of Contents

| | |
|--|--------------|
| About This Document | ix |
| Palm OS SDK Documentation | ix |
| What This Volume Contains | ix |
| Additional Resources | x |
| 1 Object Exchange | 1 |
| About the Exchange Manager | 2 |
| Exchange Libraries | 2 |
| Typed Data Objects | 3 |
| Initializing the Exchange Socket Structure | 4 |
| Identifying the Exchange Library. | 5 |
| Identifying the Type of Data | 7 |
| Registering for Data. | 8 |
| General Registration Guidelines | 9 |
| Setting the Default Application. | 10 |
| Registering to Receive Unwrapped Data | 14 |
| Sending Data. | 15 |
| Sending a Single Object | 15 |
| Sending Multiple Objects | 16 |
| Implementing the Send Command | 18 |
| Receiving Data | 19 |
| Controlling the Exchange Dialog | 19 |
| Displaying a Preview | 21 |
| Receiving the Data | 23 |
| Sending and Receiving Databases. | 26 |
| Sending a Database. | 26 |
| Receiving a Database | 28 |
| Requesting Data | 29 |
| Sending a Get Request for a Single Object | 29 |
| Responding to a Get Request | 30 |
| Two-Way Communications | 30 |
| Requesting a URL | 31 |
| Sending and Receiving Locally | 32 |
| Interacting with the Launcher | 34 |
| Summary of Exchange Manager | 36 |

| | |
|---|---------------|
| 2 Exchange Libraries | 37 |
| About Exchange Libraries | 37 |
| Exchange Libraries, Exchange Manager, and Applications | 38 |
| Palm OS Exchange Libraries | 39 |
| Exchange Library Components | 40 |
| The Exchange Library API. | 40 |
| Dispatch Table | 42 |
| Implementing an Exchange Library | 46 |
| Required Functions. | 46 |
| Registering with the Exchange Manager. | 48 |
| Summary of Exchange Library | 49 |
| 3 Personal Data Interchange | 51 |
| About Personal Data Interchange | 52 |
| About vObjects | 52 |
| Overview of vObject Structure | 53 |
| About the PDI Library. | 55 |
| PDI Property and Parameter Types | 56 |
| The PDI Library Properties Dictionary | 57 |
| PDI Readers | 57 |
| PDI Writers | 58 |
| Format Compatibility. | 59 |
| International Considerations. | 60 |
| Features Not Yet Supported | 60 |
| Using the PDI Library | 60 |
| Accessing the PDI Library | 64 |
| Unloading the PDI Library | 65 |
| Creating a PDI Reader | 65 |
| Reading Properties | 66 |
| Reading Property Values | 67 |
| Creating a PDI Writer | 71 |
| Writing Properties | 72 |
| Writing Property Values. | 72 |
| Specifying PDI Versions. | 73 |

| | |
|---|-----------|
| Using UDA for Different Media | 73 |
| About the UDA Library | 73 |
| Using a PDI Reader - An Example | 74 |
| Using a PDI Writer - An Example | 79 |
| Summary of Personal Data Interchange | 83 |
| Summary of Unified Data Access Manager. | 84 |
| 4 Beaming (Infrared Communication) | 85 |
| IR Library | 85 |
| IrDA Stack | 86 |
| Accessing the IR Library | 87 |
| Summary of Beaming | 87 |
| 5 Serial Communication | 89 |
| Serial Hardware | 90 |
| Byte Ordering | 90 |
| Serial Communications Architecture Hierarchy. | 91 |
| The Serial Manager | 92 |
| Which Serial Manager Version To Use. | 93 |
| Steps for Using the Serial Manager | 97 |
| Opening a Port. | 98 |
| Closing a Port | 101 |
| Configuring the Port | 102 |
| Sending Data | 105 |
| Receiving Data. | 106 |
| Serial Manager Tips and Tricks. | 112 |
| Writing a Virtual Device Driver | 114 |
| The Connection Manager | 116 |
| The Serial Link Protocol | 119 |
| SLP Packet Structures. | 119 |
| Transmitting an SLP Packet | 122 |
| Receiving an SLP Packet | 122 |
| The Serial Link Manager. | 122 |
| Using the Serial Link Manager | 123 |
| Summary of Serial Communications | 126 |

| | |
|--|----------------|
| 6 Network Communication | 129 |
| Net Library | 129 |
| About the Net Library | 130 |
| Net Library Usage Steps. | 133 |
| Obtaining the Net Library's Reference Number | 134 |
| Setting Up Berkeley Socket API | 135 |
| Setup and Configuration Calls | 135 |
| Opening the Net Library | 140 |
| Closing the Net Library | 142 |
| Version Checking. | 143 |
| Network I/O and Utility Calls | 143 |
| Berkeley Sockets API Functions | 144 |
| Extending the Network Login Script Support | 151 |
| Internet Library | 156 |
| System Requirements | 157 |
| Initialization and Setup | 157 |
| Accessing Web Pages | 158 |
| Asynchronous Operation | 159 |
| Using the Low Level Calls. | 160 |
| Cache Overview | 161 |
| Internet Library Network Configurations | 162 |
| Summary of Network Communication | 163 |
| 7 Internet and Messaging Applications | 167 |
| Internet Access on Palm Powered Handhelds | 168 |
| Overview of Web Clipping Architecture | 168 |
| About Web Clipping Applications | 169 |
| Using the Viewer to Display Information | 170 |
| Sending Email Messages. | 172 |
| Registering an Email Application. | 172 |
| Sending Mail from the Viewer | 173 |
| Launching the Email Application for Editing. | 173 |
| Adding an Email to the Outbox | 173 |
| Using Wireless Capabilities in Your Applications | 174 |
| System Version Checking | 174 |

| | |
|---|------------|
| Wireless keyDownEvent Key Codes | 175 |
| Including Over-the-Air Characters | 176 |
| 8 Telephony Manager | 177 |
| Telephony Service Types. | 177 |
| Using the Telephony API | 179 |
| Accessing the Telephony Manager Library. | 179 |
| Closing the Telephony Manager Library. | 181 |
| Using Synchronous and Asynchronous Calls. | 181 |
| Using Data Structures With Variably-sized Fields. | 182 |
| Testing the Telephony Environment. | 184 |
| Using the Phone Book Capabilities | 185 |
| About the PhBkApp Program | 186 |
| Launching the PhBkApp Program | 188 |
| Event Processing in the PhBkApp Program | 190 |
| Displaying the Phone Book | 191 |
| Retrieving the List of Phone Book Entries | 192 |
| Editing Phone Book Entries | 196 |
| Summary of Telephony Manager | 197 |
| Index | 201 |

About This Document

The *Palm OS Programmer's Companion* is part of the Palm OS® Software Development Kit. This introduction provides an overview of SDK documentation, discusses what materials are included in this document and what conventions are used.

Palm OS SDK Documentation

The following documents are part of the SDK:

| Document | Description |
|--|--|
| <i>Palm OS Programmer's API Reference</i> | An API reference document that contains descriptions of all Palm OS function calls and important data structures. |
| <i>Palm OS Programmer's Companion</i> | A multi-volume guide to application programming for the Palm OS. This guide contains conceptual and "how-to" information that complements the Reference. |
| <i>Constructor for Palm OS</i> | A guide to using Constructor to create Palm OS resource files. |
| <i>Palm OS Programming Development Tools Guide</i> | A guide to writing and debugging Palm OS applications with the various tools available. |

What This Volume Contains

This volume is designed for random access. That is, you can read any chapter in any order.

Note that each chapter ends with a list of hypertext links into the relevant function descriptions in the Reference book.

About This Document

Additional Resources

Here is an overview of this volume:

- [Chapter 1, “Object Exchange.”](#) Describes how applications use the Exchange Manager to send and receive typed data objects.
- [Chapter 2, “Exchange Libraries.”](#) Describes how to implement an exchange library.
- [Chapter 3, “Personal Data Interchange.”](#) Describes the PDI library, which you use to exchange Personal Data Interchange (PDI) information with other devices and media
- [Chapter 4, “Beaming \(Infrared Communication\).”](#) Describes the two facilities for beaming, or IR communication: the exchange manager and the IR library.
- [Chapter 5, “Serial Communication.”](#) Describes the serial port hardware, the serial communications architecture, the serial link protocol, and the various serial communication managers.
- [Chapter 6, “Network Communication.”](#) Describes the net library and Internet library and how to perform communications with networking protocols such as TCP/IP and UDP. The net library API maps very closely to the Berkeley UNIX sockets API.
- [Chapter 7, “Internet and Messaging Applications.”](#) Describes the Palm.Net system and how to use the Web Clipping Application Viewer and iMessenger applications to access and send information using the wireless capabilities of the Palm VII™ device.
- [Chapter 8, “Telephony Manager.”](#) Describes the component parts of the telephony API and shows how to use the telephony API in your applications.

Additional Resources

- Documentation
Palm publishes its latest versions of this and other documents for Palm OS developers at
<http://www.palmos.com/dev/tech/docs/>

- Training

Palm and its partners host training classes for Palm OS developers. For topics and schedules, check

<http://www.palmos.com/dev/tech/support/classes/>

- Knowledge Base

The Knowledge Base is a fast, web-based database of technical information. Search for frequently asked questions (FAQs), sample code, white papers, and the development documentation at

<http://www.palmos.com/dev/tech/kb/>

Object Exchange

The simplest form of communication for a Palm OS[®] application to implement is the sending and receiving of typed data objects, such as MIME data, databases, or database records.

You use the Exchange Manager to send and receive typed data objects. The Exchange Manager interface is independent of the transport mechanism. You can use IR, SMS, or any other protocol that has an Exchange Manager plug-in called an **exchange library**.

The Exchange Manager is supported in Palm OS 3.0 and higher. In Palm OS 4.0, significant updates were made.

This chapter describes how applications use the Exchange Manager to send and receive typed data objects. It covers the following topics:

- [About the Exchange Manager](#)
- [Initializing the Exchange Socket Structure](#)
- [Registering for Data](#)
- [Registering to Receive Unwrapped Data](#)
- [Receiving Data](#)
- [Sending and Receiving Databases](#)
- [Requesting Data](#)
- [Sending and Receiving Locally](#)
- [Interacting with the Launcher](#)

This chapter does not describe how to implement an exchange library.

About the Exchange Manager


This section explains concepts you need to know before you can begin using the Exchange Manager. It discusses the following topics:

- [Exchange Libraries](#)
- [Typed Data Objects](#)

Exchange Libraries

The Exchange Manager works in conjunction with an exchange library. Each **exchange library** is transport-dependent and performs the actual communication with the remote device. When an application makes an Exchange Manager call, the Exchange Manager forwards the request to the appropriate exchange library. The Exchange Manager's main duty is to maintain a registry of which libraries implement each protocol and which applications receive each type of data. See [Figure 1.1](#).

Figure 1.1 Object exchange using Exchange Manager



The list of supported exchange libraries depends on the version of Palm OS. See [Table 1.1](#).

Table 1.1 Supported exchange libraries

| Exchange Library | Minimum Palm OS Version |
|--------------------------------------|--------------------------------|
| IR Library (IrDA) | Palm OS 3.0 |
| Local Exchange Library | Palm OS 4.0 |
| SMS Library (Short Messaging System) | Palm OS 4.0 |
| Bluetooth Library ^a | Palm OS 4.0 |

a. The Bluetooth Library is not present in Palm OS 4.0, but is planned to be provided shortly after Palm OS 4.0 ships.

As other exchange libraries become available, users can install them on their Palm Powered™ handhelds and use the communications functionality they provide.

Note that on Palm OS 3.X the only exchange library available is the IR Library, and it is not extensible. The IR Library cannot, for example, be replaced with a different exchange library.

Typed Data Objects

The Exchange Manager sends and receives typed data objects. A **typed data object** (or **object**) is a stream of bytes plus some information about its contents. The content information includes any of: a creator ID, a MIME data type, or a filename.

The object itself can be in any format, but it's best to use a standardized data format rather than a proprietary one if you have a choice. [Table 1.2](#) lists the standardized data formats that the built-in Palm OS applications can receive.

Object Exchange

Initializing the Exchange Socket Structure

Table 1.2 Built-in applications and standard data types

| Application | Data Type |
|--------------|--|
| Address Book | vCards (vcf file extension, text/x-vCard MIME type) |
| Datebook | vCalendars (vcs file extension, text/x-vCalendar MIME type) |
| Launcher | Palm OS databases (prc, pdb, oprc, and pqa file extensions, application/x-pilot and application/vnd.palm MIME types) |
| Memo | Plain text (txt file extension, text/plain MIME type) |
| ToDo | Not explicitly registered, but receives vCalendar objects from Datebook as appropriate |

NOTE: The MIME type application/vnd.palm has been registered with the IANA and is preferred over the application/x-pilot MIME type.

If you want your application to receive objects, you must first register with the Exchange Manager for the type of data you want to receive. See “[Registering for Data](#)” for instructions on how to do so. You can override the built-in applications by registering for any data type listed in [Table 1.2](#) and becoming the default application for that type. See “[Setting the Default Application](#)” for more information.

If you only want to send data, you do not have to register. Your application can send data of the types listed in [Table 1.2](#), and the Exchange Manager ensures that the appropriate application receives it.

Initializing the Exchange Socket Structure

The Exchange Manager, exchange library, and application use an exchange socket structure ([ExgSocketType](#)) to communicate with

each other. This structure is passed from the application to the Exchange Manager to the exchange library and vice versa. (The use of the term “socket” in the Exchange Manager API is not related to the term “socket” as used in sockets communication programming.) When your application sends data, you must create this structure and initialize it with the appropriate information. When you receive data, this structure provides information about the connection and the incoming data.

The `ExgSocketType` structure you use must identify two important pieces of information:

- the exchange library that should do the sending (see [“Identifying the Exchange Library”](#))
- the type of data being sent (see [“Identifying the Type of Data”](#))

The socket structure defines other fields that you may use to provide other information if you want. See the description of the [ExgSocketType](#) structure in the *Palm OS Programmer’s API Reference* for complete details.

IMPORTANT: When initializing the `ExgSocketType` structure, set all unused fields to 0.

Identifying the Exchange Library

The [ExgSocketType](#) structure identifies the library to be used in one of the following ways:

- a library reference number in the `libraryRef` field
- a Uniform Resource Locator (URL) in the `name` field

The Exchange Manager checks for a library reference number first. If it is 0, it checks for a URL.

When your application sends data, it must identify which exchange library to use. You only need to identify the exchange library in Palm OS 4.0 and higher. Earlier releases contain only one exchange library (for IR), so all sending is automatically done by that library. If you do not specify an exchange library on Palm OS 4.0 and higher, the IR Library is used to maintain backward compatibility.

Object Exchange

Initializing the Exchange Socket Structure

It's more common to identify the library using a URL instead of a library reference number. The URL scheme specifies which exchange library to use. The **scheme** is the part of the URL that appears before the colon (:). For example, the scheme in the following URL is "http"

```
http://www.palmos.com
```

When you pass the preceding URL to a web browser, the scheme tells the browser to connect to the server using the HTTP protocol. Similarly, when you pass the Exchange Manager a URL, the scheme tells the Exchange Manager which exchange library to use. For example, the following URL tells the Exchange Manager to connect to a remote Palm Powered handheld using the IR Library:

```
_beam:BusinessCard.vcf
```

On Palm OS, a URL has the following format:

```
[?]scheme1[;scheme2]...:filename
```

where:

?

If more than one exchange library is registered for the provided schemes, the Exchange Manager has the user select the exchange library by displaying the Send With dialog.

scheme1[;*scheme2*]...

The URL schemes that identify which exchange library should be used. If more than one exchange library is registered for the scheme, the default exchange library is selected unless the URL begins with a question mark.

As shown, multiple schemes may be provided, separated by semicolons. Multiple schemes are only supported in conjunction with the question mark. For example, the string "?_send;_beam" has the Exchange Manager display a Send With dialog that lists all exchange libraries that support either the _send scheme or the _beam scheme.

filename The name of the file to send. Typically, this file also has an extension that is used, if necessary, to determine which application should receive the data. See “[Identifying the Type of Data](#)” for more information about the file extension.

Palm OS defines some URL prefixes that any application can use to connect with the installed exchange libraries. A URL prefix is everything up to and including the colon character. [Table 1.3](#) describes the prefixes.

Table 1.3 Exchange Library URL Prefixes

| Exchange Library | URL Prefix |
|---|-------------------|
| IR Library | exgBeamPrefix |
| Local Exchange Library | exgLocalPrefix |
| SMS Library | kSmsScheme |
| Any library that supports the _send scheme (user’s choice) | exgSendPrefix |
| Any library that supports the _send or _beam scheme (user’s choice) | exgSendBeamPrefix |

The section “[Implementing the Send Command](#)” provides more information on using `exgSendPrefix` or `exgSendBeamPrefix`.

Identifying the Type of Data

When your application sends data, the exchange socket structure ([ExgSocketType](#)) identifies the type of data being sent. It can do so with one of the following values:

- A MIME type in the `type` field. This field is only used on Palm OS 4.0 and higher.
- A file extension for the file in the `name` field. That is, you might supply `MyDB.pdb` as the value of the `name` field. The part after the last period (.) is the extension.

In most cases, the data type determines which application receives the data on the remote side. (If the `target` field is specified, it

Object Exchange

Registering for Data

determines which application receives the data instead of the data type as described below.) The Exchange Manager maintains a registry of applications and the types of data each application can receive. When the Exchange Manager receives an object, it checks the exchange socket for the data type. It checks the `type` field first, and if it is not defined or if no application is registered to receive that MIME type, it checks the `name` field for a file extension. This is discussed in more detail in the “[Registering for Data](#)” section.

Note that you may also directly specify which application should receive the data. To do so, place the creator ID in the `target` field. You do not have to specify a MIME type or file extension in this instance. When the `target` field is nonzero, the Exchange Manager checks for the existence of that application on the receiving device. If it exists, that application receives the data regardless of whether it is registered. If the target application does not exist, the Exchange Manager searches the registry as usual. Use the `target` field only if you know that you are communicating with a Palm Powered handheld and want to explicitly specify which application should receive the data.

On Palm OS 4.0 and higher, an application can register for another application’s creator ID and receive all objects targeted to that creator ID. See “[Setting the Default Application](#)” for more details.

Registering for Data

In most cases, applications that want to receive data from the Exchange Manager must register for the MIME type and/or file extension that they want to receive. The function that you use to do so differs depending on which operating system versions you want to support.

On Palm OS 3.X, you call [ExgRegisterData](#) and pass it three parameters: your application’s creator ID, a constant that identifies the type of data you want to register to receive (`exgRegExtensionID` for file extensions or `exgRegTypeID` for MIME types), and a string that lists the MIME types or file extensions. For example, on Palm OS 3.X the Beamer sample application distributed with the Palm OS SDK makes this call:

```
ExgRegisterData (beamerCreator,  
                 exgRegExtensionID, BitmapExt);
```

On Palm OS 4.0 and higher, `ExgRegisterData` is deprecated and replaced with [ExgRegisterDatatype](#). `ExgRegisterDatatype` supports more types of data and takes more parameters. You still pass the creator ID, the type of data you want to register for, and the string that describes the specifics of what you are registering for. Palm OS 4.0 and higher supports registering for creator IDs (`exgRegCreatorID`) or URL schemes (`exgRegSchemeID`) in addition to MIME types and file extensions; however, registering for these new data types is not as common. See “[Setting the Default Application](#)” for a case where you would register for a creator ID, and see “[Requesting a URL](#)” for a case where you would register for a URL.

In addition, you must pass two more parameters to `ExgRegisterDatatype`: a string containing descriptions of the data you are registering to receive and a flag indicating whether you want to receive the data directly if it is sent as part of another object. The descriptions that you pass in are displayed to preview the data in the exchange dialog under certain circumstances. The flag parameter is described in the “[Registering to Receive Unwrapped Data](#)” section.

For example, on Palm OS 4.0 the Beamer sample application distributed with the Palm OS SDK makes this call:

```
ExgRegisterDatatype (beamerCreator,  
                    exgRegExtensionID, BitmapExt, "bitmap", 0);
```

General Registration Guidelines

Follow these guidelines when registering for data:

- Register as early as possible.

To ensure that your application can receive data at any time after it is installed, call [ExgRegisterData](#) or [ExgRegisterDatatype](#) in response to the [sysAppLaunchCmdSyncNotify](#) launch code. This launch code is sent to your application upon its first installation and any time the HotSync[®] operation modifies the application's database.

- It's best to use a standardized data format rather than a proprietary one if you have a choice.

Object Exchange

Registering for Data

- On Palm OS 4.0 and higher, multiple applications can register to receive the same data type. The section “[Setting the Default Application](#)” describes this further.
- When registering for file extensions, do not include the period (.) as part of the extension. Register for “TXT”, for example, not “.TXT”.

- Do **not** make multiple calls if you want to register for more than one MIME type or more than one file extension.

Instead, make one call for all file extensions and one call for all MIME types. Pass a single string containing file extensions or MIME types separated by a tab (\t) character. For example, the following call registers the application for two file extensions, TXT and DOC:

```
ExgRegisterData(myCreator, exgRegExtensionID,  
"TXT\tDOC", "plain text", 0);
```

- The description parameter is optional. If you implement the preview mode as described in “[Displaying a Preview](#)” later in this chapter, you do not need to provide a description. It is, however, strongly recommended that you provide one.

Setting the Default Application

Because multiple applications can register for the same data type on Palm OS 4.0 and higher, the Exchange Manager supports the concept of a default application that receives all objects of a particular data type. To set the default application, call the function [ExgSetDefaultApplication](#). There is one default application per data type in the registry. Palm OS 3.X does not support having multiple applications registered for the same data types.

Suppose a device running Palm OS 4.0 receives a vCard object, and it has three applications registered to receive vCards. The Exchange Manager checks the registry to see if any of these applications is assigned as the default. If so, the default application receives all vCards (unless the exchange socket structure’s `target` field is set). If none of the three applications is the default, the Exchange Manager chooses one, and that application receives all vCards.

Palm, Inc. strongly recommends that you allow users to choose which application is the default. To do so, you could display a panel

that shows users the applications that can receive the same type of data as your application, show them which is the default, and allow them to select a different default. Use [ExgGetRegisteredApplications](#) to get a list of all applications registered to receive the same data type as yours, and use [ExgGetDefaultApplication](#) to retrieve the current default, if any. See [Listing 1.2](#) to see how the iMessenger example application performs this task for the `mailto` URL scheme. The full source code is distributed with the SDK.

Listing 1.1 Initializing a List of Registered Applications

```
void PrvSetMailAppsList(Int32 listSelection)
{
    ControlPtr ctl;
    ListPtr lst;
    UInt32 defaultID;

    ctl = GetObjectPtr(PrefDefaultMailTrigger);
    lst = GetObjectPtr(PrefDefaultMailList);

    // crIDs, appCnt, appNames are all global variables.
    // Get the list of creator IDs if we don't have it already.
    if(!crIDs) {
        ExgGetRegisteredApplications(&crIDs, &appCnt, &appNames, NULL,
            exgRegSchemeID, "mailto");
        if(appCnt) {
            MemHandle tmpH = SysFormPointerArrayToStrings(appNames, appCnt);
            if(tmpH)
                appNamesArray = MemHandleLock(tmpH);
            else
                return;
        }
        else
            return;
    }

    if(appNamesArray)
        LstSetListChoices(lst, appNamesArray, appCnt);
    LstSetHeight(lst, appCnt < 6 ? appCnt : 6);

    if(listSelection == -1)
    {
        UInt16 i;
```

Object Exchange

Registering for Data

```
ExgGetDefaultApplication(&defaultID, exgRegSchemeID, "mailto");

for(i=0;i<appCnt;i++) {
    if(crIDs[i] == defaultID)
        LstSetSelection(lst, i);
}
else
    LstSetSelection(lst, listSelection);

CtlSetLabel(ctl, appNamesArray[LstGetSelection(lst)]);
}
```

To become the default application for a data type that a built-in Palm OS application is registered to receive (see [Table 1.2](#)), you must perform some extra steps to ensure that you can receive that type of object when it is beamed from a device running Palm OS 3.X. You must register for the built-in application's creator ID and become the default application for that creator ID.

On Palm OS 3.X, the built-in applications always set their creator IDs in the `target` field when sending data, causing the data to always be sent to that application. On Palm OS 4.0 and higher, the built-in applications still register to receive the same type of data, but they do not set the `target` field when sending. This means that if your application is registered for the same data type and is the default application, it receives the data from Palm OS 4.0 and higher as expected, but if the data is sent from a device running Palm OS 3.X, you still won't receive that data because it is specifically targeted for the built-in application.

To solve this problem, the `ExgRegisterData` function in Palm OS 4.0 and higher supports registering for another application's creator ID. [Listing 1.2](#) shows how an application that receives vCards might set the default application after allowing the user to select the default from a list, assuming the list is initialized with code similar to that in [Listing 1.1](#).

Note that, as with all data types, your application won't receive the data targeted for the other application unless yours is the default application for that creator ID.

Listing 1.2 Setting the default application for vCards

```
UInt32 PilotMain (UInt16 cmd, void *cmdPBP, UInt16 launchFlags)
{
    ...
    // Register for vCard MIME type, extension, and Address Book's creator ID.
    // At this point, we are not the default application so we do not receive
    // vCards. We still must register upon install so that our application
    // appears in the preferences list when the user chooses the default
    // application for vCards.
    case sysAppLaunchCmdSyncNotify:
        Char addressCreatorStr[5];

        // Create a string from Address Book's creator ID.
        MemMove(addressCreatorStr, sysFileCAddress, 4);
        addressCreatorStr[4] = chrNull;

        ExgRegisterDatatype(crID, exgRegTypeID, "text/x-vCard", "vCard", 0);
        ExgRegisterDatatype(crID, exgRegExtensionID, "vcf", "vCard", 0);
        ExgRegisterDatatype(crID, exgRegCreatorID, addressCreatorStr, NULL, 0);
        ...
}

static void PrefApply (void)
{
    MemHandle h;
    FieldType *fld;
    ControlType *ctl;
    UInt16 listItem;

    // Set the default vCard app
    vif(appCnt && crIDs)
    {
        UInt32 crID;
        Char addressCreatorStr[5];

        // Create a string from Address Book's creator ID.
        MemMove(addressCreatorStr, sysFileCAddress, 4);
        addressCreatorStr[4] = chrNull;

        listItem = LstGetSelection(GetObjectPtr(PrefDefaultAppList));
        crID = crIDs[listItem];
        ExgSetDefaultApplication(crID, exgRegTypeID, "text/x-vCard");
        ExgSetDefaultApplication(crID, exgRegExtensionID, "vcf");
        ExgSetDefaultApplication(crID, exgRegCreatorID, addressCreatorStr);
    }
}
```

Registering to Receive Unwrapped Data

On Palm OS 4.0 or higher, in rare circumstances, you can register to receive data that is sent enclosed in another object.

For example, suppose you have a stock quote application that wants to receive vStock objects. If the device is sent an e-mail message that has the vStock object attached, your application may want to register to receive the vStock object directly rather than having the e-mail application receive it. To do so, call [ExgRegisterDatatype](#) and pass the constant `exgUnwrap` as the last parameter. The flag is named `exgUnwrap` because the exchange library unwraps the received object (the e-mail message in this example) so that it can send the contained objects (the vStock object) directly.

If you want to register to receive an object when it is sent as part of another object, you probably also want to receive it when it is sent by itself. This requires two calls to `ExgRegisterDatatype`: one with the `exgUnwrap` flag set, and one without.

```
ExgRegisterDatatype(myCreator,
    exgRegExtensionID, "TXT\tdoc", "plain text",
    0);
ExgRegisterDatatype(myCreator,
    exgRegExtensionID, "TXT\tdoc", "plain text",
    exgUnwrap);
```

Thus, you might make four calls to `ExgRegisterDatatype`:

- one call to register for the file extensions
- one call to register for file extensions that are sent as part of another object
- one call to register for MIME types
- one call to register for MIME types that are sent as part of another object

As mentioned previously, it's rare for an application to register to receive unwrapped data directly. It's more common for one application (such as an e-mail application) to receive the entire compound object and then unwrap and disperse the enclosed objects using the Local Exchange Library. See "[Sending and Receiving Locally](#)" for more information.

Sending Data

This section describes how to send data using the Exchange Manager. It discusses the following topics:

- [Sending a Single Object](#)
- [Sending Multiple Objects](#)
- [Implementing the Send Command](#)

Sending a Single Object

The most common use of the Exchange Manager is to send or receive a single object. To send an object, do the following:

1. Create and initialize an [ExgSocketType](#) data structure with information about which library to use and the data to be sent. See “[Initializing the Exchange Socket Structure](#)” for more information.
2. Call [ExgPut](#) to establish the connection with the exchange library.
3. Call [ExgSend](#) one or more times to send the data.

In this function, you specify the number of bytes to send, and [ExgSend](#) returns the number of bytes that were sent. You may need to call it multiple times if data is remaining to be sent after the first and subsequent calls.

4. Call [ExgDisconnect](#) to end the connection.

A zero (0) return value indicates a successful transmission. However, this doesn’t necessarily mean that the receiver kept the data. If the target application for an object doesn’t exist on the receiving device, the data is discarded; or the user can decide to discard any received objects.

Note that the [ExgSend](#) function blocks until it returns. However, most libraries provide a user interface dialog that keeps the user informed of transmission progress and allows them to cancel the operation.

The Exchange Manager automatically displays error dialogs as well, if errors occur. You must check for error codes from Exchange Manager routines, but you don’t need to display an error dialog if you get one because the Exchange Manager handles this for you.

Object Exchange

Sending Data

For example, [Listing 1.3](#) shows how to send the current draw window from one Palm Powered handheld to another Palm Powered handheld. It is modified from the Beamer example application that is included in the Palm OS SDK.

Listing 1.3 Sending data using Exchange Manager

```
Err SendData(void)
{
    ExgSocketType exgSocket;
    UInt32 size = 0;
    UInt32 sizeSent = 0;
    Err err = 0;
    BitmapType *bmpP;

    // copy draw area into the bitmap
    SaveWindow();
    bmpP = PrvGetBitmap(canvasWinH, &size, &err);
    // Is there data in the field?
    if (!err && size) {
        // important to init structure to zeros...
        MemSet(&exgSocket, sizeof(exgSocket), 0);
        exgSocket.description = "Beamer picture";
        exgSocket.name = "Beamer.pbm";
        exgSocket.length = size;
        err = ExgPut(&exgSocket);
        if (!err) {
            while (!err && sizeSent < size) {
                sizeSent += ExgSend(&exgSocket, bmpP, size, &err);
            }
            ExgDisconnect(&exgSocket, err);
        }
    }
    if (bmpP) MemPtrFree(bmpP);
    return err;
}
```

Sending Multiple Objects

On Palm OS 4.0 and higher, if the exchange library supports it, you can send multiple objects in a single connection. To send multiple objects, do the following:

1. Create and initialize an [ExgSocketType](#) data structure with information about which library to use and the data to be

sent. See “[Initializing the Exchange Socket Structure](#)” for more information. You might also supply a value for the count field to specify how many objects are to be sent.

2. Call [ExgConnect](#) to establish the connection with the exchange library.

3. For each object, do the following:

a. Call [ExgPut](#) to signal the start of a new object.

b. Call [ExgSend](#) multiple times to send the data.

In this function you specify the number of bytes to send, and ExgSend returns the number of bytes that were sent. You may need to call it multiple times if data is remaining to be sent after the first and subsequent calls.

4. Call [ExgDisconnect](#) to end the connection.

A zero (0) return value indicates a successful transmission. However, this doesn’t necessarily mean that the receiver kept the data. If the target application for an object doesn’t exist on the receiving device, the data is discarded; or the user can decide to discard any beamed objects.

The ExgConnect call is optional. Some exchange libraries, such as the IR Library, support the sending of multiple objects but do not support ExgConnect. If ExgConnect returns an error, the first call to ExgPut initiates the connection. You should only continue to send objects if the first ExgPut call succeeds. See [Listing 1.4](#). Libraries that support the ExgConnect call also support sending multiple objects without using ExgConnect.

Listing 1.4 Sending multiple objects

```
Boolean isConnected = false;
err = ExgConnect(&exgSocket);          //optional
if (!err)
    isConnected = true;
if (!err || err == exgErrNotSupported) {
    while (/* we have objects to send */) {
        err = ExgPut(&exgSocket);
        if (!isConnected && !err)
            isConnected = true; //auto-connected on first put.
        while (!err && (sizeSent < size))
            sizeSent += ExgSend(&exgSocket, dataP, size, &err);
    }
}
```

Object Exchange

Sending Data

```
        if (err)
            break;
    }
}
if (isConnected)
    ExgDisconnect(&exgSocket, err);
```

Implementing the Send Command

Starting in Palm OS 4.0, the built-in applications support a Send menu command. The purpose of this command is to allow the user to send data using any available transport mechanism.

The Exchange Manager defines a `_send` URL scheme. The intent is that any exchange library that supports sending is registered for the `_send` scheme. Currently, only the SMS Library is registered for this scheme on release ROMs. When Bluetooth support becomes available, the Bluetooth Library will be registered for this scheme. The IR Library is **not** registered for the `_send` scheme.

To implement the Send command in your application, construct a URL that has the prefix `exgSendPrefix`, and send the data in the normal manner. You can also use the `exgSendBeamPrefix` instead so that the user can select from all exchange libraries registered for either sending or beaming (which includes the IR Library). Both of these prefixes begin with a question mark, causing the Exchange Manager to display a dialog if it finds more than one exchange library registered for the specified schemes.

Currently on a Palm OS 4.0 release ROM, only the SMS Exchange Library supports the `_send` scheme, so using `exgSendPrefix` would not cause the dialog to be displayed. If the user later adds Bluetooth support, the prefix would cause the dialog to be displayed.

NOTE: On debug ROMs, the Local Exchange Library is listed as one of the possible transport mechanisms. This allows you to debug your Send command. The Local Exchange Library is not listed in the Send With dialog on release ROMs.

For an example of how to implement the Send command, see the Memo application example code distributed with the Palm OS SDK.

Receiving Data

To have your application receive data from the Exchange Manager, do the following:

1. Register for the type of data you want to receive. See “[Registering for Data](#)” for more information.
2. Handle the launch code [sysAppLaunchCmdExgAskUser](#) if you want to control the user confirmation dialog that is displayed. See “[Controlling the Exchange Dialog](#)” for more information.
3. Handle the launch code [sysAppLaunchCmdExgPreview](#) if you want to display a preview of the data to be received. See “[Displaying a Preview](#)” for more information.
4. Handle the launch code [sysAppLaunchCmdExgReceiveData](#) to receive the data. See “[Receiving the Data](#)” for more information.
5. If you want, handle [sysAppLaunchCmdGoto](#) to display the record.

Controlling the Exchange Dialog

When the Exchange Manager receives an object and decides that your application is the target for that object, it sends your application a series of launch codes. The first launch code your application receives, in most cases, is [sysAppLaunchCmdExgAskUser](#).

NOTE: In Palm OS 4.0 and higher, the Exchange Manager allows the exchange library to turn off the user confirmation dialog. In this case, your application does not receive the [sysAppLaunchCmdExgAskUser](#) launch code.

The Exchange Manager sends this launch code because it is about to display the exchange dialog, which asks the user to confirm the receipt of data. The launch code is your opportunity to accept the data without confirmation, reject the data without confirmation, or replace the exchange dialog.

Object Exchange

Receiving Data

Responding to this launch code is optional. If you don't respond, the Exchange Manager calls [ExgDoDialog](#) to display the exchange dialog.

On Palm OS 3.5 and higher, the `ExgDoDialog` function allows you to specify that the dialog display a category pop-up list. This pop-up list allows the user to receive the data into a certain category in the database, but the pop-up list is not shown by default. If you want the exchange dialog to display the pop-up list, you must respond to `sysAppLaunchCmdExgAskUser` and call `ExgDoDialog` yourself. Pass a pointer to an `ExgDialogInfoType` structure. The `ExgDialogInfoType` structure is defined as follows:

```
typedef struct {
    UInt16      version;
    DmOpenRef   db;
    UInt16      categoryIndex;
} ExgDialogInfoType;
```

- > version Set this field to 0 to specify version 0 of this structure.
- > db A pointer to an open database that defines the categories the dialog should display.
- <- categoryIndex The index of the category in which the user wants to file the incoming data.

If `db` is valid, the function extracts the category information from the specified database and displays it in a pop-up list. Upon return, the `categoryIndex` field contains the index of the category the user selected, or `dmUnfiledCategory` if the user did not select a category.

If the call to `ExgDoDialog` is successful, your application is responsible for retaining the value returned in `categoryIndex` and using it to file the incoming data as a record in that category. One way to do this is to store the `categoryIndex` in the socket's `appData` field (see [ExgSocketType](#)) and then extract it from the socket in your response to the launch code [sysAppLaunchCmdExgReceiveData](#). See [Listing 1.5](#) for an example.

Listing 1.5 Extracting the category from the exchange socket

```
UInt16 categoryID = (ExgSocketType *)cmdPBP->appData;

/* Receive the data, and create a new record using the
   received data. indexNew is the index of this record. */
if (category != dmUnfiledCategory){
    UInt16 attr;
    Err err;
    err = DmRecordInfo(dbP, indexNew, &attr, NULL, NULL);

    // Set the category to the one the user specified, and
    // mark the record dirty.
    if ((attr & dmRecAttrCategoryMask) != category) {
        attr &= ~dmRecAttrCategoryMask;
        attr |= category | dmRecAttrDirty;
        err = DmSetRecordInfo(dbP, indexNew, &attr, NULL);
    }
}
```

Some of the Palm OS built-in applications (Address Book, Memo, and ToDo) use this method of setting the category on data received through beaming. Refer to the example code provided in the Palm OS SDK for these applications for a more complete example of how to use ExgDoDialog.

When you explicitly call ExgDoDialog, you must set the `result` field of the `sysAppLaunchCmdExgAskUser` launch code's parameter block to either `exgAskOk` (upon success) or `exgAskCancel` (upon failure) to prevent the system from displaying the dialog a second time.

Displaying a Preview

On Palm OS 4.0 and higher, the exchange dialog contains a preview of the data to be received. The preview allows the user to see what the data is. The reason for the preview is that Palm OS 4.0 and higher supports exchange libraries other than the IR Library. When you use the IR Library to beam data to another Palm Powered handheld, the sender and the receiver must be in close contact with one another. Other transport mechanisms do not require the devices to be within close proximity, so the user might not know that the data is being received or why. In this case, the user might need more

Object Exchange

Receiving Data

information about the object being received, so the Exchange Manager displays information about the object in the exchange dialog. Also, some exchange libraries do not transmit information for the exchange socket's description field, so the Exchange Manager must provide another means of supplying the user with information about the data being received.

To display the preview, the Exchange Manager launches the receiving application with the launch code [sysAppLaunchCmdExgPreview](#). Your application does not have to respond to this launch code. If it doesn't, the Exchange Manager displays the first item that it locates in the following list:

- The data's description from the exchange socket's description field
- The filename in the socket's name field
- The receiving application's description as stored in the exchange registry (you pass this description to [ExgRegisterDatatype](#) when registering)
- The MIME type in the socket's type field
- The file extension in the socket's name field

If you want to support a preview that is more elaborate than those in the previous list, handle the `sysAppLaunchCmdExgPreview` launch code.

The launch code's parameter block is an [ExgPreviewInfoType](#) structure. This structure contains the [ExgSocketType](#) structure, an `op` field that describes what type of preview data the Exchange Manager expects, and fields in which to return the data.

To respond to the launch code, do the following:

1. Check the `op` field in the parameter block to see what type of preview data is expected. In most cases, the preview data is a string, but a graphical display might also be requested.
2. Call [ExgAccept](#) to establish a connection with the exchange library.
3. Call [ExgReceive](#) one or more times to receive the data.

In this function, you specify the number of bytes to receive and it returns the number of bytes that were received. You

may need to call it multiple times if data is remaining to be received after the first and subsequent calls.

4. Place the data in the parameter block's `string` field if the `op` field specifies a string preview. If the `op` field specifies a graphical preview, draw the data into the rectangle identified by the parameter block's `bounds` field.
5. Call [ExgDisconnect](#) to end the connection.

A zero (0) return value indicates a successful transmission.

Note that you perform essentially the same steps to preview the data as you do to receive it. The only difference is what you do with the data after you receive it. In response to `sysAppLaunchCmdExgPreview`, you pass the data back to the Exchange Manager and discard it in case the user rejects the data. In response to [sysAppLaunchCmdExgReceiveData](#), you store the data.

For an example of handling the `sysAppLaunchCmdExgPreview` launch code, see the Address Book example application that is distributed with the Palm OS SDK. The `TransferPreview` function handles the launch code.

Receiving the Data

If the Exchange Manager receives `exgAskOk` in response to the exchange dialog or the [sysAppLaunchCmdExgAskUser](#) launch code, the next step is to launch the application with [sysAppLaunchCmdExgReceiveData](#). This launch code tells the application to actually receive the data.

To respond to this launch code, do the following:

1. Call [ExgAccept](#) to accept the connection.
2. Call [ExgReceive](#) one or more times to receive the data.

In this function you specify the number of bytes to receive, and `ExgReceive` returns the number of bytes that were received. You may need to call it multiple times if data is remaining to be received after the first and subsequent calls.

Note that in the socket structure, the `length` field may not be accurate, so in your receive loop you should be flexible in handling more or less data than `length` specifies.

Object Exchange

Receiving Data

3. If you want your application launched again with the [sysAppLaunchCmdGoto](#) launch code, place your application's creator ID in the [ExgSocketType](#)'s `goToCreator` field and supply the information that should be passed to the launch code in the `gotoParams` field. (The [ExgSocketType](#) structure is the `sysAppLaunchCmdExgReceiveData`'s parameter block.)
4. Call [ExgDisconnect](#) to end the connection.

A zero (0) return value indicates a successful transmission.

After your application returns from `sysAppLaunchCmdExgReceiveData`, if the `goToCreator` specifies your application's creator ID and if the exchange library supports it, your application is launched with `sysAppLaunchCmdGoto`. In response to this launch code, your application should launch, open its database, and display the record identified by the `recordNum` field (or `matchCustom` field) in the parameter block. The Exchange Manager always does a full application launch with `sysAppLaunchCmdGoto`, so your application has access to global variables; however, if you also use this launch code to implement the global find facility, you may not have access to global variables in that instance. The example code in [Listing 1.6](#) checks to see if globals are available, and if so, calls `StartApplication` to initialize them.

Listing 1.6 Responding to `sysAppLaunchCmdGoto`

```
case sysAppLaunchCmdGoto:
    if (launchFlags & sysAppLaunchFlagNewGlobals) {
        err = StartApplication();
        if (err) return err;
        GoTo(cmdPBP, true);
        EventLoop();
        StopApplication();
    } else {
        GoTo(cmdPBP, false);
    }
}
```

On Palm OS 4.0 and higher, not all exchange libraries support using the `sysAppLaunchCmdGoto` launch code after the receipt of data.

Also note that because Palm OS 4.0 and higher supports multiple object exchange, there is no guarantee that your application is the one that is launched at the end of a receipt of data. If multiple objects are being received, it is possible for another application to receive data after yours and to set the `goToCreator` field to its own creator ID. In this case, the last application to set the field is the one that is launched.

[Listing 1.7](#) shows a function that receives a data object and sets the `goToCreator` and `goToParams`. This code is taken from the Beamer example application that is distributed with the Palm OS SDK.

Listing 1.7 Receiving a data object

```
static Err ReceiveData(ExgSocketPtr exgSocketP)
{
    Err err;
    MemHandle dataH;
    UInt16 size;
    UInt8 *dataP;
    Int16 len;
    UInt16 dataLen = 0;

    if (exgSocketP->length)
        size = exgSocketP->length;
    else
        size = ChunkSize;
    dataH = MemHandleNew(size);
    if (!dataH) return -1; //
    // accept will open a progress dialog and wait for your receive commands
    err = ExgAccept(exgSocketP);
    if (!err){
        dataP = MemHandleLock(dataH);
        do {
            len = ExgReceive(exgSocketP,&dataP[dataLen], size-dataLen,&err);
            if (len && !err) {
                dataLen+=len;
                // resize block when we reach the limit of this one...
                if (dataLen >= size) {
                    MemHandleUnlock(dataH);
                    err = MemHandleResize(dataH,size+ChunkSize);
                    dataP = MemHandleLock(dataH);
                    if (!err) size += ChunkSize;
                }
            }
        }
    }
```

Object Exchange

Sending and Receiving Databases

```
    }
    while (len && !err);

    MemHandleUnlock(dataH);

    ExgDisconnect(exgSocketP,err); // closes transfer dialog

    if (!err) {
        exgSocketP->goToCreator = beamerCreator;
        exgSocketP->goToParams.matchCustom = (UInt32)dataH;
    }
}
// release memory if an error occurred
if (err) MemHandleFree(dataH);
return err;
}
```

Sending and Receiving Databases

It's common to want to send and receive an entire database using the Exchange Manager. For example, you might want to allow your application's users to share their versions of the PDB file associated with your application by beaming that file to each other.

Sending and receiving a database involves the extra steps of flattening the database into a byte stream when sending and unflattening it upon return.

Sending a Database

To send a database, do the following:

1. Create and initialize an [ExgSocketType](#) data structure with information about which library to use and the data to be sent. See "[Initializing the Exchange Socket Structure](#)" for more information.
2. Call [ExgPut](#) to establish the connection with the exchange library.
3. Call [ExgDBWrite](#) and pass it a pointer to a callback function in your application that it can use to send the database. You make the call to [ExgSend](#) in that function.
4. Call [ExgDisconnect](#) to end the connection.

The `ExgDBWrite` function takes as parameters the local ID and card number of the database to be sent and a pointer to a callback function. You may also pass in the name of the database as it should appear in a file list and any application-specific data you want passed to the callback function. In this case, you would pass the pointer to the exchange socket structure as the application-specific data. If you need any other data, create a structure that contains the exchange socket and pass a pointer to that structure instead.

The write callback function is called as many times as is necessary to send the data. It takes three arguments: a pointer to the data to be sent, the size of the data, and the application-specific data passed as the second argument to `ExgDBWrite`.

[Listing 1.8](#) shows an example of how to send a database. The `SendMe` function looks up the database creator ID and card number and passes it to the `SendDatabase` function. The `SendDatabase` function creates and initializes the exchange socket structure and then passes all that information along to the `ExgDBWrite` function. The `ExgDBWrite` function locates the database in the storage heap, translates it into a stream of bytes and passes that byte stream as the first argument to the write callback function `WriteDBData`. `WriteDBData` forwards the exchange socket and the data stream to the `ExgSend` call, sets its size parameter to the number of bytes sent (the return value of `ExgSend`), and returns any error returned by `ExgSend`.

Listing 1.8 Sending a database

```
// Callback for ExgDBWrite to send data with Exchange Manager
Err WriteDBData(const void* dataP, ULONG* sizeP, void* userDataP)
{
    Err err;

    *sizeP = ExgSend((ExgSocketPtr)userDataP, (void*)dataP, *sizeP, &err);
    return err;
}

Err SendDatabase (Word cardNo, LocalID dbID, CharPtr nameP,
CharPtr descriptionP)
{
    ExgSocketType exgSocket;
```

Object Exchange

Sending and Receiving Databases

```
Err err;

// Create exgSocket structure
MemSet(&exgSocket, sizeof(exgSocket), 0);
exgSocket.description = descriptionP;
exgSocket.name = nameP;

// Start an exchange put operation
err = ExgPut(&exgSocket);
if (!err) {
    err = ExgDBWrite(WriteDBData, &exgSocket, NULL, dbID, cardNo);
    err = ExgDisconnect(&exgSocket, err);
}
return err;
}

// Sends this application
Err SendMe(void)
{
    Err err;

    // Find our app using its internal name
    LocalID dbID = DmFindDatabase(0, "Beamer");

    if (dbID)
        err = SendDatabase(0, dbID, "Beamer.prc", "Beamer application");
    else
        err = DmGetLastError();
    return err;
}
```

Note that there is nothing about `ExgDBWrite` that is tied to the Exchange Manager, so it may be used to send a database using other transport mechanisms as well. For example, if you wanted to transfer a database from your Palm Powered handheld to your desktop PC using the serial port, you could use `ExgDBWrite` to do so.

Receiving a Database

The Launcher application receives databases with the `.prc` or `.pdb` file extension. If you want your application to be launched when the database is received, you can use a different extension and handle receiving the database within your application. For example, a book reader application might want to be launched when the user is

beamed a book. In this case, the book reader application might use an extension such as .bk for the book databases.

You receive a database by responding to the same launch codes that you do for receiving any other data object (see “[Receiving Data](#)”); however, your response to the [sysAppLaunchCmdExgReceiveData](#) launch code is a little different:

1. Call [ExgAccept](#) to accept the connection.
2. Call [ExgDBRead](#) and pass it a pointer to a callback function in your application that it can use to read the database. You make the call to [ExgReceive](#) in that function.
3. Call [ExgDisconnect](#) to end the connection.

The ExgDBRead function takes as parameters two pointers to callback functions. The first callback function is a function that is called multiple times to read the data. The second function is used if the database to be received already exists on the device.

Requesting Data

On Palm OS 4.0 and higher, some exchange libraries allow you to request data from a remote device through a call to [ExgGet](#). You can use [ExgGet](#) to implement two-way communications between two Palm™ devices.

This section describes how to use the Exchange Manager to request data. It covers:

- [Sending a Get Request for a Single Object](#)
- [Responding to a Get Request](#)
- [Two-Way Communications](#)
- [Requesting a URL](#)

Sending a Get Request for a Single Object

To request data from a remote device, do the following:

1. Create and initialize an exchange socket structure ([ExgSocketType](#)) as described in “[Initializing the Exchange Socket Structure](#)” section. The data structure should identify

Object Exchange

Requesting Data

the exchange library and the type of data that your application wants to receive.

2. Call [ExgGet](#) to establish the connection and request the data.

In response, the exchange library establishes a connection with the remote device, and upon return has data that your application should receive. If the remote device is a Palm Powered handheld, the exchange library obtains this data from an application on the remote side using the process described in the “[Responding to a Get Request](#)” section.

3. Call [ExgReceive](#) one or more times to receive the data.
4. Call [ExgDisconnect](#) to end the connection.

Responding to a Get Request

When the Exchange Manager on the remote device receives the get request, it launches the appropriate application with the launch code [sysAppLaunchCmdExgGetData](#).

Your response to the `sysAppLaunchCmdExgGetData` launch code should be to send the requested data:

1. Call [ExgSend](#) one or more times.
2. Call [ExgDisconnect](#) when finished.

See the “[Sending a Single Object](#)” section for more information.

Two-Way Communications

You can use [ExgGet](#) and [ExgPut](#) in combination with the [ExgConnect](#) call to have your application perform two-way communication. For example, you may want to implement two-way communication in a multiuser game.

In such a situation, one device acts as a client and the other acts as a server. The client calls `ExgConnect`, which tells the exchange library that a connection is established to perform multiple operations, such as the sending of multiple objects. The client then calls `ExgGet` or `ExgPut` repeatedly and calls [ExgDisconnect](#) when finished. On the server device, the appropriate application is launched for each of these requests. The server also calls

`ExgDisconnect` when it is done sending or receiving each object. The swapping of client and server roles is not supported.

Remember that not all exchange libraries support `ExgConnect` and `ExgGet`. If either one of these returns an error, your application should assume that this feature is not available.

Requesting a URL

In addition to requesting data with an [ExgGet](#) call, you can request a URL with a [ExgRequest](#) call on Palm OS 4.0 and higher. The idea behind the `ExgRequest` call is to follow the model of pull technology. You could, for example, implement a web browser if you had an exchange library that supported the HTTP protocol. You could then send an `ExgRequest` call with an exchange socket containing a URL such as `http://www.palmos.com` and receive the web page in response.

The fundamental differences between `ExgRequest` and `ExgGet` are:

- `ExgRequest` does not automatically send the data back to the application that requested it. With `ExgRequest`, when the exchange library receives the requested data, it has the Exchange Manager send it to the default application for that data type.
- Applications can register for URLs sent using `ExgRequest`. `ExgRequest` first looks for an exchange library that handles the URL scheme. If it cannot find one, it looks for an application instead. If it finds an application, it launches it with the [sysAppLaunchCmdGoToURL](#) launch code.

For example, the iMessenger application distributed with the Palm OS SDK registers for the `mailto` URL scheme. If another application wants to implement an e-mail command, it could do so by calling `ExgRequest` and passing an exchange socket with a URL that begins with `mailto`. In response to this command, the Exchange Manager launches the iMessenger application, allowing the user to compose the email.

Sending and Receiving Locally

Most of this chapter has described how to use the Exchange Manager to send data to a remote device and receive data from a remote device.

You may also use the Exchange Manager to exchange data with other applications on the local device. To do so, use the Local Exchange Library. You might want to do so in the following circumstances:

- You might have an application that creates some sort of event in the Datebook application. Your users might have an application that they use in place of the built-in Datebook. To ensure that the appointment is sent to the user's chosen application, you can send that data as a vCalendar object using the Local Exchange Manager. This way, whichever application is the default in the Exchange Manager registry is the one that receives your vCalendar.
- You could use the preview feature of the Exchange Manager to have another application display data for you. As described in the "[Displaying a Preview](#)" section, an application can be launched with the `sysAppLaunchCmdExgPreview` launch code to display a preview of the data it is registered to receive. You could use this feature in your own application to display data your application does not recognize. Suppose your application has a GIF and wants to display it in a dialog. It could use the Local Exchange Library to send that GIF to a graphics application on the local device, which in response draws the preview into the bounds of a rectangle you provide.
- Your application receives compound data objects, such as e-mail messages that contain attachments intended for other applications. As described in the "[Registering to Receive Unwrapped Data](#)" section, exchange libraries can "unwrap" a compound object and deliver the objects it contains directly; however, doing so is the exception the rule.

It's much more common for the e-mail message to be sent to the e-mail application and have the attachments delivered to the appropriate applications only when the user requests it. In response to a user request, the e-mail application extracts

the attached object and uses the Local Exchange Library to send it to the application that should receive it.

- Your application exchanges data with a remote device, and you want to debug the code that interacts with the Exchange Manager. In this case, using the Local Exchange Library causes your application to send data in loopback mode, where it is also the recipient of the data.

To use the Local Exchange Library, do the following:

1. Use a URL in the name field of the [ExgSocketType](#) structure to identify the Local Exchange Library. Begin the URL with the constant string `exgLocalPrefix`.

The Exchange Manager only supports URLs on Palm OS 4.0 and higher. On Palm OS 3.X devices, set the `localMode` flag to 1 to interact with the Local Exchange Library instead of the IR Library.

2. If you want to suppress the exchange dialog or if you want to perform a preview operation, create and initialize an [ExgLocalSocketInfoType](#) structure and assign it to the socket's `socketRef` field.

```
typedef struct {
    Boolean freeOnDisconnect;
    Boolean noAsk;
    ExgPreviewInfoType *previewInfoP;
    ExgLocalOpType op;
    FileHand tempFileH;
} ExgLocalSocketInfoType;
```

where the following are parameters you might want to set:

| | |
|-------------------------------|---|
| <code>freeOnDisconnect</code> | Whether the structure is freed when the <code>ExgDisconnect</code> call is made. The default is <code>true</code> . In general, code that allocates a structure should be responsible for freeing that structure. Therefore, if you have allocated <code>ExgLocalSocketInfoType</code> , you should set this field to <code>false</code> and explicitly free the structure when you are finished with it. |
|-------------------------------|---|

Object Exchange

Interacting with the Launcher

| | |
|---------------------------|--|
| <code>noAsk</code> | Set to <code>true</code> to disable the display of the exchange dialog. If you want to, for example, create a <code>vCalendar</code> object and send it to the datebook application in response to a user command, you probably want to set <code>noAsk</code> to <code>true</code> so that the user does not have to confirm the receipt of the data they just requested you to send. |
| <code>previewInfoP</code> | A pointer to an ExgPreviewInfoType structure, used to display a preview of the data. If you wanted to simply use another application to help display data, you would create and initialize this structure. |

All other fields are set by the Local Exchange Library. If you don't create this structure, the library does it for you; therefore, you only need to create this structure if you want to supply non-default values for the `noAsk` or `previewInfoP` fields.

3. You can suppress the display of the progress dialogs that the exchange libraries typically display by setting the `noStatus` field of the `ExgSocketType` structure to `true`.
4. Send and receive data in the normal manner. See "[Sending Data](#)" and "[Receiving Data](#)" for details.

Interacting with the Launcher

On Palm OS 4.0 and higher, when you beam an application from the Launcher, other databases can be automatically beamed with it. If the application has an associated overlay database, the overlay is beamed along with the application. You do not have to perform any extra work to allow this to happen.

Overlay database support begins in Palm OS 3.5; however, if you beam an application from the Palm OS 3.5 Launcher application, it does not beam the overlay.

In addition to beaming overlays, you can set up a record database so that the Launcher beams it along with the application database and the overlay. For example, a dictionary application might have its

dictionary data in an associated database. When a user beams the dictionary application to another user, the dictionary data should be beamed along with the application itself. To allow this to happen, you set the bit `dmHdrAttrBundle` in the database's attributes, as shown here:

```
DmDatabaseInfo(cardNo, dbID, NULL, &attributes,  
              NULL, NULL, NULL, NULL, NULL, NULL, NULL,  
              NULL, NULL);  
attributes |= dmHdrAttrBundle;  
DmSetDatabaseInfo(cardNo, dbID, NULL,  
                  &attributes, NULL, NULL, NULL, NULL, NULL,  
                  NULL, NULL, NULL, NULL);
```

If you beam an application plus databases to a device running Palm OS 4.0 or higher, the user sees a single confirmation message. If you beam the application to a device running Palm OS 3.X, the device receives only the application database and displays an alert saying that it cannot receive the other databases.

Object Exchange

Summary of Exchange Manager

Summary of Exchange Manager

Exchange Manager Functions

Sending Data

[ExgSend](#)

[ExgDBWrite](#)

[ExgPut](#)

Receiving Data

[ExgReceive](#)

[ExgDBRead](#)

[ExgAccept](#)

Registering for Data

[ExgRegisterDatatype](#)

[ExgRegisterData](#)

[ExgSetDefaultApplication](#)

Requesting Data

[ExgGet](#)

[ExgRequest](#)

Connecting and Disconnecting

[ExgDisconnect](#)

[ExgConnect](#)

Displaying the Exchange Dialog

[ExgDoDialog](#)

Obtaining Registry Information

[ExgGetTargetApplication](#)

[ExgGetRegisteredTypes](#)

[ExgGetRegisteredApplications](#)

[ExgGetDefaultApplication](#)

Querying the Exchange Library

[ExgControl](#)

For Exchange Library Use Only

[ExgNotifyReceive](#)

[ExgNotifyGoto](#)

[ExgNotifyPreview](#)

Exchange Libraries

This chapter describes how to implement an exchange library. It covers the following topics:

- [About Exchange Libraries](#)
- [Exchange Library Components](#)
- [Implementing an Exchange Library](#)

Prior to implementing an exchange library, you should have a clear understanding of how the Exchange Manager operates. See [Chapter 1, “Object Exchange,”](#) on page 1 for an in-depth discussion on the Exchange Manager. Also see [Chapter 59, “Exchange Library,”](#) on page 1179 of the *Palm OS Programmer’s API Reference* for a detailed description of the functions that must be implemented in each exchange library.

About Exchange Libraries

Exchange libraries are Palm OS® shared libraries that act as “plugins” to the [Exchange Manager](#). They deal with protocols and communication devices and allow Palm OS applications to import and export data objects without regard to the transport mechanism. For example, one exchange library always available to Palm Powered™ handhelds implements the IrDA protocol, IrOBEX. This allows applications to beam objects by way of infrared from one Palm Powered handheld to another.

The following can take advantage of the Exchange Library API:

- Removable storage cards
- Notification services
- Email attachments
- Web (HTTP/FTP/CTP/WAP) exchange
- HotSync® simplified import and export

Exchange Libraries

About Exchange Libraries

Exchange Libraries, Exchange Manager, and Applications


The Exchange Manager is a high-level tool for applications to use. An exchange library is a set of routines that handle the implementation specifics of a particular transport. Typically, exchange library functions are called from the Exchange Manager and are not directly accessed by applications. Applications wanting to send or receive data call the functions provided by the Exchange Manager API, many of which do little more than invoke the corresponding function in the appropriate exchange library.

Exchange libraries also make calls back into the Exchange Manager. For example, an exchange library would call [ExgNotifyReceive](#) to have the Exchange Manager deliver objects received by the exchange library.

No one component involved with data exchange (Exchange Manager, exchange library, or application) is complete in itself. However, applications and exchange libraries should be written so the user experiences all interaction as a single seamless interface, even though what takes place is really a complex interaction between different pieces of code.

[Figure 2.1](#) illustrates the relationship between applications, the Exchange Manager, and the exchange libraries within two devices that are in communication.

Figure 2.1 Object exchange using Exchange Manager



The following table lists the division of responsibilities between Palm OS applications, the Exchange Manager, and the exchange libraries.

Table 2.1 Division of responsibility for data object exchange

| Palm OS Application | Exchange Manager | Exchange Library |
|---|--|--|
| Creates, edits, and stores data | Maintains registry of exchange libraries | Sends data to or receives data from other devices |
| Converts data to and from the interchange formats | Maintains registry of applications that can receive data | Displays a dialog to get addressing information from user |
| Views or describes data | Passes send and receive requests to appropriate exchange library Displays a dialog asking if user wants to receive data | Displays status and error dialogs, possibly using the Progress Manager |

Palm OS Exchange Libraries

The Exchange Manager was introduced in Palm OS 3.0 and was significantly enhanced in Palm OS 4.0. Because of this, the various exchange libraries require different versions of the OS. [Table 2.2](#) lists the minimum OS version required by various exchange libraries.

Table 2.2 Version of Palm OS required by exchange libraries

| Exchange Library | Minimum Palm OS Version |
|-------------------------|--------------------------------|
| IR Library (IrDA) | Palm OS 3.0 |
| Local Exchange Library | Palm OS 4.0 |

Exchange Libraries

Exchange Library Components

Table 2.2 Version of Palm OS required by exchange libraries

| Exchange Library | Minimum Palm OS Version |
|--------------------------------------|-------------------------|
| SMS Library (Short Messaging System) | Palm OS 4.0 |
| Bluetooth Library ^a | Palm OS 4.0 |

a. Although not present in Palm OS 4.0, Palm plans to provide a Bluetooth Library soon after Palm OS 4.0 ships.

Included with the Palm OS SDK version 4 is the HostTransfer sample exchange library which can be used as a starting point when creating your own exchange libraries.

Exchange Library Components

This section describes the components that make up an exchange library. The topics covered are:

- [The Exchange Library API](#)
- [Dispatch Table](#)

The Exchange Library API

The Palm OS [Exchange Library](#) API specifies the minimum set of functions that all exchange libraries must implement. These functions can be classified into three major categories: functions that must be included in all shared libraries, functions that establish a connection and send and receive data, and miscellaneous support functions.

Standard Shared Library Functions

Any Palm OS shared library must implement open, close, sleep, and wake functions.

- [ExgLibOpen](#)
- [ExgLibClose](#)
- [ExgLibSleep](#)
- [ExgLibWake](#)

Functions That Send and Receive Data

These functions do the work of establishing a connection and sending and receiving data.

- [ExgLibAccept](#)
- [ExgLibConnect](#)
- [ExgLibDisconnect](#)
- [ExgLibGet](#)
- [ExgLibPut](#)
- [ExgLibReceive](#)
- [ExgLibRequest](#)
- [ExgLibSend](#)

Note that each of these corresponds directly to an Exchange Manager function; in most cases the Exchange Manager simply calls the corresponding exchange library function.

Support Functions

This category consists of functions that provide information about your exchange library and that handle events.

- [ExgLibControl](#)
- [ExgLibHandleEvent](#)

Although each of the functions in these three categories must be present in every exchange library, depending on the specific requirements of the exchange library some of them can simply return `errNone` or `exgErrNotSupported`.

As with any shared library, the order in which the functions appear in the exchange library's dispatch table identifies the functions in the library. This order is specified in `ExgLib.h`. Because it's the function's position in the dispatch table and not its name that is important, the actual function names used in a given exchange library may be different from those specified in `ExgLib.h`. In fact, you'll likely want to use function names that are unique to your shared library, as the Host Transfer library does with such functions as `HostTransferLibPut`, `HostTransferLibSend`, and `HostTransferLibDisconnect`. By using function names specific to your exchange library, you can link your functions into the Mac

Exchange Libraries

Exchange Library Components

Simulator and debug with it. If you use the function names defined in `ExgLib.h` for your functions, you'll get a link error because the Simulator uses those names for stub functions which call your functions.

Beyond the functions listed above, additional library-specific functions must appear in the exchange library's dispatch table after `exgLibTrapLast`.

Dispatch Table

The dispatch table is a map used by the Palm OS to find the functions in the exchange library. At link time, references to the exchange library functions are resolved to a system trap by way of the `SYS_TRAP` macro. At runtime, when an exchange library function is called, a trap occurs and the trap finds the function in its library dispatch table and computes the function's offset into the code resource of the exchange library. A JMP instruction to the function's address is made, causing the function to be executed.

NOTE: The structure of the dispatch table for exchange libraries is the same as that of shared libraries. Exchange libraries must do everything shared libraries must do, plus they must register with the Exchange Manager. This gives applications access to their services by way of the Exchange Manager APIs such as [ExgPut](#).

A sample dispatch table source file, `HostTransferDispatch.c`, is provided with the OS SDK. [Listing 2.1](#) provides a sample of the dispatch table contained within this file (some parts are omitted for clarity).

Listing 2.1 HostTransferDispatch.c

```
...
void *PrvHostTransferDispatchTable(void);
...
extern Err PrvInstallHostTransferDispatcher(UINT16 refNum, SysLibTblEntryType
*entryP);
...
Err __Startup__(UINT16 refNum, SysLibTblEntryType *entryP)
{
```

```
    return PrvInstallHostTransferDispatcher(refNum, entryP);
}
...
asm void *PrvHostTransferDispatchTable(void)
{
    LEA    @Table, A0                // table ptr
    RTS                                // exit with it

@Table:
    DC.W   @Name
    DC.W   (kOffset)                // Open
    DC.W   (kOffset+(1*4))          // Close
    DC.W   (kOffset+(2*4))          // Sleep
    DC.W   (kOffset+(3*4))          // Wake
    // Start of the exchange library
    DC.W   (kOffset+(4*4))          // HostTransferLibHandleEvent
    ...
    DC.W   (kOffset+(12*4))         // HostTransferLibControl
    DC.W   (kOffset+(13*4))         // HostTransferLibRequest

@GotoOpen:
    JMP    HostTransferLibOpen
@GotoClose:
    JMP    HostTransferLibClose
@GotoSleep:
    JMP    HostTransferLibSleep
@GotoWake:
    JMP    HostTransferLibWake

@GotoHandleEvent:
    JMP    HostTransferLibHandleEvent
    ...
@GotoOption:
    JMP    HostTransferLibControl
@GotoCheck:
    JMP    HostTransferLibRequest

@Name:
    DC.B   HostTransferName
}
...
```

The last entry in the dispatch table is the name of the exchange library. This must match the name of the database containing the exchange library, and on the simulator, it must end with *"-crið"*,

Exchange Libraries

Exchange Library Components

where *crid* is the creator ID. For example, the Host Transfer library uses "HostTransfer Library-HXfr".

The code segment must be locked so that the dispatch table itself, and the routine addresses in it, will remain valid. The library's database is automatically protected so that it cannot be deleted.

NOTE: The system's shared library table has a slot for library globals for each loaded library. The start-up routine should at least zero this field, if not actually allocate the globals. Some libraries allocate a small structure with an `openCount` and leave the larger allocation for later, when the library is opened by way of the library's `Open()` entry point. In this case, the small structure has a reference to the larger one.

The code resource of an exchange library must start with a routine that sets up the dispatch table. This routine must be named `__Startup__`. The prototype for this function is:

```
Err __Startup__(UInt16 refNum,
               SysLibTblEntryType *entryP)
```

Usually, `__Startup__` consists of a one line call in a `MyLibDispatch.c` file that calls the actual setup routine in a corresponding `MyLib.c` file. For example, in the `HostTransferDispatch.c` sample file provided with the OS SDK the following is used to install the HostTransfer dispatch table:

```
extern Err PrvInstallHostTransferDispatcher(UInt16 refNum,
                                             SysLibTblEntryType *entryP);
...
Err __Startup__(UInt16 refNum, SysLibTblEntryType *entryP)
{
    return PrvInstallHostTransferDispatcher(refNum, entryP);
}
...
```

`__Startup__` is called to set up the dispatch table when a call to [SysLibInstall](#) or [SysLibLoad](#) is made. For example:

```
SysLibInstall(PrvInstallHostTransferDispatcher,
              &refNum);
```


[Listing 2.2](#) shows how the HostTransfer dispatch table installer function is implemented. This function can be found in the OS SDK sample file `HostTransferLib.c`. The dispatch table installer function is responsible for making the system's library table entry (`entryP`) point to the dispatch table. For example:

```
entryP->dispatchTblP =  
    (MemPtr *)PrvHostTransferDispatchTable();
```

The dispatch installer routine generally does a bit of initialization as well.

Listing 2.2 Host transfer dispatch table installer function

```
Err PrvInstallHostTransferDispatcher(UINT16 refNum, SysLibTblEntryType *entryP)  
{  
    Err err;  
    HostTransferGlobalsType *gP;  
    UInt32 value;  
    Char macro[14];  
  
    // Must be 4.0 or greater  
    err = FtrGet(sysFtrCreator, sysFtrNumROMVersion, &value);  
    if (err || value < kVersion4_0) return -1;  
  
    // Allocate library globals and store pointer to them in the system's  
    // library table  
    gP = MemPtrNew(sizeof(HostTransferGlobalsType));  
    ErrFatalDisplayIf(!gP, "No memory for globals");  
    if (gP)  
    {  
        MemPtrSetOwner(gP, 0);  
        MemSet(gP, sizeof(HostTransferGlobalsType), 0);  
        gP->refNum = refNum;    // make self reference  
        entryP->globalsP = gP;  
    }  
  
    // Install pointer to our dispatch table in system's library table  
    entryP->dispatchTblP = (MemPtr *)PrvHostTransferDispatchTable();  
  
    // Check if we're running on the simulator or emulator. On a real device,  
    // there's no host so we don't register this library with the Exchange  
    // Manager. In this case, we should really abort the library installation  
    // altogether, but this demonstrates how exchange libs can change their  
    // registration status.  
    #if EMULATION_LEVEL == EMULATION_NONE
```

Exchange Libraries

Implementing an Exchange Library

```
    if (FtrGet('pose', 0, &value) != ftrErrNoSuchFeature)
#endif
    {
        Char description[exgTitleBufferSize + 1];
        UInt16 descriptionSize = sizeof(description);
        Err err;

        // Get the title of the library
        err = HostTransferLibControl(refNum, exgLibCtlGetTitle, &description,
            &descriptionSize);
        if (! err)
        {
            // Register this library with the Exchange Manager
            err = ExgRegisterDatatype(HostTransferCreator, exgRegSchemeID,
                kHostTransferScheme "\t" exgSendScheme, description, 0 /*flags*/);
        }
    }

    // Add a magic macro to initiate ExgRequest
    StrCopy(macro, "\x01" "0117" "0000" "0408");
    // virtualkeycode,vchrIrReceive,refnum,libEvtHookKeyMask
    macro[7] = PrvHexToAscii((refNum>>4) & 0x0f); // put refnum into string as
hex
    macro[8] = PrvHexToAscii(refNum & 0x0f);
    PrvDeleteExistingMacro(".r");
    GrfAddMacro(".r", (UInt8 *)macro, 13);

    return err;
}
```

Implementing an Exchange Library

In order to work with the Palm OS Exchange Manager, an exchange library must implement a required set of functions and must register with the Exchange Manager.

Required Functions

Exchange libraries contain functions to handle implementation specifics of a particular transport plus the functions required by the [Exchange Library](#) API. Functions required to handle transport-specific tasks or other tasks that aren't specific to the Exchange Library API are outside the scope of this document. In general, however, other functions required by the exchange library could

include tasks such as polling devices, handling interrupts, or checking for user input.

Depending on the application, the exchange library's requirements may be send only, receive only, or both. At a minimum, when sending objects, [ExgLibPut](#), [ExgLibSend](#), and [ExgLibDisconnect](#) are typically required; for receiving objects, [ExgLibAccept](#), [ExgLibReceive](#), and [ExgLibDisconnect](#) are needed. See [Chapter 59, "Exchange Library,"](#) on page 1179 of the *Palm OS Programmer's API Reference* for a detailed description of each exchange library function.

Implementing ExgLibAccept

There are two situations in which an application calls the Exchange Manager's [ExgAccept](#) function:

- The application wants to initiate a connection to receive data, which it does in response to `sysAppLaunchCmdExgReceiveData`.
- The application wants to initiate a connection to receive a preview of the data, which it does in response to `sysAppLaunchCmdExgAskUser`.

The Exchange Manager in turn calls [ExgLibAccept](#).

When previewing data, you must buffer incoming data. Your `ExgLibAccept` function should observe the preview flag and rewind the buffer, preparing for non-destructive read. When it is called again without the preview flag, it should rewind again, this time preparing for destructive read.

`ExgLibAccept` must update any progress dialogs to indicate that data is being accepted, or received, into an application.

Handling Connection Errors

[ExgLibConnect](#) can be used by exchange libraries as a convenient place to put code that needs to be executed prior to the first [ExgLibPut](#) call. Many exchange libraries don't support `ExgLibConnect`, however, instead establishing a connection in the initial call to `ExgLibPut`. If your library doesn't need to support `ExgLibConnect`, your implementation of this function should simply return `errNone`.

Exchange Libraries

Implementing an Exchange Library

If your exchange library doesn't support `ExgLibConnect` and an error occurs during the initial call to `ExgLibPut`, your implementation of `ExgLibPut` should clean up after itself; it should not count on [ExgLibDisconnect](#) being called. If the initial call to `ExgLibPut` succeeds, however, cleanup of subsequent errors can be done in `ExgLibDisconnect`.

If your exchange library does support `ExgLibConnect` and an error occurs during a call to it, `ExgLibConnect` should clean up after itself. Cleanup of errors that occur after a successful call to `ExgLibConnect`, however, can be delegated to `ExgLibDisconnect`.

Finally, if your exchange library supports `ExgLibConnect` but the application doesn't call it prior to calling `ExgLibPut`, the situation is as if your library didn't implement `ExgLibConnect`: if an error occurs during the initial call to `ExgLibPut` your implementation of `ExgLibPut` should clean up after itself, while if the initial call to `ExgLibPut` succeeds you can clean up after any subsequent errors in `ExgLibDisconnect`.

Note that you must support `ExgLibConnect` if your exchange library supports two-way communication as discussed in "[Two-Way Communications](#)" on page 30.

Buffering Data

Data can be sent by the exchange library as it receives it by using [ExgLibSend](#) calls or by buffering the data and sending it in response to an [ExgLibDisconnect](#) call. Buffering has some advantages. For example, the communication stack does not have to share cycles with the sending or receiving application and the communication hardware is on for the shortest possible time, conserving battery power. One drawback is that buffering requires extra storage that could be problematic if the amount of data exchanged is large.

Registering with the Exchange Manager

Exchange libraries, like applications, must register with the Exchange Manager for the object types they are to receive. Exchange libraries typically register for two URL schemes, one that is used to uniquely identify the exchange library, and one for how it is used.

For example, the IR library registers for “_irobex”, which identifies the specific protocol, and for “_beam” which makes it accessible from the Beam command. The Host Transfer sample exchange library registers for “_host” and “_send”. The latter registration makes it accessible from the Send command. Most exchange libraries will probably want to register for the “_send” scheme. These URL schemes all start with an underscore to avoid conflicting with standard URL schemes like “http” and “mailto”. See [Table 1.3](#) in [Chapter 1](#), “[Object Exchange](#),” on page 1 for the supported URL schemes.

Summary of Exchange Library

Exchange Library Functions

Handling the Connection

[ExgLibConnect](#)

[ExgLibAccept](#)

[ExgLibDisconnect](#)

[ExgLibPut](#)

Requesting Data

[ExgLibGet](#)

[ExgLibRequest](#)

Transferring Data

[ExgLibReceive](#)

[ExgLibSend](#)

Querying the Exchange Library

[ExgLibControl](#)

Handling Events

[ExgLibHandleEvent](#)

Required Shared Library Functions

[ExgLibOpen](#)

[ExgLibSleep](#)

[ExgLibClose](#)

[ExgLibWake](#)

Personal Data Interchange

The Palm OS® provides the PDI library API for exchanging Personal Data Interchange (PDI) information with other devices and media. This chapter contains the following sections that describe how to use the Palm OS PDI library:

- [About Personal Data Interchange](#) briefly introduces the PDI standard and provides links to sources of more complete information.
- [About the PDI Library](#) describes how the Palm OS PDI library implements PDI reader and writer objects for exchanging information.
- [Using the PDI Library](#) describes how to use the functions in the PDI library.
- [Using UDA for Different Media](#) describes how you can use the Unified Data Access (UDA) Manager to access data from different media in your PDI reader or writer.
- [Using a PDI Reader - An Example](#) provides a detailed walk-through of a code segment that creates a PDI reader and then uses it to parse vCard information.
- [Using a PDI Writer - An Example](#) provides a detailed walk-through of a code segment that creates a PDI writer and then uses it to generate vCal information.

For detailed information about the PDI library data types, constants, and functions, see [Chapter 78, “Personal Data Interchange Library”](#) in the *Palm OS SDK Reference*.

The PDI reader and writer objects make use of the United Data Access (UDA) Manager to manage input and output data streams. “[Using UDA for Different Media](#)” on page 73 provides an overview of using the UDA Manager. The reference information for UDA functions is in [Chapter 79, “Unified Data Access Manager,”](#) on page 1745 in *Palm OS Programmer’s API Reference*.

About Personal Data Interchange

Personal data interchange involves the exchange of information using a communications medium. The Palm OS PDI Library facilitates the exchange of information using standard **vObjects**, including data formatted according to **vCard** and **vCal** standards.

The vObject standards are maintained by a group known as the versit consortium, which consists of individuals from a number of companies and institutions. The best information about the PDI standards can be found at the consortium's web site:

<http://www.imc.org/pdi/>

These standards are finding increased use in a number of computers and hand-held devices that wish to exchange personal data such as business card and calendar information.

The PDI Library provides a `PdiReaderType` object for reading vObjects from an input stream, and a `PdiWriterType` object for writing vObjects to an output stream. The input streams and output streams can be connected to various data sources.

About vObjects

This section provides a brief overview of vObject standards. Two common vObject types are vCards and vCals:

- vCards are used to exchange virtual business card information electronically. Each vCard can include a large variety of personal and business information about an individual, including name, address, and telecommunications numbers.
- vCals are used to exchange virtual calendaring and scheduling information electronically. Each vCal can include:
 - vEvent objects, each of which represents a scheduled amount of time on a calendar
 - vTodo objects, each of which defines an action item or assignment

Overview of vObject Structure

This section provides a brief overview of vObject standards, including the vCard and vCal standards. Each vObject standard provides the same, basic organizational structure:

- Each vObject is a collection of one or more property definitions.
- Each property definition contains a name, a value, and an optional collection of property parameter definitions.
- Each property parameter definition contains a name and a value. Each parameter value qualifies the property definition with additional information.
- A property value can be structured to contain multiple values. The values are typically separated with commas or semicolons.

The vObject standards also allow developers to add custom extensions. All vObject readers that conform to the standard, including the `PdiReaderType` object, can read these extensions, though not all readers will act upon the information contained in them.

Each property has the following syntax:

```
PropertyName [';' Parameters] ':' PropertyValue
```

Note that property and parameter names are case insensitive.

[Listing 3.1](#) shows a typical vCard definition.

Listing 3.1 Example of a vCard definition

```
BEGIN:VCARD
VERSION:2.1
N:Smith, John;M.;Mr.; Esq.
TEL;WORK;VOICE; MSG:+1 (408) 555-1234
TEL;CELL:+1 (408) 555-4321
TEL;WORK;FAX:+1 (408) 555-9876
ADR;WORK;PARCEL;POSTAL;DOM:Suite 101;1 Central St.;Any
Town;NC;28654
END:VCARD
```

Personal Data Interchange

About Personal Data Interchange

Each line in [Listing 3.1](#) is a property definition, with the exception of the next to last line, which is a continuation of the ADR property definition, and begins with white space. Each property definition is delimited by a CR/LF sequence.

The BEGIN, VERSION, and END lines are examples of simple property definitions.

The N (Name) property has a structured value. The components of the name are separated by semicolons.

Each TEL (Telephone) property has parameters that qualify the kind of telephone number that is being specified.

The ADR (Address) property has parameters and a structured value.

NOTE: The vObject specifications also allow long lines of text to be **folded**. This means that wherever you can have white space in a property definition, you can insert a CR/LF followed by white space, as shown in the next to last line in [Listing 3.1](#). When the vObject reader finds a CR/LF followed by white space, it **unfolds** the text back into one long line.

Grouping vObjects

You can specify multiple vObjects in a single vObject data stream. You can also specify a vObject as the value of a property; for example, you can include a vCard as the value of the ADR property of another vCard.

Grouping Properties

You can specify a name for a group of related properties within a vObject. The name is a single character that you use as a prefix to each property in the group.

One use of this facility is to group a comment that describes a property with the property to keep the two together. For example, the following creates a group named G that includes a vCard home telephone property with a comment property:

```
G.TEL;HOME:+1 (831) 555-1234
G.Note: This is my home office number.
```

Encodings

The default encoding for vObject properties is 7-bit. You can override this encoding for individual property values by using the `ENCODING` parameter. You can specify various encoding values, including `BASE64`, `QUOTED-PRINTABLE`, and `8-BIT`.

Character Sets

The default character set for vObject properties is ASCII. You can override the character set for individual property values by using the `CHARSET` parameter. You can specify any character set that has been registered with the Internet Assigned Numbers Authority (IANA). For example, to specify the Latin/Hebrew encoding, you would use the value `ISO-8859-8`.

Finding More Information

For a complete description of the vObject specifications, visit the versit consortium's web site:

<http://www.imc.org/pdi/>

About the PDI Library

The Palm OS PDI library is a shared library that provides objects and functions for:

- Reading vCard objects from an input data stream. The section [Creating a PDI Reader](#) describes how to create and use a PDI reader, and the section [Using a PDI Reader - An Example](#) provides an example of reading vCard data from an input stream.
- Writing vCard objects to an output data stream. The section [Creating a PDI Writer](#) describes how to create and use a PDI reader, and the section [Using a PDI Writer - An Example](#) provides an example of reading vCard data from an input stream.

The PDI library handles reading and writing objects in a number of different formats, and from or to a variety of media. For more information about specifying the media, see "[Using UDA for Different Media](#)" on page 73.

PDI Property and Parameter Types

The PDI library provides constants that you can use with the reader and writer objects to specify property information. These include the following types of constants that specify vObject standard entities:

- The **Property Name** constants represent the PDI property names. Each of the property name constants starts with the `kPdiPRN_` prefix. For example, the `kPdiPRN_ADR` constant represents the ADR property name. For more information, see the section [Property Name Constants](#) in [Chapter 78](#), “[Personal Data Interchange Library](#),” on page 1705 in *Palm OS Programmer’s API Reference*.
- The **Property Value Field** constants represent the position of property value fields for properties with structured field values. Each of the property value field constants starts with the `kPdiPVF_` prefix. For example, the `kPdiPVF_ADR_COUNTRY` constant represents the COUNTRY field of an ADR property value. For more information, see the section [Property Value Field Constants](#) in [Chapter 78](#), “[Personal Data Interchange Library](#),” on page 1705 in *Palm OS Programmer’s API Reference*.
- The **Parameter Name** constants represent the names of vObject property parameters. Each of the parameter name constants starts with the `kPdiPAN_` prefix. For example, the `kPdiPAN_Type` constant represents the TYPE parameter, and the `kPdiPAN_Encoding` constant represents the ENCODING parameter. For more information, see the section [Parameter Name Constants](#) in [Chapter 78](#), “[Personal Data Interchange Library](#),” on page 1705 in *Palm OS Programmer’s API Reference*.
- The **Parameter Value** constants represent the combined name and value of parameters. Each of the parameter value constants starts with the `kPdiPAV_` prefix. For example, `kPdiPAV_ENCODING_BASE64` constant represents the Base64 encoding. For more information, see the section [Parameter Value Constants](#) in [Chapter 78](#), “[Personal Data Interchange Library](#),” on page 1705 in *Palm OS Programmer’s API Reference*.

For a complete list of all of these constants, see the `PdiConst.h` file.

The PDI Library Properties Dictionary

The PDI library features a dictionary that stores information about the properties that are considered “well-known.” A well-known property is one that is defined in one of the vObject standard specifications, including the vCard and vCal standards. Both of these standards can be found online at the PDI developer’s web page:

<http://www.imc.org/pdi/pdiproddev.html>

PDI readers and writers use information in the properties dictionary to determine how to read or write a certain property. Specifically, the dictionary stores information about the format of each property value; the reader uses this information to correctly parse the property value, and the writer uses this information to correctly format the written value. This information is important because some property values are structured with multiple fields, while others contain a single value field.

For example, the standard address (ADR) property has a structured value with seven required fields, and the fields are separated by semicolons. The dictionary stores this information, and the PDI reader then knows to read seven, semicolon-separated fields when parsing an ADR property.

By default, each PDI reader and writer uses a standard dictionary when parsing input and generating output. You can, however, override this behavior to parse or generate the value for a property in some other way. For more information, see “[Reading Property Values](#)” on page 67 and “[Writing Property Values](#)” on page 72.

You can also amend or replace the dictionary to add parsing and/or generation of customized PDI properties for your application. For more information, see “[Adding Custom Extensions](#)” on page 70.

PDI Readers

The PDI library provides the PDI reader object for reading and parsing vObject input. A PDI reader object is a structure that stores the current state of parsing through a PDI input stream.

Personal Data Interchange

About the PDI Library

The PDI reader parses the input stream one property at a time, starting with the Begin Object property and finishing with the End Object property.

The [PdiReaderType](#) structure stores a variety of information about the current state of parsing the input stream, including the following information about the current property:

- the encoding and character set
- the type of the current property, parameter, and property value
- the name of the current property and parameter
- the current property's value string
- a mask of the parsing events encountered for the current property

About Parsing Events

The PDI reader records each parsing event that it encounters while processing a property. For example, when it parses a BEGIN:VCARD property, the PDI reader records the `kPdiBeginObjectEventMask`, and when it parses a property name, the PDI reader records the `kPdiPropertyNameEventMask`.

Each event is represented by one of the [Reader Event Constants](#), which are described in [Chapter 78](#), “[Personal Data Interchange Library](#),” on page 1705 in *Palm OS Programmer's API Reference*. The PDI reader records the event by adding (OR'ing) the event constant into the `events` field of the [PdiReaderType](#) structure.

You can determine if a specific event has occurred while parsing the current property by testing that event's constant against the `events` field in the reader structure. For example, the following statement returns `false` if the end of the input stream was reached.

```
return((reader->events & kPdiEOFFEventMask)==0);
```

PDI Writers

The PDI library provides the PDI writer object for writing vObject output. A PDI writer object is a structure that stores the current state of and manages the generation of PDI data.

The PDI writer sends data to the output stream one property at a time, starting with the Begin Object property and finishing with the End Object property.

The [PdiWriterType](#) structure stores information about the current state of writing the output stream, including the following:

- the encoding and character set of the current property
- the mode used to write the current property value, which specifies how the property value is structured
- the number of required fields for the current property value

Format Compatibility

The PDI library can read and write data streams in the following formats:

- vCard 3.0
- vCard 2.1
- vCal 1.0
- iCalendar
- Palm format

You can use the PDI library to convert an input data stream that uses one format into an output data stream in another format. For more information, see “[Specifying PDI Versions](#)” on page 73.

Compatibility with Earlier Versions of the Palm OS

The PDI library has been designed to maintain compatibility with earlier versions of the Palm OS, which means that you can use the library functions to receive vObjects from or send vObjects to devices that use those earlier versions.

To take advantage of this compatibility, the PDI library has been built to send or receive data in different formats, one of which is the format supported by earlier versions of the Palm OS that included the `ImcUtils` implementation.

To include support for this compatibility in a PDI Reader, specify the `kPdiOpenParser` constant in your call to the [PdiReaderNew](#) function.

To include support for this compatibility in a PDI Writer, specify the `kPdiPalmCompatibility` option when calling the [PdiWriterNew](#) function.

International Considerations

The PDI library handles various character sets, including Katakana. If you specify the `CHARSET` parameter in the input stream, the PDI reader will correctly read the property value.

The PDI library included with version 4.0 of the Palm OS[®] understands the following character sets:

- `charEncodingAscii`
- `charEncodingISO8859_1`
- `charEncodingShiftJIS`
- `charEncodingISO2022Jp`

If you specify an unknown character set, the current character set becomes unknown, as represented by the `charEncodingUnknown` constant.

Features Not Yet Supported

The PDI library included with version 4.0 of the Palm OS does not handle the following features:

- Multi-part MIME messages are not handled.
- The XML version of vObjects is not supported.
- Applications ignore grouping. The PDI reader parses group identifiers, but ignores them. However, the name of the group most recently parsed is stored in the `groupName` field of the [PdiReaderType](#) object.

Using the PDI Library

This section describes how to use the functions in the PDI library to read or write PDI content. [Figure 3.1](#) shows the typical sequences of calls that you make to read or write vObjects.

To read vObjects, you need to:

- access the PDI library
- create a PDI reader
- read each property in the input stream:
 - read the property name
 - read any parameters for the property
 - read the property value
- delete the PDI reader
- unload the PDI library

To write vObjects, you need to:

- access the PDI library
- create a PDI writer
- write each property in the input stream:
 - write the property name
 - write any parameters for the property
 - write the property value
- delete the PDI writer
- unload the PDI library

The remainder of this section describes the following operations:

- [Accessing the PDI Library](#)
- [Unloading the PDI Library](#)
- [Creating a PDI Reader](#)
- [Reading Properties](#)
- [Creating a PDI Writer](#)
- [Writing Property Values](#)
- [Specifying PDI Versions](#)
- [Using UDA for Different Media](#)


Personal Data Interchange

Using the PDI Library

The section “[Using a PDI Reader - An Example](#)” on page 74 provides a detailed example of creating a PDI Reader and using it to import vCard data into a database.

The section “[Using a PDI Writer - An Example](#)” on page 79 provides a detailed example of creating a PDI Writer and using it to export data from a database in vCal format.

Figure 3.1 Using the PDI library



Accessing the PDI Library

Before you can use the PDI library, you must load the library and obtain a reference number for it. Each of the functions in the library requires a reference number argument, which is used with the system code to access a shared library.

The example function `LoadPdiLibrary`, which is shown in [Listing 3.2](#), makes sure that the PDI library is loaded and returns a reference number for it.

Listing 3.2 Loading the PDI library

```
Static Err LoadPdiLibrary(UInt16 *libRefNum)
{
    Err    error

    error = SysLibFind(kPdiLibName, librefNum);
    if (error != 0)
    {
        error = SysLibLoad(sysResTLibrary,
                           sysFileCPdiLib, libRefNum);
    }
    if (error)
    {
        ErrNonFatalDisplay(kPdiLibName "not found")
        return error;
    }
    error = PdiLibOpen(*libRefNum);
    return error;
}
```

The `LoadPdiLibrary` function first calls the [SysLibFind](#) function to determine if the library has already been loaded, which might be the case if your code has been called by another application that has already loaded the library. Note that the call to `SysLibFind` uses the `kPdiLibName` constant, which is defined as follows in the `PdiLib.h` file:

```
#define kPdiLibName "Pdi.lib"
```

If the library has not already been loaded, `LoadPdiLibrary` calls the [SysLibLoad](#) function to load the library and obtain a reference number for it.

After obtaining a reference number for the library, LoadPdiLibrary calls the [PdiLibOpen](#) function to open the loaded library.

Unloading the PDI Library

When you are done with the library, you should unload it. The example function UnloadPdiLibrary, which is shown in [Listing 3.2](#), unloads the PDI library.

Listing 3.3 Unloading the PDI library

```
static void UnloadPdiLibrary(UINT16 refNum)
{
    if (PdiLibClose(refNum) == 0)
    {
        SysLibRemove(refNum);
    }
}
```

Note that the library reference number becomes invalid after you call the [SysLibRemove](#) function.

Creating a PDI Reader

To create a PDI reader, you need to first access the library, and then call the [PdiReaderNew](#) function, which is declared as follows:

```
PdiReaderType* PdiReaderNew(UINT16 libRefnum,
    UDAREader *input, UINT16 optionFlags)
```

The PdiReaderNew parameters are:

- The library reference number, as described in “[Accessing the PDI Library](#)” on page 64.
- The Unified Data Access (UDA) input stream to use with the reader. The UDA Manager allows you to read input from various sources, including strings and the Exchange Manager. For more information, see “[Using UDA for Different Media](#)” on page 73.
- Option flags that control the parsing behavior of the reader, including its default encoding and compatibility settings. The option flags are described in [Reader and Writer Options](#).

Personal Data Interchange

Using the PDI Library

[Constants](#) in [Chapter 78, “Personal Data Interchange Library,”](#) on page 1705 in *Palm OS Programmer’s API Reference*.

Once you have created the reader, you can use it to parse properties from the input stream. The section “[Using a PDI Reader - An Example](#)” on page 74 provides an example of creating and using a PDI reader.

Reading Properties

To read PDI property data with a PDI reader, you need to call the data reading functions:

- [PdiReadProperty](#) reads a property and all of its parameters from the input stream.
- [PdiReadPropertyName](#) reads just the name of the next property from the input stream. You can call this function if you want to then handle the reading of the property’s parameters individually.
- [PdiReadParameter](#) reads a single parameter and its value from the input stream.
- [PdiReadPropertyField](#) reads a property value field. A property value can a simple value, or it can be structured to contain multiple fields that are separated by commas or semicolons, as described in “[Reading Property Values](#)” on page 67.

The most common way to read input data is to follow these steps:

- Call `PdiReadProperty` to read the vObject Begin property. For example, if you are reading vCards, you can call `PdiReadProperty` until it reads the `kPdiPRN_BEGIN_VCARD` property from the input stream.
- Once you have found the beginning of the object, repeatedly call `PdiReadProperty` to read the next property and its parameters.
- For each property, call the `PdiReadPropertyField` function as required to read the fields of the property.
- Continue reading properties until you read the vObject End property. For vCards, you process properties until `PdiReadProperty` reads the `kPdiPRN_END_VCARD` property from the input stream.

Examining Property Information

After calling a property-reading function, you can access fields of the `PdiReaderType` object to determine information about the current property. The current property is the one that is currently being parsed, or which has just been parsed.

For example, you can examine the property field of the [PdiReaderType](#) object to determine which type of property has just been read, or you can call the [PdiParameterPairTest](#) macro to determine if a certain parameter pair was present in the property definition.

Reading Property Values

Some properties have simple values and others have structured values. A structured property value has multiple fields that are separated by commas or semicolons.

For example, the following phone property definition has a simple value:

```
TEL;CELL:+1 (408) 555-4321
```

Note that the phone property contains a semicolon to separate the CELL parameter from the property name. Each property's value follows the colon in the definition.

The following name property definition has a structured value that contains four fields separated by semicolons:

```
N:Smith; John;M.;Mr.; Esq.
```

You must pass a parameter to the [PdiReadPropertyField](#) function to tell it how to process a property value. To specify how the field is formatted, use one of the [Property Value Format Constants](#) described in [Chapter 78](#), "[Personal Data Interchange Library](#)," on page 1705 in *Palm OS Programmer's API Reference*.

You can specify `kPdiDefaultFields` to allow the PDI reader to determine the property value format. The reader looks up the property name in the dictionary to determine its format.

- Specify `kPdiNoFields` to have the reader parse the entire value in one operation.

Personal Data Interchange

Using the PDI Library

- Specify `kPdiCommaFields` or `kPdiSemicolonFields` to have the reader parse a single field from the value.
- Specify `kPdiConvertComma` or `kPdiConvertSemicolon` to have the reader parse all of the fields in a value into a single value.

You can usually specify `kPdiDefaultFields` and allow the PDI Reader to use the information in the dictionary to properly parse the value. However, this might not always meet your needs, especially if your input stream contains custom properties.

[Table 3.1](#) shows the results of using the different format constants to read the same property from the input stream. The example property is a standard address (ADR) property that has a structured value with seven, semicolon-delimited fields:

```
ADR:postoffice;extended;street;locale;region;postal_code;country
```

Note that since the ADR property is defined in the vCard standard as a structured value with seven, semicolon-delimited field, the PDI library dictionary defines its default format as `kPdiSemicolon`.

Table 3.1 Parsing a structured value with different value format types

| Value format type | Description of PdiReadPropertyField results |
|----------------------------|---|
| <code>kPdiNoFields</code> | One call returns the entire value as a string: "postoffice;extended;street;locale;region;postal_code;country" |
| <code>kPdiSemicolon</code> | Each call returns a single, semicolon-delimited field from the value. For example: <ul style="list-style-type: none">• the first call returns "postoffice"• the second call returns "extended"• the third call returns "street" |

Table 3.1 Parsing a structured value with different value format types (*continued*)

| Value format type | Description of PdiReadPropertyField results |
|----------------------|--|
| kPdiComma | Each call returns a single, comma-delimited field from the value. For example, if the input string is "postoffice,extended,street," then: <ul style="list-style-type: none">• the first call returns "postoffice"• the second call returns "extended"• the third call returns "street" |
| kPdiConvertSemicolon | One call returns the entire value as a string that has newline characters wherever a semicolon appeared in the input: "postoffice extended street locale region postal_code country" |
| kPdiConvertComma | One call returns the entire value as a string that has newline characters wherever a comma appeared in the input: "postoffice extended street locale region postal_code country" |
| kPdiDefaultFields | Same as kPdiSemicolon, because the PDI library dictionary defines the property value format of the ADR field as kPdiSemicolon. |

Personal Data Interchange

Using the PDI Library

Reading Value Fields One At a Time

If you are reading the fields in a structured value one at a time, and you don't know the exact number of fields, you can call [PdiReadPropertyField](#) repeatedly until it returns a nonzero result.

For example, the following code segment from the `DateTransfer.c` program parses each field of the EXDATE property value fields:

Listing 3.4 Reading an undetermined number of value fields

```
while (PdiReadPropertyField(pdiRefNum, reader, &tempP,
                           kPdiResizableBuffer, kPdiSemicolonFields) == 0)
{
    // Resize handle to hold exception
    err = MemHandleResize(exceptionListH,
sizeof(ExceptionsListType) + sizeof(DateType) * exceptionCount);
    ErrFatalDisplayIf(err != 0, "Memory full");
    // Lock exception handle
    exceptionListP = MemHandleLock(exceptionListH);
    // Calc exception ptr
    exceptionP = (DateType*)((UInt32)exceptionListP
                           + (UInt32)sizeof(UInt16)
                           + (UInt32)(sizeof(DateType) * exceptionCount));
    // Store exception into exception handle
    MatchDateTimeToken(tempP, exceptionP, NULL);
    // Increase exception count
    exceptionCount++;
    // Unlock exceptions list handle
    MemHandleUnlock(exceptionListH);
}
```

NOTE: If you leave fields in a structured value unread, the next call to `PdiReadProperty` will skip over them and correctly find the beginning of the next property.

Adding Custom Extensions

The vObject standards are extensible, which means that you can add custom properties to vCards and other vObjects. The PDI library handles these custom properties; however, you must either add an

entry to the library's dictionary for each custom property, or specify a constant other than `kPdiDefaultFields` when parsing the property's value.

Each PDI reader object and each PDI writer object can have a custom dictionary associated with it. You can configure the custom dictionary to amend or to replace the standard, built-in dictionary.

To associate a custom dictionary with a reader or writer, you need to first create the dictionary with the `PdiDefineReaderDictionary` function. You can then call the `PdiDefineReaderDictionary` function to associate that dictionary with a reader object or call the `PdiDefineWriterDictionary` function to associate the dictionary with a writer object.

NOTE: For more information about the dictionary tool at <http://www.palmos.com/dev/tech/kb>.

Creating a PDI Writer

To create a PDI writer, you need to first access the library, and then call the `PdiWriterNew` function, which is declared as follows:

```
PdiWriterType* PdiWriterNew(UInt16 libRefnum,
    UDAWriter *output, UInt8 optionFlags)
```

The `PdiWriterNew` parameters are:

- The library reference number, as described in “[Accessing the PDI Library](#)” on page 64..
- The UDA output stream to use with the writer. For more information, see “[Using UDA for Different Media](#)” on page 73.
- Option flags that control the output generation behavior of the writer, including its default encoding and compatibility settings. The option flags are described in [Reader and Writer Options Constants](#) in [Chapter 78](#), “[Personal Data Interchange Library](#),” on page 1705 in *Palm OS Programmer's API Reference*.

Once you have created the writer, you can use it to generate properties to the output stream. The section “[Using a PDI Writer - An Example](#)” on page 79 provides an example of creating and using a PDI writer.

Writing Properties

To write PDI data with a PDI writer, you need to call the data writing functions. The most commonly used functions are:

- [PdiWriteBeginObject](#), which writes a vObject Begin tag to the output stream.
- [PdiWriteEndObject](#), which writes a vObject End tag to the output stream.
- [PdiWriteProperty](#), which writes a property to the output stream.
- [PdiWritePropertyValue](#), which writes a property value to the output stream.

The most common way to write output data is to follow these steps:

- Call `PdiWriteBeginObject` to write the vObject Begin property. For example, if you are writing vCards, you call `PdiWriteBeginObject` to write the `kPdiPRN_BEGIN_VCARD` property to the output stream.
- For each property that you want to write, call `PdiWriteProperty` to write the next property and its parameters, and then call the `PdiWritePropertyValue` function to write the property's value.
- Call `PdiWriteEndObject` to write the vObject End property. For example, if you are writing vCards, you call `PdiWriteEndObject` to write the `kPdiPRN_END_VCARD` property to the output stream.

Writing Property Values

In many cases, you can simply call the [PdiWritePropertyValue](#) function to write a value to the output stream. If a value contains a variable number of fields, you can instead use the [PdiWritePropertyFields](#) to write the fields from an array. Or you can use the [PdiWritePropertyStr](#) to write multiple fields separated by commas or semicolons.

Specifying PDI Versions

The PDI library options constants control how the PDI reader and PDI writer operate. These options are described in [Reader and Writer Options Constants](#) in [Chapter 78, “Personal Data Interchange Library,”](#) on page 1705 in *Palm OS Programmer’s API Reference*.

Using UDA for Different Media

The PDI reader and writer objects use Unified Data Access (UDA) Manager objects for reading from and writing to a variety of media. The UDA data types, constants, and functions are documented in [Chapter 79, “Unified Data Access Manager,”](#) on page 1745 in *Palm OS Programmer’s API Reference*. This section provides an overview of using UDA objects with the PDI library.

About the UDA Library

The UDA Manager provides an abstract layer for reading, filtering, and writing data to and from different media. The UDA Manager provides three general purpose object types:

- [UDAREaderType](#) objects (UDA Readers) read data from an input stream.
- [UDAFilterType](#) objects (UDA Filters) take input from UDA Readers or UDA Filters, perform some encoding or decoding operations, and output the data to a memory buffer.
- [UDAWriterType](#) objects (UDA Writers) write data to a filter or an output stream.

The UDA Manager provides general purpose functions for creating these object types. In addition, the UDA Manager provides built-in object types for working with memory buffers and the Exchange Manager.

NOTE: The implementation of the UDA Manager in version 4.0 of the Palm OS does not provide built-in filter objects. These objects are planned for future versions.

Personal Data Interchange

Using a PDI Reader - An Example

Interfacing with the Exchange Manager

The UDA Manager provides two functions for interfacing with the Exchange Manager:

- The [UDAExchangeReaderNew](#) function creates a UDA Reader object that reads data from an Exchange Manager socket.
- The [UDAExchangeWriterNew](#) function creates a UDA Writer object that writes data to an Exchange Manager socket.

The Exchange Manager, which is described in [Chapter 1](#), “[Object Exchange](#),” on page 1, provides a mechanism for reading typed data in a transport-independent manner.

When you use the UDA interface to the Exchange Manager, you add the benefits of a simple, uniform way to read and write data in a transport-independent manner. This allows you to create PDI readers and writers that can work on data that is stored on a variety of media types.

If you wish to parse PDI objects from memory, you can use an object created by the [UDAMemoryReaderNew](#) function instead of an Exchange Manager reader object.

The PDI Reader example in the next section reads its data from an Exchange Manager socket, using the [UDAExchangeReaderNew](#) function to create the reader object.

The PDI Writer example in “[Using a PDI Writer - An Example](#)” on page 79 writes its data to an Exchange Manager socket, using the [UDAExchangeWriterNew](#) function to create the writer object.

Using a PDI Reader - An Example

This section provides an example of reading PDI data from an input stream and storing it in a database. This example is from the `AddressTransfer.c` file, which is located inside of the `Examples/Address/Src` folder.

[Listing 3.5](#) shows the `TransferReceiveData` function from the `AddressTransfer.c` sample program. This function controls the

reading of vCard data into the address database by performing the following operations:

- Calls the [ExgAccept](#) function to accept a connection from a remote device.
- Calls a local function, `PrvTransferPdiLoadLibrary`, to load an open the PDI library. The `PrvTransferPdiLoadLibrary` function is almost exactly the same as the `LoadPdiLibrary` function shown in [Listing 3.2](#).
- Calls the [UDAExchangeReaderNew](#) function to create an input data stream for connection with the Exchange Manager.
- Calls the [PdiReaderNew](#) function to create a new PDI reader object that reads from the input stream.
- Repeatedly calls the local function `TransferImportVCard` to read vCard data and store it into the address database. This function is described in the next section, [Importing vCard Data Into a Database](#).
- Calls the [ExgDisconnect](#) function to terminate the transfer and close the connection.
- Calls the `PrvTransferPdiLibUnload` function to unload the PDI library.
- Deletes the PDI reader and UDA input stream objects.

Listing 3.5 Reading a PDI input stream

```
extern Err TransferReceiveData(DmOpenRef dbP, ExgSocketPtr exgSocketP)
{
    volatile Err err;
    UInt16 pdiRefNum = sysInvalidRefNum;
    PdiReaderType* reader = NULL;
    UDARReader* stream = NULL;
    Boolean loaded;

    if ((err = ExgAccept(exgSocketP)) != 0)
        return err;
    if ((err = PrvTransferPdiLibLoad(&pdiRefNum, &loaded)))
    {
        pdiRefNum = sysInvalidRefNum;
        goto errorDisconnect;
    }
}
```

Personal Data Interchange

Using a PDI Reader - An Example

```
if ((stream = UDAExchangeReaderNew(exgSocketP)) == NULL)
{
    err = exgMemError;
    goto errorDisconnect;
}
if ((reader = PdiReaderNew(pdiRefNum, stream, kPdiOpenParser)) == NULL)
{
    err = exgMemError;
    goto errorDisconnect;
}
reader->appData = exgSocketP;
ErrTry
{
    while(TransferImportVCard(dbP, pdiRefNum, reader, false, false)){};
}
ErrCatch(inErr)
{
    err = inErr;
} ErrEndCatch
if (err == errNone && exgSocketP->goToParams.uniqueID == 0)
    err = exgErrBadData;
errorDisconnect:
if (reader)
    PdiReaderDelete(pdiRefNum, &reader);
if (stream)
    UDADelete(stream);
if (pdiRefNum != sysInvalidRefNum)
    PrvTransferPdiLibUnload(pdiRefNum, loaded);
ExgDisconnect(exgSocketP, err); // closes transfer dialog
err = errNone; // error was reported, so don't return it
return err;
}
```

Importing vCard Data Into a Database

The `TransferImportVCard` function imports a vCard record from an input stream. [Listing 3.6](#) shows the basic outline of the `TransferImportVCard` function; you can review the entire function by viewing the `AddressTransfer.c` file, which is located inside of the `Examples/Address/Src` folder.

Listing 3.6 Importing vCard data into a database

```
Boolean TransferImportVCard(DmOpenRef dbP, UInt16 pdiRefNum,
PdiReaderType* reader, Boolean obeyUniqueIDs, Boolean beginAlreadyRead)
{
...    // local declarations and initialization code

    ErrTry
    {
        phoneField = firstPhoneField;
        if (!beginAlreadyRead)
        {
            PdiReadProperty(pdiRefNum, reader);
            beginAlreadyRead = reader->property == kPdiPRN_BEGIN_VCARD;
        }
        if (!beginAlreadyRead)
            ErrThrow(exgErrBadData);
        PdiEnterObject(pdiRefNum, reader);
        PdiDefineResizing(pdiRefNum, reader, 16, tableMaxTextItemSize);
        while (PdiReadProperty(pdiRefNum, reader) == 0
            && (property = reader->property) != kPdiPRN_END_VCARD)
        {
            switch(property)
            {
            case kPdiPRN_N:
                PdiReadPropertyField(pdiRefNum, reader,
                    (Char **) &newRecord.fields[name],
                    kPdiResizableBuffer, kPdiDefaultFields);
                PdiReadPropertyField(pdiRefNum, reader,
                    (Char **) &newRecord.fields[firstName],
                    kPdiResizableBuffer, kPdiDefaultFields);
                break;
            case kPdiPRN_NOTE:
                PdiDefineResizing(pdiRefNum, reader, 16,
                    noteViewMaxLength);
                PdiReadPropertyField(pdiRefNum, reader,
                    Char **) &newRecord.fields[note],
                    kPdiResizableBuffer, kPdiNoFields);
                PdiDefineResizing(pdiRefNum, reader, 16,
                    tableMaxTextItemSize);
                break;
            ... // other cases here for other properties
            }
        } // end while
        if (newRecord.fields[name] != NULL
```

Personal Data Interchange

Using a PDI Reader - An Example

```
&& newRecord.fields[company] != NULL
&& newRecord.fields[firstName] != NULL
&& StrCompare(newRecord.fields[name],
               newRecord.fields[company]) == 0)
{
    // if company & name fields are identical, assume company only
    MemPtrFree(newRecord.fields[name]);
    newRecord.fields[name] = NULL;
}
AddRecord:
    err = AddrDBNewRecord(dbP, (AddrDBRecordType*) &newRecord,
                          &indexNew);

    if (err)
        ErrThrow(exgMemError);

...    // handle category assignment here

} //end of ErrTry
if (error == exgErrBadData)
    return false;
if (error != errNone)
    ErrThrow(error);
return ((reader->events & kPdiEOFEventMask) == 0);
}
```

The `TransferImportVCard` function performs the following operations:

- Calls the [PdiReadProperty](#) function to read the `BEGIN:VCard` property from the input stream.
- Calls the [PdiEnterObject](#) function to notify the PDI library that it is reading a new object from the input stream.
- Calls the [PdiDefineResizing](#) function to set the maximum buffer size for reading properties for the address card.
- Repeatedly calls the [PdiReadProperty](#) function to read properties of the address card. This repeats until `PdiReadProperty` reads the `END:VCard` property, which indicates the end of data for the address card.
- For each address card property, calls [PdiReadPropertyField](#) as required to read the values associated with the property. For example, when it reads the `kPdiPRN_N` name property, `AddrImportVCard` calls `PdiReadPropertyField` twice: once to read the last name, and a second time to read the first name.

- Creates a new address record and adds it to the Address Book database.
- Deallocates memory that it has allocated and performs other cleanup operations.

Again, note that [Listing 3.6](#) only shows the outline of this function. You can find the entire function in the `AddressTransfer.c` file.

Using a PDI Writer - An Example

This section provides an example of writing PDI data from a database record to an output stream. This example is from the `ToDoTransfer.c` file, which is located inside of the `Examples/ToDo/Src` folder.

[Listing 3.7](#) shows an example of creating and using a PDI writer. The `ToDoSendRecordTryCatch` function controls the writing of data from the To Do database to vCal objects by performing the following operations:

- Calls a local function, `LoadPdiLibrary`, to load and open the PDI library. The `LoadPdiLibrary` function is shown in [Listing 3.2](#).
- Calls the `PdiWriterNew` function to create a new PDI writer object that writes to the UDA output stream specified by the `media` parameter.
- Calls the `PdiWriteBeginObject` function to write the `BEGIN:VCAL` property to the output stream.
- Calls the `PdiWriteProperty` function to write the `VERSION` property, and then calls the `PdiWritePropertyValue` function to write the version value.
- Calls the `ToDoExportVCal` function to write the To Do record, as described in the next section, [Exporting vCal Data From a Database](#).
- Calls the `PdiWriteEndObject` function to write the `END:VCAL` property to the output stream.
- Deletes the PDI writer object and unloads the PDI library.

Personal Data Interchange

Using a PDI Writer - An Example

Listing 3.7 Writing a PDI Output Stream

```
static Err ToDoSendRecordTryCatch (DmOpenRef dbP,
    Int16 recordNum, ToDoDBRecordPtr recordP, UDAWriter* media)
{
    volatile Err error = 0;
    UInt16 pdiRefNum;
    PdiWriterType* writer;

    if ((error = LoadPdiLibrary(&pdiRefNum)))
        return error;
    writer = PdiWriterNew(pdiRefNum, media, kPdiPalmCompatibility);
    if (writer)
    {
ErrTry
        {
            PdiWriteBeginObject(pdiRefNum, writer,
                                kPdiPRN_BEGIN_VCALENDAR);
            PdiWriteProperty(pdiRefNum, writer, kPdiPRN_VERSION);
            PdiWritePropertyValue(pdiRefNum, writer, (Char*)"1.0",
                                kPdiWriteData);
            ToDoExportVCal(dbP, recordNum, recordP, pdiRefNum,
                           writer, true);
            PdiWriteEndObject(pdiRefNum, writer,
                              kPdiPRN_END_VCALENDAR)
;
        }
ErrCatch(inErr)
        {
            error = inErr;
        } ErrEndCatch
        PdiWriterDelete(pdiRefNum, &writer);
    }
    UnloadPdiLibrary(pdiRefNum);
    return error;
}
```

Exporting vCal Data From a Database

The `ToDoExportVCal` function exports a vCal record from the To Do database to an output stream. [Listing 3.8](#) shows the basic outline of the `ToDoExportVCal` function; you can review the entire function by viewing the `ToDoTransfer.c` file, which is located inside of the `Examples/Address/Src` folder.

Listing 3.8 Exporting vCal data from a database

```
extern void ToDoExportVCal(DmOpenRef dbP, Int16 index,
ToDoDBRecordPtr recordP, UInt16 pdiRefNum, PdiWriterType* writer,
Boolean writeUniqueIDs)
{
    Char *          note;
        UInt32      uid;
        Char        tempString[tempStringLengthMax];
        UInt16      attr;
    ...

    PdiWriteBeginObject(pdiRefNum, writer, kPdiPRN_BEGIN_VTODO);
        // Emit the Category
    PdiWriteProperty(pdiRefNum, writer, kPdiPRN_CATEGORIES);
        // ...code to create the property string (tempString)
    PdiWritePropertyValue(pdiRefNum, writer, tempString, kPdiWriteText);

        // Code to emit the record information, including the:
        //   - due date
        //   - completed flag
        //   - priority value
        //   - description text
    ...

        // Emit the note
    if (*note != '\0')
    {
        PdiWriteProperty(pdiRefNum, writer, kPdiPRN_ATTACH);
        PdiWritePropertyValue(pdiRefNum, writer, note, kPdiWriteText);
    }

        // Emit an unique id
    if (writeUniqueIDs)
    {
        PdiWriteProperty(pdiRefNum, writer, kPdiPRN_UID);
        // Get the record's unique id and append to the string.
        DmRecordInfo(dbP, index, NULL, &uid, NULL);
        StrIToA(tempString, uid);
        PdiWritePropertyValue(pdiRefNum, writer, tempString, kPdiWriteData);
    }

    PdiWriteEndObject(pdiRefNum, writer, kPdiPRN_END_VTODO);
}
```

Personal Data Interchange

Using a PDI Writer - An Example

The `ToDoExportVCal` function performs the following operations:

- Calls the [PdiWriteBeginObject](#) function to write the `BEGIN:VTODO` property to the output stream.
- Calls the [PdiWriteProperty](#) function to write the category information for the To Do record.
- Calls the [PdiWriteProperty](#) function to write other information for the To Do record, including the due date, completed flag, priority value, and description text.
- Calls the [PdiWriteProperty](#) function to write the note and again to write a unique ID for the note.
- Calls the [PdiWriteEndObject](#) function to write the `END:VTODO` property to the output stream.

Again, note that [Listing 3.8](#) only shows the outline of this function. You can find the entire function in the `ToDoTransfer.c` file.

Summary of Personal Data Interchange

PDI Library Functions

Library Open and Close

[PdiLibClose](#)

[PdiLibOpen](#)

Object Creation and Deletion

[PdiReaderNew](#)

[PdiWriterNew](#)

[PdiReaderDelete](#)

[PdiWriterDelete](#)

Property Reading

[PdiDefineResizing](#)

[PdiReadProperty](#)

[PdiEnterObject](#)

[PdiReadPropertyField](#)

[PdiParameterPairTest](#)

[PdiReadPropertyName](#)

[PdiReadParameter](#)

Property Writing

[PdiSetCharset](#)

[PdiWriteParameterStr](#)

[PdiSetEncoding](#)

[PdiWriteProperty](#)

[PdiWriteBeginObject](#)

[PdiWritePropertyBinaryValue](#)

[PdiWriteEndObject](#)

[PdiWritePropertyFields](#)

[PdiWriteParameter](#)

[PdiWritePropertyStr](#)

[PdiWritePropertyValue](#)

Property Dictionary

[PdiDefineReaderDictionary](#)

[PdiDefineWriterDictionary](#)

Summary of Unified Data Access Manager

UDA Manager Functions

[UDAControl](#)

[UDAMoreData](#)

[UDADelete](#)

[UDARead](#)

[UDAEndOfReader](#)

[UDAWriterFlush](#)

[UDAFilterJoin](#)

[UDAWriterJoin](#)

[UDAInitiateWrite](#)

Object Creation

[UDAExchangeReaderNew](#)

[UDAMemoryReaderNew](#)

[UDAExchangeWriterNew](#)

Beaming (Infrared Communication)

The Palm OS® provides three levels of support for beaming, or infrared communication (IR):

- The Exchange Manager provides a high-level interface that handles all of the communication details transparently. See the “[Object Exchange](#)” chapter for more information.
- The Serial Manager provides a virtual driver that implements the IrComm protocol. To use IrComm, you specify `sysFileCVirtIrComm` as the port you want to open and use the Serial Manager APIs to send and receive data on that port. See the “[Serial Communication](#)” chapter for information on how to use the Serial Manager APIs.
- The [IR Library](#) provides a low-level, direct interface to the IR communications capabilities of the Palm OS. It is designed for applications that want more direct access to the IR capabilities than the Exchange Manager provides.

This chapter discusses the IR Library.

IR Library

The IR (InfraRed) library is a shared library that provides a direct interface to the IR communications capabilities of the Palm OS. It is designed for applications that want more direct access to the IR capabilities than the exchange manager provides.


The IR support provided by the Palm OS is compliant with the IrDA specifications. IrDA (Infrared Data Association), is an industry body consisting of representatives from a number of companies involved in IR development. For a good introduction to the IrDA standards, see the IrDA web site at:

<http://www.IrDA.org/>

IrDA Stack

The IrDA stack comprises a number of protocol layers, of which some are required and some are optional. The complete stack looks something like [Figure 4.1](#).

Figure 4.1 IrDA Protocol Stack



The SIR/FIR layer is purely hardware. The SIR (Serial IR) layer supports speeds up to 115k bps while the FIR (Fast IR) layer supports speeds up to 4M bps. IrLAP is the IR Link Access Protocol that provides a data pipe between IrDA devices. IrLMP, the IR Link Management Protocol, manages multiple sessions using the IrLAP. Tiny TP is a lightweight transfer protocol on which some higher-level IrDA layers are built.

One or more of SIR/FIR must be implemented, and Tiny TP, IrLMP and IrLAP must also be implemented. IrComm provides serial and parallel port emulation over an IR link and is optional (it is not currently supported in the Palm OS). IrLAN provides an access point to Local Area Network protocol adapters. It too is optional (and is not supported in the Palm OS).

OBEX is an object exchange protocol that can be used (for instance) to transfer business cards, calendar entries or other objects between devices. It too is optional and is supported in the Palm OS. The capabilities of OBEX are made available through the exchange manager; there is no direct API for it.

The Palm OS implements all the required protocol layers (SIR, IrLAP, IrLMP, and Tiny TP), as well as the OBEX layer, to support the Exchange Manager. Palm III™ devices provide SIR (Serial IR) hardware supporting the following speeds: 2400, 9600, 19200, 38400, 57600, and 115200 bps. The software (IrOpen) currently limits bandwidth to 57600 bps by default, but you can specify a connection speed of up to 115200 bps if desired.

The stack is capable of connection-based or connectionless sessions.

IrLMP Information Access Service (IAS) is a component of the IrLMP protocol that you will see mentioned in the interface. IAS provides a database service through which devices can register information about themselves and retrieve information about other devices and the services they offer.

Accessing the IR Library

Before you can use the IR library, you must obtain a reference number for it by calling the function [SysLibFind](#), as in this example:

```
err = SysLibFind(irLibName, &refNum);
```

This function returns the library reference number in the `refNum` parameter. This parameter is passed to most of the other functions in the IR library.

Summary of Beaming

IR Library Functions

[IrAdvanceCredit](#)

[IrIsNoProgress](#)

[IrBind](#)

[IrIsRemoteBusy](#)

[IrClose](#)

[IrLocalBusy](#)

[IrConnectIrLap](#)

[IrMaxRxSize](#)

[IrConnectReq](#)

[IrMaxTxSize](#)

[IrConnectRsp](#)

[IrOpen](#)

Beaming (Infrared Communication)

Summary of Beaming

IR Library Functions

| | |
|---|--|
| <u>IrDataReq</u> | <u>IrSetConTypeLMP</u> |
| <u>IrDisconnectIrLap</u> | <u>IrSetConTypeTTP</u> |
| <u>IrDiscoverReq</u> | <u>IrSetDeviceInfo</u> |
| <u>IrIsIrLapConnected</u> | <u>IrTestReq</u> |
| <u>IrIsMediaBusy</u> | <u>IrUnbind</u> |

IR Library IAS Database Functions

| | |
|---|---|
| <u>IrIAS_Add</u> | <u>IrIAS_GetUserString</u> |
| <u>IrIAS_GetInteger</u> | <u>IrIAS_GetUserStringCharSet</u> |
| <u>IrIAS_GetIntLsap</u> | <u>IrIAS_GetUserStringLen</u> |
| <u>IrIAS_GetObjectID</u> | <u>IrIAS_Next</u> |
| <u>IrIAS_GetOctetString</u> | <u>IrIAS_Query</u> |
| <u>IrIAS_GetOctetStringLength</u> | <u>IrIAS_SetDeviceName</u> |
| <u>IrIAS_GetType</u> | <u>IrIAS_StartResult</u> |

Serial Communication

The Palm OS[®] serial communications software provides high-performance serial communications capabilities, including byte-level serial I/O, best-effort packet-based I/O with CRC-16, reliable data transport with retries and acknowledgments, connection management, and modem dialing capabilities.

This chapter helps you understand the different parts of the serial communications system and explains how to use them, discussing these topics:

- [Serial Hardware](#) describes the serial port hardware.
- [Byte Ordering](#) briefly explains the byte order used for all data.
- [Serial Communications Architecture Hierarchy](#) provides an overview of the hierarchy, including an illustration.
- [The Serial Manager](#) is responsible for byte-level serial I/O and control of the RS-232, USB, Bluetooth, and IR signals.
- [The Connection Manager](#) allows other applications to access, add, and delete connection profiles contained in the Connection preferences panel.
- [The Serial Link Protocol](#) provides an efficient mechanism for sending and receiving packets.
- [The Serial Link Manager](#) is the Palm OS implementation of the serial link protocol.

NOTE: Although the Palm OS supports Bluetooth connections, Bluetooth requires additional hardware and software that is not available as of this writing.

Serial Hardware

The Palm OS platform device serial port is used for implementing desktop PC connectivity or other external communication. The serial communication is fully interrupt-driven for receiving data. Currently, interrupt-driven transmission of data is not implemented in software, but the hardware does support it. Five external signals are used for this communication:

- SG (signal ground)
- TxD (transmit data)
- RxD (receive data)
- CTS (clear to send)
- RTS (request to send)

Some devices also have a configurable DTR (data terminal ready) signal. Normally, the DTR signal is always high.

The Palm OS platform device has an external connector that provides:

- Five serial communication signals
- General-purpose output
- General-purpose input
- Cradle button input

Palm, Inc. publishes information designed to assist hardware developers in creating devices to interface with the serial communications port on Palm OS platform products. You can obtain this information by joining the Alliance Program and enrolling in the Plugged-In Program. For more information about this program and the serial port hardware, see the Palm™ developer web page at:

<http://www.palmos.com/dev/tech/palmhardware/>.

Byte Ordering

By convention, all data coming from and going to the Palm OS device use Motorola byte ordering. That is, data of compound types such as `UInt16` (2 bytes) and `UInt32` (4 bytes), as well as their integral counterparts, are packaged with the most-significant byte at the lowest address. This contrasts with Intel byte ordering.

Serial Communications Architecture Hierarchy


The serial communications software has multiple layers. Higher layers depend on the more primitive functionality provided by lower layers. Applications can use the functionality of all layers. The software consists of the following layers, described in more detail below:

- The Serial Manager, at the lowest layer, deals with the serial port and control of the RS-232 signals, USB signals, or IR signals, providing byte-level serial I/O. See [“The Serial Manager” on page 92](#).
- The Modem Manager provides modem dialing capabilities.
- The Serial Link Protocol (SLP) provides best-effort packet send and receive capabilities with CRC-16. Packet delivery is left to the higher-level protocols; SLP does not guarantee it. See [“The Serial Link Protocol” on page 119](#).
- The Packet Assembly/Disassembly Protocol (PADP) sends and receives buffered data. PADP is an efficient protocol featuring variable-size block transfers with robust error checking and automatic retries. Applications don’t need access to this part of the system.
- The Desktop Link Protocol (DLP) provides remote access to Palm OS data storage and other subsystems.

DLP facilitates efficient data synchronization between desktop (PC or Macintosh) and Palm OS applications, database backup, installation of code patches, extensions, applications, and other databases, as well as Remote Interapplication Communication (RIAC) and Remote Procedure Calls (RPC).

Figure 5.1 illustrates the communications layers.

Figure 5.1 Palm OS Serial Communications Architecture



The Serial Manager

The Palm OS Serial Manager is responsible for byte-level serial I/O and control of the RS-232, IR, Bluetooth, or USB signals.

NOTE: Although the Palm OS supports Bluetooth connections, Bluetooth requires additional hardware and software that is not available as of this writing.

To ensure that the Serial Manager does not slow down processing of user events, the Serial Manager receives data asynchronously. Sending data is performed synchronously in the current implementation.

This section describes the Serial Manager and how to write the virtual serial drivers that it can use. It covers the following topics:

- [Which Serial Manager Version To Use](#)
- [Steps for Using the Serial Manager](#)
- [Opening a Port](#)
- [Closing a Port](#)
- [Configuring the Port](#)
- [Sending Data](#)
- [Receiving Data](#)
- [Serial Manager Tips and Tricks](#)
- [Writing a Virtual Device Driver](#)

NOTE: You must check which Serial Manager is present before making any calls. See the next section for details. When in doubt, the old Serial Manager API is always available.

Which Serial Manager Version To Use

There are several versions of the Serial Manager available. The first several releases of Palm OS had a Serial Manager that supported only a single serial port. The API for this Serial Manager is documented in the chapter “[Old Serial Manager](#)” on page 1383 of the *Palm OS Programmer’s API Reference*.

If the [New Serial Manager Feature Set](#) is present, the Serial Manager has a different set of API (described in the chapter “[Serial Manager](#)” on page 1345 of the *Palm OS Programmer’s API Reference*) and can support multiple physical serial hardware devices and virtual serial devices. Physical serial drivers manage communication with the hardware as needed, and virtual drivers manage blocks of data to be sent to some sort of block-based serial code. The detailed operation of drivers is abstracted from the main serial management code.

Serial Communication

The Serial Manager

The newest versions of Palm OS may have an updated version of the new Serial Manager installed. Version 2 provides USB and Bluetooth virtual drivers and provides a few enhancements to the Serial Manager and virtual driver APIs.

When deciding which API to use, note the following:

- If you are writing new application code, best performance is achieved by using the new Serial Manager functions directly, if it is available. The new Serial Manager was introduced in Palm OS 3.3. If it is available on all devices in your target market, consider using new Serial Manager directly.
- The old Serial Manager API is available on all versions of Palm OS; however, it only supports RS-232 communications and low-level IrDA communications.
- The new Serial Manager API supports the IrComm protocol.
- Version 2 of the new Serial Manager supports USB and Bluetooth communication.
- If you write a virtual serial driver, you must use the new Serial Manager API.

Checking the Serial Manager Version

To check whether you can use the new Serial Manager API, check for the existence of the new Serial Manager feature set by calling [FtrGet](#) as follows:

```
err = FtrGet(sysFileCSerialMgr,  
            sysFtrNewSerialPresent, &value);
```

If the new Serial Manager is installed, the value parameter is non-zero and the returned error is zero (for no error).

To check for the existence of version 2 of the new Serial Manager, you should check both the Serial Manager version number and the Palm OS version number as follows:

```
err = FtrGet(sysFileCSerialMgr,  
            sysFtrNewSerialVersion, &value);  
err = FtrGet(sysFtrCreator,  
            sysFtrNumROMVersion, &romVersion);
```

If the value parameter is 2, the romVersion is 0x04003000, and both calls to `FtrGet` return 0 (for no error), version 2 of the new Serial Manager feature set is present.


Version 2 of the new Serial Manager ships with roughly Palm OS 4.0 and higher; however, some Handspring devices that run Palm OS 3.5 have a Serial Manager that returns a version number of 2. This Serial Manager has a slightly different feature set than the Serial Manager that ships with Palm OS 4.0. It contains virtual driver operation codes and virtual driver enhancements to support USB, but it does not contain any of the public Serial Manager functions added in version 2. Therefore, you need to check both the Serial Manager version number and the Palm OS version number before you use the version 2 Serial Manager functions.

About the New Serial Manager

The new Serial Manager manages multiple serial devices with minimal duplication of hardware drivers and data structures. In older Palm systems, the serial library managed any and all connections to the serial hardware in the 68328 (Dragonball) processor, which was the only serial device in the system. Newer systems contain additional serial devices, such as an IR port and possibly a USB port.

The figure below shows the layering of communication software with the Serial Manager and hardware drivers.

Figure 5.2 Serial Communications Architecture with Serial Manager



The Serial Manager maintains a database of installed hardware and currently open connections. Applications, libraries, or other serial communication tasks open different pieces of serial hardware by specifying a logical port number or a four-character code identifying the exact piece of serial hardware that a task wishes to open a connection with. The Serial Manager then performs the proper actions on the hardware through small hardware drivers that are opened dynamically when the port is needed. One hardware driver is needed for each serial communication hardware device available to the Palm unit.

At system restart, the Serial Manager searches for all serial drivers on the Palm device. Serial drivers are independent .prc files with a code resource and a version resource and are of type 'sdrv' (for physical serial drivers) or 'vdrv' (for virtual serial drivers). Once a driver is found, it is asked to locate its associated hardware and provide information on the capabilities of that hardware. This is done for each driver found and the Serial Manager always maintains a list of hardware currently on the device.

Once a port is opened, the Serial Manager allocates a structure for maintaining the current information and settings of the particular port. The task or application that opens the port is returned a port

ID and must supply the port ID to refer to this port when other Serial Manager functions are called.

Upon closing the port, the Serial Manager deallocates the open port structure and unlocks the driver code resource to prevent memory fragmentation.

Note that applications can use the Connection Manager to obtain the proper port name and other serial port parameters that the user has stored in connection profiles for different connection types. For more information, see the section "[The Connection Manager](#)" on page 116.

Steps for Using the Serial Manager

Regardless of which version of the API you use, the main steps to perform serial communication are the same. They are:

1. **Open a serial port.**

To open a port in the new Serial Manager, you specify which port to open and obtain a port ID that uniquely identifies this connection. You pass that port ID to every other Serial Manager call you make.

Because the old Serial Manager only has one port, it uses the serial library reference number to uniquely identify the connection. Therefore, with the old Serial Manager, you must first obtain the serial library reference number and then open the port.

See "[Opening a Port](#)" on page 98.

2. **If necessary, configure the connection.**

You might need to change the baud rate or increase the size of the receive queue before you use any other Serial Manager calls. See "[Configuring the Port](#)" on page 102.

3. **Send or receive data.**

See "[Sending Data](#)" on page 105 and "[Receiving Data](#)" on page 106.

4. **Close the port.**

See "[Closing a Port](#)" on page 101.

Serial Communication

The Serial Manager

The next several sections describe these steps in more detail. Where the old and new Serial Manager APIs are similar, the task is described in terms of using the new Serial Manager, and the old Serial Manager API is given in parentheses. In these cases, the only difference is in the name of the function and the ID you pass to identify the connection. Where the two APIs differ considerably, both are described.

TIP: See “[Serial Manager Tips and Tricks](#)” on page 112 for debugging information and information on how to fix common errors.

Opening a Port

The Serial Manager is installed when the device is booted. Before you can use it, however, you must enable the serial hardware by opening a port.

You open a port for the Serial Manager differently depending on which API you are using: the new Serial Manager or the old Serial Manager.

IMPORTANT: Applications that open a serial port are responsible for closing it. Opening a serial port powers up the UART and drains batteries. To conserve battery power, don't keep the port open longer than necessary.

When you attempt to open a serial port, regardless of which API you use, you must check for errors upon return:

- If `errNone` is returned, the port was opened successfully. The application can then perform its tasks and close the port when finished.
- If `serErrAlreadyOpen` is returned, the port was already open. For example, you might receive this error if the console opened the port during a previous debugging session and never closed it or, on some devices, if there is an open TCP/IP stack.
- If any other error is returned, the port was not opened, and the application must **not** close it.

Opening a Port With the New Serial Manager

To open a port using the new Serial Manager, call the [SrmOpen](#) function, specifying the port (see “[Specifying the Port](#)” on page 100) and the initial baud rate of the UART. SrmOpen returns a port ID that uniquely identifies this connection. You pass this port ID to all other Serial Manager calls.

Version 2 of the new Serial Manager supports USB and Bluetooth connections as well as RS-232 and IR connections. With the Bluetooth and USB protocols, it is often more important to specify the reason why the application is opening the port. The baud rate is unimportant as that is negotiated in USB and Bluetooth protocols. To open a USB or Bluetooth connection, use [SrmExtOpen](#) instead of SrmOpen. This function takes a [SrmOpenConfigType](#) structure, which allows you to specify the purpose of the connection instead of the baud rate.

Once the SrmOpen or SrmExtOpen call is made successfully, it indicates that the Serial Manager has successfully allocated internal structures to maintain the port and has successfully loaded the serial driver for this port.

Listing 5.1 Opening the port (new Serial Manager)

```
UInt16 portId;
Boolean serPortOpened = false;

err = SrmOpen(serPortCradlePort /* port */, 57600, /* baud */
    &portId);
if (err) {
    // display error message here.
}
//record our open status in global.
serPortOpened = true;
```

A port may be opened with either a foreground connection (SrmOpen or SrmExtOpen) or background connection ([SrmOpenBackground](#) or [SrmExtOpenBackground](#)). A foreground connection makes an active connection to the port and controls usage of the port until the connection is closed. A background connection opens the port but relinquishes control to any other task requesting a foreground connection. Background

connections are provided to support tasks (for example, a keyboard driver) that want to use a serial device to receive data only when no other task is using the port.

Note that background ports have limited functionality: they can only receive data and notify owning clients of what data has been received.

Specifying the Port

Ports must be specified using one of the following methods:

- Logical ports (see “[Logical Serial Port Constants](#)” on page 1351 of the *Palm OS Programmer’s API Reference*)

The recommended way to specify the port is to use the logical port name. Logical ports are hardware independent. Palm OS will map them to the correct physical port. It is better to use logical ports instead of physical ports.

- Physical ports (see “[Physical Serial Port Constants](#)” on page 1352 of the *Palm OS Programmer’s API Reference*)

Physical ports are 4-character constants (‘uxxx’) that reference the physical hardware of the device. It is usually not a good idea to use these ports because the hardware they reference may not exist on a particular device.

- Virtual ports (see “[Virtual Serial Port Constants](#)” on page 1352 of the *Palm OS Programmer’s API Reference*)

Virtual ports are associated with virtual drivers installed on the device. For example, the virtual port constant `sysFileCVirtIrComm` specifies the virtual driver that implements the IrComm protocol.

- Connection Manager (see “[The Connection Manager](#)” on page 116)

If you want to use a particular connection profile as stored in the Connection preferences panel, use the Connection Manager to obtain the port name from the connection profile and then use that name to open the port.

Note that other 4-character codes for the physical and virtual ports will be added in the future. Also note that the port IDs, like creator IDs, are 4-character constants, not strings. Therefore, they are enclosed in single quotes (‘ ’), not double quotes (“ ”).

Opening a Port with the Old Serial Manager

If you are using the old Serial Manager, there is only one port, so you always pass 0 (or the constant `serPortLocalHotSync`) to identify the port. The serial library reference number identifies the connection. To obtain the reference number, call [SysLibFind](#), passing "Serial Library" for the library name.

The reference number remains the same within one invocation of the application. You can close and open the library as needed using the number. Between invocations, the reference number may change. Because of that, you should call `SysLibFind` each time you reopen the Serial Manager.

After the call to `SysLibFind`, use [SerOpen](#) to open the port. Like `SrmOpen`, you pass the baud rate along with the reference number.

Listing 5.2 Opening the port (old Serial Manager)

```
UInt16 refNum = sysInvalidRefNum;
Boolean serPortOpened = false;
Err err;

err = SysLibFind("Serial Library", &refNum);
err = SerOpen(refNum, 0 /* port is always 0*/,
    57600 /* baud */);
if (err == serErrAlreadyOpen) {
    err = SerClose(refNum);
    // display error message here.
}
//record our open status in global.
serPortOpened = true;
```

Closing a Port

Once an application is finished with the serial port, it must close the port using the [SrmClose](#) function (or [SerClose](#) function if you are using the old Serial Manager). If `SrmClose` returns no error, it indicates that the Serial Manager has successfully closed the driver and deallocated the data structures used for maintaining the port.

To conserve battery power, it is important not to leave the serial port open longer than necessary. It is generally better to close and reopen the connection multiple times than it is to leave it open unnecessarily.

Configuring the Port

A newly opened port has the default configuration. The default port configuration is:

- A receive queue of 512 bytes
- A default CTS timeout (currently 5 seconds) set
- 1 stop bit
- 8 data bits
- Hardware handshaking on input
- Flow control enabled
- For RS-232 connections, the baud rate you specified when you opened the port.

You can change this configuration if necessary before sending or receiving data.

Increasing the Receive Queue Buffer Size

The default receive queue size is 512 bytes. If you notice a large number of hardware overruns or software overruns while running your application, consider replacing the default receive queue with a bigger one.

To use a custom receive queue, an application must:

- Allocate a memory chunk for the custom queue. This needs to be an actual memory chunk, not a global variable or an offset from the chunk.
- Call [`SrmSetReceiveBuffer`](#) (or [`SerSetReceiveBuffer`](#) in the old Serial Manager) with the new buffer and the size of the new buffer as arguments.
- Restore the default queue before closing the port. That way, any bits sent in have a place to go.
- Deallocate the custom queue after restoring the default queue. The system only deallocates the default queue.

The following code fragment illustrates replacing the default queue with a custom queue.

Listing 5.3 Replacing the receive queue

```
#define myCustomSerQueueSize 1024
void *customSerQP;
// Allocate a dynamic memory chunk for our custom receive
// queue.
customSerQP = MemPtrNew(myCustomSerQueueSize);
// Replace the default receive queue.
if (customSerQP) {
    err = SrmSetReceiveBuffer(portId, customSerQP,
                             myCustomSerQueueSize);
}

// ... do Serial Manager work

// Now restore default queue and delete custom queue.
// Pass NULL for the buffer and 0 for bufSize to restore the
// default queue.
err = SrmSetReceiveBuffer(portId, NULL, 0);
if(customSerQP) {
    MemPtrFree(customSerQP);
    customSerQP = NULL;
}
```

Changing Other Configuration Settings

To change the other serial port settings, use [SrmControl](#) (or [SerSetSettings](#) in the old Serial Manager API).

[Listing 5.4](#) configures the serial port for 19200 baud, 8 data bits, even parity, 1 stop bit, and full hardware handshake (input and output) with a CTS timeout of 0.5 seconds. The CTS timeout specifies the maximum number of system ticks the serial library will wait to send a byte when the CTS input is not asserted. The CTS timeout is ignored if `srmSettingsFlagCTSAutoM` is not set.

Listing 5.4 Changing the configuration (new Serial Manager)

```
Err err;
Int32 paramSize;
Int32 baudRate = 19200;
UInt32 flags = srmSettingsFlagBitsPerChar8 |
srmSettingsFlagParityOnM | srmSettingsFlagParityEvenM |
srmSettingsFlagStopBits1 | srmSettingsFlagRTSAutoM |
srmSettingsFlagCTSAutoM;
```

Serial Communication

The Serial Manager

```
Int32 ctsTimeout = SysTicksPerSecond() / 2;

paramSize = sizeof(baudRate);
err = SrmControl(portId, srmCtlSetBaudRate, &baudRate,
    &paramSize);

paramSize = sizeof(flags);
err = SrmControl(portId, srmCtlSetFlags, &flags, &paramSize);

paramSize = sizeof(ctsTimeout);
err = SrmControl(portId, srmCtlSetCtsTimeout, &ctsTimeout,
    &paramSize);
```

[Listing 5.5](#) shows how to set up the same configuration in the old Serial Manager.

Listing 5.5 Changing the configuration (old Serial Manager)

```
SerSettingsType serSettings;

serSettings.baudRate = 19200;
serSettings.flags = serSettingsFlagBitsPerChar8 |
serSettingsFlagParityOnM | serSettingsFlagParityEvenM |
serSettingsFlagStopBits1 | serSettingsFlagRTSAutoM |
serSettingsFlagCTSAutoM;
serSettings.ctsTimeout = SysTicksPerSecond() / 2;
err = SerSetSettings(refNum, &serSettings);
```

The settings remain in effect until you change them again or close the connection. As you configure the Serial Manager, note the following points:

- Set a CTS timeout if a lack of a CTS signal means a loss of connection. (Use -1 to specify no timeout.)
- If `srmSettingsFlagRTSAutoM` is not set, the RTS output will be permanently asserted. (This flag is set by default.)
- For baud rates above 19200, the use of full hardware handshaking (`srmSettingsFlagRTSAutoM | SrmSettingsFlagCTSAutoM`) is advised.

If you want to find out what the current configuration is, pass one of the `srmCtlGet...` op codes to the `SrmControl` function. For example, to find out the current baud rate, pass

`srnCtlGetBaudRate`. To find out the current configuration in the old Serial Manager, use the [SerGetSettings](#) function.

Sending Data

To send data, use [SrmSend](#) (or [SerSend](#) in the old Serial Manager). Sending data is performed synchronously. To send data, the application only needs to have an open connection with a port that has been configured properly and then specify a buffer to send. The larger the buffer to send, the longer the send function operates before returning to the calling application. The send function returns the actual number of bytes that were placed in the UART's FIFO. This makes it possible to determine what was sent and what wasn't in case of an error.

[Listing 5.6](#) illustrates the use of `SrmSend`.

Listing 5.6 Sending data

```
UInt32 toSend, numSent;
Err err;
Char msg[] = "logon\n";
toSend = StrLen(msg);
numSent = SrmSend(portId, msg, toSend, &err);
if (err == serErrTimeout) {
    //cts timeout detected
}
```

If `SrmSend` returns an error, or if you simply want to ensure that all data has been sent, you can use any of the following functions:

- Use [SrmSendWait](#) ([SerSendWait](#) in the old Serial Manager) if you need to wait for all data to leave the device before performing other actions. The `SrmSend` function returns when it has loaded the last byte into the FIFO. The `SrmSendWait` function does not return until the FIFO empties. Like `SrmSend`, the `SrmSendWait` call can timeout if CTS handshaking is on and the CTS timeout value is reached. Note that the old Serial Manager version of this call, `SerSendWait`, takes a timeout parameter, but this parameter is ignored. The new Serial Manager call simply takes the port ID.

Serial Communication

The Serial Manager

- Use [SrmSendCheck](#) (or `SerSendCheck`) to determine how many bytes are left in the FIFO. Note that not all serial devices support this feature.

If the hardware does not provide an exact reading, the function returns an approximate number: 8 means full, 4 means approximately half-full. If the function returns 0, the queue is empty.

- The [SrmSendFlush](#) (or [SerSendFlush](#)) function can be used to flush remaining bytes in the FIFO that have not been sent.

Receiving Data

Receiving data is a more involved process because it depends on the receiving application actually listening for data from the port.

To receive data, an application must do the following:

- Ensure that the code does not loop indefinitely waiting for data from the receive queue.

The most common way to do this is to pass a timeout value to [EvtGetEvent](#).

Virtual devices often run in the same thread as applications. If you don't specify a timeout for the event loop, it can prevent the virtual device and other serial related code from properly handling received data.

If your code is outside of an event loop, you can use the [EvtEventAvail](#) function to see if the system has an event it needs to process, and if so, call `SysHandleEvent`.

- To avoid having the system go to sleep while it's waiting to receive data, an application should call [EvtResetAutoOffTimer](#) periodically (or call [EvtSetAutoOffTimer](#)). For example, the Serial Link Manager automatically calls `EvtResetAutoOffTimer` each time a new packet is received.

TIP: For many applications, the auto-off feature presents no problem. Use `EvtResetAutoOffTimer` with discretion; applications that use it drain the battery.

- To receive the data, call [SrmReceive](#) (or [SerReceive](#)). Pass a buffer, the number of bytes you want to receive, and the inter-byte timeout in system ticks. This call blocks until all the requested data have been received or an error occurs. This function returns the number of bytes actually received. (The error is returned in the last parameter that you pass to the function.)
- If you want to wait until a certain amount of data is available before you receive it, call [SrmReceiveWait](#) (or [SerReceiveWait](#)) before you call `SrmReceive`. Specify the number of bytes to wait for, which must be less than the current receive buffer size, and the amount of time to wait in system ticks. If `SrmReceiveWait` returns `errNone`, it means that the receive queue contains the specified number of bytes. If it returns anything other than `errNone`, that number of bytes is not available.

`SrmReceiveWait` is useful, for example, if you are receiving data packets. You can use `SrmReceiveWait` to wait until an entire packet is available and then read that packet.

- It's common to want to receive data only when the system is idle. In this case, have your event loop respond to the `nilEvent`, which is generated whenever `EvtGetEvent` times out and another event is not available. In response to this event, call [SrmReceiveCheck](#) (or [SerReceiveCheck](#)). Unlike `SrmReceiveWait`, `SrmReceiveCheck` does not block awaiting input. Instead, it immediately returns the number of bytes currently in the receive queue. If there is data in the receive queue, call `SrmReceive` to receive it. If the queue has no data, your event handler can simply return and allow the system to perform other tasks.
- Check for and handle error conditions returned by any of the receive function calls as described in "[Handling Errors](#)" on page 108.

IMPORTANT: Always check for line errors. Due to unpredictable conditions, there is no guaranteed of success. If a line error occurs, all other Serial Manager calls fail until you clear the error.

Serial Communication

The Serial Manager

For example code that shows how to receive data, see “[Receive Data Example](#)” on page 109.

In the new Serial Manager, you can directly access the receive queue using [SrmReceiveWindowOpen](#), and [SrmReceiveWindowClose](#). These functions allow fast access to the buffer to reduce buffer copying. These functions are not supported on systems where the new Serial Manager feature set is not present.

Handling Errors

If an error occurs on the line, all of the receive functions return the error condition `serErrLineErr`. This error will continue to be returned until you explicitly clear the error condition and continue.

To clear line errors, call [SrmClearErr](#) (or [SerClearErr](#)).

If you want more information about the error, call [SrmGetStatus](#) (or [SerGetStatus](#)) before you clear the line.

[Listing 5.7](#) checks whether a framing or parity error have returned and clears the line errors.

Listing 5.7 Handling line errors (new Serial Manager)

```
void HandleSerReceiveErr(UInt16 portId, Err err) {
    UInt32 lineStatus;
    UInt16 lineErrs;

    if (err == serErrLineErr) {
        SrmGetStatus(portId, &lineStatus, &lineErrs);
        // test for framing or parity error.
        if (lineErrs & serLineErrorFraming | serLineErrorParity)
        {
            //framing or parity error occurred. Do something.
        }
        SrmClearErr(portId);
    }
}
```

[Listing 5.8](#) performs the same tasks using the old Serial Manager. Note that the `SerGetStatus` call looks a little different from the `SrmGetStatus` call.

Listing 5.8 Handling line errors (old Serial Manager)

```
void HandleSerReceiveErr(UInt16 refNum, Err err) {
    UInt16 lineErrs;
    Boolean ctsOn, dsrOn;

    if (err == serErrLineErr) {
        lineErrs = SerGetStatus(refNum, &ctsOn, &dsrOn);
        // test for framing or parity error.
        if (lineErrs & serLineErrorFraming | serLineErrorParity)
        {
            //framing or parity error occurred. Do something.
        }
        SerClearErr(refNum);
    }
}
```

TIP: See “[Common Errors](#)” on page 113 for some common causes of line errors and how to fix them.

In some cases, you may want to discard any received data when an error occurs. For example, if your protocol is packet driven and you detect data corruption, you should flush the buffer before you continue. To do so, call [SrmReceiveFlush](#) (or [SerReceiveFlush](#)). This function flushes any bytes in the receive queue and then calls `SrmClearErr` for you.

`SrmReceiveFlush` takes a timeout value as a parameter. If you specify a timeout, it waits that period of time for any other data to be received in the queue and flushes it as well. If you pass 0 for the timeout, it simply flushes the data currently in the queue, clears the line errors, and returns. The flush timeout has to be large enough to flush out the noise but not so large that it flushes part of the next packet.

Receive Data Example

[Listing 5.9](#) shows how to receive large blocks of data using the Serial Manager.

Serial Communication

The Serial Manager

Listing 5.9 Receiving Data Using the Serial Manager

```
#include <PalmOS.h> // all the system toolbox headers
#include <SerialMgr.h>
#define k2KBytes 2048
/*****
 *
 * FUNCTION: RcvSerialData
 *
 * DESCRIPTION: An example of how to receive a large chunk of data
 * from the Serial Manager. This function is useful if the app
 * knows it must receive all this data before moving on. The
 * YourDrainEventQueue() function is a chance for the application
 * to call EvtGetEvent and handle other application events.
 * Receiving data whenever it's available during idle events
 * might be done differently than this sample.
 *
 * PARAMETERS:
 * thePort -> valid portID for an open serial port.
 * rcvDataP -> pointer to a buffer to put the received data.
 * bufSize <-> pointer to the size of rcvBuffer and returns
 * the number of bytes read.
 *
 *****/
Err RcvSerialData(UInt16 thePort, UInt8 *rcvDataP, UInt32 *bufSizeP)
{
    UInt32 bytesLeft, maxRcvBlkSize, bytesRcvd, waitTime, totalRcvBytes = 0;
    UInt8 *newRcvBuffer;
    UInt16 dataLen = sizeof(UInt32);
    Err* error;

    // The default receive buffer is only 512 bytes; increase it if
    // necessary. The following lines are just an example of how to
    // do it, but its necessity depends on the ability of the code
    // to retrieve data in a timely manner.
    newRcvBuffer = MemPtrNew(k2KBytes); // Allocate new rcv buffer.
    if (newRcvBuffer)
        // Set new rcv buffer.
        error = SrmSetReceiveBuffer(thePort, newRcvBuffer, k2KBytes);
        if (error)
            goto Exit;
    else
        return memErrNotEnoughSpace;

    // Initialize the maximum bytes to receive at one time.
    maxRcvBlkSize = k2KBytes;
    // Remember how many bytes are left to receive.
    bytesLeft = *bufSizeP;
```

```
// Only wait 1/5 of a second for bytes to arrive.
waitTime = SysTicksPerSecond() / 5;

// Now loop while getting blocks of data and filling the buffer.
do {
    // Is the max size larger then the number of bytes left?
    if (bytesLeft < maxRcvBlkSize)
        // Yes, so change the rcv block amount.
        maxRcvBlkSize = bytesLeft;
    // Try to receive as much data as possible,
    // but wait only 1/5 second for it.
    bytesRcvd = SrmReceive(thePort, rcvDataP, maxRcvBlkSize, waitTime,
        &error);
    // Remember the total number of bytes received.
    totalRcvBytes += bytesRcvd;
    // Figure how many bytes are left to receive.
    bytesLeft -= bytesRcvd;
    rcvDataP += bytesRcvd; // Advance the rcvDataP.
    // If there was a timeout and no data came through...
    if ((error == serErrTimeout) && (bytesRcvd == 0))
        goto ReceiveError; // ...bail out and report the error.
    // If there's some other error, bail out.
    if ((error) && (error != serErrTimeout))
        goto ReceiveError;

    // Call a function to handle any pending events because
    // someone might press the cancel button.
    YourDrainEventQueue();
    // Continue receiving data until all data has been received.
} while (bytesLeft);

ReceiveError:
    // Clearing the receive buffer can also be done right before
    // the port is to be closed.
    // Set back the default buffer when we're done.
    SrmSetReceiveBuffer(thePort, 0L, 0);

Exit:
    MemPtrFree(newRcvBuffer); // Free the space.
    *bufSizeP = totalRcvBytes;
    return error;
}
```

Serial Manager Tips and Tricks

The following tips and tricks help you debug your serial application and help avoid errors in the first place.

Debugging Tips

The following are some tips to help you track down errors while debugging.

- Debug first using the Palm OS Emulator. Debug on the device last.

The Palm OS Emulator supports all Serial Manager functions and lets you test applications that use the Serial Manager. You can use the desktop computer's serial port to connect to outside devices. For more information on how to set up and use the emulator to debug serial communications, see the emulator documentation.

- Track communication errors and the amount of data sent and received.

In your debug build, maintain individual counts for the amount of data transferred and for each communication error of interest. This includes timeouts and retries for reliable protocols.

- Use an easily recognizable start-of-frame signature. This helps during debugging of packet-based protocols.
- Implement developer back doors for debugging.

Implement a mechanism to trigger one or more debugging features at runtime without recompiling. For example, you may want to create a back door to disable the receive timeout on one side to prevent it from timing out while you are debugging the other side. Another back door might print some debugging information to the display. For example, your application might look for a pen down event in the upper right corner of the digitizer while the page-up key is being pressed to trigger one of your back doors.

- Use the HotSync[®] log for debug-time error logging on the device.

You may use `DlkSetLogEntry` to write your debugging messages to the HotSync log on the device. The HotSync log will accept up to 2KB of text. You may then switch to the HotSync application to view the log.

NOTE: Restrict writing to the HotSync log to debugging. Users will not appreciate having your debugging messages in their HotSync log.

- If you have a protocol analyzer, use it to examine the data that is actually sent and received.

Common Errors

Even if you're careful, errors may crop up. Here are some frequently encountered problems and their solutions.

- Nothing is being received
Check for a broken or incorrectly wired connection and make sure the expected handshaking signals are received.
- Garbage is received
Check that baud rate, word length, and/or parity agree.
- Baud rate mismatch
If the two sides disagree on the baud rate, it may either show up as a framing error, or the number of received characters will be different from the number that was sent.
- Parity error
Parity errors indicate that the data has been damaged. They can also mean that the sender and receiver have not been configured to use the same parity or word length.
- Word-length mismatch
Word-length mismatches may show up as a framing error.

Serial Communication

The Serial Manager

- Framing error

Framing errors indicate a mismatch in the number of bits and are reported when the stop bit is not received when it is expected. This could indicate damaged data, but frequently it signals a disagreement in common baud rate, word length, or parity setting.

- Hardware overrun

The Serial Manager's receive interrupt service routine cannot keep up with incoming data. Enable full hardware handshaking (see "[Configuring the Port](#)" on page 102).

- Software overrun

The application is not reading incoming data fast enough. Read data more frequently, or replace the default receive queue with a larger one. (see "[Configuring the Port](#)" on page 102).

Writing a Virtual Device Driver

If the new Serial Manager feature set is present, the Serial Manager supports the ability to add virtual device drivers to the system. Virtual serial device drivers transmit and receive data in blocks instead of a byte at a time.

A virtual driver is a code resource (ID=0) that is independently compiled and installed on a Palm device. Virtual driver .prc files are of file type 'vdrv' and their creator type is chosen by the developer (and must be registered with Palm, Inc. in the creator ID database). When the Serial Manager is installed, it searches the Database Manager for code resources of the 'vdrv' type and then calls the driver's entry point function to get information about the features and capabilities of this virtual device. Unlike physical serial device drivers, virtual device drivers send and receive data in blocks instead of transferring one byte at a time. Their purpose is to abstract a level of communication protocol away from serial devices without forcing applications to work through a different API than the Serial Manager that may already be used for normal RS-232 serial communication.

NOTE: Creator types with all lowercase letters are reserved by Palm, Inc. For more information about assigning and registering creator types, see “[Assigning a Database Type and Creator ID](#)” on page 15 of the *Palm OS Programmer’s Companion*, vol. I.

Virtual Driver Functions

There are six functions that each virtual driver must minimally support in order to work with the Serial Manager. These functions are briefly described in this section. For details on the exact operations each function must perform, see the function descriptions in the *Palm OS Programmer’s API Reference*.

The functions a virtual driver must implement include:

- [DrvEntryPoint](#) must be the first function defined in a virtual driver code resource and must be marked as the `__Startup__` function of the code resource. When the code resource is loaded, the Serial Manager jumps to the beginning of the code resource and begins execution at `DrvEntryPoint`. This function is called at system restart, when the Serial Manager is building a database of installed drivers and their capabilities, and when a virtual port is opened.
- The [VdrvOpenProcPtr](#) and `VdrvOpenProcV4Ptr` function is responsible for initializing the virtual device to begin communication.
- The [VdrvCloseProcPtr](#) function must handle all activities needed to close the virtual device.
- [VdrvControlProcPtr](#) extends the `SrmControl` function to the level of the virtual device.
- [VdrvStatusProcPtr](#) returns a bitfield that describes the current state of the virtual device.
- [VdrvWriteProcPtr](#) writes a block of bytes to the virtual device.
- The optional [VdrvControlCustomProcPtr](#) function can handle any custom control codes defined specifically for this virtual driver.

Note that there is no virtual read function in the current implementation. Virtual devices must save received data by using the functions provided in the [DrvRcvOType](#) when they are notified that data is available using some callback mechanism.

For an example of how to implement a virtual serial driver, download the CryptoDrv example from the Palm OS Developer Knowledge Base.

The Connection Manager

The Connection Manager allows applications to access, add, and delete connection profiles contained in the Connection preferences panel. Earlier releases of the Palm OS have a Modem preferences panel. The Connection panel replaces the Modem panel. This change was made as more connection choices (serial cable, IR, modem, network and so on) became available to users.

The Connection Manager was introduced at the same time as the Connection panel to manage connection profiles that save preferences for various connection types. A connection profile includes information on the hardware port to be used for a particular connection, the port details (speed, flow control, modem initialization string), and any other pertinent information.

The Connection Manager is not available on all Palm devices. You must ensure that it is present before you can make Connection Manager calls. If the [New Serial Manager Feature Set](#) is present, then at least the basic version of the Connection Manager is available. If the [Connection Manager Feature Set](#) is present, then an expanded version of the Connection Manager is available. This expanded Connection Manager allows profiles that specify communications with mobile phones and profiles that specify communications with Bluetooth devices. It is also more extensible, allowing you to create your own profile parameters if necessary.

NOTE: Although the Connection Manager supports Bluetooth connections, Bluetooth requires additional hardware and software that is not available as of this writing.

The basic version of the Connection Manager provides functions that list the saved connection profiles ([CncGetProfileList](#)), return details for a specific profile ([CncGetProfileInfo](#)), add a profile ([CncAddProfile](#)), and delete a profile ([CncDeleteProfile](#)).

When you create a profile with the basic Connection Manager, each profile parameter is passed as a parameter to the `CncAddProfile` function. Similarly, when you request profile information, each profile parameter is passed in an output parameter to `CncGetProfileInfo`.

Because the newer, expanded Connection Manager supports more types of connections than the basic Connection Manager, it also supports many more types of profile parameters. For this reason, you now retrieve profile information one parameter at a time using [CncProfileSettingGet](#). In the new API, constants specify the predefined profile parameters. (See “[Profile Parameter Constants](#)” on page 1092 of the *Palm OS Programmer’s API Reference*.) For example, to retrieve the connection’s port, you use code similar to that shown in [Listing 5.10](#).

Listing 5.10 Retrieving port information

```
UInt16 dataSize;
UInt32 portCreator;

dataSize = kCncParamPortSize;
err = CncProfileSettingGet(profileID, kCncParamPort,
    &portCreator, &dataSize);
```

To create a profile, you first must obtain a unique profile ID and then set the profile parameters one by one as shown in [Listing 5.11](#). Note that [Listing 5.11](#) uses [CncProfileOpenDB](#) to open the Connection Manager profile database and [CncProfileCloseDB](#) to close it. These are not required calls. If you don’t explicitly open and close the database, each Connection Manager function opens the database, performs its work, and then closes the database. By calling `CncProfileOpenDB` in front of a series of Connection Manager calls and calling `CncProfileCloseDB` at the end, you save the overhead of having each function open and close the database.

Listing 5.11 Creating a connection profile

```
// Open the Connection Manager profile database;
err = CncProfileOpenDB();
// obtain new profile ID.
err = CncProfileCreate(&profileId);

if (!err) {
    // Create a name for the profile.
    err = CncProfileSettingSet(profileId, kCncParamName,
                               myProfileName, StrLen(myProfileName)+1);

    // Set some other required parameters.
    port = serPortLocalHotSync;
    err = CncProfileSettingSet(profileId, kCncParamPort,
                               &port, kCncParamPortSize);
    baud = 57600;
    err = CncProfileSettingSet(profileId, kCncParamBaud,
                               &baud, kCncParamBaudSize);
    deviceKind = kCncDeviceKindSerial;
    err = CncProfileSettingSet(profileId, kCncParamDeviceKind,
                               &deviceKind, kCncParamDeviceKindSize);
}

// close the profile database.
err = CncProfileCloseDB();
```

The expanded Connection Manager API also allows you to create profile parameters that are unique to your type of connection. You can do so with the [CncDefineParamID](#) macro. See its description in the *Palm OS Programmer's API Reference* for more information.

The Serial Link Protocol

The Serial Link Protocol (SLP) provides an efficient packet send and receive mechanism that is used by the Palm desktop software and debugger. SLP provides robust error detection with CRC-16. SLP is a best-effort protocol; it does not guarantee packet delivery (packet delivery is left to the higher-level protocols). For enhanced error detection and implementation convenience of higher-level protocols, SLP specifies packet type, source, destination, and transaction ID information as an integral part of its data packet structure.

SLP Packet Structures


The following sections describe:

- [SLP Packet Format](#)
- [Packet Type Assignment](#)
- [Socket ID Assignment](#)
- [Transaction ID Assignment](#)

SLP Packet Format

Each SLP packet consists of a packet header, client data of variable size, and a packet footer, as shown in [Figure 5.3](#).

Figure 5.3 Structure of a Serial Link Packet



- The **packet header** contains the packet signature, the destination socket ID, the source socket ID, packet type, client data size, transaction ID, and header checksum. The packet signature is composed of the three bytes 0xBE, 0xEF, 0xED, in that order. The header checksum is an 8-bit arithmetic checksum of the entire packet header, not including the checksum field itself.
- The **client data** is a variable-size block of binary data specified by the user and is not interpreted by the Serial Link Protocol.
- The **packet footer** consists of the CRC-16 value computed over the packet header and client data.

Packet Type Assignment

Packet type values in the range of 0x00 through 0x7F are reserved for use by the system software. The following packet type assignments are currently implemented:

- 0x00 Remote Debugger, Remote Console, and System Remote Procedure Call packets.
- 0x02 PADP packets.
- 0x03 Loop-back test packets.

Socket ID Assignment

Socket IDs are divided into two categories: static and dynamic. The static socket IDs are “well-known” socket ID values that are reserved by the components of the system software. The dynamic socket IDs are assigned at runtime when requested by clients of SLP. Static socket ID values in the ranges 0x00 through 0x03 and 0xE0 through 0xFF are reserved for use by the system software. The following static socket IDs are currently implemented or reserved:

- 0x00 Remote Debugger socket.
- 0x01 Remote Console socket.
- 0x02 Remote UI socket.
- 0x03 Desktop Link Server socket.
- 0x04 -0xCF Reserved for dynamic assignment.
- 0xD0 - 0xDF Reserved for testing.

Transaction ID Assignment

Transaction ID values are not interpreted by the Serial Link Protocol and are for the sole benefit of the higher-level protocols. The following transaction ID values are currently reserved:

- 0x00 and 0xFF Reserved for use by the system software.
- 0x00 Reserved by the Palm OS implementation of SLP to request automatic transaction ID generation.
- 0xFF Reserved for the connection manager’s WakeUp packets.

Transmitting an SLP Packet

This section provides an overview of the steps involved in transmitting an SLP packet. The next section describes the implementation.

Transmission of an SLP packet consists of these steps:

1. Fill in the packet header and compute its checksum.
2. Compute the CRC-16 of the packet header and client data.
3. Transmit the packet header, client data, and packet footer.
4. Return an error code to the client.

Receiving an SLP Packet

Receiving an SLP packet consists of these steps:

1. Scan the serial input until the packet header signature is matched.
2. Read in the rest of the packet header and validate its checksum.
3. Read in the client data.
4. Read in the packet footer and validate the packet CRC.
5. Dispatch/return an error code and the packet (if successful) to the client.

The Serial Link Manager

The serial link manager is the Palm OS implementation of the Serial Link Protocol.

Serial link manager provides the mechanisms for managing multiple client sockets, sending packets, and receiving packets both synchronously and asynchronously. It also provides support for the Remote Debugger and Remote Procedure Calls (RPC).

Using the Serial Link Manager

Before an application can use the services of the serial link manager, the application must open the manager by calling [SlkOpen](#). Success is indicated by error codes of 0 (zero) or `slkErrAlreadyOpen`. The return value `slkErrAlreadyOpen` indicates that the serial link manager has already been opened (most likely by another task). Other error codes indicate failure.

When you finish using the serial link manager, call [SlkClose](#). `SlkClose` may be called only if [SlkOpen](#) returned 0 (zero) or `slkErrAlreadyOpen`. When the open count reaches zero, `SlkClose` frees resources allocated by `SlkOpen`.

To use the serial link manager socket services, open a Serial Link socket by calling [SlkOpenSocket](#). Pass a reference number or port ID (for the Serial Manager) of an opened and initialized communications library (see `SlkClose`), a pointer to a memory location for returning the socket ID, and a Boolean indicating whether the socket is static or dynamic. If a static socket is being opened, the memory location for the socket ID must contain the desired socket number. If opening a dynamic socket, the new socket ID is returned in the passed memory location. Sharing of sockets is not supported. Success is indicated by an error code of 0 (zero). For information about static and dynamic socket IDs, see [“Socket ID Assignment” on page 121](#).

When you have finished using a Serial Link socket, close it by calling [SlkCloseSocket](#). This releases system resources allocated for this socket by the serial link manager.

To obtain the communications library reference number for a particular socket, call `SlkSocketRefNum`. The socket must already be open. To obtain the port ID for a socket, if you are using the Serial Manager, call [SlkSocketPortID](#).

To set the interbyte packet receive timeout for a particular socket, call [SlkSocketSetTimeout](#).

To flush the receive stream for a particular socket, call [SlkFlushSocket](#), passing the socket number and the interbyte timeout.

Serial Communication

The Serial Link Manager

To register a socket listener for a particular socket, call [SlkSetSocketListener](#), passing the socket number of an open socket and a pointer to the `SlkSocketListenType` structure. Because the serial link manager does not make a copy of the `SlkSocketListenType` structure but instead saves the pointer passed to it, the structure may not be an automatic variable (that is, allocated on the stack). The `SlkSocketListenType` structure may be a global variable in an application or a locked chunk allocated from the dynamic heap. The `SlkSocketListenType` structure specifies pointers to the socket listener procedure and the data buffers for dispatching packets destined for this socket. Pointers to two buffers must be specified:

- Packet header buffer (size of `SlkPktHeaderType`).
- Packet body buffer, which must be large enough for the largest expected client data size.

Both buffers can be application global variables or locked chunks allocated from the dynamic heap.

The socket listener procedure is called when a valid packet is received for the socket. Pointers to the packet header buffer and the packet body buffer are passed as parameters to the socket listener procedure. The serial link manager does not free the `SlkSocketListenType` structure or the buffers when the socket is closed; freeing them is the responsibility of the application. For this mechanism to function, some task needs to assume the responsibility to “drive” the serial link manager receiver by periodically calling [SlkReceivePacket](#).

To send a packet, call [SlkSendPacket](#), passing a pointer to the packet header (`SlkPktHeaderType`) and a pointer to an array of `SlkWriteDataType` structures. [SlkSendPacket](#) stuffs the signature, client data size, and the checksum fields of the packet header. The caller must fill in all other packet header fields. If the transaction ID field is set to 0 (zero), the serial link manager automatically generates and stuffs a new non-zero transaction ID. The array of `SlkWriteDataType` structures enables the caller to specify the client data part of the packet as a list of noncontiguous blocks. The end of list is indicated by an array element with the size field set to 0 (zero). [Listing 5.12](#) incorporates the processes described in this section.

Listing 5.12 Sending a Serial Link Packet

```
Err                err;
//serial link packet header
SlkPktHeaderType    sendHdr;
//serial link write data segments
SlkWriteDataType    writeList[2];
//packet body(example packet body)
UInt8              body[20];

// Initialize packet body
...

// Compose the packet header. Let Serial Link Manager
// set the transId.
sendHdr.dest = slkSocketDLP;
sendHdr.src = slkSocketDLP;
sendHdr.type = slkPktTypeSystem;
sendHdr.transId = 0;

// Specify packet body
writeList[0].size = sizeof(body);    //first data block size
writeList[0].dataP = body;    //first data block pointer
writeList[1].size = 0;    //no more data blocks

// Send the packet
err = SlkSendPacket( &sendHdr, writeList );
...
}
```

Listing 5.13 Generating a New Transaction ID

```
//
// Example: Generating a new transaction ID given the
// previous transaction ID. Can start with any seed value.
//

UInt8 NextTransactionID (UInt8 previousTransactionID)
{
    UInt8  nextTransactionID;

    // Generate a new transaction id, avoid the
    // reserved values (0x00 and 0xFF)
    if ( previousTransactionID >= (UInt8)0xFE )
        nextTransactionID = 1;    // wrap around
}
```

Serial Communication

Summary of Serial Communications

```
else
    nextTransactionID = previousTransactionID + 1;
    // increment

return nextTransactionID;
}
```

To receive a packet, call [SlkReceivePacket](#). You may request a packet for the passed socket ID only, or for any open socket that does not have a socket listener. The parameters also specify buffers for the packet header and client data, and a timeout. The timeout indicates how long the receiver should wait for a packet to begin arriving before timing out. A timeout value of (-1) means “wait forever.” If a packet is received for a socket with a registered socket listener, the packet is dispatched via its socket listener procedure.

Summary of Serial Communications

New and Old Serial Manager Functions

Opening and Closing the Port

[SrmOpen](#)

[SrmOpenBackground](#)

[SerOpen](#)

[SerClose](#)

[SrmExtOpen](#)

[SrmExtOpenBackground](#)

[SrmClose](#)

Receiving Data

[SrmReceive](#)

[SrmReceiveCheck](#)

[SrmReceiveFlush](#)

[SrmReceiveWait](#)

[SrmReceiveWindowClose](#)

[SrmReceiveWindowOpen](#)

[SerReceive](#)

[SerReceiveCheck](#)

[SerReceiveFlush](#)

[SerReceiveWait](#)

Sending Data

[SrmSend](#)

[SrmSendCheck](#)

[SrmSendFlush](#)

[SrmSendWait](#)

[SerSend](#)

[SerSendFlush](#)

[SerSendWait](#)

New and Old Serial Manager Functions

Configuring the Port

| | |
|-------------------------------------|-------------------------------------|
| SrmSetReceiveBuffer | SerControl |
| SrmControl | SerSetReceiveBuffer |
| SrmCustomControl | SerSetSettings |
| | SerGetSettings |

Error Checking

| | |
|------------------------------|------------------------------|
| SrmClearErr | SerClearErr |
| SrmGetStatus | SerGetStatus |

Obtaining Device Information

| | |
|-----------------------------------|----------------------------------|
| SrmGetDeviceCount | SrmGetDeviceInfo |
|-----------------------------------|----------------------------------|

Implementing a Wakeup Handler

| | |
|---------------------------------------|-------------------------------------|
| SrmPrimeWakeupHandler | SrmSetWakeupHandler |
|---------------------------------------|-------------------------------------|

Virtual Driver Functions

| | |
|------------------------------------|--|
| DrvEntryPoint | VdrvStatusProcPtr |
| GetSizeProcPtr | VdrvWriteProcPtr |
| GetSpaceProcPtr | VdrvControlCustomProcPtr |
| VdrvControlProcPtr | WriteBlockProcPtr |
| VdrvOpenProcPtr | WriteByteProcPtr |
| VdrvOpenProcV4Ptr | SignalCheckPtr |

Serial Communication

Summary of Serial Communications

Connection Manager Functions

Basic Connection Manager Functions

| | |
|----------------------------------|-----------------------------------|
| CncAddProfile | CncGetProfileInfo |
| CncDeleteProfile | CncGetProfileList |

Extended Connection Manager Functions

| | |
|--|--|
| CncProfileCreate | CncGetParamType |
| CncProfileDelete | CncGetSystemFlagBitnum |
| CncProfileGetCurrent | CncGetTrueParamID |
| CncProfileGetIDFromIndex | CncIsFixedLengthParamType |
| CncProfileGetIDFromName | CncIsSystemFlags |
| CncProfileGetIndex | CncIsSystemRange |
| CncProfileOpenDB | CncIsThirdPartiesRange |
| CncProfileSetCurrent | CncIsVariableLengthParamType |
| CncProfileSettingGet | CncProfileCloseDB |
| CncProfileSettingSet | CncProfileCount |

Serial Link Manager Functions

| | |
|--------------------------------|--------------------------------------|
| SlkClose | SlkReceivePacket |
| SlkCloseSocket | SlkSendPacket |
| SlkFlushSocket | SlkSetSocketListener |
| SlkOpen | SlkSocketPortID |
| SlkOpenSocket | SlkSocketSetTimeout |

Network Communication

Two different Palm OS® libraries provide network services to applications:

- The net library provides basic network services using TCP and UDP via a socket API. This library is discussed in the section [Net Library](#).
- The Internet library builds on the net library to provide a socket-like API to high-level Internet protocols such as HTTP. This library is discussed in the section [Internet Library](#).

Net Library

The net library allows Palm OS applications to easily establish a connection with any other machine on the Internet and transfer data to and from that machine using the standard TCP/IP protocols.

The basic network services provided by the net library include:

- Stream-based, guaranteed delivery of data using TCP (Transmission Control Protocol).
- Datagram-based, best-effort delivery of data using UDP (User Datagram Protocol).

You can implement higher-level Internet-based services (file transfer, e-mail, web browsing, etc.) on top of these basic delivery services.

IMPORTANT: Applications cannot directly use the net library to make wireless connections. Use the Internet library for wireless connections.

Network Communication

Net Library

This section describes how to use the net library in your application. It covers:

- [About the Net Library](#)
- [Net Library Usage Steps](#)
- [Obtaining the Net Library's Reference Number](#)
- [Setting Up Berkeley Socket API](#)
- [Setup and Configuration Calls](#)
- [Opening the Net Library](#)
- [Closing the Net Library](#)
- [Version Checking](#)
- [Network I/O and Utility Calls](#)
- [Berkeley Sockets API Functions](#)
- [Extending the Network Login Script Support](#)

About the Net Library

The net library consists of two parts: a netlib interface and a net protocol stack.

The **netlib interface** is the set of routines that an application calls directly when it makes a net library call. These routines execute in the caller's task like subroutines of the application. They are not linked in with the application, however, but are called through the library dispatch mechanism.

With the exception of functions that open, close, and set up the net library, the net library's API maps almost directly to the Berkeley UNIX sockets API, the de facto standard API for Internet applications. You can compile an application written to use the Berkeley sockets API for the Palm OS with only slight changes to the source code.

The **net protocol stack** runs as a separate task in the operating system. Inside this task, the TCP/IP protocol stack runs, and received packets are processed from the network device drivers. The netlib interface communicates with the net protocol stack through an operating system mailbox queue. It posts requests from

applications into the queue and blocks until the net protocol stack processes the requests.

Having the net protocol stack run as a separate task has two big advantages:

- The operating system can switch in the net protocol stack to process incoming packets from the network even if the application is currently busy.
- Even if an application is blocked waiting for some data to arrive off the network, the net protocol stack can continue to process requests for other applications.

One or more network interfaces run inside the net protocol stack task. A **network interface** is a separately linked database containing code necessary to abstract link-level protocols. For example, there are separate network interface databases for PPP and SLIP. A network interface is generally specified by the user in the Network preference panel. In rare circumstances, interfaces can also be attached and detached from the net library at runtime as described in the section “[Settings for Interface Selection](#)” later in this chapter.

Constraints

Because it’s unclear whether all future platforms will need or want network support (especially devices with very limited amounts of memory), network support is an optional part of the operating system. For this reason, the net library is implemented as a system library that is installed at runtime and doesn’t have to be present for the system to work properly.

When the net library is present and running, it requires an estimated additional 32 KB of RAM. This in effect doubles the overall system RAM requirements, currently 32 KB without the net library. It’s therefore not practical to run the net library on any platform that has 128 KB or less of total RAM available since the system itself will consume 64 KB of RAM (leaving only 64 KB for user storage in a 128 KB system).

Because of the RAM requirements, the net library is supported only on PalmPilot Professional and newer devices running Palm OS 2.0 and later.

All applications written for Palm OS must pay special attention to memory and CPU usage because Palm OS runs on small devices with limited amounts of memory and other hardware resources. Applications that use the net library, therefore, must pay even more attention to memory usage. After opening the net library, the total remaining amount of RAM available to an application is approximately 12 KB on a PalmPilot Professional and 36KB on a Palm IIITM.

The Programmer's Interface

There are essentially two sets of API into the net library: the net library's native API, and the Berkeley sockets API. The two APIs map almost directly to each other. You can use the Berkeley sockets API with no performance penalty and little or no modifications to any existing code that you have.

The header file `<unix/sys_socket.h>` contains a set of macros that map Berkeley sockets calls directly to net library calls. The main difference between the net library API and the Berkeley sockets API is that most net library API calls accept additional parameters for:

- **A reference number.** All library calls in the Palm OS must have the library reference number as the first parameter.
- **A timeout.** In consumer systems such as the Palm OS device, infinite timeouts don't work well because the end user can't "kill" a process that's stuck. The timeout allows the application to gracefully recover from hung connections. The default timeout is 2 seconds.
- **An error code.** The sockets API by convention returns error codes in the application's global variable `errno`. The net library API doesn't rely on any application global variables. This allows system code (which cannot have global variables) to use the net library API.

The macros in `sys_socket.h` do the following:

| For... | The macros pass... |
|------------------|--|
| reference number | <code>AppNetRefnum</code> (application global variable). |

| For... | The macros pass... |
|------------|--|
| timeout | AppNetTimeout (application global variable). |
| error code | Address of the application global errno. |

For example, consider the Berkeley sockets call `socket`, which is declared as:

```
Int16 socket(Int16 domain, Int16 type,
             Int16 protocol);
```

The equivalent net library call is `NetLibSocketOpen`, which is declared as:

```
NetSocketRef NetLibSocketOpen(UInt16 libRefnum,
                               NetSocketAddrEnum domain,
                               NetSocketTypeEnum type, Int16 protocol,
                               Int32 timeout, Err* errP)
```

The macro for `socket` is:

```
#define socket(domain,type,protocol) \
    NetLibSocketOpen(AppNetRefnum, domain, type, \
    protocol, AppNetTimeout, &errno)
```

Net Library Usage Steps

In general, using the net library involves the steps listed below. The next several sections describe some of the steps in more detail.

For an example of using the net library, see the example application `NetSample` in the Palm OS Examples directory. It exercises many of the net library calls.

- 1. Obtain the net library's reference number.**

Because the net library is a system library, all net library calls take the library's reference number as the first parameter. For this reason, your first step is to obtain the reference number and save it. See "[Obtaining the Net Library's Reference Number](#)."

- 2. Set up for using Berkeley sockets API.**

You can either use the net library's native API or the Berkeley sockets API for the majority of what you do with the net library. If

you're already familiar with Berkeley sockets API, you'll probably want to use it instead of the native API. If so, follow the steps in "[Setting Up Berkeley Socket API](#)."

3. If necessary, configure the net library the way you want it.

Typically, users set up their networking services by using the Network preferences panel. Most applications don't set up the networking services themselves; they simply access them through the net library preferences database. In rare instances, your application might need to perform some network configuration, and it usually should do so before the net library is open. See "[Setup and Configuration Calls](#)."

4. Open the net library right before the first network access.

Because of the limited resources in the Palm OS environment, the net library was designed so that it only takes up extra memory from the system when an application actually needs to use its services. An Internet application must therefore inform the system when it needs to use the net library by opening the net library when it starts up and by closing it when it exits. See "[Opening the Net Library](#)."

5. Make calls to access the network.

Once the net library has been opened, sockets can be opened and data sent to and received from remote hosts using either the Berkeley sockets API or the native net library API. See "[Network I/O and Utility Calls](#)."

6. Close the net library when you're finished with it.

Closing the net library frees up the resources. See "[Closing the Net Library](#)."

Obtaining the Net Library's Reference Number

To determine the reference number, call [SysLibFind](#), passing the name of the net library, "Net.lib". In addition, if you intend to use Berkeley sockets API, save the reference number in the application global variable AppNetRefnum.

```
err = SysLibFind("Net.lib", &AppNetRefnum);  
if (err) { /* error handling here */ }
```

Remember that the net library requires Palm OS version 2.0 or later. If the `SysLibFind` call can't find the net library, it returns an error code.

Setting Up Berkeley Socket API

To set up the use of Berkeley sockets API, do the following:

- Include the header file `<unix/sys_socket.h>`, provided with the Palm OS SDK.
- Link your project with the module `NetSocket.c`, which declares and initializes three required global variables: `AppNetTimeout`, `AppNetRefnum`, and `errno`. `NetLibSocket.c` also contains the glue code necessary for a few of the Berkeley sockets functions.
- As described in the previous section, assign the net library's reference number to the variable `AppNetRefnum`.
- Adjust `AppNetTimeout`'s value if necessary.

This value represents the maximum number of system ticks to wait before a net library call expires. Most applications should adjust this timeout value and possibly adjust it for different sections of code. The following example sets the timeout value to 10 seconds.

```
AppNetTimeout = SysTicksPerSecond() * 10;
```

Setup and Configuration Calls

The setup and configuration API calls of the net library are normally only used by the Network preferences panel. This includes calls to set IP addresses, host name, domain name, login script, interface settings, and so on. Each setup and configuration call saves its settings in the net library preferences database in nonvolatile storage for later retrieval by the runtime calls.

In rare instances, an application might need to perform setup and configuration itself. For example, some applications might allow users to select a particular "service" before trying to establish a connection. Such applications present a pick list of service names and allow the user to select a service name. This functionality is provided via the Network preferences panel. The panel provides

launch codes (defined in `SystemMgr.h`) that allow an application to present a list of possible service names to let the end user pick one. The preferences panel then makes the necessary net library setup and configuration calls to set up for that particular service.

Usually, the setup and configuration calls are made while the library is closed. A subset of the calls can also be issued while the library is open and will have real-time effects on the behavior of the library. [Chapter 62, “Net Library,”](#) in *Palm OS Programmer’s API Reference*, describes the behavior of each call in more detail.

Settings for Interface Selection

As you learned in the section “[About the Net Library](#),” the net library uses one or more network interfaces to abstract low-level networking protocols. The user specifies which network interface to use in the Network preference panel.

You can also use net library calls to specify which interface(s) should be used:

- [NetLibIFAttach](#) attaches an interface to the library so that it will be used when and if the library is open.
- [NetLibIFDetach](#) detaches an interface from the library.
- [NetLibIFGet](#) returns an interface’s creator and instance number.

Unlike most net library functions, these functions can be called while the library is open or closed. If the library is open, the specific interface is attached or detached in real time. If the library is closed, the information is saved in preferences and used the next time the library is opened.

Each interface is identified by a creator and an instance number. You need these values if you want to attach or detach an interface or to query or set interface settings. You use `NetLibIFGet` to obtain this information. `NetLibIFGet` takes four parameters: the net library’s reference number, an index into the library’s interface list, and addresses of two variables where the creator and instance number are returned.

The creator is one of the following values:

- `netIFCreatorLoop` (Loopback network)

- `netIFCreatorSLIP` (SLIP network)
- `netIFCreatorPPP` (PPP network)

If you know which interface you want to obtain information about, you can iterate through the network interface list, calling `NetLibIFGet` with successive index values until the interface with the creator value you need is returned.

Interface Specific Settings

The net library configuration is structured so that network interface-specific settings can be specified for each network interface independently. These interface specific settings are called IF settings and are set and retrieved through the [NetLibIFSettingGet](#) and [NetLibIFSettingSet](#) calls.

- The [NetLibIFSettingGet](#) call takes a setting ID as a parameter along with a buffer pointer and buffer size for the return value of the setting. Some settings, like login script, are of variable size so the caller must be prepared to allocate a buffer large enough to retrieve the entire setting. (`NetLibIFSettingGet` returns the required size if you pass `NULL` for the buffer. See the `NetLibIFSettingGet` description in the reference documentation for more information.)
- The [NetLibIFSettingSet](#) call also takes a setting ID as a parameter along with a pointer to the new setting value and the size of the new setting.

If you're using `NetLibIFSettingSet` to set the login script, see the next section.

For an example of using these functions, see the `NetSample` example application in the `Palm OS Examples` directory. The function `CmdSettings` in the file `CmdInfo.c`, for example, shows how to loop through and obtain information about all of the network interfaces.

Setting an Interface's Login Script

The `netIFSettingLoginScript` setting is used to store the login script for an interface. The login script is generated either from the script that the user enters in the Network preferences panel or from a script file that is downloaded onto the device during a HotSync®

operation. The format of the script is rigid; if a syntactically incorrect login script is presented to the net library, the results are unpredictable. The basic format is a series of null-terminated command lines followed by a null byte at the end of the script. Each command line has the format:

`<command-byte> [<parameter>]`

where the command byte is the first character in the line and there is 1 and only 1 space between the command byte and the parameter string. [Table 6.1](#) lists the possible commands.

Table 6.1 Login Script Commands

| Function | Command | Parameter | Example |
|-----------------------------|---------|-----------|-------------------|
| Send | s | string | s go PPP |
| Wait for | w | string | w password: |
| Delay | d | seconds | d 1 |
| Get IP | g | | g |
| Prompt | a | string | a Enter Name: |
| Wait for prompt | f | string | f ID: |
| Send CR | s | string | s ^N |
| Send User ID | s | string | s jdoe |
| Send Password | s | string | s mypassword |
| Plugin command ^a | sp | string | sp plugin:cmd:arg |

a. See "[Extending the Network Login Script Support](#)."

The parameter string to the send (s) command can contain the escape sequences shown in [Table 6.2](#).

Table 6.2 Send Command Escape Sequences

| | |
|--------------|---|
| \$USERID | substitutes user name |
| \$PASSWORD | substitutes password |
| \$DBUSERID | substitutes dialback user name |
| \$DBPASSWORD | substitutes dialback password |
| ^c | if c is '@' -> '_', then byte value 0 -> 31 else if c is 'a' -> 'z', then byte value 1 -> 26 else c |
| <cr> | carriage return (0x0D) |
| <lf> | line feed (0x0A) |
| \" | " |
| \^ | ^ |
| \< | < |
| \\ | \ |

Note also that login scripts can be created on a desktop computer and then installed onto the device during synchronization. The script commands are inspired by the Windows dial-up scripting command language for dial-up networking. For documentation from Microsoft, search for the file `Script.doc` in the Windows folder. The Network preferences panel on Palm OS supports the following subset of commands:

```
set serviceName
set userName
set password
set phoneNumber
set primaryDNS
set secondaryDNS
set ipAddr
set closewait
set inactivityTimeout
set establishmentTimeout
```

Network Communication

Net Library

```
set protocol
set dynamicIP
waitfor
transmit
getip
delay
prompt
waitforprompt
plugin "pluginname:cmd[:arg]"
```

The plugin command is a Palm OS-specific extension used to perform a command defined in a plugin. See “[Extending the Network Login Script Support](#)” for more information on plugins.

Create a script file with the extension .pnc or .scp and place it in the user’s install directory. The network conduit will download it to the device during the next HotSync operation. Each script file should contain only one service definition.

General Settings

In addition to the interface-specific settings, there’s a class of settings that don’t apply to any one particular interface. These general settings are set and retrieved through the [NetLibSettingGet](#) and [NetLibSettingSet](#) calls. These calls take setting ID, buffer pointer, and buffer size parameters.

Opening the Net Library

Call [NetLibOpen](#) to open the net library, passing the reference number you retrieved through [SysLibFind](#). Before the net library is opened, most calls issued to it fail with a netErrNotOpen error code.

```
err = NetLibOpen(AppNetRefnum, &ifErrs);
if (err || ifErrs) { /* error handling here */ }
```

Multiple applications can have the library open at a time, so the net library may already be open when [NetLibOpen](#) is called. If so, the function increments the library’s **open count**, which keeps track of how many applications are accessing it, and returns immediately. (You can retrieve the open count with the function [NetLibOpenCount](#).)

If the net library is not already open, `NetLibOpen` starts up the net protocol stack task, allocates memory for internal use by the net library, and brings up the network connection. Most likely, the user has configured the Palm OS device to establish a SLIP or PPP connection through a modem and in this type of setup, `NetLibOpen` dials up the modem and establishes the connection before returning.

If any of the attached network interfaces (such as SLIP or PPP) fail to come up, the final parameter (`ifErrs` in the example above) contains the error number of the first interface that encountered a problem.

It's possible, and quite likely, that the net library will be able to open even though one or more interfaces failed to come up (due to bad modem settings, service down, etc.). Some applications may therefore wish to close the net library using [NetLibClose](#) if the interface error parameter is non-zero and display an appropriate message for the user. If an application needs more detailed information, e.g. which interface(s) in particular failed to come up, it can loop through each of the attached interfaces and ask each one if it is up or not. For example:

```
UInt16 index, ifInstance;
UInt32 ifCreator;
Err err;
UInt8 up;
Char ifName[32];
...
for (index = 0; 1; index++) {
    err = NetLibIFGet(AppNetRefnum, index,
        &ifCreator, &ifInstance);
    if (err) break;

    settingSize = sizeof(up);
    err = NetLibIFSettingGet(AppNetRefnum,
        ifCreator, ifInstance, netIFSettingUp, &up,
        &settingSize);
    if (err || up) continue;
    settingSize = 32;
```

```
err = NetLibIFSettingGet(AppNetRefnum,
    ifCreator, ifInstance, netIFSettingName,
    ifName, &settingSize);
if (err) continue;

//display interface didn't come up message
}
NetLibClose(AppNetRefnum, true);
```

Closing the Net Library

Before an application quits, or if it no longer needs to do network I/O, it should call [NetLibClose](#).

```
err = NetLibClose(AppNetRefnum, false);
```

`NetLibClose` simply decrements the open count. The `false` parameter specifies that if the open count has reached 0, the net library should not immediately close. Instead, `NetLibClose` schedules a timer to shut down the net library unless another [NetLibOpen](#) is issued before the timer expires. When the net library's open count is 0 but its timer hasn't yet expired, it's referred to as being in the **close-wait state**.

Just how long the net library waits before closing is set by the user in the Network preferences panel. This timeout value allows users to quit from one network application and launch another application within a certain time period without having to wait for another network connection establishment.

If `NetLibOpen` is called before the close timer expires, it simply cancels the timer and marks the library as fully open with an open count of 1 before returning. If the timer expires before another `NetLibOpen` is issued, all existing network connections are brought down, the net protocol stack task is terminated, and all memory allocated for internal use by the net library is freed.

It's recommended that you allow the net library to enter the close-wait state. However, if you do need the net library to close immediately, you can do one of two things:

- Set `NetLibClose`'s second parameter to `true`. This parameter specifies whether the library should close immediately or not.

- Call [NetLibFinishCloseWait](#). This function checks the net library to see if it's in the close-wait state and if so, performs an immediate close.

Version Checking

Besides using [SysLibFind](#) to determine if the net library is installed, an application can also look for the net library version feature. This feature is only present if the net library is installed. This feature can be used to get the version number of the net library as follows:

```
UInt32* version;  
err = FtrGet(netFtrCreator, netFtrNumVersion,  
             &version);
```

If the net library is not installed, `FtrGet` returns a non-zero result code.

The version number is encoded in the format `0xMMmf sbbb`, where:

| | |
|-----|--|
| MM | major version |
| m | minor version |
| f | bug fix level |
| s | stage: 3-release, 2-beta, 1-alpha, 0-development |
| bbb | build number for non-releases |

For example:

V1.1.2b3 would be encoded as 0x01122003

V2.0a2 would be encoded as 0x02001002

V1.0.1 would be encoded as 0x01013000

This document describes version 2.01 of the net library (0x02013000).

Network I/O and Utility Calls

For the network I/O and utility calls, you can either make calls using Berkeley sockets API or using the net library's native API.

Several books have been published that describe how to use Berkeley sockets API to perform network communication. Net library API closely mirrors Berkeley sockets API in this regard. However, you should keep in mind these important differences between using networking I/O on a typical computer and using net library on a Palm OS device:

- You can open a maximum of four sockets at once in the net library. This is to keep net library's memory requirements to a minimum.
- When you try to send a large block of data, the net library automatically buffers only a portion of that block because of the limited available dynamic memory. The function call returns the number of bytes of data that it actually transmitted. You must check the return value and if there's more data to send, call the function again until the transmission is finished.
- If you expect to also receive data during a large transmission, you should send a smaller block, then read back whatever is available to read before sending the next block. In this way, the amount of memory in the dynamic heap that must be used to buffer data waiting to send out and data waiting to be read back in by the application is kept to a minimum.

For more information, see the following:

- The next section, "[Berkeley Sockets API Functions](#)," provides tables that list the supported Berkeley sockets calls, the corresponding native net library call, and gives a brief description of what each call does.
- [Chapter 62](#), "[Net Library](#)," of the *Palm OS Programmer's API Reference* provides detailed descriptions of each net library call. Where applicable, it gives the equivalent sockets API call for each net library native call.
- The NetSample example application in the Palm OS Examples directory shows how to use the Berkeley sockets API in Palm OS applications.

Berkeley Sockets API Functions

This section provides tables that list the functions in the Berkeley sockets API that are supported by the net library. In some cases, the

calls have limited functionality from what's found in a full implementation of the sockets API and these limitations are described here.

Socket Functions

| Berkeley Sockets Function | Net Library Function | Description |
|----------------------------------|---|---|
| accept | <u>NetLibSocketAccept</u> | Accepts a connection from a stream-based socket. |
| bind | <u>NetLibSocketBind</u> | Binds a socket to a local address. |
| close | <u>NetLibSocketClose</u> | Closes a socket. |
| connect | <u>NetLibSocketConnect</u> | Connects a socket to a remote endpoint to establish a connection. |
| fcntl | <u>NetLibSocketOptionSet</u> <u>NetLibSocketOptionGet</u> (..., netSocketOptSockNonBlocking, ...) | Supported only for socket refnums and the only commands it supports are F_SETFL and F_GETFL. The commands can be used to put a socket into non-blocking mode by setting the FNDELAY flag in the argument parameter appropriately — all other flags are ignored. The F_SETFL, F_GETFL, and FNDELAY constants are defined in <unix/unix_fcntl.h>. |
| getpeername | <u>NetLibSocketAddr</u> | Gets the remote socket address for a connection. |
| getsockname | <u>NetLibSocketAddr</u> | Gets the local socket address of a connection. |

Network Communication

Net Library

| Berkeley Sockets Function | Net Library Function | Description |
|---------------------------|---------------------------------------|--|
| getsockopt | NetLibSocketOptionGet | <p>Gets a socket's control options. Only the following options are implemented:</p> <ul style="list-style-type: none">• TCP_NODELAY Allows the application to disable the TCP output buffering algorithm so that TCP sends small packets as soon as possible. This constant is defined in <code><unix/netinet_tcp.h></code>.• TCP_MAXSEG Get the TCP maximum segment size. This constant is defined in <code><unix/netinet_tcp.h></code>.• SO_KEEPALIVE Enables periodic transmission of probe segments when there is no data exchanged on a connection. If the remote endpoint doesn't respond, the connection is considered broken, and <code>so_error</code> is set to <code>ETIMEOUT</code>.• SO_LINGER Specifies what to do with the unsent data when a socket is closed. It uses the <code>linger</code> structure defined in <code><unix/sys_socket.h></code>. |

| Berkeley Sockets Function | Net Library Function | Description |
|--|--|--|
| | | <ul style="list-style-type: none"> • <code>SO_ERROR</code> Returns the current value of the variable <code>so_error</code>, defined in <code><unix/sys_socketvar.h></code> • <code>SO_TYPE</code> Returns the socket type to the caller. |
| <code>listen</code> | NetLibSocketListen | Sets up the socket to listen for incoming connection requests. The queue size is quietly limited to 1. (Higher values are ignored.) |
| <code>read, recv, recvmsg, recvfrom</code> | NetLibReceive NetLibReceivePB | Read data from a socket. The <code>recv</code> , <code>recvmsg</code> , and <code>recvfrom</code> calls support the <code>MSG_PEEK</code> flag but not the <code>MSG_OOB</code> or <code>MSG_DONTROUTE</code> flags. |
| <code>select</code> | NetLibSelect | <p>Allows the application to block on multiple I/O events. The system will wake up the application process when any of the multiple I/O events occurs.</p> <p>This function uses the <code>timeval</code> structure defined in <code><unix/sys_time.h></code> and the <code>fd_set</code> structure defined in <code>sys/types.h</code>.</p> |

Network Communication

Net Library

| Berkeley Sockets Function | Net Library Function | Description |
|--|--|---|
| | | <p>Also associated with this function are the following four macros defined in <code><unix/sys_types.h></code>:</p> <ul style="list-style-type: none">• <code>FD_ZERO</code>• <code>FD_SET</code>• <code>FD_CLR</code>• <code>FD_ISSET</code> <p>Besides socket descriptors, this function also works with the “stdin” descriptor, <code>sysFileDescStdIn</code>. This descriptor is marked as ready for input whenever a user or system event is available in the event queue. This includes any event that would be returned by <code>EvtGetEvent</code>. No other descriptors besides <code>sysFileDescStdIn</code> and socket refnums are allowed.</p> |
| <code>send</code> , <code>sendmsg</code> , <code>sendto</code> | NetLibSend NetLibSendPB | <p>These functions write data to a socket. These calls, unlike the <code>recv</code> calls, do support the <code>MSG_OOB</code> flag. The <code>MSG_PEEK</code> flag is not applicable and the <code>MSG_DONTROUTE</code> flag is not supported.</p> |
| <code>setsockopt</code> | NetLibSocketOptionSet | <p>This function sets control options of a socket. Only the following options are allowed:</p> <ul style="list-style-type: none">• <code>TCP_NODELAY</code>• <code>SO_KEEPALIVE</code>• <code>SO_LINGER</code> |

| Berkeley Sockets Function | Net Library Function | Description |
|----------------------------------|--------------------------------------|--|
| shutdown | NetLibSocketShutdown | Similar to <code>close()</code> ; however, it gives the caller more control over a full-duplex connection. |
| socket | NetLibSocketOpen | Creates a socket for communication. The only valid address family is <code>AF_INET</code> . The only valid socket types are <code>SOCK_STREAM</code> , <code>SOCK_DGRAM</code> , and in Palm OS version 3.0 and higher, <code>SOCK_RAW</code> . The protocol parameter should be set to 0. |
| write | NetLibSend | Writes data to a socket. |

Supported Network Utility Functions

| Berkeley Sockets Function | Net Library Function | Description |
|----------------------------------|---|--|
| getdomainname | NetLibSocketOptionGet (<code>..</code> , <code>netSettingDomainName</code> , <code>...</code>) | Returns the domain name of the local host. |
| gethostbyaddr | NetLibGetHostByAddr | Looks up host information given the host's IP address. It returns a <code>hostent</code> structure, as defined in <code><netdb.h></code> . |
| gethostbyname | NetLibGetHostByName | Looks up host information given the host's name. It returns a <code>hostent</code> structure which is defined in <code><netdb.h></code> . |

Network Communication

Net Library

| Berkeley Sockets Function | Net Library Function | Description |
|---------------------------|---|---|
| gethostname | NetLibSettingGet (..., netSettingHostName, ...) | Returns the name of the local host. |
| getservbyname | NetLibGetServByName | Returns a servent structure, defined in <netdb.h> given a service name. |
| gettimeofday | glue code using TimGetSeconds | Returns the current date and time. |
| setdomainname | NetLibSettingSet (..., netSettingDomainName, ...) | Sets the domain name of the local host. |
| sethostname | NetLibSettingSet (..., netSettingHostName, ...) | Sets the name of the local host. |
| settimeofday | glue code using TimSetSeconds | Sets the current date and time. |

Supported Byte Ordering Macros

The byte ordering macros are defined in <unix/netinet_in.h>. They convert an integer between network byte order and the host byte order.

| Berkeley Sockets Macro | Description |
|------------------------|---|
| htonl | Converts a 32-bit integer from host byte order to network byte order. |
| htons | Converts a 16-bit integer from host byte order to network byte order. |
| ntohl | Converts a 32-bit integer from network byte order to host byte order. |
| ntohs | Converts a 16-bit integer from network byte order to host byte order. |

Supported Network Address Conversion Functions

The network address conversion functions are declared in the `<unix/arpa_inet.h>` header file. They convert a network address from one format to another, or manipulate parts of a network address.

| Berkeley Sockets Function | Net Library Function | Description |
|----------------------------|----------------------------------|--|
| <code>inet_addr</code> | NetLibAddrAToIN | Converts an IP address from dotted decimal format to 32-bit binary format. |
| <code>inet_network</code> | glue code | Converts an IP network number from a dotted decimal format to a 32-bit binary format. |
| <code>inet_makeaddr</code> | glue code | Returns an IP address in an <code>in_addr</code> structure given an IP network number and an IP host number in 32-bit binary format. |
| <code>inet_lnaof</code> | glue code | Returns the host number part of an IP address. |
| <code>inet_netof</code> | glue code | Returns the network number part of an IP address. |
| <code>inet_ntoa</code> | NetLibAddrINTToA | Converts an IP address from 32-bit format to dotted decimal format. |

Extending the Network Login Script Support

Beginning in Palm OS 3.3, you can write a plugin that extends the list of available script commands in the Network preferences panel. You might do so, for example, if:

- You are a corporate IT shop, system integrator, or a token card vendor and want the login script to properly respond to a range of different connection scenarios defined by the authentication server.
- You are a token card vendor and you want to create the Palm OS version of your password generator.
- You want to perform conditional tests and branching during the execution of the script.

The login script enhancement can also be installed on any device that already has network library support (that is, PalmPilot™ Professional and newer devices running Palm OS 2.0 or higher). To do so, you install a file named `Network.prc` along with a PRC file for the network interface you use (i.e., PPP or SLIP). These files provide the new Network preferences panel, which contains support for some new commands and support for the ability to write script plugins.

The sections below describe the basics of how to write a login script plugin. For more detailed information on the API you use to write a plugin, see the chapter “[Script Plugin](#)” on page 1307 in the *Palm OS Programmer’s API Reference*.

Writing the Login Script Plugin

To write a login script plugin, you create a project like you normally would; however, specify `'scpt'` as the database type instead of `'appl'`. (If you’re using Metrowerks CodeWarrior, you specify the database type in the PalmRez post linker panel.)

In the [PilotMain](#) function, the plugin should respond to two launch codes:

- [scptLaunchCmdListCmds](#) to inform the Network preferences panel of the commands your plugin implements.
- [scptLaunchCmdExecuteCmd](#) to execute one of your commands.

Responding to `scptLaunchCmdListCmds`

The Network preferences panel sends the `scptLaunchCmdListCmds` launch code when it is constructing the pull-down list of available commands that it displays in its script view. The panel sends this launch code to all PRCs of type `'scpt'`. It passes an empty structure of type [PluginInfoType](#) as its parameter block. Your plugin should respond by filling in the structure with the following information:

- The name of your plugin (the name of the PRC file)
- The number of commands your plugin implements. No more than `pluginMaxNumOfCmds` is allowed.

- An array containing the name of each command your plugin implements and a Boolean value that indicates whether your plugin takes an argument.

A given device might have multiple plugins installed. If so, the resulting pull-down list contains the union of all commands supported by all of the plugins installed on the device. For this reason, you should make sure the command names you supply are unique. You also should make sure the names are as brief as possible, as only 15 characters are allowed for the name.

Responding to `scptLaunchCmdExecuteCmd`

The `scptLaunchCmdExecuteCmd` launch code is sent when the login script is being executed. That is, the user has attempted to connect to the network service specified in the Network preferences panel, and the panel is executing the script to perform authentication.

The `scptLaunchCmdExecuteCmd` parameter block is a structure of type [PluginExecCmdType](#). It contains:

- The name of the command to be executed
- The command argument, if it takes one
- A pointer to a network interface function
- A handle to information specific to the current connection

Your plugin should execute the specified command. When a plugin is launched with this code, it is launched as a subroutine and as such does not have access to global variables. Also keep in mind that the network library and a connection application (such as the HotSync application) are already running when the plugin is launched. Thus, available memory and stack space are extremely limited.

To perform most of its work, the plugin command probably needs access to the network interface (such as SLIP or PPP) specified for the selected network service. For this reason, the plugin is passed a pointer to a callback function defined by the network interface. The plugin should call this function when it needs to perform the following tasks:

- Read a number of bytes from the network
- Write a number of bytes to the network

- Get the user's name and password information
- Write a string to the connection log
- Prompt the user for information
- Check to see if the user pressed the Cancel button
- Display a form
- Obtain access to the serial library

The callback's prototype is defined by [ScriptPluginSelectorProc](#). It takes as arguments the handle to the connection-specific data passed in with the launch code, the task that the network interface should perform (specified as a `pluginNetLib...` constant), followed by a series of parameters whose interpretations depend on which task is to be performed.

For example, the following code implements the command "Send Uname", which sends the user's name to the host computer.

Listing 6.1 Simple Script Plugin Command

```
#define pluginSecondCmd "Send Uname"

UInt32 PilotMain(UInt16 cmd, void *cmdPBP,
UInt16 launchFlags) {
    PluginExecCmdPtr execPtr;
    UInt32 error = success;
    Int16 dataSize = 0;
    Char* dataBuffer = NULL;
    ScriptPluginSelectorProcPtr selectorTypeP;

    if (cmd == scptLaunchCmdExecuteCmd) {
        execPtr = (PluginExecCmdPtr)cmdPBP;
        selectorTypeP = execPtr->procP->selectorProcP;

        dataBuffer = MemPtrNew(pluginMaxLenTxtStringArg+1);
        if (!dataBuffer) {
            return failure;
        }
        MemSet(dataBuffer, pluginMaxLenTxtStringArg+1, 0);

        if (!StrCompare(execPtr->commandName, pluginSecondCmd)) {

            /* get the user name from the network interface */
            error = (selectorTypeP)(execPtr->handle,
```

```
        pluginNetLibGetUserName, (void*)dataBufferP,
&dataSize, 0,
        NULL);
    if (error) goto Exit;

    dataSize = StrLen((Char*)dataBufferP);

/* have the network interface send the user name to the host
*/
    error = (selectorTypeP)(execPtr->handle,
        pluginNetLibWriteBytes, (void*)dataBufferP,
&dataSize, 0,
        NULL);

    return error;
}
}
```

If your command needs to interact with the user, it must do so through the network interface. When the connection attempt is taking place, the user sees either the Network preferences panel or the HotSync application. Your plugin does not have control of the screen, so you cannot simply display a form. You have two options:

- The network interface can display a prompt for you and return the value that the user enters in response. It can also query the Network preferences panel to see if the user cancelled the connection attempt.
- If you want to do more than simply display a prompt or check the cancel status, you can use the command `pluginNetLibCallUIProc` to display a form and call your own user interface routine.

To use `pluginNetLibCallUIProc`, you must do the following:

1. Initialize the form using a form resource that you've created.
2. Create a struct that contains your form's handle and any other values that you are going to need in your user interface routine.
3. Call the network interface's callback function with the `pluginNetLibCallUIProc` command, the structure with the form's handle and other pertinent information, and the address of a function in your plugin that will perform the user interface routine. This function should take one

argument—the struct you’ve passed to the network interface—and return `void`.

4. When the call to the network interface returns, close the form.

For an example of using `pluginNetLibCallUIProc`, see the functions `WaitForData` and `promptUser` in the example code `ScriptPlugin.c`.

Internet Library

The Internet library provides Palm™ applications easy access to World Wide Web documents. The Internet library uses the net library for basic network access and builds on top of the net library's socket concept to provide a socket-like API to higher level internet protocols like HTTP and HTTPS.

Using the Internet library, an application can access a web page with as little as three calls ([INetLibURLOpen](#), [INetLibSockRead](#), and [INetLibSockClose](#)). The Internet library also provides a more advanced API for those applications that need finer control.

NOTE: The information in this section applies only to version 3.2 or later of the Palm OS on Palm VII devices. These features are implemented only if the [Wireless Internet Feature Set](#) is present.

WARNING! In future OS versions, Palm, Inc. does not intend to support or provide backward compatibility for the Internet library API.

The Internet library is implemented as a system library that is installed at runtime and doesn't have to be present for the system to work properly.

This section describes how to use the Internet library in your application. It covers:

- [System Requirements](#)
- [Initialization and Setup](#)

- [Accessing Web Pages](#)
- [Asynchronous Operation](#)
- [Using the Low Level Calls](#)
- [Cache Overview](#)
- [Internet Library Network Configurations](#)

System Requirements

The Internet library is available only on version 3.2 or later of the Palm OS on Palm VII devices. Before making any Internet library calls, ensure that the Internet library is available. You can be sure it is available by using the following [FtrGet](#) call:

```
err = FtrGet(inetLibFtrCreator,  
            inetFtrNumVersion, &value);
```

If the Internet library is installed, the value parameter will be non-zero and the returned error will be zero (for no error).

When the Internet library is present and running, it requires an estimated additional 1 KB of RAM, beyond the net library. More additional memory is used for the security library, if that is used (when accessing secure sites), and for opening a cache database, if that is used.

Initialization and Setup

Before using the Internet library, an application must call [SysLibFind](#) to obtain a library reference number, as follows:

```
err = SysLibFind("INet.lib", &libRefNum)
```

Next, it must call [INetLibOpen](#) to allocate an `inetH` handle. The `inetH` handle holds all application specific environment settings and each application that uses the Internet library gets its own private `inetH` handle. Any calls that change the default behavior of the Internet library affect environment settings stored in the application's own `inetH` structure, so these changes will not affect other applications that might be using the Internet library at the same time.

`INetLibOpen` also opens the net library for the application. In addition, the application can tell `INetLibOpen` the type of network

service it prefers: wireline or wireless. `INetLibOpen` queries the available network interfaces and attaches the appropriate one(s) for the desired type of service. When the application calls [`INetLibClose`](#), the previous interface configuration is restored. For more information on configurations, see the section “[Internet Library Network Configurations](#)” on page 162.

The Internet library gets some of its default behavior from the system preferences database, and some of these preference settings are made by the user via the Wireless preferences panel. The preferences set by this panel include the proxy server to use and a setting that determines whether or not the user is warned when the device ID is sent. Other settings stored in the preferences database come from Internet library network configurations (see “[Internet Library Network Configurations](#)” on page 162). All these settings can be queried and/or overridden by each application through the [`INetLibSettingGet`](#) and [`INetLibSettingSet`](#) calls. However, any changes made by an application are not stored into the system preferences, but only take effect while that `inetH` handle is open.

Accessing Web Pages

In the Palm.Net environment, all HTML documents are dynamically compressed by the Palm Web Clipping Proxy server before being transmitted to the Palm device.

The procedure for reading a page from the network operates as follows. First, the application passes the desired URL to the [`INetLibURLOpen`](#) routine, which creates a socket handle to access that web page. This routine returns immediately before performing any required network I/O. Then the application calls [`INetLibSockRead`](#) to read the data, followed by [`INetLibSockClose`](#) to close down the socket.

Note that if no data is available to read immediately, `INetLibSockRead` blocks until at least one byte of data is available to be read. To implement asynchronous operation using events, see the next section, [Asynchronous Operation](#).

If an application requires finer control over the operation, it can replace the call to `INetLibURLOpen` with other lower-level Internet library calls ([`INetLibSockOpen`](#), [`INetLibSockSettingSet`](#), etc.) that are described in the section “[Using the Low Level Calls](#)” on page 160.

Asynchronous Operation

A major challenge in writing an Internet application is handling the task of accessing content over a slow network while still providing good user-interface response. For example, a user should be able to scroll, select menus, or tap the Cancel button in the middle of a download of a web page.

To easily enable this type of functionality, the Internet library provides the [INetLibGetEvent](#) call. This call is designed to replace the `EvtGetEvent` call that all traditional, non-network Palm applications use. The `INetLibGetEvent` call fetches the next event that needs to be processed, whether that event is a user-interface event like a tap on the screen, or a network event like some data arriving from the remote host that needs to be read. If no events are ready, `INetLibGetEvent` automatically puts the Palm device into low-power mode and blocks until the next event occurs.

Using `INetLibGetEvent` is the preferred way of performing network I/O since it maximizes battery life and user-interface responsiveness.

With `INetLibGetEvent`, the process of accessing a web page becomes only slightly more complicated. Instead of calling `INetLibSockRead` immediately after `INetLibURLOpen`, the application should instead return to its event loop and wait for the next event. When it gets a network event that says data is ready at the socket, then it should call `INetLibSockRead`.

There are two types of network events that `INetLibGetEvent` can return in addition to the standard user-interface events. The first event is a status change event ([inetSockStatusChangeEvent](#)). This event indicates that the status of a socket has changed and the application may want to update its user interface. For example, when calling `INetLibURLOpen` to access an HTTP server, the status on the socket goes from “finding host,” to “connecting with host,” to “waiting for data,” to “reading data,” etc. The event structure associated with an event of this type contains both the socket handle and the new status so that the application can update the user interface accordingly.

The second type of event that `INetLibGetEvent` can return is a data-ready event ([inetSockReadyEvent](#)). This event is returned

when data is ready at the socket for reading. This event tells the application that it can call `INetLibSockRead` and be assured that it will not block while waiting for data to arrive.

The general flow of an application that uses the Internet library is to open a URL using `INetLibURLOpen`, in response to a user command. Then it repeatedly calls `INetLibGetEvent` to process events from both the user interface and the newly created socket returned by `INetLibURLOpen`. In response to `inetSockStatusChangeEvent` events, the application should update the user interface to show the user the current status, such as finding host, connecting to host, reading data, etc. In response to `inetSockReadyEvent` events, the application should read data from the socket using `INetLibSockRead`. Finally, when all available data has been read (`INetLibSockRead` returns 0 bytes read), the application should close the socket using `INetLibSockClose`.

Finally, the convenience call [`INetLibSockStatus`](#) is provided so that an application can query the status of a socket handle. This call never blocks on network I/O so it is safe to call at any time. It not only returns the current status of the socket but also whether or not it is ready for reading and/or writing. It essentially returns the same information as conveyed via the events `inetSockReadyEvent` and `inetSockStatusChangeEvent`. Applications that don't use `INetLibGetEvent` could repeatedly poll `INetLibSockStatus` to check for status changes and readiness for I/O, though polling is not recommended.

Using the Low Level Calls

Applications that need finer control than `INetLibURLOpen` provides can use the lower level calls of the Internet library. These include [`INetLibSockOpen`](#), [`INetLibSockConnect`](#), [`INetLibSockSettingSet`](#), [`INetLibSockHTTPReqCreate`](#), [`INetLibSockHTTPAttrGet`](#), [`INetLibSockHTTPAttrSet`](#), and [`INetLibSockHTTPReqSend`](#).

A single call to `INetLibURLOpen` for an HTTP resource is essentially equivalent to this sequence: `INetLibSockOpen`, `INetLibSockConnect`, `INetLibSockHTTPReqCreate`, and `INetLibSockHTTPReqSend`. These four calls provide the

capability for the application to access non-standard ports on the server (if allowed), to modify the default HTTP request headers, and to perform HTTP PUT and POST operations. The only calls here that actually perform network I/O are `INetLibSockConnect`, which establishes a TCP connection with the remote host, and `INetLibSockHTTPReqSend`, which sends the HTTP request to the server.

`INetLibSockHTTPAttrSet` is provided so that the application can add or modify the default HTTP request headers that `INetLibSockHTTPReqCreate` creates.

`INetLibSockSettingSet` allows an application finer control over the socket settings.

Finally, the routine [`INetLibURLCrack`](#) is provided as a convenient utility for breaking a URL into its component parts.

Cache Overview

The Internet library maintains a cache database of documents that have been downloaded. This is an LRU (Least Recently Used) cache; that is, the least recently used items are flushed when the cache fills. Whether or not a retrieved page is cached is determined by a flag (`inetOpenURLFlagKeepInCache`) set in the socket or by `INetLibURLOpen`. Another flag (`inetOpenURLFlagLookInCache`) determines if the Internet library should check the cache first when retrieving a URL.

The same cache database can be used by any application using the Internet library, so that every application can share the same pool of prefetched documents. Alternately, an application can use a different cache database. The cache database to use is specified in the `INetLibOpen` call.

Generally, a cached item is stored in one or more database records in the same format as it arrives from the server.

In the cache used by the Web Clipping Application Viewer application, each record includes a field that contains the “master” URL of the item. This field is set to the URL of the active PQA, so all pages linked from one PQA have the same master URL. This facilitates finding all pages in a hierarchy to build a history list.

The Internet library maintains a list of items in the cache. You can retrieve items in this list, or iterate over the whole list, by calling [INetLibCacheList](#). You can retrieve a cached document directly by using [INetLibCacheGetObject](#).

You can check if a URL is cached by calling [INetLibURLGetInfo](#).

Internet Library Network Configurations

The Internet library supports network configurations. A **configuration** is a specific set of values for several of the Internet library settings (from the [INetSettingEnum](#) type).

The Internet library keeps a list of available configurations and aliases to them. There are three built-in configurations:

- A wireless configuration that uses the Palm.Net wireless system and the Palm Web Clipping Proxy server.
- A wireline configuration that uses the wireline network configuration specified in the Network preferences panel and the Palm Web Clipping Proxy server.
- A generic configuration that uses the wireline network configuration specified in the Network preferences panel and no proxy server.

You can also define your own configuration by modifying an existing one and saving it under a different name.

The Internet library also defines several **configuration aliases** (see “[Configuration Aliases](#)” on page 1634 in the *Palm OS Programmer’s API Reference*). An alias is a configuration name that simply points to another configuration. You can specify an alias anywhere in the API you would specify a configuration. This facilitates easy re-assignment of the built-in configurations and eliminates having duplicate settings. You assign an alias by using [INetLibConfigAliasSet](#) and can retrieve an alias by using [INetLibConfigAliasGet](#).

For example, to change the default configuration used by the Internet library for a particular kind of connection, you can set up the appropriate values for a connection, save the configuration, and then set the Internet library’s default alias configuration to point to your custom configuration. When an application specifies which configuration it wants to use, if it specifies the alias, it will use the custom settings.

If you use configurations at all, it will probably be to specify a specific configuration when opening the Internet library via `INetLibOpen`. The Internet library also contains an API to allow you to manipulate configurations in your application, but doing so is rare. You can list the available configurations ([INetLibConfigList](#)), get a configuration index ([INetLibConfigIndexFromName](#)), select ([INetLibConfigMakeActive](#)) the Internet library network configuration you would prefer to use (wireless, wireline, etc.), rename existing configurations ([INetLibConfigRename](#)), and delete configurations ([INetLibConfigDelete](#)).

The configuration functions are provided primarily for use by Preferences panels while editing and saving configurations. The general procedure is to make the configuration active that you want to edit, set the settings appropriately, then save the configuration using [INetLibConfigSaveAs](#). Note that configuration changes are not saved after the Internet library is closed, unless you call `INetLibConfigSaveAs`.

Summary of Network Communication

Net Library Functions

Library Open and Close

[NetLibClose](#)

[NetLibConnectionRefresh](#)

[NetLibFinishCloseWait](#)

[NetLibOpen](#)

[NetLibOpenCount](#)

Socket Creation and Deletion

[NetLibSocketClose](#)

[NetLibSocketOpen](#)

Socket Options

[NetLibSocketOptionGet](#)

[NetLibSocketOptionSet](#)

Socket Connections

[NetLibSocketAccept](#)

[NetLibSocketAddr](#)

[NetLibSocketBind](#)

[NetLibSocketConnect](#)

[NetLibSocketListen](#)

[NetLibSocketShutdown](#)

Network Communication

Summary of Network Communication

Net Library Functions

Send and Receive Routines

[NetLibDmReceive](#)

[NetLibReceive](#)

[NetLibReceivePB](#)

[NetLibSend](#)

[NetLibSendPB](#)

Utilities

[NetHToNL](#)

[NetHToNS](#)

[NetLibAddrAToIN](#)

[NetLibAddrINToA](#)

[NetLibGetHostByAddr](#)

[NetLibGetHostByName](#)

[NetLibGetMailExchangeByName](#)

[NetLibGetServByName](#)

[NetLibMaster](#)

[NetLibSelect](#)

[NetLibTracePrintF](#)

[NetLibTracePutS](#)

[NetNToHL](#)

[NetNToHS](#)

Setup

[NetLibIFAttach](#)

[NetLibIFDetach](#)

[NetLibIFDown](#)

[NetLibIFGet](#)

[NetLibIFSettingGet](#)

[NetLibIFSettingSet](#)

[NetLibIFUp](#)

[NetLibSettingGet](#)

[NetLibSettingSet](#)

Network Utilities

[NetUReadN](#)

[NetUTCPOpen](#)

[NetUWriteN](#)

Internet Library Functions

Library Open and Close

[INetLibClose](#)

[INetLibOpen](#)

Settings

[INetLibSettingGet](#)

[INetLibSettingSet](#)

Internet Library Functions

Event Management

[INetLibGetEvent](#)

High-Level Socket Calls

[INetLibSockClose](#)

[INetLibURLOpen](#)

[INetLibSockRead](#)

Low-Level Socket Calls

[INetLibSockConnect](#)

[INetLibSockSettingSet](#)

[INetLibSockOpen](#)

[INetLibSockStatus](#)

[INetLibSockSettingGet](#)

HTTP Interface

[INetLibSockHTTPAttrGet](#)

[INetLibSockHTTPReqCreate](#)

[INetLibSockHTTPAttrSet](#)

[INetLibSockHTTPReqSend](#)

Utilities

[INetLibCheckAntennaState](#)

[INetLibURLsAdd](#)

[INetLibURLCrack](#)

[INetLibWiCmd](#)

[INetLibURLGetInfo](#)

Cache Interface

[INetLibCacheGetObject](#)

[INetLibCacheList](#)

Configuration

[INetLibConfigAliasGet](#)

[INetLibConfigList](#)

[INetLibConfigAliasSet](#)

[INetLibConfigMakeActive](#)

[INetLibConfigDelete](#)

[INetLibConfigRename](#)

[INetLibConfigIndexFromName](#)

[INetLibConfigSaveAs](#)

Internet and Messaging Applications

This chapter provides an overview of wireless Internet access with the Palm OS® and describes the programmatic interfaces to the Web Clipping Application Viewer and email applications.

NOTE: You cannot use the features described in this chapter with a version of the Palm OS earlier than version 3.2.

This chapter begins with a brief discussion of Internet access on Palm Powered™ handhelds and then provides a brief overview of how web clipping applications work in the following sections:

- [Internet Access on Palm Powered Handhelds](#)
- [Overview of Web Clipping Architecture](#)

For more information about web clipping applications, displaying HTML pages on Palm Powered handhelds, and the Palm.Net system, see the *Web Clipping Developer's Guide*.

This chapter also describes how to programmatically access the Web Clipping Application Viewer (the *Viewer*) and IMessenger applications in the following sections:

- [Using the Viewer to Display Information](#)
- [Sending Email Messages](#)
- [Using Wireless Capabilities in Your Applications](#)

For more information about programmatic access to the Internet, see [Chapter 75](#), “[Internet Library](#),” in the *Palm OS Programmer's API Reference*.

Internet Access on Palm Powered Handhelds

Starting with version 3.2, the Palm OS added support for wireless Internet access and messaging. Version 3.5 of the Palm OS extended those capabilities, and along with the Mobile Internet Kit, extended wireless access capabilities to other Palm Powered handhelds. Version 4.0 extends the wireless communications features even further, adding numerous additional messaging, telephony, and web access capabilities.

Two of the fundamental communications capabilities that Palm OS users can take advantage of are:

- sending and receiving email communications
- viewing and interacting with the Internet

Users can access these capabilities with the built-in wireless antenna on the Palm VII™ family of devices, or with a PPP connection that uses a wireline or a wireless modem and cell phone on other Palm Powered handhelds.

Overview of Web Clipping Architecture

Palm, Inc. invented web clippings to make it possible for users to easily access information on the Internet with a small screen and low connection bandwidth. Web clipping technology allows users to extract and receive specific information from a web page, much like clipping a specific article out of a newspaper.

Numerous web sites are now enabled for web clipping, which means that the site's content is available in web clipping format. In the typical scenario, a web clipping application running on a Palm Powered handheld sends a query to the web site. The web site responds to the query by sending a clipping back to the handheld, and the web clipping application displays the returned clipping.

You create web clipping applications by compiling standard HTML 3.2 pages with Palm's Web Clipping Application Builder tool, which generates a .pqa that operates like a mini-web site and can execute on Palm Powered handhelds. These .pqa files are actually databases that are run by the Viewer, which communicates with the Internet.

The Viewer sends requests for information to the Internet via a Palm Proxy server, which converts the compressed format used by the Viewer into standard format and relays the request to the destination server. The server sends information back to the proxy server in standard format, and the proxy server converts the information into compressed format and relays it to the user's device, on which the Viewer displays it.

NOTE: The Palm OS automatically launches the Viewer when the user taps on a web clipping application icon in the Applications Launcher. The Viewer is not visible to users as an application in the Launcher.

For a more complete description of how web clipping works, including a discussion of the Palm Proxy Servers, see the *Web Clipping Developer's Guide*.

About Web Clipping Applications

A web clipping application might contain hyperlinks or an HTML form that displays information and allows the sending or requesting of information. The information can be stored locally, on the handheld device, or remotely, on a web site that can be accessed on the Internet. A web clipping application can also be a self-contained web site.

[Figure 7.1](#) shows a typical web clipping application. This application contains a number of links; when the user taps on any of these links, the HTTP(S) request is sent to the Internet, and the web site sends back a web clipping page that is displayed on the handheld screen.

Figure 7.1 Typical web clipping application



For complete information about creating and building web clipping applications, including reference information about the HTML language features and extensions you can use in these applications, see the *Web Clipping Developer's Guide*.

Using the Viewer to Display Information

The Viewer program is a Palm OS program that displays web clipping applications, interacts with the Palm Proxy Server, and displays web clippings sent back from the Internet. You can also use the Viewer to display HTML content that you have created by launching the Viewer from your Palm OS applications.

Before using the features described in this section, you should verify that the wireless access features are available in the system on which your application is running. For more information, see "[System Version Checking](#)" on page 174.

To launch the Viewer and display a web clipping page, use the launch code [sysAppLaunchCmdOpenDB](#). Pass the database ID and card number for the .pqa that you want to display.

To launch the Viewer and display a specific URL, use the launch code [sysAppLaunchCmdGoToURL](#). Pass a pointer to the URL string as a parameter to this launch code. [Listing 7.1](#) shows an example.

NOTE: The Viewer was previously known as the Clipper; thus you see "Clipper" used in various constant names.

Listing 7.1 Launching Viewer with a URL

```
Err GoToURL(Char* origurl)
{
    // parameter is ptr to URL string
    Err err;
    Char* url;
    DmSearchStateType searchState;
    UInt16* cardNo;
    LocalID* dbID;

    // make a copy of the URL, since the OS will free
    // the parameter once Viewer quits
    url = MemPtrNew(StrLen(origurl)+1);
    if (!url) return sysErrNoFreeRAM;
    StrCopy(url, origurl);
    MemPtrSetOwner(url, 0);

    // find Viewer and launch it
    err = DmGetNextDatabaseByTypeCreator (true, &searchState,
    sysFileTApplication, sysFileCClipper, true, &cardNo, &dbID);
    if (err) { // Viewer is not present
        FrmAlert (NoClipperAlert);
        MemPtrFree(url);
    }
    else
        err =
SysUIAppSwitch(cardNo,dbID,sysAppLaunchCmdGoToURL,url);

    return err; // ErrNone (0) means no error
}
```

IMPORTANT: When programmatically launching an application that connects to the Internet, remember that many Palm users pay for their wireless transmissions on a per-byte basis, and that web sites that are not designed to be Palm-friendly can result in increased airtime charges. For more information about Palm-friendly web pages, see the *Web Clipping Developer's Guide*.

Sending Email Messages

You can send email messages from your Palm OS applications in three different ways:

- Use the standard `mailto` URL in the Viewer.
- Use the [sysAppLaunchCmdAddRecord](#) launch code to launch the email program with its editor open.
- Use the [sysAppLaunchCmdAddRecord](#) launch code to silently add the email item to the outbox.

Each of these message-sending methods is described in this section.

Before using the features described in this section, you should verify that the wireless access are available in the system on which your application is running. For more information, see “[System Version Checking](#)” on page 174.

Registering an Email Application

The standard, default email application on the Palm OS is either the Palm iMessenger program (for the Palm VII device family) or MultiMail (for other Palm Powered handhelds). Starting with version 4.0 of the Palm OS, you can register additional email handling applications by calling the Exchange Manager from within a Palm OS application:

```
ExgRegisterDatatype(  CRID,           // ID of registering app
                      exgReg          // URL scheme registry
                      "mailto",        // the scheme to associate
                      "Email URL",    // description
                      0 );             // any flags
```

When you register a new email-handling application, the Exchange Manager makes that application the default handler for email messages.

For more information about the Palm Exchange Manager, see [Chapter 58](#), “[Exchange Manager](#),” on page 1123 and the *Palm OS Programmer’s API Reference* book.

Sending Mail from the Viewer

You can send an email message with the Viewer just like you do in standard HTML pages, by using the `mailto:` tag. For example:

```
<a href="mailto:us@company.com">Email us</a>
```

When the Viewer encounters the `mailto` tag, it calls the Exchange Manager to handle sending the email message. The Exchange Manager calls the default email application.

Launching the Email Application for Editing

Use the [sysAppLaunchCmdAddRecord](#) launch code to launch the iMessenger email program with its editor open (optionally filling in some of the fields via the passed parameter block). This allows the user to edit the email message. To make the email program display the message in its editor, set the `edit` field in the parameter block to `true`.

NOTE: The `sysAppLaunchCmdAddRecord` method of launching an email program is only guaranteed to work with the iMessenger email program.

Adding an Email to the Outbox

Use the [sysAppLaunchCmdAddRecord](#) launch code to silently add an item (the email message) to the default email program's outbox database. You must pass all the needed information in the parameter block. To prevent the email program from displaying the message in its editor, set the `edit` field in the parameter block to `false`.

When launched via the `sysAppLaunchCmdAddRecord` launch code, the email application returns an error code, or `errNone` if there was no error.

To send a launch code to the default email application, you need obtain its database ID. You can use [DmGetNextDatabaseByTypeCreator](#) and pass the constant `sysFileCMessaging` for the `creator` parameter.

Note that adding an item to the email outbox does not actually send the message over the radio. It simply stores the message in the outbox until the user later opens the email application and chooses to send queued messages. This always gives the user control over when the radio is used.

Using Wireless Capabilities in Your Applications

This section provides information about system-level features that you may need to use with your Palm OS applications that access wireless communications capabilities. The following topics are covered:

- [System Version Checking](#)
- [Wireless keyDownEvent Key Codes](#)
- [Including Over-the-Air Characters](#)

System Version Checking

Before using any special features of the operating system for wireless communications, you must ensure that your application is running on a device that supports the wireless internet access features of the Palm OS.

NOTE: In some Palm Powered handhelds, the web clipping components are not built into the operating system, but are installed as separate components.

You can check that this feature set is implemented by checking for the existence of the Viewer and iMessenger™ applications. Here's an example of how to check for the Viewer:

```
DmSearchStateType searchState;  
UInt cardNo;  
LocalID dbID;  
  
err = DmGetNextDatabaseByTypeCreator(true, &searchState,  
    sysFileTApplication, sysFileCCLipper, true, &cardNo, &dbID);
```

If Viewer is not present, the `DmGetNextDatabaseByTypeCreator` function returns an error. To check for iMessenger, you can use the creator type `sysFileCMessaging`.

For more information on checking system compatibility, see [Appendix B, “Compatibility Guide.”](#)

Wireless keyDownEvent Key Codes

Versions 3.2 and later of the Palm OS provide special `keyDownEvent` virtual key codes to support the wireless capabilities of the Palm VII family of devices. These include:

- `vchrHardAntenna`, which signals that the user has raised the antenna, activating the radio
- `vchrRadioCoverageOK`, which signals that the unit is within radio coverage following a coverage check
- `vchrRadioCoverageFail`, which signals that the unit is outside radio coverage following a coverage check, and thus cannot communicate with the Palm.Net system

Virtual key codes are passed in the `chr` field of a `keyDownEvent` data block, with the `commandKeyMask` bit set in the `modifiers` field, as described in the section “[keyDownEvent](#)” on page 83 of the *Palm OS Programmer’s API Reference*.

Normally, you ignore these events in your application event handler, and let the system event handler handle them. For example, the `vchrHardAntenna` event causes the system to invoke the Launcher and switch to the Palm.Net category. If you want to do something different in your application, you must trap and handle the event in your application event handler.

Alternatively, if you want your application to have control over the antenna (avoiding having the system switch to the Launcher on a `vchrHardAntenna` event), you can open the Internet library when your application starts, by calling [INetLibOpen](#). You need to open the Internet library with the default or wireless configuration. When your application exits, you must close the Internet library by calling [INetLibClose](#). For more information about using the Internet library, see [Chapter 6, “Network Communication.”](#)

Including Over-the-Air Characters

One of the overriding user interface design goals of the Palm wireless communications system is to always give the user control when making a wireless transaction, partly because of the costs associated with doing so.

You can use the Palm over-the-air characters in your user interface buttons to help the user recognize a wireless transaction. Palm provides two different characters: one for standard transactions, and another for secure transactions, as shown in [Figure 7.2](#).

Figure 7.2 Over the Air Characters



Over the air

Over the air secure

If your application includes a button that causes data to be transmitted when tapped, end the button text with the “Over-the-air” character (`chrOta`). This alerts the user that tapping the button will cause data transmission and incur possible airtime charges.

If your application includes a button that causes data to be transmitted securely when tapped, end the button text with the “Over-the-air-secure” character (`chrOtaSecure`). This alerts the user that tapping the button will cause secure data transmission and incur possible airtime charges.

Note that the Viewer application automatically adds these special characters when rendering remote hyperlinks or buttons. You only need to explicitly add these characters if you are building an application that doesn’t use this capability of the Viewer.

Telephony Manager

You can use the Palm OS® Telephony Manager to access a variety of telephony services in your applications. This chapter contains the following sections that describe how to use the Palm OS Telephony API:

- [Telephony Service Types](#) describes the component parts of the telephony API.
- [Using the Telephony API](#) describes how to use the telephony API in your applications.
- [Using the Phone Book Capabilities](#) describes the PhBkApp sample program, which provides an excellent example of a program that uses the Telephony Manager.

For detailed information about the Telephony Manager data types, constants, and functions, see the following chapters in the *Palm OS Programmer's API Reference*:

- [Chapter 69, "Telephony Basic Services."](#)
- [Chapter 70, "Telephony Security and Configuration."](#)
- [Chapter 71, "Telephony Network."](#)
- [Chapter 72, "Telephony Calls."](#)
- [Chapter 73, "Telephony SMS."](#)
- [Chapter 74, "Telephony Phone Book."](#)

The "[Telephony Basic Services](#)" chapter describes the basic services and provides a map to the other functions.

Telephony Service Types

The telephony API organizes functions within sets called **service sets**. Each service set contains a related set of functions that may or may not be available on a particular mobile device or network. You can use the [TelIs<ServiceSet>Available](#) macro to determine if a service set is supported in the current environment, and you can

Telephony Manager

Telephony Service Types

use the [TelIs<FunctionName>Supported](#) macro to determine if a specific function is supported in the current environment.

NOTE: Sometimes a service set is supported, but not all of the functions in that service set are supported. See [Testing the Telephony Environment](#) for more information.

Each function in the telephony API is prefixed with `Tel`; each telephony service set adds an additional 3 characters to the prefix. [Table 8.1](#) describes the telephony service sets.

Table 8.1 Telephony API service sets

| Service set | Functionality | Service prefix |
|-----------------|--|---------------------|
| Basic | Basic functions that are always available | <code>Tel</code> |
| Configuration | Services that allow you to configure phones, including SMS configuration. | <code>TelCfg</code> |
| Data calls | Data call handling | <code>TelDtc</code> |
| Emergency calls | Emergency call handling | <code>TelEmc</code> |
| Information | Functions to retrieve information about the current phone. | <code>TelInf</code> |
| Network | Functions that provide network-oriented services, including authorized networks, current network, signal level, and search mode information | <code>TelNwk</code> |
| OEM | Functions that allow hardware manufacturers to extend the Telephony Manager. Each manufacturer can provide a specific set of OEM functions for a particular device | <code>TelOem</code> |
| Phone book | Functions to access the phone's SIM and address book, including the ability to create, view, and delete phone book entries. | <code>TelPhb</code> |
| Power | Power supply level functions. | <code>TelPow</code> |

Table 8.1 Telephony API service sets (*continued*)

| Service set | Functionality | Service prefix |
|-----------------------|---|-----------------------|
| Security | Functions that provide PIN code management and related services for phone and SIM security-related features | TelSty |
| Short Message Service | Services to handle Short Message Service (SMS) and to enable the reading, sending, and deleting of short messages | TelSms |
| Sound | Phone sound management, including the playing of key tones and muting. | TelSnd |
| Speech calls | Functions to handle the sending and receiving of speech calls. This service also includes functions that handle DTMF. | TelSpc |

Using the Telephony API

This section provides examples excerpted from the Phone Book Application (PhBkApp) sample program, which provides the following capabilities:

- creates, modifies, and deletes entries on a phone, using the SIM and built-in storage on the phone device
- imports entries from the Address Book application
- exports entries to the Address Book application

The PhBkApp program opens and accesses the Telephony Manager library and makes a number of calls into the library. It provides an excellent example of using telephony services in your applications.

Accessing the Telephony Manager Library

Before you can use the Telephony Manager library, you must load the library and obtain a reference number for it. Each of the functions in the library requires a reference number argument, which is used with the system code to access a shared library.

Telephony Manager

Using the Telephony API

Each of the functions in the library also requires an application attachment identifier, which you can obtain by calling the [TelOpen](#) function.

The example function `LoadTelMgrLibrary`, which is shown in [Listing 8.1](#), makes sure that the Telephony Manager library is loaded, obtains an application attachment identifier, and returns a reference number for it.

Listing 8.1 Loading the Telephony Manager library

```
Err LoadTelMgrLibrary(UInt16 *telRefNumP, UInt16 *telAppIdP)
{
    Err err;

    err = SysLibFind(kTelMgrLibName, telRefNumP);
    if (err != errNone)
    {
        err = SysLibLoad(kTelMgrDatabaseType,
                        kTelMgrDatabaseCreator, telRefNumP);
        if (err)
            return err;
    }

    err = TelOpen(*telRefNumP, kTelMgrVersion, telAppIdP);
    return err;
}
```

The `LoadTelMgrLibrary` function first calls the [SysLibFind](#) function to determine if the library has already been loaded, which might be the case if your code has been called by another application that has already loaded the library.

If the library has not already been loaded, `LoadTelMgrLibrary` calls the [SysLibLoad](#) function to load the library and obtain a reference number for it.

After obtaining a reference number for the library, `LoadTelMgrLibrary` calls the [TelOpen](#) function to open the loaded library.

Closing the Telephony Manager Library

When you are done with the library, you should close it by calling the [TelClose](#) function, which releases any resources associated with your use of the Telephony Manager.

As shown in [Listing 8.2](#), you must test the return value of the `TelClose` function; if the result is not `telErrLibStillInUse`, you must unload the shared library by calling the [SysLibRemove](#) function.

Listing 8.2 Closing the Telephony Manager library

```
Err UnloadTelMgrLibrary(UInt16 telRefNum, UInt16 telAppId)
{
    if ((TelClose(telRefNum, telAppId) != telErrLibStillInUse))
        SysLibRemove(telRefNum);

    return errNone;
}
```

Using Synchronous and Asynchronous Calls

Almost all of the telephony API functions can be called either synchronously or asynchronously. If you call a function asynchronously, your application receives an event to notify it that the function has completed; the event that you receive contains status and other information returned by the function.

This section provides a simple example of calling the `TelPhbAddEntry` function both synchronously and asynchronously to illustrate the difference.

When you call a function synchronously, you need to test the result value returned by the function to determine if the call was successful. For example, the code in [Listing 8.3](#) calls the `TelPhAddEntry` function synchronously.

Listing 8.3 Calling a function synchronously

```
err = TelPhbAddEntry(gPrefsP->telRefNum,
                    gPrefsP->telAppID, &gEntry, NULL);
printf("Result of adding entry is %d", err);
```

Telephony Manager

Using the Telephony API

To call the same function asynchronously, you specify a transaction ID in the call, instead of specifying NULL as the last argument. The transaction ID (transId in [Listing 8.4](#)) is an unsigned integer value that is filled in with a value associated with the asynchronous operation that is begun. This same ID value is found in the transId field of event you receive when the operation completes.

Listing 8.4 Calling a function asynchronously

```
err = TelPhbAddEntry(gPrefsP->telRefNum,
                    gPrefsP->telAppID, &gEntry, &transId);

static void ProcessTelephonyEvent(TelEventType *eventP)
{
    switch( eventP->functionId )
    {
    ...
        case kTelPhbAddEntryMessage:
            printf("Result of adding entry is %d",
                  eventP->returnCode);
            break;
    ...
    }
```

Using Data Structures With Variably-sized Fields

Many of the telephony functions use data structures that have variably-sized buffer fields. For example, the [TelPhbGetEntry](#) function uses the [TelPhbEntryType](#) structure, which contains two such fields.

```
typedef struct _TelPhbEntryType
{
    UInt16    phoneIndex;
    Char*     fullName;
    UInt8     fullNameSize;
    Char*     dialNumber;
    UInt8     dialNumberSize;
} TelPhbEntryType;
```

The `fullName` and `dialNumber` buffers are variable-sized strings that you allocate in the heap. When you initialize one of these structures to pass to the [TelPhbGetEntry](#) function, you must preallocate the buffers and store the allocated size in the corresponding size fields.

The following code sample initializes a `TelPhbEntryType` data structure and passes it to the `TelPhbGetEntry` function to retrieve an entry from the phone book.

```
#define maxNameSize      45
#define maxNumSize      20
TelPhbEntryType myEntry;
UInt16 theIndex = 1;

myEntry.phoneIndex =      theIndex;
myEntry.fullName =      MemPtrNew(maxNameSize);
myEntry.fullNameSize =      maxNameSize;
myEntry.dialNumber =      MemPtrNew(maxNumSize);
myEntry.dialNumberSize =      maxNumSize;

err = TelPhbGetEntry(gPrefs->telRefNum, gPrefsP->telAppId,
                    &myEntry, NULL);
```

Note that you can call the [TelPhbGetEntryMaxSizes](#) function to retrieve the maximum name size (in addition to other information) instead of hardcoding it, as done in the above example.

Upon return from the function, the buffer fields are filled in, and the size fields contain the actual number of bytes that were stored into the buffer fields.

If the allocated size of a buffer is not large enough to contain the entire value, the command function does the following:

- Returns the `telErrBufferSize` error.
- Fills the buffer with as much data as it can, and truncates the data that does not fit. If the data ends with a null terminator and is truncated, the null terminator is retained.
- Sets the value of the size field to the actual size required to contain all of the data.

Note that for string buffers, the size includes the byte required for the null terminator character.

NOTE: When you call a function asynchronously, the `telErrBufferSize` error is returned in the `returnCode` field of the event you receive upon completion of the function's execution.

Also, when you call a function asynchronously, it is your responsibility to ensure that any data structure used by the function remains in memory until you receive the completion event.

Testing the Telephony Environment

Before running your application, you need to verify that the environment in which it is running (the Palm Powered™ handheld and the telephone device) supports the facilities that your application needs. The Telephony Manager allows you to determine if a specific service set is available, and also allows you to determine if a specific function call is supported.

The code excerpt in [Listing 8.5](#) shows how the `PhBkApp` program verifies that the environment supports the capabilities that it needs, which include all of the phone book-related features of the Telephony Manager. The `PhBkApp` program first tests for the availability of the phone book services, and then determines if several specific functions are supported. Note that the `PhBkApp` refuses to run if any of the capabilities it is using are not available.

Listing 8.5 Testing for the presence of specific capabilities

```
err = TelIsPhbServiceAvailable(gDataP->refNum, gDataP->appId, NULL);
// Test if phone book capabilities are present
if (err != errNone)
    return err;

// Check that this phone supports adding entry services
err = TelIsPhbAddEntrySupported(gDataP->refNum, gDataP->appId, NULL);
if (err != errNone)
    return err;

// Check that this phone supports selecting a phone book
err = TelIsPhbSelectPhonebookSupported(gDataP->refNum, gDataP->appId, NULL);
```

```
if (err != errNone)
    return err;

    // Check that this phone supports getting entries
err = TelIsPhbGetEntriesSupported(gDataP->refNum, gDataP->appId, NULL);
if (err != errNone)
    return err;

    // Check that this phone supports getting entry count
err = TelIsPhbGetEntryCountSupported(gDataP->refNum, gDataP->appId, NULL);
if (err != errNone)
    return err;

    // Check that this phone supports deleting an entry
err = TelIsPhbDeleteEntrySupported(gDataP->refNum, gDataP->appId, NULL);
return err;
```

For a complete list of the service availability macros, see [TelIs<ServiceSet>Available](#) in [Chapter 69](#), “[Telephony Basic Services](#),” in *Palm OS Programmer’s API Reference*.

For more information about determining if a specific function is supported, see [TelIs<FunctionName>Supported](#) in [Chapter 69](#), “[Telephony Basic Services](#),” in *Palm OS Programmer’s API Reference*.

Using the Phone Book Capabilities

This section describes the implementation of the PhBkApp program, which you can use as a model for implementing your own telephony-based applications. The PhBkApp code is described in the following sections:

- [About the PhBkApp Program](#) provides an overview of the PhBkApp program user interface.
- [Launching the PhBkApp Program](#) describes the main entry point in the program, which performs initialization and verifies that the environment supports the required telephony services.
- [Event Processing in the PhBkApp Program](#) describes how the program fields events and calls the appropriate functions for each event type.

Telephony Manager

Using the Phone Book Capabilities

- [Displaying the Phone Book](#) describes how the PhBkApp program accesses and provides a user interface to the phone book entries in the connected phone.
- [Retrieving the List of Phone Book Entries](#) provides a detailed walkthrough of how PhBkApp retrieves the current entries from one of the phone books on the connected phone.
- [Editing Phone Book Entries](#) describes how the PhBkApp program makes modifications to the phone book entries in the connected phone.


About the PhBkApp Program

The PhBkApp sample program uses Telephony Manager services and provides an interface to the phone book on a connected phone device.

NOTE: The PhBkApp program makes asynchronous calls to the Telephony Manager, which allows for operations to be cancelled, and allows the program to display progress to the user.


The PhBkApp program uses the simple form shown in [Figure 8.1](#) as its initial interface.

Figure 8.1 The initial screen of the PhBkApp program



When the user taps the **Get List** button, PhBkApp reads the entries in the selected phone book (SIM, built-in, or other) on the connected phone, and displays the list to the user. [Figure 8.2](#) shows a sample display of the phone list.


Figure 8.2 Phone book display in the PhBkApp program



Note that the phone book indicator in the upper right corner of [Figure 8.2](#) shows “Phone,” which indicates that the displayed list is the built-in phone book. The user can switch to a different phone book by tapping the arrow and choosing from the popup list.

The user can tap on an entry in the list to edit or delete that entry. If the user deletes an entry, the list maintains an empty entry in that position, as shown in [Figure 8.3](#), in which the entry for Harry (the seventh entry) has been deleted.

Figure 8.3 Phone list with deleted entry



To create a new entry, or look up an existing entry in the phone book, the user can tap the **New** button, which displays the editing form shown in [Figure 8.4](#).

Figure 8.4 The phone book entry editing form

| Phone Book | | 8/100 | ▼ Phone |
|------------|---------|------------|---------|
| 1 | Cynthia | 8315551234 | |
| 2 | Barbara | 8315559876 | |
| 3 | Greg | 4085558102 | |
| 4 | Lisa | 4085559234 | |
| 5 | John | 831555499 | |
| 6 | Jean | 4085557612 | |

| Phone - 7 | | i |
|---------------------------|--|---|
| Name: | | |
| Number: | | |
| OK Cancel Lookup Delete ↑ | | |

PhBkApp also displays the editing form when the user taps on an entry.

The next sections describe how the PhBkApp program implements this interface.

Launching the PhBkApp Program

The main entry point for the PhBkApp program, `PilotMain`, first verifies that the handheld device is version compatible with the program, which means that the device is running version 4.0 or later of the Palm OS. If so, then `PilotMain`, which is shown in [Listing 8.6](#), performs the following actions:

- Calls `PrvPhbkAppStart` to start the application. This function creates the database used by PhBkApp, opens the telephony library, and initializes the form that the program uses to display the phone book entries.
- Calls its main loop, `PrvPhbkAppEventLoop`, which is described in [Event Processing in the PhBkApp Program](#).
- Calls `PrvPhbkAppStop` to stop the application. This function closes the database and form, and deallocates the storage that PhBkApp allocated for its structures.

Listing 8.6 Launching the PhBkApp program

```
UInt32 PilotMain(UInt16 cmd, MemPtr cmdPBP, UInt16 launchFlags)
{
#pragma unused (cmdPBP)
    Err err = errNone;

    switch (cmd)
    {
        case sysAppLaunchCmdNormalLaunch:
            err = PrvPhbkAppRomVersionCompatible(kPhbkMinVersion, launchFlags);
            if (err != errNone)
                return (err);

            err = PrvPhbkAppStart();
            if (err == errNone)
                PrvPhbkAppEventLoop();
            PrvPhbkAppStop();
            break;

        default:
            break;
    }

    return 0;
}
```

Note that PilotMain passes a version value to the RomVersionCompatible function. This value is defined as follows:

```
#define kPhbkMinVersion sysMakeROMVersion(4,0,0,sysROMStageDevelopment,0)
```

The PrvPhbkAppRomVersionCompatible function, which is shown in [Listing 8.7](#), determines if the device has a compatible ROM, returning 0 if so.

Listing 8.7 The PrvPhbkAppRomVersionCompatible function

```
static Err PrvPhbkAppRomVersionCompatible(UInt32 requiredVersion,
    UInt16 launchFlags)
{
    UInt32 romVersion;

    FtrGet(sysFtrCreator, sysFtrNumROMVersion, &romVersion);
    if (romVersion < requiredVersion)
    {
        if ((launchFlags & (sysAppLaunchFlagNewGlobals | sysAppLaunchFlagUIApp))
            == (sysAppLaunchFlagNewGlobals | sysAppLaunchFlagUIApp))
        {
            ErrNonFatalDisplay("Incompatible ROM");
            // Palm OS 1.0 will continuously relaunch this app unless we switch to
            // another safe one.
            if (romVersion < sysMakeROMVersion(2,0,0,sysROMStageRelease,0))
            {
                AppLaunchWithCommand(sysFileCDefaultApp, sysAppLaunchCmdNormalLaunch,
                    NULL);
            }
        }

        return (sysErrRomIncompatible);
    }
    return 0; //ROM is compatible
}
```

Event Processing in the PhBkApp Program

The main loop of the PhBkApp program processes events for the program, branching to the appropriate functions when certain events arrive. This is a standard event loop, as described in [The Application Event Loop](#) in [Chapter 4](#), “[Event Loop](#).”

The PhBkApp main loop function, PrvPhbkAppEventLoop, calls the PrvPhbkAppHandleEvent function to process PhBkApp events, which pertain to one of two forms:

- The List form displays the list of numbers in the phone book. List form handling is described in [Displaying the Phone Book](#).

- The Edit form allows the user to edit an entry in the phone book. Edit form handling is described in [Editing Phone Book Entries](#).

Displaying the Phone Book

The PhBkApp list form manages display of the phone book entries. The PrvPhbkListFormDoCommand function processes user command events in this form, which include:

- The form's menu commands:
 - When the user taps the **About Phone Book** command, PhBkApp displays an about screen.
 - When the user taps the **Export to Address Book** command, PhBkApp uses the UDA and PDI interfaces to export a category from the phone book to the Palm Powered handheld's address book.

For more information about the PDI library, see [Chapter 3, "Personal Data Interchange."](#)

- Selection of items in the list for editing.
- Handling of the phone book selection control, which the user can tap to pick from among the phone books available on the device. For example, most phones feature a phone book stored on the SIM and a phone book in the phone's memory.
- Standard form handling, including scrolling and key handling.
- Retrieving of the phone book entries from the connected phone when the user taps the **Get List** button, as described in [Retrieving the List of Phone Book Entries](#).
- Adding a new entry in PhBkApp's database and displaying the Edit form to insert values into the fields in the new entry when the user taps the **New** button or double-taps an empty entry in the list. For more information, see [Editing Phone Book Entries](#).

[Listing 8.8](#) shows the PrvPhbkListFormDoCommand, which processes form commands.

Listing 8.8 Processing phone list form commands

```
static Boolean PrvPhbkListFormDoCommand( DmResID cmdId )
{
    switch (cmdId)
    {
        case PhbkListGetButton:
            PhbkGetList();
            break;

        case PhbkListNewButton:
            gAction = kPhbkActionNew;
            PrvPhbkListFormNewEntry();
            break;

        case MenuExporttoAddressBook:
            if ((gStorage[gCurCategory].canEdit == true)
                && (gStorage[gCurCategory].entryCount != 0))
                if (!HostGremlinIsRunning())
                    TransferExportCategory(gCurCategory);
            break;

        case MenuAboutPhoneBook:
            MenuEraseStatus(0);
            AbtShowAbout(kPhbkAppCreator);
            break;

        default:
            return false;
    }
    return true;
}
```

Retrieving the List of Phone Book Entries

The PhBkApp program retrieves the entries in the selected phone book by calling the PhbkGetList function, which is shown in [Listing 8.9](#). This function displays a progress bar and calls the PrvPhbkGetListHandleEvent function to read phone book entries and store them in the linked list managed by PhBkApp.

Listing 8.9 Retrieving the phone book entries

```
Err PhbkGetList( void )
{
    Err err;
    EventType evt;
    Boolean handled = false;
    UInt16 linkedListCount;

    err = PrvPhbkGetListStart();
    if (err)
        return err;

    gStorage[gCurCategory].canEdit = true;

    do
    {
        TelGetEvent(gDataP->refNum, gDataP->appId, &evt, kPhbkMidBallRefreshRate);
        PrgHandleEvent(gDataP->prgP, &evt);
        PrvPhbkGetListHandleEvent(&evt);

        if (gDataP->prgP == 0)
            gDataP->exit = true;

        // When a phone UI error dialog is displayed, progress is closed
        if ( (gDataP->prgP != 0) && ( (gDataP->prgP->stage ==
kPhbkStageClosingConnection) || PrgUserCancel(gDataP->prgP) || ( evt.eType ==
appStopEvent) ) )
        {
            if (PrgUserCancel(gDataP->prgP))
            {
                gStorage[gCurCategory].canEdit = false;
                PhbkTelMgrCancel();
            }
            gDataP->exit = true;
        }

        linkedListCount = PhbkToolsLinkedListCount();
    } while (!(gDataP->exit) && (linkedListCount));
    // Close the progress if not done before
    PrvPhbkGetListPrgClose();

    FrmUpdateForm(FrmGetActiveFormID(), frmRedrawUpdateCode);
    return errNone;
}
```

Telephony Manager

Using the Phone Book Capabilities

The PhBkApp program uses a progression of states to manage retrieving phone book entries from the connected device. When it enters into a state, the program updates the progress dialog and sends an asynchronous request to the Telephony Manager.

NOTE: The functions mentioned in this section are found in the PhBkGetList module, the PhBkTelMgr module, or in the Telephony Manager API.

The PrvPhbkGetListHandleEvent function processes the events returned from the Telephony Manager. When it receives a response back from a previous request, PrvPhbkGetListHandleEvent transitions to the next state, performs whatever tasks go along with entering that state, and sends the next request to the Telephony Manager.

[Table 8.2](#) shows the progression of states used to retrieve phone book entries.

Table 8.2 Phone book list retrieval states

| # | State name constant | Description of state |
|----|--------------------------------|---|
| 1. | kPhbkStageConnecting | PhBkApp is opening a connection to the phone device; a call to TelOpenPhoneConnection is pending. |
| 2. | kPhbkStageSelectingPhonebook | PhBkApp is selecting the current phone book (such as SIM or built-in); a call to TelPhbSelectPhonebook is pending. |
| 3. | kPhbkStageGettingPhonebookInfo | PhBkApp is retrieving information about the entries in the selected phone book; a call to TelPhbGetEntryCount is pending. |

Table 8.2 Phone book list retrieval states (*continued*)

| # | State name constant | Description of state |
|----|-----------------------------|--|
| 4. | kPhbkStageGettingEntries | PhBkApp is retrieving entries from the selected phone book; a call to TelPhbGetEntries is pending. |
| 5. | kPhbkStageClosingConnection | PhBkApp is closing the connection with the phone device; a call to TelClosePhoneConnection is pending. |

Each state transition involves updating the progress dialog display, so PhBkApp signals the transitions by passing the new state to the PrgUpdateDialog function, which passes the state onto the progress dialog's callback function, PrvPhbkGetListCallback.

Connecting with the Phone

When the user taps the **Get List** button, the PrvPhbkGetListStart function form code initializes the progress dialog display and:

- sets the current state to kPhbkStageConnecting
- calls the PhbkTelMgrConnect function, which issues an asynchronous call to the [TelOpenPhoneConnection](#) telephony function

Selecting the Phone Book on the Phone

When the list form event handler receives a response from the Telephony Manager indicating that it has connected with the phone, it does the following:

- sets the current state to kPhbkStageSelectingPhonebook
- calls the PhbkTelMgrSelectPhoneBook function, which issues an asynchronous call to the [TelPhbSelectPhonebook](#) function to select the phone book that was chosen by the user

Telephony Manager

Using the Phone Book Capabilities

Retrieving Phone Book Information from the Phone

When the list form event handler receives a response from the Telephony Manager indicating that it has selected the phone book on the phone, it does the following:

- sets the current state to `kPhbkStageGettingPhonebookInfo`
- calls the `PhbkTelMgrGetEntryCount` function, which issues an asynchronous call to the [TelPhbGetEntryCount](#) function to retrieve the number of entries in the selected phone book

Retrieving Phone Book Entries from the Phone

When the list form event handler receives a response from the Telephony Manager that specifies the number of entries in the selected phone book, it does the following:

- sets the current state to `kPhbkStageGettingEntries`
- creates space in the internal data storage system for the entries
- issues an asynchronous call to the [TelPhbGetEntries](#) function to retrieve the phone book data

Closing the Connection

When the list form event handler receives the entry data back from the Telephony Manager, it does the following:

- sets the current state to `kPhbkStageClosingConnection`
- calls the `PhbkTelMgrCloseConnection` function, which issues an asynchronous call to the [TelClosePhoneConnection](#) function to close the connection
- adds the downloaded phone book entries to the `PhBkApp` program's internal data storage system

Editing Phone Book Entries

The `PhBkApp` edit form manages editing of the phone book entries, including the following actions:

- adding a new entry to the phone book

- modifying the name or number data in an existing entry
- deleting an entry

PhBkApp displays the edit form when the user taps the **New** button or when the user taps on an entry in the displayed list. The edit form, which allows either modification or deletion of the selected entry, is shown in [Figure 8.4](#) on page 188.

This form operates in a analogous manner to the list form: a state machine tracks which Telephony Manager call is pending and performs the appropriate actions according to the current state. In addition to calling the [TelOpenPhoneConnection](#), [TelPhbSelectPhonebook](#), and [TelClosePhoneConnection](#) functions, the edit form calls the [TelPhbAddEntry](#) and [TelPhbDeleteEntry](#) functions.

Summary of Telephony Manager

Telephony Manager Functions

Basic Functions

| | |
|--|--|
| TelCancel | TelIsPhoneConnected |
| TelClose | TelIsPowServiceAvailable |
| TelClosePhoneConnection | TelIsSmsServiceAvailable |
| TelGetCallState | TelIsSndServiceAvailable |
| TelGetEvent | TelIsSpcServiceAvailable |
| TelGetTelephonyEvent | TelIsStyServiceAvailable |
| TelInfGetInformation | TelMatchPhoneDriver |
| TelIsCfgServiceAvailable | TelOemCall |
| TelIsDtcServiceAvailable | TelOpen |
| TelIsEmcServiceAvailable | TelOpenPhoneConnection |
| TelIsInfServiceAvailable | TelSendCommandString |
| TelIsNwkServiceAvailable | TelIs<FunctionName>Supported |

Telephony Manager

Summary of Telephony Manager

Telephony Manager Functions

[TelIsOemServiceAvailable](#)

[TelIs<ServiceSet>Available](#)

[TelIsPhbServiceAvailable](#)

Data Calls

[TelDtcCallNumber](#)

[TelDtcReceiveData](#)

[TelDtcCloseLine](#)

[TelDtcSendData](#)

Emergency Calls

[TelEmcCall](#)

[TelEmcGetNumberCount](#)

[TelEmcCloseLine](#)

[TelEmcSelectNumber](#)

[TelEmcGetNumber](#)

[TelEmcSetNumber](#)

Network Interface

[TelNwkGetLocation](#)

[TelNwkGetSelectedNetwork](#)

[TelNwkGetNetworkName](#)

[TelNwkGetSignalLevel](#)

[TelNwkGetNetworks](#)

[TelNwkSelectNetwork](#)

[TelNwkGetNetworkType](#)

[TelNwkSetSearchMode](#)

[TelNwkGetSearchMode](#)

Phone Book

[TelPhbAddEntry](#)

[TelPhbGetEntryCount](#)

[TelPhbDeleteEntry](#)

[TelPhbGetEntryMaxSizes](#)

[TelPhbGetAvailablePhonebooks](#)

[TelPhbGetSelectedPhonebook](#)

[TelPhbGetEntries](#)

[TelPhbSelectPhonebook](#)

[TelPhbGetEntry](#)

Power Management

[TelPowGetBatteryStatus](#)

[TelPowSetPhonePower](#)

[TelPowGetPowerLevel](#)

Telephony Manager Functions

Security

[TelStyChangeAuthenticationType](#) [TelStyGetAuthenticationState](#)
[TelStyEnterAuthenticationCode](#)

Short Message Services

| | |
|--|--|
| <u>TelCfgGetSmsCenter</u> | <u>TelSmsReadMessages</u> |
| <u>TelCfgSetSmsCenter</u> | <u>TelSmsReadReport</u> |
| <u>TelSmsDeleteMessage</u> | <u>TelSmsReadReports</u> |
| <u>TelSmsGetAvailableStorage</u> | <u>TelSmsReadSubmittedMessage</u> |
| <u>TelSmsGetDataMaxSize</u> | <u>TelSmsReadSubmittedMessages</u> |
| <u>TelSmsGetMessageCount</u> | <u>TelSmsSelectStorage</u> |
| <u>TelSmsGetSelectedStorage</u> | <u>TelSmsSendManualAcknowledge</u> |
| <u>TelSmsGetUniquePartId</u> | <u>TelSmsSendMessage</u> |
| <u>TelSmsReadMessage</u> | |

Sound

| | |
|--|--|
| <u>TelSndMute</u> | <u>TelSndStopKeyTone</u> |
| <u>TelSndPlayKeyTone</u> | |

Speech Calls

| | |
|--|--|
| <u>TelSpcAcceptCall</u> | <u>TelSpcRejectCall</u> |
| <u>TelSpcCallNumber</u> | <u>TelSpcRetrieveHeldLine</u> |
| <u>TelSpcCloseLine</u> | <u>TelSpcSelectLine</u> |
| <u>TelSpcConference</u> | <u>TelSpcSendBurstDTMF</u> |
| <u>TelSpcGetCallerNumber</u> | <u>TelSpcStartContinuousDTMF</u> |
| <u>TelSpcHoldLine</u> | <u>TelSpcStopContinuousDTMF</u> |
| <u>TelSpcPlayDTMF</u> | |

Index

Symbols

_send 18

A

AppNetRefnum 134, 135

AppNetTimeout 135

B

battery

 life, maximizing 48

baud rate, parity options 103, 104

_beam URL scheme 49

beaming 51, 85, 177

 registering for 49

Berkeley Sockets API 130

 mapping example 133

bind (Berkeley Sockets API) 145

Bluetooth 3, 92

Bluetooth exchange library 40

byte ordering 90

C

Clipper application 174

Clipper. *See* Web Clipping Application Viewer

close (Berkeley Sockets API) 145

close-wait state 142

closing net library 142

closing serial link manager 123

CncAddProfile 117

CncDefineParamID 118

CncDeleteProfile 117

CncGetProfileInfo 117

CncGetProfileList 117

CncProfileCloseDB 117

CncProfileCreate 118

CncProfileOpenDB 117

CncProfileSettingGet 117

CncProfileSettingSet 118

configuration, net library 135

connect (Berkeley Sockets API) 145

connection errors

 handling in exchange library 47

Connection Manager 116

Connection panel 116

connectivity 90

connector (external) 90

CRC-16 119

CTS timeout 103, 104

D

databases

 sending and receiving 26

debugging exchange libraries 42

desktop link protocol 91

Desktop Link Server 121

dispatch table

 exchange library 41–45

DLP 91

dmHdrAttrBundle 35

dmUnfiledCategory 20

DrvEntryPoint 115

DrvRcvQType 116

E

email applications

 registering 172

errno 135

errors

 handling in exchange library 47

EvtEventAvail 106

EvtGetEvent 106

EvtResetAutoOffTimer 106

EvtSetAutoOffTimer 106

exchange libraries

 and the Simulator 42

 buffering data 47, 48

 code resource 44

 connection errors 47

 creating 37

 debugging 42

 dispatch table 41–45

 HostTransfer example 40

 library-specific functions in 42

 naming functions 41

 previewing data 47

 registering with Exchange Manager 48

 relationship to Exchange Manager 38

- required functions 40, 46
- standard 39
- exchange library 2
 - local 32, 39
- Exchange Manager 1
 - creating libraries for 37
 - registering exchange libraries 48
 - relationship to exchange libraries 38
- ExgAccept 23, 29
- exgAskOk 23
- exgBeamPrefix 7
- ExgConnect 17, 30
- ExgDBRead 29
- ExgDBWrite 26
- ExgDialogInfoType 20
- ExgDisconnect 15, 17, 26, 29, 30
- ExgDoDialog 20
- ExgGet 29, 30, 31
- ExgGetDefaultApplication 11
- ExgGetRegisteredApplications 11
- ExgLibAccept 47
- ExgLibConnect 47
- ExgLibDisconnect 47, 48
- ExgLibPut 47
- ExgLibReceive 47
- ExgLibSend 47, 48
- exgLocalPrefix 7
- ExgLocalSocketInfoType 33
- ExgPreviewInfoType 22, 34
- ExgPut 15, 17, 26
- ExgReceive 29, 30
- exgRegCreatorID 9
- ExgRegisterData 8, 9, 12, 22
- ExgRegisterDatatype 9
- exgRegSchemeID 9
- ExgRequest 31
- ExgSend 15, 17, 26
- exgSendBeamPrefix 7, 18
- exgSendPrefix 7, 18
- ExgSetDefaultApplication 10
- ExgSocketType 4, 5, 15, 16, 22, 26, 29, 33
- exgUnwrap 14

F

- fcntl 145
- FIR 86

G

- getdomainname (Berkeley Sockets API) 149
- gethostbyaddr (Berkeley Sockets API) 149
- gethostbyname (Berkeley Sockets API) 149
- gethostname (Berkeley Sockets API) 150
- getpeername (Berkeley Sockets API) 145
- getservbyname (Berkeley Sockets API) 150
- getsockname (Berkeley Sockets API) 145
- getsockopt (Berkeley Sockets API) 146
- gettimeofday() (Berkeley Sockets API) 150
- global variables
 - and shared libraries 44

H

- handshaking options 103, 104
- _host URL scheme 49
- HostTransfer sample exchange library 40
- htonl (Berkeley Sockets API) 150
- htons (Berkeley Sockets API) 150

I

- iMessenger application 174
- inet_addr (Berkeley Sockets API) 151
- inet_lnaof (Berkeley Sockets API) 151
- inet_makeaddr (Berkeley Sockets API) 151
- inet_netof (Berkeley Sockets API) 151
- inet_network (Berkeley Sockets API) 151
- inet_ntoa (Berkeley Sockets API) 151
- infrared library 85
- interface(s) used by net library 136
- Internet 134
- Internet applications 130
- Internet library
 - RAM requirement 157
- IR 1, 92
- IR library 39, 85
 - accessing 87
- IrDA 3

IrDA stack 86
IrLAP 86
IrLMP 86
_irobex URL scheme 49

K

kSmsScheme 7

L

Launcher 34
libraries
 creating exchange 37
 shared 37, 42
listen (Berkeley Sockets API) 147
Local Exchange Library 32
local exchange library 39
Loop-back Test 121

M

mailbox queue 130
MIME data type 3
Modem Manager 91
Motorola byte ordering 90

N

net library
 closing 142
 open sockets maximum 144
 opening and closing 140
 OS requirement 131
 overview 130–133
 preferences 135
 RAM requirement 131
 setup and configuration 135
 version checking 143
net protocol stack 130
 as separate task 131
netIFCreatorLoop 136
netIFCreatorPPP 137
netIFCreatorSLIP 137
netlib interface introduction 130
NetLibIFAttach 136
NetLibIFDetach 136

NetLibIFGet 136
NetLibIFSettingGet 137
NetLibIFSettingSet 137
NetLibSettingGet 140
NetLibSettingSet 140
NetSocket.c 135
network device drivers 130
network interface 131
network services 129
nilEvent 107
ntohl (Berkeley Sockets API) 150
ntohs (Berkeley Sockets API) 150

O

OBEX 86
open sockets maximum (net library) 144
opening net library 140
opening serial link manager 123
opening serial port 98, 99, 101
over the air characters 176
overlays
 beaming 34
overview of net library 130–133

P

packet assembly/disassembly protocol 91
packet footer, SLP 120
packet header, SLP 120
packet receive timeout 123
PADP 91, 121
PDI library
 about 55
 accessing 64
 function summary 83
 international considerations 60
 properties dictionary 57
 unloading 65, 181
 using 60
 using different media with 73
 using with UDA 73
PDI properties
 about 56
 parameter name 56
 parameter value 56

- property name 56
- property value field 56
- PDI readers
 - about 57
 - creating 65
 - example of using 74
 - reading properties 66
 - reading property values 67
- PDI writers
 - about 58
 - creating 71
 - example of using 79
 - writing property values 72
- PdiEnterObject 78
- PdiReader 60, 67
- PdiReaderNew 65, 75
- PdiReadParameter 66
- PdiReadProperty 66
- PdiReadPropertyField 66, 68, 70, 78
- PdiReadPropertyName 66
- PdiWriteBeginObject 72, 79
- PdiWriteEndObject 72, 79
- PdiWriteProperty 72
- PdiWritePropertyFields 72
- PdiWritePropertyStr 72
- PdiWritePropertyValue 72
- PluginInfoType 152
- pluginMaxNumOfCmds 152
- pluginNetLibCallUIProc 155
- port ID for socket 123
- preferences database
 - net library 135
- preview 21
 - in exchange library 47
- properties dictionary 57

R

- read (Berkeley Sockets API) 147
- receiving SLP packet 122
- recv (Berkeley Sockets API) 147
- recvfrom (Berkeley Sockets API) 147
- recvmsg (Berkeley Sockets API) 147
- reference number for socket 123
- Remote Console 121

- Remote Console packets 121
- Remote Debugger 121, 122
- remote inter-application communication 91
- Remote Procedure Call packets 121
- remote procedure calls 91, 122
- Remote UI 121
- RIAC 91
- RPC 91, 122
- RS-232 signals 92

S

- scheme 6
- scptLauncCmdListCmds 152
- scptLaunchCmdExecuteCmd 152, 153
- scptLaunchCmdListCmds 152
- select (Berkeley Sockets API) 147
- _send URL scheme 49
- send (Berkeley Sockets API) 148
- Send command
 - registering for 49
- Send menu command 18
- Send With dialog 18
- sending stream of bytes 105, 106
- sendmsg (Berkeley Sockets API) 148
- sendto (Berkeley Sockets API) 148
- SerClearErr 108
- SerClose 101
- serErrAlreadyOpen 98
- SerGetStatus 108
- serial communication 90
- serial link manager 122
 - opening 123
- serial link protocol 91, 119, 120, 122
- Serial Manager 93
- serial port
 - opening 98, 99, 101
- SerOpen 101
- serPortLocalHotSync 101
- SerReceive 107
- SerReceiveCheck 107
- SerReceiveFlush 109
- SerReceiveWait 107
- SerSend 105

SerSendCheck 106
SerSendFlush 106
SerSendWait 105
SerSetSettings 103
setdomainname (Berkeley Sockets API) 150
sethostname (Berkeley Sockets API) 150
setsockopt (Berkeley Sockets API) 148
settimeofday (Berkeley Sockets API) 150
setup, net library 135
shared libraries 37, 42
 and library globals 44
 dispatch table 42–45
 startup routine 44
shutdown (Berkeley Sockets API) 149
Simulator
 and exchange libraries 42
SIR 86
SlkClose 123
SlkCloseSocket 123
slkErrAlreadyOpen 123
SlkOpen 123
SlkOpenSocket 123
SlkPktHeaderType 124
SlkReceivePacket 124, 126
SlkSendPacket 124
SlkSocketListenType 124
SlkSocketPortID 123
SlkSocketRefNum 123
SlkSocketSetTimeout 123
SlkWriteDataType 124
SLP 91, 119
SLP packet 119
 footer 120
 header 120
 receiving 122
 transmitting 122
SMS 1, 3
SMS exchange library 40
SO_ERROR (Berkeley Sockets API) 147
SO_KEEPALIVE (Berkeley Sockets API) 146, 148
SO_LINGER (Berkeley Sockets API) 146, 148
SO_TYPE (Berkeley Sockets API) 147
socket (Berkeley Sockets API) 149
 socket listener 124, 126
 socket listener procedure 124, 126
 sockets, opening serial link socket 123
SrmClearErr 108
SrmClose 101
SrmControl 103
SrmExtOpen 99
SrmExtOpenBackground 99
SrmGetStatus 108
SrmOpen 99
SrmOpenBackground 99
SrmOpenConfigType 99
SrmReceive 107
SrmReceiveCheck 107
SrmReceiveFlush 109
SrmReceiveWait 107
SrmReceiveWindowClose 108
SrmReceiveWindowOpen 108
SrmSend 105
SrmSendCheck 106
SrmSendFlush 106
SrmSendWait 105
SrmSetReceiveBuffer 102
SrmSettingsFlagCTSAutoM 104
srmSettingsFlagCTSAutoM 103
srmSettingsFlagRTSAutoM 104
__Startup__ 44
sys_socket.h 132, 135
SYS_TRAP macro 42
sysAppLaunchCmdExgAskUser 19, 23
sysAppLaunchCmdExgGetData 30
sysAppLaunchCmdExgPreview 19, 22
sysAppLaunchCmdExgReceiveData 19, 20, 23
sysAppLaunchCmdGoto 19
sysAppLaunchCmdGoToURL 31
sysAppLaunchCmdSyncNotify 9
sysFileCVirtIrComm 85, 100
sysFileDescStdIn 148
sysFtrNewSerialVersion 94
SysLibFind 87, 101
SysLibRemove 65
SystemMgr.h 136

T

- TCP/IP 129
- TCP_MAXSEG (Berkeley Sockets API) 146
- TCP_NODELAY (Berkeley Sockets API) 146, 148
- timeout
 - serial link socket 123
- Tiny TP 86
- transmitting SLP packet 122
- two-way communications 30
- typed data object 3

U

- UDA library
 - using with PDI 73
- UDP 129
- URL 5
- URL requests 31
- URL scheme 6
 - registering for 49
- USB 92

V

- vCal objects 52
- vCalendars 4
- vCard objects 52
- vCards 4
- vchrHardAntenna 175
- vchrRadioCoverageFail 175
- vchrRadioCoverageOK 175

- VDrvClose 115
- VDrvControl 115
- VDrvCustomControlProcPtr 115
- VDrvOpen 115
- VDrvStatus 115
- VDrvWrite 115
- version checking, net library 143
- vEvent objects 52
- Viewer application 174
- Viewer. *See* Web Clipping Application Viewer
- vObjects
 - about 52
 - character sets 55
 - encodings 55
 - grouping 54
 - structure of 53
- vTodo 52

W

- WCA Viewer. *See* Web Clipping Application Viewer
- Web Clipper. *See* Web Clipping Application Viewer
- Web Clipping Application Viewer 174
- web clipping applications
 - architecture 168
- web clipping architecture 168
- web clippings
 - architecture 168
- wireless internet feature set 174
- write (Berkeley Sockets API) 149