



Palm OS[®] Programming Development Tools Guide

CONTRIBUTORS

Written by Brian Maas and Gary Hillerson

Production by <dot>PS Document Production Services

Engineering contributions by Keith Rollin, Derek Johnson, Ken Krugler, Jesse Donaldson, Andy Stewart, and Kenneth Albanowski

Copyright © 1996 - 2001, Palm, Inc. All rights reserved. This documentation may be printed and copied solely for use in developing products for Palm OS software. In addition, two (2) copies of this documentation may be made for archival and backup purposes. Except for the foregoing, no part of this documentation may be reproduced or transmitted in any form or by any means or used to make any derivative work (such as translation, transformation or adaptation) without express written consent from Palm, Inc.

Palm, Inc. reserves the right to revise this documentation and to make changes in content from time to time without obligation on the part of Palm, Inc. to provide notification of such revision or changes. PALM, INC. MAKES NO REPRESENTATIONS OR WARRANTIES THAT THE DOCUMENTATION IS FREE OF ERRORS OR THAT THE DOCUMENTATION IS SUITABLE FOR YOUR USE. THE DOCUMENTATION IS PROVIDED ON AN "AS IS" BASIS. PALM, INC. MAKES NO WARRANTIES, TERMS OR CONDITIONS, EXPRESS OR IMPLIED, EITHER IN FACT OR BY OPERATION OF LAW, STATUTORY OR OTHERWISE, INCLUDING WARRANTIES, TERMS, OR CONDITIONS OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, AND SATISFACTORY QUALITY.

TO THE FULL EXTENT ALLOWED BY LAW, PALM, INC. ALSO EXCLUDES FOR ITSELF AND ITS SUPPLIERS ANY LIABILITY, WHETHER BASED IN CONTRACT OR TORT (INCLUDING NEGLIGENCE), FOR DIRECT, INCIDENTAL, CONSEQUENTIAL, INDIRECT, SPECIAL, OR PUNITIVE DAMAGES OF ANY KIND, OR FOR LOSS OF REVENUE OR PROFITS, LOSS OF BUSINESS, LOSS OF INFORMATION OR DATA, OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THIS DOCUMENTATION, EVEN IF PALM, INC. HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Palm Computing, Palm OS, Graffiti, HotSync, iMessenger and Palm Modem are registered trademarks, and Palm III, Palm IIle, Palm IIIx, Palm V, Palm Vx, Palm VII, Palm, Palm Powered, More connected., Simply Palm, the Palm logo, Palm Computing platform logo, Palm III logo, Palm IIIx logo, Palm V logo, and HotSync logo are trademarks of Palm, Inc. or its subsidiaries. All other product and brand names may be trademarks or registered trademarks of their respective owners.

IF THIS DOCUMENTATION IS PROVIDED ON A COMPACT DISC, THE OTHER SOFTWARE AND DOCUMENTATION ON THE COMPACT DISC ARE SUBJECT TO THE LICENSE AGREEMENT ACCOMPANYING THE COMPACT DISC.

Palm OS Programming Development Tools Guide

Document Number 3011-003

May 1, 2001

For the latest version of this document, visit

<http://www.palmos.com/dev/tech/docs/>.

Palm, Inc.

5470 Great America Pkwy.

Santa Clara, CA 95052

USA

www.palmos.com

Table of Contents

About This Document	19
Palm OS SDK Documentation	19
What This Volume Contains	19
Conventions Used in This Guide	21
Additional Resources	21

Part I: Testing Your Application

1 Using Palm OS Emulator	25
About Palm OS Emulator	26
Feature Overview.	26
Standard Device Features	28
Extended Emulation Features	28
Debugging Features	28
Prerequisites	29
Palm OS Emulator Runtime Requirements.	29
Using ROM Images.	29
Downloading Palm OS Emulator	30
Versions of Palm OS Emulator	31
Loading ROM Images	33
Downloading a ROM Image Obtained From Palm	33
Transferring a ROM Image From a Handheld	33
Transferring a ROM File in Windows	33
Transferring a ROM File On a Macintosh	34
Transferring a ROM File On a Unix System	35
Using a ROM Image in Palm OS Emulator.	36
Running Palm OS Emulator	38
Command Line Options.	38
Starting Palm OS Emulator	42
Using Emulation Sessions	45
Configuring a New Session	45
The Difference Between the New Menu Item and the Open Menu Item	47
Dragging and Dropping Files	47

Saving and Restoring Session State	48
Changing the Emulator's Appearance	48
Modifying the Runtime Environment	50
Palm OS Emulator Properties	50
Installing Applications	51
Serial Communications and Palm OS Emulator.	52
Using the HotSync Application With Palm OS Emulator.	53
Emulating Expansion Cards	56
Testing Your Application	58
Testing Software	58
Debug Options.	58
Logging Options	61
Using Gremlins to Automate Testing	65
Setting Breakpoints.	70
Source Level Debugging	72
Connecting Emulator with Palm Debugger	73
Connecting Emulator with the GDB Debugger	73
Connecting the Emulator With External Debuggers	74
Profiling Your Code	75
Error Handling Concepts	76
Detecting an Error Condition	77
Error Condition Types	77
Error Messages	78
Advanced Topics	84
Creating Demonstration Versions of Palm OS Emulator.	84
Sending Commands to Palm OS Emulator.	84
User Interface Summary	86
Palm OS Emulator Display	86
Using the Menus	86
Using the Hardware Buttons.	91
Entering Data	92
Control Keys	92
Getting Help With Palm OS Emulator	93

2 Host Control API Reference	95
About the Host Control API	95
Constants	96
Host Error Constants	96
Host Function Selector Constants.	100
Host ID Constants	100
Host Platform Constants	100
Host Signal Constants	101
Data Types.	101
HostBoolType	102
HostClockType	102
HostDirEntType	102
HostDIRType	102
HostFILEType	103
HostGremlinInfoType.	103
HostIDType	104
HostPlatformType	104
HostSignalType	104
HostSizeType	104
HostStatType	105
HostTimeType.	106
HostTmType	106
HostUTimeType	107
Functions	108
HostAscTime	108
HostClock.	108
HostCloseDir	109
HostCTime	109
HostErrNo	109
HostExportFile.	110
HostFClose	110
HostFEOF.	111
HostFError	111
HostFFlush	111
HostFGetC	112
HostFGetPos	112
HostFGetS.	112

HostFOpen	113
HostFPrintf	113
HostFPutC	113
HostFPutS.	114
HostFRead	114
HostFree	114
HostFReopen	115
HostFScanF	115
HostFSeek.	116
HostFSetPos.	116
HostFTell	117
HostFWrite	117
HostGestalt	117
HostGetDirectory	118
HostGetEnv	118
HostGetFile	118
HostGetFileAttr	119
HostGetHostID	120
HostGetHostPlatform.	120
HostGetHostVersion	120
HostGetPreference	121
HostGMTime	122
HostGremlinCounter	122
HostGremlinIsRunning	122
HostGremlinLimit	123
HostGremlinNew	123
HostGremlinNumber	123
HostImportFile	124
HostIsCallingTrap	124
HostIsSelectorImplemented	125
HostLocalTime.	125
HostLogFile	126
HostMalloc	126
HostMkDir	126
HostMkTime	127
HostOpenDir	127

HostProfileCleanup	127
HostProfileDetailFn	128
HostProfileDump	129
HostProfileGetCycles	129
HostProfileInit	130
HostProfileStart	131
HostProfileStop	131
HostPutFile	132
HostReadDir	132
HostRealloc	133
HostRemove.	133
HostRename.	133
HostRmDir	134
HostSaveScreen	134
HostSessionClose	135
HostSessionCreate	135
HostSessionOpen	136
HostSessionQuit	136
HostSetFileAttr	137
HostSetLogFileSize	138
HostSetPreference	138
HostSignalResume	139
HostSignalSend	139
HostSignalWait	140
HostSlotHasCard.	141
HostSlotMax.	142
HostSlotRoot	142
HostStat	143
HostStrFTime	143
HostTime	144
HostTmpFile	144
HostTmpNam	144
HostTraceClose	145
HostTraceInit	145
HostTraceOutputB	146
HostTraceOutputT	146
HostTraceOutputTL	148

HostTraceOutputVT	149
HostTraceOutputVTL.	150
HostTruncate	150
HostUTime	151
Reference Summary.	151
Host Control Database Functions.	151
Host Control Directory Handler Functions.	152
Host Control Environment Functions	152
Host Control File Chooser Support Functions	153
Host Control Gremlin Functions	153
Host Control Logging Functions	154
Host Control Preference Functions	154
Host Control Profiling Functions	154
Host Control RPC Functions	155
Host Control Standard C Library Functions	155
Host Control Time Functions	157
Host Control Tracing Functions	158

3 Using Palm Simulator 161

About Palm Simulator.	161
Feature Overview.	162
Palm Simulator Compared to Palm OS Emulator	163
Differences Between Palm Simulator and Actual Hardware	164
Using Palm Simulator	166
Building a Project for Use with Simulator	166
Tracing Events	168
Scripting Pen and Key Events	169
Using Gremlins	170
Saving Memory Information to File.	170
Simulator Menu Commands Summary	171
File Menu	171
Edit Menu.	172
Window Menu.	172
Replay Menu	172
Gremlin Menu	173
Serial Port Menu	174
Panel Menu	174

Part II: Debugging Your Application

4 Using Palm Debugger	179
About Palm Debugger.	180
Connecting Palm Debugger With a Target	182
Connecting to The Palm OS Emulator.	182
Connecting to The Handheld Device	182
Using the Console and Debugging Windows Together	186
Entering Palm Debugger Commands	187
Palm Debugger Menus	188
Palm Debugger Command Syntax	190
Using the Debugging Window	192
Using Debugger Expressions	194
Performing Basic Debugging Tasks	200
Advanced Debugging Features.	207
Using the Source Window	209
Debugging With the Source Window	210
Using Symbol Files	211
Using the Source Menu	212
Source Window Debugging Limitations	214
Palm Debugger Error Messages.	214
Palm Debugger Tips and Examples	215
Performing Calculations	215
Shortcut Characters.	216
Repeating Commands	216
Finding a Specific Function	216
Finding Memory Corruption Problems	220
Displaying Local Variables and Function Parameters	222
Changing the Baud Rate Used by Palm Debugger	225
Debugging Applications That Use the Serial Port	226
Importing System Extensions and Libraries	226
Determining the Current Location Within an Application	227

5 Palm Debugger Command Reference	229
Command Syntax.	229
Specifying Numeric and Address Values	231
Using the Expression Language	231
Debugging Window Commands	231
>	232
alias	233
aliases	233
atb	234
atc	234
atd	234
atr	235
att	235
bootstrap	235
br	236
brc	236
brd	237
cardInfo.	237
cl.	238
db	238
dir	239
dl	241
dm	241
dump.	242
dw	242
dx	242
fb	243
fill	243
fl.	244
ft.	244
fw	245
g.	246
gt	246
hChk	246
hd	247

help (?)	249
hl	249
ht	250
il	251
Info	252
keywords	252
load	253
opened	253
penv	254
reg	255
reset	255
run	256
s	256
save	256
sb	257
sc	257
sc6	258
sc7	258
sizeof	259
sl	259
ss	260
storeInfo	260
sw	261
t	262
templates	262
typedef	263
typeend	263
var	264
variables	264
wh	265
Debugging Command Summary	265
Flow Control Commands	265
Memory Commands	266
Template Commands	267
Register Commands	267

Utility Commands	267
Console Commands	268
Miscellaneous Debugger Commands	269
Debugger Environment Variables.	269
Predefined Constants	269

6 Debugger Protocol Reference 271

About the Palm Debugger Protocol	271
Packets	272
Packet Structure	272
Packet Communications.	274
Constants	274
Packet Constants	274
State Constants	275
Breakpoint Constants	275
Command Constants	275
Data Structures	276
_SysPktBodyCommon	276
SysPktBodyType	277
SysPktRPCParamType	277
BreakpointType	278
Debugger Protocol Commands	278
Continue	278
Find	280
Get Breakpoints	281
Get Routine Name	282
Get Trap Breaks	284
Get Trap Conditionals.	285
Message	286
Read Memory	287
Read Registers	288
RPC	289
Set Breakpoints	290
Set Trap Breaks.	291
Set Trap Conditionals	292

State	294
Toggle Debugger Breaks.	296
Write Memory	297
Write Registers.	298
Summary of Debugger Protocol Packets	299

7 Using the Console Window 301

About the Console Window	301
Connecting the Console Window	302
Activating Console Input	302
Using Shortcut Numbers to Activate the Windows	303
Entering Console Window Commands	305
Command Syntax.	308
Specifying Numeric and Address Values	310
Console Window Commands	310
AddRecord	311
AddResource	311
AttachRecord	312
AttachResource	312
Battery	313
CardFormat	313
CardInfo	314
ChangeRecord	314
ChangeResource	315
Close	315
ColdBoot	315
Create	316
Del	316
DelRecord	317
DelResource	317
DetachRecord	318
DetachResource	318
Dir	319
DM.	320
Doze	321

Exit.	321
Export	322
Feature	323
FindRecord	324
Free	324
GDB	324
GetResource	325
Gremlin.	325
GremlinOff	325
HC	326
HChk.	326
HD.	327
Help	328
HF	329
HI	329
HL	329
HS	330
HT	330
HTorture	331
Import	332
Info	333
KInfo	334
Launch	335
ListRecords	336
ListResources	336
Lock	336
Log.	337
MDebug	337
MoveRecord.	339
New	339
Open	340
Opened	340
Performance.	341
PowerOn	341
Reset	342

Resize	342
SaveImages	343
SB	343
SetInfo	343
SetOwner	344
SetRecordInfo	344
SetResourceInfo	345
SimSync	345
Sleep	345
StoreInfo	346
Switch	347
SysAlarmDump	347
Unlock	348
Console Command Summary	348
Card Information Commands	348
Chunk Utility Commands	348
Database Utility Commands	349
Debugging Utility Commands	349
Gremlin Commands	349
Heap Utility Commands	349
Host Control Commands	350
Miscellaneous Utility Commands	350
Record Utility Commands	350
Resource Utility Commands	351
System Commands	351

Part III: Tracing Your Application

8 Using Palm Reporter	355
About Palm Reporter	355
Palm Reporter Features	355
Downloading Palm Reporter	356
Palm Reporter Package Files	356
Installing Palm Reporter	356
Adding Trace Calls to Your Application	357

Specifying Trace Strings	358
Trace Functions in a Code Sample	359
Displaying Trace Information in Palm Reporter	360
Starting a Palm Reporter Session	360
Filtering Information in a Palm Reporter Session	361
Using the Palm Reporter Toolbar	362
Troubleshooting Palm Reporter	363

Part IV: Creating National Language Versions of Your Application

9 Using the Overlay Tools	369
Using Overlays to Localize Resources	369
Overlay Database Names	370
Overlay Specification Resources	370
About the Overlay Tools	371
Using the PRC-to-Overlay Function	371
How the PRC-to-Overlay Function Works	371
Choosing a Locale	371
Modifying the Filter Set	372
PRC2OVL Example.	373
Using the Patch Overlay Function.	374
PRC2OVL Options Summary	375
Getting Help.	377
Using PRC2OVL on the Macintosh	377
Opening a PRC file	377
Selecting Resources.	377

Part V: Appendixes

A Resource Tools	381
B Simple Data Types	383
Glossary	385
Index	387

About This Document

Palm OS® Programming Development Tools Guide describes various tools you can use to develop software for Palm Powered™ handhelds.

Palm OS SDK Documentation

In addition to this book, the following documents are part of the SDK:

Document	Description
<i>Palm OS Programmer's API Reference</i>	An API reference document that contains descriptions of all Palm OS function calls and important data structures.
<i>Palm OS Programmer's Companion</i> , vol. I and <i>Palm OS Programmer's Companion</i> , vol. II, <i>Communications</i>	A guide to application programming for the Palm OS. These volumes contain conceptual and "how-to" information that complements <i>Palm OS Programmer's API Reference</i> .

What This Volume Contains

This volume is designed for random access. That is, you can read any chapter in any order. Here is an overview of this volume:

- ["Testing Your Application"](#) covers the developer tools you can use to test your application:
 - [Chapter 1, "Using Palm OS Emulator."](#) Describes Palm OS Emulator, which emulates Palm™ hardware in software on a Macintosh, Unix or Windows-based desktop computer.

About This Document

What This Volume Contains

- [Chapter 2, “Host Control API Reference.”](#) Describes the host control API, which provides functions that an emulated application can use to call into Palm OS Emulator for certain services.
- [Chapter 3, “Using Palm Simulator.”](#) Describes Palm Simulator, which simulates a Palm handheld on a Macintosh-based desktop computer.
- [“Debugging Your Application”](#) covers developer tools and commands you can use to do further debugging of your application:
 - [Chapter 4, “Using Palm Debugger.”](#) Provides an introduction to Palm Debugger, which is an assembly language and limited source code level debugger for Palm OS programs. This chapter describes how to use Palm Debugger, including a description of its expression language and a variety of debugging strategies and tips.
 - [Chapter 5, “Palm Debugger Command Reference.”](#) Provides a complete reference description for each command available in Palm Debugger.
 - [Chapter 6, “Debugger Protocol Reference.”](#) Describes the API for sending commands and responses between a debugging host, such as Palm Debugger, and a debugging target, which can be a Palm Powered handheld ROM or an emulator program such as Palm OS Emulator.
 - [Chapter 7, “Using the Console Window.”](#) Describes how the Console Window can be used to perform maintenance and do high-level debugging of a Palm handheld device.
- [“Tracing Your Application”](#) covers a tool you can use to do trace analysis of your application.
 - [Chapter 8, “Using Palm Reporter.”](#) Describes Palm Reporter, which is a trace utility that can be used with Palm OS Emulator.
- [“Creating National Language Versions of Your Application”](#) covers tools that you can use to develop translated resource overlays for your application.
 - [Chapter 9, “Using the Overlay Tools.”](#)

- “[Appendixes](#)” cover additional topics that may be of interest to Palm application developers.
 - [Appendix A, “Resource Tools.”](#) Provides a short description of resource tools that can be used to develop application resources.
 - [Appendix B, “Simple Data Types.”](#) Describes the simple data type name changes made in recent versions of the Palm OS software.

Conventions Used in This Guide

This guide uses the following typographical conventions:

This style...	Is used for...
fixed width font	Code elements such as function, structure, field, bitfield.
<u>fixed width underline</u>	Emphasis (for code elements).
bold	Emphasis (for other elements).
blue and underlined	Hot links in the online version.

Additional Resources

- Documentation
Palm publishes its latest versions of this and other documents for Palm OS developers at
<http://www.palmos.com/dev/tech/docs/>
- Training
Palm and its partners host training classes for Palm OS developers. For topics and schedules, check
<http://www.palmos.com/dev/tech/support/classes/>

About This Document

Additional Resources

- Knowledge Base

The Knowledge Base is a fast, web-based database of technical information. Search for frequently asked questions (FAQs), sample code, white papers, and the development documentation at

<http://www.palmos.com/dev/tech/kb/>



Part I: Testing Your Application

Using Palm OS Emulator

This chapter describes how to use the Palm OS® Emulator program, a hardware emulator for the Palm Powered™ platform. You can use Palm OS Emulator to test and debug programs that you have developed for this platform.

This edition covers Palm OS Emulator 3.0a8.

Note: Palm OS Emulator has previously been referred to as POSE or Poser. The name Palm OS Emulator is used throughout this book and in new versions of other Palm™ documentation. In this chapter, Emulator is sometimes used as an abbreviated form of Palm OS Emulator.

This chapter begins with overview information:

- [“About Palm OS Emulator”](#) on page 26
- [“Feature Overview”](#) on page 26
- [“Prerequisites”](#) on page 29

Next, the chapter addresses how you can use an Emulator session to test your application:

- [“Downloading Palm OS Emulator”](#) on page 30
- [“Loading ROM Images”](#) on page 33
- [“Running Palm OS Emulator”](#) on page 38
- [“Using Emulation Sessions”](#) on page 45
- [“Modifying the Runtime Environment”](#) on page 50
- [“Testing Your Application”](#) on page 58

The remainder of the chapter covers additional concepts and reference information:

- [“Error Handling Concepts”](#) on page 76

Using Palm OS Emulator

About Palm OS Emulator

- “[Advanced Topics](#)” on page 84
- “[User Interface Summary](#)” on page 86
- “[Getting Help With Palm OS Emulator](#)” on page 93

About Palm OS Emulator

Palm OS Emulator is a hardware emulator program for the Palm Powered platform, which means that it emulates the Palm hardware in software, providing you with the ability to test and debug Palm OS software on a Macintosh, Unix, or Windows-based desktop computer.

When you run a Palm OS application with Palm OS Emulator on your desktop computer, Palm OS Emulator fetches instructions, updates the handheld screen display, works with special registers, and handles interrupts in exactly the same manner as does the processor inside of Palm Powered handhelds. The difference is that Palm OS Emulator executes these instructions in software on your desktop computer.

Feature Overview

Palm OS Emulator displays an on-screen image that looks exactly like a Palm Powered handheld, as shown in [Figure 1.1](#).

Figure 1.1 Palm OS Emulator display



You can select which type of Palm handheld device you want to emulate. You can also specify whether you want Palm OS Emulator to display the screen in double size, which continues to provide an accurate representation and makes the Palm screen easier to view.

You can use the mouse on your desktop computer just as you use the stylus on a Palm Powered handheld. You can even use the Graffiti® power writing software with Palm OS Emulator and your mouse. And Palm OS Emulator includes additional keyboard shortcuts that you can use on your desktop computer.

You can use Palm OS Emulator to perform some debugging of your applications, and you can use Emulator with Palm Debugger to perform extensive debugging of your applications. When you connect Emulator with Palm Debugger, you can debug in exactly the same manner as debugging with your application running on an actual hardware handheld device. For more information about Palm Debugger, see [Chapter 4](#), “[Using Palm Debugger](#).”

Standard Device Features

Palm OS Emulator accurately emulates Palm Powered hardware devices, and includes the following features:

- an exact replica of the Palm device display, including the silkscreen and Graffiti areas
- emulation of the Palm stylus with the desktop computer pointing device (mouse)
- emulation of the Palm device hardware buttons, including:
 - power on/off button
 - application buttons
 - up and down buttons
 - reset button
 - HotSync® button
- ability to zoom the display for enhanced readability and presentation
- screen backlighting
- communications port emulation for modem communications and synchronizing

Extended Emulation Features

Palm OS Emulator also provides the following capabilities on your desktop computer that extend the standard Palm device interface.

- ability to enter text with the desktop computer
- configurable memory card size, up to 8MB

Debugging Features

Palm OS Emulator provides a large number of debugging features that help you to detect coding problems and unsafe application operations. Palm OS Emulator includes the following debugging features and capabilities:

- use of an automated test facility called Gremlins, which repeatedly generates random events

- support for external debuggers, including Palm Debugger, the Metrowerks CodeWarrior debugger, and gdb.
- monitoring of application actions, including various memory access and memory block activities
- logging of application activities, including events handled, functions called, and CPU opcodes executed by the application
- profiling of application performance

Prerequisites

Palm OS Emulator Runtime Requirements

Palm OS Emulator requires one of the following runtime environments:

- Windows 98
- Windows 95
- Windows NT
- MacOS 7.5 or later
- Unix: some versions, including Linux

Emulator is a multi-threaded 32-bit program. It does not run on Windows 3.1, even with Win32s installed.

Using ROM Images

To run Palm OS Emulator, you need to transfer a ROM image to it. The ROM image contains all of the code used for a specific version of the Palm OS. You can obtain ROM images for different Palm OS versions from the Palm Resource Pavilion, or you can tell Palm OS Emulator to download the ROM from a handheld that has been placed in the device cradle and connected to the desktop computer. For more information about transferring a ROM image to Palm OS Emulator, see "[Loading ROM Images](#)" on page 33.

When you download ROM images from the Palm Resource Pavilion, you can also obtain debug ROM images. Debug ROM

Using Palm OS Emulator

Downloading Palm OS Emulator

images contain additional error checking and reporting functions that can help you debug Palm OS applications.

For more information about testing and debugging applications with Palm OS Emulator, see “[Testing Your Application](#)” on page 58.

Downloading Palm OS Emulator

The most recent released version of Palm OS Emulator for both the Macintosh and Windows is always posted on the Internet in the Palm developer zone:

<http://www.palmos.com/dev>

Follow the links from the developer zone main page to the Emulator page to retrieve the released version of Emulator. If you want to test-drive the version of Palm OS Emulator that is currently under development, follow links from the developer zone page to the Emulator seed page.

The Palm OS Emulator package that you download includes the files shown in [Table 1.1](#).

Note: For the Unix version of Palm OS Emulator, the source code is provided rather than the executables listed in the table below.

Table 1.1 Files Included in the Palm OS Emulator Package

File name	Description
<ul style="list-style-type: none">Emulator.exe (Windows)Palm OS Emulator (Macintosh)	Main Palm OS Emulator executable
<ul style="list-style-type: none">Emulator_Profile.exe (Windows)Palm OS Emulator - Profile (Macintosh)	Palm OS Emulator with added profiling facilities

Table 1.1 Files Included in the Palm OS Emulator Package

File name	Description
Docs (directory)	Palm OS Emulator documents, including: <ul style="list-style-type: none">• <code>_ReadMe.txt</code>, which describes the files in the Docs directory• <code>_News.txt</code>, which describes changes in the most recent version• <code>_OldNews.txt</code>, which describes previous version changes• <code>_Building.txt</code>, which describes how to build Emulator executables
<ul style="list-style-type: none">• <code>ROM_Transfer.prc</code> (Windows, Macintosh)• <code>ROM_Transfer.prc</code> (Unix)	Palm OS application used to transfer the ROM image from your handheld device to your desktop.
<code>HostControl.h</code>	C/C++ header file declaring functions that can be used to control Palm OS Emulator. For more information about the Host Control API, see Chapter 2, “Host Control API Reference.”

Versions of Palm OS Emulator

Each released version of Palm OS Emulator has a version number that uses the following scheme:

`<majorVers>.<minorVers>.<bugFix>[dab]<preRel>`

Each field has the following semantics:

<code>majorVers</code>	The major version number.
<code>minorVers</code>	The minor version number.
<code>bugFix</code>	The optional bug repair revision number.
<code>dab</code>	The prelease stage of the product, as follows:

Using Palm OS Emulator

Downloading Palm OS Emulator

	d	Indicates that the version is currently under development, and features are still being added.
	a	Indicates alpha status, which means that the feature set is complete and some quality assurance testing has been performed.
	b	Indicates beta status, which means that bugs uncovered in the alpha version have been addressed, and more extensive testing has been performed.
preRel		The developmental, pre-release version number.

Some examples of version numbers are shown in [Table 1.2](#)

Table 1.2 Version number examples

Version	Description
3.0	Official release version 3.0
2.1d19	The 19th developmental release of version 2.1.
3.0a8	The 8th alpha release of version 3.0.

Profile Versions

Some releases of Palm OS Emulator include a profile version, with the word profile appended to the program name. Each profile version adds the ability to perform selective profiling of your program's execution, and to save the results to a file.

The code required to add profiling capability slows down your application, even when you are not using profiling. That means that you are better off using the non-profiling version of Palm OS Emulator if you don't expect to use the profiling capabilities.

For more information about profiling with Palm OS Emulator, see "[Profiling Your Code](#)" on page 75.

Loading ROM Images

Because Palm OS Emulator emulates the Palm Powered hardware, all components of the hardware must be present. This includes a ROM image file, which is not shipped with the Emulator. There are two ways to obtain a ROM image:

- download a ROM image from the Palm Resource Pavilion
- transfer a ROM image from a handheld

Downloading a ROM Image Obtained From Palm

To download a debug ROM image from Palm, see:

<http://www.palmos.com/dev>

The ROM image files are found in the Resource Pavilion.

The Resource Pavilion is an area for developers who have registered as members of the Palm Alliance Program. You can find instructions for joining the Palm Alliance Program at the developer site.

Transferring a ROM Image From a Handheld

To transfer a ROM image from a handheld, follow these steps:

1. Install the Palm OS application named `ROM Transfer.prc` on your handheld device. You can use the Install program in the Palm Desktop organizer software and then synchronize with the handheld to install this program.
2. Place the handheld in the HotSync cradle that is connected to your desktop computer.
3. Follow the steps in the appropriate section below.

Transferring a ROM File in Windows


This section describes how to transfer a ROM image from a handheld on a Windows-based desktop computer. Before proceeding, you must have the `ROM Transfer.prc` program installed on the handheld, as described in the previous section.

Using Palm OS Emulator

Loading ROM Images

If you are running the program for the first time, Palm OS Emulator presents the Startup dialog box shown in [Figure 1.2](#). Click **Download** to begin the transfer of a ROM image from a handheld.

Figure 1.2 Palm OS Emulator Startup Dialog Box



If you are not running Palm OS Emulator for the first time, it usually restarts the session that you most recently ran, as described in “[Starting Palm OS Emulator](#)” on page 42.

To transfer a new ROM image for Palm OS Emulator to use, you can right-click on the Palm OS Emulator display (the Palm device image) and select **Transfer ROM**.


Palm OS Emulator opens a Transfer ROM dialog box that will guide you through the process.

Transferring a ROM File On a Macintosh

This section describes how to transfer a ROM image from a handheld on a Macintosh desktop computer. Before proceeding, you must have the ROM `Transfer.prc` program installed on the handheld, as described in the previous section.

If you are running the program for the first time, Palm OS Emulator presents the dialog box shown in [Figure 1.3](#).

Figure 1.3 Running Palm OS Emulator for the First Time on a Macintosh System



You can dismiss this dialog box and choose **Transfer ROM** from the File menu.

If you are not running Palm OS Emulator for the first time, it usually restarts the session that you most recently ran. To transfer a new ROM image for Palm OS Emulator to use, select **Transfer ROM** from the File menu.

Palm OS Emulator opens a Transfer ROM dialog box that will guide you through the process.

Transferring a ROM File On a Unix System


This section describes how to transfer a ROM image from a handheld on a Unix-based desktop computer. Before proceeding, you must have the ROM `Transfer.prc` program installed on the handheld, as described in the previous section.

When running the program on a Unix system, Palm OS Emulator presents an empty window frame as shown in [Figure 1.4](#) on page 36.

Using Palm OS Emulator

Loading ROM Images

Figure 1.4 Running Palm OS Emulator for the First Time on a Unix System



Right-click (use mouse button two) on the window to display the Emulator popup menu. Click **Transfer ROM** to begin the transfer of a ROM image from a handheld.

Palm OS Emulator opens a Transfer ROM dialog box that will guide you through the process.

Using a ROM Image in Palm OS Emulator


Once you have transferred a ROM image to disk, you need to create a new session that is based on the image. To initiate the new session, you select **New** from the popup menu. [Table 1.3](#) shows the first step in creating a new session for each transfer method.

Table 1.3 Initiating a New Session After Transferring a ROM Image

Method Used to Initiate ROM Transfer	New Session Method
Clicked Download initial dialog box in Windows	Click New in the dialog box.
Selected Transfer ROM in Windows	Select either New or Close from the File menu.
Selected Transfer ROM on a Macintosh	Select New from the File menu.
Selected Transfer ROM on Unix	Select New from the File menu.

After you initiate the session, Palm OS Emulator presents the new session dialog box, which is described in “[Configuring a New Session](#)” on page 45. The Windows version of this dialog box is shown in [Figure 1.5](#).

Figure 1.5 New Session Dialog Box



After you select your parameters and click **OK**, Palm OS Emulator begins an emulation session.

Drag and Drop a ROM Image

You can use drag and drop to start a new Emulator session in either of two ways:

Using Palm OS Emulator

Running Palm OS Emulator

- Drag and drop a ROM image file onto the Emulator screen to start a new session.
- Drag and drop a ROM image file onto the Emulator executable or shortcut (alias) to start the Palm OS Emulator program.

You can also drag and drop other file types, as described in [“Dragging and Dropping Files”](#) on page 47.

Running Palm OS Emulator

Run Palm OS Emulator just like you would any other program. When Palm OS Emulator starts up, it displays an image of a handheld device, as shown in [Figure 1.1](#) on page 27.

Command Line Options

If you are running Palm OS Emulator on a Windows-based desktop computer or on a Unix system, you can supply the session parameters as command-line parameters. For example:

```
Emulator -psf C:\Data\Session1.psf
```

[Table 1.4](#) shows the options that you can specify on the Windows command line. You can also change most of these options by starting a new session with the **New** menu, as described in [“Configuring a New Session”](#) on page 45.

Note that the command line option specifications are not case sensitive.

Table 1.4 Palm OS Emulator Command Line Options

Option syntax	Parameter values	Description
-horde <num>	A Gremlin number	The number of the Gremlin to run after the session is created or loaded. Note that this is equivalent to supplying the same Gremlin number for the horde_first and horde_last options.
-horde_first <num>	A Gremlin number	The first Gremlin to run in a horde.
-horde_last <num>	A Gremlin number	The last Gremlin to run in a horde.
-horde_apps <app name list>	A comma-separated list of applications	The list of applications to which the Gremlin horde is allowed to switch. The default is no restrictions.
-horde_save_dir <path>	A path name	The name of the directory in which to save session and log files. The default log location is the directory in which the Palm OS Emulator application is stored.
-horde_save_freq <num>	An event count	The Gremlin snapshot frequency. The default value is to not save snapshots.

Using Palm OS Emulator

Running Palm OS Emulator

Table 1.4 Palm OS Emulator Command Line Options

Option syntax	Parameter values	Description
-horde_depth_max <num>	An event count	The maximum number of Gremlin events to generate for each Gremlin. The default value is no upper limit.
-horde_depth_switch <num>	An event count	The number of Gremlin events to generate before switching to another Gremlin in the horde. The default is to use the same value as specified for the horde_depth_max option.
-psf <fileName>	Any valid PSF file name	The emulator session file to load upon start-up. You can also load a session file with the Open menu.
-rom <fileName>	Any valid ROM file name	The name of the ROM file to use.
-ram <size> or -ramsize <size>	One of the following kilobyte size values: 128 256 512 1024 2048 4096 8192	The amount of RAM to emulate during the session.

Table 1.4 Palm OS Emulator Command Line Options

Option syntax	Parameter values	Description
-device <type>	One of the following device type values: Pilot, Pilot1000, Pilot5000, PalmPilot, PalmPilotPersonal, PalmPilotProfessional, PalmIII, PalmIIIC, PalmIIIE, PalmIIIX, PalmV, PalmVx, PalmVII, PalmVIIIEZ, PalmVIIx, m100, Symbol1700, TRGpro, Visor	The device type to emulate during the session. Note that Pilot1000 and Pilot5000 are synonyms for Pilot. Also note that PalmPilotPersonal and PalmPilotProfessional are synonyms for PalmPilot.
-load_apps <file name list>	A list of valid file names, separated by commas	A list of PRC files or other files to load into the session after starting up.
-log_save_dir <path>	A path name	The name of the directory in which to save the standard log file. The default log location is the directory in which the Palm OS Emulator application is stored.
-quit_on_exit	None	If the -run_app option was specified, this option indicates that Palm OS Emulator should quit after that application terminates.

Using Palm OS Emulator

Running Palm OS Emulator

Table 1.4 Palm OS Emulator Command Line Options

Option syntax	Parameter values	Description
<code>-run_app <app name></code>	Application name	The name of an application to run in the session after starting up. You must specify the name of the application, not the name of the application's file.
<code>-silkscreen <type></code> or <code>-skin <type></code>	The name of a skin. The skin names are defined by the device-specific <code>.skin</code> files. For most devices, these skin names are available: Generic Standard-English Standard-Japanese	The skin types to emulate during the session.


Starting Palm OS Emulator

The most common scenario for starting Palm OS Emulator is without any command line parameters. In this case, Emulator restarts with saved information from the previous session.

When Palm OS Emulator starts execution, it determines its configuration by sequencing through the following rules:

1. If the CAPS LOCK key is on, the Startup dialog box is always displayed. The Startup dialog box is shown in [Figure 1.6](#).

Figure 1.6 Palm OS Emulator Startup Dialog Box



NOTE: The dialog box shown in [Figure 1.6](#) is displayed when you are running Palm OS Emulator on a Windows-based computer.

If you are using a Macintosh computer, the new session dialog box shown in [Figure 1.3](#) on page 35 is displayed instead.

If you are using a Unix system, Palm OS Emulator does not provide an automatic startup sequence; instead, it presents you with a window shown in [Figure 1.4](#) on page 36, and you must right-click in that window to display the new session menu.

2. If you are using Windows or Unix with command line options specified:
 - If the CAPS LOCK key is not on, Palm OS Emulator scans the command line for options. If an error is encountered on the command line, Palm OS Emulator displays an error message and then presents the Startup dialog box.
 - If a session (PSF) file was specified on the command line, Palm OS Emulator attempts to load the file. If the file cannot be loaded, Palm OS Emulator displays an error message and then presents the Startup dialog box.
 - If any other options are specified on the command line, Palm OS Emulator attempts to start a new session with those values. If any of the four values is missing, Palm OS

Using Palm OS Emulator

Running Palm OS Emulator

Emulator displays the session configuration dialog box, as shown in [Figure 1.7](#).

If any of the command line options are not valid, or if the user cancels the dialog box, Palm OS Emulator displays an error message and then presents the Startup dialog box.

Figure 1.7 New Session Dialog Box



3. If no command line options are specified, Palm OS Emulator attempts to reopen the session file from the most recent session, if one was saved. If the file cannot be opened, Palm OS Emulator displays an error message, and then presents the Startup dialog box.
4. Palm OS Emulator attempts to create a new session based on the setting most recently specified by the user. If an error occurs, Palm OS Emulator displays an error message, and then presents the Startup dialog box.

NOTE: When it starts up, Palm OS Emulator looks for the most recently saved PSF file:

- On Windows and Unix, Emulator uses the full path name of that file.
- On Macintosh, Emulator uses aliases to locate the file.

If Emulator cannot find that file, it looks for the file name in the directory in which the Palm OS Emulator executable is located.

Using Emulation Sessions

Palm OS Emulator uses the concept of an emulation session, which is a testing or debugging session for a combination of the following items:

- the handheld device type to emulate
- the amount of RAM to emulate
- the ROM file to use for the emulation


You can start new emulation sessions during a single run of Palm OS Emulator. You can also save the current state of a session and restore it in a later session. This session describes these features of Palm OS Emulator.

Configuring a New Session

You can start a new session in Palm OS Emulator by choosing **New** from the Palm OS Emulator menu. If you are already running an emulation session, Palm OS Emulator will optionally ask if you want to save the session in a Palm OS Emulator session (PSF) file before starting the new session. You set this option in your preferences.

[Figure 1.8](#) shows the New Session dialog box, which Palm OS Emulator displays when you choose **New** from the menu.

Figure 1.8 Configuring a New Session



You need to make the following choices in this dialog box:

- Select the ROM file on your desktop computer that you want to use for the session. You can click on the arrow and select

Using Palm OS Emulator

Using Emulation Sessions

Other... to navigate to the file. For more information about ROM files, see "[Loading ROM Images](#)" on page 33.

- Select the Palm handheld device that you want to emulate in the session. Only those devices that apply to the selected ROM will be shown in the list. The list may include the following choices:

-Pilot	-Pilot 1000	-Pilot 5000
-PalmPilot	-PalmPilotPersonal	-PalmPilotProfessional
-Palm III	-Palm IIIc	-Palm IIIe
-Palm IIIx	-Palm V	-Palm Vx
-Palm VII	-Palm VIIEZ	-Palm VIIx
-m100	-Symbol1700	-TRGpro
-Visor		

- Select the skin that you want displayed on the emulation screen.

Note that the skin is simply a graphic; it does not change the ROM or the device being emulated. The skin simply changes the appearance of the Emulator window.

The skin choices available are dependent on the device selection. When you select a device, Emulator reads through the available SKIN files for the skin names that support the selected device.

Alternative skins, such as the Japanese skin, are only available for certain device types. The **Generic** choice is always available, even when alternatives are not available. For additional information, see the section "[Changing the Emulator's Appearance](#)" on page 48.

- Select the amount of memory that you want emulated. You can choose from the following RAM sizes:
 - 128K
 - 256K
 - 512K
 - 1024K

- 2048K
- 4096K
- 8192K

Note that 1 MB (1024K) is most often the right amount of RAM to emulate. Using 1 MB of RAM tells you if your application will work properly across the majority of hardware devices available.

After you click **OK**, Palm OS Emulator begins an emulation session.

The Difference Between the New Menu Item and the Open Menu Item

Both **New** and **Open** can be used to initiate an emulator session. However, the **Open** menu is used to open an existing session file (PSF file) that has been saved from a previous emulator session. The **Open** menu does not allow you to change the ROM file or device being emulated.

Dragging and Dropping Files

You can drag and drop the following file type categories onto the Palm OS Emulator LCD screen:

- PRC, PDB, and PQA files
- ROM files
- PSF files

When dragging and dropping files, observe the following rules:

- You can drag and drop only one ROM file at a time.
- You can drag and drop only one PSF file at a time.
- You can drag and drop any number of PRC, PDB, and PQA files.
- You cannot drag and drop files from more than one of the file type categories in the same operation.


Saving and Restoring Session State

You can save the current state of a Palm OS Emulator session to a session file for subsequent restoration. Palm OS Emulator saves a session to a session file. The Emulator uses Save and Save As in the standard manner, with one addition: you can automate what happens when closing a session by changing the Save options.

Saving the Screen

You can save the current screen to a bitmap file by selecting the **Save Screen**, which saves the contents of the emulated Palm handheld device screen.

Figure 1.9 A Palm OS Emulator Screen Shot




Palm OS Emulator saves screen images on Windows-based systems as BMP bitmap images, saves screen images on MacOS-based systems as SimpleText image files, and saves screen images on Unix-based systems as PPM files.

Changing the Emulator's Appearance

You can change the appearance of Palm OS Emulator by choosing **Skins** from the **Settings** submenu. This displays the Skins dialog box, which is shown in [Figure 1.10](#).

Figure 1.10 Changing Palm OS Emulator Appearance



The Skins dialog box lists the skins that are available for the device that is being emulated. This means that you cannot use a Palm V™ skin for a Palm III™ device, for example.

Emulator comes with a built-in **Generic** skin. You can download additional skins from:

<http://www.palmos.com/dev/tech/tools/emulator/>

When you download the package of additional skins, you place the skins in a skins directory. When you select a device during session configuration, Emulator reads through the skins directory and finds all of the skins that can be used with the selected device. The supported skins are displayed in the Skins dialog box.

Note that the skin is simply a graphic. Selecting a skin changes the appearance of the Emulator window, but it does not change the ROM or the device being emulated.

Other Options on the Skins Dialog Box

In addition to selecting a skin, use the Skins dialog box to change these appearance options:

- Select or deselect **Double scale** to display the emulated device in double size or actual size on your monitor.

Using Palm OS Emulator

Modifying the Runtime Environment

- Select or deselect **White Background** to display the emulated device LCD background color in white or green on your monitor.


Modifying the Runtime Environment

This section describes how you can modify the Palm OS Emulator runtime environment, including changing the properties and installing applications in the emulator session.

Palm OS Emulator Properties

Use the Properties dialog box to modify characteristics of your Palm OS Emulator sessions. To display this dialog box, choose **Properties** on Windows or **Preferences** on Macintosh or Unix. The Properties dialog box is shown in [Figure 1.11](#).

Figure 1.11 Changing Palm OS Emulator Properties



[Table 1.5](#) describes the options available in the properties dialog box.

Table 1.5 Palm OS Emulator properties

Option	Description
Serial Port	Specifies which serial port Palm OS Emulator uses to emulate serial communications on the handheld device.
Redirect Netlib calls	Redirects Netlib calls in emulated software to TCP/IP calls on the desktop computer.
Enable sounds	Specifies whether Palm OS Emulator should enable emulation of device sounds.
Session saving	Selects what action Palm OS Emulator takes when you close a session or quit the program.
User name	Selects the user account name for synchronizing from Palm OS Emulator with the desktop computer HotSync application.

Preferences Files

Your properties are stored in a preferences file on your computer. Each property is stored as a text string that you can view with a text editor. The location of your preferences file depends on the type of computer that you are using, as shown in [Table 1.6](#).

Table 1.6 Palm OS Emulator Preference File Locations

Platform	File name	File location
Macintosh	Palm OS Emulator Prefs	In the Preferences folder.
Windows	Palm OS Emulator.ini	In the Windows System directory.
Unix	.poserrc	In your home directory.

Installing Applications

Use **Install** to load applications or databases directly into the current Palm OS Emulator session.

Using Palm OS Emulator

Modifying the Runtime Environment

- For Windows and Unix, right-click on the Palm OS Emulator screen display and choose **Install Application/Database**
- On a Macintosh system, select **Install Application/Database** from the File menu

Install displays an open file dialog box in which you can choose the application (PRC), database (PDB), or Palm Query Application (PQA) file that you want installed.

Palm OS Emulator immediately loads the file into emulated RAM. If Palm OS Emulator finds another application or database with the same creator ID, that application or database is deleted before the new version is loaded.

IMPORTANT: If you install an application while the Palm OS Launcher is running, the Launcher does not update its data structures, and thus does not reflect the fact that a database has been added or modified. Use **Install** while an application is running in the emulated session.

Serial Communications and Palm OS Emulator

Palm OS Emulator supports emulation of the Palm device serial port connection. It does so by mapping Palm OS serial port operations to a communications port on the desktop computer. To select which port the Emulator uses, use **Properties** (on Macintosh and Unix computers, this is **Preferences**), as described in “[Palm OS Emulator Properties](#)” on page 50.

When emulated software accesses the processor serial port hardware registers, Palm OS Emulator performs the appropriate actions on the specified serial port on the desktop computer. This means that serial read and write operations work as follows:

- when outgoing data is written to the UART's tx register, the Emulator redirects that data to the desktop computer's serial port.
- when the emulated software attempts to read data from the UART's rx register, the Emulator reads data from the desktop computer's serial port and places the data into that register.

Using the HotSync Application With Palm OS Emulator

You can perform a HotSync operation from your emulated session in one of two ways:

- If you are using a Windows-based computer, you can use the Network HotSync option, which greatly simplifies your communications efforts. This method is described in the [“Emulating Network Hotsync with Palm OS Emulator on Windows”](#) section below.
- Alternatively, you can use a null-modem cable to connect two serial ports together and perform a HotSync operation. This method is described in [“Emulating HotSync with a Null Modem Cable”](#) section below.

Emulating Network Hotsync with Palm OS Emulator on Windows

You do not need to be connected to a network to emulate Network HotSync with Palm OS Emulator. This method can be used with Emulator and a single Windows computer. However, other configurations are possible.

In general, you need these two:

- a Windows computer running HotSync Manager
- a computer running Emulator that can access the computer running HotSync Manager.

The computer running Emulator can be the same Windows computer that is running HotSync Manager, or it can be a second computer (either Windows, Macintosh, or Unix). If you are using a single Windows computer, you don't need to be connected to a network. However, if you are using a second computer, you will need the actual IP address of the Windows computer running HotSync Manager for step 4 below.

Here is the complete process for emulating Network HotSync:

1. Ensure that you have the Network HotSync application on your emulated device:
 - If you are emulating a Palm III or m100 device, you must first download and install the Network HotSync

Using Palm OS Emulator

Modifying the Runtime Environment

application on the emulated device. You can get the Network HotSync files from:

<http://www.palm.com/support/downloads/netsync.html>

- If you are emulating a device running Palm OS version 3.1 or later, then you may already have the Network HotSync application installed on the emulated device.
2. Configure HotSync on your Windows computer:
 - Right-click (use mouse button two) on the HotSync icon in the system tray.
 - In the pop-up menu, select **Network** to enable Network HotSync. (A checkmark will appear next to the **Network** menu item if it is already enabled.)
 3. Configure Palm OS Emulator to Redirect NetLib Calls to TCP/IP:
 - Right-click (use mouse button two) on Emulator.
 - In the pop-up menu, select **Settings>Properties...**
 - In the Properties dialog box, click the **Redirect NetLib Calls to TCP/IP** checkbox. Click **OK** to save the changed properties.
 4. Configure HotSync on the emulated device:
 - From the device's application launcher, tap the HotSync application to open it.
 - Tap **Menu** to display the HotSync application's menu.
 - Select **Options>Modem Sync Prefs...**
 - In the Modem Sync Preferences dialog box, tap the **Network** button. Tap the **OK** button to save the changed preferences.
 - Tap **Menu** to display the HotSync application's menu again.
 - Select **Options>LANSync Prefs...**
 - In the LANSync Preferences dialog box, tap the **LANSync** button. Tap the **OK** button to save the changed preferences.

- Tap **Menu** to display the HotSync application's menu again.
- Select **Options>Primary PC Setup...**
- In the Primary PC Setup dialog box, enter the **Primary PC Address** (the middle entry field):
 - If you are running Emulator and HotSync manager on the same Windows computer, enter 127.0.0.1
 - If you are running Emulator on a second computer, then enter the actual IP address of the Windows computer running Network HotSync.
- Tap the **OK** button to save the changed preferences.
- In the HotSync application, tap **Modem**. Next, tap the **Select Service** button under the Modem Sync icon.
- In the Preferences dialog box, tap the **Tap to enter phone** field. In the Phone Setup dialog box, enter 00 in the **Phone #** entry field. Then tap the **OK** button. Then tap the **Done** button.
- To start the HotSync, tap the HotSync icon in the center of the HotSync dialog box.

Emulating HotSync with a Null Modem Cable

You can emulate HotSync by connecting the serial port that the HotSync application uses to communicate with the handheld device to another serial port that Palm OS Emulator uses. You connect these ports together with a null modem cable, such as a LapLink cable.

For example, if your HotSync application uses the COM1 port, follow these steps:

1. Select **Properties (Preferences)** on a Macintosh or Unix) and specify the COM2 port for Palm OS Emulator.
2. Connect COM1 and COM2 together with a null modem cable.
3. Select **HotSync** from the Palm OS Emulator menu.

The HotSync application synchronizes with Palm OS Emulator just as it does with an actual hardware handheld device.

Using Palm OS Emulator

Modifying the Runtime Environment

TIP: The desktop HotSync application is CPU-intensive, which is not generally an issue; however, when you are using the HotSync application with Palm OS Emulator, the two programs are sharing the same CPU, which can dramatically slow the synchronization down.

A handy trick to deal with this problem is to click on the Palm OS Emulator window after the HotSync process starts. This brings the Emulator back into the foreground and allows it to use more CPU time, which improves the speed of the overall process.

If your desktop computer has two ports and you use a serial mouse on one of them, you can temporarily disable the mouse, perform a synchronization, and re-enable the mouse. Follow these steps:

1. Disable your mouse.
2. Restart Windows.
3. Connect the serial ports together with a null modem cable.
4. Start Palm OS Emulator.
5. Press F10 to display the menu, then H to begin the HotSync operation.
6. After the HotSync operation completes, re-enable your mouse.
7. Restart Windows again.

TIP: When you first perform a HotSync operation with Palm OS Emulator, the HotSync application asks you to select a user name. It is a good idea to create a new user account, with a different name, for use with the Emulator.

Emulating Expansion Cards


Palm OS 4.0 includes the Expansion Manager, which manages plug-in memory cards, and the Virtual File System manager, which supports the management of files on memory cards.

Palm OS Emulator can emulate these cards, which the Expansion Manager will recognize and mount in the same way it would mount an actual hardware expansion card. The Virtual File System Manager will then read from and write to the host operating system using the mount information associated with the emulated card. The host operating manipulation is performed using the many file-related host control functions available. (See “[Host Control API Reference](#)” on page 95 for more information on the host control API.)

Palm provides an implementation of a file system, called HostFS, that works in conjunction with Emulator's Host Control API to mount a local directory on the desktop as a volume or card. You can download the HostFS application from the Palm Resource Pavilion. Note that the `HostFS.prc` application needs to be installed on a VZColor ROM. (See “[Using ROM Images](#)” on page 29 for more information on using ROM images with Emulator.)

Once you have installed `HostFS.prc` in an Emulator session running a VZColor ROM, you are ready to emulate memory cards. To specify mount information for card emulation, use the Card Options dialog box shown in [Figure 1.12](#) on page 57.

Figure 1.12 Palm OS Emulator Card Options Dialog Box



The Card Options dialog box supports the mounting of up to four emulated cards. For each card, you can specify a directory in the host file system that will serve as the root for the card as managed by the Virtual File System Manager. You can also specify whether a particular card is actually mounted.

You can change the card options settings while an emulation session is running. Changes regarding whether a card is mounted or not take place immediately; the Palm OS is notified that the card has been added or removed. Changes regarding the root path take effect only when the card is mounted.

Testing Your Application

This section describes how to use Palm OS Emulator to test and/or debug an application.

Testing Software


Testing software is probably the most common use of Palm OS Emulator. This section provides a quick summary of the steps to load and test an application.

Debug Options

Palm OS Emulator monitors the actions of your application while it is emulating the operation of the handheld device. When your application performs an action that does not strictly conform to Palm OS's programming guidelines, the Emulator displays a dialog box that explains what is happening.

The debugging options dialog box, which is shown in [Figure 1.13](#), lets you enable or disable the monitoring activities applied to your application. Use **Debug Options** to display this dialog box.

Figure 1.13 Palm OS Emulator Debug Options Dialog Box



[Table 1.7](#) describes each of the debugging options.

Table 1.7 Emulator Debugging Options

Option	Description
Low-Memory Access	Monitors low-memory access by applications. Low-memory access means an attempt to read from or write to a memory location in the range 0x0000 to 0x00FF.
System Globals Access	Monitors access to system global variables by applications. System global variable access is defined as reading from or writing to a memory location in the range from 0x0100 to the end of the trap dispatch table.
Screen Access	Monitors LCD screen buffer access by applications. LCD screen buffer access is defined as reading from or writing to the memory range indicated by the LCD-related hardware registers.
Hardware Register Access	Monitors accesses to hardware registers by applications. Hardware register access is defined as reading from or writing to memory in the range from 0xFFFFF000 to 0xFFFFFFFF.
MemMgr Data Structure	Monitors access to Memory Manager data structures, which is restricted to only the Memory Manager. Memory Manager data structures are the heap headers, master pointer tables, memory chunk headers, and memory chunk trailers.
Storage Heap Access	Monitors naked access to the storage heap by applications. To access the storage heap, your application should use the <code>DmWrite</code> functions.

Table 1.7 Emulator Debugging Options (*continued*)

Option	Description
MemMgr Semaphore	<p>Monitors how long the Memory Manager semaphore has been acquired for write access using the <code>MemSemaphoreReserve</code> and <code>MemSemaphoreRelease</code> functions.</p> <p>Your applications should not be calling these functions; however, if you must call them, you should not hold the semaphore for longer than 10 milliseconds.</p>
Low Stack Access	Monitors access to the range of memory below the stack pointer.
Free Chunk Access	<p>Monitors access to free memory chunks.</p> <p>No process should ever access the contents of a chunk that has been deallocated by the <code>MemChunkFree</code>, <code>MemPtrFree</code>, or <code>MemHandleFree</code> functions.</p>
Unlocked Chunk Access	Monitors access to unlocked, relocatable memory chunks, which is restricted to the Memory Manager.
Uninitialized Stack Access	Monitors read accesses to uninitialized portions of the stack. You can use this option to detect read accesses to uninitialized local variables.

Table 1.7 Emulator Debugging Options (*continued*)


Option	Description
Uninitialized Chunk Access	<p>Monitors read access to uninitialized portions of memory chunks that have been allocated by the <code>MemChunkNew</code>, <code>MemPtrNew</code>, and <code>MemHandleNew</code> functions.</p> <p>You can use this option to detect read accesses to uninitialized portions of dynamically allocated memory chunks. Note that your application's global variables are stored in memory chunks allocated by these functions, so enabling this option also detects read accesses to uninitialized global variables.</p>
Stack Almost Overflow	<p>Ensures that the stack pointer has not dipped below the space allocated for it by the kernel.</p> <p>When this option is enabled, Palm OS Emulator warns you when the application stack is getting close to full.</p> <p>Note that you are always warned of a stack overflow, even if this option is disabled.</p>

Logging Options

Palm OS Emulator also logs various actions taken by your application to help you debug and performance tune your code. The logged information is automatically written to a text file that is saved in the same directory as the Emulator executable.

You can control the logging activity with the logging options dialog box, which is shown in [Figure 1.14](#). Use **Logging Options** to display this dialog box.

Figure 1.14 Palm OS Emulator Logging Options Dialog Box



The logging options dialog box features radio buttons to indicate logging during normal operations (**Normal**), and logging while a Gremlin is running (**Gremlins**). Both offer the same options, which are described in [Table 1.8](#)

Table 1.8 Emulator Logging Options

Option	Description
Error Messages	Not yet implemented.
Warning Messages	Logs any message that is displayed in a dialog box that can be dismissed by tapping the Continue button.
Misc Gremlin Info	Logs information about Gremlins that is mostly useful for debugging the Gremlins themselves.
Assembly Opcodes	Logs assembly-level trace information, including registers, the program counter, opcodes, and related information. This option is not yet implemented.

Table 1.8 Emulator Logging Options (*continued*)

Option	Description
Posted Events	Logs events that have entered into the system by way of calls to the <code>EvtAddEventToQueue</code> , <code>EvtAddUniqueEventToQueue</code> , <code>EvtEnqueuePenPoint</code> , and <code>EvtEnqueueKey</code> functions.
Received Events	Logs events returned by calls to the <code>EvtGetEvent</code> , <code>EvtGetPen</code> , and <code>EvtGetSysEvent</code> functions.
System Calls	Logs calls to Palm OS functions.
Application Calls	Logs calls to functions in your application.
	This option is not yet implemented.
Serial Activity	Logs changes in serial port settings, and the opening and closing of the serial port.

Table 1.8 Emulator Logging Options (*continued*)

Option	Description
Serial Data	<p>Logs data sent and received over the serial port. Data is logged as it is being transferred over the host serial port</p> <p>Incoming data follows this path:</p> <ol style="list-style-type: none">1. Serial port2. Emulated hardware registers3. Palm OS4. Palm application <p>Palm OS Emulator logs the serial port data.</p> <p>Outgoing data follows this path:</p> <ol style="list-style-type: none">1. Palm application2. Palm OS3. Emulated hardware registers4. Serial port <p>Again, Palm OS Emulator logs the serial port data.</p>
NetLib Activity	Logs calls to <code>NetLib</code> functions, including parameter and return values.
NetLib Data	Logs data sent and received via <code>NetLib</code> calls.
ExgMgr Activity	Logs calls to <code>ExgMgr</code> functions.
ExgMgr Data	Logs data sent and received via <code>ExgMgr</code> calls.
RPC Activity	Logs remote procedure calls.
RPC Data	Logs data sent and received via remote procedure calls.

Table 1.8 Emulator Logging Options (*continued*)

Option	Description
High-level Debugger Activity	Logs messages received back from an external debugger, and the messages sent back to the debugger.
High-level Debugger Data	Logs details of the messages sent to and received from an external debugger.
Low-level Debugger Activity	Traces the low-level mechanisms that receive raw data from external debuggers and send data back to external debuggers.
Low-level Debugger Data	Logs the raw data being sent to and received from an external debugger.

Using Gremlins to Automate Testing

You can use Gremlins to automate testing of an application. A **Gremlin** generates a series of user input events that test your application's capabilities. You can have a Gremlin to run a specified number of times, or to loop forever, which lets you set up a Gremlin and allow it to run overnight to thoroughly test your application.

A **Gremlin horde** is a range of Gremlins that you want Palm OS Emulator to run. The Emulator generates a stream of events for each Gremlin and then moves onto the next Gremlin. The Emulator cycles through the Gremlins until the maximum number of events have been generated for the horde.

Palm OS Emulator generates a stream of events for each Gremlin in the horde until one of the following conditions occurs:

- An error such as a hardware exception or illegal memory access is generated.
- The maximum number of events for a single Gremlin have been generated.
- The maximum number of events for the horde have been generated.
- You stop the horde by choosing **Stop** or **Step** from the Emulator menu or from the Gremlin Status dialog box.

Using Palm OS Emulator

Testing Your Application

If a Gremlin generates an error, it is halted and Palm OS Emulator does not include it when cycling through the horde again.

Gremlin Characteristics

Each Gremlin has the following characteristics:

- it generates a unique, random sequence of stylus and key input events to step through the user interface possibilities of an application
- it has a unique “seed” value between 0 and 999
- it generates the same sequence of random events whenever it is run
- it runs with a specific application or applications
- it displays a report immediately when an error occurs

Gremlin Horde Characteristics

Each Gremlin horde has the following characteristics:

- The number of the first Gremlin to run. This must be a value between 0 and 999.
- The number of the last Gremlin to run. This must be a value between 0 and 999.
- The switching depth of the Gremlin horde. This is the number of events to run for each Gremlin. After this many events have been generated for the Gremlin, it is suspended, and the next Gremlin in the horde starts running.
- The maximum number of events for each gremlin in the horde. The Emulator stops running the Gremlin after it posts this many events, or after it terminates with an error.
- With which applications the Gremlins are to run. You can select a single application, a group of applications, or all applications.
- Errors that occur are logged to the log file and the emulation continues with the next Gremlin in the horde.

When Palm OS Emulator runs a Gremlin horde, it actually maintains a separate stream for each Gremlin in the horde. When it starts a horde, the Emulator first saves the complete state of the emulation to a session (PSF) file. Then, the Emulator:


- Starts the first Gremlin. When the Gremlin has posted a number of events equal to the specified switching depth, the Emulator saves its state to a new file and suspends the Gremlin.
- Reloads the original session state.
- Starts the second Gremlin and run it until it posts that number of events, at which time its state is saved to another file, and the Gremlin is suspended.
- Runs each Gremlin in the horde, until each has been suspended or terminated:
 - A Gremlin is terminated when an error occurs while the Gremlin is posting events.
 - A Gremlin is suspended when it has posted a number of events equal to the switching depth for the horde.
- Returns to the first suspended Gremlin in the horde, reloads its state from the saved file, and resumes its execution as if nothing else had happened in the meantime.
- Continues cycling through the Gremlins in the horde until each Gremlin has finished. A Gremlin finishes when either of these conditions occurs:
 - the Gremlin has terminated due to an error
 - the Gremlin has posted a total number of events equal to the maximum specified for the horde.

Running a Gremlin Horde

Select **New Gremlin** to start a Gremlin. The new Gremlin dialog box displays, as shown in [Figure 1.15](#). Use this dialog box to specify the characteristics of the Gremlin horde that you want to run.

TIP: If you wish to run a single Gremlin, simply set the Gremlin Start Number and Gremlin End Number fields to the same value.

Figure 1.15 The Gremlin Horde Dialog Box



When Palm OS Emulator runs the example shown in [Figure 1.15](#), the horde will operate as follows:

- The Emulator will only run the Address application when generating key and stylus events for this horde.
- The Emulator will use a seed value of 2 for the first Gremlin in the horde and a seed value of 14 for the last Gremlin in the horde. It also runs all intervening Gremlins: numbers 3 through 13.
- The Emulator will generate 25 events for each Gremlin before switching to the next Gremlin in the horde.
- The Emulator will cycle through the Gremlins in the horde until a total of 1000 events have been generated for each Gremlin. Thus, a total of 13,000 events will be generated.

This means that the Emulator will generate the following sequence of Gremlin events:

1. Gremlin #2 runs and receives twenty-five events, after which Gremlin 2 is suspended.
2. Gremlin #3 runs and receives twenty-five events, after which Gremlin #3 is suspended.


3. Similarly, each Gremlin (#4 through #14) runs and receives twenty-five events, after which it is suspended.
4. The Emulator loops back to Gremlin #2 and runs it, sending it twenty-five events before again suspending it.
5. Gremlin #3 runs again, receives twenty-five events, and suspends.
6. This looping through the Gremlins and sending each events until the switch depth (25) is reached continues until the maximum number of horde events (1000) have been generated.
7. All activity for the Gremlin horde completes.

NOTE: If an error occurs while a specific Gremlin is running, Palm OS Emulator halts that Gremlin rather than suspending it. This means that the Gremlin is not run when the Emulator next iterates through the horde.

Stepping and Stopping Gremlins

After the horde starts running, Palm OS Emulator displays the Gremlin control dialog box, which is shown in [Figure 1.16](#). You can use the commands in this dialog box to stop, resume, and single-step a Gremlin. You can also use the **Gremlins** menu to perform these actions.

Figure 1.16 The Gremlin Status Dialog Box



Gremlin Snapshots

When you start a new Gremlin horde, you can specify that you want Palm OS Emulator to take a snapshot on a regular basis. You specify a frequency value, as shown in [Figure 1.15](#) on page 68, and the Emulator saves a session file each time that many Gremlins have

Using Palm OS Emulator


Testing Your Application

run. Each snapshot is a PSF file that captures the current state of the emulation. You can open the snapshot in the Emulator as a new session and begin debugging from that state.

Logging While Gremlins Are Running

Palm OS Emulator lets you specify separate logging options to use while Gremlins are running. [Figure 1.17](#) shows the Gremlin logging options dialog box. Each of the options is described in “[Logging Options](#)” on page 61.

Figure 1.17 Gremlin logging options



Setting Breakpoints

You can set breakpoints in your code with the Emulator. When Palm OS Emulator encounters a breakpoint that you have set, it halts and takes one of the following actions:


- If you are running the Emulator connected to a debugger, the Emulator sends a message to the debugger, informing it that the breakpoint was hit. The debugger then handles that command as it sees fit.

- If the Emulator is not connected to a debugger, the Emulator displays an error message. This message will typically say something like “TRAP \$0 encountered.”

To set a breakpoint, select **Breakpoints** from the **Settings** menu. The Breakpoints dialog box is displayed, as shown in [Figure 1.18](#).

NOTE: You cannot use the Breakpoints feature on the Macintosh or Unix versions of Palm OS Emulator.

Figure 1.18 Setting a Breakpoint



Setting the Data Breakpoint

You can set exactly one data breakpoint. While your program is executing, the Emulator watches the specified address range; if it is written to, the Emulator generates a break. You can specify both the address and number of bytes in either hexadecimal (0x) or decimal.

Setting Conditional Breakpoints

You can set up to six independent conditional breakpoints. The Emulator generates a break for a conditional breakpoint when both of the following are true:

- the program counter reaches the specifies address
- the specified condition is true

To set one of these breakpoints, select the breakpoint number in the list at the top of the dialog box, and click **Edit**. This displays the Code Breakpoint dialog box, which is shown in [Figure 1.19](#).

Figure 1.19 Setting a code breakpoint



To set the breakpoint, specify an address and the break condition. You can specify the address in hexadecimal (0x) or decimal.

The condition that you specify must have the following format:

`<register> <condition> <constant>`

register One of the registers: A0, A1, A2, A3, A4, A5, A6, A7, D0, D1, D2, D3, D4, D5, D6, or D7.

condition One of the following operators: ==, !=, <, >, <=, or >=.

constant A decimal or hexadecimal constant value.

IMPORTANT: All comparisons are unsigned.

Source Level Debugging

Palm OS Emulator provides an interface that external debugger applications can use to debug an application. For example,

Metrowerks has developed a plug-in module that you can use to debug an application that Palm OS Emulator is running, in exactly the same manner as you would debug an application running on the handheld. This plug-in module is shipped with the latest version of CodeWarrior for Palm OS.

Connecting Emulator with Palm Debugger

You can use Palm Debugger with Palm OS Emulator to perform extensive debugging of your applications. To use Palm Debugger with the Emulator, follow these steps:

1. Start Palm Debugger and Palm OS Emulator programs.
2. In the Palm Debugger Communications menu, select **Emulator**. This establishes the emulator program as the “device” with which Palm Debugger is communicating.
3. In the debugging window, type the `att` command.

You can now send commands from Palm Debugger to Palm OS Emulator.

Connecting Emulator with the GDB Debugger

You can use the `gdb` debugger with Palm OS Emulator to debug your applications. To use the `gdb` debugger with an emulator session, follow these steps:

1. When you build your application, both compile and link with the `-g` option (that is, using “`gcc -g . . .`”). When you compile using the `-g` option, the compiler generates the necessary symbol information. When you link using the `-g` option, the linker forces the inclusion of a debug runtime routine that installs a breakpoint in `PilotMain`.
2. Start Palm OS Emulator, and install your application in the emulator session.
3. Start the `gdb` debugger, loading your application’s symbol table (for example, using “`gdb myApp`”). Note that the file to be loaded is the `myApp` file created by the `gcc` linker, not the `myApp.prc` created by `buildprc`.

Using Palm OS Emulator

Testing Your Application

4. In the gdb debugger, enter “`target pilot localhost:2000`”. The gdb debugger will respond with a message indicating that remote debugging is starting.
5. Start your application on Palm OS Emulator.
6. Wait for the gdb debugger to see the initial breakpoint and prompt you, then start debugging.

Connecting the Emulator With External Debuggers

Palm OS Emulator can communicate with external debuggers using the methods shown in [Table 1.9](#).

Table 1.9 Palm OS Emulator Connections

Connection type	Platforms
TCP	All
PPC Toolbox	Macintosh
Memory-mapped files	Windows

NOTE: Currently, Palm Debugger uses TCP only when running on Windows. The CodeWarrior plug-in uses TCP if you select `Use sockets` in the debugger preference panel.

However, although you can configure the TCP port that Palm OS Emulator uses, you cannot configure which TCP port that either Palm Debugger or the CodeWarrior plug-in uses.

If you are communicating with a debugger using TCP, you can configure which socket port the debugger connects to by editing the value of the `DebuggerSocketPort` preference setting in your preferences file. You can disable the TCP connection by setting the value of the `DebuggerSocketPort` preference to 0.

NOTE: In some versions of Palm OS Emulator, you may notice that an unwanted PPP dial-up starts whenever you begin a new emulation session. You can disable this behavior by disabling the use of TCP for communications, which you do by setting the `DebuggerSocketPort` preference to 0.

Profiling Your Code

One of the features of Palm OS Emulator that is most useful for developers is the ability to profile your application while it is running, and to save the resulting data to a file that you can examine.

When the Emulator profiles your application, it monitors and generates statistics about where your code is spending its time, which enables you to focus your optimization efforts in the most productive manner.

NOTE: In order to use the profiling features, you must be using a version of Palm OS Emulator with profiling enabled.

On Windows and Macintosh, this means that you must be using the executable with “profile” in its name. See [Table 1.1](#) on page 30 for more information.

On Unix, this means that you must build the executable with the configure switch “--enable-profile”. (See the `_Building.txt` file mentioned in [Table 1.1](#).)

You can start a profiling session by choosing **Profiling Start**. While profiling is active, Palm OS Emulator monitors which application and system functions are executed, and the amount of time executing each. The Emulator collects the timing information until you select **Profiling Stop**.

You can then save the profiling information to a file by selecting **Profiling Dump**. The information is saved to file in two different

Using Palm OS Emulator

Error Handling Concepts

formats. Both of these files are stored in the directory in which the Emulator executable is located:

File name	Description
Profile Results.txt	A text version of the profiling results.
Profile Results.mwp	A Metrowerks Profiler version of the results, which can be used with the MW Profiler application bundled with CodeWarrior Pro.

IMPORTANT: The MW Profiler is only available on Macintosh computers.

You do not have to prepare your code in any special way for Palm OS Emulator to profile it, because the Emulator can determine when functions are entered and exited on its own. And the Emulator performs its profiling calculations between cycles, thus the timing information is quite accurate.

NOTE: It is a good idea to set your compiler's switch to embed debug symbols in your code so that you can easily interpret the profiling results.

Error Handling Concepts

This section describes the error handling and reporting features of the Palm OS Emulator program, including the following information:


- which conditions are detected
- what the Emulator does upon detecting an error condition
- the message displayed for each error condition
- the options available to the user when an error condition occurs

Detecting an Error Condition

When Palm OS Emulator detects an error condition, it generates error message text and displays the error dialog box. If you click **Debug** in the error dialog box, the Emulator attempts to send the text to an external debugger such as Palm Debugger or MWDebug; if successful, the Emulator then stops emulating opcodes until the external debugger sends a command specifying that it can resume emulation.

If the Emulator cannot send the text to a debugger, it presents the error text to the user in a dialog box like the one shown in [Figure 1.20](#).

Figure 1.20 Palm OS Emulator Error Dialog Box



You can click one of the three buttons in the dialog box:

Button	Description
Continue	Continues emulation, if possible.
Debug	Enters the external debugger, if one is running.
Reset	Performs a soft reset on the emulated device ROM.

Error Condition Types

Palm OS Emulator detects condition types:

- A *processor exception* involves the CPU pushing the current program counter and processor state onto the stack, and then branching through a low-memory vector.

Using Palm OS Emulator

Error Handling Concepts

- A *memory access exception* involves access to a memory location that the application is not supposed to access.
- An *application error message* is a message displayed when software running on the handheld device calls a system function such as `ErrDisplayFileLineMsg` or `SysFatalAlert`.

Palm OS Emulator uses four levels of accessibility when checking memory accesses:

- Applications have the least access to memory. An application is any software running in RAM on the handheld device.
- The system has more access to memory than do applications. The system is any software running in ROM on the handheld device.
- The memory manager has the most access to memory. The memory manager is any function operating within the context of a memory manager call, which means any function that runs while a memory manager function is still active.
- Some sections of memory cannot be accessed by any software.

Error Messages

[Table 1.10](#) shows Palm OS Emulator error messages. Note that you can prevent some of these messages by disabling the relevant debugging option, as described in “[Debug Options](#)” on page 58.

Table 1.10 Palm OS Emulator error messages

Error type	Description	Message example
Hardware register access	The application or system software has accessed a processor hardware register.	"Mytest" 1.0 has just read directly from the hardware registers.
Low-memory access	The application or system software has accessed low memory (the first 256 bytes), which contains the exception vectors.	"Mytest" 1.0 has just read directly from low memory. or "Mytest" 1.0 has just read directly from NULL (memory location zero)
System variable access	The application or system software has accessed a system variable, which resides in a memory location between low memory and the the end of the system function dispatch table.	"Mytest" 1.0 has just read directly from Palm OS global variables.
LCD screen buffer access	The application or system software has accessed the screen buffer, which is defined by the LCD-related hardware registers.	"Mytest" 1.0 has just read directly from screen memory.
Memory Manager data structure access	The application or system software has accessed a memory manager data structure, which includes heap headers, master pointer tables, chunk headers, and chunk trailers.	"Mytest" 1.0 has just read directly from memory manager data structures.
Unlocked chunk access	The application or system software has accessed an unlocked memory chunk.	"Mytest" 1.0 has just read directly from an unlocked memory chunk.

Using Palm OS Emulator

Error Handling Concepts

Table 1.10 Palm OS Emulator error messages (*continued*)

Error type	Description	Message example
Low-stack access	<p>The application or system software has accessed an area of the stack below the stack pointer.</p> <p>The stack is defined by values returned by the SysGetAppInfo function when it is called during system startup.</p> <p>If Palm OS Emulator cannot determine the stack range, it does not monitor low-stack accesses.</p>	<p>"Mytest" 1.0 has just read directly from an invalid section of memory known as the "stack" .</p>
Uninitialized stack access	<p>The application or system software has accessed uninitialized memory, which is memory that has not previously been written.</p>	<p>"Mytest" 1.0 has just read directly from an uninitialized section of memory known as the "stack" .</p>
Free chunk access	<p>The application or system software has accessed an unallocated memory chunk.</p>	<p>"Mytest" 1.0 has just read directly from an unallocated chunk of memory.</p>
Uninitialized chunk access	<p>The application or system software has attempted read access to uninitialized memory.</p>	<p>"Mytest" 1.0 has just read directly from an uninitialized chunk of memory.</p>
Storage heap access	<p>The application has accessed the storage heap.</p>	<p>"Mytest" 1.0 has just tried to write to the storage heap and that's just plain not allowed! Try using DmWrite.</p>

Table 1.10 Palm OS Emulator error messages (*continued*)

Error type	Description	Message example
Stack overflow	The application pushed more information onto the stack than is allocated for the stack.	"Mytest" 1.0 has just overflowed its stack.
Stack almost overflowed	The stack is close to overflowing, which means that the stack pointer is within a small number of bytes (typically 100) of the end of the stack.	"Mytest" 1.0 is getting close to overflowing the stack.
Memory Manager semaphore acquisition time	The application or system software has acquired the Memory Manager semaphore for write access, and has held it for more than 10 milliseconds.	"Mytest" 1.0 has held the "Memory Manager semaphore" for approximately 20 milliseconds. It is recommended that applications not hold the semaphore longer than 10 milliseconds.

Using Palm OS Emulator

Error Handling Concepts

Table 1.10 Palm OS Emulator error messages (*continued*)

Error type	Description	Message example
Invalid heap	Heap corruption detected during a regular heap check. Palm OS Emulator regularly checks the heap.	<p>During a regular checkup, the Emulator determined that the dynamic heap got corrupted.</p> <p>(corruption type) is one of the following message fragments:</p> <ul style="list-style-type: none">• The chunk was not within the heap it was supposed to be• The size of the chunk (chunk_size) was larger than the currently accepted maximum (chunk_max)• Some unused flags were set to "1" <p>The "hOffset" field of the chunk header did not reference a memory location within a master pointer block</p> <ul style="list-style-type: none">• The master pointer referenced by the "hOffset" field in the chunk
Invalid program counter	The program counter has been set to an invalid memory location, which is a location outside of a 'CODE' resource.	"Mytest" 1.0 has just set the Program Counter (PC) to an invalid memory location.

Table 1.10 Palm OS Emulator error messages (*continued*)

Error type	Description	Message example
Unimplemented trap.	<p>The application or system software has attempted to invoke an unimplemented system function.</p> <p>An unimplemented system function is one with a trap number outside of the numbers in the system function dispatch table, or one whose table entry matches that of the SysUnimplemented function.</p>	<p>"Mytest" 1.0 tried to call Palm OS routine trapNum (trapName). This routine does not exist in this version of the Palm OS.</p>
SysFatalAlert	<p>The application or system software has called the SysFatalAlert function.</p> <p>Palm OS Emulator patches the SysFatalAlert function and present the message in its own dialog box, to allow the user to choose how to respond to the error.</p>	<p>"Mytest" 1.0 has failed, reporting "attempted divide by 0". If this is the latest version of "Mytest", please report this to the application author.</p>
Unhandled exception	<p>The application or system software has caused an exception that Palm OS Emulator cannot handle itself.</p>	<p>"Mytest" 1.0 has just performed an illegal operation. It performed a "exception". If this is the latest version of "Mytest" 1.0, please report this to the application author.</p>

Advanced Topics

Creating Demonstration Versions of Palm OS Emulator

If you are running Palm OS Emulator on Windows NT, you can create an executable that binds the Emulator program with a ROM image and optionally a RAM image. The bound program can then be used for demonstrations, training, and kiosk systems.

To save a demonstration version of the Emulator session, you can right-click on the Palm OS Emulator display (the Palm device image) and select **Save Bound Emulator...**

Sending Commands to Palm OS Emulator

You can use RPC packets to send commands to Palm OS Emulator. You can invoke any function in the Palm OS dispatch table, including the Host Control functions, which are described in [Chapter 2, "Host Control API Reference."](#)

The RPC packets use the same format as do packets that are sent to the debugger interface, which is described in [Chapter 6, "Debugger Protocol Reference."](#)

You use the socket defined by the `RPCSocketPort` preference to make RPC calls to Palm OS Emulator. When you send a packet to the emulator, you must set the `dest` field of the packet header to the value defined here:

```
#define slkSocketRPC (slkSocketFirstDynamic+10)
```

NOTE: You can disable the RPC command facility by setting the value of the `RPCSocketPort` preference to 0.

You can send four kinds of command packets to the emulator:

- ReadMem
- WriteMem
- RPC
- RPC2

The first three packet types are described in [Chapter 6, “Debugger Protocol Reference.”](#) The fourth packet type, RPC2, is an extension of the RPC packet format that allows support for a wider range of operations.

The RPC2 Packet Format

```
#define sysPktRPC2Cmd0x20
#define sysPktRPC2Rsp0xA0

struct SysPktRPCParamInfo
{
    UInt8    byRef;
    UInt8    size;
    UInt16   data[1];
};

struct SysPktRPC2Type
{
    _sysPktBodyCommon;
    UInt16   trapWord;
    UInt32   resultD0;
    UInt32   resultA0;
    UInt16   resultException;
    UInt8    DRegMask;
    UInt8    ARegMask;
    UInt32   Regs[1];
    UInt16   numParams;
    SysPktRPCParamTypeparam[1];
};
```

Almost all of the RPC2 packet format is the same as the RPC format that is described in [Chapter 6, “Debugger Protocol Reference.”](#) The RPC2 packet includes the following additional fields:

resultException	Stores the exception ID if a function call failed due to a hardware exception. Otherwise, the value of this field is 0.
DRegMask	A bitmask indicating which D registers need to be set to make this call.

Using Palm OS Emulator

User Interface Summary

ARegMask	A bitmask indicating which A registers need to be set to make this call.
Regs [1]	<p>A variable-length array containing the values to be stored in the registers that need to be set.</p> <p>Only the registers that are being changed need to be supplied. Most of the time, DRegMask and ARegMask are set to zero and this field is not included in the packet.</p> <p>If more than one register needs to be set, then the register values should appear in the following order: D0, D1, ..., D6, D7, A0, A1, ..., A6, A7. Again, only values for the registers specified in DRegMask and ARegMask need to be provided.</p>

User Interface Summary

This section provides a description of the user interface for Palm OS Emulator, including descriptions of the menus and keyboard usage.

Palm OS Emulator Display


The Palm OS Emulator display looks very much like a real Palm Powered handheld device. You can use your mouse to perform actions that you perform with the stylus on handheld devices, and you can use the menus to access Palm OS Emulator functionality.

Using the Menus

You can also access features that are specific to Palm OS Emulator by choosing menu items:

- If you are using Windows, right-click on the Palm OS Emulator screen display to access the menu items, or press the F10 key. The Palm OS Emulator menu displays, as shown in [Figure 1.21](#).

Figure 1.21 The Windows Version of the Palm OS Emulator Menu



- If you are using a Macintosh, select menu items from the menu bar. The Macintosh menu presents the same items in four different menus, as described in [Table 1.11](#). The Macintosh version is only slightly different:
 - The Macintosh version of Palm OS Emulator uses **Preferences** instead of **Properties** to access the option-setting dialog box.
 - The Macintosh version of the Emulator features **Undo**, **Cut**, **Copy**, **Paste**, and **Clear**, which are not available in the Windows version.
 - The Macintosh version of the Emulator uses **Quit** instead of **Exit**.
 - The Macintosh version does not feature **Breakpoints**.

Table 1.11 Palm OS Emulator Macintosh Menus

Menu	Commands
File	New
	Open
	Close
	Save
	Save As
	Save Bound Emulator
	Save Screen
	Install Application/Database
	HotSync
	Reset
	Transfer ROM
	Quit
Edit	Undo
	Cut
	Copy
	Paste
	Clear
	Preferences
	Logging Options
	Debug Options
Gremlins	Skins
	New
	Step
	Resume
Profile	Stop
	Start
	Stop
	Dump

If you are using Unix, Palm OS Emulator provides the same items as are included with the Windows version, except that **Breakpoints** is not available. The Unix version of the menu pops up like the Windows version, and uses a different hierarchy, but presents the same items.

[Table 1.12](#) provides a brief description of the Palm OS Emulator menu items, listed in alphabetical order.

Table 1.12 The Palm OS Emulator Menu Items

Command	Description
Close	Closes and optionally saves the current emulator session.
Exit	Exits Palm OS Emulator. If you have unsaved changes in your session file, Palm OS Emulator optionally prompts you to save the file before exiting.
Gremlin:New	Create a new Gremlin and start running it.
Gremlin:Step	Step a Gremlin, after stopping.
Gremlin:Resume	Resume running of the Gremlin. NOTE: this menu item is only shown in Windows versions, and is not yet implemented.
Gremlin:Stop	Stop running the Gremlin.
Gremlin: Resume from control file	Resumes running of Gremlins from data that was previously saved in a file. For more information, see “ Using Gremlins to Automate Testing ” on page 65.
HotSync	Lets you synchronize the emulator session environment with the desktop computer. See “ Using the HotSync Application With Palm OS Emulator ” on page 53 for more information about the cabling requirements and other considerations for this menu item.

Using Palm OS Emulator

User Interface Summary

Table 1.12 The Palm OS Emulator Menu Items (*continued*)

Command	Description
Install App/DB	Lets you install an application into the emulator session, in the same way that a user would install it on the handheld with the Palm Install tool. For more information, see “Installing Applications” on page 51.
Export Database...	Exports a database to your desktop computer as a PDB or PQA file, or exports an application to your desktop computer as a PRC file.
New	Displays the New Session dialog box. The New Session dialog box lets you select the session’s ROM file, device, skin, and RAM size.
Open	Displays the open file dialog box for opening a saved emulator session file. Note that the Open menu is for opening saved session files (PSF files), not for opening ROM files. To change the ROM file for your emulator session, you need to use the New menu.
Profiling:Start	Start profiling your application.
Profiling:Stop	Stop profiling your application.
Profiling:Dump	Save the profiling information to a file. For more information, see “Profiling Your Code” on page 75.
Reset	Resets the current emulation session, as if the reset button on the back of the handheld was pressed.
Save	Saves the current emulator session to an emulator PSF file.
Save As	Saves the current emulator session to an emulator PSF file.
Save Bound Emulator	Saves the current emulator session as an executable, which can be used for demonstration purposes.

Table 1.12 The Palm OS Emulator Menu Items (*continued*)

Command	Description
Save Screen	Saves the current screen image as a bitmap file. TIP: Save Screen is a very convenient means of capturing screen images for documentation of Palm OS applications.
Settings: Properties	Presents the properties dialog box, as described in " Palm OS Emulator Properties " on page 50.
Settings: Logging	Presents the logging options dialog box, as described in " Logging Options " on page 61.
Settings: Debug	Presents the debug options dialog box, as described in " Debug Options " on page 58.
Settings: Skins	Presents the skins dialog box, as described in " Changing the Emulator's Appearance " on page 48.
Settings: Card Options	Presents the card options dialog box, as described in " Emulating Expansion Cards " on page 56.
Settings: Breakpoints	Presents the breakpoints dialog box, as described in " Setting Breakpoints " on page 70.
Transfer ROM	Lets you download a ROM image and save it to disk. You can then initiate a new session based on that ROM image. For more information, see " Transferring a ROM Image From a Handheld " on page 33.

Using the Hardware Buttons

Palm OS Emulator emulates each of the hardware buttons on Palm Powered devices. You can click on a button to activate it, and you can press and hold down a button just as you would on a handheld. Palm OS Emulator also lets you activate the hardware buttons with keyboard equivalents, as shown in [Table 1.13](#).

Table 1.13 Keyboard equivalents for the hardware buttons

Button	Keyboard equivalent
On/off	ESC
Palm Date Book	F1
Palm Address Book	F2
Palm To Do List	F3
Palm Memo Pad	F4
Up	PAGE UP
Down	PAGE DOWN

Entering Data

Palm OS Emulator lets you use your desktop computer pointing device to tap and to draw Graffiti characters, just as you do with the stylus on the handheld.

Palm OS Emulator also lets you enter text from the desktop computer keyboard. For example, you can type the text for a note by tapping in the note text entry area and then using the keyboard.

Control Keys

Palm OS Emulator also supports a set of control keys that you can use for input. These keys, which are shown in [Table 1.14](#), are the same control keys that you can use with the Palm OS Simulator program.

Table 1.14 Palm OS Emulator Control Keys

Control key combination	Description
CONTROL+A	Displays the menu
CONTROL+B	Low battery warning
CONTROL+C	Command character
CONTROL+D	Confirmation character

Table 1.14 Palm OS Emulator Control Keys (*continued*)

Control key combination	Description
CONTROL+E	Displays the application launcher
CONTROL+F	Displays the onscreen keyboard
CONTROL+M	Enters a linefeed character
CONTROL+N	Jumps to the next field
CONTROL+P	Jumps to the previous field
CONTROL+S	Automatic off character
CONTROL+T	Sets or unsets hard contrasts
CONTROL+U	Turns backlighting on or off

Getting Help With Palm OS Emulator

Palm OS Emulator is constantly evolving, and Palm is always interested in hearing your comments and suggestions.

Palm provides a forum (emulator-forum@news.palmos.com) for questions and comments about Palm OS Emulator. To subscribe to the forum, see:

<http://www.palmos.com/dev/tech/support/forums/>

You can the latest information about Palm OS Emulator in the Palm developer zone on the Internet:

<http://www.palmos.com/dev/>

Note: The source code for Palm OS Emulator is available at:

<http://www.palmos.com/dev/tech/tools/emulator/>

You can create your own emulator by modifying this source code.

For more information on the protocol used in Palm OS Emulator to send requests to and receive responses from a debugging target, see [Chapter 6](#), “[Debugger Protocol Reference](#).”

Host Control API Reference

This chapter describes the host control API. The following topics are covered in this chapter:

- “[About the Host Control API](#)” - Conceptual information about the host control API
- “[Constants](#)” on page 96 - A list of the constants that can be used with the host control functions
- “[Data Types](#)” on page 101 - A list of the data types that can be used with the host control functions
- “[Functions](#)” on page 108 - A list of all host control functions, sorted alphabetically
- “[Reference Summary](#)” on page 151 - A summary of all host control functions, sorted by category

About the Host Control API

You can use the host control API to call emulator-defined functions while your application is running under the Palm OS® Emulator. For example, you can make function calls to start and stop profiling in the emulator.

Host control functions are defined in the `HostControl.h` header file. These functions are invoked by executing a trap/selector combination that is defined for use by the emulator and other foreign host environments. Palm OS Emulator catches the calls intended for it that are made to this selector.

IMPORTANT: This chapter describes the version of the host control API that shipped with Palm OS Emulator 3.0a8. If you are using a different version, the features in your version might be different than the features described here.

Constants

This section lists the constants that you use with the host control API.

Host Error Constants

Several of the host control API functions return a `HostErrType` value.

```
enum
{
    hostErrNone = 0,
    hostErrBase = hostErrorClass,
    hostErrUnknownGestaltSelector,
    hostErrDiskError,
    hostErrOutOfMemory,
    hostErrMemReadOutOfRange,
    hostErrMemWriteOutOfRange,
    hostErrMemInvalidPtr,
    hostErrInvalidParameter,
    hostErrTimeout,
    hostErrInvalidDeviceType,
    hostErrInvalidRAMSize,
    hostErrFileNotFound,
    hostErrRPCCall,
    hostErrSessionRunning,
    hostErrSessionNotRunning,
    hostErrNoSignalWaiters,
    hostErrSessionNotPaused,
    hostErrPermissions,
    hostErrFileNameTooLong,
    hostErrNotADirectory,
```



```
hostErrTooManyFiles,  
hostErrFileTooBig,  
hostErrReadOnlyFS,  
hostErrIsDirectory,  
hostErrExists,  
hostErrOpNotAvailable,  
hostErrDirNotEmpty,  
hostErrDiskFull,  
hostErrUnknownError  
};
```

hostErrNone No error.

hostErrBase A class error occurred.

hostErrUnknownGestaltSelector
The specified Gestalt selector value is not valid.

hostErrDiskError
A disk error occurred. The standard C library error code EIO is mapped to this error constant.

hostErrOutOfMemory
There is not enough memory to complete the request. The standard C library error code ENOMEM is mapped to this error constant.

hostErrMemReadOutOfRange
An out of range error occurred during a memory read.

hostErrMemWriteOutOfRange
An out of range error occurred during a memory write.

hostErrMemInvalidPtr
The pointer is not valid.

hostErrInvalidParameter
A parameter to a function is not valid. The standard C library error codes EBADE, EFAULT and EINVAL are mapped to this error constant.

hostErrTimeout
A timeout occurred.

Host Control API Reference

Constants

<code>hostErrInvalidDeviceType</code>	The specified device type is not valid.
<code>hostErrInvalidRAMSize</code>	The specified RAM size value is not valid.
<code>hostErrFileNotFound</code>	The specified file could not be found. The standard C library error code <code>ENOENT</code> is mapped to this error constant.
<code>hostErrRPCCall</code>	A function that must be called remotely was called by an application. These functions include: <code>HostSessionCreate</code> , <code>HostSessionOpen</code> , <code>HostSessionClose</code> , <code>HostSessionQuit</code> , <code>HostSignalWait</code> , and <code>HostSignalResume</code> .
<code>hostErrSessionRunning</code>	A session is already running and one of the following functions was called: <code>HostSessionCreate</code> , <code>HostSessionOpen</code> , or <code>HostSessionQuit</code> .
<code>hostErrSessionNotRunning</code>	No session is running and the <code>HostSessionClose</code> function was called.
<code>hostErrNoSignalWaiters</code>	The <code>HostSendSignal</code> function was called, but there are no external scripts waiting for a signal.
<code>hostErrSessionNotPaused</code>	The <code>HostSignalResume</code> function was called, but the session has not been paused by a call to <code>HostSendSignal</code> .
<code>hostErrPermissions</code>	The standard C library error code <code>EACCES</code> and <code>EPERM</code> are mapped to this error constant.

`hostErrFileNameTooLong`

The standard C library error code `ENAMETOOLONG` is mapped to this error constant.

`hostErrNotADirectory`

The standard C library error code `ENOTDIR` is mapped to this error constant.

`hostErrTooManyFiles`

The standard C library error code `EMFILE` and `ENFILE` are mapped to this error constant.

`hostErrFileTooBig`

The standard C library error code `EFBIG` is mapped to this error constant.

`hostErrReadOnlyFS`

The standard C library error code `EROFS` is mapped to this error constant.

`hostErrIsDirectory`

The standard C library error code `EISDIR` is mapped to this error constant.

`hostErrExists`

The standard C library error code `EEXIST` is mapped to this error constant.

`hostErrOpNotAvailable`

The standard C library error codes `ENOSYS` and `ENODEV` are mapped to this error constant.

`hostErrDirNotEmpty`

The standard C library error code `ENOTEMPTY` is mapped to this error constant.

`hostErrDiskFull`

The standard C library error code `ENOSPC` is mapped to this error constant.

`hostErrUnknownError`

The standard C library error code values that are not mapped to any of the above error constants are mapped to this error constant.

Host Function Selector Constants

You can use the host function selector constants with the [HostIsSelectorImplemented](#) function to determine if a certain function is implemented on your debugging host. Each constant is the name of a function, with the `Host` portion replaced by `HostSelector`.

For a complete list of the constants available, see the `HostControl.h` header file.

Host ID Constants

Some of the host control API functions use a Host ID value to specify the debugging host type.

```
enum
{
    hostIDPalmOS,
    hostIDPalmOSEmulator,
    hostIDPalmOSSimulator
};
```

`hostIDPalmOS` A Palm Powered hardware device.

`hostIDPalmOSEmulator`
 The Palm OS Emulator application.

`hostIDPalmOSSimulator`
 The Macintosh Simulator application.

Host Platform Constants

Several of the host control API functions use a `HostPlatform` value to specify operating system hosting the emulation.

```
enum
{
    hostPlatformPalmOS,
    hostPlatformWindows,
    hostPlatformMacintosh,
    hostPlatformUnix
};
```

`hostPlatformPalmOS`

The Palm OS platform.

`hostPlatformWindows`

The Windows operating system platform.

`hostPlatformMacintosh`

The Mac OS platform.

`hostPlatformUnix`

The Unix operating system platform.

Host Signal Constants

This section describes the host signal values, which you can use with the `HostSendSignal`.

```
enum
{
    hostSignalReserved,
    hostSignalIdle,
    hostSignalQuit
};
```

`hostSignalReserved`

System-defined signals start here.

`hostSignalIdle`

Palm OS Emulator is about to go into an idle state.

`hostSignalQuit`

Palm OS Emulator is about to quit.

Data Types

This section describes the data types that you use with the host control API.

HostBoolType

The host control API defines `HostBoolType` for use as a Boolean value.

```
typedef long HostBoolType;
```



HostClockType

The host control API defines `HostClockType` as a platform-independent representation of the standard C library `clock_t` type.

```
typedef long HostClockType;
```



HostDirEntType

The host control API defines `HostDirEntType` as a return value for the `HostReadDir` function. The contents are platform-specific, usually a simple null-terminated file name.

```
struct HostDirEntType
{
    char    d_name[HOST_NAME_MAX + 1];
};

typedef struct HostDirEntType HostDirEntType;
```



HostDIRType

The host control API defines `HostDIRType` for use in directory-related functions. It is returned by `HostOpenDir` and used by `HostReadDir` and `HostCloseDir`. It represents an open directory whose contents can be read.

```
struct HostDIRType
{
    long    _field;
```

```
};  
typedef struct HostDIRType HostDIRType;
```

HostFileType

The host control API defines HostFileType for the standard C library functions that take FILE* parameters. It is returned by HostFOpen and used by other host control functions. It represents an open file whose contents can be manipulated.

```
typedef struct HostFileType  
{  
    long _field;  
} HostFileType;
```

HostGremlinInfoType

The host control API defines the HostGremlinInfoType structure type to store information about a horde of gremlins.

```
typedef struct HostGremlinInfoType  
{  
    long    fFirstGremlin;  
    long    fLastGremlin;  
    long    fSaveFrequency;  
    long    fSwitchDepth;  
    long    fMaxDepth;  
    char    fAppNames[200];  
};  
  
typedef struct HostGremlinInfoType  
HostGremlinInfoType;
```

HostGremlinInfo Fields

fFirstGremlin	The number of the first gremlin to run.
fLastGremlin	The number of the last gremlin to run.
fSaveFrequency	The gremlin snapshot frequency.
fSwitchDepth	The number of gremlin events to generate before switching to another gremlin.

Host Control API Reference

Data Types

<code>fMaxDepth</code>	The maximum number of gremlin events to generate for each gremlin.
<code>fAppNames</code>	<p>A comma-separated string containing a list of application names among which the gremlin horde is allowed to switch.</p> <p>If this string is empty, all applications are available for use with the gremlins.</p> <p>If this string begins with a dash (' - '), the applications named in the string are excluded, rather than included in the list of available applications.</p>

HostIDType

The host control API defines `HostIDType` for use as an identifier value.

```
typedef long HostIDType;
```

HostPlatformType

The host control API defines `HostPlatformType` for use as a platform identifier value.

```
typedef long HostPlatformType;
```

HostSignalType

The host control API defines `HostSignalType` for use in signal functions.

```
typedef long HostSignalType;
```



HostSizeType

The host control API defines `HostSizeType` as a platform-independent version of the standard C library `size_t` type.

```
typedef long HostSizeType;
```




New HostStatType

The host control API defines HostStatType for status information about files.

```
struct HostStatType
{
    unsigned long    st_dev_;
    unsigned long    st_ino_;
    unsigned long    st_mode_;
    unsigned long    st_nlink_;
    unsigned long    st_uid_;
    unsigned long    st_gid_;
    unsigned long    st_rdev_;
    HostTimeType     st_atime_;
    HostTimeType     st_mtime_;
    HostTimeType     st_ctime_;
    unsigned long    st_size_;
    unsigned long    st_blksize_;
    unsigned long    st_blocks_;
    unsigned long    st_flags_;
};
typedef struct HostStatType HostStatType;
```

HostStatType Fields

st_dev_	Drive number of the disk containing the file (the same as st_rdev_).
st_ino_	Number of the information node for the file (Unix-specific information).
st_mode_	Bit mask for file-mode information. The <code>_S_IFDIR</code> bit indicates if this is a directory; the <code>_S_IFREG</code> bit indicates an ordinary file or device. User read/write bits are set according to the file's permission mode; user execute bits are set according to the filename extension.
st_nlink_	Always returns 1 on non-NTFS file systems.

Host Control API Reference

Data Types

<code>st_uid_</code>	Numeric identifier of the user who owns the file (Unix-specific information).
<code>st_gid_</code>	Numeric identifier of the group who owns the file (Unix-specific information).
<code>st_rdev_</code>	Drive number of the disk containing the file (the same as <code>st_dev_</code>).
<code>st_atime_</code>	Time of the last access of the file.
<code>st_mtime_</code>	Time of the last modification of the file.
<code>st_ctime_</code>	Time of the creation of the file.
<code>st_size_</code>	Size of the file in bytes.
<code>st_blksize_</code>	Block size for the file.
<code>st_blocks_</code>	Number of blocks.
<code>st_flags_</code>	File flags.



New

HostTimeType

The host control API defines `HostTimeType` as a platform-independent version of the standard C library `time_t` type.

```
typedef long HostTimeType;
```



New

HostTmType

The host control API defines `HostTmType` for use in time functions.

```
struct HostTmType
{
    long    tm_sec_;
    long    tm_min_;
    long    tm_hour_;
    long    tm_mday_;
    long    tm_mon_;
    long    tm_year_;
    long    tm_wday_;
```

```

        long    tm_yday_;
        long    tm_isdst_;
    };
    typedef struct HostTmType HostTmType;

```

HostTmType Fields

tm_sec_	Seconds after the minute: range from 0 to 59.
tm_min_	Minutes after the hour: range from 0 to 59.
tm_hour_	Hours since midnight: range from 0 to 23.
tm_mday_	Day of the month: range from 1 to 31.
tm_mon_	Months since January: range from 0 to 11.
tm_year_	Years since 1900.
tm_wday_	Days since Sunday: range from 0 to 6.
tm_yday_	Days since January 1: range from 0 to 365.
tm_isdst_	Daylight savings time flag.



New

HostUTimeType

The host control API defines HostUTimeType for use in time functions.

```

    struct HostUTimeType
    {
        HostTimeType crtime_;
        HostTimeType actime_;
        HostTimeType modtime_;
    };
    typedef struct HostUTimeType HostUTimeType;

```

HostUTimeType Fields

crtime_	Creation time.
actime_	Access time.
modtime_	Modification time.

Functions

This section describes the host control API functions.

NOTE: For host control API functions that return pointers to character strings (that is, functions that return type `char *`), the returned value is valid only until the next call to a function that returns a pointer to a character string. If you need ongoing access to a character string, you should make a copy of the string before making the subsequent host control function call.



New

HostAscTime

Purpose Returns a character string representation of the time encoded in `time`.

Prototype `char* HostAscTime(const HostTmType* time);`

Parameters `time` The time structure.

Result The time as a character string.



New

HostClock

Purpose Returns an elapsed time.

Prototype `HostClockType HostClock(void);`

Parameters None.

Result The elapsed time in terms of the operating system's clock function (usually the number clock ticks that have elapsed since the start of the process), or -1 if the function call was not successful.



New HostCloseDir

Purpose Closes a directory.

Prototype `long HostCloseDir(HostDIRType* directory);`

Parameters `directory` The directory to be closed.

Result Returns 0 if the operation was successful, and a non-zero value if not.



New HostCTime

Purpose Converts the calendar time in `*timeofday` to a text representation.

Prototype `char* HostCTime(const HostTimeType* totimeofday)`

Parameters `timeofday` The calendar time.

Result The calendar time as a time string.

HostErrNo

Purpose Returns the value of `errno`, the standard C library variable that reflects the result of many standard C library functions. You can call this function after calling one of the Host Control functions that wraps the standard C library.

IMPORTANT: The `HostErrNo` function is only applicable to functions that wrap the standard C library. It is not applicable to all Host Control functions.

Host Control API Reference

Functions

Prototype `long HostErrNo(void);`

Parameters None.

Result The error number.

HostExportFile

Purpose Copies a database from the handheld device to the desktop computer.

Prototype `HostErr HostExportFile(const char* fileName,
 long cardNum, const char* dbName);`

Parameters

<code>fileName</code>	The file name to use on the desktop computer.
<code>cardNum</code>	The number of the card on the handheld device on which the database is contained.
<code>dbName</code>	The name of the handheld database.

Result Returns 0 if the operation was successful, and a non-zero value if not.

HostFClose

Purpose Closes a file on the desktop computer.

Prototype `long HostFClose(HostFILE* f);`

Parameters `f` The file to close.

Result Returns 0 if the operation was successful, and a non-zero value if not.

HostFEOF

Purpose	Determines if the specified file is at its end.
Prototype	<code>long HostFEOF (HostFILE* f) ;</code>
Parameters	<code>f</code> The file to test.
Result	Returns 0 if the specified file is at its end, and a non-zero value otherwise.

HostFError

Purpose	Retrieves the error code from the most recent operation on the specified file.
Prototype	<code>long HostFError (HostFILE* f) ;</code>
Parameters	<code>f</code> The file.
Result	The error code from the most recent operation on the specified file. Returns 0 if no errors have occurred on the file.

HostFFlush

Purpose	Flushes the buffer for the specified file.
Prototype	<code>long HostFFlush (HostFILE* f) ;</code>
Parameters	<code>f</code> The file to flush.
Result	Returns 0 if the operation was successful, and a non-zero value if not.

HostFGetC

Purpose	Retrieves the character at the current position in the specified file.		
Prototype	<code>long HostFGetC (HostFILE* f) ;</code>		
Parameters	<table><tr><td><code>f</code></td><td>The file.</td></tr></table>	<code>f</code>	The file.
<code>f</code>	The file.		
Result	The character, or EOF to indicate an error.		

HostFGetPos

Purpose	Retrieves the current position in the specified file.				
Prototype	<code>long HostFGetPos (HostFILE* f, long* posn) ;</code>				
Parameters	<table><tr><td><code>f</code></td><td>The file.</td></tr><tr><td><code>posn</code></td><td>Upon successful return, the current position in the file.</td></tr></table>	<code>f</code>	The file.	<code>posn</code>	Upon successful return, the current position in the file.
<code>f</code>	The file.				
<code>posn</code>	Upon successful return, the current position in the file.				
Result	Returns 0 if the operation was successful, and a non-zero value if not.				

HostFGetS

Purpose	Retrieves a character string from the selected file and returns a pointer to that string.						
Prototype	<code>char* HostFGetS (char* s, long n, HostFILE* f) ;</code>						
Parameters	<table><tr><td><code>s</code></td><td>A pointer to the string buffer to be filled with characters from the file.</td></tr><tr><td><code>n</code></td><td>The number of characters to retrieve.</td></tr><tr><td><code>f</code></td><td>The file.</td></tr></table>	<code>s</code>	A pointer to the string buffer to be filled with characters from the file.	<code>n</code>	The number of characters to retrieve.	<code>f</code>	The file.
<code>s</code>	A pointer to the string buffer to be filled with characters from the file.						
<code>n</code>	The number of characters to retrieve.						
<code>f</code>	The file.						
Result	The character string, or NULL to indicate an error.						

HostFOpen

Purpose Opens a file on the desktop computer.

Prototype `HostFILE* HostFOpen(const char* name,
const char* mode);`

Parameters

<code>name</code>	The name of the file to open.
<code>mode</code>	The mode to use when opening the file.

Result The file stream pointer, or NULL to indicate an error.

HostFPrintf

Purpose Writes a formatted string to a file.

Prototype `long HostFPrintf(HostFILE* f, const char* format,
...);`

Parameters

<code>f</code>	The file to which the string is written.
<code>format</code>	The format specification.
<code>...</code>	String arguments.

Result The number of characters actually written.

HostFPutC

Purpose Writes a character to the specified file.

Prototype `long HostFPutC(long c, HostFILE* f);`

Parameters

<code>c</code>	The character to write.
<code>f</code>	The file to which the character is written.

Result The number of characters written, or EOF to indicate an error.

HostFPutS

Purpose Writes a string to the specified file.

Prototype `long HostFPutS(const char* s, HostFILE* f);`

Parameters

<code>s</code>	The string to write.
<code>f</code>	The file to which the character is written.

Result A non-negative value if the operation was successful, or a negative value to indicate failure.

HostFRead

Purpose Reads a number of items from the file into a buffer.

Prototype `long HostFRead(void* buffer, long size, long count, HostFILE* f);`

Parameters

<code>buffer</code>	The buffer into which data is read.
<code>size</code>	The size of each item.
<code>count</code>	The number of items to read.
<code>f</code>	The file from which to read.

Result The number of items that were actually read.

HostFree

Purpose Frees memory on the desktop computer.

Prototype `void HostFree(void* p);`

Parameters

<code>p</code>	A pointer to the memory block to be freed.
----------------	--

Result None.

HostFReopen

Purpose Changes the file with which the stream `f` is associated. `HostFReopen` first closes the file that was associated with the stream, then opens the new file and associates it with the same stream.

Prototype `HostFILE* HostFReopen(const char* name, const char* mode, HostFILE *f);`

Parameters

<code>name</code>	The name of the file to open.
<code>mode</code>	The mode to use when opening the file.
<code>f</code>	The file from which to read.

Result The file stream pointer, or `NULL` to indicate an error.

HostFScanF

Purpose Reads formatted text from a file.

Prototype `long HostFReopen(HostFILE* f, const char *fmt, ...);`

Parameters

<code>f</code>	The file from which to read input.
<code>fmt</code>	A format string, as used in standard C-library calls such as <code>scanf</code> .
<code>...</code>	The list of variables into which scanned input are written.

Result The number of items that were read, or a negative value to indicate an error.

Returns `EOF` if end of file was reached while scanning.

HostFSeek

Purpose Moves the file pointer to the specified position.

Prototype `long HostFSeek (HostFILE* f, long offset, long origin);`

Parameters	<code>f</code>	The file.
	<code>offset</code>	The number of bytes to move from the initial position, which is specified in the <code>origin</code> parameter.
	<code>origin</code>	The initial position.

Result Returns 0 if the operation was successful, and a non-zero value if not.

HostFSetPos

Purpose Sets the position indicator of the file.

Prototype `long HostFSetPos (HostFILE* f, long posn);`

Parameters	<code>f</code>	The file.
	<code>posn</code>	The position value.

Result Returns 0 if the operation was successful, and a non-zero value if not.

HostFTell

Purpose	Retrieves the current position of the specified file.		
Prototype	<code>long HostFTell (HostFILE* f);</code>		
Parameters	<table><tr><td><code>f</code></td><td>The file.</td></tr></table>	<code>f</code>	The file.
<code>f</code>	The file.		
Result	Returns -1 to indicate an error.		

HostFWrite

Purpose	Writes data to a file.								
Prototype	<code>long HostFWrite (const void* buffer, long size, long count, HostFILE* f);</code>								
Parameters	<table><tr><td><code>buffer</code></td><td>The buffer that contains the data to be written.</td></tr><tr><td><code>size</code></td><td>The size of each item.</td></tr><tr><td><code>count</code></td><td>The number of items to write.</td></tr><tr><td><code>f</code></td><td>The file to which the data is written.</td></tr></table>	<code>buffer</code>	The buffer that contains the data to be written.	<code>size</code>	The size of each item.	<code>count</code>	The number of items to write.	<code>f</code>	The file to which the data is written.
<code>buffer</code>	The buffer that contains the data to be written.								
<code>size</code>	The size of each item.								
<code>count</code>	The number of items to write.								
<code>f</code>	The file to which the data is written.								
Result	The number of items actually written.								

HostGestalt

Purpose	Currently does nothing except return an “invalid selector” error. In the future, this function will be used for queries about the runtime environment.				
Prototype	<code>HostErr HostGestalt (long gestSel, long* response);</code>				
Parameters	<table><tr><td><code>gestSel</code></td><td></td></tr><tr><td><code>response</code></td><td></td></tr></table>	<code>gestSel</code>		<code>response</code>	
<code>gestSel</code>					
<code>response</code>					



New

HostGetDirectory

Purpose Gets a directory, in support of the operating system file chooser dialog box.

Prototype `const char* HostGetDirectory(const char* prompt, const char* defaultDir);`

Parameters `prompt`
`defaultDir` The default directory to get.

Result Returns the directory as a character string.

HostGetEnv

Purpose Retrieves the value of an environment variable.

Prototype `char* HostGetEnv(char* varName);`

Parameters `varName` The name of the environment variable that you want to retrieve.

Result The string value of the named variable, or NULL if the variable cannot be retrieved.



New

HostGetFile

Purpose Gets a file, in support of the operating system file chooser dialog box.

Prototype `const char* HostGetFile(const char* prompt, const char* defaultFile)`

Parameters `prompt`

`defaultFile` The default file to get.

Result Returns the file as a character string.



New **HostGetFileAttr**

Purpose Get the attribute settings of a file or directory. This function can tell you whether the file is read-only, hidden, or a system file.

Prototype `long HostGetFileAttr(const char* fileOrPathName,
long* attrFlag)`

Parameters `fileOrPathName` The file name or directory path for which you want to get the file attribute setting.

`attrFlag` One of the following attribute flags:

 - `hostFileAttrReadOnly`

 - `hostFileAttrHidden`

 - `hostFileAttrSystem`

The file attribute flags match the `EmFileAttr` flags:

```
enum
{
    hostFileAttrReadOnly = 1,
    hostFileAttrHidden = 2,
    hostFileAttrSystem = 4
}
```

Result The file attribute.

HostGetHostID

Purpose Retrieves the ID of the debugging host. This is one of the constants described in [Host ID Constants](#). Palm OS Emulator always returns the value `hostIDPalmOSEmulator`.

Prototype `HostID HostGetHostID(void);`

Parameters None.

Result The host ID.

HostGetHostPlatform

Purpose Retrieves the host platform ID, which is one of the values described in [Host Platform Constants](#).

Prototype `HostPlatform HostGetHostPlatform(void);`

Parameters None.

Result The platform ID.

HostGetHostVersion

Purpose Retrieves the version number of the debugging host.

Prototype `long HostGetHostVersion(void);`

Parameters None.

Result The version number.

Comments This function returns the version number in the same format that is used by the Palm OS, which means that you can access the version number components using the following macros from the `SystemMgr.h` file:


```
sysGetROMVerMajor(dwROMVer)
sysGetROMVerMinor(dwROMVer)
sysGetROMVerFix(dwROMVer)
sysGetROMVerStage(dwROMVer)
sysGetROMVerBuild(dwROMVer)
```

HostGetPreference

Purpose Retrieves the specified preference value.

Prototype `HostBool HostGetPreference(const char* prefName, char* prefValue);`

Parameters

<code>prefName</code>	The name of the preference whose value you want to retrieve.
<code>prefValue</code>	Upon successful return, the string value of the specified preference.

Result A Boolean value that indicates whether the preference was successfully retrieved.

Comments Each preference is identified by name. You can view the preference names in the Palm OS Emulator preferences file for your platform, as shown in [Table 2.1](#).

Table 2.1 Palm OS Emulator preferences file names and locations

Platform	File name	File location
Macintosh	Palm OS Emulator Prefs	In the Preferences folder
Windows	Palm OS Emulator.ini	In the Windows System directory
Unix	.poserrc	In your home directory

See Also The [HostSetPreference](#) function.



New

HostGMTime

Purpose Returns time structure representation of the time, expressed as Universal Time Coordinated, or UTC (UTC was formerly Greenwich Mean Time, or GMT).

Prototype `HostTmType* HostGMTime(const HostTimeType* time);`

Parameters time

Result The time structure.

HostGremlinCounter

Purpose Returns the current event count of the currently running gremlin.

Prototype `long HostGremlinCounter(void);`

Parameters None.

Result The event count.

Comments This return value of this function is only valid if a gremlin is currently running.

HostGremlinIsRunning

Purpose Determines if a gremlin is currently running.

Prototype `HostBool HostGremlinIsRunning(void);`

Parameters None.

Result A Boolean value indicating whether a gremlin is currently running.

HostGremlinLimit

Purpose	Retrieves the limit value of the currently running gremlin.
Prototype	<code>long HostGremlinLimit(void);</code>
Parameters	None.
Result	The limit value of the currently running gremlin.
Comments	This return value of this function is only valid if a gremlin is currently running.

HostGremlinNew

Purpose	Creates a new gremlin.
Prototype	<code>HostErr HostGremlinNew(const HostGremlinInfo* info);</code>
Parameters	<code>info</code> A <code>HostGremlinInfo</code> structure with information about the new horde of gremlins

HostGremlinNumber

Purpose	Retrieves the number of the currently running gremlin.
Prototype	<code>long HostGremlinNumber(void);</code>
Parameters	None.
Result	The gremlin number of the currently running gremlin.
Comments	This return value of this function is only valid if a gremlin is currently running.

HostImportFile

Purpose Copies a database from the desktop computer to the handheld device, and stores it on the specified card number. The database name on the handheld device is the name stored in the file.

Prototype `HostErr HostImportFile(const char* fileName,
long cardNum);`

Parameters	<code>fileName</code>	The file on the desktop computer that contains the database.
	<code>cardNum</code>	The card number on which the database is to be installed. You almost always use 0 to specify the built-in RAM.

Result Returns 0 if the operation was successful, and a non-zero value if not.

HostIsCallingTrap

Purpose Determines if Palm OS Emulator is currently calling a trap.

Prototype `HostBool HostIsCallingTrap(void);`

Parameters None.

Result TRUE if Palm OS Emulator is currently calling a trap, and FALSE if not.

HostIsSelectorImplemented

Purpose	Determines if the specified function selector is implemented on the debugging host.	
Prototype	<code>HostBool HostIsSelectorImplemented(long selector);</code>	
Parameters	<code>selector</code>	The function selector. This must be one of the constants described in Host Function Selector Constants .
Result	TRUE if the specified function selector is implemented on the host, and FALSE if not	



New

HostLocalTime

Purpose	Returns time structure representation of the time, expressed as local time.	
Prototype	<code>HostTmType* HostLocalTime(const HostTimeType* time);</code>	
Parameters	<code>time</code>	The time structure.
Result	The time structure.	

HostLogFile

Purpose Returns a reference to the file that the Emulator is using to log information. You can use this to add your own information to the same file.

Prototype `HostFILE* HostLogFile(void);`

Parameters None.

Result A pointer to the log file, or NULL if not successful.

HostMalloc

Purpose Allocates a memory block on the debugging host.

Prototype `void* HostMalloc(long size);`

Parameters `size` The number of bytes to allocate.

Result A pointer to the allocated memory block, or NULL if there is not enough memory available.



New

HostMkDir

Purpose Creates a directory.

Prototype `long HostMkDir(const char* directory);`

Parameters `directory` The directory to create.

Result Returns 0 if the operation was successful, and a non-zero value if not.



New

HostMkTime

Purpose Alters the parameter values to represent an equivalent encoded local time, but with the values of all members within their normal ranges.

Prototype `HostTimeType HostMkTime (HostTmType* time)`

Parameters `time` The time structure.

Result Returns the calendar time equivalent to the encoded time, or returns a value of -1 if the calendar time cannot be represented



New

HostOpenDir

Purpose Opens a directory.

Prototype `HostDIRType* HostOpenDir (const char* directory);`

Parameters `directory` The directory to open.

Result Returns a directory structure.

HostProfileCleanup

Purpose Releases the memory used for profiling and disables profiling.

Prototype `HostErr HostProfileCleanup (void);`

Parameters None.

Result Returns 0 if the operation was successful, and a non-zero value if not.

Host Control API Reference

Functions

Comments This function is available only in the profiling version of the emulator.

If you call this function out of profiling sequence, then it will return an error. For information on profiling sequence, see “[HostProfileInit](#)” on page 130.

See Also The [HostProfileStart](#), [HostProfileStop](#), and [HostProfileDump](#) functions.

HostProfileDetailFn

Purpose Profiles the function that contains the specified address.

Prototype `HostErr HostProfileDetailFn(void* addr,
HostBool logDetails);`

Parameters

<code>addr</code>	The address in which you are interested.
<code>logDetails</code>	A Boolean value. If this is TRUE, profiling is performed at a machine-language instruction level, which means that each opcode is treated as its own function.

Result Returns 0 if the operation was successful, and a non-zero value if not.

Comments This function is available only in the profiling version of the emulator.

See Also The [HostProfileInit](#), [HostProfileStart](#), [HostProfileStop](#), [HostProfileDump](#), and [HostProfileCleanup](#) functions.

HostProfileDump

Purpose	Writes the current profiling information to the named file.		
Prototype	<code>HostErr HostProfileDump(const char* filename);</code>		
Parameters	<table><tr><td><code>filename</code></td><td>The name of the file to which the profile information gets written.</td></tr></table>	<code>filename</code>	The name of the file to which the profile information gets written.
<code>filename</code>	The name of the file to which the profile information gets written.		
Result	Returns 0 if the operation was successful, and a non-zero value if not.		
Comments	<p>This function is available only in the profiling version of the emulator.</p> <p>If you call this function out of profiling sequence, then it will return an error. For information on profiling sequence, see “HostProfileInit” on page 130.</p>		
See Also	The HostProfileInit , HostProfileStart , HostProfileStop , and HostProfileCleanup functions.		



New

HostProfileGetCycles

Purpose	Returns the current running CPU cycle count.
Prototype	<code>long HostProfileGetCycles(void)</code>
Parameters	None.
Result	Returns the current running CPU cycle count.
Comments	This function is available only in the profiling version of the emulator.
See Also	The HostProfileInit , HostProfileStart , HostProfileStop , HostProfileDump , and HostProfileCleanup functions.

HostProfileInit

Purpose	Initializes and enables profiling in the debugging host.	
Prototype	<pre>HostErr HostProfileInit(long maxCalls, long maxDepth);</pre>	
Parameters	<code>maxCalls</code>	The maximum number of calls to profile. This parameter determines the size of the array used to keep track of function calls. A typical value for <code>maxCalls</code> is 65536.
	<code>maxDepth</code>	The maximum profiling depth. This parameter determines the size of the array used to keep track of function call depth. A typical value for <code>maxDepth</code> is 200.
Result	Returns 0 if the operation was successful, and a non-zero value if not.	
Comments	This function is available only in the profiling version of the emulator.	
	<p>The host control profiling functions are intended to be called in sequence:</p> <ol style="list-style-type: none">1. <code>HostProfileInit</code> - All profiling starts with the <code>HostProfileInit</code> function, which initializes and enables profiling.2. <code>HostProfileStart</code> - This function turns profiling on.3. <code>HostProfileStop</code> - This function turns profiling off. After calling <code>HostProfileStop</code>, you can either call <code>HostProfileStart</code> to restart profiling or call <code>HostProfileDump</code>, which disables profiling and writes data to a file.4. <code>HostProfileDump</code> - This function disables profiling and writes data to a file. If you need to do more profiling after calling <code>HostProfileDump</code>, you need to call <code>HostProfileInit</code> to re-enable profiling.	

5. `HostProfileCleanup` - This function releases the memory used for profiling and disables profiling.

See Also The [HostProfileStart](#), [HostProfileStop](#), [HostProfileDump](#), and [HostProfileCleanup](#) functions.

HostProfileStart

Purpose Turns profiling on.

Prototype `HostErr HostProfileStart(void);`

Parameters None.

Result Returns 0 if the operation was successful, and a non-zero value if not.

Comments This function is available only in the profiling version of the emulator.

If you call this function out of profiling sequence, then it will return an error. For information on profiling sequence, see “[HostProfileInit](#)” on page 130.

See Also The [HostProfileInit](#), [HostProfileStop](#), [HostProfileDump](#), and [HostProfileCleanup](#) functions.

HostProfileStop

Purpose Turns profiling off.

Prototype `HostErr HostProfileStop(void);`

Parameters None.

Result Returns 0 if the operation was successful, and a non-zero value if not.

Host Control API Reference

Functions

Comments This function is available only in the profiling version of the emulator.

If you call this function out of profiling sequence, then it will return an error. For information on profiling sequence, see “[HostProfileInit](#)” on page 130.

See Also The [HostProfileInit](#), [HostProfileStop](#), [HostProfileDump](#), and [HostProfileCleanup](#) functions.



New

HostPutFile

Purpose Writes a file, in support of the operating system “Save As” dialog box.

Prototype `const char* HostPutFile(const char* prompt, const char* defaultDir, const char* defaultName);`

Parameters

<code>prompt</code>	
<code>defaultDir</code>	The default directory to use.
<code>defaultName</code>	The default file name to use.

Result Returns the file name as a character string.



New

HostReadDir

Purpose Reads a directory.

Prototype `HostDirEntType* HostReadDir(HostDIRType* directory);`

Parameters

<code>directory</code>	The directory to read.
------------------------	------------------------

Result Returns a character array for the directory.

HostRealloc

Purpose Reallocates space for the specified memory block.

Prototype `void* HostRealloc(void* ptr, long size);`

Parameters

<code>ptr</code>	A pointer to a memory block that is being resized.
<code>size</code>	The new size for the memory block.

Result A pointer to the allocated memory block, or NULL if there is not enough memory available.

HostRemove

Purpose Deletes a file.

Prototype `long HostRemove(const char* name);`

Parameters

<code>name</code>	The name of the file to be deleted.
-------------------	-------------------------------------

Result Returns 0 if the operation was successful, and a non-zero value if not.

HostRename

Purpose Renames a file.

Prototype `long HostRemove(const char* oldName,
const char* newName);`

Parameters

<code>oldName</code>	The name of the file to be renamed.
<code>newName</code>	The new name of the file.

Result Returns 0 if the operation was successful, and a non-zero value if not.

Host Control API Reference

Functions



New

HostRmDir

Purpose Removes a directory.

Prototype `long HostRmDir(const char* directory);`

Parameters `directory` The directory to remove.

Result Returns 0 if the operation was successful, and a non-zero value if not.



New

HostSaveScreen

Purpose Saves the LCD frame buffer to the given file name.

Prototype `HostErrType HostSaveScreen(const char* fileName)`

Parameters `fileName` The name of the file to which the current LCD frame buffer is to be saved.

Result Returns 0 if the operation was successful, and a non-zero value if not.

HostSessionClose

Purpose	Closes the current emulation session.	
Prototype	<code>HostErr HostSessionClose(const char* psfFileName);</code>	
Parameters	<code>psfFileName</code>	The name of the file to which the current session is to be saved.
Result	Returns 0 if the operation was successful, and a non-zero value if not.	
Comments	This function is defined for external RPC clients to call; the effect of calling it for Palm OS applications running on the emulated device is undefined.	

HostSessionCreate

Purpose	Creates a new emulation session.	
Prototype	<code>HostErr HostSessionCreate(const char* device, long ramSize, const char* romPath);</code>	
Parameters	<code>device</code>	The name of the handheld device to emulate in the session.
	<code>ramSize</code>	The amount of emulated RAM in the new session.
	<code>romPath</code>	The path to the ROM file for the new session.
Result	Returns 0 if the operation was successful, and a non-zero value if not.	
Comments	This function is defined for external RPC clients to call; the effect of calling it for Palm OS applications running on the emulated device is undefined.	

Host Control API Reference

Functions

IMPORTANT: This function is not implemented in the current version of Palm OS Emulator; however, it will be implemented in the near future.

HostSessionOpen

Purpose	Opens a previously saved emulation session.		
Prototype	<code>HostErr HostSessionOpen(const char* psfFileName);</code>		
Parameters	<table><tr><td><code>psfFileName</code></td><td>The name of the file containing the saved session that you want to open.</td></tr></table>	<code>psfFileName</code>	The name of the file containing the saved session that you want to open.
<code>psfFileName</code>	The name of the file containing the saved session that you want to open.		
Result	Returns 0 if the operation was successful, and a non-zero value if not.		
Comments	This function is defined for external RPC clients to call; the effect of calling it for Palm OS applications running on the emulated device is undefined.		

IMPORTANT: This function is not implemented in the current version of Palm OS Emulator; however, it will be implemented in the near future.

HostSessionQuit

Purpose	Asks Palm OS Emulator to quit. Returns an error if a session is already running.
Prototype	<code>HostErr HostSessionQuit(void);</code>
Parameters	None.
Result	Returns 0 if the operation was successful, and a non-zero value if not.

Comments This function is defined for external RPC clients to call; the effect of calling it for Palm OS applications running on the emulated device is undefined.

IMPORTANT: This function is defined for external RPC clients to call, and returns an error if you call it from within a Palm application.



New

HostSetFileAttr

Purpose Set the attribute settings of a file or directory. This function can set the read-only, hidden, or system-file attribute for the file or directory.

Prototype `long HostSetFileAttr(const char* fileOrPathName, long* attrFlag)`

Parameters `fileOrPathName` The file name or directory path for which you want to set the file attribute setting.

`attrFlag` One of the following attribute flags:

- `hostFileAttrReadOnly`

- `hostFileAttrHidden`

- `hostFileAttrSystem`

The file attribute flags match the `EmFileAttr` flags:

```
enum
{
    hostFileAttrReadOnly = 1,
    hostFileAttrHidden = 2,
    hostFileAttrSystem = 4
}
```

Result The file attribute.

HostSetLogFileSize

- Purpose** Determines the size of the logging file that Palm OS Emulator is using.
- Prototype** `void HostSetLogFileSize(long size);`
- Parameters** `size` The new size for the logging file, in bytes.
- Result** None.
- Comments** By default, Palm OS Emulator saves the last 1 megabyte of log data to prevent logging files from becoming enormous. You can call this function to change the log file size.

HostSetPreference

- Purpose** Sets the specified preference value.
- Prototype** `void HostSetPreference(const char* prefName, const char* prefValue);`
- Parameters** `prefName` The name of the preference whose value you are setting.
`prefValue` The new value of the preference.
- Result** None.
- Comments** Each preference is identified by name. You can view the preference names in the Palm OS Emulator preferences file for your platform, as shown in [Table 2.1](#).
- See Also** The [HostGetPreference](#) function.

HostSignalResume

Purpose	Restarts Palm OS Emulator after it has issued a signal.
Prototype	<code>HostErr HostSignalResume(void);</code>
Parameters	None.
Result	Returns 0 if the operation was successful, and a non-zero value if not.
Comments	Palm OS Emulator waits to be restarted after issuing a signal to allow external scripts to perform operations.
See Also	The HostSignalSend and HostSignalWait functions.

IMPORTANT: This function is defined for external RPC clients to call, and returns an error if you call it from within a Palm application.

HostSignalSend

Purpose	Sends a signal to any scripts that have HostSignalWait calls pending.		
Prototype	<code>HostErr HostSignalSend(HostSignal signalNumber);</code>		
Parameters	<table><tr><td><code>signalNumber</code></td><td>The signal for which you want to wait. This can be a predefined signal or one that you have defined.</td></tr></table>	<code>signalNumber</code>	The signal for which you want to wait. This can be a predefined signal or one that you have defined.
<code>signalNumber</code>	The signal for which you want to wait. This can be a predefined signal or one that you have defined.		
Result	Returns 0 if the operation was successful, and a non-zero value if not.		
Comments	Palm OS Emulator halts and waits to be restarted after sending the signal. This allows external scripts to perform operations. The		

Host Control API Reference

Functions

external script must call the [HostSignalResume](#) function to restart Palm OS Emulator.

If there are not any scripts waiting for a signal, Palm OS Emulator does not halt.

The predefined signals are:

- `hostSignalIdle`, which Palm OS Emulator issues when it detects that it is going into an idle state.
- `hostSignalQuit`, which Palm OS Emulator issues when it is about to quit.

See Also The [HostSignalResume](#) and [HostSignalWait](#) functions.

IMPORTANT: This function is defined for external RPC clients to call, and returns an error if you call it from within a Palm application.

HostSignalWait

Purpose Waits for a signal from Palm OS Emulator, and returns the signalled value.

Prototype `HostErr HostSignalWait(long timeout, HostSignal* signalNumber);`

Parameters

<code>timeout</code>	The number of milliseconds to wait for the signal before timing out.
<code>signalNumber</code>	The number of the signal that occurred.

Result Returns 0 if the operation was successful, and a non-zero value if not. Returns the number of the signal that occurred in `signalNumber`.

Comments Palm OS Emulator waits to be restarted after issuing a signal to allow external scripts to perform operations.

The predefined signals are:

- `hostSignalIdle`, which Palm OS Emulator issues when it detects that it is going into an idle state.
- `hostSignalQuit`, which Palm OS Emulator issues when it is about to quit.

See Also The [HostSignalResume](#) and [HostSignalSend](#) functions.

IMPORTANT: This function is defined for external RPC clients to call, and returns an error if you call it from within a Palm application.



New

HostSlotHasCard

Purpose Ask whether Emulator is emulating a Virtual File System card for a specific slot number.

Prototype `HostBoolType HostSlotHasCard(long slotNo)`

Parameters `slotNo` The slot number. This number can be in the range from 1 up to and including the number returned by function `HostSlotMax`.

Result A Boolean value that indicates whether Emulator is emulating a Virtual File System card in the slot specified by `slotNo`. This function is provided in support of Expansion Manager emulation.

Comments This function may return `FALSE` if the user has not selected to emulate a Virtual File System card in the given slot, or if Emulator is emulating a different kind of card in that slot.



New

HostSlotMax

Purpose Returns the number of Virtual File System cards that Emulator is emulating.

Prototype `long HostSlotMax(void)`

Parameters None.

Result A long value indicating the number of Virtual File System cards Emulator is emulating. This function is provided in support of Expansion Manager emulation.

Comments The functions that accept card numbers, HostSlotHasCard and HostSlotRoot, accept numbers from 1 up to and including the number returned by HostSlotMax.



New

HostSlotRoot

Purpose Returns a string representing the root directory of the emulated slot.

Prototype `const char* HostSlotRoot(long slotNo)`

Parameters `slotNo` The slot number. This number can be in the range from 1 up to and including the number returned by function HostSlotMax.

Result The character string representing the directory to be used as the root for the given Virtual File System card. This function is provided in support of Expansion Manager emulation.

Comments The string returned is in host path format. This function may return NULL if there is no Virtual File System card mounted in the slot specified by `slotNo` or if the user has not selected a root directory for that slot.



New HostStat

Purpose Returns status information about a file.

Prototype `long HostStat(const char* filename, HostStatType* buffer);`

Parameters

<code>filename</code>	The name of the file or directory for which you want status information
<code>buffer</code>	The structure that stores the status information

Result Returns 0 if the operation was successful, and a non-zero value if not.



New HostStrFTime

Purpose Generates formatted text, under the control of the format parameter and the values stored in the time structure parameter.

Prototype `HostSizeType HostStrFTime(char* string, HostSizeType size, const char* format, const HostTmType* time)`

Parameters

<code>string</code>	The formatted text
<code>size</code>	The size of an array element in the formatted text
<code>format</code>	The format definition
<code>time</code>	A time structure

Result Returns the number of characters generated, if the number is less than the `size` parameter; otherwise, returns zero, and the values stored in the array are indeterminate.



New HostTime

Purpose Returns the current calendar time.

Prototype `HostTimeType HostTime(HostTimeType* time);`

Parameters `time` The time structure.

Result Returns the current calendar time if the operation is successful, and returns -1 if not.

HostTmpFile

Purpose Returns the temporary file used by the debugging host.

Prototype `HostFILE* HostTmpFile(void);`

Parameters None.

Result A pointer to the temporary file, or NULL if an error occurred.

HostTmpNam

Purpose Creates a unique temporary file name.

Prototype `char* HostTmpNam(char* s);`

Parameters `s` Either be a NULL pointer or a pointer to a character array. The character array must be at least `L_tmpnam` characters long.
If `s` is not NULL, the newly created temporary file name is stored into `s`.

Result A pointer to an internal static object that the calling program can modify.

HostTraceClose

Purpose Closes the connection to the external trace reporting tool.

Prototype `void HostTraceClose(void);`

Parameters None.

Result None.

HostTraceInit

Purpose Initiates a connection to the external trace reporting tool.

Prototype `void HostTraceInit(void);`

Parameters None.

NOTE: The tracing functions are used in conjunction with an external trace reporting tool. You can call these functions to send information to the external tool in real time.

Result None.

HostTraceOutputB

Purpose	Outputs a buffer of data, in hex dump format, to the external trace reporting tool.	
Prototype	<pre>void HostTraceOutputB(unsigned short moduleId, const unsigned char* buffer, unsigned long len/*size_t*/);</pre>	
Parameters	<code>moduleId</code>	The ID of the Palm OS subsystem from which this output originates. You can use this with the external tracing tool to filter traces according to their origin.
		The ID must match one of the error classes defined in the <code>SystemMgr.h</code> file.
	<code>buffer</code>	A pointer to a buffer of raw data.
	<code>len</code>	The number of bytes of data in the buffer.
Result	None.	

HostTraceOutputT

Purpose	Outputs a text string to the external trace reporting tool.	
Prototype	<pre>void HostTraceOutputT(unsigned short moduleId, const char* fmt, ...);</pre>	
Parameters	<code>moduleId</code>	The ID of the Palm OS subsystem from which this output originates. You can use this with the external tracing tool to filter traces according to their origin.
		The ID must match one of the error classes defined in the <code>SystemMgr.h</code> file.

`fmt` A format string, as used in standard C-library calls such as `printf`. The format string has the following form:

`% flags width type`

...

The list of variables to be formatted for output.

[Table 2.2](#) shows the flag types that you can use in the format specification for the tracing output functions.

Table 2.2 Trace function format specification flags

Flag	Description
-	Left-justified output.
+	Always display the sign symbol.
space	Display a space when the value is positive, rather than a '+' symbol.
#	Alternate form specifier.

[Table 2.3](#) shows the output types that you can use in the format specification for the tracing output functions.

Table 2.3 Trace function format specification types

Flag	Description
%	Displays the '%' character.
s	Displays a null-terminated string value.
c	Displays a character value.
ld	Displays an Int32 value.
lu	Displays a UInt32 value.
lx or lX	Displays a UInt32 value in hexadecimal.
hd	Displays an Int16 value.
hu	Displays a UInt16 value.
hx or hX	Displays an Int16 or UInt16 value i hexadecimal.

Result None.

HostTraceOutputTL

Purpose Outputs a text string, followed by a newline, to the external trace reporting tool. This function performs the same operation as the `HostTraceOutputT` function, and adds the newline character.

```
Prototype void HostTraceOutputTL(unsigned short moduleId,
const char* fmt, ...);
```

Parameters	<code>moduleId</code>	The ID of the Palm OS subsystem from which this output originates. You can use this with the external tracing tool to filter traces according to their origin.
-------------------	-----------------------	--

The ID must match one of the error classes defined in the `SystemMgr.h` file.

fmt	A format string, as used in standard C-library calls such as <code>printf</code> . For more information about the formatting specification, see the description of the HostTraceOutputT function.
-----	---

... The list of variables to be formatted for output.

Result None.

HostTraceOutputVT

Purpose Outputs a text string to the external trace reporting tool.

Prototype `void HostTraceOutputVT(unsigned short moduleId, const char* fmt, va_list vars);`

Parameters

<code>moduleId</code>	The ID of the Palm OS subsystem from which this output originates. You can use this with the external tracing tool to filter traces according to their origin.
-----------------------	--

The ID must match one of the error classes defined in the `SystemMgr.h` file.

<code>fmt</code>	A format string, as used in standard C-library calls such as <code>printf</code> . For more information about the formatting specification, see the description of the HostTraceOutputT function.
------------------	---

<code>vars</code>	A structure containing the variable argument list. This is the same kind of variable argument list used for standard C-library functions such as <code>vprintf</code> .
-------------------	---

Result None.

HostTraceOutputVTL

Purpose	Outputs a text string, followed by a newline, to the external trace reporting tool. This function performs the same operation as the HostTraceOutputVT function, and adds the newline character.	
Prototype	<pre>void HostTraceOutputVTL(unsigned short moduleId, const char* fmt, va_list vars);</pre>	
Parameters	<code>moduleId</code>	The ID of the Palm OS subsystem from which this output originates. You can use this with the external tracing tool to filter traces according to their origin. The ID must match one of the error classes defined in the <code>SystemMgr.h</code> file.
	<code>fmt</code>	A format string, as used in standard C-library calls such as <code>printf</code> . For more information about the formatting specification, see the description of the HostTraceOutputT function.
	<code>vars</code>	A structure containing the variable argument list. This is the same kind of variable argument list used for standard C-library functions such as <code>vprintf</code> .
Result	None.	



New

HostTruncate

Purpose	Extends or truncates the file associated with the file handle to the length specified by the size.	
Prototype	<pre>long HostTruncate(const char* filename, long filesize);</pre>	
Parameters	<code>filename</code>	The name of the file.

filesize The size of the file.

Result Returns the value 0 if the file is successfully changed, or returns -1 if there was an error.



New **HostUTime**

Purpose Sets the modification time for a file.

Prototype `long HostUTime (const char* filename,
HostUTimeType* buffer);`

Parameters filename The filename of the file.
buffer The stored time values.

Result Returns 0 if the file-modification time was successfully changed, or returns -1 if there was an error.

Reference Summary

The tables in this section summarize the host control API functions.

Host Control Database Functions

Table 2.4 Host Control Database Functions

Function	Description
<u>HostExportFile</u>	Copies a database from the handheld device to the desktop computer.
<u>HostImportFile</u>	Copies a database from the desktop computer to the handheld device, and stores it on the specified card number. The database name on the handheld device is the name stored in the file.
<u>HostSaveScreen</u>	Saves the LCD frame buffer to a file.



New

Host Control Directory Handler Functions

Table 2.5 Host Control Directory Handler Functions

Function	Description
HostCloseDir	Closes a directory.
HostMkDir	Makes a directory.
HostOpenDir	Opens a directory.
HostReadDir	Reads a directory.
HostRmDir	Removes a directory.

Host Control Environment Functions

Table 2.6 Host Control Environment Functions

Function	Description
HostGestalt	Currently does nothing except to return an “invalid selector” error.
HostGetHostID	Retrieves the ID of the debugging host. Palm OS Emulator always returns the value <code>hostIDPalmOSEmulator</code> .
HostGetHostPlatform	Retrieves the host platform ID.
HostGetHostVersion	Returns the version number of the debugging host.
HostIsCallingTrap	Returns a Boolean indicating whether the specified function selector is implemented on the debugging host.
HostIsSelectorImplemented	Returns a Boolean indicating whether the specified function selector is implemented on the debugging host.



New

Host Control File Chooser Support Functions

Table 2.7 Host Control File Choose Support Functions

Function	Description
HostGetDirectory	Gets a directory, in support of the operating system file chooser dialog box.
HostGetFile	Gets a file, in support of the operating system file chooser dialog box.
HostPutFile	Writes a file, in support of the operating system file chooser dialog box.

Host Control Gremlin Functions

Table 2.8 Host Control Gremlin Functions

Function	Description
HostGremlinCounter	Returns the current count for the currently running gremlin.
HostGremlinIsRunning	Returns a Boolean value indicating whether a gremlin is currently running.
HostGremlinLimit	Returns the limit value of the currently running gremlin.
HostGremlinNew	Creates a new gremlin.
HostGremlinNumber	Returns the gremlin number of the currently running gremlin.

Host Control Logging Functions

Table 2.9 Host Control Logging Functions

Function	Description
HostLogFile	Returns a reference to the file that Palm OS Emulator is using to log information.
HostSetLogFileSize	Modifies the size of the logging file.

Host Control Preference Functions

Table 2.10 Host Control Preference Functions

Function	Description
HostGetPreference	Retrieves the value of a preference.
HostSetPreference	Sets a new value for a preference.

Host Control Profiling Functions

Table 2.11 Host Control Profiling Functions

Function	Description
HostProfileCleanup	Releases the memory used for profiling and disables profiling.
HostProfileDetailFn	Profiles the function that contains the specified address.
HostProfileDump	Writes the current profiling information to the named file.
HostProfileGetCycles	Returns the current running CPU cycle count.
HostProfileInit	Initializes and enables profiling in the debugging host.
HostProfileStart	Turns profiling on.
HostProfileStop	Turns profiling off.

Host Control RPC Functions

Table 2.12 Host Control RPC Functions

Function	Description
HostSessionClose	Closes the current emulation session
HostSessionCreate	Creates a new emulation session.
HostSessionOpen	Opens a previously saved emulation session.
HostSessionQuit	Asks Palm OS Emulator to quit.
HostSignalResume	Resumes Palm OS Emulator after it has halted to wait for external scripts to handle a signal.
HostSignalSend	Sends a signal to external scripts.
HostSignalWait	Waits for Palm OS Emulator to send a signal.

Host Control Standard C Library Functions

Table 2.13 Host Control Standard C Library Functions

Function	Description
HostErrNo	Returns the error number from the most recent host control API operation.
HostFClose	Closes a file on the desktop computer. Returns 0 if the operation was successful, and a non-zero value if not.
HostFEOF	Returns 0 if the specified file is at its end, and a non-zero value otherwise.
HostFError	Returns the error code from the most recent operation on the specified file. Returns 0 if no errors have occurred on the file.
HostFFlush	Flushes the buffer for the specified file.
HostFGetC	Returns the character at the current position in the specified file. Returns EOF to indicate an error.

Host Control API Reference

Reference Summary

Table 2.13 Host Control Standard C Library Functions

Function	Description
HostFGetPos	Retrieves the current position in the specified file. Returns 0 if the operation was successful, and a non-zero value if not.
HostFGetS	Retrieves a character string from the selected file and returns a pointer to that string. Returns NULL to indicate an error.
HostFOpen	Opens a file on the desktop computer and returns a <code>HostFILE</code> pointer for that file. Returns NULL to indicate an error.
HostFPrintf	Writes a formatted string to a file, and returns the number of characters written.
HostFPutC	Writes a character to the specified file, and returns the character written. Returns EOF to indicate an error.
HostFPutS	Writes a string to the specified file, and returns a non-negative value to indicate success.
HostFRead	Reads a number of items from the file into a buffer. Returns the number of items that were actually read.
HostFree	Frees memory on the desktop computer.
HostFReopen	Associates a file stream with a different file.
HostFScanF	Scans a file for formatted input.
HostFSeek	Moves the file pointer to the specified position, and returns 0 to indicate success.
HostFSetPos	Sets the position indicator of the file, and returns 0 to indicate success.
HostFTell	Retrieves the current position of the specified file. Returns -1 to indicate an error.

Table 2.13 Host Control Standard C Library Functions

Function	Description
HostFWrite	Writes data to a file, and returns the actual number of items written.
HostGetEnv	Retrieves the value of an environment variable.
HostMalloc	Allocates a memory block on the debugging host, and returns a pointer to the allocated memory. Returns NULL if there is not enough memory available.
HostRealloc	Reallocates space for the specified memory block.
HostRemove	Deletes a file.
HostRename	Renames a file.
HostTmpFile	Returns the temporary file used by the debugging host.
HostTmpNam	Creates a unique temporary file name.



Host Control Time Functions

Table 2.14 Host Control Time Functions

Function	Description
HostAscTime	Returns a character string representation of the time.
HostClock	Returns an elapsed time.
HostCTime	Converts calendar time to a text representation.
HostGMTime	Returns time structure representation of the time expressed as Universal Time Coordinated (UTC). UTC was formerly Greenwich Mean Time (GMT).

Host Control API Reference

Reference Summary

Table 2.14 Host Control Time Functions (*continued*)

Function	Description
HostLocalTime	Returns time structure representation of the time expressed as local time.
HostMkTime	Alters the parameter values to represent an equivalent encoded local time, but with the values of all members within their normal ranges.
HostStrFTime	Generates formatted text, under the control of the format parameter and the values stored in the time structure parameter.
HostTime	Returns the current calendar time.
HostUTime	Sets the modification time for a file.

Host Control Tracing Functions

Table 2.15 Host Control Tracing Functions

Function	Description
HostTraceClose	Must be called when done logging trace information.
HostTraceInit	Must be called before logging any trace information.
HostTraceOutputT	Outputs text to the trace log using printf-style formatting.
HostTraceOutputTL	Outputs text to the trace log using printf-style formatting, and appends a newline character to the text.
HostTraceOutputVT	Outputs text to the trace log using vprintf-style formatting.

Table 2.15 Host Control Tracing Functions (*continued*)

Function	Description
<u>HostTraceOutputVTL</u>	Outputs text to the trace log using vprintf-style formatting, and appends a newline character to the text.
<u>HostTraceOutputB</u>	Outputs a buffer of raw data to the trace log in hex dump format.

Using Palm Simulator

This chapter describes Palm Simulator, which you can use to test and debug Palm OS® applications.

NOTE: Palm Simulator can be run only on Macintosh computers; there is no Simulator available for developers using Windows-based computers. If you are using Windows, you can use Palm OS Emulator, which can run on Windows, Unix, and Macintosh computers. Emulator is described in [Chapter 1](#), “[Using Palm OS Emulator](#).”

This chapter covers the following topics:

- “[About Palm Simulator](#)”
- “[Feature Overview](#)” on page 162
- “[Using Palm Simulator](#)” on page 166
- “[Simulator Menu Commands Summary](#)” on page 171

About Palm Simulator

Palm Simulator simulates a Palm™ handheld device on a Macintosh computer, and lets you test and debug your Palm OS application within the simulated environment. Simulator provides a graphical representation of a Palm handheld device on the Macintosh screen, and supports user interactions that mimic actual stylus actions on a handheld device.

Feature Overview

To use Simulator, you need to build your Palm OS application with Simulator as your target, instead of the hardware device, as described in [Building a Project for Use with Simulator](#).

[Figure 3.1](#) shows the Simulator screen.

Figure 3.1 The Simulator Screen



Using Simulator is very much like using an actual device, with some differences, which are described in [Differences Between Palm Simulator and Actual Hardware](#). Use Simulator to test your application as follows:

- Click the mouse on the representation of the device's physical controls (including the silk-screened icons) to activate those controls as you would tap on controls on the actual handheld device.
- Click any of the menus, buttons, or other user interface items your application provides, just as you would tap on those items on the actual handheld device.

- Use the mouse to write Graffiti® in the Graffiti area of the simulated screen. Or you can enter characters by typing on your Macintosh keyboard.
- Use the function keys F9 through F12 to simulate the four buttons if you have made special button assignments in your application. Otherwise, these buttons are not functional.

As you interact with the simulated interface, you can trace events, run Gremlins, and use the Console window to debug your application. For more information, see [Using Palm Simulator](#).

Palm Simulator Compared to Palm OS Emulator

Palm Simulator presents a similar interface to the Palm OS Emulator, which is described in [Chapter 1, “Using Palm OS Emulator.”](#) Simulator runs your program faster than the Emulator, but Simulator has a few limitations of which you need to be aware:

- Simulator runs only on Macintosh computers.
- Simulator allows your application to make calls and perform actions that do not work on Palm handheld devices, while the Emulator does not allow these calls or actions. For more information, see the next section, [Differences Between Palm Simulator and Actual Hardware](#).

Palm Simulator does provide certain debugging advantages relative to Palm OS Emulator, as follows:

- The time to compile and then test your application is reduced when using Simulator: you simply build your application for Simulator, and double-click on the application to test it.
- Gremlins run somewhat faster on Simulator than they do with Palm OS Emulator.
- Debugging is more robust with Simulator than with Palm OS Emulator.
- Running code conditionally is easier in the Simulator than in the Palm OS Emulator.

In summary, if you are building your application on a Macintosh computer, Simulator tends to provide a faster environment for the initial debugging and testing of your application. Palm

recommends, however, that you run your application with the Palm OS Emulator before downloading it to an actual handheld device. This will help you to discover any calls your application is making that do not work with the Palm OS.

Differences Between Palm Simulator and Actual Hardware

The few differences between an application running under Palm Simulator and one running on a Palm OS device can cause difficulties during debugging. In particular, Simulator allows an application to do a few things that won't work on the device.

If your application runs under Simulator but doesn't run on the handheld device, check for the potential problems shown in [Table 3.1](#).

Table 3.1 Application Problems Due to Simulator and Palm OS Differences

Cause of problem	Explanation
Application calls standard C run-time library functions	These calls work under Simulator, but may not work on handheld devices. Memory management functions such as <code>malloc</code> and <code>free</code> , string operations such as <code>strcpy</code> and <code>strcmp</code> , mathematical functions such as <code>rand</code> and <code>cos</code> , and other library functions do not work with the Palm OS. Note that even if a standard C run-time library function does work with the Palm OS, it can unnecessarily enlarge your application.
Application writes to storage RAM without using the <code>DMWrite</code> function	The Palm OS enforces write protection, while Simulator does not. Your application will work properly with Simulator, but will generate a bus error when you run it on the handheld device.

Table 3.1 Application Problems Due to Simulator and Palm OS Differences (*continued*)

Cause of problem	Explanation
Application accesses 16-bit or 32-bit memory values at odd addresses	<p>Simulator allows these memory accesses, which generate bus errors on the handheld device.</p> <p>You often encounter this error when working with packed data.</p>
Application attempts a code jump of more than 32K bytes	The Palm OS does not allow jumps that exceed 32K bytes. You need to rearrange your code to avoid such jumps.
Application writes records that are larger than 64K bytes	Simulator allows records that are larger than 64K bytes long, but the Palm OS does not allow these records, which prevent HotSync from working properly.
Application overflows the stack	<p>Palm OS handheld devices provide a stack that is only 2K bytes long, while Simulator runs in an environment that allows for a much larger stack.</p> <p>This problem commonly arises when your application uses a large amount of local data. You can work around this limitation by storing your data in global variables or allocated database chunks instead of using local storage.</p>
Application pointer errors	Pointer errors tend to have a more dramatic effect on Palm handheld devices than on Simulator because of the greater density of data in memory on the device. Bad pointer values, array overwrites, and related problems are more likely to destroy important data on the Palm handheld device than on the Macintosh computer.
Launch code problems	<p>When the handheld device is reset, it sends certain launch codes to applications. The main body of your PilotMain function should be enveloped in the following conditional code:</p> <pre>if (cmd == launchcode)</pre>

Using Palm Simulator

Using Palm Simulator

In addition, the user interface to Simulator differs from the user interface on Palm handheld devices, as shown in [Table 3.2](#).

Table 3.2 User interface differences

Difference	Description
Multiple applications unavailable with Simulator	The user can switch which application is running on a Palm handheld device by selecting a new application from the Applications menu, or by pressing one of the hardware buttons at the bottom of the device. Simulator runs only the application that you have built for the Simulator target.
Application buttons	The simulated buttons at the bottom of the Simulator display are only available if your application has made special assignments to them. These four buttons are simulated by the F9, F10, F11, and F12 keys on the Macintosh keyboard.
Scrolling buttons	The scroll up and scroll down buttons are simulated by the PAGE UP and PAGE DOWN keys on the Macintosh keyboard.

Using Palm Simulator

This section describes how to perform various tasks with Simulator, including:

- building a project for use with Simulator
- tracing events
- scripting events for replay
- using gremlins
- testing communications
- saving memory images to file


Building a Project for Use with Simulator

To use Simulator, you need to build your Palm OS application in CodeWarrior with Simulator libraries as your target, rather than

targeting the Palm OS. When you activate the resulting executable, Simulator starts up with your application loaded.

[Figure 3.2](#) shows selecting the Simulator target for the Starter project.

Figure 3.2 Choosing Simulator as a Target



Most of the example projects provided with the Palm OS SDK have two targets: one that builds a Palm OS executable with a PRC suffix, and one that builds an executable with a MAC suffix that runs with Simulator. When you select your target in CodeWarrior, the Simulator target version ends with Sim. [Table 3.3](#) shows several examples.

Using Palm Simulator

Using Palm Simulator

Table 3.3 Example project target names

Project File	Target name	Executable name
Datebook.mcp	Datebook	Datebook.prc
	DatebookSim	Datebook.mac
Address.mcp	Address	Address.prc
	AddressSim	Address.mac
Starter.mcp	Starter	Starter.prc
	StarterSim	Starter.mac

Using Simulator with CodeWarrior Debugger

If you want to set breakpoints or single-step through your applications' code, you can run Palm Simulator from within the CodeWarrior Debugger. To do so, follow these steps:

1. Select **Enable Debugging** in the Project menu of the CodeWarrior IDE.
2. Build your project with the Simulator target. The resulting executable has the Macintosh SYM extension.
3. Double-click the executable to start the CodeWarrior Debugger.


Tracing Events

To trace the events that your application generates, select **Event Trace** from the Window menu. This displays the event tracing window until you once again select **Event Trace** to close the window.

The event trace shown in [Figure 3.3](#) is the result of the following sequence of activities while running the Simulator version of the To Do list application:

1. Click **New** to create a new To Do item.
2. Type `Hello, Mr. Soul` on the keyboard
3. Click the **Details...** button to view the item details.

Figure 3.3 The event trace window



You can use the event tracing facility of Simulator to verify that your application is properly receiving and processing key and pen events.

Scripting Pen and Key Events

Simulator lets you record user input events and save them in a script file for subsequent replay. You can replay the events in rapid order, or in realtime speed, which lets you watch the processing of each event.

While recording the script, you can insert breaks, each of which causes the script to stop during replay.

To record a script, follow these steps:

1. Select **Replay > Record**. This begins the event recording
2. Record pen and key events.
3. Deselect **Replay > Record**.
4. Select **Replay>Save As** to save the recorded script to a file.

Using Palm Simulator

Using Palm Simulator

To playback a recorded script, follow these steps:

1. Select **Replay > Playback**. This displays the Open File dialog box, which lets you select a script to replay. The most recently saved script is always displayed as the default selection.
2. Select **Replay>Realtime** to play the script at the same speed at which it was recorded, or deselect **Replay>Realtime** to play the script rapidly.
3. Choose **Replay >Pause** and **Replay >Step** during replay to look in detail at the events that are executed.

Using Gremlins

Simulator lets you run a single gremlin, which is the gremlin numbered 0. To define and run other gremlins, you need to activate the Console window, and then run gremlins from that window. Gremlins are described in more detail in both [Chapter 7, “Using the Console Window.”](#) and [Chapter 4, “Using Palm Debugger.”](#)

To run gremlin 0 in Simulator, follow these steps:

1. Select **Gremlin>New** to run gremlin 0. This command iterates through all of the events in the gremlin and runs continuously until stopped.
2. Select **Gremlin>Step** to perform the next gremlin event and then pause.
3. Select **Gremlin>Resume** to resume continuous execution of the gremlin events.
4. Select **Gremlin>Stop** to stop generating gremlin events.

Saving Memory Information to File

You can save the contents of the simulated built-in RAM by selecting **File>Save Card 0...**, which displays the standard Save dialog box and then saves the contents of RAM to a file. If the simulated device also has an extra memory card, you can use **File>Save Card 1...** to save the contents of that card to file.

If you select **File>Save Before Quitting**, Simulator will automatically save the contents of the built-in RAM and of memory

card 1 (if simulated) to file. The files are named Pilot Card 0 and Pilot Card 1, respectively.

Simulator Menu Commands Summary

This section describes the Simulator menus in the same order as they appear on the Macintosh menu bar:

- [File Menu](#)
- [Edit Menu](#)
- [Window Menu](#)
- [Replay Menu](#)
- [Gremlin Menu](#)
- [Serial Port Menu](#)
- [Panel Menu](#)

File Menu

[Table 3.4](#) describes the commands available on the File menu.

Table 3.4 File menu commands

Command	Description
Save Card 0...	Writes the contents of memory card 0 to a file. This command uses the standard Save dialog box to prompt you for the file name and location. The default name is PilotCard 0, and the default location is the current application folder. Card 0 is the Palm built-in RAM, on which all applications and add-on applications are stored.
Save Card 1...	Writes the contents of memory card 1 to a file.

Using Palm Simulator

Simulator Menu Commands Summary

Table 3.4 File menu commands (*continued*)

Command	Description
Save Before Quitting	Saves a snapshot of the contents of both memory cards after <code>StopApplication</code> has been called. When an application exits, it saves information such as its preferences to the memory card. If you use this command, Simulator saves the files <code>Pilot Card 0</code> and <code>Pilot Card 1</code> .
Quit	Quits the application.

Edit Menu

The Edit menu offers the standard Mac OS editing commands for the Console window and the Event Trace window.

Window Menu

The Window menu provides access to two special windows: the Console window and the Event Trace window. You can close either of these windows by clicking the button in the top-left corner or by deselecting the window in the menu. [Table 3.5](#) describes the Window menu commands.

Table 3.5 Window menu commands

Command	Description
Console	Activates the Console window, which is described in Chapter 7, “Using the Console Window.”
Event Trace	Displays the Event Trace window. The Event Trace window displays the last 100 events generated by the system software and application. For more information, see Tracing Events .

Replay Menu

The Replay menu lets you record pen and key events to a script file. You can then use the script file to replay the same events. This is useful for testing and repeating problem cases. For more

information about using the Replay menu commands, see [“Scripting Pen and Key Events”](#) on page 169.

[Table 3.6](#) describes the commands available on the Replay menu.

Table 3.6 Replay menu commands

Command	Description
Record	Begins recording pen and key events to a file. To stop recording, deselect this command.
Break	Inserts a stop into the script so it stops during replay. Does not stop the recording process.
Save As	Saves the recorded script to file. By default, Simulator saves a script to a file with the extension LOG whenever you stop recording. Use the Save As command to create an additional copy of that script file. The default file name is “Pilot Script.”
Playback	Plays back a previously recorded script that you select with the standard Open dialog box.
Pause	Pauses playback of a script. This command is available during playback, but not during the recording process.
Step	Plays back the next pen or key event, then pauses. This command is available during playback, but not during the recording process.
Realtime	Tries to execute the script at the rate at which it was recorded. With this option off, scripts execute as fast as possible. Realtime is useful when you need to test user interface elements that are timing dependent, such as repeating buttons.

Gremlin Menu

Gremlins are a facility to generate pseudo-random pen and key events. You can use Gremlins to reveal program problems. Each Gremlin is a unique sequence of random taps, strokes, and so on. Red lines indicate how the pen was moved over the screen by the Gremlin.

Although you can define a large number of gremlins, the Gremlin menu of Simulator only lets you run gremlin number 0. To run other gremlins, you need to activate the Console window and use its

Using Palm Simulator

Simulator Menu Commands Summary

Gremlin command, as described in [Gremlin](#) in [Chapter 7](#), “[Using the Console Window](#).”

[Table 3.7](#) describes the commands available on the Gremlins menu.

Table 3.7 Gremlins menu commands

Command	Description
New	Runs Gremlin number 0. Iterates through all events in that Gremlin, running continuously.
Step	Performs the next Gremlin event, then stops.
Resume	Resumes running continuously after a step or stop.
Stop	Stops generating Gremlin events.

Serial Port Menu

The Serial Port menu lets you select a Mac OS port to use when your application connects to another application with the serial port.

[Table 3.8](#) shows the choices available on the Serial Port menu.

Table 3.8 Serial port menu commands

Command	Description
Modem Port	Selects the Mac OS Modem port.
Printer Port	Selects the Mac OS Printer port.

Panel Menu

The Panel menu lets you set modem and network preferences so that you can test applications that use TCP/IP. [Table 3.9](#) shows the commands available on the Panel menu.

This menu is disabled unless your application’s directory contains the files `Modem.prc` and `Network.prc`, which you can copy from the `PalmOS Libraries` folder. The Panel menu is also disabled if one of the panels is already running.

Table 3.9 Panel menu commands

Command	Description
Modem Panel	<p>Displays the Modem panel from the Preferences application. Use this panel to enter the settings for the modem connected to your Macintosh computer.</p> <p>The Modem selection list only displays modems compatible with the Palm device, so it may not have a selection for your computer's modem. If this is the case, choose the Standard selection. You may need to change the initialization string.</p>
Network Panel	<p>Displays the Network panel from the Preferences application. Use this panel to enter network settings and to connect to the network.</p>



Part II: Debugging Your Application

Using Palm Debugger

Palm Debugger is a tool for debugging Palm OS® applications. Palm Debugger is available for use on both Mac OS and Windows 95/98/NT platforms.

This chapter provides an introduction to and overview of using Palm Debugger. The commands that you can use are described in [Chapter 5, “Palm Debugger Command Reference.”](#)

This chapter contains the following sections:

- [“About Palm Debugger”](#) on page 180 provides a broad overview of the program and a description of its windows.
- [“Connecting to The Handheld Device”](#) on page 182 describes how to connect Palm Debugger with the Palm OS Emulator or with a Palm Powered™ handheld device.
- [“Using the Console and Debugging Windows Together”](#) on page 186 describes how to use the menus and keyboard to send commands to the handheld device from the debugging and console windows.
- [“Using the Debugging Window”](#) on page 192 and [“Using the Source Window”](#) on page 209 describe the command and display capabilities available in each of these windows. The debugging window section also includes a full description of [“Using Debugger Expressions”](#) on page 194.
- [“Palm Debugger Error Messages”](#) on page 214 describes how to decode the error messages you receive from Palm Debugger.
- [“Palm Debugger Tips and Examples”](#) on page 215 provides a collection of tips to make your debugging efforts easier and examples of performing common debugging tasks.

About Palm Debugger

Palm Debugger provides source and assembly level debugging of Palm OS executables, and includes the following capabilities:

- support for managing Palm OS databases
- communication with Palm™ handheld devices
- communication with Palm OS Emulator, the Palm emulation program
- command line interface for system administration on Palm handheld devices

NOTE: You can use Palm Debugger with a Palm Powered handheld device, or with the Palm OS Emulator program. Debugging is the same whether you are sending commands to the emulator or to actual hardware. Connecting with either a handheld device or the Emulator is described in [“Connecting Palm Debugger With a Target”](#) on page 182.

Palm Debugger provides two different interfaces that you can use to send commands from your desktop computer to the handheld device:

- The console interface is provided by the *console nub* on the handheld device. You can connect to the console nub and then send console commands to the nub from Palm Debugger’s console window. The console commands are used primarily for administration of databases on the handheld device.

The console can also be used with Palm Simulator and the CodeWarrior Debugger, and is documented in a separate chapter. For more information about the console window and the console commands, see [Chapter 7, “Using the Console Window.”](#)

- The debugging interface is provided by the *debugger nub* on the handheld device. You can attach to the debugger nub and then send debugging commands to the debugger nub from Palm Debugger’s debugging window. For more information about using the debugging window and the debugging

commands, see [“Using the Debugging Window”](#) on page 192.

The console window and the debugging window each has its own set of commands that you can use to interface with the handheld device. The debugging commands are described in [Chapter 5](#), [“Palm Debugger Command Reference,”](#) and the console window commands are described in [Chapter 7](#), [“Using the Console Window.”](#)

NOTE: The Palm OS Emulator emulates the console and debugging nubs, which allows Palm Debugger to send the same commands to the Emulator as it does to a handheld device.

On certain platforms, Palm Debugger also provides a multi-pane source window for source-level debugging. You can use this window if you have compiled your program with certain compilers that generate an appropriate symbol file. [Table 4.1](#) summarizes the Palm Debugger windows.

Table 4.1 Palm Debugger Windows

Window name	Usage
Console	Command language shell for performing administrative tasks, including database management, on the handheld device.
CPU Registers	Assembly language debugging output only window.
Debugging	Assembly language debugging command window.
Source	Source level debugging window.

NOTE: Source level debugging is not currently available in the Macintosh version of palm Debugger.

Connecting Palm Debugger With a Target

You can use Palm Debugger to debug programs running on a Palm Powered handheld device or to debug programs running on a hardware emulator such as the Palm OS Emulator. This section describes how to connect the debugger to each of these targets.

Connecting to The Palm OS Emulator

You can interact with the Palm OS Emulator from Palm Debugger just as you do with actual hardware. With the emulator, you don't need to activate the console or debugger stubs. All you need to do is follow these steps:

1. In the Palm Debugger Communications menu, select **Emulator**. This establishes the emulator program as the "device" with which Palm Debugger is communicating.
2. In the debugging window, type the `att` command.

Connecting to The Handheld Device

You can interact with the handheld device from Palm Debugger by issuing commands from the console window or from the debugging window.

You must activate the console nub on the handheld device before sending commands from the console window. For more information on activating console input, see [Chapter 7, "Using the Console Window."](#)

WARNING! When you activate either the console nub or the debugger nub on the handheld device, the device's serial port is opened. This causes a rapid and significant power drain. The only way to close the port and stop the power drain is to perform a soft reset.

Activating Debugging Input

If you are debugging with the Palm OS Emulator, you can activate debugging input by sending the `att` command from the debugging window to the emulator.

To send debugging commands to a hardware device, you must connect your desktop computer to the handheld device, halt the device in its debugger nub, and then type commands into the debugging window of Palm Debugger.

IMPORTANT: When the handheld device is halted in its debugger nub, a tiny square flashes in the upper left corner of the screen, and the device does not respond to pen taps or key presses.

You can use the following methods to halt the handheld in its debugger nub:

1. Use the Graffiti Shortcut-1 to enter debugger mode on the handheld device, as described in “[Using Shortcut Numbers to Activate the Windows](#)” on page 184.
2. If you have already activated the console nub, you can use the **Break** command in the Source menu to activate the debugger nub. The **Break** command sends a key command to the handheld device that is identical to using the Graffiti Shortcut-1 sequence.
3. Compile a `DbgBreak()` call into your application, and run the application until you encounter that call.

This method only works if you have already entered debugger mode once, or if you have set the low memory global variable `GDbgWasEntered` to a non-zero value, which tricks the handheld into thinking that the debugger was previously entered. For example, you can use the following code in your application to ensure that your break works:

```
GDbgWasEntered = true;
DbgBreak();
```

4. You can hold the down button and press the reset button in the back of the device.

This halts the device in the *SmallROM* debugger, which is the bootstrap code that can initialize the hardware and start the debugger nub. Enter the `g` command, and the system jumps

Using Palm Debugger

Connecting Palm Debugger With a Target

into the *BigROM*, which contains the same code as the *SmallROM* and all of the system code.

If you press the down button on the handheld device while executing the `g` command, you land in the *BigROM*'s debugger. This lets you set A-trap breaks or single step through the device boot sequence.

Verifying Your Connection

If Palm Debugger is running and connected when the handheld device halts into its debugger nub, the debugging window displays a message similar to the following:

```
EXCEPTION ID = $A0
'SysHandleEvent '
+$0512 10C0EEFE *MOVEQ.L    #$01,D0 | 7001
```

Alternatively, if Palm Debugger is not connected or running when the device halts, you can use the `att` command to attach Palm Debugger to the device.

IMPORTANT: The debugger nub activates at 57,600 baud, and your port configuration must match this if you are connecting over a serial port. You can set the connection parameters correctly with Palm Debugger Connection menu.

After you activate the debugger nub on the handheld device, the nub prevents other applications, including HotSync® from using the serial port. You have to soft-reset the handheld device before the port can be used.

Using Shortcut Numbers to Activate the Windows

The Palm OS responds to a number of “hidden” shortcuts for debugging your programs, including shortcuts for activating the console and debugger nubs on the handheld device. You generate each of these shortcuts by drawing characters on your Palm Powered device, or by drawing them in the Palm OS Emulator program, if you are using Palm OS Emulator to debug your program.

NOTE: If you open the Find dialog box on the handheld device before entering a shortcut number, you get visual feedback as you draw the strokes.

To enter a shortcut number, follow these steps:

1. On your Palm Powered device, or in the emulator program, draw the shortcut symbol. This is a lowercase, cursive “L” character, drawn as follows:



2. Next, tap the stylus twice, to generate a dot (a period).
3. Next, draw a number character in the number entry portion of the device’s text entry area. [Table 4.2](#) shows the different shortcut numbers that you can use.




For example, to activate the console nub on the handheld device, enter the follow sequence:



Using Palm Debugger

Connecting Palm Debugger With a Target

Table 4.2 Shortcut Numbers for Debugging

Shortcut	Description	Notes
	The device enters debugger mode, and waits for a low-level debugger to connect. A flashing square appears in the top left corner of the device.	This mode opens a serial port, which drains power over time. You must perform a soft reset or use the debugger's reset command to exit this mode.
 .2	The device enters console mode, and waits for communication, typically from a high-level debugger.	This mode opens a serial port, which drains power over time. You must perform a soft reset to exit this mode.
 .3	The device's automatic power-off feature is disabled.	You can still use the device's power button to power it on and off. Note that your batteries can drain quickly with automatic power-off disabled. You must perform a soft reset to exit this mode.

NOTE: These debugging shortcuts leave the device in a mode that requires a soft reset. To perform a soft reset, press the reset button on the back of the handheld with a blunt instrument, such as a paper clip.

Using the Console and Debugging Windows Together

When Palm Debugger is attached to a handheld device or emulator program, you cannot talk to the console nub on the device. However, a subset of the console commands — those that do not

change the contents of memory— are available from the debugging window. These include the following commands:

- `dir`
- `hl`
- `hd`
- `hchk`
- `mdebug`
- `reset`

You can enter these commands in either the debugging window or the console window when the debugger nub is active. When you enter a console command while the debugging window is attached, the command is sent to the debugger nub rather than the console nub.

You can use the console commands while debugging for purposes such as displaying a heap dump in the console window while stepping through code in the debugging window.

Entering Palm Debugger Commands

Most of your work with Palm Debugger is done with the keyboard. You enter console commands into the console window, and debugging commands into the debugging window. Both of these windows supports standard scrolling and clipboard operations.

[Table 4.3](#) summarizes the keyboard commands that you can use to enter commands in Palm Debugger's console or debugging windows.

Using Palm Debugger

Entering Palm Debugger Commands

Table 4.3 Entering Palm Debugger Commands From the Keyboard

Command description	Windows key(s)	Macintosh key(s)
Execute selected text as command(s). You can select multiple lines to sequentially execute multiple commands.	Enter	Enter on numeric keypad, or Cmd+Return
Execute the current line (no text selected).		
Display help for a command	Help <cmdName>	Help <cmdName>
Enter a new line without executing the text	Shift+Enter	Return
Copy selected text from window to clipboard	Ctrl+C	Cmd+C
Paste clipboard contents to window	Ctrl+V	Cmd+V
Cut selected text from window to clipboard	Ctrl+X	Cmd+X
Delete previous command's output from the window	Ctrl+Z	Not available
Delete all text to the end	Shift+Backspace	Cmd+Delete

Palm Debugger Menus

Palm Debugger includes five menus, as summarized in [Table 4.4](#). The most commonly used menu commands are on the Connection and Source menus; these commands are described in other sections in this chapter.

Table 4.4 Palm Debugger Menu Commands

Menu	Commands	Descriptions
File	<u>O</u> pen	Commands for saving and printing the contents of a window.
	<u>S</u> ave	
	<u>S</u> ave <u>A</u> s	
	<u>P</u> age Setup...	
	<u>P</u> rint	
	<u>E</u> xit	
Edit	<u>U</u> ndo	Standard editing commands
	<u>R</u> edo	
	<u>C</u> ut	
	<u>C</u> opy	
	<u>P</u> aste	
	<u>S</u> elect <u>A</u> ll	
	<u>F</u> ind	
	<u>F</u> ind <u>N</u> ext	
Connection	<u>F</u> ont	For setting up how to communicate with the handheld device or Palm OS Emulator.
	(select baud rate)	
	<u>H</u> andshake	
	(select connection port)	

Using Palm Debugger

Entering Palm Debugger Commands

Table 4.4 Palm Debugger Menu Commands (*continued*)

Menu	Commands	Descriptions
Source	Break	Source code debugging commands, for use in conjunction with the source window.
	Step Into	
	Step Over	
	Go	
	Go Till	
	Toggle Breakpoint	NOTE: Source level debugging is not currently available in the Macintosh version of Palm Debugger.
	Disassemble at Cursor	
	Show Current Location	
	Install Database and Load Symbols	
	Load Symbols	
	Load Symbols for Current Program Counter	
	Remove All Symbols	
Window	Cascade	Standard window access commands.
	Tile	
	Arrange Icons	NOTE: Only available on Windows systems.
	Close <u>A</u>ll	
	Keyboard Simulator...	
	(select numbered window)	

Palm Debugger Command Syntax

Palm Debugger's help facility uses simple syntax to specify the format of the commands that you can type in the console and debugging windows. This same syntax is used in [Chapter 5, "Palm Debugger Command Reference."](#) This section summarizes that syntax.

The basic format of a command is specified as follows:

commandName <parameter>* [options]

commandName The name of the command.

parameter	Parameter(s) for the command. Each parameter name is enclosed in angle brackets (< and >). Sometimes a parameter can be one value or another. In this case the parameter names are bracketed by parentheses and separated by the character.
options	Optional flags that you can specify with the command. Note that options are specified with the dash (-) character in the console window and with the backslash (\) character in the debugging window.

NOTE: Any portion of a command that is shown enclosed in square brackets (“[“ and “]”) is optional.

The following is an example of a command definition

```
dir (<cardNum>|<srchOptions>) [displayOptions]
```

The `dir` command takes either a card number or a search specification, followed by display options.

Here are two examples of the `dir` command sent from the console window:

```
dir 0 -a
dir -t rsrc
```

And here are the same two commands sent from the debugging window:

```
dir 0 \a
dir \t rsrc
```

Specifying Command Options

All command options and some command parameters are specified as flags that begin with a dash (in the console window) or backslash (in the debugging window). For example:

```
-c
-enable
```

`\enable`

Some flags are followed by a keyword or value. You must leave white space between the flag and the value. For example:

```
-f D:\temp\myLogFile
\t Rsrc
```

Specifying Numeric and Address Values

Many of the debugging commands take address or numeric arguments. You can specify these values in hexadecimal, decimal, or binary. All values are assumed to be hexadecimal unless preceded by a sign that specifies decimal (#) or binary (%). [Table 4.5](#) shows values specified as binary, decimal, and hexadecimal in a debugging command:

Table 4.5 Specifying Numeric Values in Palm Debugger

Hex value	Decimal value	Binary value
64 or \$64	#100	%01100100
F5 or \$F5	#245	%11110101
100 or \$100	#256	%100000000

IMPORTANT: Some register names, like A0 and D4, look like hexadecimal values. You must preface these values with the \$ sign, or you will get the value of the register. For example, A4 + 3 computes to the value of the A4 register added with three, but \$A4 + 3 computes to \$A7.

For more information, see “[Specifying Constants](#)” on page 195.

Using the Debugging Window

You use the debugging window to enter debugging commands, which are used to perform assembly language debugging of executables on the handheld device. Commands that you type into the debugging window are sent to the debugger nub on the

handheld device, and the results sent back from the device are displayed in the debugging window.

The debugging window provides numerous capabilities, including the following:

- A rich expression language for specifying command arguments, as described in “[Using Debugger Expressions](#)” on page 194.
- Ability to debug applications, system code, extensions, shared libraries, background threads, and interrupt handlers.
- Custom aliases for commands or groups of commands, as described in “[Defining Aliases](#)” on page 209.
- Script files for saving and reusing complex sequences of commands, as described in “[Using Script Files](#)” on page 209.
- Templates for defining data structure layouts in memory, which allow you to view a structure with the memory display commands. Templates are described in “[Defining Structure Templates](#)” on page 207.
- Your aliases and templates can be saved in files that are automatically loaded for you when Palm Debugger starts execution, as described in “[Automatic Loading of Definitions](#)” on page 209.

This section also provides examples of using some of the more common debugging commands:

- See “[Displaying Registers and Memory](#)” on page 201 for examples of using the debugging commands to display the current register values.
- See “[Using the Flow Control Commands](#)” on page 203 for examples of using commands to set breakpoints.
- See “[Using the Heap and Database Commands](#)” on page 206 for examples of using commands to examine the heap and databases.

The remainder of this section describes how to use these capabilities. [Table 4.6](#) shows the most debugging window command categories.

Table 4.6 Debugging Window Command Categories

Category	Description	Commands
Console	Commands shared with the console window for viewing card, database, and heap information.	cardinfo, dir, hchck, hd, hl, ht, info, opened, storeinfo
Flow Control	Commands for working with breakpoints, A-traps, and program execution control.	atb, atc, atd, br, brc, cl, brd, dx, g, gt, s, t, reset
Memory	Commands for viewing the registers, and for displaying and setting memory, the stack, and system function information.	atr, db, dl, dm, dw, fb, fill, fl, ft, fw, il, reg, sb, sc, sc6, sc7, sl, sw, wh
Miscellaneous	Commands for displaying debugging help and current debugging environment information.	att, help, penv
Template	Commands for defining and reviewing structure templates.	>, sizeof, typedef, typeend
Utility	Commands for working with aliases, symbol files, and variables.	alias, aliases, bootstrap, keywords, load, run, save, sym, templates, var, variables

All of the debugging commands are described in detail in [Chapter 5, “Palm Debugger Command Reference.”](#)

Before you can use the debugging commands, you must attach Palm Debugger to the debugger nub on the handheld device, as described in [“Activating Debugging Input”](#) on page 182.

Using Debugger Expressions

Palm Debugger provides a rich expression language that you can use when specifying arguments to the debugging commands. This section describes the expression language.

NOTE: Debugger expressions cannot contain white space. White space delimits command parameters; thus, any white space ends an expression.

Specifying Constants

The expression language lets you specify numbers as character constants.

Character Constants

A character is a string enclosed in single quotes. The string can include escape sequences similar to those used in the C language. For example:

```
'xyz1 '  
'a\ 'Y\ ' '  
'\123 '
```

Character constants are interpreted as unsigned integer values. The size of the resulting value depends on the number of characters in the string, as follows:

Number of characters	Result type
1 character	UInt8
2 characters	UInt16
more than 2 characters	UInt32

Binary Numbers

To specify a binary number, use the % character followed by any number of binary digits. For example:

```
%00111000  
%1010
```

The size of the resulting value is determined as follows:

Using Palm Debugger

Using the Debugging Window

Number of Digits	Result Type
1 to 8	UInt8
8 to 16	UInt16
more than 16	UInt32

Decimal Numbers

To specify a decimal number, use the # character followed by any number of decimal digits. For example:

```
#256
#32756
```

Hexadecimal Numbers

Palm Debugger interprets hexadecimal digit strings that are not preceded by a special character as hexadecimal numbers. You can optionally use the \$ character to indicate that a value is hexadecimal. For example:

```
c123
C123
F0
$A0
```

The size of the resulting value is determined as follows:

Number of digits	Result type
1 to 2	UInt8
3 to 4	UInt16
more than 4	UInt32

WARNING! If you want to specify a hexadecimal value that can also be interpreted as a register name, you must preface the value with the \$ symbol. For example, using `A0` in an expression will generate the current value of the `A0` register, while using `$A0` will generate the hexadecimal equivalent of the decimal value 160.

Using Operators

Palm Debugger expression language includes the typical set of binary and unary operators, as summarized in [Table 4.7](#).

Table 4.7 Palm Debugger Expression Language Operators

Type	Operator	Description	Example
Cast	.a	Casts the value to an address.	0ff0.a
	.b	Casts the value to a byte.	45.b
	.l	Casts the value to a double word.	45.l
	.w	Casts the value to a word.	45.w
	.s	Extends the sign of its operand without changing the operand's size.	45.s
Unary	~	Performs a bitwise NOT of the operand.	~1
	-	Changes the sign of the operand.	2*-1
Dereference	@	Dereferences an address or integer value. See Table 4.8 for more examples.	@A7
Arithmetic	*	Multiplies the two operands together.	A1*2
	/	Divides the first operand by the second operand.	21/3
	+	Adds the two operands together.	A2+2
	-	Subtracts the second operand from the first operand.	A2-2

Table 4.7 Palm Debugger Expression Language Operators

Type	Operator	Description	Example
Assignment	=	Assigns the second operand value to the register specified as the first operand.	d0=45
Bitwise	&	Performs a bitwise AND operation.	A7&FFF
	^	Performs a bitwise XOR operation.	A2^F0F0
		Performs a bitwise OR operation.	A2 %1011

The Dereference Operator

The @ dereference operator is similar to the * dereference operator used in the C programming language. This operators dereferences an address value, as shown in [Table 4.8](#).

Table 4.8 Dereference Operator Examples

Expression	Description	Example
@	Retrieves 4 bytes as an unsigned integer value	@A7
@.a	Retrieves 4 bytes as an address	@.a (A1)
@.b	Retrieves 1 byte as an unsigned integer value	@.b (PC)
@.w	Retrieves 2 bytes as an unsigned integer value	@.w (PC)
@.l	Retrieves 4 bytes as an unsigned integer value	@.l (A2)

Register Variables

The expression language provides named variables for each register. The names of these variables are replaced by their respective register values in any expression. [Table 4.9](#) shows the register name variables.

Table 4.9 The Built-in Register Variables

Variable name	Description
a0	address register 0
a1	address register 1
a2	address register 2
a3	address register 3
a4	address register 4
a5	address register 5
a6	address register 6
a7	address register 7
d0	data register 0
d1	data register 1
d2	data register 2
d3	data register 3
d4	data register 4
d5	data register 5
d6	data register 6
d7	data register 7
pc	the program counter
sr	the status register
sp	the stack pointer (this is an alias for a7)

NOTE: The expression parser interprets any string that can represent a register name as a register name. If you want the string interpreted as a hexadecimal value instead, precede it with either a 0 or the \$ character.

For example, the following expression:

a0+d0

Adds the values stored in the a0 and d0 registers together.

If you want to add the value 0xd0 to the value stored in register a0, use one of the following expressions:

a0+0d0

a0+\$d0

Special Shortcut Characters

Palm Debugger's expression language includes the two special value characters shown in [Table 4.10](#). These characters are converted into values in any expression.

Table 4.10 Special Value Expression Characters

Character	Converts into	Examples
.	The most recently entered address.	dm . dm .+10
:	The starting address of the current routine.	il : il :+24

Performing Basic Debugging Tasks

This section describes how to use Palm Debugger to perform three of the most common debugging tasks:

- displaying memory values
- setting breakpoints and using the flow control commands
- examining the heap

The final section of this chapter, “[Palm Debugger Tips and Examples](#)” on page 215, provides examples of how to perform other debugging tasks.

Assigning Values to Registers

You can use the assignment operator (=) to assign a value to a register. However, if you include white space around the operator, the assignment does not work. For example, the following statement correctly assigns a value to the program counter:

```
pc=010c8954
```

However, this statement does not assign the correct value to the program counter:

```
pc = 010c8954c
```

Displaying Registers and Memory

One of the primary operations you perform with a debugger is to examine and change values in memory. Palm Debugger provides a number of commands for displaying registers, memory locations, the program counter, and the stack. [Table 4.11](#) summarizes the commands you commonly use to examine memory and related values.

Table 4.11 Frequently Used Memory Commands

Command	Description
db	Displays the byte value at a specified address.
d1	Displays the 32-bit long value at a specified address.
dm	Displays memory for a specified number of bytes or templates.
dw	Displays the 16-bit word value at a specified address.
il	Disassembles code in a specified line range or for a specified function name.
reg	Displays all registers.
sb	Sets the value of the byte at the specified address.

Table 4.11 Frequently Used Memory Commands (*continued*)

Command	Description
<code>sc</code>	Lists the A6 stack frame chain, starting at the specified address.
<code>sc7</code>	Lists the A7 stack frame chain, starting at the specified address.
<code>sl</code>	Sets the value of the 32-bit long value at the specified address.
<code>sw</code>	Sets the value of the word at the specified address.

Palm Debugger also lets you define structure templates and use those for displaying memory values. For example, you can define a structure that matches the layout of a complex data structure, and then display that structure with a single `dm` command. For more information about structure templates, see [“Defining Structure Templates”](#) on page 207.

[Listing 4.1](#) shows an example of displaying memory with the `dm` command and disassembling memory with the `il` command. It also provides several examples of using expressions with these commands. In this example, **boldface** is used to denote commands that you type, and `<=` starts a comment.

Listing 4.1 Displaying and Disassembling Memory

```
dm 0                                <=Display memory at address 0
00000000: FF FF FF FF 1A 34 3E 40 10 C0 92 D4 10 C0 92 F2 ".....4>@....."

dm 100                              <=Display memory at address 0x100
00000100: 01 01 00 00 02 B0 00 01 78 30 00 00 00 01 47 EE ".....x0....G."

dm #100                             <=Display memory at address 100 decimal
00000064: 10 C6 BE 32 10 C6 BE 60 10 C6 BE 8E 10 C6 BE BC "...2...`....."

dm 100+20                           <=Specify an address with an expression
00000120: 6F BC 00 00 07 22 00 00 00 06 00 01 7D 72 00 FD "o...."}r.."

dm .+10                             <=Use the'.' character for the most recent addr
00000130: 00 00 00 00 00 00 00 B6 3E C0 69 45 A4 0C 03 4A ".....>.iE...J"
```

```
dm pc                                <=Use the current program counter value
10C0EEFE: 70 01 60 00 01 7E 4E 4F A0 BE 70 01 60 00 01 74 "p.`...~NO..p.`..t"

dm pc+20                             <=An expression using the program counter
10C0EF1E: FF F4 4E 4F A0 AC 38 00 4A 44 50 4F 66 2A 48 6E "..NO..8.JDPof*Hn"

il pc                                <=Disassemble code at current program counter
'SysHandleEvent 10C0E9EC'
+$0512 10C0EEFE *MOVEQ.L #$01,D0 | 7001
+$0514 10C0EF00 BRA.W SysHandleEvent+$0694 ; 10C0F080 | 6000 017E
+$0518 10C0EF04 _SysLaunchConsole ; $10C0E30C | 4E4F A0BE
+$051C 10C0EF08 MOVEQ.L #$01,D0 | 7001
+$051E 10C0EF0A BRA.W SysHandleEvent+$0694 ; 10C0F080 | 6000 0174
+$0522 10C0EF0E MOVEQ.L #$00,D0 | 7000
+$0524 10C0EF10 BRA.W SysHandleEvent+$0694 ; 10C0F080 | 6000 016E
+$0528 10C0EF14 CLR.L -$0010(A6) | 42AE FFF0
+$052C 10C0EF18 PEA -$0006(A6) | 486E FFFA
+$0530 10C0EF1C PEA -$000C(A6) | 486E FFF4

il pc-10                             <=Display code at program counter - 0x10
'SysHandleEvent 10C0E9EC'
+$0502 10C0EEEE ORI.B #$01,(A5)+ ; '.' | 001D 7001
+$0506 10C0EEF2 BRA.W SysHandleEvent+$0694 ; 10C0F080 | 6000 018C
+$050A 10C0EEF6 MOVE.B #$01,$00000101 ; '.' | 11FC 0001 0101
+$0510 10C0EEFC _DbgBreak | 4E48
+$0512 10C0EEFE *MOVEQ.L #$01,D0 | 7001
+$0514 10C0EF00 BRA.W SysHandleEvent+$0694 ; 10C0F080 | 6000 017E
+$0518 10C0EF04 _SysLaunchConsole ; $10C0E30C | 4E4F A0BE
+$051C 10C0EF08 MOVEQ.L #$01,D0 | 7001
+$051E 10C0EF0A BRA.W SysHandleEvent+$0694 ; 10C0F080 | 6000 0174
+$0522 10C0EF0E MOVEQ.L #$00,D0 | 7000
```

All of the commands mentioned in this section are described in detail in [Chapter 5, “Palm Debugger Command Reference.”](#)

Using the Flow Control Commands

Palm Debugger provides a number of commands for setting breakpoints and continuing the flow of execution. [Table 4.12](#) summarizes the commands you commonly use for these purposes.

Table 4.12 Commonly Used Flow Control Commands

Command	Description
atb	Adds an A-trap break.
atc	Clears an A-trap break.
atd	Displays all A-trap breaks.
br	Sets a breakpoint.
brc	Clears a breakpoint. This is the same as the cl command.
brd	Display all breakpoints.
cl	Clears a breakpoint. This is the same as the brc command.
g	Continues execution until the next breakpoint is encountered.
gt	Sets a temporary breakpoint at the specified address, and resumes execution from the current program counter.
s	Single steps one source line, stepping into functions.
ss	Step-spy: step until the value of the specified address changes.
t	Single steps one source line, stepping over functions.

[Listing 4.2](#) shows an example of setting breakpoints, disassembling, and using other flow control commands to debug an application. In this example, **boldface** is used to denote commands that you type, and <= starts a comment.

Listing 4.2 Using the Debugging Flow Control Commands

```
sc          <= Display stack crawl, listed from oldest to newest. In this
            <= example, the current fcn was called from EventLoop+0016
```

Calling chain using A6 Links:

A6 Frame	Caller	
00000000	10C68982	cjtkend+0000
00015086	10C6CA26	__Startup__+0060
00015066	10C6CCCE	PilotMain+0250
00014FC2	10C0F808	SysAppLaunch+0458
00014F6E	10C10258	PrvCallWithNewStack+0016
00013418	10CD88B2	__Startup__+0060
000133F8	10CDB504	PilotMain+0036
000133DE	10CDB47C	EventLoop+0016

```
s                                     <= Single-Step one instruction
'SysHandleEvent' Will Branch
+$0514 10C0EF00 *BRA.W SysHandleEvent+$0694 ; 10C0F080 | 6000 017E
                                     <= Single step again by pressing the ENTER key
+$0694 10C0F080 *MOVEM.L (A7)+,D3-D5/A2-A4 | 4CDF 1C38
                                     <= Press ENTER again
+$0698 10C0F084 *UNLK A6 | 4E5E
                                     <= ... and again
+$069A 10C0F086 *RTS | 4E75 8E53 7973 4861
                                     <= ... and again
+$0018 10CDB47E *TST.B D0 | 4A00
```

```
il                                     <= Disassemble at current program counter
'EventLoop 10CDB466'
+$0018 10CDB47E *TST.B D0 | 4A00
+$001A 10CDB480 LEA $000C(A7),A7 | 4FEF 000C
+$001E 10CDB484 BNE.S EventLoop+$0050 ; 10CDB4B6 | 6630
...                                     <= Remainder of disassembly removed here
```

```
gt 10cdb484                             <= Go-Till address 0x10CDB484
+$001E 10CDB484 *BNE.S EventLoop+$0050 ; 10CDB4B6 | 6630
```

```
br :+50                                 <= Set a breakpoint at current routine+0x50
Breakpoint set at 10CDB4B6 (EventLoop+0050)
```

```
g                                     <= Go until a break occurs
+$0050 10CDB4B6 *CMPI.W #$0016,-$0018(A6) ; '..' | 0C6E 0016 FFE8
```

```
brd                                     <= Display all currently set breakpoints
10CDB4B6 (EventLoop+0050)
```

```
cl                                     <= Clear all breakpoints
All breakpoints cleared
```

```
atb "EvtGetEvent" <= Break whenever the EvtGetEvent system trap is called
A-trap set on 011d (EvtGetEvent)
```

Using Palm Debugger

Using the Debugging Window

```
g                               <= Go until a break occurs
Remote stopped due to: A-TRAP BREAK EXCEPTION
'EvtGetEvent'
+$0000 10C3B1E2 *LINK A6,$0000 | 4E56 0000

atc                             <= Clear all A-Traps
All A-Traps cleared

ss a2                           <= Step-Spy until the UInt32 at address 0x15404 changes
                               <= (the current value of register A2 is 0x15404)
Step Spying on address: 00015404
'EvtGetSysEvent'
+$00E8 10C1E980 *CLR.B          $0008 (A4) | 422C 0008
```

TIP: Some commands, like the `atb` command, require that the operand be quoted. Forgetting to quote the trap name in the `atb` command is a common mistake with Palm Debugger.

All of the commands mentioned in this section are described in detail in [Chapter 5, “Palm Debugger Command Reference.”](#)

Using the Heap and Database Commands

You can use the heap and database commands to display information about the databases and heaps on the handheld device. These commands, which are summarized in [Table 4.13](#), mirror commands available from the console window.

Table 4.13 Commonly Used Heap and Database Commands

Command	Description
<code>dir</code>	Lists the databases.
<code>hchk</code>	Checks a heap.
<code>hd</code>	Displays a dump of a memory heap.
<code>hl</code>	Lists all of the memory heaps on the specified memory card.
<code>ht</code>	Performs a heap summary.

The heap commands take heap ID values as parameters. The following table shows the values you can use for heap IDs.

Heap ID	Description
0	The dynamic heap.
1	The storage heap.

All of the commands mentioned in this section are described in detail in [Chapter 5, “Palm Debugger Command Reference.”](#)

To learn more about the console window and all of the console commands, see [Chapter 7, “Using the Console Window.”](#)

Advanced Debugging Features

This section presents several advanced features of the debugging window of Palm Debugger, including the following:

- defining structure template for displaying memory
- defining aliases for commands
- using script files to run sequences of commands
- automated loading of structure and alias definitions at program start-up time

Defining Structure Templates

You can define structure templates to use with Palm Debugger’s memory display commands. Each template matches a data type or structure type that you use in your application, which lets you display a structure in the debugging window with one command.

You define templates in a manner similar to the way you define structure types in a high-level programming language: start a template definition with the `typedef` command, follow with some number of field definition (`>`) commands, and finish with a `typeend` command. And once you have defined a structure template, you can use fields of that type in other template definitions.

[Table 4.14](#) summarizes the commands you use to define and display templates. For more information about these commands, see [Chapter 5, “Palm Debugger Command Reference.”](#)

Table 4.14 Structure Template Commands

>	Defines a structure field.
sizeof	Displays the size, in bytes, of a template.
templates	Lists the names of the debugger templates.
typedef	Begins a structure definition block.
typeend	Ends a structure definition block.

Note that the structure and field names must be quoted in your structure template definition commands. [Listing 4.3](#) shows the debugging commands used to define a template named `PointType`, and then defines a second template named `RectangleType` that uses two `PointType` fields.

Listing 4.3 Defining and using two structure templates

```
typedef struct "PointType"
> Int16 "X"
> Int16 "Y"
typeend

typedef struct "RectangleType"
> PointType "topLeft"
> PointType "extent"
typeend

sizeof PointType

Size = 4 byte(s)

sizeof RectangleType
Size = 8 byte(s)

dm 0 RectangleType
00000000 struct RectangleType
        {
00000000 PointType topLeft
        {
00000000 Int16 x = $-1
00000002 Int16 y = $-1
```



```
    }  
00000004    PointType extent  
    {  
00000004        Int16 x          = $1A34  
00000006        Int16 y          = $3E40  
    }  
}
```

Defining Aliases

For convenience, you can create aliases. Each alias stands for a specific command sequence. For example:

```
alias "checkheap" "hchk 0 -c"  
alias "ls" "dir 0"
```

After defining these aliases, you can type `ls` to display a directory listing for card 0 (built-in RAM), and you can type `checkheap` to check heap 0 with examination of each chunk.

Using Script Files

You use the `run` command to run a script file. A script file is any text file that contains debugging commands. For example, the following command reads and executes the debugging commands found in the text file named `MyCommands`:

```
run "MyCommands"
```

Automatic Loading of Definitions

When Palm Debugger is launched, it automatically runs the script file named `UserStartupPalmDebugger`. You can store your aliases, script files, and data structure templates in this file to have them available whenever you use Palm Debugger.

Using the Source Window

This section describes the source window, which you can use to perform limited debugging with the source code for your application.

Using Palm Debugger

Using the Source Window

NOTE: Palm Debugger's source level debugging is only available on Windows systems, and is only available for code that has been built using the GNU gcc compiler for Palm OS.

The source window works in conjunction with the debugging and CPU registers windows. For example, if you single step in the debugging window, the source window tracks along and displays any breakpoints that are currently set.

The source window is split into two panes:

- The upper pane displays the values of local variables for the current function.
- The lower pane displays the source code. This pane is automatically updated whenever you move through your code with flow control commands. You can also scroll this pane to view the code or to set a breakpoint.

The left margin of the lower pane displays indicators for breakpoints and the current program counter:

- a solid red circle is displayed next to a line that contains a breakpoint
- a green arrow is displayed next to the line containing the current program location

The two panes in the source window are separated by a thick horizontal line. This line is colored red when the connected handheld device is halted in the debugger nub, and is green when the handheld device is running code.

Debugging With the Source Window

To debug with the source code for an executable, you need to associate a symbol file on your desktop computer with the executable that is running on the handheld device. You can load any number of symbol files into Palm Debugger at once; whenever the device stops in the debugger nub, Palm Debugger automatically determines which symbol file to display in the source window.

You can use the following steps to load an application and its symbol file, and then use the source debugging commands:

1. Activate the console nub, as described in “[Activating Console Input](#)” on page 302.
2. Select **Install Database and Load Symbols** from the Source menu.
3. Select the PRC file to load onto the device.
4. Palm Debugger imports the PRC file into the handheld device and looks in the same directory for the associated symbol file.

Palm Debugger now associates the symbol file with the application that has been imported into the handheld device. Whenever the debugger nub breaks in the code for that application, the source window displays the associated source file and line number.

You can also break into the debugger manually and set a breakpoint on specific source code lines with **Toggle Breakpoint** in the Source menu or on the source window’s context menu.

Using Symbol Files

This section provides information about symbol files. You need to have a symbol file for your executable to use Palm Debugger’s source code debugging facility.

Each symbol file represents a single code resource and is created by the linker. Most Palm OS applications contain a single code resource of type 'code' and a resource ID of 1. Some applications have more than one code resource, and thus more than one symbol file.

A symbol file contains the following items:

- the names of each of the source files that were linked together to create the code resource
- the offset from the start of the code resource to the object code for each source file
- the offset from the start of the code resource for each line in the source file
- descriptions of the data structures used
- descriptions of the name, type, and location of each local variable used in the source code’s functions

Using Palm Debugger

Using the Source Window

- descriptions of the name, type, and location of each global variable

To make use of a symbol file, Palm Debugger needs the address of the code resource on the handheld device that corresponds to the symbol file. The **Load Symbols** command on the Source menu associates a symbol file on the desktop computer with a code resource on the handheld device.

Using the Source Menu

Palm Debugger's Source menu contains commands that you can use for source level debugging. [Table 4.15](#) summarizes these commands. Note that several of these commands are also available from the Source context menu, as described in the next section.

Table 4.15 Source Menu Commands

Command	Description
Break	Halts the handheld device in the debugger nub by sending the same key event as does the Graffiti Shortcut-1 shortcut. The device must be running the console nub to activate this command.
Step Into	Single steps one source line, and stops if it steps into a subroutine.
Step Over	Single steps one source line. If it steps into a subroutine, doesn't stop until the subroutine returns.
Go	Continues execution until a breakpoint is encountered.
Go Till	Sets a temporary breakpoint at the currently selected line in the source window and then continues execution.

Table 4.15 Source Menu Commands (*continued*)

Command	Description
Toggle Breakpoint	Toggles a breakpoint on or off at the currently selected line in the source window.
Disassemble at Cursor	Disassembles code at the currently selected line in the source window. The disassembled output is displayed in the debugging window.
Show Current Location	Scrolls the source window to show the current line in the source file.
Install Database and Load Symbols	Imports a PRC file into the handheld device and looks in the same directory for the associated symbol file.
Load Symbols	Opens a symbol file for use by Palm Debugger.
Remove All Symbols	Unloads any loaded symbols.

Using the Source Window Context Menu

You can activate the source context menu by right clicking your mouse in the source window. The context menu features many of the commands are available in the Source menu, including:

- **Break**
- **Go Till**
- **Toggle Breakpoint**
- **Disassemble at Cursor**
- **Show Current Location**

The context menu also lists the source files for each symbol file that is loaded. You can use this list to select which source file you want to view.

Source Window Debugging Limitations

Source level debugging is limited in the current version of Palm Debugger. Although you can perform some of your debugging with the source window, you need to keep the following limitations in mind to remember when you need to switch back to assembly language debugging:

- You cannot display a stack crawl in the source window. You need to switch to the debugging window and use the `sc` command.
- Local variables that are structures or pointers to structures display as hexadecimal addresses in the local variables pane of the source window. To view the contents of these structures, you need to use the `dm` command in the debugging window.
- You cannot view global variables in the source window.
- Local variables are only displayed in hexadecimal format.
- You cannot change the values of local variables from the source window. To change these values, you must use the `sb`, `sw`, or `sl` commands in the debugging window.

Palm Debugger Error Messages

Most of the error messages displayed by Palm Debugger are hexadecimal codes that can be difficult to understand. To determine the meaning of the message, you need to look up the code in the Palm OS header files.

Each error code is a 16-bit value, in which the upper byte represents the code manager that generated the error, and the lower byte represents the specific error code. For example, suppose that you receive the following error message from Palm Debugger:

```
### Error $00000219
```

The code manager code is `0x02`, which is the Data Manager, and the error code is `0x19`, which is `dmErrAlreadyExists`.

The manager codes are located in the `SystemMgr.h` header file. The value `0x02` is defined as `dmErrorClass`.

The specific error codes for each manager are found in the header file for that manager. For example, the value 0x19 is defined in `DataMgr.h` as `dmErrAlreadyExists`.

Palm Debugger Tips and Examples

This section provides a collection of tips and examples for working with Palm Debugger, including the following sections:

- [“Performing Calculations”](#)
- Saving time with [“Shortcut Characters”](#) and [“Repeating Commands”](#) on page 216
- [“Finding a Specific Function”](#) on page 216
- [“Finding Memory Corruption Problems”](#) on page 220
- [“Displaying Local Variables and Function Parameters”](#) on page 222
- [“Changing the Baud Rate Used by Palm Debugger”](#) on page 225
- [“Debugging Applications That Use the Serial Port”](#) on page 226
- [“Importing System Extensions and Libraries”](#) on page 226
- [“Determining the Current Location Within an Application”](#) on page 227

NOTE: Several of the examples in this section show user input mixed with the output displayed by Palm Debugger. In these cases, the user input—the commands you type—is shown in **boldface**.

Performing Calculations

You can type numeric expressions into the debugging window to use it as a simple hexadecimal calculator. Here are several examples of typing a numeric expression and the results displayed in the debugging window.

Typed Expression	Displayed Result
#20*4+3	\$00000053 #83 #83 '...S'
20*4+3	\$83 #131 #-125 '.'
123+ff	\$0222 #546 #546 '."''

Shortcut Characters

Use the two shortcut characters to simplify your typing efforts: type the period (.) character to specify the address value used for the most recent command, or use the semicolon (;) character to specify the starting address of the current routine.

Repeating Commands

You can repeat several of the debugging commands by pressing the ENTER key repeatedly. For example, you can type the `dm` command to display sixteen bytes of memory, and then press the ENTER key to display the next sixteen bytes of memory. The `s` and `t` commands also provide this capability.

Finding a Specific Function

A typical debugging problem is that you want to single step through some problem code, but need to first find the code. This section presents four different methods that you can use to find code:

- Rebuild the application with a call to `DbgBreak` in the problem routine.
- Use debugging commands to set an A-trap break on a system call that the problem routine makes.
- Use the `ft` command to find the name of your routine.
- Use the source level debugging support to locate your routine.

Rebuilding the Application

If you can rebuild the application that you are debugging, it is often easiest to compile a `DbgBreak` call into the problem routine. Palm Debugger will break on the line containing that call.

Setting an A-trap Break

If you know that the problem routine makes a certain system call, you can use debugging commands to set an a-trap break on that call. The potential problem with this method is that other routines might make the same system call, which means that you will get false triggers.

For example, if you want to find your application's main event loop, you can use the following steps.

1. Set an a-trap break for the `EvtGetEvent` system call, and then tell Palm Debugger to go until it hits a break, as shown here:

```
atb "evtgetevent"
```

```
A-trap set on 011d (evtgetevent)
```

```
g
```

```
Remote stopped due to: A-TRAP BREAK EXCEPTION  
'EvtGetEvent'  
+$0000 10C3B1E2 *LINK A6,$0000 | 4E56 0000
```

When Palm Debugger breaks due to an a-trap break, the current location is at the beginning of the system call. This means that the return address on the stack is the function that made the system call. In the above example, this will be your application's main event loop.

2. Set a temporary breakpoint at the function return address that is currently on the stack. You can use the `@` operator to fetch the long word at the stack pointer, as shown here:

```
gt @sp
```

```
EXCEPTION ID = $80
```

```
'EventLoop'
```

```
+$0016 1001B2E6 *MOVE.L A2,-(A7) | 2F0A
```

The program counter is now at the instruction in your main event loop that immediately follows the `EvtGetEvent` call.

Using Palm Debugger

Palm Debugger Tips and Examples

3. Disassemble your main event loop. You can use the colon (:) symbol to easily grab the starting address of the current routine.

```
il :
'EventLoop 1001B2D0'
+$0000 1001B2D0  LINK A6,-$001C| 4E56 FFE4
+$0004 1001B2D4  MOVEM.L D3-D4/A2,-(A7)| 48E7
1820
+$0008 1001B2D8  LEA -$0018(A6),A2| 45EE FFE8
+$000C 1001B2DC  PEA $00000032 ; 00000032| 4878
0032
+$0010 1001B2E0  MOVE.L A2,-(A7)| 2F0A
+$0012 1001B2E2  _EvtGetEvent ; $10C3B1E2| 4E4F
A11D
+$0016 1001B2E6  *MOVE.L A2,-(A7)| 2F0A
+$0018 1001B2E8  _SysHandleEvent ; $10C0E9EC|
4E4F A0A9
+$001C 1001B2EC  ADD.W #$000C,A7| DEFC 000C
+$0020 1001B2F0  TST.B D0| 4A00
```

The `atb`, `g`, `gt`, and `il` commands are described in detail in [Chapter 5, “Palm Debugger Command Reference.”](#)

Using the Find Text Command

Another method for finding a certain code routine is to search through memory for the name of the routine. You can use Palm Debugger's `ft` command to search for text. This command takes three arguments: the text to find, the starting address of the search, and the number of bytes to search.

For example, to search through the first megabyte of RAM on a Palm III™, you can use the following command:

```
ft "EventLoop" 10000000 100000
dm 100005C4 ;100005C4: 45 76 65 6E 74 4C 6F 6F
70 63 61 74 69 6F 6E 00 "EventLoop....."
```

NOTE: RAM starts at address 0x10000000 in all current Palm handheld devices except for the Palm V™. RAM starts at address 0 on the Palm V.

To search ROM instead, use address 0x10C00000.

You can repeat the find, starting from the current location, by pressing the ENTER key.

```
dm 1001B355 ;1001B355: 45 76 65 6E 74 4C 6F 6F
70 00 00 4E 56 00 00 2F "EventLoop..NV../"
```

Again, you can ensure that the routine you've found is the one you want, you can disassemble the current routine by entering the following command:

```
il :
```

IMPORTANT: In the above example, the `ft` command first found the text at address 0x100005C4. This is actually a copy of the search string the debugger nub is using. You must search a second time to find the first “actual” instance of the text string.

The `ft` and `il` commands are described in detail in [Chapter 5, “Palm Debugger Command Reference.”](#)

Using the Source Level Debugging Support

If you have built your application with the gcc compiler and generated a symbol file, you can find your code by following these steps:

1. Launch the console nub on the handheld device, as described in [“Activating Console Input”](#) on page 302.
2. Open your symbols file. You can use the **Open Symbol File** command from Palm Debugger's Source menu.
3. After the symbol file has loaded, choose the **Break** command from the Source menu to break into the debugger nub on the device.

4. In the source window, select the source line of the routine you want to debug.
5. Select **Toggle Breakpoint** from the Source menu to set the breakpoint.

Finding Memory Corruption Problems

As anyone who has tried knows, finding the routine that is trashing memory can be a very frustrating task. A memory bug can trash the low memory globals used by the system, the dynamic memory heap, or an application variable, any of which can cause unpredictable behavior. This section provides tips for tracking down two kinds of memory bugs:

- heap corruptions
- application variable corruption

Tracking Down Heap Corruption

If you suspect a corrupted heap, check the heap. You can perform a fast check of the heap with the `hchk` command, which verifies the validity of the heap. For example:

```
hchk 0
Heap OK
```

You can also use the `hd 0` command to display a dump of the dynamic heap. If the heap is in a valid state, the heap dump will complete and you will see the heap summary displayed at the bottom of the window. For example:

```
hd 0
```

```
Displaying Heap ID: 0000, mapped to 00001480
                                req    act                                resType/
#resID/
start    handle    localID    size    size    lck own flags type    index attr ctg
uniqueID name
-----
-----
-00001534 00001494 F0001495 000456 00045E #0 #0    fM Graffiti Private
-00001992 00001498 F0001499 000012 00001A #0 #0    fM DataMgr Protect List
(DmProtectEntryPtr*)
-000019AC 00001490 F0001491 00001E 000026 #0 #0    fM Alarm Table
-000019D2 0000148C F000148D 000038 000040 #0 #0    fM
```

```

*00001A12 0000149C F000149D 000396 00039E #2 #1 fM Form "3:03 pm"
*00001DB0 000014A0 F00014A1 00049A 0004A2 #2 #0 fM
00002252 ----- F0002252 00002E 00003E #0 #0 FM
00002290 ----- F0002290 00EC40 00EC50 #0 #0 FM
-00010EE0 ----- F0010EE0 000600 000608 #0 #15 fM Stack: Console Task

...

000114E8 ----- F00114E8 000FF8 001008 #0 #0 FM
-000124F0 ----- F00124F0 001000 001008 #0 #15 fM
-00017D30 ----- F0017D30 00003C 000044 #0 #15 fM SysAppInfoPtr: AMX
-00017D74 ----- F0017D74 000008 000010 #0 #15 fM Feature Manager Globals
(FtrGlobalsType)
-00017D84 ----- F0017D84 000024 00002C #0 #15 fM DmOpenInfoPtr: 'Update
3.0.2'
-00017DB0 ----- F0017DB0 00000E 000016 #0 #15 fM DmOpenRef: 'Update
3.0.2'
-00017DC6 ----- F0017DC6 0001F4 0001FC #0 #15 fM Handle Table: 'Ô®Update
3.0.2'
-00017FC2 ----- F0017FC2 000024 00002C #0 #15 fM DmOpenInfoPtr:
'Ô®Update 3.0.2'
-00017FEE ----- F0017FEE 00000E 000016 #0 #15 fM DmOpenRef: 'Ô®Update
3.0.2'
-----
-----
Heap Summary:
  flags:          8000
  size:           016B80
  numHandles:     #40
  Free Chunks:    #14      (010C50 bytes)
  Movable Chunks: #51      (005E80 bytes)
  Non-Movable Chunks: #0      (000000 bytes)

```

If you break into the debugger nub at various points during the execution of your application and check the heap, you can narrow down where the corruption is occurring in your code.

Another method for tracking down heap corruption is to use the mdebug command, which puts the handheld device into one of several heap checking modes. Once a heap-checking mode has been activated on the device, the Palm OS performs an automatic heap check and verification after each call to the Memory Manager. If the heap is corrupted, the system automatically breaks into the debugger. The following is an example of the mdebug command:

Using Palm Debugger

Palm Debugger Tips and Examples

mdebug -partial

Current mode = 001A

Only Affected heap checked/scrambled per call

Heap(s) checked on EVERY Mem call

Heap(s) scrambled on EVERY Mem call

Free chunk contents filled & checked

Minimum dynamic heap free space recording OFF

Note that the memory checking modes can seriously degenerate the performance of an application. You can enable or disable various mdebug options to strike a balance between performance and debugging information. For more information, see “[MDebug](#)” on page 337.

The hd, hchk, and mdebug commands are described in detail in [Chapter 5, “Palm Debugger Command Reference.”](#)

Tracking Down Global Variable Corruption

When you have a bug that is trashing a system or application global, you must first determine which address in memory is being corrupted. Once you know that address, you can use the Step-Spy (ss) command to watch the address. The ss command puts the processor into single-step mode and automatically checks the contents of a specified address after each instruction. If the instruction causes the contents of the address to change, the debugger breaks. For example:

```
ss 100
```

```
Step Spying on address: 00000100
```

Note that the ss command is single-stepping through instructions, and thus the handheld device runs slowly. Ideally, you can narrow down the range of code involved with the corruption and use this command to watch the execution of this code section.

Displaying Local Variables and Function Parameters

If you are debugging with the source window, the current function’s local variables and parameters are displayed in the upper pane of the window. However, if you do not have access to symbol

information, you need to use debugging commands to manually look up the variable values. This section describes the steps you need to take to look up values for a typical function, which is shown in [Listing 4.4](#)

Listing 4.4 An Example Function for Viewing Local Variables and Parameters

```
static Boolean
MainFrmEventHandler (EventPtr eventP)
{
    FormPtr      formP;
    Boolean      handled = false;
    Err          err;
    char         buffer[64];
    UInt32       numBytes=0;
    Int16        i;
    static       char prevChar = 0;

    // See if StdIO can handle it
    if (StdHandleEvent (eventP)) return true;

    // body of function omitted for clarity
    ...

    return false;
}
```

If you break into the debugger and disassemble the code at the beginning of this function, just before it calls the StdHandleEvent function, this is what you see:

```
il :
'MainFrmEventHandler 1001E296'
+$0000 1001E296  LINK A6,-$0048| 4E56 FFB8
+$0004 1001E29A  MOVEM.L D3-D5/A2,-(A7)| 48E7
1C20
+$0008 1001E29E  MOVE.L $0008(A6),A2| 246E 0008
+$000C 1001E2A2  CLR.B D5| 4205
+$000E 1001E2A4  CLR.L -$0044(A6)| 42AE FFBC
+$0012 1001E2A8  *MOVE.L A2,-(A7)| 2F0A
+$0014 1001E2AA  BSR.W StdHandleEvent ;
1001F214      | 6100 0F68
```

Using Palm Debugger

Palm Debugger Tips and Examples

```
+$0018 1001E2AE  ADDQ.W #04,A7| 584F
+$001A 1001E2B0  TST.B D0| 4A00
+$001C 1001E2B2  BEQ.S
MainFrmEventHandler+$0024 ; 1001E2BA | 6706
```

The first UInt32 on the stack upon function entry is the return address for the function. Immediately following that are the parameter values, from left to right. In the listing above, if you display the memory pointed to by the stack pointer at the beginning of the function, you see the following:

```
dm sp
00014A2A: 10 C4 77 00 00 01 4A 4E 00 01 4A 4E
00 01 51 0E "...w...JN..JN..Q."
```

The first UInt32 (0x10C47700) is the return address of the function.

The second UInt32 (0x00014A4E) is the value of the function's eventP parameter.

After the LINK instruction executes however, the stack pointer register is changed: the stack pointer is decremented to make room for a saved value of the A6 register and for local variables; in this example, there are 0x48 bytes of local variables.

After the LINK instruction executes, the A6 register is changed to point to the beginning of the functions' stack frame. This register is used by the function to access parameters and local variables. The following shows what the stack looks like after the LINK instruction executes:

```
Address : Contents
-----
A7 => 149CE                                     <= new "top" of stack
      : ...                                     <= 0x48 bytes of local
variables
A6 => 14A26 : 00 01 4A 3A                       <= saved value of A6
14A2A : 10 C4 77 00                             <= return address
14A2E : 00 01 4A 4E<= eventP parameter
```

If you display the memory referenced by register A6 at this time, you see the following:


```
dm a6
```

```
00014A26: 00 01 4A 3A 10 C4 77 00 00 01 4A 4E  
00 01 4A 4E "...J:...w...JN..JN"
```

The first `UInt32` pointed to by `A6` is the old value of `A6`, the next `UInt32` is the return address of the routine, and following that are the function parameter values. This means that the first parameter to the function can always be found at 8 (`A6`).

Any local variables belonging to the function are stored in memory locations preceding `A6`. In the above example, the `numBytes` local variable is located at `-$0044 (A6)`. Once you know the offset of the variable, you can access by using an offset from the `A6` register; thus, you can use the following command to view the `numBytes` parameter:

```
dm -44+a6
```

```
000149E2: 00 00 00 00 00 00 1A 0C 20 00 20 04  
00 01 4A 08 "..... . ...J."
```

Changing the Baud Rate Used by Palm Debugger

Both the debugger and console nubs on the handheld device always start communicating at 57,600 baud. You can change this baud rate by selecting a new speed from Palm Debugger's Communications menu.

If you are using a serial cable that does not include hardware handshaking lines, you might need to switch to a lower baud rate. And if you are downloading a large file to the handheld device, you might want to switch higher baud rate. Palm Debugger lets you set the baud rate to values ranging from 2400 baud to 230,400 baud.

When you choose a new baud rate, Palm Debugger sends a request packet to the nub on the handheld device to change its baud rate, and then Palm Debugger changes its own baud rate. If Palm Debugger is attached to the debugger nub on the device, the request goes to the debugger nub; otherwise, the request goes to the console nub.

In either case, changing the baud rate of either nub on the handheld device changes the baud rate of both nubs.

NOTE: The new baud rate is only in effect until you soft reset the handheld device.

Debugging Applications That Use the Serial Port

Although it is very difficult to debug an application that uses the serial port, you can still use a limited set of debugging functions. You cannot use the console nub while an application on the handheld device is using the serial port.

When you do enter the debugger nub on the handheld device while debugging a serial application, the debugger sends data over the serial port and probably disrupts the application's communications. At that point, you can switch the serial cable back over to Palm Debugger, double-check your baud rate setting, attach to the device with the `att` command, and perform "post-mortem" analysis of the problem.

Making Sure the Baud Rates Match

If the debugger nub on the handheld device has already been entered at least once, and you later launch a handheld application that opens the serial port, that application might change the port speed. The debugger nub will then use the new baud rate, but you will need to manually change the baud rate that Palm Debugger is using for communications to work. Use Palm Debugger's Communications menu to change the speed.

Importing System Extensions and Libraries

You can use the console window `import` command to copy a new database or replace an existing database on the handheld device. However, the `import` command cannot replace a database that is currently opened.

If you are developing a system extension or shared library and need to use the `import` command, you need to do some extra work. This is due to the fact that system extension databases and shared libraries are generally either opened or marked as protected. To

import a newer version of a system extension database or shared library, you have to make sure that the old database has been closed and is not protected; otherwise, the `import` command generates the following message:

```
###Error $00000219 occurred
```

To get around this problem, you need to perform a soft reset on the handheld device and tell the Palm OS to not automatically load system extensions or shared libraries. To do so, follow these steps:

1. Press the Up button on the handheld device while pressing the reset button on the back of the device with a paper clip or similar blunt object. This tells the Palm OS on the device to not load the system extension databases and shared libraries.
2. Start the console nub on the handheld device.
3. Import your system extension or shared library with the `import` command.
4. Perform another soft reset on the device, and the system will use the new version of the extension or library.

Determining the Current Location Within an Application

You can use one of the following three methods to determine where you are in your code:

1. Disassemble code starting at the beginning of the current routine, using the following command:

```
il :  
'EventLoop 1001B2D0'  
+$0000 1001B2D0 LINK A6,-$001C| 4E56 FFE4  
+$0004 1001B2D4 MOVEM.L D3-D4/A2,-(A7)| 48E7  
1820  
+$0008 1001B2D8 LEA -$0018(A6),A2| 45EE FFE8  
+$000C 1001B2DC PEA $00000032 ; 00000032| 4878  
0032  
+$0010 1001B2E0 MOVE.L A2,-(A7)| 2F0A  
+$0012 1001B2E2 _EvtGetEvent ; $10C3B1E2| 4E4F  
A11D  
+$0016 1001B2E6 *MOVE.L A2,-(A7)| 2F0A
```

Using Palm Debugger

Palm Debugger Tips and Examples

```
+$0018 1001B2E8  _SysHandleEvent ; $10C0E9EC|
4E4F A0A9
+$001C 1001B2EC  ADD.W #$000C,A7| DEFC 000C
+$0020 1001B2F0  TST.B D0| 4A00
```

2. Perform a stack crawl with the `sc` command, which displays the oldest routine at the top and the newest at the bottom. For example:

```
sc
Calling chain using A6 Links:
A6 Frame Caller
00000000 10C68982 cjtken+0000
00015086 10C6CA26 __Startup__+0060
00015066 10C6CCCE PilotMain+0250
00014FC2 10C0F808 SysAppLaunch+0458
00014F6E 10C10258 PrvCallWithNewStack+0016
0001491E 1001CC7E start+006E
000148E6 1001CF44 PilotMain+001C
```

3. Get a list of the currently opened databases. Your application should be one of the listed databases. Note that the System and GraffitiShortCuts databases are always opened by the system, and will appear at the bottom of the list. Use the `opened` command as follows:

`opened`

name	resDB	cardNum	accessP	ID	openCnt	mode
LauncherDB	no	0	00015146	0001814F	1	0003
*Launcher	yes	0	00016DD2	00D1FA98	1	0001
*Graffiti ShortCuts	yes	0	00017D5C	001FFE7F	1	0007
*System	yes	0	00017FEE	00D20A44	1	0005

Total: 4 databases opened

Palm Debugger Command Reference

This chapter describes Palm Debugger commands. For an introduction to using Palm Debugger, see [Chapter 4, “Using Palm Debugger.”](#)

This chapter begins with a description of the syntax used to describe commands, and then expands into the following sections:

- [“Debugging Window Commands”](#) on page 231 provides a reference description for each command that you can use in the debugging window to communicate with the debugger nub running on the handheld device. The command reference listings are ordered alphabetically.
- [“Debugging Command Summary”](#) on page 265 provides tables that summarize the debugging commands by category.

Command Syntax

This chapter uses the following syntax to specify the format of debugger commands:

<code>commandName</code>	<code><parameter> [options]</code>
<code>commandName</code>	The name of the command.
<code>parameter</code>	Parameter(s) for the command. Each parameter name is enclosed in angle brackets (< and >). Sometimes a parameter can be one value or another. In this case the parameter names are bracketed by parentheses and separated by the character.

Palm Debugger Command Reference

Command Syntax

options Optional flags that you can specify with the command. Note that options are specified with the dash (-) character in the console window and with the backslash (\) character in the debugging window.

NOTE: Any portion of a command that is shown enclosed in square brackets (“[” and “]”) is optional.

The following is an example of a command definition

```
dir (<cardNum>|<srchOptions>) [displayOptions]
```

The `dir` command takes either a card number or a search specification, followed by display options.

Here are two examples of the `dir` command sent from the console window:

```
dir 0 -a
dir -t rsrc
```

And here are the same two commands sent from the debugging window:

```
dir 0 \a
dir \t rsrc
```

Specifying Command Options

All command options and some command parameters are specified as flags that begin with a dash (in the console window) or backslash (in the debugging window). For example:

```
-c
-enable
\enable
```

Some flags are followed by a keyword or value. You must leave white space between the flag and the value. For example:

```
-f D:\temp\myLogFile
\t Rsrc
```

Specifying Numeric and Address Values

Many of the debugging commands take address or numeric arguments. You can specify these values in hexadecimal, decimal, or binary. All values are assumed to be hexadecimal unless preceded by a sign that specifies decimal (#) or binary (%). [Table 5.1](#) shows values specified as binary, decimal, and hexadecimal in a debugging command:

Table 5.1 Specifying numeric values in Palm Debugger

Hex value	Decimal value	Binary value
64 or \$64	#100	%01100100
F5 or \$F5	#245	%11110101
100 or \$100	#256	%100000000

For more information, see “[Specifying Constants](#)” on page 195.

Using the Expression Language

When you send commands from the debugging window to the debugger nub on the handheld device, you can use Palm Debugger’s expression language to specify the command arguments. This language is described in “[Using Debugger Expressions](#)” on page 194.

Debugging Window Commands

You use Palm Debugger’s debugging window to send commands to the debugger nub that is running on the handheld device.

NOTE: You can use Palm Debugger’s expression language to specify arguments to debugging window commands. The expression language is described in “[Using Debugger Expressions](#)” on page 194.

Palm Debugger Command Reference

Debugging Window Commands

This section provides a description of all of the commands in alphabetical order. For convenience, the commands are categorized here:

Table 5.2 Debugging window command categories

Category	Commands
Console	cardInfo , dir , hChk , hd , hl , ht , Info , opened , storeInfo
Flow Control	att , atb , atc , atd , br , brc , brd , cl , dx , g , gt , s , ss t , reset
Memory	atr , db , dl , dm , dw , fb , fill , fl , ft , fw , il , sb , sc , sc6 , sc7 , sl , sw , wh
Miscellaneous	help (?) , penv
Register	reg
Template	> , sizeof , templates , typedef , typeend
Utility	alias , aliases , bootstrap , keywords , load , run , save , var , variables

>

Purpose Defines a structure field.

Usage > <typeName> <"fieldName">

Parameters

typeName	The type of the field.
fieldName	The quoted name of the field in the template.

Comments Use the > command in conjunction with the [typedef](#) and [typeend](#) commands to defined structure templates that you can use to display complex structures with a single memory display ([dm](#)) command.

Example

```
typedef struct "PointType"
> SWord "X"
> SWord "Y"
typeend
```


alias

Purpose Defines or displays an alias.

Usage `alias <"name">`
`alias <"name"> <"definition">`

Parameters

<code>name</code>	The quoted name of the alias.
<code>definition</code>	The quoted definitional text for the alias.

Comments Use the `alias` command to define an alias for a command or group of commands.

If you provide only the name of an alias, this command displays the definition for that name.

Example `alias "ls" "dir"`

aliases

Purpose Displays the names of all defined aliases.

Usage `aliases`

Parameters None.

Comments

Example

```
aliases
ls
```

Palm Debugger Command Reference

Debugging Window Commands

atb

Purpose Adds an A-Trap break.

Usage `atb (<"funcName"> | <trapNum>)
([libRefNum> | <"libName">])`

Parameters	<code>funcName</code>	The quoted name of the function.
	<code>trapNum</code>	The A-Trap number.
	<code>libRefNum</code>	Optional. the reference number for the library in which the function resides.
	<code>libName</code>	Optional. The quoted name of the library in which the function resides.

atc

Purpose Clears an A-Trap break.

Usage `atc (<"funcName"> | <trapNum>)
([libRefNum> | <"libName">])`

Parameters	<code>funcName</code>	The quoted name of the function.
	<code>trapNum</code>	The A-Trap number.
	<code>libRefNum</code>	Optional. the reference number for the library in which the function resides.
	<code>libName</code>	Optional. The quoted name of the library in which the function resides.

atd

Purpose Displays a list of all the A-Trap breaks currently set.

Usage `atd`

Parameters None.

atr

Purpose Registers a function name with an A-Trap number.

Usage `atr <"funcName"> <trapNum> [<"libName">]`

Parameters	<code>funcName</code>	The quoted name of the function.
	<code>trapNum</code>	The A-Trap number.
	<code>libName</code>	Optional. The quoted name of the library in which the function resides.

att

Purpose Attach to the handheld device.

Usage `att [options]`

Parameters	<code>options</code>	You can optionally specify the following options: <code>\async</code> Attach asynchronously.
-------------------	----------------------	--

Example

```
att
EXCEPTION ID = $A
+$0512 10C0EEFE *MOVEQ.L    #$01,D0 | 7001
```

bootstrap

Purpose Loads a ROM image into memory on the handheld device, using the bootstrap mode of the processor.

Usage `bootstrap <"hwInitFileName"> <"romFileName"> [options]`

Parameters	<code>hwInitFileName</code>	The quoted name of the hardware initialization file on your desktop computer.
-------------------	-----------------------------	---

Palm Debugger Command Reference

Debugging Window Commands

romFileName	The quoted name of the ROM image file on your desktop computer.
options	You can optionally specify the following options: \slow ???.

br

Purpose Sets a breakpoint at the specified address.

Usage br [options] <addr>

Parameters	options	Optional. You can specify the following option: \toggle Toggles the breakpoint on or off.
	addr	The memory address at which to set the breakpoint.

brc

Purpose Clears a breakpoint or all breakpoints.

Usage brc
brc <addr>

Parameters	addr	A memory address.
-------------------	------	-------------------

Comments Use the br command to clear a specific breakpoint or to clear all breakpoints. If you specify a valid address value, that breakpoint is cleared. If you do not specify any address value, all breakpoints are cleared.

NOTE: The cl and brc commands are identical.

brd

Purpose	Displays a list of all of the breakpoints that are currently set.
Usage	<code>brd</code>
Parameters	None.

cardInfo

Purpose	Retrieves information about a memory card.		
Usage	<code>cardinfo <cardNum></code>		
Parameters	<table><tr><td><code>cardNum</code></td><td>The number of the card for which you want information displayed. You almost always use 0 to specify the built-in RAM.</td></tr></table>	<code>cardNum</code>	The number of the card for which you want information displayed. You almost always use 0 to specify the built-in RAM.
<code>cardNum</code>	The number of the card for which you want information displayed. You almost always use 0 to specify the built-in RAM.		

Comments	NOTE: You can use the <code>cardinfo</code> command in either the Console window or the debugging window.
-----------------	--

Example	<pre>cardinfo 0 Name: PalmCard Manuf: Palm, Inc Version: 0001 CreationDate: B1243780 ROM Size: 00118FFC RAM Size: 00200000 Free Bytes : 0015ACB2 Number of heaps: #3</pre>
----------------	---

Palm Debugger Command Reference

Debugging Window Commands

cl

Purpose Clears a breakpoint or all breakpoints.

Usage `cl`
`cl <addr>`

Parameters `addr` A memory address.

Comments Use the `cl` command to clear a specific breakpoint or to clear all breakpoints. If you specify a valid address value, that breakpoint is cleared. If you do not specify any address value, all breakpoints are cleared.

NOTE: The `cl` and `brc` commands are identical.

db

Purpose Displays the byte value at a specified address.

Usage `db <addr>`

Parameters `addr` A memory address.

Comments

Example `db 0100`
Byte at 00000100 = \$01 #1 #1 '.'

dir

Purpose Displays a list of the databases on the handheld device.

Usage `dir (<cardNum>|<searchOptions>)`
`[<displayOptions>]`

Parameters

<code>cardNum</code>	The card number whose databases you want listed. You almost always use 0 to specify the built-in RAM.
<code>searchOptions</code>	Optional. Options for listing a specific database. Specify any combination of the following flags. <code>\c <creatorID></code> Search for a database by creator ID. <code>\latest</code> List only the latest version of each database. <code>\t <typeID></code> Search for a database by its type.
<code>displayOptions</code>	Optional. Options for which information is displayed in the listing. Specify any combination of the following flags. <code>\a</code> Show all information. <code>\at</code> Show the database attributes. <code>\d</code> Show the database creation, modification, and backup dates. <code>\i</code> Show the database appInfo and sortInfo field values. <code>\id</code> Show the database chunk ID <code>\s</code> Show the database size <code>\m</code> Show the database modification number. <code>\n</code> Show the database name.

Palm Debugger Command Reference

Debugging Window Commands

- `\r` Show the number of records in the database.
- `\tc` Show the database type ID and creator ID.
- `\v` Show the database version number.

Comments Use the `dir` command to display a list of the databases on a specific card or in the handheld device built-in RAM. You typically use the following command to list all of the databases stored in RAM on the handheld device:

```
dir 0
```

Or use the `-a` switch to display all of the information for each database:

```
dir 0 -a
```

NOTE: You can use the `dir` command in either the Console window or the debugging window. However, the command options must be prefaced with the “\” character in the debugging window, rather than with the “-” character that you use in the console window version.

Example

```
dir 0
```

name	ID	total	data

*System	00D20A44	392.691 Kb	390.361 Kb
*AMX	00D209C4	20.275 Kb	20.123 Kb
*UIAppShell	00D20944	1.327 Kb	1.175 Kb
*PADHTAL Library	00D208E2	7.772 Kb	7.674 Kb
*IrDA Library	00D20876	39.518 Kb	39.402 Kb
...			
MailDB	0001817F	1.033 Kb	0.929 Kb
NetworkDB	0001818B	0.986 Kb	0.722 Kb
System MIDI Sounds	000181B3	1.066 Kb	0.842 Kb
DatebookDB	000181FB	0.084 Kb	0.000 Kb

Total: 41			

dl

Purpose Displays the 32-bit long value at a specified address.

Usage `dl <addr>`

Parameters `addr` A memory address.

Example `dl 0100`
Long at 00000100 = \$01010000 #16842752 #16842752 '....'

dm

Purpose Displays memory for a specified number of bytes or templates.

Usage `dm <addr> [<count>] [<template>]`

Parameters `addr` A memory address.
`count` Optional. The number of bytes to display.
`template.` The name of the structure template to use. This defines how much memory to display and how to display it.

Comments Use the `dm` command to display a range of memory values. You can specify a byte count or a structure template; if you do not specify either, `dm` displays sixteen bytes of memory.

Example `dm 0100 8`
`00000100: 01 01 00 00 02 B0 00 01`

Palm Debugger Command Reference

Debugging Window Commands

dump

Purpose Dumps memory to a file.

Usage `dump <"filename"> <addr> <numBytes>`

Parameters	<code>filename</code>	The quoted name of the file to which the data is to be written.
	<code>addr</code>	A memory address.
	<code>numBytes</code>	The number of bytes of memory to write to the file.

Comments Use the dump command to write a dump of a range of memory addresses to file.

dw

Purpose Displays the 16-bit word value at a specified address.

Usage `dw <addr>`

Parameters	<code>addr</code>	A memory address.
-------------------	-------------------	-------------------

Example

```
dw 0100
Word at 00000100 = $0101 #257 #257 '...'
```

dx

Purpose Enables or disables `DbgBreak()` breaks.

`dx`

Parameters	None.
-------------------	-------

fb

Purpose Searches through a range of memory for a specified byte value.

Usage fb <value> <addr> <numBytes> [flags]

Parameters	value	The byte value to find.
	addr	The address at which to start the search.
	numBytes	The number of bytes to search.
	flags	Optional. You can specify the following flags:
	\a	Find all occurrences within the specified range.
	\i	Use caseless comparison.

Comments By default, fb uses a case sensitive comparison.

Example fb ff 0100 200

```
dm 00000110 ;00000110: FF 00 00 00 03 18 00 00 03 BC 00
01 7D 72 00 01 ".....}r.."
```

fill

Purpose Fills memory with a specified byte value.

Usage fill <addr> <numBytes> <value>

Parameters	addr	A memory address.
	numBytes	The number of bytes to fill with the value.
	value	The value assigned to each byte.

Example fill 0100 8 FF

Palm Debugger Command Reference

Debugging Window Commands

fl

Purpose Searches through a range of memory for a specified 32-bit long value.

Usage `fb <value> <addr> <numBytes> [flags]`

Parameters

<code>value</code>	The byte value to find.
<code>addr</code>	The address at which to start the search.
<code>numBytes</code>	The number of bytes to search.
<code>flags</code>	Optional. You can specify the following flags: <code>\a</code> Find all occurrences within the specified range. <code>\i</code> Use caseless comparison.

Comments By default, `fl` uses a case sensitive comparison.

Example `fl ffff 0 1000`

```
dm 00000034      ;00000034: FF FF 00 00 FF FF 00 00      FF FF 00
00 FF FF 00 00      "....."
```

ft

Purpose Searches through a range of memory for the specified text.

Usage `ft <text> <addr> <numBytes> [flags]`

Parameters

<code>text</code>	The quoted text to find.
<code>addr</code>	The address at which to start the search.
<code>numBytes</code>	The number of bytes to search.
<code>flags</code>	Optional. You can specify the following flags: <code>\a</code> Find all occurrences within the specified range.

\i Use caseless comparison.

Comments By default, `ft` uses a case sensitive comparison.

Example `ft "abc" 0 1000`

```
dm 000005C4      ;000005C4: 61 62 63 27 00 00 00 00      00 01 4B
06 00 00 0
```

fw

Purpose Searches through a range of memory for the specified 16-bit word value.

Usage `fw <value> <addr> <numBytes> [flags]`

Parameters	value	The value to find.
	addr	The address at which to start the search.
	numBytes	The number of bytes to search.
	flags	Optional. You can specify the following flags:
	\a	Find all occurrences within the specified range.
	\i	Use caseless comparison.

Comments By default, `fw` uses a case sensitive comparison.

Example `fw 32000 0 1000`

```
dm 00000258      ;00000258: 00 20 00 00 00 07 A7 0E      00 00 00
01 00 00 00 00      ". ...."
```

Palm Debugger Command Reference

Debugging Window Commands

g

Purpose Continues execution.

Usage g
g <addr>

Parameters addr Optional. The address from which to continue execution.

Comments You can optionally specify a starting address for the g command. If you do not specify an address, execution continues from the current program counter location.

Example g

gt

Purpose Sets a temporary breakpoint at the specified address, and resumes execution from the current program counter.

gt <addr>

Parameters addr The address at which to set the breakpoint. If you do not specify an address, the current program counter location is used.

Comments

hChk

Purpose Checks the integrity of a heap.

Usage hchk <heapId> [options]

Parameters heapId The hexadecimal number of the heap whose contents are to be checked. Heap number 0x0000 is always the dynamic heap.

options

Optional. You can specify the following option:

\c Check the contents of each chunk.

Comments

NOTE: You can use the `hchk` command in either the Console window or the debugging window. However, the command options must be prefaced with the “\” character in the debugging window, rather than with the “-” character that you use in the console window version.

Example

```
hchk 0000
Heap OK
```

hd

Purpose Displays a hexadecimal dump of the specified heap.

Usage `hd <heapId>`

Parameters `heapId` The hexadecimal number of the heap whose contents are to be displayed. Heap number 0x0000 is always the dynamic heap.

Comments Use the `hd` command to display a dump of the contents of a specific heap from the handheld device. You can use the [HL](#) command to display the heap IDs.

Example

```
hd 0
```

```
Displaying Heap ID: 0000, mapped to 00001480
```

```
                                req      act                                resType/
#resID/
```

Palm Debugger Command Reference

Debugging Window Commands

start uniqueID	handle name	localID	size	size	lck	own	flags	type	index	attr	ctg

-00001534	00001494	F0001495	000456	00045E	#0	#0		fM Graffiti Private			
-00001992	00001498	F0001499	000012	00001A	#0	#0		fM DataMgr Protect List			
(DmProtectEntryPtr*)											
-000019AC	00001490	F0001491	00001E	000026	#0	#0		fM Alarm Table			
-000019D2	0000148C	F000148D	000038	000040	#0	#0		fM			
*00001A12	0000149C	F000149D	000396	00039E	#2	#1		fM Form "3:03 pm"			
*00001DB0	000014A0	F00014A1	00049A	0004A2	#2	#0		fM			
00002252	-----	F0002252	00002E	00003E	#0	#0		FM			
00002290	-----	F0002290	00EC40	00EC50	#0	#0		FM			
-00010EE0	-----	F0010EE0	000600	000608	#0	#15		fM Stack: Console Task			
...											
000114E8	-----	F00114E8	000FF8	001008	#0	#0		FM			
-000124F0	-----	F00124F0	001000	001008	#0	#15		fM			
-00017D30	-----	F0017D30	00003C	000044	#0	#15		fM SysAppInfoPtr: AMX			
-00017D74	-----	F0017D74	000008	000010	#0	#15		fM Feature Manager Globals			
(FtrGlobalsType)											
-00017D84	-----	F0017D84	000024	00002C	#0	#15		fM DmOpenInfoPtr: 'Update			
3.0.2'											
-00017DB0	-----	F0017DB0	00000E	000016	#0	#15		fM DmOpenRef: 'Update			
3.0.2'											
-00017DC6	-----	F0017DC6	0001F4	0001FC	#0	#15		fM Handle Table: 'Ô®Update			
3.0.2'											
-00017FC2	-----	F0017FC2	000024	00002C	#0	#15		fM DmOpenInfoPtr:			
'Ô®Update 3.0.2'											
-00017FEE	-----	F0017FEE	00000E	000016	#0	#15		fM DmOpenRef: 'Ô®Update			
3.0.2'											

Heap Summary:											
flags:		8000									
size:		016B80									
numHandles:		#40									
Free Chunks:		#14	(010C50	bytes)							
Movable Chunks:		#51	(005E80	bytes)							
Non-Movable Chunks:		#0	(000000	bytes)							

help (?)

Purpose Displays a list of commands or help for a specific command.

Usage `help`
`help <command>`

Parameters `command` The name of the command for which you want help displayed.

Comments

NOTE: You can use the `help` command in either the Console window or the debugging window.

Example `help hchk`

Do a Heap Check.
Syntax: `hchk <hex heapID> [options...]`
 `-c` : Check contents of each chunk

hl

Purpose Displays a list of memory heaps.

Usage `hl <cardNum>`

Parameters `cardNum` The card number on which the heaps are located. You almost always use 0 to specify the built-in RAM.

Comments Use the `hl` command to list the memory heaps in built-in RAM or on a card.

Palm Debugger Command Reference

Debugging Window Commands

NOTE: You can use the `hl` command in either the Console window or the debugging window.

Example

```
hl 0
```

index	heapID	heapPtr	size	free	maxFree	flags
0	0000	00001480	00016B80	00010C50	0000EC48	8000
1	0001	1001810E	001E7EF2	0014AD6A	00147D3A	8000
2	0002	10C08212	00118DEE	0000A01C	0000A014	8001

ht

Purpose Displays summary information for the specified heap.

Usage `ht 0`

Parameters None.

Comments The `ht` commands displays the summary information that is also shown at the end of a heap dump generated by the [hd](#) command.

NOTE: You can use the `ht` command in either the Console window or the debugging window.

Example

```
ht 0000
Displaying Heap ID: 0000, mapped to 00001480
-----
Heap Summary:
  flags:                8000
  size:                 016B80
  numHandles:          #40
  Free Chunks:         #14      (010CAA bytes)
```

Movable Chunks: #48 (005E26 bytes)
 Non-Movable Chunks: #0 (000000 bytes)

il

Purpose Disassembles code in a specified line range.

Usage il [<addr> | <"funcName"> [lineCount]]

Parameters	addr	Optional. The starting address at which to disassemble.
	funcName	Optional. The name of the function whose code you want disassembled.
	lineCount	Optional. If you provide a value for addr, you can also specify the number of lines of code to disassemble starting at addr.

Comments Use the il command to disassemble code. If you do not provide a function name or starting address value, disassembly begins at the current program counter value.

Example

il 0100

00000100	BTST	D0,D1		0101
00000102	ORI.B	#\$B0,D0 ; '.'		0000 02B0
00000106	ORI.B	#\$30,D1 ; '0'		0001 7830
0000010A	ORI.B	#\$01,D0 ; '.'		0000 0001
0000010E				474A
00000110	CoProc			FF00 0000 0318
00000116	ORI.B	#\$BC,D0 ; '.'		0000 03BC
0000011A	ORI.B	#\$72,D1 ; 'r'		0001 7D72
0000011E	ORI.B	#\$BC,D1 ; '.'		0001 6FBC
00000122	ORI.B	#\$22,D0 ; '"'		0000 0722

Palm Debugger Command Reference

Debugging Window Commands

Info

Purpose Displays information about a memory chunk.

Usage `info (<hexChunkPtr> | localID>) [options]`

Parameters `hexChunkPtr` or `localID`
A pointer to a chunk in memory, or the ID of a chunk on the specified card number.

`options`
Optional. You can specify the following options:

- `-card <cardNum>`
The card number if a local ID is specified instead of a chunk pointer.

Comments

NOTE: You can use the `info` command in either the Console window or the debugging window. However, the command options must be prefaced with the “\” character in the debugging window, rather than with the “-” character that you use in the console window version.

Example

keywords

Purpose Lists all debugger keywords.

Usage `keywords`

Parameters None.

Example `keywords`

t
g
SR
PC
SP
A7
A6
A5
A4
A3
A2
A1
A0
D7
...

load

Purpose Loads the data fork of a file at the specified address.

Usage `load <"fileName"> <addr>`

Parameters	<code>fileName</code>	The quoted name of the file whose data fork you want loaded.
	<code>addr</code>	The memory address at which you want the data fork loaded.

opened

Purpose Lists all of the currently opened databases.

Usage `opened`

Parameters None.

NOTE: You can use the `opened` command in either the Console window or the debugging window.

Palm Debugger Command Reference

Debugging Window Commands

Example

opened

name	resDB	cardNum	accessP	ID	openCnt	mode
*Graffiti ShortCuts	yes	0 00017D5C	001FFE7F		1	0007
*System	yes	0 00017FEE	00D20A44		1	0005

Total: 2 databases opened

penv

Purpose Displays current environment information for the debugger.

Usage penv

Parameters None.

Comments The penv command displays the current values of the predefined debugger environment variables, which are summarized in [Debugger Environment Variables](#).

Example

```
penv
=====
DebOut = false
SymbolsOn = true
StepRegs = false
ReadMemHack = false
Attached = true

.....
dot address = 00000000
last address = 00001022
last count = 0000000a
=====
```

reg

Purpose Displays all registers.

Usage `reg`

Parameters None.

Example `reg`

```
D0 = 00000102    A0 = 10C0EEF6    USP = BF6E446F
D1 = 00000013    A1 = 10C0EF0E    SSP = 000132E4
D2 = 00000027    A2 = 000133C2
D3 = 00000000    A3 = 00015404
D4 = 00014B06    A4 = 10CCFB7C
D5 = 00000000    A5 = 000149AA
D6 = 00D1EFE8    A6 = 000133AC    PC  = 10C0EEFE
D7 = 0001515E    A7 = 000132E4    SR  = tSxnzvc    Int = 0
```

reset

Purpose Performs a soft reset on the handheld device.

Usage `reset`

Parameters None.

Comments This command performs the same reset that is performed when you press the recessed reset button on a Palm Powered handheld device. It resets the memory system and reformats both cards.

NOTE: You can use the `reset` command in either the Console window or the debugging window.

Example `reset`
Resetting system

Palm Debugger Command Reference

Debugging Window Commands

run

Purpose Runs a debugger script from file.

Usage run <"fileName">

Parameters filename The quoted name of the file that contains the debugger script.

s

Purpose Single steps the processor, stepping into subroutines.

Usage s

Parameters None.

Example s

```
'SysHandleEvent '  
+$0694 10C0F080 *MOVEM.L (A7)+,D3-D5/A2-A4 | 4CDF 1C38
```

save

Purpose Saves a range of data from memory to file.

Usage save <"fileName"> <addr> <numBytes>

Parameters fileName The quoted name of the file to which you want the data saved.

addr The starting address in memory to save.

numBytes The number of bytes to save.

Example save "savedMem1" 0100 100

sb

Purpose Sets the value of the byte at the specified address.

Usage `sb <addr> <value>`

Parameters

<code>addr</code>	The address of the byte.
<code>value</code>	The byte value.

Example

```
sb 0111 0a

Memory set starting at 00000111
```

sc

Purpose Displays a list of functions on the stack using information stored in the A6 frame pointer register.

Usage `sc [<addr> [<frames>]]`

Parameters

<code>addr</code>	Optional. The address from which to start listing.
<code>frames</code>	Optional. The number of frames to list. You can specify this only if you specify a value for <code>addr</code> .

Example

```
sc
Calling chain using A6 Links:
A6 Frame     Caller
00000000     10C68982     cjtken+0000
00015086     10C6CA26     __Startup__+0060
00015066     10C6CCCE     PilotMain+0250
00014FC2     10C0F808     SysAppLaunch+0458
00014F6E     10C10258     PrvCallWithNewStack+0016
00013414     10CCFBEO     __Startup__+0060
000133F4     10CD08CE     PilotMain+0036
000133DA     10CD6D18     EventLoop+0016
```

Palm Debugger Command Reference

Debugging Window Commands

sc6

Purpose Lists the A6 stack frame chain, starting at the specified address.

Usage `sc6 [<addr> [<frames>]]`

Parameters

<code>addr</code>	Optional. The address from which to start listing.
<code>frames</code>	Optional. The number of frames to list. You can specify this only if you specify a value for <code>addr</code> .

Comments This command is the same as the [sc](#) command.

Example

```
sc
Calling chain using A6 Links:
A6 Frame    Caller
00000000    10C68982    cjtken+0000
00015086    10C6CA26    __Startup__+0060
00015066    10C6CCCE    PilotMain+0250
00014FC2    10C0F808    SysAppLaunch+0458
00014F6E    10C10258    PrvCallWithNewStack+0016
00013414    10CCFBEO    __Startup__+0060
000133F4    10CD08CE    PilotMain+0036
000133DA    10CD6D18    EventLoop+0016
```

sc7

Purpose Displays a list of functions on the stack using the stack pointer (A7). This displays information about functions on the stack that do not set up frame pointers

Usage `sc7 [<addr> [<frames>]]`

Parameters

<code>addr</code>	Optional. The address from which to start listing.
<code>frames</code>	Optional. The number of frames to list. You can specify this only if you specify a value for <code>addr</code> .

Comments Use the `sc7` command instead of the standard `stack crawl` command, `sc`, when you want to display information about routines on the stack that have not set up frame pointers. Note that this command will sometimes display bogus routines.

Example `sc7`

```
Return Addresses on the stack:
Stack Addr  Caller
00013AFC    00000000
000133B0    10CD6D18  EventLoop+0016
00013344    10C1F964  PrvHandleExchangeEvents+0028
```

sizeof

Purpose Displays the size, in bytes, of a template.

Usage `sizeof <template>`

Parameters `template` The name of the template.

Comments You can use the [templates](#) command to list the available templates.

Example `sizeof sdword`
Size = 4 byte(s)

sl

Purpose Sets the value of the 32-bit long integer at the specified address.

Usage `sl <addr> <value>`

Parameters `addr` The address of the 32-bit value.
`value` The long value.

Example `sl 0110 ffffffff`

Palm Debugger Command Reference

Debugging Window Commands

Memory set starting at 00000110

SS

Purpose Breaks into the debugger when the value of the long word at the specified address changes.

Usage `ss [<addr>]`

Parameters `addr` Optional. The address of the 32-bit value. If you do not specify an address value, the current program counter location is used.

Example `ss 1000F024`

storeInfo

Purpose Displays information about a memory store.

Usage `storeinfo <cardNum>`

Parameters `cardNum` The card number for which you want information displayed. You almost always use 0 to specify the built-in RAM.

Comments

NOTE: You can use the `storeinfo` command in either the Console window or the debugging window.

Example `storeinfo 0`

ROM Store:
version: 0001

```
flags: 0000
name: ROM Store
creation date: 00000000
backup date: 00000000
heap list offset: 00C08208
init code offset1: 00C0D652
init code offset2: 00C1471E
database dirID: 00D20F7E
```

```
RAM Store:
version: 0001
flags: 0001
name: RAM Store 0
creation date: 00000000
backup date: 00000000
heap list offset: 00018100
init code offset1: 00000000
init code offset2: 00000000
database dirID: 0001811F
```

SW

Purpose Sets the value of the word at the specified address.

Usage `sw <addr> <value>`

Parameters

<code>addr</code>	The address of the 16-bit value.
<code>value</code>	The word value.

Example

```
sw 0110 ffff
Memory set starting at 00000110
```

Palm Debugger Command Reference

Debugging Window Commands

t

Purpose Single steps the processor, stepping over subroutines.

Usage t

Parameters None.

Example t

```
'SysHandleEvent '  
Will Branch  
+$0514 10C0EF00 *BRA.W SysHandleEvent+$0694 ;  
10C0F080 |6000 017E
```

templates

Purpose Lists the names of the debugger templates.

Usage templates

Parameters None.

Example templates

```
Char  
Byte  
SByte  
Word  
SWord  
DWord  
SDWord
```

typedef

Purpose	Begins a structure definition block.	
Usage	<code>typedef struct <"name"></code>	
Parameters	<code>name</code>	The quoted name of the template whose definition you are beginning.
Comments	Use the <code>typedef</code> command in conjunction with the > and typeend commands to defined structure templates that you can use to display complex structures with a single memory display (dm) command.	
Example	<pre>typedef struct "PointType" > SWord "X" > SWord "Y" typeend</pre>	

typeend

Purpose	Ends a structure definition block.	
Usage	<code>typeend</code>	
Parameters	None.	
Comments	Use the <code>typedef</code> command in conjunction with the > and typeend commands to defined structure templates that you can use to display complex structures with a single memory display (dm) command.	
Example	<pre>typedef struct "PointType" > SWord "X" > SWord "Y" typeend</pre>	

Palm Debugger Command Reference

Debugging Window Commands

var

Purpose Defines a debugger variable.

Usage `var <"name"> [<initialValue>]`

Parameters

<code>name</code>	The quoted name of the variable that you are defining.
<code>initialValue</code>	Optional. The initial value for the variable. If you are assigning a string value to the variable, you must quote the initial value.

Example

```
var "testvar" 100

var "testvar" "Hello"
WARNING: redefining variable: testvar
```

variables

Purpose Lists the names of the debugger variables.

Usage `variables`

Parameters None.

Example

```
variables

DebOut
SymbolsOn
ReadMemHack
StepRegs
Attached
testvar
testvar2
```


wh

Purpose Displays system function information for a specified function name or A-Trap number. Also identifies the memory chunk that contains a specific address or lists all system functions.

Usage `wh [\a <addr>] [<"funcName"> | <ATrapNumber>]`

Parameters	<code>addr</code>	Specifies an address. The wh command displays the memory chunk that contains this address.
	<code>funcName</code>	The quoted name of the system function for which you want information displayed.
	<code>ATrapNumber</code>	The number of the A-trap number for which you want information displayed.

Debugging Command Summary

Flow Control Commands

<code>atb</code>	Adds an A-Trap break.
<code>atc</code>	Clears an A-Trap break.
<code>atd</code>	Displays a list of all A-Trap breaks.
<code>att</code>	Attach to the handheld device.
<code>br</code>	Sets a breakpoint at the specified address.
<code>brc</code>	Clears a breakpoint or all breakpoints.
<code>brd</code>	Displays a list of all breakpoints.
<code>cl</code>	Clears a breakpoint or all breakpoints.
<code>dx</code>	Enables or disables <code>DbgBreak()</code> breaks.
<code>g</code>	Continues execution.

Palm Debugger Command Reference

Debugging Command Summary

gt	Sets a temporary breakpoint at the specified address, and resumes execution from the current program counter.
reset	Resets the memory system and formats both cards.
s	Single steps the processor, stepping into subroutines.
ss	Breaks into the debugger when the long word value at the specified address changes.
t	Single steps the processor, stepping over subroutines.

Memory Commands

atr	Registers a function name with an A-Trap number.
db	Displays the byte value at a specified address.
dl	Displays the 32-bit long value at a specified address.
dm	Displays memory for a specified number of bytes or templates.
dw	Displays the 16-bit word value at a specified address.
fb	Searches through a range of memory for a specified byte value.
fill	Fills memory with a specified byte value.
fl	Searches through a range of memory for a specified 32-bit long value.
ft	Searches through a range of memory for the specified text.
fw	Searches through a range of memory for the specified 16-bit word value.
il	Disassembles code in a specified line range.

<code>sb</code>	Sets the value of the byte at the specified address.
<code>sc</code>	Lists the A6 stack frame chain, starting at the specified address.
<code>sc6</code>	Lists the A6 stack frame chain, starting at the specified address.
<code>sc7</code>	Lists the A7 stack frame chain, starting at the specified address.
<code>sl</code>	Sets the value of the long at the specified address.
<code>sw</code>	Sets the value of the word at the specified address.
<code>wh</code>	Displays system function information for a specified function name or A-Trap number. Also identifies the memory chunk that contains a specific address or lists all system functions.

Template Commands

<code>></code>	Defines a structure field.
<code>sizeof</code>	Displays the size, in bytes, of a template.
<code>templates</code>	Lists the names of the debugger templates.
<code>typedef</code>	Begins a structure definition block.
<code>typeend</code>	Ends a structure definition block.

Register Commands

<code>reg</code>	Displays all registers.
------------------	-------------------------

Utility Commands

<code>alias</code>	Defines or displays an alias.
<code>aliases</code>	Displays all debugger alias names.
<code>bootstrap</code>	Loads a ROM image into memory on the handheld device, using the bootstrap mode of the processor.

Palm Debugger Command Reference

Debugging Command Summary

flash	Loads the file's data fork into Flash Memory at the specified address.
keywords	Lists all debugger keywords.
load	Loads the file's data fork at the specified remote address.
run	Runs a debugger script.
save	Saves a range of data from memory to file.
var	Defines a debugger variable.
variables	Lists the names of the debugger variables.

Console Commands

CardInfo	Retrieves information about a memory card.
Dir	Lists the databases.
Dump	Dumps a range of memory to a file.
HChk	Checks a heap.
HD	Displays a dump of a memory heap.
HL	Lists all of the memory heaps on the specified memory card.
HT	Performs a heap total.
Info	Displays information on a heap chunk.
Opened	Lists all currently opened databases.
StoreInfo	Retrieves information about a memory store.

Miscellaneous Debugger Commands

help (or ?)	Displays a list of available commands.
help <cmd> or ? <cmd>	Displays help for a specific command.
penv	Displays debugger environment information.

Debugger Environment Variables

DebOut	A Boolean value that specifies if debug style output is enabled.
ReadMemHack	A Boolean value that specifies if the read memory hack is enabled.
SymbolsOn	A Boolean value that specifies if printing of disassembly symbols is enabled.
StepRegs	A Boolean value that specifies if register values should be shown after every step.

Predefined Constants

true	Integer value 1.
false	Integer value 0.
srCmask	The status register Carry bit.
srImask	The status register Interrupt field mask.
srNmask	The status register Negative bit.
srSmask	The status register Supervisor bit.
srTmask	The status register Trace bit.
srVmask	The status register Overflow bit.
srXmask	The status register extend bit.
srZmask	The status register Zero bit.

Debugger Protocol Reference

This appendix describes the debugger protocol, which provides an interface between a debugging target and a debugging host. For example, the Palm Debugger and the Palm OS® Emulator use this protocol to exchange commands and information.

IMPORTANT: This chapter describes the version of the Palm Debugger protocol that shipped on the Metrowerks CodeWarrior for the Palm™ Operating System, Version 6 CD-ROM. If you are using a different version, the features in your version might be different from the features described here.

This chapter covers the following topics:

- “[About the Palm Debugger Protocol](#)” on page 271
- “[Constants](#)” on page 274
- “[Data Structures](#)” on page 276
- “[Debugger Protocol Commands](#)” on page 278
- “[Summary of Debugger Protocol Packets](#)” on page 299

About the Palm Debugger Protocol

The Palm debugger protocol allows a *debugging target*, which is usually a handheld device ROM or an emulator program such as the Palm OS Emulator, to exchange information with a *debugging host*, such as the Palm Debugger or the Metrowerks debugger.

The debugger protocol involves sending packets between the host and the target. When the user of the host debugging program enters a command, the host converts that command into one or more command packets and sends each packet to the debugging target. In

Debugger Protocol Reference

About the Palm Debugger Protocol

most cases, the target subsequently responds by sending a packet back to the host.

Packets

There are three packet types used in the debugger protocol:

- The debugging host sends *command request packets* to the debugging target.
- The debugging target sends *command response packets* back to the host.
- Either the host or the target can send a *message packet* to the other.


Although the typical flow of packets involves the host sending a request and the target sending back a response, although there are a some exceptions, as follows:

- The host can send some requests to the target that do not result in a response packet being returned. For example, when the host sends the `Continue` command packet to tell the target to continue execution, the target does not send back a response packet.
- The target can send response packets to the host without receiving a request packet. For example, whenever the debugging target encounters an exception, it sends a `State` response packet to the host.

Packet Structure

Each packet consists of a packet header, a variable-length packet body, and a packet footer, as shown in [Figure 6.1](#).

Figure 6.1 Packet Structure



The Packet Header

The packet header starts with the 24-bit key value \$BEEFFD and includes header information and a checksum of the header itself.

The Packet Body

The packet body contains the command byte, a filler byte, and between 0 and 270 bytes of data. See “[SysPktBodyCommon](#)” on page 276 for a description of the structure used to represent the two byte body header (the command and filler bytes), and see [Table 6.1](#) for a list of the command constants.

The Packet Footer

The packet footer contains a 16-bit CRC of the header and body. Note that the CRC computation does not include the footer.

Packet Communications

The communications protocol between the host and target is very simple: the host sends a request packet to the target and waits for a time-out or for a response from the target.

If a response is not detected within the time-out period, the host does not retry the request. When a response does not come back before timing out, it usually indicates that one of two things is happening:

- the debugging target is busy executing code and has not encountered an exception
- the state of the debugging target has degenerated so badly that it cannot respond

The host has the option of displaying a message to the user to inform him or her that the debugging target is not responding.

Constants

This section describes the constants and structure types that are used with the packets for various commands.

Packet Constants

```
#define sysPktMaxMemChunk256
#define sysPktMaxBodySize (sysPktMaxMemChunk+16)
#define sysPktMaxNameLen32
```

`sysPktMaxMemChunk`

The maximum number of bytes that can be read by the Read Memory command or written by the Write Memory command.

`sysPktMaxBodySize`

The maximum number of bytes in a request or response packet.

`sysPktMaxNameLen`

The maximum length of a function name.

State Constants

```
#define sysPktStateRspInstWords15
```

`sysPktStateRspInstWords`
The number of remote code words sent in the response packet for the State command.

Breakpoint Constants

```
#define dbgNormalBreakpoints5
#define dbgTempBPIndexdbNormalBreakpoints
#define dbgTotalBreakpoints (dbgTempBPIndex+1)
```

`dbgNormalBreakpoints`
The number of normal breakpoints available in the debugging target.

`dbgTempBPIndex`
The index in the breakpoints array of the temporary breakpoint.

`dbgTotalBreakpoints`
The total number of breakpoints in the breakpoints array, including the normal breakpoints and the temporary breakpoint.

Command Constants

Each command is represented by a single byte constant. The upper bit of each request command is clear, and the upper bit of each response command is set. [Table 6.1](#) shows the command constants.

Table 6.1 Debugger protocol command constants

Command	Request constant	Response constant
Continue	<code>sysPktContinueCmd</code>	N/A
Find	<code>sysPktFindCmd</code>	<code>sysPktFindRsp</code>
Get Breakpoints	<code>sysPktGetBreakpointsCmd</code>	<code>sysPktGetBreakpointsRsp</code>
Get Routine Name	<code>sysPktGetRtnNameCmd</code>	<code>sysPktGetRtnNameRsp</code>

Debugger Protocol Reference

Data Structures

Table 6.1 Debugger protocol command constants (*continued*)

Command	Request constant	Response constant
Get Trap Breaks	sysPktGetTrapBreaksCmd	sysPktGetTrapBreaksRsp
Get Trap Conditionals	sysPktGetTrapConditionalsCmd	sysPktGetTrapConditionalsRsp
Message	sysPktRemoteMsgCmd	N/A
Read Memory	sysPktReadMemCmd	sysPktReadMemRsp
Read Registers	sysPktReadRegsCmd	sysPktReadRegsRsp
RPC	sysPktRPCCmd	sysPktRPCRsp
Set Breakpoints	sysPktSetBreakpointsCmd	sysPktSetBreakpointsRsp
Set Trap Breaks	sysPktSetTrapBreaksCmd	sysPktSetTrapBreaksRsp
Set Trap Conditionals	sysPktSetTrapConditionalsCmd	sysPktSetTrapConditionalsRsp
State	sysPktStateCmd	sysPktStateRsp
Toggle Debugger Breaks	sysPktDbgBreakToggleCmd	sysPktDbgBreakToggleRsp
Write Memory	sysPktWriteMemCmd	sysPktWriteMemRsp
Write Registers	sysPktWriteRegsCmd	sysPktWriteRegsRsp

Data Structures

This section describes the data structures used with the request and response packets for the debugger protocol commands.

_SysPktBodyCommon

The `_SysPktBodyCommon` macro defines the fields common to every request and response packet.

```
#define _sysPktBodyCommon \  
    Byte command; \  
    Byte _filler;
```

Fields

<code>command</code>	The 1-byte command value for the packet.
<code>_filler</code>	Included for alignment only. Not used.

SysPktBodyType

The `SysPktBodyType` represents a command packet that is sent to or received from the debugging target.

```
typedef struct SysPktBodyType
{
    _SysPktBodyCommon;
    Byte data[sysPktMaxBodySize-2];
} SysPktBodyType;
```

Fields

<code>_SysPktBodyCommon</code>	The command header for the packet.
<code>data</code>	The packet data.

SysPktRPCParamType

The `SysPktRPCParamType` is used to send a parameter in a remote procedure call. See the [RPC](#) command for more information.

```
typedef struct SysPktRPCParamInfo
{
    Byte byRef;
    Byte size;
    Word data[?];
} SysPktRPCParamType;
```

Fields

<code>byRef</code>	Set to 1 if the parameter is passed by reference.
<code>size</code>	The number of bytes in the data array. This must be an even number.
<code>data</code>	The parameter data.

BreakpointType

The BreakpointType structure is used to represent the status of a single breakpoint on the debugging target.

```
typedef struct BreakpointType
{
    Ptr      addr;
    Boolean  enabled;
    Boolean  installed;
} BreakpointType;
```

Fields

addr	The address of the breakpoint. If this is set to 0, the breakpoint is not in use.
enabled	A Boolean value. This is TRUE if the breakpoint is currently enabled, and FALSE if not.
installed	Included for correct alignment only. Not used.

Debugger Protocol Commands

This section describes each command that you can send to the debugging target, including a description of the response packet that the target sends back.

Continue

Purpose Tells the debugging target to continue execution.

Comments This command usually gets sent when the user specifies the Go command. Once the debugging target continues execution, the debugger is not reentered until a breakpoint or other exception is encountered.

NOTE: The debugging target does not send a response to this command.

Commands The Continue request command is defined as follows:

```
#define sysPktContinueCmd0x07
```

Request Packet

```
typedef struct SysPktContinueCmdType
{
    _sysPktBodyCommon;
    M68KresgType  regs;
    Boolean       stepSpy;
    DWord         ssAddr;
    DWord         ssCount;
    DWord         ssChecksum;
}SysPktContinueCmdType;
```

Fields

<— _sysPktBodyCommon	The common packet header, as described in _SysPktBodyCommon .
—> regs	The new values for the debugging target processor registers. The new register values are stored in sequential order: D0 to D7, followed by A0 to A6.
—> stepSpy	A Boolean value. If this is TRUE, the debugging target continues execution until the value that starts at the specified step-spy address changes. If this is FALSE, the debugging target continue execution until a breakpoint or other exception is encountered.
—> ssAddr	The step-spy starting address. An exception is generated when the value starting at this address, for ssCount bytes, changes on the debugging target.
—> ssCount	The number of bytes in the “spy” value.
—> ssChecksum	A checksum for the “spy” value.

Find

Purpose Searches for data in memory on the debugging target.

Comments .

Commands The Find request and response commands are defined as follows:

```
#define sysPktFindCmd0x13
#define sysPktFindRsp0x93
```

Request Packet

```
typedef struct SysPktFindCmdType
{
    _sysPktBodyCommon;
    DWord    firstAddr;
    DWord    lastAddr;
    Word     numBytes
    Boolean   caseInsensitive;
    Byte     searchData[?];
}SysPktFindCmdType;
```

Fields

—> `_sysPktBodyCommon` The common packet header, as described in [SysPktBodyCommon](#).

—> `firstAddr` The starting address of the memory range on the debugging target to search for the data.

—> `lastAddr` The ending address of the memory range on the debugging target to search for the data.

—> `numBytes` The number of bytes of data in the search string.

—> `searchData` The search string. The length of this array is defined by the value of the `numBytes` field.

Response Packet

```
typedef struct SysPktFindRspType
{
    _sysPktBodyCommon;
```



```

        DWord    addr;
        Boolean  found;
    }SysPktFindRspType

```

Fields

<— _sysPktBodyCommon	The common packet header, as described in SysPktBodyCommon .
<— addr	The address of the data string in memory on the debugging target.
<— found	A Boolean value. If this is TRUE, the search string was found on the debugging target, and the value of addr is valid. If this is FALSE, the search string was not found, and the value of addr is not valid.

Get Breakpoints

Purpose	Retrieves the current breakpoint settings from the debugging target.
Comments	<p>The body of the response packet contains an array with dbgTotalBreakpoints values in it, one for each possible breakpoint.</p> <p>If a breakpoint is currently disabled on the debugging target, the enabled field for that breakpoint is set to 0.</p> <p>If a breakpoint address is set to 0, the breakpoint is not currently in use.</p> <p>The dbgTotalBreakpoints constant is described in “Breakpoint Constants” on page 275.</p>
Commands	<p>The Get Breakpoints command request and response commands are defined as follows:</p> <pre> #define sysPktGetBreakpointsCmd0x0B #define sysPktGetBreakpointsRsp0x8B </pre>

Debugger Protocol Reference

Debugger Protocol Commands

Request Packet

```
typedef struct SysPktGetBreakpointsCmdType
{
    _sysPktBodyCommon;
}SysPktGetBreakpointsCmdType
```

Fields

—> _sysPktBodyCommon
The common packet header, as described in [_SysPktBodyCommon](#).

Response Packet

```
typedef struct SysPktGetBreakpointsRspType
{
    _sysPktBodyCommon;
    BreakpointType db[dbgTotalBreakpoints];
}SysPktGetBreakpointsRspType
```

Fields

<— _sysPktBodyCommon
The common packet header, as described in [_SysPktBodyCommon](#).

<— bp
An array with an entry for each of the possible breakpoints. Each entry is of the type [BreakpointType](#).

Get Routine Name

Purpose Determines the name, starting address, and ending address of the function that contains the specified address.

Comments The name of each function is imbedded into the code when it gets compiled. The debugging target can scan forward and backward in the code to determine the start and end addresses for each function.

Commands The Get Routine Name command request and response commands are defined as follows:

```
#define sysPktGetRtnNameCmd0x04
#define sysPktGetRtnNameRsp0x84
```

Request Packet

```
typedef struct SysPktRtnNameCmdType
{
    _sysPktBodyCommon;
    void*    address
}SysPktRtnNameCmdType;
```

Fields

- > _sysPktBodyCommon The common packet header, as described in [_SysPktBodyCommon](#).
- > address The code address whose function name you want to discover.

Response Packet

```
typedef struct SysPktRtnNameRspType
{
    _sysPktBodyCommon;
    void*    address;
    void*    startAddr;
    void*    endAddr;
    char     name[sysPktMaxNameLen] ;
}SysPktRtnNameRspType;
```

Fields

- <— _sysPktBodyCommon The common packet header, as described in [_SysPktBodyCommon](#).
- <— address The code address whose function name was determined. This is the same address that was specified in the request packet.
- <— startAddr The starting address in target memory of the function that includes the address.

Debugger Protocol Reference

Debugger Protocol Commands

<code><— endAddr</code>	The ending address in target memory of the function that includes the address. If a function name could not be found, this is the last address that was scanned.
<code><— name</code>	The name of the function that includes the address. This is a null-terminated string. If a function name could not be found, this is the null string.

Get Trap Breaks

Purpose Retrieves the settings for the trap breaks on the debugging target.

Comments Trap breaks are used to force the debugging target to enter the debugger when a particular system trap is called.

The body of the response packet contains an array with `dbgTotalBreakpoints` values in it, one for each possible trap break.

Each trap break is a single word value that contains the system trap number.

Commands The `Get Trap Breaks` request and response commands are defined as follows:

```
#define sysPktGetTrapBreaksCmd0x10
#define sysPktGetTrapBreaksRsp0x90
```

Request Packet

```
typedef struct SysPktGetTrapBreaksCmdType
{
    _sysPktBodyCommon;
} SysPktGetTrapBreaksCmdType;
```

Fields

—> `_sysPktBodyCommon`

The common packet header, as described in [_SysPktBodyCommon](#).

Response Packet

```
typedef struct SysPktGetTrapBreaksRspType
{
    _sysPktBodyCommon;
    Word trapBP[dbgTotalTrapBreaks];
}SysPktGetTrapBreaksRspType;
```

Fields

<— `_sysPktBodyCommon` The common packet header, as described in [_SysPktBodyCommon](#).

<— `trapBP` An array with an entry for each of the possible trap breaks. A value of 0 indicates that the trap break is not used.

Get Trap Conditionals

Purpose Retrieves the trap conditionals values from the debugging target.

Comments Trap conditionals are used when setting A-Traps for library calls. You can set a separate conditional value for each A-Trap.

The body of the response packet contains an array with `dbgTotalBreakpoints` values in it, one for each possible trap break.

Each trap conditional is a value; if the value of the first word on the stack matches the conditional value when the trap is called, the debugger breaks.

Commands The Get Trap Conditionals request and response commands are defined as follows:

```
#define sysPktGetTrapConditionsCmd0x14
#define sysPktGetTrapConditionsRsp0x94
```

Request Packet

```
typedef struct SysPktGetTrapConditionsCmdType
{
    _sysPktBodyCommon;
}SysPktGetTrapConditionsCmdType
```

Debugger Protocol Reference

Debugger Protocol Commands

Fields

—> `_sysPktBodyCommon`

The common packet header, as described in [_SysPktBodyCommon](#).

Response Packet

```
typedef struct SysPktGetTrapConditionsRspType
{
    _sysPktBodyCommon;
    Word trapParam[dbgTotalTrapBreaks];
}SysPktGetTrapConditionsRspType
```

Fields

<— `_sysPktBodyCommon`

The common packet header, as described in [_SysPktBodyCommon](#).

<— `trapParam` An array with an entry for each of the possible trap breaks. A value of 0 indicates that the trap conditional is not used.

Message

Purpose Sends a message to display on the debugging target.

Comments Application can compile debugger messages into their code by calling the `DbgMessage` function.

The debugging target does not send back a response packet for this command.

Commands The Message request command is defined as follows:

```
#define sysPktRemoteMsgCmd0x7F
```

Request Packet

```
typedef struct SysPktRemoteMsgCmdType
{
    _sysPktBodyCommon;
    Byte text[1];
}SysPktRemoteMsgCmdType;
```

Fields

—> `_sysPktBodyCommon` The common packet header, as described in [SysPktBodyCommon](#).

—> `text` .

Read Memory

Purpose Reads memory values from the debugging target.

Comments This command can read up to `sysPktMaxMemChunk` bytes of memory. The actual size of the response packet depends on the number of bytes requested in the request packet.

Commands The Read Memory command request and response commands are defined as follows:

```
#define sysPktReadMemCmd0x01
#define sysPktReadMemRsp0x81
```

Request Packet

```
typedef struct SysPktReadMemCmdType
{
    _sysPktBodyCommon;
    void*    address;
    Word     numBytes;
}SysPktReadMemCmdType;
```

Fields

—> `_sysPktBodyCommon` The common packet header, as described in [SysPktBodyCommon](#).

—> `address` The address in target memory from which to read values.

—> `numBytes` The number of bytes to read from target memory.

Debugger Protocol Reference

Debugger Protocol Commands

Response Packet

```
typedef struct SysPktReadMemRspType
{
    _sysPktBodyCommon;
    //Byte data[?];
}SysPktReadMemRspType;
```

Fields

<— `_sysPktBodyCommon` The common packet header, as described in [_SysPktBodyCommon](#).

<— `data` The returned data. The number of bytes in this field matches the `numBytes` value in the request packet.

Read Registers

Purpose Retrieves the value of each of the target processor registers.

Comments The eight data registers are stored in the response packet body sequentially, from D0 to D7. The seven address registers are stored in the response packet body sequentially, from A0 to A6.

Commands The Read Registers command request and response commands are defined as follows:

```
#define sysPktReadRegsCmd0x05
#define sysPktReadRegsRsp0x85
```

Request Packet

```
typedef struct SysPktReadRegsCmdType
{
    _sysPktBodyCommon;
}SysPktReadRegsCmdType;
```

Fields

—> `_sysPktBodyCommon` The common packet header, as described in [_SysPktBodyCommon](#).

Response Packet

```
typedef struct SysPktReadRegsRspType
{
    _sysPktBodyCommon;
    M68KRegsType reg;
}SysPktReadRegsRspType;
```

Fields

<— `_sysPktBodyCommon` The common packet header, as described in [SysPktBodyCommon](#).

<— `reg` The register values in sequential order: D0 to D7, followed by A0 to A6.

RPC

Purpose Sends a remote procedure call to the debugging target.

Comments .

Commands The RPC request and response commands are defined as follows:

```
#define sysPktRPCCmd0x0A
#define sysPktRPCRsp0x8A
```

Request Packet

```
typedef struct SysPktRPCType
{
    _sysPktBodyCommon;
    Word trapWord;
    DWord resultD0;
    DWord resultD0;
    Word numParams;
    SysPktRPCParamTypeparam[?];
}
```

Debugger Protocol Reference

Debugger Protocol Commands

Fields

—> <code>_sysPktBodyCommon</code>	The common packet header, as described in SysPktBodyCommon .
—> <code>trapWord</code>	The system trap to call.
—> <code>resultD0</code>	The result from the D0 register.
—> <code>resultA0</code>	The result from the A0 register.
—> <code>numParams</code>	The number of RPC parameter structures in the param array that follows.
—> <code>param</code>	An array of RPC parameter structures, as described in SysPktRPCParamType .

Set Breakpoints

Purpose Sets breakpoints on the debugging target.

Comments The body of the request packet contains an array with `dbgTotalBreakpoints` values in it, one for each possible breakpoint. If a breakpoint is currently disabled on the debugging target, the enabled field for that breakpoint is set to 0.

The `dbgTotalBreakpoints` constant is described in [Breakpoint Constants](#).

Commands The Set Breakpoints command request and response commands are defined as follows:

```
#define sysPktSetBreakpointsCmd0x0C
#define sysPktSetBreakpointsRsp0x8C
```

Request Packet

```
typedef struct SysPktSetBreakpointsCmdType
{
    _sysPktBodyCommon;
    BreakpointType db[dbgTotalBreakpoints];
}SysPktSetBreakpointsCmdType
```

Fields

- > `_sysPktBodyCommon`
The common packet header, as described in [SysPktBodyCommon](#).
- > `bp`
An array with an entry for each of the possible breakpoints. Each entry is of the type [BreakpointType](#).

Response Packet

```
typedef struct SysPktSetBreakpointsRspType
{
    _sysPktBodyCommon;
}SysPktSetBreakpointsRspType
```

Fields

- <— `_sysPktBodyCommon`
The common packet header, as described in [SysPktBodyCommon](#).

Set Trap Breaks

- Purpose** Sets breakpoints on the debugging target.
- Comments** The body of the request packet contains an array with `dbgTotalBreakpoints` values in it, one for each possible trap break. If a trap break is currently disabled on the debugging target, the value of that break is set to 0.
- The `dbgTotalBreakpoints` constant is described in [Breakpoint Constants](#).
- Commands** The Set Breakpoints command request and response commands are defined as follows:
- ```
#define sysPktSetTrapBreaksCmd0x0C
#define sysPktSetTrapBreaksRsp0x8C
```

## Debugger Protocol Reference

### Debugger Protocol Commands

---

**Request Packet**

```
typedef struct SysPktSetTrapBreaksCmdType
{
 _sysPktBodyCommon;
 Word trapBP[dbgTotalBreakpoints];
}SysPktSetTrapBreaksCmdType
```

#### Fields

- > `_sysPktBodyCommon`      The common packet header, as described in [\\_SysPktBodyCommon](#).
- > `trapBP`      An array with an entry for each of the possible trap breaks. If the value of an entry is 0, the break is not currently in use.

**Response Packet**

```
typedef struct SysPktSetTrapBreaksRspType
{
 _sysPktBodyCommon;
}SysPktSetTrapBreaksRspType
```

#### Fields

- <— `_sysPktBodyCommon`      The common packet header, as described in [\\_SysPktBodyCommon](#).

## Set Trap Conditionals

**Purpose**      Sets the trap conditionals values for the debugging target.

**Comments**      Trap conditionals are used when setting A-Traps for library calls. You can set a separate conditional value for each A-Trap.

The body of the request packet contains an array with `dbgTotalBreakpoints` values in it, one for each possible trap break.

Each trap conditional is a value; if the value of the first word on the stack matches the conditional value when the trap is called, the debugger breaks.

**Commands**      The Set Trap Conditionals request and response commands are defined as follows:

```
#define sysPktSetTrapConditionsCmd0x15
#define sysPktSetTrapConditionsRsp0x95
```

**Request Packet**

```
typedef struct SysPktSetTrapConditionsCmdType
{
 _sysPktBodyCommon;
 Word trapParam[dbgTotalTrapBreaks];
}SysPktSetTrapConditionsCmdType
```

**Fields**

- > \_sysPktBodyCommon      The common packet header, as described in [\\_SysPktBodyCommon](#).
- > trapParam      An array with an entry for each of the possible trap breaks. A value of 0 indicates that the trap conditional is not used.

**Response Packet**

```
typedef struct SysPktSetTrapConditionsRspType
{
 _sysPktBodyCommon;
}SysPktSetTrapConditionsRspType
```

**Fields**

- <— \_sysPktBodyCommon      The common packet header, as described in [\\_SysPktBodyCommon](#).

## Debugger Protocol Reference

### Debugger Protocol Commands

---

## State

**Purpose** Sent by the host program to query the current state of the debugging target, and sent by the target whenever it encounters an exception and enters the debugger.

**Comments** The debugging target sends the State response packet whenever it enters the debugger for any reason, including a breakpoint, a bus error, a single step, or any other reason.

**Commands** The State request and response commands are defined as follows:

```
#define sysPktStateCmd0x00
#define sysPktStateRsp0x80
```

**Request Packet**

```
typedef struct SysPktStateCmdType
{
 _sysPktBodyCommon;
} SysPktStateCmdType
```

### Fields

—> `_sysPktBodyCommon`

The common packet header, as described in [\\_SysPktBodyCommon](#).

**Response Packet**

```
typedef struct SysPktStateRspType
{
 _sysPktBodyCommon;
 Boolean resetted;
 Word exceptionId;
 M68KregsType reg;
 Word inst [sysPktStateRspInstWords] ;
 BreakpointTypebp [dbgTotalBreakpoints] ;
 void* startAddr;
 void* endAddr;
 char name [sysPktMaxNameLen] ;
 Byte trapTableRev;
} SysPktStateRspType;
```

**Fields**

|                                   |                                                                                                                                                         |
|-----------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------|
| <— <code>_sysPktBodyCommon</code> | The common packet header, as described in <a href="#">SysPktBodyCommon</a> .                                                                            |
| <— <code>resetted</code>          | A Boolean value. This is TRUE if the debugging target has just been reset.                                                                              |
| <— <code>exceptionId</code>       | The ID of the exception that caused the debugger to be entered.                                                                                         |
| <— <code>reg</code>               | The register values in sequential order: D0 to D7, followed by A0 to A6.                                                                                |
| <— <code>inst</code>              | A buffer of the instructions starting at the current program counter on the debugging target.                                                           |
| <— <code>bp</code>                | An array with an entry for each of the possible breakpoints. Each entry is of the type <a href="#">BreakpointType</a> .                                 |
| <— <code>startAddr</code>         | The starting address of the function that generated the exception.                                                                                      |
| <— <code>endAddr</code>           | The ending address of the function that generated the exception.                                                                                        |
| <— <code>name</code>              | The name of the function that generated the exception. This is a null-terminated string. If no name can be found, this is the null string.              |
| <— <code>trapTableRev</code>      | The revision number of the trap table on the debugging target. You can use this to determine when the trap table cache on the host computer is invalid. |

## Toggle Debugger Breaks

**Purpose** Enables or disables breakpoints that have been compiled into the code.

**Comments** A breakpoint that has been compiled into the code is a special TRAP instruction that is generated when source code includes calls to the DbgBreak and DbgSrcBreak functions.

Sending this command toggles the debugging target between enabling and disabling these breakpoints.

**Commands** The Toggle Debugger Breaks request and response commands are defined as follows:

```
#define sysPktDbgBreakToggleCmd0x0D
#define sysPktDbgBreakToggleRsp0x8D
```

**Request Packet**

```
typedef struct SysPktDbgBreakToggleCmdType
{
 _sysPktBodyCommon;
}SysPktDbgBreakToggleCmdType;
```

### Fields

—> \_sysPktBodyCommon  
The common packet header, as described in [\\_SysPktBodyCommon](#).

**Response Packet**

```
typedef struct SysPktDbgBreakToggleRspType
{
 _sysPktBodyCommon;
 Boolean newState
}SysPktDbgBreakToggleRspType;
```

### Fields

<— \_sysPktBodyCommon  
The common packet header, as described in [\\_SysPktBodyCommon](#).



`<— newState`      A Boolean value. If this is set to `TRUE`, the new state has been set to enable breakpoints that were compiled into the code. If this is set to `FALSE`, the new state has been set to disable breakpoints that were compiled into the code.

## Write Memory

**Purpose**      Writes memory values to the debugging target.

**Comments**      This command can write up to `sysPktMaxMemChunk` bytes of memory. The actual size of the request packet depends on the number of bytes that you want to write.

**Commands**      The `Write Memory` command request and response commands are defined as follows:

```
#define sysPktWriteMemCmd0x02
#define sysPktWriteMemRsp0x82
```

**Request Packet**

```
typedef struct SysPktWriteMemCmdType
{
 _sysPktBodyCommon;
 void* address;
 Word numBytes;
 //Byte data[?]
}SysPktWriteMemCmdType;
```

### Fields

`—> _sysPktBodyCommon`      The common packet header, as described in [SysPktBodyCommon](#).

`--> address`      The address in target memory to which the values are written.

`--> numBytes`      The number of bytes to write.

`--> data`      The bytes to write into target memory. The size of this field is defined by the `numBytes` parameter.

## Debugger Protocol Reference

### Debugger Protocol Commands

---

**Response Packet**

```
typedef struct SysPktWriteMemRspType
{
 _sysPktBodyCommon;
}SysPktWriteMemRspType;
```

#### Fields

<-- \_sysPktBodyCommon  
The common packet header, as described in [\\_SysPktBodyCommon](#).

## Write Registers

**Purpose** Sets the value of each of the target processor registers.

**Comments** The eight data registers are stored in the request packet body sequentially, from D0 to D7. The seven address registers are stored in the request packet body sequentially, from A0 to A6.

**Commands** The Write Registers command request and response commands are defined as follows:

```
#define sysPktWriteRegsCmd0x06
#define sysPktWriteRegsRsp0x86
```

**Request Packet**

```
typedef struct SysPktWriteRegsCmdType
{
 _sysPktBodyCommon;
 M68KRegsType reg;
}SysPktWriteRegsCmdType;
```

#### Fields

--> \_sysPktBodyCommon  
The common packet header, as described in [\\_SysPktBodyCommon](#).

—> reg                      The new register values in sequential order: D0 to D7, followed by A0 to A6.

**Response Packet**            typedef struct SysPktWriteRegsRspType  
                               {  
                                   \_sysPktBodyCommon;  
                               }SysPktWriteRegsRspType;

**Fields**

<— \_sysPktBodyCommon  
                               The common packet header, as described in [\\_SysPktBodyCommon](#).

## Summary of Debugger Protocol Packets

[Table 6.2](#) summarizes the command packets that you can use with the debugger protocol.

**Table 6.2    Debugger protocol command packets**

| Command                               | Description                                                                                                    |
|---------------------------------------|----------------------------------------------------------------------------------------------------------------|
| <a href="#">Continue</a>              | Tells the debugging target to continue execution.                                                              |
| <a href="#">Find</a>                  | Searches for data in memory on the debugging target.                                                           |
| <a href="#">Get Breakpoints</a>       | Retrieves the current breakpoint settings from the debugging target.                                           |
| <a href="#">Get Routine Name</a>      | Determines the name, starting address, and ending address of the function that contains the specified address. |
| <a href="#">Get Trap Breaks</a>       | Retrieves the settings for the trap breaks on the debugging target.                                            |
| <a href="#">Get Trap Conditionals</a> | Retrieves the trap conditionals values from the debugging target.                                              |

## Debugger Protocol Reference

### *Summary of Debugger Protocol Packets*

---

**Table 6.2 Debugger protocol command packets (*continued*)**

| Command                                | Description                                                                                                                                                      |
|----------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <a href="#">Message</a>                | Sends a message to display on the debugging target.                                                                                                              |
| <a href="#">Read Memory</a>            | Reads memory values from the debugging target.                                                                                                                   |
| <a href="#">Read Registers</a>         | Retrieves the value of each of the target processor registers.                                                                                                   |
| <a href="#">RPC</a>                    | Sends a remote procedure call to the debugging target.                                                                                                           |
| <a href="#">Set Breakpoints</a>        | Sets breakpoints on the debugging target.                                                                                                                        |
| <a href="#">Set Trap Breaks</a>        | Sets breakpoints on the debugging target.                                                                                                                        |
| <a href="#">Set Trap Conditionals</a>  | Sets the trap conditionals values for the debugging target.                                                                                                      |
| <a href="#">State</a>                  | Sent by the host program to query the current state of the debugging target, and sent by the target whenever it encounters an exception and enters the debugger. |
| <a href="#">Toggle Debugger Breaks</a> | Enables or disables breakpoints that have been compiled into the code.                                                                                           |
| <a href="#">Write Memory</a>           | Writes memory values to the debugging target.                                                                                                                    |
| <a href="#">Write Registers</a>        | Sets the value of each of the target processor registers.                                                                                                        |

# Using the Console Window

---

This chapter describes the console window, which you can use with Palm<sup>®</sup> Debugger, Palm Simulator, and the Metrowerks CodeWarrior environment to perform maintenance and high-level debugging of a Palm<sup>™</sup> handheld device.

The following topics are covered in this chapter:

- [“About the Console Window”](#)
- [“Connecting the Console Window”](#) on page 302
- [“Entering Console Window Commands”](#) on page 305
- [“Command Syntax”](#) on page 308
- [“Console Window Commands”](#) on page 310
- [“Console Command Summary”](#) on page 348

## About the Console Window

The console window interfaces with a handheld device by sending information packets to and receiving information packets from the *console nub* on the device. The console interface provides a number of commands, which are used primarily for administration of databases and heap testing on handheld devices.

The console is available in three environments:

- as a separate window for sending and receiving commands in the Palm Debugger program, which is described in [Chapter 4, “Using Palm Debugger.”](#)
- as a separate window that you can open from within Palm Simulator program, which is described in [Chapter 3, “Using Palm Simulator.”](#)

## Using the Console Window

### *Connecting the Console Window*

---

- as a separate window that you can open within the Metrowerks CodeWarrior environment.

The console window provides the same commands and same interface in all three environments.

To use the console commands, you must connect your desktop computer with the console nub on the device, as described in the next section, [Connecting the Console Window](#).

To learn more about using console commands, see the section “[Entering Console Window Commands](#)” on page 305. For a complete reference description of each console command, see “[Console Window Commands](#)” on page 310. The commands are summarized in “[Console Command Summary](#)” on page 348.

## Connecting the Console Window

### Activating Console Input

To send console commands to the handheld device, you must connect your desktop computer to the handheld device, activate the console nub on the device, and then type commands into the console window.

The console nub runs as a background thread on the device, listening for commands on the serial or USB port. To activate the console nub, use the Graffiti® Shortcut-2 command, as described in “[Using Shortcut Numbers to Activate the Windows](#)” on page 303.

When the console nub activates, it sends out a “Ready” message. If your desktop computer is connected to the device when the nub is activated, this message will display in the console window.

---

**IMPORTANT:** The console nub activates at 57,600 baud, and your port configuration must match this if you are connecting over a serial port. You must set the connection parameters correctly for communications to work.

After you activate the console nub on the handheld device, the nub prevents other applications, including HotSync® from using the serial port. You have to soft-reset the handheld device before the port can be used.

---

### Verifying Your Connection

To verify your device connection, you can type one of the simple console commands, such as `dir` or `hl 0`. If your connection is working and the console nub is active on the handheld device, you will see a list of memory heaps displayed in the window.

If the console nub is not running on the handheld device, or if the communications connection is not correctly configured, you will see an error message:

```
Error $00000404 occurred
```

If you are certain that the console nub is running on the handheld, you need to set the connection parameters correctly. If you are using the console with Palm Debugger, you can use the Communications menu to set the parameters.

### Using Shortcut Numbers to Activate the Windows

The Palm OS® responds to a number of “hidden” shortcuts for debugging your programs, including shortcuts for activating the console nub on the handheld device. You generate each of these shortcuts by drawing characters on your Palm Powered device, or by drawing them in the Palm OS Emulator emulator program, if you are using Palm OS Emulator to debug your program.

## Using the Console Window

### *Connecting the Console Window*

---

---

**NOTE:** If you open the Find dialog box on the handheld device before entering a shortcut number, you get visual feedback as you draw the strokes.

---

To enter a shortcut number, follow these steps:

1. On your Palm Powered device, or in the emulator program, draw the shortcut symbol. This is a lowercase, cursive “L” character, drawn as follows:






2. Next, tap the stylus twice, to generate a dot (a period).
3. Next, draw a number character in the number entry portion of the device’s text entry area. [Table 7.1](#) shows the different shortcut numbers that you can use.

For example, to activate the console nub on the handheld device, enter the follow sequence:





**Table 7.1**    **Shortcut Numbers for Debugging**

| Number                                                                                | Description                                                                                                                                     | Notes                                                                                                                                                                                                            |
|---------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  .1  | The device enters debugger mode, and waits for a low-level debugger to connect. A flashing square appears in the top left corner of the device. | <p>This mode opens a serial port, which drains power over time.</p> <p>You must perform a soft reset or use the debugger's reset command to exit this mode.</p>                                                  |
|  .2  | The device enters console mode, and waits for communication, typically from a high-level debugger.                                              | <p>This mode opens a serial port, which drains power over time.</p> <p>You must perform a soft reset to exit this mode.</p>                                                                                      |
|  .3 | The device's automatic power-off feature is disabled.                                                                                           | <p>You can still use the device's power button to power it on and off. Note that your batteries can drain quickly with automatic power-off disabled.</p> <p>You must perform a soft reset to exit this mode.</p> |

---

**NOTE:** These debugging shortcuts leave the device in a mode that requires a soft reset. To perform a soft reset, press the reset button on the back of the handheld with a blunt instrument, such as a paper clip.

---

## Entering Console Window Commands

You use the console window to enter console commands, which are typically used for administrative tasks such as managing databases on the handheld device. Commands that you type into the console window are sent to the console nub on the handheld device, and the

## Using the Console Window

### Entering Console Window Commands

---

results sent back from the device are displayed in the console window.

---

**NOTE:** Console command input is not case sensitive.

---

[Table 7.2](#) shows the most commonly used console window commands.

**Table 7.2 Commonly Used Console Commands**

| Command | Description                                                                 |
|---------|-----------------------------------------------------------------------------|
| del     | Deletes a database from the handheld device.                                |
| dir     | Displays a list of the databases on the handheld device.                    |
| export  | Copies a Palm OS database from the handheld device to the desktop computer. |
| import  | Copies a Palm OS database from the desktop computer to the handheld device. |

[Listing 7.1](#) shows an example of using console commands. In this example, **boldface** is used to denote commands that you type.

**Listing 7.1 Importing a Database into the Handheld Device**

---

```
import 0 "C:Documents\MyDbs\Tex2HexApp.prc"
```

```
Creating Database on card 0
```

```
name: Text to Hex
```

```
type appl, creator TxHx
```

```
Importing resource 'code'=0....
```

```
Importing resource 'data'=0....
```

```
Importing resource 'pref'=0....
```

```
Importing resource 'rloc'=0....
```

```
Importing resource 'code'=1....
```

```
Importing resource 'tFRM'=1000....
```

```
Importing resource 'tver'=1....
```

```
Importing resource 'tAIB'=1000....
```

```
Importing resource 'Tbmp'=1000....
```

## Using the Console Window

### Entering Console Window Commands

---

```
Importing resource 'Tbmp'=1001....
Importing resource 'MBAR'=1000....
Importing resource 'Talt'=1000....
Importing resource 'Talt'=1001....
Success!!
```

**dir 0**

| name                 | ID       | total      | data       |
|----------------------|----------|------------|------------|
| *System              | 00D20A44 | 392.691 Kb | 390.361 Kb |
| *AMX                 | 00D209C4 | 20.275 Kb  | 20.123 Kb  |
| *UIAppShell          | 00D20944 | 1.327 Kb   | 1.175 Kb   |
| *PADHTAL Library     | 00D208E2 | 7.772 Kb   | 7.674 Kb   |
| *IrDA Library        | 00D20876 | 39.518 Kb  | 39.402 Kb  |
| *Net Library         | 00D207E2 | 86.968 Kb  | 86.780 Kb  |
| *PPP NetIF           | 00D2073A | 30.462 Kb  | 30.238 Kb  |
| *SLIP NetIF          | 00D20692 | 15.812 Kb  | 15.588 Kb  |
| *Loopback NetIF      | 00D20630 | 1.810 Kb   | 1.712 Kb   |
| *MS-CHAP Support     | 00D205C4 | 4.342 Kb   | 4.226 Kb   |
| *Network             | 00D203D2 | 40.442 Kb  | 39.624 Kb  |
| *Address Book        | 00D20226 | 59.825 Kb  | 59.133 Kb  |
| *Calculator          | 00D2002A | 14.597 Kb  | 13.761 Kb  |
| *Date Book           | 00D1FCF8 | 106.200 Kb | 104.806 Kb |
| *Launcher            | 00D1FA98 | 36.633 Kb  | 35.617 Kb  |
| *Memo Pad            | 00D1F91E | 24.267 Kb  | 23.665 Kb  |
| *Preferences         | 00D1F876 | 1.403 Kb   | 1.179 Kb   |
| *Security            | 00D1F706 | 8.414 Kb   | 7.830 Kb   |
| *HotSync             | 00D1F334 | 39.078 Kb  | 37.396 Kb  |
| *To Do List          | 00D1F1E2 | 33.232 Kb  | 32.702 Kb  |
| *Digitizer           | 00D1F126 | 2.002 Kb   | 1.742 Kb   |
| *General             | 00D1EFE8 | 8.749 Kb   | 8.255 Kb   |
| *Formats             | 00D1EF4A | 4.732 Kb   | 4.526 Kb   |
| *ShortCuts           | 00D1EE34 | 6.499 Kb   | 6.077 Kb   |
| *Owner               | 00D1ED5A | 4.095 Kb   | 3.781 Kb   |
| *Buttons             | 00D1EC4E | 7.419 Kb   | 7.015 Kb   |
| *Modem               | 00D1EB74 | 8.222 Kb   | 7.908 Kb   |
| *Mail                | 00D1E838 | 59.765 Kb  | 58.353 Kb  |
| *Expense             | 00D1E614 | 42.304 Kb  | 41.396 Kb  |
| *Unsaved Preferences | 0001811B | 0.898 Kb   | 0.550 Kb   |
| *Net Prefs           | 00018133 | 0.084 Kb   | 0.000 Kb   |
| AddressDB            | 00018137 | 66.149 Kb  | 51.945 Kb  |
| MemoDB               | 0001815F | 2.186 Kb   | 1.902 Kb   |
| ToDoDB               | 00018173 | 1.000 Kb   | 0.876 Kb   |
| MailDB               | 0001817F | 1.033 Kb   | 0.929 Kb   |
| DatebookDB           | 000181EB | 53.162 Kb  | 29.678 Kb  |
| System MIDI Sounds   | 000181B3 | 1.066 Kb   | 0.842 Kb   |
| *Saved Preferences   | 00018123 | 3.753 Kb   | 3.031 Kb   |
| NetworkDB            | 0001818B | 0.986 Kb   | 0.722 Kb   |

## Using the Console Window

### Command Syntax

---

|                     |          |            |            |
|---------------------|----------|------------|------------|
| *Giraffe High Score | 00018273 | 0.126 Kb   | 0.020 Kb   |
| Datebk3DB           | 0001827B | 0.084 Kb   | 0.000 Kb   |
| ReDoDB              | 0001827F | 0.084 Kb   | 0.000 Kb   |
| LauncherDB          | 0001814F | 0.294 Kb   | 0.190 Kb   |
| *MineHunt           | 00018287 | 9.810 Kb   | 9.264 Kb   |
| *SubHunt            | 000182DF | 17.700 Kb  | 16.758 Kb  |
| *Puzzle             | 0001837F | 5.256 Kb   | 4.886 Kb   |
| *HardBall           | 000183B7 | 18.877 Kb  | 18.177 Kb  |
| Pictures            | 0001842B | 0.084 Kb   | 0.000 Kb   |
| *Jot                | 0001842F | 120.409 Kb | 119.841 Kb |
| *Graffiti ShortCuts | 001FFE7F | 2.872 Kb   | 2.766 Kb   |
| *UnDupe             | 001FFE87 | 9.462 Kb   | 9.070 Kb   |
| *WordView           | 001FFEC3 | 17.320 Kb  | 16.752 Kb  |
| *SheetView          | 001FFF1F | 56.753 Kb  | 55.877 Kb  |
| AOU Birds of NA     | 001FFE15 | 130.265 Kb | 90.021 Kb  |
| ExpenseDB           | 001FBCB5 | 0.150 Kb   | 0.046 Kb   |
| DocsToGoDB          | 001FBCC1 | 0.326 Kb   | 0.202 Kb   |
| birds.PDB           | 001FBCD1 | 0.709 Kb   | 0.585 Kb   |
| foo                 | 0001812F | 0.084 Kb   | 0.000 Kb   |
| *Text To Hex        | 001FFF85 | 34.725 Kb  | 33.827 Kb  |

-----  
---  
Total: 59

---

These and all of the other console commands are described in detail in “[Console Window Commands](#)” on page 310.

## Command Syntax

This chapter uses the following syntax to specify the format of debugger commands:

|             |                                                                                                                                                                                                                                                      |
|-------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| commandName | <parameter> [options]                                                                                                                                                                                                                                |
| commandName | The name of the command.                                                                                                                                                                                                                             |
| parameter   | Parameter(s) for the command. Each parameter name is enclosed in angle brackets (< and >).<br><br>Sometimes a parameter can be one value or another. In this case the parameter names are bracketed by parentheses and separated by the   character. |

**options**                      Optional flags that you can specify with the command. Note that options are specified with the dash (-) character in the console window.

---

**NOTE:** Any portion of a command that is shown enclosed in square brackets (“[” and “]”) is optional.

---

The following is an example of a command definition

```
dir (<cardNum>|<srchOptions>) [displayOptions]
```

The `dir` command takes either a card number or a search specification, followed by display options.

Here are two examples of the `dir` command sent from the console window:

```
dir 0 -a
dir -t rsrc
```

### Specifying Command Options

All command options and some command parameters are specified as flags that begin with a dash. For example:

```
-c
-enable
```

Some flags are followed by a keyword or value. You must leave white space between the flag and the value. For example:

```
-f D:\temp\myLogFile
-t Rsrc
```

---

**NOTE:** You use the dash (-) character to specify options for console commands. If you are using Palm Debugger, you must use the backslash (\) character to specify options for commands that you type in the debugging window; this is because the expression parser used for debugging commands interprets the dash as a minus sign.

---

## Using the Console Window

### Console Window Commands

---

### Specifying Numeric and Address Values

Many of the console commands take address or numeric arguments. You can specify these values in hexadecimal, decimal, or binary. All values are assumed to be hexadecimal unless preceded by a sign that specifies decimal (#) or binary (%). [Table 7.3](#) shows values specified as binary, decimal, and hexadecimal in a debugging command:

**Table 7.3 Specifying Numeric Values in Palm Debugger**

| Hex value    | Decimal value | Binary value |
|--------------|---------------|--------------|
| 64 or \$64   | #100          | %01100100    |
| F5 or \$F5   | #245          | %11110101    |
| 100 or \$100 | #256          | %100000000   |

## Console Window Commands

You use the console window to send commands to the console nub that is running on the handheld device.

This section provides a description of all of the commands in alphabetical order. For convenience, the commands are categorized here:

**Table 7.4 Console Window Command Categories**

| Command category  | Commands                                                                                                                                                                                                                     |
|-------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Card Information  | <a href="#">CardFormat</a> , <a href="#">CardInfo</a> , and <a href="#">StoreInfo</a> .                                                                                                                                      |
| Chunk Utility     | <a href="#">Free</a> , <a href="#">Info</a> , <a href="#">Lock</a> , <a href="#">New</a> , <a href="#">Resize</a> , <a href="#">SetOwner</a> , and <a href="#">Unlock</a> .                                                  |
| Database Utility  | <a href="#">Close</a> , <a href="#">Create</a> , <a href="#">Del</a> , <a href="#">Dir</a> , <a href="#">Export</a> , <a href="#">Import</a> , <a href="#">Open</a> , <a href="#">Opened</a> , and <a href="#">SetInfo</a> . |
| Debugging Utility | <a href="#">DM</a> , <a href="#">GDB</a> , <a href="#">MDebug</a> , and <a href="#">SB</a> .                                                                                                                                 |
| Gremlin           | <a href="#">Gremlin</a> and <a href="#">GremlinOff</a> .                                                                                                                                                                     |
| Heap Utility      | <a href="#">HC</a> , <a href="#">HChk</a> , <a href="#">HD</a> , <a href="#">HE</a> , <a href="#">HI</a> , <a href="#">HL</a> , <a href="#">HS</a> , <a href="#">HT</a> , and <a href="#">HTorture</a> .                     |
| Host Control      | <a href="#">Help</a> , <a href="#">Log</a> , and <a href="#">SaveImages</a> .                                                                                                                                                |

**Table 7.4 Console Window Command Categories (*continued*)**

| Command category      | Commands                                                                                                                                                                                                                                                                                                           |
|-----------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Miscellaneous Utility | <a href="#">SimSync</a> and <a href="#">SysAlarmDump</a> .                                                                                                                                                                                                                                                         |
| Record Utility        | <a href="#">AddRecord</a> , <a href="#">DelRecord</a> , <a href="#">DetachRecord</a> , <a href="#">FindRecord</a> , <a href="#">ListRecords</a> , <a href="#">MoveRecord</a> , and <a href="#">SetRecordInfo</a> .                                                                                                 |
| Resource Utility      | <a href="#">AddResource</a> , <a href="#">AttachResource</a> , <a href="#">ChangeResource</a> , <a href="#">DelResource</a> , <a href="#">DetachResource</a> , <a href="#">ListResources</a> , and <a href="#">SetResourceInfo</a> .                                                                               |
| System                | <a href="#">Battery</a> , <a href="#">ColdBoot</a> , <a href="#">Doze</a> , <a href="#">Exit</a> , <a href="#">Feature</a> , <a href="#">KInfo</a> , <a href="#">Launch</a> , <a href="#">Performance</a> , <a href="#">PowerOn</a> , <a href="#">Reset</a> , <a href="#">Sleep</a> , and <a href="#">Switch</a> . |

## AddRecord

**Purpose** Adds a record to a database.

**Usage** `addrecord <accessPtr> <index> <recordText>`

**Parameters**

|                         |                                          |
|-------------------------|------------------------------------------|
| <code>accessPtr</code>  | A pointer to the database.               |
| <code>index</code>      | The index of the record in the database. |
| <code>recordText</code> | The record data.                         |

## AddResource

**Purpose** Adds a resource to a database.

**Usage** `addresource <accessPtr> -t <type> -id <id> <resourceText>`

**Parameters**

|                           |                                               |
|---------------------------|-----------------------------------------------|
| <code>accessPtr</code>    | A pointer to the database.                    |
| <code>type</code>         | The type of the resource that you are adding. |
| <code>id</code>           | The ID for the resource that you are adding.  |
| <code>resourceText</code> | The resource data.                            |

## Using the Console Window

### Console Window Commands

---

## AttachRecord

**Purpose** Attaches a record to a database.

**Usage** `attachrecord <accessPtr> <recordHandle> <index> [options]`

**Parameters**

|                           |                                                                                                                                     |
|---------------------------|-------------------------------------------------------------------------------------------------------------------------------------|
| <code>accessPtr</code>    | A pointer to the database.                                                                                                          |
| <code>recordHandle</code> | A handle to the record that you are attaching to the database.                                                                      |
| <code>index</code>        | The index of the record.                                                                                                            |
| <code>options</code>      | Optional. You can specify the following option:<br><code>-r</code> Replaces the existing record with the same index, if one exists. |

## AttachResource

**Purpose** Attaches a resource to a database.

**Usage** `attachrecord <accessPtr> <recordHandle> <index> [options]`

**Parameters**

|                           |                                                                                                                                       |
|---------------------------|---------------------------------------------------------------------------------------------------------------------------------------|
| <code>accessPtr</code>    | A pointer to the database.                                                                                                            |
| <code>recordHandle</code> | A handle to the resource that you are attaching to the database.                                                                      |
| <code>index</code>        | The index of the resource.                                                                                                            |
| <code>options</code>      | Optional. You can specify the following option:<br><code>-r</code> Replaces the existing resource with the same index, if one exists. |



## Battery

**Purpose** A battery utility command for performing battery operations.

**Usage** `battery [options]`

**Parameters**    `options`                      Optional. Specifies the battery operation to perform. Use one of the following values:

- `-rStart <deltaSeconds>`  
Start radio charging in the number of seconds specified by `deltaSeconds`.
- `-rStop`  
Stop radio charging.
- `-rLoaded (yes | no)`  
Set loaded state to yes or no.

**Example**            `battery -rStop`

## CardFormat

**Purpose** Formats a memory card.

**Usage** `cardformat <cardNum> <cardName> <manufName> <ramStoreName>`

**Parameters**

|                           |                                                   |
|---------------------------|---------------------------------------------------|
| <code>cardNum</code>      | The card number.                                  |
| <code>cardName</code>     | The name to associate with the card.              |
| <code>manufName</code>    | The manufacturer name to associate with the card. |
| <code>ramStoreName</code> | The RAM store name to associate with the card.    |

## Using the Console Window

### Console Window Commands

---

#### CardInfo

|                   |                                                                                                                                                                             |                                                                                              |
|-------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------|
| <b>Purpose</b>    | Displays information about a memory card.                                                                                                                                   |                                                                                              |
| <b>Usage</b>      | <code>cardinfo &lt;cardNum&gt;</code>                                                                                                                                       |                                                                                              |
| <b>Parameters</b> | <code>cardNum</code>                                                                                                                                                        | The card number about which you want information. You can use 0 to specify the built-in RAM. |
| <b>Example</b>    | <pre>cardinfo 0  Name: PalmCard Manuf: Palm, Inc Version: 0001 CreationDate: B1243780 ROM Size: 00118FFC RAM Size: 00200000 Free Bytes : 0015ACB2 Number of heaps: #3</pre> |                                                                                              |

#### ChangeRecord

|                   |                                                                              |                                          |
|-------------------|------------------------------------------------------------------------------|------------------------------------------|
| <b>Purpose</b>    | Replaces a record in a database.                                             |                                          |
| <b>Usage</b>      | <code>changerecord &lt;accessPtr&gt; &lt;index&gt; &lt;recordText&gt;</code> |                                          |
| <b>Parameters</b> | <code>accessPtr</code>                                                       | A pointer to the database.               |
|                   | <code>index</code>                                                           | The index of the record in the database. |
|                   | <code>recordText</code>                                                      | The new record data.                     |

## ChangeResource

**Purpose** Replaces a resource in a database.

**Usage** `changeresource <accessPtr> <index> <recordText>`

**Parameters**

|                           |                                            |
|---------------------------|--------------------------------------------|
| <code>accessPtr</code>    | A pointer to the database.                 |
| <code>index</code>        | The index of the resource in the database. |
| <code>resourceText</code> | The new resource data.                     |

## Close

**Purpose** Closes a database.

**Usage** `close <accessPtr>`

**Parameters**

|                        |                            |
|------------------------|----------------------------|
| <code>accessPtr</code> | A pointer to the database. |
|------------------------|----------------------------|

## ColdBoot

**Purpose** Initiates a hard reset on the handheld device.

**Usage** `coldboot`

**Parameters** None

**Comments** Use the coldboot command to perform a hard reset of the handheld device. A hard reset erases all data on the device, restoring it to its new condition.

The handheld device requires confirmation of this operation. You are prompted to press the Up button on the device to confirm that you want to perform a hard reset, or press any other button to cancel the operation.

**Example** `coldboot`

## Using the Console Window

### Console Window Commands

---

#### Create

**Purpose** Creates a new database on the handheld device.

**Usage** `create <cardNum> <name> [options]`

|                   |                      |                                                                                                                                                                                                                                                                                                               |
|-------------------|----------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Parameters</b> | <code>cardNum</code> | The card number whose databases you want listed. You almost always use 0 to specify the built-in RAM.                                                                                                                                                                                                         |
|                   | <code>name</code>    | The name for the new database on the handheld device.                                                                                                                                                                                                                                                         |
|                   | <code>options</code> | Optional. Specifies information about the new database:<br><br>-t <type><br>The 4-character database type identifier.<br><br>-c <creator><br>The 4-character database creator ID.<br><br>-v <version><br>The database version number.<br><br>-r Specify to indicate that the database is a resource database. |

**Comments** Use the create command to create a new record or resource database on the handheld device.

#### Example

#### Del

**Purpose** Deletes a database from the handheld device.

**Usage** `del <cardNum> <fileName>`

|                   |                      |                                                                                                        |
|-------------------|----------------------|--------------------------------------------------------------------------------------------------------|
| <b>Parameters</b> | <code>cardNum</code> | The card number on which the database is located. You almost always use 0 to specify the built-in RAM. |
|-------------------|----------------------|--------------------------------------------------------------------------------------------------------|

fileName            The name of the database on the handheld device. Note that you must quote the database name if it contains spaces.

**Comments**        Use the `del` command to delete a database from the specified card on the handheld device.

                  You can get a list of the databases on the device with the [Dir](#) command.

                  You cannot delete an open database.

**Result**            If the database you want to delete is not found or is currently opened, you receive an error message.

**Example**            `del 0 birds.pdb`

                      Success!!

## DelRecord

**Purpose**            Deletes a record from a database.

**Usage**            `delrecord <accessPtr> <index>`

**Parameters**        `accessPtr`            A pointer to the database.

`index`                The index of the record in the database.

**Comments**        Use the `delrecord` command to delete the record at the specified index value from the database specified by `accessPtr`.

## DelResource

**Purpose**            Deletes a resource from a database.

**Usage**            `delresource <accessPtr> <index>`

**Parameters**        `accessPtr`            A pointer to the database.

## Using the Console Window

### Console Window Commands

---

`index`                      The index of the resource in the database.

**Comments**      Use the `delresource` command to delete the resource at the specified `index` value from the database specified by `accessPtr`.

## DetachRecord

**Purpose**          Detaches a record from a database.

**Usage**           `detachrecord <accessPtr> <index>`

**Parameters**    `accessPtr`            A pointer to the database.  
                  `index`                The index of the record in the database.

**Comments**      Use the `detachrecord` command to detach the record at the specified `index` value from the database specified by `accessPtr`.

## DetachResource

**Purpose**          Detaches a resource from a database.

**Usage**           `detachresource <accessPtr> <index>`

**Parameters**    `accessPtr`            A pointer to the database.  
                  `index`                The index of the resource in the database.

**Comments**      Use the `detachresource` command to detach the resource at the specified `index` value from the database specified by `accessPtr`.

## Dir

**Purpose** Displays a list of the databases on the handheld device.

**Usage** `dir (<cardNum>|<searchOptions>)`  
`[<displayOptions>]`

**Parameters**

|                             |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|-----------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>cardNum</code>        | The card number whose databases you want listed. You almost always use 0 to specify the built-in RAM.                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| <code>searchOptions</code>  | Optional. Options for listing a specific database. Specify any combination of the following flags.<br><br><code>-c &lt;creatorID&gt;</code><br>Search for a database by creator ID.<br><br><code>-latest</code><br>List only the latest version of each database.<br><br><code>-t &lt;typeID&gt;</code><br>Search for a database by its type.                                                                                                                                                                                                                            |
| <code>displayOptions</code> | Optional. Options for which information is displayed in the listing. Specify any combination of the following flags.<br><br><code>-a</code> Show all information.<br><code>-at</code> Show the database attributes.<br><code>-d</code> Show the database creation, modification, and backup dates.<br><code>-i</code> Show the database appInfo and sortInfo field values.<br><code>-id</code> Show the database chunk ID<br><code>-s</code> Show the database size<br><code>-m</code> Show the database modification number.<br><code>-n</code> Show the database name. |

## Using the Console Window

### Console Window Commands

---

- r Show the number of records in the database.
- tc Show the database type ID and creator ID.
- v Show the database version number.

**Comments** Use the dir command to display a list of the databases on a specific card or in the handheld device built-in RAM. You typically use the following command to list all of the databases stored in RAM on the handheld device:

```
dir 0
```

Or use the -a switch to display all of the information for each database:

```
dir 0 -a
```

**Example**

```
dir 0
```

| name               | ID       | total      | data       |
|--------------------|----------|------------|------------|
| -----              |          |            |            |
| *System            | 00D20A44 | 392.691 Kb | 390.361 Kb |
| *AMX               | 00D209C4 | 20.275 Kb  | 20.123 Kb  |
| *UIAppShell        | 00D20944 | 1.327 Kb   | 1.175 Kb   |
| *PADHTAL Library   | 00D208E2 | 7.772 Kb   | 7.674 Kb   |
| *IrDA Library      | 00D20876 | 39.518 Kb  | 39.402 Kb  |
| ...                |          |            |            |
| MailDB             | 0001817F | 1.033 Kb   | 0.929 Kb   |
| NetworkDB          | 0001818B | 0.986 Kb   | 0.722 Kb   |
| System MIDI Sounds | 000181B3 | 1.066 Kb   | 0.842 Kb   |
| DatebookDB         | 000181FB | 0.084 Kb   | 0.000 Kb   |
| -----              |          |            |            |
| Total:             |          | 41         |            |

## DM

**Purpose** Displays a range of memory values.

**Usage** `dm <addr> [<count>]`

**Parameters** `addr` The starting memory address to be displayed.



**count**                      The number of bytes to be displayed. If this is omitted, eight bytes of data are displayed.

**Example**                  `dm 0000f000`

`0000F000: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00`  
`.....`

## Doze

**Purpose**                  Instructs the handheld device's CPU to sleep while maintaining the peripherals and the clock.

**Usage**                  `doze [options]`

**Parameters**            `options`                  You can optionally specify the following flags:

`-light`  
                             The handheld device will awaken in response to any interrupt.

**Example**                  `doze -light`

## Exit

**Purpose**                  Exits the debugger.

**Usage**                  `exit`

**Parameters**            None.

## Using the Console Window

### Console Window Commands

---

## Export

**Purpose** Copies a Palm OS database from the handheld device to the desktop computer.

**Usage** `export <cardNum> <fileName>`

**Parameters**

|                       |                                                                                                                    |
|-----------------------|--------------------------------------------------------------------------------------------------------------------|
| <code>cardNum</code>  | The card number on which the database is located. You almost always use 0 to specify the built-in RAM.             |
| <code>fileName</code> | The name of the database on the handheld device. Note that you must quote the database name if it contains spaces. |

**Comments** Use the `export` command to copy a database from the handheld device to your desktop computer. You can get a list of the databases on the device with the [Dir](#) command.

If the database contains resources, it is copied in standard PRC format; if the database contains records, it is copied in standard PDB format. Note that these two formats are actually identical.

The exported file is stored in the `Device` subdirectory of the directory in which Palm Debugger executable is stored.

The exported file is named `fileName`, with no added extensions.

**Example** `export 0 "Text to Hex"`

```
Exporting resource 'code'=0....
Exporting resource 'data'=0....
Exporting resource 'pref'=0....
Exporting resource 'rloc'=0....
Exporting resource 'code'=1....
Exporting resource 'tFRM'=1000....
Exporting resource 'tver'=1....
Exporting resource 'tAIB'=1000....
Exporting resource 'Tbmp'=1000....
Exporting resource 'Tbmp'=1001....
Exporting resource 'MBAR'=1000....
Exporting resource 'Talt'=1000....
```

```
Exporting resource 'Talt'=1001....
Success!!
```

## Feature

**Purpose**   Accesses features.

**Usage**   feature [options]

**Parameters**   options                      Optional. You can use the following options:

- all   Displays a list of all known features
- unreg <creator> <num>  
          Unregisters the specified feature
- get <creator> <num>  
          Displays the value of a feature
- set <creator> <num> <value>  
          Sets the value of a feature.

### Example

```
feature -all

ROM: creator number value
 'psys' #1 03003000
 'psys' #2 00010000
RAM: creator number value
 'psys' #3 00000001
 'psys' #4 00000001
 'psys' #7 00000001
 'netl' #0 02003000
 'irda' #0 03003000

feature -get psys 3

Value = 00000001
```

## Using the Console Window

### Console Window Commands

---

#### FindRecord

**Purpose** Finds a record by ID.

**Usage** `findrecord <accessPtr> <id>`

**Parameters**

|                        |                            |
|------------------------|----------------------------|
| <code>accessPtr</code> | A pointer to the database. |
| <code>id</code>        | The unique record ID.      |

#### Free

**Purpose** Disposes of a chunk.

**Usage** `free (<hexChunkPtr> | localID>) [options]`

**Parameters**

|                                                  |                                                                                                                                                                                                                |
|--------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>hexChunkPtr</code> or <code>localID</code> | A pointer to a chunk in memory, or the ID of a chunk on the specified card number.                                                                                                                             |
| <code>options</code>                             | Optional. You can specify the following options: <ul style="list-style-type: none"><li><code>-card &lt;cardNum&gt;</code><br/>The card number if a local ID is specified instead of a chunk pointer.</li></ul> |

#### GDB

**Purpose** Enables or disables Gdb debugging

**Usage** `gdb [options]`

**Parameters**

|                      |                                                                                                                                                                                                            |
|----------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>options</code> | Optional. You can specify the following options: <ul style="list-style-type: none"><li><code>-enable</code><br/>Enables gdb debugging.</li><li><code>-disable</code><br/>Disables gdb debugging.</li></ul> |
|----------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

## GetResource

|                   |                                                         |                                                   |
|-------------------|---------------------------------------------------------|---------------------------------------------------|
| <b>Purpose</b>    | Retrieves the specified resource.                       |                                                   |
| <b>Usage</b>      | <code>getresource -t &lt;type&gt; -id &lt;id&gt;</code> |                                                   |
| <b>Parameters</b> | <code>type</code>                                       | The type of resource that you want to retrieve.   |
|                   | <code>id</code>                                         | The ID of the resource that you want to retrieve. |

## Gremlin

|                   |                                                       |                                         |
|-------------------|-------------------------------------------------------|-----------------------------------------|
| <b>Purpose</b>    | Activates a gremlin until the specified event occurs. |                                         |
| <b>Usage</b>      | <code>gremlin &lt;num&gt; &lt;until&gt;</code>        |                                         |
| <b>Parameters</b> | <code>num</code>                                      | The number of the gremlin to activate.  |
|                   | <code>until</code>                                    | The event that deactivates the gremlin. |

## GremlinOff

|                   |                                  |  |
|-------------------|----------------------------------|--|
| <b>Purpose</b>    | Deactivates the current gremlin. |  |
| <b>Usage</b>      | <code>gremlinoff</code>          |  |
| <b>Parameters</b> | None                             |  |
| <b>Example</b>    | <code>gremlinoff</code>          |  |

## Console Window Commands

|                |                         |
|----------------|-------------------------|
| <b>Purpose</b> | Compacts a memory heap. |
|----------------|-------------------------|

|                   |        |                                                                                                    |
|-------------------|--------|----------------------------------------------------------------------------------------------------|
| <b>Parameters</b> | heapId | The hexadecimal number of the heap to be compacted. Heap number 0x0000 is always the dynamic heap. |
|-------------------|--------|----------------------------------------------------------------------------------------------------|

**Purpose** Checks the integrity of a heap.

|                   |         |                                                                                                                     |
|-------------------|---------|---------------------------------------------------------------------------------------------------------------------|
| <b>Parameters</b> | heapId  | The hexadecimal number of the heap whose contents are to be checked. Heap number 0x0000 is always the dynamic heap. |
|                   | options | Optional. You can specify the following option:                                                                     |

326 *Palm OS Programming Development Tools Guide*

## HD

**Purpose** Displays a hexadecimal dump of the specified heap.

**Usage** `hd <heapId>`

**Parameters** `heapId` The hexadecimal number of the heap whose contents are to be displayed. Heap number 0x0000 is always the dynamic heap.

**Comments** Use the `hd` command to display a dump of the contents of a specific heap from the handheld device. You can use the [HL](#) command to display the heap IDs.

**Example** `hd 0`

```

Displaying Heap ID: 0000, mapped to 00001480
 req act
resType/ #resID/
start handle localID size size lck own flags type
index attr ctg uniqueID name

-00001534 00001494 F0001495 000456 00045E #0 #0 fM
Graffiti Private
-00001992 00001498 F0001499 000012 00001A #0 #0 fM
DataMgr Protect List (DmProtectEntryPtr*)
-000019AC 00001490 F0001491 00001E 000026 #0 #0 fM Alarm
Table
-000019D2 0000148C F000148D 000038 000040 #0 #0 fM
*00001A12 0000149C F000149D 000396 00039E #2 #1 fM Form
"3:03 pm"
*00001DB0 000014A0 F00014A1 00049A 0004A2 #2 #0 fM
00002252 ----- F0002252 00002E 00003E #0 #0 FM
00002290 ----- F0002290 00EC40 00EC50 #0 #0 FM
-00010EE0 ----- F0010EE0 000600 000608 #0 #15 fM
Stack: Console Task

...

000114E8 ----- F00114E8 000FF8 001008 #0 #0 FM
-000124F0 ----- F00124F0 001000 001008 #0 #15 fM
-00017D30 ----- F0017D30 00003C 000044 #0 #15 fM
SysAppInfoPtr: AMX

```

## Using the Console Window

### Console Window Commands

---

```
-00017D74 ----- F0017D74 000008 000010 #0 #15 fM
Feature Manager Globals (FtrGlobalsType)
-00017D84 ----- F0017D84 000024 00002C #0 #15 fM
DmOpenInfoPtr: 'Update 3.0.2'
-00017DB0 ----- F0017DB0 00000E 000016 #0 #15 fM
DmOpenRef: 'Update 3.0.2'
-00017DC6 ----- F0017DC6 0001F4 0001FC #0 #15 fM
Handle Table: 'ÛUpdate 3.0.2'
-00017FC2 ----- F0017FC2 000024 00002C #0 #15 fM
DmOpenInfoPtr: 'ÛUpdate 3.0.2'
-00017FEE ----- F0017FEE 00000E 000016 #0 #15 fM
DmOpenRef: 'ÛUpdate 3.0.2'
```

#### Heap Summary:

```
flags: 8000
size: 016B80
numHandles: #40
Free Chunks: #14 (010C50 bytes)
Movable Chunks: #51 (005E80 bytes)
Non-Movable Chunks: #0 (000000 bytes)
```

## Help

**Purpose** Displays a list of commands or help for a specific command.

**Usage** help  
help <command>

**Parameters** command                      The name of the command for which you want help displayed.

**Example**                      help hchk

Do a Heap Check.

Syntax: hchk <hex heapID> [options...]

      -c           : Check contents of each chunk



## HF

**Purpose** Allocates almost all of the free bytes in a heap, reserving the specified amount of free space.

**Usage** hf <heapId> <freeBytes>

**Parameters**

|           |                                                                                    |
|-----------|------------------------------------------------------------------------------------|
| heapId    | The hexadecimal number of the heap. Heap number 0x0000 is always the dynamic heap. |
| freeBytes | The number of bytes to leave unallocated.                                          |

**Example** hf 0000 20

## HI

**Purpose** Initializes the specified memory heap.

**Usage** hi <heapId>

**Parameters**

|        |                                                                                                      |
|--------|------------------------------------------------------------------------------------------------------|
| heapId | The hexadecimal number of the heap to be initialized. Heap number 0x0000 is always the dynamic heap. |
|--------|------------------------------------------------------------------------------------------------------|

**Example** hi 0006

## HL

**Purpose** Displays a list of memory heaps.

**Usage** hl <cardNum>

**Parameters**

|         |                                                                                                      |
|---------|------------------------------------------------------------------------------------------------------|
| cardNum | The card number on which the heaps are located. You almost always use 0 to specify the built-in RAM. |
|---------|------------------------------------------------------------------------------------------------------|

**Comments** Use the hl command to list the memory heaps in built-in RAM or on a card.

## Using the Console Window

### Console Window Commands

---

**Example**      `hl 0`

|       | index | heapID | heapPtr  | size     | free     | maxFree  |
|-------|-------|--------|----------|----------|----------|----------|
| flags |       |        |          |          |          |          |
|       | 0     | 0000   | 00001480 | 00016B80 | 00010C50 | 0000EC48 |
| 8000  |       |        |          |          |          |          |
|       | 1     | 0001   | 1001810E | 001E7EF2 | 0014AD6A | 00147D3A |
| 8000  |       |        |          |          |          |          |
|       | 2     | 0002   | 10C08212 | 00118DEE | 0000A01C | 0000A014 |
| 8001  |       |        |          |          |          |          |

## HS

**Purpose**      Scrambles the specified heap.

**Usage**      `hs <heapId>`

**Parameters**    `heapId`                      The hexadecimal number of the heap to be scrambled. Heap number 0x0000 is always the dynamic heap.

**Comments**      Scrambling a heap moves its contents around. You can use this to verify that the program is using handles in the prescribed manner.

**Example**            `hs 0002`  
                      `heap scrambled`

## HT

**Purpose**      Displays summary information for the specified heap.

**Usage**      `ht <heapId>`

**Parameters**    `heapId`                      The hexadecimal number of the heap to be scrambled. Heap number 0x0000 is always the dynamic heap.

**Comments** The `ht` command displays the summary information that is also shown at the end of a heap dump generated by the [HD](#) command.

**Example**

```
ht 0000
Displaying Heap ID: 0000, mapped to 00001480

Heap Summary:
 flags: 8000
 size: 016B80
 numHandles: #40
 Free Chunks: #14 (010CAA bytes)
 Movable Chunks: #48 (005E26 bytes)
 Non-Movable Chunks: #0 (000000 bytes)
```

## HTorture

**Purpose** Tortures a heap to test its integrity.

**Usage** `htorture <heapId> [options]`

**Parameters**

|                      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
|----------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>heapId</code>  | The hexadecimal number of the heap to be tortured. Heap number <code>0x0000</code> is always the dynamic heap.                                                                                                                                                                                                                                                                                                                                                                                                                                |
| <code>options</code> | Optional. You can specify a combination of the following options: <ul style="list-style-type: none"><li><code>-c</code> Checks the contents of every chunk.</li><li><code>-f &lt;number&gt;</code><br/>Reports if the heap is filled beyond the specified percentage. The default is 90 percent.</li><li><code>-l &lt;filename&gt;</code><br/>Specifies the name of the log file</li><li><code>-m &lt;hexSize&gt;</code><br/>The maximum chunk size. The default value is <code>0x400</code>.</li><li><code>-p &lt;level&gt;</code></li></ul> |

## Using the Console Window

### Console Window Commands

---

The progress level to display. Specify a number between 0 (minimum detail) and 2 (maximum detail). The default value is 0.

**Comments** Use the `htorture` command to torture-test a memory heap. You can specify a logging file to which the output of the test is sent. You can also use the `-p` command to control how progress is displayed.

## Import

**Purpose** Copies a Palm OS database from the desktop computer to the handheld device.

**Usage** `import <cardNum> <fileName>`

**Parameters** `cardNum` The card number on which the database is to be installed. You almost always use 0 to specify the built-in RAM.

`fileName` The name of the file on the desktop computer. You can specify an absolute file name path, or a relative file name path.

The default search path is the `Device` subdirectory of the directory in which Palm Debugger executable is stored.

**Comments** Use the `import` command to load a new version of your application or database onto the handheld device.

This command provides a more convenient install operation and has the same functionality as the installer tool provided with the HotSync Manager application.

The name of the database on the handheld device is the name stored in the file, and is not the same as the file name. If a database with a matching name is already open on the handheld device, an error is generated. If a database with a matching name is already stored on

the handheld device, that database is deleted and replaced by the file.

**Result** If a database with a matching name is currently open on the handheld device, the `dmErrAlreadyExists` error code (0x0219) is generated.

**Example**

```
import 0 Tex2HexApp.prc

Creating Database on card 0
name: Text to Hex
type appl, creator TxHx

Importing resource 'code'=0....
Importing resource 'data'=0....
Importing resource 'pref'=0....
Importing resource 'rloc'=0....
Importing resource 'code'=1....
Importing resource 'tFRM'=1000....
Importing resource 'tver'=1....
Importing resource 'tAIB'=1000....
Importing resource 'Tbmp'=1000....
Importing resource 'Tbmp'=1001....
Importing resource 'MBAR'=1000....
Importing resource 'Talt'=1000....
Importing resource 'Talt'=1001....
Success!!
```

## Info

**Purpose** Displays information about a memory chunk.

**Usage** `info (<hexChunkPtr> | localID>) [options]`

**Parameters** `hexChunkPtr` or `localID`  
A pointer to a chunk in memory, or the ID of a chunk on the specified card number.

`options` Optional. You can specify the following options:

-card <cardNum>  
The card number if a local ID is specified instead of a chunk pointer.

## KInfo

**Purpose** Displays a list of all system kernel information.

**Usage** kinfo [options]

**Parameters** options      Optional. Specify the kernel information that you want to see displayed. Use a combination of the following flags:

- all  
Display all kernel information.
- task (<id> | all)  
Display task information.
- sem (<id> | all)  
Display semaphore information.
- tmr (<id> | all)  
Display timer information.

**Comments** Use the kinfo command to display a list of system kernel information, including tasks, semaphores, event groups, and timers.

**Example** kinfo -all

```
Task Information:
 taskID tag priority stackPtr status

 000176EA AMX # 0 00017556 Idle: Waiting for
Trigger
 000178BE psys # 30 00013364 Waiting on event timer
 0001795A CONS # 10 0001103E Running

Semaphore Information:
 semID tag type initValue curValue
 nesting ownerID
```

```


000177EE MemM resource #-1 #1 (free) #0
00000000
00017822 SlkM counting #1 #1 (avail.) #0
00000000
0001788A SndM counting #1 #1 (avail.) #0
00000000
00017A5E SerM counting #0 #0 (unavail.) #0
00000000

```

```

Timer Information:
tmrID tag ticksLeft period procPtr

000177BA psys # 83 # 0 10C6C618

```

## Launch

**Purpose** Launches an application on the handheld device.

**Usage** `launch [-t] [-ns] [-ng] <cardNum> <name> [<cmd>  
<cmdStr>`

|                   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|-------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Parameters</b> | <p><code>-t</code> Launches the application as a separate task.</p> <p><code>-ns</code> Use the caller's stack.</p> <p><code>-ng</code> Use the caller's globals environment.</p> <p><code>cardNum</code> The card number on which application is located. You almost always use 0 to specify the built-in RAM.</p> <p><code>name</code> The name of the application to be launched.</p> <p><code>cmd</code> Optional. Use to specify a command for the application.</p> <p><code>cmdStr</code> Optional. Use to specify an arguments string for <code>cmd</code>.</p> |
|-------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

## Using the Console Window

### Console Window Commands

---

#### ListRecords

**Purpose** Lists the records in a database.

**Usage** `listrecords <accessPtr>`

**Parameters** `accessPtr` A pointer to the database.

#### ListResources

**Purpose** Lists the resources in a database.

**Usage** `listresources <accessPtr>`

**Parameters** `accessPtr` A pointer to the database.

#### Lock

**Purpose** Locks a memory chunk.

**Usage** `lock (<hexChunkPtr> | localID) [options]`

**Parameters** `hexChunkPtr` or `localID`  
A pointer to a chunk in memory, or the ID of a chunk on the specified card number.

`options`  
Optional. You can specify the following options:

- `-card <cardNum>`  
The card number if a local ID is specified instead of a chunk pointer.



## Log

|                   |                                                                            |                                                        |
|-------------------|----------------------------------------------------------------------------|--------------------------------------------------------|
| <b>Purpose</b>    | Toggles logging of debugger output to a file.                              |                                                        |
| <b>Usage</b>      | log <fileName>                                                             |                                                        |
| <b>Parameters</b> | fileName                                                                   | The name of the file to which debugger output is sent. |
| <b>Comments</b>   | Use the log command to start or stop logging of debugger output to a file. |                                                        |

## MDebug

|                   |                                                                                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
|-------------------|-------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>    | Sets the Memory Manager debug mode, which you can use to track down memory corruption problems. |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| <b>Usage</b>      | mdebug [options]                                                                                |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| <b>Parameters</b> | options                                                                                         | Optional. Specify the kernel information that you want to see displayed. Use a combination of the following flags: <ul style="list-style-type: none"><li>-full<br/>Shortcut for full debugging.</li><li>-partial<br/>Shortcut for partial debugging.</li><li>-off<br/>Shortcut to disable debugging.</li><li>-a<br/>Check/scramble all heaps each time.</li><li>-a-<br/>Check only the heap currently in use.</li><li>-c<br/>Check heap(s) on some memory calls.</li><li>-ca<br/>Check heap(s) on all memory calls.</li></ul> |

## Using the Console Window

### Console Window Commands

---

|       |                                                                                               |
|-------|-----------------------------------------------------------------------------------------------|
| -c-   | Do not check heaps.                                                                           |
| -f    | Check free chunk contents.                                                                    |
| -f-   | Do not check free chunk contents.                                                             |
| -min  | Store minimum available free space in dynamic heap in the global variable GMemMinDynHeapFree. |
| -min- | Do not record minimum free space.                                                             |
| -s    | Scramble heap(s) on some memory calls.                                                        |
| -sa   | Scramble heap(s) on all memory calls.                                                         |
| -s-   | Do not scramble heaps.                                                                        |

**Comments**    Use the mdebug command to enable debugging for tracking down memory corruption problems.

---

**IMPORTANT:** The different debug modes enabled by mdebug can significantly slow down operations on the handheld device. Full checking is slowest, partial checking is slow, and only enabling specific options is the fastest.

---

**Example**

```
mdebug -full
Current mode = 003A
Every heap checked/scrambled per call
Heap(s) checked on EVERY Mem call
Heap(s) scrambled on EVERY Mem call
Free chunk contents filled & checked
Minimum dynamic heap free space recording OFF
```

## MoveRecord

**Purpose** Moves a record in the database by changing its index.

**Usage** `moverecord <accessPtr> <fromIndex> <toIndex>`

|                   |                        |                                                   |
|-------------------|------------------------|---------------------------------------------------|
| <b>Parameters</b> | <code>accessPtr</code> | A pointer to the database.                        |
|                   | <code>fromIndex</code> | The original index of the record in the database. |
|                   | <code>toIndex</code>   | The new index for the record in the database.     |

## New

**Purpose** Allocates a new chunk in a heap.

**Usage** `new <heapId> <hexChunkSize> [options]`

|                   |                           |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|-------------------|---------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Parameters</b> | <code>heapId</code>       | The hexadecimal number of the heap in which to allocate a new chunk. Heap number 0x0000 is always the dynamic heap. Note that <code>heapId</code> is ignored if you specify the <code>-near</code> option.                                                                                                                                                                                                                                                                                                                                       |
|                   | <code>hexChunkSize</code> | The number of bytes in the new chunk, specified as a hexadecimal number.                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|                   | <code>options</code>      | Optional. You can specify a combination of the following options: <ul style="list-style-type: none"><li><code>-c</code> Fill the chunk contents.</li><li><code>-lock</code><br/>Pre-lock the chunk.</li><li><code>-n</code> Make the chunk unmoveable.</li><li><code>-near &lt;ptr&gt;</code><br/>Allocate the new chunk in the same heap as the specified pointer. If this option is specified, the <code>heapId</code> is ignored.</li><li><code>-o &lt;ownerId&gt;</code><br/>Set the owner of the chunk to the specified ID value.</li></ul> |

## Using the Console Window

### Console Window Commands

---

#### Open

**Purpose** Opens a database.

**Usage** `open <cardNum> <name> [options]`

**Parameters**

|                      |                                                                                                                                                                                                           |
|----------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>cardNum</code> | The card number on which the database is located. You almost always use 0 to specify the built-in RAM.                                                                                                    |
| <code>name</code>    | The name of the database.                                                                                                                                                                                 |
| <code>options</code> | Optional. You can specify the following options: <ul style="list-style-type: none"><li><code>-r</code> Open the database for read-only access.</li><li><code>-p</code> Leave the database open.</li></ul> |

#### Opened

**Purpose** Lists all of the currently opened databases.

**Usage** `opened`

**Parameters** None.

**Example** `opened`

```
name resDB cardNum accessP ID
openCnt mode

*Graffiti ShortCutsyes 0 00017D5C 001FFE7F
1 0007
*System yes 0 00017FEE 00D20A44
1 0005

Total: 2 databases opened
```

## Performance

|                   |                                                    |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|-------------------|----------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>    | Sets the performance level of the handheld device. |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| <b>Usage</b>      | performance [options]                              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| <b>Parameters</b> | options                                            | <p>You can specify the following options:</p> <ul style="list-style-type: none"><li>-b &lt;baud&gt;<br/>Uses the specified &lt;baud&gt; rate to calculate the nearest clock frequency value.</li><li>-d &lt;duty&gt;<br/>Set the CPU duty cycle. The &lt;duty&gt; value specifies the number of CPU cycles out of every 31 system clock ticks.</li><li>-f &lt;freq&gt;<br/>Set the system clock frequency to the specified Hz value; select the nearest baud multiple as the frequency.</li><li>-ff &lt;freq&gt;<br/>Set the system clock frequency to the specified Hz value; do not pick the nearest baud multiple.</li></ul> |

## PowerOn

|                   |                                |
|-------------------|--------------------------------|
| <b>Purpose</b>    | Powers on the handheld device. |
| <b>Usage</b>      | poweron                        |
| <b>Parameters</b> | None.                          |
| <b>Example</b>    | poweron                        |

## Using the Console Window

### Console Window Commands

---

#### Reset

|                   |                                                                                                                                    |
|-------------------|------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>    | Performs a soft reset on the handheld device.                                                                                      |
| <b>Usage</b>      | <code>reset</code>                                                                                                                 |
| <b>Parameters</b> | None.                                                                                                                              |
| <b>Comments</b>   | This command performs the same reset that is performed when you press the recessed reset button on a Palm Powered handheld device. |
| <b>Example</b>    | <pre>reset Resetting system</pre>                                                                                                  |

#### Resize

|                                                  |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |                                                  |                                                                                    |                         |                                      |                      |                                                                                                                                                                                                                                                                                        |
|--------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------|------------------------------------------------------------------------------------|-------------------------|--------------------------------------|----------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>                                   | Resizes an existing memory chunk.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |                                                  |                                                                                    |                         |                                      |                      |                                                                                                                                                                                                                                                                                        |
| <b>Usage</b>                                     | <code>resize (&lt;hexChunkPtr&gt;   localID) &lt;hexNewSize&gt; [options]</code>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |                                                  |                                                                                    |                         |                                      |                      |                                                                                                                                                                                                                                                                                        |
| <b>Parameters</b>                                | <table><tr><td><code>hexChunkPtr</code> or <code>localID</code></td><td>A pointer to a chunk in memory, or the ID of a chunk on the specified card number.</td></tr><tr><td><code>hexNewSize</code></td><td>The new size of the chunk, in bytes.</td></tr><tr><td><code>options</code></td><td>Optional. You can specify the following options:<ul style="list-style-type: none"><li><code>-c</code> Checks and fills the contents of the resized chunk.</li><li><code>-card &lt;cardNum&gt;</code> The card number if a local ID is specified instead of a chunk pointer.</li></ul></td></tr></table> | <code>hexChunkPtr</code> or <code>localID</code> | A pointer to a chunk in memory, or the ID of a chunk on the specified card number. | <code>hexNewSize</code> | The new size of the chunk, in bytes. | <code>options</code> | Optional. You can specify the following options: <ul style="list-style-type: none"><li><code>-c</code> Checks and fills the contents of the resized chunk.</li><li><code>-card &lt;cardNum&gt;</code> The card number if a local ID is specified instead of a chunk pointer.</li></ul> |
| <code>hexChunkPtr</code> or <code>localID</code> | A pointer to a chunk in memory, or the ID of a chunk on the specified card number.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |                                                  |                                                                                    |                         |                                      |                      |                                                                                                                                                                                                                                                                                        |
| <code>hexNewSize</code>                          | The new size of the chunk, in bytes.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |                                                  |                                                                                    |                         |                                      |                      |                                                                                                                                                                                                                                                                                        |
| <code>options</code>                             | Optional. You can specify the following options: <ul style="list-style-type: none"><li><code>-c</code> Checks and fills the contents of the resized chunk.</li><li><code>-card &lt;cardNum&gt;</code> The card number if a local ID is specified instead of a chunk pointer.</li></ul>                                                                                                                                                                                                                                                                                                                 |                                                  |                                                                                    |                         |                                      |                      |                                                                                                                                                                                                                                                                                        |

## SaveImages

|                   |                            |
|-------------------|----------------------------|
| <b>Purpose</b>    | Saves a memory card image. |
| <b>Usage</b>      | <code>saveimages</code>    |
| <b>Parameters</b> | None.                      |

## SB

|                   |                                               |
|-------------------|-----------------------------------------------|
| <b>Purpose</b>    | Sets the value of a byte in memory.           |
| <b>Usage</b>      | <code>sb &lt;addr&gt; &lt;value&gt;</code>    |
| <b>Parameters</b> | <code>addr</code> The address of the byte.    |
|                   | <code>value</code> The new value of the byte. |

## SetInfo

|                   |                                                                                                                                                                                                                                                                        |
|-------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>    | Sets new information values for a database.                                                                                                                                                                                                                            |
| <b>Usage</b>      | <code>setinfo &lt;cardNum&gt; &lt;dbName&gt; [options]</code>                                                                                                                                                                                                          |
| <b>Parameters</b> | <code>cardNum</code> The card number on which the database is located. You almost always use 0 to specify the built-in RAM.                                                                                                                                            |
|                   | <code>dbName</code> The name of the database.                                                                                                                                                                                                                          |
|                   | <code>options</code> Options. You can specify a combination of the following values:<br>-m <modification><br>Sets the modification number for the database.<br>-n <name><br>Sets the name of the database.<br>-v <version><br>Sets the version number of the database. |
|                   |                                                                                                                                                                                                                                                                        |

## SetOwner

**Purpose** Sets the owner ID of a memory chunk.

**Usage** `setowner (<hexChunkPtr> | <localID>) <owner> [options]`

**Parameters**

|                                                  |                                                                                                                                                                                                     |
|--------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>hexChunkPtr</code> or <code>localID</code> | A pointer to a chunk in memory, or the ID of a chunk on the specified card number.                                                                                                                  |
| <code>hexNewSize</code>                          | The new size of the chunk, in bytes.                                                                                                                                                                |
| <code>owner</code>                               | The new owner ID for the chunk.                                                                                                                                                                     |
| <code>options</code>                             | Optional. You can specify the following options:<br><code>-card &lt;cardNum&gt;</code><br>The card number if a local ID is specified instead of a chunk pointer. Use 0 to specify the built-in RAM. |

## SetRecordInfo

**Purpose** Changes information for a record in a database.

**Usage** `setrecordinfo <accessPtr> <index> [options]`

**Parameters**

|                        |                                                                                                                                                                                                                                  |
|------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>accessPtr</code> | A pointer to the database.                                                                                                                                                                                                       |
| <code>index</code>     | The index of the record in the database.                                                                                                                                                                                         |
| <code>options</code>   | Optional. You can specify a combination of the following options:<br><code>-a &lt;hexAttr&gt;</code><br>Sets attribute bit settings for the record.<br><code>-u &lt;uniqueId&gt;</code><br>Sets unique record ID for the record. |



## SetResourceInfo

**Purpose** Changes information for a resource in a database.

**Usage** `setresourceinfo <accessPtr> <index> [options]`

**Parameters**

|                        |                                                                                                                                                                                                                                                                          |
|------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>accessPtr</code> | A pointer to the database.                                                                                                                                                                                                                                               |
| <code>index</code>     | The index of the resource in the database.                                                                                                                                                                                                                               |
| <code>options</code>   | Optional. You can specify a combination of the following options: <ul style="list-style-type: none"><li><code>-t &lt;resType&gt;</code><br/>Sets resource type for the resource.</li><li><code>-id &lt;resId&gt;</code><br/>Sets resource ID for the resource.</li></ul> |

## SimSync

**Purpose** Simulates a synchronization operation on a specific database.

**Usage** `simsync <accessPtr>`

**Parameters** `accessPtr` A pointer to the database.

## Sleep

**Purpose** Shuts down all peripherals, the CPU, and the system clock.

**Usage** `sleep`

**Parameters** None.

## Using the Console Window

### Console Window Commands

---

## StoreInfo

**Purpose** Displays information about a memory store.

**Usage** `storeinfo <cardNum>`

**Parameters** `cardNum` The card number for which you want information displayed. You almost always use 0 to specify the built-in RAM.

**Example** `storeinfo 0`

```
ROM Store:
version: 0001
flags: 0000
name: ROM Store
creation date: 00000000
backup date: 00000000
heap list offset: 00C08208
init code offset1: 00C0D652
init code offset2: 00C1471E
database dirID: 00D20F7E
```

```
RAM Store:
version: 0001
flags: 0001
name: RAM Store 0
creation date: 00000000
backup date: 00000000
heap list offset: 00018100
init code offset1: 00000000
init code offset2: 00000000
database dirID: 0001811F
```

## Switch

**Purpose** Switches the application that is used to provide the user interface on the handheld device.

**Usage** `switch <cardNum> <name> [<cmd> <cmdStr>]`

|                   |                      |                                                                                                                                |
|-------------------|----------------------|--------------------------------------------------------------------------------------------------------------------------------|
| <b>Parameters</b> | <code>cardNum</code> | The number of the card on which the user interface application is stored. You almost always use 0 to specify the built-in RAM. |
|                   | <code>name</code>    | The name of the application.                                                                                                   |
|                   | <code>cmd</code>     | Optional. Use to specify a command for the application.                                                                        |
|                   | <code>cmdStr</code>  | Optional. Use to specify an arguments string for <code>cmd</code> .                                                            |

## SysAlarmDump

**Purpose** Displays the system alarm table.

**Usage** `sysalarmdump`

**Parameters** None.

**Example** `sysalarmdump`

```
 date time ref alarm dbID card
 triged noted # quiet

7/29/1999 00:00 00000000 B3C54A00 00D1FCF8 4004 false
false false
1/ 1/1904 00:00 00000000 00000000 00000000 0000 false
false true
```

## Unlock

**Purpose**      Unlocks a memory chunk.

**Usage**      `unlock (<hexChunkPtr> | localID>) [options]`

**Parameters**    `hexChunkPtr` or `localID`  
A pointer to a chunk in memory, or the ID of a chunk on the specified card number.

`options`  
Optional. You can specify the following options:

`-card <cardNum>`  
The card number if a local ID is specified instead of a chunk pointer.

## Console Command Summary

### Card Information Commands

|                         |                                             |
|-------------------------|---------------------------------------------|
| <code>CardFormat</code> | Formats a memory card.                      |
| <code>CardInfo</code>   | Retrieves information about a memory card.  |
| <code>StoreInfo</code>  | Retrieves information about a memory store. |

### Chunk Utility Commands

|                       |                                       |
|-----------------------|---------------------------------------|
| <code>Free</code>     | Disposes of a heap chunk.             |
| <code>Info</code>     | Displays information on a heap chunk. |
| <code>Lock</code>     | Locks a heap chunk.                   |
| <code>New</code>      | Allocates a new chunk in a heap.      |
| <code>Resize</code>   | Resizes an existing heap chunk.       |
| <code>SetOwner</code> | Sets the owner of a heap chunk.       |
| <code>Unlock</code>   | Unlocks a heap chunk.                 |

## Database Utility Commands

|         |                                                                                       |
|---------|---------------------------------------------------------------------------------------|
| Close   | Closes a database.                                                                    |
| Create  | Creates a new database.                                                               |
| Del     | Deletes a database.                                                                   |
| Dir     | Lists the databases.                                                                  |
| Export  | Exports a database to the desktop computer.                                           |
| Import  | Imports a database from the desktop computer.                                         |
| Open    | Opens a database.                                                                     |
| Opened  | Lists all currently opened databases.                                                 |
| SetInfo | Sets database information, such as its name, version number, and modification number. |

## Debugging Utility Commands

|        |                                     |
|--------|-------------------------------------|
| DM     | Displays memory.                    |
| GDB    | Enables or disables Gdb debugging.  |
| MDebug | Sets the Memory Manager debug mode. |
| SB     | Sets the value of a byte.           |

## Gremlin Commands

|            |                                                                 |
|------------|-----------------------------------------------------------------|
| Gremlin    | Activates the specified gremlin until a specified event occurs. |
| GremlinOff | Deactivates the current gremlin.                                |

## Heap Utility Commands

|      |                                   |
|------|-----------------------------------|
| HC   | Compacts a memory heap.           |
| HChk | Checks a heap.                    |
| HD   | Displays a dump of a memory heap. |

## Using the Console Window

### *Console Command Summary*

---

|          |                                                                               |
|----------|-------------------------------------------------------------------------------|
| HF       | Allocates all free space in a memory heap, minus a specified number of bytes. |
| HI       | Initializes a memory heap.                                                    |
| HL       | Lists all of the memory heaps on the specified memory card.                   |
| HS       | Scrambles a heap.                                                             |
| HT       | Performs a heap total.                                                        |
| HTorture | Torture-tests a heap.                                                         |

### Host Control Commands

|            |                                          |
|------------|------------------------------------------|
| Help       | Provides help on the console commands.   |
| Log        | Starts or stops logging to a file.       |
| SaveImages | Saves an image of a memory card to file. |

### Miscellaneous Utility Commands

|              |                                                      |
|--------------|------------------------------------------------------|
| SimSync      | Simulates a synchronization operation on a database. |
| SysAlarmDump | Displays the alarm table.                            |

### Record Utility Commands

|              |                                         |
|--------------|-----------------------------------------|
| AddRecord    | Adds a record to a database.            |
| AttachRecord | Attaches a record to a database.        |
| ChangeRecord | Replaces a record in a database.        |
| DelRecord    | Deletes a record from a database.       |
| DetachRecord | Detaches a record from a database.      |
| FindRecord   | Finds a record by its unique ID.        |
| ListRecords  | Lists all of the records in a database. |

|                            |                                                         |
|----------------------------|---------------------------------------------------------|
| <code>MoveRecord</code>    | Changes the index of a record.                          |
| <code>SetRecordInfo</code> | Sets record information, such as its ID and attributes. |

## **Resource Utility Commands**

|                              |                                                              |
|------------------------------|--------------------------------------------------------------|
| <code>AddResource</code>     | Adds a resource to a database.                               |
| <code>AttachResource</code>  | Attaches a resource to a database.                           |
| <code>ChangeResource</code>  | Replaces a resource in a database.                           |
| <code>DelResource</code>     | Deletes a resource from a database.                          |
| <code>DetachResource</code>  | Detaches a resource from a database.                         |
| <code>GetResource</code>     | Retrieves a resource from a database.                        |
| <code>ListResources</code>   | Lists all resources in a database.                           |
| <code>SetResourceInfo</code> | Sets resource information, such as its ID and resource type. |

## **System Commands**

|                       |                                                                                                     |
|-----------------------|-----------------------------------------------------------------------------------------------------|
| <code>Battery</code>  | Battery utility command for starting or stopping radio charging, and for setting the loaded status. |
| <code>ColdBoot</code> | Boots the handheld device.                                                                          |
| <code>Doze</code>     | Puts the CPU to sleep while keeping the peripherals and clock running on the handheld device.       |
| <code>Exit</code>     | Exits the console.                                                                                  |
| <code>Feature</code>  | Displays, retrieves, registers, or unregisters features.                                            |
| <code>KInfo</code>    | Displays kernel information.                                                                        |
| <code>Launch</code>   | Launches an application.                                                                            |

## Using the Console Window

### *Console Command Summary*

---

|             |                                                                                 |
|-------------|---------------------------------------------------------------------------------|
| Performance | Sets performance levels, such as the system clock frequency and CPU duty cycle. |
| PowerOn     | Powers on the handheld device.                                                  |
| Reset       | Resets the memory system and formats both cards.                                |
| Sleep       | Shuts down all peripherals, the CPU, and the system clock.                      |
| Switch      | Switches the current user interface application.                                |





# **Part III: Tracing Your Application**



# Using Palm Reporter

---

This chapter describes Palm Reporter, which you can use to do trace analysis of your Palm OS® applications. The following topics are covered in this chapter:

- “[About Palm Reporter](#)” - An introduction to Palm Reporter concepts
- “[Downloading Palm Reporter](#)” on page 356 - How to download and install the Palm Reporter package
- “[Adding Trace Calls to Your Application](#)” on page 357 - How to add HostControl trace calls to your application
- “[Displaying Trace Information in Palm Reporter](#)” on page 360 - How to open a Palm Reporter session to view the trace information
- “[Troubleshooting Palm Reporter](#)” on page 363 - How to make sure Palm Reporter is running correctly

## About Palm Reporter

Palm Reporter is a trace utility that can be used with Palm OS Emulator. As an application runs on Palm OS Emulator, it can send information in real time to Reporter. This information can help pinpoint problems that might be hard to identify when executing code step-by-step or when specifying breakpoints. To view the realtime traces, simply run Reporter at the same time as you run your application on Palm OS Emulator.

## Palm Reporter Features

Palm Reporter has a number of features that make it useful:

- High throughput of trace output, allowing for realtime traces
- Trace output filtering, searching, saving, printing, and copying

- Display of Trace output through a TCP/IP connection

## Downloading Palm Reporter

The most recent released version of Palm Reporter is posted on the internet in the Palm™ developer zone:

<http://www.palmos.com/dev>

Follow the links from the developer zone main page to the Emulator page to retrieve the released version of Palm Reporter.

### Palm Reporter Package Files

The Palm Reporter package includes the following files:

**Table 8.1 Files Included in the Palm Reporter Package**

| File                      | Description                                                                                                                                    |
|---------------------------|------------------------------------------------------------------------------------------------------------------------------------------------|
| Reporter.exe              | Main Palm Reporter program file (Windows only)                                                                                                 |
| PalmTrace.dll             | Palm OS Emulator add-on that relays traces to Palm Reporter (Windows only)                                                                     |
| TracingApp.prc            | Sample application containing HostTrace API calls                                                                                              |
| Documentation (directory) | Palm Reporter documentation, including: <ul style="list-style-type: none"><li>• Reporter guide.html</li><li>• Reporter protocol.html</li></ul> |

### Installing Palm Reporter

Palm Reporter requires Palm OS Emulator. Place the `PalmTrace.dll` in the same directory as Palm OS Emulator (`Emulator.exe`). Emulator will not be able to send trace information to Reporter if it cannot find and load `PalmTrace.dll`.

The Reporter.exe file can be located in any folder on your Windows system; it does not need to be in the same directory as Palm OS Emulator.

---

**NOTE:** Palm Reporter requires Windows 95, Windows NT, Windows 98 or Windows 2000 to run; it is a multi-threaded Win32 program. Reporter will not run on Windows 3.1 even with Win32 DLLs installed. Also, only the Win32 version of Palm OS Emulator can be used to handle traces.

---

## Adding Trace Calls to Your Application

Traces are generated by system calls that are recognized by Palm OS Emulator but ignored by actual handheld devices. These system calls are listed in `hostcontrol.h`, which is part of both the Palm OS SDK and the Palm OS Emulator package. For more information about the HostControl API, see [Chapter 2, “Host Control API Reference.”](#)

The HostControl system calls pertinent to tracing are listed in the following table:

| System Call Format                                                             | Function Description                                                      |
|--------------------------------------------------------------------------------|---------------------------------------------------------------------------|
| <code>void HostTraceInit(void)</code>                                          | Initiate a connection to Reporter                                         |
| <code>void HostTraceOutputT(UINT16 mod, const char* fmt, ...)</code>           | Output a string to Reporter (printf format)                               |
| <code>void HostTraceOutputTL(UINT16 mod, const char* fmt, ...)</code>          | Output a string to Reporter (printf format) with an additional line break |
| <code>void HostTraceOutputB(UINT16 mod, const char* buff, UINT32 len)</code>   | Send binary data to Reporter                                              |
| <code>void HostTraceOutputVT(UINT16 mod, const char* fmt, va_list vars)</code> | Output a string to Reporter (vprintf format)                              |

## Using Palm Reporter

### *Adding Trace Calls to Your Application*

---

| System Call Format                                                               | Function Description                                                       |
|----------------------------------------------------------------------------------|----------------------------------------------------------------------------|
| <code>void HostTraceOutputVTL(UInt16 mod, const char* fmt, va_list vargs)</code> | Output a string to Reporter (vprintf format) with an additional line break |
| <code>void HostTraceClose(void)</code>                                           | Close the connection to Reporter                                           |

All `HostTraceOutput` functions take an error class identifier as their first parameter. This parameter allows filtering of traces according to their origin. Recognized error classes are listed in `SystemMgr.h`. For example, applications should specify the error class `appErrorClass`.

## Specifying Trace Strings

Trace strings use the following format:

```
% <flags> <width> <type>
<flags>
```

- Left-justify display (Default is right justify)
- + Always display the sign character (Default is to display the sign character for negative values only)
- space Display a space (when a value is positive) rather than displaying a "+" sign
- # Alternate form specifier

<width> Must be a positive number

<type>

- % Display a "%" character
- s Display a null-terminated string
- c Display a character
- ld) Display an Int32 value
- lu Display a UInt32 value

lX or lx

Display an Int32 or UInt32 value in hexadecimal

hd Display an Int16 value

hu Display a UInt16 value

hX or hX

Display an Int16 or UInt16 value in hexadecimal

---

**NOTE:** The following types are not supported for <type>: o, e, E, f, F, g, G, p, l, n, d, i, u, X, or x.

---

## Trace Functions in a Code Sample

---

```
void function(void)
{
 unsigned char theBuffer[256];
 unsigned long theUInt32 = 0xFEDC1234;
 unsigned short theUInt16 = 0xFE12;
 int i;

 HostTraceInit();

 HostTraceOutputTL(appErrorClass, "This is an Int32:");
 HostTraceOutputTL(appErrorClass, " unsigned (lu) [4275835444]=[%lu]", theUInt32);
 HostTraceOutputTL(appErrorClass, " signed (ld) [-19131852]=[%ld]", theUInt32);
 HostTraceOutputTL(appErrorClass, " hexa (lx) [fedc1234]=[%lx]", theUInt32);

 HostTraceOutputTL(appErrorClass, "This is an Int16:");
 HostTraceOutputTL(appErrorClass, " unsigned (hu) [65042]=[%hu]", theUInt16);
 HostTraceOutputTL(appErrorClass, " signed (hd) [-494]=[%hd]", theUInt16);
 HostTraceOutputTL(appErrorClass, " hexa (hX) [FE12]=[%hX]", theUInt16);

 HostTraceOutputTL(appErrorClass, "This is a string (s) [Hello world]=[%s]", "Hello world");
 HostTraceOutputTL(appErrorClass, "This is a char (c) [A]=[%c]", 'A');

 HostTraceOutputTL(appErrorClass, "This is a buffer:");

 for (i = 0 ; i < 256 ; i++) theBuffer[i] = (unsigned char) i;

 HostTraceOutputB(appErrorClass, theBuffer, 256);
}
```

## Using Palm Reporter

### *Displaying Trace Information in Palm Reporter*

---

```
HostTraceClose();
}
```

---

## Displaying Trace Information in Palm Reporter

To view trace information in Palm Reporter, you need to do the following:

- Add trace calls to your application and build your application
- Start a Palm Reporter session
- Start a Palm OS Emulator session
  - Set the Emulator “Tracing Options” to display output to “Palm Reporter”
  - Install your trace-enabled application in the Emulator session
  - Run your trace-enabled application in the Emulator session

### Starting a Palm Reporter Session

To start a Palm Reporter session, run the `Reporter.exe` file. After starting Palm Reporter, you should see an empty window. This window will serve as a container for other windows which display the trace information. A new trace window is created for each `HostTraceInit` to `HostTraceClose` sequence in your trace-enabled application.


Each `HostTraceOutput` call will send information into the current trace window. The `HostTraceOutput` call will fail if there is no active trace window, which can happen if Reporter is not running when the `HostTraceInit` function is called.

Also, a reset in Emulator will close any pending connection. That is, Emulator will call the `HostTraceClose` function for your application if you used `HostTraceInit` to open a trace connection.

[Figure 8.1](#) shows a Palm Reporter session window.



Figure 8.1 Palm Reporter Session Window



## Filtering Information in a Palm Reporter Session

You can control the type of trace information Palm Reporter displays. You control this information by setting *filters*. Filters can be set either globally, by using the **Global filters...** menu, or for the current window, by using the **Active view filters...** menu. By enabling or disabling the filters, you can choose to view traces sent by corresponding modules in your application. Global filter settings are saved when you exit the Palm Reporter session.













## Using Palm Reporter



### *Displaying Trace Information in Palm Reporter*

---

## Using the Palm Reporter Toolbar

Palm Reporter provides a toolbar with the following functions:

| Toolbar Icon                                                                        | Function                                                                   |
|-------------------------------------------------------------------------------------|----------------------------------------------------------------------------|
|    | Save the contents of the Reporter window to a file                         |
|    | Print the contents of the Reporter window                                  |
|    | Select all of the text in the Reporter window                              |
|    | Copy the selected text into the Windows clipboard                          |
|    | Clear the contents of the Reporter window                                  |
|  | Draw a horizontal line across the Reporter window                          |
|  | Search the Reporter window for specified text                              |
|  | Search the Reporter window for the next occurrence of specified text       |
|  | Search the Reporter window for the previous occurrence of specified text   |
|  | Set “on top” mode to keep the Reporter window always visible on the screen |
|  | Set filters for the current window only                                    |
|  | Set font for the current window only                                       |

| Toolbar Icon                                                                      | Function                        |
|-----------------------------------------------------------------------------------|---------------------------------|
|  | Set filters for all new windows |
|  | Set font for all new windows    |

## Troubleshooting Palm Reporter

**Table 8.2 How to Solve Possible Palm Reporter Problems**

| Symptom                                                                                                        | Solution                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|----------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| You are unable to set the Emulator “Tracing Options” to display output to “Palm Reporter”.                     | Make sure that the file <code>PalmTrace.dll</code> is in the same directory as <code>Emulator.exe</code> .                                                                                                                                                                                                                                                                                                                                                                       |
| The <code>PalmTrace.dll</code> file doesn’t appear in the folder where you decompressed the Reporter’s archiv. | Check to see if your Windows shell is configured to “Hide system files.”                                                                                                                                                                                                                                                                                                                                                                                                         |
| Nothing appears in the Palm Reporter session window.                                                           | Make sure that: <ul style="list-style-type: none"><li>• <code>PalmTrace.dll</code> is in the same directory as <code>Emulator.exe</code>.</li><li>• Your application code is calling <code>HostTraceInit</code>.</li><li>• You are using Palm OS Emulator version 3.0a4 or later.</li><li>• You have set the Emulator “Tracing Options” to display output to “Palm Reporter”.</li><li>• Your filters are set correctly, and traces are emitted with the right modules.</li></ul> |
| You have checked everything in this table, and Reporter still isn’t displaying trace information.              | Send a note describing your problem to <a href="mailto:reporter@palm.com">reporter@palm.com</a> .                                                                                                                                                                                                                                                                                                                                                                                |

**Table 8.3 Palm Reporter Error Message**

| <b>Error Message</b>                                       | <b>Problem</b>                              | <b>Possible Solution</b>                                                                          |
|------------------------------------------------------------|---------------------------------------------|---------------------------------------------------------------------------------------------------|
| An error occurred while trying to listen for traces.       | Default reception port is already in use.   | Check that no other instance of the Reporter is running.                                          |
| An error occurred while initializing ObjectSet.            | Framework initialization failed.            | Send a note describing your problem to <a href="mailto:reporter@palm.com">reporter@palm.com</a> . |
| An error occurred while ObjectSet was initializing TCP/IP. | TCP/IP related failure.                     | Check that TCP/IP networking is correctly set up.                                                 |
| Cannot load filters description.                           | The Reporter executable file was altered.   | Send a note describing your problem to <a href="mailto:reporter@palm.com">reporter@palm.com</a> . |
| Unable to start a reader thread.                           | Reporter could not create receiver thread.  | Free up system resources.                                                                         |
| Unable to start a format thread.                           | Reporter could not create displayer thread. | Free up system resources.                                                                         |







# **Part IV: Creating National Language Versions of Your Application**





# Using the Overlay Tools

---

This chapter describes how the PRC-to-Overlay tools can be used to produce a localized version of an application. The following topics are covered in this chapter:

- [“Using Overlays to Localize Resources”](#) - An overview of using overlay databases to localize application resources.
- [“About the Overlay Tools”](#) on page 371 - An introduction to the PRC-to-Overlay and Patch Overlay tools.
- [“Using the PRC-to-Overlay Function”](#) on page 371 describes how to create overlay resource databases for localized data.
- [“Using the Patch Overlay Function”](#) on page 374 describes how to use multiple overlay resource databases with a single bases application database.
- [“PRC2OVL Options Summary”](#) on page 375 lists the command line options used with PRC2OVL.
- [“Using PRC2OVL on the Macintosh”](#) on page 377 contains special instructions for using PRC2OVL on a Macintosh system.

## Using Overlays to Localize Resources

Palm OS® 3.5 added support for localizing applications through overlay databases. Each overlay database is a separate resource database that provides an appropriately localized set of resources for a single base database (a PRC file) and a single target locale (language and country).

Support for overlay databases is provided by Overlay Manager. To use Overlay Manager, create a base application that has your base resources (usually English) for your user interface and a separate overlay database that has the substitutions you want to make for

## Using the Overlay Tools

### *Using Overlays to Localize Resources*

---

each locale (French, German, Japanese, etc.). When an application runs on a localized version of Palm OS, Overlay Manager automatically substitutes localized resources from the appropriate overlay database at runtime. Alternatively, you can use Data Manager routine `DMOpenDBWithLocale()` to open a base database with an arbitrary overlay.

For more information about Overlay Manager and localizing your applications, see *Palm OS Programmer's Companion*.

## Overlay Database Names

Each overlay database name contains a *locale suffix*. A locale consists of a language indicator and a country code:

- The first two letters indicate the language and must be lower case.
- The second two letters indicate the country and must be upper case.

For example, the database name `Address_Book_enUS.PRC` indicates that this is an overlay for the language “English” and the country “United States.”

## Overlay Specification Resources

Overlay specification resources establish a link between the base and the overlay databases. They bind resources together and are important when you have multiple version of the same database (for example, version 1 and version 2 of an application). Overlay specifications are required for overlay databases, but optional for the base database.

Overlay specification resources contain the following information:

- Type information (`'ovly'` for overlay databases)
- ID = 1000
- Target locale (language and country)
- Information about the base database (type, creator, checksum, etc.)
- Information about each overlaid resource. This content specifies exactly which resources are overlaid. Normally, this

content consists of replacements for resources in the base, but it can also specify additional resources that are not in the base.

## About the Overlay Tools

The overlay tools allow you to produce an overlay database that can be superimposed on top of another so that any requests for the underlying base database first go through the overlay database. This allows localization to be performed by placing the localized (for example, German) data in an overlay for a particular locale (for example, Germany).

You can edit and distribute the overlay separately from the underlying database. Because the overlay only needs to contain localized data, it does not need to include your application code or other large resources.

## Using the PRC-to-Overlay Function

The PRC-to-Overlay function takes a normal resource database (usually an application) as input and produces an overlay. You can also give the tool an overlay as input to create a new overlay for a different locale.

### How the PRC-to-Overlay Function Works

The PRC-to-Overlay function takes a single file as input, passes the file through a set of filters to decide which particular resources (components of the database) are localizable and should be put in the overlay. Then, given a particular locale, the tool generates an overlay file.

### Choosing a Locale

A locale consists of a language indicator and a country code:

- The first two letters indicate the language and must be lower case.

## Using the Overlay Tools

### *Using the PRC-to-Overlay Function*

---

- The second two letters indicate the country and must be upper case.

To list the available language and country codes, use the following command:

```
prc2ovl -showlocales
```

For example, the following command creates an English language overlay for the country United States (using the default filter set):

```
PRC2OVL NewApp.prc -locale enUS -o
NewApp_enUS.prc
```

where:

|                    |                                                                                                |
|--------------------|------------------------------------------------------------------------------------------------|
| NewApp.prc         | Indicates the input file name "NewApp.prc"                                                     |
| -locale enUS       | Indicates the language code is "en" for English and the country code is "US" for United States |
| -o NewApp_enUS.prc | Specifies the output file name "NewApp_enUS.prc"                                               |

## Modifying the Filter Set

A filter set indicates which particular resources (components of the database) are localizable and which resources should be put in the overlay PRC.

To modify the filter set, use the -a, -n, -i, and -e switches:

- a indicates that all resources are to be localized.
- n indicates that no resources are to be localized.
- i includes a particular set of resources (in the list of localized resources).
- e excludes a particular set.

Each switch operates in the order in which it appears on the command line. The last switch that matches is the one that is operated on. For example, the filter set:

```
-n -i tFRM 1000
```

produces an overlay that only contains the single `'tFRM 1000'` resource (if it is present in the input), but the filter set:

```
-a -e tFRM 1000
```

localizes everything but the `'tFRM 1000'` resource.

### Default Filters

Recreate the default filters with the following set of parameters:

```
-a -e CODE -e DATA -e code -e data
-e boot -e extn -e pref
```

### Restricting Resource Matches

You can restrict matches by ID number. For example, if you only want to localize resource type `'BAZZ'` with ID 567, specify the filter set:

```
-i BAZZ 567
```

You can also supply ranges in your filter set, as shown in the following example:

```
-i BAZZ 567-599
```

**Note:** To see which resources are selected in the output, use the `-v` (for verbose) switch.

## PRC2OVL Example

This example shows the files that are included as part of an application that needs to be localized.

The `NewApp.prc` file contains the application named `NewApp` which is written in English. The PRC file contains the following resources:

- Resource 0: `'CODE' 0`, application code
- Resource 1: `'CODE' 1`, more application code
- Resource 2: `'tFRM' 1000`, application form
- Resource 3: `'tSTR' 1000`, UI strings

## Using the Overlay Tools

### *Using the Patch Overlay Function*

---

Using the following command:

```
PRC2OVL NewApp.prc -locale deDE -o
NewApp_deDE.prc
```

Creates a German overlay, `NewApp_deDE.prc`, which is a file containing the following resources:

- Resource 0: `'tFRM' 1000`, application form
- Resource 1: `'tSTR' 1000`, UI strings

## Using the Patch Overlay Function

The Patch Overlay function takes two input files, a base PRC and an overlay PRC, and outputs a new overlay PRC that has been modified so it will work with the given base PRC. This is accomplished by copying the appropriate data over the overlay resource in the overlay file, synthesizing necessary data if the base PRC was stripped.

You specify the Patch Overlay function with the `-p` switch. For example,

```
PRC2OVL OrigGermanOvl.prc -c
-p EnglishBase.prc -o FixedGermanOvl.prc
```

where:

`OrigGermanOvl.prc`

Indicates the input overlay PRC filename.

`-c`

Indicates whether to generate a new checksum for the output overlay PRC.

If you omit the `"-c"` parameter, then `PRC2OVL` will copy appropriate data over the overlay resource in the overlay file, synthesizing necessary data if the base PRC was stripped, and will generate a new checksum for the output overlay PRC.

If you include the “-c” parameter, then PRC2OVL will simply generate a new checksum for the output overlay PRC, without copying data over the overlay resource in the overlay PRC.

-p EnglishBase.prc

Indicates this is a Patch Overlay function and EnglishBase.prc is the input base PRC filename.

-o FixedGermanOvl.prc

Indicates the output overlay PRC filename.

### **Example**

This example shows how you could build two language versions as separate projects, and generate two language overlays that would work for a single base:

1. Build your English language project: EnglishApp.prc.
2. Create a second project, where you duplicate the code from the first project, but change the resources for your desired localization. For example: GermanApp.prc.
3. Use PRC-to-Overlay to generate an English overlay: EnglishOvl.prc.
4. Use PRC-to-Overlay to generate a German overlay: GermanOvl.prc.
5. Use the Patch Overlay function to incorporate the checksums and overlay resource descriptions from the English application into the GermanOvl.prc, calling it FixedGermanOvl.prc.

As a result, you would have an EnglishBase.prc that would work with two overlay PRCs: EnglishOvl.prc and FixedGermanOvl.prc.

## **PRC2OVL Options Summary**

The following tables list the PRC2OVL command line options. These options can be specified in any order.

## Using the Overlay Tools

### PRC2OVL Options Summary

---

**Table 9.1 PRC2OVL Options for the PRC-to-Overlay Function**

| Option                  | Description                                                                                                                                                                                                  |
|-------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| -h                      | Display help information.                                                                                                                                                                                    |
| -o <i>filename</i>      | Specify the name of output file.                                                                                                                                                                             |
| -showlocales            | List the available language and country codes.                                                                                                                                                               |
| -locale <i>llCC</i>     | Specify a locale code, where <i>ll</i> indicates the language and <i>CC</i> indicates the country code.                                                                                                      |
| -a                      | Specify a filter set that localizes all resources.                                                                                                                                                           |
| -n                      | Specify a filter set that localizes no resources.                                                                                                                                                            |
| -i <i>resourceID(s)</i> | Specify a filter set that includes a particular set of resources, where <i>resourceID(s)</i> can be a single resource ID number (for example, 567) or a range of resource ID numbers (for example, 567-599). |
| -e <i>resourceID(s)</i> | Specify a filter set that excludes a particular set of resources, where <i>resourceID(s)</i> can be a single resource ID number (for example, 567) or a range of resource ID numbers (for example, 567-599). |
| -v                      | Print status information to the screen.                                                                                                                                                                      |

---

**Table 9.2 PRC2OVL Options for the Patch Overlay Function**

| Option             | Description                                                                                                            |
|--------------------|------------------------------------------------------------------------------------------------------------------------|
| -h                 | Display help information.                                                                                              |
| -c                 | Generate a new checksum for the output overlay PRC, without copying data over the overlay resource in the overlay PRC. |
| -p <i>filename</i> | Specify the name of the input base PRC file.                                                                           |
| -o <i>filename</i> | Specify the name of output overlay PRC file.                                                                           |

---



## Getting Help

You can get help when you:

- Run PRC2OVL (or MPWPRC2OVL) without arguments.
- Enter invalid arguments.
- Use `-h` on the command line.

Help lists the default resource selection filters.

## Using PRC2OVL on the Macintosh

This section describes how to use PRC2OVL on a Macintosh graphical user interface (GUI).

### Opening a PRC file

You can use the Mac GUI to create an overlay for a PRC file; typically the PRC file contains an application or a preference panel. Open the PRC file, then pick a target locale (which is the same as the `-locale` switch). The application displays the entire list of resources in the file, using the same default selection criteria, if necessary, to provide a suggested set of resources to localize. You can edit these by clicking on the checkbox by each item in the list. Then you can build an output file by clicking on the Build button.

### Selecting Resources

The Mac GUI tool lets you select the resources you want to localize from a list rather than specifying resources with filters on the command line. By default, the tool assumes that all resources are overlaid except those of types `'CODE'`, `'DATA'`, `'code'`, `'data'`, `'boot'`, `'extn'`, and `'pref'`. (You can select other resources via the filter options you use in the command-line tool.)





# **Part V: Appendixes**



# Resource Tools

---

There are two tools provided with the Metrowerks CodeWarrior environment that you can use to work with resources:

- Use the Rez tool to compile a textual description of the resources for your application into a resource file.
- Use the DeRez tool to decompile a resource file into a text file.

Both of these tools are standard Apple Computer tools for working with MacOS application resources. Documentation for both the Rez and DeRez programs is found in the Apple book *Building and Managing Programs in MPW, 2nd Edition*. This book is available online at the following URL:

<http://developer.apple.com/tools/mpw-tools/books.html>



# Simple Data Types

---

[Table B.1](#) describes the simple data types, which have been renamed in the newest release of the Palm OS® software.

**Table B.1 Simple Data Types**

| Old data type name | New data type name | Description                |
|--------------------|--------------------|----------------------------|
| Byte               | UInt8              | unsigned 8-bit value       |
| UChar              | UInt8              | unsigned 8-bit value       |
| SByte              | Int8               | signed 8-bit value         |
| Int                | Int16              | signed 16-bit value        |
| SWord              | Int16              | signed 16-bit value        |
| Short              | Int16              | signed 16-bit value        |
| UShort             | UInt16             | unsigned 16-bit value      |
| UInt               | UInt16             | unsigned 16-bit value      |
| Word               | UInt16             | unsigned 16-bit value      |
| Long               | Int32              | signed 32-bit value        |
| SDWord             | Int32              | signed 32-bit value        |
| ULong              | UInt32             | unsigned 32-bit value      |
| DWord              | UInt32             | unsigned 32-bit value      |
| Handle             | MemHandle          | a handle to a memory chunk |
| VoidHand           | MemHandle          | a handle to a memory chunk |
| Ptr                | MemPtr             | a pointer to memory        |
| VoidPtr            | MemPtr             | A pointer to memory        |





# Glossary

---

|                                  |                                                                                                                                                                                                                                                                                             |
|----------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>application error message</b> | A message displayed when software running on the handheld device calls a system function such as <code>ErrDisplayFileLineMsg</code> or <code>SysFatalAlert</code> .                                                                                                                         |
| <b>BigROM</b>                    | The ROM code that initializes the hardware and contains all of the system code.                                                                                                                                                                                                             |
| <b>command request packet</b>    | A packet sent from a debugging host to a debugging target that requests a certain action.                                                                                                                                                                                                   |
| <b>command response packet</b>   | A packet sent from a debugging target to a debugging host in response to a command request packet, or in response to a state change.                                                                                                                                                        |
| <b>console nub</b>               | A background thread on the handheld device that listens for commands on the serial or USB port. This thread provides the functionality required to perform database and heap management functions, and must be activated before Palm Debugger's console commands can be sent to the device. |
| <b>debugger nub</b>              | A background thread on the handheld device that listens for commands on the serial or USB port. This thread provides the functionality required to support debugging of Palm OS applications, and must be activated before Palm Debugger's debugging commands can be sent to the device.    |
| <b>debugging host</b>            | The desktop computer that hosts the debugging program.                                                                                                                                                                                                                                      |
| <b>debugging target</b>          | The handheld device ROM or emulator running the executable that is being debugged.                                                                                                                                                                                                          |
| <b>gremlin</b>                   | A series of user input events that test your application's capabilities.                                                                                                                                                                                                                    |

## Glossary

---

|                                |                                                                                                                                                                                                                                  |
|--------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>gremlin horde</b>           | A group of gremlins that you can use to test specific capabilities.                                                                                                                                                              |
| <b>heap scrambling</b>         | The process of moving items around in a heap to test if a program has correctly used handles for memory accesses. Direct memory pointers will no longer work after the heap has been scrambled, but handles do continue to work. |
| <b>memory access exception</b> | An error condition that involves access to a memory location the application is not supposed to access.                                                                                                                          |
| <b>message packet</b>          | A packet sent from a debugging host to a debugging target.                                                                                                                                                                       |
| <b>processor exception</b>     | An error condition that involves the CPU pushing the current program counter and processor state onto the stack, and then branching through a low-memory vector.                                                                 |
| <b>skin</b>                    | A set of graphics that an application uses to create its appearance. You can change the appearance of an application such as the Palm OS Emulator by changing its skin.                                                          |
| <b>SmallROM</b>                | The bootstrap code on the handheld device. This is the code at the very front of the device ROM that can initialize the hardware and activate the debugger nub.                                                                  |

# Index

---

## Symbols

> command 232

## A

- adding trace calls 357
- AddRecord command 311
- AddResource command 311
- alias command 233
- aliases 209
- aliases command 233
- application
  - localizing 369
- application error
  - definition 78
- application locale 371
- arithmetic operators 197
- assigning values to registers 201
- assignment operator 198
- atb command 234
- atc command 234
- atd command 234
- atr command 235
- att command 235
- AttachRecord command 312
- AttachResource command 312

## B

- basic debugging tasks 200
- Battery command 313
- baud rate
  - changing in Palm Debugger 225
- baud rate, changing 225
- BigROM 184
- bitwise operators 198
- bootstrap command 235
- bound emulator 84
- br command 236
- brd command 237
- Break command 173
- break command 183
- breakpoint constants 275
- breakpoint dialog box 71
- BreakpointType structure 278
- building project for Simulator 166

## C

- C library functions 155
- card options dialog box 57
- CardFormat command 313
- CardInfo command 314
- cardinfo command 237
- cast operator 197
- ChangeRecord command 314, 315
- choosing Simulator as project target 167
- cl command 238
- Close command 315
- ColdBoot command 315
- command constants 275
- command line options
  - for Palm OS Emulator 38
- command packets
  - Continue 278
  - Find 280
  - Get Breakpoints 281
  - Get Routine Name 282
  - Get Trap Breaks 284
  - Get Trap Conditionals 285
  - Message 286
  - Read Memory 287
  - Read Registers 288
  - RPC 289
  - Set Breakpoints 290
  - Set Trap Breaks 291
  - Set Trap Conditionals 292
  - State 294
  - Toggle Debugger Breaks 296
  - Write Memory 297
  - Write Registers 298
- command request packets 272
- command response packets 272
- command syntax 190
- commands
  - debugger protocol 278
- connecting to handheld device 182
- Console comjmand 172
- console commands 306, 310
  - AddRecord 311
  - AddResource 311
  - AttachRecord 312
  - AttachResource 312
  - Battery 313

## Index

---

- CardFormat 313
  - CardInfo 314
  - ChangeRecord 314, 315
  - Close 315
  - ColdBoot 315
  - Create 316
  - Del 316
  - DelRecord 317
  - DelResource 317
  - DetachRecord 318
  - DetachResource 318
  - Dir 319
  - DM 320
  - Doze 321
  - Exit 321
  - Export 322
  - Feature 323
  - FindRecord 324
  - Free 324
  - GDB 324
  - GetResource 325
  - Gremlin 325
  - GremlinOff 325
  - HC 326
  - HChk 326
  - HD 327
  - Help 328
  - HF 329
  - HI 329
  - HL 329
  - HS 330
  - HT 330
  - HTorture 331
  - Import 332
  - Info 333
  - Kinfo 334
  - Launch 335
  - ListRecords 336
  - ListResources 336
  - Lock 336
  - Log 337
  - MDebug 337
  - MoveRecord 339
  - New 339
  - Open 340
  - Opened 340
  - Performance 341
  - PowerOn 341
  - Reset 342
  - Resize 342
  - SaveImages 343
  - SB 343
  - SetInfo 343
  - SetOwner 344
  - SetOwnerInfo 344
  - SetResourceInfo 345
  - SimSync 345
  - Sleep 345
  - StoreInfo 346
  - Switch 347
  - SysAlarmDump 347
  - Unlock 348
  - console stub 302
  - console window 181
    - activating input 302
    - using 305
  - constants
    - breakpoint 275
    - debugger protocol command 275
    - debugging 269
    - host control API 96
    - host control error 96
    - host control ID 100
    - host control platform 100
    - host function selector 100
    - host signal platform 101
    - packet 274
    - state 275
  - Continue 278
  - converting PRC to overlay 369
  - country code 371
  - CPU registers window 181
  - Create command 316
  - creating Palm demos 84
- D**
- data types
    - host control API 101
  - database commands 206
  - database functions 151
  - db command 238
  - DbgBreak 183

- debug options 58
- debug options dialog box 58
- debugger
  - connecting with Palm OS Emulator 73
- debugger protocol
  - breakpoint constants 275
  - command constants 275
  - command request packets 272
  - command response packets 272
  - commands 278
    - Continue command 278
    - Find command 280
    - Get Breakpoints command 281
    - Get Routine Name command 282
    - Get Trap Breaks command 284
    - Get Trap Conditionals command 285
  - host and target 271
  - Message command 286
  - message packets 272
  - packet communications 272, 274
  - packet constants 274
  - packet structure 272
  - packet summary 299
  - packet types 272
    - Read Memory command 287
    - Read Registers command 288
    - RPC command 289
    - Set Breakpoints command 290
    - Set Trap Breaks command 291
    - Set Trap Conditional command 292
    - State command 294
    - state constants 275
    - Toggle Debugger Breaks command 296
    - Write Memory command 297
    - Write Registers command 298
- debugger protocol API 271
- debugger stub 182
- debugging
  - with Palm OS Emulator 27
- debugging commands
  - > 232
  - alias 233
  - aliases 209, 233
  - atb 234
  - atc 234
  - atd 234
  - atr 235
  - att 235
  - automatic loading of definitions 209
  - binary numbers in 195
  - bootstrap 235
  - br 236
  - brd 237
  - cardinfo 237
  - character constants in 195
  - cl 238
  - db 238
  - decimal numbers in 196
  - dir 239
  - dl 241
  - dm 241
  - dump 242
  - dw 242
  - dx 242
  - expression operators 197
  - fb 243
  - fill 243
  - fl 244
  - flow control 203
  - ft 244
  - fw 245
  - g 246
  - gt 246
  - hChk 246
  - hd 247
  - help 249
  - hexadecimal numbers in 196
  - hl 249
  - ht 250
  - il 251
  - info 252
  - keywords 252
  - load 253
  - opened 253
  - penv 254
  - reg 255
  - reset 255
  - run 256
  - s 256
  - save 256
  - sb 257
  - sc 257
  - sc6 258

## Index

---

- sc7 258
- script files 209
- shortcut characters in 200
- sizeof 259
- sl 259
- ss 260
- storeinfo 260
- structure templates 207
- summary 265
- sw 261
- t 262
- templates 262
- typedef 263
- typeend 263
- using expressions in 194
- var 264
- variables 264
- wh 265
- debugging conduits
  - shortcut numbers 184, 303
- debugging constants 269
- debugging host 271
- debugging memory corruption problems 220
- debugging target 271
- debugging variables 269
- debugging window 181
  - activating 182
  - using 192
- debugging window commands 231
- debugging with Palm OS Emulator 58
- defining structure templates 208
- Del command 316
- DelRecord command 317
- DelResource command 317
- dereference operator 197
- DetachRecord command 318
- DetachResource command 318
- developer forum 93
- developer zone 30
- differences between Simulator and Palm OS
  - hardware 164
- Dir command 319
- dir command 239
- directory handler functions 152
- disassembling memory 202

- displaying and disassembling memory 202
- displaying memory 202
- displaying registers and memory 201
- displaying trace information 360
- dl command 241
- DM command 320
- dm command 241
- double scale option 49
- downloading
  - reporter 356
- downloading emulator 30
- downloading ROM images 33
- downloading skins 49
- Doze command 321
- dump command 242
- dw command 242
- dx command 242

## E

- Edit menu 172
- emulation sessions 45
- emulator 25
  - about 26
  - and HotSync application 53
  - and RPC 84
  - and serial communications 52
  - bound program 84
  - breakpoints dialog box 71
  - card options dialog box 57
  - changing appearance 49
  - command line options 38
  - compared to simulator 163
  - connecting with external debugger 74
  - connecting with gdb debugger 73
  - connecting with Palm Debugger 73
  - control keys 92
  - debug options 58
  - debug options dialog box 58
  - debugging 58
  - debugging features 28
  - debugging with 27
  - demo version 84
  - device options 46
  - display 86
  - downloading 30

- downloading ROM images 33
  - entering data in 92
  - error conditions 77
  - error dialog box 77
  - error handling 76
  - error messages 78
  - expansion card 56
  - extended features 28
  - gremlin horde dialog box 68
  - gremlin logging options 70
  - gremlin status dialog box 69
  - gremlins and logging 70
  - hardware button use 91
  - installing applications 51
  - latest information 93
  - list of files included 30
  - loading a ROM file on Macintosh 34
  - loading a ROM file on Unix 35
  - loading a ROM file on Windows 33
  - loading ROM images 33
  - logging options 61
  - logging options dialog box 62
  - memory card 56
  - memory checking 78
  - menu commands 88
  - menus 86
  - Netlib calls 51
  - new configuration dialog box 35
  - new session dialog box 37, 45
  - preference dialog box 50
  - preference file 51
  - preference file location 121
  - profiling 75
  - profiling with 32
  - properties dialog box 50
  - RAM selection 46
  - running 38
  - runtime requirements 29
  - saving and restoring sessions 48
  - saving session 51
  - saving the screen 48
  - serial port 51
  - session configuration 45
  - session configuration dialog box 44
  - session features 45
  - session file 43
  - setting breakpoints 70
  - skin selection 46
  - skins dialog box 49
  - snapshots 69
  - sounds 51
  - source level debugging 72
  - speeding up synchronization operations 56
  - standard device features 28
  - starting execution 42
  - startup dialog box 34, 43
  - testing 58
  - testing applications 58
  - transferring ROM images 33
  - user interface 86
  - user name 51
  - using gremlins 65
  - using reporter 360
  - using ROM images 29, 36
  - version 25
  - version numbers 31
  - web site 93
  - entering commands in Palm Debugger 187
  - environment functions 152
  - error handling
    - in Palm OS Emulator 76
  - error messages
    - in Palm Debugger 214
    - in Palm OS Emulator 78
  - Event Trace 172
  - Event Trace command 172
  - event trace window 169
  - Exit command 321
  - expansion card emulation 56
  - Expansion Manager 56
  - Export command 322
  - expression language for Palm Debugger 231
  - expressions in Palm Debugger 194
  - external debugger
    - connecting with Palm OS Emulator 74
- F**
- fb command 243
  - Feature command 323
  - file chooser support functions 153
  - fill command 243
  - filter set
    - localization 372

## Index

---

- filtering trace information 361
- Find 280
- finding code in the debugger 216
- finding memory corruption problems 220
- finding specific code 216
- FindRecord command 324
- fixing reporter problems 363
- fl command 244
- flow control commands 203
- forum, developers 93
- Free command 324
- ft command 244
- functions
  - host control 108
  - HostAscTime 108
  - HostClock 108
  - HostCloseDir 109
  - HostCTime 109
  - HostErrNo 109
  - HostExportFile 110
  - HostFClose 110
  - HostFEOF 111
  - HostFError 111
  - HostFFlush 111
  - HostFGetC 112
  - HostFGetPos 112
  - HostFGetS 112
  - HostFOpen 113
  - HostFFPrintF 113
  - HostFPutC 113
  - HostFPutS 114
  - HostFRead 114
  - HostFree 114
  - HostFReopen 115
  - HostFScanf 115
  - HostFSeek 116
  - HostFSetPos 116
  - HostFTell 117
  - HostFWrite 117
  - HostGestalt 117
  - HostGetDirectory 118
  - HostGetEnv 118
  - HostGetFile 118
  - HostGetFileAttr 119
  - HostGetHostID 120
  - HostGetHostPlatform 120
  - HostGetHostVersion 120
  - HostGetPreference 121
  - HostGMTIME 122
  - HostGremlinCounter 122
  - HostGremlinIsRunning 122
  - HostGremlinLimit 123
  - HostGremlinNew 123
  - HostGremlinNumber 123
  - HostImportFile 124
  - HostIsCallingTrap 124
  - HostIsSelectorImplemented 125
  - HostLocalTime 125
  - HostLogFile 126
  - HostMalloc 126
  - HostMkDir 126
  - HostMkTime 127
  - HostOpenDir 127
  - HostProfileCleanup 127
  - HostProfileDetailFn 128
  - HostProfileDump 129
  - HostProfileGetCycles 129
  - HostProfileInit 130
  - HostProfileStart 131
  - HostProfileStop 131
  - HostPutFile 132
  - HostReadDir 132
  - HostRealloc 133
  - HostRemove 133
  - HostRmdir 134
  - HostSaveScreen 134
  - HostSessionClose 135
  - HostSessionCreate 135
  - HostSessionOpen 136
  - HostSessionQuit 136
  - HostSetFileAttr 137
  - HostSetLogFileSize 138
  - HostSetPreference 138
  - HostSignalResume 139
  - HostSignalWait 140
  - HostSlotHasCard 141
  - HostSlotMax 142
  - HostSlotRoot 142
  - HostStat 143
  - HostStrFTime 143
  - HostTime 144
  - HostTmpFile 144
  - HostTmpNam 144



- HostTraceClose 145
- HostTraceInit 145
- HostTraceOutputB 146
- HostTraceOutputT 146
- HostTraceOutputTL 148
- HostTraceOutputVT 149
- HostTraceOutputVTL 150
- HostTruncate 150
- HostUtime 151
- fw command 245

## G

- g command 246
- GDB command 324
- gdb debugger
  - connecting with Palm OS Emulator 73
- GDbgWasEntered 183
- generic skin 49
- Get Breakpoints 281
- Get Routine Name 282
- Get Trap Breaks 284
- Get Trap Conditionals 285
- GetResource command 325
- Gremlin command 325
- gremlin functions 153
- gremlin horde dialog box 68
- Gremlin menu 173
- gremlin status dialog box 69
- GremlinOff command 325
- gremlins 65
  - and logging 70
  - in Simulator 170
  - snapshots 69
- gt command 246

## H

- handheld device
  - connecting with Palm Debugger 182
- hardware buttons
  - in Palm OS Emulator 91
- HC command 326
- HChk command 326
- hChk command 246
- HD command 327

- hd command 247
- heap and database commands 206
- heap commands 206
- Help command 328
- help command 249
- HF command 329
- HI command 329
- HL command 329
- hl command 249
- host control
  - adding trace calls 357
  - constants 96
  - data types 101
  - database functions 151
  - directory handler functions 152
  - environment functions 152
  - file chooser support functions 153
  - function summary 151
  - functions 108
  - gremlin functions 153
  - host error constants 96
  - host function selector constants 100
  - host ID constants 100
  - host platform constants 100
  - host signal constants 101
  - HostAscTime function 108
  - HostBool data type 102
  - HostClock data type 102
  - HostClock function 108
  - HostCloseDir function 109
  - HostCTime function 109
  - HostDIR data type 102
  - HostDirEnt data type 102
  - HostErrNo function 109
  - HostExportFile function 110
  - HostFClose function 110
  - HostFEOF function 111
  - HostFError function 111
  - HostFFlush function 111
  - HostFGetC function 112
  - HostFGetPos function 112
  - HostFGetS function 112
  - HostFILE data type 103
  - HostFOpen function 113
  - HostFPrintf function 113
  - HostFPutS function 114

## Index

---

- HostFRead function 114
- HostFree function 114
- HostFREopen function 115
- HostFScanF function 115
- HostFSeek function 116
- HostFSetPos function 116
- HostFTell function 117
- HostFWrite function 117
- HostGestalt function 117
- HostGetDirectory function 118
- HostGetEnv function 118
- HostGetFile function 118
- HostGetFileAttr function 119
- HostGetHostID function 120
- HostGetHostPlatform function 120
- HostGetHostVersion function 120
- HostGetPreference function 121
- HostGMTime function 122
- HostGremlinCounter function 122
- HostGremlinInfo data type 103
- HostGremlinIsRunning function 122
- HostGremlinLimit function 123
- HostGremlinNew function 123
- HostGremlinNumber function 123
- HostID data type 104
- HostImportFile function 124
- HostIsCallingTrap function 124
- HostIsSelectorImplemented function 125
- HostLocalTime function 125
- HostLogFile function 126
- HostMalloc function 126
- HostMkDir function 126
- HostMkTime function 127
- HostOpenDir function 127
- HostPlatform data type 104
- HostProfileCleanup function 127
- HostProfileDetailFn function 128
- HostProfileDump function 129
- HostProfileGetCycles function 129
- HostProfileInit function 130
- HostProfileStart function 131
- HostProfileStop function 131
- HostPutC function 113
- HostPutFile function 132
- HostReadDir function 132
- HostRealloc function 133
- HostRemove function 133
- HostRmdir function 134
- HostSaveScreen function 134
- HostSessionClose function 135
- HostSessionCreate function 135
- HostSessionOpen function 136
- HostSessionQuit function 136
- HostSetFileAttr function 137
- HostSetLogFileSize function 138
- HostSetPreference function 138
- HostSignal data type 104
- HostSignalResume function 139
- HostSignalWait function 140
- HostSize data type 104
- HostSlotHasCard function 141
- HostSlotMax function 142
- HostSlotRoot function 142
- HostStat data type 105
- HostStat function 143
- HostStrFTime function 143
- HostTime data type 106
- HostTime function 144
- HostTm data type 106
- HostTmpFile function 144
- HostTmpNam function 144
- HostTraceClose function 145
- HostTraceInit function 145
- HostTraceOutputB function 146
- HostTraceOutputT function 146
- HostTraceOutputTL function 148
- HostTraceOutputVT function 149
- HostTraceOutputVTL function 150
- HostTruncate function 150
- HostUTime data type 107
- HostUTime function 151
- logging functions 154
- preference functions 154
- profiling functions 154
- reference summary 151
- RPC functions 155
- standard C library functions 155
- time functions 157
- tracing functions 158
- using reporter 357
- host control API 95
- host error constants 96
- host function selector constants 100
- host ID constants 100

- host platform constants 100
- host signal constants 101
- HostAscTime 108
- HostBool data type 102
- HostClock 108
- HostClock data type 102
- HostCloseDir 109
- HostCTime 109
- HostDIR data type 102
- HostDirEnt data type 102
- HostErrNo 109
- HostExportFile 110
- HostFClose 110
- HostFEOF 111
- HostFError 111
- HostFFlush 111
- HostFGetC 112
- HostFGetPos 112
- HostFGetS 112
- HostFILE data type 103
- HostFOpen 113
- HostFPrintf 113
- HostFPutC 113
- HostFPutS 114
- HostFRead 114
- HostFree 114
- HostFREopen 115
- HostFS 57
- HostFScanF 115
- HostFSeek 116
- HostFSetPos 116
- HostFTell 117
- HostFWrite 117
- HostGestalt 117
- HostGetDirectory 118
- HostGetEnv 118
- HostGetFile 118
- HostGetFileAttr 119
- HostGetHostID 120
- HostGetHostPlatform 120
- HostGetHostVersion 120
- HostGetPreference 121
- HostGMTIME 122
- HostGremlinCounter 122
- HostGremlinInfo data type 103
- HostGremlinIsRunning 122
- HostGremlinLimit 123
- HostGremlinNew 123
- HostGremlinNumber 123
- HostID data type 104
- HostImportFile 124
- HostIsCallingTrap 124
- HostIsSelectorImplemented 125
- HostLocalTime 125
- HostLogFile 126
- HostMalloc 126
- HostMkDir 126
- HostMkTime 127
- HostOpenDir 127
- HostPlatform data type 104
- HostProfileCleanup 127
- HostProfileDetailFn 128
- HostProfileDUMP 129
- HostProfileGetCycles 129
- HostProfileInit 130
- HostProfileStart 131
- HostProfileStop 131
- HostPutFile 132
- HostReadDir 132
- HostRealloc 133
- HostRemove 133
- HostRmdir 134
- HostSaveScreen 134
- HostSessionClose 135
- HostSessionCreate 135
- HostSessionOpen 136
- HostSessionQuit 136
- HostSetFileAttr 137
- HostSetLogFileSize 138
- HostSetPreference 138
- HostSignal data type 104
- HostSignalResume 139
- HostSignalWait 140
- HostSize data type 104
- HostSlotHasCard 141
- HostSlotMax 142

## Index

---

HostSlotRoot 142  
HostStat 143  
HostStat data type 105  
HostStrFTime 143  
HostTime 144  
HostTime data type 106  
HostTm data type 106  
HostTmpFile 144  
HostTmpNam 144  
HostTraceClose 145  
HostTraceInit 145  
HostTraceOutputB 146  
HostTraceOutputT 146  
HostTraceOutputTL 148  
HostTraceOutputVT 149  
HostTraceOutputVTL 150  
HostTruncate 150  
HostUTime 151  
HostUTime data type 107  
HotSync application  
    and Palm OS Emulator 53  
    emulating on Windows 53  
    emulating with null modem cable 55  
HS command 330  
HT command 330  
ht command 250  
HTorture command 331

## I

il command 251  
Import command 332  
importing a database 306  
Info command 333  
info command 252  
installing applications  
    in Palm OS Emulator 51

## K

keywords command 252  
Kinfo command 334

## L

language indication 371

Launch command 335  
ListRecords command 336  
ListResources command 336  
load command 253  
loading debugger definitions 209  
loading ROM images 33  
local variables  
    displaying in Palm Debugger 222  
localization 369  
Lock command 336  
Log command 337  
logging functions 154  
logging options 61  
logging options dialog box 62, 70  
logging while running gremlins 70

## M

MDebug command 337  
memory access exception  
    definition 78  
memory card emulation 56  
memory corruption 220  
menus in Palm Debugger 188  
Message 286  
message packets 272  
Modem Panel command 175  
Modem Port command 174  
Modem.prc 174  
MoveRecord command 339  
MPWPRC2OVL 377

## N

Network HotSync 54  
Network Panel command 175  
Network.prc 174  
New command 174, 339

## O

Open command 340  
Opened command 340  
opened command 253  
operators in debugging commands 197

overlay tool  
  about 371  
  choosing a locale 371  
  filter set 372  
  help 377  
  Macintosh use 377  
  option summary 375  
  patch overlay 374  
  PRC2OVL 372, 374  
  PRC-to-overlay 371  
overlay tools 369

## **P**

packet communications 274  
packet constants 274  
packet types 272  
Palm Debugger 216, 225  
  > command 232  
  about 180  
  AddRecord command 311  
  AddResource command 311  
  address values 192  
  alias command 233  
  aliases 209  
  aliases command 233  
  and memory corruption problems 220  
  arithmetic operators 197  
  assigning values to registers 201  
  assignment operator 198  
  atb command 234  
  atc command 234  
  atd command 234  
  atr command 235  
  att command 235  
  AttachRecord command 312  
  AttachResource command 312  
  basic tasks 200  
  Battery command 313  
  bitwise operators 198  
  bootstrap command 235  
  br command 236  
  brd command 237  
  CardFormat command 313  
  CardInfo command 314  
  cardinfo command 237  
  cast operator 197

ChangeRecord command 314, 315  
cl command 238  
Close command 315  
ColdBoot command 315  
command options 191, 230, 309  
command syntax 190, 308  
connecting to handheld device 182  
console commands 310  
console window 181, 305  
CPU registers window 181  
Create command 316  
db command 238  
debugger environment variables 269  
debugging command summary 265  
debugging window 181  
debugging window commands 231  
Del command 316  
DelRecord command 317  
DelResource command 317  
dereference operator 197  
DetachRecord command 318  
DetachResource command 318  
dir command 239  
displaying local variables 222  
displaying registers and memory 201  
dl command 241  
DM command 320  
dm command 241  
Dor command 319  
Doze command 321  
dump command 242  
dw command 242  
dx command 242  
entering commands 187  
error messages 214  
Exit command 321  
Export command 322  
expression language 194, 231  
fb command 243  
Feature command 323  
fill command 243  
FindRecord command 324  
fl command 244  
flow control commands 203  
Free command 324  
ft command 244  
fw command 245

## Index

---

- g command 246
- GDB command 324
- GetResource command 325
- Gremlin command 325
- GremlinOff command 325
- gt command 246
- HC command 326
- HChk command 326
- hChk command 246
- HD command 327
- hdcommand 247
- heap and database commands 206
- Help command 328
- help command 249
- HF command 329
- HI command 329
- HL command 329
- hl command 249
- HS command 330
- HT command 330
- ht command 250
- HTorture command 331
- il command 251
- Import command 332
- importing system extensions and libraries 226
- Info command 333
- info command 252
- keywords command 252
- Kinfo command 334
- Launch command 335
- ListRecords command 336
- ListResources command 336
- load command 253
- Lock command 336
- Log command 337
- MDebug command 337
- menus 188
- MoveRecord command 339
- New command 339
- numeric and address values 231, 310
- numeric values 192
- Open command 340
- Opened command 340
- opened command 253
- penv command 254
- Performance command 341
- performing calculations 215
- PowerOn command 341
- predefined constants 269
- reg command 255
- register variables 198
- repeating commands 216
- Reset command 342
- reset command 255
- Resize command 342
- run command 256
- s command 256
- save command 256
- SaveImages command 343
- SB command 343
- sb command 257
- sc command 257
- sc6 command 258
- sc7 command 258
- script files 209
- SetInfo command 343
- SetOwner command 344
- SetRecordInfo command 344
- SetResourceInfo command 345
- shortcut characters 200
- shortcut characters in 216
- SimSync command 345
- sizeof command 259
- sl command 259
- Sleep command 345
- source debugging limitations 214
- source menu 212
- source window 181, 209
- ss command 260
- StoreInfo command 346
- storeinfo command 260
- structure templates 207
- sw command 261
- Switch command 347
- symbol files 211
- SysAlarmDump command 347
- t command 262
- templates command 262
- tips and examples 215
- typedef command 263
- typeend command 263
- unary operators 197
- Unlock command 348
- using 179

- using console and debugging windows 186
- using the debugging window 192
- var command 264
- variables command 264
- wh command 265
- windows 181
- Palm OS Emulator 25
- Palm reporter 355
- Panel menu 174
- patch overlay 374
- Pause command 173
- penv command 254
- Performance command 341
- performing calculations in Palm Debugger 215
- Playback command 173
- port selection in Simulator 174
- POSE
  - see emulator 25
- Pose
  - see emulator 25
- PowerOn command 341
- PRC2OVL 372, 374
  - help 377
  - option summary 375
- PRC-to-OVL tool 369
- Preference dialog box 50
- preference file names 121
- preference functions 154
- Printer Port command 174
- processor exception
  - definition 77
- profiling
  - with Palm OS Emulator 32
- profiling code 75
- profiling functions 154
- Properties dialog box 50
- PSF file
  - see emulator session file 43

## **Q**

- Quit command 172

## **R**

- Read Memory 287
- Read Registers 288
- Realtime command 173
- Record command 173
- reference summary
  - host control functions 151
- reg command 255
- register variables 198
- Replay menu 172
- reporter 355
  - about 355
  - adding trace calls 357
  - downloading 356
  - features 355
  - filtering information 361
  - functions 362
  - installation errors 363
  - installing 356
  - package file contents 356
  - sample code 359
  - session window 361
  - toolbar 362
  - trace session 360
  - trace strings 358
  - troubleshooting 363
  - using emulator 360
- Reset command 342
- reset command 255
- Resize command 342
- Resource Pavilion web site 33
- resource tools 381
- Resume command 174
- ROM images 29
  - downloading 33
  - loading into the emulator 33
  - transferring 33
  - using 36
- RPC 289
- RPC calls 84
- RPC functions 155
- RPC packets 84
- run command 256
- running emulator 38

## Index

---

### S

- s command 256
- Save As command 173
- Save Before Quitting command 172
- Save Card 0 command 171
- Save Card 1 command 171
- save command 256
- SaveImages command 343
- saving and restoring sessions 48
- saving the screen 48
- SB command 343
- sb command 257
- sc command 257
- sc6 command 258
- sc7 command 258
- screen shots 48
- script files 209
- scripts in Simulator 169
- serial communications
  - and Palm OS Emulator 52
- Serial Port menu 174
- session features 45
- Set Breakpoints 290
- Set Trap Breaks 291
- Set Trap Conditionals 292
- SetInfo command 343
- SetOwner command 344
- SetOwnerInfo command 344
- SetResourceInfo command 345
- setting debug breakpoints 70
- shortcut characters in Palm Debugger 216
- shortcut number 184, 303
- shortcut numbers 184, 303
- simple data types 383
- SimSync command 345
- Simulator
  - and Palm OS hardware 164
  - console 172
  - event trace 172
  - menu commands 171–175
  - port selection 174
- simulator
  - about 161
  - application problems 164

- Break command 173
- building a project for 166
- compared to emulator 163
- compared to handheld device 164
- Console command 172
- controls 162
- Edit menu 172
- Event Trace command 172
- event trace window 169
- File menu 171
- Gremlin menu 173
- menus 171
- Modem Panel command 175
- Modem Port command 174
- Network Panel command 175
- New Gremlin command 174
- Pause command 173
- Playback command 173
- Printer Port command 174
- Quit command 172
- Realtime command 173
- Record command 173
- Replay menu 172
- restrictions 161
- Resume command 174
- Save As command 173
- Save Before Quitting command 172
- Save Card 0 command 171
- Save Card 1 command 171
- saving memory to file 170
- screen 162
- scripting 169
- Serial Port Menu 174
- Step command 173, 174
- Stop command 174
- target 167
- tracing events 168
- user interface differences 166
- Using 166
- using 161
- using gremlins 170
- using with CodeWarrior debugger 168
- warning about 161
- Window menu 172
- sizeof command 259
- skins
  - double scale option 49



- downloading 49
- emulator dialog box 49
- generic 49
- white background option 50
- skins dialog box
  - other options 49
- sl command 259
- Sleep command 345
- SmallROM 183
- snapshots 69
- soft reset 186, 305
- source level debugging 72
- source window 181, 209
  - and symbol files 211
  - context menu 213
  - debugging limitations 214
  - debugging with 210
  - menu 212
- specifying Palm Debugger numeric and address value 231, 310
- specifying Palm Debugger options 230, 309
- ss command 260
- standard C library functions 155
- State 294
- state constants 275
- Step command 173, 174
- Stop command 174
- StoreInfo command 346
- storeinfo command 260
- structure templates 207
- sw command 261
- Switch command 347
- symbol files
  - using 211
- synchronizing
  - with Palm OS Emulator 56
- SysAlarmDump command 347
- SysPktBodyCommon structure 276
- SysPktBodyType structure 277
- SysPktRPCParamType structure 277
- system extensions
  - importing 226

- system libraries
  - importing 226

## **T**

- t command 262
- TCP/IP applications, debugging 174
- templates 207
- templates command 262
- testing
  - Gremlins 173
  - Replay in Simulator 172
- testing with Palm OS Emulator 58
- time data type 106
- time functions 157
- Toggle Debugger Breaks 296
- trace analysis 355
- trace strings 358
- tracing
  - sample code 359
- tracing applications 355
- tracing events 168
- tracing functions 158
- transferring ROM images 33
- typedef command 263
- typeend command 263

## **U**

- unary operators 197
- Unlock command 348
- user interface
  - of Palm OS Emulator 86
- using reporter 355
- using ROM images 36

## **V**

- var command 264
- variables 269
- variables command 264
- versions
  - of Palm OS Emulator 31
- Virtual File System Manager 56

## Index

---

### W

web page

    Network HotSync 54

web site

    developer forum 93

    developer zone 30

    emulator 49, 93

    Resource Pavilion 33

wh command 265

white background option 50

Window menu 172

windows

    in Palm Debugger 181

Write Memory 297

Write Registers 298