

VadaTech UTC001

Upgrade Instructions

May 20, 2009

Version 1.2

Copyright

© 2009 VadaTech Incorporated

All rights reserved

VadaTech and the globe image are trademarks of VadaTech Incorporated.

All other product or service names mentioned in this document are the property of their respective owners.

Notice

While reasonable efforts have been made to assure the accuracy of this document, VadaTech, Inc. assumes no liability resulting from any omissions in this document or from the use of the information obtained herein. VadaTech reserves the right to revise this document and to make changes periodically and the content hereof without obligation of VadaTech to notify any person of such revision or changes.

Electronic versions of this material may be read online, downloaded for personal use, or referenced in another document as a URL to the VadaTech Incorporated Web site. The text itself may not be published commercially in print or electronic form, edited, translated, or otherwise altered without the permission of VadaTech, Inc.

It is possible that this publication may contain reference to or information about VadaTech products (machines and programs), programming, or services that are not available in your country. Such references or information must not be construed to mean that VadaTech intends to announce such products, programming, or services in your country.

Trademarks

The VadaTech, Inc name and logo are registered trademarks of VadaTech Incorporated in the U.S.A. All other product or service names mentioned in this document are the property of their respective owners.

© 2009, VadaTech Incorporated. Printed in the U.S.A., All Rights Reserved.

Revision History

Doc Rev	Description of Change	Revision Date
1.0	Document Created	02/23/2009
1.1	Updated for UTC001 release 1.3.3	03/18/2009
1.2	Updated description of default IP connection	05/20/2009

Table of Contents

1	Overview	6
1.1	Document References.....	6
1.2	Acronyms Used in this Document.....	6
2	MCH	7
3	MCMC Configuration.....	9
4	Daughter Card Configuration	10

Tables

Table 1: Acronyms..... 6

1 Overview

The VadaTech UTC001 is the most feature-rich MCH (MicroTCA Carrier Hub) on the market. This document is a guide to upgrading the components that make up the UTC001. These components include the MCMC, Carrier Manager, Shelf Manager, Daughter Card configuration, Services, and Tools.

1.1 Document References

- [VadaTech MicroTCA Carrier Manager Command Line Interface Reference Manual](#)
- [VadaTech MicroTCA Shelf Manager Command Line Interface Reference Manual](#)

1.2 Acronyms Used in this Document

Acronym	Description
MCH	MicroTCA Carrier Hub
MCMC	MicroTCA Carrier Management Controller

Table 1: Acronyms

2 MCH

The MCH package upgrades the MCMC, Carrier Manager, Shelf Manager, Services, and Tools. The package will also update the file-system. The package can be found in the file `mch-X.X.X.X.tgz`, where X.X.X.X is the version number.

The default IP address for all UTC001's is set to 192.168.1.252. The IP address is a configurable value in `etc/rc.d/rc.conf`, and may be changed at any time.

Note: When upgrading with the MCH package, all data will be lost. Only the files in `/etc` will be saved during the upgrade.

The following procedure outlines the steps to update an MCH:

- 1) The package must be extracted on a machine other than the target MCH due to memory constraints.

```
# tar xzvf mch-X.X.X.X.tgz
```

- 2) Once uncompressed, copy the contents of the created folder to `/upgrade` on the target UTC001.

```
# scp mch-X.X.X.X/* root@192.168.1.252:/upgrade
```

- 3) Connect to the UTC001 and go to `/upgrade`.

```
# cd /upgrade
```

Refer to the [VadaTech MicroTCA Shelf Manager Command Line Interface Reference Manual](#) and [VadaTech MicroTCA Carrier Manager Command Line Interface Reference Manual](#) for establishing a connection.

- 4) Run the `upgrade` command.
 - a. The user will be prompted to keep the old serial number, or enter a new one. Press `<ENTER>` to keep the old serial number. Otherwise, enter the new serial number and press `<ENTER>`.
 - b. The user will be shown the current software, management, and daughter card settings. Press `<ENTER>` to keep the old serial number. Otherwise, enter `n` to change the settings.
 - c. To continue with the upgrade, enter `y`.

```
# upgrade
Use serial number 1234567? (press ENTER to keep it)
Serial number:
Keeping old serial number

****CURRENT SETTINGS****
Shelf Manager      : Enabled
SNMP daemon        : Enabled
SNMP trap handler  : Enabled
Web server         : Disabled
Spread spectrum clocking mode is disabled

Do you want to keep these settings? (press ENTER to keep existing or 'n')

==== VT002 Upgrader ====

REDBOOT:
  ROOTFS: vt002_nand_flash_mch-X.X.X.X.img
  KERNEL:
  FPGA:

Please ensure that you have specified the proper images.
Do you wish to continue with the upgrade (y/n)? y
```

5) Power cycle for the changes to take effect.

3 MCMC Configuration

The UTC001 comes in many different configurations. When upgrading the MCMC configuration, verify that the correct package is being used; otherwise the UTC001 may not function as expected. The configuration package can be found in the file `utc001-ABC-DEF-GHJ-X.X.X.tgz`, where ABC-DEF-GHJ represents the configuration options of the UTC001 and X.X.X is the version number.

The default IP address for all UTC001's is set to 192.168.1.252. The IP address is a configurable value in `etc/rc.d/rc.conf`, and may be changed at any time.

The following procedure outlines the steps to update an MCMC configuration:

- 1) Copy the configuration package to `/upgrade` on the target UTC001.

```
# utc001-ABC-DEF-GHJ-X.X.X.tgz root@192.168.1.252:/upgrade
```

- 2) Connect to the UTC001 and go to `/upgrade`.

```
# cd /upgrade
```

Refer to the [VadaTech MicroTCA Shelf Manager Command Line Interface Reference Manual](#) and [VadaTech MicroTCA Carrier Manager Command Line Interface Reference Manual](#) for establishing a connection.

- 3) Extract the files from the package.

```
# tar xzvf utc001-ABC-DEF-GHJ-X.X.X.tgz
```

- 4) Go to the created folder.

```
# cd utc001-ABC-DEF-GHJ-X.X.X
```

- 5) Run the `upgrade` command.

```
# upgrade
```

- 6) Power cycle for the changes to take effect.

4 Daughter Card Configuration

The UTC001 can be manufactured with one of several different daughter cards. When upgrading the Daughter Card configuration, verify that the correct package is being used; otherwise the UTC001 may not function as expected. The configuration package can be found in the file `DA###-x.x.x.tgz`, where `###` is the type of Daughter Card and `X.X.X` is the version number.

The default IP address for all UTC001's is set to 192.168.1.252. The IP address is a configurable value in `etc/rc.d/rc.conf`, and may be changed at any time.

The following procedure outlines the steps to update the Daughter Card configuration:

- 1) Copy the configuration package to `/upgrade` on the target UTC001.

```
# DA###-X.X.X.tgz root@192.168.1.252:/upgrade
```

- 2) Connect to the UTC001 and go to `/upgrade`.

```
# cd /upgrade
```

Refer to the [VadaTech MicroTCA Shelf Manager Command Line Interface Reference Manual](#) and [VadaTech MicroTCA Carrier Manager Command Line Interface Reference Manual](#) for establishing a connection.

- 3) Extract the files from the package.

```
# tar xzvf utc001-ABC-DEF-GHJ-X.X.X.tgz
```

- 4) Go to the created folder.

```
# cd utc001-ABC-DEF-GHJ-X.X.X
```

- 5) Run the `upgrade` command. The daughter card's serial number must be specified as an argument.

```
# upgrade XXXXXXXX
```

- 6) Power cycle for the changes to take effect.