

## RealWear Guide – HOW TO


- **See which commands can be pronounced**
  1. Say *"Show Help"*
- **Go to Home page**
  1. Say *"Navigate Home"*
- **Switch On**
  1. Click the power button for at least 3 seconds
- **Switch Off**
  1. Follow *"HOW TO – Go to Home Page"*
  2. Say *"My Programs"*
  3. Say *"My Controls"*
  4. Say *"Power Options"*
  5. Say *"Power Down"*
- **Go to Bluetooth settings - Alternative 1**
  1. Follow *"HOW TO – Go to Home Page"*
  2. Say *"My Programs"*
  3. Say *"Settings"*
  4. Say *"Connected devices"*
- **Go to Bluetooth settings - Alternative 2 (if Alternative 1 does not work)**
  1. Follow *"HOW TO – Go to Home Page"*
  2. Say *"My Programs"*
  3. Say *"My Controls"*
  4. Say *"Bluetooth"*
  5. Say *"Bluetooth Settings"*
- **Pair new device via Bluetooth**
  1. Follow *"HOW TO - Go to Bluetooth settings - Alternative 1"*
  2. If Bluetooth settings are shown go to step 3.  
Otherwise, follow *"HOW TO - Go to Bluetooth settings - Alternative 2"*
  3. Say *"Pair new device"*
  4. Say *"Select item number X"* where X is the number shown near to the device name when the window is opened.  
If you don't see a number, try to say *"Page down"* or *"Page up"* and numbers should be displayed.
  5. Check if the code is the same shown on the device to which you are connecting and say *"Pair"*
- **Pair previously connected device via Bluetooth**
  1. Follow *"HOW TO - Go to Bluetooth settings - Alternative 1"*
  2. If Bluetooth settings are shown go to step 3.  
Otherwise, follow *"HOW TO - Go to Bluetooth settings - Alternative 2"*

3. Say "Select item number X" where X is the number shown near to the device name when the window is opened.  
If you don't see a number, try to say "Page down" or "Page up" and numbers should be displayed.
4. Say "Connect"

- **Disconnect connected device**

1. Follow "HOW TO - Go to Bluetooth settings - Alternative 1"
2. If Bluetooth settings are shown go to step 3.  
Otherwise, follow "HOW TO - Go to Bluetooth settings - Alternative 2"
3. If no device is shown under "Media devices", there is no connected device and the procedure is finished.  
Otherwise, say "settings".
4. Say "Disconnect"

- **Forget previously connected device**

1. Follow "HOW TO - Go to Bluetooth settings - Alternative 1"
2. If Bluetooth settings are shown go to step 3.  
Otherwise, follow "HOW TO - Go to Bluetooth settings - Alternative 2"
3. If no device is shown under "Previously connected device", there is no need to forget anything, and the procedure is finished.  
Otherwise, say "Select item number X" where X is the number shown when the page is opened close to the settings symbol (  ) of the device you want to forget.
4. Say "Forget"
5. Say "Forget device"

- **Change Screen timeout**

1. Follow "HOW TO - Go to Home Page"
2. Say "My Programs"
3. Say "Settings"
4. Say "Display"
5. Say "Screen timeout"
6. Say "Select item number X" where X is the number shown when the page is opened close to the screen timeout you desire.