
Referenced Components and Variables

1. Controller Components

This section gives an overview of the 'Controller' components, which are introduced in OCPP 2.0. A controller component can be recognized by the 'Ctrlr' suffix and is responsible for the configuration of a certain functionality. Most of the [Referenced components](#) that are described in this document, are 'Controller' components.

The table below contains a summary of all Controller components, for more details, please refer to Part 2 - Appendices.

Controller Component	Description
AlignedDataCtrlr	Responsible for configuration relating to the reporting of clock-aligned meter data.
AuthCacheCtrlr	Responsible for configuration relating to the use of a local cache for authorization for Charging Station use.
AuthCtrlr	Responsible for configuration relating to the use of authorization for Charging Station use.
CHAdemoCtrlr	Responsible for configuration relating to the CHAdemo controller
ClockCtrlr	Provides a means to configure management of time tracking by Charging Station.
CustomizationCtrlr	Responsible for configuration relating to custom vendor-specific implementations, using the DataTransfer message and CustomData extensions.
DeviceDataCtrlr	Responsible for configuration relating to the exchange and storage of Charging Station device model data.
DisplayMessageCtrlr	Responsible for configuration relating to the display of messages to Charging Station users.
ISO15118Ctrlr	Responsible for configuration relating to the ISO 15118 controller
LocalAuthListCtrlr	Responsible for configuration relating to the use of local authorization lists for Charging Station use.
MonitoringCtrlr	Responsible for configuration relating to the exchange of monitoring event data.
OCPPCommCtrlr	Responsible for configuration relating to information exchange between Charging Station and CSMS.
ReservationCtrlr	Responsible for configuration relating to reservations.
SampledDataCtrlr	Responsible for configuration relating to the reporting of sampled meter data.
SecurityCtrlr	Responsible for configuration relating to security of communications between Charging Station and CSMS.
SmartChargingCtrlr	Responsible for configuration relating to Smart Charging.
TariffCostCtrlr	Responsible for configuration relating to tariff and cost display.
TxCtrlr	Responsible for configuration relating to transaction characteristics and behaviour.

Every Controller component has an 'Enabled' variable. This variable can be used to enable/disable a certain functionality. Any data in the charging station is not part of the controller component, so when disabling a functionality, any relating data stored in the Charging Station will not be changed or removed.

For example: if ReservationCtrlr is disabled when there is an active reservation, the EVSE will become available, but the reservation entries will still be there – they are just not used. If afterwards ReservationCtrlr is enabled again, the reservation entries will become active again as long as they have not expired and no transaction is in progress. If a transaction has started in the mean time, that transaction remains active. The reservation is then considered expired.

2. Referenced Components and Variables

Below follows a list of all Component Variable combinations with a role standardized in this specification.

These Configuration Variables replace the Configuration Keys from OCPP 1.x

The list is split by functionality: [General](#), [Security](#), [Authorization](#), [Local Authorization List Management related](#), [Authorization Cache](#), [Transaction](#), [Metering](#), [Reservation](#), [Smart Charging](#), [Tariff & Cost](#), [Diagnostics](#), [Display Message](#) and [Charging Infrastructure related](#).

A required Configuration Variable mentioned under a particular function block only has to be supported by the Charging Station if it supports that functional block.

Requirements for all the Configuration Variables in this document:

- All variables that are writable SHALL have the VariableAttribute field: *persistence* = true, and SHALL thus be stored in a persistent way.
- Any fields not defined SHALL be left empty.
- Any field marked with a * (Asterisk) can be of any possible value.
- When the AttributeType is NOT given, the CSMS and Charging Station SHALL assume the AttributeType to be Actual.

NOTE

See 'OCPP 2.0 Part 4 - JSON over Websockets implementation guide' for a number of Configuration Variables that are specific to controlling the JSON/Websocket behavior.

2.1. General

2.1.1. ActiveNetworkProfile

Required	no		
Component	componentName	OCPPCommCtrlr	
Variable	variableName	ActiveNetworkProfile	
	variableAttributes	mutability	ReadOnly
	variableCharacteristics	dataType	integer
Description	Indicates the configuration profile the station uses at that moment to connect to the network. This configuration variable only has to be implemented when NetworkConnectionProfile is implemented.		

2.1.2. AllowNewSessionsPendingFirmwareUpdate

Required	no		
Component	componentName	ChargingStation	
Variable	variableName	AllowNewSessionsPendingFirmwareUpdate	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	dataType	boolean
Description	Indicates whether new sessions can be started on EVSEs, while Charging Station is waiting for all EVSEs to become Available in order to start a pending firmware update. When a firmware update is waiting to be installed and this variable exists and has the value <i>true</i> , then, the Charging Station will not set free EVSEs to Unavailable, pending the update. This means that it may take longer until there is a point in time when all EVSEs of the Charging Station are free and it can perform the firmware update.		

2.1.3. DefaultMessageTimeout

Required	yes		
Component	componentName	OCPPCommCtrlr	

Variable	variableName	MessageTimeout	
	variableInstance	Default	
	variableAttributes	mutability	ReadOnly
	variableCharacteristics	unit	seconds
		dataType	integer
Description	The purpose of the message timeout is to be able to consider a request message as not sent and continue with other tasks when the message did not arrive due to communication errors or software failure. The message timeout setting in a Charging Station can be configured in the messageTimeout field in the <i>NetworkConnectionProfile</i> .		

2.1.4. FileTransferProtocols

Required	yes		
Component	componentName	OCPPCommCtrlr	
Variable	variableName	FileTransferProtocols	
	variableAttributes	mutability	ReadOnly
	variableCharacteristics	dataType	MemberList
Description	List of supported file transfer protocols. Possible values: FTP, FTPS, HTTP, HTTPS, SFTP.		

2.1.5. HeartbeatInterval

Required	no		
Component	componentName	OCPPCommCtrlr	
Variable	variableName	HeartbeatInterval	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	unit	seconds
		dataType	integer
Description	Interval of inactivity (no OCPP exchanges) with CSMS after which the Charging Station should send HeartbeatRequest .		

2.1.6. NetworkConfigurationPriority

Required	yes		
Component	componentName	OCPPCommCtrlr	
Variable	variableName	NetworkConfigurationPriority	
	variableAttributes	attributeType	Actual
		mutability	ReadWrite
	variableCharacteristics	dataType	SequenceList
		valueList	List of possible values
Description	A comma separated ordered list of the priority of the possible Network Connection Profiles. The list of possible available profile slots for the network configuration profiles SHALL be reported, via the valueList characteristic of this Variable.		

2.1.7. NetworkProfileConnectionAttempts

Required	yes		
Component	componentName	OCPPCommCtrlr	
Variable	variableName	NetworkProfileConnectionAttempts	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	dataType	integer

Description	Specifies the number of connection attempts the Charging Station executes before switching to a different profile.		
--------------------	--	--	--

2.1.8. OfflineThreshold

Required	yes		
Component	componentName	OCPPCommCtrlr	
Variable	variableName	OfflineThreshold	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	unit	seconds
		dataType	integer
Description	When the offline period of a Charging Station exceeds the <code>OfflineThreshold</code> it is recommended to send a StatusNotificationRequest for all its Connectors.		

2.1.9. QueueAllMessages

Required	no		
Component	componentName	OCPPCommCtrlr	
Variable	variableName	QueueAllMessages	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	dataType	boolean
Description	<p>When this variable is set to <code>true</code>, the Charging Station will queue all message until they are delivered to the CSMS. When set to <code>false</code> the Charging Station will only queue Transaction related messages as required in: E04.FR.01. and other requirements</p> <p>When this variable is the to <code>true</code>, and the Charging Station is running low on memory, the Charging Station SHALL drop TransactionEvent messages last, and when dropping measurements/meter data, the Charging Station SHALL drop intermediate values first (1st value, 3th value, 5th etc), not start dropping values from the beginning or and of the measurements/meter data.</p> <p>Default = false</p>		

2.1.10. MessageAttemptsTransactionEvent

Required	yes		
Component	componentName	OCPPCommCtrlr	
Variable	variableName	MessageAttempts	
	variableInstance	TransactionEvent	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	dataType	integer
Description	How often the Charging Station should try to submit a TransactionEventRequest message when the CSMS fails to process it.		

2.1.11. MessageAttemptIntervalTransactionEvent

Required	yes		
Component	componentName	OCPPCommCtrlr	
Variable	variableName	MessageAttemptInterval	
	variableInstance	TransactionEvent	
	variableAttributes	attributeType	Actual
		mutability	ReadWrite
	variableCharacteristics	unit	seconds
		dataType	integer
Description	How long the Charging Station should wait before resubmitting a TransactionEventRequest message that the CSMS failed to process.		

2.1.12. UnlockOnEVSideDisconnect

Required	yes		
Component	componentName	OCPPCommCtrlr	
Variable	variableName	UnlockOnEVSideDisconnect	
	evse	*	
	variableAttributes	mutability	ReadWrite/ReadOnly
	variableCharacteristics	dataType	boolean
Description	When set to <i>true</i> , the Charging Station SHALL unlock the cable on Charging Station side when the cable is unplugged at the EV. For an EVSE with a fixed cable the mutability SHALL be ReadOnly and the actual value SHALL be false.		

2.1.13. WebSocketPingInterval

Required	no		
Component	componentName	OCPPCommCtrlr	
Variable	variableName	WebSocketPingInterval	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	unit	seconds
		dataType	integer
Description	Only relevant for websocket implementations. 0 disables client side websocket Ping/Pong. In this case there is either no ping/pong or the server initiates the ping and client responds with Pong. Positive values are interpreted as number of seconds between pings. Negative values are not allowed. SetConfiguration is expected to return a <i>Rejected</i> result.		

2.1.14. ResetRetries

Required	yes		
Component	componentName	OCPPCommCtrlr	
Variable	variableName	ResetRetries	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	dataType	integer
Description	Number of times to retry a reset of the Charging Station when a reset was unsuccessful.		

2.1.15. ItemsPerMessageGetReport

Required	yes		
Component	componentName	DeviceDataCtrlr	
Variable	variableName	ItemsPerMessage	
	variableInstance	GetReport	
	variableAttributes	mutability	ReadOnly
	variableCharacteristics	dataType	integer
Description	Maximum number of ComponentVariable entries that can be sent in one getReportRequest message.		

2.1.16. ItemsPerMessageGetVariables

Required	yes		
Component	componentName	DeviceDataCtrlr	
Variable	variableName	ItemsPerMessage	
	variableInstance	GetVariables	
	variableAttributes	mutability	ReadOnly
	variableCharacteristics	dataType	integer

Description	Maximum number of GetVariableData objects in GetVariablesRequest .
--------------------	--

2.1.17. BytesPerMessageGetReport

Required	yes		
Component	componentName	DeviceDataCtrlr	
Variable	variableName	BytesPerMessage	
	variableInstance	GetReport	
	variableAttributes	mutability	ReadOnly
	variableCharacteristics	dataType	integer
Description	Message Size (in bytes) - puts constraint on getReportRequest message size.		

2.1.18. BytesPerMessageGetVariables

Required	yes		
Component	componentName	DeviceDataCtrlr	
Variable	variableName	BytesPerMessage	
	variableInstance	GetVariables	
	variableAttributes	mutability	ReadOnly
	variableCharacteristics	dataType	integer
Description	Message Size (in bytes) - puts constraint on GetVariablesRequest message size.		

2.1.19. ConfigurationValueSize

Required	no		
Component	componentName	DeviceDataCtrlr	
Variable	variableName	ConfigurationValueSize	
	variableAttributes	mutability	ReadOnly
	variableCharacteristics	dataType	integer
		maxLimit	1000
Description	This Configuration Variable can be used to limit the following fields: SetVariableData.attributeValue and VariableCharacteristics.valueList. The max size of these values will always remain equal.		

2.1.20. ReportingValueSize

Required	no		
Component	componentName	DeviceDataCtrlr	
Variable	variableName	ReportingValueSize	
	variableAttributes	mutability	ReadOnly
	variableCharacteristics	dataType	integer
		maxLimit	2500
Description	This Configuration Variable can be used to limit the following fields: GetVariableResult.attributeValue, VariableAttribute.value and EventData.actualValue. The max size of these values will always remain equal.		

2.1.21. ItemsPerMessageSetVariables

Required	yes		
Component	componentName	DeviceDataCtrlr	

Variable	variableName	ItemsPerMessage	
	variableInstance	SetVariables	
	variableAttributes	mutability	ReadOnly
	variableCharacteristics	dataType	integer
Description	Maximum number of SetVariableData objects in SetVariablesRequest .		

2.1.22. BytesPerMessageSetVariables

Required	yes		
Component	componentName	DeviceDataCtrlr	
Variable	variableName	BytesPerMessage	
	variableInstance	SetVariables	
	variableAttributes	mutability	ReadOnly
	variableCharacteristics	dataType	integer
Description	Message Size (in bytes) - puts constraint on SetVariablesRequest message size.		

2.1.23. DateTime

Required	yes		
Component	componentName	ClockCtrlr	
Variable	variableName	DateTime	
	variableAttributes	mutability	ReadOnly
	variableCharacteristics	dataType	DateTime
Description	Contains the current date and time.		

2.1.24. NtpSource

Required	no		
Component	componentName	ClockCtrlr	
Variable	variableName	NtpSource	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	dataType	OptionList
		valuesList	DHCP, manual
Description	When an NTP client is implemented, this variable can be used to configure the client: Use the NTP server provided via DHCP, or use the manually configured NTP server.		

2.1.25. NtpServerUri

Required	no		
Component	componentName	ClockCtrlr	
Variable	variableName	NtpServerUri	
	variableInstance	Single digit, multiple servers allowed, primary NtpServer has instance '1', the secondary has instance '2'. etc	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	dataType	string
Description	When an NTP client is implemented, this variable can be used to configure the client: This contains the address of the NTP server.		
	Multiple NTP servers can be configured. These can be back-up NTP servers. If the NTP client supports it, it can also connect to multiple NTP servers simultaneous to get a more reliable time source.		

2.1.26. TimeOffset

Required	no		
Component	componentName	ClockCtrlr	
Variable	variableName	TimeOffset	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	dataType	string
Description	<p>Configured current local time offset in the format: "+01:00", "-02:00" etc.</p> <p>When a TimeOffset is used, it is advised not to implement: TimeZone. If a Charging Station has implemented both TimeOffset and TimeZone it is RECOMMENDED to not use both at the same time.</p> <p>The time offset is for display purposes.</p>		

2.1.27. NextTimeOffsetTransitionDateTime

Required	no		
Component	componentName	ClockCtrlr	
Variable	variableName	NextTimeOffsetTransitionDateTime	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	dataType	DateTime
Description	<p>Date time of the next time offset transition. On this date time, the clock displayed to the EV driver will be given the new offset as configured via 'TimeOffsetNextTransition'.</p> <p>This can be used to manually configure the next start or end of a daylight saving time period.</p>		

2.1.28. TimeOffsetNextTransition

Required	no		
Component	componentName	ClockCtrlr	
Variable	variableName	TimeOffset	
	variableInstance	NextTransition	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	dataType	string
Description	<p>Next local time offset in the format: "+01:00", "-02:00" etc.</p> <p>New offset that will be set on the next time offset transition as configured via 'NextTimeOffsetTransitionDateTime'.</p> <p>This can be used to manually configure the offset for the start or end of the daylight saving time period.</p>		

2.1.29. TimeSource

Required	yes		
Component	componentName	ClockCtrlr	
Variable	variableName	TimeSource	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	dataType	SequenceList
		valuesList	List of all implemented time sources. Possible values: Heartbeat, NTP, GPS, RealTimeClock, MobileNetwork, RadioTimeTransmitter

Description	<p>Via this variable, the Charging Station provides the CSMS with the option to configure a clock source, if more than 1 are implemented.</p> <p>By providing a list of possible sources, the CSO can configure fallback sources.</p> <p>Example: "NTP,Heartbeat" means, use NTP, but when none of the NTP servers responses, use time synchronization via Heartbeat.</p> <p>NOTE: RadioTimeTransmitter: At various locations around the globe, low-frequency radio transmitters provide accurate local time information e.g. DCF77 in Germany, MSF in the United Kingdom, JJY in Japan etc. Such a radio time clock can be used as a time source for a Charging Station. The Charging Station shall convert the broadcasted time to UTC. For this TimeZone, TimeOffset, NextTimeOffsetTransitionDateTime and TimeOffsetNextTransition can be used.</p>		
--------------------	---	--	--

2.1.30. TimeZone

Required	no		
Component	componentName	ClockCtrlr	
Variable	variableName	TimeZone	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	dataType	string
Description	<p>Configured current local time zone in the format: "Europe/Oslo", "Asia/Singapore" etc.</p> <p>When a time zone is used, it is advised not to implement: TimeOffset. If a Charging Station has implemented both TimeOffset and TimeZone it is RECOMMENDED to not use both at the same time.</p> <p>The time zone is for display purposes.</p>		

2.2. Security related

2.2.1. BasicAuthPassword

The basic authentication password is used for HTTP Basic Authentication. The configuration value is write-only, so that it cannot be accidentally stored in plaintext by the CSMS when it reads out all configuration values.

Required	no		
Component	componentName	SecurityCtrlr	
Variable	variableName	BasicAuthPassword	
	variableAttributes	mutability	WriteOnly
	variableCharacteristics	dataType	identifierString
		maxLimit	40 (Max length of the BasicAuthPassword)
Description	<p>The basic authentication password is used for HTTP Basic Authentication. The password SHALL be a randomly chosen identifierString with a sufficiently high entropy, consisting of minimum 16 and maximum 40 characters (alpha-numeric characters and the special characters allowed by identifierString). The password SHALL be sent as a UTF-8 encoded string (NOT encoded into octet string or base64). This configuration variable is write-only, so that it cannot be accidentally stored in plaintext by the CSMS when it reads out all configuration variables. This configuration variable is required unless only "security profile 3 - TLS with client side certificates" is implemented.</p>		

2.2.2. Identity

Required	no	
Component	componentName	SecurityCtrlr

Variable	variableName	Identity	
	variableAttributes	mutability	ReadOnly or ReadWrite
	variableCharacteristics	dataType	identifierString
		maxLimit	48 (Charging Station Identity)
Description	The Charging Station identity. identity is an identifierString , however because this value is also used as the basic authentication username, the colon character ':' SHALL not be used. Maximum length was chosen to ensure compatibility with EVSE ID from [EMI3-BO] "Part 2: business objects".		

2.2.3. OrganizationName

Required	yes		
Component	componentName	SecurityCtrlr	
Variable	variableName	OrganizationName	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	dataType	string
Description	This configuration variable is used to set the organization name of the CSO or an organization trusted by the CSO. This organization name is used to specify the subject field in the client certificate.		

2.2.4. CertificateEntries

Required	yes		
Component	componentName	SecurityCtrlr	
Variable	variableName	CertificateEntries	
	variableAttributes	mutability	ReadOnly
	variableCharacteristics	dataType	integer
		maxLimit	Maximum number of Certificates installed at any time.
Description	Amount of Certificates currently installed on the Charging Station.		

2.2.5. SecurityProfile

Required	yes		
Component	componentName	SecurityCtrlr	
Variable	variableName	SecurityProfile	
	variableAttributes	mutability	ReadOnly
	variableCharacteristics	dataType	integer
Description	This configuration variable is used to report the security profile used by the Charging Station.		

2.2.6. AdditionalRootCertificateCheck

Required	no		
Component	componentName	SecurityCtrlr	
Variable	variableName	AdditionalRootCertificateCheck	
	variableAttributes	mutability	ReadOnly
	variableCharacteristics	dataType	boolean

Description	<p>When set to true, only one certificate (plus a temporarily fallback certificate) of certificateType CSMSRootCertificate is allowed to be installed at a time. When installing a new CSMS Root certificate, the new certificate SHALL replace the old one AND the new CSMS Root Certificate MUST be signed by the old CSMS Root Certificate it is replacing.</p> <p>This configuration variable is required unless only "security profile 1 - Unsecured Transport with Basic Authentication" is implemented. Please note that security profile 1 SHOULD only be used in trusted networks.</p> <p><i>Note: When using this additional security mechanism please be aware that the Charging Station needs to perform a full certificate chain verification when the new CSMS Root certificate is being installed. However, once the old CSMS Root certificate is set as the fallback certificate, the Charging Station needs to perform a partial certificate chain verification when verifying the server certificate during the TLS handshake. Otherwise the verification will fail once the old CSMS Root (fallback) certificate is either expired or removed.</i></p>		
--------------------	---	--	--

2.2.7. MaxCertificateChainSize

Required	no		
Component	componentName	SecurityCtrlr	
Variable	variableName	MaxCertificateChainSize	
	variableAttributes	mutability	ReadOnly
	variableCharacteristics	dataType	integer
		maxLimit	10000
Description	<p>This configuration variable can be used to limit the size of the 'certificateChain' field from the CertificateSignedRequest PDU. This value SHOULD NOT be set too small. The smaller this value, the less security architectures the Charging Station will support. It is RECOMMENDED to set at least a size of 5600. This will allow the Charging Station to support most security architectures.</p>		

2.3. Authorization related

2.3.1. AuthEnabled

Required	no		
Component	componentName	AuthCtrlr	
Variable	variableName	Enabled	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	dataType	boolean
Description	<p>If set to FALSE, then authorization is switched off. Transactions are still possible, but no authorization will take place. This implies, that the value of idToken in transaction events SHALL be <code>NoAuthorization</code></p>		

2.3.2. AdditionalInfoItemsPerMessage

Required	no		
Component	componentName	AuthCtrlr	
Variable	variableName	AdditionalInfoItemsPerMessage	
	variableAttributes	mutability	ReadOnly
	variableCharacteristics	dataType	integer
Description	<p>Maximum number of AdditionalInfo items that can be sent in one message. This configuration variable only has to be implemented when AdditionalInfo is implemented.</p>		

2.3.3. OfflineTxForUnknownIdEnabled

Required	no		
Component	componentName	AuthCtrlr	

Variable	variableName	OfflineTxForUnknownIdEnabled	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	dataType	boolean
Description	If this key exists, the Charging Station supports Unknown Offline Authorization . If this key reports a value of <i>true</i> , Unknown Offline Authorization is enabled.		

2.3.4. AuthorizeRemoteStart

Required	yes		
Component	componentName	AuthCtrlr	
Variable	variableName	AuthorizeRemoteStart	
	variableAttributes	mutability	ReadOnly or ReadWrite. Choice is up to Charging Station implementation.
	variableCharacteristics	dataType	boolean
Description	Whether a remote request to start a transaction in the form of RequestStartTransactionRequest message should be authorized beforehand like a local action to start a transaction.		

2.3.5. LocalAuthorizeOffline

Required	yes		
Component	componentName	AuthCtrlr	
Variable	variableName	LocalAuthorizeOffline	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	dataType	boolean
Description	Whether the Charging Station, when <i>Offline</i> , will start a transaction for locally-authorized identifiers.		

2.3.6. LocalPreAuthorize

Required	yes		
Component	componentName	AuthCtrlr	
Variable	variableName	LocalPreAuthorize	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	dataType	boolean
Description	Whether the Charging Station, when online, will start a transaction for locally-authorized identifiers without waiting for or requesting an AuthorizeResponse from the CSMS.		

2.3.7. MasterPassGroupId

Required	no		
Component	componentName	AuthCtrlr	
Variable	variableName	MasterPassGroupId	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	dataType	string
		maxLimit	36 (The maximum string length of MasterPassGroupId)
Description	IdTokens that have this id as groupId belong to the Master Pass Group. Meaning they can stop any ongoing transaction, but cannot start transactions. This can, for example, be used by law enforcement personal to stop any ongoing transaction when an EV has to be towed away.		

2.4. Authorization Cache related

2.4.1. AuthCacheEnabled

NOTE When the value of this variable is changed, the content of the authorization cache should not be altered.

Required	no		
Component	componentName	AuthCacheCtrlr	
Variable	variableName	Enabled	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	dataType	boolean
Description	If this variable exists and reports a value of <i>true</i> , Authorization Cache is enabled.		

2.4.2. AuthCacheAvailable

Required	no		
Component	componentName	AuthCacheCtrlr	
Variable	variableName	Available	
	variableAttributes	mutability	ReadOnly
	variableCharacteristics	dataType	boolean
Description	If this variable exists and reports a value of <i>true</i> , Authorization Cache is supported, but not necessarily enabled.		

2.4.3. AuthCacheLifeTime

Required	no		
Component	componentName	AuthCacheCtrlr	
Variable	variableName	LifeTime	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	unit	Seconds
		dataType	integer
Description	Indicates how long it takes until a token expires in the authorization cache since it is last used.		

2.4.4. AuthCacheStorage

Required	no		
Component	componentName	AuthCacheCtrlr	
Variable	variableName	Storage	
	variableAttributes	mutability	ReadOnly
	variableCharacteristics	dataType	integer
		maxLimit	The maximum number of bytes
Description	Indicates the number of bytes currently used by the Authorization Cache . MaxLimit indicates the maximum number of bytes that can be used by the Authorization Cache .		

2.4.5. AuthCachePolicy

Required	no		
Component	componentName	AuthCacheCtrlr	
Variable	variableName	Policy	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	dataType	OptionList
		valuesList	LRU, LFU, FIFO, CUSTOM
Description	Cache Entry Replacement Policy: least recently used, least frequently used, first in first out, other custom mechanism.		

2.5. Local Authorization List Management related

2.5.1. LocalAuthListEnabled

Required	no		
Component	componentName	LocalAuthListCtrlr	
Variable	variableName	Enabled	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	dataType	boolean
Description	If this variable exists and reports a value of <i>true</i> , Local Authorization List is enabled.		

2.5.2. LocalAuthListEntries

Required	when <code>LocalAuthListAvailable</code> is <i>true</i>		
Component	componentName	LocalAuthListCtrlr	
Variable	variableName	Entries	
	variableAttributes	mutability	ReadOnly
	variableCharacteristics	dataType	integer
		maxLimit	The maximum number of IdTokens that can be stored in the Local Authorization List .
Description	Amount of IdTokens currently in the Local Authorization List . The maxLimit of this variable SHALL be provided to report the maximum number of IdTokens that can be stored in the Local Authorization List .		

2.5.3. LocalAuthListAvailable

Required	no		
Component	componentName	LocalAuthListCtrlr	
Variable	variableName	Available	
	variableAttributes	mutability	ReadOnly
	variableCharacteristics	dataType	boolean
Description	If this variable exists and reports a value of <i>true</i> , Local Authorization List is supported.		

2.5.4. ItemsPerMessageSendLocalList

Required	when <code>LocalAuthListAvailable</code> is <i>true</i>		
Component	componentName	LocalAuthListCtrlr	
Variable	variableName	ItemsPerMessage	
	variableAttributes	mutability	ReadOnly
	variableCharacteristics	dataType	integer

2.5.5. BytesPerMessageSendLocalList

Required	when <code>LocalAuthListAvailable</code> is <i>true</i>		
Component	componentName	LocalAuthListCtrlr	
Variable	variableName	BytesPerMessage	
	variableAttributes	mutability	ReadOnly
	variableCharacteristics	dataType	integer

2.5.6. LocalAuthListStorage

Required	no		
Component	componentName	LocalAuthListCtrlr	
Variable	variableName	Storage	
	variableAttributes	mutability	ReadOnly
	variableCharacteristics	dataType	integer
		maxLimit	The maximum number of bytes
Description	Indicates the number of bytes currently used by the Local Authorization List . MaxLimit indicates the maximum number of bytes that can be used by the Local Authorization List .		

2.6. Transaction related

2.6.1. EVConnectionTimeOut

Required	yes		
Component	componentName	TxCtrlr	
Variable	variableName	EVConnectionTimeOut	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	unit	seconds
		dataType	integer
Description	Interval from between "starting" of a transaction until incipient transaction is automatically canceled, due to failure of EV driver to (correctly) insert the charging cable connector(s) into the appropriate socket(s). The Charging Station SHALL go back to the original state, probably: 'Available'. "Starting" might be the swiping of the RFID, pressing a start button, a RequestStartTransactionRequest being received etc.		

2.6.2. StopTxOnEVSideDisconnect

Required	yes		
Component	componentName	TxCtrlr	
Variable	variableName	StopTxOnEVSideDisconnect	
	variableAttributes	mutability	ReadWrite or ReadOnly, depending on Charging Station implementation.
	variableCharacteristics	dataType	boolean
Description	When set to <i>true</i> , the Charging Station SHALL deauthorize the transaction when the cable is unplugged from the EV.		

2.6.3. TxBeforeAcceptedEnabled

Required	no		
Component	componentName	TxCtrlr	
Variable	variableName	TxBeforeAcceptedEnabled	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	dataType	boolean
Description	With this configuration variable the Charging Station can be configured to allow charging before having received a BootNotificationResponse with RegistrationStatus : Accepted. See: Transactions before being accepted by a CSMS .		

2.6.4. TxStartPoint

Required	yes		
Component	componentName	TxCtrlr	

Variable	variableName	TxStartPoint	
	variableAttributes	mutability	ReadOnly or ReadWrite. Choice is up to Charging Station implementation.
	variableCharacteristics	dataType	MemberList
		valueList	See TxStartStopPoint values for allowed values. It is not required to implement all possible values.
Description	<p>Defines when the Charging Station starts a new transaction: first transactioneventRequest: eventType = Started. When any event in the given list occurs, the Charging Station SHALL start a transaction.</p> <p>The Charging Station SHALL only send the <i>Started</i> event once for every transaction.</p> <p>It is advised to put all events that should be part of a transaction in the list, in case the start event never occurs. Because the possible events don't always have to come in the same order it is possible to provide a list of events. Which ever comes first will then cause a transaction to be started. For example: EVConnected, Authorized would mean that a transaction is started when an EV is detected (Cable is connected), or when an EV Driver swipes his RFID card en the CSMS successfully authorizes the ID for charging.</p>		

2.6.4.1. TxStartStopPoint values

The values allowed for the [TxStartPoint](#) and [TxStopPoint](#) variables.

Value	Description
ParkingBayOccupancy	An object (probably an EV) is detected in the parking/charging bay.
EVConnected	Both ends of the Charging Cable are connected (if this can be detected, otherwise detection of a cable being plugged in to the socket), or for wireless: initial communication between EVSE and EV is established.
Authorized	Driver or EV is authorized, this can also be some form of anonymous authorization like a start button.
DataSigned	Signed data is received from the energy meter which is required by some legislation. There are countries that require signed metering data before a billable transaction can be started.
PowerPathClosed	All preconditions are met, power can flow. In case of a wired charger, the cable is properly connected, driver is authorized, power relay is closed etc. This does not mean that the EV is read to charge it's battery, it might, for example, be to warm.
EnergyTransfer	Energy is being transferred between EV and EVSE.

2.6.5. TxStopPoint

Required	yes		
Component	componentName	TxCtrlr	
Variable	variableName	TxStopPoint	
	variableAttributes	mutability	ReadOnly or ReadWrite. Choice is up to Charging Station implementation.
	variableCharacteristics	dataType	MemberList
		valueList	See TxStartStopPoint values for allowed values. It is not required to implement all possible values.
Description	<p>Defines when the Charging Station ends a transaction: last transactioneventRequest: eventType = Ended. When any event in the given list is no longer valid, the Charging Station SHALL end the transaction.</p> <p>The Charging Station SHALL only send the <i>Ended</i> event once for every transaction.</p>		

2.6.6. MaxEnergyOnInvalidId

Required	no	
Component	componentName	TxCtrlr

Variable	variableName	MaxEnergyOnInvalidId	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	unit	Wh
		dataType	integer
Description	Maximum amount of energy in Wh delivered when an identifier is deauthorized by the CSMS after start of a transaction.		

2.6.7. StopTxOnInvalidId

Required	yes		
Component	componentName	TxCtrlr	
Variable	variableName	StopTxOnInvalidId	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	dataType	boolean
Description	whether the Charging Station will deauthorize an ongoing transaction when it receives a non- <i>Accepted</i> authorization status in TransactionEventResponse for this transaction.		

2.7. Metering related

2.7.1. SampledDataEnabled

Required	no		
Component	componentName	SampledDataCtrlr	
Variable	variableName	Enabled	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	dataType	boolean
Description	If this variable reports a value of <i>true</i> , Sampled Data is enabled.		

2.7.2. SampledDataAvailable

Required	no		
Component	componentName	SampledDataCtrlr	
Variable	variableName	Available	
	variableAttributes	mutability	ReadOnly
	variableCharacteristics	dataType	boolean
Description	If this variable reports a value of <i>true</i> , Sampled Data is supported.		

2.7.3. SampledDataSignReadings

Required	no		
Component	componentName	SampledDataCtrlr	
Variable	variableName	SignReadings	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	dataType	boolean
Description	If set to <i>true</i> , the Charging Station SHALL include signed meter values in the TransactionEventRequest to the CSMS. When a Charging Station does not support signed meter values it SHALL NOT report this variable.		

2.7.4. SampledDataTxEndedMeasurands

Required	yes		
Component	componentName	SampledDataCtrlr	

Variable	variableName	TxEndedMeasurands	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	dataType	MemberList
		maxLimit	The maximum length of the CSV formatted string, to be defined by the implementer.
Description	<p>Sampled measurands to be included in the <i>meterValues</i> element of TransactionEventRequest (<i>eventType = Ended</i>), every SampledDataTxEndedInterval seconds from the start of the transaction.</p> <p>The Charging Station reports the list of supported Measurands in VariableCharacteristicsType.valuesList of this variable. This way the CSMS knows which Measurands it can put in the <i>TxEndedSampledData</i>.</p> <p>When left empty, no sampled measurands SHALL be put into the TransactionEventRequest (<i>eventType = Ended</i>).</p>		

2.7.5. SampledDataTxEndedInterval

Required	yes		
Component	componentName	SampledDataCtrlr	
Variable	variableName	TxEndedInterval	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	unit	seconds
		dataType	integer
Description	<p>Interval between sampling of metering (or other) data, intended to be transmitted in the TransactionEventRequest (<i>eventType = Ended</i>) message. For transaction data (<i>evseld>0</i>), samples are acquired and transmitted only in the TransactionEventRequest (<i>eventType = Ended</i>) message.</p> <p>A value of "0" (numeric zero), by convention, is to be interpreted to mean that only the values taken at the <i>start</i> and <i>end</i> of a transaction should be transmitted (no intermediate values).</p>		

2.7.6. SampledDataTxStartedMeasurands

Required	yes		
Component	componentName	SampledDataCtrlr	
Variable	variableName	TxStartedMeasurands	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	dataType	MemberList
		maxLimit	The maximum length of the CSV formatted string, to be defined by the implementer.
Description	<p>Sampled measurand(s) to be taken at the start of any transaction to be included in the <i>meterValues</i> field of the first TransactionEventRequest message send at the start of a transaction (<i>eventType = Started</i>).</p> <p>The Charging Station reports the list of supported Measurands in VariableCharacteristicsType.valuesList of this variable. This way the CSMS knows which Measurands it can put in the <i>SampledDataTxStartedMeasurands</i>.</p> <p>If the Charging Station has a meter, recommended to use as default: "Energy.Active.Import.Register"</p>		

2.7.7. SampledDataTxUpdatedMeasurands

Required	yes		
Component	componentName	SampledDataCtrlr	
Variable	variableName	TxUpdatedMeasurands	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	dataType	MemberList
		maxLimit	The maximum length of the CSV formatted string, to be defined by the implementer.

Description	<p>Sampled measurands to be included in the <i>meterValues</i> element of every TransactionEventRequest (<i>eventType</i> = Updated), every SampledDataTxUpdatedInterval seconds from the start of the transaction.</p> <p>The Charging Station reports the list of supported Measurands in VariableCharacteristicsType.valuesList of this variable. This way the CSMS knows which Measurands it can put in the <i>SampledDataTxUpdatedMeasurands</i>.</p> <p>If the Charging Station has a meter, recommended to use as default: "Energy.Active.Import.Register"</p>		
--------------------	---	--	--

2.7.8. SampledDataTxUpdatedInterval

Required	yes		
Component	component Name	SampledDataCtrlr	
Variable	variableName	TxUpdatedInterval	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	unit	seconds
		dataType	integer
Description	<p>Interval between sampling of metering (or other) data, intended to be transmitted via TransactionEventRequest (<i>eventType</i> = Updated) messages. For transaction data (<i>evseld</i>>0), samples are acquired and transmitted periodically at this interval from the start of the charging transaction.</p> <p>A value of "0" (numeric zero), by convention, is to be interpreted to mean that no sampled data should be transmitted during the transaction.</p>		

2.7.9. AlignedDataEnabled

Required	no		
Component	componentName	AlignedDataCtrlr	
Variable	variableName	Enabled	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	dataType	boolean
Description	If this variable reports a value of <i>true</i> , Aligned Data is enabled.		

2.7.10. AlignedDataAvailable

Required	no		
Component	componentName	AlignedDataCtrlr	
Variable	variableName	Available	
	variableAttributes	mutability	ReadOnly
	variableCharacteristics	dataType	boolean
Description	If this variable reports a value of <i>true</i> , Aligned Data is supported.		

2.7.11. AlignedDataMeasurands

Required	yes		
Component	componentName	AlignedDataCtrlr	
Variable	variableName	Measurands	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	dataType	MemberList
		maxLimit	The maximum length of the CSV formatted string, to be defined by the implementer.
Description	<p>Clock-aligned measurand(s) to be included in MeterValuesRequest, every AlignedDataInterval seconds. For all the allowed values see: Measurand.</p> <p>The Charging Station reports the list of supported Measurands in VariableCharacteristicsType.valuesList of this variable. This way the CSMS knows which Measurands it can put in the <i>AlignedDataMeasurands</i>.</p>		

2.7.12. AlignedDataInterval

Required	yes		
Component	componentName	AlignedDataCtrlr	
Variable	variableName	Interval	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	unit	seconds
		dataType	integer
Description	<p>Size (in seconds) of the clock-aligned data interval, intended to be transmitted in the MeterValuesRequest message. This is the size (in seconds) of the set of evenly spaced aggregation intervals per day, starting at 00:00:00 (midnight). For example, a value of 900 (15 minutes) indicates that every day should be broken into 96 15-minute intervals.</p> <p>When clock aligned data is being transmitted, the interval in question is identified by the start time and (optional) duration interval value, represented according to the ISO8601 standard. All "per-period" data (e.g. energy readings) should be accumulated (for "flow" type measurands such as energy), or averaged (for other values) across the entire interval (or partial interval, at the beginning or end of a transaction), and transmitted (if so enabled) at the end of each interval, bearing the interval start time timestamp.</p> <p>A value of "0" (numeric zero), by convention, is to be interpreted to mean that no clock-aligned data should be transmitted.</p>		

2.7.13. AlignedDataSendDuringIdle

Required	no		
Component	componentName	AlignedDataCtrlr	
Variable	variableName	SendDuringIdle	
	evse	*	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	dataType	boolean
Description	<p>If set to <i>true</i>, the Charging Station SHALL NOT send clock aligned meter values when a transaction is ongoing. When an EVSE is specified, it SHALL stop sending the clock aligned meter values for this EVSE when it has an ongoing transaction. When no EVSE is specified, it SHALL stop sending the clock aligned meter values when any transaction is ongoing on this Charging Station.</p>		

2.7.14. AlignedDataSignReadings

Required	no		
Component	componentName	AlignedDataCtrlr	
Variable	variableName	SignReadings	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	dataType	boolean
Description	<p>If set to <i>true</i>, the Charging Station SHALL include signed meter values in the SampledValueType in the MeterValuesRequest to the CSMS. When a Charging Station does not support signed meter values it SHALL NOT report this variable.</p>		

2.7.15. AlignedDataTxEndedMeasurands

Required	yes		
Component	componentName	AlignedDataCtrlr	
Variable	variableName	TxEndedMeasurands	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	dataType	MemberList
		maxLimit	The maximum length of the CSV formatted string, to be defined by the implementer.

Description	<p>Clock-aligned periodic measurand(s) to be included in the <i>meterValues</i> element of TransactionEventRequest (<i>eventType = Ended</i>) for every AlignedDataTxEndedInterval of the transaction.</p> <p>The Charging Station reports the list of supported Measurands in VariableCharacteristicsType.valuesList of this variable. This way the CSMS knows which Measurands it can put in the <i>TxEndedAlignedData</i>.</p> <p>When left empty, no Clock-aligned measurands SHALL be put into the TransactionEventRequest (<i>eventType = Ended</i>).</p>		
--------------------	---	--	--

2.7.16. AlignedDataTxEndedInterval

Required	yes		
Component	componentName	AlignedDataCtrlr	
Variable	variableName	TxEndedInterval	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	unit	seconds
		dataType	integer
Description	<p>Size (in seconds) of the clock-aligned data interval, intended to be transmitted in the TransactionEventRequest (<i>eventType = Ended</i>) message. This is the size (in seconds) of the set of evenly spaced aggregation intervals per day, starting at 00:00:00 (midnight). For example, a value of 900 (15 minutes) indicates that every day should be broken into 96 15-minute intervals.</p> <p>When clock aligned data is being collected, the interval in question is identified by the start time and (optional) duration interval value, represented according to the ISO8601 standard. All "per-period" data (e.g. energy readings) should be accumulated (for "flow" type measurands such as energy), or averaged (for other values) across the entire interval (or partial interval, at the beginning or end of a transaction), and transmitted (if so enabled) at the end of the transaction in 1 TransactionEventRequest (<i>eventType = Ended</i>) message.</p> <p>+ A value of "0" (numeric zero), by convention, is to be interpreted to mean that only the values taken at the <i>start</i> and <i>end</i> of a transaction should be transmitted (no intermediate values).</p>		

2.7.17. PublicKeyWithSignedMeterValue

Required	no		
Component	componentName	OCPPCommCtrlr	
Variable	variableName	PublicKeyWithSignedMeterValue	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	dataType	OptionList
		valueList	Never,OncePerTransaction,EveryMeterValue
Description	This Configuration Variable can be used to configure whether a public key needs to be sent with a signed meter value.		

2.8. Reservation related

2.8.1. ReservationEnabled

Required	no		
Component	componentName	ReservationCtrlr	
Variable	variableName	Enabled	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	dataType	boolean
Description	Whether Reservation is enabled.		

2.8.2. ReservationAvailable

Required	no		
Component	componentName	ReservationCtrlr	

Variable	variableName	Available	
	variableAttributes	mutability	ReadOnly
	variableCharacteristics	dataType	boolean
Description	Whether Reservation is supported.		

2.8.3. ReservationNonEvseSpecific

Required	no		
Component	componentName	ReservationCtrlr	
Variable	variableName	NonEvseSpecific	
	variableAttributes	mutability	ReadOnly
	variableCharacteristics	dataType	boolean
Description	If this configuration variable is present and set to <i>true</i> : Charging Station supports Reservation where EVSE id is not specified.		

2.9. Smart Charging related

2.9.1. SmartChargingEnabled

Required	no		
Component	componentName	SmartChargingCtrlr	
Variable	variableName	Enabled	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	dataType	boolean
Description	Whether Smart Charging is enabled.		

2.9.2. SmartChargingAvailable

Required	no		
Component	componentName	SmartChargingCtrlr	
Variable	variableName	Available	
	variableAttributes	mutability	ReadOnly
	variableCharacteristics	dataType	boolean
Description	Whether Smart Charging is supported.		

2.9.3. ACPhaseSwitchingSupported

Required	no		
Component	componentName	SmartChargingCtrlr	
Variable	variableName	ACPhaseSwitchingSupported	
	variableAttributes	mutability	ReadOnly
	variableCharacteristics	dataType	boolean
Description	This variable can be used to indicate an on-load/in-transaction capability. If defined and true, this EVSE supports the selection of which phase to use for 1 phase AC charging.		

2.9.4. ChargingProfileMaxStackLevel

Required	yes		
Component	componentName	SmartChargingCtrlr	

Variable	variableName	ProfileStackLevel	
	variableAttributes	mutability	ReadOnly
	variableCharacteristics	dataType	integer
Description	Max StackLevel of a ChargingProfile. The number defined also indicates the max allowed number of installed charging schedules per Charging Profile Purposes .		

2.9.5. ChargingScheduleChargingRateUnit

Required	yes		
Component	componentName	SmartChargingCtrlr	
Variable	variableName	RateUnit	
	variableAttributes	mutability	ReadOnly
	variableCharacteristics	dataType	MemberList
Description	A list of supported quantities for use in a ChargingSchedule . Allowed values: 'A' and 'W'		

2.9.6. PeriodsPerSchedule

Required	yes		
Component	componentName	SmartChargingCtrlr	
Variable	variableName	PeriodsPerSchedule	
	variableAttributes	mutability	ReadOnly
	variableCharacteristics	dataType	integer
Description	Maximum number of periods that may be defined per ChargingSchedule .		

2.9.7. ExternalControlSignalsEnabled

Required	no		
Component	componentName	SmartChargingCtrlr	
Variable	variableName	ExternalControlSignalsEnabled	
	variableAttributes	mutability	ReadOnly or ReadWrite. Choice is up to Charging Station implementation.
	variableCharacteristics	dataType	boolean
Description	Indicates whether a Charging Station should respond to external control signals that influence charging.		

2.9.8. NotifyChargingLimitWithSchedules

Required	no		
Component	componentName	SmartChargingCtrlr	
Variable	variableName	NotifyChargingLimitWithSchedules	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	dataType	boolean
Description	Indicates if the Charging Station should include the externally set charging limit/schedule in the message when it sends a NotifyChargingLimitRequest message. This might increase the data usage significantly, especially when an external system sends new profiles/limits with a short interval. Default is false when omitted.		

2.9.9. Phases3to1

Required	no		
Component	componentName	SmartChargingCtrlr	

Variable	variableName	Phases3to1	
	variableAttributes	mutability	ReadOnly
	variableCharacteristics	dataType	boolean
Description	If defined and true, this Charging Station supports switching from 3 to 1 phase during a transaction.		

2.9.10. ChargingProfileEntries

Required	yes		
Component	componentName	SmartChargingCtrlr	
Variable	variableName	Entries	
	variableInstance	ChargingProfiles	
	variableAttributes	mutability	ReadOnly
	variableCharacteristics	dataType	integer
		maxLimit	Maximum number of Charging profiles installed at any time.
Description	Amount of Charging profiles currently installed on the Charging Station.		

2.9.11. LimitChangeSignificance

Required	yes		
Component	componentName	SmartChargingCtrlr	
Variable	variableName	LimitChangeSignificance	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	dataType	decimal
Description	If at the Charging Station side a change in the limit in a ChargingProfile is lower than this percentage, the Charging Station MAY skip sending a NotifyChargingLimitRequest or a TransactionEventRequest message to the CSMS. It is RECOMMENDED to set this key to a low value. See Smart Charging signals to a Charging Station from multiple actors .		

2.10. Tariff & Cost related

2.10.1. TariffEnabled

Required	no		
Component	componentName	TariffCostCtrlr	
Variable	variableName	Enabled	
	variableInstance	Tariff	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	dataType	boolean
Description	Whether Tariff is enabled.		

2.10.2. TariffAvailable

Required	no		
Component	componentName	TariffCostCtrlr	
Variable	variableName	Available	
	variableInstance	Tariff	
	variableAttributes	mutability	ReadOnly
	variableCharacteristics	dataType	boolean
Description	Whether Tariff is supported.		

2.10.3. TariffFallbackMessage

Required for Charging Stations supporting Tariff Information.

Required	yes		
Component	componentName	TariffCostCtrlr	
Variable	variableName	TariffFallbackMessage	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	dataType	string
		maxLimit	255
Description	Message (and/or tariff information) to be shown to an EV Driver when there is no driver specific tariff information available.		

2.10.4. CostEnabled

Required	no		
Component	componentName	TariffCostCtrlr	
Variable	variableName	Enabled	
	variableInstance	Cost	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	dataType	boolean
Description	Whether Cost is enabled.		

2.10.5. CostAvailable

Required	no		
Component	componentName	TariffCostCtrlr	
Variable	variableName	Available	
	variableInstance	Cost	
	variableAttributes	mutability	ReadOnly
	variableCharacteristics	dataType	boolean
Description	Whether Cost is supported.		

2.10.6. TotalCostFallbackMessage

Required for Charging Stations supporting Tariff Information.

Required	yes		
Component	componentName	TariffCostCtrlr	
Variable	variableName	TotalCostFallbackMessage	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	dataType	string
		maxLimit	255
Description	Message to be shown to an EV Driver when the Charging Station cannot retrieve the cost for a transaction at the end of the transaction.		

2.10.7. Currency

Required for Charging Stations supporting Tariff Information.

Required	yes		
Component	componentName	TariffCostCtrlr	

Variable	variableName	Currency	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	dataType	string
		maxLimit	3
Description	Currency used by this Charging Station in a ISO 4217 [ISO4217] formatted currency code.		

2.11. Diagnostics related

2.11.1. MonitoringEnabled

Required	no		
Component	componentName	MonitoringCtrlr	
Variable	variableName	Enabled	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	dataType	boolean
Description	Whether Monitoring is enabled.		

2.11.2. MonitoringAvailable

Required	no		
Component	componentName	MonitoringCtrlr	
Variable	variableName	Available	
	variableAttributes	mutability	ReadOnly
	variableCharacteristics	dataType	boolean
Description	Whether Monitoring is supported.		

2.11.3. ItemsPerMessageClearVariableMonitoring

Required	no		
Component	componentName	MonitoringCtrlr	
Variable	variableName	ItemsPerMessage	
	variableInstance	ClearVariableMonitoring	
	variableAttributes	mutability	ReadOnly
	variableCharacteristics	dataType	integer
Description	Maximum number of IDs in a ClearVariableMonitoringRequest .		

2.11.4. ItemsPerMessageSetVariableMonitoring

Required	yes		
Component	componentName	MonitoringCtrlr	
Variable	variableName	ItemsPerMessage	
	variableInstance	SetVariableMonitoring	
	variableAttributes	mutability	ReadOnly
	variableCharacteristics	dataType	integer
Description	Maximum number of setMonitoringData elements that can be sent in one setVariableMonitoringRequest message.		

2.11.5. BytesPerMessageClearVariableMonitoring

Required	no		
----------	----	--	--

Component	componentName	MonitoringCtrlr	
Variable	variableName	BytesPerMessage	
	variableInstance	ClearVariableMonitoring	
	variableAttributes	mutability	ReadOnly
	variableCharacteristics	dataType	integer
Description	Message Size (in bytes) - puts constraint on ClearVariableMonitoringRequest message size.		

2.11.6. BytesPerMessageSetVariableMonitoring

Required	yes		
Component	componentName	MonitoringCtrlr	
Variable	variableName	BytesPerMessage	
	variableInstance	SetVariableMonitoring	
	variableAttributes	mutability	ReadOnly
	variableCharacteristics	dataType	integer
Description	Message Size (in bytes) - puts constraint on setVariableMonitoringRequest message size.		

2.11.7. OfflineMonitoringEventQueuingSeverity

Required	no		
Component	componentName	MonitoringCtrlr	
Variable	variableName	OfflineQueuingSeverity	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	dataType	integer
Description	When set and the Charging Station is <i>offline</i> , the Charging Station shall queue any notifyEventRequest messages triggered by a monitor with a severity number equal to or lower than the severity configured here. Value ranging from 0 (Emergency) to 9 (Debug).		

2.12. Display Message related

2.12.1. DisplayMessageEnabled

Required	no		
Component	componentName	DisplayMessageCtrlr	
Variable	variableName	Enabled	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	dataType	boolean
Description	Whether Display Message is enabled.		

2.12.2. DisplayMessageAvailable

Required	no		
Component	componentName	DisplayMessageCtrlr	
Variable	variableName	Available	
	variableAttributes	mutability	ReadOnly
	variableCharacteristics	dataType	boolean
Description	Whether Display Message is supported.		

2.12.3. NumberOfDisplayMessages

Required	yes		
Component	componentName	DisplayMessageCtrlr	
Variable	variableName	DisplayMessages	
	variableAttributes	mutability	ReadOnly
	variableCharacteristics	dataType	integer
		maxLimit	Maximum number of different messages that can be configured in this Charging Station simultaneously, via SetDisplayMessageRequest .
Description	Amount of different messages that are currently configured in this Charging Station, via SetDisplayMessageRequest		

2.12.4. DisplayMessageSupportedFormats

Required	yes		
Component	componentName	DisplayMessageCtrlr	
Variable	variableName	SupportedFormats	
	variableAttributes	mutability	ReadOnly
	variableCharacteristics	dataType	MemberList
Description	List of message formats supported by this Charging Station. Possible values: MessageFormat .		

2.12.5. DisplayMessageSupportedPriorities

Required	yes		
Component	componentName	DisplayMessageCtrlr	
Variable	variableName	SupportedPriorities	
	variableAttributes	mutability	ReadOnly
	variableCharacteristics	dataType	MemberList
Description	List of the priorities supported by this Charging Station. Possible values: MessagePriority .		

2.12.6. CustomImplementationEnabled

Required	no		
Component	componentName	CustomizationCtrlr	
Variable	variableName	CustomImplementationEnabled	
	variableInstance	<VendorId>	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	dataType	boolean
Description	<p>This standard configuration variable can be used to enable/disable custom implementations that the Charging Station supports.</p> <p>It is recommended to first check if the custom behavior is able to be implemented using the device model, otherwise DataTransfer message(s) and/or CustomData fields can be used.</p>		

2.13. Charging Infrastructure related

2.13.1. Available

Required	yes
----------	-----

Components	componentName	ChargingStation	
		EVSE	
		Connector	
	evse	* (for EVSE and Connector)	
Variable	variableName	Available	
	variableAttributes	mutability	ReadOnly
	variableCharacteristics	dataType	boolean
Description	When <i>true</i> the Component exists and is locally configured/wired for use, but may not be (remotely) Enabled. This variable is required on any Component that can be reported by the Charging Station. As a minimum it shall exist on ChargingStation, EVSE and Connector.		
Note	If any other variables are reported for a Component, then reporting <i>Available</i> does not add much value and may be omitted. However, the variable needs to exist, because it can be queried for by a GetCustomReport request for all Components that are 'available'.		

2.13.2. AvailabilityState

Required	yes		
Components	componentName	ChargingStation	
		EVSE	
	evse	* (for EVSE)	
Variable	variableName	AvailabilityState	
	variableAttributes	mutability	ReadOnly
	variableCharacteristics	dataType	optionList
		valuesList	Available, Occupied, Reserved, Unavailable, Faulted
Description	This variable reports current availability state for the ChargingStation and EVSE. If a Connector has its own availability state independent of the EVSE, then this variable may be used to report the Connector's availability state. As such it replicates ConnectorStatus values reported in StatusNotification messages.		

2.13.3. AllowReset

Required	no		
Component	componentName	EVSE	
	evse	*	
Variable	variableName	AllowReset	
	variableAttributes	mutability	ReadOnly
	variableCharacteristics	dataType	boolean
Description	Component can be reset. Can be used to announce that an EVSE can be reset individually.		

2.13.4. ConnectorType

Required	yes		
Component	componentName	Connector	
	evse	*	
Variable	variableName	ConnectorType	
	variableAttributes	mutability	ReadOnly
	variableCharacteristics	dataType	string
Description	Value of the type of connector as defined by ConnectorEnumType in "Part 2 - Specification".		

2.13.5. PhaseRotation

Required	no		
----------	----	--	--

Component	componentName	*	
	evse	*	
Variable	variableName	PhaseRotation	
	variableAttributes	mutability	ReadOnly or ReadWrite.
	variableCharacteristics	dataType	String
Description	<p>This variable describes the phase rotation of a Component relative to its parent Component, using a three letter string consisting of the letters: R, S, T and x.</p> <p>The letter 'R' can be identified as phase 1 (L1), 'S' as phase 2 (L2), 'T' as phase 3 (L3). The lower case 'x' is used to designate a phase that is not connected. An empty string means that phase rotation is not applicable or not known.</p> <p>Certain measurands, like voltage and current, are reported with a phase relative to the grid connection. In order to support this, all components in the chain from Connector to ElectricalFeed need to have a value for PhaseRotation.</p> <p>Some examples: "" (unknown) "RST" (Standard Reference Phasing) "RTS" (Reversed Reference Phasing) "SRT" (Reversed 240 degree rotation) "STR" (Standard 120 degree rotation) "TRS" (Standard 240 degree rotation) "TSR" (Reversed 120 degree rotation) "RSx" (Two phases connected) "Rxx" (One phase connected)</p>		

2.13.6. SupplyPhases

Required	yes		
Components	componentName	ChargingStation	
		EVSE	
		Connector	
	evse	* (for EVSE and Connector)	
Variable	variableName	SupplyPhases	
	variableAttributes	mutability	ReadOnly
	variableCharacteristics	dataType	integer
Description	Number of alternating current phases connected/available. 1 or 3 for AC, 0 means DC (no alternating phases). Null value indicates that the number of phases (e.g. in use) is unknown.		

2.13.7. Power

Required	yes (<i>maxLimit only</i>)		
Component	componentName	EVSE	
	evse	*	
Variable	variableName	Power	
	variableAttributes	mutability	ReadOnly
	variableCharacteristics	dataType	decimal
		maxLimit	decimal
Description	The variableCharacteristic <i>maxLimit</i> , that holds the maximum power that this EVSE can provide, is required. The <i>Actual</i> value of the instantaneous (real) power is desired, but not required.		

2.14. ISO 15118 Related

2.14.1. CentralContractValidationAllowed

Required	no		
Component	componentName	ISO15118Ctrlr	
Variable	variableName	CentralContractValidationAllowed	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	dataType	Boolean
Description	If this variable exists and has the value <i>true</i> , then Charging Station can provide a contract certificate that it cannot validate, to the CSMS for validation as part of the AuthorizeRequest.		

2.14.2. ContractValidationOffline

Required	yes		
Component	componentName	ISO15118Ctrlr	
Variable	variableName	ContractValidationOffline	
	variableAttributes	mutability	ReadWrite
	variableCharacteristics	dataType	Boolean
Description	If this variable is <i>true</i> , then Charging Station will try to validate a contract certificate when it is offline.		