

GETTING STARTED



SOKKIATM



SDR33 GETTING STARTED GUIDE

Software Version V04-03

© Copyright SOKKIA TECHNOLOGY, INC. 1992

November 1992

Distributed by

Sokkia Technology, Inc.

9102 Barton, Overland Park, Kansas 66214, USA

Telephone (913) 492-7585 Fax (913) 492-8233

Table of Contents

Preface	Read This First!	1
P1.1	Quick summary	2
P1.2	Introduction	3
P1.3	Making the best use of this Guide	3
P1.3.1	Existing SDR users: how to get started	3
P1.3.2	New SDR users: how to get started	3
P1.4	Utilizing the available SDR files	4
P1.5	Using this Guide	5
P1.6	How to get support	7
P1.7	About the tutorials	8
P1.7.1	Sample survey	8
P1.7.2	Starting the tutorials	9
Lesson 1	Starting a job	11
1.1	Quick summary	11
1.2	Job creation	12
1.2.1	Background	13
1.3	Checking units	17
1.4	Setting the instrument selection	19
1.5	Setting the date and time	21
1.5.1	Timeout and Timestamp	22
1.6	Checking the configuration	22
Lesson 2	Defining a feature code list	25
2.1	Quick summary	25
2.2	Creating Feature code lists	26
2.3	Naming feature code lists	27
2.4	Editing feature code lists	27
2.5	Entering feature codes	30
Lesson 3	Collecting traverse data	33
3.1	Entering coordinates of known points	33

Table of Contents

3.2	Set collection	39
3.3	Traverse adjustment	55
Lesson 4	Collecting Topographical Data	63
4.1	Quick summary	63
4.2	Setup and backsight	64
4.3	Topography readings	66
4.4	Changing stations	68
4.5	Offset readings	72
Lesson 5	Viewing the Database	79
5.1	Moving through the database	79
5.2	Searching	80
5.3	Adding notes	82
Lesson 6	Intersections	85
Lesson 7	Areas	93
Lesson 8	Resection	101
8.1	Resection setup	101
8.2	Resection observation	103
8.3	Resection calculation	105
Lesson 9	Setting out points	109
9.1	Quick summary	109
9.2	Setting up	110
9.3	Entering list of points to be set out	111
9.4	Setting out list of points	113
Lesson 10	Road setout	119
10.1	Template definition	119
10.2	Road definition	123
10.2.1	Horizontal road geometry	124
10.2.2	Vertical road geometry	128
10.3	Cross section definition	129
10.4	Setting out the road	130
10.5	Sideslope (catch) points	137
Lesson 11	Sending data	143
11.1	Output record views	144
11.2	Communications setup	144
11.3	Sending	146
Appendix A	The Complete Tutorial Database	147

Preface

Read This First!

The first section of this SDR33 **Getting Started Guide** is addressed to those people who normally do **not** read manuals. If you wish to get started immediately using the SDR33 (in doing so, it is unlikely that you will be able to make the best use of the SDR33's powerful facilities), this section is a concise introduction to using the SDR33. If you intend to read this **Guide** and follow the series of tutorial lessons, we suggest you turn to the Introduction (page 3).

The SDR33 has been designed so that it is easy and intuitive to use. Follow the simple instructions in this section to set up your equipment and perform simple surveys immediately:

1. Enter the name of a **job**. Data is stored in this job.
2. Make sure the SDR33 is set up correctly for the type of total-station/surveying instrument you intend to use (see the **"Instrument"** entry of the **"FUNC"** or **"Functions"** menu). In particular, be sure you have set up the total station's prism constant appropriately. The SDR33 should apply a prism constant correction only if the total station does not. You should also check the instrument's PPM settings. Chapter 3 of the **SDR33 Reference Manual** supplies more details about available instruments and settings.
3. Make sure the configuration parameter **"Topo view stored"** (in the **"CNFG"** or configuration menu) is set appropriately for your purposes. In general, store observations as position (**POS**) records or as raw observation (**OBS**) records, the default being **POS**. Chapter 5 of the **SDR33 Reference Manual** explains the **"VIEW"** system in detail.
4. Check (under the **"Units"** entry in the **"FUNC"** menu) that the distance, angle, temperature, and pressure units are set appropriately. These settings should have been configured for your region by the distributor.
5. Press the **<READ>** key (bottom right-hand corner with instrument icon).

6. Enter the name of your station and backsight points and you're ready to take topographic observations.

Once your total station has sent an observation to the SDR33, save the observation in the SDR33's database using the <OK> key. Alternatively, the observation is automatically saved when you press the <READ> key and initiate another reading.

To make best use of the SDR33, follow through the tutorial lessons in this Guide, or refer to the appropriate chapters of the SDR33 Reference Manual.

P1.1

Quick summary

The following list is a brief guide to SDR33 use:

- To turn off, press gold <FUNC> and <CLEAR> (or gold <O>).
- Screen contrast adjustment is gold <FUNC> ⇐ or gold <FUNC> ⇒.
- Page up/page down is gold <FUNC> ↑ or gold <FUNC> ↓.
- Backlight turns on for one minute by pressing gold <FUNC> <L>.
- Booting is done with the SDR in the "OFF" condition:
 - for warm boot (*resets units, autpoint number, other parameters*), hold down gold <FUNC> <L>, and press and release <CLEAR>.
 - for cold boot (**WARNING—clears data!**), hold down <F1> <F4> <READ>, and press and release <CLEAR>.
- If you experience problems and cannot turn off SDR33, hold down <CLEAR> for 16 seconds; this will force it off. **Do not turn back on!**
 - Do a boot, preferably cold boot (read warning above) instead.
- To review data press <VIEW> key, use ⇐ to zoom in on details.
- To write a note anytime press <NOTE> key. If done while reviewing data, the note is entered prior to highlighted record.
- + − × ÷ are entered by pressing gold <FUNC> and the key desired.

In this Guide, < > denotes a keystroke of named key (e.g., <Enter>).

<READ> refers to large key at lower right corner of keyboard with theodolite icon. Generally used to initiate readings.

P1.2

Introduction

Congratulations on your purchase of the SDR33 Electronic Field Book. If you are familiar with data collectors, but have never used an Electronic Field Book, you are about to discover how quickly your surveying field work can be completed.

The SDR33's large screen allows menus and survey data to display concurrently, as well as directions and messages on courses of action. The ease of using SDR33 use should not mask the underlying power of the survey calculations it completes and records in the field.

P1.3

Making the best use of this Guide

This **Guide** is set up in a tutorial style; the information it contains is the minimum required to have a good working knowledge of the SDR33 system. As it is only a starting point for learning data collection and calculation methodology in the field, you may wish to read more detailed sections of the **SDR33 Reference Manual**.

How you use this **Guide** and the **Reference Manual** depends on your previous SDR Electronic Field Book experience.

P1.3.1

Existing SDR users: how to get started

If you have previously used an SDR Electronic Field Book, read Appendix A of the **SDR33 Reference Manual**, which discusses the differences between the SDR20 Series and the SDR33. Then work through the lessons in the **SDR33 Getting Started Guide**.

P1.3.2

New SDR users: how to get started

If you have never used an SDR Electronic Field Book, work your way steadily through this **Guide**. This will give you confidence to attempt some

simple surveys. After gaining some experience, read the **SDR33 Reference Manual** to develop a better understanding of the overall SDR33 system.

P1.4

Utilizing the available SDR files

Accompanying this manual are diskettes with files representing the data that should be in your SDR33 at the completion of seven of the lessons in this **Guide**. These diskettes have copies of the data resulting from the lessons covered in this **SDR33 Getting Started Guide**. There are 7 SDR files in total that contain the SDR33 data at the completion of the Traversing, Topography, Intersections, Areas, Resection, Point Setting Out, and Road Setout lessons. These SDR files are named TRAVERSE.SDR, TOPO.SDR, INTSECT.SDR, AREAS.SDR, RESECTN.SDR, PTSETOUT.SDR and RDSETOUT.SDR respectively. The SDR files are in “*Comms output*” format.

If you wish to cover a specific lesson without carrying out all the previous lessons, you can download the SDR file for the lesson preceding the lesson you wish work on. In order to upload one or more of these SDR files to your SDR33, you will need a software package that is capable of outputting the data over a serial RS232 interface to the SDR33. The Sokkia Software MAP or LINK modules will allow you to do this. The SDR files may be read into the Sokkia MAP or LINK program using the “*Import data file*” option in the “*Receive data from SDR*” menu selection. Send the SDR file to the SDR33 using the “*Send current SDR file*” option.

Note that there may be minor differences in any calculations carried out using data from these uploaded files. This is due to differences in the internal accuracy of coordinates stored in the SDR33 database and the accuracy of coordinates as read from the SDR files. The SDR files contain coordinate values rounded to a limited number of decimal places. These file differences are unavoidable and do not have a significant effect on the lessons covered.

You should make sure that the auto point number is set up appropriately for continuing a lesson after uploading an SDR file if you wish to use the same point numbering as in the examples. Set the auto point number using the

appropriate option in the “*Configuration*” menu (access with the <CNFG> softkey) or from the menu item in the <Func> menu.

P1.5

Using this Guide

Typefaces and icons are used in this manual as follows:

Main Menu

Indicates field identifiers, menu options, unit names, variables, and functions.

Prompt

Represents screen prompts and other information displayed on the screen.

<KEY>

Indicates a keyboard key that causes an immediate action. Examples: <1>, <F1>, <ESC>, <Y>, <N>, <↓>.

TEXT

Represents user-typed text, numeric or special character input (always followed by one of the action keys above).

Print

Represents reports or output to a printer.



Indicates that adjoining text is to be typed by the user.



Indicates that adjoining information is displayed on the computer screen.



Indicates that adjoining text is either a printed report or text from a disk file.



Indicates that adjoining text explains previous text.




Indicates important information, or warning information concerning adjoining text.



Indicates that adjoining text is to be typed by the user on the SDR33's keyboard.

Preface

Screen snaps of the SDR33 screen are shown to provide a reference as to what should be on your screen at any given moment during a tutorial lesson. They will look like the following:



A copy of the printed output of the tutorial is included at the end of this **Guide**. In addition, a partial printout appears at the end of most tutorial lessons summarizing the state of the database at the completion of those lessons.

P1.6

How to get more information

For more information regarding your Sokkia product, please contact the Sokkia organization for your country or region.

Europe

Sokkia B.V.
Damsluisweg 1, 1332 EA Almere
P.O. Box 1292, 1300 BG Almere
The Netherlands
Phone 31-36-5322-880
Fax 31-36-5326-241

USA

Sokkia Corporation
9111 Barton, Box 2934
Overland Park, KS 66201
Phone (913) 492-4900
Fax (913) 492-0188

Canada

Sokkia Inc.
820 Denison Street, Unit 1
Markham, Ontario
L3R 3K5
Phone (416) 475-1450
Fax (416) 475-1453

U.K.

Sokkia U.K. Ltd.
Electra Way
Crewe Business Park
Crewe, Cheshire, CW1 1ZT
Phone 0270-250525
Fax 0270-250533

Oceania

Sokkia Pty. Ltd.
107 Leicester Street, Carlton
Victoria 3053, Australia
Phone 03-347-5844
Fax 03-347-0740
AND
Sokkia N.Z. Ltd.
20 Constellation Drive
Mairangi Bay, Auckland 10
C.P.O. Box 4464
Auckland, New Zealand
Phone 09-479-3064
Fax 09-479-3066

Asia/Africa

Sokkia Singapore Pte. Ltd.
401 Commonwealth Drive
#06-01 Haw Par Technocentre
Singapore 0314
Phone 65-479-3966
Fax 65-479-4966

P1.7

About the tutorials

This **Getting Started Guide** uses an example job, outlined below, to illustrate the various features of the SDR33 that can help you collect survey information. The **Guide** is designed to give you a consistent, procedural approach to your surveys.


P1.7.1

Sample survey

The following is an outline of a survey to be carried out for Mrs. Smith. She requires:

- a. A cadastral plan of her property,
- b. A contour plan, including setting out of a building, including cut and fill values as detailed in the engineer's specifications, and
- c. A road design of a driveway, to be followed by a staking of cross sections.

Engineer's Plan



P1.7.2

Starting the tutorials

The following tutorials should be completed in order as each tutorial makes use of the experience (and data) acquired in previous tutorials. The tutorials assume that your SDR33 contains no survey jobs initially (which will be the case when you purchase it or whenever you perform a “cold boot”).

To begin, get your SDR33 to display the “*Start up screen*,” which looks like the following:

```

06-Oct-92  08:00:00
Job        Smith Topo
Stn        0100
BS Pt      0101
Free recs   3318
FUNC SURV COM COGO ROAD
  
```

This is the first screen that displays when you initially turn the SDR33 on. Get to this screen by pressing the <CLEAR> key several times. If you are unable to locate this screen in the SDR33’s menu hierarchy, perform a “cold boot” (see Chapter 2 of the **SDR33 Reference Manual**). This is guaranteed to get you to the “*Start up screen*” (but it will also clear the SDR33’s memory of any data that may have previously been entered).

Preface

This page was intentionally left blank.

Lesson 1

Starting a job

All surveying field data must be associated with a “*job*.” A job (which must have a name) records such details as the atmospheric conditions applied when the field work was performed. The job is the basic group of data that the SDR33 manipulates. Creating a job, is one of your first tasks.

In this lesson you will:

- Create a job file
- Enter a note
- Set units, instrument selection, date, and time
- Check configuration parameters.

1.1

Quick summary

Brief steps for setting up jobs and tips for SDR33 use are listed below. Details for executing these steps are provided in this lesson.

- SDR33 operation is shown by a sequence of keystrokes or menu selections to complete the named operation. For example, <FUNC> “Hardware” is used to check battery status. Press <FUNC> softkey, then use cursor keys to select “Hardware” from the menu options (or press “H” to highlight hardware). Then press <ENTER> or <OK>.
- To select an existing job (file), press <FUNC> softkey “*Job*.” Then use the arrow keys to position the highlight cursor over the job name. Finally, press <OK> or <ENTER>.
- To create a new job (file), press <FUNC> softkey “*Job*,” <ENTER>. Then type in a new name, check the settings on the job screen before you press <OK>. Once a job file is set up, the settings cannot be changed.
- The following settings must be correctly selected on the job screen at time of job file creation:
 - Scale factor
 - Record elev
 - C&R Corr
 - Point Id format
 - Atmos corr
 - Sea level corr

1: Job start-up


- Press the gold <FUNC> key followed by the <1/0> key to turn the SDR33 off at any time; pressing the <1/0> key again turns the SDR33 back on.
- Pressing gold <FUNC> and then <L> turns the screen backlight on—it will be turned off automatically if the SDR33 is switched off or if 60 seconds elapse without a key being pressed. Pressing gold <FUNC> <=> and gold <FUNC> <=> decreases and increases the screen's contrast, respectively.
- **Before starting you may also want to check:**

<u>Setting</u>	<u>Accessed by:</u>	
Starting autopoint number	<FUNC>	"Configure reading"
Combine F1/F2	<FUNC>	"Configure reading"
Tracking	<FUNC>	"Configure reading"
Battery	<FUNC>	"Hardware"
Code list on/off	<FUNC>	"Configure reading"
Instrument	<FUNC>	"Instrument"
Prism constant	<FUNC>	"Instrument"
Time/date set, time stamping	<FUNC>	"Time+date"
Topo view stored format	<FUNC>	"Configure reading"
Units	<FUNC>	"Units"
Tolerances	<FUNC>	"Tolerances"
Code fields	<FUNC>	"Configure reading"
Info blocks	<FUNC>	"Configure reading"

1.2

Job creation

If the SDR33 is turned "*off*" (i.e., the screen is blank), press the <1/0 CLEAR> key to turn it back on. Make sure that the SDR33 is displaying the "*Start up screen.*" Before you begin the task of job creation, there is some brief background information you need.



1.2.1

Background

Softkeys


The bottom line of the “*Start up screen*” contains five “softkey” labels; each softkey is the name of a “menu” of possible actions. The first of these (called <FUNC>) is the “*Functions*” menu; this menu contains various functions that will not be performed often (e.g., only at the beginning or end of a surveying task).

Highlighted and selecting menu entries

In an SDR33 menu, you can move the highlighting bar from entry to entry using the <↑> UP and <↓> DOWN arrow keys. You can then press the <ENTER> or <OK> key to actually select the currently-highlighted menu entry. The task associated with the entry is performed when you press <ENTER> or <OK>. Pressing the <CLEAR> key exits the menu and returns you to the next highest level in the SDR33’s menu structure.

Follow these steps to create a job:

1. Press the <F1> key (which corresponds to the <FUNC> softkey) to enter the “*Functions*” menu.



The first entry of this menu, entitled “*Job*,” should be highlighted.

2. Press <ENTER> if “*Job*” is highlighted. Otherwise highlight “*Job*” before pressing <ENTER>.


1: Job start-up



Note: If the SDR33 already contains a job, (which is unlikely since you have just begun the first tutorial exercise), a screen like the following will appear:



In this case, press the <F1> key (corresponding to the “*New*” softkey) in order to create a new job. Once you have pressed the <F1> key, the SDR33, the following “*Job creation*” screen appears.



3. With the cursor on the “*Job*” field (the highlighted line beginning with the word *Job*), type the following characters:



SMITH 001

4. Press the <ENTER> key. You have now named the new job “**SMITH 001.**”



Note: You can press the <SHIFT> key to toggle between upper- and lower-case letters.

```

create job
Job      SMITH 001
S.F.     1.00000000
Point Id Numeric (4)
Record elev Yes
Atmos crn No
C and R crn No
Sea level crn No

```

The highlighted cursor is now on “**Scale**,” the second line of the screen. This denotes the scale-factor to use for the job “**SMITH 001**.” It should be left as **1.00000000**.

5. Move to the third line of the screen by pressing the <↓> arrow key.

The “**Point Id**” field determines whether the point names in the “**SMITH 001**” job are to be 4-digit numeric, or 14-digit alphanumeric (i.e., a mixture of letters, digits, and punctuation characters).

This field is a “**selector field**,” which means it accepts one of a fixed number of values (in this case, two). View the possible values of a selector field using the <=> and <=> arrow keys. Press the <=> arrow key, and the value under the cursor should change from “**Numeric (4)**” to “**Alpha (14)**.” Press the <=> arrow key again, and the highlighted value reverts to “**Numeric (4)**.” We want this job to have numeric point names so leave the “**Point Id**” field with the value “**Numeric (4)**.”

Warning

Note: If you use SOKKIA Software (Version 4.00 or earlier) in conjunction with the SDR33, you **must** use Point Id’s of type “**Numeric (4)**.” If you are using another brand check to see what its requirements are.

6. Continue to the next line on the screen by pressing the <↓> arrow key.

The field entitled “**Record Elev**” asks whether or not you are interested in elevations for the new job. For Mrs. Smith’s job we are required to produce a contour map, so leave this field with a “**Yes**” value.

7. We are not interested in any sort of atmospheric or sea-level corrections so leave the following three fields with a “**No**” value.

The Job Creation screen should look like this:

1: Job start-up

Create Job	
Job	SMITH 001
S.F.	1.00000000
Point Id Numeric (4)	
Record elev	Yes
Atmos crn	No
C and R crn	No
Sea level crn	No

If the display of your SDR33 looks different from this screen, use the <↑> and <↓> arrows to move to any field and correct the value of that field so it matches the illustrated display.

8. Press the <OK> key when you are satisfied with the contents of the job creation screen. This tells the SDR33 to create the new job called **“SMITH 001”** with the indicated options and to make this the current SDR33 job.



Note: The SDR33 can contain many jobs at once, but at any time only one job is **“active;”** this is referred to as the **“current job.”**

After you press the <OK> key, the SDR33 beeps and displays the message **“Input accepted.”** This message indicates that the SDR33 has stored the details for the Job **“SMITH 001”** in its database and accepted it as the current job. Then the following screen displays:

Note
<div></div>

You may type in one or more **“notes”** containing information about the newly-created job in this screen.

Follow these steps to enter a note:

1. Type the following three lines to enter a note about the lot and address of the current survey:



LOT4 DP356784 <↓>
16 SHIRAZ RD <↓>
DOONAVILLE <OK>



The SDR33 beeps and briefly displays the “*Input accepted*” message before giving you the opportunity to enter another note.

2. Since we will not be entering additional notes, press <OK> to continue.



When you have typed as many notes as you require, press the <ENTER> or <OK> key on an empty note to continue.

The SDR33 returns to the “*Functions*” menu; you have now created a job file for the survey.

1.3


Checking units

Before starting to collect data, you should set the units, instrument type, date, and time. Once defined, you should not change these parameters during the course of the job (although some of them may have to be changed if the job takes place over a long period of time, etc.).

1: Job start-up


Follow these steps to set the units:

1. From the **“Functions”** menu, move the highlighted cursor (using the <↑> or <↓> arrow keys) until the **“Units”** entry of the menu is highlighted. Your screen should like like this:



2. Press the <ENTER> or <OK> key.
3. Check that the **“Units”** for the current job are satisfactory. Generally, an SDR33 is configured so that the default units are appropriate for the countries where it is sold. Sometimes, however, you may wish to use different units from the norm (e.g., for a specific contract that specifies military units or for an overseas surveying job, etc.).

When you have selected the **“Units”** menu, you will see a screen similar to the one on the left :



Your SDR33 may be configured differently from the screen shown here with slightly different menu selections.

You should set the units as shown above on the right. All of the fields are selectors, so move to each line and select the appropriate values using the <=> and <=> arrow keys.



Note: Unless the units in your SDR33 are set to those illustrated above, the tutorial lessons will make little sense. You must also remember to reset the units to sensible values (for your country) before using the SDR33 in the field. A simple way to reset the units may be to perform a cold boot of the SDR33 (see the **SDR33 Reference Manual**, Chapter 2, “*Cold boot*”). This will also remove any tutorial jobs from the SDR33’s memory.

4. When the units are set as indicated in the illustration, press the <OK> key to return to the “*Functions*” menu.



Note: Pressing the <ENTER> key when the cursor is positioned on the last field of *most* screens is equivalent to pressing the <OK> key. The SDR33 accepts the current screen and moves to the next logical screen.


1.4

Setting the instrument selection

Before using your SDR33 with a total station for field work, it is important to set both up properly so that units and corrections are applied correctly. (See Appendix B of the **SDR33 Reference Manual** for details.) For the purposes of this tutorial, however, we will ignore these details and use the “*Manual*” instrument setting (i.e., we will enter all survey data on the SDR33’s keyboard, rather than using a total station).

Follow these steps to set the instrument selection:

1. From the “*Functions*” menu, move the highlighted cursor until the “*Instrument*” entry of the menu is highlighted or press the <I> key to go straight to the “*Instrument*” entry.



2. Press the <ENTER> or <OK> key to select this option.

1: Job start-up



Note: When in an SDR33 menu, you may type the initial letter of a menu-entry's name to proceed directly to that entry. If more than one entry begins with the same letter, repeatedly pressing the key corresponding to that letter moves the highlight from one such entry to the next.

You should now see the following “*Instrument selection*” screen:

Instrument	
EDM S/N	000000
U.obs	Zenith
P.C. mm	0

3. If the value of the “*Instrument*” field is **not** “*Manual*” (it will probably be the “*SET*” instrument by default) use the <=> or <=> arrow keys to step through the instrument types until the “*Manual*” option appears.

Instrument	
Theo desc	<No text>
Theo S/N	000000
EDM desc	<No text>
EDM S/N	000000

When “*Manual*” is highlighted, you can use <ENTER>, <↓>, or <↑> to enter the various facets of your manual “*instrument*,” such as “*Theo desc*” (a short description of the theodolite being used, if any), “*Theo Serial*” (the serial number of your theodolite, if any), etc. We are not particularly interested in such details at present so we will accept (with the <OK> key) our manual “*instrument*” and return to the “*Functions*” menu.

4. Press the <OK> key again. The SDR33 beeps and lets us know that it has recorded our choice of instrument into the database for the current job (“*SMITH 001*”).

1.5

Setting the date and time

When you receive your SDR33 and first turn it on, the date and time will probably be as they were set in the factory (i.e., 1 January, 1980 and 0:00:00). You should set the date and time appropriately to your time zone.

Follow these steps to set the date:

1. Select the ***"Date and time"*** entry in the ***"Functions"*** menu by moving the cursor until this entry is highlighted.
2. Press the <ENTER> or <OK> key. You should see the following screen.

```

Date format  DDMMYY
Date         31-05-92
Time         00:36:00

Time out     10
Timestamp    0
  
```

3. If the ***"Date"*** field's value is incorrect, position the cursor over it and type the correct date in the format shown by the ***"Date format"*** field. **DDMMYY** means that you should type the day (between 01 and 31,) followed by the month (between 01 for January and 12 for December,) followed by the year (92 for 1992, 93 for 1993, etc.). The format **MMDDYY** means that the month is entered before the day. You must type two digits for each component of the date and do not enter any spaces or punctuation.
4. Press the <ENTER> key to accept and display the new date.
5. Check that the date is correct. If it is not, follow the above instructions again until the displayed date is correct.

```

Date format  DDMMYY
Date         12-May-92
Time         00:38:00

Time out     10
Timestamp    10
  
```

1: Job start-up

Follow these steps to set the time:

1. Position the cursor over the ***“Time”*** field and type the correct time into the field. Use 24-hour clock format, i.e., **HHMMSS**. You must type two digits for each component of the time (e.g., 083000 for 8:30 a.m. or 172500 for 5:25 p.m. Leave the seconds component as 00). There should be no spaces or punctuation in the time entry.
2. Press **<ENTER>** and check that the time displayed is what you intended.

1.5.1

Timeout and Timestamp

The final two fields of this screen are ***“Timeout”*** and ***“Timestamp.”*** ***“Timeout”*** specifies the time, in minutes, which the SDR33 will allow to elapse between keystrokes before switching itself off. The SDR33 attempts to maximize battery life by “going to sleep” if it is unused for a period of time. You may set the timeout period as low as one minute or as high as 99 minutes. The latter is not recommended, as it is easy to forget to turn off the SDR33. (It is frustrating to find the battery discharged several days later.) If you set the timeout to one minute, you may often find that the SDR33 turns off while you are sighting a point, etc. If this happens, press the **<1/0>** key to turn it back on. It will be in exactly the same state as it was before it turned itself off.

The ***“Timestamp”*** option may be used to record the time (in the database) at the requested interval (in minutes). The value 0 means that the SDR33 should not store timestamps at all.

Press **<OK>** to save your data and time settings and to return to the ***“Functions”*** menu.

1.6

Checking the configuration

There are several miscellaneous configuration parameters that affect the behavior of the SDR33. These parameters appear under the ***“Configure reading”*** menu. It is a good idea to check these settings before you start any field work.

Follow these steps to check Configuration parameters:

1. Select the “*Configure reading*” option.



Note: You can generally (unless doing so would result in the loss of some important data) move up the menu hierarchy to the “*Start up screen*” by repeatedly pressing the <CLEAR> key. If you become “lost” in the depths of the SDR33, and you cannot find your way around (even with the help of this **Guide** and the **SDR33 Reference Manual**), press the <CLEAR> key. Examine each level as you step your way out until you arrive back on familiar ground. There is one exception to this process: if you are asked a question with a “*Yes*” or “*No*” response, <CLEAR> will not bypass the prompt.

The “*Configuration*” screen should look like this:

```

Auto pt num      0000
Topo view stored 085
Combine F1/F2    No
Num dist read    1
Tracking         No
Code list active Yes
Info blocks      0
Code fields      0
  
```

As with the “*units*,” some of the SDR33’s configuration parameters will be configured differently for different markets.

2. Change the values appearing on your screen to those illustrated in the diagram above. Again, you should remember to reset them to their defaults (or perform a cold boot) before undertaking field work with the SDR33.

You will now be back at the “*Functions*” menu.

```

Job
Instrument
Configure reading
Tolerances
Units
Date and time
Job deletion
SURU COM COGO ROWO
  
```

1: Job start-up

You have now created a new job and made sure that the SDR33 is configured correctly for field work.

The following lesson uses the SDR33's feature-code-list mechanism to set up appropriate codes before they are actually needed. This simplifies code entry when you're in the field.

The following is a printout produced by an SDR33 describing the database (for the job "**SMITH 001**") after the first lesson is completed.



SDR33 V04-03.00	Copyright STI		13-May-92 11:55
	Angle Degrees	Dist Meters	Press Millibar
	Temp Celsius	Coord N-E-Elev	
JOB	SMITH 001	Point id Numeric (4)	
	Atmos crn No	C and R crn No	Refract const 0.14
	Record elev Yes	Sea level crn No	
SCALE	S.F. 1.00000000		
NOTE TS	12-May-92 09:59		
NOTE	LOT4 DP356784	16 SHIRAZ RD	DOONVILLE
INSTRUMENT	Manual	EDM <No text>	EDM serial 000000
	Theo desc <No text>	Theo serial 000000	Mount Not applic
	V.obs Zenith	EDM o/s <Null>	Refl o/s <Null>
	P.C. mm 0.000		
** End of report **			

Lesson 2

Defining a feature code list

Before collecting traverse data, we will discuss feature coding and its significance to efficient SDR33 use. The SDR method of feature coding is based on a “**plain language**” description of a feature. The style of feature coding you use is dependent upon the requirements of any computer software that will subsequently process the output of your SDR33 (e.g., SOKKIA Software). To help you consistently code different features, the SDR33 stores feature code lists. The SDR33 can store as many lists and feature codes as you wish, constrained only by available memory space.

We will now create a feature code list and enter some appropriate codes to help us collect information for Mrs. Smith’s job. Access the feature code list whenever you wish to enter a code (during actual field work) via the “**Feature code list**” entry in the “**Functions**” menu.

In this lesson you will:

- Access the “**Feature code**” menu
- Move through menus, screens
- Name the feature code list
- Learn how to correct typing errors
- Enter feature codes
- Learn how to delete and edit codes.

2.1

Quick summary

Brief steps for using feature codes are listed below:

- To create a new feature code list, press <FUNC> “**Feature code list**” <LISTS> <ADD>. Then type in name of new list.
- To select an existing feature code list, press <FUNC> “**Feature code list**” <LISTS>. Then position highlight cursor over the list you wish to select. Press <OK> or <ENTER>.
- To add a feature code to the currently selected list, press <FUNC> “**Feature code list**” <ADD>. Type in the new code. Press <OK> or <ENTER>.


2: Feature codes

2.2

Creating Feature code lists

Follow these steps to access the “*Feature code*” menu:


1. Enter the “*Functions*” menu. If you are in the “*Start up screen*,” press the <F1> key, which corresponds to the <FUNC> softkey. The following screen will appear:



As you can see, there is no (visible) entry for the “*Feature code list*.” Note, however, the <⇓> arrow character in the bottom–right corner of the screen (just above the softkeys); this indicates the “*Functions*” menu extends over more than one screen.

2. Move to the next screen of the menu by one of three ways:
 - a. Press the <⇓> arrow key seven times
 - b. Press the <⇑> arrow key once. Menus are circular — if you go off the bottom you get back to the top, and vice versa.
 - c. Press the gold <FUNC> key followed by the <⇓> arrow key to go down a page.

The following screen displays:



Note: This screen has an <⇑> arrow at the top right of the screen, indicating that the menu extends onto a page above the currently–displayed one.



Moving through screens

Note: Whenever the SDR33 displays a logical “page” of data too long to fit onto one screen, it will position an <↑> or <↓> arrow (or both) in the top–right or bottom–right corner(s) of the screen to indicate that there is more information above and/or below the current screen. In such cases, pressing gold <FUNC> <↑> will take you one screen–height up the logical “page.” Pressing gold <FUNC> <↓> will take you one screen–height down.

2.3

Naming feature code lists

Follow these steps to highlight and select the current name:

1. Highlight the “*Feature code list*” entry of the menu.
2. Press the <ENTER> or <OK> key to select this entry. The following screen displays:



The name at the top of the screen is the name of the current feature–code list (the default being “*Default list*”). We will change the name of this default list to “**TUTORIAL**”.

2.4

Editing feature code lists

The “*LISTS*” softkey enables us to actually create, delete, or rename entire feature–code lists so we will use this feature to rename the “*Default list*.”

Follow these steps to rename the list:

1. Press the <F4> key corresponding to the “*LISTS*” softkey; you will see a screen like this:

2: Feature codes



Note: In the remainder of this **Guide**, we will direct you to press a softkey without giving its corresponding function key number. For example, in the above circumstance, instead of saying “Press the <F4> key corresponding to the “*LISTS*” softkey,” we will say “Press the <*LISTS*> softkey.”

This “*Feature code lists*” screen displays the names of all feature-code lists currently in the SDR33 memory. By default, only the list called “*Default list*” will be present. You can select an existing list and make it active (only the active list is used during the entry of feature-codes in field work) by highlighting the name of the desired list and pressing the <ENTER> or <OK> key. You can create a new list (which will then become the active list) by pressing the <ADD> softkey and entering a name for the new list. You can delete lists that are no longer required using the softkey, and you can change the name of the currently-highlighted list using the <EDIT> softkey. .

2. Press the <EDIT> softkey; you will see the following screen:



3. Type in the new list name as follows:



TUTORIAL

4. Blank out the rest of the line with spaces, then press the **<ENTER>** key.



Correcting typing errors

Note: When typing in names and values, correct errors by pressing the **<CLEAR>** key. This clears the whole field; pressing **<CLEAR>** again will reinstate the original value of the field. Pressing the **<BKSP>** key deletes the last character typed (the character to the immediate left of the cursor). Pressing the gold **<FUNC>** key—sequence deletes the character at the cursor location.

Your screen should be the “*Feature code lists*” screen with the name of the currently–highlighted list changed, as shown below:



5. Press the **<ENTER>** or **<OK>** key to get back to the first feature–code screen, which will have the new list name on the top line.



Note: Feature codes and job files are stored in the same memory space. If your codes use a lot of memory the capacity of the SDR33 for field and calculations data is reduced.

2: Feature codes

2.5

Entering feature codes

We will now proceed to add some feature codes to the “**TUTORIAL**” list.

Follow these steps to enter feature codes:


1. Press the **<ADD>** softkey. The following screen appears:



```
ADD feature code
Cd [REDACTED] <No text>
Join [REDACTED] No
Attributes [REDACTED] 0
```

2. Type the following code:

BLD <OK>



```
TUTORIAL
Cd [REDACTED] BLD
ADD DEL EDIT LISTS
```

This is the feature code for a “**BuiLDing**.”

3. Press **<ADD>** again and type:

NS <OK>


This is a code for a “**Natural Surface**.”

4. Type in the following codes in the same way:



Press: <ADD>
 Type: TREE <OK>
 Press: <ADD>
 Type: SM <OK>
 Press: <ADD>
 Type: STN <OK>

The codes *SM* and *STN* denote “Survey Mark” and “STationN.”



Deleting and editing codes

Using the <↑> and <↓> arrow keys, you can scroll through the codes that you have entered. If you wish to delete any of the codes, position the cursor over the unwanted code and press the softkey. Edit a particular code by positioning the cursor over it, pressing the <EDIT> softkey, and typing in a replacement code or fixing the old one.

5. Now that we have entered several feature codes, press <CLEAR> to return to the “*Functions*” menu and to the “*Start up screen*.”

Feature-code lists are described in detail in Chapter 8 of the **SDR33 Reference Manual**.

2: Feature codes

This page was intentionally left blank.

Lesson 3

Collecting traverse data

In our example job we will measure a traverse around the perimeter of the lot to collect cadastral information as well as to provide control for a resection. We'll also complete topographical and setting out work.

In this lesson you will:

- Enter coordinates of known points
- Enter feature codes for points
- Enter known azimuths and distances
- Establish parameters for set collection
- Pre-enter points for set collection
- Initiate readings
- Complete a traverse adjustment.

3.1

Entering coordinates of known points

Our first step in this operation is to enter the useful survey information that we already have (on our cadastral plan). We have the coordinates of two of our lot corners (0001 and 0004), as well as the azimuths and distances to several survey marks (3847, 3846, and 3830).

Follow these steps to enter coordinates of known points:

1. Move from the “*Functions*” menu (where you currently should be) to the “*Survey*” menu in either of two ways:
 - a. Press <CLEAR> to move from the “*Functions*” menu to the “*Start up screen*.” Then select the “*Survey*” menu by pressing the <SURV> softkey (which corresponds to the <F2> key).
 - b. Press the <SURV> softkey on the “*Functions*” menu, and you go directly to the “*Survey*” menu.

Each of the top-level menus (those accessible from the “*Start up screen*”) has softkeys for direct access to the other top-level menus, thus avoiding the need to continually move up to the “*Start up screen*” and back down to the desired menu.

3: Traversing

2. Select the “**Survey**” menu by pressing the <SURV> softkey from the “**Start up screen.**”



3. Select the “**Keyboard input**” entry of this menu (by using the <↓> key or by pressing <K> directly).
4. Press the <ENTER> or <OK> key. The following screen appears:



We will enter the coordinates of one of our known points (0004), and then azimuths and distances from that known point to the others to demonstrate the SDR33’s capabilities.

5. Select the “**Key in coords**” entry of the “**Keyboard input**” menu by pressing <ENTER> or <OK>. The following screen displays, which provides fields for the coordinates of a single point.





Automatic Point Ids

Note: You will notice that the “*Pt*” field already contains a (highlighted) point name (1000). The SDR33 maintains an “*Auto Pt Id*” field (in the “*Configuration*” menu) that determines the next point name. You can always override such automatically-generated point names, but they are often useful when you are progressing from point to point and none of the points are known/named.

6. Type in the following data with the cursor positioned over the “*Pt*” field.



For Pt,	type:	4 <ENTER>
For North,	type:	14981.117 <ENTER>
For East,	type:	10078.135 <ENTER>
For Elev,	type:	106.261 <ENTER>

Your screen should look like this:




Now, since the point 0004 corresponds to a station, we should enter the feature code **STN** into the “*Cd*” field.

Follow these steps to enter a feature code for the point:


1. Position the cursor over the “*Cd*” field.
2. Press the <S> key.

You will be automatically taken to the first feature code in the current list (“**TUTORIAL**”) that starts with the letter **S**. The first code is **SM**, for **Survey Mark**, as indicated in the following display:

3: Traversing




3. Press the <T> key and the cursor highlights the first feature code beginning with the letters **ST**, which is **STN** (for station).



4. Press the <ENTER> or <OK> key since this is the code we require.

The “**Key in coords**” screen displays but with “**STN _**” in the “**Cd**” field. (A ‘space’ character is automatically inserted in order that another code may be appended to the “**Cd**” field.)




5. Press the <ENTER> or <OK> key to accept the current point and its coordinates. The SDR33 will beep and briefly display “**Input accepted**” before returning to the same screen (which will again be blank, except for the automatically-suggested point name and the **STN** code).
6. Press <CLEAR> to return to the “**Keyboard input**” menu (illustrated below) so you can enter azimuths and distances for other known points.



Follow these steps to enter known azimuths and distances:

1. Select the “*Key in azmth & dist*” entry by pressing the <↓> key twice and then pressing <ENTER> or <OK>. The following screen displays:



This screen accepts information about known points in a similar way to the “*Key in coords*” screen. In this screen the information required is an azimuth and distance between two named points. In addition to point 0004, whose coordinates we entered above, we know azimuths and distances between points 3847, 3846, 0001, and 3830.

2. Enter the following data:



For From,	type:	4 <ENTER>
For To pt,	type:	3847 <ENTER>
For Azimuth,	type:	96.2849 <ENTER>
For H.dist,	type:	296.451 <ENTER>

Follow these steps to enter a feature code for the point:

1. Type <S> at the “Cd” prompt. This highlights the SM entry in the feature-code list.
2. Press <ENTER> to accept the Survey Mark code (for point 3847).

3: Traversing




3. Press **<OK>** to accept the information on the screen. After saving the data, the SDR33 offers you the opportunity to enter an azimuth and distance between another pair of points.

Follow these steps to enter additional azimuths and distances:

1. Enter the following data:



For From,	type:	3847 <ENTER>
For To pt,	type:	3846 <ENTER>
For Azimuth,	type:	5.5022 <ENTER>
For H.dist,	type:	260.092 <ENTER>
For Cd,	type:	<OK>



The information will be saved to the database.

2. Enter the following data for the azimuth and distance between points 3846 and 0001:



For From,	type:	3846 <ENTER>
For To pt,	type:	1 <ENTER>
For Azimuth,	type:	252.0020 <ENTER>
For H.dist,	type:	325 <ENTER>
For Cd,	type:	<S> <T> <ENTER>



3. Press **<OK>** to save the data.
4. Enter the following data as an azimuth and distance from point 0001 to point 3830:



For From,	type:	1 <ENTER>
For To pt,	type:	3830 <ENTER>
For Azimuth,	type:	272.0819 <ENTER>
For H.dist,	type:	230.623 <ENTER>
For Cd,	type:	<S> <ENTER>



5. Press **<OK>** to save the data.

We have now entered the coordinates of one station, and azimuths and distances between four other known points.

6. Press the **<CLEAR>** key to get back to the main **“Keyboard input”** menu, and press it again to get out to the **“Survey”** menu. We will now proceed to observe a set from this station.

3.2

Set collection

The set-collection facilities provided by the SDR33 are considerably more sophisticated than those provided by the SDR20 series. Essentially, the ways

3: Traversing

you may collect sets are controlled through a series of parameters. Once you have set these parameters for your purposes, you should be able to collect multiple sets, aided by the SDR33, without having to alter these parameters again.

In order to calculate a traverse for Mrs. Smith's job, we will collect sets from the stations 0001, 0002, 0003, and 0004, as described in the remainder of this section.

Follow these steps to establish your set collection parameters:


1. Position the cursor on the **"Set Collection"** entry in the **"Survey"** menu and select it (using the <ENTER> or <OK> key). The following screen displays:



```
Confirm orientation
Stn      [ ]
BS pt    [ ]
OPTIONS
```

This screen is where you enter your station name and backsight (and coordinates/azimuths, if these cannot be derived from data already entered). Also use it to set the parameters for set collection (via **"OPTIONS"**).

2. Press the <OPTIONS> softkey; the following screen displays:



```
Options
Method  Direction
Data    HUD
Number of H sets  1
Num dist read    1
Face order F1F2/F2F1
Obs order  123..321
Return sight No
Pre-enter points Yes
```



Note: It is good practice to check the suitability of the various parameters for your purposes each time you start set collection.

For a further explanation of the meaning of the various options, see the **SDR33 Reference Manual** (Chapter 11).

3. Make sure the options are as illustrated above (they should be, by default).
4. Press the <OK> key to accept these parameters; you will return to the **“Confirm Orientation”** screen shown previously. You should now type in the number of our first station (station 0001); type

Follow these steps to enter the station and its coordinates, the backsight, and points for set collection:

1. Type the number of our first station (station 0001):



Type: **1 <Enter>**

The following screen appears:

Stn	0001
North	15106.001
East	10090.051
Elev	<Null>
Theo ht	Null
Cd	Stn



Note: The SDR33 derived the coordinates of point 0001 from the contents of the database (by following the chain from the coordinates for point 0004 through points 3847 and 3846 to 0001 using the keyed-in azimuths and distances). You only need to enter the elevation, theodolite height, and code for point 0001.

2. Position the cursor on the **“Elev”** field and enter the following data:



For Elev,	type:	100.5 <ENTER>
For Theo Ht,	type:	1.57 <ENTER>

3: Traversing

Your screen should look like this:

Stn	0001
North	15106.001
East	10090.051
Elev	100.500
Theo ht	1.570
Cd	SIN

3. Press the <ENTER> or <OK> key to accept the station and its coordinates.

You will return to the “*Confirm Orientation*” screen with the cursor now positioned on the “*BS Pt*” field.

4. Enter point 3846 for the backsight. Type the following:

Confirm orientation	
Stn	0001
BS pt	3846
OPTIONS	



3846 <OK>

The SDR33 computes the azimuth from the station 0001 to point 3846 and does not require you to explicitly enter the azimuth to the backsight. The message “**Analyzing Sets**” appears (while the SDR33 examines the database to see whether you have previously collected sets from station 0001), then the following screen appears:

Pre-enter points	
Pt	3846
Pt	
INS DEL	
DELALL	

The “*Pre-enter points*” option (one of the set-collection parameters accessed by the <OPTION> key when you select “*Set collection*”) specified that we wanted to pre-enter the names of all points that we would be observing in sets. The SDR33 can then prompt for observations to each point.



Note: If you normally do not follow any particular order of observation while collecting sets, change the “*Pre-enter points*” option to “*No.*” In general, however, the SDR33 is of more assistance if you do pre-enter points, specify how many sets you wish to observe, and whether or not you want to take a return-sight, etc.

Point order

Notice that point 3846 (the backsight) has already been selected as the first point for observation. You may alter the order of observation so that the backsight is not the first point, but you will not be permitted to observe a set that does **not** contain any observation to the backsight. (The exception to this is if you are collecting sets to perform a resection.) In general, it is better to observe the backsight first in a set, particularly if you intend to take a return sight, because the first point observed in a set will be treated as the reference point. The difference(s) between the first observation to the reference point and the return observation to the reference point will be distributed across all other observations in the set. Thus, it makes more sense for the reference point to be the backsight, and the backsight to be the first point observed in a set.

5. Add the points 0002 and 0004 to the list of points to observe, by typing:

2 <ENTER>

4 <ENTER>



3: Traversing

Pre-enter points	
Pt	3846
Pt	0002
Pt	0004
Pt	

INS DEL DELALL

- Press the <OK> key to indicate that the sequence of points to observe is complete.

Follow these steps to take readings for the set from station 0001:

The following screen (called the “*Take reading*” screen) appears. After step 6 above. This screen informs you that you are taking face 1 of set 1 (i.e., the first face of the first set collected) from station 0001. The screen indicates that the backsight for this station is 3846 and that you should now sight to point 3846 and take a reading.

Take face 1		Set1
Stn		0001
BS pt		3846
To pt		3846

DFS DFS-0 DS-20 ANGLE CNFG



Note: The softkeys on the bottom of the “*Take reading*” screen indicate various types of readings that are possible at this point, including angles-only readings and various offset readings. In general, you press the large <READ> key to initiate a reading.

- Press the <ANGLE> softkey to take an angles-only reading since we will not observe an EDM distance to our backsight. The following screen appears:

Code	<No text>
Pt	3846
Target ht	<Null>
H.obs	<Null>
V.obs	<Null>
S.Dist	<Null>

DFS DFS-0 DS-20 ANGLE CNFG



Note: The angle-only screen has a prompt for a slope distance that shows a null reading (also the case when you're using a total station). This field is included if you want to record a taped measurement.

2. Enter the following data:




For Cd, type: **<S> <ENTER> <ENTER>**

Now the **SM** code is on the screen.



For Target ht, type **2 <ENTER>**
 For H.obs, type **72.0020 <ENTER>**
 For V.obs, type **88.4420 <ENTER>**

The screen should look like this:



3. Accept the data and move on to the next reading in one of two ways:
 - a. Press **<OK>** to accept the screen of data and bring up the next point's **"Take reading"** prompt screen.
 - b. Press **<READ>**, which accepts the current screen of data and automatically initiates the next reading.



Note: In practice, sight the total station at the new point with the previous point's data still on the screen before pressing **<READ>**.

4. Press **<READ>** and enter the following data (for point 0002):

3: Traversing



For Cd,	type:	<S> <T> <ENTER> <ENTER>
For Target Ht,	type:	1.75 <ENTER>
For H.obs,	type:	93.0517 <ENTER>
For V.obs,	type:	89.1624 <ENTER>
For S.Dist,	type:	215.316 <ENTER>

5. Press the **<READ>** key to store this observation and start another reading. The SDR33 will prompt you to enter observations to each of the pre-entered points in turn.
6. Enter the following data (for point 0004):



For Cd,	type:	<S> <T> <ENTER> <ENTER>
For Target Ht,	type:	1.7 <ENTER>
For H.obs,	type:	185.2705 <ENTER>
For V.obs,	type:	87.1840 <ENTER>
For S.Dist,	type:	125.59 <ENTER>

7. Press the **<READ>** key once more. The following message displays:

Turn face over ...

...Press any key...

This message tells you to change faces on your theodolite.

8. Press any key and you will be able to start observations on the second face. Note that the first observation is to point 0004, the last point observed on the first face. This is because the set-collection parameter "**Obs order**" has the value "123. . .321," meaning that you observe points on alternate faces in opposite order.

Take face 2	Set1
Stn	0001
BS Pt	3846
To Pt	0004
OFS OFS-0 OS-20 ANGLE CNFG	

9. Press the **<READ>** key and enter information for the second-face observation to point 0004. Note that the “*Cd*” and “*Target Ht*” fields have been retained from the first face observation. Unless these have changed (in general, they won’t have), move the cursor down to the “*H.obs*” field. Enter the following data:



For H.obs, type: **5.2655 <ENTER>**
 For V.obs, type: **272.4117 <ENTER>**
 For S.Distance, type: **125.585 <ENTER>**

Code	
Pt	STN 0004
Target ht	1.700
H.obs	5'26.55"
V.obs	272'41.17"
S.Distance	125.585
OFS OFS-0 OS-20 ANGLE CNFG	

10. Press the **<READ>** key to initiate the second-face observation to point 0002. Again, the “*Cd*” and “*Target Ht*” fields are filled-in from the first-face observation; move the cursor down to the “*H.obs*” field and type in the following details:



For H.obs, type: **273.0520 <ENTER>**
 For V.obs, type: **270.4333 <ENTER>**
 For S.Distance, type: **215.318 <ENTER>**

11. Press the **<ANGLE>** softkey to initiate the second (angles-only) observation to the backsight. Move the cursor down to the “*H.obs*” field and type in the following details:

3: Traversing



For H.obs, type: **252.0015 <ENTER>**
For V.obs, type: **271.1545 <ENTER>**

```
Code
Pt          SM
Target ht   3846
H.obs       252°00'15"
V.obs       271°15'45"
S.Dist      <Null>
[OK] [F5-0] [F5-20] [ANGLE] [ENF5]
```

12. Press the **<OK>** key.

The SDR33 displays the **"Processing Data"** message, and then the following screen appears:

```
Stn          0001
Number of sets  1
[Change station]
Collect more sets
Review existing sets
[OPTIONS]
```

We have collected our first set and will now collect a set from station 0002.

Follow these steps to enter the station, backsight and points for set collection:

1. Position the cursor on the **"Change Station"** entry in the menu illustrated above and press the **<ENTER>** or **<OK>** key. The **"Confirm Orientation"** screen (following) reappears:

```
Confirm orientation
Stn          [ ]
BS Pt        3846
Azimuth      72°00'20"
H.obs        72°00'18"
[OPTIONS]
```

Note that the <OPTIONS> softkey is available at this screen.

2. Type the following in the “*Stn*” field to indicate station 0002:



2 <ENTER>

the following screen appears:

Stn	0002
North	15094.398
East	10305.038
Elev	103.049
Theo ht	000.000
Cd	STN

The coordinates displayed on this screen are the calculated values using the averages from the sightings made to station 0002 from station 0001 in the previously-collected set.

3. Enter a theodolite height by typing:



1.58 <ENTER>

4. Accept this station by pressing the <OK> key. The “*Confirm Orientation*” screen displays with the cursor on the “*BS pt*” field.
5. Type the following to indicate point 0001 as the backsight:



1 <OK>

The SDR33 computes the azimuth from 0002 to 0001 and then asks us to pre-enter points:

3: Traversing




```
re-enter points
Pt 0001
Pt
INS DEL DELALL
```

6. Type the following to indicate that we will observe point 0003:

3 <ENTER>

7. Press the <OK> key, and the “*Take Reading*” screen appears with a prompt to observe point 0001 (the backsight).

Follow these steps to take readings for the set from station 0002:



```
Take F1 Set1
Stn 0001
BS pt 0001
To pt 0001
OFS OFS-0 OS-20 ANGLE CNFG
```

1. Press the <READ> key and enter the following data:

For Cd,	type:	<S> <T> <ENTER> <ENTER>
For Target Ht,	type:	1.75 <ENTER>
For H.obs,	type:	273.0518 <ENTER>
For V.obs,	type:	90.38 <ENTER>
For S.Distance,	type:	215.313 <ENTER>

```
Code STN
Pt 0001
Target ht 1.750
H.obs 273.0518"
V.obs 90.38.00"
S.Distance 215.313
OFS OFS-0 OS-20 ANGLE CNFG
```

2. Press the **<READ>** key to initiate the next reading (to point 0003).
Enter the following data:



For Cd, type: **<S> <T> <ENTER> <ENTER>**
For Target Ht, type: **1.7 <ENTER>**
For H.obs, type: **185.2658 <ENTER>**
For V.obs, type: **82.4620 <ENTER>**
For S.Distance, type: **103.15 <ENTER>**

3. Press **<READ>**. The prompt to change faces displays
4. Press any key and then press **<READ>**.
5. Enter the following information for point 0003 after moving the cursor down to the **"H.obs"** field:



For H.obs, type: **5.2703 <ENTER>**
For V.obs, type: **277.1343 <ENTER>**
For S.Distance, type: **103.152 <ENTER>**

6. Press **<READ>** and enter the following information for the final observation to point 0001:



For H.obs, type: **93.0520 <ENTER>**
For V.obs, type: **269.2204 <ENTER>**
For S.Distance, type: **215.31 <ENTER>**

7. Press **<OK>**. Once again, you will reach the following screen:

Stn	0002
Number of sets	1
Change station	
Collect more sets	
Review existing sets	
OPTIONS	

Follow these steps to collect a set from station 0003:

3: Traversing

1. Select “*Change Station*” and press <ENTER>.
2. Type the following in the “*Stn*” field:



3 <ENTER>

3. Note the coordinates calculated by the SDR33 for the point 3 and then enter the following theodolite height:



1.6 <ENTER>

4. Press <OK> to accept the station.
5. Type the following to indicate point 0002 as the backsight:



2 <OK>

You will again see the pre-entry screen (below) with the backsight (0002) already entered:



6. Enter point 0004 by typing:



4 <OK> <OK>

The “*Take reading*” screen displays.

- Press the **<READ>** key. Enter the following data as observations to points 0002 and 0004 from station 0003:



Code	Point	Target Ht	H.obs	V.obs	S.Dist	
STN	0002	1.75	5.2703	97.0445	103.136	<READ>
STN	0004	1.7	266.5950	92.3050	217.69	<READ>
... change faces ...						
STN	0004	1.7	86.5948	267.2909	217.69	<READ>
STN	0002	1.75	185.2658	262.5515	103.135	<OK>

Follow these steps to collect a set from station 0004:

- Select **"Change Station."**
- Enter the following in the **"Stn"** field:

4 <OK>

- Enter the following theodolite height:

1.59 <OK>

- Type the following to indicate point 0003 as the backsight:

3 <OK>

- Enter the following at the point pre-entry screen:

3830 <ENTER>
1 <OK>

Your screen should look like this:

3: Traversing



6. Press the **<OK>** key and enter the following data as observations for the set from station 0004:




Press the **<ANGLE>** softkey as indicated below to initiate an angles-only reading.




Code	Point	Target Ht	H. obs	V. obs	S. Dist	
STN	0003	1.75	86.5950	87.2505	217.7	<ANGLE>
SM	3830	2	301.2455	89.0010		<READ>
STN	0001	1.7	5.27	92.3445	125.58	<READ>
... change faces ...						
STN	0001	1.7	185.2658	267.2515	125.577	<ANGLE>
SM	3830	2	121.25	270.5950		<READ>
STN	0003	1.75	266.5950	272.3458	217.7	<OK>

You will finally arrive at the following screen:



7. Press the **<CLEAR>** key to return to the **"Survey"** menu illustrated below:



We may now use the data collected in the above sets to calculate and adjust a traverse.



Note: Observations collected in sets may be viewed using the special “*Set review*” mechanism. This powerful facility is described in Chapter 11 of the **SDR33 Reference Manual**.


3.3

Traverse adjustment

We will now use the information collected in the sets from stations 0001, 0002, 0003, and 0004 to perform a traverse adjustment.

Follow these steps to complete a traverse adjustment:

1. Highlight the “*Traverse adjustment*” entry on the “*Survey*” menu and press <ENTER> or <OK> to select it.



The “*Occupied stations*” screen (below) prompts you for the station point numbers that you occupied in the course of your traverse.



3: Traversing



2. Type the following:

Type **1 <ENTER>**

Type **2 <ENTER>**

The traverse program automatically attempts to generate a route using the connected traverse stations in the job. Whenever the program arrives at a station that could be a useful closing point it stops (i.e., it ceases to display the “**Searching ...**” message) and awaits further station numbers to continue or close. In a few seconds you will see the following:

```
Occupied stations
Start      0001
To Pt     0002
To Pt     0003
To Pt     0004
To Pt
```

3. When stations 0001 to 0004 are shown on the screen, press **<OK>**. The message “**Processing data**” displays, and the following screen appears:

```
Traverse orientation
Stn        0001
BS Pt     3846
Azimuth    72°00'20"
Stn        0004
FS Pt     3830
Azimuth    301°24'38"
```

We will utilize the orientation shown in the above screen for this example.

4. Press the **<OK>** key to accept this orientation. The SDR33 then calculates a closure using the two established survey marks (3846 and 3830) and our occupied stations (0001 to 0004). The following screen shows the results of this calculation:

Traverse Precision	
D.ang	0°00'20"
D.Dist	0.013
Precision	42714
D.North	0.013
D.East	0.000
D.Elev	-0.002
<div> <div>ADJUST</div> <div>STORE</div> <div>OPTIONS</div> </div>	

- Record this traverse precision data by selecting the **<STORE>** softkey. This action stores two notes in the database that record the traverse misclose (closure) details shown on the above screen. The **<STORE>** softkey will disappear once it has been selected.
- Check and/or set the traverse adjustment options by selecting the **<OPTIONS>** softkey. The following screen displays:

Adjustment options	
Method	COMPASS
Angular	Weighted
Elev	Weighted
Report angle adjust	Yes

The “**Method**” field allows you to select the coordinate adjustment method to be used in the traverse adjustment. Leave this set on the default “**Compass**” method. This will adjust the coordinates according to the Compass (also referred to as Bowditch) rule. The other fields on this screen should be set as shown. Refer to the **SDR33 Reference Manual** (Chapter 12) for details relating to the traverse adjustment methods.

- Select **<OK>** to save these traverse adjustment options and return to the previous “**Traverse precision**” screen.
- Select the **<ADJUST>** softkey to carry out the angular adjustment. The angular adjustment is always carried out first when it is applied. After the angular adjustment has been computed the following screen displays:

3: Traversing

```

after angle adjusted
D.ang      0°00'00"
D.Dist     0.007
Precision   74936
D.North    -0.004
D.East     0.006
D.Elev     -0.002
ADJUST     STORE     OPTIONS

```

The displayed traverse misclose details are the revised values computed after the angular misclose in the traverse has been adjusted out.

9. Select the <STORE> softkey to record the misclose details in the SDR33 database.
10. Select the <ADJUST> softkey to carry out the coordinate adjustment. Once the coordinate adjustment has been completed, the adjusted coordinates for each traverse point are stored at the end of the database. These coordinates will then be used in all subsequent calculations involving these traverse points. Once these adjusted coordinates have been saved, the “Survey” menu displays.

The following printout produced by the SDR33 shows the contents of the database (for the “SMITH 001” job) after this lesson has been completed. Note the POS records with the adjusted coordinates of traverse points (2 and 3) at the end of the printout.



SDR33 V04-03.00	Copyright STI	13-May-92 11:57
	Angle Degrees	Dist Meters
	Temp Celsius	Coord N-E-Elev
JOB	SMITH 001	Point id Numeric (4)
	Atmos crn No	C and R crn No
	Record elev Yes	Sea level crn No
SCALE	S.F. 1.00000000	Refract const 0.14
NOTE TS	12-May-92 09:59	
NOTE	LOT4 DP356784	16 SHIRAZ RD
INSTRUMENT	Manual	EDM <No text>
	Theo desc <No text>	Theo serial 000000
	V.obs Zenith	EDM o/s <Null>
	P.C. mm 0.000	Refl o/s <Null>
NOTE TS	12-May-92 10:15	

3: Traversing



POS KI 0004	North 14981.117	East 10078.135	Elev 106.261
	Code STN		
RED KI 0004-3847	Azimuth 96-28'49"	H.dist 296.451	V.dist <Null>
	Code SM		
RED KI 3847-3846	Azimuth 5-50'22"	H.dist 260.092	V.dist <Null>
	Code SM		
RED KI 3846-0001	Azimuth 252-00'20"	H.dist 325.000	V.dist <Null>
	Code STN		
RED KI 0001-3830	Azimuth 272-08'19"	H.dist 230.623	V.dist <Null>
	Code SM		
STN SC 0001	North 15106.001	East 10090.051	Elev 100.500
	Theo ht 1.570	Code STN	
SET SC 0001	Set # 1	Point count 6	
TARGET	Target ht 2.000		
OBS F1 0001-3846	S.dist <Null>	V.obs 88-44'20"	H.obs 72-00'20"
	Code SM		
NOTE TS	12-May-92 10:25		
TARGET	Target ht 1.750		
OBS F1 0001-0002	S.dist 215.316	V.obs 89-16'24"	H.obs 93-05'17"
	Code STN		
TARGET	Target ht 1.700		
OBS F1 0001-0004	S.dist 125.590	V.obs 87-18'40"	H.obs 185-27'05"
	Code STN		
OBS F2 0001-0004	S.dist 125.585	V.obs 272-41'17"	H.obs 5-26'55"
	Code STN		
TARGET	Target ht 1.750		
OBS F2 0001-0002	S.dist 215.318	V.obs 270-43'33"	H.obs 273-05'20"
	Code STN		
TARGET	Target ht 2.000		
OBS F2 0001-3846	S.dist <Null>	V.obs 271-15'45"	H.obs 252-00'15"
	Code SM		
NOTE SC	The following MCs are derived from set(s) 1.		
OBS MC 0001-3846	S.dist <Null>	V.ang <Null>	Azimuth 72-00'20"
	Code SM		
OBS MC 0001-0002	S.dist 215.315	V.ang 89-19'18"	Azimuth 93-05'21"
	Code STN		
OBS MC 0001-0004	S.dist 125.581	V.ang 87-22'15"	Azimuth 185-27'03"
	Code STN		
BKB SC 0001-3846	Azimuth 72-00'20"	H.obs 72-00'18"	
STN SC 0002	North 15094.398	East 10305.038	Elev 103.049

3: Traversing



	Theo ht 1.580	Code STN	
SET SC 0002	Set # 1	Point count 4	
TARGET	Target ht 1.750		
OBS F1 0002-0001	S.dist 215.313	V.obs 90-38'00"	H.obs 273-05'18"
	Code STN		
NOTE TS	12-May-92 10:36		
TARGET	Target ht 1.700		
OBS F1 0002-0003	S.dist 103.150	V.obs 82-46'20"	H.obs 185-26'58"
	Code STN		
OBS F2 0002-0003	S.dist 103.152	V.obs 277-13'43"	H.obs 5-27'03"
	Code STN		
TARGET	Target ht 1.750		
OBS F2 0002-0001	S.dist 215.310	V.obs 269-22'04"	H.obs 93-05'20"
	Code STN		
NOTE SC	The following MCs are derived from set(s) 1.		
OBS MC 0002-0001	S.dist 215.313	V.ang 90-40'41"	Azimuth 273-05'21"
	Code STN		
OBS MC 0002-0003	S.dist 103.136	V.ang 82-50'17"	Azimuth 185-27'02"
	Code STN		
BKB SC 0002-0001	Azimuth 273-05'21"	H.obs 273-05'19"	
STN SC 0003	North 14992.530	East 10295.317	Elev 115.908
	Theo ht 1.600	Code STN	
SET SC 0003	Set # 1	Point count 4	
OBS F1 0003-0002	S.dist 103.136	V.obs 97-04'45"	H.obs 5-27'03"
	Code STN		
TARGET	Target ht 1.700		
OBS F1 0003-0004	S.dist 217.690	V.obs 92-30'50"	H.obs 266-59'50"
	Code STN		
OBS F2 0003-0004	S.dist 217.690	V.obs 267-29'09"	H.obs 86-59'48"
	Code STN		
TARGET	Target ht 1.750		
OBS F2 0003-0002	S.dist 103.135	V.obs 262-55'15"	H.obs 185-26'58"
	Code STN		
NOTE SC	The following MCs are derived from set(s) 1.		
OBS MC 0003-0002	S.dist 103.154	V.ang 97-09'43"	Azimuth 5-27'02"
	Code STN		
OBS MC 0003-0004	S.dist 217.694	V.ang 92-32'25"	Azimuth 266-59'51"
	Code STN		
BKB SC 0003-0002	Azimuth 5-27'02"	H.obs 5-27'01"	



STN SC 0004	North 14981.117	East 10078.135	Elev 106.261
	Theo ht 1.590	Code STN	
NOTE TS	12-May-92 10:46		
SET SC 0004	Set # 1	Point count 6	
OBS F1 0004-0003	S.dist 217.700	V.obs 87-25'05"	H.obs 86-59'50"
	Code STN		
TARGET	Target ht 2.000		
OBS F1 0004-3830	S.dist <Null>	V.obs 89-00'10"	H.obs 301-24'55"
	Code SM		
TARGET	Target ht 1.700		
OBS F1 0004-0001	S.dist 125.580	V.obs 92-34'45"	H.obs 5-27'00"
	Code STN		
OBS F2 0004-0001	S.dist 125.577	V.obs 267-25'15"	H.obs 185-26'58"
	Code STN		
TARGET	Target ht 2.000		
OBS F2 0004-3830	S.dist <Null>	V.obs 270-59'50"	H.obs 121-25'00"
	Code SM		
TARGET	Target ht 1.750		
OBS F2 0004-0003	S.dist 217.700	V.obs 272-34'58"	H.obs 266-59'50"
	Code STN		
NOTE SC	The following MCs are derived from set(s) 1.		
OBS MC 0004-0003	S.dist 217.693	V.ang 87-27'35"	Azimuth 86-59'31"
	Code STN		
OBS MC 0004-3830	S.dist <Null>	V.ang <Null>	Azimuth 301-24'38"
	Code SM		
OBS MC 0004-0001	S.dist 125.583	V.ang 92-37'45"	Azimuth 5-26'40"
	Code STN		
BKB SC 0004-0003	Azimuth 86-59'31"	H.obs 86-59'50"	
NOTE TS	12-May-92 10:56		
NOTE TV	Start 0001	To pt 0004	
NOTE TV	BS pt 3846	Azimuth 72-00'20"	
NOTE TV	FS pt 3830	Azimuth 301-24'38"	
NOTE TV	Method Compass	Angular Weighted	Elev Weighted
NOTE TV	D.ang 0-00'20"	D.Dist 0.013	Precision 42714
NOTE TV	D.North 0.013	D.East 0.000	D.Elev -0.002
NOTE TV	Method Compass	Angular Weighted	Elev Weighted
NOTE TV	D.ang 0-00'00"	D.Dist 0.007	Precision 74936
NOTE TV	D.North -0.004	D.East 0.006	D.Elev -0.002
POS AJ 0002	North 15094.403	East 10305.035	Elev 103.049

3: Traversing



POS AJ 0003

Code STN

North 14992.526

East 10295.318

Elev 115.909

Code STN

** End of report **

Lesson 4

Collecting Topographical Data

In this lesson you will:

- Complete station setup and backsight for topography observations
- Take topography readings
- Take offset readings.

4.1

Quick summary

A brief outline of steps to collect topographical data is listed below:

1. Select job name; default is current job.
2. Press: <SURV> softkey and select “*Topography*” option.
3. Enter the required information for **Stn** (Id of instrument set up) and **Theo ht. North, East, Elev,** and **Cd** (identification of observed point) are optional. (Bold text represents a screen prompt or message.)
4. Enter **BS pt** (Id of point used as backsight).
5. **Key in azimuth** to BS or **Key in coords** of BS. Move highlight cursor to select. Azimuth required if **Stn** coord not given in step (3).
6. Connect to instrument, press <READ> key to take BS observation, enter target height (instrument must be on and pointed at target).
7. You may change **Stn** number or **BS pt** number or take previous observation again. Otherwise take additional observations to continue survey.
8. Enter codes as needed, last code repeats unless overwritten. If keys pressed for code match feature—code list entries, the list is displayed with the matched code highlighted. If the highlighted code is correct, press <OK> or <ENTER> to copy it into the code field on the measurement screen.
9. Press <OK> to store data or press <READ>, and the previous observation is stored before beginning the new observation. If you wish to reject a reading, press <CLEAR> and answer the **Discard data?** question.

4: Topography

10. To move to new set up, change **Stn** number and **BS pt**, and continue from step (5) above.

4.2

Setup and backsight


Mrs. Smith requires a simple contour and detail survey to check on a copy of a previous survey. After the previous lesson you should still be in the “*Survey*” menu.

Follow these steps to complete setup and backsight:

1. Press <T> or use the arrow keys to highlight the “*Topography*” entry:



2. Press <ENTER> or <OK>. The following screen appears:



An alternate way to enter “Topography”

Note: Whenever you are **not** taking readings for some other purpose (i.e., whenever you are not collecting sets or performing a resection, etc.) pressing the <READ> key automatically enters topographical surveying mode in the same way as selecting the “*Topography*” entry of the “*Survey*” menu.

3. Highlight the “*Stn*” field and type:

1 <ENTER>



The following station setup screen appears:

Stn	0001
North	15106.001
East	10090.051
Elev	100.500
Theo ht	3846
Cd	STN

This screen shows the coordinates for the station 0001.

- Position the cursor on the “*Theo ht*” field and type



1.59 <ENTER>

- Press the <OK> key to accept the station’s details. You will return to the “*Take reading*” screen with the cursor on the “*BS pt*” field.
- Type:



3846

This indicates 3846 as the backsight for station 0001.

Take reading	
Stn	0001
BS pt	3846
Topo	
DFS DFS-0 DS-20 ANGLE CNFG	

- Press <OK> and the SDR33 searches its database and finds the most recent record of point 3846; it uses this record to calculate the orientation once a reading has been taken to the backsight.

4: Topography

The SDR33 should now be prompting you to ***“Take BS reading.”***

8. Press the **<ANGLE>** softkey to take an angles-only reading to the backsight. The following screen appears:

Code	
Pt	3846
Target ht	<Null>
H.obs	<Null>
V.obs	<Null>
S.Dist	<Null>
OFS OFS-0 DS-20 ANGLE CNFG	

9. Enter the following data:



For Cd,	type:	<S> <ENTER> <ENTER>
For Target ht,	type:	1.6 <ENTER>
For H.obs,	type:	72.0020 <ENTER>
For V.obs,	type:	88.1616 <ENTER>

The display should look like this:


Code	
Pt	3846
Target ht	1.600
H.obs	72°00'20"
V.obs	88°16'16"
S.Dist	<Null>
OFS OFS-0 DS-20 ANGLE CNFG	

10. Press the **<OK>** key to accept the observation to the backsight. The ***“Take reading”*** screen will re-appear.

4.3

Topography readings

The SDR33 is ready for you to take topography readings. It displays the current station and backsight points to remind you where you are set up and displays the ***“Topo”*** message to indicate topographical mode.




Follow these steps to take topography readings from station 0001:

1. Press the <READ> key to initiate a reading.



Note: In normal practice, your SDR33 would be connected to a theodolite or total station, and you would sight to a target point before pressing the <READ> key.


The following screen appears (note that the “*Pt*” field has been automatically filled in with point number 1000).



2. Enter the following data:



For Cd,	type:	<N> <ENTER> <ENTER>
For Target ht,	type:	1.6 <ENTER>
For H.obs,	type:	185.0730 <ENTER>
For V.obs,	type:	86.5750 <ENTER>
For S.Dist,	type:	64.210



4: Topography

3. Press the **<READ>** key to initiate the next reading.
4. Enter the following data in the same manner as above:



Code	Pt	Target Ht	H. obs	V. obs	S. Dist	
NS	1001	1.6	159.3650	86.18	126.2	<READ>
NS	1002	1.6	140.3420	86.1340	79.94	<READ>
NS	1003	1.6	96.0120	89.0050	59.22	<OK>

You have now entered observations to points 1000, 1001, 1002, and 1003, all of which were given the code of **NS** and target height of **1.6**.

4.4

Changing stations

At this point, we move on to station 0002.

Follow these steps to take topography readings from station 0002:

1. Highlight the **"Stn"** field of the **"Take reading"** screen.

Take reading

Stn 0001

B5 pt 3846

Topo

DFS DFS-0 DS-20 ANGLE CNFG

2. Type

2 <ENTER>



The coordinates for station 0002 display:

Stn 0002

North 15094.403

East 10305.035

Elev 103.049

Theo ht 3846


Cd STN

3. Type in this theodolite height:



1.57

Press **<OK>** to accept the station setup for 0002.




You will now be prompted for the backsight station number.

4. Type



1 **<ENTER>**

The SDR33 computes the azimuth to 0001 from 0002, and uses this to calculate the orientation once you have taken an observation to the backsight.



The SDR33 prompts you to **"Take BS reading."**

5. Press the **<READ>** key to take a full reading to point 0001.
6. Type in the following data:

4: Topography



For Cd, type <S> <T> <ENTER> <ENTER>
 For Target ht, type 1.6 <ENTER>
 For H.obs, type 273.0521 <ENTER>
 For V.obs, type 90.4015 <ENTER>
 For S.Distance, type 215.315

- Press the <READ> key to initiate a topography reading immediately.
- Type in the following data to take observations to points 1004, 1005, 1006, 1007 and 1008, all with a code of NS and target height of 1.6.



Code	Pt	Target Ht	H.obs	V.obs	S.Distance
NS	1004	1.6	271.5650	90.3450	95.4 <READ>
NS	1005	1.6	272.34	90.43	46.34 <READ>
NS	1006	1.6	244.01	87.5330	114.24 <READ>
NS	1007	1.6	240.3230	87.3645	123.72 <READ>
NS	1008	1.6	239.22	86.5830	123.62

```

Code
Pt      NS
Target ht 1.600
H.obs    239'22"00"
V.obs    86'58"30"
S.Distance 123.62
DFS DFS-0 DS-20 ANGLE CNFG
  
```

After pressing <OK> you will be back in the following screen:

```

Take reading
Stn      0000
BS pt    0001
Topo
DFS DFS-0 DS-20 ANGLE CNFG
  
```

Follow these steps to take readings from station 0003:

- Position the cursor on the "Stn" field and type:



3 <ENTER>

2. Type in a theodolite height:



1.57

Stn	0003
North	14992.525
East	10295.318
Elev	115.909
Theo ht	1.57
Cd	STN

3. Press <OK> to accept the station setup and return to the “*take reading*” screen.

4. Type the backsight point:



4 <ENTER>

5. Press the <READ> key to take an observation to the backsight.

Code	STN
Pt	0004
Target ht	1.600
H.obs	<Null>
V.obs	<Null>
S.Dist	<Null>
DFS DFS-0 DS-20 ANGLE CNFG	

4: Topography

6. Enter the following data:



For Cd,	type:	<S> <T> <ENTER> <ENTER>
For Target ht ,	type:	1.57 <ENTER>
For H.obs,	type:	266.5951 <ENTER>
For V.obs,	type:	92.3157 <ENTER>
For S.Distance,	type:	217.693 <OK>

4.5

Offset readings

Our first reading from this station is an offset reading to a tree. In the field, you would position the prism to one side of the tree and the same distance from the instrument as the tree. You would sight on the prism then press the **<OFS>** softkey to take an offset reading; the following screen would display:

Code	
Pt	1009
Target ht	<Null>
V.obs	<Null>
S.Distance	<Null>
CONF	

Follow these steps to complete an offset reading to a tree:

1. Type in the following data:



	Press	<OFS>
For Cd,	type:	<T> <ENTER> <ENTER>
For Target ht	type:	1.57 <ENTER>
For V.obs,	type:	96.3830 <ENTER>
For S.Distance,	type:	66.27 <ENTER>

Code	TREE
Pt	1009
Target ht	1.570
V.obs	96°38'30"
S.Distance	66.27
CONF	

At this point, you would sight your instrument to the center of the tree trunk and press the **<READ>** key.

- Press the **<READ>** key now and the following screen appears:

```

Code      [REDACTED] TREE
Pt        1009
Target ht 1.570
H.obs     <Null>
          [CNFG]
  
```



Note: The code, point number, and target height have been brought forward from the previous screen.

- Move the cursor to the **"H.obs"** field and type:

325.0730 <ENTER>



- Press the **<READ>** key to initiate the following topographical observations and enter the following data:

<u>Code</u>	<u>Point</u>	<u>Target Ht</u>	<u>H.obs</u>	<u>V.obs</u>	<u>S.Dist</u>	
NS	1010	1.57	4.04	97.18	55.6	<READ>
NS	1011	1.57	273.23	92.2850	39.88	<READ>
NS	1012	1.57	295.55	94.0030	89.74	<READ>
NS	1013	1.57	268.39	92.3410	94.15	<READ>
NS	1014	1.57	285.0230	93.3440	100.54	<READ>
NS	1015	1.57	287.3120	93.4450	83.87	<READ>
NS	1016	1.57	287.5550	94.1310	85.28	<READ>



4: Topography

Follow these steps to complete an offset reading to the northeastern corner of the house:


1. Enter the following data:



Code	Point	Target Ht	H.obs	V.obs	S.Dist
BLD	1017	1.57	295.0235	93.5940	90.06 <OK>

Code	BLD
Pt	1017
Target ht	1.570
H.obs	295°02'35"
V.obs	93°59'40"
S.Dist	90.06
OFFS OFFS-0 OS-20 ANGLE CNFG	

To determine the orientation of the house, we will take a different kind of offset reading. For your reading point, you would point your instrument at the prism pole in line with the southeastern corner of the building. The prism is between the instrument and the building corner as shown in the following diagram :



- Press the <OFS-D> softkey to initiate an offset reading using a direction and offset distance. The following screen appears:

Code	BLD
Pt	1018
Target ht	1.570
Ofs dist	0.000
Dirn to prism	<
H.obs	<Null>
CNFG	

- Position the cursor on the “*Target ht*” field and enter the following data:



For Target ht, type: 2.1 <ENTER>
 For Ofs dist, type: 0.9 <ENTER>

The cursor is now positioned on the “*Dirn to prism*” field.

Code	BLD
Pt	1018
Target ht	2.100
Ofs dist	0.900
Dirn to prism	<
H.obs	<Null>
CNFG	

The “*Direction to prism*” field



Note: The “*Dirn to prism*” field is a selector field whose values indicate the position of the object relative to the prism. The position is given from the viewpoint of the person at the instruments as follows:

“<” indicates that the prism is to the left of the object,

“>” indicates that the prism is to the right of the object,

“^” indicates that the prism is behind the object, and

“v” indicates that the prism is in front of the object.

4: Topography

4. Use the <=> and <=> arrows until the “*Dirn to prism*” field has the value “v” so the prism is in front of the object being observed.

```
Code          . BLD
Pt            1018
Target ht     2.100
Ofs dist      0.900
Dirn to prism <Null>
H.obs         <Null>
[CNFG]
```

5. Press <ENTER>.
6. Position the cursor on the “*H.obs*” field and enter the following data:

For H.obs, type: 288.2210 <ENTER>

```
Code          . BLD
Pt            1018
Target ht     2.100
Ofs dist      0.900
Dirn to prism v
H.obs         288.2210
[CNFG]
```

The screen automatically scrolls up.

7. Enter the following data:

For V.obs, type: 94.11 <ENTER>
For S.Distance, type: 86 <ENTER>

8. Press the <OK> key to accept the offset observation.

This concludes the tutorial on topographical data collection. (We will make use of these observations in subsequent tutorials).

9. Press the <CLEAR> key to move back to the “Survey” menu.

More information about the topography program can be found in Chapter 7 of the **SDR33 Reference Manual**.

The following is a printout produced by the SDR33 showing the topographical data collected in the tutorial just completed:



SDR33 V04-03.00	Copyright STI	13-May-92 12:00
	Angle Degrees	Dist Meters
	Temp Celsius	Coord N-E-Elev
JOB	SMITH 001	Point id Numeric (4)
	Atmos crn No	C and R crn No
	Record elev Yes	Sea level crn No
SCALE	S.F. 1.00000000	
NOTE TS	12-May-92 09:59	
NOTE	LOT4 DP356784	16 SHIRAZ RD
INSTRUMENT	Manual	EDM <No text>
	Theo desc <No text>	Theo serial 000000
	V.obs Zenith	EDM o/s <Null>
	P.C. mm 0.000	
NOTE TS	12-May-92 11:12	

The details of the first lessons are omitted for brevity, see Appendix A for a full printout ...

STN TP 0001	North 15106.001	East 10090.051	Elev 100.500
	Theo ht 1.590	Code STN	
BKB TP 0001-3846	Azimuth 72-00'20"	H.obs 72-00'20"	
TARGET	Target ht 1.600		
OBS F1 0001-3846	S.dist <Null>	V.obs 88-16'16"	H.obs 72-00'20"
	Code SM		
POS TP 1000	North 15042.137	East 10084.323	Elev 103.891
	Code NS		
POS TP 1001	North 14987.952	East 10133.920	Elev 108.634
	Code NS		
POS TP 1002	North 15044.387	East 10140.711	Elev 105.749
	Code NS		
POS TP 1003	North 15099.789	East 10148.935	Elev 101.509
	Code NS		
STN TP 0002	North 15094.403	East 10305.035	Elev 103.049
	Theo ht 1.570	Code STN	
BKB TP 0002-0001	Azimuth 273-05'17"	H.obs 273-05'21"	

4: Topography



OBS F1 0002-0001	S.dist 215.315	V.obs 90-40'15"	H.obs 273-05'21"
POS TP 1004	North 15097.642	East 10209.695	Elev 102.053
	Code NS		
POS TP 1005	North 15096.477	East 10258.745	Elev 102.440
	Code NS		
POS TP 1006	North 15044.385	East 10202.413	Elev 107.222
	Code NS		
POS TP 1007	North 15033.609	East 10197.405	Elev 108.173
	Code NS		
POS TP 1008	North 15031.499	East 10198.816	Elev 109.543
	Code NS		
NOTE TS	12-May-92 11:23		
STN TP 0003	North 14992.526	East 10295.318	Elev 115.909
	Theo ht 1.570	Code STN	
BKB TP 0003-0004	Azimuth 266-59'35"	H.obs 266-59'51"	
TARGET	Target ht 1.570		
OBS F1 0003-0004	S.dist 217.693	V.obs 92-31'57"	H.obs 266-59'51"
	Code STN		
POS TP 1009	North 15046.526	East 10257.675	Elev 108.244
	Code TREE		
POS TP 1010	North 15047.557	East 10299.226	Elev 109.005
	Code NS		
POS TP 1011	North 14994.874	East 10255.544	Elev 114.183
	Code NS		
POS TP 1012	North 15031.645	East 10214.797	Elev 109.636
	Code NS		
POS TP 1013	North 14990.302	East 10201.288	Elev 111.688
	Code NS		
POS TP 1014	North 15018.559	East 10198.410	Elev 109.635
	Code NS		
POS TP 1015	North 15017.717	East 10215.508	Elev 110.428
	Code NS		
POS TP 1016	North 15018.703	East 10214.397	Elev 109.634
	Code NS		
POS TP 1017	North 15030.549	East 10213.919	Elev 109.635
	Code BLD		
NOTE TS	12-May-92 11:35		
TARGET	Target ht 2.100		
NOTE OS	86.000 94-11'00"	288-22'10"	OS 0.900
NOTE OS	Dirn v		
POS TP 1018	North 15019.833	East 10213.061	Elev 109.105
	Code BLD		

** End of report **

Lesson 5

Viewing the Database

The database for the current job is always accessible for viewing by pressing the <VIEW> key. The SDR33's eight-line screen makes it easy to examine data in the database. The view screen also provides you with search and scrolling capabilities that make finding data easy.

In this lesson you will:

- Move through the database
- Search the database
- View records
- Add a note to the database.

5.1

Moving through the database**Follow these steps to move through the database:**

1. Press the <VIEW> key, and the following screen appears:

POS	10150
POS	1016
POS	1017
Target ht	2.100
Note 86.000	94-11
Note	Dirn v
POS	1018
SEARCH PREV NEXT PGUP PGDN	

The SDR33 screen provides you with a window to view a portion of the job database. Whenever you press <VIEW>, the SDR33 displays the end of the current job. Any work you have just completed is immediately visible. This level gives you an abridged description of each record in the database; you can see up to seven records on the screen at once. There is a more detailed view available where the information for a single record is displayed on an entire screen. We will discuss this view after learning how to search.

2. Move the highlighted cursor from one entry to another in the database using the <↑> and <↓> arrow keys. Pressing the gold <FUNC> <↑>

5: Viewing data

(or gold <FUNC> <↓>) to move up (or down) by one screen-height (i.e., seven lines).

5.2

Searching

To search for a particular point within the database, press the <SRCH> (for “search”) softkey. The following screen appears:



```
Pt [redacted]
Code <No text>

PREV NEXT
```


You can search for objects in the database by:

- specifying a point name (which would be typed into the “*Pt*” field of the above screen), **or**
- specifying a code (in the “*Code*” field).

If you specify both a point name **and** a code, the SDR33 will search for any records that match **either** the given point name **or** the given code. You can also search forwards or backwards in the database.

Follow these steps to complete an example search of the database:

1. Press the <SRCH> softkey.
2. Highlight the “*Code*” field of the above screen (using the <↓> key) and type . This activates the feature-code list, with the “*BLD*” code highlighted, as shown below:



```
TUTORIAL
>
Cd [redacted] b
Cd [redacted] BLD
Cd [redacted] NS
Cd [redacted] SM
Cd [redacted] STN
Cd [redacted] TREE

ADD DEL EDIT LISTS
```

3. Press **<ENTER>** to accept "BLD" and return to the searching screen.

```
Pt
Code
BLD
PREV NEXT
```

4. Press the **<OK>** key to start searching for the most recent record in the database that contained the code "BLD." (Since you were positioned at the end of the database, the search went backwards towards the beginning of the database by default).

Your screen should look like this with a position (**POS**) record for point 1017 highlighted.

```
POS      1015
POS      1016
POS      1017
Target ht 2.100
Note 86.000 94-11
Note      Dirn v
POS      1018
SRCH PREV NEXT PGUP PGDN
```

As mentioned above, you are now looking at an abridged view of records in the database.

Follow these steps to examine the details of each record:

1. Highlight the record in this abridged-view.
2. Press **<ENTER>** or the **<=>** key.

If you highlight the **Pos** record for point 1017, and press the **<=>** key, this screen appears:

```
POS      TP
Pt      1017
North    15030.549
East     10213.920
Elev     109.635
Cd       BLD
EDIT DBS MC RED
```

5: Viewing data



Note: The softkeys at the bottom of this inner “view” level constitute the SDR33’s powerful “data-view” mechanism, described in detail in Chapter 5 of the **SDR33 Reference Manual**.

This screen displays the coordinates of point 1017, which we observed in the previous (topography) tutorial. As you can see, the code we entered for point 1017 was “**BLD**,” so our search correctly located the point for us.

3. Press the <CLEAR> key to return to the “upper” view level.

5.3

Adding notes



Note: For users of SOKKIA Software, adding a note to the database just before the record for point 1017 is useful when you process the SDR33’s output through the Feature-code processing. Notes are inserted prior to the record selected for viewing.


Follow these steps to insert a note:

1. Press the <NOTE> key and type in the following:



BLD DIST P 1017 1018 R14 R5 R9 L6 R5 <ENTER>

This will be inserted as a “note” record just before the **POS** record for point 1017. This causes the automatic plotting of a building whose dimensions are contained in the notations you just typed.



POS	10150
POS	1016
Note	BLD DIST P 1016
POS	1017
Target ht	2.100
Note	86.000 94-11
Note	Dirn vll
<div> <div>Srch</div> <div>PREV</div> <div>NEXT</div> <div>PGUP</div> <div>PGDN</div> </div>	

2. Press **<CLEAR>** to return to the “Survey” menu.

5: Viewing data

This page was intentionally left blank.