

# — Ekinox AHRS & INS

Use in automotive applications

## Operating handbook



Document  
Revision

EKINOXOHAUTO.1.1  
1.1 - Nov 18, 2013

Support

support@sbg-systems.com  
+33 1 80 88 45 00

*This operating handbook aims to guide Ekinox users during sensor installation and configuration in automotive environments.*

*If carefully followed, those instructions will enable full Ekinox Device performance.*

*You don't need to use the sbgCenter to configure the products.*

## Mechanical installation

When used in automotive application, Ekinox performs some velocity assumptions: No lateral velocity is allowed and therefore, a good sensor installation is a key point to follow.

### Vibrations

Ekinox is designed to handle vibrations. Nevertheless in case of highly vibrating environment, or vibrations above 1kHz, an efficient mechanical vibration isolation is required for proper operation. Silicon dampers can be used for that purpose.

### Ekinox placement in the vehicle

The vehicle coordinate frame is defined as follows:

- X axis points to the front of the car
- Y axis points Rightward.
- Z axis points downward.


The Ekinox **MUST** be mechanically aligned with the vehicle coordinate frame, as explained in the following diagram.

**Alignment accuracy should be better than 1°.**

The main lever arm is the signed distance, expressed in the vehicle coordinate frame, **FROM** the Ekinox center of measurements **TO** the vehicle center of rotations.

The vehicle center of rotation is located on the rear axle for conventional cars.

The main lever arm must be measured within 5 cm accuracy.




**Note:** If a correct mechanical alignment is not possible, then a software alignment can be used. Please refer to the Ekinox User Manual for such operation.

## GPS Antenna placement

GPS antenna must be fixed with respect to the Ekinox. It should have a clear view of sky.

The GPS lever arm is the signed distance, expressed in the vehicle coordinate frame, from the Ekinox center of measurements, to the GPS antenna. It must be measured within 5cm accuracy.



In addition, this lever arm should be lower than 10m for best performance.

## Dual GPS antenna placement

Dual antenna systems installation will require special care in order to obtain optimal performance:

- Maximum separation between two antennas should not exceed 3 meters on Ekinox D. For external GPS receivers, please conform to Manufacturer guidelines
- Same antenna type, same cables with identical lengths must be used for both antennas. No signal splitter should be used.
- Both antennas must be mounted in the same orientation with respect to the car.
- Both antennas must have the same view of sky when mounted on the vehicle.

Once installed, the main GPS antenna lever arm must be measured. It is the signed distance, expressed in the vehicle coordinate frame, from the Ekinox center of measurements, to the main GPS antenna. It must be measured within 5cm accuracy. Then, the absolute distance between main and secondary antennas should be measured.


Finally, the alignment angle between the antennas and the vehicle coordinate frame must be accurately measured. The following diagram shows a typical installation, using a  $0^\circ$  angle offset, and another with a  $-90^\circ$  offset:



## Odometer placement

Odometer has to be placed on a **non steering wheel** (rear wheel in most applications).

The Odometer lever arm is the signed distance, expressed in the vehicle coordinate frame, from the Ekinox Center of measurements to the Odometer. It has to be measured with 5cm accuracy, and should be lower than 10m for best performance.



# Software configuration

All Ekinox configuration is done through the web interface.




**Note:** At the first access or if the device firmware has been updated, the Ekinox will cache the entire embedded website to optimize the responsiveness. This preload operation may take up to two minutes depending on your system configuration.

## Sensor

### *Motion profile*

Conventional vehicles should use the “Automotive” motion profile.



### Alignment and lever arm

Here you have to configure the device alignment in the vehicle and its lever arm in regard to the center of rotation of the car (rear axle).

On the alignment settings you only need to set up the first two axis, then the third one will be automatically computed.

Sensor

Aiding Assignment

Aiding Setting

Inputs/Outputs

Data Output

Advanced

Import/Export

Motion Profile

Alignment and lever arms

Initial Position and Date

Heave

Alignment

Enter device rough orientation in the vehicle

Enter misalignment angles

X Axis

Forward

Y Axis

Right

Z Axis

Down

Roll

0.000

Pitch

0.000

Yaw

0.000

Primary lever arm

Enter primary lever arm, from the IMU to the center of rotation

Center of rotation lever arm (X,Y,Z)

0.000

0.000

0.000

m

### Aiding Assignment

In automotive applications, conventional vehicles should avoid using magnetometers since there is usually a lot of disturbances.

You can enable one or two GPS on this panel and in case of Ekinox N, you can chose whether you want to use the internal GPS or not.

Sensor

Aiding Assignment

Aiding Setting

Inputs/Outputs

Data Output

Advanced

Device Settings

Aiding peripheral port assignment

Port

Sync

GPS 1

COM D

GPS 2

COM C

Magnetometer

Disabled

Odometer


COM E

Off

Off

You can enable or disable the odometer, if you have the opportunity to use one it may significantly improve the dead reckoning performance.

6/9

 SBG SYSTEMS

## Aiding settings

### GPS Configuration

The following panel provides GPS configuration:


The screenshot shows the 'Device Settings' window with the 'GPS 1' tab selected. The left sidebar contains a menu with options: Sensor, Aiding Assignment, Aiding Setting (highlighted), Inputs/Outputs, Data Output, Advanced, and Import/Export. The main panel is divided into sections: Basic Configuration, Main Antenna, True Heading, and Aiding Use and Rejection. The 'Basic Configuration' section has a 'Model' dropdown set to 'NMEA'. The 'Main Antenna' section has a 'Lever Arm (X,Y,Z)' field with three input boxes set to '0.000' and a unit 'm'. The 'True Heading' section has an 'Alignment offset (Pitch, Yaw)' field with two input boxes set to '0.000' and a unit '°', and a 'Distance between antennas' field with an input box set to '0.000' and a unit 'm'. The 'Aiding Use and Rejection' section has a note: 'You can force this device measurements to always be used, ignored or automatically verified when a false measurement is detected.' Below this, there are four dropdown menus: 'Position' (Auto rejection), 'Course' (Auto rejection), 'Velocity' (Auto rejection), and 'True Heading' (Auto rejection). At the bottom of the window, there are 'Default', 'Save', and 'Cancel' buttons.

Please check following point at the GPS configuration level:

1. Choose this parameter depending on the GPS you are using (NMEA or Novatel), you can refer to the corresponding manual to know how to configure the GPS.
2. Set up the lever arm of the GPS depending on its position on the car (GPS Antenna placement).
3. If two antennas are used you have to define here the distance between antennas and the antennas misalignment with respect to the vehicle coordinate frame.
4. Auto-rejection is advised for each parameter, it automatically detects the confidence so the Kalman filter knows it can rely more on a parameter or less on an other.

## Odometer configuration

If you are using an odometer and activated it in Aiding Assignments, you will see a thumbnail called “odometer” in the Aiding Settings panel.



1. Model of profile used for the odometer. Only one is available at this time, but more are coming in future. If you need a specific one, please contact the support team.
2. Define here the initial Odometer gain in pulses per meter. This parameter will be then automatically tuned by the Kalman filter to optimize the dead reckoning performance. Depending on your hardware configuration, the reverse mode can be use to reverse the velocity value in order to fit with an actual velocity direction. Initial gain error in percent should also be entered in this section: this defines how much the Kalman filter needs to estimate the Odometer's gain.
3. Set up here the Odometer lever arm depending on its position (Odometer placement).
4. Auto-rejection is advised so the Kalman filter determines the confidence of this parameter by itself.



# Operation

---

## Initialization

For applications with single antenna GPS receivers, the unit will be able to provide full navigation data once the platform has been moved at higher speed than 15 km/h.

Applications that use a dual antenna GPS system will start providing navigation data as soon as the GPS true heading data is available. For such systems, the unit should be started up in a clear view of sky environment to prevent bad initialization of the GPS true heading.

## Self-Calibration

Once the navigation data is initialized, the system will be functional, but will require about 15 minutes to provide full navigation performance. This is required to let the sensors warm up, and to let the Kalman filter self calibrate some parameters, such as GPS lever arm, or sensors bias.

During this phase, some motion is recommended to ensure proper calibration. A good way to do it is driving with left and right turns, accelerations, decelerations and so on. The following picture shows a typical successful calibration path:



# Support

---

If you have any trouble or question with the use of the Ekinox, feel free to contact our support team by email, at [support@sbg-systems.com](mailto:support@sbg-systems.com).