

53-1003637-01
31 March 2015

FastIron

Command Reference

Supporting FastIron Software Release 08.0.30

BROCADE 

© 2015, Brocade Communications Systems, Inc. All Rights Reserved.

ADX, Brocade, Brocade Assurance, the B-wing symbol, DCX, Fabric OS, HyperEdge, ICX, MLX, MyBrocade, OpenScript, The Effortless Network, VCS, VDX, Vplane, and Vyatta are registered trademarks, and Fabric Vision and vADX are trademarks of Brocade Communications Systems, Inc., in the United States and/or in other countries. Other brands, products, or service names mentioned may be trademarks of others.

Notice: This document is for informational purposes only and does not set forth any warranty, expressed or implied, concerning any equipment, equipment feature, or service offered or to be offered by Brocade. Brocade reserves the right to make changes to this document at any time, without notice, and assumes no responsibility for its use. This informational document describes features that may not be currently available. Contact a Brocade sales office for information on feature and product availability. Export of technical data contained in this document may require an export license from the United States government.

The authors and Brocade Communications Systems, Inc. assume no liability or responsibility to any person or entity with respect to the accuracy of this document or any loss, cost, liability, or damages arising from the information contained herein or the computer programs that accompany it.

The product described by this document may contain open source software covered by the GNU General Public License or other open source license agreements. To find out which open source software is included in Brocade products, view the licensing terms applicable to the open source software, and obtain a copy of the programming source code, please visit <http://www.brocade.com/support/oscd>.

Contents

Preface.....	13
Document conventions.....	13
Text formatting conventions.....	13
Command syntax conventions.....	13
Notes, cautions, and warnings.....	14
Brocade resources.....	15
Contacting Brocade Technical Support.....	15
Document feedback.....	16
 About This Document.....	 17
What's new in this document.....	17
Supported hardware and software.....	19
 Using the FastIron command-line interface.....	 21
Accessing the CLI.....	21
Command modes.....	21
Command help.....	22
Command completion.....	22
Scroll control.....	23
Line editing commands.....	24
Searching and filtering command output.....	24
Searching and filtering output at the --More-- prompt.....	24
Searching and filtering show command output.....	25
Creating an alias for a CLI command.....	29
Configuration notes for creating a command alias.....	29
Specifying stack-unit, slot number, and port number.....	30
Specifying a port on a modular device.....	30
Specifying a port on stackable devices.....	30
 Commands A - E.....	 31
aaa authorization coa enable.....	31
aaa authorization coa ignore	32
accept-mode.....	33
access-list enable accounting.....	34
address-family unicast (BGP).....	35
aggregate-address (BGP).....	36
alias.....	38
always-compare-med	39
always-propagate	40
anycast-rp.....	41
arp-internal-priority.....	43
as-path-ignore	44
authentication.....	45
authentication auth-default-vlan.....	46
authentication auth-order.....	47
authentication disable-aging.....	48
authentication dos-protection.....	49

authentication fail-action.....	50
authentication filter-strict-security.....	51
authentication max-sessions.....	52
authentication reauth-timeout.....	53
authentication source-guard-protection enable.....	54
authentication timeout-action.....	55
auth-default-vlan.....	56
auth-fail-action.....	57
auth-order dot1x mac-auth.....	58
auth-order mac-auth dot1x.....	59
auto-cost reference-bandwidth (OSPF).....	60
auto-cost reference-bandwidth (OSPFv3).....	61
bandwidth (interface).....	62
bgp-redistribute-internal	63
breakout ethernet.....	64
bsr-candidate.....	67
capability as4	69
clear access-list accounting.....	70
clear cable diagnostics tdr.....	71
clear dot1x sessions.....	72
clear dot1x statistics	73
clear dot1x-mka statistics.....	74
clear ip mroute.....	75
clear ip pim counters.....	76
clear ip pim hw-resource.....	77
clear ip pim rp-map.....	78
clear ip pimsm-snoop.....	79
clear ipv6 dhcp-relay delegated-prefixes.....	80
clear ipv6 dhcp-relay statistics.....	81
clear ipv6 mroute.....	82
clear ipv6 neighbor.....	83
clear ipv6 pim cache.....	84
clear ipv6 pim counters.....	85
clear ipv6 pim hw-resource.....	86
clear ipv6 pim rp-map.....	87
clear ipv6 pim traffic.....	88
clear ipv6 pimsm-snoop.....	89
clear ipv6 rguard	90
clear link-oam statistics.....	91
clear macsec ethernet	92
clear mac-authentication sessions.....	93
clear notification-mac statistics.....	94
clear openflow	95
clear stack ipc.....	96
clear statistics openflow	97
client-to-client-reflection	98
cluster-id	99
compare-routerid	100
confederation identifier.....	101
confederation peers.....	102
connect.....	103
copy disk0.....	104
copy flash disk0.....	105
copy flash scp.....	106
copy running-config disk0.....	108
copy running-config scp.....	109
copy scp flash.....	110
copy scp license.....	112

copy scp running-config.....	114
copy scp startup-config.....	116
copy startup-config disk0.....	117
copy startup-config scp.....	118
critical-vlan.....	119
dampening	120
default-information-originate (BGP).....	122
default-local-preference	123
default-metric (BGP).....	124
default-ports.....	125
disable-aging.....	126
disable authentication md5.....	127
distance (BGP).....	128
dlb-internal-trunk-hash.....	129
dot1x auth-filter.....	130
dot1x enable.....	131
dot1x guest-vlan.....	132
dot1x max-reauth-req	133
dot1x-mka-enable.....	134
dot1x timeout	135
eee.....	136
egress-buffer-profile.....	137
enable-accounting.....	138
enable-mka.....	139
enforce-first-as	140
errdisable packet-inerror-detect.....	141
errdisable recovery.....	142
ethernet (EFM-OAM).....	144
ethernet loopback.....	146
ethernet loopback (VLAN-aware).....	147
ethernet loopback test-mac.....	149

Commands F - J..... 151

failover.....	153
fast-external-falover	154
filter-strict-security enable.....	155
flash-timeout.....	156
flow-control.....	157
force-up ethernet.....	158
format disk0.....	159
graceful-restart (BGP).....	160
graft-retransmit-timer.....	162
hardware-drop-disable.....	163
hello-interval.....	164
hello-timer.....	165
hitless-failover enable.....	166
inactivity-timer.....	167
inline power	168
inline power install-firmware scp.....	171
interface tunnel	173
ip arp inspection validate.....	174
ip bootp-use-intf-ip.....	175
ip dhcp-client continuous-mode max-duration.....	176
ip dhcp-client discover-interval.....	177
ip dscp-remark	178
ip igmp group-membership-time.....	179
ip igmp max-response-time.....	180

ip igmp port-version.....	181
ip igmp proxy.....	182
ip igmp query-interval.....	183
ip igmp tracking.....	184
ip igmp version.....	185
ip max-mroute.....	186
ip mroute.....	187
ip mroute (next hop).....	188
ip mroute next-hop-enable-default.....	189
ip mroute next-hop-recursion.....	190
ip multicast.....	191
ip multicast age-interval.....	192
ip multicast disable-flooding.....	193
ip multicast leave-wait-time.....	194
ip multicast max-response-time.....	195
ip multicast mcache-age.....	196
ip multicast query-interval.....	197
ip multicast report-control.....	198
ip multicast verbose-off.....	199
ip multicast version.....	200
ip multicast-routing rpf-check mac-movement	201
ip multicast-nonstop-routing.....	202
ip pcp-remark	203
ip pim.....	204
ip pim border.....	205
ip pim dr-priority.....	206
ip pim neighbor-filter.....	207
ip pimsm-snooping.....	208
ip pim-sparse.....	209
ip ssh encryption disable-aes-cbc.....	210
ip ssl min-version.....	211
ipv6 dhcp-relay destination.....	212
ipv6 dhcp-relay distance.....	213
ipv6 dhcp-relay include-options.....	214
ipv6 dhcp-relay maximum-delegated-prefixes.....	215
ipv6 max-mroute.....	216
ipv6 mld group-membership-time.....	217
ipv6 mld llqi	218
ipv6 mld max-group-address.....	219
ipv6 mld max-response-time.....	220
ipv6 mld port-version.....	221
ipv6 mld query-interval.....	222
ipv6 mld robustness.....	223
ipv6 mld static-group.....	224
ipv6 mld tracking.....	225
ipv6 mroute.....	226
ipv6 mroute (next hop).....	227
ipv6 mroute next-hop-enable-default.....	228
ipv6 mroute next-hop-recursion.....	229
ipv6 multicast age-interval.....	230
ipv6 multicast disable-flooding.....	231
ipv6 multicast leave-wait-time.....	232
ipv6 multicast mcache-age.....	233
ipv6 multicast query-interval.....	234
ipv6 multicast report-control.....	235
ipv6 multicast verbose-off.....	236
ipv6 multicast version.....	237
ipv6 multicast-boundary.....	238

ipv6 multicast-routing rpf-check mac-movement	239
ipv6 nd router-preference.....	240
ipv6 nd skip-interface-ra.....	241
ipv6 neighbor inspection.....	242
ipv6 neighbor inspection vlan.....	243
ipv6 pim border.....	244
ipv6 pim dr-priority.....	245
ipv6 pim neighbor-filter.....	246
ipv6 pim-sparse.....	247
ipv6 rguard policy	248
ipv6 rguard vlan	249
ipv6 rguard whitelist	250
ipv6 router pim.....	251
ipv6-address auto-gen-link-local.....	252
ipv6-neighbor inspection trust.....	253
jtc enable.....	254
jtc show.....	255

Commands K - S.....257

key-server-priority.....	258
link-oam.....	259
local-as	260
logging	261
logging cli-command.....	262
loop-detection shutdown-disable	263
loop-detection-syslog-interval	264
mac filter enable-accounting.....	265
mac-auth auth-filter.....	266
mac-auth dot1x-override.....	267
mac-auth enable.....	268
mac-auth password-format	269
mac-auth password-override.....	270
mac-notification interval	271
macsec cipher-suite.....	272
macsec confidentiality-offset.....	273
macsec frame-validation.....	274
macsec replay-protection.....	275
match ipv6 address	276
max-hw-age.....	277
maximum-paths	278
maximum-paths ebgp ibgp	279
maximum-preference	281
max-mcache.....	282
max-sw-age.....	283
med-missing-as-worst	284
mesh-group.....	285
message-interval.....	286
mka-cfg-group	287
mount disk0.....	289
mstp instance.....	290
mstp scope.....	291
multicast disable-pism-snoop.....	292
multicast fast-convergence.....	293
multicast fast-leave-v2.....	294
multicast pism-snooping prune-wait.....	295
multicast port-version.....	296
multicast proxy-off.....	297

multicast router-port.....	298
multicast static-group.....	299
multicast tracking.....	300
multicast version.....	301
multicast6 disable-mld-snoop.....	302
multicast6 disable-pimsm-snoop.....	303
multicast6 fast-convergence.....	304
multicast6 port-version.....	305
multicast6 proxy-off.....	306
multicast6 router-port.....	307
multicast6 static-group.....	308
multicast6 tracking.....	309
multicast6 version.....	310
multipath	311
nbr-timeout.....	313
neighbor activate.....	314
neighbor advertisement-interval	315
neighbor allowas-in	316
neighbor as-override	317
neighbor capability as4	318
neighbor capability orf prefixlist.....	319
neighbor default-originate	320
neighbor description	321
neighbor ebgp-btsh	322
neighbor ebgp-multihop	323
neighbor enforce-first-as	324
neighbor filter-list	325
neighbor local-as	326
neighbor maxas-limit in	327
neighbor maximum-prefix	328
neighbor next-hop-self	329
neighbor password	330
neighbor peer-group	331
neighbor prefix-list	332
neighbor remote-as	333
neighbor remove-private-as.....	334
neighbor route-map	335
neighbor route-reflector-client	336
neighbor send-community	337
neighbor shutdown	338
neighbor soft-reconfiguration inbound	339
neighbor timers	340
neighbor update-source	341
neighbor weight	342
network	343
next-hop-enable-default	344
next-hop-recursion	345
openflow enable	346
openflow purge-time.....	347
originator-id.....	348
packet-inerror-detect.....	349
pass-through.....	350
pdu-rate (EFM-OAM).....	351
phy cable diagnostics tdr.....	352
port-statistics-reset-timestamp enable.....	353
prefix-list	354
pre-shared-key.....	355
priority.....	356

priority-flow-control.....	357
priority-flow-control enable.....	358
prune-timer.....	359
prune-wait.....	360
qos egress-buffer-profile.....	361
qos ingress-buffer-profile.....	363
qos priority-to-pg.....	365
qos scheduler-profile.....	367
qos-internal-trunk-queue	370
radius-client coa host.....	372
radius-client coa port	373
raguard	374
redistribute (BGP).....	375
redistribute ospf.....	377
register-probe-time.....	378
register-suppress-time.....	379
remote-loopback.....	380
restricted-vlan.....	381
reverse-path-check.....	382
route-precedence.....	383
route-precedence admin-distance.....	385
router bgp	386
router msdp.....	387
router pim.....	388
rpf-mode.....	389
rp-address.....	390
rp-adv-interval.....	391
rp-candidate.....	392
rp-embedded.....	394
scheduler-profile.....	395
set ip next-hop.....	396
sflow sample-mode.....	397
sflow source.....	398
system-max max-ecmp.....	399
Show Commands.....	401
show cable-diagnostics tdr.....	401
show cpu.....	402
show cpu histogram.....	404
show default values.....	409
show dlb-internal-trunk-hash.....	410
show dot1x ip-acl.....	411
show dot1x mac-filter.....	412
show dot1x sessions.....	413
show dot1x statistics.....	415
show dot1x-mka config.....	417
show dot1x-mka config-group.....	419
show dot1x-mka sessions.....	421
show dot1x-mka statistics.....	424
show eee-statistics	425
show eee-statistics ethernet.....	427
show ethernet loopback interfaces.....	428
show ethernet loopback resources.....	430
show files disk0.....	431
show breakout.....	432
show interfaces ethernet.....	433
show interfaces tunnel.....	435

show interfaces ve.....	437
show interfaces lag.....	438
show interfaces stack-ports.....	440
show ip mroute.....	442
show ip msdp mesh-group.....	444
show ip multicast group.....	446
show ip multicast mcache.....	448
show ip multicast optimization	450
show ip multicast pimsm-snooping.....	451
show ip multicast vlan.....	452
show ip ospf interface	457
show ip pim interface.....	461
show ip pim mcache.....	462
show ip pim traffic.....	468
show ip pimsm-snooping cache.....	471
show ip reverse-path-check.....	473
show ip reverse-path-check interface.....	474
show ip ssl.....	475
show ip static mroute.....	476
show ipv6 dhcp-relay.....	477
show ipv6 dhcp-relay delegated-prefixes.....	478
show ipv6 dhcp-relay destinations.....	479
show ipv6 dhcp-relay interface.....	480
show ipv6 dhcp-relay options.....	481
show ipv6 dhcp-relay prefix-delegation-information.....	482
show ipv6 mroute.....	483
show ipv6 multicast mcache.....	484
show ipv6 multicast group.....	485
show ipv6 multicast mcache.....	487
show ipv6 multicast optimization	488
show ipv6 multicast pimsm-snooping.....	489
show ipv6 multicast vlan.....	490
show ipv6 ospf interface	492
show ipv6 neighbor	496
show ipv6 pim interface.....	499
show ipv6 pim traffic.....	500
show ipv6 pimsm-snooping cache.....	502
show ipv6 static mroute.....	504
show link-oam info.....	505
show link-oam statistics.....	509
show loop-detect no-shutdown-status.....	513
show mac-auth configuration.....	514
show mac-auth ip-acl.....	517
show mac-auth sessions.....	518
show mac-auth statistics.....	519
show macsec statistics ethernet.....	520
show memory.....	524
show memory task.....	526
show notification-mac.....	527
show openflow.....	528
show openflow controller.....	530
show openflow flows.....	531
show openflow groups.....	532
show openflow interfaces.....	533
show openflow meters.....	535
show packet-inerror-detect.....	537
show power-savings-statistics.....	538
show priority-flow-control.....	540

show qos egress-buffer-profile.....	541
show qos ingress-buffer-profile.....	542
show qos-internal-trunk-queue.....	543
show qos priority-to-pg.....	544
show qos-profiles.....	546
show qos scheduler-profile.....	547
show rmon.....	549
show running interface.....	554
show running-config interface ethernet	555
show running-config interface tunnel	556
show running-config interface ve	557
show span designated-protect.....	558
show stack.....	559
show stack connection.....	561
show stack detail.....	562
show stack failover.....	564
show stack flash.....	565
show stack link-sync.....	566
show stack neighbors.....	567
show stack rel-ipc stats	568
show stack resource.....	575
show stack stack-ports.....	576
show statistics l2-tunnel	578
show statistics stack-ports.....	579
show version.....	580

Commands Sn - Z.....583

snmp-server enable traps mac-notification	583
snmp-server group.....	584
spanning-tree designated-protect.....	586
stack disable.....	587
stack enable.....	588
stack mac.....	589
stack-port.....	590
stack secure-setup.....	591
stack stack-port-resiliency.....	592
stack suggested-id.....	594
stack suppress-warning.....	595
stack switch-over.....	596
stack-trunk.....	597
stack unconfigure.....	598
store-and-forward.....	601
symmetrical-flow-control enable.....	602
system-max igmp-snoop-group-addr.....	603
system-max igmp-snoop-mcache.....	604
system-max mac-notification-buffer.....	605
system-max max-ecmp.....	606
system-max mld-snoop-group-addr.....	607
system-max mld-snoop-mcache.....	608
table-map	609
timers (BGP).....	611
timeout (EFM-OAM).....	612
traffic-policy count.....	613
traffic-policy rate-limit adaptive.....	614
traffic-policy rate-limit fixed.....	616
tunnel destination	618
tunnel mode gre ip	619

tunnel source	620
unmount disk0.....	621
update-lag-name.....	622
update-time (BGP).....	623
use-v2-checksum.....	624
version.....	625
vxlan vlan.....	626

Preface

- [Document conventions.....](#) 13
- [Brocade resources.....](#) 15
- [Contacting Brocade Technical Support.....](#) 15
- [Document feedback.....](#) 16

Document conventions

The document conventions describe text formatting conventions, command syntax conventions, and important notice formats used in Brocade technical documentation.

Text formatting conventions

Text formatting conventions such as boldface, italic, or Courier font may be used in the flow of the text to highlight specific words or phrases.

Format	Description
bold text	Identifies command names
	Identifies keywords and operands
	Identifies the names of user-manipulated GUI elements
	Identifies text to enter at the GUI
<i>italic text</i>	Identifies emphasis
	Identifies variables
	Identifies document titles
<code>Courier font</code>	Identifies CLI output
	Identifies command syntax examples

Command syntax conventions

Bold and italic text identify command syntax components. Delimiters and operators define groupings of parameters and their logical relationships.

Convention	Description
bold text	Identifies command names, keywords, and command options.
<i>italic text</i>	Identifies a variable.
value	In Fibre Channel products, a fixed value provided as input to a command option is printed in plain text, for example, --show WWN.

Convention	Description
[]	Syntax components displayed within square brackets are optional. Default responses to system prompts are enclosed in square brackets.
{ x y z }	A choice of required parameters is enclosed in curly brackets separated by vertical bars. You must select one of the options. In Fibre Channel products, square brackets may be used instead for this purpose.
x y	A vertical bar separates mutually exclusive elements.
< >	Nonprinting characters, for example, passwords, are enclosed in angle brackets.
...	Repeat the previous element, for example, <i>member[member...]</i> .
\	Indicates a “soft” line break in command examples. If a backslash separates two lines of a command input, enter the entire command at the prompt without the backslash.

Notes, cautions, and warnings

Notes, cautions, and warning statements may be used in this document. They are listed in the order of increasing severity of potential hazards.

NOTE

A Note provides a tip, guidance, or advice, emphasizes important information, or provides a reference to related information.

ATTENTION

An Attention statement indicates a stronger note, for example, to alert you when traffic might be interrupted or the device might reboot.



CAUTION

A Caution statement alerts you to situations that can be potentially hazardous to you or cause damage to hardware, firmware, software, or data.



DANGER

A Danger statement indicates conditions or situations that can be potentially lethal or extremely hazardous to you. Safety labels are also attached directly to products to warn of these conditions or situations.

Brocade resources

Visit the Brocade website to locate related documentation for your product and additional Brocade resources.

You can download additional publications supporting your product at www.brocade.com. Select the Brocade Products tab to locate your product, then click the Brocade product name or image to open the individual product page. The user manuals are available in the resources module at the bottom of the page under the Documentation category.

To get up-to-the-minute information on Brocade products and resources, go to [MyBrocade](#). You can register at no cost to obtain a user ID and password.

Release notes are available on [MyBrocade](#) under Product Downloads.

White papers, online demonstrations, and data sheets are available through the [Brocade website](#).

Contacting Brocade Technical Support

As a Brocade customer, you can contact Brocade Technical Support 24x7 online, by telephone, or by e-mail. Brocade OEM customers contact their OEM/Solutions provider.

Brocade customers

For product support information and the latest information on contacting the Technical Assistance Center, go to <http://www.brocade.com/services-support/index.html>.

If you have purchased Brocade product support directly from Brocade, use one of the following methods to contact the Brocade Technical Assistance Center 24x7.

Online	Telephone	E-mail
<p>Preferred method of contact for non-urgent issues:</p> <ul style="list-style-type: none"> • My Cases through MyBrocade • Software downloads and licensing tools • Knowledge Base 	<p>Required for Sev 1-Critical and Sev 2-High issues:</p> <ul style="list-style-type: none"> • Continental US: 1-800-752-8061 • Europe, Middle East, Africa, and Asia Pacific: +800-AT FIBREE (+800 28 34 27 33) • For areas unable to access toll free number: +1-408-333-6061 • Toll-free numbers are available in many countries. 	<p>support@brocade.com</p> <p>Please include:</p> <ul style="list-style-type: none"> • Problem summary • Serial number • Installation details • Environment description

Brocade OEM customers

If you have purchased Brocade product support from a Brocade OEM/Solution Provider, contact your OEM/Solution Provider for all of your product support needs.

- OEM/Solution Providers are trained and certified by Brocade to support Brocade® products.
- Brocade provides backline support for issues that cannot be resolved by the OEM/Solution Provider.

- Brocade Supplemental Support augments your existing OEM support contract, providing direct access to Brocade expertise. For more information, contact Brocade or your OEM.
- For questions regarding service levels and response times, contact your OEM/Solution Provider.

Document feedback

To send feedback and report errors in the documentation you can use the feedback form posted with the document or you can e-mail the documentation team.

Quality is our first concern at Brocade and we have made every effort to ensure the accuracy and completeness of this document. However, if you find an error or an omission, or you think that a topic needs further development, we want to hear from you. You can provide feedback in two ways:

- Through the online feedback form in the HTML documents posted on www.brocade.com.
- By sending your feedback to documentation@brocade.com.

Provide the publication title, part number, and as much detail as possible, including the topic heading and page number if applicable, as well as your suggestions for improvement.

About This Document

- [What's new in this document.....17](#)
- [Supported hardware and software.....19](#)

What's new in this document

Information has been added or updated to reflect new FastIron features and enhancements to existing FastIron features.

For commands introduced since Release 08.0.01, a history table provides information on modifications to the command. For commands introduced prior to Release 08.0.01, a history table is not provided, unless the command has been modified in recent releases.

The lists of the new, modified, and deprecated commands, see:

New commands

The following commands have been added (new for this release).

- **auto-cost reference-bandwidth (OSPF)**
- **auto-cost reference-bandwidth (OSPFv3)**
- **bandwidth (interface)**
- **breakout ethernet**
- **clear ipv6 dhcp-relay delegated-prefixes**
- **clear ipv6 dhcp-relay statistics**
- **clear link-oam**
- **copy disk0**
- **copy flash disk0**
- **copy running-config disk0**
- **copy startup-config disk0**
- **eee**
- **errdisable recovery**
- **ethernet (EFM-OAM)**
- **ethernet loopback**
- **ethernet loopback (VLAN-aware)**
- **ethernet loopback test-mac**
- **flash-timeout**
- **interface tunnel**
- **ip dhcp-client continuous-mode max-duration**
- **ip dhcp-client discover-interval**
- **ipv6 dhcp-relay destination**
- **ipv6 dhcp-relay distance**
- **ipv6 dhcp-relay include-options**
- **ipv6 dhcp-relay maximum-delegated-prefixes**
- **link-oam**
- **openflow purge-time**

- pdu-rate (EFM-OAM)
- port-statistics-reset-timestamp enable
- remote-loopback
- reverse-path-check
- rpf-mode
- set ip next-hop
- sflow sample-mode
- sflow source
- show cpu
- show cpu histogram
- show eee-statistics
- show eee-statistics Ethernet
- show ethernet loopback interfaces
- show ethernet loopback resources
- show files disk0
- show interface breakout
- show interfaces lag
- show interface ve
- show interface tunnel
- show ip ospf interface
- show ip reverse-path-check
- show ip reverse-path-check interface
- show ipv6 dhcp-relay
- show ipv6 dhcp-relay delegated-prefixes
- show ipv6 dhcp-relay destinations
- show ipv6 dhcp-relay interface
- show ipv6 dhcp-relay options
- show ipv6 dhcp-relay prefix-delegation-information
- show ipv6 ospf interface
- show link-oam info
- show link-oam statistics
- show memory
- show memory task
- show power-savings-statistics
- show running-config interface ethernet
- show running-config interface tunnel
- show running-config interface ve
- system-max max-ecmp
- timeout (EFM-OAM)
- tunnel destination
- tunnel mode
- tunnel source
- update-lag-name

Modified commands

The following commands have been modified in this release.

- ip multicast disable-flooding
- ipv6 multicast disable-flooding
- mac-auth password-format

- **show interfaces ethernet**
- **show ip multicast vlan**
- **show ip pim mcache**
- **show ipv6 multicast vlan**
- **show version**

Deprecated commands

The following commands have been removed (they have been deprecated).

- **authentication voice-timeout-action**

Supported hardware and software

This guide supports the following product families for FastIron release 08.0.30:

- FCX Series
- FastIron X Series (FSX 800 and FSX 1600)
- ICX 6610 Series
- ICX 6430 Series (ICX 6430, ICX 6430-C12)
- ICX 6450 Series (ICX 6450, ICX 6450-C12-PD)
- ICX 6650 Series
- ICX 7250 Series
- ICX 7450 Series
- ICX 7750 Series

NOTE

The Brocade ICX 6430-C switch supports the same feature set as the Brocade ICX 6430 switch unless otherwise noted.

NOTE

The Brocade ICX 6450-C12-PD switch supports the same feature set as the Brocade ICX 6450 switch unless otherwise noted.

For information about the specific models and modules supported in a product family, refer to the hardware installation guide for that product family.

Using the FastIron command-line interface

• Accessing the CLI.....	21
• Searching and filtering command output.....	24
• Creating an alias for a CLI command.....	29
• Specifying stack-unit, slot number, and port number.....	30

Accessing the CLI

Once an IP address is assigned to a Brocade device running Layer 2 software or to an interface on the Brocade device running Layer 3 software, you can access the CLI either through a direct serial connection or through a local or remote Telnet session.

You can initiate a local Telnet or SNMP or SSH connection by attaching a cable to a port and specifying the assigned management station IP address.

Command modes

The FastIron CLI uses an industry-standard hierarchical shell familiar to Ethernet/IP networking administrators. You can use one of three major command modes to enter commands and access sub-configuration modes on the device.

User EXEC mode

User EXEC mode is the default mode for the device; it supports the lowest level of user permissions. In this mode, you can execute basic commands such as **ping** and **traceroute**, but only a subset of clear, show, and debug commands can be entered in this mode. The following example shows the User EXEC prompt after login. The **enable** command enters privileged EXEC mode.

```
device> enable
device#
```

Privileged EXEC mode

Privileged EXEC mode supports all clear, show, and debug commands. In addition, you can enter some configuration commands that do not make changes to the system configuration. The following example shows the privileged EXEC prompt. At this prompt, you issue the **configure terminal** command to enter global configuration mode.

```
device# configure terminal
device(config)#
```

Global configuration mode

Global configuration mode supports commands that can change the device configuration. For any changes to be persistent, you must save the system configuration before rebooting the device. The global configuration mode provides access to sub-configuration modes for individual interfaces, VLANs,

routing protocols, and other configuration areas. The following example shows how you access the interface sub-configuration mode by issuing the **interface** command with a specified interface.

```
device(config)# interface ethernet 1/1/1
device(config-if-e1000-1/1/1)#
```

Command help

You can display commands and syntax information in any mode and from any point in the command hierarchy.

Enter a question mark (?) or a tab in any command mode to display the list of commands available in that mode.

```
device(config)#?
aaa                Define authentication method list
access-list        Define Access Control List (ACL)
aggregated-vlan    Support for larger Ethernet frames up to 1536 bytes
alias              Configure alias or display configured alias
all-client         Restrict all remote management to a host
arp                Enter a static IP ARP entry
arp-internal-priority Set packet priority
arp-subnet-only    Only learn ARP in the subnet of this device
authentication     Configure flexible authentication
banner             Define a login banner
batch              Define a group of commands
boot              Set system boot options
(output truncated)
```

To display a list of commands that start with a specified character, type the character followed by a question mark (?) or a tab.

```
device(config)#e ?
ICX6450-48P Switch(config)#e
enable            Password, page-mode and other options
end               End Configuration level and go to Privileged level
errdisable        Set Error Disable Attributions
exit              Exit current level
extern-config-file Extern configuration file
```

To display keywords and arguments associated with a command, enter the command followed by a question mark (?) or a tab.

```
deviceh(config)#qos ?
egress-buffer-profile User defined QoS egress profile
mechanism              Change mechanism
name                   Change name
profile                Change bandwidth allocation
scheduler-profile      User defined QoS profile
tagged-priority         Change tagged frame priority to profile mapping
```

Command completion

Command completion allows you to execute a command by entering a partial string.

NOTE

Command completion is not supported in the boot loader prompt of ICX 6430 and the ICX 6450 devices.

To complete the spelling of commands or keywords automatically, begin typing the command or keyword and then press Tab. For example, at the CLI command prompt, type `te` and press Tab. For

example, entering **conf t** in privileged EXEC mode auto-completes the keyword and executes the **configure terminal** as shown.

```
device#conf t
    terminal    Configure thru terminal
device#conf terminal
device(config)#
```

If there is more than one command or keyword associated with the characters typed, the CLI displays all choices matching the characters. Type another character to identify the keyword you are looking for.

```
device(config)#show li
    license                Show software license information
    link-error-disable     Link Debouncing Control
    link-keepalive         Link Layer Keepalive
device(config)#show lic
    license                Show software license information
device(config)#show license
```

If you enter an invalid command or partial string that cannot be completed, an error message is displayed.

```
device(config)#shw
Unrecognized command
device(config)#shw
```

Scroll control

By default, the CLI uses a page mode to paginate displays that are longer than 23 lines. The maximum number of lines per page is 23 (line 24 is reserved for printing). Displays that are longer than 23 lines are automatically segmented into pages with 23 lines per page.

If you use the question mark (?) to display a listing of available options in a given mode, the display stops at each 23 line increment and lists your choices for continuing the display.

```
aaa
all-client
appletalk
arp
boot
some lines omitted for brevity...

ipx
lock-address
logging
mac
--More--, next page: Space, next line:
Return key, quit: Control-c
```

Use one of the following scrolling options to display additional information:

- Press the **Space bar** to display the next page (one screen at a time).
- Press the **Return** or **Enter** key to display the next line (one line at a time).
- Press **Ctrl+C** or **Ctrl+Q** to cancel the display.
- Use the **skip** command in privileged EXEC mode to disable page display mode. Use the **page** command to re-enable page display mode

The following example toggles between page display modes.

```
Brocade#skip
Disable page display mode
Brocade#page
Enable page display mode
```

Line editing commands

The CLI supports the following line editing commands. To enter a line-editing command, use the CTRL+key combination for the command by pressing and holding the CTRL key, then pressing the letter associated with the command.

TABLE 1 CLI line editing commands

Ctrl+Key combination	Description
Ctrl+A	Moves to the first character on the command line.
Ctrl+B	Moves the cursor back one character.
Ctrl+C	Escapes and terminates command prompts and ongoing tasks (such as lengthy displays), and displays a fresh command prompt.
Ctrl+D	Deletes the character at the cursor.
Ctrl+E	Moves to the end of the current command line.
Ctrl+F	Moves the cursor forward one character.
Ctrl+K	Deletes all characters from the cursor to the end of the command line.
Ctrl+L; Ctrl+R	Repeats the current command line on a new line.
Ctrl+N	Enters the next command line in the history buffer.
Ctrl+P	Enters the previous command line in the history buffer.
Ctrl+U; Ctrl+X	Deletes all characters from the cursor to the beginning of the command line.
Ctrl+W	Deletes the last word you typed.
Ctrl+Z	Moves from any CONFIG level of the CLI to the Privileged EXEC level; at the Privileged EXEC level, moves to the User EXEC level.

Searching and filtering command output

You can filter the output from **show** commands at the --More-- prompt. You can search for characters strings, or you can construct complex regular expressions to filter the output.

Searching and filtering output at the --More-- prompt

The --More-- prompt displays when output extends beyond a single page. At this prompt, you can press the Space bar to display the next page, the Return or Enter key to display the next line, or Ctrl+C or Q to cancel the display. In addition, you can search and filter output from this prompt.

At the `--More--` prompt, enter a forward slash (/) followed by a search string. The Brocade device displays output starting from the first line that contains the search string as shown in the following example. The search feature is similar to the **begin** option for **show** commands.

```
--More--, next page: Space, next line: Return key, quit: Control-c
/telnet
```

The results of the search are displayed.

```
searching...
telnet           Telnet by name or IP address
temperature      temperature sensor commands
terminal         display syslog
tracert          TraceRoute to IP node
undeb            Disable debugging functions (see also 'debug')
undelete         Undelete flash card files
whois            WHOIS lookup
write            Write running configuration to flash or terminal
```

To display lines containing only a specified search string (similar) press the plus key (+) at the `--More--` prompt followed by a search string. This option is similar to the **include** option supported with **show** commands.

```
--More--, next page: Space, next line: Return key, quit: Control-c
+telnet
```

The filtered results are displayed.

```
filtering...
telnet           Telnet by name or IP address
```

To display lines that do not contain a specified search string, press the minus key (-) at the `--More--` prompt followed by a search string. This option is similar to the **exclude** option supported with **show** commands.

```
--More--, next page: Space, next line: Return key, quit: Control-c
-telnet
```

The filtered results are displayed.

```
filtering...
temperature      temperature sensor commands
terminal         display syslog
tracert          TraceRoute to IP node
undeb            Disable debugging functions (see also 'debug')
undelete         Undelete flash card files
whois            WHOIS lookup
write            Write running configuration to flash or terminal
```

As with the commands for filtering output from **show** commands, the search string is a regular expression consisting of a single character or string of characters. You can use special characters to construct complex regular expressions. See the next section for information on special characters used with regular expressions.

Searching and filtering show command output

You can filter output from **show** commands to display lines containing a specified string, lines that do not contain a specified string, or output starting with a line containing a specified string. The search string is a regular expression consisting of a single character or a string of characters. You can use special characters to construct complex regular expressions.

Using special characters to construct complex regular expressions

Special characters allow you to construct complex regular expressions to filter output from **show** commands. You can use a regular expression to specify a single character or multiple characters as a search string. In addition, you can include special characters that influence the way the software matches the output against the search string. Supported special characters are listed in the following table.

TABLE 2 Special characters for regular expressions

Character	Operation
.	<p>The period matches on any single character, including a blank space.</p> <p>For example, the following regular expression matches "aaz", "abz", "acz", and so on, but not just "az":</p> <p>a.z</p>
*	<p>The asterisk matches on zero or more sequential instances of a pattern.</p> <p>For example, the following regular expression matches output that contains the string "abc", followed by zero or more Xs:</p> <p>abcX*</p>
+	<p>The plus sign matches on one or more sequential instances of a pattern.</p> <p>For example, the following regular expression matches output that contains "de", followed by a sequence of "g"s, such as "deg", "degg", "deggg", and so on:</p> <p>deg+</p>
?	<p>The question mark matches on zero occurrences or one occurrence of a pattern.</p> <p>For example, the following regular expression matches output that contains "dg" or "deg":</p> <p>de?g</p>
<p>NOTE</p> <p>Normally when you type a question mark, the CLI lists the commands or options at that CLI level that begin with the character or string you entered. However, if you enter Ctrl+V and then type a question mark, the question mark is inserted into the command line, allowing you to use it as part of a regular expression.</p>	
^	<p>A caret (when not used within brackets) matches on the beginning of an input string.</p> <p>For example, the following regular expression matches output that begins with "deg":</p> <p>^deg</p>
\$	<p>A dollar sign matches on the end of an input string.</p> <p>For example, the following regular expression matches output that ends with "deg":</p> <p>deg\$</p>

TABLE 2 Special characters for regular expressions (Continued)

Character	Operation
<code>_</code>	<p>An underscore matches on one or more of the following:</p> <ul style="list-style-type: none"> • <code>,</code> (comma) • <code>{</code> (left curly brace) • <code>}</code> (right curly brace) • <code>(</code> (left parenthesis) • <code>)</code> (right parenthesis) • The beginning of the input string • The end of the input string • A blank space <p>For example, the following regular expression matches on "100" but not on "1002", "2100", and so on.</p> <p><code>_100_</code></p>
<code>[]</code>	<p>Square brackets enclose a range of single-character patterns.</p> <p>For example, the following regular expression matches output that contains "1", "2", "3", "4", or "5":</p> <p><code>[1-5]</code></p> <p>You can use the following expression symbols within the brackets. These symbols are allowed only inside the brackets.</p> <ul style="list-style-type: none"> • <code>^</code> - The caret matches on any characters except the ones in the brackets. For example, the following regular expression matches output that does not contain "1", "2", "3", "4", or "5": <code>^[1-5]</code> • <code>-</code> - The hyphen separates the beginning and ending of a range of characters. A match occurs if any of the characters within the range is present. See the example above.
<code> </code>	<p>A vertical bar separates two alternative values or sets of values. The output can match one or the other value.</p> <p>For example, the following regular expression matches output that contains either "abc" or "defg":</p> <p><code>abc defg</code></p>
<code>()</code>	<p>Parentheses allow you to create complex expressions.</p> <p>For example, the following complex expression matches on "abc", "abcabc", or "defg", but not on "abcdefgdefg":</p> <p><code>((abc)+)((defg)?)</code></p>

If you want to filter for a special character instead of using the special character as described in the table above, enter a backslash (`\`) before the character. For example, to filter on output containing an asterisk, enter the asterisk portion of the regular expression as `"*"`.

```
device#show ip route bgp | include \*
```

Displaying lines containing a specified string

The following command filters the output of the **show interface** command for port 3/11 to display only lines containing the word "Internet". This command can be used to display the IP address of the interface.

```
device#show interface e 3/11 | include Internet
Internet address is 10.168.1.11/24, MTU 1518 bytes, encapsulation ethernet
```

Syntax: *show-command* | **include** *regular-expression*

NOTE

The vertical bar (|) is part of the command.

Note that the regular expression specified as the search string is case sensitive. In the example above, a search string of "Internet" would match the line containing the IP address, but a search string of "internet" would not.

Displaying lines that do not contain a specified string

The following command filters the output of the **show who** command to display only the lines that do not contain the word "closed". This command can be used to display open connections to the Brocade device.

```
device#show who | exclude closed
Console connections:
    established
    you are connecting to this session
    2 seconds in idle
Telnet connections (inbound):
    1    established, client ip address 10.168.9.37
        27 seconds in idle
Telnet connection (outbound):
SSH connections:
```

Syntax: *show-command* | **exclude** *regular-expression*

Displaying lines starting with a specified string

The following command filters the output of the **show who** command to display output starting with the first line that contains the word "SSH". This command can be used to display information about SSH connections to the Brocade device.

```
device#show who | begin SSH
SSH connections:
1    established, client ip address 10.168.9.210
    7 seconds in idle
2    closed
3    closed
4    closed
5    closed
```

Syntax: *show-command* | **begin** *regular-expression*

Creating an alias for a CLI command

An alias serves as a shorthand version of a longer CLI command. For example, you can create an alias called *shoro* for the **show ip route** command. You can then enter the *shoro* alias at the command prompt and the **show ip route** command is issued.

To create an alias called *shoro* for the CLI command **show ip route**, enter the **alias shoro = show ip route** command.

```
device(config)# alias shoro = show ip route
```

Syntax: **[no] alias** *alias-name* = *cli-command*

The *alias-name* must be a single word, without spaces.

After the alias is configured, entering *shoro* in the privileged EXEC mode or in the global configuration mode issues the **show ip route** command.

Enter the command **copy running-config** with the appropriate parameters to create an alias called *wrsbc*.

```
device(config)#alias wrsbc = copy running-config tftp 10.10.10.10 test.cfg
```

To remove the *wrsbc* alias from the configuration, enter one of the following commands.

```
device(config)#no alias wrsbc
```

or

```
device(config)#unalias wrsbc
```

Syntax: **unalias** *alias-name*

The specified *alias-name* must be the name of an alias already configured on the Brocade device.

To display the aliases currently configured on the Brocade device, enter the following command in the Privileged EXEC mode or in the global configuration mode.

```
device# alias
      wrsbc      copy running-config tftp 10.10.10.10 test.cfg
      shoro      show ip route
```

Syntax: **alias**

Configuration notes for creating a command alias

The following configuration notes apply to this feature:

- You cannot include additional parameters with the alias at the command prompt. For example, after you create the *shoro* alias, *shoro bgp* would not be a valid command.
- If configured on the Brocade device, authentication, authorization, and accounting is performed on the actual command, not on the alias for the command.
- To save an alias definition to the startup-config file, use the **write memory** command.

Specifying stack-unit, slot number, and port number

Many CLI commands require users to enter port numbers as part of the command syntax, and many **show** command outputs display port numbers. Port numbers are entered and displayed in one of the following formats:

- port number only
- slot number and port number
- stack-unit, slot number, and port number

Not all formats are supported on all devices. To identify a port, refer to the labels on the front panel of the device.

Specifying a port on a modular device

On modular devices such as the FSX 800 and FSX 1600, you must specify the port number in the following format when you issue a command that requires a port parameter: *slot/port*.

The following example enters the ethernet interface sub-configuration mode for the first port on a modular device.

```
device(config)#interface e 1/1
device(config-if-1/1)#
```

Specifying a port on stackable devices

On stackable devices (FCX and ICX) you must specify the port in the following format when you issue a command that requires a port parameter: *stack-unit /slot/port*.

The following example enters the ethernet interface sub-configuration mode for the first port on a stackable device.

```
device(config)#interface e 1/1/1
device(config-if-e1000-1/1/1)#
```

Refer to "Brocade Stackable Devices" in the *FastIron Ethernet Switch Stacking Configuration Guide* for more information on stackable devices.

Commands A - E

aaa authorization coa enable

Enables RADIUS Change of Authorization (CoA).

Syntax **aaa authorization coa enable**
no aaa authorization coa enable

Command Default RADIUS CoA is not enabled.

Parameters None

Modes Global configuration mode

Usage Guidelines Use this command to enable RADIUS CoA authorization. The no form of the command disables the CoA functionality. A change of authorization request packet can be sent by the Dynamic Authorization Client (DAC) to change the session authorizations on the Network Access Server (NAS). This is used to change the filters, such as Layer 3 ACLs.

Before RFC 5176 when a user or device was authenticated on the RADIUS server, the session could only be ended if the user or device logs out. RFC 5176 addresses this issue by adding two more packet types to the current RADIUS standard: Disconnect Message and Change of Authorization. The Dynamic Authorization Client (DAC) server makes the requests to either delete the previously established sessions or replace the previous configuration or policies. Currently, these new extensions can be used to dynamically terminate or authorize sessions that are authenticated through multi-device-port-authentication or dot1x authentication.

Examples The following example enables RADIUS CoA.

```
device(config)# aaa authorization coa enable
```

History		
	Release version	Command history
	08.0.20	This command was introduced.

aaa authorization coa ignore

Discards the specified RADIUS Change of Authorization (CoA) messages.

Syntax	aaa authorization coa ignore { dm-request modify-acl } no aaa authorization coa ignore { dm-request modify-acl }
Command Default	The default state is maintained and the packets are not discarded.
Parameters	dm-request Disconnects the message request. modify-acl Modifies the access control list.
Modes	Global configuration mode
Usage Guidelines	<p>Use this command to discard the specified RADIUS messages. A CoA request packet can be sent by the Dynamic Authorization Client (DAC) to change the session authorizations on the Network Access Server (NAS). This is used to change the filters, such as Layer 3 ACLs.</p> <p>Before RFC 5176 when a user or device was authenticated on the RADIUS server, the session could only be ended if the user or device logs out. RFC 5176 addresses this issue by adding two more packet types to the current RADIUS standard: Disconnect Message and Change of Authorization. The Dynamic Authorization Client (DAC) server makes the requests to either delete the previously established sessions or replace the previous configuration or policies. Currently, these new extensions can be used to dynamically terminate or authorize sessions that are authenticated through multi-device-port-authentication or dot1x authentication.</p> <p>The no form of the command honors the dm-request message.</p>
Examples	<p>The following example ignores the disconnect message request.</p> <pre>device(config)# aaa authorization coa ignore dm-request</pre>

History	Release version	Command history
	08.0.20	This command was introduced.

accept-mode

Enables the non-Owner Master router to respond to ping, traceroute, and Telnet packets destined for the virtual IPv4 or IPv6 address of a VRRP cluster.

Syntax **accept-mode**

no accept-mode

Command Default A VRRP non-Owner Master router does not respond to any packet destined for the virtual IPv4 or IPv6 address.

Modes VRRP configuration mode

Usage Guidelines The **no** form of this command causes the non-Owner Master router to not respond to any packet destined for the virtual IPv4 or IPv6 address of the VRRP cluster.

A VRRP non-Owner Master router does not respond to any packet destined for the virtual IPv4 or IPv6 address. This prevents troubleshooting of network connections to this router using ping, traceroute, or Telnet. To resolve this, you can use this command to enable this router to respond to ping, traceroute, and Telnet packets destined for the virtual IPv4 or IPv6 address of a VRRP cluster. The router drops all other packets destined for the virtual IPv4 or IPv6 address of the VRRP cluster.

Examples The following example shows the configuration of accept mode on an IPv6 Backup router.

```
Brocade(config)# interface ve 3
Brocade(config-vif-3)# ipv6 vrrp vrid 2
Brocade(config-vif-3-vrid-2)# backup
Brocade(config-vif-3-vrid-2)# advertise backup
Brocade(config-vif-3-vrid-2)# ipv6-address 2001:DB8::1
Brocade(config-vif-3-vrid-2)# accept-mode
Brocade(config-vif-3-vrid-2)# activate
```

History

Release version

Command history

08.0.01

This command was introduced.

access-list enable accounting

Enables Access Control List (ACL) accounting for IPv4 numbered ACLs.

Syntax	access-list <i>number</i> enable-accounting
	no access-list <i>number</i> enable-accounting
Command Default	This option is disabled.
Parameters	<i>number</i>
	Defines the IPv4 ACL ID.
	enable-accounting
	Enables ACL accounting on the specified interface.
Modes	Global configuration mode
Usage Guidelines	This command is only applicable to numbered ACLs.
	The no form of this command disables ACL accounting for IPv4 numbered ACLs.
Examples	The following example enables ACL accounting for a numbered ACL.
	<pre>device(config)# access-list 10 permit host 10.10.10.1 device(config)# access-list 10 enable-accounting device(config)# interface ethernet 1/1 device(config-if-1/1)# ip access-group 10 in</pre>
	The following example enables ACL accounting for an extended ACL.
	<pre>device(config)# ip access-list extended 101 device(config-ip-access-list-101)# enable-accounting</pre>

History	Release version	Command history
	08.0.10	This command was introduced.

address-family unicast (BGP)

Enables the IPv4 or IPv6 address family configuration mode to configure a variety of BGP4 unicast routing options.

Syntax	address-family ipv4 unicast vrf <i>vrf-name</i>	
	address-family ipv6 unicast [vrf <i>vrf-name</i>]	
	no address-family ipv4 unicast vrf <i>vrf-name</i>	
	no address-family ipv6 unicast [vrf <i>vrf-name</i>]	
Parameters	ipv4	Specifies an IPv4 address family.
	ipv6	Specifies an IPv6 address family.
	vrf <i>vrf-name</i>	Specifies the name of the VRF instance to associate with subsequent address-family configuration mode commands.
Modes	BGP configuration mode	
Usage Guidelines	Use the no form of this command to remove IPv4 or IPv6 address family configurations from the device.	
Examples	This example enables BGP IPv6 address family configuration mode.	

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# address-family ipv6 unicast
device(config-bgp-ipv6u)#
```

This example creates a BGP4 unicast instance for VRF green.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# address-family ipv4 unicast vrf green
device(config-bgp-ipv4u-vrf)#
```

History	Release version	Command history
	8.0.30	Multi-VRF support was added for IPv6 BGP.

aggregate-address (BGP)

Configures the device to aggregate routes from a range of networks into a single network prefix.

Syntax **aggregate-address** { *ip-addr ip-mask* | *ipv6-addr ipv6-mask* } [**advertise-map** *map-name*] [**as-set**] [**attribute-map** *map-name*] [**summary-only**] [**suppress-map** *map-name*]

no aggregate-address { *ip-addr ip-mask* | *ipv6-addr ipv6-mask* } [**advertise-map** *map-name*] [**as-set**] [**attribute-map** *map-name*] [**summary-only**] [**suppress-map** *map-name*]

Command Default The address aggregation feature is disabled. By default, the device advertises individual routes for all networks.

Parameters

<i>ip-addr</i>	IPv4 address.
<i>ip-mask</i>	IPv4 mask.
<i>ipv6-addr</i>	IPv6 address.
<i>ipv6-mask</i>	IPv6 mask.
advertise-map	Causes the device to advertise the more-specific routes in the specified route map.
<i>map-name</i>	Specifies a route map to be consulted.
as-set	Causes the device to aggregate AS-path information for all routes in the aggregate routes from a range of networks into a single network prefix.
attribute-map	Causes the device to set attributes for the aggregate routes according to the specified route map.
summary-only	Prevents the device from advertising more-specific routes contained within the aggregate route.
suppress-map	Prevents the more-specific routes contained in the specified route map from being advertised.

Modes

- BGP configuration mode
- BGP address-family IPv6 unicast configuration mode
- BGP address-family IPv4 unicast VRF configuration mode
- BGP address-family IPv6 unicast VRF configuration mode

Usage Guidelines Use the **no** form of this command to restore the defaults. When this command is entered in BGP global configuration mode, it applies only to the IPv4 address family. Use this command in BGP address-family IPv6 unicast configuration mode for BGP4+ configurations.

Examples This example aggregates routes from a range of networks into a single network prefix and prevents the device from advertising more-specific routes.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# aggregate-address 10.11.12.0 summary-only
```

This example aggregates routes from a range of networks into a single network prefix under the IPv6 address family and advertises the paths for this route as AS_SET.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# address-family ipv6 unicast
device(config-bgp-ipv6u)# aggregate-address 2001:DB8:12D:1300::/64 as-set
```

This example aggregates routes from a range of networks into a single network prefix for BGP VRF instance "red".

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# address-family ipv4 unicast vrf red
device(config-bgp-ipv4u-vrf)# aggregate-address 5.0.0.0/8
```

History

Release version	Command history
8.0.30	Support was added for the BGP address-family IPv6 unicast VRF configuration mode.

alias

An alias serves as a shorthand version of a longer CLI command.

Syntax	<p>alias</p> <p>alias <i>alias-name</i> = <i>cli-command</i></p> <p>no alias <i>alias-name</i></p> <p>unalias <i>alias-name</i></p>
Command Default	No aliases are defined.
Parameters	<p><i>alias-name</i></p> <p>=</p> <p><i>cli-command</i></p> <p>Alias name. Must be a single word, without spaces.</p> <p>Operator representing "equals."</p> <p>Command string for which the alias is created.</p>
Modes	<p>Privileged EXEC mode.</p> <p>Global configuration mode.</p>
Usage Guidelines	<p>To remove an alias you can enter the no alias or the unalias command followed by the <i>alias-name</i>.</p> <p>An alias saves typing in a longer command that you commonly use. For example, you can create an alias called <i>shoro</i> for the CLI command show ip route. Then when you enter <i>shoro</i> at the command prompt, the show ip route command is issued.</p> <p>Entering the alias command with no parameters displays the currently configured aliases on the device.</p>
Examples	<p>The following example creates an alias called <i>shoro</i> for the CLI command show ip route, enter the alias shoro = show ip route command:</p> <pre>device(config)# alias shoro = show ip route</pre> <p>The following example uses the command copy running-config with the appropriate parameters to create an alias called <i>wrsbc</i>:</p> <pre>device(config)# alias wrsbc = copy running-config tftp 10.10.10.10 test.cfg</pre> <p>The following example removes the <i>wrsbc</i> alias from the configuration:</p> <pre>device(config)# no alias wrsbc</pre> <p>An alternate method of removing the alias is shown below:</p> <pre>device(config)# unalias wrsbc</pre> <p>To display the aliases currently configured on the Brocade device, enter the following command at either the Privileged EXEC or global configuration modes of the CLI.</p>

```
device# alias
      wrsbc      copy running-config tftp 10.10.10.10 test.cfg
      shoro      show ip route
```

always-compare-med

Configures the device always to compare the Multi-Exit Discriminators (MEDs), regardless of the autonomous system (AS) information in the paths.

Syntax **always-compare-med**
no always-compare-med

Command Default This feature is disabled.

Modes BGP configuration mode

Usage Guidelines Use the **no** form of this command to restore the default.

Examples This example configures the device always to compare the MEDs.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# always-compare-med
```

always-propagate

Enables the device to reflect BGP routes even though they are not installed in the Routing Table Manager (RTM).

Syntax	always-propagate				
	no always-propagate				
Command Default	This feature is disabled.				
Modes	BGP configuration mode				
	BGP address-family IPv6 unicast configuration mode				
	BGP address-family IPv4 unicast VRF configuration mode				
	BGP address-family IPv6 unicast VRF configuration mode				
Usage Guidelines	Use the no form of this command to restore the default.				
	When this command is entered in BGP global configuration mode, it applies only to the IPv4 address family. Use this command in BGP address-family IPv6 unicast configuration mode for BGP4+ configurations.				
Examples	This example configures the device to reflect routes that are not installed in the RTM.				
	<pre>device# configure terminal device(config)# router bgp device(config-bgp-router)# always-propagate</pre>				
	This example configures the device to reflect routes that are not installed in the RTM in IPv6 address-family unicast configuration mode.				
	<pre>device# configure terminal device(config)# router bgp device(config-bgp-router)# address-family ipv6 unicast device(config-bgp-ipv6u)# always-propagate</pre>				
	This example configures the device to reflect routes that are not installed in the RTM in a nondefault VRF instance.				
	<pre>device# configure terminal device(config)# router bgp device(config-bgp-router)# address-family ipv4 unicast vrf red device(config-bgp-ipv4u-vrf)# always-propagate</pre>				
History	<table><tr><th>Release version</th><th>Command history</th></tr><tr><td>8.0.30</td><td>Support was added for the BGP address-family IPv6 unicast VRF configuration mode.</td></tr></table>	Release version	Command history	8.0.30	Support was added for the BGP address-family IPv6 unicast VRF configuration mode.
Release version	Command history				
8.0.30	Support was added for the BGP address-family IPv6 unicast VRF configuration mode.				

anycast-rp

Configures PIM anycast rendezvous points (RPs) in IPv4 and IPv6 multicast domains.

Syntax **anycast-rp** *rp-address anycast-rp-set-acl*

no anycast-rp *rp-address anycast-rp-set-acl*

Command Default PIM anycast RPs are not configured.

Parameters *rp-address*

Specifies a shared RP address used among multiple PIM routers.

anycast-rp-set-acl

Specifies a host-based simple access -control list (ACL) used to specify the address of the anycast RP set, including a local address.

Modes PIM router configuration mode

Usage Guidelines The **no** form of this command removes the anycast RP configuration.

PIM anycast RP is a way provide load balancing and fast convergence to PIM RPs in an IPv4 or IPv6 multicast domain. The RP address of the anycast RP is a shared address used among multiple PIM routers, known as PIM RP.

The PIM software supports up to eight PIM anycast RP routers. All deny statements in the my-anycast-rp-set-acl ACL are ignored.

Examples This example shows how to configure a PIM anycast RP.

```
Device(config)# router pim
Device(config-pim-router)#rp-address 100.1.1.1
Device(config-pim-router)#anycast-rp 100.1.1.1 my-anycast-rp-set-acl
```

This example shows how to configure PIM anycast RP 100.1.1.1. The example avoids using loopback 1 interface when configuring PIM Anycast RP because the loopback 1 address could be used as a router-id. A PIM first-hop router registers the source with the closest RP. The first RP that receives the register re-encapsulates the register to all other anycast RP peers.

```
Device(config)# interface loopback 2
Device(config-lbif-2)#ip address 100.1.1.1/24
Device(config-lbif-2)#ip pim-sparse
Device(config-lbif-2)#interface loopback 3
Device(config-lbif-3)#ip address 1.1.1.1/24
Device(config-lbif-3)#ip pim-sparse
Device(config-lbif-3)#router pim
Device(config-pim-router)#rp-address 100.1.1.1
Device(config-pim-router)#anycast-rp 100.1.1.1 my-anycast-rp-set
Device(config-pim-router)#ip access-list standard my-anycast-rp-set
Device(config-std-nacl)#permit host 1.1.1.1
Device(config-std-nacl)#permit host 2.2.2.2
Device(config-std-nacl)#permit host 3.3.3.
```

This example shows how to configure a PIM anycast RP for a VRF.

```
Device(config)# ipv6 router pim vrf blue
Device(config-ipv6-pim-router-vrf-blue)# rp-address 1001::1
Device(config-ipv6-pim-router-vrf-blue)# anycast-rp 1001::1 my-anycast-rp-set-acl
```

This example shows how to configure PIM anycast RP 1001:1 so that it avoids using loopback 1.

```
Device(config)# interface loopback 2
Device(config-lbif-2)# ipv6 address 1001::1/96
Device(config-lbif-2)# ipv6 pim-sparse
Device(config-lbif-2)# interface loopback 3
Device(config-lbif-3)# ipv6 address 1:1:1::1/96
Device(config-lbif-3)# ipv6 pim-sparse
Device(config-lbif-3)# ipv6 router pim
Device(config-ipv6-pim-router)# rp-address 1001::1
Device(config-ipv6-pim-router)# anycast-rp 1001::1 my-anycast-rp-set
Device(config-ipv6-pim-router)# ipv6 access-list my-anycast-rp-set
Device(config-std-nacl)# permit ipv6 host 1:1:1::1 any
Device(config-std-nacl)# permit ipv6 host 2:2:2::2 any
Device(config-std-nacl)# permit ipv6 host 3:3:3::3 any
```

arp-internal-priority

Configures the priority of ingress ARP packets.

Syntax `arp-internal-priority priority-value`

Command Default The default priority of ingress ARP packets is 4.

Parameters *priority-value*

Specifies the priority value of the ingress ARP packets. It can take a value in the inclusive range of 0 to 7, where 7 is the highest priority.

Modes Global configuration mode

Usage Guidelines High traffic volume or non-ARP packets with a higher priority may cause ARP packets to be dropped, thus causing devices to become temporarily unreachable. You can use this command to increase the priority of ingress ARP packets. However, if the priority of ARP traffic is increased, a high volume of ARP traffic might cause drops in control traffic, possibly causing traffic loops in the network.

Stacking packets have a priority value of 7 and have higher precedence over ARP packets. If the ARP packets have priority value 7 in a stack system, they will be treated as priority value 6 packets when compared to stacking packets.

This command does not affect the priority of egress ARP packets.

You cannot change the priority of ingress ARP packets on the management port.

Examples The following example sets the priority of ingress ARP packets to a value of 7.

```
Brocade(config)# arp-internal-priority 7
```

History

Release version	Command history
FastIron 08.0.01	This command was introduced.

as-path-ignore

Disables the comparison of the autonomous system (AS) path lengths of otherwise equal paths.

Syntax **as-path-ignore**

no as-path-ignore

Command Default This feature is disabled.

Modes BGP configuration mode

Usage Guidelines Use the **no** form of this command to restore the default.

Examples This example configures the device to always disable the comparison of AS path lengths.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# as-path-ignore
```

authentication

Enters the authentication mode.

Syntax **authentication**

no authentication

Command Default Authentication mode is not enabled.

Modes Global configuration mode

Usage Guidelines The **no** form of the command will disable the authentication functionality.

Use this command to enter the authentication mode from global configuration mode. After entering authentication mode, you can configure additional authentication functionality that applies globally. Authentication functionality is also available for configuration at the interface configuration mode using different commands that apply only to the specified interface.

Examples The following example enables authentication.

```
device(config)#authentication
device(config-authen)#
```

History

Release version	Command history
08.0.20	This command was introduced.

authentication auth-default-vlan

Specifies the default VLAN ID in interface configuration mode.

Syntax **authentication auth-default-vlan** *vlan-id*
no authentication auth-default-vlan *vlan-id*

Command Default The default VLAN is not specified.

Parameters *vlan-id*
Specifies the VLAN ID of the default VLAN.

Modes Interface configuration

Usage Guidelines The **no** form of the command disables the default VLAN.
The **authentication auth-default-vlan** command must be enabled before enabling dot1x or MAC-authentication. When any port is enabled for dot1x or MAC authentication, the port is moved into this VLAN by default as a MAC-based VLAN member.

Examples The following example creates a default VLAN with VLAN 3 at the interface level.

```
device(config)# authentication
device(config-authen)# interface ethernet 1/1/1
device(config-if-e1000-1/1/1)# authentication auth-default-vlan 3
```

History	Release version	Command history
	08.0.20	This command was introduced.

authentication auth-order

Specifies the order of authentication methods, 802.1x (dot1x) and MAC authentication, at the interface level.

Syntax **authentication auth-order {dot1x mac-auth | mac-auth dot1x }**
no authentication auth-order {dot1x mac-auth | mac-auth dot1x }

Command Default The authentication order is not configured.

Parameters **dot1x mac-auth**
 Specifies dot1x authentication followed by MAC authentication as the order of authentication methods on the interface.
mac-auth dot1x
 Specifies MAC authentication followed by dot1x authentication as the order of authentication methods on the interface.

Modes Interface configuration mode.

Usage Guidelines The **no** form of the command disables the authentication order functionality.

The **authentication auth-order** command entered at the interface level overrides the global configuration commands, **auth-order dot1x mac-auth** and **auth-order mac-auth dot1x**.

Examples The following example specifies dot1x authentication followed by MAC authentication as the order of authentication methods on Ethernet interface 1/1/3.

```
device(config)# authentication
device(config-authen)# interface ethernet 1/1/3
device(config-if-e1/1/3)# authentication auth-order dot1x mac-auth
```

The following example specifies MAC authentication followed by dot1x authentication as the order of authentication methods on Ethernet interface 1/1/3.

```
device(config)# authentication
device(config-authen)# interface ethernet 1/1/3
device(config-if-e1/1/3)# authentication auth-order mac-auth dot1x
```

History		
	Release version	Command history
	08.0.20	This command was introduced.

authentication disable-aging

Disables aging of MAC sessions at the interface level.

Syntax	authentication disable-aging { permitted-mac denied-mac } no authentication disable-aging { permitted-mac denied-mac }
Command Default	Aging of MAC sessions is not disabled.
Parameters	permitted-mac Prevents permitted (authenticated and restricted) sessions from being aged out and ages denied sessions. denied-mac Prevents denied sessions from being aged out, but ages out permitted sessions.
Modes	Interface configuration mode
Usage Guidelines	The no form of the command does not disable aging. Use this command to disable the aging of MAC sessions. Use the authentication disable-aging command at the interface level and the disable-aging command in the authentication configuration mode. Entered at the interface level, this command overrides the command entered at the authentication configuration level.
Examples	The following example disables aging for permitted MAC addresses. device(config)# authentication device(config-authen)# interface ethernet 1/1/1 device(config-if-e1000-1/1/1)# authentication disable-aging denied-mac

History	Release version	Command history
	08.0.20	This command was introduced.

authentication dos-protection

Enables denial of service (DoS) authentication protection on the interface.

Syntax **authentication dos-protection** *mac-limit*

no authentication dos-protection *mac-limit*

Command Default Denial of service is disabled by default.

Parameters *mac-limit*

Specifies the rate limit for dos protection. You can specify a rate from 1 - 65535 authentication attempts per second. The default is a rate of 512 authentication attempts per second.

Modes Interface configuration mode

Usage Guidelines The **no** form of the command disables DoS protection.

To limit the susceptibility of the Brocade device to DoS attacks, you can configure the device to use multiple RADIUS servers, which can share the load when there are a large number of MAC addresses that need to be authenticated. The Brocade device can run a maximum of 10 RADIUS clients per server and will attempt to authenticate with a new RADIUS server if current one times out.

In addition, you can configure the Brocade device to limit the rate of authentication attempts sent to the RADIUS server. When the multi-device port authentication feature is enabled, the number of RADIUS authentication attempts made per second is tracked. When you also enable the DoS protection feature, if the number of RADIUS authentication attempts for MAC addresses learned on an interface per second exceeds a configurable rate (by default 512 authentication attempts per second), the device considers this a possible DoS attack and disables the port. You must then manually re-enable the port.

Examples The example specifies the DoS protection count as 256.

```
device(config)# authentication
device(config-authen)# interface ethernet 3/1
device(config-if-e1000-3/1)# authentication dos-protection mac-limit 256
```

History

Release version

Command history

08.0.20

This command was introduced.

authentication fail-action

Specifies the action to be performed after a MAC or dot1x authentication failure at the interface.

Syntax	authentication fail-action <i>restricted-vlan id</i> no authentication fail-action <i>restricted-vlan id</i>
Command Default	The default action is to block MAC addresses.
Parameters	<i>restricted-vlan id</i> Specifies the ID of the restricted VLAN.
Modes	Interface configuration mode
Usage Guidelines	<p>The no form of the command disables the authentication failure action.</p> <p>If you configure the authentication failure action to place the client port in a restricted VLAN, you can specify the ID of the restricted VLAN. If you do not specify a VLAN ID, the default VLAN is used. If a previous authentication failed, and as a result the port was placed in the restricted VLAN, but a subsequent authentication attempt was successful, the RADIUS Access-Accept message may specify a VLAN for the port. The device moves the port out of the restricted VLAN and into the RADIUS specified VLAN. If a previous authentication was successful and the RADIUS Access-Accept message specifies a VLAN for the port and then the device moves into the RADIUS-specified VLAN, but a subsequent authentication failed, the port will not be placed in the restricted VLAN. But the non-authenticated client will be blocked.</p>
Examples	<p>The example specifies a restricted VLAN 1 for the authentication failure action.</p> <pre>device(config)# authentication device(config-authen)# interface ethernet 1/1/1 device(config-if-e1000-1/1/1)# auth-fail-action restricted-vlan 1</pre>

History	Release version	Command history
	08.0.20	This command was introduced.

authentication filter-strict-security

Enables or disables strict filter security for dot1x and MAC-authentication on the interface.

Syntax **authentication filter-strict-security**
 no authentication filter-strict-security

Command Default Strict filter security is not enabled.

Modes Interface configuration

Usage Guidelines The **no** form of the command disables strict filter security.
 When enabled, if the filters contain invalid information, the authentication fails.

Examples The following example enables strict filter security.

```
device(config)# authentication
device(config-authen)# interface ethernet 1/1/1
device(config-if-e1000-1/1/1)# authentication filter-strict-security
```

History

Release version	Command history
08.0.20	This command was introduced.

authentication max-sessions

Specifies the maximum number of authenticated MAC sessions per port for MAC authentication and 802.1x (dot1x) authentication.

Syntax	authentication max-sessions <i>count</i>
	no authentication max-sessions <i>count</i>
Command Default	The default maximum number of MAC sessions per port is 2.
Parameters	<i>count</i>
	Specifies the maximum number of authenticated MAC sessions per port. The range of possible values is from 1 through 32.
Modes	Interface configuration mode
Usage Guidelines	The no form of this command disables this functionality.
	This command is supported on the following devices:
	<ul style="list-style-type: none">• FCX• ICX 6610• ICX 6430• ICX 6450
	This command is not supported on the following devices:
	<ul style="list-style-type: none">• ICX 7250• ICX 7450• ICX 7750

NOTE
On these devices, the default is 32 and cannot be changed.

Examples The example specifies the maximum number of authenticated MAC sessions .

```
device(config)# authentication
device(config)# interface ethernet 1/1/1
device(config-if-e1000-1/1/1)# auth max-sessions 30
```

History	Release version	Command history
	08.0.20	This command was introduced.

authentication reauth-timeout

Sets the time to re-authenticate a client after a timeout-action has been applied. This command is applicable for MAC authentication and dot1x authentication.

Syntax **authentication reauth-timeout** *seconds*

 no authentication reauth-timeout *seconds*

Command Default The default re-authentication timeout is 60 seconds.

Parameters *seconds*

 Sets the re-authentication timeout, in seconds. The range is from 60 to 4294967295.

Modes Interface configuration.

Usage Guidelines The **no** form disables re-authentication timeout.

 Use this command to specify an authentication timeout action for MAC authentication or dot1x authentication enabled clients. This command sets the re-authentication timeout at the interface level after the timeout action is specified as success, restricted VLAN or critical VLAN.

Examples The example shows specifying a re-authentication timeout of 100 seconds.

```
device(config)# authentication
device(config-authen)# interface ethernet 1/1/2
device(config-if-e1000-1/1/1)# authentication reauth-timeout 100
```

History		
	Release version	Command history
	08.0.20	This command was introduced.

authentication source-guard-protection enable

Enables Source Guard Protection along with authentication on a specified interface.

Syntax	authentication source-guard-protection enable
	no authentication source-guard-protection enable
Command Default	Source Guard Protection is not enabled.
Modes	Interface configuration mode
Usage Guidelines	The no form of the command disables source guard protection.
	When a new MAC session begins on a port that has Source Guard Protection enabled, the session either applies a dynamically created Source Guard ACL entry or it uses the dynamic IP ACL assigned by the RADIUS server. If a dynamic IP ACL is not assigned, the session uses the Source Guard ACL entry. The Source Guard ACL entry is permit ip secure-ip any , where <i>secure-ip</i> is obtained from the ARP Inspection table or from the DHCP Secure table. The DHCP Secure table is comprised of DHCP Snooping and Static ARP Inspection entries. The Source Guard ACL permit entry is added to the hardware table after all of the following events occur: <ul style="list-style-type: none">• The MAC address is authenticated• The IP address is learned• The MAC-to-IP mapping is checked against the Static ARP Inspection table or the DHCP Secure table The Source Guard ACL entry is not written to the running configuration file. However, you can view the configuration using the show auth-mac-addresses authorized-mac command.

NOTE

The secure MAC-to-IP mapping is assigned at the time of authentication and remains in effect as long as the MAC session is active. The existing MAC session doesn't get affected if the DHCP Secure table is updated after the session is authenticated and while the session is still active.

The Source Guard ACL permit entry is removed when the MAC session expires or is cleared.

Examples The following example enables source guard protection on an interface.

```
device(config)# authentication
device(config-authen)# interface ethernet 1/1/1
device(config-if-e1000-1/1/1)# authentication source-guard-protection enable
```

History	Release version	Command history
	08.0.20	This command was introduced.

authentication timeout-action

Specifies the action for the RADIUS server if an authentication timeout occurs.

Syntax authentication timeout-action { success | failure | critical-vlan }

no authentication timeout-action { success | failure | critical-vlan }

Command Default	The default action is failure.
------------------------	--------------------------------

Parameters success

Specifies the RADIUS timeout action as a success. After the successful timeout action is enabled, use the **no** form of the command to set the RADIUS timeout behavior to retry.

failure

Specifies the RADIUS timeout action as failure. Once the failure timeout action is enabled, use the **no** form of the command to reset the RADIUS timeout behavior to retry.

critical-vlan

Specifies the RADIUS timeout action as critical-VLAN. This command applies only to data traffic.

Modes Interface configuration mode

Usage Guidelines The **no** form of this command will disable this functionality.

Examples The following example sets the **authentication timeout-action** command to success.

```
device(config)# authentication
device(config)# interface ethernet 1/1/1
device(config-if-e1000-1/1/1)# authentication timeout-action success
```

History

Release version	Command history
08.0.20	This command was introduced.

auth-default-vlan

Specifies the default VLAN globally.

Syntax **auth-default-vlan** *vlan-id*

no auth-default-vlan *vlan-id*

Command Default The default VLAN is not specified.

Parameters *vlan-id*
Specifies the VLAN ID of the default VLAN.

Modes Authentication mode

Usage Guidelines The **no** form of the command disables the default VLAN.
The **auth-default-vlan** command must be enabled before enabling dot1x or MAC-authentication. When any port is enabled for dot1x or MAC authentication, the port is moved into this VLAN by default as a MAC-based VLAN member.

Examples The following example creates a default VLAN with VLAN 2 at the authentication configuration mode.

```
device(config)# authentication
device(config-authen)# auth-default-vlan 2
```

History	Release version	Command history
	08.0.20	This command was introduced.

auth-fail-action

Specifies the authentication failure action as a restricted VLAN for both MAC authentication and dot1x authentication globally.

Syntax **auth-fail-action** *restricted-vlan id*

 no auth-fail-action *restricted-vlan id*

Command Default The default action is to block MAC addresses.

Parameters *restricted-vlan id*
 Specifies the ID of the restricted VLAN.

Modes Authentication mode

Usage Guidelines The **no** form of this command disables the authentication failure action.

If you configure the authentication failure action to place the client port in a restricted VLAN, you can specify the ID of the restricted VLAN. If you do not specify a VLAN ID, the default VLAN is used. If a previous authentication failed, and as a result the port was placed in the restricted VLAN, but a subsequent authentication attempt was successful, the RADIUS Access-Accept message may specify a VLAN for the port. The device moves the port out of the restricted VLAN and into the RADIUS specified VLAN. If a previous authentication was successful and the RADIUS Access-Accept message specifies a VLAN for the port and then the device moves into the RADIUS-specified VLAN, but a subsequent authentication failed, the port will not be placed in the restricted VLAN. But the non-authenticated client will be blocked.

Examples The following example specifies restricted VLAN 1 for the authentication failure action.

```
device(config)# authentication
device(config-authen)# auth-fail-action restricted-vlan 1
```

History	Release version	Command history
	08.0.20	This command was introduced.

auth-order dot1x mac-auth

Specifies the order of authentication methods to be 802.1x (dot1x) authentication before MAC authentication at the global level.

Syntax **auth-order dot1x mac-auth**

 no auth-order dot1x mac-auth

Command Default The authentication order is not configured.

Modes Authentication mode

Usage Guidelines The **no** form of the command disables the authentication order functionality.

 This command specifies the dot1x authentication followed by mac authentication as the order of authentication methods on the device. Use the **auth-order mac-auth dot1x** command to reverse this order of authentication.

Examples The following example specifies dot1x authentication followed by mac authentication as the order of authentication methods.

```
device(config)# authentication
device(config-authen)# auth-order dot1x mac-auth
```

History	Release version	Command history
	08.0.20	This command was introduced.

auth-order mac-auth dot1x

Specifies the order of authentication methods to be MAC authentication before 802.1x (dot1x) authentication at the global level.

Syntax **auth-order mac-auth dot1x**

 no auth-order mac-auth dot1x

Command Default The authentication order is not configured.

Modes Authentication mode

Usage Guidelines The **no** form of the command disables the authentication order functionality.

 This command specifies the MAC authentication followed by dot1x authentication as the order of authentication methods on the device. Use the **auth-order dot1x mac-auth** command to reverse this order of authentication.

Examples The following example specifies MAC authentication followed by dot1x authentication as the order of authentication methods.

```
device(config)# authentication
device(config-authen)# auth-order mac-auth dot1x
```

History		
	Release version	Command history
	08.0.20	This command was introduced.

auto-cost reference-bandwidth (OSPF)

Configures reference bandwidth.

Syntax `auto-cost reference-bandwidth { ref-bw | use-active-ports }`

`no auto-cost reference-bandwidth`

Command Default Reference bandwidth is 100 Mbps.

Parameters *ref-bw*

Reference bandwidth in Mbps. Valid values range from 1 through 4294967.

use-active-ports

When set, any dynamic change in bandwidth immediately affects the cost of OSPF routes. This parameter enables cost calculation for currently active ports only.

Modes OSPF router configuration mode

Usage Guidelines Use this command to configure the cost of an interface that a device advertises to its OSPF neighbors. OSPF calculates the cost of a route as the ratio of the reference bandwidth to the bandwidth of the egress interface. An increase in the reference bandwidth results in an increased cost. If the resulting cost is less than 1, the software rounds the cost up to 1.

The bandwidth for interfaces that consist of more than one physical port is calculated as follows:

- LAG group — The combined bandwidth of all the ports.
- Virtual interface — The combined bandwidth of all the ports in the port-based VLAN that contains the virtual interface.

If a change to the reference bandwidth results in a cost change to an interface, the device sends a link-state update to update the costs of interfaces advertised by the device.

NOTE

If you specify the cost for an individual interface (by using the **ip ospf cost** command), the cost you specify overrides the cost calculated by the software.

Enter **no auto-cost reference-bandwidth** to disable bandwidth configuration.

Examples This example configures a reference bandwidth of 500.

```
device# configure
device(config)# router ospf
device(config-ospf-router)# auto-cost reference-bandwidth 500
```

The reference bandwidth specified in this example results in the following costs:

- 10 Mbps port's cost = $500/10 = 50$.
- 100 Mbps port's cost = $500/100 = 5$.
- 1000 Mbps port's cost = $500/1000 = 0.5$, which is rounded up to 1.

The costs for 10 Mbps and 100 Mbps ports change as a result of the changed reference bandwidth. Costs for higher-speed interfaces remain the same.

auto-cost reference-bandwidth (OSPFv3)

Configures reference bandwidth.

Syntax **auto-cost reference-bandwidth** { *ref-bw* }

no auto-cost reference-bandwidth

Command Default Reference bandwidth is 100 Mbps.

Parameters *ref-bw*

Reference bandwidth in Mbps. Valid values range from 1 through 4294967.

Modes OSPFv3 router configuration mode

Usage Guidelines Use this command to configure the cost of an interface that a device advertises to its OSPF neighbors. OSPFv3 calculates the cost of a route as the ratio of the reference bandwidth to the bandwidth of the egress interface. An increase in the reference bandwidth results in an increased cost. If the resulting cost is less than 1, the software rounds the cost up to 1.

The bandwidth for interfaces that consist of more than one physical port is calculated as follows:

- LAG group — The combined bandwidth of all the ports.
- Virtual interface — The combined bandwidth of all the ports in the port-based VLAN that contains the virtual interface.

If a change to the reference bandwidth results in a cost change to an interface, the device sends a link-state update to update the costs of interfaces advertised by the device.

NOTE

If you specify the cost for an individual interface (by using the **ipv6 ospf cost** command), the cost you specify overrides the cost calculated by the software.

Enter **no auto-cost reference-bandwidth** to disable bandwidth configuration.

Examples This example configures a reference bandwidth of 500.

```
device# configure terminal
device(config)# ipv6 router ospf
device(config-ospf6-router)# auto-cost reference-bandwidth 500
```

- The reference bandwidth specified in this example results in the following costs: 10 Mbps port's cost = $500/10 = 50$.
- 100 Mbps port's cost = $500/100 = 5$.
- 1000 Mbps port's cost = $500/1000 = 0.5$, which is rounded up to 1.
- 155 Mbps port cost = $500/155 = 3.23$, which is rounded up to 4
- 622 Mbps port cost = $500/622 = 0.80$, which is rounded up to 1
- 2488 Mbps port cost = $500/2488 = 0.20$, which is rounded up to 1

The costs for 10 Mbps, 100 Mbps, and 155 Mbps ports change as a result of the changed reference bandwidth. Costs for higher-speed interfaces remain the same.

bandwidth (interface)

Sets and communicates bandwidth value for an interface to higher-level protocols such as OSPFv2 and OSPFv3, so this setting can be used to influence the routing cost for routes learnt on these interfaces.

Syntax **bandwidth** { *kilobits* }
no bandwidth { *kilobits* }

Command Default For physical ports, the port speed is the default bandwidth. For VE interfaces and Link aggregation (LAG) groups, the sum of port speeds of individual physical ports is the default bandwidth.

Parameters *kilobits*

Intended bandwidth, in kilobits per second. There is no default value for this parameter. The range is from 1 to 1000000000 kbps (100 Gbps).

Modes Interface configuration mode.

Usage Guidelines Use the **no bandwidth** command to remove the bandwidth value.

This command is supported on all Brocade FastIron platforms.

You cannot adjust the actual bandwidth of an interface with this command. When you configure the interface bandwidth for virtual Ethernet that is associated with multiple physical interfaces, OSPF does not adjust its metric cost if one of those associated interfaces is down, and does not generate network and router link state advertisement.

This command is

Examples This example sets the bandwidth to 2000 kbps on a specific Ethernet interface.

```
device# configure terminal
device(config)# interface ethernet 1/1/1
device(config-if-e1000-1/1/1) bandwidth 2000
```

This example sets the bandwidth to 2000 kbps on a specific virtual Ethernet (VE) interface.

```
device# configure terminal
device(config)# vlan 10
device(config-vlan-10)# interface ve 10
device(config-vif-10) bandwidth 2000
```

This example sets the bandwidth to 2000 kbps on a specific tunnel interface.

```
device# configure terminal
device(config)# interface tunnel 2
device(config-tnif-2) bandwidth 2000
```

History	Release version	Command history
	8.0.30	This command was introduced.

Related Commands [show interfaces ethernet](#), [show interfaces tunnel](#), [show interfaces ve](#), [show ip ospf interface](#), [show ipv6 ospf interface](#), [show running-config interface ethernet](#), [show running-config interface tunnel](#), [show running-config interface ve](#)

bgp-redistribute-internal

Causes the device to allow the redistribution of IBGP routes from BGP into OSPF for nondefault VRF instances.

Syntax	bgp-redistribute-internal	
	no bgp-redistribute-internal	
Command Default	This feature is disabled.	
Modes	BGP configuration mode	
	BGP address-family IPv6 unicast configuration mode	
	BGP address-family IPv4 unicast VRF configuration mode	
	BGP address-family IPv6 unicast VRF configuration mode	
Usage Guidelines	Use the no form of the command to restore the defaults.	
	When this command is entered in BGP global configuration mode, it applies only to the IPv4 address family. Use this command in BGP address-family IPv6 unicast configuration mode for BGP4+ configurations.	
Examples	This example enables BGP4 route redistribution.	
	<pre>device# configure terminal device(config)# router bgp device(config-bgp-router)# bgp-redistribute-internal</pre>	
	This example enables BGP4+ route redistribution in BGP address-family IPv6 unicast configuration mode.	
History	<pre>device# configure terminal device(config)# router bgp device(config-bgp-router)# address-family ipv6 unicast device(config-bgp-ipv6u)# bgp-redistribute-internal</pre>	
	Release version	Command history
	8.0.30	Support was added for the BGP address-family IPv6 unicast VRF configuration mode.

breakout ethernet

Configures sub-ports from 40 Gbps ports.

Syntax **breakout ethernet** *unit/slot/port*

breakout ethernet *unit/slot/port to ethernet unit/slot/port*

breakout ethernet *unit/slot/port ethernet unit/slot/port*

no breakout ethernet *unit/slot/port*

no breakout ethernet *unit/slot/port to ethernet unit/slot/port*

no breakout ethernet *unit/slot/port ethernet unit/slot/port*

Command Default By default, ports that can be broken out are configured as 40 Gbps ports.

Parameters **ethernet**

Specifies the connection as ethernet.

unit/slot/port

Specifies the port to be broken into 10 Gbps sub-ports. If there are two port identifiers in the command line, the first port designates the beginning port in a range of ports to be broken out, and the second port indicates the end of the breakout range. When a range is specified, the 10 Gbps sub-ports within the range are implicitly included.

to

Designates a range of ports to be configured when followed by an ending port identifier. This is an optional keyword.

Modes Global configuration mode.

Usage Guidelines Use the **no** form of the command to remove breakout configuration from the designated port or range of ports.

No configuration may be present on a port for which the **breakout ethernet** command is issued. When the command is issued on a port with pre-existing configuration, an error message is returned. The existing configuration must be removed before the **breakout ethernet** command is re-issued.

The **breakout ethernet** command is available only on certain ICX 7750 40 Gbps ports. Refer to the *FastIron Ethernet Switch Administration Guide* for a table of available breakout ports. Refer to the *ICX 7750 Ethernet Switch Hardware Installation Guide* for detailed information on breakout cables.

The **breakout ethernet** command can be issued on stand-alone units only. Stacking cannot be enabled on a port configured for breakout. An error is returned if you try to enable stacking on a unit that has any breakout ports configured. The breakout configuration must be removed manually before stacking can be enabled. Use the **show breakout** command to display the breakout configuration for a unit.

The **breakout ethernet** and **no breakout ethernet** commands must be followed by a **write memory** command and a **reload** command for the port configuration changes to take effect.

Examples The following example configures breakout on port 1/1/5, after existing configuration on the port is removed.

```
Device# configure terminal
Device(config)# breakout ethernet 1/1/5
Error: Port 1/1/5 has sflow forwarding
Device(config)# interface ethernet 1/1/5
Device(config-if-e40000-1/1/5)# no sflow forwarding
Device(config-if-e40000-1/1/5)# end
Device# write memory
Write startup-config done.
Device# configure terminal
Device(config)# breakout ethernet 1/1/5
Reload required. Please write memory and then reload or power cycle.
Device(config)# write memory
Write startup-config done.
Device(config)# Flash Memory Write (8192 bytes per dot) .
Copy Done.
Device(config)# end
Device# reload
```

The following example checks for ports with active breakout configuration and then removes breakout from ports 1/3/1 through 1/3/6.

```
Device# show breakout

Unit-Id: 1
```

Port	Module Exist	Module Conf	breakout_conf	breakout_oper
1/1/5	Yes	No	Yes	Yes
1/1/6	Yes	No	Yes	Yes
1/1/7	Yes	No	Yes	Yes
1/1/8	Yes	No	Yes	Yes
1/1/9	Yes	No	Yes	Yes
1/1/10	Yes	No	Yes	Yes
1/1/11	Yes	No	Yes	Yes
1/1/12	Yes	No	Yes	Yes
1/1/13	Yes	No	Yes	Yes
1/1/14	Yes	No	Yes	Yes
1/1/15	Yes	No	Yes	Yes
1/1/16	Yes	No	Yes	Yes
1/2/1	Yes	No	Yes	Yes
1/2/2	Yes	No	Yes	Yes
1/2/3	Yes	No	Yes	Yes
1/2/4	Yes	No	Yes	Yes
1/2/5	Yes	No	Yes	Yes
1/2/6	Yes	No	Yes	Yes
1/3/1	Yes	No	Yes	Yes
1/3/2	Yes	No	Yes	Yes
1/3/3	Yes	No	Yes	Yes
1/3/4	Yes	No	Yes	Yes
1/3/5	Yes	No	Yes	Yes
1/3/6	Yes	No	Yes	Yes

```
Device# configure terminal
Device(config)# no breakout ethernet 1/3/1 to 1/3/6
Reload required. Please write memory and then reload or power cycle.
Device(config)# write memory
Write startup-config done.

Device(config)# Flash Memory Write (8192 bytes per dot) .
Copy Done.
Device(config)# end
Device# reload
```

NOTE

If there had been any configuration on any sub-ports (1/3/1:1 to 1/3/6:4), the **no breakout** command would have returned an error. The configuration would then have to be removed from the sub-ports before breakout configuration could be removed.

History	Release version	Command history
	FastIron Release 08.0.30	This command was introduced.

bsr-candidate

Configures a bootstrap router (BSR) as a candidate to distribute rendezvous point (RP) information to the other PIM Sparse devices within a PIM Sparse domain.

Syntax **bsr-candidate ethernet** *stackid/slot/portnum hash-mask-length [priority]*

bsr-candidate loopback *num hash-mask-length [priority]*

bsr-candidate ve *num hash-mask-length [priority]*

bsr-candidate tunnel *num hash-mask-length [priority]*

no bsr-candidate

Command Default The PIM router does not participate in BSR election.

Parameters **ethernet** *stackid/slot/portnum*

Specifies the physical interface for the candidate BSR. On standalone devices specify the interface ID in the format slot/port-id; on stacked devices you must also specify the stack ID, in the format stack-id/slot/port-id.

loopback *num*

Specifies the loopback interface for the candidate BSR.

ve *num*

Specifies the virtual interface for the candidate BSR.

tunnel *num*

Specifies a GRE tunnel interface.

hash-mask-length

Specifies the number of bits in a group address that are significant when calculating the group-to-RP mapping. The range is 1 to 32.

NOTE

It is recommended that you specify 30 for IPv4 networks.

priority

Specifies the BSR priority. The range is from 0 to 255, from low to high. The default is 0.

Modes Router configuration mode

Usage Guidelines The **no** form of this command makes the PIM router cease to act as a candidate BSR.

Each PIM Sparse domain has one active BSR. For redundancy, you can configure ports on multiple devices as candidate BSRs. The PIM Sparse protocol uses an election process to select one of the candidate BSRs as the BSR for the domain. The BSR with the highest BSR priority is elected. If the priorities result in a tie, the candidate BSR interface with the highest IP address is elected.

Although you can configure the device as only a candidate BSR or an RP, it is recommended that you configure the same interface on the same device as both a BSR and an RP.

Examples The following example uses a physical interface to configure a device as a candidate BSR.

```
Device(config)# router pim
Device(config-pim-router)# bsr-candidate ethernet 2/2 30 255
```

The following example uses a loopback interface to configure a device as a candidate BSR.

```
Device(config)# router pim
Device(config-pim-router)# bsr-candidate loopback 1 30 240
```

The following example uses a virtual interface to configure a device as a candidate BSR.

```
Device(config)# router pim
Device(config-pim-router)# bsr-candidate ve 120 30 250
```

History	Release version	Command history
	8.0.20	This command was modified to add the tunnel keyword.

capability as4

Enables 4-byte autonomous system number (ASN) capability at the BGP global level.

Syntax **capability as4 { disable | enable }**
no capability as4 { disable | enable }

Command Default This feature is disabled.

Parameters **disable**
Disables 4-byte ASN capability at the BGP global level.
enable
Enables 4-byte ASN capability at the BGP global level.

Modes BGP configuration mode

Usage Guidelines Use the **no** form of this command to disable this functionality.

Examples To enable 4-byte ASN capability:

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# capability as4 enable
```

clear access-list accounting

Clears Access Control List (ACL) accounting statistics for IPv4 ACLs, IPv6 ACLs, and Layer 2 MAC filters.

Syntax **clear access-list accounting all**

clear access-list accounting *interface-type interface-name* **in**

clear access-list accounting traffic-policy { **all** | *name* }

Parameters **all** Clears all statistics for all ACLs.

interface-type interface-name Specifies the ID of the Ethernet or virtual interface. Clears the accounting statistics for ACLs bound to a physical port or clears statistics for all ACLs bound to ports that are members of a virtual routing interface.

in Clears statistics of the inbound ACLs.

traffic-policy Clears traffic-policy statistics.

all Clears all traffic-policy statistics.

name Clears statistics of a specific traffic-policy.

Modes Privileged EXEC mode

Usage Guidelines To clear accounting statistics for all configured ACLs, use the **all** keyword.

Examples The following example clears ACL accounting statistics for all configured ACLs.

```
device# clear access-list accounting all
```

 The following example clears ACL accounting statistics for a specific port.

```
device# clear access-list accounting ethernet 1/5 in
```

 The following example clears all traffic-policy statistics.

```
device#clear access-list accounting traffic-policy all
```

History	Release version	Command history
	08.0.10	This command was introduced.

clear cable diagnostics tdr

Clears the results of Virtual Cable Test (VCT) TDR testing (if any) conducted on the specified port

Syntax **clear cable-diagnostics tdr** *stackid/slot/port*

Command Default By default, the results of the previous test (if any) are present and are displayed in response to the **show cable-diagnostics tdr** command for the specified port.

Parameters *stackid/slot/port*

Identifies the specific interface (port), by device, slot, and port number in the format shown.

Modes Privileged EXEC mode

Usage Guidelines Use this command to clear TDR test registers before every TDR cable diagnostic test. Most Brocade devices support VCT technology. VCT technology enables the diagnosis of a conductor (wire or cable) by sending a pulsed signal into the conductor, then examining the reflection of that pulse. This method of cable analysis is referred to as Time Domain Reflectometry (TDR). By examining the reflection, the Brocade device can detect and report cable statistics such as local and remote link pair, cable length, and link status.

Use the command in conjunction with the **phy cable-diagnostics tdr stackid/slot/port** command to test the interface.

Show diagnostic test results using the **show cable-diagnostics tdr stackid/slot/port** command.

This command is supported only on the Brocade ICX 6610, ICX 6430, ICX 6430-C, ICX 6450, ICX6450-C, and FCX Series devices.

Examples In the following example, results from the previous test are cleared from the third interface on the second slot of the first device in the stack.

```
device# clear cable-diagnostics tdr 1/2/3
```

History

Release version

Command history

08.0.20

This command was introduced.

clear dot1x sessions

Clears 802.1x (dot1x) authentication sessions.

Syntax `clear dot1x sessions { mac-address | ethernet device/slot/port }`

Parameters *mac-address*

Specifies the mac-address from which the dot1x authentication sessions are to be cleared.

ethernet *device/slot/port*

Specifies the interface from which the dot1x authentication sessions are to be cleared.

Modes Privileged EXEC mode.

Usage Guidelines Use this command to clear the dot1x authentication sessions.

Examples The following example clears the dot1x authentication session for the specified MAC address.

```
device(config)# clear dot1x sessions 0000.0034.abd4
```

History	Release version	Command history
	08.0.20	This command was introduced.

clear dot1x statistics

Clears dot1x authentication statistics.

Syntax **clear dot1x statistics** { **ethernet** *device/slot/port* | **all** }

Parameters **ethernet** *device/slot/port*
 Specifies the interface on which the dot1x authentication statistics are to be cleared.

all
 Specifies that dot1x authentication statistics are to be cleared for all interfaces.

Modes Privileged EXEC mode.

Usage Guidelines Use this command to clear dot1x authentication statistics on all or one specified interface.

Examples The following example clears dot1x statistics on all interfaces.

```
device(config)# clear dot1x statistics all
```

History

Release version	Command history
08.0.20	This command was introduced.

clear dot1x-mka statistics

Clears current MACsec Key Agreement (MKA) statistics.

Syntax **clear dot1x-mka statistics ethernet** *device/slot/port*

Parameters **ethernet** *device/slot/port*
Specifies an Ethernet interface by device position in stack, slot on the device, and interface on the slot.

Modes EXEC or Privileged EXEC mode

Usage Guidelines This command is supported only on the Brocade ICX 6610 in FastIron Release 08.0.20. In FastIron Release 08.0.30 and later releases, MACsec commands are also supported on the ICX 7450.

Examples In the following example, MKA statistics are cleared for Ethernet interface 1/3/3 (port 3 of slot 3 on the first device in the stack).

```
device# clear dot1x-mka statistics ethernet 1/3/3
```

History	Release version	Command history
	08.0.20	This command was introduced.

clear ip mroute

Removes multicast routes from the IP multicast routing table .

Syntax **clear ip mroute** [**vrf** *vrf-name*] [*ip-address* { *ip-mask* | *mask-bits* }]

Parameters **vrf** *vrf-name*

Specifies a VRF.

ip-address

Specifies an IP address.

ip-mask

Specifies an IP subnet mask.

mask-bits

Specifies a subnet mask in bits.

Modes Global configuration mode

Usage Guidelines After multicast routes are cleared from an IP multicast routing table, the best static multicast routes are added back to the routing table.

When used without specifying a **vrf** *vrf-name* this command clears multicast routes from the multicast routing table.

Examples The following example removes all mroutes from the IP multicast routing table:

```
Device# configure terminal
Device(config)# clear ip mroute
```

The following example removes all mroutes from the vrf green IP multicast routing table:

```
Device# configure terminal
Device(config)# clear ip mroute vrf green
```

The following example removes mroute 10.0.0.2/24 from the IP multicast routing table:

```
Device# configure terminal
Device(config)# clear ip mroute 10.0.0.2/24
```

History

Release version	Command history
8.0.10a	This command was introduced.

clear ip pim counters

Clears PIM message counters.

Syntax	clear ip pim [vrf <i>vrf-name</i>] counters
Parameters	vrf <i>vrf-name</i> Specifies a VRF instance.
	counters Specifies PIM message counters.
Modes	Privileged EXEC mode
Usage Guidelines	When entered without the vrf keyword, this command clears the PIM message counters for all VRFs.
Examples	The following example clears the PIM message counters.

```
Device# clear ip pim counters
```

The following example clears the PIM message counters on a VRF named blue.

```
Device# clear ip pim vrf blue counters
```

clear ip pim hw-resource

Clears the PIM hardware resource fail count for a specific VRF instance or for all VRFs.

Syntax **clear ip pim [vrf *vrf-name*] hw-resource**

Parameters **vrf** *vrf-name* Specifies a VRF instance.
 hw-resource Specifies hardware resource fail count.

Modes Privileged EXEC mode

Usage Guidelines When entered without the **vrf** keyword, this command clears the PIM hardware resource fail count for all VRFs.

Examples The following example clears the PIM hardware resource fail count.

```
Device# clear ip pim hw-resource
```

clear ip pim rp-map

Updates the entries in the static multicast forwarding table for a specific VRF instance or for all VRFs.

Syntax	clear ip pim [vrf <i>vrf-name</i>] rp-map
Parameters	vrf <i>vrf-name</i> Specifies a VRF instance.
	rp-map Specifies the entries in a PIM sparse static multicast forwarding table.
Modes	Privileged EXEC mode
Usage Guidelines	When entered without the vrf keyword, this command clears the PIM forwarding cache for all VRFs. Configure this command to update the entries in the static multicast forwarding table immediately after making rendezvous point (RP) configuration changes. This command is meant to be used with the rp-address command.
Examples	The following example clears the entries in a PIM sparse static multicast forwarding table on a VRF instance named blue. Device# clear ip pim vrf blue rp-map

clear ip pimsm-snoop

Clears PIM sparse mode (SM) information.

Syntax	clear ip pimsm-snoop [<i>vlan</i> <i>vlan-id</i>] { cache [<i>ip-address</i>] stats }		
Parameters	vlan <i>vlan-id</i>		
	cache	Specifies clearing information on a specific VLAN.	
	<i>ip-address</i>	Specifies clearing the PIM SM snooping cache.	
	stats	Specifies clearing PIM SM snooping-cache information on a specific source or group.	
		Specifies clearing traffic and error counters.	
Modes	Global configuration mode		

Examples The following example clears PIM SM information from all VLANs.

```
Device(config)#clear ip pimsm-snoop cache
```

 The following example clears PIM SM information from a specific VLAN.

```
Device(config)#clear ip pimsm-snoop vlan 10 cache
```

 The following example clears PIM SM information from a specific source.

```
Device(config)#clear ip pimsm-snoop cache 10.1.1.1
```

 The following example clears traffic and error counters from all VLANs.

```
Device(config)#clear ip pimsm-snoop stats
```

History	Release version	Command history
	8.0.20	This command was introduced.

clear ipv6 dhcp-relay delegated-prefixes

Clears the IPv6 DHCP relay delegated prefixes.

Syntax **clear ipv6 dhcp-relay delegated-prefixes**

Modes Privileged EXEC mode.

Usage Guidelines Use this command to clear the IPv6 DHCP relay delegated prefixes.

Examples The following example clears the IPv6 DHCP relay delegated prefixes.

```
device# clear ipv6 dhcp-relay delegated-prefixes vrf VRF1
```

History	Release version	Command history
	08.0.10d	This command was introduced.
	08.0.30	Support for this command was added in 08.0.30 and later releases.

clear ipv6 dhcp-relay statistics

Clears the IPv6 DHCP packet counters.

- Syntax

clear ipv6 dhcp-relay statistics
- Modes

Privileged EXEC mode.
- Usage Guidelines

Use this command to clear the IPv6 DHCP packet counters.
- Examples

The following example clears the IPv6 DHCP packet counters.

device# clear ipv6 dhcp-relay statistics

History	Release version	Command history
	08.0.10d	This command was introduced.
	08.0.30	Support for this command was added in 08.0.30 and later releases.

clear ipv6 mroute

Removes IPv6 multicast routes from the IPv6 multicast routing table.

Syntax **clear ipv6 mroute** [**vrf** *vrf-name*] [*ipv6-address-prefix/prefix-length*]

Parameters **vrf** *vrf-name* Specifies a VRF route.
 ipv6-address-prefix/prefix-length
 Specifies an IPv6 address prefix in hexadecimal using 16-bit values between colons as documented in RFC 2373 and a prefix length as a decimal value.

Modes Privileged EXEC mode

Usage Guidelines After mroutes are removed from an IPv6 multicast routing table, the best static mroutes are added back to it.

Examples The following example removes all mroutes from the IPv6 multicast routing table:
Device(config)# clear ipv6 mroute

The following example removes all mroutes from the vrf green IPv6 multicast routing table:
Device(config)# clear ipv6 mroute vrf green

The following example removes mroute 2000:7838::/32 from the IPv6 multicast routing table:
Device(config)# clear ipv6 mroute 2000:7838::/32

History	Release version	Command history
	8.0.10a	This command was introduced.

clear ipv6 neighbor

Clears the static neighbor discovery (ND) inspect entries and ND inspection statistics.

Syntax `clear ipv6 neighbor [vrf vrf-name] inspection [static-entry | statistics]`

Parameters	vrf	Specifies the VRF instance (optional).
	<i>vrf-name</i>	Specifies the ID of the VRF instance required with vrf .
	inspection	Specifies that the neighbor discovery messages are verified against the static ND inspection entries or dynamically learned DHCPv6 snoop entries.
	static-entry	Clears the manually configured static ND inspect entries that are used to validate the packets received on untrusted ports.
	statistics	Clears the total number of neighbor discovery messages received and the number of packets discarded after ND inspection.

Modes Privileged EXEC mode
Global configuration mode
VRF configuration mode

Usage Guidelines This command can be used in three different modes as shown in the examples. If used without specifying a VRF, this command clears data from the default VRF.

Examples The following example removes the manually configured static ND inspect entries.

```
device# clear ipv6 neighbor inspection static-entry
```

The following example removes the manually configured static ND inspect entries on a VRF.

```
device# configure terminal
device(config)# vrf vrf2
device(config-vrf-vrf2)# clear ipv6 neighbor vrf vrf2 inspection static-entry
```

The following example deletes the ND inspection statistics.

```
device# configure terminal
device(config)# clear ipv6 neighbor inspection statistics
```

The following example deletes the ND inspection statistics on a VRF.

```
device# configure terminal
device(config)# clear ipv6 neighbor vrf vrf2 inspection statistics
```

History

Release version	Command history
08.0.20	This command was introduced.

clear ipv6 pim cache

Clears the IPv6 PIM forwarding cache.

Syntax `clear ipv6 pim [vrf vrf-name] cache ipv6-address`

Parameters `vrf vrf-name`

Specifies a VRF instance.

`cache ipv6-address`

Specifies group or address of the PIM forwarding cache to clear.

Modes Privileged EXEC mode

Usage Guidelines When entered without the **vrf** keyword, this command clears information for all VRF instances.

Examples This example shows how to clear the IPv6 PIM forwarding cache:

```
Device#clear ipv6 pim cache 2001:0DB8:0:1::1/120 5100::192:1:1:1
```

clear ipv6 pim counters

Clears IPv6 PIM message counters.

Syntax **clear ipv6 pim [vrf *vrf-name*] counters**

Parameters **vrf** *vrf-name*

Specifies a VRF instance.

counters

Specifies the IPv6 PIM message counters.

Modes Privileged EXEC mode

Usage Guidelines When entered without the **vrf** keyword, this command clears information for all VRF instances.

Examples This example shows how to clear the IPv6 PIM message counters:

```
Device#clear ipv6 pim counters
```

clear ipv6 pim hw-resource

Clears the IPv6 PIM hardware resource fail count for a specific VRF instance or for all VRFs.

Syntax	clear ipv6 pim hw-resource
Parameters	vrf <i>vrf-name</i> Specifies a VRF instance.
	hw-resource Specifies hardware resource fail count.
Modes	Privileged EXEC mode
Usage Guidelines	When entered without the vrf keyword, this command clears the PIM hardware resource fail count for all VRFs.
Examples	The following example clears the IPv6 PIM hardware resource fail count.
	<pre>Device# clear ipv6 pim hw-resource</pre>

clear ipv6 pim rp-map

Clears the entries in an IPv6 PIM Sparse static multicast forwarding table, allowing a new rendezvous point (RP) configuration to be effective immediately.

Syntax **clear ipv6 pim [vrf *vrf-name*] rp-map**

Parameters **vrf** *vrf-name*

Specifies a VRF instance.

rp-map

Specifies the entries in a PIM sparse static multicast forwarding table.

Modes Privileged EXEC mode

Usage Guidelines Configuring this command clears and overwrites the static RP configuration. If you change the static RP configuration, the entries in the IPv6 PIM Sparse multicast forwarding table continue to use the old RP configuration until they are aged out. You can configure the **clear ipv6 pim rp-map** command to update the entries in the static multicast forwarding table immediately after making RP configuration changes.

This command is meant to be used with the **rp-address** command.

Examples This example shows how to clear the entries in an IPv6 PIM Sparse static multicast forwarding table after you change the RP configuration:

```
Device#clear ipv6 pim rp-map
```

clear ipv6 pim traffic

Clears counters on IPv6 PIM traffic.

Syntax	clear ipv6 pim [vrf <i>vrf-name</i>] traffic
Parameters	vrf <i>vrf-name</i>
	Specifies a VRF instance.
	traffic
	Specifies counters on IPv6 PIM traffic.
Modes	Privileged EXEC mode
Usage Guidelines	When entered without the vrf keyword, this command clears counters for all VRF instances.
Examples	This example shows how to clear IPv6 PIM traffic counters on all VRF instances:
	<pre>Device#clear ipv6 pim traffic</pre>

clear ipv6 pimsm-snoop

Clears PIM sparse mode (SM) information.

Syntax	clear ipv6 pimsm-snoop [<i>vlanvlan-id</i>] { cache [<i>ipv6-address</i>] stats }		
Parameters	vlanvlan-id	Specifies clearing information on a specific VLAN.	
	cache	Specifies clearing the PIM SM snooping cache.	
	<i>ipv6-address</i>	Specifies clearing PIM SM snooping-cache information on a specific source or group.	
	stats	Specifies clearing traffic and error counters.	

Modes	Global configuration mode
Examples	The following example clears PIM SM information from all VLANs.
	Device(config)#clear ipv6 pimsm-snoop cache
	The following example clears PIM SM information from a specific VLAN.
	Device(config)#clear ipv6 pimsm-snoop vlan 10 cache
	The following example clears PIM SM information from a specific source.
	Device(config)#clear ipv6 pimsm-snoop cache ff05::100
	The following example clears traffic and error counters from all VLANs.
	Device(config)#clear ipv6 pimsm-snoop stats

History	Release version	Command history
	8.0.20	This command was introduced.

clear ipv6 raguard

Resets the drop or permit packet counters for Router Advertisement (RA) guard policies.

Syntax	clear ipv6 raguard { <i>name</i> all }
Parameters	<p><i>name</i></p> <p>An ASCII string indicating the name of the RA guard policy of which the packet counters must be cleared.</p> <p>all</p> <p>Clears the packet counters of all RA guard policies.</p>
Modes	Global configuration mode
Usage Guidelines	To clear RA guard packet counters for all RA guard policies, use the all keyword. To clear the RA guard packet counters for a specific RA guard policy, specify the <i>name</i> of the policy.
Examples	<p>The following example clears the packet count for an RA guard policy:</p> <pre>Brocade(config)# clear ipv6 raguard policy1</pre> <p>The following example clears the packet counters for all RA guard policies:</p> <pre>Brocade(config)# clear ipv6 raguard all</pre>

clear link-oam statistics

Clears EFM-OAM statistics from all EFM-OAM-enabled interfaces.

Syntax **clear link-oam statistics**

Modes Privileged EXEC mode
Global configuration mode
EFM-OAM protocol configuration mode

Examples The following example clears EFM-OAM statistics from all EFM-OAM-enabled interfaces.
`device(config)# clear link-oam statistics`

History

Release version	Command history
08.0.30	This command was introduced.

clear macsec ethernet

Clears the MACsec traffic statistics for the specified interface.

Syntax `clear macsec ethernet device/slot/port`

Parameters `device/slot/port`
Specifies an interface by device position in stack, slot on the device, and interface on the slot.

Modes Privileged EXEC mode.

Usage Guidelines This command is supported only on the Brocade ICX 6610 in FastIron Release 08.0.20. In FastIron Release 08.0.30 and later releases, MACsec commands are also supported on the ICX 7450.

Examples In the following example, MACsec traffic statistics are cleared for interface 1/3/3 (port 3 of slot 3 on the first device in the stack).

```
device(config-dot1x-mka-1/3/3)# clear macsec ethernet 1/3/3
```

History	Release version	Command history
	08.0.20	This command was introduced.

clear mac-authentication sessions

Clears MAC authentication sessions.

Syntax	clear mac-authentication sessions { mac-address <i>mac-address</i> ethernet <i>device/slot/port</i> }				
Parameters	<p><i>mac-address</i></p> <p>Specifies the mac-address from which the MAC authentication sessions are to be cleared.</p> <p>ethernet <i>device/slot/port</i></p> <p>Specifies the interface from which the MAC authentication sessions are to be cleared.</p>				
Modes	Privileged EXEC mode.				
Usage Guidelines	Use this command to clear the MAC authentication sessions for either a specified MAC address or an ethernet interface.				
Examples	<p>The following example clears the MAC authentication session for the specified MAC address.</p> <pre>device# clear mac-authentication sessions 0000.0034.abd4</pre>				
History	<table> <tr> <th>Release version</th><th>Command history</th></tr> <tr> <td>08.0.20</td><td>This command was introduced.</td></tr> </table>	Release version	Command history	08.0.20	This command was introduced.
Release version	Command history				
08.0.20	This command was introduced.				

clear notification-mac statistics

Clears the MAC-notification statistics, such as the number of trap messages and number of MAC notification events sent.

- Syntax

clear notification-mac statistics
- Command Default

The MAC-notification statistics are available on the device.
- Modes

Global configuration
Privileged EXEC
- Usage Guidelines

MAC notification statistics can be viewed using the **show notification-mac** display command.
- Examples

The following example clears the MAC notification statistics:

```
device(config)# clear notification-mac statistics
```

History	Release version	Command history
	08.0.10	This command was introduced.

clear openflow

Clears flows from the flow table.

Syntax **clear openflow** { **flowid** *flow-id* | **all** }

Parameters **flowid** *flow-id*

Clears the given flow ID that you want to delete from the flow table.

all

Deletes all flows from the flow table.

Modes User EXEC mode

Privileged EXEC mode

Global configuration mode

Usage Guidelines When an OpenFlow rule or all flows in the flow table need to be deleted you can use the **clear openflow** command with the **all** option. To delete a single OpenFlow rule based on a flow-id, use the **clear openflow** command with the **flowid** *flow-id* options.

Examples The following example clears the flow with an ID of 6.

```
device# clear openflow flowid 6
```

The following example clears all flows in the flow table.

```
device# clear openflow all
```

History

Release

Command History

08.0.20

This command was introduced.

clear stack ipc

Clears stack traffic statistics.

Syntax	clear stack ipc
Command Default	Stack traffic statistics are collected and retained.
Modes	Privileged EXEC mode
Usage Guidelines	Use the clear stack ipc command before issuing the show stack ipc command. This helps to ensure that the data are the most recent traffic statistics for the stack. This command must be executed from the active stack controller.
Examples	The following example clears stack traffic statistics prior to using the show stack ipc command to display current stack traffic statistics.

```
device# clear stack ipc
device# show stack ipc
V15, G1, Recv: SkP0:3749372, P1:3756064, MAIL:184291175, sum:191796611, t=457152.2
Message types have callbacks:
1 :Reliable IPC message 2 :Reliable IPC atomic 4 :fragmentation, jumbo
5 :probe by mailbox 6 :rel-mailbox 7 :test ipc
8 :disable keep-alive 9 :register cache 10:ipc dnld stk
11:chassis operation 12:ipc stk boot 13:Rconsole IPC message
14:auth msg 15:ipc erase flash 16:unconfigure
17:ipc stk boot 18:ss set 19:sFlow IPC message
21:SYNC download reques 23:SYNC download 1 spec 28:SYNC client hello
30:SYNC dy chg error 32:active-uprintf 33:test auth msg
34:probe KA 39:unrel-mailbox 40:trunk-probe
Send message types:
[1]=2342639, [4]=44528, [5]=961830, [6]=37146,
[9]=73104634, [11]=137082, [14]=487007, [20]=2304,
[22]=1395, [25]=23, [26]=1901701, [29]=415888,
[34]=1827543, [39]=30451, [40]=289420,
Recv message types:
[1]=2016251, [4]=1352759, [5]=470884, 475144,
[6]=114459, 114572, [9]=367644144, [11]=1785229,
[14]=973285, 974177, [21]=1395, [30]=25,
[34]=912972, 914086, [39]=973492, 973440, [40]=700313,
Statistics:
send pkt num : 34068433, recv pkt num : 191796609,
send msg num : 79756048, recv msg num : 379902767,
send frag pkt num : 22264, recv frag pkt num : 493860,
pkt buf alloc : 34068433,
Reliable-mail send success receive duplic
target ID 1 1 0 0
target MAC 15230 15230 0 0
unrel target ID 7615 0
There is 1 current jumbo IPC session
Possible errors:
*** recv from non-exist unit 2 times: unit 5
```

History	Release version	Command history
	08.0.00a	This command was introduced.

clear statistics openflow

Clears OpenFlow statistics.

Syntax	clear statistics openflow { group meter controller }	
Parameters	group	Clears statistics for all groups.
	meter	Clears statistics for all meters.
	controller	Clears statistics for all controllers.
Modes	EXEC and Privileged EXEC mode	
	Global configuration mode	
Usage Guidelines	This command can be entered in three configuration modes as shown in the examples below.	
Examples	The following example, entered in User EXEC mode, clears statistics for all groups in User EXEC mode.	
	<pre>device> clear statistics openflow group</pre>	
	The following example, entered in Privileged EXEC mode, clears statistics for all meters in Privileged EXEC mode.	
	<pre>device> enable device# clear statistics openflow meter</pre>	
	The following examples, entered in global configuration mode, clears statistics for all controllers.	
History	<pre>device# configure terminal device(config) # clear statistics openflow controller</pre>	
	Release	Command History
	08.0.20	This command was introduced.

client-to-client-reflection

Enables routes from one client to be reflected to other clients by the host device on which it is configured.

Syntax **client-to-client-reflection**

no client-to-client-reflection

Command Default This feature is enabled.

Modes BGP configuration mode
BGP address-family IPv6 unicast configuration mode

Usage Guidelines Use the **no** form of this command to restore the default.

The host device on which it is configured becomes the route-reflector server.

When this command is entered in BGP global configuration mode, it applies only to the IPv4 address family. Use this command in BGP address-family IPv6 unicast configuration mode for BGP4+ configurations.

Examples This example configures client-to-client reflection on the BGP4 host device.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# client-to-client-reflection
```

This example disables client-to-client reflection on the BGP4+ host device.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# address-family ipv6 unicast
device(config-bgp-ipv6u)# no client-to-client-reflection
```

cluster-id

Configures a cluster ID for the route reflector.

Syntax **cluster-id** { *num* | *ip-addr* }

no cluster-id { *num* | *ip-addr* }

Command Default The default cluster ID is the device ID.

Parameters *num*

Integer value for cluster ID. Range is from 1 through 65535.

ip-addr

IPv4 address in dotted-decimal notation.

Modes BGP configuration mode

Usage Guidelines Use the **no** form of this command to restore the default.

When configuring multiple route reflectors in a cluster, use the same cluster ID to avoid loops within the cluster.

Examples This example configures a cluster ID for the route reflector.

```
device# configure terminal
device(config)# router bgp
switch(config-bgp-router)# cluster-id 1234
```

compare-routerid

Enables comparison of device IDs, so that the path-comparison algorithm compares the device IDs of neighbors that sent otherwise equal-length paths.

- Syntax** **compare-routerid**
 no compare-routerid
- Modes** BGP configuration mode
- Usage Guidelines** Use the **no** form of this command to restore the default.
- Examples** This example configures the device always to compare device IDs.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# compare-routerid
```

confederation identifier

Configures a BGP confederation identifier.

Syntax **confederation identifier** *autonomous-system number*
no confederation identifier

Command Default No BGP confederation identifier is identified.

Parameters *autonomous-system number*
 Specifies an autonomous system number (ASN). The configurable range of values is from 1 through 4294967295.

Modes BGP configuration mode

Usage Guidelines Use the **no** form of this command to remove a BGP confederation identifier.
 Use this command to configure a single AS number to identify a group of smaller autonomous systems as a single confederation.

Examples This example specifies that confederation 65220 belongs to autonomous system 100.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# local-as 65220
device(config-bgp-router)# confederation identifier 100
```

confederation peers

Configures subautonomous systems to belong to a single confederation.

Syntax **confederation peers** *autonomous-system number* [...*autonomous-system number*]

no confederation peers

Command Default No BGP peers are configured to be members of a BGP confederation.

Parameters *autonomous-system number*
Autonomous system (AS) numbers for BGP peers that will belong to the confederation. The configurable range of values is from 1 through 4294967295.

Modes BGP configuration mode

Usage Guidelines Use the **no** form of this command to remove an autonomous system from the confederation.

Examples This example configures autonomous systems 65520, 65521, and 65522 to belong to a single confederation under the identifier 100.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# local-as 65020
device(config-bgp-router)# confederation identifier 100
device(config-bgp-router)# confederation peers 65520 65521 65522
```

Syntax **connect** *stack-unit/slotnum/portnum*
 no connect *stack-unit/slotnum/portnum*

Parameters	<i>stack-unit</i>	Specifies the stack unit ID.
	<i>slotnum</i>	Specifies the slot number.
	<i>portnum</i>	Specifies the port number in the slot. If the port is part of a trunk, specify only the first port number (the odd-numbered port) in the trunk.

Usage Guidelines

- The **connect** command can only be used on the ICX 6610.
- The **no** form of this command removes the connection configuration.
- The active controller always generates a connect for live peripheral units during stack construction.
- This command is optional and can be specified only for peripheral units. You cannot override the physical connections using the **connect** command. However, you can use this command on peripheral devices to make sure that a peripheral device has the unit ID you want if a unit is replaced.
- You can use this command when configuring a mixed stack with the automatic configuration method.

```
Brocade(config-unit-3)# connect 1/3/1
Brocade(config-unit-3)# connect 4/2/3
```

History	Release	Command History
	08.0.00a	This command was introduced.

copy disk0

Copies the license, running configuration, and startup configuration from disk0 to flash.

Syntax	copy disk0 [license running-config startup-config] filename	
Parameters	license	Copies the software license from disk0 to flash.
	running-config	Copies the running configuration from disk0 to flash.
	startup-config	Copies the startup-configuration from disk0 to flash.
Modes	Privileged EXEC mode.	
Usage Guidelines	Use the show files command to verify if the running configuration and startup configuration are copied to flash correctly. Use the show license command to verify if the license is copied correctly.	
Examples	The following example shows copying the license from disk0 to flash.	
	device# copy disk0 license 20140611132829945ICX7450-PREM-LIC-SW.XML unit 1	
	Copy Software License from disk0 to Flash	
	The following example shows copying the running configuration from disk0 to flash.	
	device# copy disk0 running-config running-config	
	The following example shows copying the log file.	
	device# copy flash disk0 file ./logs/pid-log.txt pid-log-brocade	
	Done.	
History	Release version	Command history
	08.0.30	This command was introduced.

copy flash disk0

Copies the image binary stored in primary or secondary partition of the flash to the external USB flash drive.

Syntax **copy flash disk0 { file | primary | secondary } file name**

Parameters file

Specifies the file to be copied.

primary

Specifies the primary partition of the flash where the source file is located.

secondary

Specifies the secondary partition of the flash where the source file is located.

Modes Privileged EXEC mode.

Usage Guidelines Use the **show files disk0** to verify the files copied.

Examples The following example shows copying the image binary stored in the primary partition of the flash to the external USB.

```
device# copy flash disk0 primary SWR08030q040.bin
Flash Memory Write (8192 bytes per dot)
.....
.....
Copy Done.
```

The following example shows copying the core files from the flash to disk0.

```
device# copy flash disk0 file ./cores/core_1078-1.gz    core-file
Automatic copy to member units: 1
Flash Memory Write (8192 bytes per dot) ICX7450-48
Switch#. . . . .
. . . . .
. . . . .
. . . . .
. . . . .
. . . . .
Copy Done.
```

The following example shows copying the log files from flash to disk0.

```
device# copy flash disk0 file ./logs/pid-log.txt pid-log-brocade
Done.
```

History

Release version	Command history
08.0.30	This command was introduced.

copy flash scp

Uploads a copy of an OS image file from a FastIron device's primary or secondary flash memory to an SCP server. The syntax for copying an image between two devices under test (DUTs) is different from the syntax for uploading from a Brocade device to a Linux or a Windows server.

Syntax Syntax for copying an image between two DUTs:

```
copy flash scp { ipv4-address- | ipv4-hostname- | ipv6 { ipv6-address-prefix/prefix-length | ipv6-hostname- } } outgoing-interface { ethernet stackid/slot/port | ve ve-number } } [ public-key { dsa | rsa } ] [ remote-port ] remote-filename { flash:primary | secondary }
```

Syntax for uploading from a Brocade device to a Linux or a Windows server:

```
copy flash scp { ipv4-address- | ipv4-hostname- | ipv6 { ipv6-address-prefix/prefix-length | ipv6-hostname- } } outgoing-interface { ethernet stackid/slot/port | ve ve-number } } [ public-key { dsa | rsa } ] [ remote-port ] remote-filename { primary | secondary }
```

Parameters	<i>ipv4-address-</i>	Specifies the IPV4 address of the SCP server.
	<i>ipv4-hostname-</i>	Specifies the IP hostname of the SCP server.
	ipv6	Specifies the IPV6 address method for SCP file transfer.
	<i>ipv6-address-prefix/prefix-length</i>	Specifies the IPV6 address of the SCP server. You must specify this address in hexadecimal using 16-bit values between colons, as documented in RFC 2373.
	<i>ipv6-hostname-</i>	Specifies the IPv6 hostname of the SCP server.
	outgoing-interface	Specifies the interface to be used to reach the remote host.
	ethernet <i>stackid/slot/port</i>	Configures an Ethernet interface as the outgoing interface.
	ve <i>ve-number</i>	Configures a virtual interface (VE) as the outgoing interface.
	public-key	Specifies the type of public key authentication to use for the connection, either digital signature algorithm (DSA) or Rivest, Shamir, and Adelman (RSA) . If you do not configure this parameter, the default authentication type is password.
	dsa	Specifies DSA as the public key authentication.
	rsa	Specifies RSA as the public key authentication.
	<i>remote-port</i>	Specifies the remote port number for the TCP connection.
	<i>remote-filename</i>	Specifies the name of the file in the SCP server that is be transferred. You can specify up to 127 characters for the filename.
	flash:primary	Specifies the binary image in primary flash memory. Configure the flash:primary keyword when transferring files between DUTs,. See the usage note regarding using this keyword when transferring files between DUTs.
	primary	

secondary Specifies the binary image in primary flash memory.

secondary Specifies the binary image in secondary flash memory.

Modes Privileged EXEC mode

Usage Guidelines You are prompted for username and password when you configure this command.

NOTE

When transferring files between DUTs, you should configure the **flash:primary** keyword instead of the **primary** keyword because the SCP server does not support remote-filename aliases.

Examples The following example uploads a copy of an OS image file from the primary flash memory on a Brocade device to the SCP server:

```
device# copy flash scp 10.20.1.1 FCXR08011-scp.bin primary
device# copy flash scp 10.20.1.1 FCXR08011-scp.bin secondary
```

The following example uploads a copy of an OS image file from the primary flash memory on a Brocade device to an SCP server with the IP address of 172.26.51.180 :

```
device# copy flash scp 172.26.51.180 filename primary
```

The following example specifies that the SCP connection is established using SSH public key authentication:

```
device# copy flash scp 172.26.51.180 public-key dsa filename primary
```

History

Release version	Command history
08.0.20	This command was introduced.

copy running-config disk0

Copies the running configuration from internal flash to external USB flash drive.

Syntax	copy running-config disk0 {filename}	
Parameters	filename	Specifies the system's running configuration file.
Modes	Privileged EXEC.	
Usage Guidelines	Use the show files command to verify the running configuration is copied.	
Examples	The following example shows copying the running configuration from the internal flash to the external USB flash drive. device# copy running-config disk0 running-config7750	
History	Release version	Command history
	08.0.30	This command was introduced.

copy running-config scp

Uploads a copy of the running configuration file from a FastIron device to an SCP server.

Syntax **copy running-config scp** { *ipv4-address* | *ipv4-hostname* | **ipv6** { *ipv6-address* | *ipv6-hostname* } **outgoing-interface** { **ethernet** *stackid/slot/port* | **ve** *ve-number* } } [**public-key** { **dsa** | **rsa** }] [*remote-port*] *remote-filename*

Parameters	<i>ipv4-address</i>	Specifies the IPV4 address of the SCP server.
	<i>ipv4-hostname</i>	Specifies the IP hostname of the SCP server.
	ipv6	Specifies the IPV6 address method for SCP file transfer.
	<i>ipv6-address</i>	Specifies the IPV6 address of the SCP server. You must specify this address in hexadecimal using 16-bit values between colons, as documented in RFC 2373.
	<i>ipv6-hostname</i>	Specifies the IPv6 hostname of the SCP server.
	outgoing-interface	Specifies the interface to be used to reach the remote host.
	ethernet <i>stackid/slot/port</i>	Configures an Ethernet interface as the outgoing interface.
	ve <i>ve-number</i>	Configures a virtual interface (VE) as the outgoing interface.
	public-key	Specifies the type of public key authentication to use for the connection, either digital signature algorithm (DSA) or Rivest, Shamir, and Adelman (RSA) . If you do not configure this parameter, the default authentication type is password.
	dsa	Specifies DSA as the public key authentication.
	rsa	Specifies RSA as the public key authentication.
	<i>remote-port</i>	Specifies the remote port number for the TCP connection.
	<i>remote-filename</i>	Specifies the name of the file in the SCP server that is going to be uploaded. You can specify up to 127 characters for the filename.

Modes Privileged EXEC mode

Usage Guidelines You are prompted for username and password when you configure this command.

Examples The following example uploads a copy of the running configuration file from a FastIron device to a 172.26.51.180 SCP server:

```
device# copy running-config scp 172.26.51.180 runConfig
```

History	Release version	Command history
	08.0.20	This command was introduced.

copy scp flash

Downloads from an SCP server a copy of the OS image file to a FastIron's device's primary or secondary flash memory or a copy of the boot file or the signature file to the FastIron device. The syntax for copying an image between two devices under test (DUTs) is different from the syntax for downloading from a DUT to a Linux or a Windows server.

Syntax Syntax for copying an image between two DUTs:

```
copy scp flash { ipv4-address | ipv4-hostname | ipv6 { ipv6-address | ipv6-hostname } } outgoing-interface { ethernet stackid/slot/port | ve ve-number } } [ public-key { dsa | rsa } ] [ remote-port ] remote-filename { { flash:primary | secondary } | bootrom | { fips-primary-sig | fips-secondary-sig | fips-bootrom-sig } } [ icx6450 | icx6610 ]
```

Syntax for downloading from a DUT to a Linux or a Windows server:

```
copy scp flash { ipv4-address | ipv4-hostname | ipv6 { ipv6-address | ipv6-hostname } } outgoing-interface { ethernet stackid/slot/port | ve ve-number } } [ public-key { dsa | rsa } ] [ remote-port ] remote-filename { { primary | secondary } | bootrom | { fips-primary-sig | fips-secondary-sig | fips-bootrom-sig } } [ icx6450 | icx6610 ]
```

Parameters	<i>ipv4-address</i>	
	<i>ipv4-hostname</i>	Specifies the IPV4 address of the SCP server.
	ipv6	Specifies the IP hostname of the SCP server.
	<i>ipv6-address</i>	Specifies the IPV6 address method for SCP file transfer.
	<i>ipv6-hostname</i>	Specifies the IPV6 address of the SCP server.
	outgoing-interface	Specifies the IPv6 hostname of the SCP server.
	ethernet <i>stackid/slot/port</i>	Specifies the interface to be used to reach the remote host.
	ve <i>ve-number</i>	Configures an Ethernet interface as the outgoing interface.
	public-key	Configures a virtual interface (VE) as the outgoing interface.
	dsa	Specifies the type of public key authentication to use for the connection, either digital signature algorithm (DSA) or Rivest, Shamir, and Adelman (RSA) . If you do not configure this parameter, the default authentication type is password.
	rsa	Specifies DSA as the public key authentication.
	<i>remote-port</i>	Specifies RSA as the public key authentication.
	<i>remote-filename</i>	Specifies the remote port number for the TCP connection.
	flash:primary	Specifies the name of the file in the SCP server that is be transferred. You can specify up to 127 characters for the filename.

	Specifies the binary image in primary flash memory. Configure the flash:primary keyword when transferring files between DUTs. See the usage note regarding using this keyword when transferring files between DUTs.
primary	
	Specifies the binary image in primary flash memory. Configure the primary keyword when transferring files between DUTs. See the usage note regarding using this keyword when transferring files between DUTs.
secondary	
	Specifies the binary image in secondary flash memory.
bootrom	
	Specifies the boot file image in the SCP server.
fips-primary-sig	
	Specifies the signature filename in SCP server.
fips-secondary-sig	
	Specifies the signature filename in SCP server.
fips-bootrom-sig	
	Specifies the signature filename in SCP server.
icx6450	
	Specifies the FastIron ICX 6450 as the device to which the signature file is downloaded.
icx6610	
	Specifies the FastIron ICX 6610 as the device to which the signature file is downloaded.

Modes Privileged EXEC mode

Usage Guidelines You are prompted for username and password when you configure this command.

NOTE

When transferring files between DUTs, you should configure the **flash:primary** keyword instead of the **primary** keyword because the SCP server does not support remote-filename aliases.

Examples The following example copies an image from an SCP server to a Brocade device:

```
device# copy scp flash 10.20.1.1 FCXR08011.bin primary
device# copy scp flash 10.20.1.1 FCXR08011.bin secondary
```

The following example downloads a copy of the signature file from a 172.26.51.180 SCP server to a Brocade ICX 6610 device:

```
device# copy scp flash 172.26.51.180 /tftpboot/ICX6610.sig fips-primary-sig
```

History

Release version	Command history
08.0.20	This command was introduced.

copy scp license

Downloads a copy of the license file from an SCP server to a FastIron device.

Syntax	copy scp license { <i>ipv4-address-</i> <i>ipv4-hostname-</i> ipv6 { <i>ipv6-address-</i> <i>ipv6-hostname-</i> } } outgoing-interface { ethernet <i>stackid/slot/port</i> ve <i>ve-number</i> } } [public-key { dsa rsa }] [<i>remote-port</i>] <i>remote-filename</i> [unit <i>unit-id</i>]
Parameters	<p><i>ipv4-address-</i> Specifies the IPV4 address of the SCP server, using 8-bit values in dotted decimal notation.</p> <p><i>ipv4-hostname-</i> Specifies the IP hostname of the SCP server.</p> <p>ipv6 Specifies the IPV6 address method for SCP file transfer.</p> <p><i>ipv6-address-prefix/prefix-length</i> Specifies the IPV6 address of the SCP server. You must specify this address in hexadecimal using 16-bit values between colons, as documented in RFC 2373.</p> <p><i>ipv6-hostname-</i> Specifies the IPv6 hostname of the SCP server.</p> <p>outgoing-interface Specifies the interface to be used to reach the remote host.</p> <p>ethernet <i>stackid/slot/port</i> Configures an Ethernet interface as the outgoing interface.</p> <p>ve <i>ve-number</i> Configures a virtual interface (VE) as the outgoing interface.</p> <p>public-key Specifies the type of public key authentication to use for the connection, either digital signature algorithm (DSA) or Rivest, Shamir, and Adelman (RSA) . If you do not configure this parameter, the default authentication type is password.</p> <p>dsa Specifies DSA as the public key authentication.</p> <p>rsa Specifies RSA as the public key authentication.</p> <p><i>remote-port</i> Specifies the local port number for the TCP connection.</p> <p><i>remote-filename</i> Specifies the name of the file in the SCP server that is be transferred. You can specify up to 127 characters for the filename.</p> <p>unit <i>unit-id</i> Specifies the unit ID of the device in the stack. If two or more pizza-box devices are connected and acting as a single device, a single management ID is assigned to the stack.</p>
Modes	Privileged EXEC mode
Usage Guidelines	You are prompted for username and password when you configure this command.
Examples	<p>The following example downloads a copy of the license file from an SCP server to a FastIron device:</p> <pre>Device# copy scp license 172.26.21.180 /tftpboot/abc.xml unit 1 Device#</pre>

History	Release version	Command history
	08.0.20	This command was introduced.

copy scp running-config

Downloads a copy of the running configuration file from an SCP server to a FastIron device.

Syntax	copy scp running-config { <i>ipv4-address</i> <i>ipv4-hostname</i> ipv6 { <i>ipv6-address</i> <i>ipv6-hostname</i> } [outgoing-interface { ethernet <i>stackid/slot/port</i> ve <i>ve-number</i> }] } [public-key { dsa rsa }] [<i>remote-port</i>] <i>remote-filename</i> overwrite
Parameters	<p><i>ipv4-address</i> Specifies the IPV4 address of the SCP server.</p> <p><i>ipv4-hostname</i> Specifies the IP hostname of the SCP server.</p> <p>ipv6 Specifies the IPV6 address method for SCP file transfer.</p> <p><i>ipv6-address-prefix</i> Specifies the IPV6 address of the SCP server. You must specify this address in hexadecimal using 16-bit values between colons, as documented in RFC 2373.</p> <p><i>ipv6-hostname</i> Specifies the IPv6 hostname of the SCP server.</p> <p>outgoing-interface Specifies the interface to be used to reach the remote host.</p> <p>ethernet <i>stackid/slot/port</i> Configures an Ethernet interface as the outgoing interface.</p> <p>ve <i>ve-number</i> Configures a virtual interface (VE) as the outgoing interface.</p> <p>public-key Specifies the type of public key authentication to use for the connection, either digital signature algorithm (DSA) or Rivest, Shamir, and Adelman (RSA) . If you do not configure this parameter, the default authentication type is password.</p> <p>dsa Specifies DSA as the public key authentication.</p> <p>rsa Specifies RSA as the public key authentication.</p> <p><i>remote-port</i> Specifies the remote port number for the TCP connection.</p> <p><i>remote-filename</i> Specifies the name of the file in the SCP server that is be transferred. You can specify up to 127 characters for the filename.</p> <p>overwrite Specifies that the FastIron device should overwrite the current configuration file with the copied file. If you do not specify the overwrite keyword, the device copies the downloaded file into the current running or startup configuration but does not overwrite the current configuration.</p>
Modes	Privileged EXEC mode
Usage Guidelines	You are prompted for username and password when you configure this command.
Examples	<p>The following example downloads a copy of the running configuration file from an SCP server to a FastIron device:</p> <pre>device# copy scp running-config 172.26.51.180 abc.cfg</pre>

The following example downloads a copy of the running configuration file from an SCP server to a FastIron device and overwrite the current configuration file with the copied file:

```
device# copy scp running-config 172.26.51.180 abc.cfg overwrite
```

History

Release version	Command history
08.0.20	This command was introduced.

copy scp startup-config

Downloads a copy of the startup configuration file from an SCP server to a FastIron device.

Syntax	copy scp startup-config { <i>ipv4-address</i> <i>ipv4-hostname</i> ipv6 { <i>ipv6-address</i> <i>ipv6-hostname</i> } outgoing-interface { ethernet <i>stackid/slot/port</i> ve <i>ve-number</i> } } [public-key { dsa rsa }] [<i>remote-port</i>] <i>remote-filename</i>	
Parameters	<i>ipv4-address</i>	Specifies the IPV4 address of the SCP server, using 8-bit values in dotted decimal notation.
	<i>ipv4-hostname</i>	Specifies the IP hostname of the SCP server.
	ipv6	Specifies the IPV6 address method for SCP file transfer.
	<i>ipv6-address</i>	Specifies the IPV6 address of the SCP server. You must specify this address in hexadecimal using 16-bit values between colons, as documented in RFC 2373.
	<i>ipv6-hostname</i>	Specifies the IPv6 hostname of the SCP server.
	outgoing-interface	Specifies the interface to be used to reach the remote host.
	ethernet <i>stackid/slot/port</i>	Configures an Ethernet interface as the outgoing interface.
	ve <i>ve-number</i>	Configures a virtual interface (VE) as the outgoing interface.
	public-key	Specifies the type of public key authentication to use for the connection, either digital signature algorithm (DSA) or Rivest, Shamir, and Adelman (RSA) . If you do not configure this parameter, the default authentication type is password.
	dsa	Specifies DSA as the public key authentication.
	rsa	Specifies RSA as the public key authentication.
	<i>remote-port</i>	Specifies the remote port number for the TCP connection.
	<i>remote-filename</i>	Specifies the name of the file in the SCP server that is be transferred. You can specify up to 127 characters for the filename.
Modes	Privileged EXEC mode	
Usage Guidelines	You are prompted for username and password when you configure this command.	
Examples	The following example downloads a copy of the startup configuration file from an SCP server to a FastIron device:	
	device# copy scp startup-config 172.26.51.180 abc.cfg	
History	Release version	Command history
	08.0.20	This command was introduced.

copy startup-config disk0

Copies the configuration file present on the external USB to the systems startup configuration file.

Syntax `copy startup-config disk0 { filename }`

Parameters **filename**
The system's startup configuration file.

Modes Privileged EXEC.

Usage Guidelines Use the **show files** command to verify the startup configuration is copied.

Examples The following example shows copying the configuration file from the external USB to the system's startup configuration file.

```
device# copy startup-config disk0 startup-config7750
SYNCING IMAGE TO FLASH. DO NOT SWITCH OVER OR POWER DOWN THE UNIT(8192 bytes per
dot)...
```

Done.

Copy Done.

History

Release version	Command history
08.0.30	This command was introduced.

copy startup-config scp

Uploads a copy of the startup configuration file from a FastIron device to an SCP server.

Syntax	copy startup-config scp { <i>ipv4-address-</i> <i>ipv4-hostname-</i> ipv6 { <i>ipv6-address-</i> <i>ipv6-hostname-</i> } outgoing-interface { ethernet <i>stackid/slot/port</i> ve <i>ve-number</i> } } [public-key { dsa rsa }] [<i>remote-port</i>] <i>remote-filename</i>	
Parameters	<i>ipv4-address-</i>	Specifies the IPV4 address of the SCP server, using 8-bit values in dotted decimal notation.
	<i>ipv4-hostname-</i>	Specifies the IP hostname of the SCP server.
	ipv6	Specifies the IPV6 address method for SCP file transfer.
	<i>ipv6-address-prefix/prefix-length</i>	Specifies the IPV6 address of the SCP server. You must specify this address in hexadecimal using 16-bit values between colons, as documented in RFC 2373.
	<i>ipv6-hostname-</i>	Specifies the IPv6 hostname of the SCP server.
	outgoing-interface	Specifies the interface to be used to reach the remote host.
	ethernet <i>stackid/slot/port</i>	Configures an Ethernet interface as the outgoing interface.
	ve <i>ve-number</i>	Configures a virtual interface (VE) as the outgoing interface.
	public-key	Specifies the type of public key authentication to use for the connection, either digital signature algorithm (DSA) or Rivest, Shamir, and Adelman (RSA) . If you do not configure this parameter, the default authentication type is password.
	dsa	Specifies DSA as the public key authentication.
	rsa	Specifies RSA as the public key authentication.
	<i>remote-port</i>	Specifies the remote port number for the TCP connection.
	<i>remote-filename</i>	Specifies the name of the file in the SCP server that is be transferred. You can specify up to 127 characters for the filename.
Modes	Privileged EXEC mode	
Usage Guidelines	You are prompted for username and password when you configure this command.	
Examples	The following example uploads a copy of the startup configuration file from a FastIron device to a to a 172.26.51.180 SCP server: device# copy startup-config scp 172.26.51.180 my_startup_file	
History	Release version	Command history
	08.0.20	This command was introduced.

critical-vlan

Specifies the VLAN into which the client should be placed when the RADIUS server times out while authenticating or re-authenticating users.

Syntax **critical-vlan** *vlan-id*

 no critical-vlan *vlan-id*

Command Default The client is not part of the critical VLAN.

Parameters *vlan-id*

 Specifies the VLAN ID of the specific critical VLAN.

Modes Authentication mode.

Usage Guidelines The **no** form of the command disables the critical VLAN by removing the client from the VLAN.

Examples The following example enables VLAN 20 as critical VLAN.

```
device(config)# authentication
device(config-authen)# critical-vlan 20
```

History	Release version	Command history
	08.0.20	This command was introduced.

dampening

Sets dampening parameters for the route in BGP address-family mode.

Syntax	dampening { <i>half-life reuse suppress max-suppress-time</i> route-map <i>route-map</i> }		
	no dampening		
Parameters	<i>half-life</i>		Number of minutes after which the route penalty becomes half its value. Range is from 1 through 45. Default is 15.
	<i>reuse</i>		Minimum penalty below which the route becomes usable again. Range is from 1 through 20000. Default is 750.
	<i>suppress</i>		Maximum penalty above which the route is suppressed by the device. Range is from 1 through 20000. Default is 2000.
	<i>max-suppress-time</i>		Maximum number of minutes a route can be suppressed by the device. Default is 40.
	<i>route-map</i>		Enables selection of dampening values established in a route map by means of the route-map command.
	<i>route-map</i>	Name of the configured route map.	
Modes	BGP configuration mode		
	BGP address-family IPv6 unicast configuration mode		
Usage Guidelines	Use the no form of this command to disable dampening.		
	Use dampening without operands to set default values for all dampening parameters.		
	When this command is entered in BGP global configuration mode, it applies only to the IPv4 address family. Use this command in BGP address-family IPv6 unicast configuration mode for BGP4+ configurations.		
	To use the dampening values established in a route map, configure the route map first, and then enter the route-map command, followed by the name of the configured route map.		
	A full range of dampening values (<i>half-life</i> , <i>reuse</i> , <i>suppress</i> , <i>max-suppress-time</i>) can also be set by means of the set as-path prepend command.		
Examples	This example enables default dampening as an IPv4 address-family function.		
	<pre>device# configure terminal device(config)# router bgp device(config-bgp-router)# dampening</pre>		
	This example changes all the dampening values as an IPv6 address-family function.		
	<pre>device# configure terminal device(config)# router bgp device(config-bgp-router)# address-family ipv6 unicast device(config-bgp-ipv6u)# dampening 20 200 2500 40</pre>		

This example applies the dampening half-life established in a route map, configures the route map using the **set dampening** command.

```
device# configure terminal
device(config)# route-map myroutemap permit 1
device(config-route-map myroutemap)# set dampening 20
```

default-information-originate (BGP)

Configures the device to originate and advertise a default BGP4 or BGP4+ route.

Syntax **default-information-originate**

 no default-information-originate

Modes BGP configuration mode
 BGP address-family IPv6 unicast configuration mode
 BGP address-family IPv4 unicast VRF configuration mode
 BGP address-family IPv6 unicast VRF configuration mode

Usage Guidelines Use the **no** form of this command to restore the default.

When this command is entered in BGP global configuration mode, it applies only to the IPv4 address family. Use this command in BGP address-family IPv6 unicast configuration mode for BGP4+ configurations.

Examples This example originates and advertises a default BGP4 route.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# default-information-originate
```

This example originates and advertises a default BGP4 route in a nondefault VRF instance.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# address-family ipv4 unicast vrf red
device(config-bgp-ipv4u-vrf)# default-information-originate
```

History	Release version	Command history
	8.0.30	Support was added for the BGP address-family IPv6 unicast VRF configuration mode.

default-local-preference

Enables setting of a local preference value to indicate a degree of preference for a route relative to that of other routes.

Syntax **default-local-preference** *num*

no default-local-preference

Command Default The default local preference is 100.

Parameters *num*

Local preference value. Range is from 0 through 65535.

Modes BGP configuration mode

Usage Guidelines Use the **no** form of this command to restore the default.

Use this command to change the local preference value. Local preference indicates a degree of preference for a route relative to that of other routes. BGP4 neighbors can send the local preference value as an attribute of a route in an UPDATE message.

Examples This example sets the local preference value to 200.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# default-local-preference 200
```

default-metric (BGP)

Changes the default metric used for redistribution.

Syntax **default-metric** *value*

no default-metric

Command Default The default metric value is 1.

Parameters *value*

Metric value. Range is from 0 through 65535. The default metric value is 1.

Modes BGP configuration mode

BGP address-family IPv6 unicast configuration mode

Usage Guidelines Use the **no** form of this command to restore the default.

When this command is entered in BGP global configuration mode, it applies only to the IPv4 address family. Use this command in BGP address-family IPv6 unicast configuration mode for BGP4+ configurations.

Examples This example changes the default metric used for redistribution to 100.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# default-metric 100
```

default-ports

Assigns ports (interfaces) other than the factory-assigned ports as the default stacking ports.

Syntax **default-ports** *unit/slot/ port*

no default-ports

Command Default The factory-assigned default stacking ports are the only default stacking ports on the device.

Parameters *unit*

Stack unit ID for the device on which the interface resides.

slot

Stack unit slot or module on which the interface resides.

port

Interface to be used as a default stacking port.

Modes Stack unit configuration mode

Usage Guidelines The **no** form of the command restores the factory-assigned default stacking ports. Any ports you previously assigned as the default stacking ports using the **default-ports** command are overwritten.

When you use the **default-ports** command, the factory-assigned default stacking ports are no longer the default stacking ports.

Only valid stacking ports can be assigned as default stacking ports. Valid ports vary depending on the type of FastIron device.

Tagged ports cannot be assigned as default stacking ports.

The number of ports you can assign as default stacking ports varies depending on the type of FastIron device. Some devices allow you to assign two ports as the default stacking ports, and some devices allow you to assign a single port as the default stacking port.

Examples The following example assigns the stacking ports on Module 3 on the rear panel of an ICX 7750 as the default stacking ports.

```
device# configure terminal
device(config)# stack unit 1
device;(config-unit-1)# default-ports 1/3/1 1/3/4
```

disable-aging

Disables aging of MAC sessions at the global level.

Syntax	disable-aging { permitted-mac denied-mac } no disable-aging { permitted-mac denied-mac }
Command Default	Aging of MAC sessions is not disabled.
Parameters	permitted-mac Prevents permitted (authenticated and restricted) sessions from being aged out and ages denied sessions. denied-mac Prevents denied sessions from being aged out, but ages out permitted sessions.
Modes	Authentication mode
Usage Guidelines	The no form of the command does not disable aging. Use this command to disable the aging of MAC sessions. Use the disable-aging command in the authentication mode and the authentication disable-aging command at the interface level. The command entered at the interface level overrides the command entered at the authentication level.
Examples	The example disables aging for permitted MAC addresses. device(config)# authentication device(config-authen)# disable-aging permitted-mac

History	Release version	Command history
	08.0.20	This command was introduced.

disable authentication md5

Disables the MD5 authentication scheme for Network Time Protocol (NTP).

Syntax **disable authentication md5**

 no disable authentication md5

Command Default If JITC is enabled, the MD5 authentication scheme is disabled. In the standard mode, the MD5 authentication scheme is enabled.

Modes Global configuration mode

Usage Guidelines In the standard mode, both SHA1 and MD5 authentication schemes are supported. If JITC is enabled, The MD5 authentication for Network Time Protocol (NTP) is disabled by default and the **disable authentication md5** command can be seen in the running configuration. In the JITC mode, only the SHA1 option is available. The SHA1 authentication scheme must be enabled manually to define the authentication key for NTP using the **authentication-key key-id** command.

The **no** form of the command enables the MD5 authentication scheme.

Examples The following example disables the MD5 authentication scheme.

```
device(config)# disable authentication md5
```

History	Release version	Command history
	08.0.20a	This command was introduced.

distance (BGP)

Changes the default administrative distances for EBGp, IBGP, and local BGP.

Syntax	distance <i>external-distance internal-distance local-distance</i> no distance
Parameters	<p><i>external-distance</i> EBGP distance. Range is from 1 through 255.</p> <p><i>internal-distance</i> IBGP distance. Range is from 1 through 255.</p> <p><i>local-distance</i> Local BGP4 and BGP4+ distance. Range is from 1 through 255.</p>
Modes	BGP configuration mode
Usage Guidelines	<p>Use the no form of this command to restore the defaults.</p> <p>To select one route over another according to the source of the route information, the device can use the administrative distances assigned to the sources. The administrative distance is a protocol-independent metric that IP devices use to compare routes from different sources. Lower administrative distances are preferred over higher ones.</p>
Examples	<p>This example configures the device to change the administrative distance.</p> <pre>device# configure terminal device(config)# router bgp device(config-bgp-router)# distance 100 150 200</pre>

dlb-internal-trunk-hash

Changes the hashing method for inter-packet-processor (inter-pp) HiGig links that are used to connect master and slave units in ICX 7450-48 devices.

Syntax	dlb-internal-trunk-hash { inactivity-mode spray-mode } no dlb-internal-trunk-hash { inactivity-mode spray-mode }
Command Default	The hashing method is inactivity mode.
Parameters	inactivity-mode Specifies that the flow is set by the inactivity of traffic loading. spray-mode Specifies that the flow is set to receive new member assignments for every packet arrival in accordance with the traffic loading of each aggregate member.
Modes	Global configuration mode
Usage Guidelines	The no form of this command restores the default hashing method.

NOTE
This command is supported only on ICX 7450-48 devices that have master and slave units.

Dynamic load balancing (DLB) enhances hash-based load balancing by taking into account the traffic loading in the network. The inter-pp HiGig links in ICX7450-48 devices use hash-based load balancing to distribute traffic evenly. You can configure the **dlb-internal-trunk-hash** command to change the hashing method.

Examples The following example globally enables spray mode as the inter-pp links hashing method.

```
ICX7450-48P Router(config)#dlb-internal-trunk-hash spray-mode
```

History	Release version	Command history
	08.0.20	This command was introduced.

dot1x auth-filter

Applies the specified filter on the interface.

Syntax **dot1x auth-filter** *filter-id* *vlan-id*

no dot1x auth-filter *filter-id* *vlan-id*

Command Default There are no filters applied on the interface.

Parameters *filter-id*

Specifies the filter ID to be applied on the interface.

vlan-id

Specifies the VLAN ID.

Modes Interface configuration mode.

Usage Guidelines The **no** form of the command disable the dot1x auth-filter functionality. If the VLAN is not specified, the auth-default-vlan is used.

The following rules apply when using the **dot1x auth-filter** command:

- The maximum number of filters that can be bound to a port is limited by the `mac-filter-port` default or a configured value.
- The filters must be applied as a group. For example, if you want to apply four filters to an interface, they must all appear on the same command line.
- You cannot add or remove individual filters in the group. To add or remove a filter on an interface, apply the filter group again containing all the filters you want to apply to the port.
- If you apply a filter group to a port that already has a filter group applied, the older filter group is replaced by the new filter group.
- If you add filters to or modify the dot1x authentication filter, the system clears all 802.1X sessions on the port. Consequently, all users that are logged in will need to be re-authenticated.

Examples The following example applies the dot1x filter on a specific VLAN.

```
device(config)# authentication
device(config-authen)# interface ethernet 1/1/1
device(config-if-e1000-1/1/1)# dot1x auth-filter 1 2
```

History	Release version	Command history
	08.0.20	This command was introduced.

Syntax `dot1x enable`

dot1x enable ethernet *stackid/slot/port*

no dot1x enable [all | ethernet *stackid/slot/port*]

Parameters all

Enables dot1x authentication on all interfaces.

ethernet *stackid/slot/port*

Enables dot1x authentication on the specified interface.

Modes Authentication mode.

Usage Guidelines The **no** form of the command disables dot1x authentication.

Examples The following example enables dot1x authentication on all interfaces.

```
device(config)# authentication
device(config-authen)# dot1x enable all
```

The following example shows enabling dot1x authentication on ethernet interface 1/1/1.

```
device(config)# authentication
device(config-authen)# dot1x enable ethernet 1/1/1
```

131

dot1x guest-vlan

Specifies the guest VLAN ID at the global level.

Syntax **dot1x guest-vlan** *vlan-id*
no dot1x guest-vlan *vlan-id*

Command Default The guest VLAN ID is not specified.

Parameters *vlan-id*
Specifies the VLAN ID of the guest VLAN.

Modes dot1x configuration mode.

Usage Guidelines The **no** form of this command disables the functionality.
Use this command when the client does not support the dot1x authentication, so that the client can access default privileges.

Examples The following example specifies the guest VLAN.

```
device(config)# authentication
device(config-authen)# dot1x guest-vlan 7
```

History	Release version	Command history
	08.0.20	This command was introduced.

dot1x max-reauth-req

Specifies the maximum number of Extensible Authentication Protocol (EAP) frame retransmissions.

Syntax **dot1x max-reauth-req** *count*
no dot1x max-reauth-req *count*

Command Default The EAP frame retransmissions are not specified.

Parameters *count*
Specifies the EAP frame re-transmissions. This is a number from 1 through 10. The default is 2.

Modes Authentication mode.

Usage Guidelines The **no** form of this command will disable this functionality.

The Brocade device retransmits the EAP-request/identity frame a maximum of two times. If no EAP response/identity frame is received from the client after two EAP-request/identity frame re-transmissions (or the amount of time specified with the max-reauth-req command), the device restarts the authentication process with the client.

You can optionally change the number of times the Brocade device should retransmit the EAP request/identity frame.

Examples The following example configures the device to retransmit an EAP-request/identity frame to a client a maximum of three times.

```
device(config)# authentication
device(config-authen)# dot1x max-reauth-req 3
```

History	Release version	Command history
	08.0.20	This command was introduced.

dot1x-mka-enable

Enables MACsec Key Agreement (MKA) capabilities on a licensed device and enters dot1x-mka configuration mode.

Syntax **dot1x-mka-enable**

 no dot1x-mka-enable

Command Default No MACsec capability is available.

Modes Global configuration

Usage Guidelines This command is supported only on the Brocade ICX 6610 in FastIron Release 08.0.20. In FastIron Release 08.0.30 and later releases, MACsec commands are also supported on the ICX 7450.

 The **no** form of this command disables the MKA and MACsec functionality on all ports. This may require the already authenticated hosts to re-authenticate.

 Use the **dot1x-mka-enable** command to enable MACsec on an already licensed device. Commands may be visible, but they do not work on a non-licensed device.

Examples The following example enables MACsec capabilities on the device.

```
device(config)# dot1x-mka-enable
device(config-dot1x-mka)#
```

History	Release version	Command history
	08.0.20	This command was introduced.

Related Commands [enable-mka](#), [mka-cfg-group](#)

dot1x timeout

Describes the timeout parameters applicable to the device.

Syntax **dot1x timeout** {**quiet-period** *seconds*| **tx-period** *seconds* | **supplicant** *seconds* }
no dot1x timeout {**quiet-period** *seconds*| **tx-period** *seconds* | **supplicant** *seconds* }

Command Default The timeout parameters are not applied to the device.

Parameters **quiet-period** *seconds*
 Specifies the time, in seconds, that the device waits before trying to re-authenticate the client. The quiet period can be from 1 through 4294967295 seconds. The default is 60 seconds. If the Brocade device is unable to authenticate the client, the Brocade device waits a specified amount of time before trying again. The amount of time the Brocade device waits is specified with the quiet period parameter.

tx-period *seconds*
 Specifies the EAP request retransmission interval, in seconds, with the client. By default, if the Brocade device does not receive an EAP-response/identity frame from a client, the device waits 30 seconds, then retransmits the EAP-request/identity frame. You can optionally change the amount of time the Brocade device waits before re-transmitting the EAP-request/identity frame to the client. If the client does not send back an EAP-response/identity frame within 60 seconds, the device will transmit another EAP-request/identity frame. The tx-period is a value from 1 through 4294967295. The default is 30 seconds.

supplicant *seconds*
 By default, when the Brocade device relays an EAP-Request frame from the RADIUS server to the client, it expects to receive a response from the client within 30 seconds. You can optionally specify the wait interval using the **supplicant** *seconds* parameters.

Modes Authentication mode.

Usage Guidelines The **no** form of the command disables dot1x timeout.

Examples The following example specifies the quiet period as 30 seconds.

```
device(config)# authentication
device(config-authen)# dot1x enable
device(config-authen)# dot1x timeout quiet-period 30
```

History		
	Release version	Command history
	08.0.20	This command was introduced.

eee

eee

Enables Energy Efficient Ethernet (EEE) globally, per port or on a range of ports.

- Syntax

eee

no eee
- Command Default

Energy Efficient Ethernet is not enabled.
- Modes

Global configuration mode
Interface configuration mode
- Usage Guidelines

The **no** form of the command disables Energy Efficient Ethernet.
- Examples

The following example enables Energy Efficient Ethernet globally.

device(config)# eee
EEE Feature Enabled

The following example enables Energy Efficient Ethernet on multiple ports.

```
device(config)# interface ethernet 1/1/1 to 1/1/12
device(config-mif-1/1/1-1/1/12)# eee
EEE Feature Enabled
EEE Feature Enabled on port 1/1/1
EEE Feature Enabled on port 1/1/2
EEE Feature Enabled on port 1/1/3
EEE Feature Enabled on port 1/1/4
EEE Feature Enabled on port 1/1/5
EEE Feature Enabled on port 1/1/6
EEE Feature Enabled on port 1/1/7
EEE Feature Enabled on port 1/1/8
EEE Feature Enabled on port 1/1/9
EEE Feature Enabled on port 1/1/10
EEE Feature Enabled on port 1/1/11
EEE Feature Enabled on port 1/1/12
```

The following example enables Energy Efficient Ethernet per port.

```
device(config)# interface ethernet e1000-1/1/1
device(config-if-e1000-1/1/1)# eee
EEE Feature Enabled EEE on port 1/1/1
```

History	Release version	Command history
	08.0.30	This command was introduced.

egress-buffer-profile

Attaches a user-configured egress buffer profile to one or more ports.

Syntax **egress-buffer-profile** *profile-name*
no egress-buffer-profile *profile-name*

Command Default If a port is not attached to a user-configured egress buffer profile, it uses the default egress buffer profile.

Parameters *profile-name*
Specifies the name of the egress buffer profile to be attached to the port.

Modes Interface mode
Multiple-interface mode

Usage Guidelines The **no** form of this command removes a user-configured egress buffer profile from the port and the port uses the default egress buffer profile.

You must configure an egress buffer profile before you can attach it to a port.

Only one egress buffer profile at a time can be attached to any port. You can attach an egress buffer profile to more than one port.

Examples The following example attaches an egress buffer profile named egress1 to a port:
`Device(config-if-e10000-1/1/1)# egress-buffer-profile egress1`

The following example attaches an egress buffer profile named egress2 to multiple ports:
`Device(config-mif-1/1/2-1/1/16)# egress-buffer-profile egress2`

The following example removes an egress buffer profile named egress2 from multiple ports:
`Device(config-mif-1/1/2-1/1/16)# no egress-buffer-profile egress2`

History		
	Release version	Command history
	8.0.10	This command was introduced.

enable-accounting

Enables Access Control List (ACL) accounting for IPv4 and IPv6 named ACLs.

Syntax	enable-accounting no enable-accounting
Command Default	This option is disabled.
Modes	IPv4 and IPv6 access-list configuration modes
Usage Guidelines	This is only applicable to named ACLs. The no form of this command disables ACL accounting on the associated ACL interface.
Examples	The following example enables IPv6 ACL accounting. The named access-list must be configured before enabling the ACL accounting.

```
device(config)# ipv6 access-list v6
device(config-ipv6-access-list-v6)# enable-accounting
```

The following example enables ACL accounting for an IPv4 named ACL.

```
device(config)# ip access-list standard std
device(config-std-nacl)# permit 10.10.10.0/24
device(config-std-nacl)# deny 10.20.20.0/24
device(config-std-nacl)# enable-accounting
```

History	Release version	Command history
	08.0.10	This command was introduced.

enable-mka

Enables MACsec Key Agreement (MKA) on a specified interface and changes the mode to dot1x-mka-interface mode to enable related parameters to be configured.

Syntax **enable-mka ethernet device/slot/port**
no enable-mka ethernet device/slot/port

Command Default MKA is not enabled on an interface.

Parameters **ethernet device/slot/port**
 Specifies an Ethernet interface and the number of the device, the slot on the device, and the port on that slot.

Modes dot1x-mka-interface mode

Usage Guidelines When the **no** version of the command is executed, MACSec is removed from the port.
 This command is supported only on the Brocade ICX 6610 in FastIron Release 08.0.20. In FastIron Release 08.0.30 and later releases, MACsec commands are also supported on the ICX 7450.
 For a MACsec channel to be created between two ports, both ports and devices designated must have MACsec enabled and configured.

Examples The following example enables MACsec on port 2, slot 3 of the first device in the stack.

```
device(config)# dot1x-mka-enable
device(config-dot1x-mka)# enable-mka ethernet 1/3/2
device(config-dot1x-mka-1/3/2)#
```

History

Release version	Command history
08.0.20	This command was introduced.

enforce-first-as

Enforces the use of the first autonomous system (AS) path for external BGP (EBGP) routes.

Syntax **enforce-first-as**

no enforce-first-as

Command Default This option is disabled.

Modes BGP configuration mode

Usage Guidelines Use the **no** form of this command to restore the default.

This command causes the router to discard updates received from EBGP peers that do not list their AS number as the first AS path segment in the AS_PATH attribute of the incoming route.

Examples This example configures the device to enforce the use of the first AS path.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# enforce-first-as
```

errdisable packet-inerror-detect

Enables the device to monitor configured ports for inError packets and defines the sampling time interval in which the number of inError packets is counted.

Syntax **errdisable packet-inerror-detect** *sampling-interval*

 no errdisable packet-inerror-detect *sampling-interval*

Command Default There is no monitoring for inError packets on any port of the device.

Parameters *sampling-interval*

 Specifies the sampling interval in seconds. It can take a value in the inclusive range of 2 through 60 seconds.

Modes Global configuration mode

Usage Guidelines If the number of inError packets exceeds the configured threshold for two consecutive sampling windows, then the configured port is error-disabled. The **no** form of this command disables this monitoring.

Examples The following example sets the sampling interval in which the number of inError packets is counted to three seconds.

 device(config)# errdisable packet-inerror-detect 3

History	Release version	Command history
	07.3.00g	This command was introduced.

errdisable recovery

Enables a port to recover automatically from the error-disabled state.

Syntax **errdisable recovery cause { all | cause }**

no errdisable recovery cause { all | cause }

errdisable recovery interval time

no errdisable recovery interval time

Command Default The ports in the error-disabled state are not recovered.

Parameters **all**

Enables the ports to automatically recover from an error-disabled state caused by reasons such as BPDU guard violation, the number of inError packets exceeding the configured threshold, a loop-detection violation, or due to reception of a critical event from the remote device in the case of EFM-OAM interface.

cause

Configures the ports to recover from an error-disabled state caused by a specific reason which can be any of the following:

- **bpduguard**
- **loam-critical-event**
- **loop-detection**
- **packet-inerror-detect**

bpduguard

Configures the port to recover from the error-disabled state if the state was caused because of BPDU guard violation.

loam-critical-event

Configures the EFM-OAM interface to recover from the error-disabled state if the state was caused due to reception of a critical event from the remote device.

loop-detection

Configures the port to recover from the error-disabled state if the state was caused because of loop detection.

packet-inerror-detect

Configures the port to recover from the error-disabled state if the state was caused because the number of inError packets exceeded the configured threshold.

interval

Configures a timeout value for the recovery mechanism when the port is in an error-disabled state. Upon the expiry of the timeout value, the ports are automatically recovered.

time

Specifies the recovery time interval in seconds for the device to wait before automatically recovering the ports. The valid values are from 10 through 65535 seconds. The default recovery timeout value is 300 seconds.

Modes Global configuration mode

Usage Guidelines When automatic recovery re-enables the port, the port is not in the error-disabled state, but it can remain down for other reasons, such as the Tx/Rx of the fibre optic not being seated properly. Thus, the port is not able to receive the signal from the other side. In this case, after the optic is inserted correctly, you should manually disable the port and then enable it.

The **no** form of the **errdisable recovery cause** command disables the error-disabled recover functionality.

The **no** form of the **errdisable recovery interval** command reverts to the default recovery time interval value.

Examples The following example configures the device to recover the port from the error-disabled state caused because of BPDU guard violation.

```
device(config)# errdisable recovery bpduguard
```

The following example configures the device to recover the EFM-OAM interface from the error-disabled state caused by reception of a critical event from the remote device.

```
device(config)# errdisable recovery loam-critical-event
```

The following example configures the device to recover the port from the error-disabled state caused because of loop detection.

```
device(config)# errdisable recovery loop-detection
```

The following example configures the device to recover the port from the error-disabled state caused because the number of inError packets exceeded the configured threshold.

```
device(config)# errdisable recovery packet-inerror-detect
```

The following example configures the error-disabled recovery timeout interval as 120 seconds.

```
device(config)# errdisable recovery interval 120
```

History

Release version	Command history
08.0.30	The loam-critical-event option was introduced.

ethernet (EFM-OAM)

Enables or disables EFM-OAM on an interface or multiple interfaces.

Syntax	<p>ethernet <i>stackid/slot/port</i> [[to <i>stackid/slot/port</i>] [ethernet <i>stackid/slot/port</i>] ...] { active passive allow-loopback remote-failure critical-event action block-interface }</p> <p>no ethernet <i>stackid/slot/port</i> [[to <i>stackid/slot/port</i>] [ethernet <i>stackid/slot/port</i>] ...] { active passive allow-loopback remote-failure critical-event action block-interface }</p>
Command Default	The EFM-OAM is disabled locally on an interface.
Parameters	<p>ethernet <i>stackid/slot/port</i> Specifies the interface.</p> <p>to Configures the range of interfaces to enable EFM-OAM.</p> <p>active Sets the EFM-OAM operational mode as active on the interface.</p> <p>passive Sets the EFM-OAM operational mode as passive on the interface.</p> <p>allow-loopback Sets the EFM-OAM operational mode as passive on the interface.</p> <p>remote-failure critical-event action block-interface Enables the interface to respond to a loopback request from the remote device. Configures the device to block the remote interface upon reception of a critical event information from the remote interface.</p>
Modes	EFM-OAM protocol configuration mode
Usage Guidelines	<p>When the active mode is specified, the device can send OAMPDU packets over the port to initiate an EFM-OAM discovery process. For the discovery process to be initiated, the EFM-OAM protocol must be enabled.</p> <p>When the passive mode is specified, the device cannot use the port to send OAMPDU packets, but can respond if it receives OAMPDUs from the remote device.</p> <p>When both peers are in passive mode (abnormal configuration), EFM-OAM protocol will not converge.</p> <p>The OAMPDUs and pause frames will not be looped back in the loopback mode. All other Layer 2 protocol packets will be looped back if received on a loopbacked interface.</p> <p>The no form of the command disables the EFM-OAM locally on the specified interface.</p>
Examples	<p>The following example enables EFM-OAM on an interface and sets it to active mode.</p> <pre>device(config)# link-oam device(config-link-oam)# ethernet 1/1/3 active</pre> <p>The following example enables EFM-OAM on a range of interfaces and sets them to active mode.</p> <pre>device(config)# link-oam device(config-link-oam)# ethernet 1/1/4 to 1/1/8 active</pre> <p>The following example enables EFM-OAM on an interface and sets it to passive mode.</p> <pre>device(config)# link-oam device(config-link-oam)# ethernet 2/1/1 passive</pre> <p>The following example enables EFM-OAM on a range of interfaces and sets them to passive mode.</p> <pre>device(config)# link-oam device(config-link-oam)# ethernet 2/1/1 to 2/1/6 passive</pre>

The following example configures the interface to respond to the loopback request from the remote device.

```
device(config)# link-oam
device(config-link-oam)# ethernet 1/1/3 allow-loopback
```

The following example sets the device to block the interface when a critical event failure condition is detected.

```
device(config)# link-oam
device(config-link-oam)# ethernet 2/1/1 remote-failure critical-event action block-
interface
```

History

Release version	Command history
08.0.30	This command was introduced.

ethernet loopback

Enables the Ethernet loopback functionality on a port in the VLAN-unaware mode.

Syntax **ethernet loopback**

 no ethernet loopback

Command Default Ethernet loopback is not enabled on a port.

Modes Interface configuration mode

Usage Guidelines The Ethernet loopback functionality on a port in the VLAN-unaware mode can be configured either as flow-aware or flow-unaware. The specified port does not need to be explicitly assigned as a member of any VLAN.

To enable Ethernet loopback on a port in the VLAN-unaware mode as flow-aware, the **ethernet loopback test-mac** command must be executed before enabling the Ethernet loopback. The **ethernet loopback test-mac** command is mandatory on Brocade ICX 7750, Brocade ICX 7450, and Brocade ICX 7250 devices. To enable Ethernet loopback on these devices, you must first configure the **ethernet loopback test-mac** command. In other supported platforms, the **ethernet loopback test-mac** command is optional to enable Ethernet loopback.

A port cannot be configured as VLAN-aware and VLAN-unaware simultaneously, and the flow configuration must be either flow-aware or flow-unaware.

The **ethernet loopback** command is not supported on multiple ports (MIF) mode.

The **no** form of the command disables the Ethernet loopback functionality on the specified port.

Examples The following example configures Ethernet loopback on a specific port in the VLAN-unaware mode as flow-unaware.

```
device(config)# interface ethernet 1/1/1
device(config-if-e1000-1/1/1)# ethernet loopback
```

The following example configures Ethernet loopback in VLAN-unaware mode as flow-aware.

```
device# configure terminal
device(config)# interface ethernet 1/1/1
device(config-if-e1000-1/1/1)# ethernet loopback test-mac 1111.2222.3333
4444.5555.5555
device(config-if-e1000-1/1/1)# ethernet loopback
```

History	Release version	Command history
	08.0.30	This command was introduced.

ethernet loopback (VLAN-aware)

Configures the Ethernet loopback functionality on one or a set of ports in a specific VLAN (VLAN-aware mode).

Syntax **ethernet loopback ethernet** *stackid/slot/port* [[**to** *stackid/slot/port*] [**ethernet** *stackid/slot/port*]...]

no ethernet loopback ethernet *stackid/slot/port* [[**to** *stackid/slot/port*] [**ethernet** *stackid/slot/port*]...]

Command Default Ethernet loopback is not enabled on any port in a VLAN.

Parameters	ethernet	Specifies the Ethernet interface.
	to	
	<i>stackid/slot/port</i>	Configures the range of ports.
		Specifies the interface details.

Modes VLAN configuration mode

Usage Guidelines

The Ethernet loopback functionality on a port in the VLAN-aware mode can be configured either as flow-aware or flow-unaware. The ports on which Ethernet loopback is being enabled must be explicitly assigned as a member of the VLAN.

To enable Ethernet loopback on a port in the VLAN-aware mode as flow-aware, the **ethernet loopback test-mac** command must be executed for the specific port from the interface mode before enabling Ethernet loopback. The **ethernet loopback test-mac** command is mandatory on Brocade ICX 7750, Brocade ICX 7450, and Brocade ICX 7250 devices. To enable Ethernet loopback on these devices, you must first configure the **ethernet loopback test-mac** command. In other supported platforms, the **ethernet loopback test-mac** command is optional to enable Ethernet loopback.

A port cannot be configured as VLAN-aware and VLAN-unaware simultaneously, and the flow configuration must be either flow-aware or flow-unaware.

The **ethernet loopback** command in VLAN-aware mode is not supported on VLAN Group, VLAN Range, or multi-range VLAN (MVLAN) mode.

The **ethernet loopback** command VLAN-aware mode cannot be configured on a set of VLANs that share a Layer 2 topology (Topology Group).

The **no** form of the command disables Ethernet loopback from the ports of the specified VLAN.

Examples The following example configures Ethernet loopback in VLAN-aware mode as flow-aware.

```
device(config)# interface ethernet 1/1/1
device(config-if-e1000-1/1/1)# ethernet loopback test-mac 1111.2222.3333
4444.5555.5555
device(config-if-e1000-1/1/1)# exit
device(config)# vlan 100
device(config-vlan-100)# ethernet loopback ethernet 1/1/1 to 1/1/10
```

The following example configures Ethernet loopback on a port in VLAN-aware mode as flow-unaware.

```
device(config)# vlan 100
device(config-vlan-100)# ethernet loopback ethernet 1/1/1
```

The following example configures Ethernet loopback on a range of ports in VLAN-aware mode as flow-unaware.

```
device(config)# vlan 100
device(config-vlan-100)# ethernet loopback ethernet 1/1/1 to 1/1/10
```

The following example configures Ethernet loopback on two separate ports in VLAN-aware mode as flow-unaware.

```
device(config)# vlan 100
device(config-vlan-100)# ethernet loopback ethernet 1/1/1 ethernet 1/2/3
```

History	Release version	Command history
	08.0.30	This command was introduced.

ethernet loopback test-mac

Configures the port as flow-aware by specifying the source and destination MAC addresses of the flow on the interface.

Syntax `ethernet loopback test-mac destination-MAC source-MAC`

no ethernet loopback test-mac destination-MAC source-MAC

Command Default	The port is flow-unaware.
------------------------	---------------------------

Parameters *destination-MAC*

Specifies the flow parameter destination MAC address of the traffic.

source-MAC

Specifies the flow parameter source MAC address of the traffic.

Modes Interface configuration mode

Usage Guidelines You must configure the **ethernet loopback test-mac** command on Brocade ICX 7750, Brocade ICX 7450, and Brocade ICX 7250 devices before enabling Ethernet loopback. In other supported platforms, configure the **ethernet loopback test-mac** command only if you require the port to be flow-aware.

The source MAC address and destination MAC address must be unicast MAC addresses and the source MAC address must be unique across the network for proper Ethernet loopback operation.

You cannot configure a port as flow-aware and flow-unaware simultaneously. The flow can be configured on an in-service Ethernet loopback port. However, the flow configuration cannot be modified or removed if there is an ongoing loopback service on the interface.

The **ethernet loopback test-mac** command is not supported in multi-range VLAN (MVLAN) mode.

The **no** form of the command removes the flow configuration for the specified port.

Examples The following example configures the flow on a specific port.

```
device(config)# interface ethernet 1/1/1
device(config-if-e1000-1/1/1)# ethernet loopback test-mac
1111.2222.3333/4444.5555.5555
```

History

Release version	Command history
08.0.30	This command was introduced.

ethernet loopback test-mac

Commands F - J

• failover.....	153
• fast-external-fallover	154
• filter-strict-security enable.....	155
• flash-timeout.....	156
• flow-control.....	157
• force-up ethernet.....	158
• format disk0.....	159
• graceful-restart (BGP).....	160
• graft-retransmit-timer.....	162
• hardware-drop-disable.....	163
• hello-interval.....	164
• hello-timer.....	165
• hitless-failover enable.....	166
• inactivity-timer.....	167
• inline power	168
• inline power install-firmware scp.....	171
• interface tunnel	173
• ip arp inspection validate.....	174
• ip bootp-use-intf-ip.....	175
• ip dhcp-client continuous-mode max-duration.....	176
• ip dhcp-client discover-interval.....	177
• ip dscp-remark	178
• ip igmp group-membership-time.....	179
• ip igmp max-response-time.....	180
• ip igmp port-version.....	181
• ip igmp proxy.....	182
• ip igmp query-interval.....	183
• ip igmp tracking.....	184
• ip igmp version.....	185
• ip max-mroute.....	186
• ip mroute.....	187
• ip mroute (next hop).....	188
• ip mroute next-hop-enable-default.....	189
• ip mroute next-hop-recursion.....	190
• ip multicast.....	191
• ip multicast age-interval.....	192
• ip multicast disable-flooding.....	193
• ip multicast leave-wait-time.....	194
• ip multicast max-response-time.....	195
• ip multicast mcache-age.....	196
• ip multicast query-interval.....	197
• ip multicast report-control.....	198
• ip multicast verbose-off.....	199

• ip multicast version.....	200
• ip multicast-routing rpf-check mac-movement	201
• ip multicast-nonstop-routing.....	202
• ip pcp-remark	203
• ip pim.....	204
• ip pim border.....	205
• ip pim dr-priority.....	206
• ip pim neighbor-filter.....	207
• ip pimsm-snooping.....	208
• ip pim-sparse.....	209
• ip ssh encryption disable-aes-cbc.....	210
• ip ssl min-version.....	211
• ipv6 dhcp-relay destination.....	212
• ipv6 dhcp-relay distance.....	213
• ipv6 dhcp-relay include-options.....	214
• ipv6 dhcp-relay maximum-delegated-prefixes.....	215
• ipv6 max-mroute.....	216
• ipv6 mld group-membership-time.....	217
• ipv6 mld llqi	218
• ipv6 mld max-group-address.....	219
• ipv6 mld max-response-time.....	220
• ipv6 mld port-version.....	221
• ipv6 mld query-interval.....	222
• ipv6 mld robustness.....	223
• ipv6 mld static-group.....	224
• ipv6 mld tracking.....	225
• ipv6 mroute.....	226
• ipv6 mroute (next hop).....	227
• ipv6 mroute next-hop-enable-default.....	228
• ipv6 mroute next-hop-recursion.....	229
• ipv6 multicast age-interval.....	230
• ipv6 multicast disable-flooding.....	231
• ipv6 multicast leave-wait-time.....	232
• ipv6 multicast mcache-age.....	233
• ipv6 multicast query-interval.....	234
• ipv6 multicast report-control.....	235
• ipv6 multicast verbose-off.....	236
• ipv6 multicast version.....	237
• ipv6 multicast-boundary.....	238
• ipv6 multicast-routing rpf-check mac-movement	239
• ipv6 nd router-preference.....	240
• ipv6 nd skip-interface-ra.....	241
• ipv6 neighbor inspection.....	242
• ipv6 neighbor inspection vlan.....	243
• ipv6 pim border.....	244
• ipv6 pim dr-priority.....	245
• ipv6 pim neighbor-filter.....	246
• ipv6 pim-sparse.....	247

• ipv6 raguard policy	248
• ipv6 raguard vlan	249
• ipv6 raguard whitelist	250
• ipv6 router pim.....	251
• ipv6-address auto-gen-link-local.....	252
• ipv6-neighbor inspection trust.....	253
• jitc enable.....	254
• jitc show.....	255

failover

Enables or disables LAG (Link Aggregation Group) hardware failover on the next port in LAG or on all ports in LAG.

Syntax **failover {next | all}**

no failover {next | all}

Command Default LAG hardware failover is disabled.

Parameters **next**

Specifies that failover is to be enabled or disabled on the next port in LAG.

all

Specifies that failover is to be enabled or disabled on all ports in LAG.

Modes Dynamic LAG configuration mode

Usage Guidelines The **no** form of this command disables LAG hardware failover.

LAG hardware failover is supported only on Brocade ICX 7750 devices.

Examples The following example enables LAG failover on the next port in LAG:

```
device(config)# lag one dynamic
device(config-lag-one)# failover next
```

The following example enables LAG failover on all ports in LAG:

```
device(config)# lag one dynamic
device(config-lag-one)# failover all
```

History

Release version	Command history
08.0.10	This command was introduced.

fast-external-fallover

Resets the session if a link to an EBGp peer goes down.

Syntax **fast-external-fallover**

no fast-external-fallover

Command Default This option is disabled.

Modes BGP configuration mode

Usage Guidelines Use the **no** form of this command to restore the default.

Use this command to terminate and reset external BGP sessions of a directly adjacent peer if the link to the peer goes down, without waiting for the timer, set by the BGP **timers** command, to expire. This can improve BGP convergence time, but can also lead to instability in the BGP routing table as a result of a flapping interface.

Examples This example configures the device to reset the session if a link to an EBGp peer goes down.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# fast-external-fallover
```

filter-strict-security enable

Enables or disables strict filter security for MAC authentication and dot1x authentication.

Syntax **filter-strict-security**

 no filter-strict-security

Command Default MAC addresses are blocked.

 Strict filter security is enabled for all 802.1X-enabled interfaces.

Modes Authentication mode

Usage Guidelines The **no** form of the command disables strict filter security.

When strict filter security is enabled, authentication fails if the filters contain invalid information.

Use the **filter-strict-security enable** command at the configuration authentication level and the **auth filter-strict-security enable** command at the interface level.

When strict filter security is disabled:

- If the Filter-ID attribute in the Access-Accept message contains a value that does not refer to an existing filter (a MAC address filter or IP ACL is configured on the device), then the port is authenticated but no filter is dynamically applied to it.
- If the Vendor-Specific attribute specifies the syntax for a filter, but there are insufficient system resources to implement the filter, then the port is authenticated but the filter specified in the Vendor-Specific attribute is not applied to the port.
- By default, strict security mode is enabled for all 802.1X-enabled interfaces, but you can manually disable or enable it, either globally or for specific interfaces.

Examples The following example enables strict filter security.

```
device(config)# authentication
device(config-authen)# filter-strict-security enable
```

History		
	Release version	Command history
	08.0.20	This command was introduced.

flash-timeout

Configures the flash timeout duration.

Syntax **flash-timeout** *time*
no flash-timeout *time*

Command Default The default flash timeout value is 12 minutes.

Parameters *time*
Specifies the flash timeout value in minutes and the range is from 12 to 60 minutes.

Modes Global configuration mode

Usage Guidelines The new timeout value will be effective from the next flash operation.
The **no** form of the command removes the flash timeout configuration and restores the default value of 12 minutes.

Examples The following example configures the flash timeout value as 30 minutes.
device(config)# flash-timeout 30

History		
	Release version	Command history
	08.0.30	This command was introduced.

Syntax **flow-control** [**neg-on**]
 no flow-control [**neg-on**]

Parameters	neg-on	Enables negotiation on an interface.
------------	---------------	--------------------------------------

By default, when flow control is enabled globally and auto-negotiation is on, flow control is enabled and advertised on 10/100/1000M ports. If auto-negotiation is off or if the port speed was configured manually, flow control is neither negotiated with nor advertised to the peer.

Enabling only port auto-negotiation does not enable flow control negotiation. You must use the **flow-control neg-on** command to enable flow-control negotiation.

```
Device(config)# interface ethernet 1/1/2
Device(config-if-e1000-1/1/2)flow-control neg-on
```

Release version	Command history
08.0.20	This command was modified. Enabling only auto-negotiation does not enable flow-control negotiation.

force-up ethernet

Forces the member port of a dynamic LAG (Link Aggregation Group) to be logically operational even if the dynamic LAG is not operating.

Syntax	force-up ethernet <i>port</i> no force-up ethernet <i>port</i>
Command Default	The member ports of a dynamic LAG are logically operational only if the dynamic LAG is operating.
Parameters	<i>port</i> Specifies the port.
Modes	Dynamic LAG configuration mode
Usage Guidelines	<p>The no form of the command causes the specified port to be logically operational only when the dynamic LAG is operating.</p> <p>When the dynamic LAG is not operational, the port goes to "force-up" mode. In this mode, the port is logically operational, which enables a PXE-capable host to boot from the network using this port. Once the host successfully boots from the network, the dynamic LAG can connect the host to the network with the LAG link. Even if the dynamic LAG fails later, this port is brought back to "force-up" mode and remains logically operational.</p> <p>A port that is in "force-up" mode has the operational status ("Ope") of "Frc". Use the show lag command to display the operational status.</p> <p>If any port in a dynamic LAG receives an LACPDU, the port in force-up mode leaves force-mode and becomes a member port in the dynamic LAG.</p>
Examples	<p>The following example enables PXE boot support on member port 3/1/1 of a dynamic LAG R4-dyn.</p> <pre>device(config)# lag R4-dyn device(config-lag-R4-dyn)# force-up ethernet 3/1/1</pre>

History	Release version	Command history
	08.0.01	This command was introduced.

format disk0

Formats the external USB.

Syntax **format disk0**

Modes User EXEC mode.

Examples The following example formats the external USB.

```
device# format disk0
Are you sure?(enter 'y' or 'n'): formatting The External USB (disk0) of size 64.2GB
```

History	Release version	Command history
	08.0.30	This command was introduced.

graceful-restart (BGP)

Enables the BGP graceful restart capability.

Syntax	graceful-restart [purge-time <i>seconds</i> restart-time <i>seconds</i> stale-routes-time <i>seconds</i>] no graceful-restart [purge-time <i>seconds</i> restart-time <i>seconds</i> stale-routes-time <i>seconds</i>]
Command Default	Graceful restart is enabled globally.
Parameters	<p>purge-time <i>seconds</i> Specifies the maximum period of time, in seconds, for which a restarting device maintains stale routes in the BGP routing table before purging them. Range is from 1 to 3600 seconds. The default value through 600 seconds.</p> <p>restart-time <i>seconds</i> Specifies the restart time, in seconds, advertised to graceful-restart-capable neighbors. Range is from 1 through 3600 seconds. The default value is 120 seconds.</p> <p>stale-routes-time <i>seconds</i> Specifies the maximum period of time, in seconds, that a helper device will wait for an End-of-RIB (EOR) marker from a peer. All stale paths are deleted when this time period expires. Range is from 1 through 3600 seconds. The default value is 360 seconds.</p>
Modes	BGP configuration mode BGP address-family IPv6 unicast configuration mode
Usage Guidelines	<p>Use the no form of this command to disable the BGP graceful restart capability globally for all BGP neighbors.</p> <p>Use this command to enable or disable the graceful restart capability globally for all BGP neighbors in a BGP network. If the graceful restart capability is re-enabled after a BGP session has been established, the neighbor session must be cleared for GR to take effect.</p> <p>When this command is entered in BGP global configuration mode, it applies only to the IPv4 address family. Use this command in BGP address-family IPv6 unicast configuration mode for BGP4+ configurations.</p> <p>Use this command in BGP configuration mode to disable or re-enable the BGP4 graceful restart capability globally, or to alter the default parameters. Use this command in address-family IPv6 unicast configuration mode to disable or re-enable the BGP4+ graceful restart capability globally or to alter the default parameters.</p> <p>The purge-time parameter is applicable for both restarting and helper devices. The timer starts when a BGP connection is closed. The timer ends when an EOR is received from all nodes, downloaded into BGP and an EOR sent to all neighbors. The configured purge-time timer value is effective only on the configured node.</p> <p>The restart-time parameter is applicable only for helper devices. The timer starts at the time the BGP connection is closed by the remote peer and ends when the Peer connection is established. The configured restart time timer value is effective only on the peer node, and not in the configured node. During negotiation time, the timer value is exchanged.</p> <p>The stale-routes-time parameter is applicable only for helper devices. The timer starts when the peer connection is established once the HA-failover peer node has been established. The timer ends at the time an EOR is received from the peer. The configured stale-time timer value is effective only on the configured node.</p>

Use the **clear ip bgp neighbor** command with the **all** parameter for the changes to the GR parameters to take effect immediately.

Examples This example disables the BGP4 graceful restart capability.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# no graceful-restart
```

This example re-enables the BGP4 graceful restart capability.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# local-as 1
device(config-bgp-router)# neighbor 1.1.1.1 remote-as 2
device(config-bgp-router)# graceful-restart
```

This example disables the BGP4+ graceful restart capability.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# address-family ipv6 unicast
device(config-bgp-ipv6u)# no graceful-restart
```

This example re-enables the BGP4+ graceful restart capability.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# local-as 1
device(config-bgp-router)# neighbor 1000::1 remote-as 2
device(config-bgp-router)# address-family ipv6 unicast
device(config-bgp-ipv6u)# neighbor 1000::1 activate
device(config-bgp-ipv6u)# graceful-restart
```

This example sets the purge time to 240 seconds at the IPv4 address family configuration level.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# local-as 1
device(config-bgp-router)# neighbor 1.1.1.1 remote-as 2
device(config-bgp-router)# graceful-restart
%Warning: Please clear the neighbor session for the parameter change to take effect!
device(config-bgp-router)# graceful-restart purge-time 240
```

This example sets the restart time to 60 seconds at the IPv4 address family configuration level.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# local-as 1
device(config-bgp-router)# neighbor 1.1.1.1 remote-as 2
device(config-bgp-router)# graceful-restart
%Warning: Please clear the neighbor session for the parameter change to take effect!
device(config-bgp-router)# graceful-restart restart-time 60
%Warning: Please clear the neighbor session for the parameter change to take effect!
```

This example sets the stale-routes time to 180 seconds at the IPv6 address family configuration level.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# local-as 1
device(config-bgp-router)# neighbor 1000::1 remote-as 2
device(config-bgp-router)# address-family ipv6 unicast
device(config-bgp-ipv6u)# neighbor 1000::1 activate
device(config-bgp-ipv6u)# graceful-restart
%Warning: Please clear the neighbor session for the parameter change to take effect!
device(config-bgp-ipv6u)# graceful-restart stale-routes-time 180
%Warning: Please clear the neighbor session for the parameter change to take effect!
```

graft-retransmit-timer

Configures the time between the transmission of graft messages sent by a device to cancel a prune state.

Syntax **graft-retransmit-timer** *seconds*

no graft-retransmit-timer *seconds*

Command Default The graft retransmission time is 180 seconds.

Parameters *seconds*

Specifies the time in seconds. The range is 60 through 3600 seconds. The default is 180 seconds.

Modes PIM router configuration mode

Usage Guidelines The **no** form of this command restores the default graft retransmission time, 180 seconds.

Messages sent by a device to cancel a prune state are called graft messages. When it receives a graft message, the device responds with a Graft Ack (acknowledge) message. If this Graft Ack message is lost, the device that sent it resends it.

Examples This example configures a graft retransmission timer to 90 seconds.

```
device(config)# router pim
device(config-pim-router)# graft-retransmit-timer 90
```

hardware-drop-disable

Disables passive multicast route insertion (PMRI).

Syntax **hardware-drop-disable**
no hardware-drop-disable

Command Default PMRI is enabled.

Modes PIM router configuration mode

Usage Guidelines The **no** form of this command restores the default and enables PMRI.
To prevent unwanted multicast traffic from being sent to the CPU, PIM routing and PMRI can be used together to ensure that multicast streams are forwarded out only on ports with interested receivers and unwanted traffic is dropped in hardware on Layer 3 switches. To disable this process, use the **hardware-drop-disable** command.

NOTE

Disabling hardware-drop does not immediately take away existing hardware-drop entries, they will go through the normal route aging processing when the traffic stops.

Examples This example disables PMRI.

```
device(config)#router pim
device(config-pim-router)# hardware-drop-disable
```

hello-interval

Sets the hello-interval in seconds or milliseconds for IPv4 VRRP and IPv6 VRRP.

Syntax **hello-interval** { *seconds* | *milliseconds* }

hello-interval msec *milliseconds*

no hello-interval

Command Default The hello-interval is 1 second.

Parameters *seconds*
Specifies the hello-interval in seconds from 1 through 40 seconds for IPv4 VRRP, IPv4 VRRPv3, VRRP-E, and IPv6 VRRP-E. The default is 1 second.

milliseconds
Specifies the hello-interval in seconds from 1 through 84 seconds for IPv4 VRRP, VRRP-E, and IPv6 VRRP-E and 1 through 40 seconds for IPv4 VRRPv3. The default is 1 second.

Modes VRRP virtual router ID configuration

Usage Guidelines IPv4 VRRPv2 supports the hello-interval configuration in seconds, while IPv6 VRRP supports this configuration in milliseconds; both use the CLI **hello-interval** . However, IPv4 VRRPv3 supports both the seconds and milliseconds configuration using the **hello-interval** command and the **hello-interval** command with the **msec** option.

Examples The following example configures the hello-interval on IPv4 VRRPv2 to 20 seconds.

```
device Router1(config)# interface ethernet 1/6
device Router1(config-if-1/6)# ipv4 vrrp vrid 1
device Router1(config-if-1/6-vrid-1)# hello-interval 20
```

The following example configures the hello-interval on IPv4 VRRPv3 to 200 milliseconds.

```
device Router1(config)# interface ethernet 1/6
device Router1(config-if-1/6)# ipv4 vrrp vrid 1
device Router1(config-if-1/6-vrid-1)# hello-interval msec 200
```

History	Release version	Command history
	08.0.10	This command was introduced.

hello-timer

Configures the interval at which hello messages are sent out of Protocol Independent Multicast (PIM) interfaces.

Syntax **hello-timer** *seconds*

no hello-timer *seconds*

Command Default The hello interval is 30 seconds.

Parameters *seconds*

Specifies the interval in seconds. The range is 10 through 3600 seconds. The default is 30 seconds.

Modes PIM router configuration mode

Usage Guidelines The **no** form of this command restores the default hello interval, 30 seconds. Devices use hello messages to inform neighboring devices of their presence.

Examples This example configures a hello interval of 120 seconds on all ports on a device operating with PIM.

```
device(config)# router pim
device(config-pim-router)# hello-timer 120
```

hitless-failover enable

Enables hitless stacking failover and switchover. The standby controller is allowed to take over the active role without reloading the stack when failover occurs.

Syntax **hitless-failover enable**

 no hitless-failover enable

Command Default Hitless stacking failover is enabled. In earlier releases, failover and switchover were disabled by default.

Modes Global configuration mode

Usage Guidelines Use the **no** form of the command to disable hitless stacking failover. The change takes effect immediately.

 The **hitless-failover enable** and **no hitless-failover enable** commands must be executed from the active stack controller.

 You must assign a stack mac address to the device using the **stack mac address** command before you can execute the **hitless-failover enable** command.

Examples The following example enables hitless stacking switchover and failover on the active controller for the stack.

```
device(config)# hitless-failover enable
```

History	Release version	Command history
	08.0.00a	This command was introduced.
	08.0.20	Hitless failover is enabled by default.

inline power

Configures inline power on Power over Ethernet (PoE) ports in interface configuration mode and link aggregation group (LAG) secondary ports in global configuration mode.

Syntax **inline power ethernet** *interface* [**decouple-datalink**] [**power-by-class** *power-class*] [**power-limit** *power-limit*] [**priority** *priority -value*]

no inline power ethernet *interface* [**decouple-datalink**] [**power-by-class** *power-class*] [**power-limit** *power-limit*] [**priority** *priority -value*]

NOTE

The **ethernet***interface* pair of parameters is required only if you want to configure inline power on secondary ports (you must use global configuration mode to do this).

Parameters	ethernet	Specifies an ethernet interface. You can configure the ethernet keyword only in global configuration mode.
	<i>interface</i>	Specifies the number of the ethernet interface. This is used only with the ethernet keyword.
	decouple-datalink	Specifies decoupling of datalink and PoE so that datalink state changes do not affect the PoE state. You can configure the decouple-datalink keyword in global and interface configuration modes.
	power-by-class	Specifies the power limit based on class value. The range is 0-4. The default is 0.
	power-limit	Specifies the power limit based on actual power value in mW. The range is 1000-15400 30000mW. The default is 15400 30000mW. For PoH ports, the range is 1000-95000mW, and the default is 95000mW. The power-limit value is rounded to the nearest multiple of 5 on PoH ports.
	priority	Specifies the priority for power management. The range is 1 (highest) to 3 (lowest). The default is 3.

Modes Global configuration mode
Interface configuration mode

Usage Guidelines You cannot configure inline power on PoE LAG ports in interface configuration mode because the interface-level configuration is not available in the CLI for LAG secondary ports. The **inline power ethernet** command enables you to configure inline power on secondary ports in global configuration mode.

The **decouple-datalink** keyword was introduced in Release 08.0.01 to support the inline-power functionality. The decouple-datalink functionality is not supported in releases earlier than Release 08.0.01.

WARNING

If you want to keep decoupling in place on a PoE port when you configure the **inline power ethernet** command to change its other parameters, (for example, priority) you must also configure the **decouple-datalink** keyword.

WARNING

If you downgrade to a release earlier than 08.0.01, you cannot use **inline power** commands that have the **decouple-datalink** keyword. Any **inline power** commands in the startup config will not be effective.

Examples Configuring inline power on LAG ports

The following example configures inline power on LAG ports.

```
Device(config)# lag "mylag" static id 5
Device(config-lag-mylag)# ports ethernet 1/1/1 to 1/1/4
Device(config-lag-mylag)# primary-port 1/1/1
Device(config-lag-mylag)# deploy
LAG mylag deployed successfully!
Device(config)#inline power ethernet 1/1/1 power-by-class 3
Device(config)#inline power ethernet 1/1/2
Device(config)#inline power ethernet 1/1/3 priority 2
Device(config)#inline power ethernet 1/1/4 power-limit 12000
```

Decoupling of inline power and datalink operations on PoE LAG ports

The following example decouples the behavior of the PoE and the datalink operations for PoE LAG ports. After the optional **decouple-datalink** keyword in the **inline power ethernet** command is entered, the datalink operational behavior on a PoE port does not affect the power state of the powered device (PD) that is connecting to the port.

```
Device(config)#inline power ethernet 1/1/1 decouple-datalink power-by-class 3
Device(config)#inline power ethernet 1/1/2 decouple-
datalink
Device(config)#inline power ethernet 1/1/3 decouple-datalink priority 2
Device(config)#inline power ethernet 1/1/4 decouple-datalink power-limit 12000
Device(config)# lag "mylag" static id 5
Device(config-lag-mylag)# ports ethernet 1/1/1 to 1/1/4
Device(config-lag-mylag)# primary-port 1/1/1
Device(config-lag-mylag)# deploy
LAG mylag deployed successfully!
```

Decoupling of inline power and datalink operations on regular PoE ports

The following example decouples the behavior of the PoE and the datalink operations for regular PoE ports. After the optional **decouple-datalink** keyword in the **inline power** command is entered, the datalink operational behavior on a PoE port does not affect the power state of the powered device (PD) that is connecting to the port.

```
Device(config)# interface ethernet 1/1/1
Device(config-if-e1000-1/1/1)# inline power decouple-datalink power-by-class 3
Device(config-if-e1000-1/1/1)# interface ethernet 1/1/2
Device(config-if-e1000-1/1/2)# inline power decouple-datalink
Device(config-if-e1000-1/1/2)# interface ethernet
1/1/3
Device(config-if-e1000-1/1/3)# inline power decouple-datalink priority 2
Device(config-if-e1000-1/1/3)# interface ethernet 1/1/4
Device(config-if-e1000-1/1/4)# inline power decouple-datalink power-limit 12000
```

History	Release	Command History
	08.0.01	This command was modified to run in global configuration mode using the ethernet keyword. The decouple-datalink keyword was also introduced.
	08.0.20	This command was modified to allow requisite PoH power limits.

inline power install-firmware scp

Upgrades the PoE firmware of a Brocade SX module or FastIron stacking device by downloading a firmware file from an SCP server.

Syntax **inline power install-firmware** { **stack-unit** *unit-id* | **module** *module-id* } **scp** { *ipv4-address-* | *ipv4-hostname-* | **ipv6** { *ipv6-address-* | *ipv6-hostname-* } } **outgoing-interface** { **ethernet** *stackid/slot/port* | **ve** *ve-number* } } [**public-key** { **dsa** | **rsa** }] [*remote-port*] *remote-filename*

Parameters **stack-unit** *unit-id*
Specifies the unit ID of the FastIron device in the stack to copy the PoE firmware. You must specify the stack unit when you configure the **inline power install-firmware** command to upgrade PoE firmware on a stacking device.

module *module-id*
Specifies the module ID of the Brocade SX device to copy the PoE firmware. You must specify the module when you configure the **inline power install-firmware** command to upgrade PoE firmware on a Brocade SX device.

ipv4-address-
Specifies the IPV4 address of the SCP server, using 8-bit values in dotted decimal notation.

ipv4-hostname-
Specifies the IP hostname of the SCP server.

ipv6
Specifies the IPV6 address method for SCP file transfer.

ipv6-address-prefix/prefix-length
Specifies the IPV6 address of the SCP server. You must specify this address in hexadecimal using 16-bit values between colons, as documented in RFC 2373.

ipv6-hostname-
Specifies the IPv6 hostname of the SCP server.

outgoing-interface
Specifies the interface to be used to reach the remote host.

ethernet *stackid/slot/port*
Configures an Ethernet interface as the outgoing interface.

ve *ve-number*
Configures a virtual interface (VE) as the outgoing interface.

public-key
Specifies the type of public key authentication to use for the connection, either digital signature algorithm (DSA) or Rivest, Shamir, and Adelman (RSA) . If you do not configure this parameter, the default authentication type is password.

dsa
Specifies DSA as the public key authentication.

rsa
Specifies RSA as the public key authentication.

remote-port
Specifies the remote port number for the TCP connection.

remote-filename
Specifies the name of the file in the SCP server that is be transferred. You can specify up to 127 characters for the filename.

Modes Privileged EXEC mode

Usage Guidelines You are prompted for username and password when you configure this command.

If you do not configure the type of public key authentication, the default authentication type is password.

You must specify the stack unit and module when you configure the **inline power install-firmware** command to upgrade PoE firmware on a stacking device.

Examples This example upgrades the PoE firmware of a FastIron device by downloading a firmware file from an SCP server:

```
Device#inline power install-firmware stack-unit 2 scp 2.2.2.2  
icx64xx_poeplus_02.1.0.b004.fw
```

History

Release version	Command history
08.0.20	This command was introduced.

interface tunnel

Configures a tunnel interface.

Syntax **interface tunnel** *tunnel-number*

no interface tunnel *tunnel-number*

Command Default No tunnel interface is configured.

Parameters *tunnel-number*

Specifies the tunnel number.

Modes Global configuration mode

Usage Guidelines Use the **no interface tunnel** command to remove the tunnel interface.

Examples This example creates a tunnel interface.

```
device# configure terminal
device(config)# interface tunnel 2
device(config-tunif-2)#
```

Related Commands [tunnel destination](#), [tunnel mode gre ip](#), [tunnel source](#)

ip arp inspection validate

Enables validation of the ARP packet destination MAC, ARP Packet IP, and source MAC addresses.

Syntax	ip arp inspection validate [dst-mac ip src-mac]		
Command Default	IP ARP packet destination address validation is disabled.		
Parameters	dst-mac	Checks the destination MAC address in the Ethernet header against the target MAC address in the ARP body for ARP responses. When enabled, packets with different MAC addresses are classified as invalid and are dropped.	
	ip	Checks the ARP body for invalid and unexpected IP addresses. Addresses include 0.0.0.0, 255.255.255.255, and all IP multicast addresses. Sender IP addresses are checked in all ARP requests and responses, and target IP addresses are checked only in ARP responses.	
	src-mac	Checks the source MAC address in the Ethernet header against the sender MAC address in the ARP body for ARP requests and responses. When enabled, packets with different MAC addresses are classified as invalid and are dropped.	
	Modes	Global configuration mode	
Usage Guidelines	You can enable validation of ARP packet destination addresses for a single destination address or for all destination addresses.		
	You must execute the command once for each type of ARP packet destination address you want to validate.		
Examples	The following example enables validation of the MAC, ARP Packet IP, and source MAC ARP packet destination addresses.		
	device(config)# configure terminal device(config)# ip arp inspection validate dst-mac device(config)# ip arp inspection validate src-mac device(config)# ip arp inspection validate ip		
History	Release version	Command history	
	08.0.10a	This command was introduced.	

ip bootp-use-intf-ip

Configures a Dynamic Host Configuration Protocol (DHCP) relay agent to set the source IP address of a DHCP-client packet with the IP address of the interface in which the DHCP-client packet is received.

Syntax **ip bootp-use-intf-ip**

no ip bootp-use-intf-ip

Command Default The DHCP relay agent sets the source IP address of a DHCP-client packet with the IP address of the outgoing interface to the DHCP server.

Modes Global configuration mode

Usage Guidelines You can configure ACLs on a DHCP server to permit or block access to the DHCP server from particular subnets or networks. You can then use this command on the DHCP relay agent to reveal the source subnet or network of a DHCP packet to the DHCP server, which enables the DHCP server to process or discard the DHCP traffic according to the configured ACLs.

Examples The following example configures a FastIron DHCP relay agent so that it sets the source IP address of a DHCP-client packet with the IP address of the interface on which the DHCP-client packet is received.

```
device(config)# ip bootp-use-intf-ip
```

ip dhcp-client continuous-mode max-duration

Limits the level of IPv4 address acquisition attempts globally on a DHCP client.

Syntax	ip dhcp-client continuous-mode max-duration <i>interval</i>	
	no dhcp-client continuous-mode max-duration <i>interval</i>	
Command Default	The default time is one hour.	
Parameters	<i>interval</i>	Specifies the interval value for the DHCP client to limit or stop the address acquisition feature in hours. The minimum time is 1 hour and the maximum time is 65535 hours.
Modes	Global configuration mode	
Usage Guidelines	The no form of the command disables the functionality.	
	Address acquisition stops once it reaches the configured maximum duration.	
Examples	The following example sets the maximum duration interval to two hours.	
	<pre>device(config)# ip dhcp-client continuous-mode max-duration 2</pre>	

History	Release version	Command history
	08.0.30	This command was introduced.

ip dhcp-client discover-interval

Specifies the discover interval value for the DHCP client to acquire IPv4 addresses.

Syntax **ip dhcp-client discover-interval** *interval*
no ip dhcp-client discover-interval *interval*

Command Default The default interval is 10 minutes.

Parameters *interval*
Specifies the interval value for the DHCP client to acquire IPv4 addresses, in minutes. The minimum is 5 minutes, while the maximum time is 60 minutes.

Modes Global configuration mode
Interface configuration mode

Usage Guidelines The **no** form of this command disables the functionality.
Use this command to configure the discover-interval value. The DHCP client starts sending discover messages based on the interval value you configure on the device.

Examples The following example configures the client to send discover messages at intervals of every 20 minutes. This global configuration mode is applicable only for a switch.

```
device(config)# ip dhcp-client discover-interval 20
```

The following example configures the client to send discover messages at intervals of every 20 minutes. The interface configuration mode is applicable only for a router.

```
device(config-if-e1000-0/1/1)# ip dhcp-client discover-interval 20
```

History	Release version	Command history
	08.0.30	This command was introduced.

ip dscp-remark

Enables remarking of the differentiated services code point (DSCP) field for all IPv4 packets.

Syntax **ip dscp-remark** *dscp-value*

no ip dscp-remark *dscp-value*

Command Default DSCP remarking is disabled.

Parameters *dscp-value*

Specifies the DSCP value ranges you are remarking.

Modes Global configuration mode

Interface configuration mode

Usage Guidelines The **no** form of this command disables DSCP remarking.

In interface configuration mode, the command enables DSCP remarking for the given port. The configuration can be done on a physical port, LAG, and VE port.

Examples The following example globally enables DSCP remarking on all IPv4 packets when the DSCP bit value is 40:

```
Device(config)# ip dscp-remark 40
```

The following example enables DSCP remarking on all IPv4 packets received on a specific port when the DSCP bit value is 50:

```
Device(config)# interface ethernet1/1/1
Device(config-if-e1000-1/1/1)# ip dscp-remark 50
```

ip igmp group-membership-time

Specifies how long an IGMP group remains active on an interface in the absence of a group report.

Syntax `ip igmp group-membership-time num`

no ip igmp group-membership-time *num*

Command Default By default, a group will remain active on an interface for 260 seconds in the absence of a group report.

Parameters *num*

Number in seconds, from 5 through 26000.

Modes Global configuration mode.

Usage Guidelines	<p>The no form of this command resets the group membership time interval to the default of 260 seconds.</p> <p>Group membership time defines how long a group will remain active on an interface in the absence of a group report.</p>
-------------------------	---

Examples This example specifies an IGMP (V1 and V2) membership time of 240 seconds.

```
Device(config)# ip igmp group-membership-time 240
```

ip igmp max-response-time

Defines how long a device waits for an IGMP response from an interface before determining that the group member on that interface is down and removing the interface from the group.

Syntax `ip igmp max-response-time num`

`no ip igmp max-response-time num`

Command Default The device waits 10 seconds.

Parameters *num*

Number, in seconds, from 1 through 25. The default is 10.

Modes Global configuration mode.

Usage Guidelines The **no** form of this command resets the maximum response time interval to the default of 10 seconds.

Examples To define

This example changes the IGMP (V1 and V2) maximum response time to 8 seconds.

```
Device(config)# ip igmp max-response-time 8
```

ip igmp port-version

Configures an IGMP version recognized by a physical port that is a member of a virtual routing interface.

Syntax **ip igmp port-version** *version-number* **ethernet** *port-number* [**to** **ethernet** *port-number* [**ethernet** *port-number*...]]

no ip igmp port-version *version-number* **ethernet** *port-number* [**to** **ethernet** *port-number* [**ethernet** *port-number*...]]

Command Default IGMP Version 2 is enabled.

Parameters *version-number*

Specifies the version number: 1, 2, or 3. Version 2 is the default.

ethernet *port-number*

Specifies the physical port within a virtual routing interface.

Modes Interface configuration mode

Usage Guidelines The **no** form of this command restores the default; IGMP Version 2 is enabled.

Examples This example enables IGMP Version 3 on a physical port that is a member of a virtual routing interface. It first enables IGMP Version 2 globally, then enables Version 3 on ports 1/3 through 1/7 and port e2/9. All other ports in this virtual routing interface are configured with IGMP Version 2.

```
device(config)#interface ve 3
device(config-vif-3)# ip igmp version 2
device(config-vif-3)# ip igmp port-version 3 e1/3 to e1/7 e2/9
```

ip igmp proxy

Configures IGMP proxy on an interface

Syntax **ip igmp proxy** [**group-filter***access-list*]

no ip igmp proxy [**group-filter***access-list*]

Command Default IGMP proxy is not enabled.

Parameters **group-filter**

Specifies filtering out groups in proxy report messages.

access-list

Specifies the access list name or number you want filtered out.

Modes Interface configuration mode.

Usage Guidelines The **no** form of this command disables IGMP proxy on an interface.

IGMP proxy is supported only in PIM dense environments where there are IGMP clients connected to the Brocade device. PIM DM must be enabled in passive mode.

IGMP proxy is not supported on interfaces on which PIM sparse mode (SM) or Source Specific Multicast (SSM) is enabled.

Enter the **ip igmp proxy** command without the **group-filter** keyword to remove the group-filter association without disabling the proxy.

Examples This example enables IGMP proxy on an interface. It first shows how to configure PIM globally, configure an IP address that will serve as the IGMP proxy for an upstream device on interface 1/3, enable PIM passive on the interface, and then enable IGMP proxy.

```
device(config)#router pim
device(config)#interface ethernet 1/3/3
device(config-if-e1000-1/3)#ip address 10.95.5.1/24
device(config-if-e1000-1/3)#ip pim passive
device(config-if-e1000-1/3)#ip igmp proxy
```

The following example filters out the ACL1 group in proxy report messages.

```
device(config)#router pim
device(config)#interface ethernet 1/3/3
device(config-if-e1000-1/3)#ip address 10.95.5.1/24
device(config-if-e1000-1/3)#ip pim passive
device(config-if-e1000-1/3)#ip igmp proxy group-filter ACL1
```


ip igmp tracking

Enables tracking and fast leave on an interface.

Syntax **ip igmp tracking**

no ip igmp tracking

Command Default Tracking and fast leave are disabled.

Modes Interface configuration mode.

Usage Guidelines The **no** form of this command restores the default; tracking and fast leave are disabled.
The IGMP Version 3 fast leave feature is supported in include mode but does not work in exclude mode.

Examples This example enables tracking and fast leave on a virtual routing interface.

```
Device(config)# interface ve 13  
Device(config-vif-13)# ip igmp tracking
```

This example enables tracking and fast leave on a physical interface.

```
Device(config)# i(config)#interface ethernet 1/2/2  
Device(config-if-e10000-1/2/2)# ip igmp tracking
```


Syntax **ip igmp version** *version-number*
no ip igmp version *version-number*

Parameters *version-number*

Modes Global configuration mode.
Interface configuration mode

Configure the **ip igmp port-version** command to configure an IGMP version recognized by a physical port that is a member of a virtual routing interface

```
device#configure terminal
device(config)#ip igmp version 3
```

The following example, in interface configuration mode, enables IGMP Version 3 for a physical port.

```
device#configure terminal
device(config)#interface ethernet 1/5
device(config-if-1/5)#ip igmp version 3
```

The following example, in interface configuration mode, enables IGMP Version 3 for a virtual routing interface on a physical port.

```
device#configure terminal
device(config)#interface ve 3
device(config-vif-1)#ip igmp version 3
```

ip max-mroute

Configures the maximum number of IPv4 multicast routes that are supported.

Syntax	ip max-mroute <i>num</i>
	no ip max-mroute <i>num</i>
Command Default	No maximum number of supported routes is configured.
Parameters	<i>num</i> Configures the maximum number of multicast routes supported.
Modes	VRF configuration mode
Usage Guidelines	The no form of this command restores the default (no maximum number of supported routes is configured).
Examples	The following example configures the maximum number of 20 supported IPv4 multicast routes on the VRF named my_vrf. Device(config)# vrf my_vrf Device(config)# address-family ipv4 Device(config-vrf)# ip max-mroute 20

History	Release version	Command history
	8.0.10a	This command was introduced.

ip mroute

Configures a directly connected static IPv4 multicast route.

Syntax **ip mroute** [**vrf** *vrf-name*] *ip-address ip-address mask* { **ethernet** *stackid / slot / portnum* | **ve** *num* | **tunnel** *num* } [*cost*] [**distance** *distance-value*] [**name** *name*]

no ip mroute [**vrf** *vrf-name*] *ip-address ip-address mask* { **ethernet** *stackid / slot / portnum* | **ve** *num* | **tunnel** *num* } [*cost*] [**distance** *distance-value*] [**name** *name*]

Command Default No static IPv4 multicast route is configured.

Parameters **vrf** *vrf-name*
Configures a static mroute for this virtual routing and forwarding (VRF) route.

ip-address ip-address mask
Configures the destination IPv4 address and prefix for which the route should be added.

ethernet *stackid / slot / portnum*
Configures an Ethernet interface as the route path.

ve *num*
Configures a virtual interface as the route path.

tunnel *num*
Configures a tunnel interface as the route path.

cost
Configures a metric for comparing the route to other static routes in the static route table that have the same destination. The range is 1-16; the default is 1.

distance *distance-value*
Configures the route's administrative distance. The range is 1-255; the default is 1.

name *name*
Name for this static route.

Modes VRF configuration mode

Usage Guidelines The **no** form of this command deletes a previously configured directly connected static multicast route. Connected routes on PIM enabled interfaces are automatically added to the mRTM table.

Examples The following example configures a directly connected mroute to network 10.1.1.0/24 on interface ve 10.

```
Device(config-vrf)# ip mroute 10.1.1.0 255.255.255.0 ve 10
```

History

Release version	Command history
8.0.10a	This command was introduced.

ip mroute (next hop)

Configures a static IPv4 multicast route (mroute) with a next hop..

Syntax	ip mroute [vrf <i>vrf-name</i>] <i>ip-address ip-address mask next-hop address</i> [<i>cost</i>] [distance <i>distance-value</i>] [name <i>name</i>] no ip mroute [vrf <i>vrf-name</i>] <i>ip-address ip-address mask next-hop address</i> [<i>cost</i>] [distance <i>distance-value</i>] [name <i>name</i>]	
Command Default	No next-hop static IPv4 multicast route is configured.	
Parameters	vrf <i>vrf-name</i>	Configures a static mroute for this virtual routing and forwarding (VRF) route.
	<i>ip-address ip-address mask</i>	Configures the destination IPv4 address and prefix for which the route should be added.
	<i>next-hop address</i>	Configures a next-hop address as the route path.
	<i>cost</i>	Configures a metric for comparing the route to other static routes in the static route table that have the same destination. The range is 1-16; the default is 1.
	distance <i>distance-value</i>	Configures the route's administrative distance. The range is 1 through 255; the default is 1.
	name <i>name</i>	Name for this static route.
Modes	VRF configuration mode	
Usage Guidelines	The no form of this command deletes a previously configured next-hop static IPv4 multicast route.	
Examples	The following example configures a next-hop static multicast IPv4 route to network 10.1.1.0/24 with next hop 10.2.1.1. Device(config-vrf)# ip mroute 10.1.1.0 255.255.255.0 10.2.1.1	
History	Release version	Command history
	8.0.10a	This command was introduced.

ip mroute next-hop-enable-default

Enables the option to use the default multicast route (mroute) to resolve a static IPv4 mroute next hop.

Syntax **ip mroute [vrf *vrf-name*] next-hop-enable-default**

no ip mroute [vrf *vrf-name*] next-hop-enable-default

Command Default Static mroutes are not resolved using the default mroute.

Parameters **vrf** *vrf-name*

Configures a static mroute for this virtual routing and forwarding (VRF) route.

Modes VRF configuration mode

Usage Guidelines The **no** form of this command disables the default IPv4 mroute option for next hops.

Examples The following example enables the use of the default mroute to resolve a static IPv4 mroute next hop:

```
Device(config-vrf)# ip mroute next-hop-enable-default
```

History

Release version	Command history
8.0.10a	This command was introduced.

ip multicast

Configures the IGMP mode on a specific VLAN or on all VLANs on a device as active or passive.

Syntax `ip multicast [vlan | vlan-id] [active | passive]`

`no ip multicast`

Command Default IGMP mode is passive.

Parameters `vlan` *vlan-id*

Specifies a VLAN.

active

Configures IGMP active mode, that is, the device actively sends out IGMP queries to identify multicast groups on the network and makes entries in the IGMP table based on the group membership reports it receives.

passive

Configures IGMP passive mode, that is, the device does not send queries but forwards reports to the router ports that receive queries. When passive mode is configured on a VLAN, queries are forwarded to the entire VLAN.

Modes Global configuration mode

VLAN configuration mode

Usage Guidelines The **no** form of this command returns the device to the previous IGMP mode.

When entered without the **vlan** keyword, this command configures active or passive IGMP mode on all VLANs.

Routers in the network generally handle mode. Configure active IGMP mode only on a device is in a standalone Layer 2 Switched network with no external IP multicast router attachments. If you want to configure active IGMP mode on a device in such a network, you should do so on only one device and leave the others configured as passive.

The IGMP mode configured on a VLAN overrides the mode configured globally.

Examples The following example globally configures IGMP mode as active.

```
device#configure terminal
device(config)#ip multicast active
```

This example configures IGMP mode as active on VLAN 20.

```
device#configure terminal
device(config)#config vlan 20
device(config-vlan-20)#ip multicast active
```

ip multicast age-interval

Configures the time that group entries can remain in an IGMP group table on a specific VLAN or on all VLANs.

Syntax **ip multicast age-interval** [**vlan** *vlan-id*] *interval*

no ip multicast age-interval [**vlan** *vlan-id*] *interval*

Command Default Group entries can remain in the IGMP group table for up to 260 seconds.

Parameters **vlan** *vlan-id*

Specifies a VLAN.

interval

Specifies time, in seconds, that group entries can remain in the IGMP group table. The range is 20 through 26000 seconds. The default is 260 seconds.

Modes Global configuration mode

Usage Guidelines The **no** form of this command restores the default age interval to 260 seconds.

When entered without the **vlan** keyword, this command configures the time that group entries can remain in an IGMP group table on all VLANs.

When a device receives a group membership report it makes an entry for that group in the IGMP group table. You can configure the **ip multicast age-interval** to specify how long the entry can remain in the table before the device receives another group membership report. When multiple devices are connected, they must all be configured for the same age interval, which must be at least twice the length of the query interval, so that missing one report does not stop traffic.

Non-querier age intervals must be the same as the age interval of the querier.

Examples This example configures the IGMP group-table age interval to 280 seconds.

```
device#configure terminal
device(config)#ip multicast age-interval 280
```


ip multicast disable-flooding

Disables the flooding of unregistered IPv4 multicast frames in an IGMP-snooping-enabled VLAN.

Syntax **ip multicast disable-flooding**

no ip multicast disable-flooding

Command Default The device floods unregistered IPv4 multicast frames in an IGMP-snooping-enabled VLAN.

Modes Global configuration mode

Usage Guidelines

NOTE

Disabling the flooding of unregistered IPv4 multicast frames in an IGMP-snooping-enabled VLAN is supported only on the following platforms:

- The Brocade ICX 6650
- The Brocade ICX 7750 (standalone and stacking)
- The Brocade ICX 7450 (standalone and stacking)
- The Brocade ICX 7250 (standalone and stacking)

The **no** form of this command enables the flooding of unregistered IPv4 multicast frames in an IGMP-snooping-enabled VLAN.

Support for this command on the Brocade ICX 7750 was introduced in FastIron 8.0.10d. In releases prior to FastIron 8.0.30, support for this command on the Brocade ICX 7750 was for devices in standalone mode only.

Support for this command on the Brocade ICX 7450 and Brocade ICX 7250 was introduced in FastIron 8.0.30.

After the hardware forwarding database (FDB) entry is made, the multicast traffic is switched only to the VLAN hosts that are members of the multicast group. This can avoid congestion and loss of traffic on the ports that have not subscribed to this IPv4 multicast traffic.

Examples The following example disables flooding of unregistered IPv4 multicast frames.

```
Device(config)# ip multicast disable-flooding
```

History

Release version	Command history
08.0.01	This command was introduced.

ip multicast leave-wait-time

Configures the wait time before stopping traffic to a port when a leave message is received.

Syntax `ip multicast leave-wait-time num`

`no ip multicast leave-wait-time num`

Command Default The wait time is 2 seconds.

Parameters *num*

Specifies the time, in seconds, the device should wait before stopping traffic to a port when a leave message is received. The range is 1 through 5 seconds. The default is 2 seconds.

Modes Global configuration mode

Usage Guidelines The **no** form of this command restores the default wait time.

The device sends group-specific queries once per second to ask if any client in the same port still needs this group. Because of internal timer granularity, the actual wait time is between *n* and (*n*+1) seconds (*n* is the configured value).

Examples This example configures the maximum time a client can wait before responding to a query to 1 second.

```
Device(config)#ip multicast leave-wait-time 1
```

ip multicast max-response-time

Sets the maximum number of seconds a client can wait before responding to a query sent by the device.

Syntax **ip multicast max-response-time** *interval*

no ip multicast max-response-time *interval*

Command Default The wait time is 10 seconds.

Parameters *interval*

Specifies the maximum time, in seconds, a client can wait before responding to a query sent by the switch. The range is 1 through 10 seconds. The default is 10 seconds.

Modes Global configuration mode

Usage Guidelines The **no** form of this command restores the default maximum interval.

Examples This example configures the maximum time a client can wait before responding to a query to 5 seconds.

```
Device(config)#ip multicast max-response-time 5
```

ip multicast mcache-age

Configures the time for an mcache to age out when it does not receive traffic.

Syntax `ip multicast mcache-age num`

`no ip multicast mcache-age`

Command Default The mcache ages out after the default age-out interval, which is 180 seconds for FSX 800/1600, ICX 7750, ICX 7450, and ICX 7250 devices, and 60 seconds for all other devices.

Parameters *num*

Specifies the time, in multiples of 60 seconds, the device should wait before stopping traffic to a port when a leave message is received. The range is 60 through 3600 seconds, in multiples of 60.

Modes Global configuration mode

Usage Guidelines The **no** form of this command restores the default mcache age-out time.

Multicast traffic is hardware switched. One minute before aging out an mcache, the device mirrors a packet of this mcache to CPU to reset the age. If no data traffic arrives within 60 seconds, this mcache is deleted. Configuring a lower age-out time removes resources consumed by idle streams quickly, but it mirrors packets to CPU often. Configure a higher value only when data streams are arriving consistently.

Examples This example configures the time for an mcache to age out to 180 seconds.

```
Device(config)#ip multicast mcache-age 180
```

ip multicast query-interval

Configures how often the device sends general queries when IP multicast traffic reduction is set to active mode.

Syntax **ip multicast query-interval** *interval*
no ip multicast query-interval *interval*

Command Default The query interval is 125 seconds.

Parameters *interval*
Specifies the time, in seconds, between queries. The range is 10 through 3600 seconds. The default is 125 seconds.

Modes Global configuration mode

Usage Guidelines The **no** form of this command restores the query interval to 125 seconds.
You can configure this command only when IP multicast traffic reduction is set to active IGMP snooping mode.
When multiple queries are connected, they must all be configured for the same interval.

Examples This example configures the time between queries to 120 seconds.
Device(config)#ip multicast query-interval 120

ip multicast report-control

Limits report forwarding within the same multicast group to no more than once every 10 seconds.

Syntax	ip multicast report-control no ip multicast report-control
Command Default	A device in passive mode forwards reports and leave messages from clients to the upstream router ports that are receiving queries.
Modes	Global configuration mode
Usage Guidelines	The no form of this command restores the default.

NOTE

This feature applies to IGMP V2 only. The leave messages are not rate limited.

This rate-limiting does not apply to the first report answering a group-specific query.

Configure this command to alleviate report storms from many clients answering the upstream router query.

The **ip multicast report-control** command was formerly named **ip igmp-report-control**. You can still configure the command as **ip igmp-report-control**; however, it is renamed when you configure the **show configuration** command.

Examples This example limits the rate of report forwarding within the same multicast group.

```
Device(config)#ip multicast report-control
```

ip multicast verbose-off

Turns off the error or warning messages displayed by the device when it runs out of software resources or when it receives packets with the wrong checksum or groups.

Syntax **ip multicast verbose-off**

no ip multicast verbose-off

Command Default Error and warning messages are displayed.

Modes Global configuration mode

Usage Guidelines The **no** form of this command restores display of error and warning messages .
Error and warning messages are rate-limited.

Examples This example turns off error or warning messages .
`Device(config)#ip multicast verbose-off`

ip multicast version

Configures the IGMP version for snooping globally.

Syntax **ip multicast version [2 | 3]**

no ip multicast version

Command Default IGMP version 2 is configured.

Parameters **2**
Configures IGMP version 2.

3
Configures IGMP version 3.

Modes Global configuration mode

Usage Guidelines The **no** form of this command restores the version to IGMP version 2.

If Layer 3 multicast routing is enabled on the device, Layer 2 IGMP snooping is automatically enabled.

See the description of the **multicast version** command for information on how to configure the IGMP version on a VLAN.

See the description of the **multicast port-version** command for information on how to configure the IGMP version on an individual port

Examples This example specifies IGMP version 3 on a device.

Device(config)#ip multicast version 3

ip multicast-routing rpf-check mac-movement

Triggers Reverse Path Forwarding (RPF) check on MAC movement for directly connected sources and sends a MAC address movement notification to the Protocol Independent Multicast (PIM) module which results in PIM convergence.

Syntax **ip multicast-routing rpf-check mac-movement**

no ip multicast-routing rpf-check mac-movement

Command Default RPF check on MAC movement for directly connected sources is not enabled.

Modes Global configuration mode

Usage Guidelines PIM convergence on MAC movement is applicable only in a topology where the multicast source port and PIM routers are in the same Layer 2 domain.

The **ip multicast-routing rpf-check mac-movement** command is not supported on the Brocade ICX 6650, Brocade ICX 7250, and FSX 800/FSX 1600 devices.

The **no** form of the command disables RPF check on MAC movement for directly connected sources.

Examples The following example configures RPF check on MAC movement for directly connected sources.

```
device(config)# ip multicast-routing rpf-check mac-movement
```

History	Release version	Command history
	08.0.10h	This command was introduced.
	08.0.30	Support for the ip multicast-routing rpf-check mac-movement command was added in 08.0.30 and later releases.

ip multicast-nonstop-routing

Globally enables multicast non-stop routing for all virtual routing and forwarding (VRF) instances.

Syntax **ip multicast-nonstop-routing**

no ip multicast-nonstop-routing

Command Default Multicast non-stop routing is not enabled on VRFs.

Modes Global configuration mode

Usage Guidelines The **no** form of this command restores the default non-stop routing.

Examples The following example globally enables multicast non-stop routing for all VRFs.

```
device#configure terminal
device(config)#ip multicast-nonstop-routing
```

ip pcp-remark

Enables remarking of the priority code point (PCP) field in the VLAN header for all received tagged packets.

Syntax `ip pcp-remark pcp-value`

`no ip pcp-remark pcp-value`

Command Default PCP remarking is disabled.

Parameters *pcp-value*

Specifies the PCP value ranges you are remarking.

Modes Global configuration mode

Interface configuration mode

Usage Guidelines The **no** form of this command disables PCP remarking.

In Interface configuration mode, the command enables PCP remarking for each port. The command can be configured only on Layer 2 ports. The configuration can be done on a physical port, LAG, and VE port.

Examples The following example globally enables remarking of received tagged packets when the PCP bit value is 4.

```
Device(config)# ip pcp-remark 4
```

The following example enables remarking of received tagged packets on a specific port when the PCP bit value is 5.

```
Device(config)# interface ethernet1/1/1
Device(config-if-e1000-1/1/1)# ip pcp-remark 5
```

ip pim

Configures PIM in Dense mode on an interface.

Syntax **ip pim [passive]**

no ip pim [passive]

Command Default PIM is not enabled.

Parameters **passive**

Specifies PIM passive mode on the interface.

Modes Interface configuration mode

Usage Guidelines The **no** form of this command disables PIM.

You must enable PIM globally before you enable it on an interface.

You must enable PIM on an interface before you can configure PIM passive on it.

Support for the **ip pim passive** command is implemented at Layer 3 interface (Ethernet or virtual Ethernet) level.

Because the loopback interfaces are never used to form PIM neighbors, the **ip pim passive** command is not supported on loopback interfaces.

The sent and received statistics of a PIM Hello message are not changed for an interface while it is configured as PIM passive.

Examples This example enables PIM globally, then enables it on interface 3.

```
Device(config)# router pim
Device(config-pim-router)# interface ethernet 1/1/3
Device(config-if-e10000-1/1/3)# ip address 207.95.5.1/24
Device(config-if-e10000-1/1/3)# ip pim
```

This example enables PIM passive on an interface.

```
Device(config)# router pim
device(config-pim-router)#exit
Device(config)#interface ethernet 2
Device(config-if-e1000-2)#ip pim
Device(config-if-e1000-2)#ip pim passive
Device(config-if-e1000-2)#exit
Device(config)#interface ve 2
Device(config-vif-2)#ip pim-sparse
Device(config-vif-2)#ip pim passive
Device(config-vif-2)#exit
```

ip pim border

Configures PIM parameters on an interface on a PIM Sparse border.

Syntax **ip pim border**

no ip pim border

Command Default The interface is not configured as a border device.

Modes Interface configuration mode

Usage Guidelines The **no** form of this command removes the boundary on a PIM-enabled interface.
You can configure this command only in a PIM Sparse domain, that is, you must configure the **ip pim-sparse** command before you configure the **ip pim border** command.

Examples This example adds an IPv4 interface to port 1/2/2, enables PIM Sparse on the interface and configures it as a border device.

```
Device(config)# interface ethernet 1/2/2
Device(config-if-e10000-1/2/2)# ip address 207.95.7.1 255.255.255.0
Device(config-if-e10000-1/2/2)# ip pim-sparse
Device(config-if-e10000-1/2/2)# ip pim border
```

ip pim dr-priority

Configures the designated router (DR) priority on IPv4 interfaces.

Syntax **ip pim dr-priority** *priority-value*

no ip pim dr-priority *priority-value*

Command Default The DR priority value is 1.

Parameters *priority-value*

Specifies the DR priority value as an integer. The range is 0 through 65535. The default is 1.

Modes Interface configuration mode

Usage Guidelines The **no** form of this command restores the default DR priority value, 1.

You must enable PIM globally before you enable it on an interface.

You can configure the **ip pim dr-priority** command in either Dense mode (DM) or Sparse mode (SM).

If more than one device has the same DR priority on a subnet (as in the case of default DR priority on all), the device with the numerically highest IP address on that subnet is elected as the DR.

The DR priority information is used in the DR election only if all the PIM devices connected to the subnet support the DR priority option. If at least one PIM device on the subnet does not support this option, the DR election falls back to the backwards compatibility mode in which the device with the numerically highest IP address on the subnet is declared the DR regardless of the DR priority values.

Examples This example configures a DR priority value of 50.

```
Device(config)# interface ethernet 1/3/24
Device(config-if-e10000-1/3/24)# ip pim dr-priority 50
```

ip pim neighbor-filter

Determines which devices can become PIM neighbors.

Syntax `ip pim neighbor-filter { acl-name | acl-id }`

no ip pim neighbor-filter { *acl-name* | *acl-id* }

Command Default Neighbor filtering is not applied on the interface.

Parameters *acl-name*

Specifies an ACL as an ASCII string.

acl-id

Specifies either a standard ACL as a number in the range 1 to 99 or an extended ACL as a number in the range 100 to 199.

Modes Interface configuration mode

Usage Guidelines The **no** form of this command removes any neighbor filtering applied on the interface.

You must enable PIM globally before you enable it on an interface.

You can configure the **ip pim neighbor-filter** command in either Dense mode (DM) or Sparse mode (SM).

Configure the **access-list** command to create an access-control list (ACL)that specifies the devices you want to permit and deny participation in PIM

Examples This example prevents the host from becoming a PIM neighbor on interface Ethernet 1/3/24.

```
Device(config)# interface ethernet 1/3/24
Device(config-if-e10000-1/3/24)# ip pim neighbor-filter
```

This example configures an ACL named 10 to deny a host and then prevents that host, 10.10.10.2, identified in that ACL from becoming a PIM neighbor on interface Ethernet 1/3/24.

```
Device(config)# access-list 10 deny host 10.10.10.2
Device(config)# access-list 10 permit any
Device(config)# interface ethernet 1/3/24
Device(config-if-e10000-1/3/24)# ip pim neighbor-filter 10
```

History

Release version	Command history
8.0.20a	This command was introduced.

ip pimsm-snooping

Enables PIM Sparse mode (SM) traffic snooping globally.

Syntax **ip pimsm-snooping**

no ip pimsm-snooping

Command Default PIM SM traffic snooping is disabled.

Modes Global configuration mode
VLAN configuration mode

Usage Guidelines The **no** form of this command disables PIM SM traffic snooping.

The device must be in passive mode before it can be configured for PIM SM snooping.

Use PIM SM snooping only in topologies where multiple PIM sparse routers connect through a device. PIM SM snooping does not work on a PIM dense mode router that does not send join messages and on which traffic to PIM dense ports is stopped. A PIM SM snooping-enabled device displays a warning if it receives PIM dense join or prune messages.

When PIM SM snooping is enabled globally, you can override the global setting and disable it for a specific VLAN.

Examples This example shows how to enable PIM SM traffic snooping.

```
Device(config)# ip pimsm-snooping
```

This example overrides the global setting and disable PIM SM traffic snooping on VLAN 20.

```
Device(config)# vlan 20
Device(config-vlan-20)# no ip pimsm-snooping
```


ip pim-sparse

Enables PIM Sparse on an interface that is connected to the PIM Sparse network.

Syntax **ip pim-sparse [passive]**

no ip pim-sparse [passive]

Command Default PIM Sparse is not enabled on the interface.

Parameters **passive**

Specifies PIM passive mode on the interface.

Modes Interface configuration mode

Usage Guidelines The **no ip pim-sparse** command disables PIM Sparse.

The **no ip pim-sparse passive** command disables PIM passive mode on the interface.

You must enable PIM Sparse globally before you enable it on an interface.

If the interface is on the border of the PIM Sparse domain, you also must configure the **ip pim border** command.

Examples This example adds an IP interface to port 1/2/2, then enable PIM Sparse on the interface.

```
Device(config)# interface ethernet 1/2/2
Device(config-if-e10000-2/2)# ip address 207.95.7.1 255.255.255.0
Device(config-if-e10000-2/2)# ip pim-sparse
```

ip ssh encryption disable-aes-cbc

Disables the Advanced Encryption Standard - Cipher-Block Chaining (AES-CBC) encryption mode for the Secure Shell (SSH) protocol.

Syntax **ip ssh encryption disable-aes-cbc**

 no ip ssh encryption disable-aes-cbc

Command Default If JITC is enabled, only AES-CTR encryption mode is supported and AES-CBC mode is disabled by default. In the standard mode, the AES-CBC encryption mode is enabled.

Modes Global configuration mode

Usage Guidelines The **no** form of the command enables the AES-CBC encryption mode.

Examples The following example disables the AES-CBC encryption mode.

device(config)# ip ssh encryption disable-aes-cbc

History		
	Release version	Command history
	08.0.20a	This command was introduced.

ip ssl min-version

Configures the minimum TLS version to be used to establish the TLS connection.

Syntax `ip ssl min-version { tls_1_0 | tls_1_1 | tls_1_2 }`
`no ip ssl min-version { tls_1_0 | tls_1_1 | tls_1_2 }`

Command Default For devices which act as an SSL server or HTTPS server, the default connection is with TLS1.2.
 For the Brocade device which acts as the SSL client or the syslog, OpenFlow, or secure AAA client, the TLS version is decided based on the server support.

Parameters `tls_1_0`
 Specifies TLS 1.0 as the minimum version.

`tls_1_1`
 Specifies TLS 1.1 as the minimum version.

`tls_1_2`
 Specifies TLS 1.2 as the minimum version.

Modes Global configuration mode

Usage Guidelines If `tls_1_1` is set as the minimum version, TLS 1.1 and later versions are supported.
 The **no** form of the command removes the minimum TLS version configuration and supports all TLS versions.

Examples The following example establishes the TLS connection using the TLS 1.1 version and above.

```
device(config)# ip ssl min-version tls_1_1
```

History	Release version	Command history
	08.0.20a	This command was introduced.

ipv6 dhcp-relay destination

Enables IPv6 DHCP relay agent function and specifies the ipv6-address as a destination address to which the client messages are forwarded.

Syntax	ipv6 dhcp-relay destination <i>ipv6-address</i> no ipv6 dhcp-relay destination <i>ipv6-address</i>
Command Default	The IPv6 DHCP relay agent functionality is disabled.
Parameters	<i>ipv6-address</i> Specifies the IPv6 address as a destination address to which the client messages can be forwarded.
Modes	Interface configuration
Usage Guidelines	The no form of the command removes the DHCP relay agent from the interface. You can configure up to 16 relay destination addresses on an interface.
Examples	The following example enables the DHCPv6 relay agent function and specifies the relay destination (the DHCP server) address on an interface. device(config)# interface ethernet 2/3 device(config-if-e10000-2/3)# ipv6 dhcp-relay destination 2001::2 device(config-if-e10000-2/3)# ipv6 dhcp-relay destination fe80::224:38ff:febb:e3c0 outgoing-interface ethernet 2/5

History	Release version	Command history
	08.0.10d	This command was introduced.
	08.0.30	Support for this command was added in 08.0.30 and later releases.

ipv6 dhcp-relay distance

Assigns the administrative distance to IPv6 DHCP static routes installed in the IPv6 route table for the delegated prefixes on the interface.

Syntax `ipv6 dhcp-relay distance value`

no ipv6 dhcp-relay distance *value*

Command Default	The administrative distance is not assigned.
------------------------	--

Parameters	value
------------	-------

Assigns the administrative distance to DHCPv6 static routes on the interface. The range is from 1 to 255. If the value is set to 255, then the delegated prefixes for this interface will not be installed in the IPv6 static route table.

Modes Interface configuration.

Usage Guidelines The **no** form of the command sets the parameter to a default value of 10.

The administrative distance value has to be set so that it does not replace the same IPv6 static route configured by the user.

Examples The following example sets the administrative distance value to 25.

```
device(config-if-eth2/1)# ipv6 dhcp-relay distance 25
```

History

Release version	Command history
08.0.10d	This command was introduced.
08.0.30	Support for this command was added in 08.0.30 and later releases.

ipv6 dhcp-relay include-options

Includes the interface-id parameter on the ipv6 DHCP relay agent messages.

Syntax **ipv6 dhcp-relay include-options** *interface-id*
no ipv6 dhcp-relay include-options *interface-id*

Command Default The interface-id parameter is not included on the ipv6 DHCP relay agent messages.

Parameters *interface-id*
Includes the interface-id parameter on the ipv6 DHCP relay agent messages.

Modes Interface configuration.

Usage Guidelines The **no** form of the command disables this functionality.
The interface-id parameter on the DHCPv6 relay forward message is used to identify the interface on which the client message is received. By default, this parameter is included only when the client message is received with the link-local source address.

Examples The following example includes the interface-id parameter on the DHCPv6 relay agent messages.

```
device(config)# interface ethernet 2/3
device(config-if-eth2/3)# ipv6 dhcp-relay include-options interface-id
```

History	Release version	Command history
	08.0.10d	This command was introduced.
	08.0.30	Support for this command was added in 08.0.30 and later releases.

ipv6 dhcp-relay maximum-delegated-prefixes

Sets the number of delegated prefixes that can be learned at the global and interface level.

Syntax **ipv6 dhcp-relay maximum-delegated-prefixes** *value*
no ipv6 dhcp-relay maximum-delegated-prefixes *value*

Command Default The DHCPv6 Relay Agent Prefix Delegation Notification is enabled when the DHCPv6 relay agent feature is enabled on the interface.

Parameters *value*
Used to limit the maximum number of prefixes that can be learnt at the global level. The range is from 0 to 512. The global level default value is 500 while the interface level default is 100.

Modes Global configuration
Interface configuration

Usage Guidelines Use the **no** form of the command to set the parameter to the default value of the specified platform. You can disable the DHCPv6 Relay Agent Prefix Delegation Notification at the system or the interface level by setting ipv6 dhcp-relay maximum-delegated prefixes to 0 at the system or interface level.

The sum of all the delegated prefixes that can be learned at the interface level is limited by the system max. Make sure that there is enough free space in the flash memory to save information about delegated prefixes in flash on both the Active and Standby management processor.

Examples The following example sets the maximum delegated prefixes to 500 at the global level.

```
device(config)# ipv6 dhcp-relay maximum-delegated-prefixes 500
```


The following example sets the maximum delegated prefixes to 100 at the interface level.

```
device(config)# config-if-eth2/1
device(config-if-eth2/1)# ipv6 dhcp-relay maximum-delegated-prefixes 100
```

History	Release version	Command history
	08.0.10d	This command was introduced.
	08.0.30	Support for this command was added in 08.0.30 and later releases.

ipv6 max-mroute

Configures the maximum number of IPv6 multicast routes that are supported.

Syntax	ipv6 max-mroute <i>num</i>
	no ipv6 max-mroute <i>num</i>
Command Default	No maximum number of supported routes is configured.
Parameters	<i>num</i>
	Configures the maximum number of multicast routes supported.
Modes	VRF configuration mode
Usage Guidelines	The no form of this command restores the default (no maximum number of supported routes is configured).
Examples	The following example configures the maximum number of 20 supported IPv6 multicast routes on the VRF named my_vrf.
	Device(config)# vrf my_vrf Device(config)# address-family ipv6 Device(config-vrf)# ipv6 max-mroute 20

History	Release version	Command history
	8.0.10a	This command was introduced.

ipv6 mld group-membership-time

Specifies the multicast listener discovery (MLD) group membership time for the default VRF or for a specified VRF.

Syntax `ipv6 mld group-membership-time num`

`no ipv6 mld group-membership-time num`

Command Default An MLD group will remain active on an interface in the absence of a group report for 260 seconds, by default.

Parameters *num*

Number in seconds, from 5 through 26000.

Modes Global configuration mode.

VRF configuration mode.

Usage Guidelines The **no** form of this command resets the group membership time interval to the default of 260 seconds. Group membership time defines how long a group will remain active on an interface in the absence of a group report.

Examples This example specifies an MLD group membership time of 2000 seconds for the default VRF.

```
device# configure terminal
device(config)# ipv6 mld group-membership-time 2000
```

This example specifies an MLD group membership time of 2000 seconds for a specified VRF.

```
device# configure terminal
device(config)# ipv6 router pim vrf blue
device(config-ipv6-pim-router-vrf-blue)# ipv6 mld group-membership-time 2000
```

ipv6 mld llqi

Configures the multicast listener discovery (MLD) last listener query interval.

Syntax	ipv6 mld llqi <i>seconds</i>
	no ipv6 mld llqi <i>seconds</i>
Command Default	The MLD last listener query interval is 1 second.
Parameters	<i>seconds</i>
	specifies the number in seconds, of MLD group addresses available for all VRFs. The range is 1 through 25; the default is 1.
Modes	Global configuration mode
	VRF configuration mode
Usage Guidelines	The no form of this command restores the default MLD last listener query interval.
	Any MLD group memberships exceeding the group limit are not processed. The last listener query interval is the maximum response delay inserted into multicast address-specific queries sent in response to Done messages, and is also the amount of time between multicast address-specific query messages. When a device receives an MLD Version 1 leave message or an MLD Version 2 state-change report, it sends out a query and expects a response within the time specified by the last listener query interval. Configuring a lower value for the last listener query interval allows members to leave groups faster.
Examples	This example configures a last listener query interval of 5 seconds. Device(config)# ipv6 mld llqi 5
	This example configures a last listener query interval of 5 seconds for a VRF. Device(config)# ipv6 router pim vrf blue Device(config-ipv6-pim-router-vrf-blue)# ipv6 mld llqi 5

ipv6 mld max-group-address

Configures the maximum number of MLD addresses for the default virtual routing and forwarding (VRF) instance or for a specified VRF.

Syntax `ipv6 mld max-group-address num`

`no ipv6 mld max-group-address num`

Command Default If this command is not configured, the maximum number of MLD addresses is determined by available system resources.

Parameters *num*

specifies the maximum number of MLD group addresses available for all VRFs. The range is 1 through 8192; the default is 4096.

Modes Global configuration mode
VRF configuration mode

Usage Guidelines If the **no** form of this command is configured, the maximum number of MLD addresses is determined by available system resources.
Any MLD group memberships exceeding the group limit are not processed.

Examples This example configures a maximum of 1000 IGMP addresses for the default VRF.

```
Device(config)# ipv6 mld max-group-address 1000
```

This example configures a maximum of 1000 IGMP addresses for the VRF named vpn1.

```
Device(config)# vrf vpn1
Device(config-vrf-vpn1)# address-family ipv4
Device(config-vrf-vpn1-ipv4)# ip igmp max-group-address 1000
```

ipv6 mld max-response-time

Configures the maximum time a multicast listener has to respond to queries for the default virtual routing and forwarding (VRF) instance or for a specified VRF.

Syntax	<p>ipv6 mld max-response-time <i>num</i></p> <p>no ipv6 mld max-response-time <i>num</i></p>
Command Default	<p>If this command is not configured, the maximum time a multicast listener has to respond to queries is 10 seconds.</p>
Parameters	<p><i>num</i></p> <p>specifies the maximum time, in seconds, a multicast listener has to respond. The range is 1 through 25; the default is 10.</p>
Modes	<p>Global configuration mode</p> <p>VRF configuration mode</p>
Usage Guidelines	<p>If the no form of this command is configured, the maximum time a multicast listener has to respond to queries is 10 seconds.</p>
Examples	<p>The following example configures the maximum time a multicast listener has to respond to queries to 20 seconds.</p>

```
device# configure terminal
device(config)# ipv6 mld max-response-time 20
```

The following example configures the maximum time a multicast listener has to respond to queries to 20 seconds for the VRF named vpn1.

```
device# configure terminal
device(config)# vrf vpn1
Device(config-vrf-vpn1)# address-family ipv6
device(config)# ipv6 mld max-response-time 20
```

ipv6 mld port-version

Configures the multicast listening discovery (MLD) version on a virtual Ethernet interface.

Syntax **ipv6 mld port-version** *version-number*

no ipv6 mld port-version

Command Default The port uses the MLD version configured globally.

Parameters *version-number*

Specifies the MLD version, 1 or 2.

Modes Interface configuration mode

Usage Guidelines The **no** form of this command restores the MLD version configured globally.

Examples This example configures MLD version 2 on virtual Ethernet interface 10.

```
device# configure terminal
device(config)# interface ve 10
device(config-vif-10)# ipv6 mld port-version 2
```

ipv6 mld query-interval

Configures the frequency at which multicast listening discovery (MLD) query messages are sent.

Syntax `ipv6 mld query-interval num`

`no ipv6 mld query-interval num`

Command Default 125 seconds

Parameters *num*

Number in seconds, from 2 through 3600. The default is 125.

Modes Global configuration mode.
VRF configuration mode.

Usage Guidelines The **no** form of this command resets the query interval to the default of 125 seconds.
You must specify a query-interval value that is greater than the interval configured by the `ipv6 mld max-response-time` command.

Examples This example sets the MLD query interval to 50 seconds.

```
Device(config)# ipv6 mld query-interval 50
```

This example sets the MLD query interval for a VRF to 50 seconds.

```
Device(config)# ipv6 router pim vrf blue
Device(config-ipv6-pim-router-vrf-blue)# ipv6 mld query-interval 50
```

ipv6 mld robustness

Configures the number of times that the device sends each multicast listening discovery (MLD) message from an interface.

Syntax **ipv6 mld robustness** *num*

no ipv6 mld robustness *num*

Command Default The MLD robustness is 2 seconds.

Parameters *num*

Number in seconds, from 2 through 7. The default is 2.

Modes Global configuration mode.

VRF configuration mode.

Usage Guidelines The **no** form of this command resets the query interval to the default of 2 seconds.
Configure a higher value to ensure high MLD reliability.

Examples This example configures the MLD robustness to 3 seconds.

```
Device(config)# ipv6 mld robustness 3
```

This example configures the MLD robustness for a VRF to 3 seconds.

```
Device(config)# ipv6 router pim vrf blue
Device(config-ipv6-pim-router-vrf-blue)# ipv6 mld robustness 3
```

ipv6 mld static-group

Configures one or more physical ports to be a permanent (static) member of a multicast listening discovery (MLD) group based on the range or count.

Syntax	<p>ipv6 mld static-group <i>multicast-group-addr</i> [count <i>count-number</i> to <i>multicast-group-addr</i>] [ethernet <i>stackid/slot/portnum</i>] [ethernet <i>stackid/slot/portnum</i> to ethernet <i>stackid/slot/portnum</i>]]</p> <p>no ipv6 mld static-group <i>multicast-group-addr</i> [count <i>count-number</i> to <i>multicast-group-addr</i>] [ethernet <i>stackid/slot/portnum</i>] [ethernet <i>stackid/slot/portnum</i> to ethernet <i>stackid/slot/portnum</i>]]</p>
Command Default	The port is not added to MLD group.
Parameters	<p><i>ip-addr</i></p> <p>The address of the static MLD group.</p> <p>count <i>count-number</i></p> <p>Specifies the number of static MLD groups The range is 2 through 256.</p> <p>to</p> <p>Specifies a range of addresses.</p> <p>ethernet <i>stackid/slot/portnum</i></p> <p>Specifies the ID of the physical port that will be a member of the MLD group. On standalone devices specify the interface ID in the format slot/port-id; on stacked devices you must also specify the stack ID, in the format stack-id/slot/port-id. You can configure a single port or a list of ports, separated by a space.</p>
Modes	Interface configuration mode.
Usage Guidelines	<p>The no form of this command removes the port or ports from the MLD group.</p> <p>You can specify as many port numbers as you want to include in the static group.</p> <p>For a virtual routing interface (ve), specify the physical Ethernet ports on which to add the group address.</p>
Examples	<p>The following example configures two static groups, starting from ff0d::1, without having to receive an MLDv1 report on a virtual Ethernet interface,</p> <pre>device# configure terminal device(config)# interface ethernet 10000 1/1/2 device(config-if-e10000-1/1/2)# ipv6 mld static-group ff0d::1 count 2</pre> <p>The following example configures two static MLD groups, starting from ff0d::1, using the to keyword.</p> <pre>device# configure terminal device(config)# interface ethernet 10000 1/1/2 device(config-if-e10000-1/1/2)# ipv6 mld static-group ff0d::1 to ff0d::2</pre> <p>The following example configures two static MLD groups on virtual ports starting from ff0d::1 using the count keyword.</p> <pre>device# configure terminal device(config)# interface ve 10 device(config-vif-10)# ipv6 mld static-group ff0d::1 count 2 ethernet 1/5/2</pre> <p>The following example configures two static groups on virtual ports starting from ff0d::1 using the to keyword.</p> <pre>device# configure terminal device(config)# interface ve 10 device(config-vif-10)# ipv6 mld static-group ff0d::1 to ff0d::2 ethernet 1/5/2</pre>

ipv6 mld tracking

Enables multicast listening discovery (MLD) tracking on a virtual interface.

Syntax **ipv6 mld tracking**

no ipv6 mld tracking

Command Default Multicast tracking is disabled on the virtual interface.

Modes Virtual interface configuration mode

Usage Guidelines The **no** form of this command restores the default; tracking is disabled.

When MLD tracking is enabled, a Layer 3 device tracks all clients that send membership reports. When a Leave message is received from the last client, the device immediately stops forwarding to the physical port, without waiting 3 seconds to confirm that no other clients still want the traffic.

Examples This example enables multicast tracking on a virtual interface.

```
device# configure terminal
device(config)# interface ve 13
device(config-vif-13)# ipv6 mld tracking
```

ipv6 mroute

Configures a static IPv6 route to direct multicast traffic along a specific path.

Syntax	ipv6 mroute [vrf <i>vrf-name</i>] <i>ipv6-address-prefix/prefix-length</i> { ethernet <i>stackid / slot / portnum</i> ve <i>num</i> tunnel <i>num</i> } [<i>cost</i>] [distance <i>distance-value</i>] [name <i>name</i>] no ipv6 mroute [vrf <i>vrf-name</i>] <i>ipv6-address-prefix/prefix-length</i> { ethernet <i>stackid / slot / portnum</i> ve <i>num</i> tunnel <i>num</i> } [<i>cost</i>] [distance <i>distance-value</i>] [name <i>name</i>]				
Command Default	No static IPv6 multicast route is configured.				
Parameters	<p>vrf <i>vrf-name</i></p> <p>Configures a static mroute for this virtual routing and forwarding (VRF) route.</p> <p><i>ipv6-address-prefix/prefix-length</i></p> <p>Configures the destination IPv6 address and prefix for which the route should be added.</p> <p>ethernet <i>stackid / slot / portnum</i></p> <p>Configures an Ethernet interface as the route path.</p> <p>ve <i>num</i></p> <p>Configures a virtual interface as the route path.</p> <p>tunnel <i>num</i></p> <p>Configures a tunnel interface as the route path.</p> <p><i>cost</i></p> <p>Configures a metric for comparing the route to other static routes in the IPv6 static route table that have the same destination. The range is 1 to 16; the default is 1.</p> <p>distance <i>distance-value</i></p> <p>Configures the route's administrative distance. The range is 1 to 255; the default is 1.</p> <p>name <i>name</i></p> <p>Name for this static route.</p>				
Modes	VRF configuration mode				
Usage Guidelines	<p>The no form of this command deletes a previously configured static multicast route.</p> <p>Connected routes on PIM enabled interfaces are automatically added to the mRTM table.</p>				
Examples	<p>The following example configures a static IPv6 mroute to directly connected network 2020::0/120 on virtual interface ve 130.</p> <pre>Device(config-vrf)# ipv6 mroute 2020::0/120 ve 130</pre>				
History	<table><tr><th>Release version</th><th>Command history</th></tr><tr><td>8.0.10a</td><td>This command was introduced.</td></tr></table>	Release version	Command history	8.0.10a	This command was introduced.
Release version	Command history				
8.0.10a	This command was introduced.				

ipv6 mroute next-hop-enable-default

Enables the option to use the default multicast route (mroute) to resolve a static IPv6 mroute next hop.

Syntax **ipv6 mroute [vrf vrf-name] next-hop-enable-default**
no ipv6 mroute [vrf vrf-name] next-hop-enable-default

Command Default Static mroutes are not resolved using the default mroute.

Parameters **vrf vrf-name**
Configures a static mroute for this virtual routing and forwarding (VRF) route.

Modes VRF configuration mode

Usage Guidelines The **no** form of this command disables the default IPv6 mroute option for next hops.

Examples The following example enables the use of the default mroute to resolve a static IPv6 mroute next hop:
Device(config-vrf)# ipv6 mroute next-hop-enable-default

History	Release version	Command history
	8.0.10a	This command was introduced.

ipv6 multicast age-interval

Configures the time that group entries can remain in a multicast listening discovery (MLD) group table.

Syntax **ipv6 multicast age-interval** *interval*

no ipv6 multicast age-interval *interval*

Command Default Group entries can remain in the MLD group table for up to 260 seconds.

Parameters *interval*

Specifies the time, in seconds, that group entries can remain in the MLD group table. The range is 20 through 7200 seconds. The default is 260 seconds.

Modes Global configuration mode

Usage Guidelines The **no** form of this command restores the default age interval to 260 seconds.

When a device receives a group membership report it makes an entry for that group in the MLD group table. You can configure the **ipv6 multicast age-interval** to specify how long the entry can remain in the table before the device receives another group membership report. When multiple devices are connected, they must all be configured for the same age interval, which must be at least twice the length of the query interval, so that missing one report does not stop traffic.

Non-querier age intervals must be the same as the age interval of the querier.

Examples This example configures the MLD group-table age interval to 280 seconds.

```
Device(config)#ipv6 multicast age-interval 280
```

ipv6 multicast disable-flooding

Disables the flooding of unregistered IPv6 multicast frames in an MLD-snooping-enabled VLAN.

Syntax **ipv6 multicast disable-flooding**

no ipv6 multicast disable-flooding

Command Default The device floods unregistered IPv6 multicast frames in an MLD-snooping-enabled VLAN.

Modes Global configuration mode

Usage Guidelines

NOTE

Disabling the flooding of unregistered IPv6 multicast frames in an MLD-snooping-enabled VLAN is supported only on the following platforms:

- ICX 6650
- ICX 7750 (standalone and stacking)

The **no** form of this command enables the flooding of unregistered IPv6 multicast frames in an MLD-snooping-enabled VLAN.

In releases prior to FastIron 8.0.30, support for this command on the Brocade ICX 7750 was for devices in standalone mode only.

After the hardware forwarding database (FDB) entry is made, the multicast traffic is switched only to the VLAN hosts that are members of the multicast group. This can avoid congestion and loss of traffic on the ports that have not subscribed to this IPv6 multicast traffic.

Examples The following example disables flooding of unregistered IPv6 multicast frames.

```
Device(config)# ipv6 multicast disable-flooding
```

History

Release version

Command history

08.0.01

This command was introduced.

ipv6 multicast leave-wait-time

Configures the wait time before stopping traffic to a port when a leave message is received.

Syntax	ipv6 multicast leave-wait-time <i>num</i>		
	no ipv6 multicast leave-wait-time <i>num</i>		
Command Default	The wait time is 2 seconds.		
Parameters	<i>num</i>		
	Specifies the time, in seconds, the device should wait before stopping traffic to a port when a leave message is received. The range is 1 through 5 seconds. The default is 2 seconds.		
Modes	Global configuration mode		
Usage Guidelines	The no form of this command restores the default wait time.		
	The device sends group-specific queries once per second to ask if any client in the same port still needs the group. Because of internal timer granularity, the actual wait time is between n and (n+1) seconds (n is the configured value).		
Examples	This example configures the maximum time a client can wait before responding to a query as 1 second.		
	<pre>Device(config)#ipv6 multicast leave-wait-time 1</pre>		

ipv6 multicast mcache-age

Configures the time for an mcache to age out when it does not receive traffic.

Syntax `ipv6 multicast mcache-age num`

`no ipv6 multicast mcache-age num`

Command Default The mcache ages out after the default age-out interval, which is 180 seconds for FSX 800/1600, ICX 7750, ICX 7450, and ICX 7250 devices, and 60 seconds for all other devices.

Parameters `num`

Specifies the time, in seconds, the device should wait before stopping traffic to a port when a leave message is received. The range is 60 through 3600 seconds.

Modes Global configuration mode

Usage Guidelines The `no` form of this command restores the default mcache age-out time.

You can set the time for a multicast cache (mcache) to age out when it does not receive traffic. Two seconds before an mcache is aged out, the device mirrors a packet of the mcache to the CPU to reset the age. If no data traffic arrives within two seconds, the mcache is deleted.

NOTE

On devices that support MAC-based MLD snooping (like the FSX, ICX 7750, ICX7450, and ICX 7250), more than one mcache can be mapped to the same destination MAC. When an mcache entry is deleted, the MAC entry may not be deleted. If you configure a lower value, the resource consumed by idle streams is quickly removed, but packets are mirrored to the CPU more frequently. Configure a higher value only when data streams are arriving consistently.

Examples This example configures the time for an mcache to age out to 180 seconds.

```
Device(config)#ipv6 multicast mcache-age 180
```

ipv6 multicast query-interval

Configures how often the device sends group membership queries when the multicast listening discovery (MLD) mode is set to active.

Syntax `ipv6 multicast query-interval interval`

`no ipv6 multicast query-interval interval`

Command Default Queries are sent every 125 seconds.

Parameters *interval*

Specifies the time, in seconds, between queries. The range is 10 through 3600 seconds. The default is 125 seconds.

Modes Global configuration mode

Usage Guidelines The **no** form of this command restores the query interval to 125 seconds.

If the MLD mode is set to active, you can modify the query interval, which specifies how often the Brocade device sends group membership queries. When multiple queriers connect together, all queriers should be configured with the same interval.

Examples The following example configures the query interval to 120 seconds.

```
device#configure terminal
device(config)#ipv6 multicast query-interval 120
```

ipv6 multicast report-control

Limits report forwarding within the same group to no more than once every 10 seconds.

Syntax **ipv6 multicast report-control**

no ipv6 multicast report-control

Command Default A device in passive mode forwards reports and leave messages from clients to the upstream router ports that are receiving queries.

Modes Global configuration mode

Usage Guidelines The **no** form of this command restores the default.

NOTE

This feature applies only to multicast listening discovery (MLD) version 1. The leave messages are not rate limited.

This rate-limiting does not apply to the first report answering a group-specific query.

Configure this command to alleviate report storms from many clients answering the upstream router query.

Examples This example limits the rate that reports are forwarded.

```
Device(config)#ipv6 multicast-report-control
```

ipv6 multicast verbose-off

Turns off error or warning messages that are displayed when the device runs out of software resources or when it receives packets with the wrong checksum or groups.

Syntax **ipv6 multicast verbose-off**

no ipv6 multicast verbose-off

Command Default Messages are displayed.

Modes Global configuration mode

Usage Guidelines The **no** form of this command restores the default display of messages.

Examples This example turns off the display of messages.

```
device# configure terminal
device(config)# ipv6 multicast verbose-off
```

ipv6 multicast version

Configures the multicast listening discovery (MLD) version for snooping globally.

Syntax **ipv6 multicast version [1 | 2]**

no ipv6 multicast version

Command Default	MLD version 1 is configured.
------------------------	------------------------------

Parameters	1	Configures MLD version 1.
	2	Configures MLD version 2.

Modes	Global configuration mode
--------------	---------------------------

Usage Guidelines The **no** form of this command restores the version to MLD version 1.

You can configure the MLD version for individual VLANs, or individual ports within VLANs. If no MLD version is specified for a VLAN, the globally configured MLD version is used. If an MLD version is specified for individual ports in a VLAN, those ports use that version instead of the version specified for the VLAN or the globally specified version. The default is MLD version 1.

Examples This example specifies MLD version 2 on a device.

```
Device(config)#ipv6 multicast version 2
```

ipv6 multicast-boundary

Defines multicast boundaries for PIM-enabled interfaces.

Syntax **ipv6 multicast-boundary** *acl-spec*
 no ipv6 multicast-boundary *acl-spec*

Command Default Boundaries are not defined.

Parameters *acl-spec*
 Specifies the number or name identifying an access control list (ACL) that controls the range of group addresses affected by the boundary.

Modes Interface configuration mode

Usage Guidelines The **no** form of this command removes the boundary on a PIM-enabled interface.
 You can use standard ACL syntax to configure an access list.

Examples This example defines a boundary named MyAccessList for a PIM-enabled interface.
 Device(config)# interface ethernet 1/2/2
 Device(config-if-e1000-1/2)#ipv6 multicast-boundary MyAccessList

ipv6 multicast-routing rpf-check mac-movement

Triggers Reverse Path Forwarding (RPF) check on MAC movement for directly connected sources and sends a MAC address movement notification to the Protocol Independent Multicast (PIM) module which results in PIM convergence.

Syntax **ipv6 multicast-routing rpf-check mac-movement**

no ipv6 multicast-routing rpf-check mac-movement

Command Default RPF check on MAC movement for directly connected sources is not enabled.

Modes Global configuration mode

Usage Guidelines PIM convergence on MAC movement is applicable only in a topology where the multicast source port and PIM routers are in the same Layer 2 domain.

IPv6 PIM Dense mode is not supported for PIM convergence on MAC movement.

The **ipv6 multicast-routing rpf-check mac-movement** command is not supported on the Brocade ICX 6650, Brocade ICX 7250, and FSX 800/FSX 1600 devices.

The **no** form of the command disables RPF check on MAC movement for directly connected sources.

Examples The following example configures RPF check on MAC movement for directly connected sources.

```
device(config)# ipv6 multicast-routing rpf-check mac-movement
```

History	Release version	Command history
	08.0.10h	This command was introduced.
	08.0.30	Support for the ipv6 multicast-routing rpf-check mac-movement command was added in 08.0.30 and later releases.

ipv6 nd router-preference

Configures the IPv6 router advertisement preference value to low or high (medium is the default). IPv6 router advertisement preference enables IPv6 router advertisement (RA) messages to communicate default router preferences from IPv6 routers to IPv6 hosts in network topologies where the host has multiple routers on its Default Router List.

Syntax	ipv6 nd router-preference [low medium high] no ipv6 nd router-preference [low medium high]	
Command Default	The IPv6 router advertisement preference value is set to medium.	
Parameters	low	The two-bit signed integer (11) indicating the preference value "low".
	medium	The two-bit signed integer (00) indicating the preference value "medium". This is the default preference value.
	high	The two-bit signed integer (01) indicating the preference value "high".
Modes	Interface configuration mode	
Usage Guidelines	The no form disables IPv6 router preference.	
Examples	The following example configures IPv6 RA preference for IPv6 routers: device #configure terminal device (config)# interface ethernet 2/3 device (config-if-eth2/3)# ipv6 nd router-preference low	
History	Release version	Command history
	08.0.10	This command was introduced.

ipv6 nd skip-interface-ra

Disables the default interface-level IPv6 RA messages on an interface configured with IPv6 VRRP or VRRP-E.

Syntax **ipv6 nd skip-interface-ra**

 no ipv6 nd skip-interface-ra

Command Default The IPv6-enabled interface sends the default IPv6 Router Advertisement (RA) messages. The IPv6 VRRP or VRRP-E instance configured on the interface also sends its virtual-IPv6 RA messages on the same interface. A connected IPv6 host receives these two different IPv6 RA messages with the same source address from this IPv6 router interface.

Modes Interface configuration mode

Usage Guidelines

NOTE
This command is valid only on an interface configured with IPv6 VRRP or VRRP-E.

The **no** form of this command enables the default interface-level IPv6 RA messages on an interface configured with IPv6 VRRP or VRRP-E.

By default, all IPv6-enabled interfaces send IPv6 Router Advertisement (RA) messages. If you configure an IPv6 VRRP or VRRP-E instance on an interface, the VRRP/ VRRP-E instance also sends its IPv6 RA messages for the virtual IPv6 address on the same interface with the same source address. An IPv6 host cannot identify the valid IPv6 address for this router interface because of these two different IPv6 RA messages with the same source address from the same IPv6 router interface. To avoid this, run this command to disable the default interface-level IPv6 RA messages on an interface configured with IPv6 VRRP or VRRP-E.

Examples The following example disables the default interface-level IPv6 RA messages on an ethernet interface 1/1/7 configured with IPv6 VRRP or VRRP-E.

```
device(config)# interface ethernet 1/1/7
device(config-if-e1000-1/1/7)# ipv6 address 2002:AB3::2/64
device(config-if-e1000-1/1/7)# ipv6 nd skip-interface-ra
```

History	Release version	Command history
	08.0.01	This command was introduced.

ipv6 neighbor inspection

Configures the static neighbor discovery (ND) inspection entries.

Syntax	ipv6 neighbor inspection <i>ipv6-address mac-address</i>	
	no ipv6 neighbor inspection <i>ipv6-address mac-address</i>	
Command Default	Static ND inspection entries are not configured.	
Parameters	<i>ipv6-address</i>	Configures the IPv6 address of the host.
	<i>mac-address</i>	Configures the MAC address of the host.
Modes	Global configuration mode	
	VRF configuration mode	
Usage Guidelines	Use the ipv6 neighbor inspection command to manually configure static ND inspection entries for hosts on untrusted ports. During ND inspection, the IPv6 address and MAC address entries in the ND inspection table are used to validate the packets received on untrusted ports.	
	The no form of the command disables static ND inspection entries.	
Examples	The following example displays the configuration of a static ND inspection entry.	
	<pre>device(config)# ipv6 neighbor inspection 2001::1 0000.1234.5678</pre>	
	The following example displays the configuration of a static ND inspection entry for VRF 3.	
	<pre>device(config)# vrf 3 device(config-vrf-3)# ipv6 neighbor inspection 2001::100 0000.0000.4567</pre>	
History	Release version	Command history
	08.0.20	This command was introduced.

ipv6 neighbor inspection vlan

Configures and enables neighbor discovery (ND) inspection on a VLAN to inspect the IPv6 packets from untrusted ports.

Syntax **ipv6 neighbor inspection vlan** *vlan-number*
no ipv6 neighbor inspection vlan *vlan-number*

Command Default IPv6 neighbor inspection is not enabled.

Parameters *vlan-number*
Configures the ID of the VLAN.

Modes Global configuration mode
VRF configuration mode

Usage Guidelines When you configure this command, IPv6 packets from untrusted ports on the VLAN undergo ND inspection.
The **no** form of the command disables ND inspection.

Examples The following example enables ND inspection on VLAN 10.

```
device(config)# ipv6 neighbor inspection vlan 10
```


The following example enables ND inspection on VLAN 10 of VRF 3.

```
device(config)# vrf 3
device(config-vrf-3)# ipv6 neighbor inspection vlan 10
```

History	Release version	Command history
	08.0.20	This command was introduced.

ipv6 pim border

Configures an interface to be on a PIM Sparse domain border.

Syntax **ipv6 pim border**

no ipv6 pim border

Command Default The interface is not configured as a border device.

Modes Interface configuration mode

Usage Guidelines The **no** form of this command removes the boundary on a PIM-enabled interface.
You must enable PIM globally before you enable it on an interface.

Examples This example configures Ethernet interface 3/2/4 to be on a PIM Sparse domain border.

```
device(config) interface ethernet 3/2/4
Device(config-if-e10000-3/2/4)# ipv6 pim border
```

ipv6 pim dr-priority

Configures the designated router (DR) priority on IPv6 interfaces.

Syntax **ipv6 pim dr-priority** *priority-value*

no ipv6 pim *priority-value*

Command Default The DR priority value is 1.

Parameters *priority-value*

Specifies the DR priority value as an integer. The range is 0 through 65535. The default is 1.

Modes Interface configuration mode

Usage Guidelines The **no** form of this command restores the default DR priority value, 1.

You must enable PIM globally before you enable it on an interface.

If more than one device has the same DR priority on a subnet (as in the case of default DR priority on all), the device with the numerically highest IPv6 address on that subnet is elected as the DR.

The DR priority information is used in the DR election only if all the PIM devices connected to the subnet support the DR priority option. If at least one PIM device on the subnet does not support this option, the DR election falls back to the backwards compatibility mode in which the device with the numerically highest IPv6 address on the subnet is declared the DR regardless of the DR priority values.

Examples This example configures a DR priority value of 50 on Ethernet interface 3/2/4.

```
device(config) interface ethernet 3/2/4
Device(config-if-e10000-3/2/4)# ipv6 pim dr-priority 50
```

This example configures a DR priority value of 50 on a virtual Ethernet interface.

```
Device(config)# interface ve 10
Device(config-vif-10)# ipv6 pim dr-priority 50
```

ipv6 pim neighbor-filter

Determines which devices can become PIM neighbors.

Syntax	ipv6 pim neighbor-filter <i>acl-name</i>	
	no ipv6 pim <i>acl-name</i>	
Command Default	Neighbor filtering is not applied on the interface.	
Parameters	<i>acl-name</i>	Specifies the access-control list (ACL) that identifies the devices you want to permit and deny participation in PIM.
Modes	Interface configuration mode	
Usage Guidelines	The no form of this command removes any neighbor filtering applied on the interface.	
	You must enable PIM globally before you enable it on an interface.	
	You can configure the ipv6 pim neighbor-filter command in either Dense mode (DM) or Sparse mode (SM).	
	Configure the access-list command to create an ACL defining the devices you want to permit and deny participation in PIM.	
Examples	This example prevents the host from becoming a PIM neighbor on interface Ethernet 1/3/24.	
	Device(config)# interface ethernet 1/3/24 Device(config-if-e10000-1/3/24)# ipv6 pim neighbor-filter	
	This example configures an ACL named 10 to deny a host and then prevents that host, 1001::1/96, identified in that ACL from becoming a PIM neighbor on interface Ethernet 1/3/24.	
	Device(config)# access-list 10 deny host 1001::1/96 Device(config)# access-list 10 permit any Device(config)# interface ethernet 1/3/24 Device(config-if-e10000-1/3/24)# ipv6 pim neighbor-filter 10	
History	Release version	Command history
	8.0.20a	This command was introduced.

ipv6 pim-sparse

Enables PIM Sparse on an IPv6 interface.

Syntax **ipv6 pim-sparse**
no ipv6 pim-sparse

Command Default PIM Sparse is not enabled on the IPv6 interface.

Modes Interface configuration mode

Usage Guidelines The **no ipv6 pim-sparse** command removes the PIM sparse configuration from the IPv6 interface.

Examples This example adds an IPv6 interface to port 1/2/2, then enables PIM Sparse on the interface.

```
Device(config)# interface ethernet 1/2/2
Device(config-if-e10000-2/2)# ipv6 address a000:1111::1/64
Device(config-if-e10000-2/2)# ipv6 pim-sparse
```

ipv6 raguard policy

Configures the specified Router Advertisement (RA) guard policy and enters RA guard policy configuration mode.

Syntax	ipv6 raguard policy <i>name</i>
	no ipv6 raguard policy <i>name</i>
Parameters	<i>name</i> An ASCII string indicating the name of the RA guard policy to configure.
Modes	Global configuration mode RA guard policy configuration mode
Usage Guidelines	You can configure up to 256 RA guard policies. The no form of this command deletes the specified RA guard policy.
Examples	The following example configures an RA guard policy and enters RA guard policy configuration mode: <pre> Brocade(config)# ipv6 raguard policy policy1 Brocade(ipv6-RAG-policy policy1)# </pre>

ipv6 raguard vlan

Associates a Router Advertisement (RA) guard policy with a VLAN.

Syntax **ipv6 raguard vlan** *vlan-number* **policy** *name*
no ipv6 raguard vlan *vlan-number* **policy** *name*

Parameters *vlan-number* Configures the ID number of the VLAN to which the specified RA guard policy should be associated. Valid range is from 1 to 4095.

policy Associates a RA guard policy to the VLAN.

name Specifies the name of the RA guard policy to be associated with the VLAN.

Modes Global configuration mode

Usage Guidelines A VLAN can have only one association with a RA guard policy. If you try to associate a new RA guard policy with a VLAN that is already associated with a policy, the new RA guard policy replaces the old one.

Examples The following example associates RA guard policy named p1 with VLAN 1:

```
Brocade(config)# ipv6 raguard vlan 1 policy p1
```

ipv6 raguard whitelist

Configures the Router Advertisement (RA) guard whitelist and adds the IPv6 address as the allowed source IP address.

Syntax	<p>ipv6 raguard whitelist <i>whitelist-number</i> permit <i>ipv6-address</i></p> <p>no ipv6 raguard whitelist <i>whitelist-number</i> permit <i>ipv6-address</i></p>
Parameters	<p><i>whitelist-number</i></p> <p>Configures the unique identifier for the RA guard whitelist. Valid values are 0 to 255.</p> <p>permit</p> <p>Configures the specified IPv6 address as the allowed source IP address to the RA guard whitelist.</p> <p><i>ipv6-address</i></p> <p>Configures the source IPv6 address. The address should be in the format X:X::X:X or X:X::X:X/M.</p>
Modes	Global configuration mode
Usage Guidelines	<p>You can configure source IP addresses from which RAs are permitted.</p> <p>You can configure up to 64 RA guard whitelists, and each whitelist can have a maximum of 128 entries.</p> <p>To remove the RA guard whitelist, use the no form the command without the permit keyword.</p> <p>To remove a particular IPv6 address from the whitelist, use the no form of the command with the permit<i>ipv6-address</i> keyword-variable pair.</p> <p>When a whitelist associated with an RA guard policy is removed, all the entries in the whitelist are also removed. All the RAs are dropped because there is no whitelist associated with the RA guard policy.</p>
Examples	<p>The following example configures an RA guard whitelist with the allowed source IP address:</p> <pre>Brocade(config)# ipv6 raguard whitelist 1 permit fe80:db8::db8:10</pre> <p>The following example removes an RA guard whitelist:</p> <pre>Brocade(config)# no ipv6 raguard whitelist 1</pre> <p>The following example removes a particular IPv6 address from the RA guard whitelist:</p> <pre>Brocade(config)# no ipv6 raguard whitelist 1 permit fe80:db8::db8:10</pre>

ipv6 router pim

Enables IPv6 PIM-Sparse mode for IPv6 routing globally or on a specified VRF.

Syntax `ipv6 router pim [vrf vrf-name]`

`no ipv6 router pim [vrf vrf-name]`

Command Default IPv6 PIM-Sparse mode is not enabled.

Parameters `vrf vrf-name`

Specifies a VRF instance.

Modes Global configuration mode.

VRF configuration mode.

Usage Guidelines The **no** form of this command removes the IPv6 PIM-Sparse mode configuration.

Examples The following example enables IPv6 PIM-Sparse mode on a VRF named blue.

```
Device(config)# ipv6 router pim vrf blue
```

ipv6-address auto-gen-link-local

Generates a virtual link-local IPv6 address and assigns it as the virtual IPv6 address for a VRRPv3 instance.

Syntax	ipv6-address auto-gen-link-local no ipv6-address auto-gen-link-local	
Modes	VRRP sub-configuration mode	
Usage Guidelines	<p>The no form of this command deletes the auto-generated virtual link-local IPv6 address for the VRRP v3 instance.</p> <p>The default VRRPv3 implementation allows only the link-local address that is configured on a physical interface to be used as the virtual IPv6 address of a VRRPv3 instance. This limits configuring a link-local address for each VRRP instance on the same physical interface because there can be only one link-local address per physical interface. You can use this command on the owner or backup router to generate a virtual link-local IPv6 address from the virtual MAC address of a VRRPv3 instance and assign it as the virtual IPv6 address for the VRRPv3 instance. This auto-generated link-local IPv6 address is not linked to any physical interface on the router.</p>	
Examples	<p>The following example generates a virtual link-local IPv6 address and its allocation as the virtual IPv6 address of a VRRPv3 cluster on an owner router.</p> <pre>device(config)# interface ve 3 device(config-vif-3)# ipv6 vrrp vrid 2 device(config-vif-3-vrid-2)# owner device(config-vif-3-vrid-2)# ipv6-address auto-gen-link-local device(config-vif-3-vrid-2)# activate</pre>	
History	Release version	Command history
	08.0.01	This command was introduced.

ipv6-neighbor inspection trust

Enables trust mode for specific ports.

Syntax `ipv6-neighbor inspection trust [vrf vrf-name]`

no ipv6-neighbor inspection trust [vrf *vrf-name*]

Command Default	Trust mode is not enabled. When you enable ND inspection on a VLAN, by default, all the interfaces and member ports are considered as untrusted.
------------------------	--

Parameters vrf

Specifies the VRF instance.

vrf-name

Specifies the ID of the VRF instance.

Modes Interface configuration mode

VRF configuration mode

Usage Guidelines The **no** form of the command disables trust mode on ports.

Examples The following example displays the trust mode configuration for ports.

```
device(config)# interface ethernet 1/1/3
device(config-if-e1000-1/1/3)# ipv6-neighbor inspection trust
```

The following example displays the trust mode configuration on a port on VRF 3.

```
device(config-if-e1000-1/1/1)# ipv6-neighbor inspection trust vrf 3
```

History

Release version	Command history
08.0.20	This command was introduced.

jitc enable

Enables the Joint Interoperability Test Command (JITC) mode.

Syntax **jitc enable**

no jitc enable

Command Default JITC is not enabled.

Modes Global configuration mode

Usage Guidelines When JITC is enabled, the Advanced Encryption Standard - Cipher-Block Chaining (AES-CBC) encryption mode for the Secure Shell (SSH) protocol is disabled and the AES-CTR (Counter) encryption mode is enabled.

When JITC is enabled, the MD5 authentication scheme for NTP is disabled.

The **no** form of the command disables the JITC mode and puts the system back to the standard mode and enables both AES-CBC encryption mode and MD5 authentication configuration.

Examples The following example enables the JITC mode.

```
device(config)# jitc enable
```

History

Release version	Command history
08.0.20a	This command was introduced.

jitc show

Displays the status of the JITC mode.

Syntax **jitc show**

Modes Global configuration mode
Privileged EXEC mode

Command Output The **jitc show** command displays the following information.

Output field	Description
JITC mode	Displays the status of the JITC mode.
SSH AES-CTR mode	Displays the status of the SSH AES-CTR mode.
SSH AES-CBC mode	Displays the status of the SSH AES-CBC mode.

Examples The following example shows the output of the **jitc show** command.

```
device(config)#jitc show
JITC mode : Enabled
Management Protocol Specific:
SSH AES-CTR mode : Enabled
SSH AES-CBC mode : Disabled
```

History	Release version	Command history
	08.0.20a	This command was introduced.

jirc show

Commands K - S

key-server-priority

Configures the MACsec key-server priority for the MACsec Key Agreement (MKA) group.

Syntax	key-server-priority <i>value</i>
	no key-server-priority <i>value</i>
Command Default	Key-server priority is set to 16. This is not displayed in configuration details.
Parameters	<i>value</i> Specifies key-server priority. The possible values range from 0 to 255, where 0 is highest priority and 255 is lowest priority.
Modes	dot1x-mka-cfg-group mode
Usage Guidelines	<p>This command is supported only on the Brocade ICX 6610 in FastIron Release 08.0.20. In FastIron Release 08.0.30 and later releases, MACsec commands are also supported on the ICX 7450.</p> <p>The no form of the command removes the previous priority setting.</p> <p>During key-server election, the server with the highest priority (the server with the lowest key-server priority value) becomes the key-server.</p>
Examples	<p>The following example sets the key-server priority for MKA group test1 to 5.</p> <pre>device(config)#dot1x-mka-enable device(config-dot1x-mka)# mka-cfg-group test1 device(config-dot1x-mka-group-test1)# key-server-priority 5</pre>

History	Release version	Command history
	08.0.20	This command was introduced.
	08.0.20a	This command was modified. The key-server priority value range was increased from 0 through 127 to 0 through 255.

link-oam

Enables the EFM-OAM protocol and enters EFM-OAM protocol configuration mode.

Syntax **link-oam**
no link-oam

Command Default The EFM-OAM protocol is not enabled.

Modes Global configuration mode

Usage Guidelines The **no** form of the command removes all the EFM-OAM configurations.

Examples The following example enables EFM-OAM protocol configuration mode.

```
device(config)# link-oam
device(config-link-oam)#
```

History		
	Release version	Command history
	08.0.30	This command was introduced.

local-as

Specifies the BGP autonomous system number (ASN) where the device resides.

Syntax **local-as** *num*

no local-as

Parameters *num*

The local ASN. The range is from 1 through 4294967295.

Modes BGP configuration mode

Usage Guidelines Use the **no** form of this command to remove the ASN from the device.

The ASN for associates a given device it with other devices in its autonomous system.

ASNs in the range from 64512 through 65535 are private numbers that are not advertised to the external community.

Examples This example assigns a separate local AS number.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# local-as 777
```

logging

Enables logging on the Router Advertisement (RA) guard policy.

Syntax **logging**

no logging

Modes RA guard policy configuration mode

Usage Guidelines The **no** form of this command disables logging on the policy.

Logging cannot be modified if the RA guard policy is in use.

You can verify the logs for RA guard, such as RAs dropped, permitted, count for dropped packets, and reasons for the drop.

Logging increases the CPU load and for higher traffic rates, RA packets drop due to congestion if they are received at the line rate. For less load on the CPU, logging can be disabled on the RA guard policy.

Examples The following example enables logging on an RA guard policy:

```
Brocade(config)# ipv6 raguard policy p1
Brocade(config-ipv6-RAG-policy p1)# logging
```

logging cli-command

Enables logging of all syntactically valid CLI commands from each user session into the system log.

Syntax	logging cli-command no logging cli-command
Command Default	Logging of CLI commands is not enabled.
Modes	Global configuration mode
Usage Guidelines	<p>If the logging cli-command command is configured, all the CLI commands executed by the user are logged in the system log and are displayed in the show logging command output.</p> <p>The no form of the command disables the logging of CLI commands from each user session into the system log.</p>

Examples The following example enables the logging of CLI commands on the device.

```
device(config)# logging cli-command
```

The following example shows the system log records which are displayed in the **show logging** command output. The system log contains the valid commands that are executed by the user.

```
Brocade (config)#show logging
Syslog logging: enabled (0 messages dropped, 0 flushes, 5 overruns)
  Buffer logging: level ACDMEINW, 50 messages logged
    level code: A=alert C=critical D=debugging M=emergency E=error
I=informational N=notification W=warning
Dynamic Log Buffer (50 lines):
8d02h28m43s:I:CLI CMD: "ip route 0.0.0.0 0.0.0.0 10.20.64.1" by un-authenticated
user from console
8d02h28m24s:I:System: Interface ethernet 1/1, state up
8d02h28m22s:I:CLI CMD: "enable" by un-authenticated user from console
8d02h28m22s:I:PORT: 1/1 enabled by un-authenticated user from console session
8d02h28m19s:I:CLI CMD: "disable" by un-authenticated user from console
8d02h28m19s:I:PORT: 1/1 disabled by un-authenticated user from console session
8d02h28m16s:I:CLI CMD: "interface ethernet 1/1" by un-authenticated user from
console
```

loop-detection shutdown-disable

Disables shutdown of a port when a loop detection probe packet is received on an interface.

Syntax **loop-detection shutdown-disable**
 no loop-detection shutdown-disable

Command Default Loop detection shutdown is enabled on the interface.

Modes Interface configuration

Usage Guidelines The **no** form of this command disables loop detection shutdown.
 Shutdown prevention for loop-detect functionality allows users to disable shut down of a port when the loop detection probe packet is received on an interface. This provides control over deciding which port is allowed to enter in to an error-disabled state and go into a shutdown state when a loop is detected.

Examples The following example disables loop detection shutdown on an interface.

```
device(config)# interface ethernet 1/7
device(config-if-e1000-1/7)# loop-detection shutdown-disable
```

History

Release version	Command history
08.0.20	This command was introduced.

loop-detection-syslog-interval

Specifies the interval (in minutes) at which a syslog is generated.

Syntax	loop-detection-syslog-interval <i>num</i>	
	no loop-detection-syslog-interval <i>num</i>	
Command Default	The syslog interval is 5 minutes.	
Parameters	<i>num</i>	Specifies the syslog interval in minutes. The interval can range from 1 through 1440 minutes.
Modes	Global configuration	
Usage Guidelines	The no form of this command restores the default settings.	
	You can specify the interval at which the loop detection syslog message is generated if the loop-detection-shutdown-disable command is configured for the port. This configuration applies to all the ports that have loop detection shutdown prevention configured.	
Examples	The following example shows the loop detection syslog interval set to 1 hour.	
	<pre>device(config)# loop-detection-syslog-interval 60</pre>	
History		
	Release version	Command history
	08.0.20	This command was introduced.

mac filter enable-accounting

Enables access control list (ACL) accounting on Layer 2 MAC filters.

Syntax `mac filter num enable-accounting`

no mac filter *num* enable-accounting

Command Default This option is disabled.

Parameters *num*

Specifies the MAC filter ID.

enable-accounting

Enables MAC filter accounting on the specified interface.

Modes	Global configuration mode
--------------	---------------------------

Usage Guidelines The **no** form of this command disables ACL accounting on the associated Layer 2 MAC filter interface.

Examples The following example enables ACL accounting on a Layer 2 MAC filter.

```
device(config)# mac filter 1 permit 0000.0000.0001 ffff.ffff.ffff any
device(config)# mac filter 1 enable-accounting
device(config)# interface ethernet 3/21
device(config-if-e1000-3/21)# mac filter-group 1
```

History

Release version	Command history
08.0.10	This command was introduced.

mac-auth auth-filter

Applies the specified filter on the interface.

Syntax **mac-auth auth-filter** *filter-id* **vlan** *vlan-id*

no mac-auth auth-filter *filter-id* **vlan** *vlan-id*

Command Default There are no filters applied on the interface.

Parameters *filter-id*

Specifies the identification number of the filter to be applied on the interface.

vlan *vlan-id*

Specifies the identification number of the VLAN to which the filter is applied.

Modes Interface configuration mode

Usage Guidelines The **no** form of this command disables this functionality.

You must use the interface configuration mode to use this command.

If the VLAN is not specified in the command, the auth-default VLAN is used.

Examples The following example applies the MAC address filter on VLAN 2.

```
device(config)# authentication
device(config-authen)# interface ethernet 1/1/1
device(config-if-e1000-1/1/1)# mac-auth auth-filter 1 vlan 2
```

History	Release version	Command history
	08.0.20	This command was introduced.

mac-auth dot1x-override

Configures the device to perform dot1x authentication when MAC authentication fails.

Syntax **mac-auth dot1x-override**

 no mac-auth dot1x-override

Command Default MAC authentication dot1x override is not enabled.

Modes Authentication mode

Usage Guidelines The **no** form of the command disables MAC authentication dot1x override functionality.

Examples The following example enables MAC authentication dot1x override when MAC authentication fails.

```
device(config)# authentication
device(config-authen)# mac-auth dot1x-override
```

History	Release version	Command history
	08.0.20	This command was introduced.

mac-auth enable

Enables MAC authentication globally or on a specific interface.

Syntax `mac-auth enable [all | ethernet device/slot/port]`

no mac-auth enable [all | ethernet *device/slot/port*]

Command Default	MAC authentication is not enabled.
------------------------	------------------------------------

Parameters all

Enables MAC authentication on all interfaces.

ethernet *device/slot/port*

Enables MAC authentication on a specific interface.

Modes Authentication mode.

Usage Guidelines The **no** form of the command disables MAC authentication.

Examples The following example globally enables MAC authentication.

```
device(config)#authentication
device(config-authen)#mac-auth enable
device(config-authen)#mac-auth enable all
```

History	Release version	Command history
	08.0.20	This command was introduced.

mac-auth password-format

Configures the MAC authentication password format.

Syntax **mac-auth password-format { xx-xx-xx-xx-xx-xx | xxxx.xxxx.xxxx | xxxxxxxxxxxx } [upper-case]**
no mac-auth password-format { xx-xx-xx-xx-xx-xx | xxxx.xxxx.xxxx | xxxxxxxxxxxx } [upper-case]

Command Default By default, the MAC address is sent to the RADIUS server in the format xxxxxxxxxxxx in lower case.

Parameters **xx-xx-xx-xx-xx-xx** Specifies the MAC authentication password format as xx-xx-xx-xx-xx-xx.
 xxxx.xxxx.xxxx Specifies the MAC authentication password format as xxxx.xxxx.xxxx.
 xxxxxxxxxxxx Specifies the MAC authentication password format as xxxxxxxxxxxx.
 upper-case Converts the password to uppercase.

Modes Authentication mode

Usage Guidelines The **no** form of the command restores the default (no MAC authentication password format is configured).

You can configure the device to send the MAC address to the RADIUS server in the format xx-xx-xx-xx-xx-xx, or the format xxxx.xxxx.xxxx. Use the **upper-case** password format option to send the password in uppercase.

Examples The following example configures the MAC authentication password format as xx-xx-xx-xx-xx-xx.

```
device(config)# authentication
device(config-authen)# mac-auth password-format xx-xx-xx-xx-xx-xx
```

The following example configures the MAC authentication password format as xx-xx-xx-xx-xx-xx in upper case.

```
device(config)# authentication
device(config-authen)# mac-auth password-format xx-xx-xx-xx-xx-xx upper-case
```

History	Release version	Command history
	08.0.20	This command was introduced.
	08.0.20c	The upper-case option was added.

mac-auth password-override

Enables password override for MAC authentication. The password you specify is used for MAC authentication instead of the MAC address.

Syntax	mac-auth password-override <i>password</i>	
	no mac-auth password-override <i>password</i>	
Command Default	MAC authentication password override is not enabled.	
Parameters	<i>password</i>	Specifies the password to be used for MAC authentication. The password can contain up to 32 alphanumeric characters, but cannot include blank spaces.
Modes	Authentication mode	
Usage Guidelines	The no form disables MAC authentication password override.	
	The MAC address is still the user name and cannot be changed.	
Examples	The following example enables MAC authentication password override on the device.	
	device(config)# authentication	
	device(config-authen)# mac-auth password-override password	

History	Release version	Command history
	08.0.20	This command was introduced.

mac-notification interval

Configures the MAC-notification interval between each set of generated traps.

Syntax **mac-notification interval secs**
no mac-notification interval secs

Command Default No interval for MAC-notification is configured.

Parameters **secs**
Specifies the MAC-notification interval in seconds between each set of traps that are generated. The range is from 1 through 3600 seconds (1 hour). The default interval is 3 seconds.

Modes Global configuration mode

Usage Guidelines The **no** form of this command sets the interval to its default value, which is 3 seconds.
A trap is sent aggregating the MAC events such as addition or deletion depending on the interval you specify.

Examples The following example configures an interval of 40 seconds.
`device(config)# mac-notification interval 40`
The following example sets the interval to its default value:
`device(config)# no mac-notification interval 3`

History	Release version	Command history
	08.0.10	This command was introduced.

macsec cipher-suite

Enables GCM-AES-128 bit encryption or GCM-AES-128 bit integrity checks on MACsec frames transmitted between group members.

Syntax	macsec cipher-suite { gcm-aes-128 gcm-aes-128 integrity-only } no macsec cipher-suite { gcm-aes-128 gcm-aes-128 integrity-only }				
Command Default	GCM-AES-128 bit encryption or integrity checking is not enabled. Frames are encrypted starting with the first byte of the data packet, and ICV checking is enabled.				
Parameters	gcm-aes-128 Enables GCM-AES-128 bit encryption. gcm-aes-128 integrity-only Enables GCM-AES-128 bit integrity checks.				
Modes	dot1x-mka-cfg-group mode				
Usage Guidelines	<p>The no form of the command restores the default encryption and integrity checking.</p> <p>This command is supported only on the Brocade ICX 6610 in FastIron Release 08.0.20. In FastIron Release 08.0.30 and later releases, MACsec commands are also supported on the ICX 7450.</p> <p>The macsec cipher-suite command can be used in conjunction with an encryption offset configured with the macsec confidentiality-offset command.</p>				
Examples	<p>The following example enables GCM-AES-128 encryption on group test1.</p> <pre>device(config)# dot1x-mka-enable device(config-dot1x-mka)# mka-cfg-group test1 device(config-dot1x-mka-group-test1)# macsec cipher-suite gcm-aes-128</pre> <p>The following example enables GCM-AES-128 bit integrity checking on test1.</p> <pre>device(config)# dot1x-mka-enable device(config-dot1x-mka)# mka-cfg-group test1 device(config-dot1x-mka-group-test1)# macsec cipher-suite gcm-aes-128 integrity-only</pre>				
History	<table><tr><th>Release version</th><th>Command history</th></tr><tr><td>08.0.20</td><td>This command was introduced.</td></tr></table>	Release version	Command history	08.0.20	This command was introduced.
Release version	Command history				
08.0.20	This command was introduced.				

macsec confidentiality-offset

Configures the offset size for MACsec encryption.

Syntax **macsec confidentiality-offset size**
no macsec confidentiality-offset size

Command Default The default value for the MACsec encryption offset size is zero (0).

Parameters size
Determines where encryption begins. Valid values are:

30	Encryption begins at byte 31 of the data packet.
50	Encryption begins at byte 51 of the data packet.

Modes dot1x-mka-cfg-group mode

Usage Guidelines This command is supported only on the Brocade ICX 6610 in FastIron Release 08.0.20. In FastIron Release 08.0.30 and later releases, MACsec commands are also supported on the ICX 7450.

The **no** form of the command disables encryption offset on all interfaces in the MACsec MKA group.

This command is only meaningful when encryption is enabled for the MACsec group using the **macsec cipher-suite** command.

Examples The following example configures a 30-byte offset on encrypted transmissions as part of group test1 parameters.

```
device(config)# dot1x-mka-enable
device(config-dot1x-mka)# mka-cfg-group test1
device(config-dot1x-mka)# macsec cipher-suite gcm-aes-128
device(config-dot1x-mka-group-test1)# macsec confidentiality-offset 30
```

History	Release version	Command history
	08.0.20	This command was introduced.

macsec frame-validation

Enables validation checks for frames with MACsec headers and configures the validation mode (strict or not strict).

Syntax **macsec frame-validation { disable | check | strict }**

no macsec frame-validation { disable | check | strict }

Command Default MACsec frame validation is disabled (not visible in configuration).

Parameters **disable**

Disables validation checks for frames with MACsec headers.

check

Enables validation checks for frames with MACsec headers and configures non-strict validation mode. If frame validation fails, counters are incremented but packets are accepted.

strict

Enables validation checks for frames with MACsec headers and configures strict validation mode. If frame validation fails, counters are incremented and packets are dropped.

Modes dot1x-mka-cfg-group mode

Usage Guidelines This command is supported only on the Brocade ICX 6610 in FastIron Release 08.0.20. In FastIron Release 08.0.30 and later releases, MACsec commands are also supported on the ICX 7450.
The **no** form of the restores the default (validation checks for frames with MACsec headers is disabled).

Examples The following example enables validation checks for frames with MACsec headers on group test1 and configures strict validation mode.

```
device(config)# dot1x-mka-enable
device(config-dot1x-mka)# mka-cfg-group test1
device(config-dot1x-mka-group-test1)# macsec frame-validation strict
```

History

Release version	Command history
08.0.20	This command was introduced.

macsec replay-protection

Specifies the action to be taken when packets are received out of order, based on their packet number. If replay protection is configured, you can specify the window size within which out-of-order packets are allowed.

Syntax `macsec replay-protection { strict | out-of-order | window-size size } [disable]`
`no macsec replay-protection { strict | out-of-order window-size size } [disable]`

Parameters

- strict**
Does not allow out-of-order packets.
- out-of-order window-size**
Allows out-of-order packets within a specific window size.
- size**
Specifies the allowable window within which an out-of-order packet can be received. Allowable range is from 0 through 4294967295.
- disable**
Available only for the ICX 7450. Disables replay protection.

Modes dot1x-mka-cfg-group mode

Usage Guidelines This command is supported only on the Brocade ICX 6610 in FastIron Release 08.0.20. In FastIron Release 08.0.30 and later releases, it is also supported on the ICX 7450.

The **no** form of the command disables macsec replay protection.

Examples The following example configures group test1 to accept packets in exact sequence only.

```
device(config)# dot1x-mka-enable
device(config-dot1x-mka)# mka-cfg-group test1
device(config-dot1x-mka-group-test1)# macsec replay-protection strict
device(config-dot1x-mka-group-test1)#
```

The following example configures group test1 to accept out-of-order MACsec frames within a window size of 2000.

```
device(config)# dot1x-mka-enable
device(config-dot1x-mka)# mka-cfg-group test1
device(config-dot1x-mka-group-test1)# macsec replay-protection out-of-order window-size 2000
```

History

Release version	Command history
08.0.20	This command was introduced.
08.0.30	The disable option for the macsec replay-protection command was introduced.

match ipv6 address

Matches IPv6 address conditions in a route map instance.

Syntax **match ipv6 address { prefix-list prefix-list-name }**

no match ipv6 address

Command Default No routes are distributed based on destination network number.

Parameters **prefix-list prefix-list-name**
 Specifies the name of an IPv6 prefix list.

Modes Route map configuration mode

Usage Guidelines Use the **no** form of this command to remove the **match ipv6 address** entry.

Examples This example matches IPv6 routes that have addresses specified by the prefix list named "myprefixlist".

```
device# configure terminal
device(config)# route-map extComRmap permit 10
device(config-route-map-sendExtComRmap)# match ipv6 address prefix-list myprefixlist
```

max-hw-age

Enables and configures the maximum hardware age for denied MAC addresses.

Syntax **max-hw-age** *age*

no max-hw-age *age*

Command Default The maximum hardware age is not configured. The default hardware aging time is 70 seconds.

Parameters *age*

Specifies the maximum hardware age in seconds. The possible values range from 1 to 65535 seconds.

Modes Authentication mode

Usage Guidelines The **no** form of this command disables maximum hardware age.

Aging of the Layer 2 hardware entry for a blocked MAC address occurs in two phases, known as hardware aging and software aging. On FastIron devices, the hardware aging period for blocked MAC addresses is fixed at 70 seconds and is non-configurable. The hardware aging time for non-blocked MAC addresses is the length of time specified with the **mac-age** command. The software aging period for blocked MAC addresses is configurable through the CLI. Once the hardware aging period ends, the software aging period begins. When the software aging period ends, the blocked MAC address ages out, and can be authenticated again if the Brocade device receives traffic from the MAC address.

On FastIron X Series devices, the hardware aging period for blocked MAC addresses is not fixed at 70 seconds. The hardware aging period for blocked MAC addresses is equal to the length of time specified with the **mac-age** command. As on FastIron devices, once the hardware aging period ends, the software aging period begins. When the software aging period ends, the blocked MAC address ages out, and can be authenticated again if the device receives traffic from the MAC address.

Examples The following example enables maximum hardware age and sets it to 160 seconds.

```
device(config)# authentication
device(config-authen)# max-hw-age 160
```

History

Release version	Command history
08.0.20	This command was introduced.

maximum-paths

Changes the maximum number of BGP4 and BGP4+ shared paths.

Syntax	maximum-paths <i>num</i> use-load-sharing no maximum-paths				
Command Default	This option is disabled.				
Parameters	<i>num</i> Maximum number of paths across which the device balances traffic to a given BGP4 destination. Range is from 2 through 8. The default is 1. use-load-sharing Uses the maximum IP ECMP path value that is configured by means of the ip load-sharing command.				
Modes	BGP configuration mode BGP address-family IPv6 unicast configuration mode BGP address-family IPv4 unicast VRF configuration mode BGP address-family IPv6 unicast VRF configuration mode				
Usage Guidelines	Use the no form of this command to restore the default. Use this command to change the maximum number of BGP4 shared paths, either by setting a value or using the value configured by the ip load-sharing command. When this command is entered in BGP global configuration mode, it applies only to the IPv4 address family. Use this command in BGP address-family IPv6 unicast configuration mode for BGP4+ configurations.				
Examples	<p>This example sets the maximum number of BGP4 shared paths to 8.</p> <pre>device# configure terminal device(config)# router bgp device(config-bgp-router)# maximum-paths 8</pre> <p>This example sets the maximum number of BGP4+ shared paths to that of the value already configured using the ip load-sharing command.</p> <pre>device# configure terminal device(config)# router bgp device(config-bgp-router)# address-family ipv6 unicast device(config-bgp-ipv6u)# maximum-paths use-load-sharing</pre> <p>This example sets the maximum number of BGP4 shared paths to 2 in a nondefault VRF instance in the IPv4 address family.</p> <pre>device# configure terminal device(config)# router bgp device(config-bgp-router)# address-family ipv4 unicast vrf red device(config-bgp-ipv4u-vrf)# maximum-paths 2</pre>				
History	<table><tr><th>Release version</th><th>Command history</th></tr><tr><td>8.0.30</td><td>Support was added for the BGP address-family IPv6 unicast VRF configuration mode.</td></tr></table>	Release version	Command history	8.0.30	Support was added for the BGP address-family IPv6 unicast VRF configuration mode.
Release version	Command history				
8.0.30	Support was added for the BGP address-family IPv6 unicast VRF configuration mode.				

maximum-paths ebgp ibgp

Specifies the number of equal-cost multipath EBGp or IBGP routes or paths that are selected.

Syntax **maximum-paths** { **ebgp** *num* | **ibgp** *num* }

no maximum-paths

Command Default This option is disabled.

Parameters **ebgp**

Specifies EBGp routes or paths.

ibgp

Specifies IBGP routes or paths.

num

The number of equal-cost multipath routes or paths that are selected. Range is from 1 through 8. 1 disables equal-cost multipath.

Modes BGP configuration mode

BGP address-family IPv6 unicast configuration mode

BGP address-family IPv4 unicast VRF configuration mode

BGP address-family IPv6 unicast VRF configuration mode

Usage Guidelines Use the **no** form of this command to restore the default.

When this command is entered in BGP global configuration mode, it applies only to the IPv4 address family. Use this command in BGP address-family IPv6 unicast configuration mode for BGP4+ configurations.

Enhancements to BGP4 load sharing support the load sharing of BGP4 and BGP4+ routes in IP Equal-Cost Multipath (ECMP), even if the BGP4 multipath load-sharing feature is not enabled by means of the **use-load-sharing** option to the **maximum-paths** command. You can set separate values for IGMP and ECMP load sharing. Use this command to specify the number of equal-cost multipath EBGp or IBGP routes or paths that are selected.

Examples This example sets the number of equal-cost multipath EBGp routes or paths that will be selected to 6 in the IPv4 address family.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# maximum-paths ebgp 6
```

This example sets the number of equal-cost multipath IBGP routes or paths that will be selected to 4 in the IPv6 address family.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# address-family ipv6 unicast
device(config-bgp-ipv6u)# maximum-paths ibgp 4
```

This example sets the number of equal-cost multipath EBGp routes or paths that will be selected to 3 in a nondefault VRF instance in the IPv4 address family.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# address-family ipv4 unicast vrf red
device(config-bgp-ipv4u-vrf)# maximum-paths ebgp 3
```

History	Release version	Command history
	8.0.30	Support was added for the BGP address-family IPv6 unicast VRF configuration mode.

maximum-preference

Configures the Router Advertisement (RA) guard policy to accept RAs based on a router preference setting.

Syntax **maximum-preference { high | low | medium }**
no maximum-preference { high | low | medium }

Command Default

The router preference setting for the RA guard policy is high (allows all RAs).

Parameters **high** Configures the router preference of RAs for the RA guard policy to high (allows all RAs). This is the default.

low Allows RAs of low router preference.

medium Allows RAs of low and medium router preference.

Modes RA guard policy configuration mode

Usage Guidelines If a very low value is set, the RAs expected to be forwarded might get dropped.
 The **no** form of this command removes the router preference for an RA guard policy.

Examples The following example configures the RA guard policy router preference to low:

```
Brocade(config)# ipv6 raguard policy p1
Brocade(config-ipv6-RAG-policy p1)# maximum-preference low
```

max-mcache

Configures the maximum number of PIM cache entries.

Syntax	max-mcache <i>num</i>
	no max-mcache <i>num</i>
Command Default	If this command is not configured, the maximum value is determined by the system max pim-hw-mcache command or by available system resources.
Parameters	<i>num</i> Specifies the maximum number of multicast cache entries for PIM.
Modes	PIM router configuration mode PIM router VRF mode
Usage Guidelines	<p>The no form of this command removes the configuration and resets the command to its default behavior.</p> <p>Configure the max-mcache command to define the maximum number of repeated cache entries for PIM traffic being sent from the same source address and being received by the same destination address. To define this maximum for the default VRF, configure the command in router PIM configuration mode; to define the maximum for a specific VRF, first configure the router pim vrf command.</p>
Examples	<p>This example configures the maximum number of PIM cache entries for the default VRF to 999.</p> <pre>device(config)# router pim device(config-pim-router)# max-mcache 999</pre> <p>This example configures the maximum number of PIM cache entries for the VRF, VPN1, to 999.</p> <pre>device(config)# router pim vrf vpn1 device(config-pim-router-vrf-vpn1)# max-mcache 999</pre>

History	Release version	Command history
	08.0.20	This command was introduced.

med-missing-as-worst

Configures the device to favor a route that has a Multi-Exit Discriminator (MED) over a route that does not have one.

Syntax **med-missing-as-worst**
no med-missing-as-worst

Command Default This option is disabled.

Modes BGP configuration mode

Usage Guidelines Use the **no** form of this command to restore the default.

When MEDs are compared, by default the device favors a low MED over a higher one. Because the device assigns a value of 0 to a route path MED if the MED value is missing, the default MED comparison results in the device favoring the route paths that do not have MEDs.

Examples This example configures the device to favor a route containing a MED.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# med-missing-as-worst
```

mesh-group

Configures a multicast source discovery protocol (MSDP) mesh group from several rendezvous points (RPs).

Syntax **mesh-group** *group-name* *peer-address*

no mesh-group *group-name* *peer-address*

Command Default Mesh groups are not configured.

Parameters *group-name*

Specifies the mesh group as alphabetic characters. The limit is 31 characters.

peer-address

Specifies the IP address of the MSDP peer that is being placed in the mesh group. Each mesh group can include up to 32 peers.

Modes MSDP VRF configuration mode

Usage Guidelines The **no** form of this command removes mesh groups.

You must configure the **msdp-peer** command to configure the MSDP peers by assigning their IP addresses and the loopback interfaces before you configure a mesh group.

You can have up to four mesh groups in a multicast network. Each mesh group can include up to 15 peers.

Each device that will be part of a mesh group must have a mesh group definition for all the peers in the mesh-group.

Examples This example configures an MSDP mesh group on each device that will be included in the mesh group.

```
Device(config)# router msdp
Device(config-msdp-router)# msdp-peer 206.251.18.31 connect-source loopback 2
Device(config-msdp-router)# msdp-peer 206.251.19.31 connect-source loopback 2
Device(config-msdp-router)# msdp-peer 206.251.20.31 connect-source loopback 2
Device(config-msdp-router)# mesh-group GroupA 206.251.18.31
Device(config-msdp-router)# mesh-group GroupA 206.251.19.31
Device(config-msdp-router)# mesh-group GroupA 206.251.20.31
Device(config-msdp-router)# exit
```

message-interval

Changes the default PIM Sparse join or prune message interval.

Syntax `message-interval [vrf vrf-name] interval`

`no message-interval [vrf vrf-name] interval`

Parameters `vrf vrf-name`

Specifies a VRF instance.

`interval`

Specifies the join or prune message interval in seconds. The range is 10 through 18724; the default is 60.

Command Default The join or prune interval is 60 seconds.

Modes PIM router configuration mode

PIM router VRF configuration mode

Usage Guidelines The **no** form of this command restores the default; the join-prune interval is 60 seconds.

PIM Sparse join and prune messages inform other PIM Sparse routers about clients who want to become receivers (join) or stop being receivers (prune) for PIM Sparse groups.

NOTE

Configure the same join or prune message interval on all the PIM Sparse routers in the PIM Sparse domain. The performance of PIM Sparse can be adversely affected if the routers use different timer intervals.

Examples This example changes the PIM join or prune interval to 30 seconds.

```
Device(config)# ipv6 router pim
Device(config-ipv6-pim-router)# message-interval 30
```

This example changes the PIM join or prune interval on a VRF to 30 seconds.

```
Device(config)# ipv6 router pim vrf blue
Device(config-ipv6-pim-router-vrf-blue)# message-interval 30
```

mka-cfg-group

Creates and names a MACsec Key Agreement (MKA) configuration group.

Syntax **mka-cfg-group** *group-name*

no mka-cfg-group *group-name*

Command Default No MACsec options are configured for an MKA configuration group. All related parameters retain their default settings.

Parameters *group-name*

Provides a name for an MKA configuration group that can be applied to ports.

Modes dot1x-mka configuration mode

dot1x-mka-interface configuration mode

Usage Guidelines This command is supported only on the Brocade ICX 6610 in FastIron Release 08.0.20. In FastIron Release 08.0.30 and later releases, MACsec commands are also supported on the ICX 7450.

The **no** form of this command deletes the MKA configuration group. MACSec is disabled on the ports where the group is configured.

The **dot1x-mka-enable** command must be executed before the **mka-cfg-group** command can be used.

After the MACsec Key Agreement (MKA) configuration group is created, you can apply the configured group and its settings to an interface being configured using the **mka-cfg-group** command in the dot1x-mka-interface configuration mode.

Examples The following example creates the MKA configuration group test1.

```
device(config)# dot1x-mka
    dot1x-mka-enable          Enable MACsec
device(config)# dot1x-mka-enable
device(config-dot1x-mka)#
device(config-dot1x-mka)# mka-cfg-group
    ASCII string      Name for this group
device(config-dot1x-mka)# mka-cfg-group test1
device(config-dot1x-mka-group-test1)#

device(config-dot1x-mka-group-test1)# key-server-priority
    DECIMAL      Priority of the Key Server. Valid values should be between 0 and 255
device(config-dot1x-mka-group-test1)# key-server-priority 5
device(config-dot1x-mka-group-test1)#

device(config-dot1x-mka-group-test1)# macsec cipher-suite
    gcm-aes-128      GCM-AES-128 Cipher suite
device(config-dot1x-mka-group-test1)# macsec cipher-suite gcm-aes-128
device(config-dot1x-mka-group-test1)#

device(config-dot1x-mka-group-test1)# macsec confidentiality-offset
    30      Confidentiality offset of 30
    50      Confidentiality offset of 50
device(config-dot1x-mka-group-test1)# macsec confidentiality-offset 30
device(config-dot1x-mka-group-test1)#

device(config-dot1x-mka-group-test1)# macsec frame-validation
    check      Validate frames with secTAG and accept frames without secTAG
    disable    Disable frame validation
    strict     Validate frames with secTAG and discard frames without secTAG
device(config-dot1x-mka-group-test1)# macsec frame-validation strict
device(config-dot1x-mka-group-test1)#

device(config-dot1x-mka-group-test1)# macsec replay-protection
    out-of-order  Validate MACsec frames arrive in the given window size
    strict        Validate MACsec frames arrive in a sequence
device(config-dot1x-mka-group-test1)# macsec replay-protection strict
device(config-dot1x-mka-group-test1)#
```

The following example applies the previously configured MKA group test1 to ethernet interface 1/3/3.

```
device(config)# dot1x-mka-enable
device(config-dot1x-mka)# enable-mka ethernet 1/3/3
device(config-dot1x-mka-1/3/3)# mka-cfg-group test1
```

History	Release version	Command history
	08.0.20	This command was introduced.
	08.0.20a	This command was expanded to support the association of a configured MKA group and its settings to an interface at the interface configuration level. The mka-group command was deprecated as part of this change.

mount disk0

Mounts the filesystem of the external USB.

Syntax **mount disk0**

Modes User EXEC mode.

Examples This example mounts the filesystem of the external USB.
device# mount disk0

History	Release version	Command history
	08.0.30	This command was introduced.

mstp instance

Configures a Multiple Spanning Tree Protocol (MSTP) instance that allows multiple VLANs to be managed by a single STP instance and supports per-VLAN STP. This allows you to use fewer spanning-tree instances to map to VLANs.

Syntax	mstp instance <i>instance-number</i> [vlan <i>vlan-id</i> vlan-group <i>group-id</i>] [priority <i>priority-value</i>] no mstp instance <i>instance-number</i> [vlan <i>vlan-id</i> vlan-group <i>group-id</i>] [priority <i>priority-value</i>]
Command Default	No MSTP instances are configured. Any VLANs remain in the common, internal spanning tree (CIST) or are free.
Parameters	<p><i>instance-number</i></p> <p>Specifies the number for the instance of MSTP that you are configuring. You can specify up to 15 instances, identifying each, in MSTP mode, by a number in the range 1 through 4094. In MSTP mode, you cannot specify the value 0, which identifies the CIST. In MSTP+ mode, the range is 0 through 4094.</p> <p>vlan <i>vlan-id</i></p> <p>Assigns one or more VLANs or a range of VLANs to the MSTP instance.</p> <p>vlan-group <i>group-id</i></p> <p>Assigns one or more VLAN groups to the MSTP instance.</p> <p>priority <i>priority-value</i></p> <p>Specifies the forwarding preference for instances within a VLAN or on the device. You can specify a numeric value in the range 0 to 61440 in increments of 4096. A higher priority variable means a lower forwarding priority. The default value is 32768.</p>
Modes	Global configuration mode
Usage Guidelines	<p>In MSTP mode, the no form of this command moves a VLAN or VLAN group from its assigned MSTP back into the CIST. In MSTP+ mode, the no form of this command assigns any VLAN as a free VLAN.</p> <p>The system does not allow an MSTP instance without any VLANs mapped to it; removing all VLANs from an MSTP instance deletes the instance from the system.</p> <p>In MSTP+ mode, you can specify an instance number value of 0 because MSTP+ mode allows you to add VLANs to and remove VLANs from the CIST.</p>
Examples	<p>The following example configures an MSTP instance and map VLANs 1 to 7 to it.</p> <pre>Device(config)# mstp instance 7 vlan 4 to 7</pre> <p>The following example specifies a priority of 8192 to MSTP instance 1.</p> <pre>Device(config)# mstp instance 1 priority 8192</pre>

mstp scope

Configures VLANs in Multiple Spanning Tee Protocol (MSTP) mode.

Syntax **mstp scope { all | pvst }**
no mstp scope { all | pvst }

Command Default No VLAN is under direct MSTP control.

Parameters **all** Configures MSTP on all VLANs.
pvst Configures MSTP in per-VLAN spanning tree (PVST) mode.

Modes Global configuration mode

Usage Guidelines The **no** form of this command removes the MSTP PVST mode and restores the device to non-MSTP mode.

MSTP is not operational until the **mstp start** command is configured. You cannot start MSTP+ unless at least one MSTP+ instance of MSTP+ is configured.

Examples The following example configures MSTP mode on all VLANs.
`Device(config)# mstp scope all`

The following example enables MSTP in PVST mode.
`Device(config)# mstp scope pvst`

History	Release version	Command history
	8.0.20	This command was modified to support the pvst keyword.

multicast disable-pimsm-snoop

Disables PIM Sparse mode (SM) snooping for a specific VLAN when snooping is enabled globally.

Syntax **multicast disable-pimsm-snoop**
no multicast disable-pimsm-snoop

Command Default The global PIM SM snooping setting applies.

Modes VLAN configuration mode

Usage Guidelines The **no** form of this command restores the global PIM SM snooping setting.

Examples This example disables PIM SM snooping on VLAN 20.

```
Device(config)#config vlan 20
Device(config-vlan-20)#multicast disable-pimsm-snoop
```

multicast fast-convergence

Configures a device to listen to topology change events in Layer 2 protocols such as spanning tree, and then send general queries to shorten the convergence time.

Syntax **multicast fast-convergence**

no multicast fast-convergence

Command Default Fast convergence is not configured.

Modes VLAN configuration mode

Usage Guidelines The **no** form of this command restores the default; fast convergence is not configured.

If the Layer 2 protocol cannot detect a topology change, fast convergence may not work in some cases. For example, if the direct connection between two devices switches from one interface to another, the Rapid Spanning Tree protocol (802.1w) considers this optimization rather than a topology change. In this example, other devices do not receive topology change notifications, and cannot send queries to speed up the convergence. Fast convergence works well with the regular spanning tree protocol in this case.

Examples This example configures fast convergence on VLAN 70.

```
Device(config)#vlan 70
Device(config-vlan-70)#multicast fast-convergence
```

multicast fast-leave-v2

Configures fast leave for IGMP V2.

Syntax **multicast fast-leave-v2**
no multicast fast-leave-v2

Command Default Fast leave for IGMP V2 is not configured.

Modes VLAN configuration mode

Usage Guidelines The **no** form of this command restores the default; fast leave for IGMP V2 is not configured.

When a device receives an IGMP V2 leave message, it sends out multiple group-specific queries. If no other client replies within the waiting period, the device stops forwarding traffic. When the **multicast fast-leave-v2** command is configured, and when the device receives a leave message, it immediately stops forwarding to that port. The device does not send group specific-queries. When the **multicast fast-leave-v2** command is configured on a VLAN, you must not have multiple clients on any port that is part of the VLAN.

In a scenario where two devices connect, the querier device should not be configured for fast-leave-v2 because the port might have multiple clients through the non-querier.

You can configure the **ip multicast leave-wait-time** command to set the number of queries and the waiting period.

Examples This example configures fast leave for IGMP on VLAN 10.

```
Device(config)#vlan 10
Device(config-vlan-10)#multicast fast-leave-v2
```

multicast pimsm-snooping prune-wait

Configures the amount of time a device waits after receiving a PIM prune message before removing the outgoing interface (OIF) from the forwarding entry.

Syntax **multicast pimsm-snooping prune-wait** *seconds*

 no multicast pimsm-snooping prune-wait *seconds*

Command Default The prune-wait time is 5 seconds.

Parameters *seconds*

 The time to wait, in seconds. The range is 0 to 65535; the default is 5.

Modes VLAN configuration mode

Usage Guidelines The **no** form of this command restores the default prune-wait time (5 seconds).

 The prune-wait time is necessary on a LAN where multiple receivers could be listening to the group; it gives them time to override the prune message. Configure the **multicast pimsm-snooping prune-wait** command to modify the prune-wait time according to topology and PIM router configurations.

 In accordance with RFC 4601, PIM routers delay pruning for 3.5 seconds by default, so configuring a lower prune-wait value may cause traffic disruption. You should configure a prune-wait value lower than 3.5 seconds only if the topology supports it, for example, if the group has only one receiver, and an immediate prune is needed.

Examples The following example configures the prune-wait time to 7 seconds.

 Device(config)#vlan 10
 Device(config-vlan-10)#multicast pimsm-snooping prune-wait 7

History	Release version	Command history
	8.0.20	This command was introduced.

multicast port-version

Configures the IGMP version on individual ports in a VLAN.

Syntax **multicast port-version** { 2 | 3 } **ethernet** *port* [**ethernet** *port* | **to** *port*]
no multicast port-version { 2 | 3 } **ethernet** *port* [**ethernet** *port* | **to** *port*]

Command Default The port uses the IGMP version configured globally or for the VLAN.

Parameters **2** Configures IGMP version 2.
 3 Configures IGMP version 3.
 ethernet *port* Specifies the port to configure the version on.
 to Specifies a range of ports.

Modes VLAN configuration mode

Usage Guidelines The **no** form of this command restores the IGMP version configured globally or for the VLAN.
 You can specify a list of ports, separated by a space, or a range of ports, or you can combine lists and ranges.
 See the description of the **ip multicast version** command for information on how to configure the IGMP version globally.
 See the description of the **multicast version** command for information on how to configure the IGMP version on a VLAN.

Examples This example configures ports 4, 5, and 6 to use IGMP version 3.

```
Device(config)#config vlan 20
(config-vlan-20)#multicast port-version 3 ethernet 2/4 to 2/6
```


multicast proxy-off

Turns off proxy activity for static groups.

Syntax **multicast proxy-off**
no multicast proxy-off

Command Default Proxy activity is on.

Modes VLAN configuration mode

Usage Guidelines The **no** form of this command restores the default; proxy activity is on.

When a device is configured for static groups, it acts as a proxy and sends membership reports for the static groups when it receives general or group-specific queries. When a static group configuration is removed, the group is deleted from the active group table immediately. However, leave messages are not sent to the querier, and the querier must age out the group. You can configure the **multicast proxy-off** command to turn off proxy activity.

Examples This example turns off proxy activity for VLAN 20.

```
Device(config)#vlan 20
Device(config-vlan-20)#multicast proxy-off
```

multicast router-port

Configures a static router Ethernet port to receive multicast control and data packets.

Syntax **multicast router-port ethernet stackid/slot/portnum [ethernet stackid/slot/portnum | to stackid/slot/portnum]**

multicast router-port ethernet stackid/slot/portnum [ethernet stackid/slot/portnum | to stackid/slot/portnum]

Command Default The device forwards all multicast control and data packets only to router ports that receive queries.

Parameters *stackid/slot/portnum*

Specifies the Ethernet port you want to force traffic to. On standalone devices specify the interface ID in the format slot/port-id; on stacked devices you must also specify the stack ID, in the format stack-id/slot/port-id. You can configure a single port or a list of ports, separated by a space.

to

Specifies a range of ports.

Modes VLAN configuration mode

Usage Guidelines The **no** form of this command restores the default, that is, the device forwards all multicast control and data packets only to router ports that receive queries.

Examples This example configures a static port on Ethernet 1/1/3 on VLAN 70.

```
device#configure terminal
device(config)#vlan 70
device(config-vlan-70)#multicast router-port ethernet 1/1/3
```

This example configures a list of static ports on VLAN 70.

```
device#configure terminal
device(config)#vlan 70
device(config-vlan-70)#multicast router-port ethernet 1/1/24 ethernet 1/6/24 ethernet 1/8/17
```

This example configures a range of static ports on VLAN 70.

```
device#configure terminal
device(config)#vlan 70
device(config-vlan-70)#multicast router-port ethernet 1/1/1 to 1/1/8
```

This example configures a combined range and list of static ports on VLAN 70.

```
device#configure terminal
device(config)#vlan 70
device(config-vlan-70)#multicast router-port ethernet 1/1/1 to 1/1/8 ethernet 1/1/24 ethernet 1/6/24 ethernet 1/8/17
```

multicast static-group

Configures a static IGMP group for a VLAN.

Syntax `multicast static-group ipv4-address [count num] [ethernet stackid/slot/portnum | drop]`

no multicast static-group *ipv4-address* [**count** *num*] [**ethernet** *stackid/slot/portnum* | **drop**]

Command Default The VLAN cannot forward multicast traffic to ports that do not receive IGMP membership reports.

Parameters *ipv4-address*

Specifies the address of the static group.

count *num*

Specifies a contiguous range of groups.

ethernet stackid/slot/portnum

Specifies the ports to be included in the group. On standalone devices specify the interface ID in the format slot/port-ID; on stacked devices you must also specify the stack ID, in the format stack-ID/slot/port-ID.

drop

Specifies discarding data traffic to a group in hardware.

Modes VLAN configuration mode

Usage Guidelines The **no** form of this command removes the static group fromr the VLAN.

A snooping-enabled VLAN cannot forward multicast traffic to ports that do not receive IGMP membership reports. You can configure the **multicast static-group** command to create a static group that applies to specific ports, allowing packets to be forwarded to them even though they have no client membership reports.

On FCX, ICX 6610, ICX 6430, ICX 6450, and ICX 6650 devices, configuring the **drop** keyword discards data traffic to a group in hardware. The group can be any multicast group including groups in the reserved range of 224.0.0.X. Configuring the **drop** keyword does not affect IGMP packets, which are always trapped to CPU when snooping is enabled. It applies to the entire VLAN, and cannot be configured for a port list. When the **drop** keyword is not configured, the group must exist outside the reserved range.

Examples This example configures on VLAN 20 a static group containing ports 1/1/3 and 1/1/5 to 1/1/7.

```
device# configure terminal
device(config)# vlan 20
device(config-vlan-20)# multicast static-group 224.1.1.1 count 2 ethernet 1/1/3
ethernet 1/1/5 to 1/1/7
```

multicast tracking

Enables tracking and fast leave on VLANs.

Syntax **multicast tracking**

no multicast tracking

Command Default Tracking and fast leave are disabled.

Modes VLAN configuration mode

Usage Guidelines The **no** form of this command restores the default, that is, tracking and fast leave are disabled.
The membership tracking and fast leave features are supported for IGMP V3 only. If any port or any client is not configured for IGMP V3, the multicast tracking command is ignored.

Examples This example enables tracking and fast leave on VLAN 20.

```
Device(config)#vlan 20  
Device(config-vlan-20)#multicast tracking
```

multicast version

Configures the IGMP version for snooping on a VLAN.

Syntax **multicast version [2 | 3]**

no multicast version

Command Default The globally-configured IGMP version is used.

Parameters **2**
Configures IGMP version 2.

3
Configures IGMP version 3.

Modes VLAN configuration mode

Usage Guidelines The **no** form of this command restores the globally configured version.

If an IGMP version is configured for an individual port, that port uses the version configured for it, not the VLAN version.

See the description of the **ip multicast version** command for information on how to configure the IGMP version globally.

See the description of the **multicast port-version** command for information on how to configure the IGMP version on an individual port

Examples This example configures IGMP version 3 on VLAN 20.

```
Device(config)#vlan 20
Device(config-vlan-20)#multicast version 3
```

multicast6 disable-mld-snoop

Disables multicast listening discovery (MLD) snooping for a specific VLAN when snooping is enabled globally.

Syntax **multicast6 disable-multicast-snoop**

no multicast6 disable-multicast-snoop

Command Default The global MLD snooping setting applies.

Modes VLAN configuration mode

Usage Guidelines The **no** form of this command restores the global MLD snooping setting.

Examples This example disables MLD snooping on VLAN 20.

```
Device(config)#vlan 20
Device(config-vlan-20)#multicast6 disable-multicast-snoop
```

multicast6 disable-pimsm-snoop

When PIM6 SM snooping is enabled globally, overrides the global setting and disables it for a specific VLAN.

Syntax **multicast6 disable-pimsm-snoop**
no multicast6 disable-pimsm-snoop

Command Default The globally configured PIM6 SM snooping applies.

Modes VLAN configuration mode

Usage Guidelines The **no** form of this command restores the globally configured PIM6 SM snooping.
The device must be in multicast listening discovery (MLD) passive mode before PIM6 SM snooping can be disabled.

Examples This example enables PIM6 SM traffic snooping on VLAN 20.
Device(config)# vlan 20
Device(config-vlan-20)#multicast6 disable-pimsm-snoop

multicast6 fast-convergence

Configures a device to listen to topology change events in Layer 2 protocols such as spanning tree, and then send general queries to shorten the convergence time.

Syntax **multicast6 fast-convergence**

no multicast6 fast-convergence

Command Default Fast convergence is not configured.

Modes VLAN configuration mode

Usage Guidelines The **no** form of this command restores the default; fast convergence is not configured.

Configure the **multicast6 fast-convergence** command to allow a device to listen to topology change events in Layer 2 protocols, such as Spanning Tree, and send general queries to shorten the convergence time.

If the Layer 2 protocol cannot detect a topology change, fast convergence may not work in some cases. For example, if the direct connection between two devices switches from one interface to another, the Rapid Spanning Tree protocol (802.1w) considers this to be optimization rather than a topology change. In this case, other devices do not receive topology change notifications and cannot send queries to speed up convergence. The original spanning tree protocol does not recognize optimization actions, and fast convergence works in all cases.

Examples This example configures fast convergence on VLAN 70.

```
device# configure terminal
device(config)# vlan 70
device(config-vlan-70)# multicast6 fast-convergence
```


multicast6 port-version

Configures the multicast listening discovery (MLD) version on individual ports in a VLAN.

Syntax `multicast6 port-version { 1 | 2 } [ethernet stackid/slot/portnum [ethernet stackid/slot/portnum | to port]]`

```
no multicast6 port-version { 1 | 2 } [ ethernet stackid/slot/portnum [ ethernet stackid/slot/portnum | to port ] ]
```

Command Default	The port uses the MLD version configured globally or for the VLAN.
------------------------	--

Parameters

1

Configures MLD version 1.

2

Configures MLD version 2.

ethernet *stackid/slot/portnum*

Specifies the port to configure the version on. On standalone devices specify the interface ID in the format `slot/port-id`; on stacked devices you must also specify the stack ID, in the format `stack-id/slot/port-id`. You can specify a list of ports, separated by a space, or a range of ports, or you can combine lists and ranges.

to

Specifies a range of ports.

Modes

VLAN configuration mode

Usage Guidelines

The **no** form of this command restores the MLD version configured globally or for the VLAN.

When you configure the MLD version on a specified port or range of ports, the other ports use the MLD version specified with the **multicast6 version** command, or the globally configured MLD version.

Examples

This example configures ports 1/1/4, 1/1/5, 1/1/6, and 1/2/1 on VLAN 20 to use MLD version 2.

```
Device(config)#vlan 20
Device(config-vlan-20)#multicast6 port-version 2 ethernet 1/2/1 ethernet 1/1/4 to
1/1/6
```

multicast6 proxy-off

Turns off multicast listening discovery (MLD) proxy activity.

Syntax **multicast6 proxy-off**

no multicast6 proxy-off

Command Default MLD snooping proxy activity is on.

Modes VLAN configuration mode

Usage Guidelines The **no** form of this command restores the default; proxy activity is on.

When a device is configured for static groups, it acts as a proxy and sends membership reports for the static groups when it receives general or group-specific queries. When a static group configuration is removed, the group is deleted from the active group table immediately. However, leave messages are not sent to the querier, and the querier must age out the group. You can configure the **multicast proxy-off** command to turn off proxy activity.

Examples This example turns off proxy activity for VLAN 20.

```
Device(config)#vlan 20
Device(config-vlan-20)#multicast6 proxy-off
```

multicast6 router-port

Configures a static router port to receive IPv6 multicast control and data packets.

Syntax **multicast6 router-port ethernet** *stackid/slot/portnum* [**ethernet** *stackid/slot/portnum* | **to** *stackid/slot/portnum*]

no multicast6 router-port ethernet *stackid/slot/portnum* [**ethernet** *stackid/slot/portnum* | **to** *stackid/slot/portnum*]

Command Default The device forwards all IPv6 multicast control and data packets only to router ports that receive queries.

Parameters **ethernet** *stackid/slot/portnum*

Specifies the Ethernet port you want to force traffic to. On standalone devices specify the interface ID in the format slot/port-ID; on stacked devices you must also specify the stack ID, in the format stack-ID/slot/port-ID. You can configure a single port or a list of ports, separated by a space.

to

Specifies a range of ports.

Modes VLAN configuration mode

Usage Guidelines The **no** form of this command restores the default, that is, the device forwards all multicast control and data packets only to router ports that receive queries.

All multicast control and data packets are forwarded to router ports that receive queries. Although router ports are learned, you can configure static router ports to force multicast traffic to specific ports, even though these ports never receive queries.

Examples This example configures a range and a list of static ports on VLAN 70.

```
device#configure terminal
device(config)#vlan 70
device(config-vlan-70)#multicast6 router-port ethernet 1/1/1 to 1/1/8 ethernet 1/1/24
ethernet 1/6/24 ethernet 1/8/17
```

multicast6 static-group

Configures a static multicast listening discovery (MLD) group for a VLAN.

Syntax **multicast6 static-group** *ipv6-address* [**count** *num*] [**ethernet** *stackid/slot/portnum* | **to** *stackid/slot/portnum*]

no multicast6 static-group *ipv6-address* [**count** *num*] [**ethernet** *stackid/slot/portnum* | **to** *stackid/slot/portnum*]

Command Default The VLAN cannot forward multicast traffic to ports that do not receive MLD membership reports.

Parameters *ipv6-address*

Specifies the IPv6 address of the multicast group.

count *num*

Specifies a contiguous range of groups. The default is 1.

to

Specifies a range of ports.

ethernet *stackid/slot/portnum*

Specifies the Ethernet port you want to force traffic to. On standalone devices specify the interface ID in the format slot/port-ID; on stacked devices you must also specify the stack ID, in the format stack-ID/slot/port-ID. You can configure a single port or a list of ports, separated by a space.

Modes VLAN configuration mode

Usage Guidelines The **no** form of this command removes the static group from the VLAN.

A snooping-enabled VLAN cannot forward multicast traffic to ports that do not receive MLD membership reports. To allow clients to send reports, you can configure a static group that applies to individual ports on the VLAN. The static group forwards packets to the static group ports even if they have no client membership reports.

You cannot configure a static group that applies to an entire VLAN.

The maximum number of supported static groups in a VLAN is 512, and the maximum number of supported static groups for individual ports in a VLAN is 256.

Examples This example configures on VLAN 20 a static group containing ports 0/1/3 and 0/1/5 to 0/1/7.

```
Device(config)#vlan 20
(config-vlan-20)#multicast6 static-group ff05::100 count 2 ethernet 0/1/3 ethernet
0/1/5 to 0/1/7
```

multicast6 tracking

Enables tracking and fast leave for IPv6 multicast listening discovery Version 2 (MLDv2) on VLANs.

Syntax **multicast6 tracking**
no multicast6 tracking

Command Default Tracking and fast leave are disabled.

Modes VLAN configuration mode

Usage Guidelines The **no** form of this command restores the default, that is, tracking and fast leave are disabled.
The membership tracking and fast leave features are supported for MLDv2 only. If any port or any client is not configured for MLDv2, the multicast tracking command is ignored.

Examples This example enables tracking and fast leave on VLAN 20.

```
Device(config)#vlan 20  
Device(config-vlan-20)#multicast6 tracking
```

multicast6 version

Configures the multicast listening discovery (MLD) version for snooping on a VLAN.

Syntax	multicast6 version { 1 2 }	
	no multicast6 version { 1 2 }	
Command Default	The globally configured MLD version is configured.	
Parameters	1	Configures MLD Version 1.
	2	Configures MLD Version 2.
Modes	Global configuration mode	
Usage Guidelines	The no form of this command restores the globally configured MLD version.	
	If an MLD version is specified for individual ports, these ports use that version instead of the version specified for the VLAN.	
Examples	This example specifies MLD Version 2 on VLAN 20.	
	Device(config)# vlan 20 Device(config-vlan-20)#multicast6 version 2	

multipath

Changes load sharing to apply to only IBGP or EBGP paths, or to support load sharing among paths from different neighboring autonomous systems.

Syntax	multipath { ebgp ibgp multi-as } no multipath { ebgp ibgp multi-as }
Command Default	This option is disabled.
Parameters	ebgp Enables load sharing of EBGP paths only. ibgp Enables load sharing of IBGP paths only. multi-as Enables load sharing of paths from different neighboring autonomous systems.
Modes	BGP configuration mode BGP address-family IPv6 unicast configuration mode BGP address-family IPv4 unicast VRF configuration mode BGP address-family IPv6 unicast VRF configuration mode
Usage Guidelines	<p>Use the no form of this command to restore the default.</p> <p>When this command is entered in BGP global configuration mode, it applies only to the IPv4 address family. Use this command in BGP address-family IPv6 unicast configuration mode for BGP4+ configurations.</p> <p>By default, when BGP4 load sharing is enabled, both IBGP and EBGP paths are eligible for load sharing, while paths from different neighboring autonomous systems are not.</p>
Examples	<p>This example changes load sharing to apply to IBGP paths in the IPv4 address family.</p> <pre>device# configure terminal device(config)# router bgp device(config-bgp-router)# multipath ibgp</pre> <p>This example enables load sharing of paths from different neighboring autonomous systems in the IPv6 address family.</p> <pre>device# configure terminal device(config)# router bgp device(config-bgp-router)# address-family ipv6 unicast device(config-bgp-ipv6u)# multipath multi-as</pre> <p>This example changes load sharing to apply to EBGP paths in a nondefault VRF instance in the IPv4 address family.</p> <pre>device# configure terminal device(config)# router bgp device(config-bgp-router)# address-family ipv4 unicast vrf red device(config-bgp-ipv4u-vrf)# multipath ebgp</pre>

History	Release version	Command history
	8.0.30	Support was added for the BGP address-family IPv6 unicast VRF configuration mode.

nbr-timeout

Configures the interval after which a PIM device considers a neighbor to be absent.

Syntax **nbr-timeout** *seconds*

no nbr-timeout *seconds*

Command Default The timeout interval is 105 seconds.

Parameters *seconds*

Specifies the interval, in seconds. The range is 35 through 65535 seconds. The default is 105 seconds.

Modes PIM router configuration mode

Usage Guidelines The **no** form of this command restores the default timeout interval, 105 seconds.
You should set the interval to be not less than 3.5 times the hello timer value.

Examples This example configures a PIM neighbor timeout value of 360 seconds on all ports on a device operating with PIM.

```
Device(config)# router pim
Device(config-pim-router)# nbr-timeout 360
```

neighbor activate

Enables the exchange of information with BGP neighbors and peer groups.

Syntax `neighbor { ip-address | ipv6-address | peer-group-name } activate`

no neighbor { ip-address | ipv6-address | peer-group-name } activate

Command Default	Enabling address exchange for the IPv6 address family is disabled.
------------------------	--

Parameters *ip-address*

Specifies the IPv4 address of the neighbor.

ipv6-address

Specifies the IPv6 address of the neighbor.

peer-group-name

Specifies a peer group.

Modes	BGP configuration mode
--------------	------------------------

BGP address-family IPv6 unicast configuration mode

BGP address-family IPv4 unicast VRF configuration mode

BGP address-family IPv6 unicast VRF configuration mode

Usage Guidelines	Use the no form of this command to disable the exchange of an address with a BGP neighbor or peer group.
-------------------------	---

When this command is entered in BGP global configuration mode, it applies only to the IPv4 address family. Use this command in BGP address-family IPv6 unicast configuration mode for BGP4+ configurations.

Examples This example establishes a BGP session with a neighbor with the IPv6 address 2001:2018:8192::125.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# address-family ipv6 unicast
device(config-bgp-ipv6u)# neighbor 2001:2018:8192::125 neighbor activate
```

This example establishes a BGP session with a neighbor with the IPv6 address 2001:2018:8192::125 for VRF instance "red".

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# address-family ipv6 unicast vrf red
device(config-bgp-ipv6u-vrf)# neighbor 2001:2018:8192::125 neighbor activate
```

History

Release version	Command history
8.0.30	Support was added for the BGP address-family IPv6 unicast VRF configuration mode.

neighbor advertisement-interval

Enables changes to the interval over which a specified neighbor or peer group holds route updates before forwarding them.

Syntax **neighbor** { *ip-address* | *ipv6-address* | *peer-group-name* } **advertisement-interval** *seconds*

no neighbor { *ip-address* | *ipv6-address* | *peer-group-name* } **advertisement-interval**

Command Default The default is 0.

Parameters *ip-address*

IPv4 address of the neighbor.

ipv6-address

IPv6 address of the neighbor.

peer-group-name

Peer group name configured by the **neighbor peer-group-name** command.

seconds

Range is from 0 through 3600.

Modes BGP configuration mode

BGP address-family IPv4 unicast VRF configuration mode

BGP address-family IPv6 unicast VRF configuration mode

Examples This example changes the BGP4 advertisement interval from the default to 60 seconds.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# neighbor 10.11.12.13 advertisement-interval 60
```

This example changes the BGP4+ advertisement interval from the default for VRF instance "red".

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# address-family ipv6 unicast vrf red
device(config-bgp-ipv6u-vrf)# neighbor 2001:2018:8192::125 advertisement-interval 60
```

History

Release version	Command history
8.0.30	Support was added for the BGP address-family IPv6 unicast VRF configuration mode.

neighbor allowas-in

Disables the AS_PATH check function for routes learned from a specified location so that BGP does not reject routes that contain the recipient BGP speaker's AS number.

Syntax **neighbor** {*ip-address* | *ipv6-address* | *peer-group-name* } **neighbor allowas-in** *number*

no neighbor allowas-in {*ip-address* | *ipv6-address* | *peer-group-name* } **neighbor allowas-in** *number*

Command Default The AS_PATH check function is enabled and any route whose path contains the speaker's AS number is rejected as a loop.

Parameters *ip-address*

Specifies the IP address of the neighbor.

ipv6-address

Specifies the IPv6 address of the neighbor.

peer-group-name

Specifies a peer group.

number

Specifies the number of times that the AS path of a received route may contain the recipient BGP speaker's AS number and still be accepted. Valid values are 1 through 10.

Modes BGP configuration mode

BGP address-family IPv6 unicast configuration mode

Usage Guidelines Use the **no** form of this command to re-enable the AS_PATH check function.

When this command is entered in BGP global configuration mode, it applies only to the IPv4 address family. Use this command in BGP address-family IPv6 unicast configuration mode for BGP4+ configurations.

Examples This example specifies that the AS path of a received route may contain the recipient BGP speaker's AS number three times and still be accepted.

```
device#configure terminal
device(config)# router bgp
device(config-bgp-router)# address-family ipv6 unicast
device(config-bgp-ipv6u)# neighbor 2001:2018:8192::125 allowas-in 3
```

neighbor as-override

Replaces the autonomous system number (ASN) of the originating device with the ASN of the sending BGP device.

Syntax **neighbor** { *ip-address* | *ipv6-address* | *peer-group-name* } **as-override**

no neighbor { *ip-address* | *ipv6-address* | *peer-group-name* } **as-override**

Parameters *ip-address*

IPv4 address of the neighbor.

ipv6-address

IPv6 address of the neighbor.

peer-group-name

Peer group name configured by the **neighbor peer-group-name** command.

Modes BGP configuration mode

Usage Guidelines Use the **no** form of this command to disable this feature.

BGP loop prevention verifies the ASN in the AS path. If the receiving router sees its own ASN in the AS path of the received BGP packet, the packet is dropped. The receiving router assumes that the packet originated from its own AS and has reached the place of origination. This can be a significant problem if the same ASN is used among various sites, preventing sites with identical ASNs from being linked by another ASN. In this case, routing updates are dropped when another site receives them.

Examples This example replaces the ASN globally.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# neighbor 10.11.12.13 as-override
```

neighbor capability as4

Enables or disables support for 4-byte autonomous system numbers (ASNs) at the neighbor or peer-group level.

Syntax **neighbor** { *ip-address* | *ipv6-address* | *peer-group-name* } **capability as4** [**enable** | **disable**]

no neighbor { *ip-address* | *ipv6-address* | *peer-group-name* } **capability as4** [**enable** | **disable**]

Command Default 4-byte ASNs are disabled by default.

Parameters *ip-address*

IPv4 address of the neighbor.

ipv6-address

IPv6 address of the neighbor .

peer-group-name

Peer group name configured by the **neighbor** *peer-group-name* command.

enable

Enables 4-byte numbering.

disable

Disables 4-byte numbering.

Modes BGP configuration mode

Usage Guidelines Use the **disable** keyword or the **no** form of this command to remove all neighbor capability for 4-byte ASNs.

4-byte ASNs are first considered at the neighbor, then at the peer group, and finally at the global level.

Examples This example enables 4-byte ASNs globally.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# neighbor 10.11.12.13 capability as4 enable
```

neighbor capability orf prefixlist

Advertises outbound route filter (ORF) capabilities to peer routers.

Syntax **neighbor** { *ip_address* | *ipv6_address* | *peer-group-name* } **capability orf prefixlist** [*receive* | *send*]

no neighbor { *ip_address* | *ipv6_address* | *peer-group-name* } **capability orf prefixlist** [*receive* | *send*]

Command Default ORF capabilities are not advertised to a peer device.

Parameters	<i>ip_address</i>	Specifies the IPv4 address of the neighbor.
	<i>ipv6_address</i>	Specifies the IPv6 address of the neighbor.
	<i>peer-group-name</i>	Specifies a peer group.
	receive	Enables the ORF prefix list capability in receive mode.
	send	Enables the ORF prefix list capability in send mode.

Modes	
	BGP configuration mode
	BGP address-family IPv6 unicast configuration mode
	BGP address-family IPv4 unicast VRF configuration mode
	BGP address-family IPv6 unicast VRF configuration mode

Usage Guidelines	Use the no form of this command to disable ORF capabilities.
	When this command is entered in BGP global configuration mode, it applies only to the IPv4 address family. Use this command in BGP address-family IPv6 unicast configuration mode for BGP4+ configurations.

Examples This example advertises the ORF send capability to a neighbor with the IP address 10.11.12.13.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# neighbor 10.11.12.13 capability orf prefixlist send
```

This example advertises the ORF receive capability to a neighbor with the IPv6 address 2001:2018:8192::125.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# address-family ipv6 unicast
device(config-bgp-ipv6u)# neighbor 2001:2018:8192::125 capability orf prefixlist
receive
```

History	Release version	Command history
	8.0.30	Support was added for the BGP address-family IPv6 unicast VRF configuration mode.

neighbor default-originate

Configures the device to send the default route 0.0.0.0 to a neighbor.

Syntax	neighbor { <i>ip-address</i> <i>ipv6-address</i> <i>peer-group-name</i> } default-originate [route-map <i>map-name</i>] no neighbor { <i>ip-address</i> <i>ipv6-address</i> <i>peer-group-name</i> } default-originate [route-map <i>map-name</i>]
Parameters	<p><i>ip-address</i> IPv4 address of the neighbor.</p> <p><i>ipv6-address</i> IPv6 address of the neighbor.</p> <p><i>peer-group-name</i> Peer group name configured by the neighbor <i>peer-group-name</i> command.</p> <p>route-map Optionally injects the default route conditionally, depending on the match conditions in the route map.</p> <p><i>map-name</i> Name of the route map.</p>
Modes	BGP configuration mode BGP address-family IPv6 unicast configuration mode
Usage Guidelines	<p>Use the no form of the command to restore the defaults.</p> <p>When this command is entered in BGP global configuration mode, it applies only to the IPv4 address family. Use this command in BGP address-family IPv6 unicast configuration mode for BGP4+ configurations.</p>
Examples	<p>This example sends the default route to a BGP4 neighbor.</p> <pre>device# configure terminal device(config)# router bgp device(config-bgp-router)# neighbor 10.11.12.13 default-originate route-map myroutemap</pre> <p>This example sends the default route to a BGP4+ neighbor.</p> <pre>device# configure terminal device(config)# router bgp device(config-bgp-router)# address-family ipv6 unicast device(config-bgp-ipv6u)# neighbor 2001:2018:8192::125 default-originate route-map myroutemap22</pre>

neighbor description

Specifies a name for a neighbor.

Syntax `neighbor { ip-address | ipv6-address | peer-group-name } description string`

no neighbor { ip-address | ipv6-address | peer-group-name } description

Parameters *ip-address*

IPv4 address of the neighbor.

ipv6-address

IPv6 address of the neighbor.

peer-group-name

Peer group name configured by the **neighbor** *peer-group-name* command.

description *string*

Specifies the name of the neighbor, an alphanumeric string up to 220 characters long.

Modes	BGP configuration mode
--------------	------------------------

BGP address-family IPv4 unicast VRF configuration mode

BGP address-family IPv6 unicast VRF configuration mode

Usage Guidelines Use the **no** form of this command to remove the name.

Examples This example specifies a BGP4 neighbor name.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# neighbor 10.11.12.13 description mygoodneighbor
```

This example specifies a BGP4+ neighbor name for VRF instance "red".

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# address-family ipv6 unicast vrf red
device(config-bgp-ipv6u-vrf)# neighbor 2001:2018:8192::125 default-originate route-
map myroutemap
```

History

Release version	Command history
8.0.30	Support was added for the BGP address-family IPv6 unicast VRF configuration mode.

neighbor ebgp-btsh

Enables EBGP TTL security hack protection (BTSH).

Syntax `neighbor { ip-address | ipv6-address | peer-group-name } ebgp-btsh`

no neighbor { *ip-address* | *ipv6-address* | *peer-group-name* } **ebgp-btsh**

Parameters *ip-address*

IPv4 address of the neighbor

ipv6-address

IPv6 address of the neighbor

peer-group-name

Peer group name configured by the **neighbor** *peer-group-name* command.

Modes	BGP configuration mode
--------------	------------------------

BGP address-family IPv4 unicast VRF configuration mode

BGP address-family IPv6 unicast VRF configuration mode

Usage Guidelines Use the **no** form of this command to disable this feature.

Examples

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# neighbor 10.11.12.13 ebgp-btsh
```

History

Release version	Command history
8.0.30	Support was added for the BGP address-family IPv6 unicast VRF configuration mode.

neighbor ebgp-multihop

Allows EBGP neighbors that are not on directly connected networks and sets an optional maximum hop count.

Syntax **neighbor** { *ip-address* | *ipv6-address* | *peer-group-name* } **ebgp-multihop** [*max-hop-count*]

```
no neighbor { ip-address | ipv6-address | peer-group-name } ebgp-multiphop [ ]
```

Parameters *ip-address*

IPv4 address of the neighbor

ipv6-address

IPv6 address of the neighbor

peer-group-name

Peer group name configured by the **neighbor** *peer-group-name* command.

max-hop-count

Maximum hop count (optional). Range is from 1 through 255.

Modes	BGP configuration mode
--------------	------------------------

BGP address-family IPv4 unicast VRF configuration mode

BGP address-family IPv6 unicast VRF configuration mode

Usage Guidelines Use the **no** form of this command to disable this feature.

Examples This example enables EBGP multihop and sets the maximum hop count to 20.

```
device# configure terminal
```

```
device(config)# router bgp
```

```
device(config-bgp-router)# neighbor 10.11.12.13 ebgp-multihop 20
```

This example enables BGP4+ EBGP multihop for VRF instance "red" and sets the maximum hop count to 40.

```
device# configure terminal
```

```
device(config)# router bgp
```

```
device(config-bgp-router)# address-family ipv6 unicast vrf red
```

```
device(config-bgp-ipv6u-vrf)# neighbor 2001:2018:8192::125 ebgp-multihop 40
```

History

Release version	Command history
8.0.30	Support was added for the BGP address-family IPv6 unicast VRF configuration mode.

neighbor enforce-first-as

Ensures that a device requires the first ASN listed in the AS_SEQUENCE field of an AS path-update message from EBGP neighbors to be the ASN of the neighbor that sent the update.

Syntax `neighbor { ip-address | ipv6-address | peer-group-name } enforce-first-as [enable | disable]`

no neighbor { *ip-address* | *ipv6-address* | *peer-group-name* } **enforce-first-as** [**enable** | **disable**]

Command Default	Disabled by default.
------------------------	----------------------

Parameters *ip-address*

IPv4 address of the neighbor.

ipv6-address

IPv6 address of the neighbor.

peer-group-name

Peer group name configured by the **neighbor** *peer-group-name* command.

enable

Enables this feature.

disable

Disables this feature.

Modes	BGP configuration mode
--------------	------------------------

Usage Guidelines Use the **no** form of this command to disable this requirement globally for the device.

Examples This example enables the enforce-first-as feature for a specified neighbor.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# neighbor 10.11.12.13 enforce-first-as enable
```

Syntax **neighbor** { *ip-address* | *ipv6-address* | *peer-group-name* } **filter-list** *ip-prefix-list-name* { **in** | **out** }

no neighbor { *ip-address* | *ipv6-address* | *peer-group-name* } **filter-list** *ip-prefix-list-name* { **in** | **out** }

Modes	BGP configuration mode
	BGP address-family IPv6 unicast configuration mode

Examples This example specifies that filter list “myfilterlist” be applied to updates to a neighbor with the IP address 10.11.12.13.

This example specifies that filter list “2” be applied to updates from a neighbor with the IPv6 address 2001:2018:8192::125.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# address-family ipv6 unicast
device(config-bgp-ipv6u)# neighbor 2001:218:8192::125 filter-list 2 in
```

neighbor local-as

Causes the device to prepend the local autonomous system number (ASN) automatically to routes received from an EBGp peer.

Syntax	neighbor { <i>ip-address</i> <i>ipv6-address</i> <i>peer-group-name</i> } local-as <i>num</i> [no-prepend] no neighbor { <i>ip-address</i> <i>ipv6-address</i> <i>peer-group-name</i> } local-as <i>num</i> [no-prepend]
Parameters	<i>ip-address</i> IPv4 address of the neighbor. <i>ipv6-address</i> IPv6 address of the neighbor. <i>peer-group-name</i> Peer group name configured by the neighbor peer-group-name command. <i>num</i> Local ASN. Range is from 1 through 4294967295. no-prepend Causes the device to stop prepending the selected ASN.
Modes	BGP configuration mode
Usage Guidelines	Use the no form of this command to remove the local ASN.
Examples	<p>This example ensures that a device prepends the local ASN.</p> <pre>device# configure terminal device(config)# router bgp device(config-bgp-router)# neighbor 10.11.12.13 local-as 100</pre> <p>This example stops the device from prepending the selected ASN.</p> <pre>device# configure terminal device(config)# router bgp device(config-bgp-router)# neighbor 10.11.12.13 local-as 100 no-prepend</pre>

neighbor maxas-limit in

Causes the device to discard routes received in UPDATE messages if those routes exceed a maximum AS path length.

Syntax **neighbor** { *ip-address* | *ipv6-address* | *peer-group-name* } **maxas-limit in** { *num* | **disable** }

no neighbor { *ip-address* | *ipv6-address* | *peer-group-name* } **maxas-limit in**

Command Default This command is disabled by default.

Parameters *ip-address*

IPv4 address of the neighbor.

ipv6-address

IPv6 address of the neighbor.

peer-group-name

Peer group name configured by the **neighbor** *peer-group-name* command.

num

Maximum length of the AS path. Range is from 0 through 300. The default is 300.

disable

Prevents a neighbor from inheriting the configuration from the peer group or global configuration and instead uses the default system value.

Modes BGP configuration mode

Usage Guidelines Use the **no** form of this command to remove this configuration.

Examples This example changes the length of the maximum allowed AS path length from the default.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# neighbor 10.11.12.13 maxas-limit in 200
```

This example prevents a neighbor from inheriting the configuration from the peer group or global configuration and instead use the default system value.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# neighbor 2001:2018:8192::125 maxas-limit in disable
```

neighbor maximum-prefix

Specifies the maximum number of IP network prefixes (routes) that can be learned from a specified neighbor or peer group.

Syntax	<p>neighbor { <i>ip-address</i> <i>ipv6-address</i> <i>peer-group-name</i> } maximum-prefix <i>num</i> [<i>threshold</i>] [teardown]</p> <p>no neighbor { <i>ip-address</i> <i>ipv6-address</i> <i>peer-group-name</i> } maximum-prefix <i>num</i> [<i>threshold</i>] [teardown]</p>
Parameters	<p><i>ip-address</i> IPv4 address of the neighbor.</p> <p><i>ipv6-address</i> IPv6 address of the neighbor.</p> <p><i>peer-group-name</i> Peer group name configured by the neighbor peer-group-name command.</p> <p><i>num</i> Maximum number of IP prefixes that can be learned. Range is from 0 through 4294967295. Default is 0 (unlimited).</p> <p><i>threshold</i> Specifies the percentage of the value specified by <i>num</i> that causes a syslog message to be generated. Range is from 1 through 100. Default is 100.</p> <p>teardown Tears down the neighbor session if the maximum number of IP prefixes is exceeded.</p>
Modes	<p>BGP configuration mode</p> <p>BGP address-family IPv6 unicast configuration mode</p>
Usage Guidelines	<p>Use the no form of the command to restore the defaults.</p> <p>When this command is entered in BGP global configuration mode, it applies only to the IPv4 address family. Use this command in BGP address-family IPv6 unicast configuration mode for BGP4+ configurations.</p>
Examples	<p>This example sets the maximum number of prefixes that will be accepted from the neighbor with the IP address 10.11.12.13 to 100000, and sets the threshold value to 80%.</p> <pre>device# configure terminal device(config)# router bgp device(config-bgp-router)# neighbor 10.11.12.13 maximum-prefix 100000 threshold 80</pre>

neighbor next-hop-self

Causes the device to list itself as the next hop in updates that are sent to the specified neighbor.

Syntax **neighbor** { *ip-address* | *ipv6-address* | *peer-group-name* } **next-hop-self** [**always**]

no neighbor { *ip-address* | *ipv6-address* | *peer-group-name* } **next-hop-self** [**always**]

Parameters *ip-address*

IPv4 address of the neighbor.

ipv6-address

IPv6 address of the neighbor.

peer-group-name

Peer group name configured by the **neighbor** *peer-group-name* command.

always

Enables this feature for route reflector (RR) routes.

Modes BGP configuration mode

BGP address-family IPv4 unicast VRF configuration mode

BGP address-family IPv6 unicast VRF configuration mode

Usage Guidelines Use the **no** form of this command to remove this configuration.

Examples This example causes all updates destined for the neighbor with the IP address 10.11.12.13 to advertise this device as the next hop.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# neighbor 10.11.12.13 next-hop-self
```

This example, for the VRF instance "red," causes all updates destined for the neighbor with the IPv6 address 2001:2018:8192::125 to advertise this device as the next hop.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# address-family ipv6 unicast vrf red
device(config-bgp-ipv6u-vrf)# neighbor 10.11.12.13 next-hop-self
```

History

Release version	Command history
8.0.30	Support was added for the BGP address-family IPv6 unicast VRF configuration mode.

neighbor password

Specifies an MD5 password for securing sessions between the device and a neighbor.

Syntax **neighbor** { *ip-address* | *ipv6-address* | *peer-group-name* } **password** *string*
no neighbor { *ip-address* | *ipv6-address* | *peer-group-name* } **password**

Parameters *ip-address* IPv4 address of the neighbor.
 ipv6-address IPv6 address of the neighbor.
 peer-group-name Peer group name configured by the **neighbor peer-group-name** command.
 string Password of up to 63 characters in length that can contain any alphanumeric character.

Modes BGP configuration mode
 BGP address-family IPv4 unicast VRF configuration mode
 BGP address-family IPv6 unicast VRF configuration mode

Usage Guidelines Use the **no** form of this command to remove this configuration.

Examples This example specifies a password for securing sessions with a specified neighbor.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# neighbor 10.11.12.13 password s0M3P@55W0Rd
```

This BGP4+ example, for VRF instance "red," specifies a password for securing sessions with a specified neighbor.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# address-family ipv6 unicast vrf red
device(config-bgp-ipv4u-vrf)# neighbor 2001:2018:8192::125 password s0M3P@55W0Rd
```

History	Release version	Command history
	8.0.30	Support was added for the BGP address-family IPv6 unicast VRF configuration mode.

neighbor prefix-list

Filters the outgoing and incoming route updates to or from a particular BGP neighbor according to IP address and mask length.

Syntax	neighbor { <i>ip-address</i> <i>ipv6-address</i> <i>peer-group-name</i> } prefix-list <i>string</i> { in out } no neighbor { <i>ip-address</i> <i>ipv6-address</i> <i>peer-group-name</i> } prefix-list <i>string</i> { in out }
Parameters	<i>ip-address</i> IPv4 address of the neighbor <i>ipv6-address</i> IPv6 address of the neighbor <i>peer-group-name</i> Peer group name configured by the neighbor <i>peer-group-name</i> command. <i>string</i> Name of the prefix list. in Applies the filter in incoming routes. out Applies the filter in outgoing routes.
Modes	BGP configuration mode BGP address-family IPv6 unicast configuration mode
Usage Guidelines	Use the no form of the command to restore the defaults. When this command is entered in BGP global configuration mode, it applies only to the IPv4 address family. Use this command in BGP address-family IPv6 unicast configuration mode for BGP4+ configurations.
Examples	This example applies the prefix list "myprefixlist" to incoming advertisements to neighbor 10.11.12.13. <pre>device# configure terminal device(config)# router bgp device(config-bgp-router)# neighbor 10.11.12.13 prefix-list myprefixlist in</pre> This example applies the prefix list "myprefixlist" to outgoing advertisements to neighbor 2001:2018:8192::125. <pre>device# configure terminal device(config)# router bgp device(config-bgp-router)# address-family ipv6 unicast device(config-bgp-ipv6u)# neighbor 2001:2018:8192::125 prefix-list myprefixlist out</pre>

neighbor remote-as

Specifies the autonomous system (AS) in which a remote neighbor resides.

Syntax `neighbor { ip-address | ipv6-address | peer-group-name } remote-as num`

no neighbor { *ip-address* | *ipv6-address* | *peer-group-name* } **remote-as**

Parameters *ip-address*

IPv4 address of the neighbor

ipv6-address

IPv6 address of the neighbor

peer-group-name

Peer group name configured by the **neighbor** *peer-group-name* command.

num

Remote AS number (ASN). Range is from 1 through 4294967295.

Modes BGP configuration mode

BGP address-family IPv4 unicast VRF configuration mode

BGP address-family IPv6 unicast VRF configuration mode

Usage Guidelines Use the **no** form of this command to remove the neighbor from the AS.

Examples This example specifies AS 100 for a neighbor.

```
device# configure terminal
device(config)# router bgp
device(config-bgp)# neighbor 10.11.12.13 remote-as 100
```

The following BGP4+ example, for VRF instance "red," specifies AS 100 for a neighbor.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# address-family ipv6 unicast vrf red
device(config-bgp-ipv6u-vrf)# neighbor 2001:2018:8192::125 remote-as 100
```

History	Release version	Command history
	8.0.30	Support was added for the BGP address-family IPv6 unicast VRF configuration mode.

neighbor remove-private-as

Configures a device to remove private autonomous system numbers (ASNs) from UPDATE messages that the device sends to a neighbor.

Syntax **neighbor** { *ip-address* | *ipv6-address* | *peer-group-name* } **remove-private-as**
no neighbor { *ip-address* | *ipv6-address* | *peer-group-name* } **remove-private-as**

Parameters *ip-address*
IPv4 address of the neighbor
ipv6-address
IPv6 address of the neighbor
peer-group-name
Peer group name configured by the **neighbor peer-group-name** command.

Modes BGP configuration mode
BGP address-family IPv4 unicast VRF configuration mode
BGP address-family IPv6 unicast VRF configuration mode

Usage Guidelines Use the **no** form of this command to restore the default.
The device will remove ASNs 64512 through 65535 (the well-known BGP4 private ASNs) from the AS-path attribute in UPDATE messages that the device sends to a neighbor.

Examples This example removes private ASNs globally.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# neighbor 10.11.12.13 remove-private-as
```

This example removes private ASNs for VRF instance "red".

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# address-family ipv6 unicast vrf red
device(config-bgp-ipv6u-vrf)# neighbor 10.11.12.13 remove-private-as
```

History	Release version	Command history
	8.0.30	Support was added for the BGP address-family IPv6 unicast VRF configuration mode.

neighbor route-map

Filters the outgoing and incoming route updates to or from a particular BGP neighbor according to a set of attributes defined in a route map.

Syntax **neighbor** { *ip-address* | *ipv6-address* | *peer-group-name* } **route-map** { *in string* | *out string* }

no neighbor { *ip-address* | *ipv6-address* | *peer-group-name* } **route-map** { *in string* | **out** *string* }

Parameters *ip-address*

IPv4 address of the neighbor

ipv6-address

IPv6 address of the neighbor

peer-group-name

Peer group name configured by the **neighbor** *peer-group-name* command.

in

Applies the filter on incoming routes.

string

Name of the route map.

out

Applies the filter on outgoing routes.

Modes BGP configuration mode

BGP address-family IPv6 unicast configuration mode

Usage Guidelines Use the **no** form of the command to restore the defaults.

When this command is entered in BGP global configuration mode, it applies only to the IPv4 address family. Use this command in BGP address-family IPv6 unicast configuration mode for BGP4+ configurations.

Examples This example applies a route map named "myroutemap" to an outgoing route from 10.11.12.13.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# neighbor 10.11.12.13 route-map myroutemap out
```

neighbor route-reflector-client

Configures a neighbor to be a route-reflector client.

Syntax	neighbor { <i>ip-address</i> <i>ipv6-address</i> <i>peer-group-name</i> } route-reflector-client no neighbor { <i>ip-address</i> <i>ipv6-address</i> <i>peer-group-name</i> } route-reflector-client
Parameters	<i>ip-address</i> IPv4 address of the neighbor <i>ipv6-address</i> IPv6 address of the neighbor <i>peer-group-name</i> Peer group name configured by the neighbor <i>peer-group-name</i> command.
Modes	BGP configuration mode BGP address-family IPv6 unicast configuration mode
Usage Guidelines	Use the no form of this command to restore the default. When this command is entered in BGP global configuration mode, it applies only to the IPv4 address family. Use this command in BGP address-family IPv6 unicast configuration mode for BGP4+ configurations. Use this command on a host device to configure a neighbor to be a route-reflector client. Once configured, the host device from which the configuration is made acts as a route-reflector server.
Examples	This example configures a neighbor to be a route-reflector client. <pre>device# configure terminal device(config)# router bgp device(config-bgp-router)# neighbor 10.11.12.13 route-reflector-client</pre>

neighbor send-community

Enables sending the community attribute in updates to the specified BGP neighbor.

Syntax **neighbor** { *ip-address* | *ipv6-address* | *peer-group-name* } **send-community** [*both* | *extended* | *standard*]

no neighbor { *ip-address* | *ipv6-address* | *peer-group-name* } **send-community** [*both* | *extended* | *standard*]

Command Default	The device does not send community attributes.
------------------------	--

Parameters	<i>ip-address</i>	IPv4 address of the neighbor
	<i>ipv6-address</i>	IPv6 address of the neighbor
	<i>peer-group-name</i>	Peer group name configured by the neighbor <i>peer-group-name</i> command.
	both	Sends both standard and extended attributes.
	extended	Sends extended attributes.
	standard	Sends standard attributes.

Modes	BGP configuration mode
	BGP address-family IPv6 unicast configuration mode

Usage Guidelines Use the **no** form of the command to restore the defaults.

When this command is entered in BGP global configuration mode, it applies only to the IPv4 address family. Use this command in BGP address-family IPv6 unicast configuration mode for BGP4+ configurations.

Examples This example sends standard community attributes to a neighbor.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# neighbor 10.11.12.13 send-community standard
```

neighbor shutdown

Causes a device to shut down the session administratively with its BGP neighbor.

Syntax **neighbor** { *ip-address* | *ipv6-address* | *peer-group-name* } **shutdown** { **generate-rib-out** }

no neighbor { *ip-address* | *ipv6-address* | *peer-group-name* } **shutdown** { **generate-rib-out** }

Parameters *ip-address*

IPv4 address of the neighbor

ipv6-address

IPv6 address of the neighbor

peer-group-name

Peer group name configured by the **neighbor** *peer-group-name* command.

generate-rib-out

When a peer is put into the shutdown state, Routing Information Base (RIB) outbound routes are not produced for that peer. Use this option to produce those routes.

Modes	BGP configuration mode
--------------	------------------------

BGP address-family IPv4 unicast VRF configuration mode

BGP address-family IPv6 unicast VRF configuration mode

Usage Guidelines Use the **no** form of this command to restore the defaults.

Shutting down a session lets you configure the neighbor and save the configuration without the need to establish a session with that neighbor.

Examples This example a device to shut down the session administratively with its neighbor.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# neighbor 10.11.12.13 shutdown
```

This example causes a device to shut down the session administratively with its neighbor and generate RIB outbound routes for VRF instance "red".

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# address-family ipv6 unicast vrf red
device(config-bgp-ipv6u-vrf)# neighbor 2001:2018:8192::125 shutdown generate-rib-out
```

History	Release version	Command history
	8.0.30	Support was added for the BGP address-family IPv6 unicast VRF configuration mode.

neighbor soft-reconfiguration inbound

Stores all the route updates received from a BGP neighbor.

Syntax **neighbor** { *ip-address* | *ipv6-address* | *peer-group-name* } **soft-reconfiguration** **inbound**

no neighbor { *ip-address* | *ipv6-address* | *peer-group-name* } **soft-reconfiguration** **inbound**

Parameters	<i>ip-address</i>	IPv4 address of the neighbor
	<i>ipv6-address</i>	IPv6 address of the neighbor
	<i>peer-group-name</i>	Peer group name configured by the neighbor <i>peer-group-name</i> command.

Modes	BGP configuration mode
	BGP address-family IPv4 unicast VRF configuration mode
	BGP address-family IPv6 unicast VRF configuration mode

Usage Guidelines	Use the no form of the command to disable this feature.
	Soft reconfiguration stores all the route updates received from a neighbor. If you request a soft reset of inbound routes, the software compares the policies against the stored route updates, instead of requesting the neighbor's BGP4 or BGP4+ route table or resetting the session with the neighbor.

Examples This example globally stores route updates from a BGP4 neighbor.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# neighbor 10.11.12.13 soft-configuration inbound
```

This example stores route updates from a BGP4+ neighbor for VRF instance "red".

```
device# configure terminal
device(config)# address-family ipv6 unicast vrf red
device(config-bgp-ipv6u-vrf)# neighbor 2001:2018:8192::125 soft-configuration inbound
```

History	Release version	Command history
	8.0.30	Support was added for the BGP address-family IPv6 unicast VRF configuration mode.

neighbor timers

Specifies how frequently a device sends KEEPALIVE messages to its BGP neighbors, as well as how long the device waits for KEEPALIVE or UPDATE messages before concluding that a neighbor is dead.

Syntax **neighbor** { *ip-address* | *ipv6-address* | *peer-group-name* } **timers keep-alive** *keepalive_interval* **hold-time** *holdtime_interval*

no neighbor { *ip-address* | *ipv6-address* | *peer-group-name* } **timers keep-alive** *keepalive_interval*
hold-time *holdtime_interval*

Command Default The keep-alive timer is 60 seconds. The hold timer is 180 seconds.

Parameters *ip-address*

IPv4 address of the neighbor

ipv6-address

IPv6 address of the neighbor

peer-group-name

Peer group name configured by the **neighbor** *peer-group-name* command.

keep-alive *keepalive_interval*

Frequency (in seconds) with which a device sends keepalive messages to a peer. Range is from 0 through 65535 seconds. The default is 60.

hold-time *holdtime_interval*

Interval in seconds that a device waits to receive a keepalive message from a peer before declaring that peer dead. Range is from 0 through 65535 seconds. The default is 180.

Modes BGP configuration mode

BGP address-family IPv4 unicast VRF configuration mode

BGP address-family IPv6 unicast VRF configuration mode

Usage Guidelines Use the **no** form of the command to restore the defaults.

Examples This example sets the keepalive timer for a device to 120 seconds and the hold-timer to 360 seconds.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# neighbor 10.11.12.13 timers keep-alive 120 hold-time 360
```

This example sets the keepalive timer for VRF instance "red" to 120 seconds and the hold-timer to 360 seconds.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# address-family ipv6 unicast vrf red
device(config-bgp-ipv6u-vrf)# neighbor 10.11.12.13 timers keep-alive 120 hold-time 360
```

History

Release version	Command history
8.0.30	Support was added for the BGP address-family IPv6 unicast VRF configuration mode.

neighbor update-source

Configures the device to communicate with a neighbor through a specified interface.

Syntax **neighbor** { *ip-address* | *ipv6-address* | *peer-group-name* } **update-source** { *ip-address* | *ipv6-address* | **ethernet** | **loopback** *num* | **ve** *vlan_id* }

no neighbor { *ip-address* | *ipv6-address* | *peer-group-name* } **update-source** { *ip-address* | *ipv6-address* | **ethernet** | **loopback** *num* | **ve** *vlan_id* }

Parameters

- ip-address*
IPv4 address of the neighbor
- ipv6-address*
IPv6 address of the neighbor
- peer-group-name*
Peer group name configured by the **neighbor peer-group-name** command.
- ip-address*
IP address of the update source.
- ipv6-address*
IPv6 address of the update source.
- ethernet** *stackid/slot/portnum*
Specifies the physical interface. On standalone devices specify the interface ID in the format slot/port-id; on stacked devices you must also specify the stack ID, in the format stack-id/slot/port-id.
- loopback** *num*
Specifies a loopback interface.
- ve** *vlan_id*
Specifies a virtual Ethernet VLAN interface.

Modes

- BGP configuration mode
- BGP address-family IPv4 unicast VRF configuration mode
- BGP address-family IPv6 unicast VRF configuration mode

Usage Guidelines Use the **no** form of the command to restore the defaults.

Examples This example configures the device globally to communicate with a neighbor through the specified IPv4 address and port.

```
device#configure terminal
device#(config)# router bgp
device(config-bgp)# neighbor 10.11.12.13 update-source ethernet 15/1/1
```

History

Release version	Command history
8.0.30	Support was added for the BGP address-family IPv6 unicast VRF configuration mode.

neighbor weight

Specifies a weight that the device will add to routes that are received from the specified BGP neighbor.

Syntax **neighbor** { *ip-address* | *ipv6-address* | *peer-group-name* } **weight** *num*
no neighbor { *ip-address* | *ipv6-address* | *peer-group-name* } **weight** *num*

Command Default The default for *num* is 0.

Parameters *ip-address*
 IPv4 address of the neighbor.
 ipv6-address
 IPv6 address of the neighbor
 peer-group-name
 Name of the peer group.
 num
 Value from 1 through 65535.

Modes BGP configuration mode
 BGP address-family IPv6 unicast configuration mode

Usage Guidelines Use the **no** form of the command to restore the defaults.
 BGP prefers larger weights over smaller weights.
 When this command is entered in BGP global configuration mode, it applies only to the IPv4 address family. Use this command in BGP address-family IPv6 unicast configuration mode for BGP4+ configurations.

Examples This example changes the weight from the default.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# neighbor 10.11.12.13 weight 100
```

network

Configures the device to advertise a network.

Syntax **network** *network/mask* [**backdoor** | **route-map** *map-name* | **weight** *num*]
no network *network/mask* [**backdoor** | **route-map** *map-name* | **weight** *num*]

Command Default No network is advertised.

Parameters *network/mask*
 Network and mask in CIDR notation.

backdoor
 Changes administrative distance of the route to this network from the EBGp administrative distance (the default is 20) to the local BGP4 weight (the default is 200), tagging the route as a backdoor route.

route-map *map-name*
 Specifies a route map with which to set or change BGP4 attributes for the network to be advertised.

weightnum
 Specifies a weight to be added to routes to this network. Range is 0 through 65535. The default is 0.

Modes BGP configuration mode
 BGP address-family IPv6 unicast configuration mode
 BGP address-family IPv4 unicast VRF configuration mode
 BGP address-family IPv6 unicast VRF configuration mode

Usage Guidelines Use the **no** form of the command to restore the defaults.

When this command is entered in BGP global configuration mode, it applies only to the IPv4 address family. Use this command in BGP address-family IPv6 unicast configuration mode for BGP4+ configurations.

Examples This example imports the IPv4 network 10.11.12.13/30 into the route map "myroutemap".

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# network 10.11.12.13/30 route-map myroutemap
```

This example imports the IPv6 prefix 2001:db8::/32 into the BGP4+ database and sets a weight of 300.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# address-family ipv6 unicast
device(config-bgp-ipv6u)# network 2001:db8::/32 weight 300
```

History

Release version	Command history
8.0.30	Support was added for the BGP address-family IPv6 unicast VRF configuration mode.

next-hop-enable-default

Configures the device to use the default route as the next hop.

Syntax	next-hop-enable-default
	no next-hop-enable-default
Modes	BGP configuration mode
	BGP address-family IPv6 unicast configuration mode
Usage Guidelines	Use the no form of this command to restore the default.
	When this command is entered in BGP global configuration mode, it applies only to the IPv4 address family. Use this command in BGP address-family IPv6 unicast configuration mode for BGP4+ configurations.
Examples	This BGP4 example configures the device to use the default route as the next hop.
	<pre>device# configure terminal device(config)# router bgp device(config-bgp-router)# next-hop-enable-default</pre>
	This BGP4+ example configures the device to use the default route as the next hop.
	<pre>device# configure terminal device(config)# router bgp device(config-bgp-router)# address-family ipv6 unicast device(config-bgp-ipv6u)# next-hop-enable-default</pre>

next-hop-recursion

Enables BGP recursive next-hop lookups.

Syntax **next-hop-recursion**

no next-hop-recursion

Modes BGP configuration mode
BGP address-family IPv6 unicast configuration mode

Usage Guidelines Use the **no** form of this command to restore the default.

When this command is entered in BGP global configuration mode, it applies only to the IPv4 address family. Use this command in BGP address-family IPv6 unicast configuration mode for BGP4+ configurations.

If the BGP next hop is not the immediate next hop, a recursive route lookup in the IP routing information base (RIB) is needed. With recursion, a second routing lookup is required to resolve the exit path for destination traffic. Use this command to enable recursive next-hop lookups.

Examples This example enables recursive next-hop lookups for BGP4.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# next-hop-recursion
```

This BGP4+ example enables recursive next-hop lookups for BGP4+.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# address-family ipv6 unicast
device(config-bgp-ipv6u)# next-hop-recursion
```

openflow enable

Enables or disables the Openflow hybrid port mode on the port.

Syntax	openflow enable [layer2 layer3 layer23 [hybrid-mode]] no openflow enable [layer2 layer3 layer23 [hybrid-mode]]
Parameters	layer2 Enables Layer 2 matching mode for flows. layer3 Enables Layer 3 matching mode for flows. layer23 hybrid-mode Enables Layer 2 and Layer 3 matching mode for flows with an option for hybrid port mode.
Modes	Interface configuration mode
Usage Guidelines	In interface configuration mode, this command enables Layer 2 or Layer 3 matching mode for flows with an optional enabling of hybrid port mode.

NOTE

OpenFlow must be globally enabled before the Layer2 or Layer 3 matching modes can be specified.

Examples After OpenFlow 1.3 is enabled, the following example configures Layer 2 and Layer 3 matching mode for flows.

```
device# configure terminal
device(config)# openflow enable ofv130
device (config)# interface ethernet 1/1/1
device (config-if-1/1/1)# openflow enable layer 23
```

History

Release	Command History
08.0.20	This command was introduced.

openflow purge-time

Configures the maximum amount of time (in seconds) before stale flows are purged from the OpenFlow flow table after a switchover, failover, or OS upgrade.

Syntax **openflow purge-time seconds**

no openflow purge-time seconds

Command Default The value of the OpenFlow purge timer is the default value for normal circumstances.

Parameters **seconds**

Specifies the maximum amount of time (in seconds), before stale flows are purged. The range is from 1 through 600. The default is 240 seconds.

Modes User EXEC mode

Privileged EXEC mode

Global configuration mode

Usage Guidelines You can configure a larger value for the OpenFlow purge timer, if delay is anticipated in learning the flows from controller after switch-over.

Examples The following example sets the OpenFlow purge time to 500 seconds:

```
device(config)# openflow purge-time 500
```

History

Release version	Command history
08.0.30	This command was introduced.

originator-id

Configures MSDP to use the specified interface IP address as the IP address of the rendezvous point (RP) in a source-active (SA) message.

Syntax **originator-id** *type number*

no originator-id *type number*

Command Default MSDP uses the IP address of the originating RP in the RP address field of the SA message.

Parameters *type*

Specifies the type of interface used by the RP. You can use Ethernet, loopback, and virtual routing interfaces (ve).

number

Specifies the interface number. For example, the Ethernet port number, loopback number, or virtual routing interface number.

Modes MSDP router configuration mode

MSDP router VRF configuration mode

Usage Guidelines The **no** form of this command restores the default

Examples This example configures an interface IP address to be the IP address of the RP.

```
Device(config)# interface loopback 2
Device(config-lbif-2)# ip address 2.2.1.99/32
Device(config)# router msdp
Device(config-msdp-router)# originator-id loopback 2
Device(config-msdp-router)# exit
```

This example configures an interface IP address to be the IP address of the RP on a VRF named blue.

```
Device(config)# interface loopback 2
Device(config-lbif-2)# ip address 2.2.1.99/32
Device(config)# router msdp vrf blue
Device(config-msdp-router-vrf blue)# originator-id loopback 2
Device(config-msdp-router-vrf blue)# exit
```

packet-inerror-detect

Enables the monitoring of a port for inError packets and defines the maximum number of inError packets allowed for the port during the configured sampling interval.

Syntax **packet-inerror-detect** *inError-count*
no packet-inerror-detect *inError-count*

Command Default The Packet InError Detect feature is disabled for the port.

Parameters *inError-count*
 Specifies the maximum number of inError packets that are allowed for a port during the configured sampling interval. The value can range from 10 through 4294967295.

Modes Interface configuration mode

Usage Guidelines The **no** form of this command disable monitoring of inError packets for the port.
 If the number of inError packets received at a port exceeds the default value for two consecutive sampling windows, the port is set to the error-disabled state.

NOTE

To enable monitoring of inError packets for the port only, you must first use the **errdisable packet-inerror-detect** command in global configuration mode to globally enable monitoring for inError packets on the device.

Examples The following example displays the maximum number of allowed inError packets for a port set to the value 10.

```
device(config)# interface ethernet 1/1/1
device(config-if-e1000-1/1/1)# packet-inerror-detect 10
```

History

Release version	Command history
07.3.00g	This command was introduced.

pass-through

Enables pass-through which allows certain protocol packets to pass through ports that have been enabled for flexible authentication.

Syntax	pass-through { lldp fdp cdp } no pass-through { lldp fdp cdp }	
Command Default	Pass-through is not enabled.	
Parameters	lldp	
	fdp	Specifies the Link Layer Discovery Protocol to pass through.
	cdp	Specifies the Foundry Discovery Protocol to pass through.
	cdp	Specifies the Cisco Discovery Protocol to pass through.
Modes	Authentication mode	
Usage Guidelines	The no form of the command disables pass-through.	
	This command specifies the protocols to be passed through even though the client is not authenticated.	
Examples	The example enables LLDP for pass-through.	
	<pre>device (config) #authentication device (config-authen) #pass-through lldp</pre>	
History	Release version	Command history
	08.0.20	This command was introduced.

pdu-rate (EFM-OAM)

Configures the number of Protocol Data Units (PDUs) to be transmitted per second by the Data Terminal Equipment (DTE).

Syntax **pdu-rate** *value*

 no pdu-rate *value*

Command Default The default value is one PDU per second.

Parameters *value*

 Specifies the number of PDUs to be sent per second. The value range can be from 1 through 10 PDUs per second.

Modes EFM-OAM protocol configuration mode

Usage Guidelines If the PDU rate is configured as 10 packets per second, PDUs may not get transmitted in a timely manner according to the configured PDU rate.

 The **no** form of the command restores the default value of one PDU per second.

Examples The following example configures the PDU rate as 6 PDUs per second.

 device(config)# link-oam
 device(config-link-oam)# pdu-rate 6

History	Release version	Command history
	08.0.30	This command was introduced.

phy cable diagnostics tdr

Runs the VCT TDR test on the specified port.

Syntax **phy cable-diagnostics tdr** *stackid/slot/port*

Parameters *stackid/slot/port*
Specifies the interface (port), by device, slot, and port number.

Modes Privileged EXEC mode

Usage Guidelines Use this command to clear TDR test registers before every TDR cable diagnostic test.
Before executing this command, use the **clear cable-diagnostics tdr** command to clear any previous TDR test results.
Display diagnostic test results using the **show cable-diagnostics tdr stackid/slot/port** command.

Examples The following example clears test registers for the interface and then runs the TDR diagnostic test for port 3 on slot 2 of the first device in the stack.

device# clear cable-diagnostics tdr 1/2/3
device# phy cable-diag tdr 1/2/3

History	Release version	Command history
	08.0.20	This command was introduced for ICX 6610, ICX 6430, ICX 6430-C, ICX 6450, and ICX6450-C devices.

port-statistics-reset-timestamp enable

Enables the display of the elapsed timestamp information in the output of the **show statistics** command.

Syntax **port-statistics-reset-timestamp enable**

 no port-statistics-reset-timestamp enable

Command Default The elapsed time after the recent reset of the port statistics counters is not displayed in the **show statistics** command output.

Modes Global configuration mode

Usage Guidelines The elapsed time is calculated as the time between the most recent reset of the port statistics counters and the time when the **show statistics** command is executed.

 The **port-statistics-reset-timestamp enable** command enables the display of the elapsed timestamp information for all the ports in the output of the **show statistics** command.

 The **no** form of the command removes the display of the elapsed time after the most recent reset of the port statistics counters in the **show statistics** command output.

Examples The following example enables the display of the elapsed time between the most recent reset of the port statistics counters and the time when the **show statistics** command is executed.

```
device (config)# port-statistics-reset-timestamp enable
```

History	Release version	Command history
	08.0.30	This command was introduced.

prefix-list

Associates an IPv6 prefix list with a Router Advertisement (RA) guard policy.

Syntax	prefix-list <i>name</i>
	no prefix-list <i>name</i>
Parameters	<i>name</i>
	Specifies the name of the IPv6 prefix list to associate with the RA guard policy.
Modes	RA guard policy configuration mode
Usage Guidelines	<p>This command associates an IPv6 prefix list with an RA guard policy so that only the RAs that have the given prefix are forwarded. You must provide the name of an IPv6 prefix list already configured using the ipv6 prefix-list command. For more information on configuring an IPv6 prefix list using the ipv6 prefix-list command, see the <i>FastIron Ethernet Switch Layer 3 Routing Configuration Guide</i> .</p> <p>Only one prefix list can be associated with an RA guard policy. If the command is configured twice with different prefix lists, the latest configured prefix list is associated with the RA guard policy.</p>
Examples	The following example associates an IPv6 prefix list with an RA guard policy:
	<pre>Brocade(config)# ipv6 prefix-list raguard-prefix1 Brocade(config)# ipv6 raguard policy p1 Brocade(config-ipv6-RAG-policy p1)# prefix-list raguard-prefix1</pre>

pre-shared-key

Configures the pre-shared MACsec key on the interface.

Syntax **pre-shared-key** *key-id* **key-name** *hex-string*

no pre-shared-key *key-id* **key-name** *hex-string*

Command Default No pre-shared MACsec key is configured on the interface.

Parameters *key-id*

Specifies the 32 hexadecimal value used as the Connectivity Association Key (CAK).

key-name *hex-string*

Specifies the name for the CAK key. Use from 2 through 64 hexadecimal characters to define the key name.

Modes dot1x-mka interface mode

Usage Guidelines The **no** form of the command removes the pre-shared key from the interface.

This command is supported only on the Brocade ICX 6610 in FastIron Release 08.0.20. In FastIron Release 08.0.30 and later releases, MACsec commands are also supported on the ICX 7450.

The pre-shared key is required for communications between MACsec peers.

Examples The following example configures MKA group test1 and assigns the MACsec pre-shared key with a name beginning with 96437a93 and with the value shown, to port 2, slot 3 on the first device in the stack.

```
device(config)#dot1x-mka-enable
device(config-dot1x-mka)# mka-cfg-group test1
device(config-dot1x-mka-group-test1)# key-server-priority 5
device(config-dot1x-mka-group-test1)# macsec cipher-suite gcm-aes-128
device(config-dot1x-mka-group-test1)# macsec confidentiality-offset 30
device(config-dot1x-mka-group-test1)# exit
device(config-dot1x-mka)# enable-mka ethernet 1/3/2
device(config-dot1x-mka-1/3/2)# mka-group test1
device(config-dot1x-mka-1/3/2)# pre-shared-key 135bd758b0ee5c11c55ff6ab19fdb199 key-
name 96437a93ccf10d9dfe347846cce52c7d
```

History

Release version	Command history
08.0.20	This command was introduced.

priority

Configures a priority value for the device. This value is used along with other factors to determine controller election if a stack failover or merge occurs.

Syntax	priority <i>num</i> no priority
Command Default	The priority value for the active controller and standby device is 128.
Parameters	<i>num</i> Possible values are 0 to 255. Lower values assign a lower priority to the device, and higher values assign a higher priority to the device.
Modes	Stack unit configuration mode
Usage Guidelines	<p>The no form of the command restores the default priority value to the device (128). You do not have to specify the default value when using the no form.</p> <p>A unit that has a relatively high priority value is more likely to be elected to be the active controller.</p> <p>When you change the priority value assigned to a stack unit, the value takes effect immediately but does not affect the active controller until the next reset.</p> <p>When the active and standby controller have the same priority value, other factors affect controller election, such as up-time and number of members controlled.</p>
Examples	<p>The following example assigns a priority value of 130 to stack unit 1.</p> <pre>device(Config)# stack unit 1 device(Config-unit-1)# priority 130</pre>

History	Release version	Command history
	08.0.01	This command was introduced.

priority-flow-control

Enables priority flow control (PFC) on a priority group.

Syntax **priority-flow-control** *priority-group-number*

no priority-flow-control *priority-group-number*

Command Default PFC is globally disabled

Parameters *priority-group-number*

Specifies a priority group. The range is 0-3.

Modes Global configuration mode

Usage Guidelines The **no** form of this command restores the default flow-control settings.

To enable global PFC, symmetrical-flow-control must be disabled.

You must enable PFC globally before you configure it for priority groups.

Enabling PFC on a priority group enables PFC on all the ports.

PFC and 802.3x flow control are mutually exclusive. Configuring the **priority-flow-control** command disables 802.3x in both transmit and receive directions.

PFC is not supported for ports across stack units on ICX 7750 devices.

PFC is not supported on ICX 7450 devices.

Examples The following example enables PFC for a priority group:

```
Device(config)# priority-flow-control enable
Device(config)# priority-flow-control 2
```

History

Release version	Command history
8.0.10	This command was introduced.
8.0.20	This command was modified. Specifying a priority group no longer enables PFC on all ports.

priority-flow-control enable

Enables priority flow control (PFC) globally or on an individual port.

Syntax **priority-flow-control enable**

 no priority-flow-control enable

Command Default PFC is disabled (globally and on all ports).

Modes Global configuration mode
 Interface configuration mode

Usage Guidelines In global configuration mode, the **no** form of this command restores the default flow-control settings. In interface configuration mode, the **no** form of the command disables PFC on the interface.

To enable global PFC, symmetrical-flow-control must be disabled.

You must enable PFC globally before you configure it for priority groups.

In global configuration mode, configuring the **priority-flow-control enable** command enables PFC globally; in interface configuration mode, configuring it enables PFC on a port. You can configure the **priority-flow-control enable** command in interface configuration mode to enable both PFC transmit and receive, that means PFC is both honored and generated. PFC must be enabled on at least one priority group before you can configure the **priority-flow-control enable** command on an interface.

Priority flow control and 802.3x flow control are mutually exclusive; therefore, configuring the **priority-flow-control enable** command disables 802.3x in both transmit and receive directions.

Examples The following example enables PFC globally.

```
Device(config)# priority-flow-control enable
```

The following example enables PFC on an interface.

```
Device(config-if-e10000-1/1/1)# priority-flow-control enable
```

History	Release version		Command history	
	8.0.10		This command was introduced.	
	8.0.20		This command was modified to add enabling PFC on a port.	

prune-timer

Configures the time a PIM device maintains a prune state for a forwarding entry.

Syntax `prune-timer seconds`

`no prune-timer seconds`

Command Default The prune time is 180 seconds.

Parameters `seconds`

Specifies the interval in seconds. The range is 60 through 3600 seconds. The default is 180 seconds.

Modes PIM router configuration mode

Usage Guidelines The **no** form of this command restores the default prune time, 180 seconds.

The first received multicast interface is forwarded to all other PIM interfaces on the device. If there is no presence of groups on that interface, the leaf node sends a prune message upstream and stores a prune state. This prune state travels up the tree and installs a prune state. A prune state is maintained until the prune timer expires or a graft message is received for the forwarding entry.

Examples This example configures a PIM prune timer to 90 seconds.

```
Device(config)# router pim
Device(config-pim-router)# prune-timer 90
```

prune-wait

Configures the time a PIM device waits before stopping traffic to neighbor devices that do not want the traffic.

Syntax **prune-wait** *seconds*

no prune-wait

Command Default The prune wait time is 3 seconds.

Parameters *seconds*

Specifies the wait time in seconds. The range is 0 through 30 seconds. The default is 3 seconds.

Modes PIM router configuration mode

Usage Guidelines The **no** form of this command restores the default prune wait time of 3 seconds.

A smaller prune wait value reduces flooding of unwanted traffic. A prune wait value of 0 causes the PIM device to stop traffic immediately upon receiving a prune message.

If there are two or more neighbors on the physical port, you should not configure the **prune-wait** command because one neighbor may send a prune message while the other sends a join message at the same time, or within less than 3 seconds.

Examples This example configures the prune wait time to 0 seconds.

```
Device(config)# router pim
Device(config-pim-router)# prune-wait 0
```


qos egress-buffer-profile

Configures an egress buffer profile.

Syntax **qos egress-buffer-profile** *user-profile-name* **queue-share-level** *level* *queue-number*
no qos egress-buffer-profile *user-profile-name* **queue-share-level** *level* *queue-number*

Command Default The egress buffer profile is:

Queue	Share level
0	level4-1/9
1	level3-1/16
2	level3-1/16
3	level3-1/16
4	level3-1/16
5	level3-1/16
6	level3-1/16
7	level3-1/16

Parameters *user-profile-name*
Specifies the name of the egress buffer profile to be configured.

queue-share-level *level*
Specifies the number of buffers that can be used in a sharing pool. Eight levels are supported.

queue-number
Specifies the queue to apply the buffer limit to. There are eight hardware queues per port.

Modes Global configuration mode

Usage Guidelines The **no** form of this command deletes the egress buffer profile.

You can attach an egress buffer profile to a port.

You must configure the **no qos egress-buffer-profile** command to detach a profile from any ports that are using it before you can configure the **no qos egress-buffer-profile** command to delete it.

The higher the sharing level, the better the port absorb micro-burst. However, higher-sharing levels of 7 and 8 may compromise QoS functions and create uneven distribution of traffic during periods of congestion.

The following eight queue-share levels are supported:

Level	Sharing-pool buffers
level1-1/64	1/64 of buffers in the sharing pool
level2-1/32	1/32 of buffers in the sharing pool
level3-1/16	1/16 of buffers in the sharing pool
level4-1/9	1/9 of buffers in the sharing pool
level5-1/5	1/5 of buffers in the sharing pool
level6-1/3	1/3 of buffers in the sharing pool
level7-1/2	1/2 of buffers in the sharing pool
level8-2/3	2/3 of buffers in the sharing pool

Examples The following example creates an egress buffer profile named port-40G.

```
Device(config)# qos egress-buffer-profile port-40G queue-share-level
level1-1/64 1/64 of buffers in the sharing pool
level2-1/32 1/32 of buffers in the sharing pool
level3-1/16 1/16 of buffers in the sharing pool
level4-1/9 1/9 of buffers in the sharing pool
level5-1/5 1/5 of buffers in the sharing pool
level6-1/3 1/3 of buffers in the sharing pool
level7-1/2 1/2 of buffers in the sharing pool
level8-2/3 2/3 buffers in the sharing pool
```

The following example configures queue 0 on the egress buffer profile named port-40G to use 1/5 of sharing pool.

```
Device(config)# qos egress-buffer-profile port-40G port-40G queue-share-level
level5-1/5 0
```

The following example configures queue 1 on the egress buffer profile named port-40G to use 1/64 of the sharing pool.

```
Device(config)# qos egress-buffer-profile port-40G port-40G queue-share-level
level1-1/64 1
```

The following example attaches the egress buffer profile named port-40G to ports 1/2/1 to 1/2/6.

```
Device(config)# interface ethernet 1/2/1 to 1/2/6
Device(config-mif-1/2/1-1/2/6)#egress-buffer-profile port-40G
Device(config-mif-1/2/1-1/2/6)#end
```

The following example shows the error if you try to delete a profile that is attached to a port.

```
Device(config)# no qos egress-buffer-profile port-40G
Error - Egress Profile port-40G is active on Port 1/2/1. It must be deactivated from
port before deleting.
```

The following example detaches the egress buffer profile named port-40G from ports 1/2/1 to 1/2/6 and then delete the profile.

```
Device(config)# interface ethernet 1/2/1 to 1/2/6
Device(config-mif-1/2/1-1/2/6)# no egress-buffer-profile port-40G
Device(config-mif-1/2/1-1/2/6)#exit
Device(config)# no qos egress-buffer-profile port-40G
```

History

Release version	Command history
8.0.10	This command was introduced.

qos ingress-buffer-profile

Configures an ingress buffer profile.

Syntax **qos ingress-buffer-profile** *user-profile-name* **priority-group** *priority-group-number* **xoff** *shared-level*
no qos ingress-buffer-profile *user-profile-name* **priority-group** *priority-group-number* **xoff** *shared-level*

Command Default An ingress buffer profile is not configured.

Parameters *user-profile-name*
 Specifies the name of the ingress buffer profile to be configured.
priority-group *priority-group-number*
 Specifies the priority group (PG) number whose XOFF threshold level has to be configured.
xoff *shared-level*
 Specifies the per-PG buffer threshold to trigger sending of priority flow control (PFC).

Modes Global configuration mode

Usage Guidelines The **no** form of this command deletes the ingress buffer profile.

You can attach an ingress buffer profile to a port.

You must configure the **no qos ingress-buffer-profile** command to detach a profile from any ports that are using it before you can configure the **no qos ingress-buffer-profile** command to delete it.

The higher the sharing level, the better the port absorbs micro-bursts, before reaching the XOFF threshold limit.

If PFC is enabled on PG and per-port with a user-defined ingress buffer profile attached to a port, port max XOFF is 50% of service pool 1. Port max is used as a cap to prevent a port from using too many buffers. Under normal conditions, the PG XOFF limit is reached first.

If a PG is not enabled to send globally, any XOFF value configured has no effect.

The default ingress buffer profiles are as follows:

- For PFC disabled ports, the default PG XOFF limit is level7-1/2
- For PFC enabled ports, the default PG XOFF limit is level2-1/32

The following six PG XOFF limits are supported:

Level	Sharing-pool buffers
level1-1/64	1/64 of buffers in the sharing pool
level2-1/32	1/32 of buffers in the sharing pool
level3-1/16	1/16 of buffers in the sharing pool
level4-1/9	1/9 of buffers in the sharing pool
level5-1/5	1/5 of buffers in the sharing pool

Level	Sharing-pool buffers
level6-1/3	1/3 of buffers in the sharing pool

Examples The following example creates an ingress buffer profile for PG 0 with a PG XOFF limit of 1/3 of buffers in the sharing pool.

```
Device(config)#qos ingress-buffer-profile ing1 priority-group 0 xoff level6-1/3
```

History

Release version	Command history
8.0.20	This command was introduced.

qos priority-to-pg

Configures priority-to-priority-group (PG) mapping for priority flow control (PFC).

Syntax **qos priority-to-pg qosp0** *priority-PG-map* **qosp1** *priority-PG-map* **qosp2** *priority-PG-map* **qosp3** *priority-PG-map* **qosp4** *priority-PG-map* **qosp5** *priority-PG-map* **qosp6** *priority-PG-map* **qosp7** *priority-PG-map*

no qos priority-to-pg

Command Default Priority-to-PG mapping is not configured.

Parameters **qosp0-7**
priority-PG-map Configures the internal priority based on classification in the range 0 through 7.
priority-PG-map Specifies the internal priority-to-PG mapping. The range is 0 through 3.

Modes Global configuration mode

Usage Guidelines The **no** form of this command restores the default priority-to-PG map.

You must configure the **priority-flow-control enable** command to enable PFC globally before you configure priority-to-PG mapping.

NOTE

Default mapping, mapping priorities, and mapping restrictions changed in Brocade FastIron Release 8.0.20. The following restrictions apply:

- Priority 7, and only Priority 7, is always mapped to PG4.
 - PG4 is always lossy.
 - PFC cannot be enabled on PG4.
 - Priorities 0 to 5 can be mapped to PG0, PG1, and PG2. They cannot be mapped to PG3 or PG4.
-

The default value of priority-to-PG maps is:

- QoS internal priority 0 is mapped to PG 0
- QoS internal priority 1 is mapped to PG 0
- QoS internal priority 2 is mapped to PG 1
- QoS internal priority 3 is mapped to PG 1
- QoS internal priority 4 is mapped to PG 1
- QoS internal priority 5 is mapped to PG 2
- QoS internal priority 6 is mapped to PG 2
- QoS internal priority 7 is mapped to PG 4

The default value of priority-to-PG maps in releases prior to Release 8.0.20 is:

- QoS internal priority 0 is mapped to PG 0
- QoS internal priority 1 is mapped to PG 0
- QoS internal priority 2 is mapped to PG 1
- QoS internal priority 3 is mapped to PG 1
- QoS internal priority 4 is mapped to PG 1
- QoS internal priority 5 is mapped to PG 2

- QoS internal priority 6 is mapped to PG 2
- QoS internal priority 7 is mapped to PG 2

In releases prior to Release 8.0.20, you can map QoS internal priority 7 to PG 3. You can also map any other priority to PG 3 if it meets these requirements:

- Lower priorities mapped to lower PGs.
- PGs are configured in ascending order.
- Multiple priorities in a single PG must be consecutive.

Priority-to-PG mapping is not configurable in other modes. Symmetrical and asymmetrical 802.3x flow control modes have their own default priority-to-PG mapping.

You must configure PGs in ascending order, 0 to 3. You can configure a higher-order PG only if all the lower-order PGs have some mapped priorities.

Examples The following example configures a priority-to-PG map.

```
Device(config)# priority-flow-control enable
Device(config)# qos priority-to-pg qosp0 0 qosp1 1 qosp2 1 qosp3 1 qosp4 2 qosp5 2
qosp6 2 qosp7 4
```

The following example restores the default priority-to-PG map.

```
Device(config)# no qos priority-to-pg qosp0 0 qosp1 1 qosp2 1 qosp3 1 qosp4 2 qosp5 2
qosp6 2 qosp7 4
```

History

Release version	Command history
8.0.10	This command was introduced.
8.0.20	This command was modified to change priority 7-to-PG4 mapping and mapping restrictions for priorities 0 through 5.

qos scheduler-profile

Configures a user-defined Quality of Service (QoS) scheduler profile.

Syntax **qos scheduler-profile** *user-profile-name* { **mechanism** *scheduling-mechanism* | **profile** [**qosp0** *wt0* | **qosp1** *wt1* | **qosp2** *wt2* | **qosp3** *wt3* | **qosp4** *wt4* | **qosp5** *wt5* | **qosp6** *wt6* | **qosp7** *wt7*] }

no qos scheduler-profile *user-profile-name*

Command Default A user-defined QoS scheduler profile is not configured.

Parameters *user-profile-name*

Specifies the name of the scheduler profile to be configured.

mechanism *scheduling-mechanism*

Configures the queue assignment with the specified scheduling mechanism.
The following scheduling mechanisms are supported:

mixed-sp-wrr

Specifies mixed strict-priority (SP) and weighted scheduling.

strict

Specifies SP scheduling.

weighted

Specifies weighted scheduling.

profile qosp0-7

Configures the profile based on classification in the range 0 through 7.

wt0-7

Specifies the bandwidth percentage for the corresponding QoS profile. The range is from 0 through 7.

Modes Global configuration mode

Usage Guidelines The **no** form of this command removes the scheduler profile configuration.

You can use the **scheduler-profile** command to attach a user scheduler profile to a port. If you want to remove a scheduler-profile you must ensure that it is not attached to any port.

On ICX 7750 and ICX 7450 devices, changing the global scheduler and port scheduler on running traffic may cause traffic loss.

The default QoS-profile weights for each queue using a weighted QoS mechanism are as follows:

Profile	Priority	Weighted bandwidth
Profile qosp7	Priority7(Highest)	Bandwidth requested 44% calculated 44%
Profile qosp6	Priority6	Bandwidth requested 8% calculated 8%
Profile qosp5	Priority5	Bandwidth requested 8% calculated 8%
Profile qosp4	Priority4	Bandwidth requested 8% calculated 8%
Profile qosp3	Priority3	Bandwidth requested 8% calculated 8%
Profile qosp2	Priority2	Bandwidth requested 8% calculated 8%
Profile qosp1	Priority1	Bandwidth requested 8% calculated 8%
Profile qosp0	Priority0 (Lowest)	Bandwidth requested 8% calculated 8%

Per-queue details	Bandwidth percentage
Class 0	3
Class 1	3
Class 2	3
Class 3	3
Class 4	3
Class 5	3
Class 6	7
Class 7	75

The default QoS-profile weights for each queue using a mixed QoS mechanism are as follows:

Per-queue details	Bandwidth percentage
Class 0	15
Class 1	15
Class 2	15
Class 3	15
Class 4	15
Class 5	25
Class 6	sp
Class 7	sp

The total weight (wt0-wt7) in both weighted and mixed mechanism must be 100 percent.

The minimum value for any weight is 1.

A maximum of eight scheduler profiles are supported.

Examples The following example configures a QoS scheduler profile named user1, with weighted scheduling, and specify the bandwidth percentage for each QoS class:.

```
Device(config)# qos scheduler-profile user1 mechanism weighted
Device(config)# qos scheduler-profile user1 profile qosp0 1 qosp1 1 qosp2 10 qosp3 10
qosp4 10 qosp5 10 qosp6 20 qosp7 38
```

The following example configures a QoS scheduler profile named user2, with SP scheduling.

```
Device(config)# qos scheduler-profile user2 mechanism strict
```


The following example configures a QoS scheduler profile named user3, with mixed SP and weighted scheduling.

```
Device(config)# qos scheduler-profile user3 mechanism mixed-sp-wrr
```

The following example removes a QoS scheduler profile named user3.

```
Device(config)# no qos scheduler-profile user3
```

History		
	Release version	Command history
	08.0.10	This command was introduced.

qos-internal-trunk-queue

Modifies the dynamic buffer-share level of inter-packet-processor (inter-pp) HiGig links egress queues on ICX 7450 devices.

Syntax `qos-internal-trunk-queue level queue`

`no qos-internal-trunk-queue level queue`

Command Default The buffer share level defaults are:

Queue	Share level
0	level4-1/9
1	level3-1/16
2	level3-1/16
3	level3-1/16
4	level3-1/16
5	level3-1/16
6	level3-1/16
7	level3-1/16

Parameters *level*

Specifies the number of buffers that can be used in a sharing pool. ICX 7450 devices support eight levels.

queue

Specifies the queue to apply the buffer limit to. Each port has eight hardware queues.

Modes Global configuration mode

Usage Guidelines The **no** form of this command restores the default queue share level on the specified queue.

NOTE

This command is supported only on ICX 7450 devices or across stack units or for ports across master and slave packet-processor (pp) devices in ICX7450-48 units.

The following eight queue-share levels are supported:

Level	Sharing-pool buffers
level1-1/64	1/64 of buffers in the sharing pool

Level	Sharing-pool buffers
level2-1/32	1/32 of buffers in the sharing pool
level3-1/16	1/16 of buffers in the sharing pool
level4-1/9	1/9 of buffers in the sharing pool
level5-1/5	1/5 of buffers in the sharing pool
level6-1/3	1/3 of buffers in the sharing pool
level7-1/2	1/2 of buffers in the sharing pool
level8-2/3	2/3 of buffers in the sharing pool

Examples The following example configures the buffer share level of inter-packet-processor (inter-pp) HiGig links egress queues.

```
ICX7450-48P Router(config)#qos-internal-trunk-queue
level1-1/64 1/64 of buffers in the sharing pool
level2-1/32 1/32 of buffers in the sharing pool
level3-1/16 1/16 of buffers in the sharing pool
level4-1/9 1/9 of buffers in the sharing pool
level5-1/5 1/5 of buffers in the sharing pool
level6-1/3 1/3 of buffers in the sharing pool
level7-1/2 1/2 of buffers in the sharing pool
level8-2/3 2/3 buffers in the sharing pool
```

History

Release version	Command history
08.0.20	This command was introduced.

radius-client coa host

Configures the key to be used between the Change of Authorization (CoA) client and FastIron device.

Syntax `radius-client coa host { addr | name } [key key-string]`

no radius-client coa host { *addr* | *name* } [**key** *key-string*]

Command Default No key is configured between the CoA client and device.

Parameters *addr*

Address of the CoA host.

name

Name of the CoA host.

key *key-string*

The key required to be used between the CoA client and FastIron device.

Modes Global configuration mode

Usage Guidelines	RADIUS Change of Authorization (CoA) messages from clients configured through this command will be processed. CoA messages from unconfigured clients will be discarded.
-------------------------	---

Examples The following example displays the configuration between CoA host and the device.

```
device(config)# radius-client coa host 10.21.240.46 key 0 Foundry1#
```

History	Release version	Command history
	08.0.20	This command was introduced.

radius-client coa port

Changes the default CoA (Change of Authorization) port number.

Syntax **radius-client coa port** *udp-port-number*
no radius-client coa port *udp-port-number*

Command Default The CoA port number is 3799.

Parameters *udp-port-number*
The number of the UDP port.

Modes Global configuration mode

Usage Guidelines The **no** form of the command restores the default port number (3799).

Examples The following example changes the CoA port number to 3000.
device(config)# radius-client coa port 3000

History	Release version	Command history
	08.0.20	This command was introduced.

raguard

Configures the current interface as a trusted, untrusted, or host Router Advertisement (RA) guard port.

Syntax	raguard { trust untrust host }
	no raguard { trust untrust host }
Parameters	<p>trust Configures an interface as a trusted RA guard port.</p> <p>untrust Configures an interface as an untrusted RA guard port.</p> <p>host Configures an interface as a host RA guard port.</p>
Modes	Interface configuration mode
Usage Guidelines	<p>The no form of this command removes the current trusted or untrusted configuration.</p> <p>A trusted RA guard port forwards all the receive RA packets without inspecting. An untrusted port inspects the received RAs against the RA guard policy's whitelist, prefix list and preference maximum settings before forwarding the RA packets. If an RA guard policy is not configured on an untrusted or host port, all the RA packets are forwarded.</p>
Examples	<p>The following example configures an interface as a trusted RA guard port:</p> <pre>Brocade(config)# interface ethernet1/1/1 Brocade(config-int-e1000-1/1/1)# raguard trust</pre> <p>The following example configures an interface as an untrusted RA guard port:</p> <pre>Brocade(config)# interface ethernet1/2/1 Brocade(config-int-e1000-1/2/1)# raguard untrust</pre> <p>The following example configures an interface as a host RA guard port:</p> <pre>Brocade(config)# interface ethernet3/2/1 Brocade(config-int-e1000-3/2/1)# raguard host</pre>

redistribute (BGP)

Configures the device to redistribute RIP routes, directly connected routes, or static routes into BGP4 and BGP4+.

Syntax	redistribute { connected rip static } [metric <i>num</i>] [route-map <i>string</i>] no redistribute { connected rip static } [metric <i>num</i>] [route-map <i>string</i>]
Command Default	The device does not redistribute routing information between BGP4 or BGP4+ and the IP interior gateway protocol OSPF.
Parameters	<p>connected Redistributes connected routes.</p> <p>rip Redistributes Routing Information Protocol (RIP) routes.</p> <p>static Redistributes static routes.</p> <p>metric Metric for redistributed routes.</p> <p>num Specifies a metric number. The range is from 0 through 4294967297. No value is assigned by default.</p> <p>route-map Specifies that a route map be consulted before a route is added to the routing table.</p> <p><i>string</i> Specifies a route map to be consulted before a route is added to the routing table.</p>
Modes	BGP configuration mode BGP address-family IPv6 unicast configuration mode BGP address-family IPv4 unicast VRF configuration mode BGP address-family IPv6 unicast VRF configuration mode
Usage Guidelines	<p>Use the no form of the command to restore the defaults. When this command is entered in BGP global configuration mode, it applies only to the IPv4 address family. Use this command in BGP address-family IPv6 unicast configuration mode for BGP4+ configurations.</p> <p>Use this command to configure the device to redistribute RIP, directly connected routes, or static routes into BGP4 or BGP4+. The routes can be filtered by means of an associated route map before they are distributed.</p>

NOTE

The **default-metric** command does not apply to the redistribution of directly connected routes into BGP4 or BGP4+. Use a route map to change the default metric for directly connected routes.

Examples This example redistributes static routes into BGP4 and specifies a metric of 200.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# redistribute static metric 200
```

This example redistributes static routes into BGP4+ and specifies that route-map "rm5" be consulted.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# address-family ipv6 unicast
device(config-bgp-ipv6u)# redistribute route-map rm5
```

This example redistributes directly connected routes into BGP4 in VRF instance "red".

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# address-family ipv4 unicast vrf red
device(config-bgp-ipv4u-vrf)# redistribute connected
```

History	Release version	Command history
	8.0.30	Support was added for the BGP address-family IPv6 unicast VRF configuration mode.

redistribute ospf

Configures the device to redistribute OSPF routes into BGP.

Syntax **redistribute ospf** [**match** [**external1** | **external2** | **internal**]] [**metric** *num*] [**route-map** *string*]

no redistribute ospf [**match** [**external1** | **external2** | **internal**]] [**metric** *num*] [**route-map** *string*]

Command Default Internal OSPF routes are distributed. No value is assigned for **metric**.

Parameters *match*

Selects the type of route to be redistributed.

external1

Redistributes OSPF external type 1 routes.

external2

Redistributes OSPF external type 2 routes.

internal

Redistributes OSPF internal routes.

num

A value that assigns the metric. The range is from 0 through 4294967297.

string

Specifies a route map to be consulted before an OSPF route is added to the BGP routing table.

Modes BGP configuration mode

BGP address-family IPv6 unicast configuration mode

BGP address-family IPv4 unicast VRF configuration mode

BGP address-family IPv6 unicast VRF configuration mode

Usage Guidelines Use the **no** form of the command to restore the defaults.

When this command is entered in BGP global configuration mode, it applies only to the IPv4 address family. Use this command in BGP address-family IPv6 unicast configuration mode for BGP4+ configurations.

Use the **redistribute ospf** command to redistribute all OSPF routes (OSPF external type 1, external type 2, or internal routes).

Examples This example redistributes IPv4 OSPF external type 1 routes with a metric of 200.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# redistribute ospf match external1 metric 200
```

This example redistributes OSPF IPv6 external type 2 routes in a nondefault VRF instance.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# address-family ipv4 unicast vrf red
device(config-bgp-ipv4u-vrf)# redistribute ospf match external2
```

History

Release version	Command history
8.0.30	Support was added for the BGP address-family IPv6 unicast VRF configuration mode.

register-probe-time

Configures the time the PIM router waits for a register-stop from a rendezvous point (RP) before it generates another NULL register to the PIM RP

Syntax	register-probe-time <i>seconds</i>
	no register-probe-time <i>seconds</i>
Command Default	The wait time is 10 seconds.
Parameters	<i>seconds</i>
	Specifies the time, in seconds, between queries. The range is 10 through 50 seconds. The default is 10 seconds.
Modes	PIM router configuration mode
Usage Guidelines	The no form of this command restores the wait time to 10 seconds.
	The register-probe time configuration applies only to the first-hop PIM router.

NOTE

When a PIM first-hop router has successfully registered with a PIM RP, the PIM first-hop router will not default back to the data registration. All subsequent registers will be in the form of the NULL registration.

Examples This example configures the register-probe time to 20 seconds.

```
Device(config)#router pim
Device(config-pim-router)#register-probe-time 20
```

register-suppress-time

Configures the interval at which the PIM router triggers the NULL register message.

Syntax **register-suppress-time** *seconds*
 no register-suppress-time *seconds*

Command Default The interval at which PIM router triggers the NULL register message is 60 seconds.

Parameters *seconds*
 Specifies the interval, in seconds, between queries. The range is 60 through 120 seconds. The default is 60 seconds.

Modes PIM router configuration mode

Usage Guidelines The **no** form of this command restores the register-suppress interval to 60 seconds.
 The register-suppress interval configuration applies only to the first-hop PIM router.

Examples The following example configures the interval at which PIM router triggers the NULL register message to 90 seconds.

```
Device(config)#router pim
Device(config-pim-router)#register-suppress-time 90
```

remote-loopback

Starts or stops the remote loopback procedure on a remote device.

Syntax	remote-loopback ethernet <i>stackid/slot/port</i> { start stop }
Command Default	Remote loopback is not initiated on a remote device.
Parameters	ethernet <i>stackid/slot/port</i> Specifies the Ethernet interface on which loopback is to be enabled. start Starts the remote loopback procedure on a remote device. stop Stops the remote loopback procedure on a remote device.
Modes	EFM-OAM protocol configuration mode
Usage Guidelines	The remote-loopback ethernet <i>stackid/slot/port</i> { start stop } command is valid only on the Data Terminal Equipment (DTE) operating in the active mode. When the remote loopback mode is enabled, all the non-OAMPDUs are looped back at the remote end. A port ceases to be in the remote loopback mode if any event triggers a change in the port status (up or down). If EEE is enabled globally, port ceases to be in the remote loopback mode. Ethernet loopback and EFM-OAM remote loopback cannot be configured on the same interface.

NOTE

Brocade recommends to ensure that any higher layer protocol running over the local and remote loopback ports does not block the interfaces in the VLAN on which loopback traffic testing is being performed.

Examples The following example initiates the remote loopback procedure on a remote DTE.

```
device(config)# link-oam
device(config-link-oam)# remote-loopback ethernet 3/1/1 start
```

The following example stops the remote loopback procedure on a remote DTE.

```
device(config)# link-oam
device(config-link-oam)# remote-loopback ethernet 3/1/1 stop
```

History

Release version	Command history
08.0.30	This command was introduced.

restricted-vlan

Configures the restricted VLAN at the global level.

Syntax **restricted-vlan** *vlan-id*
no restricted-vlan *vlan-id*

Command Default The restricted VLAN is not specified.

Parameters *vlan-id*
Specifies the identification number of the restricted VLAN.

Modes Authentication mode

Usage Guidelines The **no** form of the command disables the restricted VLAN.
Use this command to move the port to a restricted VLAN when multi-device port authentication fails.

Examples The following example creates a restricted VLAN with VLAN 1.

```
device(config)# authentication
device(config-authen)# restricted-vlan 1
```

History	Release version	Command history
	08.0.20	This command was introduced.

reverse-path-check

Enables strict mode unicast Reverse Path Forwarding for all layer 3 routes.

Syntax	reverse-path-check
	no reverse-path-check
Command Default	Reverse path check is not enabled on the device.
Modes	Global configuration mode
Usage Guidelines	On ICX 6610 devices, this command configures strict mode so that IPv4 prefixes learned over the VE interfaces that do not have tunnel termination specified as next hop are enabled for uRPF check. On ICX 7750 devices, this command enables the uRPF command line interface and hardware settings.
	The no form of the command disables the reverse path check functionality.
You must reload the device for the reverse path check setting changes to take effect. Enabling reverse path check on ICX 7750 devices reduces the following system-max values by 50 percent:	
<ul style="list-style-type: none">• ip-route• ip6-route• ip-route-default-vrf• ip6-route-default-vrf• ip-route-vrf• ip6-route-vrf	

NOTE

Disabling reverse path check doubles the system-max values on ICX 7750 devices.

You should configure these values after reloading. You should adjust or remove the max-route configuration in VRFs before reload.

Examples	The following example enables unicast Reverse Path Forwarding globally.	
	device(config)# reverse-path-check	
History	Release version	Command history
	08.0.30	This command was introduced.

route-precedence

Configures a table that defines the order (precedence) in which multicast routes are selected from the multicast routing table (mRTM) and unicast routing (uRTM) table.

Syntax `route-precedence { [mc-non-default | none] [mc-default | none] [uc-non-default | none] [uc-default | none] }`

`no route-precedence`

Command Default The default route precedence used to select routes is:

1. A non-default multicast route from the mRTM (**mc-non-default**).
2. A default multicast route from the mRTM (**mc-default**).
3. A non-default unicast route from the uRTM (**uc-non-default**).
4. A default unicast route from the uRTM (**uc-non-default**).

Parameters **mc-non-default**

Specifies the precedence for the non-default multicast route table (mRTM).

none

Specifies that this type of route is to be ignored. You can specify this option for any of the multicast or unicast route types.

mc-default

Specifies the precedence for the multicast routing table (mRTM).

uc-non-default

Specifies the precedence for the non-default unicast route table (uRTM).

uc-default

Specifies the precedence for the default unicast route table (uRTM).

Modes PIM configuration mode

Usage Guidelines The order in which you place the keywords determines the route precedence.

The **no** form of this command restores the default route precedence settings.

You must configure four parameters indicating the four different route types. If you want to specify that a particular route type is not used, configure the **none** keyword to fill the precedence table.

Examples The following example configures a route precedence in which a non-default multicast route has the highest precedence, and a default unicast route has the lowest precedence. The order used to select routes is:

1. A non-default multicast route from the mRTM.
2. A non-default unicast route from the uRTM.
3. A default multicast route from the mRTM.
4. A default unicast route from the uRTM

```
Device(config)# router pim
Device(config-pim-router)# route-precedence mc-non-default uc-non-default mc-default
uc-default
```

The following example configures a route precedence in which the unicast default route is ignored. The order used to select routes is:

- 1. A non-default multicast route from the mRTM.
- 2. A default multicast route from the mRTM.
- 3. A non-default unicast route from the uRTM.

```
Device(config)# router pim
Device(config-pim-router)# route-precedence mc-non-default mc-default uc-non-default
none
```

History	Release version	Command history
	8.0.10a	This command was introduced.

route-precedence admin-distance

Configures route precedence so that multicast routes are selected from the best route in the multicast routing table (mRTM) and unicast routing (uRTM) table.

Syntax **route-precedence admin-distance**

no route-precedence admin-distance

Command Default Multicast routes are not selected from the best route in the mRTM and uRTM. Routes are selected based on:

- The route precedence configured using the **route-precedence** command.
- The system route precedence default (if route precedence has not been configured using the **route-precedence** command).

the default route precedence settings.

Modes PIM configuration mode

Usage Guidelines The **no** form of this command restores the previous route precedence settings.
If the mRTM and the uRTM have routes of equal cost, the route from the mRTM is preferred.

Examples The following example configures route precedence so that the best multicast route from the mRTM and uRTM tables is selected.

```
Device(config)#router pim
Device(config-pim-router)#route-precedence admin-distance
```

History

Release version	Command history
8.0.10a	This command was introduced.

router bgp

Enables BGP routing.

Syntax **router bgp**

Modes Global configuration mode

Usage Guidelines Use the **no** form of this command to disable BGP routing.

Examples This example enables BGP routing.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)#
```

router msdp

Enables multicast source discovery protocol (MSDP) on a router.

Syntax **router msdp** [**vrf** *vrf-name*]

Command Default MSDP is not enabled.

Parameters **vrf** *vrf-name*
Specifies a virtual routing and forwarding (VRF) instance.

Modes Global configuration mode

Usage Guidelines When you configure the **no router msdp vrf vrf-name** command, the MSDP configuration is removed only from the specified VRF.

The PIM Sparse Rendezvous Point (RP) is also an MSDP peer.

Devices that run MSDP usually also run BGP. The source address used by the MSDP device is normally configured to be the same source address used by BGP.

All MSDP parameters available for the default router instance are configurable for a VRF-based MSDP instance.

Examples The following example enables MSDP.

```
Device(config)# router msdp
```

The following example enables MSDP on a VRF named blue.

```
Device(config)# router msdp vrf blue
```

The following example removes the MSDP configuration only from the VRF named blue.

```
Device(config-msdp-router-vrf-blue)# no router msdp vrf blue
```

router pim

Configures basic global protocol-independent multicast (PIM) Sparse parameters on a device within the PIM Sparse domain and enters PIM-router configuration mode.

Syntax	router pim [vrf vrf-name] no router pim [vrf vrf-name]
Command Default	PIM Sparse is not configured.
Parameters	vrf vrf-name Specifies a virtual routing and forwarding (VRF) instance.
Modes	Global configuration mode Interface configuration mode
Usage Guidelines	<p>The no form of this command disables PIM and removes all configuration for PIM multicast on the device (router pim level) only. Configuring the no router pim vrf vrf-name command removes all configuration for PIM multicast on the specified VRF.</p> <p>You do not need to globally enable IP multicast routing when configuring PIM Sparse.</p> <p>After you enable IP multicast routing and PIM Sparse at the global level, you must enable it on the individual interfaces connected to the PIM Sparse network.</p> <p>If you configure PIM Sparse on an interface that is on the border of the PIM Sparse domain, you also must also configure the ip pim border command on the interface.</p> <p>You must configure the bsr-candidate ethernet command to identify an interface on at least one device as a candidate PIM Sparse Bootstrap router (BSR) and candidate PIM Sparse Rendezvous Point (RP).</p> <p>You can configure the rp-address command to explicitly identify an RP, including an ACL-based RP, by its IP address instead of having it identified by the RP election process.</p> <p>Entering the router pim vrf command to enable PIM does not require a software reload.</p> <p>All PIM parameters available for the default router instance are configurable for a VRF-based PIM instance.</p>
Examples	<p>This example configures basic global PIM Sparse parameters.</p> <pre>Device(config)# router pim</pre> <p>This example configures PIM Sparse on a VRF named blue.</p> <pre>Device(config)# router pim blue</pre>

rpf-mode

Enables strict or loose unicast Reverse Path Forwarding (uRPF) modes on ICX 7750 devices.

Syntax **rpf-mode** [**strict** | **loose**] [**urpf-exclude-default**]

no rpf-mode [**strict** | **loose**] [**urpf-exclude-default**]

Command Default uRPF mode is not enabled.

Parameters **strict**

Specifies uRPF strict mode.

loose

Specifies uRPF loose mode. This mode allows all packets to pass the uRPF check.

urpf-exclude-default

Excludes the default route for uRPF source IP lookup.

Modes Interface configuration mode

Usage Guidelines The **no** form of the command disables uRPF mode.

You must enable uRPF at the global level before enabling the mode (strict or loose). This command is applicable only to the Layer 3 physical interface and Layer 3 VE interfaces.

The **loose** option allows all packets to pass through. Choose the **loose** mode along with the **urpf-exclude-default** option to subject the packets to uRPF check.

Examples The following example sets the Reverse Path Forwarding mode to strict mode.

```
device(config)# interface ethernet 1/1/3
device(config-if-e1/1/3)# rpf-mode strict
```

History

Release version

Command history

08.0.30

This command was introduced.

rp-address

Configures a device interface as a rendezvous point (RP).

Syntax **rp-address** { *ip-address* | *ipv6-address* } *acl_name_or_id*

no rp-address { *ip-address* | *ipv6-address* }

Command Default The RP is selected by the PIM Sparse protocol's RP election process.

Parameters *ip-address*

Specifies the IP address of the RP.

ipv6-address

Specifies the IPv6 address of the RP.

acl_name_or_id

Specifies the name or ID of the ACL that specifies which multicast groups use the RP.

Modes Router configuration mode

VRF configuration mode

Usage Guidelines The **no** form of this command restores the default and the RP is selected by the RP election process.

Devices in the PIM Sparse domain use the specified RP and ignore group-to-RP mappings received from the bootstrap router (BSR).

The RP is the meeting point for PIM Sparse sources and receivers. A PIM Sparse domain can have multiple RPs, but each PIM Sparse multicast group address can have only one active RP. PIM Sparse routers learn the addresses of RPs and the groups for which they are responsible from messages that the BSR sends to each of the PIM Sparse routers.

NOTE

Specify the same IP or IPv6 address as the RP on all PIM Sparse devices within the PIM Sparse domain. Make sure the device is on the backbone or is otherwise well connected to the rest of the network.

Examples This example configures the device interface at IP address 207.95.7.1 as the RP for the PIM Sparse domain.

```
Device(config)# router pim
Device(config-pim-router)# rp-address 207.95.7.1
```

This example configures an ACL named *acl1* to specify which multicast groups use the RP.

```
Device(config)# router pim
Device(config-pim-router)# rp-address 130.1.1.1 acl1
```

This example configures an RP for a VRF named *blue*.

```
Device(config)# ipv6 router pim vrf blue
Device(config-ipv6-pim-router-vrf-blue)# rp-address 31::207
```

rp-adv-interval

Configures the interval at which the candidate rendezvous point (RP) configured on the device sends candidate-RP advertisement messages to the bootstrap router (BSR).

Syntax `rp-adv-interval seconds`

`no rp-adv-interval seconds`

Command Default The device sends candidate-RP advertisement messages every 60 seconds.

Parameters `seconds`

Specifies the interval, in seconds, between advertisement messages. The range is 10 through 65535 seconds. The default is 60 seconds.

Modes PIM router configuration mode

PIM router VRF configuration mode

Usage Guidelines The `no` form of this command restores the candidate-RP advertisement-message interval to 60 seconds.

Examples The following example configures the candidate-RP advertisement-message interval to 90 seconds.

```
Device(config)#router pim
Device(config-pim-router)#rp-adv-interval 90
```

The following example configures, on a VRF named blue, the candidate-RP advertisement-message interval to 90 seconds.

```
Device(config)#ipv6 router pim vrf blue
Device(config-ipv6-pim-router-vrf-blue)#rp-adv-interval 90
```

rp-candidate

Configures a device as a candidate rendezvous point (RP) for all multicast groups with the prefix 224.0.0.0/4, by default, and explicitly adds or deletes groups with other prefixes.

Syntax **rp-candidate** { **ethernet** *stackid / slot / portnum* | **loopback** *num* | **ve** *num* | **tunnel** *num* }

rp-candidate {**add** | **delete** } *group-addr mask-bits*

no rp-candidate { **ethernet** *stackid / slot / portnum* | **loopback** *num* | **ve** *num* | **tunnel** *num* }

no rp-candidate {**add** | **delete** } *group-addr mask-bits*

Command Default The PIM router is not available for selection as an RP.

Parameters **ethernet** *stackid/slot/portnum*

Specifies a physical interface for the candidate RP. On standalone devices specify the interface ID in the format slot/port-id; on stacked devices you must also specify the stack ID, in the format stack-id/slot/port-id.

loopback *num*

Specifies a loopback interface for the candidate RP.

ve *num*

Specifies a virtual interface for the candidate RP.

tunnel *num*

Specifies a GRE tunnel interface for the candidate RP.

add

Specifies adding a group address or range of group addresses to the default group configured by the those the device is the candidate RP for by default, that is, groups with the prefix 224.0.0.0/4.

delete

Specifies deleting a group address or range of group addresses, that were added using the **add** keyword.

group-addr mask-bits

Specifies the group address and the number of significant bits in the subnet mask.

Modes Router PIM configuration mode

Usage Guidelines The **no rp-candidate** command makes the PIM router cease to act as a candidate RP.

The **no rp-candidate add** command deletes a group address or range of group addresses that were added using the **add** keyword.

Configuring the **rp-candidate** command on an Ethernet, loopback, virtual, or tunnel interface, configures the device as a candidate RP for all multicast groups with the prefix 224.0.0.0/4, by default. You can configure the **rp-candidate add** command to add to those a group address or range of group addresses. You can configure the **rp-candidate delete** command to delete a group address or range of group addresses that were added to the default addresses.

NOTE

You cannot delete the default group prefix.

The RP is the meeting point for PIM Sparse sources and receivers. A PIM Sparse domain can have multiple RPs, but each PIM Sparse multicast group address can have only one active RP. PIM Sparse

routers learn the addresses of RPs and the groups for which they are responsible from messages that the bootstrap router (BSR) sends to each of the PIM Sparse routers.

Although you can configure the device as only a candidate BSR or an RP, it is recommended that you configure the same interface on the same device as both a BSR and an RP.

NOTE

Specify the same IPv6 address as the RP on all IPv6 PIM Sparse routers within the IPv6 PIM Sparse domain. Make sure the device is on the backbone or is otherwise well connected to the rest of the network. You can configure the **rp-address** command to specify the RP address.

Examples This example configures a physical device as a candidate RP.

```
device(config)# router pim
device(config-pim-router)# rp-candidate ethernet 1/2/2
```

This example uses a loopback interface to configure a device as a candidate RP.

```
device(config)# router pim
device(config-pim-router)# rp-candidate loopback 1
```

This example uses a virtual interface to configure a device as a candidate RP.

```
device(config)# router pim
device(config-pim-router)# rp-candidate ve 120
```

This example configures an address group to the devices for which it is a candidate RP.

```
device(config)# router pim
device(config-pim-router)# rp-candidate add 224.126.0.0 16
```

This example deletes an address group from the devices for which it is a candidate RP.

```
device(config)# router pim
device(config-pim-router)# rp-candidate delete 224.126.22.0 24
```

History

Release version	Command history
8.0.20	This command was modified to add the tunnel keyword.

rp-embedded

Configures embedded-rendezvous point (RP) support on PIM devices.

Syntax **rp-embedded**

no rp-embedded

Command Default Embedded RP support is enabled.

Modes PIM router configuration mode
PIM router VRF configuration mode

Usage Guidelines The **no** form of this command disables embedded RP support.

Examples This example disables embedded RP support.

```
Device(config)# ipv6 router pim
Device(config-ipv6-pim-router)#no rp-embedded
```

This example disables embedded RP support on a VRF named blue.

```
Device(config)#ipv6 router pim vrf blue
Device(config-ipv6-pim-router-vrf-blue)#no rp-embedded
```

scheduler-profile

Attaches a scheduler profile to one or more ports.

Syntax **scheduler-profile** *profile-name*
no scheduler-profile *profile-name*

Command Default A scheduler profile is not attached to a port.

Parameters *profile-name*
Specifies the name of the scheduler profile to be attached to the port.

Modes Interface mode
Multiple-interface mode

Usage Guidelines The **no** form of this command removes the scheduler profile from the port or ports.
You must configure a user scheduler profile before you can attach it to a port.
Only one scheduler profile at a time can be attached to any port. You can attach a scheduler profile to more than one port.

Examples The following example attaches a scheduler profile named user1 to a port.
Device(config-if-e10000-1/1/1)# scheduler-profile user1
The following example attaches a scheduler profile named user2 to multiple ports.
Device(config-mif-1/1/2-1/1/16)# scheduler-profile user2
The following example removes a scheduler profile named user2 from multiple ports.
Device(config-mif-1/1/2-1/1/16)# no scheduler-profile user2

History	Release version	Command history
	8.0.10	This command was introduced.

set ip next-hop

Configures the next-hop IP address for the traffic that matches a match statement in the route map.

Syntax	set ip next-hop { <i>peer-address</i> <i>ip-address</i> [preserve-vlan no-ttl-decrement] }
	no set ip next-hop { <i>peer-address</i> <i>ip-address</i> [preserve-vlan no-ttl-decrement] }
Command Default	The next-hop IP address is not configured by default.
Parameters	<i>peer-address</i> Specifies the BGP peer IP address. <i>ip-address</i> Specifies the IP address of the next hop. preserve-vlan Preserves the VLAN and Layer 2 information of the matching packets. no-ttl-decrement Disables the TTL value decrement and ensures that the packets are forwarded to the neighbor router without decrementing Time-to-Live (TTL) for the matched traffic.
Modes	Route map configuration mode
Usage Guidelines	Policy-based Routing (PBR) does not support <i>peer-address</i> and preserve-vlan options while configuring the next-hop IP address using the set ip next-hop command. The no-ttl-decrement option is supported only on the Brocade ICX 7750 and Brocade ICX 7450 devices. The no form of the command removes the next-hop IP address configured for the traffic.
Examples	The following example configures a route map without decrementing the Time-to-Live (TTL) value.

```
device(config)#route-map test-route permit 99
device(config-routemap test-route)#match ip address 100
device(config-routemap test-route)#set ip next-hop 192.168.3.1 no-ttl-decrement
device(config-routemap test-route)#exit
```

History	Release version	Command history
	08.0.10d	The no-ttl-decrement option was introduced.
	08.0.30	The support for the no-ttl-decrement option was added in 08.0.30 and later releases.

sflow sample-mode

Enables sample mode so that dropped packets are included in sFlow sampling.

Syntax **sflow sample-mode all**

no sflow sample-mode all

Command Default Sample mode is not enabled. Dropped packets are not included in sFlow sampling.

Parameters **all**

Specifies that all packets (non-dropped and dropped) are included in sFlow sampling.

Modes Global configuration mode

Usage Guidelines The **sflow sample-mode** command is not supported on ICX 7750, ICX 7450, ICX 7250, ICX 6430, ICX 6650, and FSX 800/1600 devices.

The **no** form of the command restores the default behavior and only the non-dropped packets are included in sFlow sampling.

Examples The following example configures the sFlow sample mode to include all packets.

```
device(config)# sflow sample-mode all
```

History

Release version	Command history
08.0.30	This command was introduced.

sflow source

Configures the sFlow source interface (IPv4 or IPv6) from which the IP source address is selected for the sFlow datagram.

Syntax	sflow source [ipv6] { ethernet <i>stackid/slot/port</i> ve <i>ve-number</i> loopback <i>number</i> } no sflow source [ipv6] { ethernet <i>stackid/slot/port</i> ve <i>ve-number</i> loopback <i>number</i> }
Command Default	The sFlow source is not configured. The IP address of the outgoing interface is used in the sFlow datagram.
Parameters	ipv6 Configures the IPv6 interface as the sFlow source. If ipv6 is not specified, the IPv4 interface is automatically configured as the sFlow source. ethernet <i>stackid/slot/port</i> Configures an Ethernet interface as the sFlow source interface. ve <i>ve-number</i> Configures a virtual interface (VE) as the sFlow source interface. loopback <i>number</i> Configures a loopback interface as the sFlow source interface.
Modes	Global configuration mode
Usage Guidelines	<p>At any time, only one source of the Ethernet, VE, or loopback interface can be specified as the source interface.</p> <p>The first IP address in the interface IP address list is considered the source IP address. Upon configuring another source for an IPv4 or IPv6 address, any previously configured source for the IPv4 or IPv6 address will be deleted. You can configure IPv4 and IPv6 source interfaces independently.</p> <p>If the sFlow destination is IPv6, and the sFlow source is configured for an IPv6 address, then an IPv6 address will be selected from the configured interface. If the sFlow destination is IPv4, and the sFlow source is configured for an IPv4 address, then an IPv4 address will be selected from the configured interface.</p> <p>The no form of the command removes the sFlow source configuration from the interface and restores the default behavior of using IP address of the outgoing interface as the source IP address of the sFlow datagram.</p>
Examples	<p>The following example configures an Ethernet interface to be used as the sFlow source IPv6 interface.</p> <pre>device(config)# sflow source ipv6 ethernet 1/1/2</pre> <p>The following example configures an Ethernet interface to be used as the sFlow source IPv4 interface.</p> <pre>device(config)# sflow source ethernet 1/1/3</pre>

History	Release version	Command history
	08.0.30	This command was introduced.

system-max max-ecmp

Configures the maximum limit of ECMP paths at the system level.

Syntax **system-max max-ecmp** [*num*]
no system-max max-ecmp [*num*]

Command Default The default value is 8.

Parameters *num*
Specifies the maximum number of ECMP paths and can be from 8 through 32.

Modes Global configuration mode

Usage Guidelines The **system-max max-ecmp** command is supported only on the Brocade ICX 7750.

If the maximum number of ECMP paths is not configured at the system level, by default, you can configure the maximum number of IP load sharing paths to a value from 2 through 8.

The configuration of the maximum number of IP load sharing paths to a value more than 8 is determined by the maximum number of ECMP paths configured at the system level using the **system-max max-ecmp** command.

You cannot configure the maximum number of IP load sharing paths higher than the value defined at the system level.

You cannot configure the maximum number of ECMP paths at the system level to a value less than the configured IP load sharing value.

You must save the configuration and reload the device for the maximum ECMP value change to take effect.

The **no** form of the command removes the maximum number of ECMP paths defined at the system level.

Examples The following example defines the maximum number of ECMP paths that can be configured in the system as 20.

```
device(config)# system-max max-ecmp 20
device(config)# write memory
device(config)# exit
device# reload
```

History	Release version	Command history
	08.0.30	This command was introduced.

system-max max-ecmp

Show Commands

show cable-diagnostics tdr

Displays the results of Virtual Cable Test (VCT) TDR cable diagnostic testing.

Syntax `show cable-diagnostics tdr stackid/slot/ port`

Parameters `stackid/slot/ port`
Identifies the specific interface (port), by device, slot, and port number in the format shown.

Modes User EXEC mode
Privileged EXEC mode

Usage Guidelines Most Brocade devices support VCT technology. VCT technology enables the diagnosis of a conductor (wire or cable) by sending a pulsed signal into the conductor, then examining the reflection of that pulse. This method of cable analysis is referred to as Time Domain Reflectometry (TDR). By examining the reflection, the Brocade device can detect and report cable statistics such as local and remote link pair, cable length, and link status.

This command is supported only on the Brocade ICX 6610, ICX 6430, ICX 6430-C, ICX 6450, and ICX6450-C.

Examples The following example displays TDR test results for port 1, slot 2 on device 3 in the stack. The results indicate that the port is down or the cable is not connected.

```
device>show cable-diagnostics tdr 3/2/1
```

Port	Speed	Local pair	Pair Length	Remote pair	Pair status
01	UNKWN	Pair A	>=3 M		Open
		Pair B	>=3 M		Open
		Pair C	>=3 M		Open
		Pair D	>=3 M		Open

The following example displays the TDR test results for the same port show details for an active port.

```
device>show cable-diagnostics tdr 3/2/1
```

Port	Speed	Local pair	Pair Length	Remote pair	Pair status
01	1000M	Pair A	50M	Pair B	Terminated
		Pair B	50M	Pair A	Terminated
		Pair C	50M	Pair D	Terminated
		Pair D	50M	Pair C	Terminated

History	Release version	Command history
	08.0.20	This command was introduced.

show cpu

Displays the CPU histogram for the device, and optionally, the CPU utilization for each task running on the device.

Syntax **show cpu [tasks]**

Parameters **tasks**

Displays the CPU utilization for each task running on the device.

Modes Global configuration mode

User EXEC

Examples The following example displays the CPU histogram for the device.

```
device# show cpu
1 percent busy, from 4267 sec ago
1  sec avg: 1 percent busy
5  sec avg: 1 percent busy
60 sec avg: 1 percent busy
300 sec avg: 1 percent busy
```

The following example displays the CPU utilization for each task on the device.

```
device# show cpu tasks
... Usage average for all tasks in the last 1 second ...
=====
Name                                     %
SigHdlrTsk                             0
OsTsk                                   0
TimerTsk                               0
FlashTsk                               0
MainTsk                                0
MportPollTsk                           0
IntrTsk                                0
keygen                                  0
itc                                     0
bcmDPC                                  0
bcmINTR                                 3
socdmadesc.0                           0
bcmCNTR.0                               3
bcmTX                                   0
bcmXGS3AsyncTX                         0
bcmRX                                   0
bcmL2MOD.0                             0
scp                                     0
appl                                   86
snms                                    0
rtm                                     0
rtm6                                    0
rip                                     0
bgp                                     0
bgp_io                                 0
ospf                                    0
ospf_r_calc                            0
mcast_fwd                              0
mcast                                   0
msdp                                    0
ripng                                   0
ospf6                                   0
ospf6_rt                               0
mcast6                                  0
ipsec                                   0
dhcp6                                   0
snmp                                    0
rmon                                    0
web                                     0
acl                                     0
ntp                                     0
console                                0
ospf_msg_task                           0
auxTsk                                  0
```

History

Release version	Command history
08.0.30	This command was introduced.

show cpu histogram

Displays the CPU usage histogram for the device, and optionally, clears the hold time and wait time.

Syntax	show cpu histogram [clear holdtime waittime]	
Parameters	clear	Displays the CPU usage histogram and clears the hold time and wait time.
	holdtime	Displays the CPU hold time usage histogram.
	waittime	Displays the CPU wait time usage histogram.
Modes	Global configuration mode	
	User EXEC	
Command Output	The show cpu histogram command displays the following information:	

Output field	Description
No. of buckets	The CPU usage histogram is presented in the form of buckets. Usage is divided into different intervals called buckets.
Bucket granularity	The time interval at which the CPU usage information is collected for each bucket.
Last clear	The timestamp when the task was cleared last.

Examples The following command displays the CPU hold time usage histogram.

```
device# show cpu histogram holdtime
```

```
CPU Histogram Info
```

```
-----
No. of Buckets      : 11
Bucket Granularity  : 50 msec
No. of Tasks       : 14
Last clear          : Jan  1 18:11:39.414
-----
```

```
-----
Task               | Bkt | Bkt   | Total   | Last   | Max   |
Max Hold at      |     |      |         |        |       |
Name              | Num | Time(ms) | Count   | HoldTime(ms) | HoldTime(ms) |
-----
```

appl	1	000-050	758226345	9.521	46.543
Jan 1 18:50:16.857					
appl	2	050-100	4	50.967	52.324
Jan 1 18:46:00.638					
rtm	1	000-050	44197	0.008	0.283
Jan 1 18:33:37.651					
rtm6	1	000-050	44197	0.005	0.415
Jan 1 18:18:31.476					
ospf	1	000-050	44197	0.004	1.177
Jan 1 19:02:29.746					
openflow opm	1	000-050	9118	0.007	0.239
Jan 1 18:15:01.952					
mcast	1	000-050	90565	0.004	0.143
Jan 1 18:29:04.325					
msdp	1	000-050	4425	0.007	0.201
Jan 1 19:15:34.419					
ospf6	1	000-050	44197	0.007	0.257
Jan 1 18:44:58.033					
mcast6	1	000-050	90565	0.004	0.181
Jan 1 18:36:38.346					
rmon	1	000-050	4425	0.028	5.787
Jan 1 19:24:47.464					
web	1	000-050	88335	0.010	0.368
Jan 1 18:29:48.222					
acl	1	000-050	2360	0.015	0.177
Jan 1 18:22:40.049					
ntp	1	000-050	4425	0.007	0.011
Jan 1 18:11:40.713					
console	1	000-050	88337	0.008	35.227
Jan 1 18:11:39.498					

```
-----
```

The following example displays the CPU wait time usage histogram.

```
device# show cpu histogram waittime
CPU Histogram Info
-----
No. of Buckets      : 11
Bucket Granularity  : 50 msec
No. of Tasks       : 14
Last clear          : Jan  1 18:11:39.414
```

```
-----
Task          | Bkt | Bkt   | Total   | Last           | Max           |
Max Wait at   |     |       |         | WaitTime (ms) | WaitTime (ms) |
Name          | Num | Time (ms) | Count   |               |               |
-----
rtm            1    000-050    44876    0.008    0.283
Jan  1 18:50:16.857
rtm6           1    000-050    44876    0.005    0.415
Jan  1 18:50:16.857
ospf           1    000-050    44876    0.065    1.177
Jan  1 18:50:16.857
openflow_opm   1    000-050     9258    0.006    0.239
Jan  1 19:07:56.599
mcast          1    000-050    91957    0.005    0.143
Jan  1 18:50:16.857
msdp           1    000-050     4493    0.008    0.201
Jan  1 18:28:40.956
ospf6          1    000-050    44876    0.007    0.257
Jan  1 18:50:16.857
mcast6         1    000-050    91957    0.004    0.181
Jan  1 18:50:16.857
rmon           1    000-050     4493    0.030    5.787
Jan  1 18:28:40.956
web            1    000-050    89691    0.009    0.368
Jan  1 18:50:16.857
acl            1    000-050     2397    0.018    0.177
Jan  1 18:33:17.172
ntp            1    000-050     4493    0.007    0.011
Jan  1 18:28:40.956
console        1    000-050    89693    0.010   35.227
Jan  1 18:50:16.857
-----
```

The following example clears the CPU usage histogram information.

```
device# show cpu histogram clear
```

```
CPU Histogram Info
```

```
-----
No. of Buckets      : 11
Bucket Granularity  : 50 msec
No. of Tasks       : 14
Last clear          : Jan  1 18:11:39.414
-----
```

```
-----
Task                | Bkt | Bkt      | Total      | Last      | Max      |
Max Hold at        |     |           |            |           |           |
Name               | Num | Time(ms) | Count      | HoldTime(ms) | HoldTime(ms) |
-----
```

appl		1	000-050	793262215	0.003	46.543
Jan 1 18:50:16.857						
appl		2	050-100	4	50.967	52.324
Jan 1 18:46:00.638						
rtm		1	000-050	46242	0.009	0.283
Jan 1 18:33:37.651						
rtm6		1	000-050	46242	0.005	0.415
Jan 1 18:18:31.476						
ospf		1	000-050	46242	0.006	1.177
Jan 1 19:02:29.746						
openflow opm		1	000-050	9540	0.007	0.239
Jan 1 18:15:01.952						
mcast		1	000-050	94771	0.003	0.143
Jan 1 18:29:04.325						
msdp		1	000-050	4629	0.008	0.201
Jan 1 19:15:34.419						
ospf6		1	000-050	46242	0.006	0.257
Jan 1 18:44:58.033						
mcast6		1	000-050	94771	0.003	0.181
Jan 1 18:36:38.346						
rmon		1	000-050	4629	0.137	5.787
Jan 1 19:24:47.464						
web		1	000-050	92421	0.007	0.368
Jan 1 18:29:48.222						
acl		1	000-050	2470	0.006	0.177
Jan 1 18:22:40.049						
ntp		1	000-050	4629	0.006	0.011
Jan 1 18:11:40.713						
console		1	000-050	92423	0.008	35.227
Jan 1 18:11:39.498						

```
-----
```

```
CPU Histogram Info
```

```
-----
No. of Buckets      : 11
Bucket Granularity  : 50 msec
No. of Tasks       : 14
Last clear          : Jan  1 18:11:39.414
-----
```

```
-----
Task                | Bkt | Bkt      | Total      | Last      | Max      |
Max Wait at        |     |           |            |           |           |
Name               | Num | Time(ms) | Count      | WaitTime(ms) | WaitTime(ms) |
-----
```

rtm		1	000-050	46242	0.009	0.283
Jan 1 18:50:16.857						
rtm6		1	000-050	46242	0.005	0.415
Jan 1 18:50:16.857						
ospf		1	000-050	46242	0.006	1.177
Jan 1 18:50:16.857						
openflow opm		1	000-050	9540	0.007	0.239
Jan 1 19:07:56.599						
mcast		1	000-050	94771	0.003	0.143
Jan 1 18:50:16.857						
msdp		1	000-050	4629	0.008	0.201

Show Commands

```
Jan  1 18:28:40.956
ospf6                      1      000-050      46242      0.006      0.257
Jan  1 18:50:16.857
mcast6                     1      000-050      94771      0.003      0.181
Jan  1 18:50:16.857
rmon                       1      000-050      4629       0.137      5.787
Jan  1 18:28:40.956
web                         1      000-050      92421      0.007      0.368
Jan  1 18:50:16.857
acl                        1      000-050      2470       0.006      0.177
Jan  1 19:28:22.095
ntp                        1      000-050      4629       0.006      0.011
Jan  1 18:28:40.956
console                   1      000-050      92423      0.008      35.227
Jan  1 18:50:16.857
```

```
-----
-----
CPU Histogram data cleared
```

History

Release version	Command history
08.0.30	This command was introduced.

show default values

Displays default, maximum, current, and configured values for system maximum parameters.

Syntax **show default values**

Modes Privileged EXEC mode

Examples This example does not show complete output; it shows only PIM hardware mcache values.

```
Device(config)#show default values
System Parameters      Default      Maximum      Current      Configured
pim-hw-mcache          1024         6144         1500         1500
```

This example does not show complete output; it shows only PIM6 hardware mcache values.

```
Device(config)#show default values
System Parameters      Default      Maximum      Current      Configured
pim6-hw-mcache         512          1024         1024         1024
```

This example does not show complete output; it shows only MLD mcache values.

```
Device(config)#show default values
System Parameters      Default      Maximum      Current      Configured
mld-snoop-mcache       512          8192         512          512
```

This example does not show complete output; it shows only IGMP group values.

```
Device(config)#show default values
System Parameters      Default      Maximum      Current      Configured
igmp-snoop-group-add   4096         8192         5000         5000
```

This example does not show complete output; it shows only MLD group values.

```
Device(config)#show default values
System Parameters      Default      Maximum      Current      Configured
MLD-snoop-group-addr   4096         8192         5000         5000
```

show dlb-internal-trunk-hash

Displays the dynamic load balancing (DLB) hashing method for inter-packet-processor (inter-pp) links that connect master and slave units in ICX 7450-48 devices.

Syntax **show dlb-internal-trunk-hash**

Modes Global configuration mode

Examples The following example displays the hashing method in effect for inter-pp links on an ICX 7450-48 device.

```
ICX7450-48P Router(config)#show dlb-internal-trunk-hash
Internal trunk mode: spray-mode
```

History		
	Release version	Command history
	08.0.20	This command was introduced.

show dot1x ip-acl

Displays the layer 3 ACLs for dot1x authentication.

- Syntax

show dot1x ip-acl { **all** | **ethernet** *device/slot/port* }
- Parameters

all

Specifies the ACLs at the global level.

ethernet *device/slot/port*

Specifies the ACLs at the interface level.
- Modes

Privileged EXEC mode
- Examples

The following example displays dot1x IP ACL authentication information for all interfaces.

```
device# show dot1x ip-acl all
802.1X IP ACL Information :
Port 2/1/2 : 0013.9400.0002
In-bound IP ACL : 123
Port 2/1/2 : 0013.9400.0001
In-bound IP ACL : 123
```

The following example displays dot1x IP ACL authentication information for Ethernet interface 2/1/2.

```
device# show dot1x ip-acl ethernet 2/1/2
802.1X IP ACL Information :
Port 2/1/2 : 0013.9400.0002
In-bound IP ACL : 123
Port 2/1/2 : 0013.9400.0001
In-bound IP ACL : 123
```

History	Release version	Command history
	08.0.20	This command was introduced.

show dot1x mac-filter

Shows the layer 2 ACLs for dot1x authentication.

- Syntax

show dot1x mac-filter { **all** | **ethernet** *device/slot/port* }
- Parameters

all

Specifies the ACLs at the global level.

ethernet *device/slot/port*

Specifies the ACLs at the interface level.
- Modes

Global configuration
Interface configuration
- Command Output

The **show mac-filter** command displays the following information:

Output field	Description
Dynamic MAC filter-list	The MAC filter defined on the device.

Examples The **show dot1x mac-filter** command displays the following information

```
device# show dot1x mac-filter all
802.1x MAC Address Filter information:
Port 1/1/48:
Dynamic MAC filter-list: 1
```

History	Release version	Command history
	08.0.20	This command was introduced.

show dot1x sessions

Shows dot1x configuration sessions at the global and interface level.

Syntax **show dot1x sessions** { **all** | **ethernet device/slot/port** }

Parameters **all**

Specifies the sessions at the global level.

ethernet device/slot/port

Specifies the sessions at the interface level.

Modes Global configuration

Interface configuration

Command Output The **show dot1x sessions** command displays the following information:

Output field	Description
Port	The port number.
MAC Address	The MAC address of the client.
IP Address	The IP address of the client.
VLAN	The VLAN
Auth State	The authentication state.
ACL	The specific ACL applied.
Age	The age of the session.
PAE State	The Port Access Entity state.

Examples The **show dot1x sessions** command displays the following information:

```
device# show dot1x sessions all
Port      MAC          IP          User          Vlan  Auth      ACL  Age
PAE
State
-----
-----
1/1/1  0024.3821.48dd  N/A          N/A          4092  init      none  S36734
CONNECTING
1/1/2  748e.f8b7.8f61  N/A          N/A          200   init      none  Ena   HELD
```

```
device# show dot1x sessions ethernet 1/1/15
-----
-----
```

```
Port      MAC          IP          User          Vlan  Auth      ACL  Age
PAE
State
-----
-----
1/1/1  0024.3821.48dd  N/A          N/A          4092  init      none  S36750
CONNECTING
```

History	Release version	Command history
	08.0.20	This command was introduced.

show dot1x statistics

Displays the 802.1x (dot1x) authentication statistics.

Syntax **show dot1x statistics** { **all** | **ethernet device/slot/port** }

Parameters **all**

Displays the dot1x authentication statistics for all interfaces.

ethernet device/slot/port

Displays the dot1x authentication statistics for the specified interface.

Modes Privileged EXEC mode

Command Output The **show dot1x statistics** command displays the following information:

Output field	Description
RX EAPOL Start	The number of EAPOL-Start frames received on the port.
RX EAPOL Logoff	The number of EAPOL-Logoff frames received on the port.
RX EAPOL Invalid	The number of invalid EAPOL frames received on the port.
RX EAPOL Total	The total number of EAPOL frames received on the port.
RX EAP Resp/Id	The number of EAP-Response/Identity frames received on the port
RX EAP Resp other than Resp/Id	The total number of EAPOL-Response frames received on the port that were not EAP-Response/Identity frames.
RX EAP Length Error	The number of EAPOL frames received on the port that have an invalid packet body length.
Last EAPOL Version	The version number of the last EAPOL frame received on the port.
Last EAPOL Source	The source MAC address in the last EAPOL frame received on the port.
TX EAPOL Total	The total number of EAPOL frames transmitted on the port.
TX EAP Req/Id	The number of EAP-Request/Identity frames transmitted on the port.
TX EAP Req other than Req/Id	The number of EAP-Request frames transmitted on the port that were not EAP-Request/Identity frames.

Examples The following example displays dot1x authentication statistics for port 10/2/1.

```
device# show dot1x statistics ethernet 10/2/1
```

```
Port 10/2/1 Statistics:
RX EAPOL Start : 2
RX EAPOL Logoff : 2
RX EAPOL Invalid : 0
RX EAPOL Total : 12
RX EAP Resp/Id : 4
RX EAP Resp other than Resp/Id : 4
RX EAP Length Error : 0
Last EAPOL Version : 1
Last EAPOL Source : 0022.0002.0002
TX EAPOL Total : 0
TX EAP Req/Id : 10417
TX EAP Req other than Req/Id : 2
```

History	Release version	Command history
	08.0.20	This command was introduced.

show dot1x-mka config

Shows the MACsec Key Agreement (MKA) configuration for the device.

Syntax **show dot1x-mka config**

Modes EXEC or Privileged EXEC mode

Usage Guidelines This command is supported only on the Brocade ICX 6610 in FastIron Release 08.0.20. In FastIron Release 08.0.30 and later releases, MACsec commands are also supported on the ICX 7450.

Command Output The **show dot1x-mka config** command displays the following information:

Output field	Description
dot1x-mka-enable	MACsec is enabled on the device.
enable-mka ethernet <i>device/slot/port</i>	The ethernet interfaces specified are enabled for MACsec.
mka-cfg-group <i>group-name</i>	The configuration details that follow are for the named MACsec MKA group.
key-server-priority <i>value</i>	The key server priority for MACsec transmissions on the named group is set at this value.
macsec cipher-suite gcm-aes-128 or macsec cipher-suite gcm-aes-128 integrity-only	MACsec encryptions between members of the group are encrypted. or ICV checking only is performed, but no encryption is performed.
macsec confidentiality-offset <i>value</i>	The byte offset used for encrypted data is set to the value shown. Allowable values are 0, 30 (the first 30 bytes of data are not encrypted), and 50 (the first 50 bytes of data are not encrypted).
macsec frame-validation { check discard }	For transmissions between MKA group members, indicates whether the MACsec frame header is checked and what action is taken for invalid frames (counted or discarded).
macsec-replay protection { strict out-of-order window-size <i>value</i> }	Replay protection is enabled. The type of protection is shown as strict (discard any frame received out of sequence) or as allowing receipt of out-of-sequence frames within the specified window.
key <i>value</i> name <i>value</i>	The pre-shared key is set to this value and name for the MKA configuration group. Both key and name are hexadecimal strings.

Output field	Description
enable ethernet <i>device/slot/port</i>	The specified interface is enabled for MACsec. The interface belongs to the named MKA group, and the interface uses the pre-shared key shown to confirm peers with which it can communicate.
mka-cfg-group <i>name</i>	
key <i>hexadecimal value</i> name <i>hexadecimal value</i>	

Examples The following example displays MACsec configuration information for an ICX 6610 device with MACsec enabled. Two MKA groups, test1 and group1, are configured. Interfaces with either group of parameters applied could form secure channels because the groups have the same pre-shared key.

```
device(config-dot1x-mka-1/3/2)# show dot1x-mka config

dot1x-mka-enable
mka-cfg-group test1
  key-server-priority 5
  macsec cipher-suite gcm-aes-128 integrity-only
  macsec confidentiality-offset 30
  macsec frame-validation strict
mka-cfg-group group1
  key-server-priority 20
  macsec cipher-suite gcm-aes-128
  macsec confidentiality-offset 30
enable-mka ethernet 1/3/2
  mka-group test1
    pre-shared-key 135bd758 b0ee5c11 c55ff6ab 19fdb199 key-name 96437a93 ccf10d9d
fe347846 cce52c7d
enable-mka ethernet 1/3/3
  mka-group group1
    pre-shared-key 135bd758 b0ee5c11 c55ff6ab 19fdb199 key-name 96437a93 ccf10d9d
fe347846 cce52c7d
enable-mka ethernet 1/3/4
  mka-group group1
    pre-shared-key 135bd758 b0ee5c11 c55ff6ab 19fdb199 key-name 96437a93 ccf10d9d
fe347846 cce52c7d
```

History

Release version	Command history
08.0.20	This command was introduced.

show dot1x-mka config-group

Shows details for the specified MACsec Key Agreement (MKA) groups configured on this device, or for a designated MKA group.

Syntax **show dot1x-mka config-group** *group-name*

Parameters *group-name*

Limits the group configuration displayed to the named MKA group.

Modes EXEC or Privileged EXEC mode

Usage Guidelines This command is supported only on the Brocade ICX 6610 in FastIron Release 08.0.20. In FastIron Release 08.0.30 and later releases, MACsec commands are also supported on the ICX 7450.

Command Output The **show dot1x-mka config-group** command displays the following information:

Output field	Description
mka-cfg-group	The configuration details that follow are for the specified MACsec MKA group.
key-server-priority	The key-server priority for MACsec transmissions on the named group is set at the specified value.
macsec cipher-suite gcm-aes-128 or macsec cipher-suite gcm-aes-128 integrity-only	MACsec transmissions are encrypted. ICV checking only is performed.
macsec confidentiality-offset	The byte offset used for encrypted data is set to the value shown. Allowable values are 0, 30 (the first 30 bytes of data are not encrypted), and 50 (the first 50 bytes of data are not encrypted).
macsec frame-validation {check discard}	Indicates whether the MACsec frame header is checked and what action is taken for invalid frames (counted or discarded).
macsec replay-protection {strict out-of-order window-size size}	Replay protection is enabled. The type of protection is shown as strict (discard any frame received out of sequence) or as allowing receipt of out-of-sequence frames within the specified window.

Examples The following example lists the configuration details for MKA group test1.

```
device(config-dot1x-mka-1/3/2)# show dot1x-mka config-group test1
mka-cfg-group test1
  key-server-priority 5
  macsec cipher-suite gcm-aes-128 integrity-only
  macsec confidentiality-offset 30
  macsec frame-validation check
  macsec replay-protection strict
```

History	Release version	Command history
	08.0.20	This command was introduced.

show dot1x-mka sessions

Displays a summary of all MACsec Key Agreement (MKA) sessions on the device.

Syntax **show dot1x-mka sessions brief**

show dot1x-mka sessions ethernet *device/slot/port*

Parameters **brief**

Displays a brief status of all MKA sessions.

ethernet *device/slot/port*

Displays MKA sessions that are active on a specified Ethernet interface. The Ethernet interface is specified by device position in stack, slot on the device, and interface on the slot.

Modes EXEC or Privileged EXEC mode

Usage Guidelines This command is supported only on the Brocade ICX 6610 in FastIron Release 08.0.20. In FastIron Release 08.0.30 and later releases, MACsec commands are also supported on the ICX 7450.

Command Output The **show dot1x-mka sessions** command with the **brief** option displays the following information:

Output field	Description
Port	Designates the interface for which MACsec information is listed (by device, slot, and port).
Link-Status	Indicates whether the link is up or down.
MKA-Status	Indicates whether a secure channel has been established.
Key-Server	Indicates whether the interface is operating as a key-server.
Negotiated Capability	Indicates MACsec parameters configured on the designated interface.

The **show dot1x-mka sessions** command with the **ethernet** interface options displays the following information:

Output field	Description
Interface	The information that follows applies to the designated interface.
MKA cfg group Name	The designated MKA configuration group has been applied to the designated interface.
DOT1X-MKA Enabled (Yes, No)	Indicates whether MACsec is enabled for the designated interface.
DOT1X-MKA Active (Yes, No)	Indicates whether MACsec is active on the interface.
Key Server (Yes, No)	Indicates whether the MACsec key-server is active over the interface.
Configuration Status:	The following fields describe the MKA configuration applied to the interface.
Enabled (Yes, No)	Indicates whether MACsec is currently enabled.

Output field	Description
Capability (Integrity and or confidentiality)	Indicates whether ICV checks are being performed on MACsec frames and whether encryption is being applied.
Desired (Yes, No)	Indicates whether port is interested in becoming the key-server.
Protection (Yes, No)	Indicates whether replay protection is applied to the interface.
Frame Validation (Yes, No)	Indicates whether frames received are being checked for valid MACsec headers.
Replay Protection (Strict, Out of Order)	Indicates that replay protection is configured and whether frames must be received in exact order or within an allowable window.
Replay Protection Size	Indicates the allowable window size within which frames may be received.
Cipher Suite (GCM-AES-128)	Specifies the cipher suite used for ICV checking, encryption, and decryption.
Key Server Priority (1 to 127)	Specifies the key-server priority configured on the interface.
Secure Channel Information	The following fields describe a secure channel established on this interface.
Local SCI	Provides the hexadecimal value of the Secure Channel Identifier for this channel.
Member Identifier	Provides the MACsec number assigned to the MKA peer.
Message Number	Provides the Message Number contained in Hello packets from this MKA peer. Hello packets are exchanged to determine peer status, MACsec capabilities, and SAK Key Identifier.
Latest SAK Status (RX and or TX)	Indicates the Secure Association Key (SAK) state.
Latest SAK AN	Provides the Association Number for the most recently active Secure Association Key.
Latest SAK KI	Provides the Key Identifier for the most recently active Secure Association Key.
Negotiated Capability (Integrity and or Confidentiality with offset)	Indicates whether ICV checking, encryption, and a confidentiality offset have been applied on the secure channel. (The negotiated capability may differ from parameters configured on the interface when it does not have key-server status.)
Peer Information:	The output fields that follow provide information on actual and potential MACsec peer interfaces.
State (Live or Potential)	Indicates whether the peer is considered a live peer or a potential peer for MKA protocol.
Member Identifier	Designates the peer by its Member Identifier, a hexadecimal value.
Message Number	Provides the Message Number that appears in Hello packets from the designated peer interface as a hexadecimal value.
SCI	Provides the peer's Secure Channel Identifier.
Priority	Provides the key-server priority configured on the peer interface.

Examples In the following example, all enabled MKA interfaces on the device are listed, along with configured parameters and current status.

```
device(config-dot1x-mka-1/3/2)# show dot1x-mka sessions brief
```

Port	Link-Status	MKA-Status	Key-Server	Negotiated Capability
1/3/2	Down	Pending	---	---
1/3/3	Up	Secured	No	Integrity, Confidentiality with Off. 30
1/3/4	Up	Secured	No	Integrity, Confidentiality with Off. 30

The following example lists MKA sessions that are active on Ethernet interface 1/3/3 (device 1, slot 3, port 3), with configuration details for each active interface.

```
device(config-dot1x-mka-1/3/3)# show dot1x-mka sessions ethernet 1/3/3
```

```
Interface                : 1/3/3

MACsec Status            : Secured
DOT1X-MKA Enabled        : Yes
DOT1X-MKA Active         : Yes
Key Server                : No

Configuration Status:
Enabled                   : Yes
Capability                 : Integrity, Confidentiality
Desired                   : Yes
Protection                : Yes
Frame Validation          : Disable
Replay Protection         : Strict
Replay Protection Size    : 0
Cipher Suite              : GCM-AES-128
Key Server Priority       : 20

Local SCI                 : 748ef8344a510082
Member Identifier         : 802ed0536fcafc43407ba222
Message Number            : 8612

Secure Channel Information:
Latest SAK Status         : Rx & Tx
Latest SAK AN             : 0
Latest KI                 : d08483062aa9457e7c2470e300000001
Negotiated Capability     : Integrity, Confidentiality with offset 30

Peer Information:
State      Member Identifier      Message Number      SCI
Priority
-----
-----
Live      d08483062aa9457e7c2470e3      8527      748ef83443910082
20
```

History

Release version	Command history
08.0.20	This command was introduced.

show dot1x-mka statistics

Displays current MACsec Key Agreement (MKA) statistics on the interface.

Syntax	show dot1x-mka statistics ethernet device/slot/port
Parameters	ethernet device/slot/port Ethernet interface for which MKA statistics are to be displayed. The interface is designated by a device number in stack/slot on the device/interface on the slot.
Modes	EXEC or Privileged EXEC mode
Usage Guidelines	<p>This command is supported only on the Brocade ICX 6610 in FastIron Release 08.0.20. In FastIron Release 08.0.30 and later releases, MACsec commands are also supported on the ICX 7450.</p> <p>It is recommended that you use the clear dot1x-mka statistics command to clear results of the previous show dot1x-mka statistics command before re-executing it.</p>
Command Output	The show dot1x-mka statistics command displays the following information:

Output field	Description
Interface (device/slot/port)	The output fields describe MACsec activity for the designated interface.
MKA in Pkts	MKA protocol packets received
MKA in SAK Pkts	MKA protocol packets received containing a SAK
MKA in Bad Pkts	MKA protocol packets received that are bad
MKA in Bad ICV Pkts	MKA protocol packets received with a bad ICV
MKA in Mismatch Pkts	MKA protocol packets received with mismatched CAK
MKA out Pkts	MKA protocol packets transmitted
MKA out SAK Pkts	MKA protocol packets transmitted containing a SAK
Number of SAK	Total number of SAKs received

Examples The following example shows MKA statistics for Ethernet interface 1/3/3 (device 1, slot 3, port 3), which is transmitting and receiving MACsec frames.

```
device(config-dot1x-mka-1/3/3)# clear dot1x-mka statistics ethernet 1/3/3
device(config-dot1x-mka-1/3/3)# show dot1x-mka statistics ethernet 1/3/3
```

```
Interface                : 1/3/3
MKA in Pkts              : 8585
MKA in SAK Pkts          : 1
MKA in Bad Pkts          : 0
MKA in Bad ICV Pkts      : 0
MKA in Mismatch Pkts     : 0
MKA out Pkts             : 8687
MKA out SAK Pkts         : 0
Number of SAK            : 1
```

History	Release version	Command history
	08.0.20	This command was introduced.

show eee-statistics

Displays the global energy efficient statistics.

Syntax **show eee-statistics**

Modes Global configuration mode

Command Output The **show eee-statistics** command displays the following information:

Output field	Description
Port	The port number.
EEE-State	Displays if Energy Efficient Ethernet is enabled or disabled. If disabled then all the counters will be 0. If EEE is enabled, then these counters will be updated.
TXEventCount	TX EEE Low Power Idle (LPI) event counter. This counter specifies the number of times the LPI mode has been enforced by EEE on Transmit side.
TXDuration	TX EEE LPI duration counter. This is an LPI event duration counter on the transmit path which gets updated if the port is in LPI mode.
RXEventCount	RX EEE LPI event counter. This counter specifies the number of times the LPI mode has been enforced by EEE on the receive side.
RXDuration	RX EEE LPI duration counter. This is an LPI event duration counter on the receive path which gets updated if the port is in LPI mode.

Examples The following example displays Energy Efficient Ethernet globally.

```

device# show eee-statistics
Port      EEE-State  TXEventCount  TXDuration
RXEventCount  RXDuration
1/1/1      Enable      0              0
0          0
1/1/2      Enable      0              0
0          0
1/1/3      Enable      17             2551234
16         2561886
1/1/4      Enable      17             2545628
16         50953524
1/1/5      Enable      2              2550749
2          50952549
1/1/6      Enable      1              2543935
1          2551760
1/1/7      Enable      17             2549030
17         2550750
1/1/8      Enable      2              419455
16         50952710
1/1/9      Enable      1              424565
1          50950470
1/1/10     Enable      17             2549030
1          2549101
1/1/11     Enable      2              419455
2          424563
1/1/12     Enable      1              424565
10         50945833
1/1/13     Enable      2              1526709
10         1532337
1/1/14     Enable      10             1531808
2          2561886
1/1/15     Enable      10             1531391
2          1531834
1/1/16     Enable      2              1526292
10         50945548
1/1/17     Enable      2              1542560
10         50957135
1/1/18     Enable      10             1537443
2          1542565
1/1/19     Enable      10             1528600
2          1533722
1/1/20     Enable      2              1533717
10         50948350
1/1/21     Enable      2              1533203
10         50947920
1/1/22     Enable      10             1528087
2          1533230
1/1/23     Enable      10             1527677
2          1532799
1/1/24     Enable      2              1532794
10         50947596

```

History

Release version

Command history

08.0.30

This command was introduced.

show eee-statistics ethernet

Displays the Energy Efficient Ethernet statistics on a specific interface.

Syntax **show eee-statistics ethernet** *stackid/slot/port*

Modes Global configuration mode

Command Output The **show eee-statistics ethernet** command displays the following information:

Output field	Description
Port	The port number.
EEE-State	Displays if Energy Efficient Ethernet is enabled or disabled. If disabled then all the counters will be 0. If EEE is enabled, then these counters will be updated.
TXEventCount	TX EEE Low Power Idle (LPI) event counter. This counter specifies the number of times the LPI mode has been enforced by EEE on Transmit side.
TXDuration	The total time from the first LPI (Low Power Idle) signal transmission. This is an LPI event duration counter on the transmit path which gets updated if the port is in LPI mode.
RXEventCount	The LPI signal reception count. This counter specifies the number of times the LPI mode has been enforced by EEE on the receive side.
RXDuration	Total time from the first LPI signal reception. This is an LPI event duration counter on the receive path which gets updated if the port is in LPI mode.

Examples The following example displays energy efficient statistics on a specific interface.

```
device(config)# show eee-statistics ethernet 1/1/4
```

```
Port      EEE-State      TXEventCount      TXDuration      RXEventCount
RXDuration
1/1/4     Enable         17                2545628         16
50953524
```

History

Release version	Command history
08.0.30	This command was introduced.

show ethernet loopback interfaces

Displays the status and details of each Ethernet loopback-enabled port and the associated VLANs.

Syntax	show ethernet loopback interfaces [brief port <i>stackid/slot/port</i> vlan <i>vlan-id</i>]		
Parameters	brief	Displays the Ethernet loopback information in brief mode.	
	port	Displays the status and details of each port.	
	<i>stackid/slot/port</i>	Specifies the port number.	
	vlan	Displays the status and details of a VLAN.	
	<i>vlan-id</i>	Specifies the VLAN ID.	
Modes	Privileged EXEC mode		
	Global configuration mode		
	VLAN configuration mode		
Command Output	The show ethernet loopback interfaces command displays the following information:		

Output field	Description
Interface Type	Type of interface (VLAN-aware or VLAN-unaware)
Interface Port	Interface ID (Port number)
Interface Mode	Flow classification mode (Flow-aware or Flow-unaware)
Flow Mode DA/SA	Destination and Source MAC address of the flow

Examples The following example shows the output of the **show ethernet loopback interfaces** command.

```
device(config-vlan-10)# show ethernet loopback interfaces
```

```
ETHERNET LOOPBACK INTERFACE [1/1/11] (In Service)
Interface Type   : PORT
Interface Port   : 1/1/11
Interface Mode   : FLOW-UNAWARE
Flow Mode DA/SA : ANY/ANY
```

The following example shows the output of the **show ethernet loopback interfaces brief** command.

```
device(config-vlan-10)# show ethernet loopback interfaces brief
PORT      TYPE  VLANS STATUS OP-MODE D-MAC          S-MAC
=====|=====|=====|=====|=====|=====|=====
1/1/11    | PORT | 0    | ACTV | FLOW-U |          ANY |          ANY
1/1/12    | VLAN | 1    | ACTV | FLOW-A | 1111.2222.3333| 4444.5555.5555
```

The following example shows the output of the **show ethernet loopback interfaces port** command.

```
device(config-vlan-10)# show ethernet loopback interfaces port 1/1/1
ETHERNET LOOPBACK INTERFACE [1/1/1] (In Service)
Interface Type   : PORT
Interface Port   : 1/1/1
Interface Mode   : FLOW-UNAWARE
Flow Mode DA/SA : ANY/ANY
```

History	Release version	Command history
	08.0.30	This command was introduced.

show ethernet loopback resources

Displays the available resources and the resources that are used by loopback testing.

Syntax **show ethernet loopback resources**

Modes Privileged EXEC mode
Global configuration mode
VLAN configuration mode

Command Output The **show ethernet loopback resources** command displays the following information:

Output field	Description
Interface Resource	Maximum number of ports that can be enabled with Ethernet loopback.
H/W Pool Resource	Maximum hardware resource for loopback.

Examples The following example shows the output of the **show ethernet loopback resources** command.

```
device(config)# show ethernet loopback resources
Ethernet Loopback Resource:
  RESOURCE NAME      MAX      USED      AVAILABLE
=====|=====|=====|=====
  Interface Resource|    20|      0|      20
  H/W Pool Resource|    40|      0|      40
```

History	Release version	Command history
	08.0.30	This command was introduced.

show files disk0

Displays the contents of the USB flash drive.

Syntax **show files disk0**

Modes Enable mode

Usage Guidelines

Examples The following example displays the contents of the USB flash drive.

```
device# show files disk0
F          681 20140611132829945ICX7450-PREM-LIC-SW.XML
F      28483780 SPS08030q066.bin
F          391 stacking.boot
F          0  sil_logs
F      28483780 pri_bin
F          391 stacking.boot1111
F          2160 running-configsp2
F          2162 startup-config.sp2
F          2160 run1
F          5344 core-file
```

History	Release version	Command history
	08.0.30	This command was introduced.

show breakout

Displays information on 10 Gbps sub-ports broken out from 40 Gbps ports on certain FastIron devices.

- Syntax** **show breakout**
- Modes** Privileged EXEC mode.
- Usage Guidelines** The **show breakout** command is available only on ICX 7750 devices.
- Command Output** The **show breakout** command displays the following information:

Output field	Description
Port	Specifies the port for which breakout information is displayed to the right.
Module Exist	Indicates whether the module on which the specified port resides is present in the unit.
Module Conf	Indicates whether the module on which the specified port resides is configured.
Breakout-config	Indicates whether breakout is configured on the specified port.
Breakout-oper	Indicates whether sub-ports on the specified breakout port are operational.

- Examples** The following example shows that port 1/2/1 has been configured for breakout into four 10 Gbps sub-ports and is operational (has active sub-ports). Ports 1/2/2 and 1/2/4 are configured for breakout, pending reload.

```
Device# show breakout
Unit-Id: 1
Port      Module Exist  Module Conf  Breakout-config  Breakout-oper
1/2/1     yes           no           yes              yes
1/2/2     yes           no           yes              no
1/2/3     yes           no           no               no
1/2/4     yes           no           yes              no
1/2/5     yes           no           no               no
1/2/6     yes           no           no               no
1/3/1     yes           no           no               no
1/3/2     yes           no           no               no
1/3/3     yes           no           no               no
1/3/4     yes           no           no               no
1/3/5     yes           no           no               no
1/3/6     yes           no           no               no
```

History

Release version	Command history
FastIron Release 08.0.30	This command was introduced.

show interfaces ethernet

Displays Ethernet interface information.

Syntax	show interfaces ethernet <i>stackid/slot/port</i>
Parameters	<i>stackid / slot / port</i> Stack ID number, slot number, and port number for an existing Ethernet interface.
Modes	Privileged EXEC mode
Examples	This example shows detailed interface information. Note that the priority flow control (PFC) is shown as enabled and information for the unicast and multicast egress queues is shown separately.

```
device# show interfaces ethernet 1/1/22

10GigabitEthernet1/1/22 is up, line protocol is up
  Port up for 16 minutes 1 seconds
  Hardware is 10GigabitEthernet, address is aabb.ccdd.ef14 (bia aabb.ccdd.ef14)
  Configured speed 10Gbit, actual 10Gbit, configured duplex fdx, actual fdx
  Member of 1 L2 VLANs, port is tagged, port state is FORWARDING
  BPDU guard is Disabled, ROOT protect is Disabled, Designated protect is Disabled
  Link Error Dampening is Disabled
  STP configured to ON, priority is level0, mac-learning is enabled
  ...
  ...
  MTU 1500 bytes
  Priority-Flow-Control is Enabled
  300 second input rate: 37014512 bits/sec, 9036 packets/sec, 0.38% utilization
  300 second output rate: 731174584 bits/sec, 178509 packets/sec, 7.58% utilization
  0 packets input, 0 bytes, 0 no buffer
  Received 0 broadcasts, 0 multicasts, 0 unicasts
  0 input errors, 0 CRC, 0 frame, 0 ignored
  0 runs, 0 giants
  26055807 packets output, 13340529672 bytes, 0 underruns
  Transmitted 0 broadcasts, 98 multicasts, 26055709 unicasts
  0 output errors, 0 collisions
  Relay Agent Information option: Disabled

UC Egress queues:
Queue counters   Queued packets   Dropped Packets
0                0                2074860
1                2349160         2074861
2                2349163         2074861
3                2349165         2074860
4                2349163         2074860
5                2349165         2074860
6                5461694         518651
7                6498353         0

MC Egress queues:
Queue counters   Queued packets   Dropped Packets
0                0                0
1                0                0
2                0                0
3                0                0
4                0                0
```

This example shows information for an interface that has an ingress profile and an egress profile attached to a port.

```
device(config-if-e40000-1/1/1)# show interfaces ethernet 1/1/1

40GigabitEthernet1/1/1 is up, line protocol is up
  Port up for 5 days 12 hours 45 minutes 48 seconds
  Hardware is 40GigabitEthernet, address is 748e.f8f9.3d80 (bia 748e.f8f9.3d80)
  Configured speed 40Gbit, actual 40Gbit, configured duplex fdx, actual fdx
  Configured mdi mode AUTO, actual none
  Member of 1 L2 VLANs, port is tagged, port state is FORWARDING
  BPDU guard is Disabled, ROOT protect is Disabled, Designated protect is Disabled
  Link Error Dampening is Disabled
  STP configured to ON, priority is level0, mac-learning is enabled
  Flow Control is enabled
  Mirror disabled, Monitor disabled
  Mac-notification is disabled
  Not member of any active trunks
  Not member of any configured trunks
  No port name
  IPG MII 96 bits-time, IPG GMII 96 bits-time
  MTU 1500 bytes, encapsulation ethernet
  Ingress Profile is i1
  Egress Profile is e1
  300 second input rate: 0 bits/sec, 0 packets/sec, 0.00% utilization
  300 second output rate: 0 bits/sec, 0 packets/sec, 0.00% utilization
  8060797794 packets input, 1031782117647 bytes, 0 no buffer
  Received 0 broadcasts, 0 multicasts, 8060797794 unicasts
  4 input errors, 0 CRC, 0 frame, 0 ignored
  0 runs, 0 giants
  8078157201 packets output, 1034004121728 bytes, 0 underruns
  Transmitted 0 broadcasts, 0 multicasts, 8078157201 unicasts
  0 output errors, 0 collisions
  Relay Agent Information option: Disabled
```

This example shows information for the configured bandwidth on a specific interface. In this example the configured interface bandwidth value is 2000 kilobits.

```
device# show interfaces ethernet 1/1/1

GigabitEthernet1/1/1 is disabled, line protocol is down
  STP Root Guard is disabled, STP BPDU Guard is disabled
  Hardware is GigabitEthernet, address is 748e.f82a.6a00 (bia 748e.f82a.6a00)
  Configured speed auto, actual unknown, configured duplex fdx, actual unknown
Interface bandwidth is 2000 kbps
```

History	Release version	Command history
	8.0.20	This command was modified to include PFC status and separate unicast and multicast egress queues.
	8.0.30	This command was modified to include configured bandwidth status.

show interfaces tunnel

Displays tunnel interface information.

Syntax `show interfaces tunnel tunnel-number`

Parameters *tunnel-number*
Specifies the tunnel number. Valid values range from 1 through 72,

Modes Privileged EXEC mode

Command Output The `show interfaces tunnel` command displays the following information:

Field	Definition
Hardware is Tunnel	The interface is a tunnel interface.
Tunnel source	The source address for the tunnel.
Tunnel destination	The destination address for the tunnel.
Tunnel mode	The tunnel mode. The gre specifies that the tunnel will use GRE encapsulation (IP protocol 47).
Interface bandwidth	The configured bandwidth on a tunnel interface for routing metric purposes only.
Port name	The port name (if applicable).
Internet address	The internet address.
MTU	The configured path maximum transmission unit.
encapsulation GRE	GRE encapsulation is enabled on the port.
Keepalive	Indicates whether or not GRE link keepalive is enabled.
Path MTU Discovery	Indicates whether or not PMTUD is enabled. If PMTUD is enabled, the MTU value is also displayed.
Path MTU	The PMTU that is dynamically learned.
Age-timer	Indicates the pmtud aging timer configuration in minutes.The default is 10. The range is from 10 - 30.
Path MTU will expire	Indicates the time after which the learned PMTU expires. This line is displayed only when a PMTU is dynamically learned.

Examples This example displays the GRE tunnel configuration and the pmtu aging timer information..

```
show interfaces tunnel 10
Tunnel10 is up, line protocol is up
  Hardware is Tunnel
  Tunnel source 10.1.41.10
  Tunnel destination is 10.1.14.10
  Tunnel mode gre ip
  Port name is GRE_10 to VR1 on FCX_STACK
  Internet address is 10.11.1.1/31, MTU 1476 bytes, encapsulation GRE
  Keepalive is not Enabled
  Path MTU Discovery: Enabled, MTU is 1428 bytes, age-timer: 10 minutes
  Path MTU will expire in 0 minutes 50 secs
```

This example shows information for the configured interface bandwidth value on a tunnel interface.

```
device# show interfaces tunnel 2

Tunnel2 is up, line protocol is up
  Hardware is Tunnel
  Tunnel source 10.70.15.1
  Tunnel destination is 10.70.15.2
  Tunnel mode gre ip
  Interface bandwidth is 2000 kbps
  No port name
  Internet address is: 10.0.0.1/24
  Tunnel TOS 0, Tunnel TTL 255, Tunnel MTU 1476 bytes
  Keepalive is not Enabled

Tunnel Packet Statistics:

```

	In-Port(s)	Unicast Packets		Multicast Packets	
		[Rcv-from-tnnl	Xmit-to-tnnl]	[Rcv-from-tnnl	Xmit-to-
tnnl]	e1/1 - e1/24	2224	0	0	0

History	Release version	Command history
	8.0.30	This command was modified to include configured bandwidth status.

show interfaces ve

Displays Virtual Ethernet (VE) interface information.

- Syntax

show interfaces ve *vlan_id*
- Parameters

vlan_id
Specifies the configured corresponding VLAN interface.
- Modes

Privileged EXEC mode
- Examples

This example shows information for the configured bandwidth on a VE interface. In this example the configured interface bandwidth value is 2000 kilobits.

```
device#show interfaces ve 100
Ve100 is up, line protocol is up
  Type is Vlan (Vlan Id: 100)
  Hardware is Virtual Ethernet, address is 748e.f82a.cf00 (bia 748e.f82a.cf00)
  No port name
  Vlan id: 100
  Interface bandwidth is 2000 kbps
  ipv6 address 190::1/64
```

History	Release version	Command history
	8.0.30	This command was modified to include configured bandwidth status.

show interfaces lag

Displays information about the LAG interface including counters.

Syntax	show interfaces lag [<i>lag-id</i> <i>lag-name</i>]
Parameters	<div><div><i>lag-id</i></div><div>Displays LAG information of a LAG specified by the LAG ID. If the specified LAG ID is not available, a warning message is displayed.</div><div><i>lag-name</i></div><div>Displays LAG information of a LAG specified by the LAG name. If the specified LAG name is not available, a warning message is displayed.</div></div>
Modes	Privileged EXEC mode Global configuration mode
Examples	The following command shows that the LAG specified by LAG ID 2 is not available in the system.

```
device(config)# show interfaces lag id2
Warning: can't find LAG id2
```

The following command shows LAG information of a lag1.

```
device(config)# show interfaces lag lag1
Total number of LAGs: 1
Total number of deployed LAGs: 1
Total number of trunks created:1 (127 available)
LACP System Priority / ID: 1 / 0000.0001.c000
LACP Long timeout: 90, default: 90
LACP Short timeout: 3, default: 3
=== LAG "lag1" ID 123 (static Deployed) ===
LAG Configuration:
Ports: e 1/1 to 1/2
Port Count: 2
Primary Port: 1/1
Trunk Type: hash-based
Deployment: Trunk ID 123, Active Primary none, base fid: 0x0800
Port Link Port-State Dupl Speed Trunk Tag Priori MAC Name Type
1/1 DisabNone None None 123 No level0 0000.0001.c000
default-port
1/2 DisabNone None None 123 No level0 0000.0001.c000
default-port
LAG lag1 Counters:
      InOctets      2237519128754      OutOctets      1050988054740
      InPkts        1968838581      OutPkts        2030408443
      InBroadcastPkts      0      OutBroadcastPkts      0
      InMulticastPkts      0      OutMulticastPkts      0
      InUnicastPkts      1968838581      OutUnicastPkts      2030448142
      InDiscards      0      OutDiscards      0
      InErrors      0      OutErrors      0
      InCollisions      0      OutCollisions      0
      OutLateCollisions      0
      Alignment      0      FCS      0
      GiantPkts      0      ShortPkts      0
      InBitsPerSec      782177316      OutBitsPerSec      466226351
      InPktsPerSec      90896      OutPktsPerSec      99992
      InUtilization      7.96%      OutUtilization      4.82%
```

The following command shows information about the LAG interface, including counters.

```

device(config)# show interfaces lag
Total number of LAGs: 1
Total number of deployed LAGs: 1
Total number of trunks created: 1 (123 available)
LACP System Priority / ID: 1 / 748e.f8b1.66e0
LACP Long timeout: 120, default: 120
LACP Short timeout: 3, default: 3

=== LAG "test" ID 1 (dynamic Deployed) ===
LAG Configuration:
  Ports: e 1/1/1 to 1/1/2
  Port Count: 2
  Primary Port: 1/1/1
  Trunk Type: hash-based
  LACP Key: 20001
Deployment: HW Trunk ID 1
Port      Link      State      Dupl  Speed  Trunk  Tag  Pvid  Pri  MAC      Name
1/1/1     Up      Forward Full  1G      1      No    1      0
748e.f8b1.66e0
1/1/2     Up      Forward Full  1G      1      No    1      0  748e.f8b1.66e0
Port      [Sys P] [Port P] [Key ] [Act] [Tio] [Agg] [Syn] [Col] [Dis] [Def] [Exp] [Ope]
1/1/1     1      1      20001 Yes    L      Agg  Syn  Col  Dis  No  No  Ope
1/1/2     1      1      20001 Yes    L      Agg  Syn  Col  Dis  No  No  Ope

Partner Info and PDU Statistics
Port      Partner      Partner      LACP      LACP
          System MAC      Key      Rx Count  Tx Count
1/1/1     748e.f8b1.6020  20001      19        18
1/1/2     748e.f8b1.6020  20001      18        19

LAG test Counters:
InOctets      91162279156      OutOctets      91155682034
InPkts        171383016        OutPkts        171371929
InBroadcastPkts 75449406        OutBroadcastPkts 75438497
InMulticastPkts 10560          OutMulticastPkts 10553
InUnicastPkts 95923050        OutUnicastPkts 95922879
InBadPkts      0
InFragments    0
InDiscards     0
CRC            0
InErrors       0
InGiantPkts    0
InShortPkts    0
InJabber       0
InFlowCtrlPkts 0
InBitsPerSec   1931301848      OutFlowCtrlPkts 0
InPktsPerSec   453126          OutBitsPerSec   1931301848
InUtilization  100.00%         OutPktsPerSec   453126
OutUtilization 100.00%         OutErrors       0
Collisions     0
LateCollisions 0

```

History

Release version

Command history

08.0.30

This command was introduced.

show interfaces stack-ports

Use the **show interfaces stack-ports** command to display information about the stacking ports for all members in a stack.

- Syntax

show interfaces stack-ports
- Modes

Privileged EXEC mode
- Usage Guidelines

Use the **clear stack ipc** command before issuing the **show stack ipc** command. This helps to ensure that the data are the most recent traffic statistics for the stack.

This command must be executed from active stack controller.
- Command Output

The **show interfaces stack-ports** command displays the following information:

Output field	Description
Port	Specifies the stack identification number for this unit
Link	Identifies the configuration for modules on this unit
State	Indicates that a priority has been assigned to this stack unit
Dupl	Indicates whether the port is configured as half- or full-duplex
Speed	Indicates the port speed
Trunk	Indicates whether the port is part of a trunk
Tag	Indicates whether the port is tagged or untagged
P	Specifies port priority
MAC	Provides the MAC address of the port.
<div><div>NOTE</div><div>If a unit is provisional (it is reserved and does not have a physical unit associated with the unit ID), the interface MAC address displayed for the unit is 0000.0000.0000.</div></div>	
Name	Displays the optional name assigned to the port if present

Examples The following example displays information about the stack-port interfaces for an ICX 6610 in a mixed stack.

```
ICX6610-48 Router# show interfaces stack-ports
Port      Link      State Dupl Speed Trunk Tag Pvid Pri MAC      Name
1/2/1     Up        Forward Full 40G  None No  N/A  0  0000.0034.1db5
1/2/2     Up        Forward Full 10G  None No  N/A  0  0000.0034.1db6
1/2/6     Up        Forward Full 40G  None No  N/A  0  0000.0034.1db7
1/2/7     Down      None    None None  None No  N/A  0  0000.0034.1db8
2/2/1     Down      None    None None  None No  N/A  0  0000.0000.0000
2/2/2     Down      None    None None  None No  N/A  0  0000.0000.0000
2/2/6     Down      None    None None  None No  N/A  0  0000.0000.0000
2/2/7     Down      None    None None  None No  N/A  0  0000.0000.0000
3/2/1     Down      None    None None  None No  N/A  0  0000.0034.266d
3/2/2     Up        Forward Full 10G  None No  N/A  0  0000.0034.266e
3/2/6     Up        Forward Full 40G  None No  N/A  0  0000.0034.266f
3/2/7     Up        Forward Full 10G  None No  N/A  0  0000.0034.2670
5/2/1     Down      None    None None  None No  N/A  0  0000.0034.11ad
5/2/2     Up        Forward Full 10G  None No  N/A  0  0000.0034.11ae
5/2/6     Up        Forward Full 40G  None No  N/A  0  0000.0034.11af
5/2/7     Down      None    None None  None No  N/A  0  0000.0034.11b0
```

show ip mroute

Displays information on multicast routes. You can specify whether you want to display information from static or connected mroutes or from a particular mroute.

Syntax	show ip mroute [vrf <i>vrf-name</i>] { static connected nexthop <i>ip-subnet</i> [<i>mask</i>] }
Parameters	vrf <i>vrf-name</i>
	Specifies a VRF route.
	static
	Specifies a static multicast route.
	connected
	Specifies a directly attached (connected) multicast route.
	nexthop
	Specifies an IPv4 next hop table.
	<i>ip-subnet</i> [<i>mask</i>]
	Specifies an IP address.

Modes Privileged EXEC mode
Global configuration mode

Examples The following example displays information for IP multicast routes:

```
Device(config)# show ip mroute
```

```
Total number of IP routes: 5
Type Codes - B:BGp D:Connected S:Static; Cost - Dist/Metric
Type Destination Gateway Port Cost
1 20.20.20.0/24 220.220.220.1 ve 220 1/1
S 8m54s
2 50.50.50.0/24 DIRECT ve 50 0/0
D 8h26m
3 77.1.1.1/32 DIRECT loopback 1 0/0
D 8h26m
4 129.129.129.0/24 DIRECT ve 129 0/0
D 8h26m
5 220.220.220.0/24 DIRECT ve 220 0/0
D 2h49m
```

The following example displays information for static multicast routes:

```
Device(config)# show ip mroute static
```

```
Type Codes - B:BGp D:Connected S:Static; Cost - Dist/Metric
1 Destination Gateway Port Cost Type Uptime
1 20.20.20.0/24 220.220.220.1 ve 220 1/1 S 8m54s
```

The following example displays information for directly attached multicast routes:

```
Device(config)# show ip mroute connected
```

```
Type Codes - B:BGp D:Connected S:Static; Cost - Dist/Metric
1 Destination Gateway Port Cost Type Uptime
1 50.50.50.0/24 DIRECT ve 50 0/0 D 8h26m
2 77.1.1.1/32 DIRECT loopback 1 0/0 D 8h26m
3 129.129.129.0/24 DIRECT ve 129 0/0 D 8h26m
4 220.220.220.0/24 DIRECT ve 220 0/0 D 2h49m
```

The following example displays information for IP multicast route 50.50.50.100:

```
Device(config)# show ip mroute 50.50.50.100
```

```
Type Codes - B:BGp D:Connected S:Static; Cost - Dist/Metric
1 Destination Gateway Port Cost Type Uptime
1 50.50.50.0/24 DIRECT ve 50 0/0 D 8h26m
```

History	Release version	Command history
	8.0.10a	This command was introduced.

show ip msdp mesh-group

Displays the details of a specific mesh-group.

Syntax	show ip msdp [<i>vrf vrf-name</i>] mesh-group <i>group-name</i>		
Parameters	vrf		Displays the mesh-group details for the VRF instance specified by the <i>vrf-name</i> variable.
	<i>vrf-name</i>		Specifies the VRF instance.
	mesh-group		Specifies the MSDP group.
	<i>group-name</i>		Specifies the mesh group.
Modes	Privileged EXEC mode		
	Global configuration mode		
	MSDP router configuration mode		
Usage Guidelines	If used without specifying a VRF, this command shows data from the default VRF.		
Command Output	The show ip msdp [<i>vrf vrf-name</i>] mesh-group <i>group-name</i> command displays the following information:		

Output field	Description
Peer Address	The IP address of the MSDP peer that is placed in the mesh group.
State	The state of the MSDP device connection with the mesh group. The state can be one of the following: <ul style="list-style-type: none">• CONNECT - The session is in the active open state.• ESTABLISH - The MSDP session is fully up.• IDLE - The session is idle.• LISTEN - The session is in the passive open state.
KA (Keep Alive) In	The number of MSDP keepalive messages received by the mesh group.
KA (Keep Alive) Out	The number of MSDP keepalive messages sent by the mesh group.
SA (Source-Active) In	The number of SA messages received by the mesh group.
SA (Source-Active) Out	The number of SA messages sent by the mesh group.
NOT (Notification) In	The number of notification messages received by the mesh group.
NOT (Notification) out	The number of notification messages sent by the mesh group.
Age	The number of seconds the messages has been in the cache.

Examples The following example shows the mesh-group configuration details.

```
device#show ip msdp mesh-group
Mesh-Group-Name      Peer-IP-Address
group1                40.0.0.40
group2                21.0.0.23
```

The following example shows the details of mesh-group group1.

```
device#show ip msdp mesh-group group1
MSDP MESH-GROUP:group1
KA: Keepalive SA:Source-Active NOT: Notification
Peer Address      State      KA      SA      NOT      Age
      In      Out      In      Out      In      Out
40.0.0.40          ESTABLISH 1407    1406    0        0        0        0        6
```

The following example shows the mesh-group configuration details for the VRF 10 instance.

```
device#show ip msdp vrf 10 mesh-group
Mesh-Group-Name      Peer-IP-Address
group1                22.0.0.22
group2                21.0.0.23
```

The following example shows the mesh-group group2 details for the VRF 10 instance.

```
device#show ip msdp vrf 10 mesh-group group2
MSDP MESH-GROUP:group2
KA: Keepalive SA:Source-Active NOT: Notification
Peer Address      State      KA      SA      NOT      Age
      In      Out      In      Out      In      Out
21.0.0.23          IDLE        0        0        0        0        0        0        0
```

History

Release version	Command history
08.0.20	This command was introduced.

show ip multicast group

Displays information about IGMP groups.

Syntax **show ip multicast** [**cluster**] **group** [*group-address*] [**detail**] [**tracking**]]

- Parameters**
- cluster** Specifies a multi-chassis trunking (MCT) cluster.
 - group-address* Specifies information for a particular group.
 - detail** Specifies detailed IGMP group information for a specific group.
 - tracking** Specifies tracking information on interfaces that have tracking enabled.

Modes Privileged EXEC mode

Command Output The **show ip multicast group** command displays the following information:

Output Field	Description
group	The address of the group (destination address in this case, 224.1.1.1)
p-port	The physical port on which the group membership was received.
ST	Yes indicates that the IGMP group was configured as a static group; No means the address was learned from reports.
QR	Yes means the port is a querier port; No means it is not. A port becomes a non-querier port when it receives a query from a source with a lower source IP address than the device.
life	The number of seconds the group can remain in EXCLUDE mode. An EXCLUDE mode changes to INCLUDE mode if it does not receive an "IS_EX" or "TO_EX" message during a certain period of time. The default is 260 seconds. There is no life displayed in INCLUDE mode.
mode	Indicates current mode of the interface: INCLUDE or EXCLUDE. If the interface is in INCLUDE mode, it admits traffic only from the source list. If an interface is in EXCLUDE mode, it denies traffic from the source list and accepts the rest.
source	Identifies the source list that will be included or excluded on the interface. For example, if an IGMP V2 group is in EXCLUDE mode with a source of 0, the group excludes traffic from the 0 (zero) source list, which actually means that all traffic sources are included.

Examples The following example shows that an IGMP V2 group is in EXCLUDE mode with a source of 0. The group excludes only traffic from the 0 (zero) source list, which means that all traffic sources are included.

```
Device#show ip multicast group
p-:physical, ST:static, QR:querier, EX:exclude, IN:include, Y:yes, N:no
VL70 : 3 groups, 4 group-port, tracking enabled
  group      p-port    ST      QR      life mode    source
1   224.1.1.2    1/33    no      yes     120 EX      0
2   224.1.1.1    1/33    no      yes     120 EX      0
3   226.1.1.1    1/35    yes     yes     100 EX      0
4   226.1.1.1    1/33    yes     yes     100 EX      0
```

The following example displays detailed IGMP group information for multicast group 226.1.1.1:

```
Device#show ip multicast group 226.1.1.1 detail
Display group 226.1.1.1 in all interfaces in details.
p-:physical, ST:static, QR:querier, EX:exclude, IN:include, Y:yes, N:no
VL70 : 1 groups, 2 group-port, tracking enabled
  group      p-port    ST      QR      life mode    source
1   226.1.1.1    1/35    yes     yes     120 EX      0
   group: 226.1.1.1, EX, permit 0 (source, life):
   life=120, deny 0:
  group      p-port    ST      QR      life mode    source
2   226.1.1.1    1/33    yes     yes     120 EX      0
   group: 226.1.1.1, EX, permit 0 (source, life):
   life=120, deny 0:
```

The following example displays the list of clients that belong to multicast group 224.1.1.1 when tracking and fast leave are enabled:

```
Device#show ip multicast group 224.1.1.1 tracking
Display group 224.1.1.1 in all interfaces with tracking enabled.
p-:physical, ST:static, QR:querier, EX:exclude, IN:include, Y:yes, N:no
VL70 : 1 groups, 1 group-port, tracking enabled
  group      p-port    ST      QR      life mode    source
*** Note: has 1 static groups to the entire vlan, not displayed here
1   224.1.1.1    1/33    no      yes     100 EX      0
   receive reports from 1 clients: (age)
   (10.2.100.2 60)
```

The following example displays information for a device in an MCT cluster. In the "local" column, YES indicates that report/leave were received on local ports [cluster-edge ports (CEP) or cluster-client-edge ports (CCEP)]; NO indicates that report/leave were received on a port that is an inter-chassis link (ICL) between the MCT cluster switches, via an MCT peer.

```
Device#show ip multicast cluster group
p-:physical, ST:static, QR:querier, EX:exclude, IN:include, Y:yes, N:no
VL70 : 1 groups, 1 group-port
  group      p-port    ST      QR      life mode    source    local
1   225.1.1.1    e3/10    no      no      260 EX      0        YES
2   230.1.1.2    e3/12    no      yes     40  EX      0        NO
```

History

Release version

Command history

8.0.20

This command was modified to display MCT cluster information.

show ip multicast mcache

Displays information in the multicast forwarding mcache.

Syntax	show ip multicast [cluster] mcache
Parameters	cluster Specifies a multi-chassis trunking (MCT) cluster.
Modes	Privileged EXEC mode
Usage Guidelines	Configuring the show default values command does not show complete output; it shows only IGMP mcache values. The IGMP snooping mcache contains multicast forwarding information for VLANs and you must configure the show ip multicast mcache command to display those.
Command Output	The show ip multicast mcache command displays the following information:

Field	Description
(source group)	Source and group addresses of this data stream. (* group) means match group only; (source group) means match both.
cnt	The number of packets processed in software. Packets are switched in hardware, which increases this number slowly.
OIF	The output interfaces. If <code>entire vlan</code> is displayed, this indicates that static groups apply to the entire VLAN.
age	The mcache age. The mcache will be reset to 0 if traffic continues to arrive, otherwise the mcache will be aged out when it reaches the time defined by the ip multicast mcache-age command.
uptime	The up time of this mcache in seconds.
vidx	Vidx specifies output port list index. Range is from 4096 through 8191.
ref-cnt	The vidx is shared among mcaches having the same output interfaces. Ref-cnt indicates the number of mcaches using this vidx.
ICL	Inter-chassis link between MCT cluster switches.
CCEP	Cluster-client-edge ports (ports on cluster switch connecting it with a cluster client).

Examples The following example shows information in the multicast forwarding mcache:

```
Device#show ip multicast mcache
Example: (S G) cnt=: cnt is number of SW processed packets
        OIF: e1/22 TR(1/32,1/33), TR is trunk, e1/32 primary, e1/33 output
        vlan 10, 1 caches. use 1 VIDX
1      (10.10.10.2 239.0.0.3) cnt=0
        OIF: tag e2
        age=2s up-time=2s change=2s vidx=8191 (ref-cnt=1)
```


The following example shows information in the multicast forwarding mcache when data arrives locally:

```
Device#show ip multicast cluster mcache
Example: (S G) cnt=: (S G) are the lowest 32 bits, cnt is number of SW processed
packets
    OIF: e1/22 TR(e1/32,e1/33), TR is trunk, e1/32 primary, e1/33 output
        [1,10]: [1 - has local oif, 10 - ICL due to CCEP count]

vlan 10, 1 caches. use 1 VIDX
1    (* 225.1.1.3) cnt=52244
    OIF: tag TR(e4/23) [1,0]
    age=167s up-time=11548s, change=58639s vidx=8184 (ref-cnt=1)
```

The following example shows information in the multicast forwarding mcache when data arrives on an MCT peer:

```
Device#show ip multicast cluster mcache
Example: (S G) cnt=: (S G) are the lowest 32 bits, cnt is number of SW processed
packets
    OIF: e1/22 TR(e1/32,e1/33), TR is trunk, e1/32 primary, e1/33 output
        [1,10]: [1 - has local oif, 10 - ICL due to CCEP count]

vlan 10, 1 caches. use 1 VIDX
1    (30.0.0.10 225.1.1.3) cnt=30084
    OIF: tag TR(e3/13) [1,0]
    age=152s up-time=13728s, change=9990s vidx=8184 (ref-cnt=1)
```

History

Release version	Command history
8.0.20	This command was modified to display MCT cluster information.

show ip multicast optimization

Displays Internet Group Management Protocol (IGMP) snooping hardware resource-sharing information.

Syntax **show ip multicast optimization** [*ipmc-num*]

Parameters *ipmc-num*

Specifies the IP multicast (IPMC) group index number.

Modes Privileged EXEC mode
VLAN configuration mode

Usage Guidelines The **show ip multicast optimization** command is available only on the ICX 7250, ICX 7450, and ICX 7750 devices.

Use this command to display the availability of IPMC group indexes in the hardware and how they are used and shared.

The IPMC group index range varies depending on the platform; values out of range are not displayed.

Examples The following example displays resource information showing that IPMC group index 4 is shared by two users and the ports included in the set are 1/1/6 and 1/1/1:

```
Device(config)#vlan 150
Device(config-vlan-150)#show ip multicast optimization
Total IPMCs Allocated:      0; Available: 8192; Failed:      0
Index    IPMC              SetId          Users        Set
  1.       4                0x161fcbd8         2 {<1/1/6>,<1/1/1>,}
  2.       1                0x161d0930        10 {<1/1/6>,<1/1/4>,<1/1/3>,<1/1/2>,<1/1/1>,}
```

History

Release version	Command history
8.0.10	This command was introduced.

show ip multicast pimsm-snooping

Displays information related to PIM sparse mode (SM) snooping on the mcache.

Syntax **show ip multicast pimsm-snooping** [**vlan** *vlan-id*] [**cache** *ip-address*] [**resources**]

Parameters **cache** *ip-address*

Specifies the PIM SM Snooping cache.

vlan *vlan-id*

Specifies snooping for a VLAN.

resources

Specifies PIM SM snooping resources.

Modes Privileged EXEC mode

Usage Guidelines Use the **show ip multicast pimsm-snooping** command to display information related to the PIM SM snooping on the outgoing interface (OIF) in the mcache.

Examples The following example shows PIM SM information for the mcache:

```
Device#show ip multicast pimsm-snooping
Example: Port: 7/3 (ref_count=1)
        ref_count: no of entries in pimsm snoop cache added this oif)

vlan 503, has 1 caches.
1      (* 225.1.1.1) has 3 pim join ports out of 4 OIF
        4/23 (ref_count=2), 4/13 (ref_count=1), 4/5 (ref_count=3),
```

show ip multicast vlan

Displays IGMP snooping information for a specific VLAN.

Syntax **show ip multicast vlan [cluster] *vlan-id***

Parameters **cluster**

Specifies a Multi-Chassis Trunking (MCT) cluster.

vlan-id

Specifies the VLAN for which you want information. If you do not specify a *vlan-id*, information for all VLANs is displayed.

Modes Privileged EXEC mode

Usage Guidelines You can use the **show ip multicast vlan** command to display the querier information for a VLAN. This command displays the VLAN interface status and whether there is any other querier present with the lowest IP address. The following list provides the combinations of querier possibilities:

- Active Interface with no other querier present
- Passive Interface with no other querier present
- Active Interface with other querier present
- Passive Interface with other querier present

Command Output The **show ip multicast vlan** command displays the following information:

Output Field	Description
Version	The global IGMP version.
Query	How often a querier sends a general query on the interface.
Group Age	The number of seconds membership groups can be members of this group before aging out.
Max Resp	The maximum number of seconds a client waits before replying to a query.
Other Qr	How long it took a switch with a lower IP address to become a new querier. This value is 2 x Query + Max Resp.
Unregistered IPv4 Multicast Packets Flooding	Indicates whether flooding is enabled.
cfg	The IGMP version for the specified VLAN.
vlan cfg	The IGMP configuration mode, which is either passive or active.
pimsm	Indicates that PIM SM is enabled on the VLAN.
rtr port	The router ports, which are the ports receiving queries.

Output Field	Description
local	Entries learned on local interfaces of the cluster switch, for example, the local client edge port (CCEP) or cluster edge port (CEP).
mct peer	Entries learned by way of the MCT peer cluster switch. Control messages synchronize by way of the inter-chassis link (ICL) from the MCT peer cluster switch.

Examples The following example shows IGMP snooping information for VLAN 10:

```
Device#show ip multicast vlan 10
Version=3, Intervals: Query=10, Group Age=260, Max Resp=10, Other Qr=30
VL10: cfg V3, vlan cfg passive, , pimsm (vlan cfg), 3 grp, 1 (SG) cache, no rtr port,
    e2      has      3 groups, non-QR (passive), default V3
    **** Warning! has V2 client (life=240),
        group: 239.0.0.3, life = 240
        group: 224.1.1.2, life = 240
        group: 224.1.1.1, life = 240
    e4      has      0 groups, non-QR (passive), default V3
```

The following example shows IGMP snooping information when the VLAN interface is active and no other querier is present with the lowest IP address:

```
Device#show ip multicast vlan 10
Version=2, Intervals: Query=125, Group Age=260, Max Resp=10, Other Qr=260
VL10: dft
    V2, vlan cfg active, 0 grp, 0 (*G) cache, no rtr port,
    1/1/16 has      0 groups,
    This interface is Querier
    default V2
    1/1/24 has      0 groups,
    This interface is Querier
    default V2
    2/1/16 has      0 groups,
    This interface is Querier
    default V2
    2/1/24 has      0 groups,
    This interface is Querier
    default V2
    3/1/1  has      0 groups,
    This interface is Querier
    default V2
    3/1/4  has      0 groups,
    This interface is Querier
    default V2
```

The following example shows IGMP snooping information when the VLAN interface is passive and no other querier is present with the lowest IP address:

```
Device#show ip multicast vlan 10
Version=2, Intervals: Query=125, Group Age=260, Max Resp=10, Other Qr=260
VL10: dft V2, vlan cfg passive, 0 grp, 0 (*G) cache, no rtr port,
    1/1/16 has      0 groups,
    This interface is non-Querier (passive)
    default V2
    1/1/24 has      0 groups,
    This interface is non-Querier (passive)
    default V2
    2/1/16 has      0 groups,
    This interface is non-Querier (passive)
    default V2
    2/1/24 has      0 groups,
    This interface is non-Querier (passive)
    default V2
    3/1/1  has      0 groups,
    This interface is non-Querier (passive)
    default V2
    3/1/4  has      0 groups,
    This interface is non-Querier (passive)
    default V2
```

The following example shows IGMP snooping information when the VLAN interface is active and another querier is present with the lowest IP address:

```
Device#show ip multicast vlan 10
Version=2, Intervals: Query=125, Group Age=260, Max Resp=10, Other Qr=260
VL10: dft V2, vlan cfg active, 7 grp, 6 (*G) cache, rtr ports,
  router ports: 2/1/24(260) 10.5.5.5, 3/1/4(260) 10.8.8.8,
    1/1/16 has 4 groups,
This interface is Querier
default V2
  group: 226.6.6.6, life = 240
  group: 228.8.8.8, life = 240
  group: 230.0.0.0, life = 240
  group: 224.4.4.4, life = 240
    1/1/24 has 1 groups,
This interface is Querier
default V2
  group: 228.8.8.8, life = 240
    2/1/16 has 4 groups,
This interface is Querier
default V2
  group: 226.6.6.6, life = 240
  group: 228.8.8.8, life = 240
  group: 230.0.0.0, life = 240
  group: 224.4.4.4, life = 240
    2/1/24 has 2 groups,
This interface is non-Querier
Querier is 10.5.5.5
Age is 0
Max response time is 100
default V2
  **** Warning! has V3 (age=0) nbrs
  group: 234.4.4.4, life = 260
  group: 226.6.6.6, life = 260
    3/1/1 has 4 groups,
This interface is Querier
default V2
  group: 238.8.8.8, life = 260
  group: 228.8.8.8, life = 260
  group: 230.0.0.0, life = 260
  group: 224.4.4.4, life = 260
    3/1/4 has 1 groups,
This interface is non-Querier
Querier is 10.8.8.8
Age is 0
Max response time is 100
default V2
  **** Warning! has V3 (age=0) nbrs
  group: 236.6.6.6, life = 260
```

The following example shows IGMP snooping information when the VLAN interface is passive and another querier is present with the lowest IP address:

```
Device#show ip multicast vlan 10
Version=2, Intervals: Query=125, Group Age=260, Max Resp=10, Other Qr=260
VL10: dft V2, vlan cfg passive, 7 grp, 6 (*G) cache, rtr ports,
      router ports: 2/1/24(260) 10.5.5.5, 3/1/4(260) 10.8.8.8,
      1/1/16 has 4 groups,
This interface is non-Querier (passive)
default V2
  group: 226.6.6.6, life = 260
  group: 228.8.8.8, life = 260
  group: 230.0.0.0, life = 260
  group: 224.4.4.4, life = 260
  1/1/24 has 1 groups,
This interface is non-Querier (passive)
default V2
  group: 228.8.8.8, life = 260
  2/1/16 has 4 groups,
This interface is non-Querier (passive)
default V2
  group: 226.6.6.6, life = 260
  group: 228.8.8.8, life = 260
  group: 230.0.0.0, life = 260
  group: 224.4.4.4, life = 260
  2/1/24 has 2 groups,
This interface is non-Querier (passive)
Querier is 10.5.5.5
Age is 0
Max response time is 100
default V2
  **** Warning! has V3 (age=0) nbrs
  group: 234.4.4.4, life = 260
  group: 226.6.6.6, life = 260
  3/1/1 has 4 groups,
This interface is non-Querier (passive)
default V2
  group: 238.8.8.8, life = 260
  group: 228.8.8.8, life = 260
  group: 230.0.0.0, life = 260
  group: 224.4.4.4, life = 260
  3/1/4 has 1 groups,
This interface is non-Querier (passive)
Querier is 10.8.8.8
Age is 0
Max response time is 100
default V2
  **** Warning! has V3 (age=0) nbrs
  group: 236.6.6.6, life = 260
```

The following example shows IGMP snooping information when the device is connected to an MCT cluster:

```
Device#show ip multicast cluster vlan 10
Version=2, Intervals: Query=125, Group Age=260, Max Resp=10, Other Qr=255
VL10: dft V2, vlan cfg passive, 0 grp, 0 (*G) cache, rtr ports,
      router ports: e4/14(65) 50.0.0.1 (local:1, mct peer:0)

(local:1, mct peer:0)    <- Indicates if entry is local or\and mct-peer entry
```

The following example shows IGMP snooping information when flooding of unregistered IPv4 multicast frames is disabled:

```
Device#show ip multicast vlan
Summary of all vlans. Please use "sh ip mu vlan <vlan-id>" for details
Version=2, Intervals: Query=125, Group Age=260, Max Resp=10, Other Qr=255

Unregistered IPv4 Multicast Packets Flooding: Disabled.

VL500: dft V2, vlan cfg active, 0 grp, 0 (*G) cache, no rtr port,
VL600 no snoop: no global or local config
```

History	Release version	Command history
	8.0.20	This command was modified to display MCT cluster information.
	8.0.30	This command was modified to display flooding information.

show ip ospf interface

Displays information about all or specific OSPF-enabled interfaces.

Syntax **show ip ospf interface** [*ip address*] [**brief**] [**ethernet mappedID/slot/port**] [**loopback number**] [**tunnel number**] [**ve vlan_id**]

Parameters *ip address*

Specifies interface IP address in dotted decimal format.

brief

Displays brief summary information about the specified interface.

ethernet mappedID/slot/port

Specifies an Ethernet interface. On standalone devices specify the interface ID in the format slot/port-id; on stacked devices you must also specify the stack ID, in the format stack-id/slot/port-id.

loopback number

Specifies a loopback port number in the range of 1 to 255.

tunnel number

Specifies a tunnel interface.

ve vlan_id

Specifies the VLAN number.

Modes Privileged EXEC mode

Usage Guidelines Use the **brief** keyword to limit the display to the following fields:

- Interface
- Area
- IP address
- Cost
- State
- Nbrs(F/C)

Command Output The **show ip ospf interface** command displays the following information:

This field	Displays
Interface	The type of interface type and the port number or number of the interface.
IP Address	The IP address of the interface.
Area	The OSPF area configured on the interface
Database Filter	The router's configuration for blocking outbound LSAs on an OSPF interface. If Not Configured is displayed, there is no outbound LSA filter configured. This is the default condition.

This field	Displays
State	<p>The state of the interface. Possible states include the following:</p> <ul style="list-style-type: none"> • DR - The interface is functioning as the Designated Router for OSPFv2. • BDR - The interface is functioning as the Backup Designated Router for OSPFv2. • Loopback - The interface is functioning as a loopback interface. • P2P - The interface is functioning as a point-to-point interface. • Passive - The interface is up but it does not take part in forming an adjacency. • Waiting - The interface is trying to determine the identity of the BDR for the network. • None - The interface does not take part in the OSPF interface state machine. • Down - The interface is unusable. No protocol traffic can be sent or received on such a interface. • DR other - The interface is a broadcast or NBMA network on which another router is selected to be the DR. • Active - The interface sends or receives all the OSPFv2 control packets and forms the adjacency.
default	Shows whether or not the default passive state is set.
Pri	The interface priority.
Cost	The configured output cost for the interface.
Interface bandwidth	The configured bandwidth on a tunnel interface for routing metric purposes only.
Options	<p>OSPF Options (Bit7 - Bit0):</p> <ul style="list-style-type: none"> • unused:1 • opaque:1 • summary:1 • dont_propagate:1 • nssa:1 • multicast:1 • external route capable:1 • tos:1
Type	<p>The area type, which can be one of the following:</p> <ul style="list-style-type: none"> • Broadcast • Point to Point • non-broadcast • Virtual Link

This field	Displays
Events	OSPF Interface Event: <ul style="list-style-type: none"> • Interface_Up = 0x00 • Wait_Timer = 0x01 • Backup_Seen = 0x02 • Neighbor_Change = 0x03 • Loop_Indication = 0x04 • Unloop_Indication = 0x05 • Interface_Down = 0x06 • Interface_Passive = 0x07
Timer intervals	The interval, in seconds, of the transmit-interval, retransmit-interval, hello-interval, and dead-interval timers.
DR	The router ID (IPv4 address) of the DR.
BDR	The router ID (IPv4 address) of the BDR.
Neighbor Count	The number of neighbors to which the interface is connected.
Adjacent Neighbor Count	The number of adjacent neighbor routers.
Neighbor:	The IP address of the neighbor.

Examples This example shows sample output from the **show ip ospf interface** command when the **brief** keyword is used.

```
device# # show ip ospf interface brief
Number of Interfaces is 1
Interface Area IP Addr/Mask Cost State Nbrs(F/C)
eth 1/2      0    16.1.1.2/24   1    down  0/0
```

This example displays information about a specified OSPF-enabled VE interface.

```
device# show ip ospf interface ve 20

ve 20  admin up, oper up, ospf enabled, state up
      IP Address 21.21.21.22, Area 0
      Database Filter: Not Configured
      State BDR, Pri 1, Cost 1, Options 2, Type broadcast Events 31
      Timers(sec): Transmit 1, Retrans 5, Hello 10, Dead 40
      DR:  Router ID 3.3.3.3           Interface Address 21.21.21.21
      BDR: Router ID 2.2.2.2           Interface Address 21.21.21.22
                Packets Received      Packets Sent
      Hello                        86374                86735
      Database                      2                  4
      LSA Req                       1                  0
      LSA Upd                      451                907
      LSA Ack                      906                451
      No Packet Errors!
      Neighbor Count = 1, Adjacent Neighbor Count= 1
      Neighbor:      21.21.21.21 [id 3.3.3.3] (DR)
      Authentication-Key: None
      MD5 Authentication: Key None, Key-Id None, Auth-change-wait-time 300
```

This example displays information about a specified OSPF-enabled Ethernet interface, including the cost, where the cost is calculated using the default interface speed and auto cost.

```
device# show ip ospf interface ethernet 3/1/1
e 3/1/1 admin up, oper up, ospf enabled, state up
IP Address 89.0.0.2, Area 0
Database Filter: Not Configured
State BDR, Pri 1, Cost 1, Options 2, Type broadcast Events 3
```

This example displays information about a specified OSPF-enabled Ethernet interface, including the cost, which has been calculated using the configured interface bandwidth and the default auto-cost.

```
device# show ip ospf interface ethernet 1/1/3
e 1/1/3 admin up, oper up, ospf enabled, state up
IP Address 172.201.3.2, Area 0
Database Filter: Not Configured
State DR, Pri 1, Cost 34, Options 2, Type broadcast Events 5
Timers(sec): Transmit 1, Retrans 5, Hello 10, Dead 40
DR: Router ID 192.168.3.1      Interface Address 172.201.3.2
BDR: Router ID 192.168.1.1    Interface Address 172.201.3.1
      Packets Received      Packets Sent
Hello                73                79
Database              3                 2
LSA Req               0                 1
LSA Upd               4                 5
LSA Ack               5                 3
No Packet Errors!
Neighbor Count = 1, Adjacent Neighbor Count= 1
Neighbor:      172.201.3.1 [id 192.168.1.1] (BDR)
Authentication-Key: None
MD5 Authentication: Key None, Key-Id None, Auth-change-wait-time 300
```

History	Release version	Command history
	8.0.30	This command was modified to include configured bandwidth status.

show ip pim interface

Displays information for PIM interfaces.

Syntax `show ip pim interface { ethernet stack-id/slot/port-id | loopback loopback-number | ve ve-number }`

Parameters `ethernet stack-id/slot/port-id`

Specifies a physical interface. On standalone devices specify the interface ID in the format slot/port-id; on stacked devices you must also specify the stack ID, in the format stack-id/slot/port-id.

`loopback loopback-number`

Specifies a loopback interface.

`ve ve-number`

Specifies a virtual interface.

Modes Privileged EXEC mode

Examples This example displays output from the **show ip pim interface** command, showing that ACL 10 is applied to interface 1/1/9 to control neighbor access.

```
Device# show ip pim interface
```

```
Flags      : SM - Sparse Mode v2, DM - Dense Mode v2, P - Passive Mode
```

```
-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+
Int'face|Local      |Mode|St|Des Rtr|TTL|Mcast|Filter|VRF  |DR  |Override
      |Address    |    |  |AddPort|Thr|Bndry|ACL   |    |    |Prio|Interval
-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+
e1/1/1  5.5.5.5      SM  Ena  Itself  1  None  None  default  1  3000ms
e1/1/9  15.1.1.5      SM  Ena  Itself  1  None  10   default  1  3000ms
e1/1/12 12.12.12.1     SM  Dis  Itself  1  None  None  default  1  3000ms
v20     21.21.21.22  SM  Ena  Itself  1  None  None  default  1  3000ms
v60     60.60.60.1  SM  Ena  Itself  1  None  None  default  1  3000ms
v310    110.110.110.2 SM  Dis  Itself  1  None  None  default  1  3000ms
v360    160.160.160.1 SM  Dis  Itself  1  None  None  default  1  3000ms
l2      4.4.4.4      SM  Ena  Itself  1  None  None  default  1  3000ms
l3      10.10.10.10 SM  Ena  Itself  1  None  None  default  1  3000ms
Total Number of Interfaces : 9
```

History

Release version

Command history

8.0.20a

This command was modified to display neighbor filter information.

show ip pim mcache

Displays the PIM multicast cache.

Syntax	show ip pim [vrf <i>vrf-name</i>] mcache [<i>source-address</i> <i>group-address</i> counts dense [dit-idx <i>dit-idx</i> g_entries receiver sg_entries sparse ssm]
Parameters	<p>vrf <i>vrf-name</i> Specifies information for a VRF instance.</p> <p><i>source-address</i> Specifies the multicast cache source address.</p> <p><i>group-address</i> Specifies the multicast cache group address.</p> <p>counts Specifies the number of entries.</p> <p>dense Specifies displaying only the PIM Dense Mode entries.</p> <p>dit-idx <i>dit-idx</i> Specifies displaying all entries that match a specified downstream interface (DIT).</p> <p>g_entries Specifies displaying only the (*, G) entries.</p> <p>receiver Specifies displaying all entries that egress a specified interface.</p> <p>sg_entries Specifies displaying only the (S, G) entries.</p> <p>sparse Specifies displaying only the PIM Sparse Mode entries.</p> <p>ssm Specifies displaying only the SSM entries.</p>
Modes	Privileged EXEC mode
Command Output	The show ip pim mcache command displays the following information:

Output Field	Description
Total entries in mcache	The total number of PIM mcache entries
MJ	Membership Join
MI	Membership Include
ME	Membership Exclude - Legend for the mcache entry printed once per page, it gives the explanation of each of the flags used in the entry.
BR	Blocked RPT
BA	Blocked Assert

Output Field	Description
BF	Blocked Filter
BI	Blocked IIF
Uptime	Shows the entry uptime
Rate	Shows the Rate at which packets are ingressing for this entry
upstream neighbor	Shows the upstream neighbor for the Source/RP based on the type of entry. For (*,G) it shows the upstream neighbor towards the RP. For (S,G) entries it shows the upstream neighbor towards the source.
Flags	<p>Flags Represent Entry flags in hex format in the braces. And indicates the meaning of the flags set in abbreviated string whose explanations are as below. Only shows the flags which are set.</p> <p>SM - Shows If the entry is created by PIM Sparse Mode</p> <p>DM - Shows If DM mode entry is enabled</p> <p>SSM - Shows If the SSM mode entry is enabled</p> <p>RPT - Shows If the entry is on the rendezvous point (RP)</p> <p>SPT - Shows If the entry is on the source tree</p> <p>LSRC - Shows If the source is in a directly-connected interface</p> <p>LRcv - Shows If the receiver is directly connected to the router</p> <p>REG - if the data registration is in progress</p> <p>L2REG - if the source is directly connected to the router</p> <p>REGSUPP - if the register suppression timer is running</p> <p>RegProbe</p> <p>HW - Shows If the candidate for hardware forwarding is enabled</p> <p>FAST - Shows If the resources are allocated for hardware forwarding</p> <p>TAG - Shows If there is a need for allocating entries from the replication table</p> <p>MSDPADV - Shows If RP is responsible for the source and must be advertised to its peers.</p> <p>NEEDRTE - Shows If there is no route to the source and RP is available</p> <p>PRUNE - Shows If PIM DM Prune to upstream is required</p>
RP	Shows the IP address of the RP.
fast ports	Shows forwarding port mask.
AgeSttMsk	Shows a value of 1 if the entry is programmed in hardware, and a value of 0 if it is not programmed in hardware.
L2 FID	Shows the hardware resource allocated for the traffic switched to receivers in the ingress VLAN.

Output Field	Description
DIT	Shows the hardware resource allocated for routed receivers.
RegPkt	Shows Count of Packets forwarded due to the Register decapsulation.
AvgRate	Shows the average Rate of packets ingressing for this entry over 30 seconds.
Profile	Shows the Profile ID associated with the Stream.
Number of matching entries	Shows the total number of mcache entries matching a particular multicast filter specified.
Outgoing interfaces Section	<p>This section consists of three parts. L3 OIFs, L2OIFs and Blocked OIFs. And each section has Format of L3/L2/Blocked followed by (HW/SW) followed by count of the number of OIF in each section.</p> <p>Additionally, each section displays the OIFs one per line. And shows the OIF in the format eth/Tr(Vlan) followed by uptime/expiry time, followed by the Flags associated with each OIF.</p>
L3	Shows whether the traffic is routed out of the interface.
L2	Shows whether the traffic is switched out of the interface.
HW	Shows whether the entry is hardware forwarded.
SW	Shows whether the entry is software forwarded
Eth/Tr(VL1)	Shows the outgoing interface on the specified VLAN.
Flags (explanation of flags in the OIF section)	<p>Shows the flags set in each of the Outgoing interface in abbreviated string format whose explanations are as below. Legend of this shown at the top of each entry</p> <p>IM - Immediate</p> <p>IH - Inherited</p> <p>MJ - Membership Join</p> <p>MI - Membership Include</p> <p>ME - Membership Exclude</p> <p>BR - Blocked due to SG RPT</p> <p>BA - Blocked due to Assert</p> <p>BF - Blocked due to Filter</p> <p>BI - Blocked IIF (Incoming interface) matches OIF</p>
Src-Vlan	Shows the VLAN associated with the ingress interface.
MCTPEERF - Traffic Forw By Cluster Peer CCEP	Applies only to Layer 3 multicast routing over MCT. This means multicast traffic for this stream is forwarded by cluster peer [remote] CCEP port because of flow load balancing

Examples This example shows all PIM multicast cache entries:

```
Brocade(config)# show ip pim mcache
IP Multicast Mcache Table
Entry Flags : SM - Sparse Mode, SSM - Source Specific Multicast, DM - Dense Mode
              RPT - RPT Bit, SPT - SPT Bit, LSRC - Local Source, LRCV - Local Receiver
              HW - HW Forwarding Enabled, FAST - Resource Allocated, TAG - Need For
                Replication Entry
              REGPROB - Register In Progress, REGSUPP - Register Suppression Timer
              MSDPADV - Advertise MSDP, NEEDRTE - Route Required for Src/RP, PRUN - DM
                Prune Upstream
Interface Flags: IM - Immediate, IH - Inherited, WA - Won Assert
              MJ - Membership Join, MI - Membership Include, ME - Membership Exclude
              BR - Blocked RPT, BA - Blocked Assert, BF - Blocked Filter, BI - Blocked IIF
Total entries in mcache: 20
1 (140.140.140.3, 225.0.0.1) in v340 (tag e8/1), Uptime 00:00:02 Rate 0 (DM)
  Source is directly connected
  Flags (0x200004e1) DM HW FAST TAG
  fast ports: ethe 4/6 ethe 8/26
  AgeSltMsk: 1, L2 FID: 8188, DIT: 3 , AvgRate: 0, profile: none
  Forwarding_oif: 2
  L3 (HW) 2:
    TR(e4/6,e4/6) (VL330), 00:00:02/0, Flags: IM
    e8/26(VL310), 00:00:02/0, Flags: IM
  Src-Vlan: 340
```

This example shows the PIM multicast cache for the specified address:

```
Device(config)# show ip pim mcache 10.140.140.14 230.1.1.9
IP Multicast Mcache Table
Entry Flags : SM - Sparse Mode, SSM - Source Specific Multicast, DM - Dense Mode
              RPT - RPT Bit, SPT - SPT Bit, LSRC - Local Source, LRCV - Local Receiver
              HW - HW Forwarding Enabled, FAST - Resource Allocated, TAG - Need For
                Replication Entry
              REGPROB - Register In Progress, REGSUPP - Register Suppression Timer
              MSDPADV - Advertise MSDP, NEEDRTE - Route Required for Src/RP, PRUN - DM Prune
                Upstream
Interface Flags: IM - Immediate, IH - Inherited, WA - Won Assert
              MJ - Membership Join, MI - Membership Include, ME - Membership Exclude
              BR - Blocked RPT, BA - Blocked Assert, BF - Blocked Filter, BI - Blocked IIF
Total entries in mcache: 20
1 (10.140.140.14, 230.1.1.9) in v1001 (tag e4/29), Uptime 00:03:12, Rate 0 (SM)
  upstream neighbor 10.11.11.13
  Flags (0x600680e1) SM SPT LRCV HW FAST TAG
  fast ports: ethe 4/29 ethe 5/2
  AgeSltMsk: 1, L2 FID: 8188, DIT: 8 , AvgRate: 0, profile: none
  Forwarding_oif: 3, Immediate_oif: 0, Blocked_oif: 0
  L3 (HW) 2:
    e4/29(VL13), 00:03:12/0, Flags: MJ
    e5/2(VL1004), 00:03:12/0, Flags: MJ
  L2 (HW) 1:
    e5/2, 00:00:07/0, Flags: MJ
  L2 MASK: ethe 5/2
  Src-Vlan: 1001
```

This example shows the PIM multicast cache for the specified DIT:

```
Device#show ip pim mcache dit-idx 2
IP Multicast Mcache Table
Entry Flags      : SM - Sparse Mode, SSM - Source Specific Multicast, DM - Dense Mode
                  RPT - RPT Bit, SPT - SPT Bit, LSRC - Local Source, LRCV - Local
Receiver
                  HW - HW Forwarding Enabled, FAST - Resource Allocated, TAG - Need
For Replication Entry
                  REGPROB - Register In Progress, REGSUPP - Register Suppression Timer
                  MSDPADV - Advertise MSDP, NEEDRTE - Route Required for Src/RP, PRUN
- DM Prune Upstream
Interface Flags: IM - Immediate, IH - Inherited, WA - Won Assert
                  MJ - Membership Join, MI - Membership Include, ME - Membership
Exclude
                  BR - Blocked RPT, BA - Blocked Assert, BF - Blocked Filter, BI -
Blocked IIF
Total entries in mcache: 30
1  (20.20.20.100, 225.1.1.1) in v220 (tag e1/1/13), Uptime 07:12:07, Rate 0 (SM)
   upstream neighbor 220.220.220.1
   Flags (0x200680e1) SM SPT LRCV HW FAST TAG
   fast ports: ethe 1/1/11
   AgeSltMsk: 1, L2 FID: 105c, DIT:      2 , AvgRate: 0, profile: none
   Forwarding_oif: 1, Immediate_oif: 0, Blocked_oif: 0
   L3 (HW) 1:
     e1/1/11(VL40), 07:12:07/0, Flags: MJ
   Src-Vlan: 220
2  (20.20.20.100, 225.1.1.2) in v220 (tag e1/1/13), Uptime 00:01:00, Rate 0 (SM)
   upstream neighbor 220.220.220.1
   Flags (0x200680e1) SM SPT LRCV HW FAST TAG
   fast ports: ethe 1/1/11
   AgeSltMsk: 1, L2 FID: 105c, DIT:      2 , AvgRate: 0, profile: none
   Forwarding_oif: 1, Immediate_oif: 0, Blocked_oif: 0
   L3 (HW) 1:
     e1/1/11(VL40), 00:01:00/0, Flags: MJ
   Src-Vlan: 220
3  (20.20.20.100, 225.1.1.3) in v220 (tag e1/1/13), Uptime 00:01:00, Rate 0 (SM)
   upstream neighbor 220.220.220.1
   Flags (0x200680e1) SM SPT LRCV HW FAST TAG
   fast ports: ethe 1/1/11
   AgeSltMsk: 1, L2 FID: 105c, DIT:      2 , AvgRate: 0, profile: none
   Forwarding_oif: 1, Immediate_oif: 0, Blocked_oif: 0
   L3 (HW) 1:
     e1/1/11(VL40), 00:01:00/0, Flags: MJ
   Src-Vlan: 220
```

This example shows the PIM multicast cache with Layer 3 multicast routing over MCT, showing that multicast traffic for a stream is forwarded by a cluster peer CCEP port because of flow load balancing.

```
Device#show ip pim mcache
IP Multicast Mcache Table
Entry Flags      : SM - Sparse Mode, SSM - Source Specific Multicast, DM - Dense Mode
                  RPT - RPT Bit, SPT - SPT Bit, LSRC - Local Source, LRCV - Local
Receiver
                  HW - HW Forwarding Enabled, FAST - Resource Allocated, TAG - Need
For Replication Entry
                  REGPROB - Register In Progress, REGSUPP - Register Suppression Timer
                  MSDPADV - Advertise MSDP, NEEDRTE - Route Required for Src/RP, PRUN
- DM Prune Upstream
Interface Flags: IM - Immediate, IH - Inherited, WA - Won Assert, MCTPEERF - Traffic
Forw By Cluster Peer CCEP
                  MJ - Membership Join, MI - Membership Include, ME - Membership
Exclude
                  BR - Blocked RPT, BA - Blocked Assert, BF - Blocked Filter, BI -
Blocked IIF
Total entries in mcache: 2
1  (39.39.39.1, 229.1.1.10) in v40 (tag e2/1/12), Uptime 00:21:31, Rate 0 (SM)
   upstream neighbor 40.40.40.175
   Flags (0x200284e1) SM SPT HW FAST TAG
   fast ports: ethe 2/1/11
   AgeSltMsk: 1, IPMC:      4 , AvgRate: 0, profile: none
   Forwarding_oif: 1, Immediate_oif: 1, Blocked_oif: 0
   L3 (HW) 1:
     TR(e2/1/11,e2/1/11) (VL10), 00:21:31/178, Flags: IM MCTPEERF
   Src-Vlan: 40
```

History	Release version	Command history
	8.0.30	This command was modified to show output for Layer 3 multicast routing over MCT.

show ip pim traffic

Displays IPv4 PIM traffic statistics.

Syntax	show ip pim traffic [vrf <i>vrf-name</i>] [join-prune] [rx tx]		
Parameters	vrf <i>vrf-name</i>	Specifies information for a VRF instance.	
	join-prune	Specifies displaying join and prune statistics.	
	rx	Specifies displaying received PIM traffic statistics.	
	tx	Specifies displaying transmitted PIM traffic statistics.	
Modes	Privileged EXEC mode		
Usage Guidelines	PIM control packet statistics for interfaces that are configured for standard PIM are listed first by the display.		
Command Output	The show ip pim traffic command displays the following information:		

Output Field	Description
Port	The port or virtual interface on which the PIM interface is configured.
HELLO	The number of PIM Hello messages sent or received on the interface.
JOIN-PRUNE	The number of Join or Prune messages sent or received on the interface.
NOTE Unlike PIM Dense, PIM Sparse uses the same messages for Joins and Prunes.	
ASSERT	The number of Assert messages sent or received on the interface.
REGISTER GRAFT (DM)	The number of Register messages sent or received on the interface.
REGISTER STOP (SM)	The number of Register Stop messages sent or received on the interface.
BOOTSTRAP MSGS (SM)	The number of bootstrap messages sent or received on the interface.
CAND. RP ADV. (SM)	The total number of Candidate-RP-Advertisement messages sent or received on the interface.
Err	The total number of messages discarded, including a separate counter for those that failed the checksum comparison.

Examples This example shows PIM join and prune traffic statistics for received and sent packets:

```
Device(config)#show ip pim traffic
Port    HELLO    JOIN-PRUNE  ASSERT    REGISTER    REGISTER    BOOTSTRAP CAND. RP  Err
          GRAFT(DM) STOP(SM)  MSGS (SM) ADV. (SM)

-----+-----+-----+-----+-----+-----+-----+-----+-----+
Rx      Rx      Rx      Rx      Rx      Rx      Rx      Rx      Rx
-----+-----+-----+-----+-----+-----+-----+-----+
v30      0          0          0          0          0          0          0          0
v50    2526      1260          0          0          0      1263          0          0
v150    2531          0          0          0          0      1263          0          0
v200    2531          0          0          0          0          1          0          0
Port    HELLO    JOIN-PRUNE  ASSERT    REGISTER    REGISTER    BOOTSTRAP CAND. RP  Err
          GRAFT(DM) STOP(SM)  MSGS (SM) ADV. (SM)

-----+-----+-----+-----+-----+-----+-----+-----+
Tx      Tx      Tx      Tx      Tx      Tx      Tx      Tx      Tx
-----+-----+-----+-----+-----+-----+-----+-----+
v30    2528          0          0          0          0          0          0          0
v50      0      1263          0          0          0          2          0          0
v150    2529          0          0          0          0      1262          0          0
v200    2529          0          0          0          0      1262          0          0
```

This example shows the number of received IPv4 PIM Hello packets dropped on interface 1/1/9 because an ACL to control neighbor access is configured on it.

```
Device#show ip pim traffic rx
Port    HLO    JN-PRNE  ASSERT  REG    REG    BTSTRP    CAND RP  Err
          GRAFT(DM) STOP(SM)  MSGS(SM) ADV. (SM)

-----+-----+-----+-----+-----+-----+-----+-----+
Rx      Rx      Rx      Rx      Rx      Rx      Rx      Rx      Rx
-----+-----+-----+-----+-----+-----+-----+-----+
e1/1/1    0          0          0          0          0          0          0          0
e1/1/9    764          0          0          0          0          0      757
e1/1/12    0          0          0          0          0          0          0          0
v20      758          0          0      1916          0          0          0          0
v60          0          0          0          0          0          0          0          0
v310          0          0          0          0          0          0          0          0
v360          0          0          0          0          0          0          0          0
```

This example shows PIM join and prune traffic statistics for sent packets:

```
Device(config)#show ip pim traffic tx
Port    HELLO    JOIN-PRUNE  ASSERT    REGISTER    REGISTER    BOOTSTRAP CAND. RP  Err
          GRAFT(DM) STOP(SM)  MSGS (SM) ADV. (SM)

-----+-----+-----+-----+-----+-----+-----+-----+
Tx      Tx      Tx      Tx      Tx      Tx      Tx      Tx      Tx
-----+-----+-----+-----+-----+-----+-----+-----+
v30    2528          0          0          0          0          0          0          0
v50    2540      1263          0          0          0          2          0          0
v150    2529          0          0          0          0      1262          0          0
v200    2530          0          0          0          0      1262          0          0
```

This example shows PIM join and prune traffic statistics.

```
Device(config)#show ip pim traffic join-prune
Port    Packet    Join    Prune    Avg Aggr    Last Aggr
-----+-----+-----+-----+-----+-----+
Rx      Rx      Rx      Rx      Rx
-----+-----+-----+-----+-----+
v30      0          0          0          0          0
v50    1260      1260          0          1          1
v150      0          0          0          0          0
v200      0          0          0          0          0
Port    Packet    Join    Prune    Avg Aggr    Last Aggr
-----+-----+-----+-----+-----+
Tx      Tx      Tx      Tx      Tx
-----+-----+-----+-----+-----+
v30      0          0          0          0          0
v50    1263      1262          1          1          1
v150      0          0          0          0          0
v200      0          0          0          0          0
```

This example shows PIM join and prune traffic statistics.

Device(config)#show ip pim traffic join-prune rx					
Port	Packet	Join	Prune	Avg Aggr	Last Aggr
-----+-----+-----+-----+-----+-----					
	Rx	Rx	Rx	Rx	Rx
-----+-----+-----+-----+-----+-----					
v30	0	0	0	0	0
v50	1260	1260	0	1	1
v150	0	0	0	0	0
v200	0	0	0	0	0

This example shows PIM join and prune traffic statistics.

Device(config)#show ip pim traffic join-prune tx					
Port	Packet	Join	Prune	Avg Aggr	Last Aggr
-----+-----+-----+-----+-----+-----					
	Tx	Tx	Tx	Tx	Tx
-----+-----+-----+-----+-----+-----					
v30	0	0	0	0	0
v50	1264	1263	1	1	1
v150	0	0	0	0	0
v200	0	0	0	0	0

History	Release version	Command history
	8.0.20a	This command was modified to display, in the Err column, received Hello packets dropped on an interface because of an ACL to control neighbor access.

show ip pimsm-snooping cache

Displays the downstream PIM join/prune information for both source-path tree (SPT) and rendezvous-point tree (RPT).

Syntax **show ip pimsm-snooping cache** [**vlan** *vlan-id*] *ip-address* [**resources**]

Parameters *ip-address* Specifies the IP address.

vlan *vlan-id* Specifies snooping for a VLAN.

resources Specifies PIM SM snooping resources.

Modes Privileged EXEC mode

Usage Guidelines Use the **show ip pimsm-snooping cache** command to check and verify the outgoing interfaces (OIF)s added by pimsm-snooping module.

Command Output The **show ip pimsm-snooping cache** command displays the following information:

Output field	Description
SG	(s,g) downstream fsm state for SPT.
G	(*,g) downstream fsm state for RPT

The **show ip pimsm-snooping cache** command displays the following information only when multi-chassis trunking (MCT) is enabled on the VLAN:

Output field	Description
CCEP	Cluster client edge port
CEP	Cluster edge port
Remote/Local	Join/Prune received on MCT peer or local

Examples The following example shows PIM SM information when there is no traffic and the last-hop router (LHR) has joined the RPT. Only an (*,G) entry is created.

```

Device1#show ip pimsm-snooping cache
OIF Info:
TR - OIF Belongs to Trunk/LAG, Primary port is displayed
SG - (*,g)/(s,g) downstream fsm state:
    NI : No Info, J : Join, PP : Prune Pending, CLEAN : cleanup in progress
RPT - (s,g,rpt) downstream fsm state:
    NI : No Info, P : Pruned, PP : Prune Pending, Px : Temp step in (*,G)
    join processing, PPx : Temp State in (*,G) processing, CLEAN : cleanup
    in progress.

PIMSM Snoop cache for vlan 503
1 (* 225.1.1.1) Up Time: 5d 18:38:32
OIFs: 2
TR(e4/5) G : J(197) ET: 210, Up Time: 5d 18:38:32 , CCEP, Remote
TR(e4/23) G : J(166) ET: 210, Up Time: 1d 19:36:23 , CEP, Local

```

The following example shows PIM SM information when there is traffic from source 30.0.0.10. An (S,G) entry is created and the LHR has joined the SPT.

```
Device2#show ip pimsm-snooping cache
OIF Info:
TR - OIF Belongs to Trunk/LAG, Primary port is displayed
SG - (*,g)/(s,g) downstream fsm state:
    NI : No Info, J : Join, PP : Prune Pending, CLEAN : cleanup in progress
RPT - (s,g,rpt) downstream fsm state:
    NI : No Info, P : Pruned, PP : Prune Pending, Px : Temp step in (*,G)
    join processing, PPx : Temp State in (*,G) processing, CLEAN : cleanup
    in progress.

1    (* 225.1.1.1) Up Time: 5d 18:44:28
    OIFs: 2
    TR(e4/5) G : J(195) ET: 210, Up Time: 5d 18:44:28 , CCEP, Remote
    TR(e4/23) G : J(170) ET: 210, Up Time: 1d 19:42:18 , CEP, Local

2    (30.0.0.10 225.1.1.1) Up Time: 00:00:58
    OIFs: 2
    TR(e4/5) SG : J(202) ET: 210, Up Time: 00:00:58 , CCEP, Remote
    TR(e4/23) SG : J(168) ET: 210, Up Time: 00:00:58 , CEP, Local
```

The following example shows PIM SM resource information.

```
Device#show ip pimsm-snooping resources
          alloc in-use  avail get-fail    limit  get-mem  size init
pimsm group entry      1000    10    990         0   232000    10   61 1000
pimsm source entry     2000    20   1980         0  464000    40   65 2000
pimsm oif entry        2000    30   1970         0  464000    59   89 2000

Total memory in used: 369000 bytes
```


show ip reverse-path-check

Displays the global unicast Reverse Path Forwarding settings.

Syntax **show ip reverse-path-check**

Modes Privileged EXEC mode

Command Output The **show ip reverse-path-check** command displays the following information.

Output field	Description
CLI config	The command line configured on the device after device boot-up.
Current state	The mode set during device boot-up. This takes effect only after reload.

Examples The following example shows the global uRPF settings on ICX 6610 devices.

```
device# show ip reverse-path-check
Global uRPF Settings:
CLI config : Strict mode
Current State : Strict mode
```

The following example shows the global uRPF settings on ICX 7750 devices.

```
device# show ip reverse-path-check
Global uRPF Settings:
CLI config : Enabled
Current State : Enabled
```

History	Release version	Command history
	08.0.30	This command was introduced.

show ip reverse-path-check interface

Displays unicast Reverse Path Forwarding settings at the interface level on ICX 7750 devices.

Syntax **show ip reverse-path-check interface**

Modes Privileged EXEC mode

Usage Guidelines Use this command to display the interface level Unicast Reverse Path Forward settings such as the uRPF mode and whether uRPF is exclude default. Use the **show ip interface ethernet** command to view details about the interface level rpf-mode configuration.

Examples The following example shows the interface level uRPF settings on ICX 7750 devices.

```
device# show ip reverse-path-check interface
-----
Interface                uRPF mode                uRPF Exclude default
-----
Eth 1/1/11                Strict                    No
```

History	Release version	Command history
	08.0.30	This command was introduced.

show ip ssl

Displays SSL connection details.

Syntax **show ip ssl certificate**

Parameters **certificate**

Displays the SSL certificate details.

Modes Privileged EXEC mode

Global configuration mode

Examples The following example displays the output of the **show ip ssl** command.

```
device(config)#show ip ssl
Session Protocol Source IP      Source Port  Remote IP      Remote Port
1          TLS_1_2  10.20.157.102  634          10.25.105.201  60892
```

The following example displays the SSL certificate details.

```
device(config)#show ip ssl certificate
Trusted Certificates:
  Dynamic:
  Index 0:
    Signature Algorithm: sha256WithRSAEncryption
    Issuer:
      CN: 10.25.105.201
    Validity:
      Not Before: 2014 Aug 22 05:12:45
      Not After : 2017 Aug 21 05:12:45
    Subject:
      CN: 10.25.105.201
  X509v3 extensions:
    X509v3 Subject Alternative Name:
      IP Address: 10.25.105.201
  Signature:
    12:ec:41:d8:01:45:61:ce:cf:7e:80:de:a6:7c:a7:2e:01:7f:
    42:27:22:1d:ac:a2:47:c5:0d:4f:e3:68:24:de:bf:50:40:65:
    25:8c:30:bd:ff:a7:d0:21:73:d2:ba:5e:67:42:1f:bb:97:4a:
    d9:1d:c3:ca:31:c4:59:10:79:d1:42:f4:b6:1a:b0:98:4e:a8:
    ef:e2:a2:98:c3:14:16:63:50:02:a0:18:9c:7a:e3:17:39:0d:
    b7:30:ab:23:9f:63:bd:0f:9e:d8:67:b0:fe:ec:3b:fa:4c:f4:
    3d:34:e2:99:0e:99:24:ec:93:fb:8a:e5:4a:bf:74:d6:ff:91:
    0a:dc:fb:b9:4f:91:5d:d4:f6:77:23:eb:ec:eb:3a:62:08:e1:
    a6:ea:a8:52:b6:39:62:db:29:fa:61:1d:fd:d5:02:31:04:73:
    50:ad:de:41:54:a5:e2:96:2d:9c:f4:68:b2:68:05:bb:39:47:
    ee:74:89:a2:8c:30:f0:f9:d7:d5:4b:3b:e2:95:6f:82:61:a3:
    c2:79:4c:f2:11:56:f8:2f:cc:fc:2b:4b:cb:3b:54:59:f0:8b:
    5b:70:e1:27:c3:57:25:eb:35:c6:07:ea:6d:0b:34:04:95:81:
    35:e6:64:c6:b8:72:e8:24:18:bd:ca:90:99:74:45:44:85:71:
    9e:7f:13:96:
```

show ip static mroute

Displays information for configured multicast routes.

Syntax	show ip static mroute [vrf <i>vrf-name</i>] <i>ip-subnet mask</i>			
Parameters	vrf <i>vrf-name</i>	Specifies an optional VRF route.		
	<i>ip-subnet mask</i>	Specifies an IP address and an optional address mask.		
Modes	Privileged EXEC mode			
Usage Guidelines	Only resolved and best static mroutes are added to the mRTM table. These routes are prefixed with an asterisk in the output from the show ip static mroute command.			
Examples	The following example displays information for configured multicast routes:			
	<pre>Device(config)# show ip static mroute IP Static Routing Table - 2 entries: IP Prefix Next Hop Interface Dis/Metric/Tag Name *20.20.20.0/24 220.220.220.1 - 1/1/0 20.20.20.0/24 50.50.50.2 - 1/2/0 21.21.21.0/24 1.2.3.4 - 1/1/0</pre>			
History	Release version		Command history	
	8.0.10a		This command was introduced.	

show ipv6 dhcp-relay

Displays the DHCPv6 relay agent information configured on the device.

Syntax **show ipv6 dhcp-relay**

Modes Global configuration

Command Output The **show ipv6 dhcp-relay** command displays the following information:

Output field	Description
Current DHCPv6 relay agent state	Displays whether the current relay agent state is enabled or disabled
DHCPv6 enabled interface(s)	Displays the DHCPv6 enabled interfaces.
DHCPv6 Relay Agent Statistics	Displays statistics such as the total DHCPv6 Packets received and transmitted.
Received DHCPv6 Packets	The number of release, relay forward, relay reply packets received.

Examples The following example displays the IPv6 DHCP relay statistics.

```
device(config)#show ipv6 dhcp-relay
Current DHCPv6 relay agent state: Enabled
DHCPv6 enabled interface(s): e 2/3
DHCPv6 Relay Agent Statistics:
Total DHCPv6 Packets, Received:0, Transmitted:0
Received DHCPv6 Packets: RELEASE:0,RELAY_FORWARD:0,RELAY_REPLY:0
OtherServertoClient:0,OtherClienttoServer:0
```

History

Release version	Command history
08.0.10d	This command was introduced.
08.0.30	Support for this command was added in 08.0.30 and later releases.

show ipv6 dhcp-relay delegated-prefixes

Displays information about the delegated prefixes.

Syntax **show ipv6 dhcp-relay delegated-prefixes interface** *interface-id*

Parameters **interface**

Displays delegated prefixes for the specified outgoing interface.

Modes Privileged EXEC

Command Output The **show ipv6 dhcp-relay delegated-prefixes** command displays the following information.

Output field	Description
IPv6 prefix	The IPv6 prefix delegated to the client
Client	The IPv6 address of the client
Interface	The interface on which the DHCPv6 messages are relayed to the client.
ExpireTime	The remaining lifetime of the delegated prefix.

Examples The following example displays information about the delegated prefixes.

```
device# show ipv6 dhcp-relay delegated-prefixes interface ethernet 1/1/45

Prefix          Client          Interface  ExpireTime
fc00:2000:6:7:1::/96  fe80::210:94ff:fe00:e  1/1/45    29d23h53m0s
```

History

Release version	Command history
08.0.10d	This command was introduced.
08.0.30	Support for this command was added in 08.0.30 and later releases.

show ipv6 dhcp-relay destinations

Displays the IPv6 DHCP relay destinations.

Syntax **show ipv6 dhcp-relay destinations**

Modes Global configuration.

Command Output The **show ipv6 dhcp-relay destinations** command displays the following information:

Output field	Description
DHCPv6 Relay Destinations	The DHCPv6 relay agent configured destination information.

Examples The following example displays the IPv6 DHCP relay destinations.

```
device# show ipv6 dhcp-relay destinations
DHCPv6 Relay Destinations:
Interface e 2/3:
Destination OutgoingInterface
2001::2 NA
fe80::224:38ff:febb:e3c0 e 2/5
```

History

Release version	Command history
08.0.10d	This command was introduced.
08.0.30	Support for this command was added in 08.0.30 and later releases.

show ipv6 dhcp-relay interface

Displays the IPv6 DHCP relay information for a specific interface.

Modes Privileged EXEC

Command Output The **show ipv6 dhcp-relay interface** command displays the following information:

Output field	Description
DHCPv6 Relay Information for interface interface-type port-num	The DHCPv6 relay information for the specific interface.
Destination	The configured destination IPv6 address.
OutgoingInterface	The interface on which the packet will be relayed if the destination relay address is a link local or multicast address.
Options	The current information about the DHCPv6 relay options for the interface.
Interface-Id	The interface ID option indicating if the option is used or not.

Examples The following example displays the DHCPv6 Relay information for an interface.

```
device#show ipv6 dhcp-relay interface ethernet 2/3
DHCPv6 Relay Information for interface e 2/3:
Destinations:
Destination OutgoingInterface
2001::2 NA
fe80::224:38ff:febb:e3c0 e 2/5
Options:
Interface-Id: Yes
```

History	Release version	Command history
	08.0.10d	This command was introduced.
	08.0.30	Support for this command was added in 08.0.30 and later releases.

show ipv6 dhcp-relay options

Displays information about the relay options available to the prefixed delegates for a specific interface.

Syntax **show ipv6 dhcp-relay options**

Modes Privileged EXEC

Command Output The **show ipv6 dhcp-relay options** command displays the following information:

Output field	Description
Interface	The interface name.
Interface-ID	The interface ID option. Yes or No indicates if the option is used or not.
Remote-ID	The remote ID option. Yes or No indicates if the option is used or not.

Examples The **show ipv6 dhcp-relay options** command displays the following information:

```
device# show ipv6 dhcp-relay options
DHCPv6 Relay Options Information:
Interface      Interface-Id    Remote-Id
ve 100         No              No
ve 101         Yes             No
ve 102         No              Yes
```

History

Release version	Command history
08.0.10d	This command was introduced.
08.0.30	Support for this command was added.

show ipv6 dhcp-relay prefix-delegation-information

Displays information about the IPv6 DHCP prefix delegation.

Syntax **show ipv6 dhcp-relay prefix-delegation-information**

Modes Privileged EXEC

Command Output The **show ipv6 dhcp-relay prefix-delegation-information** command displays the following information:

Output field	Description
Interface	The interface name.
Current	The number of delegated prefixes currently learned on the interface.
Maximum	The maximum number of delegated prefixes that can be learned on the interface.
AdminDistance	The current administrative distance used for prefixes learned on this interface when added to the IPv6 static route table.

Examples The following example displays information about the IPv6 DHCP delegated prefixes.

```
device# show ipv6 dhcp prefix-delegation-information
DHCPv6 Relay Prefix Delegation Notification Information:
Interface      Current    Maximum    AdminDistance
ve 100         20        20000      10
ve 101         4000      20000      10
ve 102         0         20000      10
ve 103         0         20000      10
ve 104         0         20000      10
ve 105         0         20000      10
```

History	Release version	Command history
	08.0.10d	This command was introduced.
	08.0.30	Support for this command was added in 08.0.30 and later releases.

show ipv6 mroute

Displays information on IPv6 multicast routes. You can specify displaying information either from static or connected mroutes or from a particular mroute.

Syntax **show ipv6 mroute** [**vrf** *vrf-name*] { *ipv6-address ipv6-prefix/prefix-length* | **static** | **connect** | **summary** }

Parameters **vrf** *vrf-name*

Specifies displaying mroutes for a particular VRF.

ipv6-address ipv6-prefix/prefix-length

Displays an IPv6 mroute for the specified destination.

static

Displays only static multicast routes.

connect

Displays only connected multicast routes.

summary

Displays summary information.

Modes Privileged EXEC mode

Examples The following example displays information for IPv6 multicast routes:

```
Device(config)# show ipv6 mroute
IPv6 Routing Table - 7 entries:
Type Codes - B:BGP C:Connected S:Static
Type IPv6 Prefix      Next Hop Router      Interface      Dis/Metric      Uptime
S   1::1:0/120         ::                   ve 90          1/1             2d16h
C   2090::/64          ::                   ve 90          0/0             6d21h
C   2100::/64          ::                   ve 100         0/0             1d21h
C   2110::/64          ::                   ve 110         0/0             1d21h
C   2120::/64          ::                   ve 120         0/0             1d21h
C   2130::/64          ::                   ve 130         0/0             6d21h
C   8811::1/128        ::                   loopback 1     0/0             6d21h
```

The following example displays information for static IPv6 multicast routes:

```
Device(config)# show ipv6 mroute static
Type Codes - B:BGP C:Connected S:Static
Type IPv6 Prefix      Next Hop Router      Interface      Dis/Metric      Uptime
S   1::1:0/120         ::                   ve 90          1/1             2d16h
```

The following example displays information for directly attached (connected) IPv6 multicast routes:

```
Device(config)#show ipv6 mroute connect
Type Codes - B:BGP C:Connected S:Static
Type IPv6 Prefix      Next Hop Router      Interface      Dis/Metric      Uptime
C   2090::/64          ::                   ve 90          0/0             6d21h
C   2100::/64          ::                   ve 100         0/0             1d21h
C   2110::/64          ::                   ve 110         0/0             1d21h
C   2120::/64          ::                   ve 120         0/0             1d21h
C   2130::/64          ::                   ve 130         0/0             6d21h
C   8811::1/128        ::                   loopback 1     0/0             6d21h
```

The following example displays information for IPv6 multicast route 2090::1:

```
Device(config)# show ipv6 mroute 2090::1
Type Codes - B:BGP C:Connected S:Static
Type IPv6 Prefix      Next Hop Router      Interface      Dis/Metric      Uptime
C   2090::/64          ::                   ve 90          0/0             6d21h
```

History

Release version

Command history

8.0.10a

This command was introduced.

show ipv6 multicast mcache

Displays information in the IPv6 multicast forwarding mcache (multicast listening discovery [MLD]).

- Syntax

show ipv6 multicast mcache
- Modes

Privileged EXEC mode
- Command Output

The **show ipv6 multicast mcache** command displays the following information:

Output Field	Description
(abcd:ef50 0:100):	The lowest 32 bits of source and group. It is displayed in XXXX:XXXX hex format. Here XXXX is a 16-bit hex number.
cnt	The number of packets processed in software.
OIF	Output interfaces.
age	The mcache age in seconds. The mcache is reset to 0 if traffic continues to arrive, otherwise it is aged out when it reaches the time defined by the ipv6 multicast mcache-age command.
uptime	The up time of this mcache in seconds.
vidx	The vidx is shared among mcaches using the same output interfaces. The vidx specifies the output port list, which shows the index. Valid range is from 4096 to 8191.
ref-cnt	The number of mcaches using this vidx.

Examples This example shows information in the multicast forwarding mcache:

```
Device#show ipv6 multicast mcache
Example: (S G) cnt=: (S G) are the lowest 32 bits, cnt: SW proc. count
        OIF: 1/22 TR(1/32,1/33), TR is trunk, 1/32 primary, 1/33 output
vlan 1, has 2 cache
1  (abcd:ef50 0:100), cnt=121
   OIF: 1/11 1/9
   age=0s up-time=120s vidx=4130 (ref-cnt=1)
2  (abcd:ef50 0:101), cnt=0
   OIF: entire vlan
   age=0s up-time=0s vidx=8191 (ref-cnt=1)
vlan 70, has 0 cache
```

show ipv6 multicast group

Displays information about multicast listening discovery (MLD) groups.

Syntax **show ipv6 multicast group** [*group-address* [**detail**] [**tracking**]]

Parameters *group-address*

Specifies information for a particular group.

detail

Specifies the source list of a specific VLAN.

tracking

Specifies tracking information on interfaces that have tracking enabled.

Modes Privileged EXEC mode

Command Output The **show ipv6 multicast group** command displays the following information:

Output Field	Description
group	The address of the IPv6 group (destination IPv6 address).
p-port	The physical port on which the group membership was received.
ST	Yes indicates that the MLD group was configured as a static group; No means it was learned from reports.
QR	Yes means the port is a querier port; No means it is not. A port becomes a non-querier port when it receives a query from a source with a lower source IP address than the port.
life	The number of seconds the group can remain in EXCLUDE mode. An EXCLUDE mode changes to INCLUDE if it does not receive an IS_EX or TO_EX message during a specified period of time. The default is 140 seconds. There is no <i>life</i> displayed in INCLUDE mode.
mode	The current mode of the interface: INCLUDE or EXCLUDE. If the interface is in INCLUDE mode, it admits traffic only from the source list. If the interface is in EXCLUDE mode, it denies traffic from the source list and accepts the rest.
source	Identifies the source list that will be included or excluded on the interface. An MLDv1 group is in EXCLUDE mode with a source of 0. The group excludes traffic from 0 (zero) source list, which actually means that all traffic sources are included.
group	If you requested a <i>detailed</i> report, the following information is displayed: <ul style="list-style-type: none"> The multicast group address The mode of the group Sources from which traffic will be admitted (INCLUDE) or denied (EXCLUDE) on the interface. The life of each source list. <p>If you requested a <i>tracking/fast leave</i> report, the clients from which reports were received are identified.</p>

Examples This example shows that an MLDv1 group is in EXCLUDE mode with a source of 0. The group excludes only traffic from the 0 (zero) source list, which means that all traffic sources are included.

```
Device#show ipv6 multicast group
p-:physical, ST:static, QR:querier, EX:exclude, IN:include, Y:yes, N:no
VL1 : 263 grp, 263 grp-port, tracking_enabled
      group
1      ff0e::ef00:a0e3          p-port ST QR life mode source
2      ff01::1:f123:f567        1/7    N  Y  120  EX    0
                                1/9    N  Y      IN    1
```

This example displays detailed MLD group information for multicast group ff0e::ef00:a096:

```
Device#show ipv6 multicast group ff0e::ef00:a096 detail
Display group ff0e::ef00:a096 in all interfaces in details.
p-:physical, ST:static, QR:querier, EX:exclude, IN:include, Y:yes, N:no
VL1 : 1 grp, 1 grp-port, tracking_enabled
      group
1      ff0e::ef00:a096          p-port ST QR life mode source
                                1/7    N  Y  100  EX    0
      group: ff0e::ef00:a096, EX, permit 0 (source, life):
      life=100, deny 0:
```

This example displays the list of clients that belong to multicast group ff0e::ef00:a096 when tracking and fast leave are enabled:

```
Device#show ipv6 multicast group ff0e::ef00:a096 tracking
Display group ff0e::ef00:a096 in all interfaces with tracking enabled.
p-:physical, ST:static, QR:querier, EX:exclude, IN:include, Y:yes, N:no
VL1 : 1 grp, 1 grp-port, tracking_enabled
      group
1      ff0e::ef00:a096          p-port ST QR life mode source
                                1/7    N  Y   80   EX    0
      receive reports from 1 clients: (age)
      (2001:DB8::1011:1213:1415 60)
```

show ipv6 multicast mcache

Displays information in the IPv6 multicast forwarding mcache (multicast listening discovery [MLD]).

Syntax **show ipv6 multicast mcache**

Modes Privileged EXEC mode

Command Output The **show ipv6 multicast mcache** command displays the following information:

Output Field	Description
(abcd:ef50 0:100):	The lowest 32 bits of source and group. It is displayed in XXXX:XXXX hex format. Here XXXX is a 16-bit hex number.
cnt	The number of packets processed in software.
OIF	Output interfaces.
age	The mcache age in seconds. The mcache is reset to 0 if traffic continues to arrive, otherwise it is aged out when it reaches the time defined by the ipv6 multicast mcache-age command.
uptime	The up time of this mcache in seconds.
vidx	The vidx is shared among mcaches using the same output interfaces. The vidx specifies the output port list, which shows the index. Valid range is from 4096 to 8191.
ref-cnt	The number of mcaches using this vidx.

Examples This example shows information in the multicast forwarding mcache:

```
Device#show ipv6 multicast mcache
Example: (S G) cnt=: (S G) are the lowest 32 bits, cnt: SW proc. count
        OIF: 1/22 TR(1/32,1/33), TR is trunk, 1/32 primary, 1/33 output
vlan 1, has 2 cache
1  (abcd:ef50 0:100), cnt=121
   OIF: 1/11 1/9
   age=0s up-time=120s vidx=4130 (ref-cnt=1)
2  (abcd:ef50 0:101), cnt=0
   OIF: entire vlan
   age=0s up-time=0s vidx=8191 (ref-cnt=1)
vlan 70, has 0 cache
```

show ipv6 multicast optimization

Displays multicast listening discovery (MLD) snooping hardware resource-sharing information.

Syntax **show ipv6 multicast optimization [*l2mc*]**

Parameters *l2mc*

Specifies the Layer 2 multicast (L2MC) group index.

Modes Privileged EXEC mode
VLAN configuration mode

Usage Guidelines The **show ipv6 multicast optimization** command is supported only on the ICX 7250, ICX 7450, and ICX 7750 devices.

Use this command to display the availability of L2MC group indexes in the hardware and how it is used and shared

The L2MC group index range varies depending on the platform. Values out of range are not displayed.

Examples The following example displays resource information showing that L2MC group index 4 is shared by two users and the ports included in the set are 1/1/6 and 1/1/1:

```

Device (config)# vlan 150
Device (config-vlan-150)# show ipv6 multicast optimization
Total L2MCs Allocated:      0; Available: 8192; Failed:      0
Index      L2MC              SetId              Users              Set
  1.        4              0x161fcbdb8         2 {<1/1/6>,<1/1/1>,>
  2.        1              0x161d0930         10 {<1/1/6>,<1/1/4>,<1/1/3>,<1/1/2>,>
                                     <1/1/1>,>
Sharability Coefficient:   76%

```

History

Release version	Command history
8.0.10	This command was introduced.

show ipv6 multicast pimsm-snooping

Displays information related to PIM sparse mode (SM) snooping on the mcache.

Syntax **show ipv6 multicast pimsm-snooping** [**vlan** *vlan-id*] [**cache** *ipv6-address*] [**resources**]

Parameters **cache** *ipv6-address*

Specifies the PIM SM Snooping cache.

vlan *vlan-id*

Specifies snooping for a VLAN.

resources

Specifies PIM SM snooping resources.

Modes Privileged exec mode

Usage Guidelines Use the **show ipv6 pimsm-snooping cache** command to display information related to the PIM SM snooping outgoing interface (OIF) in the mcache.

Examples The following example shows PIM SM information for the mcache:

```
Device#show ipv6 multicast pimsm-snooping
Example: Port: 7/3 (ref_count=1)
        ref_count: no of entries in pimsm snoop cache added this oif)

vlan 503, has 1 caches.
1      (* 2:3) has 1 pim join ports out of 1 OIF
        1/1/4 (ref_count=2),
```

show ipv6 multicast vlan

Displays multicast listening discovery (MLD) snooping information for all VLANs or for a specific VLAN.

Syntax **show ipv6 multicast vlan** *vlan-id*

Parameters *vlan-id*

Specifies the VLAN for which you want information. If you do not specify a *vlan-id*, information for all VLANs is displayed.

Modes Privileged EXEC mode

Command Output The **show ipv6 multicast vlan** command displays the following information:

Output Field	Description
version	The MLD version number.
query-t	How often a querier sends a general query on the interface.
group-aging-t	Number of seconds membership groups can be members of this group before aging out.
rtr-port	The router ports which are the ports receiving queries. The display router ports: 1/36(120) 2001:DB8::2e0:52ff:fe00:9900 means port 1/36 has a querier with 2001:DB8::2e0:52ff:fe00:9900 as the link-local address, and the remaining life is 120 seconds.
max-resp-t	The maximum number of seconds a client can wait before it replies to the query.
non-QR	Indicates that the port is a non-querier.
QR	Indicates that the port is a querier.
Unregistered IPv6 Multicast Packets Flooding	Indicates whether flooding is enabled.

Examples The following example shows MLD snooping information for VLAN 70:

```
Device#show ipv6 multicast vlan 70
version=1, query-t=60, group-aging-t=140, max-resp-t=3, other-qr-present-t=123
VL70: cfg V2, vlan cfg passive, 2 grp, 0 (SG) cache, rtr ports,
      router ports: 1/36(120) 2001:DB8::2e0:52ff:fe00:9900,
      1/26 has 2 grp, non-QR (passive), cfg V1
      1/26 has 2 grp, non-QR (passive), cfg V1
      group: ff10:1234::5679, life = 100
      group: ff10:1234::5678, life = 100
      1/35 has 0 grp, non-QR (QR=2001:DB8::2e0:52ff:fe00:9900, age=20), dft V2 trunk
```

The following example shows MLD snooping information when flooding of unregistered IPv6 multicast frames is disabled:

```
Device#show ipv6 multicast vlan
Summary of all vlans. use "sh ipv6 multicast vlan vlan-id" for details
Version=1, Intervals: Query=125, Group Age=260, Max Resp=10, Other Qr=255

Unregistered IPv6 Multicast Packets Flooding: Disabled.

VL500: dft V1, vlan cfg active, 0 grp, 0 (*G) cache, no rtr port,
VL600 no snoop: no global or local config
```

History

Release version	Command history
8.0.30	This command was modified to display flooding information.

show ipv6 ospf interface

Displays interface information for all or specific OSPFv3-enabled interfaces.

Syntax	show ipv6 ospf interface [brief] [ethernet <i>mappedID/slot/port</i>] [loopback <i>number</i>] [tunnel <i>number</i>] [ve <i>vlan_id</i>]
Parameters	<p>brief Displays brief summary information about the specified port.</p> <p>ethernet <i>mappedID/slot/port</i> Specifies the physical interface. On standalone devices specify the interface ID in the format slot/port-id; on stacked devices you must also specify the stack ID, in the format stack-id/slot/port-id.</p> <p>loopback <i>number</i> Specifies a loopback port number in the range of 1 to 255.</p> <p>tunnel <i>number</i> Specifies a tunnel interface.</p> <p>ve <i>vlan_id</i> Specifies the VLAN number.</p>
Modes	Privileged EXEC mode
Usage Guidelines	<p>Use the brief keyword to limit the display to the following fields:</p> <ul style="list-style-type: none">• Interface• Area• Status• Type• Cost• State• Nbrs(F/C)
Command Output	The show ipv6 ospf interface command displays the following information:

This field	Displays
Interface status	The status of the interface. Possible status includes the following: <ul style="list-style-type: none">• Up.• Down.
Type	The type of OSPFv3 circuit running on the interface. Possible types include the following: <ul style="list-style-type: none">• BROADCAST• POINT TO POINT UNKNOWN• POINT TO POINT
IPv6 Address	The IPv6 address assigned to the interface.
Instance ID	An identifier for an instance of OSPFv3.

This field	Displays
Router ID	The IPv4 address of the device. By default, the router ID is the IPv4 address configured on the lowest numbered loopback interface. If the device does not have a loopback interface, the default router ID is the lowest numbered IPv4 address configured on the device.
Area ID	The IPv4 address or numerical value of the area in which the interface belongs.
Cost	The overhead required to send a packet through the interface.
Interface bandwidth	The configured bandwidth on a tunnel interface for routing metric purposes only.
default	Shows whether or not the default passive state is set.
State	<p>The state of the interface. Possible states include the following:</p> <ul style="list-style-type: none"> • DR - The interface is functioning as the Designated Router for OSPFv3. • BDR - The interface is functioning as the Backup Designated Router for OSPFv3. • Loopback - The interface is functioning as a loopback interface. • P2P - The interface is functioning as a point-to-point interface. • Passive - The interface is up but it does not take part in forming an adjacency. • Waiting - The interface is trying to determine the identity of the BDR for the network. • None - The interface does not take part in the OSPF interface state machine. • Down - The interface is unusable. No protocol traffic can be sent or received on such a interface. • DR other - The interface is a broadcast or NBMA network on which another router is selected to be the DR. • Active - The interface sends or receives all the OSPFv3 control packets, and forms the adjacency.
Transmit delay	The amount of time, in seconds, it takes to transmit Link State Updates packets on the interface.
Priority	The priority used when selecting the DR and the BDR. If the priority is 0, the interface does not participate in the DR and BDR election.
Timer intervals	The interval, in seconds, of the hello-interval, dead-interval, and retransmit-interval timers.
DR	The router ID (IPv4 address) of the DR.
BDR	The router ID (IPv4 address) of the BDR.
Number of I/F scoped LSAs	The number of interface LSAs scoped for a specified area, AS, or link.
DR Election	The number of times the DR election occurred.
Delayed LSA Ack	The number of the times the interface sent a delayed LSA acknowledgement.
Neighbor Count	The number of neighbors to which the interface is connected.

This field	Displays
Adjacent Neighbor Count	The number of neighbors with which the interface has formed an active adjacency.
Neighbor	The router ID (IPv4 address) of the neighbor. This field also identifies the neighbor as a DR or BDR, if appropriate.
Interface statistics	<p>The following statistics are provided for the interface:</p> <ul style="list-style-type: none"> Unknown - The number of Unknown packets transmitted and received by the interface. Also, the total number of bytes associated with transmitted and received Unknown packets. Hello - The number of Hello packets transmitted and received by the interface. Also, the total number of bytes associated with transmitted and received Hello packets. DbDesc - The number of Database Description packets transmitted and received by the interface. Also, the total number of bytes associated with transmitted and received Database Description packets. LSReq - The number of link-state requests transmitted and received by the interface. Also, the total number of bytes associated with transmitted and received link-state requests. LSUpdate - The number of link-state updates transmitted and received by the interface. Also, the total number of bytes associated with transmitted and received link-state requests. LSAck - The number of link-state acknowledgements transmitted and received by the interface. Also, the total number of bytes associated with transmitted and received link-state acknowledgements.

Examples This example shows sample output from the **show ipv6 ospf interface** command when no arguments or keywords are used.

```
device# show ipv6 ospf interface

e 1/1/9 admin up, oper up, IPv6 enabled
IPv6 Address:
    fe80::224:10ff:fe76:4bc0
    201::1/64
Instance ID 0, Router ID 2.2.2.2
Area ID 0, Cost 1, Type BROADCAST
MTU: 1500
State DR, Transmit Delay 1 sec, Priority 1, Link-LSA Tx not suppressed
Timer intervals :
    Hello 10, Hello Jitter 10 Dead 40, Retransmit 5
Authentication Use: Enabled
    KeyRolloverTime(sec): Configured: 300 Current: 0
    KeyRolloverState: NotActive
Outbound: None
Inbound: None
DR:2.2.2.2 BDR:1.1.1.1 Number of I/F scoped LSAs is 2
DRElection: 2 times, DelayedLSAck: 425 times
Neighbor Count = 1, Adjacent Neighbor Count= 1
Neighbor:
    1.1.1.1 (BDR)
Statistics of interface e 1/1/9:
  Type      tx      rx      tx-byte  rx-byte
Unknown    0        0         0         0
Hello     80035    80133    3201392    3205320
DbDesc      5         3        240        144
LSReq       1         1         28         76
LSUpdate  2095    1262    171228    92540
LSAck      425      419     32020    48604
OSPF messages dropped,no authentication: 0
```

This example shows sample output from the **show ipv6 ospf interface** command when the **brief** keyword is used.

```
device# show ipv6 ospf interface brief
Interface      Area      Status Type Cost   State   Nbrs (F/C)
e 1/1/9        0         up      BCST 1     DR      1/1
e 1/1/12       0         down    BCST 0     Down    0/0
ve 20          0         up      BCST 1     DR      0/0
ve 60          0         up      BCST 1     DR      0/0
ve 310         0         down    BCST 0     Down    0/0
ve 360         0         down    BCST 0     Down    0/0
loopback 1     0         up      BCST 1     Loopback 0/0
loopback 2     0         up      BCST 1     Loopback 0/0
loopback 3     0         up      BCST 1     Loopback 0/0
```

This example shows information about a specified OSPF-enabled Ethernet interface, including the cost, where the cost is calculated using the default interface speed and auto cost.

```
device# show ipv6 ospf interface ethernet 3/1/1

e 3/1/1 admin up, oper up, ospf enabled, state up
fe80::224:10ff:fe76:4bc0
201::1/64,
Area 0
Database Filter: Not Configured
State BDR, Pri 1, Cost 1, Options 2, Type broadcast Events 3
```

This example shows information about a specified OSPF-enabled Ethernet interface, including the cost, which has been calculated using the configured interface bandwidth and the default auto-cost.

```
device# show ipv6 ospf interface ethernet 3/1/1

e 1/1/3 admin up, oper up, IPv6 enabled
IPv6 Address:
fe80::ce4e:24ff:fe6d:bc00
9000:1111:9013::2/64
Instance ID 0, Router ID 192.168.3.1
Area ID 0, Cost 34, Type BROADCAST
MTU: 1500
State DR, Transmit Delay 1 sec, Priority 1, Link-LSA Tx not suppressed
Timer intervals :
Hello 10, Hello Jitter 10 Dead 40, Retransmit 5
Authentication Use: Enabled
KeyRolloverTime(sec): Configured: 300 Current: 0
KeyRolloverState: Not Active
Outbound: None
Inbound: None
DR:192.168.3.1 BDR:192.168.1.1 Number of I/F scoped LSAs is 2
DRElection:      2 times, DelayedLSAck:      1 times
Neighbor Count = 1, Adjacent Neighbor Count= 1
Neighbor:
192.168.1.1 (BDR)
Statistics of interface e 1/1/3:
  Type   tx      rx      tx-byte  rx-byte
Unknown 0        0         0         0
Hello   82       78      3268      3120
DbDesc  2         3        116       304
LSReq   1         1        148        28
LSUpdate 16        7       1144      1048
LSAck   1         3        156       328
OSPF messages dropped, no authentication: 0
```

History

Release version

Command history

8.0.30

This command was modified to include configured bandwidth status.

show ipv6 neighbor

Displays the status of the neighbor discovery (ND) inspection configuration, details of the VLANs on which ND inspection is enabled, ND static entries, and ND inspection statistics.

Syntax	show ipv6 neighbor [vrf <i>vrf-name</i>] inspection [static-entry statistics vlan <i>vlan-number</i>]
Parameters	<p>static-entry Specifies the manually configured static ND inspection entries that are used to validate the packets received on untrusted ports.</p> <p>statistics Specifies the total number of neighbor discovery messages received and the number of packets discarded after ND inspection.</p> <p>vlan Specifies the VLANs on which ND inspection is enabled.</p> <p><i>vlan-number</i> Specifies the ID of the configured VLAN.</p> <p>vrf Specifies the VRF instance.</p> <p><i>vrf-name</i> Specifies the ID of the VRF instance.</p> <p>inspection Specifies that the neighbor discovery messages are verified against the static ND inspection entries or dynamically learned DHCPv6 snoop entries.</p>
Modes	Privileged EXEC mode Global configuration mode VRF configuration mode
Command Output	The show ipv6 neighbor command displays the following information.

Output field	Description
VLAN	The list of VLANs on which ND inspection is enabled.
IPv6 Address	The IPv6 addresses of the hosts that are added as static ND inspection entries.
LinkLayer-Addr	The MAC addresses of the hosts that are added as static ND inspection entries.
Total number of ND Solicit received	The total number of neighbor solicitation messages received.
Total number of ND Advert received	The total number of neighbor advertisement messages received.
Total number of Router Solicit received	The total number of router solicitation messages received.
Total number of ND dropped	The total number of neighbor discovery messages that are discarded because of the IP-to-MAC address binding discrepancy.
IPv6 Neighbor inspection VLAN <i>vlan-number</i>	The status of ND inspection on a VLAN.

Output field	Description
Untrusted Ports	The interfaces or member ports on which trust mode is not enabled.
Trusted Ports	The interfaces or member ports on which trust mode is enabled.

Examples The following example shows the output of the **show ipv6 neighbor inspection** command.

```
device(config)# show ipv6 neighbor inspection
IPv6 Neighbor inspection enabled on 2 VLAN(s):
  VLAN: 2
  VLAN: 3
```

The following example shows the output of the ND inspection configuration details for a VRF.

```
device(config-vrf-3)# show ipv6 neighbor vrf 3 inspection
IPv6 Neighbor inspection enabled on 2 VLAN(s):
  VLAN: 2
  VLAN: 3
```

The following example shows the output of the **show ipv6 neighbor inspection static-entry** command.

```
device(config)# show ipv6 neighbor inspection static-entry
Total number of ND Inspect entries: 3
IPv6 Address                               LinkLayer-Addr
2001::1                                   0000.0000.1234
2001::3                                   0000.1234.4567
2001::2                                   0000.0000.4567
```

The following example shows the ND static entries of a VRF.

```
device(config-vrf-3)# show ipv6 neighbor vrf 3 inspection static-entry
Total number of ND Inspect entries: 1
IPv6 Address                               LinkLayer-Addr
2001:201:1:1::34                          cc4e.246d.2038
```

The following example shows the output of the **show ipv6 neighbor inspection statistics** command.

```
device(config)# show ipv6 neighbor inspection statistics
Total number of ND Solicit received      11
Total number of ND Advert received       29
Total number of Router Solicit received  20
Total number of ND dropped                6
```

The following example shows the ND inspection statistics of a VRF.

```
device(config-vrf-3)# show ipv6 neighbor vrf 3 inspection statistics
Total number of ND Solicit received      11
Total number of ND Advert received       29
Total number of Router Solicit received  20
Total number of ND dropped                6
```

The following example shows the output of the **show ipv6 neighbor inspection vlan *vlan-number*** command.

```
device (config)# show ipv6 neighbor inspection vlan 2
IPv6 Neighbor inspection VLAN 2: Enabled
  Untrusted Ports : ethe 1/1/1 to 1/1/2
  Trusted Ports   : ethe 1/1/3
```

The following example shows the details of the VLANs on which ND inspection is enabled for a VRF.

```
device (config-vrf-3)# show ipv6 neighbor vrf 3 inspection vlan 2
IPv6 Neighbor inspection VLAN 2: Enabled
  Untrusted Ports : ethe 1/1/1 to 1/1/2
  Trusted Ports   : ethe 1/1/3
```

History	Release version	Command history
	08.0.20	This command was introduced.

show ipv6 pim interface

Displays information for IPv6 PIM interfaces.

Syntax **show ipv6 pim interface** { **ethernetstackid/slot/port-id** | **loopback loopback-number** | **ve ve-number** }

Parameters **ethernetstackid/slot/port-id**

Specifies a physical interface. On standalone devices specify the interface ID in the format slot/port-id; on stacked devices you must also specify the stack ID, in the format stack-id/slot/port-id.

loopback loopback-number

Specifies a loopback interface.

ve ve-number

Specifies a virtual interface.

Modes Privileged EXEC mode

Examples The following example displays output from the **show ipv6 pim interface** command, showing that ACL f10 is applied to interface 1/1/9 to control neighbor access.

```
Device# show ipv6 pim interface
Flags      : SM - Sparse Mode v2
```

```
-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+
Int'face|Local      |Mode|St|Des Rtr|TTL|Mcast|Filter|VRF  |DR  |Override
      |Address    |    |  |Add Prt|Thr|Bndry|ACL   |    |    |Prio|Interval
-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+
e1/1/1  3000::2    SM  Ena  Itself  1  None  None  default  1  3000ms
e1/1/9   201::1     SM  Ena  Itself  1  None  f10   default  1  3000ms
e1/1/12  1222::1     SM  Dis  Itself  1  None  None  default  1  3000ms
v20      2000::2     SM  Ena  Itself  1  None  None  default  1  3000ms
v60      6000::1     SM  Ena  Itself  1  None  None  default  1  3000ms
v310     1100::2     SM  Dis  Itself  1  None  None  default  1  3000ms
v360     1600::1     SM  Dis  Itself  1  None  None  default  1  3000ms
l2       4444::2     SM  Ena  Itself  1  None  None  default  1  3000ms
l3       7711::11  SM  Ena  Itself  1  None  None  default  1  3000ms
Total Number of Interfaces : 9
```

History

Release version

Command history

8.0.20a

This command was modified to display neighbor filter information.

show ipv6 pim traffic

Displays IPv6 PIM traffic statistics.

Syntax	show ipv6 pim traffic [vrf <i>vrf-name</i>] [join-prune] [rx tx]		
Parameters	vrf <i>vrf-name</i>	Specifies information for a VRF instance.	
	join-prune	Specifies displaying join and prune statistics.	
	rx	Specifies displaying received PIM traffic statistics.	
	tx	Specifies displaying transmitted PIM traffic statistics.	
Modes	Privileged EXEC mode		
Usage Guidelines	PIM control packet statistics for interfaces that are configured for standard PIM are listed first by the display.		
Command Output	The show ipv6 pim traffic command displays the following information:		

Output Field	Description
Port	The port or virtual interface on which the IPv6 PIM interface is configured.
HELLO	The number of IPv6 PIM Hello messages sent or received on the interface.
JOIN-PRUNE	The number of Join or Prune messages sent or received on the interface.
NOTE Unlike PIM dense, PIM Sparse uses the same messages for Joins and Prunes.	
ASSERT	The number of Assert messages sent or received on the interface.
REGISTER GRAFT (DM)	The number of Register messages sent or received on the interface.
REGISTER STOP (SM)	The number of Register Stop messages sent or received on the interface.
BOOTSTRAP MSGS (SM)	The number of bootstrap messages sent or received on the interface.
CAND. RP ADV. (SM)	The total number of Candidate-RP-Advertisement messages sent or received on the interface. Register Graft (DM)
Err	The total number of MLD messages discarded, including a separate counter for those that failed the checksum comparison.

Examples This example shows PIM traffic statistics:

```
Device# show ipv6 pim traffic
Port    HELLO    JOIN-PRUNE  ASSERT    REGISTER    REGISTER    BOOTSTRAP CAND. RP  Err
          GRAFT(DM) STOP(SM)  MSGS (SM) ADV. (SM)
-----+-----+-----+-----+-----+-----+-----+-----+-----+
          Rx      Rx      Rx      Rx      Rx      Rx      Rx      Rx
-----+-----+-----+-----+-----+-----+-----+-----+
v170    0         0         0         0         0         0         0         0
v501    0         0         0         0         0         0         0         0
v503    3302      2524      0         0         0         0         0         0
Port    HELLO    JOIN-PRUNE  ASSERT    REGISTER    REGISTER    BOOTSTRAP CAND. RP  Err
          GRAFT(DM) STOP(SM)  MSGS (SM) ADV. (SM)
-----+-----+-----+-----+-----+-----+-----+-----+
          Tx      Tx      Tx      Tx      Tx      Tx      Tx      Tx
-----+-----+-----+-----+-----+-----+-----+-----+
v170    3576      0         0         0         0         0         0         0
v501    1456      0         0         0         0         0         0         0
v503    1456     1314      0         0         0         2         0         0
```

This example shows the number of received IPv6 PIM Hello packets dropped on interface 1/1/9 to because an ACL to control neighbor access is configured on it.

```
Device#show ipv6 pim traffic rx
Port    HELLO  JN-PRN  ASSERT  REG    REG    BTSTRP    CAND RP  Err
          GRAFT(DM) STOP(SM)  MSGS(SM) ADV.(SM)
-----+-----+-----+-----+-----+-----+-----+-----+
          Rx      Rx      Rx      Rx      Rx      Rx      Rx
-----+-----+-----+-----+-----+-----+-----+-----+
e1/1/1  0         0         0         0         0         0         0         0
e1/1/9  924        0         0         0         5         0         914
e1/1/12 0         0         0         0         0         0         0
v20     0         0         0         0         0         0         0
v60     0         0         0         0         0         0         0
v310    0         0         0         0         0         0         0
v360    0         0         0         0         0         0         0
```

History

Release version

Command history

8.0.20a

This command was modified to display, in the Err column, received Hello packets dropped on an interface because of an ACL to control neighbor access.

show ipv6 pimsm-snooping cache

Displays the downstream PIM join/prune information for both source-path tree (SPT) and rendezvous-point tree (RPT).

Syntax	show ipv6 pimsm-snooping cache [vlan <i>vlan-id</i>] <i>ipv6-address</i> [resources]
Parameters	<p><i>ipv6-address</i></p> <p>Specifies the IP address.</p> <p>vlan <i>vlan-id</i></p> <p>Specifies snooping for a VLAN.</p> <p>resources</p> <p>Specifies PIM SM snooping resources.</p>
Modes	Privileged exec mode
Command Output	The show ipv6 pimsm-snooping cache command displays the following information:

Output field	Description
SG	(s,g) downstream fsm state for SPT.
G	(*,g) downstream fsm state for RPT

The **show ipv6 pimsm-snooping cache** command displays the following information only when multi-chassis trunking (MCT) is enabled on the VLAN:

Output field	Description
CCEP	Cluster-client-edge port
CEP	Cluster-edge port
Remote/Local	Join/Prune received on MCT peer or local

Examples The following example shows PIM SM information.

```
Device#show ipv6 pimsm-snooping cache
OIF Info:
TR - OIF Belongs to Trunk/LAG, Primary port is displayed
SG - (s,g) downstream fsm state:
G - (*,g) downstream fsm state:
    NI : No Info, J : Join, PP : Prune Pending, CLEAN : cleanup in progress
RPT - (s,g,rpt) downstream fsm state:
    NI : No Info, P : Pruned, PP : Prune Pending, Px : Temp step in (*,G)
    join processing, PPx : Temp State in (*,G) processing, CLEAN : cleanup
    in progress.

PIMSM Snoop cache for vlan 503
1    (* ff7e::1:2:3) Up Time: 03:43:40
    OIF: 1
    TR(e1/1/4) G : J(183) ET: 210, Up Time: 03:43:40

2    (3000::10 ff7e::1:2:3) Up Time: 00:02:52
    OIF: 1
    TR(e1/1/4) SG : J(185) ET: 210, Up Time: 00:02:52
```

The following example shows PIM SM information for a VLAN.

```
Device#show ipv6 pimsm-snooping vlan 503
OIF Info:
TR - OIF Belongs to Trunk/LAG, Primary port is displayed
SG - (s,g) downstream fsm state:
G - (*,g) downstream fsm state:
    NI : No Info, J : Join, PP : Prune Pending, CLEAN : cleanup in progress
RPT - (s,g,rpt) downstream fsm state:
    NI : No Info, P : Pruned, PP : Prune Pending, Px : Temp step in (*,G)
    join processing, PPx : Temp State in (*,G) processing, CLEAN : cleanup
    in progress.

PIMSM Snoop cache for vlan 503
1    (* ff7e::1:2:3) Up Time: 03:43:46
    OIF: 1
    TR(e1/1/4) G : J(177) ET: 210, Up Time: 03:43:46

2    (3000::10 ff7e::1:2:3) Up Time: 00:02:58
    OIF: 1
    TR(e1/1/4) SG : J(179) ET: 210, Up Time: 00:02:58
```

The following example shows PIM SM resource information.

```
Device#show ipv6 pimsm-snooping resources
```

	alloc	in-use	avail	get-fail	limit	get-mem	size	init
pimsm group entry	1000	1	999	0	232000	2	64	1000
pimsm source entry	2000	1	1999	0	464000	2	68	2000
pimsm oif entry	2000	1	1999	0	464000	2	89	2000

```
Total memory in used: 378000 bytes
```

show ipv6 static mroute

Displays information for configured IPv6 multicast routes.

Syntax	show ipv6 static mroute [vrf <i>vrf-name</i> <i>ipv6-address-prefix/prefix-length</i>]		
Parameters	vrf <i>vrf-name</i>		
	Specifies a VRF route.		
	<i>ipv6-address-prefix/prefix-length</i>		
	Specifies an IPv6 address.		
Modes	Privileged EXEC mode		
	Global configuration mode		
Usage Guidelines	Only resolved and best static mroutes are added to the mRTM table. These routes are prefixed with an asterisk in the output from the show ipv6 static mroute command.		
Examples	This following example displays information for configured IPv6 multicast routes:		
	<pre>Device(config)# show ipv6 static mroute IPv6 Static Routing Table - 1 entries: IPv6 Prefix Interface Next Hop Router Met/Dis/Tag Name *1:1::1:0/120 ve 90 :: 1/1/0</pre>		
History	Release version	Command history	
	8.0.10a	This command was introduced.	

show link-oam info

Displays the OAM information on EFM-OAM-enabled ports.

Syntax **show link-oam info** [**detail** [**ethernet** *stackid/slot/port* [[**to** *stackid/slot/port*] [**ethernet** *stackid/slot/port*]...]]]

Parameters **detail** Displays detailed EFM-OAM information.

ethernet Displays the detailed EFM-OAM information for a specific Ethernet interface.

stackid/slot/port Specifies the interface details.

to Configures a range of interfaces.

Modes Privileged EXEC mode
Global configuration mode
EFM-OAM protocol configuration mode

Command Output The **show link-oam info** command displays the following information:

Output field	Description
Ethernet	Displays the interface details
Link Status	Displays the status of the link (up or down)
OAM Status	Displays the status of OAM
Mode	Displays the operational mode of EFM-OAM
Local Stable	Displays the local OAM status
Remote Stable	Displays the remote OAM status
multiplexer action	Displays the local/remote multiplexer action
parse action	Displays the local/remote parse action
stable	Displays the local/remote OAM status
state	Displays the local/remote EFM-OAM state
loopback support	Indicates whether there is support for loopback for remote/local
dying-gasp	Indicates whether there is support for dying gasp for remote/local
critical-event	Indicates whether there is support for critical-event for remote/local
link-fault	Indicates whether there is support for link-fault for remote/local

Examples The following example displays the OAM information on all EFM-OAM-enabled ports.

```
device(config)# show link-oam info
Ethernet Link Status      OAM Status      Mode      Local Stable      Remote Stable
1/1/1      up              up              active     satisfied          satisfied
1/1/2      up              up              passive    satisfied          satisfied
1/1/3      up              up              active     satisfied          satisfied
1/1/4      up              init            passive    unsatisfied        unsatisfied
1/1/5      down            down            passive    unsatisfied        unsatisfied
1/1/6      down            down            passive    unsatisfied        unsatisfied
1/1/7      down            down            passive    unsatisfied        unsatisfied
```

The following example displays detailed EFM-OAM information on all EFM-OAM-enabled ports.

```

device(config)# show link-oam info detail
OAM information for Ethernet port: 10/1/1
+link-oam mode:      passive
+link status:        down
+oam status:         down
Local information
  multiplexer action: forward
  parse action:       forward
  stable:             unsatisfied
  state:              linkFault
  loopback state:     disabled
  dying-gasp:         false
  critical-event:     false
  link-fault:         true
Remote information
  multiplexer action: forward
  parse action:       forward
  stable:             unsatisfied
  loopback support:   disabled
  dying-gasp:         false
  critical-event:     true
  link-fault:         false

OAM information for Ethernet port: 10/1/3
+link-oam mode:      active
+link status:        up
+oam status:         down
Local information
  multiplexer action: forward
  parse action:       forward
  stable:             unsatisfied
  state:              activeSend
  loopback state:     disabled
  dying-gasp:         false
  critical-event:     false
  link-fault:         false
Remote information
  multiplexer action: forward
  parse action:       forward
  stable:             unsatisfied
  loopback support:   disabled
  dying-gasp:         false
  critical-event:     false
  link-fault:         false

OAM information for Ethernet port: 10/1/4
+link-oam mode:      active
+link status:        up
+oam status:         up
Local information
  multiplexer action: forward
  parse action:       forward
  stable:             satisfied
  state:              up
  loopback state:     disabled
  dying-gasp:         false
  critical-event:     false
  link-fault:         false
Remote information
  multiplexer action: forward
  parse action:       forward
  stable:             satisfied
  loopback support:   disabled
  dying-gasp:         false
  critical-event:     true
  link-fault:         false

```

The following example displays detailed EFM-OAM information on a range of EFM-OAM-enabled ports.

```
device(config)# show link-oam info detail ethernet 1/1/3 to 1/1/8
OAM information for Ethernet port: 1/1/3
+link-oam mode:      active
+link status:        up
+oam status:          up
Local information
multiplexer action:  forward
parse action:        forward
stable:               satisfied
state:                up
loopback state:      disabled
dying-gasp:           false
critical-event:       false
link-fault:           false
Remote information
multiplexer action:  forward
parse action:        forward
stable:               satisfied
loopback support:    disabled
dying-gasp:           false
critical-event:       false
link-fault:           false

Link OAM is not enabled on port 1/1/4
Link OAM is not enabled on port 1/1/5
Link OAM is not enabled on port 1/1/6
Link OAM is not enabled on port 1/1/7
Link OAM is not enabled on port 1/1/8
```

History	Release version	Command history
	08.0.30	This command was introduced.

show link-oam statistics

Displays the OAM statistics of OAM-enabled ports.

Syntax **show link-oam statistics** [**detail** [**ethernet** *stackid/slot/port* [[**to** *stackid/slot/port*] [**ethernet** *stackid/slot/port*]...]]]

Parameters **detail**

Displays detailed EFM-OAM statistics.

ethernet

Displays the detailed EFM-OAM statistics of a specific ethernet interface.

stackid/slot/port

Specifies the interface details.

to

Configures a range of interfaces.

Modes Privileged EXEC mode

Global configuration mode

EFM-OAM protocol configuration mode

Command Output The **show link-oam statistics** command displays the following information:

Output field	Description
Tx PDUs	Displays the number of PDUs transmitted
Rx PDUs	Displays the number of PDUs received
information OAMPDUs	Displays the number of information OAMPDUs transmitted/received
loopback control OAMPDUs	Displays the number of loopback control OAMPDUs transmitted/received
variable request OAMPDUs	Displays the number of variable request OAMPDUs transmitted/received
variable response OAMPDUs	Displays the number of variable response OAMPDUs transmitted/received
unique event notification OAMPDUs	Displays the number of unique event notification OAMPDUs transmitted/received
duplicate event notification OAMPDUs	Displays the number of duplicate event notification OAMPDUs transmitted/received
organization specific OAMPDUs	Displays the number of organization specific OAMPDUs transmitted/received
link-fault records	Displays the number of link-fault records transmitted/received
critical-event records	Displays the number of critical-event records transmitted/received
dying-gasp records	Displays the number of dying-gasp records transmitted/received
loopback control OAMPDUs dropped	Displays the number of dropped loopback control OAMPDUs
unsupported OAMPDUs	Displays the number of unsupported OAMPDUs
discarded TLVs	Displays the number of discarded TLVs
unrecognized TLVs	Displays the number of unrecognized TLVs

Examples The following example displays the OAM statistics on all EFM-OAM-enabled ports.

```
device(config)# show link-oam statistics
Ethernet Tx Pcus      Rx Pcus
10/1/1    377908      377967
10/1/3    400         44
10/1/4    400        385
10/1/5    400        385
10/1/6    400        385
```

The following example displays detailed EFM-OAM statistics on all EFM-OAM-enabled ports.

```

device(config)# show link-oam statistics detail
OAM statistics for Ethernet port: 10/1/1
  Tx statistics
    information OAMPDUs: 377908
    loopback control OAMPDUs: 0
    variable request OAMPDUs: 0
    variable response OAMPDUs: 0
    unique event notification OAMPDUs: 0
    duplicate event notification OAMPDUs: 0
    organization specific OAMPDUs: 0
    link-fault records: 0
    critical-event records: 0
    dying-gasp records: 0
  Rx statistics
    information OAMPDUs: 377967
    loopback control OAMPDUs: 0
    loopback control OAMPDUs dropped: 0
    variable request OAMPDUs: 0
    variable response OAMPDUs: 0
    unique event notification OAMPDUs: 0
    duplicate event notification OAMPDUs: 0
    organization specific OAMPDUs: 0
    unsupported OAMPDUs: 0
    link-fault records: 0
    critical-event records: 377395
    dying-gasp records: 0
    discarded TLVs: 0
    unrecognized TLVs: 0

OAM statistics for Ethernet port: 10/1/3
  Tx statistics
    information OAMPDUs: 427
    loopback control OAMPDUs: 0
    variable request OAMPDUs: 0
    variable response OAMPDUs: 0
    unique event notification OAMPDUs: 0
    duplicate event notification OAMPDUs: 0
    organization specific OAMPDUs: 0
    link-fault records: 0
    critical-event records: 0
    dying-gasp records: 0
  Rx statistics
    information OAMPDUs: 44
    loopback control OAMPDUs: 0
    loopback control OAMPDUs dropped: 0
    variable request OAMPDUs: 0
    variable response OAMPDUs: 0
    unique event notification OAMPDUs: 0
    duplicate event notification OAMPDUs: 0
    organization specific OAMPDUs: 0
    unsupported OAMPDUs: 0
    link-fault records: 0
    critical-event records: 0
    dying-gasp records: 0
    discarded TLVs: 0
    unrecognized TLVs: 0

OAM statistics for Ethernet port: 10/1/4
  Tx statistics
    information OAMPDUs: 428
    loopback control OAMPDUs: 0
    variable request OAMPDUs: 0
    variable response OAMPDUs: 0
    unique event notification OAMPDUs: 0
    duplicate event notification OAMPDUs: 0
    organization specific OAMPDUs: 0
    link-fault records: 0
    critical-event records: 0
    dying-gasp records: 0
  Rx statistics
    information OAMPDUs: 413
    loopback control OAMPDUs: 0
    loopback control OAMPDUs dropped: 0
    variable request OAMPDUs: 0
    variable response OAMPDUs: 0
    unique event notification OAMPDUs: 0

```

```
duplicate event notification OAMPDUs: 0
organization specific OAMPDUs: 0
unsupported OAMPDUs: 0
link-fault records: 0
critical-event records: 350
dying-gasp records: 0
discarded TLVs: 0
unrecognized TLVs: 0
```

The following example displays detailed EFM-OAM statistics on a range of EFM-OAM-enabled ports.

```
device(config)# show link-oam statistics detail ethernet 1/1/3 to 1/1/8
OAM statistics for Ethernet port: 1/1/3
  Tx statistics
    information OAMPDUs: 255390
    loopback control OAMPDUs: 0
    variable request OAMPDUs: 0
    variable response OAMPDUs: 0
    unique event notification OAMPDUs: 0
    duplicate event notification OAMPDUs: 0
    organization specific OAMPDUs: 0
    link-fault records: 0
    critical-event records: 0
    dying-gasp records: 0
  Rx statistics
    information OAMPDUs: 282796
    loopback control OAMPDUs: 0
    loopback control OAMPDUs dropped: 0
    variable request OAMPDUs: 0
    variable response OAMPDUs: 0
    unique event notification OAMPDUs: 0
    duplicate event notification OAMPDUs: 0
    organization specific OAMPDUs: 0
    unsupported OAMPDUs: 0
    link-fault records: 0
    critical-event records: 0
    dying-gasp records: 0
    discarded TLVs: 0
    unrecognized TLVs: 0

Link OAM is not enabled on port 1/1/4
Link OAM is not enabled on port 1/1/5
Link OAM is not enabled on port 1/1/6
Link OAM is not enabled on port 1/1/7
Link OAM is not enabled on port 1/1/8
```

History	Release version	Command history
	08.0.30	This command was introduced.

show loop-detect no-shutdown-status

Shows the status of interfaces in a loop.

Syntax **show loop-detect no-shutdown-status**

Modes Privileged EXEC mode

Command Output The **show loop-detect no-shutdown-status** command displays the following information:

Output field	Description
Port	The specific interface
Loop status	The duration the port has been in a loop

Examples The following example shows the ports and their loop statuses.

```
device# show loop-detection no-shutdown-status

loop detection no shutdown syslog interval : 5      (unit 1 min /Default 5 min)
loop detection no shutdown port status      :
Note: Port's loop status gets cleared if loop is not detected in a particular
interval window

      Port      || Loop Status
=====||=====
ethernet 1/1/7  || (In Loop For 2309 Seconds)
ethernet 1/1/15 || (In Loop For 2309 Seconds)
```

History	Release version	Command history
	08.0.20	This command was introduced.

show mac-auth configuration

Displays the global or interface level MAC authentication configuration.

Syntax	show mac-auth configuration [all ethernet device/slot/port]
Parameters	<p>all Displays the MAC authentication configuration on all interfaces.</p> <p>ethernet device/slot/port Displays the MAC authentication configuration for a specific interface.</p>
Modes	EXEC or Privileged EXEC mode Global configuration mode
Command Output	The show mac-auth configuration command displays the following information.

Output field	Description
Status	Displays if MAC authentication is enabled or disabled
Auth-order	The authentication order enabled on the device
Default VLAN	The default VLAN specified on the device
Restricted VLAN	The restricted VLAN specified on the device
Critical VLAN	The critical VLAN specified on the device
Action on Auth failure	The action to be taken on authentication failure
MAC Session Aging	The status of the MAC session aging
Filter Strict Security	The status of filter strict security
Re-authentication	The status of re-authentication
Dot1x Override	The status of dot1x override
Password Override	The status of password override
Password Format	The configured password format
Reauth-period	The re-authentication period specified in seconds
Session max sw-age	The maximum software age configured on the device
Session max hw-age	The maximum hardware age configured on the device

The **show mac-auth configuration all | ethernet device/slot/port** command displays the following information.

Output field	Description
Auth Order	Displays the authentication order
Action on Auth failure	Displays the action to be taken on authentication failure
Action on Auth timeout	Displays the action to be taken on authentication timeout

Output field	Description
Filter Strict Security	Displays if filter strict security is enabled or disabled
DoS Protection	Displays if DoS protection is enabled or disabled
Source-guard Protection	Displays if Source-Guard Protection is enabled or disabled
Aging	Displays if aging is enabled or disabled
Max-sessions	Displays the count of the maximum sessions
Ingress-filtering	Displays if ingress filtering is enabled or disabled

Examples The following example displays the system level MAC authentication configuration.

```
device# show mac-authentication configuration

Status : Enabled
Auth Order : dot1x mac-auth
Default VLAN : 4
Restricted VLAN : Not configured
Critical VLAN : Not configured
Action on Auth failure : Block traffic
MAC Session Aging : Enabled
Filter Strict Security : Enabled
Re-authentication : Enabled
Dot1x Override : Disabled
Password Override : Disabled
Password Format : xxxx.xxxx.xxxx
Reauth-period : 600 seconds
Session max sw-age : 120 seconds
Session max hw-age : 70 seconds
```

The following example displays the MAC authentication configuration for port 1/1/15.

```
device# configure terminal
device(config)# show mac-auth configuration 1/1/15

Port 1/1/15 Configuration:
Auth Order                : dot1x mac-auth
Action on Auth failure    : Block traffic
Action on Auth timeout    : Treat as a failed authentication
Filter Strict Security     : Enabled
DoS Protection            : Disabled (limit = 512)
Source-guard Protection    : Disabled
Aging                     : Enabled
Max-sessions              : 32
Auth Filter List (Filter/VLAN) : 1/2
```

The following example displays the MAC authentication information on all interfaces.

```
device# configure terminal
device(config)# show mac-auth configuration all

Port 1/1/1 Configuration:
Auth Order                : dot1x mac-auth
Action on Auth failure    : Block traffic
Action on Auth timeout    : Treat as a failed authentication
Filter Strict Security    : Enabled
DoS Protection            : Disabled (limit = 512)
Source-guard Protection   : Disabled
Reauth-timeout            : 60 seconds
Aging                     : Enabled
Max-sessions              : 2

Port 1/1/3 Configuration:
Auth Order                : dot1x mac-auth
Action on Auth failure    : Block traffic
Action on Auth timeout    : Treat as a failed authentication
Filter Strict Security    : Enabled
DoS Protection            : Disabled (limit = 512)
Source-guard Protection   : Disabled
Reauth-timeout            : 60 seconds
Aging                     : Enabled
Max-sessions              : 2
```

History		
	Release version	Command history
	08.0.20	This command was introduced.

show mac-auth ip-acl

Shows the layer 3 access lists (ACLs) for MAC authentication.

- Syntax

show mac-auth ip-acl { all | ethernet device/slot/port }
- Parameters

all
Specifies the ACLs at the global level.

ethernet device/slot/port
Specifies the ACLs at the interface level.
- Modes

Global configuration mode

Interface configuration mode

Examples The **show mac-auth ip-acl** command displays the following information.

```
device(config)# show mac-auth ip-acl all
MAC-Auth IP ACL Information :

Port 1/1/15 : 0010.9400.0010
In-bound IP ACL : 101

Port 1/1/15 : 0010.9400.0020
In-bound IP ACL : 101

Port 2/1/15 : 0015.9400.0020
In-bound IP ACL : 102

device(config)# show mac-auth ip-acl eth 1/1/15
MAC-Auth IP ACL Information :

Port 1/1/15 : 0010.9400.0010
In-bound IP ACL : 101

Port 1/1/15 : 0010.9400.0020
In-bound IP ACL : 101
```

History	Release version	Command history
	08.0.20	This command was introduced.

show mac-auth sessions

Shows MAC authentication configuration sessions at a global and interface level.

Syntax	show mac-auth sessions { all ethernet <i>device/slot/port</i> }
Parameters	all Specifies the sessions at the global level. ethernet <i>device/slot/port</i> Specifies the sessions at the interface level.
Modes	Privileged EXEC mode Global configuration Interface configuration
Command Output	The show mac-auth sessions command displays the following information:

Output field	Description
Port	The port number.
MAC Address	The MAC address of the client.
IP Address	The IP address of the client.
VLAN	The VLAN
Auth State	The authentication state.
ACL	The specific ACL applied.
Age	The age of the session.

Examples The following example displays MAC sessions for all interfaces.

```
device# show mac-auth sessions all
```

Port	MAC Addr	IP Addr	Vlan	Auth State	ACL	Age
1/1/15	0010.9400.0010	192.85.10.1	20	Yes	in-101	
1/1/15	0010.9400.0020	192.85.20.1	20	Yes	in-101	
2/1/15	0015.9400.0020	192.85.30.1	30	Yes	in-102	

The following example displays MAC sessions for a specified interface.

```
device# show mac-auth sessions ethernet 1/1/15
```

Port	MAC Addr	IP Addr	Vlan	Auth State	ACL	Age
1/1/15	0010.9400.0010	192.85.10.1	20	Yes	in-101	
1/1/15	0010.9400.0020	192.85.20.1	20	Yes	in-101	

History	Release version	Command history
	08.0.20	This command was introduced.

show mac-auth statistics

Displays the MAC authentication statistics.

Syntax **show mac-auth statistics** { **all** | **ethernet** *device/slot/port* }

Parameters **all**

Displays the MAC authentication statistics for all interfaces.

ethernet *device/slot/port*

Displays the MAC authentication statistics for the specified interface.

Modes Privileged EXEC mode

Command Output The **show mac-auth statistics** command displays the following information:

Output field	Description
Accepted sessions	Number of accepted sessions
Rejected sessions	Number of rejected sessions
Inprogress sessions	Number of inprogress sessions
Attempted sessions	Number of attempted sessions
Number of errors	The number of errors.

Examples The following example displays MAC authentication statistics for all interfaces.

```
device# show mac-auth statistics all
```

```
Port 1/1/15 Statistics:
Accepted Sessions      :    2
Rejected Sessions      :    0
Inprogress Sessions    :    0
Attempted Sessions     :    0
Number of Errors       :    0
```

```
Port 2/1/15 Statistics:
Accepted Sessions      :    1
Rejected Sessions      :    0
Inprogress Sessions    :    0
Attempted Sessions     :    0
Number of Errors       :    0
```

The following example displays MAC authentication statistics for Ethernet interface 1/1/15.

```
device# show mac-auth statistics ethernet 1/1/15
```

```
Port 1/1/15 Statistics:
Accepted Sessions      :    2
Rejected Sessions      :    0
Inprogress Sessions    :    0
Attempted Sessions     :    0
Number of Errors       :    0
```

History

Release version	Command history
08.0.20	This command was introduced.

show macsec statistics ethernet

Displays status information and secure channel statistics for the designated MACsec interface.

Syntax	show macsec statistics ethernet <i>device/slot/port</i>
Parameters	<i>device/slot/port</i> Interface for which MACsec status information is to be displayed. The interface is designated by device number in stack/slot on the device/interface on the slot.
Modes	User EXEC mode Privileged EXEC mode Global configuration mode dot1x-mka configuration mode dot1x-mka-interface configuration mode
Usage Guidelines	<p>This command is supported only on the Brocade ICX 6610 in FastIron Release 08.0.20. In FastIron Release 08.0.30 and later releases, MACsec commands are also supported on the ICX 7450.</p> <p>It is recommended that you use the clear macsec ethernet command to clear previous results for the show macsec statistics ethernet command before re-executing it.</p>
Command Output	The show macsec statistics ethernet command displays the following information:

Output field	Description
Interface (Device/slot/port)	The information that follows describes the designated interface.
Replay Protection (Enabled, Disabled)	Indicates whether replay protection is applied on the interface.
Replay Window (0 through 127)	If out-of-order packets are allowed, indicates allowable window within which an out-of-order packet can be received.
Frame Validation (Enabled, Disabled)	Indicates whether MACsec frame headers are checked.
Secure Channel Statistics:	The fields that follow describe activity on a secure channel established over the designated interface.
TxPktProtectedOnly	Number of transmitted packets with integrity protection only.
TxOctetProtectedOnly	Number of bytes transmitted in packets with integrity protection only.
TxPktEncrypted	Number of transmitted packets that are encrypted.
TxOctetEncrypted	Number of bytes transmitted in encrypted packets.
TxPktMiss	Number of transmitted packets that are neither encrypted nor protected by integrity check.
TxOctetMiss	Number of bytes transmitted in packets that are neither encrypted nor protected by integrity checking.
TxPktDrop	Number of packets dropped at transmission because SAK has been exhausted.

Output field	Description
TxPktBad	Number of transmitted packets marked as bad.
RxPktDecryptedAuth	Number of packets received, decrypted, and checked for integrity protection.
RxOctetTotal	Number of bytes received.
RxOctetAuthOnly	Number of bytes received with Integrity protection only.
RxOctetDecrypted	Number of bytes received and decrypted.
RxPktFailReplayCheck	Number of packets received out of order.
RxPktFailICVCheck	Number of packets received that failed Integrity checking.
RxPktNoMACsecTag	Number of packets received without a MACSec Tag.
RxPktFrameValFail	Number of packets received that failed MACsec frame validation.
RxPktMiss	Number of packets received that did not find a key for decryption.
RxOctetMiss	Number of bytes received that did not find a key for decryption.
RxPktDrop	Number of received packets that were dropped.

Examples The following example shows details for Ethernet interface 1/3/1 (device 1, slot 3, port 1). The interface is verifying MACsec frames and is providing strict replay protection. Based on counter statistics, transmitted packets are being encrypted. A smaller number of packets have been received, have passed integrity checking, and have been decrypted. No packets have been received out of order, and no packets have been dropped. No packets have failed integrity checking. A number of packets have been received without MACsec headers, and numerous bytes did not have a decryption key.

```

device(config-dot1x-mka-1/3/1)# clear macsec ethernet 1/3/1
device(config-dot1x-mka-1/3/1)# show macsec statistics ethernet 1/3/1

Interface                : 1/3/1

Replay Protection       : Enabled
Replay Window           : 0
Frame Validation        : Check

Secure Channel Statistics:
TxPktProtectedOnly      165074761  TxOctetProtectedOnly      20491766144
TxPktEncrypted           0          TxOctetEncrypted           0
TxPktMiss                0          TxOctetMiss                0
TxPktDrop                0          TxPktBad                  0

RxPktDecryptedAuth       3455          RxOctetTotal              257506
RxOctetAuthOnly          230740         RxOctetDecrypted           0
RxPktFailReplayCheck     0          RxPktFailICVCheck         0
RxPktNoMACsecTag         414          RxPktFrameValFail         0
RxPktMiss                414          RxOctetMiss                26766
RxPktDrop                0

```

The following example shows output for an ICX 7450 device. The output for the ICX 7450 is different from the output for other devices.

```

device(config)#
device(config)#sh macsec stat ethe 10/2/1
device(config)#
Interface Statistics:
-----
rx Untag Pkts          : 1          tx Untag Pkts          :
0
rx Notag Pkts          : 0          tx TooLong Pkts       :
0
rx Badtag Pkts         : 0
rx Unknownsci Pkts     : 0
rx Nosci Pkts          : 0
rx Overrun Pkts        : 0

Transmit Secure Channels:
-----

SA[0] Statistics:
Protected Pkts         : 0
Encrypted Pkts         : 2436337

SA[1] Statistics:
Protected Pkts         : 0
Encrypted Pkts         : 0

SA[2] Statistics:
Protected Pkts         : 0
Encrypted Pkts         : 0

SA[3] Statistics:
Protected Pkts         : 0
Encrypted Pkts         : 0

SC Statistics:
Protected Octets       : 0          Encrypted Octets       :
134830107
Protected Pkts        : 0          Encrypted Pkts        :
2436337

Receive Secure Channels:
-----

SA[0] Statistics:
Ok Pkts               : 1949642   Invalid Pkts           :
0
Not using SA Pkts     : 0          Unused Pkts           :
0
Not Valid Pkts        : 0

SA[1] Statistics:
Ok Pkts               : 0          Invalid Pkts           :
0
Not using SA Pkts     : 0          Unused Pkts           :
0
Not Valid Pkts        : 0

SA[2] Statistics:
Ok Pkts               : 0          Invalid Pkts           :
0
Not using SA Pkts     : 0          Unused Pkts           :
0
Not Valid Pkts        : 0

SA[3] Statistics:
Ok Pkts               : 0          Invalid Pkts           :
0
Not using SA Pkts     : 0          Unused Pkts           :
0
Not Valid Pkts        : 0

SC Statistics:
OkPkts               : 1949642   Invalid Pkts           :
0
Not using SA Pkts     : 0          Unused Pkts           :

```

```

0
Not Valid Pkts          : 0                Unchecked Pkts          :
0
Delayed Pkts           : 0                Late Pkts              :
0
Valid Octets           : 0                Decrypted Octets        :
97743896
device(config)#

```

History

Release version	Command history
08.0.20	This command was introduced.
08.0.20a	This command was modified. The show macsec ethernet command name was changed to show macsec statistics ethernet .

show memory

Displays the memory usage for system tasks, transmission control protocol, and stack units.

- Syntax

show memory [**task** | **tcp** | **unit** *unit-id*]
- Parameters

task

Displays memory usage per system task.

tcp

Displays Transmission Control Protocol (TCP) memory usage.

unit *unit-id*

The ID of the stack unit.
- Modes

Global configuration mode

User EXEC mode
- Command Output

The **show memory task** command displays the following information:

Output field	Description
Task	The name of the task.
Alloc	The amount memory allocated for the task.
Free	The amount of free memory available.
Used	The amount of memory used by the specific task.
TCB usage	The availability of Transmission Control Block for the TCP connection.
TCP QUEUE BUFFER usage	The availability of the Queue buffer used to hold the TCP messages that need to be sent.
TCP SEND BUFFER usage	The availability of buffers which will be used to send the TCP packets from the device.
TCP RECEIVE BUFFER usage	The availability of buffers which will be used to receive the TCP packets to the device.
TCP OUT OF SEQUENCE BUFFER usage	The availability of re-sequence buffer used for the TCP connection.

Examples The following example command displays the memory usage per task.

```
Task Memory Usage Info
-----
Last clear : NA
-----
```

Task	Alloc	Free	Used
TimerTsk	144	0	144
FlashTsk	5552	0	5552
MainTsk	33153780	3411177	29742603
keygen	1468	0	1468
itc	9188	0	9188
bcmCNTR.0	17820	0	17820
bcmL2MOD.0	144	0	144
scp	232815	27166	205649
appl	676257682	637313495	38944187
snms	127713	52104	75609
rtm	9476869	17272	9459597
rtm6	321341	17272	304069
rip	574422	8636	565786
bgp	4048555	17272	4031283
ospf	2937465	8636	2928829
openflow_ofm	431242	14621	416621
openflow_opm	433909	17272	416637
mcast_fwd	1776859	17272	1759587
mcast	2614790	31233	2583557
msdp	221375	17272	204103
ripng	96181	8636	87545
ospf6	1989857	8636	1981221
mcast6	794175	22597	771578
ipsec	208381	8636	199745
dhcp6	134907	8636	126271
snmp	57140	17272	39868
rmon	74775	17272	57503
web	56915	17344	39571
acl	1291591	28243	1263348
flexauth	277607	8636	268971
ntp	56835	17272	39563
rconsole	48215	8636	39579
console	2059410	1476779	582631
ospf_msg_task	56035	17272	38763
auxTsk	4572	0	4572
bcmLINK.0	37152	37152	0

Total Memory Used: 97213162

The following example displays the TCP memory usage information.

```
device# show memory tcp
TCP MEMORY USAGE
TCB usage: total=73140, free=71300
TCP QUEUE BUFFER usage: total=19635, free=19635
TCP SEND BUFFER usage: total=192532, free=192532
TCP RECEIVE BUFFER usage: total=192532, free=192532
TCP OUT OF SEQUENCE BUFFER usage: total=25074, free=25074
```

The following example displays memory usage for stack unit 1.

```
device# show memory unit 1
Stack unit 1:
  Total DRAM: 268435456 bytes
  Dynamic memory: 3781353472 bytes total, 3563307008 bytes free, 5% used
```

History

Release version

Command history

08.0.30

This command was introduced.

show memory task

Displays the memory usage, allocated memory, and free memory for system tasks on the device.

- Syntax** **show memory task [clear]**
- Parameters** **clear**
Clears the displayed memory information if no memory is used.
- Modes** Global configuration mode
User EXEC mode
- Examples** The following example displays the memory usage, allocated memory, and free memory for system tasks on the device.

```
device# show memory task
Task Memory Usage Info
-----
Last clear : NA
-----
```

Task	Alloc	Free	Used
TimerTsk	144	0	144
FlashTsk	5552	0	5552
MainTsk	33153780	3411177	29742603
keygen	1468	0	1468
itc	9188	0	9188
bcmCNTR.0	17820	0	17820
bcmL2MOD.0	144	0	144
scp	232815	27166	205649
appl	676257682	637313495	38944187
snms	127713	52104	75609
rtm	9476869	17272	9459597
rtm6	321341	17272	304069
rip	574422	8636	565786
bgp	4048555	17272	4031283
ospf	2937465	8636	2928829
openflow_ofm	431242	14621	416621
openflow_opm	433909	17272	416637
mcast_fwd	1776859	17272	1759587
mcast	2614790	31233	2583557
msdp	221375	17272	204103
ripng	96181	8636	87545
ospf6	1989857	8636	1981221
mcast6	794175	22597	771578
ipsec	208381	8636	199745
dhcpc6	134907	8636	126271
snmp	57140	17272	39868
rmon	74775	17272	57503
web	56915	17344	39571
acl	1291591	28243	1263348
flexauth	277607	8636	268971
ntp	56835	17272	39563
rconsole	48215	8636	39579
console	2059410	1476779	582631
ospf_msg_task	56035	17272	38763
auxTsk	4572	0	4572
bcmLINK.0	37152	37152	0
Total Memory Used: 97213162			

History

Release version	Command history
08.0.30	This command was introduced.

show notification-mac

Displays whether MAC-notification for SNMP traps is enabled or disabled.

Syntax **show notification-mac**

Modes Privileged EXEC mode

Usage Guidelines You can view statistics such as the configured interval, the number of traps sent, and the number of events sent.

Examples The following example displays the MAC-notification statistics:

```
device# show notification-mac
Mac-notification SNMP trap is ENABLED
Configured Interval: 40 seconds
Number of trap messages sent: 2
Number of mac-notification events sent: 20
```

History

Release version	Command history
08.0.10	This command was introduced.

show openflow

Displays the configured OpenFlow parameters.

Syntax	show openflow
Modes	EXEC and Privileged EXEC mode Global configuration mode
Command Output	The show openflow command displays the following information:

Output field	Description
Administrative Status	Enable or disable status
Controller Type	OpenFlow 1.0 or OpenFlow1.3 controller
Controller	Number of controllers

Examples

```
device#show openflow

Administrative Status:      Enabled
Controller Type:           OFV 130
Number of Controllers: 4

Controller 1:
Connection Mode:           passive, TCP
Listening Address:         0.0.0.0
Connection Port:           6633
Connection Status:         TCP_LISTENING
Role:                      Equal
Asynchronous Configuration: Packet-in (no-match|action|invalid-ttl)
                           Port-status (add|delete|modify)
                           Flow-removed (idle-timeout|hard-timeout|delete|grp-
delete)

Controller 2:
Connection Mode:           active, TCP
Controller Address:         10.25.128.243
Connection Port:           2001
Connection Status:         OPENFLOW_ESABLISHED
Role:                      Master
Asynchronous Configuration: Packet-in (no-match|action|invalid-ttl)
                           Port-status (add|delete|modify)
                           Flow-removed (idle-timeout|hard-timeout|delete|grp-
delete)

Controller 3:
Connection Mode:           active, TCP
Controller Address:         10.25.128.242
Connection Port:           6633
Connection Status:         OPENFLOW_ESABLISHED
Role:                      Slave
Asynchronous Configuration: Port-status (add|delete|modify)

Controller 4:
Connection Mode:           active, TCP
Controller Address:         10.25.128.250
Connection Port:           2002
Connection Status:         OPENFLOW_ESABLISHED
Role:                      Slave
Asynchronous Configuration: Port-status (add|delete|modify)

Match Capability:
Port, Destination MAC, Vlan, Vlan PCP
Openflow Enabled Ports:    e1/1 e1/2
```


History	Release version	Command history
	08.0.20	This command was introduced.

show openflow controller

Displays the controller information in a flow.

Syntax **show openflow controller**

Modes EXEC and Privileged EXEC mode
Global configuration mode

Command Output The **show openflow controller** command displays the following information:

Output field	Description
Mode	Gives the active and passive connection of the controller.
IP address	IP address of the port
Port	Port number
Status	After the connection and OpenFlow handshake, the controller gives the role of OpenFlow channel.
Role	Equal, Master and Slave role for the controller.

Examples

```
device# show openflow controller
-----
Contlr Mode  TCP/SSL IP-address  Port  Status  Role
-----
1  (Equal)   passive TCP    0.0.0.0  6633   TCP_LISTENING
2  (Master)   active  TCP    10.25.128.179  6633   OPENFLOW_ESABLISHED
3  (Slave)   active  TCP    10.25.128.177  6633   OPENFLOW_ESABLISHED
3  (Equal)   active  TCP    10.25.128.165  6633   OPENFLOW_ESABLISHED
```

History

Release version	Command history
08.0.20	This command was introduced.

show openflow flows

Displays the flows information on the OpenFlow ports.

Syntax **show openflow flows**

Modes User EXEC mode

Privileged EXEC mode

Global configuration mode

Command Output The **show openflow flows** command displays the following information:

Output field	Description
Flow	Number of flows
Packet	Total Number of data packets trapped to be sent to controller
Byte	Total Number of data bytes trapped to be sent to controller

Examples This command displays the output for flows.

```
device# show openflow flows

Total Number of data packets sent to controller:          0
Total Number of data bytes sent to controller :          0

Total Number of Flows: 1
    Total Number of Port based Flows: 1
    Total Number of L2 Generic Flows: 0
    Total Number of L3 Generic Flows: 0
    .....
    .....

Flow ID: 1 Priority: 32768 Status: Active
    Rule:
        In Port:      e2/5
    Instructions: Apply-Actions
        Action: FORWARD
            Out Port:  e2/1
        Meter id: 1023
    Statistics:
        Total Pkts: 0
        Total Bytes: 0
```

History

Release version	Command history
08.0.20	This command was introduced.

show openflow groups

Displays the maximum number of actions in a bucket, the maximum number of buckets in a group and the maximum number of groups.

- Syntax

show openflow groups *group-id*
- Parameters

groups *group-id*
Shows details of a specific OpenFlow group.
- Modes

User EXEC mode
Privileged EXEC mode
Global configuration mode
- Command Output

The **show openflow groups** command displays the following information:

Output field	Description
Group	Maximum number of group in a flow
Bucket	Number of bucket per group
Action	Number of action per bucket

Examples

```
device#show openflow groups
Max number of groups           : 512
Max number of buckets per group : 64
Max number of actions per bucket : 1

Max number of SELECT groups    : 120
Max number of buckets in SELECT group: 8
Starting Trunk ID for SELECT groups : 257
Group id 1

    Transaction id      4043243760
    Type                ALL
    Packet Count        0
    Byte Count          0
    Flow Count          0
    Number of buckets    2
bucket #1
    Weight              0
    Number of actions    1
    action 1: out port: 2/3

    bucket #2
    Weight              0
    Number of actions    1
    action 1: out port: 2/4

----

Total no. of entries printed: 1
```

History	Release version	Command history
	08.0.20	This command was introduced.

show openflow interfaces

Displays the information about the interfaces in a OpenFlow flow.

Syntax **show openflow interfaces**

Modes User EXEC mode
Privileged EXEC mode
Global configuration mode

Usage Guidelines

Command Output The **show openflow interfaces** command displays the following information:

Output field	Description
Port	Port Number
Link	Link status
Speed	Configured speed
Tag	Tag status
Mac Address	MAC address of the port
Mode	Gives the information about the layers

Examples

```
device# openflow enable layer3 hybrid
device# show openflow interfaces

Total number of Openflow interfaces: 5

Port  Link      Speed Tag  MAC              OF-portid Name      Mode
1/1   Up          1G    Yes  000c.dbf5.bd00  1          Layer2   Layer2
1/2   Up          1G    Yes  000c.dbf5.bd01  2          Layer2   Layer2
1/3   Up          1G    Yes  000c.dbf5.bd01  3          Hybrid-Layer3 Hybrid-Layer3
1/4   Up          1G    Yes  000c.dbf5.bd01  4          Hybrid-Layer3 Hybrid-Layer3
1/5   Up          1G    Yes  000c.dbf5.bd01  5          Hybrid-Layer3 Hybrid-Layer3
```

This command displays information for a particular interface on a specific slot and port..

```
device# show interface ethernet 1/1/6

GigabitEthernet1/1/6 is up, line protocol is up
  Port up for 51 minutes 53 seconds
  Hardware is GigabitEthernet, address is 748e.f8e7.d901 (bia 748e.f8e7.d901)
  Configured speed auto, actual 1Gbit, configured duplex fdx, actual fdx
  Configured mdi mode AUTO, actual MDI
  Member of L2 VLAN ID 100, port is untagged, port state is FORWARDING
  BPDU guard is Disabled, ROOT protect is Disabled, Designated protect is Disabled
  Link Error Dampening is Disabled
  STP configured to ON, priority is level0, mac-learning is enabled
OpenFlow enabled, Openflow Index 1, Flow Type Layer2
  Flow Control is config enabled, oper enabled, negotiation disabled
  Mirror disabled, Monitor disabled
  Not member of any active trunks
  Not member of any configured trunks
  No port name
  Inter-Packet Gap (IPG) is 96 bit times
  MTU 1500 bytes, encapsulation ethernet
  300 second input rate: 3904 bits/sec, 7 packets/sec, 0.00% utilization
  300 second output rate: 0 bits/sec, 0 packets/sec, 0.00% utilization
  23153 packets input, 1530094 bytes, 0 no buffer
  Received 1721 broadcasts, 21432 multicasts, 0 unicasts
  0 input errors, 0 CRC, 0 frame, 0 ignored
  0 runts, 0 giants
  0 packets output, 0 bytes, 0 underruns
  Transmitted 0 broadcasts, 0 multicasts, 0 unicasts
  0 output errors, 0 collisions
  Relay Agent Information option: Disabled

Egress queues:
Queue counters      Queued packets      Dropped Packets
  0                  0                    0
  1                  0                    0
  2                  0                    0
  3                  0                    0
  4                  0                    0
  5                  0                    0
  6                  0                    0
  7                  0                    0
```

History		
	Release version	Command history
	08.0.20	This command was introduced.

show openflow meters

Displays all the meters in a OpenFlow flow.

Syntax **show openflow meters** *meter-id*

Parameters **meters** *meter-id*

Shows details of a specific OpenFlow meter.

Modes User EXEC mode

Privileged EXEC mode

Global configuration mode

Command Output The **show openflow meters** command displays the following information:

Output field	Description
Meter-id	Meter number
Band	Number of bands in a meter
Band type	Band type (supported type: Drop, DSCP_REMARK)
Rate	Rate of the band
Counter	Band specific counter

Examples The following example displays output with single meter band.

```
device(config)# show openflow meters 1
Meter id: 1

Transaction id:      1437
Meter Flags:         KBPS BURST STATS
Flow Count:          0
Number of bands:     1
In packet count:     -NA-
In byte count:        0

Band Type:          DROP

Rate:                750000
Burst size:           1500          kb
In packet band count: -NA-
In byte band count:   0
```

The following example displays output with two meter bands.

```
device(config)# show openflow meters 2
Meter id: 2

Transaction id:      1438
Meter Flags:         KBPS BURST STATS
Flow Count:          0
Number of bands:     2
In packet count:     -NA-
In byte count:       0

Band Type:    DSCP-REMARK

Rate:          750000
Burst size:    1500          kb
Prec level:    1
In packet band count: -NA-
In byte band count:  0

Band Type:    DROP

Rate:          1000000
Burst size:    2000          kb
In packet band count: -NA-
In byte band count:  0
```

History	Release version	Command history
	08.0.20	This command was introduced.

show packet-inerror-detect

Displays details related to the monitoring for inError packets for configured ports.

Syntax **show packet-inerror-detect**

Modes Privileged EXEC mode
Global configuration mode
Interface configuration mode

Usage Guidelines Use this show command to view details related to the monitoring of inError packets for configured ports.

Command Output The **show packet-inerror-detect** command displays the following information:

Output field	Description
Sampling interval	Displays the configured sampling interval.
Port	Identifies a port.
Packet inError count	The number of inError packets received in the sampling interval for the specific port.
State	Displays the status for the specific port.

Examples The following example displays details related to the monitoring for inError packets for configured ports.

```
device# show packet-inerror-detect
Sampling interval 5 secs

Port      Packet inError count State
1/1/1     30                  Operational
1/1/37    10                  ERR-DISABLED
2/1/1     100                 Operational
```

History	Release version	Command history
	07.3.00g	This command was introduced.

show power-savings-statistics

Displays the power savings statistics for the device.

Syntax **show power-savings-statistics**

Modes Global configuration mode

Examples The following example displays the power savings statistics for the device.

```
device(config)# show power-savings-statistics

Warning - The below is a theoretical calibrated estimation, there may be +- 5%
deviation on the data.

The Power statistics of the switch for the last 5 minutes is

The total power consumption of the switch for the past 5 minutes is
-----> 76064 milli Watts

The total power savings after enabling EEE for the past 5 minutes is
-----> 3598 milli Watts

The power efficiency of the Switch after Enabling EEE for the past 5 min is
-----> 4%
```

The Port specific statistics for the past 5 minutes is

Port	EEE-State	Traffic	Power_Rating	Power_Consumed	
Power_Consumed		Power_Efficiency			
mW		Port Utilization%	in mW	in mW	in
1/1/1	Enable	0	333	7	
257		77			
1/1/2	Enable	0	33	76	
257		77			
1/1/3	Enable	0	333	76	
257		77			
1/1/4	Enable	0	333	76	
257		77			
1/1/5	Enable	0	333	76	
257		77			
1/1/6	Enable	0	333	76	
257		77			
1/1/13	Enable	0	333	76	
257		77			
1/1/14	Enable	0	333	76	
257		77			
1/1/15	Enable	0	333	76	
257		77			
1/1/16	Enable	0	333	76	
257		77			
1/1/21	Enable	0	333	76	
257		77			
1/1/22	Enable	0	333	76	
257		77			
1/1/23	Enable	0	333	76	
257		77			
1/1/24	Enable	0	333	76	
257		77			
1/2/1	Enable	0	0	0	
0		0			
1/2/2	Enable	0	0	0	
0		0			
1/2/3	Enable	0	0	0	
0		0			
1/2/4	Enable	0	0	0	
0		0			

History	Release version	Command history
	08.0.30	This command was introduced.

show priority-flow-control

Displays the priority flow control (PFC) on the system.

Syntax **show priority-flow-control**

Modes Privileged EXEC mode

Examples The following example shows the PFC status of all priority groups.

```
Device# show priority-flow-control

Global PFC Status: Enabled
PFC Enabled on PG0
PFC Disabled on PG1
PFC Disabled on PG2
PFC Disabled on PG3
```

The following example shows the PFC status disabled.

```
Device# show priority-flow-control

Global PFC Status: Disabled
```

History	Release version	Command history
	8.0.10	This command was introduced.

show qos egress-buffer-profile

Displays information about egress buffer profiles.

- Syntax

show qos egress-buffer-profile [*user-profile-name* | **all**]
- Parameters

user-profile-name

Displays information for the specified egress buffer profile.

all

Displays information for all egress buffer profiles configured in the system and a list of all ports attached to any egress buffer profile.

Modes Global configuration mode

Examples The following example displays information for an egress buffer profile named egress1.

```
Device(config)# show qos egress-buffer-profile egress1

Egress Buffer Profile: egress1
Ports attached: 1/1/2
Per Queue Details:      Share Level:
Queue 0                  level4-1/9
Queue 1                  level3-1/16
Queue 2                  level3-1/16
Queue 3                  level3-1/16
Queue 4                  level3-1/16
Queue 5                  level3-1/16
Queue 6                  level3-1/16
Queue 7                  level2-1/32
```

History	Release version	Command history
	8.0.10	This command was introduced.

show qos ingress-buffer-profile

Displays information about ingress buffer profiles.

Syntax **show qos ingress-buffer-profile** [*user-profile-name* | **all**]

- Parameters

user-profile-name

Displays information for the specified ingress buffer profile.

all

Displays information for all the ingress buffer profiles configured in the system and a list of their XOFF threshold levels.
- Modes

Global configuration mode
- Examples

The following example displays information for all the ingress buffer profiles configured in the system and their XOFF threshold levels.

```
Device(config)# show qos ingress-buffer-profile all

Ingress Buffer Profile: i1
Ports attached: 1/1/1
Per PG Detail:      XOFF Level:
PG 0                 level1-1/64
PG 1                 level3-1/16
PG 2                 level4-1/9
PG 3                 level5-1/5

Ingress Buffer Profile: ing1
Ports attached: --
Per PG Detail:      XOFF Level:
PG 0                 level6-1/3
PG 1                 level2-1/32
PG 2                 level2-1/32
PG 3                 level2-1/32
```

History	Release version	Command history
	8.0.20	This command was introduced.

show qos-internal-trunk-queue

Displays the queue-share level of inter-packet-processor (inter-pp) links used to connect master and slave units in ICX 7450 devices.

Syntax **show qos-internal-trunk-queue**

Modes Global configuration mode

Examples The following example displays the queue-share level applied on egress queues of inter-pp links in a system.

```
device(config)#show qos-internal-trunk-queue
Per Queue Details:      Share Level:
Queue 0                  level7-1/2
Queue 1                  level3-1/16
Queue 2                  level3-1/16
Queue 3                  level3-1/16
Queue 4                  level3-1/16
Queue 5                  level3-1/16
Queue 6                  level3-1/16
Queue 7                  level3-1/16
```

History	Release version	Command history
	08.0.20	This command was introduced.

show qos priority-to-pg

Displays priority-to-priority-group (PG) mapping for priority flow control (PFC).

- Syntax** **show qos priority-to-pg**
- Modes** Global configuration mode
- Usage Guidelines** This command displays priority-to-PG mapping for the following flow control modes:
- PFC
 - Symmetrical flow control
 - Asymmetrical flow control

Examples The following example shows priority-to-PG mapping for PFC.

```
Device(config)# show qos priority-to-pg

QoS Internal Priority 0 mapped to Priority Group 0
QoS Internal Priority 1 mapped to Priority Group 0
QoS Internal Priority 2 mapped to Priority Group 1
QoS Internal Priority 3 mapped to Priority Group 1
QoS Internal Priority 4 mapped to Priority Group 1
QoS Internal Priority 5 mapped to Priority Group 2
QoS Internal Priority 6 mapped to Priority Group 2
QoS Internal Priority 7 mapped to Priority Group 4
```

The following example shows priority-to-PG mapping for 802.3x (Flow-Control). Honor is enabled.

```
Device(config)# show qos priority-to-pg

QoS Internal Priority 0 mapped to Priority Group 0
QoS Internal Priority 1 mapped to Priority Group 0
QoS Internal Priority 2 mapped to Priority Group 1
QoS Internal Priority 3 mapped to Priority Group 1
QoS Internal Priority 4 mapped to Priority Group 1
QoS Internal Priority 5 mapped to Priority Group 2
QoS Internal Priority 6 mapped to Priority Group 2
QoS Internal Priority 7 mapped to Priority Group 4
```

The following example shows priority-to-PG mapping for symmetrical flow control for 802.3x (Flow-Control) in Both mode (Generate and Honor are enabled) or Generate-only mode.

```
Device(config)# symmetrical-flow-control enable
Device(config)# show qos priority-to-pg

QoS Internal Priority 0 mapped to Priority Group 7
QoS Internal Priority 1 mapped to Priority Group 7
QoS Internal Priority 2 mapped to Priority Group 7
QoS Internal Priority 3 mapped to Priority Group 7
QoS Internal Priority 4 mapped to Priority Group 7
QoS Internal Priority 5 mapped to Priority Group 2
QoS Internal Priority 6 mapped to Priority Group 2
QoS Internal Priority 7 mapped to Priority Group 4
```

The following example enables flow control on all priorities and shows the priority-to-PG mapping.

```
Device(config)# symmetrical-flow-control enable all
Device(config)# show qos priority-to-pg

QoS Internal Priority 0 mapped to Priority Group 7
QoS Internal Priority 1 mapped to Priority Group 7
QoS Internal Priority 2 mapped to Priority Group 7
QoS Internal Priority 3 mapped to Priority Group 7
QoS Internal Priority 4 mapped to Priority Group 7
QoS Internal Priority 5 mapped to Priority Group 7
QoS Internal Priority 6 mapped to Priority Group 7
QoS Internal Priority 7 mapped to Priority Group 4
```


History	Release version	Command history
	8.0.10	This command was introduced.

show qos-profiles

Displays information about QoS profiles

Syntax	show qos-profiles { all name }		
Parameters	all		
		Displays information for all profiles.	
	name		
		Displays information for the specified profile.	
Modes	Global configuration mode		
Examples	The following example displays information for all the queues on an FSX device.		

```
Device# show qos-profiles all
bandwidth scheduling mechanism: weighted priority
Profile qosp7      : Priority7  bandwidth requested  25% calculated  25%
Profile qosp6      : Priority6  bandwidth requested  15% calculated  15%
Profile qosp5      : Priority5  bandwidth requested  12% calculated  12%
Profile qosp4      : Priority4  bandwidth requested  12% calculated  12%
Profile qosp3      : Priority3  bandwidth requested  10% calculated  10%
Profile qosp2      : Priority2  bandwidth requested  10% calculated  10%
Profile qosp1      : Priority1  bandwidth requested  10% calculated  10%
Profile qosp0      : Priority0  bandwidth requested   6% calculated   6%
```

The following example displays information, including multicast queue weights, for all the queues on an ICX 7450 device.

```
Device#show qos-profiles all
bandwidth scheduling mechanism: mixed weighted priority with strict priority
Unicast Traffic
Profile qosp7      : Priority7 (Highest) Set as strict priority
Profile qosp6      : Priority6          Set as strict priority
Profile qosp5      : Priority5          bandwidth requested  25% calculated  25%
Profile qosp4      : Priority4          bandwidth requested  15% calculated  15%
Profile qosp3      : Priority3          bandwidth requested  15% calculated  15%
Profile qosp2      : Priority2          bandwidth requested  15% calculated  15%
Profile qosp1      : Priority1          bandwidth requested  15% calculated  15%
Profile qosp0      : Priority0 (Lowest) bandwidth requested  15% calculated  15%
Multicast Traffic
Profile qosp7+qosp6      : Priority7 (Highest), 6      Set as strict
priority
Profile qosp5            : Priority5                  bandwidth
requested  25% calculated  25%
Profile qosp4+qosp3+qosp2 : Priority4, 3, 2            bandwidth
requested  45% calculated  45%
Profile qosp1+qosp0      : Priority1, 0 (Lowest)       bandwidth
requested  30% calculated  30%
```

History	Release version	Command history
	08.0.20	This command was modified to display information for multicast queue weights on ICX 7450 and ICX 7750 devices.

show qos scheduler-profile

Displays information about scheduler profiles.

Syntax `show qos scheduler-profile { all user-profile-name }`

Parameters `all`

Displays information for all the scheduler profiles configured in the system and a list of all the ports attached to any scheduler profile.

user-profile-name

Displays information for the specified scheduler profile only.

Modes Global configuration mode

Usage Guidelines A scheduler profile must be configured before it can be displayed.

Information can be displayed for a maximum of eight scheduler profiles.

On ICX 7750 and ICX 7450 devices this command also displays information for multicast queue weights.

Examples The following example displays information for a scheduler profile named user1.

```
Device(config)# show qos scheduler-profile user1
```

```
User Scheduler Profile: user1    Scheduling Option: Weighted round-robin
Ports attached: 1/1/1
Per Queue details:      Bandwidth%
Traffic Class 0          1%
Traffic Class 1          1%
Traffic Class 2         10%
Traffic Class 3         10%
Traffic Class 4         10%
Traffic Class 5         10%
Traffic Class 6         20%
Traffic Class 7         38%
```

The following example displays information for all the scheduler profiles configured in the system.

```
Device(config)# show qos scheduler-profile all

User Scheduler Profile: user1    Scheduling Option: Weighted round-robin
Ports attached: 1/1/1
Per Queue details:      Bandwidth%
Traffic Class 0          1%
Traffic Class 1          1%
Traffic Class 2          10%
Traffic Class 3          10%
Traffic Class 4          10%
Traffic Class 5          10%
Traffic Class 6          20%
Traffic Class 7          38%

User Scheduler Profile: user2    Scheduling Option: Strict scheduling
Ports attached: --

User Scheduler Profile: user3    Scheduling Option: Mixed-SP-WRR
Ports attached: --
Per Queue details:      Bandwidth%
Traffic Class 0          15%
Traffic Class 1          15%
Traffic Class 2          15%
Traffic Class 3          15%
Traffic Class 4          15%
Traffic Class 5          25%
Traffic Class 6          sp
Traffic Class 7          sp

User Scheduler Profile: user4    Scheduling Option: Weighted round-robin
Ports attached: --
Per Queue details:      Bandwidth%
Traffic Class 0          3%
Traffic Class 1          3%
Traffic Class 2          3%
Traffic Class 3          3%
Traffic Class 4          3%
Traffic Class 5          3%
Traffic Class 6          7%
Traffic Class 7          75%
```

The following example displays information, including multicast queue weights, for a scheduler profile named profile1 on ICX 7450 and ICX 7750 devices.

```
Device(config)# show qos scheduler-profile profile1
User Scheduler Profile: profile1  Scheduling Option: Weighted round-robin
Unicast per Queue details:      Bandwidth%
Traffic Class 0                 8%
Traffic Class 1                 8%
Traffic Class 2                 8%
Traffic Class 3                 8%
Traffic Class 4                 8%
Traffic Class 5                 8%
Traffic Class 6                 8%
Traffic Class 7                 44%
Multicast per Queue details:    Bandwidth%
Traffic Class 0,1               16%
Traffic Class 2,3,4             24%
Traffic Class 5                 8%
Traffic Class 6,7               52%
```

History

Release version	Command history
8.0.10	This command was introduced.
8.0.20	This command was modified to display information for multicast queue weights on ICX 7450 and ICX 7750 devices.

show rmon

Displays the Remote monitoring (RMON) agent status and information about RMON alarms, events, history, logs, and statistics on the interface.

Syntax **show rmon** { **alarm** *alarm-number* | **event** *event-number* | **history** *history-index* | **logs** *event-index* | **statistics** [*number* | *interface-type* | *interface-number*] }

Parameters	alarm	Specifies to display the RMON alarm table.
	<i>alarm-number</i>	Specifies the alarm index identification number. Valid values range from 1 through 65535.
	event	Specifies to display the RMON event table.
	<i>event-number</i>	Specifies the event index identification number. Valid values range from 1 through 65535.
	history	Specifies to display the history control data entries for port or interface.
	<i>history-number</i>	Specifies the history index identification number of the history entry.
	logs	Specifies to display the RMON logging table where RMON log entries are stored.
	<i>event-index</i>	Specifies the event index identification number. Valid values range from 1 through 65535.
	statistics	Specifies to display the RMON Ethernet statistics; and the statistics group that collects statistics on promiscuous traffic across an interface and total traffic into and out of the agent interface. Valid values range from 1 through 65535.
	<i>statistics-number</i>	Specifies the statistics index identification number of the statistics entry.
	<i>interface-type</i>	Specifies the ethernet interface or management port.
	<i>interface-number</i>	Specifies the interface or management port number.

Modes Privileged EXEC mode
Global configuration mode

Command Output The **show rmon** command displays the following information:

Output field	Description
Rising threshold	The sampling value limit, beyond which the rising alarm is triggered.
Falling threshold	The sampling value limit, beyond which the falling alarm is triggered.

Output field	Description
Octets	The total number of octets of data received on the network. This number includes octets in bad packets. This number does not include framing bits but does include Frame Check Sequence (FCS) octets.
Drop events	Indicates an overrun at the port. The port logic could not receive the traffic at full line rate and had to drop some packets as a result. The counter indicates the total number of events in which packets were dropped by the RMON probe due to lack of resources. This number is not necessarily the number of packets dropped, but is the number of times an overrun condition has been detected.
Packets	The total number of packets received. This number includes bad packets, broadcast packets, and multicast packets.
Broadcast pkts	The total number of good packets received that were directed to the broadcast address. This number does not include multicast packets.
Multicast pkts	The total number of good packets received that were directed to a multicast address. This number does not include packets directed to the broadcast address.
CRC align errors	The total number of packets received that were from 64 - 1518 octets long, but had either a bad FCS with an integral number of octets (FCS Error) or a bad FCS with a non-integral number of octets (Alignment Error). The packet length does not include framing bits but does include FCS octets.
Undersize pkts	The total number of packets received that were less than 64 octets long and were otherwise well formed. This number does not include framing bits but does include FCS octets.
Fragments	The total number of packets received that were less than 64 octets long and had either a bad FCS with an integral number of octets (FCS Error) or a bad FCS with a non-integral number of octets (Alignment Error). It is normal for this counter to increment, since it counts both runts (which are normal occurrences due to collisions) and noise hits. This number does not include framing bits but does include FCS octets.
Oversize packets	The total number of packets received that were longer than 1518 octets and were otherwise well formed. This number does not include framing bits but does include FCS octets.
NOTE 48GC modules do not support count information on oversized packets and report 0.	

Output field	Description
Jabbers	The total number of packets received that were longer than 1518 octets and had either a bad FCS with an integral number of octets (FCS Error) or a bad FCS with a non-integral number of octets (Alignment Error).
	<p>NOTE</p> <p>This definition of jabber is different from the definition in IEEE-802.3 section 8.2.1.5 (10BASE5) and section 10.3.1.4 (10BASE2). These documents define jabber as the condition where any packet exceeds 20 ms. The allowed range to detect jabber is between 20 ms and 150 ms.</p> <p>This number does not include framing bits but does include FCS octets.</p> <p>NOTE</p> <p>48GC modules do not support count information on jabbers and report 0.</p>
Collisions	The best estimate of the total number of collisions on this Ethernet segment.
64 octets pkts	The total number of packets received that were 64 octets long. This number includes bad packets. This number does not include framing bits but does include FCS octets.
65 to 127 octets pkts	The total number of packets received that were 65 - 127 octets long. This number includes bad packets. This number does not include framing bits but does include FCS octets.
128 to 255 octets pkts	The total number of packets received that were 128 - 255 octets long. This number includes bad packets. This number does not include framing bits but does include FCS octets.
256 to 511 octets pkts	The total number of packets received that were 256 - 511 octets long. This number includes bad packets. This number does not include framing bits but does include FCS octets.
512 to 1023 octets pkts	The total number of packets received that were 512 - 1023 octets long. This number includes bad packets. This number does not include framing bits but does include FCS octets.
1024 to 1518 octets pkts	The total number of packets received that were 1024 - 1518 octets long. This number includes bad packets. This number does not include framing bits but does include FCS octets.
Event Index	The event index identification number.
Log Index	The log index identification number.
Log Generated time	The time at which the log is generated.
Log Description	Indicates the type of alarm; whether it is a rising or falling alarm.

Examples The following example shows the output of the **show rmon alarm** command.

```
device(config)# show rmon alarm
Alarm 1 is active, owned by monitor
Monitors etherStatsPkts.13 every 5 seconds
Taking absolute samples, last value was 675
Rising threshold is 100, assigned to event 1
Falling threshold is 0, assigned to event 1
On startup enable rising or falling alarm

Alarm 2 is active, owned by monitor
Monitors etherStatsPkts.2 every 5 seconds
Taking absolute samples, last value was 414
Rising threshold is 100, assigned to event 3
Falling threshold is 0, assigned to event 3
On startup enable rising or falling alarm
```

The following example shows the output of the **show rmon event** command.

```
device(config)# show rmon event
Event 1 is active, owned by monitor
Description is testing
Event firing causes log, community
Batch ID 0, argument <none>
Last fired at system up time 3 minutes 52 seconds

Event 2 is active, owned by monitor
Description is logging
Event firing causes log and trap, community public
Batch ID 0, argument <none>
Last fired at system up time 8 minutes 12 seconds
```

The following example shows the output of the **show rmon history history-index** command.

```
device(config)# show rmon history 1
History 1 is active, owned by monitor
Monitors interface mgmt1 (ifIndex 25) every 30 seconds
25 buckets were granted to store statistics
```

The following example shows the output of the **show rmon logs** command.

```
device(config)# show rmon logs
Event Index = 1
  Log Index = 1
  Log Generated time = 00:03:52 (23200)
  Log Description  = rising alarm

Event Index = 2
  Log Index = 1
  Log Generated time = 00:08:12 (49200)
  Log Description  = rising alarm

Event Index = 3
  Log Index = 1
  Log Generated time = 00:05:12 (31200)
  Log Description  = rising alarm

Event Index = 4
  Log Index = 1
  Log Generated time = 00:01:32 (9200)
  Log Description  = falling alarm

  Log Index = 2
  Log Generated time = 00:02:52 (17200)
  Log Description  = rising alarm
```

The following example shows the output of the **show rmon logs event-index** command.

```
device(config)# show rmon logs 2
Event Index = 2
  Log Index = 1
  Log Generated time = 00:08:12 (49200)
  Log Description  = rising alarm
```


The following example shows the output of the **show rmon statistics number** command.

```
device(config)# show rmon statistics 1
Ethernet statistics 1 is active, owned by monitor
  Interface 1/1/1 (ifIndex 1) counters
    Octets          0
    Drop events      0
    Broadcast pkts   0
    CRC align errors 0
    Oversize pkts    0
    Jabbers          0
    Packets          0
    Multicast pkts   0
    Undersize pkts   0
    Fragments        0
    Collisions       0

  Packet size counters
    64               0
    128 to 255       0
    512 to 1023      0
    65 to 127        0
    256 to 511       0
    1024 to 1518     0
```

The following example shows the statistics of the ethernet interface 1/2/1.

```
device(config)# show rmon statistics ethernet 1/2/1
Ethernet statistics 65 is active, owned by monitor
  Interface 1/2/1 (ifIndex 65) counters
    Octets          30170677670
    Drop events      0
    Broadcast pkts   0
    CRC align errors 0
    Oversize pkts    0
    Jabbers          0
    Packets          72281139
    Multicast pkts   66309417
    Undersize pkts   0
    Fragments        0
    Collisions       0

  Packet size counters
    64               0
    128 to 255       19353559
    512 to 1023      17980963
    65 to 127        10703415
    256 to 511       18658554
    1024 to 1518     5584648
```

History

Release version	Command history
08.0.20	The logs keyword was introduced.

show running interface

Displays information about the interface.

Syntax	show running interface [ethernet <i>stack/slot/port</i> [to ethernet <i>stack/slot/port</i>] loopback <i>loopback-number</i> management <i>por-id</i> tunnel <i>tunnel-id</i> ve <i>ve-number</i>]	
Parameters	ethernet <i>stack/slot/port</i>	Specifies the configuration on a physical interface. On standalone devices specify the interface ID in the format slot/port-id; on stacked devices you must also specify the stack ID, in the format stack-id/slot/port-id.
	to	Specifies information for a range of physical interfaces.
	loopback <i>loopback-number</i>	Specifies information for a loopback interface.
	management <i>port-id</i>	Specifies information for a management port.
	tunnel <i>tunnel-id</i>	Specifies information for a tunnel interface.
	ve <i>ve-number</i>	Specifies information for a virtual interface.
Modes	Privileged EXEC mode	
Examples	The following example displays output from the show running interface command, showing that ACLs 10 and f10 are applied to interface 1/1/9 to control neighbor access. Device#show running interface ethernet 1/1/9 interface ethernet 1/1/9 ip address 15.1.1.5 255.255.255.0 ip pim-sparse ip pim neighbor-filter 10 ip ospf area 0 ipv6 address 201::1/64 ipv6 ospf area 0 ipv6 pim-sparse ipv6 pim neighbor-filter f10	
History	Release version	Command history
	8.0.20a	This command was modified to display neighbor filter information.

show running-config interface ethernet

Displays the status of a specific Ethernet interface.

- Syntax

show running-config interface ethernet { stackid / slot / port }
- Parameters

stackid / slot / port
Stack ID number, slot number, and port number for an existing Ethernet interface.
- Modes

Privileged EXEC mode
- Examples

This example displays the running configuration for an Ethernet interface including the configured bandwidth.

```
device# show running-config interface ethernet 1/1/9
interface ethernet 1/1/9
  bandwidth 2000
  ip address 10.1.1.5 10.255.255.0
  ip pim
  ip ospf area 0
  ipv6 address 201::1/64
  ipv6 ospf area 0
  ipv6 pim-sparse
  ipv6 pim dr-priority 50
  ipv6 pim border
  ipv6 mld version 2
```

History	Release version	Command history
	8.0.30	This command was modified to include configured bandwidth status.

show running-config interface tunnel

Displays the status of a specific tunnel interface.

Syntax **show running-config interface tunnel** { *tunnel-number* }

Parameters	<i>tunnel-number</i>	Specifies the tunnel number.
-------------------	----------------------	------------------------------

Modes Privileged EXEC mode

Examples This example displays the running configuration for a tunnel interface, including the configured bandwidth.

```
device# show running-config interface tunnel 2
interface tunnel 2
 tunnel mode gre ip
 tunnel source 10.0.0.1
 tunnel destination 10.10.0.1
 ip address 10.0.0.1/24
 bandwidth 2000
```

History	Release version	Command history
	8.0.30	This command was modified to include configured bandwidth status.

show running-config interface ve

Displays the status of a specific Virtual Ethernet (VE) interface.

Syntax **show running-config interface ve** { *vlan_id* }

Parameters *vlan_id*
Specifies the configured corresponding VLAN interface.

Modes Privileged EXEC mode

Examples This example displays the running configuration for a VE interface, including the configured bandwidth.

```
device# show running-config interface ve 20
interface ve 20
 ip address 10.21.21.22 10.255.255.0
 ip pim-sparse
 ip ospf area 0
 bandwidth 2000
 ipv6 address 2000::2/64
 ipv6 ospf area 0
```

History

Release version	Command history
8.0.30	This command was modified to include configured bandwidth status.

show span designated-protect

Displays a list of all ports that are not allowed to go into the designated forwarding state.

Syntax **show span designated-protect**

Modes Privileged EXEC mode
 Global configuration mode
 Interface configuration mode

Examples The following example indicates that the designated forwarding state is disallowed for interfaces 2/1/7, 2/1/19, and 2/2/3.

```
device(config)# show span designated-protect
Designated Protection Enabled on:
Ports: (U2/M1)      7 19
Ports: (U2/M2)      3
```

History	Release version	Command history
	07.3.00g	This command was introduced.

show stack

Displays information about the units in a stack and a representation of the stack topology.

Syntax **show stack** *num*

Parameters *num*
Displays information for the specified stack unit ID.

Modes Privileged EXEC mode

Command Output The **show stack** command displays the following information:

Output field	Description
ID	Specifies the identification number of the stack unit. Each unit in the stack has a unique ID number.
Type	Specifies the type (model) of the stack unit.
Role	Specifies the role of the stack unit. The roles are controller, standby, or member.
Mac Address	Specifies the MAC address of the stack unit. The roles are controller, standby, or member.
Pri	Specifies the priority value assigned to the stack unit. The default value is 128.
State	Specifies whether the stack unit is local or remote. A unit with a State value of Local is the active controller. Units with a State value of Remote are either standby units or member units.
Comment	Indicates if the stack unit is ready (available).

Examples The following example displays information about a stack with six stack trunks, including a representation of the stack topology.

```
device# show stack
```

```
T=21h22m31.3: alone: standalone, D: dynamic cfg, S: static, A=10, B=11, C=12
```

ID	Type	Role	Mac Address	Pri	State	Comment
1	S	ICX7750-48XGF	active	cc4e.246d.9e00	128	local Ready
2	S	ICX7750-48XGF	standby	cc4e.246d.8d80	0	remote Ready
3	S	ICX7750-48XGF	member	cc4e.246d.9b00	0	remote Ready
4	S	ICX7750-48XGF	member	cc4e.246d.9c80	0	remote Ready
5	S	ICX7750-20QXG	member	cc4e.2439.2a80	0	remote Ready
6	S	ICX7750-20QXG	member	cc4e.2439.3700	0	remote Ready
7	S	ICX7750-20QXG	member	cc4e.2439.3880	0	remote Ready
8	S	ICX7750-20QXG	member	cc4e.2439.2d00	0	remote Ready
9	S	ICX7750-48XGC	member	cc4e.2439.1a00	0	remote Ready
10	S	ICX7750-48XGC	member	cc4e.2439.1680	0	remote Ready
11	S	ICX7750-48XGC	member	cc4e.2439.1d80	0	remote Ready
12	S	ICX7750-48XGC	member	cc4e.2439.1280	0	remote Ready

```

      active
      +---+
-2/1| 1 |2/4--3/1| C |3/4==2/1| B |2/4==2/1| A |2/4--2/1| 9 |2/4--2/1| 8 |2/4=
| +---+ +---+ +---+ +---+ +---+ +---+
|
| standby
| +---+ +---+ +---+ +---+ +---+ +---+
-2/4| 2 |2/1==2/4| 3 |2/1--2/4| 4 |2/1==2/4| 5 |2/1--2/4| 6 |2/1==2/4| 7 |2/1=
| +---+ +---+ +---+ +---+ +---+ +---+
Standby u2 - protocols ready, can failover
Current stack management MAC is cc4e.246d.9e00

```


show stack connection

Displays a representation of stack topology and a detailed connection report that contains information on connection errors or hardware failures.

Syntax **show stack connection**

Modes Privileged EXEC mode

Examples The following example displays a representation of a ring topology that has seven stack units and details on each of the trunk link connections.

```
device# show stack connection
Probing the topology. Please wait ...
device#
    active
    +---+      +---+      +---+      +---+      +---+      +---+
=2/1| 4 |2/6==2/6| 3 |2/1==2/1| 2 |2/6==2/6| 1 |2/1==2/1| 7 |2/6==2/6| 6 |2/1=
| +---+      +---+      +---+      +---+      +---+      +---+
|                                     standby |
|                                     +---+ |
|-----2/1| 5 |2/6=
|                                     +---+

trunk probe results: 7 links
Link 1: u7 -- u1, num=5
1: 1/2/1 (T0) <----> 7/2/1 (T0)
2: 1/2/2 (T0) <----> 7/2/2 (T0)
3: 1/2/3 (T0) <----> 7/2/3 (T0)
4: 1/2/4 (T0) <----> 7/2/4 (T0)
5: 1/2/5 (T0) <----> 7/2/5 (T0)
Link 2: u2 -- u1, num=5
1: 1/2/6 (T1) <----> 2/2/6 (T1)
2: 1/2/7 (T1) <----> 2/2/7 (T1)
3: 1/2/8 (T1) <----> 2/2/8 (T1)
4: 1/2/9 (T1) <----> 2/2/9 (T1)
5: 1/2/10(T1) <----> 2/2/10(T1)
Link 3: u3 -- u2, num=5
1: 2/2/1 (T0) <----> 3/2/1 (T0)
2: 2/2/2 (T0) <----> 3/2/2 (T0)
3: 2/2/3 (T0) <----> 3/2/3 (T0)
4: 2/2/4 (T0) <----> 3/2/4 (T0)
5: 2/2/5 (T0) <----> 3/2/5 (T0)
Link 4: u4 -- u3, num=5
1: 3/2/6 (T1) <----> 4/2/6 (T1)
2: 3/2/7 (T1) <----> 4/2/7 (T1)
3: 3/2/8 (T1) <----> 4/2/8 (T1)
4: 3/2/9 (T1) <----> 4/2/9 (T1)
5: 3/2/10(T1) <----> 4/2/10(T1)
Link 5: u5 -- u4, num=5
1: 4/2/1 (T0) <----> 5/2/1 (T0)
2: 4/2/2 (T0) <----> 5/2/2 (T0)
3: 4/2/3 (T0) <----> 5/2/3 (T0)
4: 4/2/4 (T0) <----> 5/2/4 (T0)
5: 4/2/5 (T0) <----> 5/2/5 (T0)
Link 6: u6 -- u5, num=5
1: 5/2/6 (T1) <----> 6/2/1 (T0)
2: 5/2/7 (T1) <----> 6/2/2 (T0)
3: 5/2/8 (T1) <----> 6/2/3 (T0)
4: 5/2/9 (T1) <----> 6/2/4 (T0)
5: 5/2/10(T1) <----> 6/2/5 (T0)
Link 7: u7 -- u6, num=5
1: 6/2/6 (T1) <----> 7/2/6 (T1)
2: 6/2/7 (T1) <----> 7/2/7 (T1)
3: 6/2/8 (T1) <----> 7/2/8 (T1)
4: 6/2/9 (T1) <----> 7/2/9 (T1)
5: 6/2/10(T1) <----> 7/2/10(T1)
CPU to CPU packets are fine between 7 units.
```

show stack detail

Displays information on all units in the stack, including the role, MAC address, priority, status, and stack connections for each stack unit.

Syntax **show stack detail**

Modes Privileged EXEC mode

Command Output The **show stack detail** command displays the following information:

Output field	Description
ID	Specifies the identification number of the stack unit. Each unit in the stack has a unique ID number.
Type	Specifies the type (model) of the stack unit.
Role	Specifies the role of the stack unit. The roles are controller, standby, or member.
Mac Address	Specifies the MAC address of the stack unit. The roles are controller, standby, or member.
Pri	Specifies the priority value assigned to the stack unit. The default value is 128.
State	Specifies whether the stack unit is local or remote. A unit with a State value of Local is the active controller. Units with a State value of Remote are either standby units or member units.
Comment	Indicates if the stack unit is ready (available).
Unit #	Specifies the number assigned to the stack unit. Each unit in the stack has a unique unit number. (This is the same as the ID of the stack unit.)
Stack Port Status	Indicates whether the stack port is connected or disconnected. A port with the up status of up is connected to the stack, and a ports with the status of down (dn) is not connected to the stack.
Neighbors	Indicates units in the stack that are connected together. Each unit in the stack is connected to at least one other stack unit.
System uptime	Indicates the amount of time that the stack unit has been running since the last reset. The System uptime is listed for each unit in the stack.

Examples The following example displays information on a full ICX 7450 stack containing 12 units, with six different models.

```
device# show stack detail
```

```
T=17h38m45.2: alone: standalone, D: dynamic cfg, S: static, A=10, B=11, C=12
```

ID	Type	Role	Mac Address	Pri	State	Comment
1	S	ICX7450-24G	active	cc4e.246c.ff80	128	local Ready
2	S	ICX7450-24G	standby	cc4e.246d.02c8	0	remote Ready
3	S	ICX7450-24G	member	cc4e.246c.ffd0	0	remote Ready
4	S	ICX7450-24P	member	cc4e.246d.0520	0	remote Ready
5	S	ICX7450-48G	member	cc4e.246d.1c78	0	remote Ready
6	S	ICX7450-48G	member	cc4e.246d.1b78	0	remote Ready
7	S	ICX7450-48G	member	cc4e.246d.1df8	0	remote Ready
8	S	ICX7450-48P	member	cc4e.2489.8640	0	remote Ready
9	S	ICX7450-48GF	member	cc4e.246d.1478	0	remote Ready
10	D	ICX7450-24P	member	cc4e.246d.0638	0	remote Ready
11	D	ICX7450-24P	member	cc4e.246d.0778	0	remote Ready
12	D	ICX7450-48P	member	cc4e.246d.2938	0	remote Ready

```

      active      standby
+----+      +----+      +----+      +----+      +----+      +----+
3/1| 1 |4/1--3/1| 2 |4/1--3/1| 3 |4/1--3/1| 4 |4/1--3/1| 5 |4/1--3/1| 6 |4/1--
+----+      +----+      +----+      +----+      +----+      +----+
      |
      +----+      +----+      +----+      +----+      +----+      +----+
      | C |3/1--4/1| B |3/1--4/1| A |3/1--4/1| 9 |3/1--4/1| 8 |3/1--4/1| 7 |3/1--
      +----+      +----+      +----+      +----+      +----+      +----+

```

Will assign standby in 53 sec due to all ready

Standby u2 - wait for standby assignment due to election

Current stack management MAC is cc4e.246c.ff80

Image-Auto-Copy is Enabled.

Unit#	Stack-port1	Stack-port2	Neighbors Stack-port1	Stack-port2
1	dn (1/3/1)	up (1/4/1)	none	U2 (2/3/1)
2	up (2/3/1)	up (2/4/1)	U1 (1/4/1)	U3 (3/3/1)
3	up (3/3/1)	up (3/4/1)	U2 (2/4/1)	U4 (4/3/1)
4	up (4/3/1)	up (4/4/1)	U3 (3/4/1)	U5 (5/3/1)
5	up (5/3/1)	up (5/4/1)	U4 (4/4/1)	U6 (6/3/1)
6	up (6/3/1)	up (6/4/1)	U5 (5/4/1)	U7 (7/3/1)
7	up (7/3/1)	up (7/4/1)	U6 (6/4/1)	U8 (8/3/1)
8	up (8/3/1)	up (8/4/1)	U7 (7/4/1)	U9 (9/3/1)
9	up (9/3/1)	up (9/4/1)	U8 (8/4/1)	U10 (10/3/1)
10	up (10/3/1)	up (10/4/1)	U9 (9/4/1)	U11 (11/3/1)
11	up (11/3/1)	up (11/4/1)	U10 (10/4/1)	U12 (12/3/1)
12	up (12/3/1)	none	U11 (11/4/1)	none

```

Unit# System uptime
1      17 hours 38 minutes 45 seconds
2      17 hours 38 minutes 43 seconds
3      17 hours 38 minutes 45 seconds
4      17 hours 38 minutes 44 seconds
5      17 hours 38 minutes 44 seconds
6      17 hours 38 minutes 44 seconds
7      17 hours 38 minutes 44 seconds
8      17 hours 38 minutes 45 seconds
9      17 hours 38 minutes 43 seconds
10     17 hours 32 minutes 24 seconds
11     1 minutes 9 seconds
12     1 minutes 9 seconds
ICX7450-24 Route

```

show stack failover

Displays information about stack failover.

Syntax **show stack failover**

Modes Privileged EXEC mode

Usage Guidelines Use the **show stack failover** command to view information about rapid failover for the stack. This command displays if the standby is ready to takeover or not.

Examples The following example shows which unit is the current standby device and its status.

```
device# show stack failover  
  
Current standby is unit 2. state=ready  
Standby u2 - protocols ready, can failover
```

show stack flash

Displays information about flash memory for stack members.

Syntax **show stack flash**

Modes Privileged EXEC mode

Usage Guidelines Use the **show stack flash** command to display information about flash memory for stack members.

Command Output The **show stack flash** command displays the following information:

Output field	Description
ID	Specifies the identification number of the stack unit. Each unit in the stack has a unique ID number.
role	Specifies the role of the stack unit. The roles are controller, standby, or member.
priority	Specifies the priority value assigned to the stack unit. The default value is 128.
config	Indicates the port state (up or down) and identifies the port by number (stack-ID/slot/port). A port with the up status of up is connected to the stack, and a ports with the status of down (dn) is not connected to the stack.
The rest of the fields are used for debug purposes only.	

Examples The following example display flash memory information for an ICX 6610.

```
device# show stack flash
There is no startup-config.old
Stack flash that was read in bootup:
ICX6610-48P, ID =4, role= active, pri=200, config=1, jumbo=X PPVLAN=X S2M=0 FIPS=X
stack p: [0]=4/2/1 [1]=4/2/6 default p: 4/2/1(5) 4/2/6(5), , , hash-chain=X vlan#=X
ve#=X stp#=X
active-chg=0
Current written stack flash:
ICX6610-48P, ID =4, role= active, pri=200, config=1, jumbo=X PPVLAN=X S2M=0 FIPS=X
stack p: [0]=4/2/1 [1]=4/2/6 default p: 4/2/1(5) 4/2/6(5), , , hash-chain=X vlan#=X
ve#=X stp#=X
```

show stack link-sync

Displays the status of the link synchronization.

Syntax **show stack link-sync status**

Parameters **status**
Displays link status information.

Modes Privileged EXEC mode

Command Output The **show stack link-sync status** command displays the following information:

Output field	Description
STACKING_LINK_GLOBAL_CTRL messages (sent, received)	Number of global control messages sent and received.
STACKING_LINK_INDIVIDUAL_CTRL messages (sent, received)	Number of individual link control messages sent and received.
STACKING_LINK_STATUS messages (sent, received)	Number of link status control messages sent and received.
STACKING_POE_SCTRL messages (sent, received)	Number of Power over Ethernet (POE) control messages sent and received.
STACKING_POE_STATUS messages (sent, received)	Number of POE status messages sent and received.
global_ctrl_dest	Hexadecimal address of the global control destination.
individual_ctrl_dest	Hexadecimal address of the individual link control destination
status_dest	Number representing the destination status.

Examples The following example shows link synchronization information for an ICX 6610.

```
device# show stack link-sync status
STACKING LINK GLOBAL_CTRL messages sent: 0, received: 0
STACKING LINK INDIVIDUAL_CTRL messages sent: 359, received: 0
STACKING LINK STATUS messages sent: 22300, received: 128883
STACKING_POE_SCTRL messages sent: 0, received: 0
STACKING_POE_STATUS messages sent: 0, received: 0
global_ctrl_dest: ffffffff
individual_ctrl_dest: ee
status_dest: 30
```

show stack neighbors

Displays information about stack member neighbors.

Syntax **show stack neighbors**

Modes Privileged EXEC mode

Usage Guidelines Stack neighbors are identified by unit ID for each stack unit.

Command Output The **show stack neighbors** command displays the following information:

Output field	Description
U#	The identification number of the unit in the stack. Each unit in the stack has a unique identification number.
Stack-port1	Identifies the neighbor stack unit for stack-port1 of the stack unit with this unit identification number (U#). The neighbor stack unit for stack-port1 of each unit in the stack is listed.
Stack-port2	Identifies the neighbor stack unit for stack-port2 of the stack unit with this unit identification number (U#). The neighbor stack unit for stack-port2 of each unit in the stack is listed.

Examples The following example output is for an ICX 6610 device in a stack with seven members.

```

device# show stack neighbors
U#   Stack-port1           Stack-port2
1    unit7 (7/2/1-7/2/5)   unit2 (2/2/6-2/2/10)
2    unit3 (3/2/1-3/2/5)   unit1 (1/2/6-1/2/10)
3    unit2 (2/2/1-2/2/5)   unit4 (4/2/6-4/2/10)
4    unit5 (5/2/1-5/2/5)   unit3 (3/2/6-3/2/10)
5    unit4 (4/2/1-4/2/5)   unit6 (6/2/1-6/2/5)
6    unit5 (5/2/6-5/2/10)  unit7 (7/2/6-7/2/10)
7    unit1 (1/2/1-1/2/5)   unit6 (6/2/6-6/2/10)
Topology: Ring, 7 unit(s), order: 4 3 2 1 7 6 5
active
      +-+      +-+      +-+      +-+      +-+      +-+
=2/1|4|2/6==2/6|3|2/1==2/1|2|2/6==2/6|1|2/1==2/1|7|2/6==2/6|6|2/1=
|      +-+      +-+      +-+      +-+      +-+
|
|
|
-----2/1|5|2/6=
      +-+

```

show stack rel-ipc stats

Displays statistics on reliable Interprocessor Communications (IPC) communications that occur between stack units during a session.

Syntax	show stack rel-ipc stats { unit <i>num</i> }		
Parameters	rel-ipc	Abbreviation for reliable Interprocessor Communications, which designates the proprietary packets exchanged between stack units during a communications session.	
	stats	Session statistics.	
	unit <i>num</i>	Optional parameter used to specify the stack unit number for which session statistics are to be displayed. If you do not specify a stack unit, session statistics are displayed for all units in the stack.	
Modes	Privileged EXEC mode		
Usage Guidelines	To display session statistics for a particular stack unit, specify the stack unit using the unit <i>num</i> parameters.		
	To display session statistics for all units in the stack, do not specify a stack unit.		
Command Output	Depending on whether you specify a stack unit, the show stack rel-ipc stats command displays reliable IPC statistics for all units in the stack, or for a single unit in the stack. See the example output below.		

Examples The following example is reliable IPC statistics for an ICX 6610 stack.

```
device# show stack rel-ipc stats
Reliable IPC statistics:
Global statistics:
Pkts rcvd w/no session: 0
Msgs rcvd w/no handler: 0
Unit statistics:
Unit 2 statistics:
Msgs sent: 41384 Msgs received: 14052, Pkt sends failed: 0
Message types sent:
    [9]=21674,    [10]=19703,    [11]=2,    [13]=5,
Message types received:
    [9]=14016,    [10]=2,    [11]=28,    [13]=6,
Session statistics: base-channel, unit 2, channel 0:
Session state: established (last established 15 hours 33 minutes 31 seconds ago)
Connections established: 1
Remote resets: 0, Reset packets sent: 0
Connection statistics (for current connection, if established):
Msgs sent: 14636, Msgs received: 14039
Atomic batches sent: 0, Atomic batches received: 0
Pkts sent: 30892, Pkts received: 30842
Msg bytes sent: 1828190, Msg bytes received: 1232988
Pkt bytes sent: 2659848, Pkt bytes received: 1763028
Flushes requested: 30, Suspends: 0, Resumes: 0
Packets sent with data (DAT), ACKs, and window updates (WND):
Other: 888, ACK: 14010, WND: 437, ACK+WND: 0
DAT: 15556, DAT+ACK: 1, DAT+WND: 0, DAT+ACK+WND: 0
Data retransmits done: 1069, Zero-window probes sent: 0
Dup ACK pkts rcvd: 1224, Pkts rcvd w/dup data: 0
Pkts rcvd w/data past window: 0
Session statistics: image-transfer, unit 2, channel 1:
Session state: established (last established 15 hours 11 minutes 2 seconds ago)
Connections established: 1
Remote resets: 0, Reset packets sent: 0
Connection statistics (for current connection, if established):
Msgs sent: 9850, Msgs received: 1
Atomic batches sent: 0, Atomic batches received: 0
Pkts sent: 9899, Pkts received: 10606
Msg bytes sent: 10124076, Msg bytes received: 8
Pkt bytes sent: 10341308, Pkt bytes received: 127284
Flushes requested: 1, Suspends: 0, Resumes: 0
Packets sent with data (DAT), ACKs, and window updates (WND):
Other: 1, ACK: 1, WND: 0, ACK+WND: 0
DAT: 9897, DAT+ACK: 0, DAT+WND: 0, DAT+ACK+WND: 0
Data retransmits done: 49, Zero-window probes sent: 0
Dup ACK pkts rcvd: 757, Pkts rcvd w/dup data: 0
Pkts rcvd w/data past window: 0
Session statistics: ACL, unit 2, channel 3:
Session state: established (last established 15 hours 33 minutes 31 seconds ago)
Connections established: 1
Remote resets: 0, Reset packets sent: 0
Connection statistics (for current connection, if established):
Msgs sent: 7011, Msgs received: 4
Atomic batches sent: 0, Atomic batches received: 0
Pkts sent: 7588, Pkts received: 7617
Msg bytes sent: 629316, Msg bytes received: 5840
Pkt bytes sent: 802504, Pkt bytes received: 107508
Flushes requested: 0, Suspends: 0, Resumes: 0
Packets sent with data (DAT), ACKs, and window updates (WND):
Other: 1, ACK: 1, WND: 0, ACK+WND: 2
DAT: 7584, DAT+ACK: 0, DAT+WND: 0, DAT+ACK+WND: 0
Data retransmits done: 573, Zero-window probes sent: 0
Dup ACK pkts rcvd: 596, Pkts rcvd w/dup data: 0
Pkts rcvd w/data past window: 0
Session statistics: sync-reliable, unit 2, channel 4:
Session state: established (last established 15 hours 32 minutes 27 seconds ago)
Connections established: 1
Remote resets: 0, Reset packets sent: 0
Connection statistics (for current connection, if established):
Msgs sent: 27, Msgs received: 1
Atomic batches sent: 0, Atomic batches received: 0
Pkts sent: 53, Pkts received: 40
Msg bytes sent: 39420, Msg bytes received: 1460
Pkt bytes sent: 73836, Pkt bytes received: 1944
Flushes requested: 0, Suspends: 0, Resumes: 0
Packets sent with data (DAT), ACKs, and window updates (WND):
```

```

Other: 2, ACK: 1, WND: 0, ACK+WND: 0
DAT: 50, DAT+ACK: 0, DAT+WND: 0, DAT+ACK+WND: 0
Data retransmits done: 22, Zero-window probes sent: 0
Dup ACK pkts rcvd: 6, Pkts rcvd w/dup data: 0
Pkts rcvd w/data past window: 0
Session statistics: rconsole-server-to-2, unit 2, channel 6:
Session state: established (last established 15 hours 33 minutes 30 seconds ago)
Connections established: 1
Remote resets: 0, Reset packets sent: 0
Connection statistics (for current connection, if established):
Msgs sent: 5, Msgs received: 6
Atomic batches sent: 0, Atomic batches received: 0
Pkts sent: 14, Pkts received: 40
Msg bytes sent: 183, Msg bytes received: 56
Pkt bytes sent: 384, Pkt bytes received: 1052
Flushes requested: 5, Suspends: 0, Resumes: 0
Packets sent with data (DAT), ACKs, and window updates (WND):
Other: 4, ACK: 5, WND: 0, ACK+WND: 0
DAT: 5, DAT+ACK: 0, DAT+WND: 0, DAT+ACK+WND: 0
Data retransmits done: 0, Zero-window probes sent: 0
Dup ACK pkts rcvd: 0, Pkts rcvd w/dup data: 0
Pkts rcvd w/data past window: 0
Unit 3 statistics:
Msgs sent: 41356 Msgs received: 14007, Pkt sends failed: 0
Message types sent:
    [9]=21623,          [10]=19703,          [11]=29,          [13]=1,
Message types received:
    [9]=14003,          [10]=2,          [13]=2,

Session statistics: base-channel, unit 3, channel 0:
Session state: established (last established 15 hours 33 minutes 49 seconds ago)
Connections established: 1
Remote resets: 0, Reset packets sent: 0
Connection statistics (for current connection, if established):
Msgs sent: 14647, Msgs received: 14003
Atomic batches sent: 0, Atomic batches received: 0
Pkts sent: 31055, Pkts received: 31403
Msg bytes sent: 1801742, Msg bytes received: 1232204
Pkt bytes sent: 2402644, Pkt bytes received: 1877788
Flushes requested: 32, Suspends: 0, Resumes: 0
Packets sent with data (DAT), ACKs, and window updates (WND):
Other: 1269, ACK: 13911, WND: 437, ACK+WND: 0
DAT: 15346, DAT+ACK: 92, DAT+WND: 0, DAT+ACK+WND: 0
Data retransmits done: 966, Zero-window probes sent: 0
Dup ACK pkts rcvd: 661, Pkts rcvd w/dup data: 0
Pkts rcvd w/data past window: 0
Session statistics: image-transfer, unit 3, channel 1:
Session state: established (last established 15 hours 11 minutes 2 seconds ago)
Connections established: 1
Remote resets: 0, Reset packets sent: 0
Connection statistics (for current connection, if established):
Msgs sent: 9850, Msgs received: 1
Atomic batches sent: 0, Atomic batches received: 0
Pkts sent: 9930, Pkts received: 10599
Msg bytes sent: 10124076, Msg bytes received: 8
Pkt bytes sent: 10457352, Pkt bytes received: 127200
Flushes requested: 1, Suspends: 0, Resumes: 0
Packets sent with data (DAT), ACKs, and window updates (WND):
Other: 1, ACK: 1, WND: 0, ACK+WND: 0
DAT: 9928, DAT+ACK: 0, DAT+WND: 0, DAT+ACK+WND: 0
Data retransmits done: 140, Zero-window probes sent: 0
Dup ACK pkts rcvd: 798, Pkts rcvd w/dup data: 0
Pkts rcvd w/data past window: 0
Session statistics: ACL, unit 3, channel 3:
Session state: established (last established 15 hours 33 minutes 49 seconds ago)
Connections established: 1
Remote resets: 0, Reset packets sent: 0
Connection statistics (for current connection, if established):
Msgs sent: 7004, Msgs received: 0
Atomic batches sent: 0, Atomic batches received: 0
Pkts sent: 7447, Pkts received: 7300
Msg bytes sent: 616352, Msg bytes received: 0
Pkt bytes sent: 774304, Pkt bytes received: 87600
Flushes requested: 0, Suspends: 0, Resumes: 0
Packets sent with data (DAT), ACKs, and window updates (WND):
Other: 2, ACK: 0, WND: 0, ACK+WND: 0
DAT: 7445, DAT+ACK: 0, DAT+WND: 0, DAT+ACK+WND: 0
Data retransmits done: 441, Zero-window probes sent: 0

```

```

Dup ACK pkts rcvd: 295, Pkts rcvd w/dup data: 0
Pkts rcvd w/data past window: 0
Session statistics: rconsole-server-to-3, unit 3, channel 7:
Session state: established (last established 15 hours 33 minutes 48 seconds ago)
Connections established: 1
Remote resets: 0, Reset packets sent: 0
Connection statistics (for current connection, if established):
Msgs sent: 1, Msgs received: 2
Atomic batches sent: 0, Atomic batches received: 0
Pkts sent: 3, Pkts received: 2
Msg bytes sent: 35, Msg bytes received: 20
Pkt bytes sent: 76, Pkt bytes received: 52
Flushes requested: 1, Suspends: 0, Resumes: 0
Packets sent with data (DAT), ACKs, and window updates (WND):
Other: 1, ACK: 1, WND: 0, ACK+WND: 0
DAT: 1, DAT+ACK: 0, DAT+WND: 0, DAT+ACK+WND: 0
Data retransmits done: 0, Zero-window probes sent: 0
Dup ACK pkts rcvd: 0, Pkts rcvd w/dup data: 0
Pkts rcvd w/data past window: 0
Unit 4 statistics:
Msgs sent: 41337 Msgs received: 14035, Pkt sends failed: 0
Message types sent:
    [9]=21632,    [10]=19702,    [11]=2,    [13]=1,
Message types received:
    [9]=14031,    [10]=2,    [13]=2,
Session statistics: base-channel, unit 4, channel 0:
Session state: established (last established 15 hours 33 minutes 49 seconds ago)
Connections established: 1
Remote resets: 0, Reset packets sent: 0
Connection statistics (for current connection, if established):
Msgs sent: 14630, Msgs received: 14031
Atomic batches sent: 0, Atomic batches received: 0
Pkts sent: 30186, Pkts received: 31052
Msg bytes sent: 1801548, Msg bytes received: 1234680
Pkt bytes sent: 2325044, Pkt bytes received: 1857824
Flushes requested: 30, Suspends: 0, Resumes: 0
Packets sent with data (DAT), ACKs, and window updates (WND):
Other: 1199, ACK: 13879, WND: 434, ACK+WND: 4
DAT: 14522, DAT+ACK: 148, DAT+WND: 0, DAT+ACK+WND: 0
Data retransmits done: 197, Zero-window probes sent: 0
Dup ACK pkts rcvd: 560, Pkts rcvd w/dup data: 0
Pkts rcvd w/data past window: 0
Session statistics: image-transfer, unit 4, channel 1:
Session state: established (last established 15 hours 11 minutes 2 seconds ago)
Connections established: 1
Remote resets: 0, Reset packets sent: 0
Connection statistics (for current connection, if established):
Msgs sent: 9850, Msgs received: 1
Atomic batches sent: 0, Atomic batches received: 0
Pkts sent: 9852, Pkts received: 10675
Msg bytes sent: 10124076, Msg bytes received: 8
Pkt bytes sent: 10284896, Pkt bytes received: 128112
Flushes requested: 1, Suspends: 0, Resumes: 0
Packets sent with data (DAT), ACKs, and window updates (WND):
Other: 1, ACK: 1, WND: 0, ACK+WND: 0
DAT: 9850, DAT+ACK: 0, DAT+WND: 0, DAT+ACK+WND: 0
Data retransmits done: 2, Zero-window probes sent: 0
Dup ACK pkts rcvd: 826, Pkts rcvd w/dup data: 0
Pkts rcvd w/data past window: 0
Session statistics: ACL, unit 4, channel 3:
Session state: established (last established 15 hours 33 minutes 49 seconds ago)
Connections established: 1
Remote resets: 0, Reset packets sent: 0
Connection statistics (for current connection, if established):
Msgs sent: 7004, Msgs received: 0
Atomic batches sent: 0, Atomic batches received: 0
Pkts sent: 7051, Pkts received: 7240
Msg bytes sent: 616352, Msg bytes received: 0
Pkt bytes sent: 733028, Pkt bytes received: 86880
Flushes requested: 0, Suspends: 0, Resumes: 0
Packets sent with data (DAT), ACKs, and window updates (WND):
Other: 3, ACK: 0, WND: 0, ACK+WND: 0
DAT: 7048, DAT+ACK: 0, DAT+WND: 0, DAT+ACK+WND: 0
Data retransmits done: 44, Zero-window probes sent: 0
Dup ACK pkts rcvd: 234, Pkts rcvd w/dup data: 0
Pkts rcvd w/data past window: 0
Session statistics: rconsole-server-to-4, unit 4, channel 8:
Session state: established (last established 15 hours 33 minutes 48 seconds ago)

```

```
Connections established: 1
Remote resets: 0, Reset packets sent: 0
Connection statistics (for current connection, if established):
Msgs sent: 1, Msgs received: 2
Atomic batches sent: 0, Atomic batches received: 0
Pkts sent: 5, Pkts received: 8
Msg bytes sent: 35, Msg bytes received: 20
Pkt bytes sent: 140, Pkt bytes received: 264
Flushes requested: 1, Suspends: 0, Resumes: 0
Packets sent with data (DAT), ACKs, and window updates (WND):
Other: 2, ACK: 1, WND: 0, ACK+WND: 0
DAT: 2, DAT+ACK: 0, DAT+WND: 0, DAT+ACK+WND: 0
Data retransmits done: 1, Zero-window probes sent: 0
Dup ACK pkts rcvd: 1, Pkts rcvd w/dup data: 0
Pkts rcvd w/data past window: 0
```

The following example displays session statistics for stack unit 3.

```
device# show stack rel-ipc stats unit 3
Unit 3 statistics:
Msgs sent: 1217 Msgs received: 509, Pkt sends failed: 0
Message types sent:
[9]=1182, [10]=2, [11]=2, [13]=2,
[19]=29,
Message types received:
[9]=506, [10]=1, [13]=2,
Session statistics, unit 3, channel 0:
Session state: established (last established 32 minutes 19 seconds ago)
Connections established: 1
Remote resets: 0, Reset packets sent: 0
Connection statistics (for current connection, if established):
Msgs sent: 971, Msgs received: 506
Atomic batches sent: 0, Atomic batches received: 0
Pkts sent: 1205, Pkts received: 1088
Msg bytes sent: 44281, Msg bytes received: 19308
Pkt bytes sent: 238004, Pkt bytes received: 34652
Flushes requested: 59, Suspends: 0, Resumes: 0
Packets sent with data (DAT), ACKs, and window updates (WND):
Other: 2, ACK: 504, WND: 7, ACK+WND: 0
DAT: 691, DAT+ACK: 1, DAT+WND: 0, DAT+ACK+WND: 0
Data retransmits done: 129, Zero-window probes sent: 0
Dup ACK pkts rcvd: 18, Pkts rcvd w/dup data: 0
Pkts rcvd w/data past window: 0
Session statistics, unit 3, channel 2:
Session state: established (last established 32 minutes 17 seconds ago)
Connections established: 1
Remote resets: 0, Reset packets sent: 0
Connection statistics (for current connection, if established):
Msgs sent: 0, Msgs received: 0
Atomic batches sent: 0, Atomic batches received: 0
Pkts sent: 1, Pkts received: 7
Msg bytes sent: 0, Msg bytes received: 0
Pkt bytes sent: 12, Pkt bytes received: 84
Flushes requested: 0, Suspends: 0, Resumes: 0
Packets sent with data (DAT), ACKs, and window updates (WND):
Other: 1, ACK: 0, WND: 0, ACK+WND: 0
DAT: 0, DAT+ACK: 0, DAT+WND: 0, DAT+ACK+WND: 0
Data retransmits done: 0, Zero-window probes sent: 0
Dup ACK pkts rcvd: 7, Pkts rcvd w/dup data: 0
Pkts rcvd w/data past window: 0
Session statistics, unit 3, channel 3:
Session state: established (last established 32 minutes 19 seconds ago)
Connections established: 1
Remote resets: 0, Reset packets sent: 0
Connection statistics (for current connection, if established):
Msgs sent: 242, Msgs received: 0
Atomic batches sent: 0, Atomic batches received: 0
Pkts sent: 243, Pkts received: 246
Msg bytes sent: 8712, Msg bytes received: 0
Pkt bytes sent: 12596, Pkt bytes received: 2952
Flushes requested: 0, Suspends: 0, Resumes: 0
Packets sent with data (DAT), ACKs, and window updates (WND):
Other: 1, ACK: 0, WND: 0, ACK+WND: 0
DAT: 242, DAT+ACK: 0, DAT+WND: 0, DAT+ACK+WND: 0
Data retransmits done: 0, Zero-window probes sent: 0
Dup ACK pkts rcvd: 4, Pkts rcvd w/dup data: 0
Pkts rcvd w/data past window: 0
Session statistics, unit 3, channel 6:
Session state: established (last established 32 minutes 17 seconds ago)
Connections established: 1
Remote resets: 0, Reset packets sent: 0
Connection statistics (for current connection, if established):
Msgs sent: 2, Msgs received: 2
Atomic batches sent: 0, Atomic batches received: 0
Pkts sent: 8, Pkts received: 13
Msg bytes sent: 123, Msg bytes received: 20
Pkt bytes sent: 232, Pkt bytes received: 296
Flushes requested: 2, Suspends: 0, Resumes: 0
Packets sent with data (DAT), ACKs, and window updates (WND):
Other: 5, ACK: 1, WND: 0, ACK+WND: 0
DAT: 2, DAT+ACK: 0, DAT+WND: 0, DAT+ACK+WND: 0
Data retransmits done: 0, Zero-window probes sent: 0
```

```
Dup ACK pkts rcvd: 6, Pkts rcvd w/dup data: 0  
Pkts rcvd w/data past window: 0
```

show stack resource

Displays resource information for a stack unit.

Syntax **show stack resource**

Modes Privileged EXEC mode

Command Output The **show stack resource** command displays the following information:

Output field	Description
alloc	Memory allocated
in-use	Memory in use
avail	Available memory
get-fail	The number of get requests that have failed
limit	The maximum memory allocation
get-mem	The number of get-memory requests
size	The size
init	The number of requests initiated

Examples The following example displays stack resource statistics for an ICX 6610 stack unit.

```
device# show stack resource

register attribute   alloc in-use avail get-fail   limit get-mem size init
general 12B data    32    10   22      0    7424    12   12   32
RB-tree node        4096  2714  1382    0  237568  3026  18  1024
variable length link 3905    4  3901    0  905960    4    8  3905
AU msg dev0         4092    0  4092    0   16368    0   16  4092
AU msg dev1         4092    0  4092    0   16368    0   16  4092
```

show stack stack-ports

Displays status information about stack-ports.

Syntax **show stack stack-ports**

Modes Privileged EXEC mode
Global configuration mode

Command Output For ICX devices, an equal sign is used to indicate connections between trunk ports and the up port status is listed for all trunked ports. The **show stack stack-ports** command displays the following information:

Output field	Description
U# or ID	Stack unit identification number.
Stack-port 1	Indicates port status (up or down) and identifies the port by number (stack-ID/slot/port).
Stack-port 2	Indicates port status (up or down) and identifies the port by number (stack-ID/slot/port).
Stack-ID up (stack-ID/slot/port)	Indicates status (up or down) for the stack unit and the status (up or down) of all configured stacking ports on the unit by number (stack-ID/slot/port).

Examples The following output is for an FCX stack with five stacking units.

```
device(config)# show stack stack-ports
ID      Stack-port1      Stack-port2
1       up   (1/2/1)      up   (1/2/2)
2       up   (2/2/1)      up   (2/2/2)
3       up   (3/2/1)      up   (3/3/1)
4       up   (4/2/1)      up   (4/3/1)
5       up   (5/2/1)      up   (5/3/1)
```


The following output is for an ICX 6610 in a seven-unit stack configured in a ring topology.

```

device# show stack stack-ports
      active
      +-+      +-+      +-+      +-+      +-+      +-+
=2/1|4|2/6==2/6|3|2/1==2/1|2|2/6==2/6|1|2/1==2/1|7|2/6==2/6|6|2/1=
|   +-+      +-+      +-+      +-+      +-+      +-+
|
|
|
-----2/1|5|2/6=
      +-+
      +-+

U#   Stack-port1                                     Stack-port2
1    up (1/2/1-1/2/5)                                up (1/2/6-1/2/10)
    up ports: 1/2/1, 1/2/2, 1/2/3, 1/2/4, 1/2/5
    up ports: 1/2/6, 1/2/7, 1/2/8, 1/2/9, 1/2/10
2    up (2/2/1-2/2/5)                                up (2/2/6-2/2/10)
    up ports: 2/2/1, 2/2/2, 2/2/3, 2/2/4, 2/2/5
    up ports: 2/2/6, 2/2/7, 2/2/8, 2/2/9, 2/2/10
3    up (3/2/1-3/2/5)                                up (3/2/6-3/2/10)
    up ports: 3/2/1, 3/2/2, 3/2/3, 3/2/4, 3/2/5
    up ports: 3/2/6, 3/2/7, 3/2/8, 3/2/9, 3/2/10
4    up (4/2/1-4/2/5)                                up (4/2/6-4/2/10)
    up ports: 4/2/1, 4/2/2, 4/2/3, 4/2/4, 4/2/5
    up ports: 4/2/6, 4/2/7, 4/2/8, 4/2/9, 4/2/10
5    up (5/2/1-5/2/5)                                up (5/2/6-5/2/10)
    up ports: 5/2/1, 5/2/2, 5/2/3, 5/2/4, 5/2/5
    up ports: 5/2/6, 5/2/7, 5/2/8, 5/2/9, 5/2/10
6    up (6/2/1-6/2/5)                                up (6/2/6-6/2/10)
    up ports: 6/2/1, 6/2/2, 6/2/3, 6/2/4, 6/2/5
    up ports: 6/2/6, 6/2/7, 6/2/8, 6/2/9, 6/2/10
7    up (7/2/1-7/2/5)                                up (7/2/6-7/2/10)
    up ports: 7/2/1, 7/2/2, 7/2/3, 7/2/4, 7/2/5
    up ports: 7/2/6, 7/2/7, 7/2/8, 7/2/9, 7/2/10

```

show statistics l2-tunnel

Displays Layer 2 tunnel statistics such as the status of the tunnel and packet flow.

Syntax **show statistics l2-tunnel** *tunnel-id*

Parameters *tunnel-id*
Specifies the tunnel ID for the Layer 2 tunnel interface.

Modes Privileged EXEC mode
Global configuration mode

Command Output The **show statistics l2-tunnel** command displays the following information.

Output field	Description
Type	VXLAN tunnels
Tunnel Status	Status of the tunnel
Packet Received / Packet Sent	Statistics of the packet flow
KA received / KA sent	Statistics of Keepalive (Currently not supported)

Examples The following example shows the output of the **show statistics l2-tunnel** command:

```
device# show statistics l2-tunnel
L2 Tunnels
  Type      Tunnel Status  Packet Received  Packet Sent  KA  recv  KA  sent
  ----      -
  VXLAN1    down/down    0                0            0        0
  VXLAN2    up/up        0                0            0        0
```

History	Release version	Command history
	8.0.10d	This command was introduced.

show statistics stack-ports

Displays information about all stacking ports in a stack topology.

Syntax **show statistics stack-ports**

Modes Privileged EXEC mode

Command Output The **show statistics stack-ports** command displays the following information:

Output field	Description
Port	The number of the port (stack-unit number, slot number, and port number).
In Packets	The number of packets received on this port (incoming packets).
Out Packets	The number of packets sent from this port (outgoing packets).
In Errors	The number of errors received on this port (incoming errors).
Out Errors	The number of errors sent from this port (outgoing errors).

Examples The following example output is statistics for all stack ports in a stack with seven member units.

```
device# show statistics stack-ports
```

Port	In Packets	Out Packets	In Errors	Out Errors
1/2/1	22223	4528	0	0
1/2/2	35506	3844	0	0
2/2/1	3161	34173	0	0
2/2/2	24721	3676	0	0
3/2/1	3048	23881	0	0
3/2/2	13540	2857	0	0
4/2/1	2862	13537	0	0
4/2/2	3626	3184	0	0
5/2/1	3183	3621	0	0
5/2/2	3265	13508	0	0
6/2/1	14020	3655	0	0
6/3/1	3652	17705	0	0
7/2/1	17705	3658	0	0
7/3/1	4047	21802	0	0
TOTAL	154559	153629	0	0

show version

Displays information about the software version running on the standalone unit or a stacking system.

Syntax	show version
Modes	Stacking configuration mode User EXEC mode
Usage Guidelines	Depending on device support, the serial numbers of the pluggable or fixed modules are displayed in the output. The role of the stack unit and its bootup ID are displayed in the last line of command output. No role is displayed for standalone units.
Examples	The following is an example of the output displayed on an ICX 7750.

```

device# show version
Copyright (c) 1996-2014 Brocade Communications Systems, Inc. All rights reserved.
UNIT 1: compiled on Dec 22 2014 at 12:35:56 labeled as SWR08030b1
(20833985 bytes) from Secondary SWR08030b1.bin
SW: Version 08.0.30b1T203
UNIT 2: compiled on Dec 22 2014 at 12:35:56 labeled as SWR08030b1
(20833985 bytes) from Secondary SWR08030b1.bin
SW: Version 08.0.30b1T203
Compressed Boot-Monitor Image size = 1835008, Version:10.1.03T205 (swz10103b0
03)
HW: Stackable ICX7750-26Q
Internal USB: Serial #: 40D41E003CF90029
Vendor: UNIGEN, Total size = 1910 MB
=====
UNIT 1: SL 1: ICX7750-20QXG 20-port Management Module
Serial #:CRK2234J00V
License: ICX7750_L3_SOFT_PACKAGE (LID: etmHHIj1FFx)
P-ASIC 0: type B850, rev 03 Chip BCM56850_A2
=====
UNIT 1: SL 2: ICX7750-QSFP 6-port QSFP 240G Module
=====
UNIT 1: SL 3: ICX7750-6Q 6-port QSFP 240G Module
Serial #:PR320400290
=====
UNIT 2: SL 1: ICX7750-48XGF 48-port Management Module
Serial #:CRH2234J00M
License: ICX7750_L3_SOFT_PACKAGE (LID: etjHHIj1FFo)
=====
UNIT 2: SL 2: ICX7750-QSFP 6-port QSFP 240G Module
=====
UNIT 2: SL 3: ICX7750-6Q 6-port QSFP 240G Module
Serial #:PR320400289
=====
1500 MHz Power PC processor (version 8023/0022) 88 MHz bus
8192 KB boot flash memory
2048 MB code flash memory
256 MB DRAM
STACKID 1 system uptime is 14 minute(s) 30 second(s)
STACKID 2 system uptime is 14 minute(s) 6 second(s)
The system : started=warm start reloaded=by "reload"

```

The following output is for an ICX 6610 in a traditional stack. The unit has the bootup stack ID of 1. Currently, the unit has no assigned role in the stack; that is, it is a standalone unit.

```
device(config)# show version
Copyright (c) 1996-2013 Brocade Communications Systems, Inc. All rights reserved.
UNIT 1: compiled on Apr 26 2013 at 20:08:17 labeled as FCXR08000a
        (8837030 bytes) from Primary FCXR08000a.bin
        SW: Version 08.0.00aT7f3
UNIT 2: compiled on Apr 26 2013 at 20:08:17 labeled as FCXR08000a
        (8837030 bytes) from Primary FCXR08000a.bin
        SW: Version 08.0.00aT7f3
UNIT 3: compiled on Apr 26 2013 at 20:08:17 labeled as FCXR08000a
        (8837030 bytes) from Primary FCXR08000a.bin
        SW: Version 08.0.00aT7f3
UNIT 4: compiled on Apr 26 2013 at 20:08:17 labeled as FCXR08000a
        (8837030 bytes) from Primary FCXR08000a.bin
        SW: Version 08.0.00aT7f3
UNIT 5: compiled on Apr 26 2013 at 20:08:17 labeled as FCXR08000a
        (8837030 bytes) from Primary FCXR08000a.bin
        SW: Version 08.0.00aT7f3
UNIT 6: compiled on Apr 26 2013 at 20:08:17 labeled as FCXR08000a
        (8837030 bytes) from Primary FCXR08000a.bin
        SW: Version 08.0.00T7f3
UNIT 7: compiled on Apr 26 2013 at 20:08:17 labeled as FCXR08000a
        (8837030 bytes) from Primary FCXR08000a.bin
        SW: Version 08.0.00T7f3
UNIT 8: compiled on Apr 26 2013 at 20:08:17 labeled as FCXR08000a
        (8837030 bytes) from Primary FCXR08000a.bin
        SW: Version 08.0.00aT7f3
Boot-Monitor Image size = 370733, Version:07.3.03T7f5 (grz07303)
HW: Stackable ICX6610-24
=====
UNIT 1: SL 1: ICX6610-24 24-port Management Module
        Serial #: BMA2523H00P
        License: ICX6610_PREM_ROUTER_SOFT_PACKAGE (LID: dochKHjFFr)
        P-ENGINE 0: type E02B, rev 0I
=====
UNIT 1: SL 2: ICX6610-QSFP 10-port 160G Module
=====
UNIT 1: SL 3: ICX6610-8-port Dual Mode(SFP/SFP+) Module
=====
UNIT 2: SL 1: ICX6610-24 24-port Management Module
        Serial #: BMA2524H02T
        License: ICX6610_PREM_ROUTER_SOFT_PACKAGE (LID: dochKHjFHV)
        P-ENGINE 0: type E02B, rev 0I
=====
UNIT 2: SL 2: ICX6610-QSFP 10-port 160G Module
=====
UNIT 2: SL 3: ICX6610-8-port Dual Mode(SFP/SFP+) Module
=====
UNIT 3: SL 1: ICX6610-24 24-port Management Module
        Serial #: BMA2524H02W
        License: ICX6610_PREM_ROUTER_SOFT_PACKAGE (LID: dochKHjFHy)
        P-ENGINE 0: type E02B, rev 0I
=====
UNIT 3: SL 2: ICX6610-QSFP 10-port 160G Module=====
UNIT 3: SL 3: ICX6610-8-port Dual Mode(SFP/SFP+) Module
=====
UNIT 4: SL 1: ICX6610-48 48-port Management Module
        Serial #: BNX2522H00R
        License: ICX6610_PREM_ROUTER_SOFT_PACKAGE (LID: dzpHKHjFFt)
        P-ENGINE 0: type E023, rev 0I
        P-ENGINE 1: type E023, rev 0I
=====
UNIT 4: SL 2: ICX6610-QSFP 10-port 160G Module
=====
UNIT 4: SL 3: ICX6610-8-port Dual Mode(SFP/SFP+) Module
=====
UNIT 5: SL 1: ICX6610-48 48-port Management Module
        Serial #: BNX2522H00S
        License: ICX6610_PREM_ROUTER_SOFT_PACKAGE (LID: dzpHKHjFFu)
        P-ENGINE 0: type E023, rev 0I
        P-ENGINE 1: type E023, rev 0I
=====
UNIT 5: SL 2: ICX6610-QSFP 10-port 160G Module
=====
UNIT 5: SL 3: ICX6610-8-port Dual Mode(SFP/SFP+) Module
```

```

=====
UNIT 6: SL 1: ICX6610-24 24-port Management Module
        Serial #: BMA2524H02S
        License: ICX6610_PREM_ROUTER_SOFT_PACKAGE (LID: docHKHJjFHu)
        P-ENGINE 0: type_E02B, rev 01
=====
UNIT 6: SL 2: ICX6610-QSFP 10-port 160G Module
=====
UNIT 6: SL 3: ICX6610-8-port Dual Mode(SFP/SFP+) Module
=====
UNIT 7: SL 1: ICX6610-24 24-port Management Module
        Serial #: BXP2523H00L
        License: ICX6610_PREM_ROUTER_SOFT_PACKAGE (LID: dzrHKHIjFFn)
        P-ENGINE 0: type_E02B, rev 01
=====
UNIT 7: SL 2: ICX6610-QSFP 10-port 160G Module
=====
UNIT 7: SL 3: ICX6610-8-port Dual Mode(SFP/SFP+) Module
=====
UNIT 8: SL 1: ICX6610-24F 24-port Management Module
        Serial #: BLH0422G00K
        License: ICX6610_PREM_ROUTER_SOFT_PACKAGE (LID: dnjFJHHiFFm)
        P-ENGINE 0: type_E02B, rev 01
=====
UNIT 8: SL 2: ICX6610-QSFP 10-port 160G Module
=====
UNIT 8: SL 3: ICX6610-8-port Dual Mode(SFP/SFP+) Module
=====
      800 MHz Power PC processor 8544E (version 0021/0023) 400 MHz bus
65536 KB flash memory
512 MB DRAM
STACKID 1 system uptime is 32 minutes 54 seconds
STACKID 2 system uptime is 32 minutes 54 seconds
STACKID 3 system uptime is 32 minutes 54 seconds
STACKID 4 system uptime is 32 minutes 54 seconds
STACKID 5 system uptime is 32 minutes 54 seconds
STACKID 6 system uptime is 32 minutes 54 seconds
STACKID 7 system uptime is 32 minutes 54 seconds
STACKID 8 system uptime is 32 minutes 53 seconds
The system : started=warm start reloaded=by "reload"
My stack unit ID = 1, bootup role = active

```

Commands Sn - Z

snmp-server enable traps mac-notification

Enables the MAC-notification trap whenever a MAC address event is generated on a device or an interface.

Syntax **snmp-server enable traps mac-notification**
no snmp-server enable traps mac-notification

Command Default MAC-notification traps are disabled on the device.

Modes Global configuration
 Interface configuration

Usage Guidelines The **no** form of this command disables SNMP traps for MAC-notification events. The SNMP MAC-notification trap functionality allows an SNMPv3 trap to be sent to the SNMP manager when MAC addresses are added or deleted in the device.

Examples The following example enables SNMP traps on the device for MAC-notification globally:
`device(config)# snmp-server enable traps mac-notification`
The following example disables SNMP traps on the device for MAC-notification globally:
`device(config)# no snmp-server enable traps mac-notification`

History		
	Release version	Command history
	08.0.10	This command was introduced.

snmp-server group

Creates user-defined groups for SNMPv1/v2c/v3 and configures read, write, and notify permissions to access the MIB view.

Syntax **snmp-server group** *groupname* { **v1** | **v2c** } [**access** { *standard-ACL-id* | **ipv6** *ipv6-ACL-name* }] [**notify** *viewname*] [**read** *viewname*] [**write** *viewname*]

no snmp-server group *groupname* { **v1** | **v2c** } [**access** { *standard-ACL-id* | **ipv6** *ipv6-ACL-name* }] [**notify** *viewname*] [**read** *viewname*] [**write** *viewname*]

snmp-server group *groupname* **v3** { **auth** | **noauth** | **priv** } [**access** { *standard-ACL-id* | **ipv6** *ipv6-ACL-name* }] [**notify** *viewname*] [**read** *viewname*] [**write** *viewname*]

no snmp-server group *groupname* **v3** { **auth** | **noauth** | **priv** } [**access** { *standard-ACL-id* | **ipv6** *ipv6-ACL-name* }] [**notify** *viewname*] [**read** *viewname*] [**write** *viewname*]

Command Default Six default groups are supported to associate the default SNMPv3 user groups and the default SNMPv1/v2c community groups with the view configuration.

NOTE

This command is not used for SNMP version 1 and SNMP version 2. In these versions, groups and group views are created internally using community strings. When a community string is created, two groups are created, based on the community string name. One group is for SNMP version 1 packets, while the other is for SNMP version 2 packets.

Parameters	<i>groupname</i>	Specifies the name of the SNMP group to be created.
	v1	Specifies SNMP version 1.
	v2c	Specifies SNMP version 2.
	v3	Specifies SNMP version 3.
	auth	Specifies that only authenticated packets with no privacy are allowed to access the specified view. This parameter is available only for SNMPv3 user groups.
	noauth	Specifies that no authentication and no privacy are required to access the specified view. This parameter is available only for SNMPv3 user groups.
	priv	Specifies that authentication and privacy are required from the users to access the view. This parameter is available only for SNMPv3 user groups.
	access	Specifies an access list associated with the SNMP group.
	<i>standard-ACL-id</i>	Specifies the standard IP access list and allows the incoming SNMP packets to be filtered based on the standard ACL attached to the group.
	ipv6	Specifies the IPv6 ACL for the SNMP group.
	<i>ipv6-ACL-name</i>	

Specifies the IPv6 access list and allows incoming SNMP packets to be filtered based on the IPv6 ACL attached to the group.

notify *viewname*

Specifies the name of the view that enables you to provide access to the MIB for trap or inform. This allows the administrators to restrict the scope of varbind objects that will be part of the notification. All of the varbinds need to be in the included view for the notification to be created.

read *viewname*

Specifies the name of the view that enables you to provide read access.

write *viewname*

Specifies the name of the view that enables you to provide both read and write access.

viewname

Specifies the name of the view to which the SNMP group members have access. If no view is specified, then the group has no access to the MIB. The default viewname is "all", which allows access to the entire MIB.

Modes Global configuration mode

Usage Guidelines Maximum number of SNMP groups supported is 10.

The **no** form of the command removes the configured SNMP server group.

Examples The following example creates SNMP server group entries for SNMPv3 user group with auth permission.

```
device(config)# snmp-server group admin v3 auth ipv6 acl_1 read all write all notify all
```

History

Release version	Command history
08.0.20a	The ipv6 <i>ipv6-ACL-name</i> keyword-argument pair was introduced.

spanning-tree designated-protect

Disallows the designated forwarding state on a port in STP 802.1d or 802.1w.

Syntax	spanning-tree designated-protect
	no spanning-tree designated-protect
Command Default	STP (802.1d or 802.1w) can put a port into designated forwarding state.
Modes	Interface configuration mode
Usage Guidelines	The no form of this command allows the designated forwarding state on a port in STP 802.1d or 802.1w. If STP tries to put a port into designated forwarding state, the device puts this port into the designated inconsistent STP state. This is effectively equivalent to the listening state in STP in which a port cannot forward any user traffic. When STP no longer marks this port as a designated port, the port is automatically removed from the designated inconsistent state.

NOTE

You use this command to enable Designated Protection at the port-level while the designated inconsistent state is a per-STP-instance, per-port state.

NOTE

You cannot enable Designated Protection and Root Guard on the same port.

Examples	The following example disallows the designated forwarding state on interface 1/1/1.	
	<pre>device(config)# ethernet interface 1/1/1 device(config-if-e1000-1/1/1)# spanning-tree designated-protect</pre>	
History	Release version	Command history
	07.3.00g	This command was introduced.

stack disable

Prevents a device from joining a traditional stack and from listening for, or sending, stacking packets.

Syntax **stack disable**
no stack disable

Command Default Stacking is disabled by default.

Modes Global configuration mode and Stack unit configuration mode

Usage Guidelines To remove the restriction that prevents the unit from joining a stack, use the **no stack disable** command.

Examples The following example disables the device from joining a stack.

```
device# configure terminal
device(config)# stack disable
Disable stacking. This unit will not be a part of any stack
```

History

Release version	Command history
08.0.00a	This command was introduced.

stack enable

Enables stack configuration on the device. Enter this command on the intended active controller.

Syntax	stack enable
	no stack enable
Command Default	Stacking is not enabled on the device.
Modes	Global configuration mode
	Stack unit configuration mode
Usage Guidelines	Use the no form of the command to remove stacking capability from the device.

NOTE

When you use the **no stack enable** command, the unit can still be called to join an active stack. To prevent this, use the **stack disable** command instead.

You must remove all configuration information from the port before issuing the **stack enable** command.

For manual configuration, the **stack enable** command must be issued on each device in the stack.

Examples The following example enables stack configuration on the device.

```
device# config terminal
device(config)# stack enable
Enable stacking. This unit actively participates in stacking
```

History	Release version	Command history
	08.0.00a	This command was introduced.

stack mac

Manually configures a specific MAC address for a traditional stack.

Syntax **stack mac** *mac-address*

no stack mac *mac-address*

Command Default Beginning with FastIron release 08.0.20, when a stack is enabled or when hitless-failover occurs, a default stack MAC address is assigned if none is configured. In earlier releases, the stack assumed the MAC address of the active controller by default.

Parameters *mac-address*

Specifies the MAC address to be used for the stack.

Modes Active stack controller configuration mode

Usage Guidelines Enter the **no** form of this command to revert to the use of the active controllers' MAC address.
The MAC address is a hexadecimal value entered in the format xxxx.xxxx.xxxx.

Examples The following example configures the stack MAC address manually as 0000.0000.0011.

```
device(config)# stack mac 0000.0000.0011
device(config)# show running-config
Current configuration:
!
ver 05.0.01 100T7e1
!
stack 1
module 1 fcx-48-port-copper-base-module
module 2 fcx-cx4-1-port-10g-module
priority 80
stack 2
module 1 fcx-24-port-copper-base-module
module 2 fcx-cx4-1-port-10g-module
module 3 fcx-cx4-1-port-10g-module
stack enable
stack mac 0000.0000.0011
```

History

Release version	Command history
08.0.00a	This command was introduced.
08.0.20	Stack behavior was modified so that a default MAC address is assigned when the stack is enabled or when hitless failover occurs if no stack MAC address has been configured.

stack-port

Selects only one of the two stacking ports as a stacking port, which allows you to use the other port as a data port.

Syntax **stack-port** *unit[/slot]/port*

no stack-port

Command Default By default, both default ports serve as stacking ports on an FCX or ICX stack unit.

Parameters *unit*

Stack unit ID

slot

Slot or module on the unit where the interface resides.

port

Interface to be configured as the sole stack port on the unit.

Modes Stack-unit configuration mode.

Usage Guidelines The **no** form of the command restores both default stacking ports on the device.
The **stack-port** command should not be used on a live stack.

Examples The following example configures Port 3/2/1 as the only stacking port on stack unit 3.

```
device# configure terminal
device(config)# stack unit 3
device(config-unit-3)# stack-port 3/2/1
Set only one stacking port 3/2/1
```

stack secure-setup

Configures a stack automatically, to add units to an existing traditional stack, or to change stack member IDs.

Syntax **stack secure-setup**

Modes Privileged EXEC mode of a stack unit

Usage Guidelines Stacking must be enabled with the **stack enable** command before the **stack secure-setup** command can be issued.

When the **stack secure-setup** command is issued on a unit that is not already the active controller, the unit becomes the active controller.

Examples In the following example, an FCX traditional stack is formed using **stack secure-setup**.

```
device# stack secure-setup
device# Discovering the stack topology...
Current Discovered Topology - RING
Available UPSTREAM units
Hop(s) Type MAC Address
1 FCX624 0000.0039.2d40
2 FCX624 0000.00d5.2100
Available DOWNSTREAM units
Hop(s) Type MAC Address
1 FCX624 0000.00d5.2100
2 FCX624 0000.0039.2d40
Do you accept the topology (RING) (y/n)? : y
Selected Topology:
Active Id Type MAC Address
1 FCX648 0000.00ab.cd00
Selected UPSTREAM units
Hop(s) Id Type MAC Address
1 3 FCX624 0000.0039.2d40
2 2 FCX624 0000.00d5.2100
Selected DOWNSTREAM units
Hop(s) Id Type MAC Address
1 2 FCX624 0000.00d5.2100
2 3 FCX624 0000.0039.2d40
Do you accept the unit ids (y/n)? : y
```

stack stack-port-resiliency

Configures different levels of corrective steps that an active controller can take to fix stacking ports that cannot send or receive packets, despite the ports being logically operational.

Syntax	stack stack-port-resiliency <i>level</i> no stack stack-port-resiliency <i>level</i>
Command Default	The stack-port-resiliency feature is enabled with the <i>level</i> variable value set to 1.
Parameters	<i>level</i> <p>The value determines the corrective steps that an active controller can take when a stack port is malfunctioning. Then value can range from 0 through 3.</p>
Modes	Global configuration mode
Usage Guidelines	<p>The no form of the stack stack-port-resiliency command sets the <i>level</i> variable value to 1.</p> <p>The stack stack-port-resiliency command is only supported on an ICX 6610 in a stack.</p> <p>The corrective steps that can be taken depend on the value of the <i>level</i> variable and involve error-disabling malfunctioning ports or reloading one or more stack units. Traffic may be disrupted for a few seconds or longer while the port malfunction is detected and fixed.</p> <p>If the <i>level</i> value is set to 1 and the unit with the malfunctioning port is not an active controller:</p> <ul style="list-style-type: none"> • The active controller checks whether other ports in the same static LAG are fully operational. • If the total bandwidth of the operational static LAG is greater than or equal to 20 Gbps, the malfunctioning port is error-disabled. • If the total bandwidth of the operational static LAG is less than 20 Gbps and error-disabling all ports of the LAG could disconnect one or more other units from the stack, the unit reloads. • If the total bandwidth of the operational static LAG is less than 20 Gbps and error-disabling all ports of the LAG would not disconnect any other units from the stack, all the ports of the LAG are error-disabled. <p>If the <i>level</i> value is set to 2 and the unit with the malfunctioning port is not the active controller, the unit reloads. After the reload, if any other non-active controller unit is not able to communicate with the active controller, it also reloads.</p> <p>If the <i>level</i> value is set to 3, the corrective steps in level 2 are performed. If the port is still not operating correctly, the entire stack reloads.</p> <p>If you use the command and set the <i>level</i> variable value to 1, this configuration shows in the show run command output. If you use the no form of the command, the <i>level</i> variable value is set to 1, but the value does not show in the show run command output.</p>

NOTE

You can use the **show errdisable summary** command to view a list of all error-disabled ports, along with the reason the ports were error-disabled.

Examples The following example shows the configuration of stack port resiliency on a stack with the *level* variable value set to 2.

```
Device# configure terminal
Device(config)# stack stack-port-resiliency 2
```


History	Release version	Command history
	07.3.00g	This command was introduced.

stack suggested-id

Specifies the preferred stack unit ID for a standalone device before it joins a stack.

Syntax	stack suggested-id <i>stack-unit</i>
	no stack suggested-id <i>stack-unit</i>
Parameters	<i>stack-unit</i> Specifies the numeric stack unit ID.
Modes	Global configuration mode
Usage Guidelines	<p>The no form of this command removes the stack unit ID.</p> <p>The stack suggested-id command is configured on a standalone device before it joins a stack and becomes a member. The command is not for the active controller. Because the active controller always keeps its bootup ID during stack formation, it does not use the suggested-id value.</p> <p>The system attempts to assign a bootup ID of a device as its stack unit ID. However, due to timing issues or the possible unavailability of the bootup ID, a device might not get the stack unit ID that you want when the stack is formed. The optional stack suggested-id command allows you to specify the stack unit ID for member devices when you are configuring a traditional or mixed stack using the manual configuration method.</p>
Examples	<p>The following example sets the stack unit ID on a standalone device to 3.</p> <pre>device# configure terminal device(config)# stack suggested-id 3</pre>

stack suppress-warning

Stops periodic output of background stack diagnostic reports.

Syntax **stack suppress-warning**

no stack suppress-warning

Command Default By default, background diagnostics are displayed periodically on the active stack controller.

Modes Stack active controller configuration mode

Usage Guidelines Use the **no** form of the command to restore periodic output of background diagnostic reports.

Examples In the following example, background diagnostic reports are turned off for the stack.

```
Device# configure terminal
Device(config)# stack suppress-warning
```

stack switch-over

Switches active controllers without reloading the stack and without packet loss to services and protocols supported by hitless stacking.

- Syntax

stack switch-over
- Command Default

With FastIron release 08.0.20, the **stack switch-over** command is allowed by default. In earlier releases, hitless failover must first be enabled.
- Modes

Global configuration mode on a stack controller
- Usage Guidelines

Use the **stack switch-over** command before reloading or performing maintenance on the currently active controller. Hitless failover must be enabled for the command to be used; otherwise, an error message is issued.

The command cannot be used during stack election or during configuration of a multi-stack-trunk.

A standby controller must exist and must have learned stack protocols for the command to be used. The standby controller must have the same priority as the active controller for the command to be used.

More than 120 seconds must have passed since the previous switchover or failover for the command to be accepted.
- Examples

The following example shows the **stack switch-over** command being entered and the resulting output. You must confirm the switch-over before it can take effect by entering **y** when prompted.

```
device# stack switch-over
Standby unit 8 will become active controller, and unit 1 will become standby
Are you sure? (enter 'y' or 'n'): y
Unit 1 is no longer the active controller
```

History	Release version	Command history
	08.0.00a	This command was introduced.
	08.0.20	Hitless failover is enabled by default. The stack switch-over command is allowed by default as a result.

stack-trunk

Configures a stack to form a trunk from contiguous links on one side of a stack connection.

Syntax **stack-trunk** *stack-unit/slotnum/portnum* **to** *stack-unit/slotnum/portnum*
no stack-trunk *stack-unit/slotnum/portnum* **to** *stack-unit/slotnum/portnum*

Parameters	<i>stack-unit</i>	Specifies the stack unit ID.
	<i>slotnum</i>	Specifies the slot number.
	<i>portnum</i>	Specifies the port number in the slot.

Modes Stack unit configuration mode

Usage Guidelines Use the **no** form of the command to disable the stack trunk configuration.

The **stack-trunk** command must be configured on the stack units on both ends of the trunk. Use this command in a new environment on the first deployment of a stack.

To enable the **stack-trunk** command, the primary port in the trunk must be configured under the **stack-port** command configuration.

Do not use the **stack-trunk** command in a production environment. Use the **multi-stack-trunk** command instead.

Examples In the following example, ports 1/2/3 and 1/2/4 are configured as a stacking trunk on stack unit 1.

```
Device# configure terminal
Device(config)# stack unit 1
Device(config-unit-1)# stack-trunk 1/2/3 to 1/2/4
```

stack unconfigure

Returns a stack member to its pre-stacking configuration or state.

Syntax	stack unconfigure [stack-unit all me clean mixed-stack]
Parameters	<p><i>stack-unit</i></p> <p>Specifies the numerical ID of a stack member. This option is available on the active controller only.</p> <p>all</p> <p>Specifies all stack members. This option is available on the active controller only.</p> <p>me</p> <p>Specifies the stack member from which the command is executed. The command removes the unit from the stack and boots it up as a standalone. When the unit rejoins the stack, its standalone startup-config file is saved in a backup file. This option is available on stack member consoles only.</p> <p>clean</p> <p>Specifies that the startup configuration be removed from the unit on which the command is executed and that the unit be rebooted as a clean unit. This option is available on stack member consoles only.</p> <p>mixed-stack</p> <p>Specifies removal of all peripheral ports and peripheral trunks from ICX 6610 devices. It also specifies recovery and reload of prior ICX 6450 peripheral device configurations, from before the ICX 6450 units were members of the mixed stack. This option is available only on the active controller in a mixed stack.</p>
Modes	Privileged EXEC mode
Usage Guidelines	When a stack unit that did not have an original startup configuration file is unconfigured, it becomes a clean unit. It is possible that this unit could automatically rejoin the stack if its module configuration matches the configuration of the active controller. To prevent this from happening accidentally, disconnect the unit to be unconfigured, and then issue the stack unconfigure me command on it.
Examples	<p>Traditional stack example</p> <p>In the following example, stack unit 2 is unconfigured in a traditional stack.</p>

```

Device(config)# show stack
alone: standalone, D: dynamic config, S: static config
ID  Type   Role   Mac Address   Pri State  Comment
1  S FCX624 active  0012.f2eb.a900 128 local  Ready
2  S FCX648 standby 00f0.424f.4243 0  remote Ready
3  S FCX624 member 00e0.5201.0100 0  remote Ready

Device# stack unconfigure 2
Will recover pre-stacking startup config of this unit, and reset it. Are you sure?
(enter 'y' or 'n'): y

Stack 2 deletes stack bootup flash and recover startup-config.txt from .old

Device# show stack
alone: standalone, D: dynamic config, S: static config
ID  Type   Role   Mac Address   Pri State  Comment
1  S FCX624 active  0012.f2eb.a900 128 local  Ready
2  S FCX648 member 0000.0000.0000 0  reserved
3  S FCX624 standby 00e0.5201.0100 0  remote  Ready

```

Mixed stack example

In the following example, ICX 6450 peripheral devices are removed from a mixed stack. The mixed stack contains two ICX 6610 devices in a ring configuration in the backbone. There are two sub-stacks of three ICX 6450 devices each in the mixed stack.

The following **show stack** output shows the configuration of the mixed stack before the **stack unconfigure mixed-stack** command is executed. The **show stack** command is executed on the active controller.

```
Brocade(config)# show stack
alone: standalone, D: dynamic config, S: static config
ID  Type   Role   Mac Address   Pri State  Comment
1  S FCX624 active  0012.f2eb.a900 128 local  Ready
2  S FCX648 standby 00f0.424f.4243 0  remote Ready
3  S FCX624 member 00e0.5201.0100 0  remote Ready

Brocade# stack unconfigure 2
Will recover pre-stacking startup config of this unit, and reset it. Are you sure?
(enter 'y' or 'n'): y
```

Stack 2 deletes stack bootup flash and recover startup-config.txt from .old

```
Brocade# show stack
alone: standalone, D: dynamic config, S: static config
ID  Type   Role   Mac Address   Pri State  Comment
1  S FCX624 active  0012.f2eb.a900 128 local  Ready
2  S FCX648 member 0000.0000.0000 0  reserved
3  S FCX624 standby 00e0.5201.0100 0  remote  Ready
```

```

      active          standby
      +---+          +---+
=2/6| 1 |2/1==2/6| 2 |2/1=
| +---+          +---+ |
|-----|
|
      active          standby
      +---+          +---+
( 1 ) 3/7--2/1| 6 |2/3==2/1| 7 |2/3==2/1| 8 |2/3==3/7( 2 )
      +---+          +---+
      +---+          +---+
standby          active
      +---+          +---+
( 2 ) 3/1==2/1| 5 |2/3==2/1| 4 |2/3==2/1| 3 |2/3--3/1( 1 )
      +---+          +---+
      +---+          +---+

```

The following sequence shows the **stack unconfigure mixed-stack** command being executed on the active controller. After confirmation, all peripheral ports and peripheral trunks are removed from the ICX 6610 units. The peripheral ICX 6450 devices recover their configurations from before they were members of the mixed stack, and they are reloaded.

```
Brocade# stack unconfigure mixed-stack
All the peri-ports/trunks will be removed and all the ICX6450 units will recover
pre-mixed-stacking configuration. Are you sure? (enter 'y' or 'n'): y
Removed peri-ports from configuration: 1/3/1 1/3/7
Removed peri-trunks from configuration: 2/3/1-to-2/3/2 2/3/7-to-2/3/8
```

The **show stack** command is executed on the active controller. The output shows that the ICX 6450 devices are no longer part of the mixed stack because the MAC addresses are all zeroes, the State column shows “reserve,” and the device status in the Comment column does not show “Ready.”

The Role column still shows “member” because the active controller holds the configuration of the former stack member in reserve so that it can form a stack later if a stack is merged or formed.

```
Brocade# show stack
alone: standalone, D: dynamic config, S: static config
ID  Type   Role   Mac Address   Pri State  Comment
1  S ICX6610-24F active  748e.f891.c5b8 128 local  Ready
2  S ICX6610-48P standby 748e.f834.4d14 0 remote Ready
3  S ICX6450-24 member 0000.0000.0000 0 reserve
```

```

4 S ICX6450-24P member 0000.0000.0000 0 reserve
5 S ICX6450-24P member 0000.0000.0000 0 reserve
6 S ICX6450-48 member 0000.0000.0000 0 reserve
7 S ICX6450-48 member 0000.0000.0000 0 reserve
8 S ICX6450-24P member 0000.0000.0000 0 reserve

```

```

      active      standby
      +---+      +---+
=2/6| 1 |2/1==2/6| 2 |2/1=
| +---+      +---+ |
|-----|

```

Use the **show stack** command to verify that peripheral devices, such as ICX 6450 devices, are no longer part of the mixed stack.

In the following example, the Role column shows “alone,” which indicates a standalone device. This means that the device was a standalone device before joining the mixed stack.

```

Brocade# show stack

***** Warning! stack is not enabled. *****

alone: standalone, D: dynamic config, S: static config
ID  Type      Role      Mac Address  Pri State  Comment
1 S ICX6450-24P alone    748e.f8b0.6c00 0 local  None:0

      +---+
      2/1| 1 |2/3
      +---+
Current stack management MAC is 748e.f8b0.6c00
Note: no "stack mac" config. My MAC will change after failover.

```

In the following example, the Role column shows “active,” “standby,” or “member,” which indicates that these devices are part of a stack. This means that the devices were part of a traditional stack before joining the mixed stack.

```

Brocade# show stack
alone: standalone, D: dynamic config, S: static config
ID  Type      Role      Mac Address  Pri State  Comment
1 S ICX6450-24P active    748e.f8b0.6c00 128 local  Ready
2 S ICX6450-48 standby   748e.f8d4.2300 0 remote  Ready
3 S ICX6450-48 member    748e.f8d4.02c0 0 remote  Ready

      standby      active
      +---+      +---+
      2/1| 3 |2/3--2/1| 2 |2/3--2/1| 1 |2/3
      +---+      +---+
Standby u2 - No hitless failover. Reason: hitless-failover not configured
Current stack management MAC is 748e.f8b0.6c00
Note: no "stack mac" config. My MAC will change after failover.

```

History

Release	Command History
07.4.00	This command was introduced.
08.0.00a	The mixed-stack option was added. The rollback option was deprecated.

store-and-forward

Resets the switching method for forwarding packets from cut-through to store-and-forward.

Syntax **store-and-forward**

no store-and-forward

Command Default The switching method is cut-through.

Modes Global configuration mode

Usage Guidelines The **no** form of this command restores the default packet-forwarding method to cut-through.

Ethernet devices support two basic switching methods for packet forwarding: store-and-forward and cut-through. The default method on ICX 7750 devices is cut-through. You can configure the **store-and-forward** command to change it to store-and-forward.

NOTE

You must save the configuration and reload for the change to take effect.

A store-and-forward device does not make a forwarding decision on a data packet until it has received the whole frame and checked its integrity; a cut-through device starts the forwarding process soon after it makes the forwarding decision on an incoming frame that is, it might start forwarding before the entire packet is received. This reduces forwarding latency, especially for longer packets. However, there are many factors to consider when selecting which switching method is best for your environment and in some cases it is desirable to change from the default method and configure a device to store-and-forward.

The following table describes some of the differences in how packets are handled depending on the switching method.

Feature	Cut-through	Store-and-forward
Forwarding	Data forwarding starts before an entire packet is received	Device waits for entire packet received before processing.
Latency	Low latency, less than 1 micro second.	Higher latency; latency depends on frame size.
FCS Errors	FCS errors may be propagated from one device to another.	FCS errors are checked and error packets are discarded in the MAC receive.
MTU size	MTU size is validated by MAC receive. Oversize packets are marked as error packets but not dropped in the MAC receive.	MTU size is validated by MAC receive. Oversize packets are dropped at the MAC layer.

Examples This example globally enables **store-and-forward** packet switching and saves the configuration.

```
Device(config)# store-and-forward
Device(config)# write memory
Device(config)# end
```

History

Release version	Command history
08.0.10b	This command was introduced.

symmetrical-flow-control enable

Enables symmetrical flow control (SFC) globally for priorities.

Syntax	symmetrical-flow-control enable [all]
	no symmetrical-flow-control enable
Command Default	SFC is globally disabled.
Parameters	all Specifies SFC on all priorities. If you do not specify the all keyword, SFC is enabled only on priorities 0-4. This parameter is optional.
Modes	Global configuration mode
Usage Guidelines	The no form of this restores the default flow-control settings.
	Configuring the symmetrical-flow-control enable command enables SFC globally for priorities 0-4 by default and optionally for all priorities (0-7)
	By default, the system runs in tail-drop mode, with all ports honoring 802.3x flow control and disabling 802.3x transmit. The symmetrical-flow-control enable command enables transmission of 802.3x pause frames.
	Configuring the symmetrical-flow-control enable command changes priority-to-PG mapping.
	You cannot configure the symmetrical-flow-control enable command if the priority-flow-control command is enabled.
	If the symmetrical-flow-control enable command is not enabled, you cannot configure the flow-control generate-only or the flow-control both commands in interface configuration mode.

NOTE

In FastIron Release 08.0.20 and later releases, SFC is not supported for ports across stack units in ICX 7750 devices or across stack units or for ports across master and slave packet-processor (pp) devices in ICX7450-48 units.

Examples	The following example shows how to enable SFC:
	<pre>Device(config)# symmetrical-flow-control enable</pre>
	The following example shows how to enable all priorities to send the IEEE 802.3x pause:
	<pre>Device(config)# symmetrical-flow-control enable all</pre>
	The following example shows how to enable SFC for Generate-only mode:
	<pre>Device(config)# symmetrical-flow-control enable Device(config)# flow-control generate-only</pre>
	The following example shows how to enable SFC for both Honor and Generate-only mode:
	<pre>Device(config)# symmetrical-flow-control enable Device(config)# flow-control both</pre>

History	Release version	Command history
	8.0.10	This command was introduced.

system-max igmp-snoop-group-addr

Sets the maximum number of IGMP group addresses on a device.

Syntax **system-max igmp-snoop-group-addr** *num*
no system-max igmp-snoop-group-addr

Command Default The default number of IGMP group addresses is supported.

Parameters *num*
Specifies the maximum number of IGMP group addresses supported. The range is a value from 256 through 8192. The default for IGMP snooping group addresses is 4096, except for ICX 6430 devices where the default is 1024.

Modes Global configuration mode

Usage Guidelines The **no** form of this command restores the default maximum.

The configured number of IGMP group addresses is the upper limit of an expandable database. Client memberships exceeding the group limit are not processed.

The following describes the IGMP group address limits for Brocade devices:

- FCX, FSX, ICX 6610, and ICX 6450 devices support up to 8192 IGMP group addresses.
- ICX 6430 devices support up to 4096 IGMP group addresses.
- ICX 6650 devices support 8192 IGMP group addresses.
- ICX 7750 switches support 8192 IGMP group addresses.
- ICX 7750 routers support 6K IGMP group addresses.
- ICX 7250 devices support 8192 IGMP group addresses.
- ICX 7450 devices support 8192 IGMP group addresses.

Examples This example sets maximum number of IGMP snooping group addresses to 1600.

Device(config)#system-max igmp-snoop-group-addr 1600

system-max igmp-snoop-mcache

Configures the maximum number of IGMP snooping cache entries supported on a device.

Syntax **system-max igmp-snoop-mcache** *num*

no system-max igmp-snoop-mcache

Command Default The default number of IGMP snooping cache entries is supported.

Parameters *num*

Specifies the maximum number of IGMP snooping cache entries supported. The range is a value from 256 through 8192. The default is 512 entries except on ICX 6430 devices, where the default is 256.

Modes Global configuration mode

Usage Guidelines The **no** form of this command restores the default maximum.

The following describes the IGMP snooping multicast cache (mcache) resource limits for Brocade devices:

- FCX, FSX, ICX 6610, and ICX 6450 devices support up to 8192 IGMP snooping mcache entries.
- ICX 6430 devices support up to 2048 IGMP snooping mcache entries.
- ICX 6650 devices support 8192 IGMP snooping mcache entries.
- ICX 7750 switches support 8192 IGMP snooping mcache entries.
- ICX 7750 routers support 6K IGMP snooping mcache entries.
- ICX 7250 devices support 8192 IGMP snooping mcache entries.
- ICX 7450 devices support 8192 IGMP snooping mcache entries.

Examples This example shows how to configure the maximum number of IGMP snooping mcache entries supported on the device to 2000.

```
Device(config)#system-max igmp-snoop-mcache 2000
```

system-max mac-notification-buffer

Changes the value of the MAC-notification buffer.

Syntax **system-max mac-notification-buffer** *size*

no system-max mac-notification-buffer size

Command Default The default buffer size is 4000.

Parameters *size*

Sets the buffer queue size to maintain MAC-notification events.

Modes Global configuration

Usage Guidelines

Examples This example changes the value of the MAC-notification buffer:

```
device(config)# system-max mac-notification-buffer 8000
```

This example sets the MAC-notification buffer to default size:

```
device(config)# no system-max mac-notification-buffer 4000
```

History

Release version	Command history
08.0.10	This command was introduced.

system-max max-ecmp

Configures the maximum limit of ECMP paths at the system level.

Syntax	system-max max-ecmp [<i>num</i>] no system-max max-ecmp [<i>num</i>]
Command Default	The default value is 8.
Parameters	<i>num</i> Specifies the maximum number of ECMP paths and can be from 8 through 32.
Modes	Global configuration mode
Usage Guidelines	<p>The system-max max-ecmp command is supported only on the Brocade ICX 7750.</p> <p>If the maximum number of ECMP paths is not configured at the system level, by default, you can configure the maximum number of IP load sharing paths to a value from 2 through 8.</p> <p>The configuration of the maximum number of IP load sharing paths to a value more than 8 is determined by the maximum number of ECMP paths configured at the system level using the system-max max-ecmp command.</p> <p>You cannot configure the maximum number of IP load sharing paths higher than the value defined at the system level.</p> <p>You cannot configure the maximum number of ECMP paths at the system level to a value less than the configured IP load sharing value.</p> <p>You must save the configuration and reload the device for the maximum ECMP value change to take effect.</p> <p>The no form of the command removes the maximum number of ECMP paths defined at the system level.</p>
Examples	<p>The following example defines the maximum number of ECMP paths that can be configured in the system as 20.</p> <pre>device(config)# system-max max-ecmp 20 device(config)# write memory device(config)# exit device# reload</pre>

History	Release version	Command history
	08.0.30	This command was introduced.

system-max mld-snoop-group-addr

Sets the maximum number of multicast listening discovery (MLD) group addresses on a device.

Syntax **system-max mld-snoop-group-addr** *num*
 no system-max mld-snoop-group-addr

Command Default The default number of MLD group addresses is supported.

Parameters *num*
 Specifies the maximum number of MLD group addresses supported. The range is a value from 256 through 8192. The default for MLD snooping group addresses is 4096, except for ICX 6430 devices where the default is 1024.

Modes Global configuration mode

Usage Guidelines The **no** form of this command restores the default maximum.

The configured number of MLD group addresses is the upper limit of an expandable database. Client memberships exceeding the group limit are not processed.

The following describes the MLD group address limits for Brocade devices:

- FCX, FSX, ICX 6610, and ICX 6450 devices support up to 8192 MLD group addresses.
- ICX 6430 devices support up to 4096 MLD group addresses.
- ICX 6650 devices support 8192 MLD group addresses.
- ICX 7750 switches support 8192 MLD group addresses.
- ICX 7750 routers support 6K MLD group addresses.
- ICX 7250 devices support 8192 MLD group addresses.
- ICX 7450 devices support 8192 MLD group addresses.

Examples This example sets maximum number of MLD snooping group addresses to 4000.

```
Device(config)#system-max mld-snoop-group-addr 4000
```

system-max mld-snoop-mcache

Configures the maximum number of multicast listening discovery (MLD) snooping cache entries supported on a device.

Syntax **system-max mld-snoop-mcache** *num*

no system-max mld-snoop-mcache

Command Default The default number of MLD snooping cache entries is supported.

Parameters *num*

Specifies the maximum number of MLD snooping cache entries supported. The range is 256 to 8192. The default is 512 entries except on ICX 6430 devices, where the default is 256.

Modes Global configuration mode

Usage Guidelines The **no** form of this command restores the default maximum.

The following describes the MLD snooping multicast cache (mcache) resource limits for Brocade devices:

- FCX and FSX devices support up to 8192 MLD snooping mcache entries.
- ICX 6610, ICX 6450, and ICX 6650 devices support up to 8192 MLD snooping mcache entries.
- ICX 7250 and ICX 7450 devices support up to 8192 MLD snooping mcache entries.
- ICX 7750 switches support up to 8192 MLD snooping mcache entries.
- ICX 6430 devices support up to 2048 MLD snooping mcache entries.
- ICX 7750 routers support 3072 MLD snooping mcache entries.
- In Release 8.0.10a and later releases, ICX 7750 routers support 6144 MLD snooping mcache entries.

Examples This example shows how to set the maximum number of MLD snooping mcache entries to 8000.

```
Device(config)#system-max mld-snoop-mcache 8000
```


table-map

Maps external entry attributes into the BGP routing table, ensuring that those attributes are preserved after being redistributed into OSPF.

Syntax	table-map <i>string</i>
	no table-map <i>string</i>
Command Default	This option is disabled.
Parameters	<i>string</i>
	Specifies a route map to be whose attributes are to be preserved. Range is from 1 through 63 ASCII characters.
Modes	BGP configuration mode
	BGP address-family IPv6 unicast configuration mode
Usage Guidelines	Use the no form of the command to remove the table map.
	When this command is entered in BGP global configuration mode, it applies only to the IPv4 address family. Use this command in BGP address-family IPv6 unicast configuration mode for BGP4+ configurations.
	Use this command only to set the tag values. Normally, a route map is applied on routes (and therefore the routes are updated) before it is stored in the BGP routing table. Use the table-map command to begin the update before the routes are stored in the IP routing table.
	Configurations made by this command apply to all peers.
	Route maps that contain set statements change values in routes when the routes are accepted by the route map. For inbound route maps (route maps that filter routes received from neighbors), the routes are changed before they enter the BGP4 routing table. For tag values, if you do not want the value to change until a route enters the IP routing table, you can use a table map to change the value. A table map is a route map that you have associated with the IP routing table. The device applies the set statements for tag values in the table map to routes before adding them to the routing table. To configure a table map, you first configure the route map, then identify it as a table map. The table map does not require separate configuration. You can have only one table map.

NOTE

Use table maps only for setting the tag value. Do not use table maps to set other attributes. To set other route attributes, use route maps or filters. To create a route map and identify it as a table map, enter commands such those shown in the first example below. These commands create a route map that uses an address filter. For routes that match the IP prefix list filter, the route map changes the tag value to 100 and is then considered as a table map. This route map is applied only to routes that the device places in the IP routing table. The route map is not applied to all routes. The first example below assumes that IP prefix list p11 has already been configured.

Examples This example illustrates the execution of the **table-map** command.

```
device# configure terminal
device(config)# route-map tag_ip permit 1
device(config-route-map/tag_ip)# match ip address prefix-list p11
device(config-route-map/tag_ip)# set tag 100
device(config-route-map/tag_ip)# exit
device(config-bgp-router)# table-map tag_ip
```

This example removes a table map in the IPv6 address family.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# address-family ipv6 unicast
device(config-bgp-ipv6u)# no table-map tag_ip
```

timers (BGP)

Adjusts the interval at which BGP KEEPALIVE and HOLDDTIME messages are sent.

Syntax `timers { keep-alive keepalive_interval hold-time holdtime_interval }`

`no timers`

Command Default The keepalive timer is 60 seconds. The hold timer is 180 seconds.

Parameters `keep-alive keepalive_interval`

Frequency in seconds with which a device sends keepalive messages to a peer. Range is from 0 through 65535 seconds. The default is 60.

`hold-time holdtime_interval`

Interval in seconds that a device waits to receive a keepalive message from a peer before declaring that peer dead. Range is from 0 through 65535 seconds. The default is 180.

Modes BGP configuration mode

Usage Guidelines Use the `no timers` command to clear the timers.

The KEEPALIVE and HOLDDTIME message interval is overwritten when the **fast-external-failover** command takes effect on a down link to a peer.

You must enter a value for **keep-alive** before you can enter a value for **hold-time**. Both values must be entered. If you only want to adjust the value of one parameter, enter the default value of the parameter that you do not want to adjust.

Examples This example sets the keepalive timer for a device to 120 seconds and the hold-timer to 360 seconds.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# timers keep-alive 120 hold-time 360
```

timeout (EFM-OAM)

Configures the time in seconds for which the local Data Terminal Equipment (DTE) waits to receive OAM Protocol Data Units (OAMPDUs) from the remote entity.

Syntax	timeout <i>value</i> no timeout <i>value</i>
Command Default	The default value is 5 seconds.
Parameters	<i>value</i> Specifies the time in seconds for which the local DTE must wait for OAMPDUs from the remote entity. The value range can be from 1 through 10 seconds.
Modes	EFM-OAM protocol configuration mode
Usage Guidelines	If the local DTE does not receive any OAMPDU within the specified period, the peer is considered down and the EFM-OAM discovery process will start over again. The no form of the command restores the default value of 5 seconds.
Examples	The following example configures the timeout value as 10 seconds. device(config)# link-oam device(config-link-oam)# timeout 10

History	Release version	Command history
	08.0.30	This command was introduced.

traffic-policy count

Configures a traffic policy and enables counting the number of bytes and the conformance level per packet.

Syntax **traffic-policy** *traffic-policy-def* **count**
no traffic-policy *traffic-policy-def* **count**

Command Default No traffic policy is applied.

Parameters *traffic-policy-def*
Specifies the name of the traffic policy definition, in no more than seven alphanumeric characters.

Modes Global configuration mode

Usage Guidelines The **no** form of this command deletes a traffic policy definition.

Examples This example configures a traffic policy named TPD and enables counting of bytes and conformance levels.

```
device#configure terminal
device(config)#traffic-policy TPD count
```

traffic-policy rate-limit adaptive

Configures an ACL-based flexible-bandwidth traffic policy to define rate limits on packets so that you can allow for bursts above the limit.

Syntax **traffic-policy** *traffic-policy-def* **rate-limit adaptive** **cir** *cir-value* **cbs** *cbs-value* **pir** *pir-value* **pbs** *pbs-value* **count**

traffic-policy *traffic-policy-def* **rate-limit adaptive** **cir** *cir-value* **cbs** *cbs-value* **pir** *pir-value* **pbs** *pbs-value* **exceed-action drop** [**count**]

traffic-policy *traffic-policy-def* **rate-limit adaptive** **cir** *cir-value* **cbs** *cbs-value* **pir** *pir-value* **pbs** *pbs-value* **exceed-action permit-at-low-pri** [**count** | **remark-cos** [**count**]]

no traffic-policy *traffic-policy-def* **rate-limit adaptive** **cir** *cir-value* **cbs** *cbs-value* **pir** *pir-value* **pbs** *pbs-value* **count**

no traffic-policy *traffic-policy-def* **rate-limit adaptive** **cir** *cir-value* **cbs** *cbs-value* **pir** *pir-value* **pbs** *pbs-value* **exceed-action drop** [**count**]

no traffic-policy *traffic-policy-def* **rate-limit adaptive** **cir** *cir-value* **cbs** *cbs-value* **pir** *pir-value* **pbs** *pbs-value* **exceed-action permit-at-low-pri** [**count** | **remark-cos** [**count**]]

Command Default No traffic policy is applied.

Parameters *traffic-policy-def*

Specifies the name of the traffic policy definition, in no more than seven alphanumeric characters.

count

Enables counting the number of bytes and the conformance level per packet. The single-rate three-color marker (srTCM) mechanism described in RFC 2697 is used.

cir *cir-value*

Specifies the committed information rate (CIR) in Kbps, that is, the guaranteed rate of inbound traffic that is allowed on a port. The range is 64 through 1,000,000 Kbps. On ICX 6650 devices, the *cir-value* is the rate in packets per second. The range is 125 through 15,000,000 packets per second.

cbs *cbs-value*

Specifies the committed burst size (CBS), that is, the number of bytes per second allowed on a port before some packets exceed the CIR. You must specify a value greater than 0. On ICX 6650 devices, the *cbs-value* is the rate in packets per second.

pir *pir-value*

Specifies the peak information rate (PIR) in Kbps, that is, the most inbound traffic that is allowed on a port. On ICX 6650 devices, the *cir-value* is the rate in packets per second. The *pir-value* must be equal to or greater than the *cir-value*.

pbs *pbs-value*

Specifies the peak burst size (PBS), that is, the most bytes per second allowed in a burst before all packets exceed the PIR. You must specify a value greater than 0. On ICX 6650 devices, the *pbs-value* is the rate in packets per second.

exceed-action

Specifies the action for traffic that is more than is configured in the *cir-value* variable. If you do not configure this keyword, traffic that exceeds the *cir-value* is dropped

drop

Specifies dropping traffic that exceeds the rate limit.

count

Enables counting the number of bytes and the conformance level per packet. The two-rate three-color marker (trTCM) mechanism described in RFC 2698 is used.

permit-at-low-pri

Specifies permitting packets that exceed the *cir-value* and forward them at the lowest priority.

remark-cos

Sets the 802.1p priority of dropped packets to 0, that is, it sets the COS/PCP field value to 0 for the low priority traffic for any packet exceeding the rate limit set by the traffic policy

Modes Global configuration mode

Usage Guidelines The **no** form of this command deletes a traffic policy definition.

Traffic policies must be referenced by one or more ACLs before they can be effective. The policies are effective on ports to which the ACLs that reference them are bound.

NOTE

You cannot delete a traffic policy definition that a port is currently using. To delete a traffic policy, you must first unbind the associated ACL.

It is recommended that you specify a PBS value that is equal to or greater than the size of the largest possible IP packet in the stream.

Examples This example configures a traffic policy named TPDA4 that specifies a CIR of 10000 Kbps, a CBS of 1600 Kbps, a PIR of 20000 Kbps, and a PBS of 1000 Kbps and dropping any traffic that exceeds those limits.

```
device#configure terminal
device(config)#traffic-policy TPDA4 rate-limit adaptive cir 10000 cbs 1600 pir
20000 pbs 4000 exceed-action drop
```

traffic-policy rate-limit fixed

Configures an ACL-based fixed-rate traffic policy to define rate limits on packets. It either drops all traffic that exceeds the limit, or forwards it at the lowest priority level.

Syntax `traffic-policy traffic-policy-def rate-limit fixed cir-value count`

`traffic-policy traffic-policy-def rate-limit fixed cir-value exceed-action drop [count]`

`traffic-policy traffic-policy-def rate-limit fixed cir-value exceed-action permit-at-low-pri [count | remark-cos [count]]`

`no traffic-policy traffic-policy-def rate-limit fixed cir-value count`

`no traffic-policy traffic-policy-def rate-limit fixed cir-value exceed-action drop [count]`

`no traffic-policy traffic-policy-def rate-limit fixed cir-value exceed-action permit-at-low-pri [count | remark-cos [count]]`

Command Default No traffic policy is applied.

Parameters `traffic-policy-def`

Specifies the name of the traffic policy definition, in no more than seven alphanumeric characters.

`cir-value`

Specifies the committed information rate (CIR) in Kbps, that is, the guaranteed rate of inbound traffic that is allowed on a port. The range is 64 through 1,000,000 Kbps. On ICX 6650 devices, the `cir-value` is the rate in packets per second. The range is 125 through 15,000,000 packets per second

`count`

Enables counting the number of bytes and the conformance level per packet. The single-rate three-color marker (srTCM) mechanism described in RFC 2697 is used.

`exceed-action`

Specifies the action for traffic that is more than is configured in the `cir-value` variable. If you do not configure this keyword, traffic that exceeds the `cir-value` is dropped

`drop`

Specifies dropping traffic that exceeds the rate limit.

`count`

Enables counting the number of bytes and the conformance level per packet. The single-rate three-color marker (srTCM) mechanism described in RFC 2697 is used.

`permit-at-low-pri`

Specifies permitting packets that exceed the `cir-value` and forward them at the lowest priority.

`remark-cos`

Sets the 802.1p priority of dropped packets to 0, that is, it sets the COS/PCP field value to 0 for the low priority traffic for any packet exceeding the rate limit set by the traffic policy

Modes Global configuration mode

Usage Guidelines The **no** form of this command deletes a traffic policy definition.

Traffic policies must be referenced by one or more ACLs before they can be effective. The policies are effective on ports to which the ACLs that reference them are bound.

NOTE

You cannot delete a traffic policy definition that is currently in use on a port. To delete a traffic policy, you must first unbind the associated ACL.

Examples This example configures a traffic policy named TPD1 that specifies a CIR of 100 Kbps and dropping any traffic that exceeds the limit.

```
device#configure terminal
device(config)#traffic-policy TPD1 rate-limit fixed 100 exceed-action drop
```

tunnel destination

Configures the destination address for a specific tunnel interface.

Syntax **tunnel destination** { *ip address* }

no tunnel destination { *ip address* }

Command Default No tunnel interface destination is configured.

Parameters *ip address*

Specifies the IPv4 address of an interface.

Modes Interface tunnel configuration mode

Usage Guidelines Use the **no tunnel destination** command to remove the configured destination for the tunnel interface.
You must ensure that a route to the tunnel destination exists on the tunnel source device and create a static route if necessary.

Examples This example configures the IP address 10.1.2.3 as the destination address for a specific tunnel interface.

```
device# configure terminal
device(config)# interface tunnel 3
device(config-tunif-3)# tunnel destination 10.1.2.3
```

**Related
Commands** [tunnel source](#)

tunnel mode gre ip

Enables generic routing encapsulation (GRE) over on a tunnel interface and specifies that the tunneling protocol is IPv4.

Syntax **tunnel mode gre ip**

no tunnel mode gre ip

Command Default GRE is disabled.

Modes Interface tunnel configuration mode

Usage Guidelines Use the **no tunnel mode gre ip** command to disable the GRE IP tunnel encapsulation method for the tunnel interface.

Examples This example enables GRE IP encapsulation on a tunnel interface.

```
device# configure terminal
device(config)# interface tunnel 3
device(config-tunif-3)# tunnel mode gre ip
```

**Related
Commands** [interface tunnel](#)

tunnel source

Configures the source address or a source interface for a specific tunnel interface.

Syntax **tunnel destination** { *ip address* | **ethernet** *stackid / slot / port* | **loopback** *number* | **ve** *vlan_id*}

no tunnel destination { *ip address* | **ethernet** *stackid / slot / port* | **loopback** *number* | **ve** *vlan_id*}

Command Default No source address or interface is configured.

Parameters *ip address*

Specifies the IPv4 address of an interface.

ethernet *stackid / slot / port*

Specifies an Ethernet interface.

loopback *number*

Specifies an loopback port.

ve *vlan_id*

Specifies a VE interface.

Modes Interface tunnel configuration mode

Usage Guidelines Use the **no tunnel source** command to remove the configured source for the tunnel interface.

The tunnel source address should be one of the router IP addresses configured on a physical, loopback, or VE interface, through which the other end of the tunnel is reachable. The source interface must have at least one IP address configured on it.

Examples This example configures the IP address 10.1.2.4 as the source address for a specific tunnel interface.

```
device# configure terminal
device(config)# interface tunnel 3
device(config-tunif-3)# tunnel source 10.1.2.4
```

This example sets an Ethernet interface as a source tunnel.

```
device# configure terminal
device(config)# interface tunnel 1
device(config-tunif-1)# tunnel source ethernet 3/1
```

Related Commands [tunnel destination](#)

unmount disk0

Unmounts the external USB.

Syntax **unmount disk0**

Modes User EXEC mode.

Examples The following example unmounts the external USB.

```
device# unmount disk0
```

History

Release version	Command history
08.0.30	This command was introduced.

update-lag-name

Changes the name of an existing LAG without causing any impact on the functionality of the LAG.

Syntax **update-lag-name** *new-name*

Parameters *new-name*
Specifies the new name for the LAG.

Modes LAG configuration mode

Usage Guidelines The new name must be unique and unused.

Examples The following example renames LAG blue to blue1.

```
device(config)# lag blue static
device(config-lag-blue)# update-lag-name blue1
INFORMATION: Lag blue with ID 1 is updated to new name blue1
device(config)#
```

History	Release version	Command history
	08.0.30	This command was introduced.

update-time (BGP)

Configures the interval at which BGP next-hop tables are modified. BGP next-hop tables should always have IGP (non-BGP) routes.

Syntax	update-time sec
	no update-time sec
Command Default	This option is disabled.
Parameters	sec
	Update time in seconds. Range is from 0 through 30. Default is 5 seconds.
Modes	BGP configuration mode
	BGP address-family IPv6 unicast configuration mode
Usage Guidelines	Use the no form of this command to restore the defaults.
	When this command is entered in BGP global configuration mode, it applies only to the IPv4 address family. Use this command in BGP address-family IPv6 unicast configuration mode for BGP4+ configurations.
	The update time determines how often the device computes the routes (next-hops). Lowering the value set by the update-time command increases the convergence rate.
	By default, the device updates the BGP next-hop tables and affected BGP routes five seconds following IGP route changes. Setting the update time value to 0 permits fast BGP convergence for situations such as a link failure or IGP route changes, starting the BGP route calculation in sub-second time.

NOTE

Use the **advertisement-interval** command to determine how often to advertise IGP routes to the BGP neighbor.

Examples This example permits fast convergence.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# update-time 0
```

This BGP4+ example sets the update time interval to 30.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-router)# address-family ipv6 unicast
device(config-bgp-ipv6u)# update-time 30
```

use-v2-checksum

Enables the v2 checksum computation method for a VRRPv3 IPv4 session.

Syntax **use-v2-checksum**

 no use-v2-checksum

Command Default VRRPv3 uses v3 checksum computation method.

Modes VRRP configuration mode

Usage Guidelines The **no** form of this command enables the default v3 checksum computation method in VRRPv3 sessions.

Some non-Brocade devices only use the v2 checksum computation method in VRRPv3. This command enables v2 checksum computation method in VRRPv3 and provides interoperability with these non-Brocade devices.

Examples The following example shows the v2 checksum computation method enabled in IPv4 and IPv6 VRRPv3 instances.

```
IPv6 :
Brocade(config)# interface ve 3
Brocade(config-vif-3)# ipv6 vrrp vrid 2
Brocade(config-vif-3-vrid-2)# use-v2-checksum

IPv4 :
Brocade(config)# interface ve 3
Brocade(config-vif-3)# ipv4 vrrp vrid 2
Brocade(config-vif-3-vrid-2)# version v3
Brocade(config-vif-3-vrid-2)# use-v2-checksum
```

History	Release version	Command history
	08.0.01	This command was introduced for IPv6 VRRPv3 sessions running on FastIron device images.
	08.0.10b	This command was introduced for IPv4 VRRPv3 sessions running on FastIron device images.

Syntax **version {v2 | v3}**

Command Default The default is VRRP version 2.

Parameters v2

Selects version 2 of VRRP.

v3

Selects version 3 of VRRP.

Modes VRRP virtual router ID configuration.

Usage Guidelines You can choose either version 2 or version 3 of IPv4 VRRP. The default IPv4 VRRP configuration is VRRPv2. The VRRPv3 functionality is enabled only after you configure version 3. Use the **no version v3** or **version v2** commands to roll back to the default (VRRPv2).

Examples The following example configures the VRRP owner router for IPv4.

```
device(config)#router vrrp
device(config)#interface ethernet 1/6
device(config-if-1/6)#ip-address 192.53.5.1
device(config-if-1/6)#ip vrrp vrid 1
device(config-if-1/6-vrid-1)#owner
device(config-if-1/6-vrid-1)# version v3 | v2
device(config-if-1/6-vrid-1)#ip-address 192.53.5.1
device(config-if-1/6-vrid-1)#activate

The following example configures the VRRP backup router for IPv4.
device(config)#router vrrp
device(config)#interface ethernet 1/5
device(config-if-1/5)#ip-address 192.53.5.3
device(config-if-1/5)#ip vrrp vrid 1
device(config-if-1/5-vrid-1)#backup
device(config-if-1/6-vrid-1)# version v3 |v2
device(config-if-1/5-vrid-1)#advertise backup
device(config-if-1/5-vrid-1)#ip-address 192.53.5.1
device(config-if-1/5-vrid-1)#activate
```

History

Release version	Command history
08.0.10	This command was introduced.

vxlan vlan

Configures the VXLAN membership of the port by specifying the VLAN port and VNI for VXLAN mapping.

Syntax	vxlan vlan <i>vlan-id vni vni-id l2-tunnel tunnel-id</i>
	no vxlan vlan <i>vlan-id vni vni-id l2-tunnel tunnel-id</i>
Command Default	No VXLAN mapping to the tunnel.
Parameters	<i>vlan-id</i>
	Specifies the VLAN ID mapped to the VXLAN segment.
	vni <i>vni-id</i>
	Specifies the VXLAN segment ID to which the VLAN is mapped. This allows the extension of the Layer 2 VLAN segment to a remote location.
	l2-tunnel <i>tunnel-id</i>
	Specifies the Layer 2 tunnel that carries the specified VNI.
Modes	Interface configuration mode
Usage Guidelines	The command enables VLAN-to-VXLAN translation.
	Using the VXLAN maps, a VLAN is mapped to a VNI on a VXLAN Layer 2 tunnel and vice versa. Once the VXLAN mapping is configured, all frames belonging to a given {Port, VLAN} pair are "switched" into the VXLAN Layer 2 tunnel, using the VNI configured in the mapping.
	When a VXLAN packet destined to the VXLAN gateway (identified by the UDP destination port) is received, the gateway strips off the VXLAN header. The VNI carried in the VXLAN header identifies the VXLAN segment and assigns a unique outgoing port and a VLAN for the frame.
	The no form of the command disables VLAN-to-VXLAN translation.

NOTE
No {DMAC, VLAN} based bridging is performed in the E-Line service.

Examples The following example configures the VXLAN mapping to the tunnel:

```
device# configure terminal
device(config)# interface ethernet 1/1/1
device(config-if-e10000-1/1/1)# vxlan vlan 10 vni 1010 l2-tunnel 1
```

The details of the VXLAN mapping to the tunnel are displayed in the **show interface ethernet** command output for the specified .

```
device# show interface ethernet 1/1/1
VXLAN mappings:
  vlan 10 vni 1010 L2-Tunnel 1
```

History	Release version	Command history
	08.0.10d	This command was introduced.