

Instructions to Build System Images Separately

ID: RK-SM-YF-386

Release Version: V1.6.6

Release Date: 2021-10-18

Security Level: Top-Secret Secret Internal Public

DISCLAIMER

THIS DOCUMENT IS PROVIDED "AS IS". ROCKCHIP ELECTRONICS CO., LTD. ("ROCKCHIP") DOES NOT PROVIDE ANY WARRANTY OF ANY KIND, EXPRESSED, IMPLIED OR OTHERWISE, WITH RESPECT TO THE ACCURACY, RELIABILITY, COMPLETENESS, MERCHANTABILITY, FITNESS FOR ANY PARTICULAR PURPOSE OR NON-INFRINGEMENT OF ANY REPRESENTATION, INFORMATION AND CONTENT IN THIS DOCUMENT. THIS DOCUMENT IS FOR REFERENCE ONLY. THIS DOCUMENT MAY BE UPDATED OR CHANGED WITHOUT ANY NOTICE AT ANY TIME DUE TO THE UPGRADES OF THE PRODUCT OR ANY OTHER REASONS.

Trademark Statement

"Rockchip", "瑞芯微", "瑞芯" shall be Rockchip's registered trademarks and owned by Rockchip. All the other trademarks or registered trademarks mentioned in this document shall be owned by their respective owners.

All rights reserved. ©2021. Rockchip Electronics Co., Ltd.

Beyond the scope of fair use, neither any entity nor individual shall extract, copy, or distribute this document in any form in whole or in part without the written approval of Rockchip.

Rockchip Electronics Co., Ltd.

No.18 Building, A District, No.89, software Boulevard Fuzhou, Fujian, PRC

Website: www.rock-chips.com

Customer service Tel: +86-4007-700-590

Customer service Fax: +86-591-83951833

Customer service e-Mail: fae@rock-chips.com

Preface

Overview

The document presents how to build kernel, U-Boot or Rootfs of Rockchip RV1126/RV1109 Linux SDK separately, aiming to help engineers get started with RV1126/RV1109 Linux SDK faster.

[NOTICE]: Please update SDK version to V1.3.0 or the latest version

Get the version of SDK: `realpath .repo/manifests/rv1126_rv1109_linux_release.xml`

Product Version

Chipset	Kernel Version
RV1126/RV1109	Linux 4.19

Intended Audience

This document (this guide) is mainly intended for:

- Technical support engineers
- Software development engineers

Revision History

Version	Author	Date	Revision History
2020-08-10	V1.0.0	CWW	alpha
2020-08-12	V1.1.0	CWW	1. Add idblock.bin compile instructions 2. Add drivers insmod
2020-09-01	V1.2.0	CWW	1. Support eMMC compile instructions
2020-09-10	V1.3.0	CWW	1. Add Debug info chapter
2020-09-15	V1.4.0	CWW	1. Support AB system compilation
2020-09-27	V1.5.0	CWW	1. Fix BSP library build 2. Add print cif info
2020-12-08	V1.5.1	CWW	1. Fix insmod driver module
2021-01-14	V1.6.0	CWW	1. Update manufacture programmer firmware image
2021-02-18	V1.6.1	CWW	1. Update BSP library
2021-03-01	V1.6.2	CWW	1. Update CIF driver module to clear unready dev
2021-03-17	V1.6.3	CWW	1. Add the chapter of instructions to camera-related drivers insmod
2021-04-29	V1.6.4	CWW	1. Remove ./make.sh spl-s
2021-08-06	V1.6.5	CWW	1. Fix isp and cif insmod 2. Add jffs2 rootfs 3. Add Encode Debug Info
2021-10-18	V1.6.6	CWW	1. Fix isp and cif insmod Instructions to Camera-related Drivers insmod 2. Update tool Building for SPI NOR and eMMC

Instructions to Build System Images Separately

1. U-Boot Compilation
 - 1.1 Get U-Boot Code from SDK
 - 1.2 For SPI NOR U-Boot Compilation
 - 1.3 For eMMC U-Boot Compilation
 - 1.3.1 AB System Is Not Supported
 - 1.3.2 AB System Is Supported
 - 1.4 Instructions to U-Boot Images
2. Linux Kernel Compilation
 - 2.1 Get Linux Kernel Code from SDK
 - 2.2 Build Command Introduction
 - 2.3 For SPI NOR Linux Kernel Compilation
 - 2.4 For eMMC Linux Kernel Compilation
 - 2.4.1 Build eMMC Kernel Without Peripheral Drivers
 - 2.4.2 Build eMMC Kernel with Peripheral Drivers
 - 2.5 Package Drivers (only for building without peripheral drivers into kernel)
 - 2.6 Instructions to Linux Kernel Image
 - 2.7 Instructions to Drivers insmod (only for building without peripheral drivers into kernel)
 - 2.7.1 Instructions to Camera-related Drivers insmod
3. Root Filesystem Compilation
 - 3.1 Get tarball of build-busybox and Compile
 - 3.2 Instructions to Auto Mount Partition
4. Manufacture Programmer Firmware Image
 - 4.1 Building for SPI NOR and eMMC
 - 4.2 Building for SPI NAND and SLC NAND
5. Instructions to Build BSP Libraries
 - 5.1 Command to Build BSP Libraries
 - 5.2 BSP Files
6. Debug Info
 - 6.1 CPU Debug Info
 - 6.1.1 CPU Frequency Debug
 - 6.1.1.1 Print CPU Frequency
 - 6.1.1.2 Fix the Frequency of CPU
 - 6.1.2 Print CPU Thermal
 - 6.1.3 Disable CPU Thermal Control
 - 6.2 Encode Debug Info
 - 6.2.1 Print Encode Frame Rate
 - 6.3 Print CIF Info
 - 6.4 Print ISPP Info
 - 6.5 Print ISP Info

1. U-Boot Compilation

1.1 Get U-Boot Code from SDK

Get these directories from root directory of SDK:

Directory or File	Description
rkbin	about DDR and prebuilt loader bin
u-boot	U-Boot code
prebuilts	cross-compile tool

1.2 For SPI NOR U-Boot Compilation

```
cd u-boot
./make.sh rv1126-spi-nor-tiny
./make.sh --spl
./make.sh --idblock --spl
```

1.3 For eMMC U-Boot Compilation

1.3.1 AB System Is Not Supported

```
cd u-boot
./make.sh rv1126
./make.sh --spl
# parameter e.g.
#
mtdparts=rk29xxnand:0x00002000@0x00004000 (uboot),0x00010000@0x00006000 (boot),0x00
010000@0x00016000 (rootfs),-@0x00026000 (data:grow)
```

1.3.2 AB System Is Supported

```

cd u-boot
./make.sh rv1126-ab
./make.sh --spl
# parameter e.g.
#
mtdparts=rk29xxnand:0x00002000@0x00004000 (uboot_a),0x00002000@0x00006000 (uboot_b)
,0x00001000@0x00008000 (misc),0x00010000@0x00009000 (boot_a),0x00010000@0x00019000 (
boot_b),0x00020000@0x00029000 (system_a),0x00020000@0x00049000 (system_b),-
@0x00069000 (data:grow)

```

1.4 Instructions to U-Boot Images

The name of image	Description
rv1126_spl_loader_***.bin	loader file
uboot.img	U-Boot image
idblock.bin	the IDBlock partition file for firmware_merger tool

2. Linux Kernel Compilation

2.1 Get Linux Kernel Code from SDK

Get these directories from root directory of SDK:

Directory or File	Description
kernel	linux kernel code
prebuilts	cross-compile tool

2.2 Build Command Introduction

Build command format:

```
# configure linux kernel
# args1: chip architecture (e.g. arm)
# args2: linux kernel defconfig filename (e.g. xxx_defconfig)
# args3: linux kernel defconfig fragment filename (option)
make ARCH=args1 args2 args3
make menuconfig # this step is optional

# make kernel image
# args1: chip architecture (e.g. arm)
# args2: linux kernel dts's filename (e.g. arch/arm/boot/dts/rv1126-38x38-v10-
emmc.dts)
# -j12: allow 12 jobs compilation at once
make ARCH=args1 args2.img -j12
```

2.3 For SPI NOR Linux Kernel Compilation

```
make ARCH=arm rv1126_defconfig rv1126-spi-nor.config
make ARCH=arm rv1126-38x38-v10-spi-nor.img -j12
```

2.4 For eMMC Linux Kernel Compilation

2.4.1 Build eMMC Kernel Without Peripheral Drivers

```
make ARCH=arm rv1126_defconfig rv1126-emmc-drivers-modules.config
make ARCH=arm rv1126-38x38-v10-emmc.img -j12
```

2.4.2 Build eMMC Kernel with Peripheral Drivers

```
make ARCH=arm rv1126_defconfig rv1126-emmc-drivers-builtin.config
make ARCH=arm rv1126-38x38-v10-emmc.img -j12
```

2.5 Package Drivers (only for building without peripheral drivers into kernel)

```
make modules_install ARCH=arm INSTALL_MOD_STRIP=1 INSTALL_MOD_PATH=./drivers-ko
# remove unused soft link
rm -f drivers-ko/lib/modules/4.19.111/build drivers-
ko/lib/modules/4.19.111/source
```

2.6 Instructions to Linux Kernel Image

The name of image	Description
zboot.img	linux kernel image
drivers-ko	the directory of linux kernel drivers

2.7 Instructions to Drivers insmod (only for building without peripheral drivers into kernel)

```
# stop udevd before insmod driver modules
udevadm control --stop-exec-queue

# insmod videobuf2
insmod kernel/drivers/media/common/videobuf2/videobuf2-memops.ko
insmod kernel/drivers/media/common/videobuf2/videobuf2-dma-contig.ko
insmod kernel/drivers/media/common/videobuf2/videobuf2-common.ko
insmod kernel/drivers/media/common/videobuf2/videobuf2-v4l2.ko
insmod kernel/drivers/media/common/videobuf2/videobuf2-dma-sg.ko
insmod kernel/drivers/media/common/videobuf2/videobuf2-vmalloc.ko

# insmod drm
insmod kernel/drivers/gpu/drm/drm_kms_helper.ko
insmod kernel/drivers/gpu/drm/rockchip/rockchipdrm.ko

# insmod audio
insmod kernel/sound/soundcore.ko
insmod kernel/sound/core/snd.ko
insmod kernel/sound/core/snd-timer.ko
insmod kernel/sound/core/snd-pcm.ko
insmod kernel/sound/core/snd-pcm-dmaengine.ko
insmod kernel/sound/soc/snd-soc-core.ko
insmod kernel/sound/soc/codecs/snd-soc-dummy-codec.ko
insmod kernel/sound/soc/codecs/snd-soc-rk817.ko
insmod kernel/sound/soc/rockchip/snd-soc-rockchip-i2s-tdm.ko
insmod kernel/sound/soc/generic/snd-soc-simple-card-utils.ko
insmod kernel/sound/soc/generic/snd-soc-simple-card.ko

# insmod isp ispp cif rk_ircut and sensor
insmod kernel/drivers/media/v4l2-core/v4l2-fwnode.ko
insmod kernel/drivers/media/i2c/os04a10.ko
insmod kernel/drivers/media/i2c/imx415.ko
insmod kernel/drivers/media/i2c/rk_ircut.ko
insmod kernel/drivers/phy/rockchip/phy-rockchip-mipi-rx.ko
insmod kernel/drivers/media/platform/rockchip/cif/video_rkcif.ko
insmod kernel/drivers/media/platform/rockchip/isp/video_rkisp.ko
insmod kernel/drivers/media/platform/rockchip/ispp/video_rkispp.ko
echo 1 > /sys/module/video_rkcif/parameters/clr_unready_dev
echo 1 > /sys/module/video_rkisp/parameters/clr_unready_dev

# insmod vcodec
insmod kernel/drivers/video/rockchip/mpp/rk_vcodec.ko
```



```

# insmod usb for adb
insmod kernel/drivers/phy/rockchip/phy-rockchip-naneng-usb2.ko
insmod kernel/drivers/usb/dwc3/dwc3-of-simple.ko
insmod kernel/drivers/usb/dwc3/dwc3.ko

# insmod for adc key
insmod kernel/drivers/input/keyboard/adc-keys.ko

# insmod for led flash
insmod kernel/drivers/leds/led-class-flash.ko
insmod kernel/drivers/leds/leds-rgb13h.ko

# insmod sdcard ko
insmod kernel/drivers/mmc/host/dw_mmc.ko
insmod kernel/drivers/mmc/host/dw_mmc-pltfm.ko
insmod kernel/drivers/mmc/host/dw_mmc-rockchip.ko
insmod kernel/drivers/mmc/host/rk_sdmmc_ops.ko

# audio codec
insmod kernel/sound/soc/codecs/snd-soc-es8311.ko

# rtc
insmod kernel/drivers/rtc/rtc-pcf8563.ko

# pwm fill light
insmod kernel/drivers/leds/leds-pwm.ko

# restart udevd after insmod driver modules
udevadm control --start-exec-queue

```

2.7.1 Instructions to Camera-related Drivers insmod

Modify `rv1126-emmc-drivers-modules.config` as follows:

```

CONFIG_PHY_ROCKCHIP_MIPI_RX=m
# CONFIG_USB_CONFIGFS_F_UAC1 is not set
# CONFIG_USB_CONFIGFS_F_UAC2 is not set
# CONFIG_USB_CONFIGFS_F_UVC is not set
# CONFIG_USB_CONFIGFS_RNDIS is not set
CONFIG_V4L2_FWNODE=m
CONFIG_VIDEOBUF2_CORE=m
CONFIG_VIDEOBUF2_DMA_CONTIG=m
CONFIG_VIDEOBUF2_MEMOPS=m
CONFIG_VIDEOBUF2_V4L2=m
CONFIG_VIDEOBUF2_VMALLOC=m
### disable others sensor to be built-in kernel
# CONFIG_VIDEO_GC2053 is not set
# CONFIG_VIDEO_OV2718 is not set
# CONFIG_VIDEO_SC2232 is not set
# CONFIG_VIDEO_SC2310 is not set
# CONFIG_VIDEO_GC4C33 is not set
# CONFIG_VIDEO_IMX347 is not set
# CONFIG_VIDEO_IMX378 is not set
# CONFIG_VIDEO_OS04A10 is not set

```

```
# CONFIG_VIDEO_OV4689 is not set
CONFIG_VIDEO_SC200AI=m
CONFIG_VIDEO_ROCKCHIP_CIF=m
CONFIG_VIDEO_ROCKCHIP_ISP=m
CONFIG_VIDEO_ROCKCHIP_ISPP=m
```

Build kernel (`rv1126-38x38-v10-emmc` is the basename of dts) and install to the dir of drivers-ko.

```
make ARCH=arm rv1126_defconfig rv1126-emmc-drivers-modules.config
make ARCH=arm rv1126-38x38-v10-emmc.img -j12
make modules_install ARCH=arm INSTALL_MOD_STRIP=1 INSTALL_MOD_PATH=./drivers-ko
```

The script of insmod camera-related drivers:

```
#!/bin/sh

udevadm control --stop-exec-queue

insmod kernel/drivers/media/common/videobuf2/videobuf2-common.ko
insmod kernel/drivers/media/common/videobuf2/videobuf2-v4l2.ko
insmod kernel/drivers/media/common/videobuf2/videobuf2-memops.ko
insmod kernel/drivers/media/common/videobuf2/videobuf2-dma-contig.ko
insmod kernel/drivers/media/common/videobuf2/videobuf2-dma-sg.ko
insmod kernel/drivers/media/common/videobuf2/videobuf2-vmalloc.ko
insmod kernel/drivers/media/v4l2-core/v4l2-fwnode.ko
insmod kernel/drivers/media/i2c/sc200ai.ko
insmod kernel/drivers/phy/rockchip/phy-rockchip-mipi-rx.ko
insmod kernel/drivers/media/platform/rockchip/cif/video_rkcif.ko
insmod kernel/drivers/media/platform/rockchip/isp/video_rkisp.ko
insmod kernel/drivers/media/platform/rockchip/ispp/video_rkispp.ko

echo 1 > /sys/module/video_rkcif/parameters/clk_unready_dev
echo 1 > /sys/module/video_rkisp/parameters/clk_unready_dev

udevadm control --start-exec-queue
```

3. Root Filesystem Compilation

3.1 Get tarball of build-busybox and Compile

Get busybox tarball from path: `device/rockchip/rv1126_rv1109/prebuilt-packages/build-busybox`

```
# unpack busybox tarball
tar xjf busybox-1.27.2-patch-reboot-arg.tar.bz2

# copy rockchip's busybox defconfig
# busybox_spi_nor_defconfig used for spi nor
# busybox_emmc_defconfig used for eMMC (default)
cp busybox-1.27.2-patch/configs/busybox_defconfig busybox-
1.27.2/configs/busybox_defconfig
```

```

# change directory to busybox
cd busybox-1.27.2

# config defconfig
make busybox_defconfig

# compile, Notice: the cross compile tool is in the prebuilts directory of SDK
make ARCH=arm install CROSS_COMPILE=~/.RV1109-SDK/prebuilts/gcc/linux-x86/arm/gcc-arm-8.3-2019.03-x86_64-arm-linux-gnueabi/bin/arm-linux-gnueabi- -j32

# unpack base root filesystem which is prebuilt bin, e.g. target-emmc-v1.0.0.tar.bz2
tar xjf target-emmc-v1.0.0.tar.bz2

# copy busybox target bin and libs to target directory (option)
cp busybox-1.27.2/_install/* target/ -rfa

# package root filesystem with squashfs
mksquashfs target rootfs.squashfs -noappend -comp xz

# package root filesystem with squashfs
# --pad : partition size
mkfs.jffs2 -r target -o rootfs.jffs2 --pad=0x400000 -n

# package root filesystem with ext4, e.g.
tar xjf tools.tar.bz2
./tools/mkfs-ext4/do-mkfs.ext4.sh target rootfs.ext4 64M

# the command of unpack squashfs filesystem : unsquashfs ./rootfs.squashfs

```

NOTICE: The library named `/usr/lib/libv4l/plugins/libv4l-mplane.so` MUST be placed in the rootfs.

3.2 Instructions to Auto Mount Partition

target-emmc-v1.0.0.tar.bz2 support auto mount the partitions which config in the file of `/etc/fstab`. Auto mount script: `target/etc/init.d/S21mountall.sh`

Refer to the partition of userdata

```

cat target/etc/fstab
# <file system> <mount pt>      <type> <options>      <dump> <pass>
/dev/root      /                ext2    rw,noauto      0       1
proc           /proc           proc    defaults       0       0
devpts         /dev/pts        devpts  defaults,gid=5,mode=620 0       0
tmpfs          /dev/shm        tmpfs   mode=0777      0       0
tmpfs          /tmp            tmpfs   mode=1777      0       0
tmpfs          /run            tmpfs   mode=0755,nosuid,nodev 0       0
sysfs          /sys            sysfs   defaults       0       0
debug          /sys/kernel/debug debugfs  defaults      0       0
/dev/block/by-name/userdata /userdata       ext2    defaults      0       2

```

4. Manufacture Programmer Firmware Image

4.1 Building for SPI NOR and eMMC

- Build update.img

```
# e.g. select eMMC reference BoardConfig for building eMMC update.img
./build.sh device/rockchip/rv1126_rv1109/BoardConfig.mk
# or select SPI NOR reference BoardConfig for building SPI NOR update.img
# ./build.sh device/rockchip/rv1126_rv1109/BoardConfig-spi-nor-v12.mk
./build.sh all
./mkfirmware.sh
./build.sh updateimg
ls rockdev/update.img
```

- Convert update.img to Manufacture programmer firmware (out_image.img)

Get tool from `<SDK>/tools/linux/programmer_image_tool/programmer_image_tool`.

4.2 Building for SPI NAND and SLC NAND

See the document:

`<SDK>/docs/Linux/ApplicationNote/Rockchip_Developer_Guide_Linux_Nand_Flash_Open_Source_Solution_CN.pdf`.

5. Instructions to Build BSP Libraries

Get these directories from root directory of SDK:

Directory or File	Description
buildroot	buildroot's source
external	rockchip BSP codes
prebuilts	cross-compile tool
envsetup.sh	link to buildroot/build/envsetup.sh
Makefile	link to buildroot/build/Makefile

5.1 Command to Build BSP Libraries

The SDK BSP package only contains audio and video codec libraries, NPU libraries, and header files. Note: BSP package does not include file system.

```
source envsetup.sh rockchip_rv1126_rv1109_libs
make -j12
```

5.2 BSP Files

```
tree buildroot/output/rockchip_rv1126_rv1109_libs/BSP/  
buildroot/output/rockchip_rv1126_rv1109_libs/BSP/  
├─ example  
│   ├── common  
│   ├── iqfiles  
│   ├── librtsp  
│   ├── multi_audio_test  
│   ├── rknn_model  
│   ├── stressTest  
│   └─ vqefiles  
├─ include  
│   ├── rga  
│   ├── rkaiq  
│   └─ rkmedia  
├─ lib  
└─ npu  
    ├── include  
    ├── ko  
    └─ lib
```

6. Debug Info

6.1 CPU Debug Info

6.1.1 CPU Frequency Debug

6.1.1.1 Print CPU Frequency

```
# print current cpu frequency  
cat /sys/devices/system/cpu/cpu0/cpufreq/scaling_cur_freq  
1008000  
  
# print cpu available frequencies  
cat /sys/devices/system/cpu/cpu0/cpufreq/scaling_available_frequencies  
408000 600000 816000 1008000 1200000 1296000
```

6.1.1.2 Fix the Frequency of CPU

```
# set CPU 600MHz fixed frequency  
echo userspace > /sys/devices/system/cpu/cpu0/cpufreq/scaling_governor  
echo 600000 > /sys/devices/system/cpu/cpu0/cpufreq/scaling_setspeed
```

6.1.2 Print CPU Thermal

```
cat /sys/class/thermal/thermal_zone0/temp
```

6.1.3 Disable CPU Thermal Control

```
# disable thermal control
echo user_space > /sys/class/thermal/thermal_zone0/policy
# disable frequency limit
echo 0 > /sys/class/thermal/thermal_zone0/cdev0/cur_state
echo 0 > /sys/class/thermal/thermal_zone0/cdev1/cur_state
```

6.2 Encode Debug Info

6.2.1 Print Encode Frame Rate

```
# enable print fps log
echo 0x100 > /sys/module/rk_vcodec/parameters/mpp_dev_debug

# disable print fps log
echo 0 > /sys/module/rk_vcodec/parameters/mpp_dev_debug
```

```
# See mpp summary information
# cat /proc/mpp_service/session_summary
```

```
[root@RV1126_RV1109:~]# cat /proc/mpp_service/session_summary
```

session	device	width	height	format	fps_in	fps_out	rc_mode	bitrate	gop_size	fps_calc	profile
5bf7cd58	VEPU2										
52127d8e	RKVENC	2688	1520	h264	25	25	cbr	7549747	50	24.85	high
fc55943b	VEPU2										
c110fc71	RKVENC	640	480	h264	25	25	cbr	943718	50	25.05	high
d8485bb6	RKVENC	1920	1080	h264	25	25	cbr	1887436	50	25.34	high

6.3 Print CIF Info

```
cat /proc/rkcif_mipi_lvds
```

```
Driver Version:v00.01.08
Work Mode:ping pong
aclk_cif:500000000
hclk_cif:250000000
dclk_cif:297000000
Input Info:
  src subdev:m01_f_os04a10 1-0036-1
  interface:mipi csi2
  lanes:4
  vc channel: 0 1
```

```

hdr mode: hdr_x2
format:SBGGR10_1X10/2688x1520@30
crop.bounds:(0, 0)/2688x1520
Output Info:
format:BG10/2688x1520(0,0)
compact:enable
frame amount:79
fps:30
irq statistics:
        total:158
        csi over flow:0
        csi bandwidth lack:0
        all err count:0
        frame dma end:158

```

6.4 Print ISPP Info

```
cat /proc/rkispp0
```

```

cat /proc/rkispp0
rkispp0   Version:v00.01.05
Input     rkispp0 Format:FBC420 Size:3840x2160 (frame:15441 rate:41ms delay:20ms)
Output    rkispp_m_bypass Format:FBC0 Size:3840x2160 (frame:15440 rate:41ms
delay:45ms)
Output    rkispp_scale0 Format:NV12 Size:1280x720 (frame:15440 rate:41ms
delay:45ms)
Output    rkispp_scale1 Format:NV12 Size:720x480 (frame:15440 rate:41ms
delay:45ms)
Output    rkispp_scale2 Format:NV12 Size:1280x720 (frame:15440 rate:41ms
delay:45ms)
TNR       ON(0xd00000d) (mode: 2to1) (global gain: disable) (frame:15441
time:12ms) CNT:0x0 STATE:0x1e000000
NR        ON(0x47) (external gain: enable) (frame:15441 time:12ms) 0x5f0:0x0
0x5f4:0x0
SHARP     ON(0x1b) (YNR input filter: ON) (local ratio: ON) 0x630:0x0
FEC       OFF(0x2) (frame:0 time:0ms) 0xc90:0x0
ORB       OFF(0x0)
Interrupt Cnt:46278 ErrCnt:0
clk_ispp  500000000
aclk_ispp 500000000
hclk_ispp 250000000

```

6.5 Print ISP Info

```
cat /proc/rkisp0
```

```

cat /proc/rkisp0
rkisp0   Version:v00.01.05
Input     rkcif_mipi_lvds Format:SGBRG10_1X10 Size:3840x2160@30fps Offset(0,0) |
RDBK_X1(frame:15584 rate:40ms)
Output    rkispp0 Format:FBC420 Size:3840x2160 (frame:15583 rate:39ms)
Interrupt Cnt:62011 ErrCnt:0

```

```
clk_isp      594000000
aclk_isp     500000000
hclk_isp     250000000
DPCC0       ON(0x40000005)
DPCC1       ON(0x40000005)
DPCC2       ON(0x40000005)
BLS         ON(0x40000001)
SDG         OFF(0x80446197)
LSC         ON(0x1)
AWBGAIN     ON(0x80446197) (gain: 0x010d010d, 0x02260227)
DEBAYER     ON(0xf000111)
CCM         ON(0xc0000001)
GAMMA_OUT   ON(0xc0000001)
CPROC       ON(0xf)
IE          OFF(0x0) (effect: BLACKWHITE)
WDR         OFF(0x30cf0)
HDRTMO      ON(0xc8505a25)
HDRMGE      OFF(0x0)
RAWNR       ON(0xc0100001)
GIC         OFF(0x0)
DHAZ        ON(0xc0001009)
3DLUT       OFF(0x2)
GAIN        ON(0xc0010010)
LDCH        OFF(0x0)
CSM         FULL(0x80446197)
SIAF        OFF(0x0)
SIAWB       OFF(0x0)
YUVAE       ON(0x400100f3)
SIHST       ON(0x38000107)
RAWAF       ON(0x7)
RAWAWB      ON(0x4037e887)
RAWAE0      ON(0x40000003)
RAWAE1      ON(0x400000f5)
RAWAE2      ON(0x400000f5)
RAWAE3      ON(0x400000f5)
RAWHIST0    ON(0x40000501)
RAWHIST1    ON(0x60000501)
RAWHIST2    ON(0x60000501)
RAWHIST3    ON(0x60000501)
```