

ASUS Pro 16

User Manual

Product Overview

Thank you for purchasing the ASUS Pro 16. This premium laptop combines cutting-edge technology with sleek design to deliver exceptional performance for your daily computing needs. Whether you're working, creating, or entertaining, this device offers the power and versatility you need.

Technical Specifications

Specification	Details
Processor	AMD Ryzen 5 7000
Memory (RAM)	16 GB
Storage	1000 GB SSD
Display	14.0" 1920x1080
Graphics	Apple GPU
Battery Life	Up to 20 hours
Operating System	Windows 11
Weight	2.27 kg
Warranty	1 years

Key Features

- **High-Performance Processing:** Powered by AMD Ryzen 5 7000 for seamless multitasking
- **Ample Memory:** 16 GB RAM ensures smooth operation of multiple applications
- **Fast Storage:** 1000 GB SSD provides quick boot times and file access
- **Stunning Display:** 14.0-inch screen with vibrant colors and sharp details
- **All-Day Battery:** Up to 20 hours of battery life
- **Premium Build:** Sleek design weighing only 2.27 kg

Quick Setup Guide

- 1. Unboxing:** Carefully remove your laptop from the packaging. Ensure all accessories are present.
- 2. Charging:** Connect the power adapter and charge the battery fully before first use (approximately 2-3 hours).
- 3. Power On:** Press the power button located on the keyboard. The system will boot up automatically.
- 4. Initial Setup:** Follow the on-screen instructions to configure language, region, and user account.
- 5. Updates:** Connect to Wi-Fi and install any available system updates for optimal performance.

Care and Maintenance

- Cleaning:** Use a soft, lint-free cloth to clean the screen and body. Avoid harsh chemicals.
- Ventilation:** Ensure air vents are not blocked. Use on hard, flat surfaces for optimal cooling.
- Battery Care:** Avoid complete discharge. Keep battery level between 20-80% for longevity.
- Software Updates:** Regularly update your operating system and applications for security and performance.
- Backup:** Regularly backup important data to external storage or cloud services.

Troubleshooting

Issue	Solution
Device won't power on	Ensure battery is charged. Try holding power button for 10 seconds.
Screen is dim	Adjust brightness using Fn + brightness keys.
Wi-Fi not connecting	Toggle airplane mode on/off. Restart router if needed.
Device running slow	Close unused applications. Check for malware. Free up storage space.
Battery draining quickly	Reduce screen brightness. Close background apps. Check battery health in settings.

Warranty Information

This product includes a 1-year limited warranty covering manufacturing defects. The warranty does not cover physical damage, liquid damage, or damage from unauthorized repairs. For warranty service, please contact customer support with your proof of purchase and product serial number.

Customer Support: support@techstore.com | 1-800-TECH-HELP
Website: www.techstore.com/support