




Oster® 6 Cup Rice Cooker

Quick Start Guide

Model#: 4722000000

What's Inside



Safety Information

- Keep water away from heating element to reduce risk of electric shock.
- Product becomes very hot when in use. Do not touch hot surfaces.
- Use only the included pot in the base.
- Do not pour liquid into the base.
- Unplug and let cool before cleaning and when not in use.

Usage Guidelines

- Follow all instructions.
- Do not operate the unit uncovered.
- Do not leave the unit unattended while in use.
- Place on a dry, flat surface, such as a kitchen counter, for use. Do not use near other heating elements or open flame.
- Be careful around hot surfaces and steam vent. Allow the unit to cool completely before touching with bare hands.
- Do not leave the rice paddle or measuring cup inside the pot when in use.

Cooking Rice

1. Use the included measuring cup to measure 1, 2, or 3 cups of rice into the rice cooker.



2. Pour water to the same line in the pot (1, 2, or 3).



3. Cover with the lid, plug in, and press the cook button. When the left-side Warming light comes on, the rice is finished cooking.



Using the Steam Basket

- 1. Pour water into the pot to at least the 1 line.



- 2. Place the steam basket on the pot, food in the steam basket, and the lid on top.




- 3. Plug in and press the cook button. When water boils, set a timer based on the chart on the next page. Unplug when finished.



Tip: The left-side Warming light comes on when all the water has boiled. If you need to continue cooking, add more water and press the button again.

Cooking Rice and Using the Steam Basket

- 1. Follow steps 1 and 2 of Cooking Rice.



- 2. Place the steam basket on the pot, food in the steam basket, and the lid on top.



- 3. Plug in and press the cook button. When water boils, set a timer based on the chart on the next page.



- 4. After timer goes off, carefully remove steam basket. Replace lid and allow rice to finish cooking.

Time to Steam

Tip: Range indicates time from *al dente* to well-done.

Vegetable	Time (min)
asparagus	8–10
broccoli	11–13
brussels sprouts	11–13
cabbage	6–8
carrots	8–10
cauliflower	11–13
celery	8–12
green beans	8–10
spinach	6–11
squash	13–16
zucchini	10–12

Cleaning the Rice Cooker

- 1. Unplug and disassemble parts.
- 2. Wash non-electrical parts by hand. If base needs cleaning, wipe with a damp cloth. **Make sure all parts are completely dry before using again.**

Limited Warranty Information

Placeholder

Contact Information

If you have questions or comments, visit oster.com or call 1-800-334-0759.