

## Data Input Formats

[illegible]

<b>A-7</b>	<b>RAD</b>	Logical variable = T if radial coordinate are used; otherwise = F.
<p>1A note on output file names: in these instructions, files are referred to as "file n" where n may be 6, 7, 8, 9, or 11 and refers to Fortran unit numbers associated with output statements within the program. Actual file names are assigned by the user within the namelist file. The first line in that file gives the data input file for which these instructions apply (commonly vs2dt.dat); lines 2 through 6 of the namelist file list names for file 6, file 7, file 8, file 9, and file 11. File 6 is the main output file (commonly named vs2dt.out). File 7 is an auxiliary file that is currently unused. File 8 contains pressure heads and concentrations for all nodes in the model grid at selected observation times (variables.out). File 9 lists selected mass balance components at all or selected times (balance.out). File 11 contains heads, moisture content, saturations, and concentrations at selected observation points for all or selected times (obsPoints.out). Line A-6A is present only if TRANS = T.</p>		
	<b>ITSTOP</b>	Logical variable = T if simulation is to terminate after ITMAX iterations in onetime step; otherwise = F.
	<b>HEAT</b>	Logical variable = T if heat transport is to be simulated. otherwise = F.
	<b>SOLUTE</b>	Logical variable = T if reactive transport is to be simulated. otherwise = F.
Line A-8 ,A-9,A-10 is present if <b>SOLUTE=T</b>		
<b>A-8</b>	<b>CHEMFILE</b>	Phreeqc input file name (A80)
<b>A-9</b>	<b>DATABASEFILE</b>	Thermodynamics database file name(A80)
<b>A-10</b>	<b>PREFIX</b>	Prefix name (A80)
Line A-11 is present if <b>SOLUTE=T or HEAT =T</b>		
<b>A-11</b>	<b>CIS</b>	Logical variable = T if centered-in-space differencing is to be used; = F if backward-in-space differencing is to be used for transport equation
	<b>CIT</b>	Logical variable = T if centered-in-time differencing is to be used; = F if backward-in-time or fully implicit differencing is to be used.
Line A-12 is present if <b>SOLUTE=T</b>		
<b>A-12</b>	<b>IPRNTCHE</b>	= 0 FOR NO PHREEQC OUTPUT; = 1
		FOR SELECTED OUTPUT

	<b>INPRXZ</b>	SET EQUAL TO IPRNTCHE
	<b>IPOUT</b>	= 0 FOR NO PHREEQC OUTPUT; = 1
		FOR EXTENSIVE PHREEQC OUTPUT
<b>A-13</b>	<b>F11P</b>	Logical variable = T if concentration, head, moisture content, and saturation at selected observation points are to be written to file 11 at end of each time step; otherwise = F.
	<b>F7P</b>	Logical variable = T if fluxes through selected boundary faces are output to file07.out for each time step. Boundary faces are specified on input lines B-26 to B-28; otherwise = F.
	<b>F8P</b>	Logical variable = T if output of pressure heads (and concentrations if TRANS = T) to file 8 is desired at selected observation times; otherwise = F.
	<b>F9P</b>	Logical variable = T if one-line mass balance summary for each time step is to be written to file 9; otherwise = F.
	<b>F6P</b>	Logical variable = T if mass balance is to be written to file 6 for each time step; = F if mass balance is to be written to file 6 only at observation times and ends of recharge periods.
<b>A-14</b>	<b>THPT</b>	Logical variable = T if volumetric moisture contents are to be written to file 6; otherwise = F.
	<b>SPNT</b>	Logical variable = T if saturations are to be written to file 6; otherwise = F.
	<b>PPNT</b>	Logical variable = T if pressure heads are to

		be written to file 6; otherwise F.
	<b>HPNT</b>	Logical variable = T if total heads are to be written to file 6; otherwise = F.
	<b>VPNT</b>	Logical variable = T if velocities are to be written to file 6; otherwise =F.
<b>A-15</b>	<b>IFAC</b>	= 0 if grid spacing in horizontal (or radial) direction is to be read in for each column and multiplied by FACX. = 1 if all horizontal grid spacing is to be constant and equal to FACX. = 2 if horizontal grid spacing is variable, with spacing for the first two columns equal to FACX and the spacing for each subsequent column equal to XMULT times the spacing of the previous column, until the spacing equals XMAX, whereupon spacing becomes constant at XMAX.
	<b>FACX</b>	Constant grid spacing in horizontal (or radial) direction (if IFAC=1); constant multiplier for all spacing (if IFAC=0); or initial spacing (if IFAC=2), L.
Line set A-16 is present if IFAC = 0		
<b>A-16</b>	<b>DXR</b>	Grid spacing in horizontal or radial direction. Number of entries must equal NXR,L.
Line set A-17 is present if IFAC = 0		
<b>A-17</b>	<b>XMULT</b>	Multiplier by which the width of each cell is increased from that of the previous cell.
	<b>XMAX</b>	Maximum allowed horizontal or radial spacing, L.
<b>A-18</b>	<b>JFAC</b>	= 0 if grid spacing in vertical direction is to be read in for each row and multiplied by FACZ. = 1 if all vertical grid spacing is to be

		constant and equal to FACZ. = 2 if vertical grid spacing is variable, with spacing for the first two rows equal to FACZ and the spacing for each subsequent row equal to ZMULT times the spacing at the previous row, until spacing equals ZMAX, whereupon spacing becomes constant at ZMAX.
A-19	FACZ	Constant grid spacing in vertical direction (if JFAC=1); constant multiplier for all spacing (if JFAC=0); or initial vertical spacing (if JFAC=2), L.
Line set A-20 is present if JFAC = 0		
A-20	DELZ	Grid spacing in vertical direction; number of entries must equal NLY, L.
Line set A-21 is present if IFAC = 0		
A-21	ZMULT	Multiplier by which each cell is increased from that of previous cell.
	ZMAX	Maximum allowed vertical spacing, L.
Line sets A-22 to A-23 are present only if F8P = T,		
A-22	NPLT	Number of time steps to write pressure heads and concentrations to file 8 and heads, concentrations, saturations, moisture contents, and/or velocities to file 6.
A-23	PLTIM	Elapsed times at which pressure heads and concentrations are written to file 8, and heads, concentrations, saturations, velocities, and/or moisture contents to file 6, T.
Line sets A-24 to A-25 are present only if F11P = T,		
A-24	NOBS	Number of observation points for which heads, concentrations, moisture contents, and saturations are to be written to file 11. <i>(NOTE: Set NOBS equal to a negative number {-1 times number of observation points} if output to file 11 is desired only at selected output times rather than at each time step.)</i>
A-25	J,N	Row and column of observation points.

		A double entry is required for each observation point, resulting in 2xNOBS values. No comments allowed.
Lines A-26 and A-27 are present only if F9P = T.		
A-26	NMB9	Total number of mass balance components written to file 9. Must be less than 73. (NOTE: Set NMB9 equal to a negative number {-1 times number of components} if output to file 9 is desired only at selected output times rather than at each time step.)
A-27	MB9	The index number of each mass balance component to be written to file 9. (See table 7, from p. 66, in Healy (1990) listed at end of these instructions.)
[Line group B read by subroutine VSREAD]		
B-1	EPS	Head closure criterion for iterative solution of flow equation, L.
	HMAX	Relaxation parameter for iterative solution. See discussion in Lappala and others (1987) for more detail. Value is generally in the range of 0.4 to 1.2.
	WUS	Weighting option for intercell relative hydraulic conductivity: WUS = 1 for full upstream weighting. WUS = 0.5 for arithmetic mean. WUS = 0.0 for geometric mean
Line B-2 present if HEAT=T		
B-2	EPS1	Temperature closure criterion for iterative solution of transport equation, °C.
	EPS2	Velocity closure criterion for outer iteration loop at each time step, L/T.
Line B-3 present if SOLUTE=T		
B-3	EPS3	Concentration closure criterion for iterative solution of transport equation, M/L <sup>3</sup> .
B-4	MINIT	Minimum number of iterations per time step.

	<b>ITMAX</b>	Maximum number of iterations per time step.
<b>B-5</b>	<b>PHRD</b>	Logical variable = T if initial conditions are read in as pressure heads; = F if initial conditions are read in as moisture contents.
<b>B-6</b>	<b>NTEX</b>	Number of textural classes or lithologies having different values of hydraulic conductivity, specific storage, and/or constants in the functional relations among pressure head, relative conductivity, and moisture content, must be less than 11.
	<b>NPROP</b>	Number of textural classes or lithologies having different values of hydraulic conductivity, specific storage, and/or constants in the functional relations among pressure head, relative conductivity, and moisture content, must be less than 11. Number of flow properties to be read in for each textural class. When using Brooks and Corey, van Genuchten or Nimmo-Rossi functions, set NPROP = 6; when using Haverkamp functions, set NPROP = 8. When using tabulated data, set NPROP = 6 plus number of data points in table. [For example, if the number of pressure Heads in the table is equal to N1, then set NPROP=3*(N1+1)+3]
<b>B-7</b>	<b>HFT</b>	Hydraulic function type, 0 for Brooks-Corey; 1 for van Genuchten; 2 for Haverkamp; 3 for tabular data; and 4 for Rossi-Nimmo.
Line sets B-6, B-7, and B-7A must be repeated NTEX times		
<b>B-8</b>	<b>ITEX</b>	Index to textural class.
<b>B-9</b>	<b>ANIZ(ITEX)</b>	Ratio of hydraulic conductivity in the z-coordinate direction to that in the x-coordinate direction for textural class ITEX.

	<b>HK(ITEM,1)</b>	Saturated hydraulic conductivity (K) in the x-coordinate direction for class ITEM, L/T.
	<b>HK(ITEM,2)</b>	Specific storage ( $S_s$ ) for class ITEM, L <sup>-1</sup> .
	<b>HK(ITEM,3)</b>	Porosity ( $f$ ) for class ITEM. MUST BE >0
<p>Definitions for the remaining sequential values on this line are dependent upon which functional relation is selected to represent the nonlinear coefficients. Five different functional relations are allowed: (0) Brooks and Corey, (1) van Genuchten, (2) Haverkamp, (3) tabular data, and (4) Rossi-Nimmo. In the following descriptions, definitions for the different functional relations are indexed by the above numbers. For tabular data, all pressure heads are input first (in decreasing order from the largest to the smallest), all relative hydraulic conductivities are then input in the same order, followed by all moisture contents. See Healy (1990) and Lappala and others (1987) for additional details.</p>		
<b>B-9</b>	<b>HK(ITEM,4)</b>	<p>(0) <math>h_b</math>, Brooks-Corey bubbling pressure head (must be less than 0), L.</p> <p>(1) <math>\alpha</math>, van Genuchten alpha. NOTE: <math>\alpha</math> is as defined by van Genuchten (1980) and is the negative reciprocal of <math>\alpha'</math> used in earlier versions (prior to version 3.0) of VS2DT, L.</p> <p>(2) <math>A'</math>, Haverkamp parameter (must be less than 0.0), L.</p> <p>(3) Largest pressure head in table.</p> <p>(4) <math>\Psi_0</math>, Rossi-Nimmo parameter.</p>
	<b>HK(ITEM,5)</b>	<p>(0) Residual moisture content (<math>\theta_r</math>).</p> <p>(1) Residual moisture content (<math>\theta_r</math>).</p> <p>(2) Residual moisture content (<math>\theta_r</math>).</p> <p>(3) Second largest pressure head in table.</p> <p>(4) <math>\Psi_D</math>, Rossi-Nimmo parameter.</p>
	<b>HK(ITEM,6)</b>	<p>(0) <math>\lambda</math>, Brooks-Corey pore-size distribution index.</p> <p>(1) <math>n</math>, van Genuchten parameter, <math>\beta'</math> in</p>



		<p>Healy (1990) and Lappala and others (1987).</p> <p>(2) <math>B'</math>, Haverkamp parameter.</p> <p>(3) Third largest pressure head in table.</p> <p>(4) <math>\lambda</math>, Rossi-Nimmo parameter.</p>
	<b>HK(ITEM,7)</b>	<p>(0) Not used.</p> <p>(1) Not used.</p> <p>(2) <math>\alpha</math>, Haverkamp parameter (must be less than 0.0), L.</p> <p>(3) Fourth largest pressure head in table.</p> <p>(4) Not used.</p>
	<b>HK(ITEM,8)</b>	<p>(0) Not used.</p> <p>(1) Not used.</p> <p>(2) <math>\beta</math>, Haverkamp parameter.</p> <p>(3) Fifth largest pressure head in table.</p> <p>(4) Not used.</p> <p>For functional relations (0), (1), (2), and (4) no further values are required on this line for this textural class. For tabular data (3), data input continues as follows:</p>
	<b>HK(ITEM,9)</b>	Next largest pressure head in table.
	<b>HK(ITEM,N1+3)</b>	Minimum pressure head in table. Here N1 = Number of pressure heads in table; NPROP = 3*(N1+1)+3).
	<b>HK(ITEM,N1+4)</b>	Always input a value of 99.
<b>B-9</b>	<b>HK(ITEM,N1+5)</b>	Relative hydraulic conductivity corresponding to first pressure head.
	<b>HK(ITEM,N1+6)</b>	Relative hydraulic conductivity corresponding to second pressure head.
	• • •	
	<b>HK(ITEM,2*N1+4)</b>	Relative hydraulic conductivity corresponding to smallest pressure head.
	<b>HK(ITEM,2*N1+5)</b>	Always input a value of 99.
	<b>HK(ITEM,2*N1+6)</b>	Moisture content corresponding to first pressure head.
	<b>HK(ITEM,2*N1+7)</b>	Moisture content corresponding to second pressure head.
	<b>HK(ITEM,3*N1+5)</b>	Moisture content corresponding to smallest pressure head.
	<b>HK(ITEM,3*N1+6)</b>	Always input a value of 99.

Regardless of which functional relation is selected there must be NPROP+1 values on line B-9. Line B-9A is present only if HEAT = T.		
<b>B-9A</b>	<b>HT(ITE X,1)</b>	Longitudinal dispersivity ( $\alpha_L$ ), L.
	<b>HT(ITE X,2)</b>	Transverse dispersivity ( $\alpha_T$ ), L.
	<b>HT(ITE X,3)</b>	Heat capacity of dry solids ( $C_s$ ), Q/L <sup>3</sup> °C.
	<b>HT(ITE X,4)</b>	Thermal conductivity of watersediment at residual moisture content, $K_T(\theta_r)$ , Q/LT °C.
	<b>HT(ITE X,5)</b>	Thermal conductivity of watersediment at full saturation, $K_T(\phi)$ , Q/L °C.
	<b>HT(ITE X,6)</b>	Heat capacity of water ( $C_w$ ), which is the product of density times specific heat of water, Q/L <sup>3</sup> °C.
Line B-9B is present only if SOLUTE = T.		
	<b>HS(ITE X,1)</b>	Longitudinal dispersivity ( $\alpha_L$ ), L.
	<b>HS(ITE X,2)</b>	Transverse dispersivity ( $\alpha_T$ ), L.
	<b>HS(ITE X,3)</b>	Molecular diffusion coefficient, $D_m$ , L <sup>2</sup> /T.
<b>B-10</b>	<b>IROW</b>	If IROW = 0, textural classes are read for each row. This option is preferable if many rows differ from the others. If IROW = 1, textural classes are read in by blocks of rows, each block consisting of all the rows in sequence consisting of uniform properties or uniform properties separated by vertical interface.
Line set B-11 is present only if IROW = 0		
<b>B-11</b>	<b>JTEX</b>	Indices (ITE X) for textural class for each node, read in row by row. There must be NLY*NXR entries.
Line set B-11 is present only if IROW = 1 As many groups of B-11 variables as are needed to completely cover the grid are required. The final group of variables for this set must have IR = NXR and JBT = NLY.		
<b>B-12</b>	<b>IL</b>	Left hand column for which texture class

		applies. Must equal 1 or IR (from previous line set)+1.
	<b>IR</b>	Right hand column for which texture class applies. Final IR for sequence of rows must equal NXR.
	<b>JBT</b>	Bottom row of all rows for which the column designations apply. JBT must not be increased from its initial or previous value until IR = NXR
	<b>JRD</b>	Texture class within block.
Note: As an example, for a column of uniform material: IL = 1, IR = NXR, JBT = NLY, and JRD = texture class designation for the column material. One line will represent the set for this example.		
<b>B-13</b>	<b>IREAD</b>	If IREAD = 0, all initial conditions in terms of pressure head or moisture content as determined by the value of PHRD are set equal to FACTOR. If IREAD = 1, all initial conditions are read from file IU in user-designated format and multiplied by FACTOR. If IREAD = 2 initial conditions are defined in terms of pressure head, and an equilibrium profile is specified above a free-water surface at a depth of DWTX until a pressure head of HMIN is reached. all pressure heads above this are set to HMIN. If IREAD=3 initial heads and concentrations are read unformatted from file fort.13 for continuation of a previous simulation beginning at time STIM (line A-2).
	<b>FACTOR</b>	Multiplier or constant value, depending on value of IREAD, for initial conditions.
Line B-14 is present only if IREAD = 2,		

<b>B-14</b>	<b>DWTX</b>	Depth to free-water surface above which an equilibrium profile is computed, L.
	<b>HMIN</b>	Minimum pressure head to limit height of equilibrium profile, L. Must be negative.
Line B-15 is read only if IREAD =1,		
<b>B-15</b>	<b>IU</b>	Unit number from which initial head or moisture content values are to be read.
	<b>IFMT</b>	Format to be used in reading initial values from unit IU. Must be enclosed in quotation marks, for example '(10X,E10.3)'.
<b>B-16</b>	<b>BCIT</b>	Logical variable = T if evaporation is to be simulated at any time during the simulation; otherwise = F.
	<b>ETSIM</b>	Logical variable = T if evapotranspiration (plant-root extraction) is to be simulated at any time during the simulation.
<p>Note: The reader is cautioned on the use of evaporation and evapotranspiration in VS2DH. These processes can influence and be influenced by soil temperature. As described in Lappala and others (1987) and implemented in VS2DH, these processes are simplistically assumed to be isothermal. Users should evaluate the ramifications of this assumption in their applications. If these processes are an integral component of an application, then use of another numerical model that treats evaporation and evapotranspiration in a more realistic fashion may be warranted.</p> <p>Line B-17 is present only if BCIT = T or ETSIM = T.</p>		
<b>B-17</b>	<b>NPV</b>	<p>Number of ET periods to be simulated. NPV values for each variable required for the evaporation and/or evapotranspiration options must be entered on the following lines. If ET variables are held constant throughout the simulation code, NPV = 1.</p> <p><i>(NOTE: Set NPV equal to a negative number {-1 times number of ET periods} if solute uptake by plant roots is not allowed; otherwise, solute is removed</i></p>

		<i>from the domain by root uptake.)</i>
	<b>ETCYC</b>	Length of each ET period, T.
Line B-18 to B-20 are present only if BCIT = T.		
<b>B-18</b>	<b>PEVAL</b>	Potential evaporation rate (PEV) at beginning of each ET period. Number of entries must equal NPV, L/T.
To conform with the sign convention used in most existing equations for potential evaporation, all entries must be greater than or equal to 0. The program multiplies all nonzero entries by -1 so that the evaporative flux is treated as a sink rather than a source.		
<b>B-19</b>	<b>RDC(1,J)</b>	Surface resistance to evaporation (SRES) at beginning of ET period, L-1. For a uniform soil, SRES is equal to the reciprocal of the distance from the top active node to land surface, or 2/DELZ(2). If a surface crust is present, SRES may be decreased to account for the added resistance to water movement through the crust. Number of entries must equal NPV.
<b>B-20</b>	<b>RDC(2,J)</b>	Pressure potential of the atmosphere (HA) at beginning of each ET period; may be estimated using equation 6 of Lappala and others (1987), L. Number of entries must equal NPV.
Lines B-21 to B-25 are present only if ETSIM = T.		
<b>B-21</b>	<b>PTVAL</b>	Potential evapotranspiration rate (PET) at beginning of each ET period, L/T. Number of entries must equal NPV. As with PEV, all values must be greater than or equal to 0.
<b>B-22</b>	<b>RDC(3,J)</b>	Rooting depth at beginning of each ET period, L. Number of entries must equal NPV.
<b>B-23</b>	<b>RDC(4,J)</b>	Root activity at base of root zone at beginning of each ET period, L-2. Number of entries must equal NPV.

<b>B-24</b>	<b>RDC(5,J)</b>	Root activity at top of root zone at beginning of each ET period, L-2. Number of entries must equal NPV
Note: Values for root activity generally are determined empirically, but typically range from 0 to $3 \times 10^4$ m/m <sup>3</sup> . As programmed, root activity varies linearly from land surface to the base of the root zone, and its distribution with depth at any time is represented by a trapezoid. In general, root activities will be greater at land surface than at the base of the root zone.		
<b>B-25</b>	<b>RDC(6,J)</b>	Pressure head in roots (HROOT) at beginning of each ET period, L. Number of entries must equal NPV.
Lines B-26 is present only if HEAT = T		
<b>B-26</b>	<b>IREAD</b>	24 If IREAD = 0, initial temperature are set equal to FACTOR. If READ =1, all initial temperature read from file IU in user designated format and multiplied by FACTOR
	<b>FACTOR</b>	Multiplier or constant value, depending on value of IREAD, for initial temperature
Line B-27 is present only if IREAD = 1.		
<b>B-27</b>	<b>IU</b>	Unit number from which initial temperature is to be read.
	<b>IFMT</b>	Format to be used in reading initial temperature values from unit IU. Must be enclosed in quotation marks, for example '(10X, E10.3)'.
Lines B-28 and B-29 are present only if SOLUTE = T		
<b>B-28</b>	<b>IREAD</b>	If IREAD = 0 initial solution, pure phase assemblage, exchange, surface, gas, solid phase assemblage and kinetics as defined in CHEMFILE are set by INSOL If IREAD = 1 initial solution, pure phase assemblage, exchange, surface, gas, solid phase assemblage and kinetics read from file IU in user designated format

<b>B-29</b>	<b>INSOL(1)</b>	Initial SOLUTION number
	<b>INSOL(2)</b>	EQUILIBRIUM_PHASES number, if there is no EQUILIBRIUM_PHASES then set the default value of -1
	<b>INSOL(3)</b>	EXCHANGE number if there is no EXCHANGE then set the default value of -1
	<b>INSOL(4)</b>	SURFACE if there is no SURFACE then set the default value of -1
	<b>INSOL(5)</b>	GAS_PHASE if there is no GAS_PHASE then set the default value of -1
	<b>INSOL(6)</b>	SOLID_SOLUTIONS if there is no SOLID_SOLUTIONS then set the default value of -1
	<b>INSOL(7)</b>	KINETICS if there is no KINETICS then set the default value of -1
Line B-30 present only IREAD=1 in B-29		
<b>B-30</b>	<b>INDSOL(1,N)</b>	Initial SOLUTION number read at all nodes row wise
	<b>INDSOL(2,N)</b>	EQUILIBRIUM_PHASES number read at all nodes row wise If there is no EQUILIBRIUM_PHASES set in chemfile file just set default value of -1
	<b>INDSOL(3,N)</b>	EXCHANGE number read at all nodes row wise If there is no EXCHANGE just set default value of -1
	<b>INDSOL(4,N)</b>	SURFACE number read at all nodes row wise If there is no SURFACE set in chemfile file just set default value of -1
	<b>INDSOL(5,N)</b>	GAS_PHASE number read at all nodes row wise If there is no GAS_PHASE set in chemfile file just set default value of -1
	<b>INDSOL(6,N)</b>	SOLID_SOLUTIONS number read at all nodes row wise If there is no SOLID_SOLUTIONS set in chemfile file just set default value of -1
	<b>INDSOL(7,N)</b>	KINETICS number read at all nodes row wise If there is no KINETICS set in chemfile

		file just set default value of -1
Lines B-29 to B-31 are present only if F7P = T.		
<b>B-29</b>	<b>NUMBF</b>	Number of boundary faces for which fluxes will be calculated and output to file file07.out.
	<b>MAXCELLS</b>	Maximum number of cells on any boundary face.
Lines B-30 and B-31 must be repeated NUMBF times.		
<b>B-30</b>	<b>IDBF</b>	Boundary face identifier (integer).
	<b>NUMCELLS</b>	Number of finite difference cells on this boundary face
<b>B-31</b>	<b>J,N</b>	Row and column number of each cell on this boundary face. (NOTE: Line B-28 must be repeated NUMCELLS times for each boundary face.)
	<b>Inert modifications here for solute and argus one case</b>	
	<b>#####</b>	
[Line group C read by subroutine VSTMER, NRECH sets of C lines are required]		
<b>C-1</b>	<b>TPER</b>	Length of this recharge period, T.
	<b>DELT</b>	Length of initial time step for this period, T.
<b>C-2</b>	<b>TMLT</b>	Multiplier for time step length.
	<b>DLTMX</b>	Maximum allowed length of time step, T.
	<b>DLTMIN</b>	Minimum allowed length of time step, T.
	<b>TRED</b>	Factor by which time-step length is reduced if convergence is not obtained in ITMAX iterations. Values usually should be in the range 0.1 to 0.5. If no reduction of time-step length is desired, input a value of 0.0.
<b>C-3</b>	<b>DSMAX</b>	Maximum allowed change in head per time step for this period, L.
	<b>STERR</b>	Steady-state head criterion; when the maximum change in head between successive time steps is less than



		STERR, the program assumes that steady state has been reached for this period and advances to next recharge period, L.
C-4	POND	Maximum allowed height of ponded water for constant flux nodes. See Lappala and other (1987) for detailed discussion of POND, L.
C-5	PRNT	Logical variable = T if heads, concentration, moisture contents, and/or saturations are to be printed to file 6 after each time step; = F if they are to be written to file 6 only at observation times and ends of recharge periods.
C-6	BCIT	Logical variable = T if evaporation is to be simulated for this recharge period; otherwise = F.
	ETSIM	Logical variable = T if evapotranspiration (plant-root extraction) is to be simulated for this recharge period; otherwise = F.
	SEEP	Logical variable = T if seepage faces are to be simulated for this recharge period; otherwise = F.
C-7 to C-9 cards are present only if SEEP = T,		
C-7	NFCS	Number of possible seepage faces. Line sets C-8 and C-9 must be repeated NFCS times
C-8	JJ	Number of nodes on the possible seepage face.
	JLAST	Number of the node which initially represents the highest node of the seep; value can range from 0 (bottom of the face) up to JJ (top of the face).
C-9	J,N	Row and column of each cell on possible

		seepage face, in order from the lowest to the highest elevation; JJ pairs of values are required.
<b>C-10</b>	<b>IBC</b>	Code for reading in boundary conditions by individual node (IBC=0) or by row or column (IBC=1). Only one code may be used for each recharge period, and all boundary conditions for period must be input in the sequence for that code.
Line set C-11 to C-14 is read only if IBC = 0. One line is required for each node for which new boundary conditions are specified.		
Line set C-11 is read only if HEAT=TRUE or SOLUTE=TRUE		
<b>C-11</b>	<b>JJ</b>	Row number of node.
	<b>NN</b>	Column number of node.
	<b>NTX</b>	Node type identifier for boundary conditions. = 0 for no specified boundary (needed for resetting some nodes after initial recharge period); = 1 for specified pressure head; = 2 for specified flux per unit horizontal surface area in units of L/T; = 3 for possible seepage face; = 4 for specified total head; = 5 for evaporation; = 6 for specified volumetric flow in units of L <sup>3</sup> /T; = 7 for gravity drain. (The gravity drain boundary condition allows gravity driven vertical flow out of the domain assuming a unit vertical hydraulic gradient. Flow into the domain cannot occur.)
	<b>PFDUM</b>	Specified head for NTX = 1 or 4 or specified flux for NTX = 2 or 6. If codes 0, 3, 5, or 7 are specified, the line should contain a

		dummy value for PFDUM or should be terminated after NTX by a blank and a slash (/).
Line set C-12 is read only if HEAT=TRUE		
<b>C-12</b>	<b>NTT</b>	Node type identifier for heat transport boundary conditions. = 0 for no specified boundary; = 1 for specified concentration;
	<b>TF</b>	Specified temperature for NTT = 1 or NTX = 1, 2, 4, 6, or 7
Line set C-13 is read only if SOLUTE=TRUE		
<b>C-13</b>	<b>NTC</b>	Node type identifier for reactive transport boundary conditions. = 0 for no specified boundary; = 1 for specified concentration;
	<b>INSBC1</b>	Solution number of boundary solution
	<b>INSBC2</b>	Solution number of solution initially present
	<b>SBFRAC</b>	Initial solution and boundary solution mixing fraction
Line set C-14 is read only if HEAT=FALSE and SOLUTE=FALSE		
<b>C-14</b>	<b>JJ</b>	Same as C-11
	<b>NN</b>	Same as C-11
	<b>NTX</b>	Same as C-11
	<b>PFDUM</b>	Same as C-11
C-15 to C-18 is present only if IBC = 1. One line should be present for each row or column for which New boundary conditions are specified.		
Line set C-15 is read only if HEAT=TRUE or SOLUTE=TRUE		
<b>C-15</b>	<b>JJT</b>	Top node of row or column of nodes sharing same boundary condition.
	<b>JJB</b>	Bottom node of row or column of nodes having same boundary condition. Will equal JJT if a boundary row is being read.
	<b>NNL</b>	Left column in row or column of nodes having same boundary condition.
	<b>NNR</b>	Right column of row or column of nodes having same boundary condition. Will equal NNL if a boundary column is being read in.
	<b>NTX</b>	Same as line C-11.
	<b>PFDUM</b>	Same as line C-11.

Line set C-16 is read only if HEAT=TRUE		
<b>C-16</b>	<b>NTT</b>	Same as line C-12
	<b>TF</b>	Same as line C-12
Line set C-17 is read only if SOLUTE=TRUE		
<b>C-17</b>	<b>NTC</b>	Same as line C-13
	<b>INSBC1</b>	Same as line C-13
	<b>INSBC2</b>	Same as line C-13
	<b>SBFRAC</b>	Same as line C-13
Line set C-18 is read only if HEAT=FALSE and SOLUTE=FALSE		
<b>C-18</b>	<b>JJT</b>	Same as line C-15
	<b>JJB</b>	Same as line C-15
	<b>NNL</b>	Same as line C-15
	<b>NNR</b>	Same as line C-15
	<b>NTX</b>	Same as line C-15
	<b>PFDUM</b>	Same as line C-15
<b>C-19</b>	Designated end of recharge period. Must be included after line C-17 or C-18 data for each recharge period. Two C-13 lines must be included after final recharge period. Line must always be entered as 999999 /.	

**Table 7.--Index of Mass-Balance Components for Output to File 9**

Index

Number Component

- 1 Flow in across specified head boundaries -total for simulation
- 2 Flow in across specified head boundaries -total for time step
- 3 Flow in across specified head boundaries -rate for time step
- 4 Flow out across specified head boundaries -total for simulation
- 5 Flow out across specified head boundaries -total for time step
- 6 Flow out across specified head boundaries -rate for time step
- 7 Flow in across specified flux boundaries -total for simulation
- 8 Flow in across specified flux boundaries -total for time step
- 9 Flow in across specified flux boundaries -rate for time step
- 10 Flow out across specified flux boundaries -total for simulation
- 11 Flow out across specified flux boundaries -total for time step

- 12 Flow out across specified flux boundaries -rate for time step
- 13 Total flow in -total for simulation
- 14 Total flow in -total for time step
- 15 Total flow in -rate for time step
- 16 Total flow out -total for simulation
- 17 Total flow out -total for time step
- 18 Total flow out -rate for time step
- 19 Evaporation -total for simulation
- 20 Evaporation -total for time step
- 21 Evaporation -rate for time step
- 22 Transpiration -total for simulation
- 23 Transpiration -total for time step
- 24 Transpiration -rate for time step
- 25 Evaporation + Transpiration -total for simulation
- 26 Evaporation + Transpiration -total for time step
- 27 Evaporation + Transpiration -rate for time step
- 28 Change in fluid stored in domain -total for simulation
- 29 Change in fluid stored in domain -total for time step
- 30 Change in fluid stored in domain -rate for time step
- 31 Fluid volumetric balance -total for simulation
- 32 Fluid volumetric balance -total for time step
- 33 Fluid volumetric balance -rate for time step
- 34 Solute flux in across specified pressure head boundaries -total for simulation
- 35 Solute flux in across specified pressure head boundaries -total for time step
- 36 Solute flux in across specified pressure head boundaries -rate for time step
- 37 Solute flux out across specified pressure head boundaries -total for simulation
- 38 Solute flux out across specified pressure head boundaries -total for time step
- 39 Solute flux out across specified pressure head boundaries -rate for time step
- 40 Solute flux in across specified flux boundaries -total for simulation
- 41 Solute flux in across specified flux boundaries -total for time step
- 42 Solute flux in across specified flux boundaries -rate for time step
- 43 Solute flux out across specified flux boundaries -total for simulation
- 44 Solute flux out across specified flux boundaries -total for time step
- 45 Solute flux out across specified flux boundaries -rate for time step
- 46 Diffusive/Dispersive flux in across specified flux boundaries -total for simulation
- 47 Diffusive/Dispersive flux in across specified flux boundaries -total for time step
- 48 Diffusive/Dispersive flux in across specified flux boundaries -rate for time step
- 49 Diffusive/Dispersive flux out across specified flux boundaries -total for simulation
- 50 Diffusive/Dispersive flux out across specified flux boundaries -total for time step
- 51 Diffusive/Dispersive flux out across specified flux boundaries -rate for time step
- 52 Total solute flux in -total for simulation
- 53 Total solute flux in -total for time step
- 54 Total solute flux in -rate for time step
- 55 Total solute flux out -total for simulation
- 56 Total solute flux out -total for time step
- 57 Total solute flux out -rate for time step

58 Solute flux out through evapotranspiration -total for simulation  
 59 Solute flux out through evapotranspiration -total for time step  
 60 Solute flux out through evapotranspiration -rate for time step  
 61 First order decay of solute -total for simulation  
 62 First order decay of solute -total for time step  
 63 First order decay of solute -rate for time step  
 64 Adsorption or ion exchange of solute -total for simulation  
 64 Adsorption or ion exchange of solute -total for time step  
 64 Adsorption or ion exchange of solute -rate for time step  
 67 Change in solute stored in domain -total for simulation  
 68 Change in solute stored in domain -total for time step  
 69 Change in solute stored in domain -rate for time step  
 70 Solute mass balance -total for simulation  
 71 Solute mass balance -total for time step  
 72 Solute mass balance -rate for time step

---



---

**Table 7.--Index of Mass-Balance Components for Output to File 9**

Index

Number Component

1 Flow in across specified head boundaries -total for simulation  
 2 Flow in across specified head boundaries -total for time step  
 3 Flow in across specified head boundaries -rate for time step  
 4 Flow out across specified head boundaries -total for simulation  
 5 Flow out across specified head boundaries -total for time step  
 6 Flow out across specified head boundaries -rate for time step  
 7 Flow in across specified flux boundaries -total for simulation  
 8 Flow in across specified flux boundaries -total for time step  
 9 Flow in across specified flux boundaries -rate for time step  
 10 Flow out across specified flux boundaries -total for simulation  
 11 Flow out across specified flux boundaries -total for time step  
 12 Flow out across specified flux boundaries -rate for time step  
 13 Total flow in -total for simulation  
 14 Total flow in -total for time step  
 15 Total flow in -rate for time step  
 16 Total flow out -total for simulation  
 17 Total flow out -total for time step  
 18 Total flow out -rate for time step  
 19 Evaporation -total for simulation  
 20 Evaporation -total for time step  
 21 Evaporation -rate for time step  
 22 Transpiration -total for simulation  
 23 Transpiration -total for time step  
 24 Transpiration -rate for time step  
 25 Evaporation + Transpiration -total for simulation

26 Evaporation + Transpiration -total for time step  
27 Evaporation + Transpiration -rate for time step  
28 Change in fluid stored in domain -total for simulation  
29 Change in fluid stored in domain -total for time step  
30 Change in fluid stored in domain -rate for time step  
31 Fluid volumetric balance -total for simulation  
32 Fluid volumetric balance -total for time step  
33 Fluid volumetric balance -rate for time step  
34 Energy flux in across specified pressure head boundaries -total for simulation  
35 Energy flux in across specified pressure head boundaries -total for time step  
36 Energy flux in across specified pressure head boundaries -rate for time step  
37 Energy flux out across specified pressure head boundaries -total for simulation  
38 Energy flux out across specified pressure head boundaries -total for time step  
39 Energy flux out across specified pressure head boundaries -rate for time step  
40 Energy flux in across specified flux boundaries -total for simulation  
41 Energy flux in across specified flux boundaries -total for time step  
42 Energy flux in across specified flux boundaries -rate for time step  
43 Energy flux out across specified flux boundaries -total for simulation  
44 Energy flux out across specified flux boundaries -total for time step  
45 Energy flux out across specified flux boundaries -rate for time step  
46 Conductive/Dispersive flux in across specified flux boundaries -total for simulation  
47 Conductive/Dispersive flux in across specified flux boundaries -total for time step  
48 Conductive/Dispersive flux in across specified flux boundaries -rate for time step  
49 Conductive/Dispersive flux out across specified flux boundaries -total for simulation  
50 Conductive/Dispersive flux out across specified flux boundaries -total for time step  
51 Conductive/Dispersive flux out across specified flux boundaries -rate for time step  
52 Total Energy flux in -total for simulation  
53 Total Energy flux in -total for time step  
54 Total Energy flux in -rate for time step  
55 Total Energy flux out -total for simulation  
56 Total Energy flux out -total for time step  
57 Total Energy flux out -rate for time step  
58 Energy flux out through evapotranspiration -total for simulation  
59 Energy flux out through evapotranspiration -total for time step  
60 Energy flux out through evapotranspiration -rate for time step  
67 Change in Energy stored in domain -total for simulation  
68 Change in Energy stored in domain -total for time step  
69 Change in Energy stored in domain -rate for time step  
70 Energy balance -total for simulation  
71 Energy balance -total for time step  
72 Energy balance -rate for time step