


Description

This module implements a periodic impulse function. The output variable *Out* is set to 0x00007FFF for 1 sampling period. The period of the output signal *Out* is specified by the input *Period*.


Availability

This IQ module is available in one interface format:

- 1) The C interface version

Module Properties

Type: Target Independent, Application Independent

Target Devices: x281x or x280x

C Version File Names: impulse.c, impulse.h

IQmath library files for C: IQmathLib.h, IQmath.lib

Item	C version	Comments
Code Size [□] (x281x/x280x)	14/14 words	
Data RAM	0 words [*]	
xDAIS ready	No	
XDAIS component	No	IALG layer not implemented
Multiple instances	Yes	
Reentrancy	Yes	

* Each pre-initialized “_iq” IMPULSE structure consumes 8 words in the data memory

[□] Code size mentioned here is the size of the **calc()** function

C Interface

C Interface

Object Definition

The structure of IMPULSE object is defined by following structure definition

```
typedef struct { Uint32 Period;    // Input: Period of output in # of sampling cycles (Q0)
                Uint32 Out;      // Output: Impulse output (0x00000000 or 0x00007FFF)
                Uint32 Counter;  // Variable: Impulse generator counter (Q0)
                void (*calc)();  // Pointer to calculation function
            } IMPULSE;
```

```
typedef IMPULSE *IMPULSE_handle;
```

Item	Name	Description	Format	Range(Hex)
Input	Period	Period of output in # of sampling period	Q0	00000000-7FFFFFFF
Output	Out	Impulse output	Q0	0 or 00007FFF
Internal	Counter	Impulse generator counter	Q0	00000000-7FFFFFFF

GLOBAL_Q valued between 1 and 30 is defined in the IQmathLib.h header file.

Special Constants and Data types

IMPULSE

The module definition is created as a data type. This makes it convenient to instance an interface to the impulse generator. To create multiple instances of the module simply declare variables of type IMPULSE.

IMPULSE_handle

User defined Data type of pointer to IMPULSE module

IMPULSE_DEFAULTS

Structure symbolic constant to initialize IMPULSE module. This provides the initial values to the terminal variables as well as method pointers.

Methods

```
void impulse_calc(IMPULSE_handle);
```

This definition implements one method viz., the impulse generator computation function. The input argument to this function is the module handle.

Module Usage

Instantiation

The following example instances two IMPULSE objects
IMPULSE ig1, ig2;

Initialization

To Instance pre-initialized objects
IMPULSE ig1 = IMPULSE_DEFAULTS;
IMPULSE ig2 = IMPULSE_DEFAULTS;

Invoking the computation function

```
ig1.calc(&ig1);  
ig2.calc(&ig2);
```

Example

The following pseudo code provides the information about the module usage.

```
main()  
{  
  
}  
  
void interrupt periodic_interrupt_isr()  
{  
    ig1.Period = input1;           // Pass inputs to ig1  
    ig2.Period = input2;           // Pass inputs to ig2  
  
    ig1.calc(&ig1);                // Call compute function for ig1  
    ig2.calc(&ig2);                // Call compute function for ig2  
  
    out1 = ig1.Out;                // Access the outputs of ig1  
    out2 = ig2.Out;                // Access the outputs of ig2  
  
}
```

Technical Background

Implements the following equation:

$$\begin{aligned} Out &= 0x00007FFF, \text{ for } t = n \cdot Tout, n = 1, 2, 3, \dots \\ &= 0, \text{ otherwise} \end{aligned}$$

where,

$Tout$ = Time period of output pulses = $Period \times Ts$

Ts = Sampling time period

