

Használati útmutató •
INSTRUKCJA OBSŁUGI •
NÁVOD K POUŽITÍ •
NÁVOD NA POUŽITIE •
Инструкция за експлоатация •
user guide •

D27T

HU

PL

CS

SK

BG

EN

SAGEMCOM

1. Introduction

Dear customer:

Thank you for purchasing a DECT SAGEMCOM telephone we appreciate your trust in us.

This product was manufactured with the utmost care, should you encounter difficulties during its use. We recommend that you refer to this user guide. You can also find information on the following site:


<http://www.sagemcom.com>

For your comfort and safety, we ask that you read the following paragraph carefully:

Recommendations and safety instructions



Your DECT telephone must not be installed in a humid room (wash-up room, bathroom, laundry room, kitchen, etc.) unless it is 1.50 m away from a water point or outside. Your telephone must be operated at temperatures ranging from 5°C and 45°C.



Only use the supplied power adapter, connect it to the base socket according to the installation instructions provided in this booklet and the indications on the identification label affixed to it (voltage, current, electric network frequency). As a precaution, in case of danger, the mains adapters act as a disconnecting mechanism for the 230V power supply. They should be placed near the device and should be easily accessible.



This telephone was designed for use on the public switched telephone network (PSTN). In case of a problem you must first contact your reseller. Only use the supplied telephone cord.



For your personal safety, never place your handset on the base without the batteries, or without the battery cover, you could get an electric shock.

To avoid damaging your handset, only use certified rechargeable AAA batteries NiMH 1.2 V 550 mAH, never use non rechargeable batteries. Insert the batteries in the handset battery compartment respecting polarity.



At the end of their useful life, batteries must be disposed of according to the recycling instructions presented in this booklet.



Your DECT telephone has an inside radio range of about 50 metres and up to 300 metres in open space. The immediate presence of metal parts, (of a television for example), of any electric appliance may result in range reduction.



In areas where storms are frequent, we recommend that you protect your telephone line using a surge protection device.

This equipment does not function in the case of an electric network shutdown: for emergency calls, it is recommended to use another unit during power cuts.



The CE marking certifies that the product meets the essential requirements of Directive 1999/5/CE of the European Parliament and of the Council pertaining to microwave radio equipment and telecommunication terminal equipment, for the safety and health of users, for electromagnetic interference. Furthermore, it efficiently uses the frequency spectrum attributed to ground and spatial communication to prevent damaging interference.

The declaration of compliance may be looked up on the www.sagemcom.com site, or can be obtained from the following address:

SAGEMCOM SAS

250, route de l'Empereur - 92500 Rueil-Malmaison - France

2. Before you begin

Make sure your package includes the items:

1. Base unit,
2. Handset,
3. One batteries compartment cover,
4. Two rechargeable batteries,
5. Telephone line cord,
6. AC power supply,
7. This user guide.

In the case of purchasing a pack duo or trio, you will find in addition for each additional handset:

1. A handset charger,
2. One batteries compartment cover,
3. Two rechargeable batteries.

2.1. Digital security system

Your cordless phone uses a security system to provide protection against false ringing, unauthorised access and charges to your phone line.

When you place the handset in the base, the unit verifies its security code. After a power outage or batteries replacement, you should place the handset in the base for about 20 seconds to reset the code.

2.2. Installing the phone





1. Remove the batteries compartment door of handset.
2. Insert batteries pack and connect the cord from left direction into the jack inside the handset.
3. Put the compartment door back on. «*SEARCHING...*» appears on the screen.
4. Plug the power supply cord into AC outlet and the other end into the power jack on the base bottom.
5. A welcome message in all the languages supported by the telephone is displayed on the screen, press **menu** *.
6. Select the country using ▲ or ▼ keys, press **menu** *.
7. A screen asks you to confirm your choice. Press **menu**. You will hear a confirmation tone.
8. The screen saver is displayed.

* : depending on country



By default, your handset name and number are displayed on the idle screen. You can change this display.

For this purpose, press and hold down the key : The current time and date are displayed on the screen.

To return to the previous display, press and hold down the key .

Place the handset in the base station to charge for 15 hours prior to first use. if you don't properly charge the phone, batteries performance will be compromised.

9. Plug one end of the telephone line cord into the modular wall phone jack and the other end into the jack on the base.

10. After charging, press  key, you can hear dial tone.




Only use the supplied power adapter, connect it to the base socket according to the installation instructions provided in this booklet and the indications on the identification label affixed to it (voltage, current, electric network frequency). As a safety measure, you can use the power adaptors to cut off the 230V current in case of danger. They must be located near to the device, and must be easily accessible.

2.3. Handset keys



* The voice mail number can be programmed.
To change it, refer to « Assign a shortcut » page 9.

2.4. Base Station



2.5. Quick guide to handset display icons



Signal strength icon (blinking when no signal or the signal strength is weak).



Call (icon is blinking when a new call is in the caller list).



Voicemail icon: indicates that new messages are present in your voicemail box.



Handset ringer muted.





Received call list (appears when a new call is in the caller list).




Memory.




Charging status icon ( : Full;  + flashing (charger not connected) : Flat; blinking during charging).



If you see the icon change into  + flashing (charger not connected, that means your batteries are low, please put the handset in cradle of base to recharge your batteries.

3. Menu structure





* depending on country

4. Calls

4.1. Cordless phone basics



4.1.1. Handsfree

If you bought an D27T, you can enable the handsfree mode of the handset while having a conversation with your contact.




1. Press  to activate the handsfree mode of the handset.
2. To deactivate the handsfree mode, press  again.

4.1.2. Make a call

Ensure that the handset is switched on.

1. Press the Talk key , you will hear the dialling tone and the display will show you the phone icon .
2. Enter the phone number. The number is dialled.


- OR -

1. Enter the phone number first and then press  key. If you make a mistake, press  key to remove the last digit.
2. Ending a call press  key or place the handset in the base station.



4.1.3. Auto talk off *(Refer to paragraph 7.4 page 12)*

Placing the handset in the case cradle while the handset is off the hook (during a call) automatically hangs up the handset.


4.1.4. Answering a call

When the phone rings, press the  key to answer the call.



4.1.5. Handset volume

You can adjust the volume of what you hear through the handset at any time by pressing  or  key. You will hear a beep with each key press. You will hear a double beep when you reach the highest or lowest setting.

4.1.6. Caller timer

After you press **Talk** key  on the handset, the built-in call timer shows in the display (after 10 seconds) and counts the length of time of the call on minutes and seconds.





4.1.7. Ending a call

To end a call press . The timer remains displayed on the screen for 10 seconds. You can, however, return on the screen saver by pressing .

4.1.8. Redialling a call



The last five numbers you have dialled can be quickly redialled.

Redialling from Standby Mode:

1. Press  key. The phone number that was last dialled appears on the display.
2. Press the  or  key to review redial telephone list. (You can select to redial your last five numbers called).
3. Press  key to dial out the number.

4.1.9. Microphone mute function

During a call you can switch OFF the microphone. The call is placed on hold.


- **Enable MUTE function:** Press the  key during a call. The display shows "MUTE ON". Your correspondent will not be able to hear you.
- **Disable MUTE function:** Press the  key to continue the call.

4.1.10. Recall / Flash

Press the **R** key to access line transfer offered by PABX or call waiting provided by telephone Company.


4.1.11. Voice Mail (According to operator)

This function allows you to receive calls while you are absent. You can then listen to the messages as network Voice Mails.

To indicate that a new message has been received the envelope icon  and the new event message "VOICEMAIL" are displayed on the Handset screen.


1. While on idle screen, press and hold  in order to access voice messaging service.

- The envelope icon  disappears when there are no more new messages.

Note ! Your voicemail number is not set in the factory, you can set the number using the key  .
To proceed, turn to paragraph 5.5 page 9.



4.1.12. Temporary tone

In pulse dialling, you can use temporary tone dialling to temporarily access touch-tone service offered by banks.

- Press the  key after call is answered.
- Press the number key and follow the voice instructions.
- After you hang up, the phone automatically returns to dial pulse (rotary) service.

4.1.13. Paging the handset

To locate a misplaced handset:

Press the  key at the base station, "PAGING " flashes on the screen of the handsets registered on your D27T base station until you press a handset key or until you press  on the base station again.


4.2. Calling line identification presentation (CLIP)

This CLIP phone stores and displays CLIP information provided by your local telephone company. You must subscribe to CLIP service in order to use this unit.

If you have not subscribed to CLIP service or if the caller number is suppressed, the display shows "UNKNOWN".

4.2.1. Caller list

CLIP of incoming Call are stored in the CALLER LIST menu.




When you enter the CALLER LIST menu, the display will show icon .
Caller List stores the last 10 incoming calls and call time.

4.2.2. Display of numbers not available





UNAVAILABLE : you are not in same area as your contact.

WITHHOLD ID : your contact does not want their number to be displayed.




4.2.3. Accessing the caller list menu


- Press the  key to enter the Caller List menu. The display shows the recent caller phone number (up to 12 digits).
- Press the  or  key through the caller List.

4.2.4. Calling back a caller




- Press the  key to enter the caller list menu.
- Press the  or  key to select a call record.
- Press the  key to dial the number.

4.2.5. Deleting caller list record

- Press the  key to enter the caller list menu.
- Press the  or  key to select a call record.
- Press **menu** key.
 - Select "DELETE" to delete the current record.
 - Select "DELETE ALL" to delete the entire Caller list.

4. A confirmation screen appears :
 - If you do not wish to delete the current record, press .
 - To delete the current record, press **menu**.
5. The record or the entire Caller list is deleted.
You will hear a confirmation tone.

4.2.6. Storing memory from the caller list

1. Press the  key. The caller list appears on the screen. Use  or  to select the desired caller number.
 2. Press **menu** key, then select "SAVE NUMBER". Press **menu**.
 3. Enter the name of the entry. Press **menu**.
- The entry is stored in the phonebook. You will hear a confirmation tone.

Note ! *If the number is too long (more than 12 digits), the screen will not show the number in full.*





Press  key to go to last number page for CID length.

5. Phonebook

You can store 80 phonebook entries in your phonebook.

Each phonebook entry can contain the name of your contact which can be a maximum of 12 characters long (spaces included), your contact's telephone number up to 24 digits.







5.1. Dialling a memory number

1. Press  key.
2. Press the  or  key to view the phonebook locations.
3. Press  key. The display number is dialled.


5.2. Storing a memory

1. Press **menu**, "PHONEBOOK" appears on the screen. Press **menu**.
2. "NEW ENTRY" appears on the screen, press **menu**.
3. Enter the name of the entry. Press **menu** key to confirm the name.
4. Enter the number of your entry using the keypad keys. Press **menu** key.
The entry is stored in the phonebook. You will hear a confirmation tone.

5.3. Editing a memory

1. Press **menu**, "PHONEBOOK" appears on the screen. Press **menu**.
2. Using the  or  key, select "EDIT ENTRY". Press **menu**.
The list of phonebook entries organised in alphabetical order appears. Select the entry you want to edit using  or .
3. You will then enter the name input screen and the cursor will be at the end of the name:
 - The information is accurate. Press **menu** key.
 - To correct the name, press  key to delete characters.
Enter the new name and press **menu** key.
4. You will then enter the number screen and the cursor will be at the end of the number:
 - The information is accurate. Press **menu** key.
 - To correct the number, press  key to delete the numbers.
Enter the new number and press **menu** key.
5. The entry is then modified and you will hear a confirmation tone.


5.4. Deleting a memory / the whole phonebook

1. Press **menu**, "PHONEBOOK" appears on the screen. Press **menu**.
2. Using the ▲ or ▼ key, select "DELETE". Press **menu**.
The list of phonebook entries organised in alphabetical order appears. Select the entry you want to delete using ▲ or ▼.
3. A confirmation screen appears.
 - If you do not wish to delete the entry, press .
 - To delete the entry, press **menu** key.
 The entry is deleted from the phonebook. You will hear a confirmation tone.

Note ! If you enter the wrong digits press  key to delete the incorrect digits.

To delete the entire phonebook list, select "DELETE ALL", press **menu**.
A confirmation screen appears:


Note !

- If you do not wish to delete the entry, press .
- To delete the entry, press **menu** key.

 The entire phonebook are deleted.
You will hear a confirmation tone.

5.5. Assign a shortcut

This menu allows you to record two quick dial numbers assigned to the keys 1 and 2 on the keyboard.

Note ! Your voice mail number is not factory set and you can assign it to the key .
Please Contact your telephony operator in order to obtain the appropriate voicemail number.

1. Press **menu**, "PHONEBOOK" appears on the screen. Press **menu**.
2. Using the ▲ or ▼ key, select "DIRECT MEM.". Press **menu**.
3. Using the ▲ or ▼ keys, select the key you want to assign a number (1 or 2) to and press **menu**, "NO NUMBER" is displayed on the screen. Press **menu**.
4. "EDIT NUMBER" appears on the screen, Press **menu**.
5. You will then enter the name input screen. Enter the name of the entry and press **menu** to confirm.
6. You will then enter the number screen. Enter the number of the entry. Press **menu** to confirm. You will hear a confirmation tone.


5.5.1. Calling an abbreviated number

To call the number you have assigned to one of the shortcut keys:

1. Hold down the key on which the number was programmed (1 or 2).
2. The number is displayed on the screen and is automatically dialled.

5.6. Inserting a pause




You can insert a pause in the dialling sequence. Wait for a dial tone before you press **menu**. The pause time is fixed to **3 seconds**.

Press and hold  key during edit mode to inset the pause. The display shows an "P".



6. Using the Multi-Handset capabilities

These functions are used for handset management when two or more handsets are registered on the same base.

6.1. Intercom Call/Intercom

1. Make sure your handset is on standby mode.
2. Press the  key on the handset.
 - If your installation has two handsets, the second handset is directly called, and "HANDSET" followed by the handset number are displayed on the screen.
 - The display shows the **INT** icon and the number of all registered handsets.
 - Enter the desired handset number or press the  key if you want to call all handsets. All registered handsets are ringing.
3. On the called handset, press the  key to answer.



6.2. Answering an internal call


1. The ring melody from an internal call is different from an external call. "HANDSET" and the calling handset number appear on the screen. "f" is blinking.
2. Press the  key to answer. The "f" stop blinking.
3. Ending an internal call press the  key.

6.3. Call management

6.3.1. An external and an internal call

Transferring an external call to another handset registered on same base



1. During a call, press . The external user is put on hold.
2. Enter the internal call number. When the user answers, you can announce the call.
3. Press the  key to transfer the call.

Note! To switch from one call to another, press and hold down the  key until an aural signal is heard.

Note! If the called handset does not answer, press  to take back the call.

Making conference calls (3-way conversation)

You can connect one external call to two handsets registered at the base station. All users can talk and listen simultaneously:

1. Press  key. The external user is put on hold.
2. Enter the internal call number. Wait until the internal user answers.
3. Press and hold  key, until an aural signal is heard to start a three-way conference. "CONFERENCE" is displayed on the handset screen.

6.3.2. Two outside calls

Taking a second call while you are already on line

During a call, a beep is emitted by your operator to inform you that a second call is on hold. A screen displays the number of this second caller on hold.

Press **R** then the key  to take back this new call.


Your first contact is put on hold and you can talk with the second caller.

Making a second call while you already on line

During a conversation, press **R** then dial the number to be called.


The call in process is then put on hold and you can take the second call back.

Switching from one call to the other

To switch from one call to the other, press **R** then the key .

The call in process is then put on hold and you can take the second call back.

Ending one of the two calls

To end one call and continue with the other, press **R** then the key .

The call in process is then ended finally and you take the second call back.

To set up a 3-way conference (the 2 calls and yourself)

During a conversation, press **R** then the key .


You can then talk with the 2 contacts at the same time.

To end the 3-way conference, press the red key .

7. Customising the handset

7.1. Handset naming

This function allows you to change the name of your handset.

1. Press **menu**, select "*PERSONAL SET*" using the ▲ or ▼ key, Press **menu**.
2. "*HANDSET NAME*" appears on the screen. Press **menu**.
 - Use the keypad to enter the new name (up to 10 characters).
 - Use  key to delete wrong input if necessary.
3. Press **menu** key to confirm your selection. You will hear a confirmation tone

7.2. Tone settings

7.2.1. Handset ringer level

You can choose from four ringer volumes.

1. Press **menu**, select "*PERSONAL SET*" using the ▲ or ▼ key, Press **menu**.
2. Using the ▲ or ▼ key, select "*HANDSET TONE*" Press **menu**.
3. "*RING VOLUME*" appears on the screen. Press **menu**.
4. Use ▲ or ▼ to select the volume level.
5. Press **menu** key to confirm your selection.

7.2.2. Handset ringer melody

This function allows you to assign a ring tone for incoming calls.

1. Press **menu**, select "*PERSONAL SET*" using the ▲ or ▼ key, Press **menu**.
2. Using the ▲ or ▼ key, select "*HANDSET TONE*" Press **menu**.
3. Using the ▲ or ▼ key, select "*RING TONES*" Press **menu**.
4. Use ▲ or ▼ to select the ring tone.
5. Press **menu** key to confirm your selection.

7.2.3. Key tone On/Off

This function allows you to activate or deactivate tones being heard when pressing the keypad.

1. Press **menu**, select "*PERSONAL SET*" using the ▲ or ▼ key. Press **menu**.
2. Using the ▲ or ▼ key, select "*HANDSET TONE*". Press **menu**.
3. Using the ▲ or ▼ key, select "*KEY BEEP*". Press **menu**.
4. Use ▲ or ▼ to select "*ON*" or "*OFF*" setting.
5. Press **menu** key to confirm your selection.

7.3. Modifying the language

1. Press **menu**, select "*PERSONAL SET*" using the ▲ or ▼ key, Press **menu**.
2. Using the ▲ or ▼ key, select "*LANGUAGE*". Press **menu**.
3. Use ▲ or ▼ to choose the desired language.
4. Press **menu** key to confirm your selection. You will hear a confirmation tone.



7.4. Auto talk (Refer to § 4.1.3 "Auto talk off" page 6)

When active, the auto talk off feature enables you to automatically hang up as soon as you put the handset on its base.

1. Press **menu**, select "*PERSONAL SET*" using the ▲ or ▼ key. Press **menu**.
2. Using the ▲ or ▼ key, select "*AUTO HANG-UP*". Press **menu**.
3. Use ▲ or ▼ to select "*ON*" or "*OFF*" setting.
4. Press **menu** key to confirm your selection. You will hear a confirmation tone.



7.5. Key lock

You can lock the keypad to prevent inadvertent activation.

1. Press and hold  key for 1 second, when the keypad lock is switched ON, the display will show "*KEYS LOCKED*".
2. To recover to normal, press and hold  key 1 sec or replace handset into the base cradle.

8. Phone setting

8.1. Time and date

1. Press **menu**, select "*CLOCK&ALARM*" using the ▲ or ▼ key, Press **menu**.
2. Using the ▲ or ▼ key, select "*DATE/TIME*". Press **menu**.
The date is displayed.
 - To keep the date, press **menu**.
 - To change it, enter the new date in YY/MM/DD format.
 - To go back to change the entry, press .
3. Press **menu**. The date is displayed.
 - To keep the time, press **menu**.
 - To change it, enter the new time in the HH:MM format.
(If, after entering the time, the time format is *12H*, use the ▲ key to set *AM* and the ▼ key to set *PM*).
 - To go back to change the entry, press .
4. Press **menu**. You will hear a confirmation tone.

8.2. Date format / Hour format

8.2.1. Hour format

1. Press **menu**, select "*CLOCK&ALARM*" using the ▲ or ▼ key, Press **menu**.
2. Using the ▲ or ▼ key, select "*SET FORMAT*". Press **menu**.
3. Using the ▲ or ▼ key, select "*TIME FORMAT*". Press **menu**.
4. Use ▲ or ▼ to select format.
5. Press **menu** key to confirm your selection. You will hear a confirmation tone.

8.2.2. Date format

This function allows you to define the date format (JJ/MM ou MM/JJ).

1. Press **menu**, select "**CLOCK&ALARM**" using the ▲ or ▼ key, Press **menu**.
2. Using the ▲ or ▼ key, select "**SET FORMAT**". Press **menu**.
3. Using the ▲ or ▼ key, select "**DATE FORMAT**". Press **menu**.
4. Use ▲ or ▼ to select format.
5. Press **menu** key to confirm your selection. You will hear a confirmation tone.

8.3. Alarm clock

To set the date and time:

1. Press **menu**, select "**CLOCK&ALARM**" using the ▲ or ▼ key, Press **menu**.
2. Using the ▲ or ▼ key, select "**ALARM**". Press **menu**.
3. To activate the alarm once, select "**ON ONCE**".
4. To repeat the alarm each day at the programmed time, select "**ON DAILY**".
5. To deactivate the alarm, select "**OFF**".
6. Select your choice then press **menu**:
Use the touch tone pad to enter the current alarm time. Enter minutes first (format is HH:MM).
(If, after entering the time, the time format is 12H, use the ▲ key to set **AM** and the ▼ key to set **PM**).
7. Press **menu** key to confirm your selection. You will hear a confirmation tone.

8.4. Modifying alarm tone

1. Press **menu**, select "**CLOCK&ALARM**" using the ▲ or ▼ key, Press **menu**.
2. Using the ▲ or ▼ key, select "**ALARM TONE**". Press **menu**.
3 melodies are available: "**MELODY 1**", "**MELODY 2**" and "**MELODY 3**".
3. Select the desired melody.
4. Press **menu** key to confirm your selection. You will hear a confirmation tone.

9. Advanced settings

9.1. Base master PIN code

Your base station code (default setting **0000**) is required to access certain security functions. This code can include 8 digits.


1. Press **menu**.
Select "advanced set" using the ▲ or ▼ key, press **menu**.
2. "**CHANGE PIN**" appears on the screen. Press **menu**.
The base station code entry screen is displayed.
3. Enter your old code first. Each time a digit is entered the «_» is replaced by a «*».
Press **menu** to confirm.
4. Enter your new PIN code. Each time a digit is entered the «_» is replaced by a «*».
5. Press **menu** key to confirm your selection. You will hear a confirmation tone.

Note ! Carefully note your base station code. You will need it to change certain settings.

9.2. Association handset & base

This function allows you to register a new handset on your base.

1. Press **menu**. Select "**ADVANCED SET**" using the ▲ or ▼ key, press **menu**.
2. Using the ▲ or ▼ key, select "**REGISTRATION**". Press **menu**.
3. Enter the 4 digit base master PIN code (default 0000). Each time a digit is entered the «_» is replaced by a «*».

4. Press and hold  key for 5 seconds (after 1 minute if no Handset has started association process the base goes back to standby).
5. Press **menu** key to confirm. The display shall show "WAITING" to indicate the waiting state.
6. Once the handset is registered, you will hear a confirmation tone. The handset automatically exits the registering mode.
7. The handset number assigned automatically by the base appears on the screen.

9.3. Disassociation of a handset

This function allows you to de-register a handset from your base.


1. Press **menu**. Select "ADVANCED SET" using the ▲ or ▼ key, press **menu**.
2. Using the ▲ or ▼ key, select "UNREGISTER". Press **menu**.
3. Enter the 4 digit base master PIN code (default 0000). Each time a digit is entered the «_» is replaced by a «*». Press **menu** key to confirm.
4. Select the handset you want to delete (at standby state, "PLS REG H/S" is displayed on the screen). You will hear a long beep confirmation tone.

9.4. Modifying the country

1. Press **menu**. Select "ADVANCED SET" using the ▲ or ▼ key, press **menu**.
2. Using the ▲ or ▼ key, select "COUNTRY". Press **menu**.
3. Enter the 4 digit base master PIN code (default 0000). Each time a digit is entered the «_» is replaced by a «*». Press **menu** key to confirm.
4. Using the ▲ or ▼ key, select the country where you will use the telephone. Press **menu**.
5. A confirmation screen appears, press **menu**.
The message "WAITING" appears on the screen. You will hear a confirmation tone.

9.5. Restoring the Handset / Base Default Settings

To restore the factory settings for your Handset or your Base:

1. Press **menu**. Select "ADVANCED SET" using the ▲ or ▼ key, press **menu**.
2. Using the ▲ or ▼ key, select "RESET". Press **menu**.
3. A confirmation screen appears, press **menu**.
 - If you want to confirm the reset, press **menu**.
 - To cancel the reset, press .
4. You will hear a confirmation tone : the settings of your phone are restored to their initial values.

9.6. Prefix (Depending on Country)

If a PABX is used in a private network, you can program the outside call prefix.

This function sets:

- **The PABX prefix number:** this number will be added at the beginning of the number you dialled.
- **The number to be detected:** if the number you dialled starts with the recorded sequence, this sequence will be automatically deleted.

These two settings are not applied if number you dialled starts with "#" or "".*

1. Press **menu**. Select "ADVANCED SET" using the ▲ or ▼ key, press **menu**.
2. Using the ▲ or ▼ key, select "AUTO PREFIX". Press **menu**.
3. Select "DETECT DIGIT" to define the number giving you access to the outside line.
4. Select "PREFIX" to specify the «digits before prefix».
5. Press **menu** key to confirm your selection. You will hear a confirmation tone.

9.7. Flash timing

If you connect your telephone to a private automatic branch exchange or use it in a foreign country, you may need to modify the flash duration in order to use your telephone correctly with regard to the following functionalities: outgoing 2nd call, incoming 2nd call, conference call.

Contact your administrator, who will supply the appropriate time period, and proceed to the new settings.

1. Press **menu**. Select "ADVANCED SET" using the ▲ or ▼ key, press **menu**.
2. Using the ▲ or ▼ key, select "RECALL TIME". Press **menu**.
3. Three choices are available: "SHORT", "MEDIUM" and "LONG".
4. Select the appropriate time period.
5. Press **menu** key to confirm your selection. You will hear a confirmation tone.

9.8. First ring

Activating this function is only useful if your line does not have the CLIP service.

This menu allows you to arrange for your telephone to ring when a call is received even if it is connected on the same line with another device (a fax, a cord telephone, etc.).

This function is activated as default. It will be automatically deactivated when a CLIP call is received (the number of which will be displayed on the handset screen).

1. Press **menu**. Select "ADVANCED SET" using the ▲ or ▼ key, press **menu**.
2. Using the ▲ or ▼ key, select "FIRST RING". Press **menu**.
 - Select "ON" using the ▲ or ▼ key, to activate the first ring.
 - Select "OFF" using the ▲ or ▼ key, to deactivate the first ring.
3. Press **menu** key to confirm your selection. You will hear a confirmation tone.

10. Call log

10.1. Received call log



If you have subscribed to a "Caller display" service, the received call log presents the calls you received. (max.10 last calls). To consult the list:

1. Press briefly ▲ key.
2. The most recent name or call number is displayed according to whether your contact's number is included in your phonebook or not.
 - If it is a private number, the screen displays "WITHHOLD ID".
 - If you are not in same area as your contact, the screen displays "UNAVAILABLE".
3. Press **menu** to display the date and the time of the call.

10.2. Dialled call log

The dialled call log presents the calls you made (max. 5 last calls).

To consult the list:

1. Press briefly .
2. The last dialled number is displayed.
3. To recall this number, press  key.

11. Changing the batteries

Make sure the telephone is **OFF** before you replace batteries.

1. Remove the batteries compartment door.
2. Remove old batteries.
3. Insert the new batteries.
4. Put the batteries compartment door back on.

5. Place handset in the base to charge. Allow the handset batteries to properly charge (for 12 hours) prior to first use or when you install new batteries. If you do not properly charge the phone, batteries performance will be compromised.



Danger of explosion if batteries are incorrectly replaced. Replace only with **1,2V 550mAh** type or equivalent rechargeable batteries. Do not dispose of the batteries in a fire. The cell may explode. Check with local code for possible special disposal instructions.

11.1. Batteries safety precautions

- Do not burn, disassemble, mutilate or puncture. Like other batteries of this type, toxic materials could be released which can cause injury.
- To reduce the risk of fire or personal injury, use only the battery listed in the user's guide.
- Keep batteries out of the reach of children.
- Remove batteries if storing over 30 days.

12. General product care

To keep your telephone working and looking good, follow these guidelines:

- Avoid putting the phone near heating appliances and devices that generate electrical noise (for example, motors or fluorescent lamps).
- DO NOT expose to direct sunlight or moisture.
- Avoid dropping and other rough treatment to the phone.
- Clean with a soft cloth.
- Never use a strong cleaning agent or abrasive powder because this will damage the finish.
- Retain the original packaging in case you need to ship the phone at a later date.

13. Troubleshooting

13.1. Causes of poor reception

- Aluminium siding.
- Foil backing on insulation.
- Heating ducts and other metal construction can shield radio signals.
- You are too close to appliances such as microwaves, stoves, computers, etc.
- Atmospheric conditions, such as strong storms.
- Base installed in the basement or lower floor of the house.
- Base is plugged into an AC outlet with other electronic devices.
- Baby monitor is using the same frequency.
- Handset batteries is low.
- You are out of range of the base.

13.2. Troubleshooting tips

13.2.1. Caller id

Problem	Solution
No display	<ul style="list-style-type: none"> • Did you order Caller ID service from your local telephone company?

13.2.2. Telephone

Problem	Solution
No display	<ul style="list-style-type: none"> • Are batteries fully charged? Try replacing the batteries. Make sure the batteries are properly installed and connected. • If you are using AC power, make sure that the unit is connected to a non-switched electrical outlet. Disconnect the unit from the plug and plug it in again.
No dial tone	<ul style="list-style-type: none"> • Check installation: • - Is the base power cord connected to a working outlet? • - Is the telephone line cord connected to the base unit and the wall jack? • Disconnect the base from the wall jack and connect another phone to the same jack. If there is no dial tone in the second phone, the problem might be your wiring or local service. • Is the handset out of range of the base? • Make sure the batteries are properly charged (12 hours). • Are the batteries pack installed correctly? • Did the IN USE indicator come on? <p>The batteries may need to be charged.</p>
Dial tone is OK, but can't dial out	<ul style="list-style-type: none"> • Make sure the tone/pulse setting is correct.
Handset does not ring	<ul style="list-style-type: none"> • Make sure the RINGER setting on the handset is programmed to ON. • You may have too many extension phones on your line. Try unplugging some phones. • See solutions for «NO dial tone».
You experience static, noise or fading in and out	<ul style="list-style-type: none"> • Is handset out of range? Move closer to the base. • Does the base need to be relocated? • Charge batteries. • Make sure base is not plugged into an outlet with another household appliance.

13.2.3. Unit beeps

- Place handset in base for 20 seconds to reset the security code. If that doesn't work, charge batteries for 15 hours.
- Clean charging contacts on handset and base with a soft cloth.
- See solutions for «No dial tone».
- Replace batteries.

13.2.4. Memory dialling

- Did you program the memory location keys correctly?
- Did you follow proper dialling sequence?
- Make sure the tone/pulse setting is correct.
- Did you reprogram numbers into memory after power outage or batteries replacement?

14. Guarantee

14.1. Terms and Conditions for United Kingdom & Ireland only

In order to apply the guarantee, you should contact the SAGEMCOM Helpdesk or the retailer where you purchased the equipment. Proof of purchase will be required in either case.

Please make sure that you use your equipment only for the purpose for which it was designed and under normal usage conditions.

SAGEMCOM do not accept any liability for the equipment if used outside the frame of its original designed purpose or any consequence that may arise from this usage.

Should any malfunction arise, the SAGEMCOM Helpdesk or your retailer will advise you how to proceed.

A) General Guarantee conditions

SAGEMCOM undertakes to remedy by repair or exchange at its own convenience, free of charge for labour and replacement parts, any defects in the equipment during the guarantee period of 12 (twelve) months or 3 (three) months for accessories, from the date of original invoice of the Equipment, where those defects are a result of faulty workmanship.

Unless the customer has concluded with SAGEMCOM a maintenance contract in respect of the equipment which specifically provides for repairs to be carried out at the customer's premises, the repairs will not be carried out on the equipment at the customer premises.

The customer must however return the defective equipment at his/her own expense, to the address supplied by the SAGEMCOM Helpdesk or by the retailer.

In the case that a product needs to be sent in for a repair, it must always be accompanied by a proof of purchase (which is not altered, written on or in any way made illegible) showing that the product is still under guarantee. In the case that no proof of purchase is enclosed, the SAGEMCOM repair centre will use the production date as its reference for establishing the guarantee status of the product.

Apart from all legal obligatory rules, SAGEMCOM, do not give any Guarantee, either implicit or explicit which is not set force in the present section, and can not be held responsible for any direct or indirect, material or immaterial damage, either in or out of the frame of the present guarantee.

If any provision of this guarantee shall be held to be in whole or in part invalid or illegal due to an obligatory rule applicable to consumers pursuant to their national legislation, such invalidity or illegality shall not impair or affect the remaining provisions or parts of this guarantee.

This guarantee does not affect the Customer statutory rights.

B) Exclusions From Guarantee

SAGEMCOM shall have no liability under the guarantee in respect of:

- Damage, defects, breakdown or malfunction due to one or more of the following:
 - Failure to properly follow the installation process and instructions for use
 - An external cause to the equipment (including but not limited to: lightening, fire, shock, vandalism, inappropriate conditions of electrical network or water damage of any nature)
 - Modifications made without the written approval of SAGEMCOM
 - Unsuitable operating conditions, particularly of temperature and humidity
 - Repair or maintenance of the equipment by persons not authorised by SAGEMCOM
- Wear and tear from normal daily use of the equipment and its accessories
- Damage due to insufficient or bad packaging of equipment when returned to SAGEMCOM
- Usage of new versions of software without the previous approval of SAGEMCOM
- Work on any equipment or software modified or added without the prior written consent of SAGEMCOM
- Malfunctions not resulting from the Equipment or from software installed in user workstations for the purpose of use of the equipment.

Communication problems related to an unsuitable environment including:

- Problems related to access and/or connection to the Internet such as interruptions by access networks or malfunction of the line used by the subscriber or his correspondent
- Transmission faults (for example poor geographical coverage by radio and TV transmitters, interference or poor line quality)
- Local network faults (wiring, servers, workstations) or the failure of the transmission network (such as but not limited to interferences, fault or poor quality of the network)
- Modification of the parameters of the cellular or broadcast network carried out after the sale of the Product
- Normal servicing (as defined in the user guide supplied with the equipment) as well as malfunctioning due to servicing not being carried out. Servicing costs are in any event always borne by the customer.
- Malfunctions resulting from the usage of products, consumables or accessories not compatible with the equipment.

C) Out of Guarantee Repairs

In the cases set forth in B) as well as after expiry of the guarantee period, the customer must ask the Authorised SAGEMCOM Repair Centre for a cost estimation prior to work being carried out.

In such cases, the repair and delivery costs will be invoiced to the customer.

The foregoing shall apply unless otherwise agreed in writing with the customer and only for the United Kingdom and Ireland.

SAGEMCOM Helpdesk (from UK) : 08 45 09 00 316

SAGEMCOM Helpdesk (from Ireland) : 01 60 583 84

SAGEMCOM Helpdesk Email : dti.faxservice-uk@sagemcom.com

14.2. Terms and Conditions for other countries

If, despite our best efforts, your product presents any defects, you should refer to your retailer and present the proof of purchase that they gave you on the day of purchase.

Should any malfunctioning arise, the retailer will advise you what to do.

For the warranty to apply, you should ensure that the product was used in accordance with the instructions for use and the purpose for use, and that you have at your disposal the sales invoice or receipt stating the date of purchase, the name of the retailer, the reference and the serial number of the product.

No coverage shall be given under this warranty if the following conditions are applicable:

- The required documents have been modified or altered in order to take advantage of the warranty.
- The manufacturing numbers, product brands or labels have been altered or made illegible.
- Interventions on the product have been made by an unauthorized person.
- The product has been subjected to abnormal or improper use.
- The product has been damaged by external factors such as lightning, over-voltage, moisture, accidental damage, improper care as well as all Acts of God.

This present warranty does not affect the consumer rights that you may have under the laws in effect in your country.

Important:

Should you return the product to the after-sales department, please ensure that you return as well all the elements and accessories originally supplied with the product.

15. Environment

Preservation of the environment is an essential concern of SAGEMCOM. The desire of SAGEMCOM is to operate systems observing the environment and consequently it has decided to integrate environmental performances in the life cycle of its products, from manufacturing to commissioning, use and elimination.

15.1. Packaging




The presence of the logo (green dot) means that a contribution is paid to an approved national organisation to improve packaging recovery and recycling infrastructures.

To facilitate recycling, please respect the sorting rules set up locally for this kind of waste.

15.2. Batteries

If your product contains batteries, they must be disposed of at appropriate collection points.

15.3. The product



The crossed-out waste bin stuck on the product or its accessories means that the product belongs to the family of electrical and electronic equipments.

In this respect, the European regulations ask you to dispose of it selectively:

- At sales points in the event of the purchase of similar equipment.
- At the collection points made available to you locally (drop-off centre, selective collection, etc.).

In this way you can participate in the re-use and upgrading of Electrical and Electronic Equipment Waste, which can have an effect on the environment and human health.

Használati útmutató - Az adatok értesítés nélkül megváltoztathatók
Instrukcja obsługi - Dokument nie będący częścią umowy
Návod k použití - Údaje se mohou změnit bez upozornění
Návod na použitie - Údaje sa môžu zmeniť bez upozornenia
Инструкция за експлоатация - Документ без договорен характер
User Manual - Data subject to change without notice



* 2 5 3 3 2 0 5 4 7 A *

SAGEMCOM SAS

Société par actions simplifiée au capital de 158.291.895 € - 440 294 510 RCS PARIS
250, route de l'Empereur - 92500 Rueil-Malmaison - France

www.sagemcom.com