

# Raspberry Pi Based LCD Clock

User's Manual

10-November-2025



## Table of Contents

1	Introduction.....	3
1.1	List of Hardware Components .....	3
1.2	Location of Software Components .....	3
1.3	List of Software Files.....	4
2	Photographs of Hardware Components .....	5
2.1	Photographs of Prototype Unit .....	5
2.2	Photographs of Production Unit .....	6
3	Wiring Diagrams .....	7
4	Software Operational Overview .....	9
4.1	Software Processes and Communication Queues .....	9
4.2	Configuration File Setup .....	10
4.2.1	Accessing the RPi Desktop and Connecting to a Wi-Fi Network .....	10
4.2.2	Accessing the RPi Terminal Window .....	11
4.2.3	Editing the Configuration File with the Built-In Nano Editor. ....	12
4.2.4	Copying Files from the RPi to a Flash Drive. ....	12
4.3	Starting the Server .....	13
4.4	Starting the Command Line Client.....	14
4.5	Starting the GUI Client .....	15
4.6	Starting the Server Automatically at Boot Time.....	18
4.7	Memory Utilization .....	19
5	Appendix 1. A Python Based Client-Server Architecture .....	20
5.1	Introduction .....	20
5.2	A Well-Known Client Server.....	20
5.3	Closing a Client and Stopping the Server .....	20
5.4	Server's Handling of Unexpected Events .....	21
5.5	Some Assembly Required .....	21
5.6	A Potential Pitfall – Firewall .....	23
5.7	Explanatory Figures .....	25

## Table of Figures

Figure 1.	Functional Wiring Diagram .....	7
Figure 2.	Physical Wiring Diagram .....	8
Figure 3.	Communication Queues .....	9
Figure 4.	Raspberry Pi Connection Points.....	10
Figure 5.	Raspberry Desktop .....	11
Figure 6.	ifconfig Command Output Screenshot.....	11
Figure 7.	Example cfg.cfg File Screenshot .....	12
Figure 8.	Command Line Client Screenshot .....	15
Figure 9.	GUI Client Screenshot 1 .....	15
Figure 10.	GUI Client Screenshot 2 .....	16
Figure 11.	GUI Client Screenshot 3 .....	17
Figure 12.	Crontab Screenshot.....	18

## Table of Photographs

Photograph 1 - Prototype Front View .....	5
Photograph 2 - Prototype Back View 1 .....	5
Photograph 3 - Prototype Back View 2 .....	5
Photograph 4 - Production Front View .....	6
Photograph 5 - Production Back View 1 .....	6
Photograph 6 - Production Back View 2 .....	6

# 1 Introduction

This document describes the hardware and software for a Raspberry Pi (RPi) based clock that uses six 240x320 LCD displays.

## 1.1 List of Hardware Components

Hardware components, with Amazon links (if viewing this document on a computer), are listed below.

Item	Link	Cost	Comment
1. Raspberry Pi 4B (RPi):	<a href="#">RPi</a>	~ \$65	-
2. RPi SD card (OS):	<a href="#">SD_Card</a>	~ \$14	Download SD OS imager <a href="#">here</a>
3. RPi Power Supply:	<a href="#">PWR</a>	~ \$10	-
4. LCD Displays:	<a href="#">LCD</a>	~ \$15	Each, six required
5. Mini Breadboard:	<a href="#">MiniBB</a>	~\$ 8	-
6. Breadboard Jumpers:	<a href="#">JMP</a>	~\$13	Breadboard-to Breadboard
7. RPi Jumpers:	<a href="#">JMP2</a>	~\$ 6	RPi-to-Breadboard

Total cost: ~\$206.

## 1.2 Location of Software Components

This document and (most of) the clock's software can be found at this GitHub repository:

<https://github.com/sgarrow/spiClock>

Some of the clock's code is common with another, second, project. To prevent having to copy/paste changes/bug-fixes back and forth between projects, this common code resides in a third project. The common code can be found at this GitHub repository:

<https://github.com/sgarrow/sharedClientServerCode>

Just as a matter of completeness the above-mentioned second project that also uses the shared code is an RPi sprinkler controller. Its documentation and (most of) its software can be found at this GitHub repository:

<https://github.com/sgarrow/sprinkler2>

Both the clock and sprinkler run within a client/server architecture. It is the Client and Server files/functionality that are common.

### 1.3 List of Software Files

```

+---spiClock                                --+ ALL CODE RESIDES IN THIS ROOT DIRECTORY.
|   client.py                                | Only these files need to be on the client machine.
|   clientCustomize                          | The last 2 (cfg.*) also need to be on the server
|   gui.py                                    | machine (RPi). Cfg.cfg contains IP addresses, etc.,
|   cfg.py                                    | that need to be shared between the client/server
|   cfg.cfg                                    | Files below only need to be on the RPi.
|
|   server.py                                | Clients send commands, via a socket, to the server.
|   serverCustomize.py                      | The server looks up the command in a dictionary and
|   cmdVectors.py                          | vectors to the worker function. In the dictionary,
|                                           | the command string serves as the "key" and the
|                                           | associated "value" is the worker function.
|
|   startStopClock.py                      | Worker functions for the Clock Stop/Stop commands
|       clockProcess.py                    | reside in startStopClock.py. These functions spawn/
|       lcdProcess.py                      | terminate separate processes, running concurrently
|                                           | on separate cores, that increment the clock counter
|                                           | & push data out to the LCDs respectively.
|
|   makeScreen.py                          | Screens pushed to LCDs need to be made before the
|   styleMgmtRoutines.py                   | clock starts. Making a screen creates a file. When
|                                           | that file is loaded and pushed to an LCD it results
|                                           | in, e.g., a white 4 character being displayed on a
|                                           | black background. Management Routines allow for
|                                           | for changing styles, choosing a nighttime style,
|                                           | setting the times to automatically switch styles.
|
|   spiRoutines.py                         | These files contain the worker functions for the
|   swUpdate.py                            | remaining commands and various helper routines.
|   utils.py                               |
|   cmds.py                               |
|   testRoutines.py                       |
|   fileIO.py                               |
|   rpiShellCmds.py                       --+
|
+----digitScreenStyles                    --+ ALL SCREEN STYLES RESIDE IN THIS SUBDIRECTORY
|   blackOnWhite.pickle                    | blackOnWhite is the default and can't be deleted -
|   greyOnBlack.pickle                    | other styles can be. New styles can be created at
|   orangeOnTurquoise.pickle              | will. Each file contains an image for all digits.
|   turquoiseOnOrange.pickle              |
|   whiteOnBlack.pickle                  --+
|
+----fonts                                --+ ALL FONTS RESIDE IN THIS SUBDIRECTORY
|   Font00.ttf                            --+ This file contains the font used for all digits.
|
+----pics                                --+ ALL PICTURES RESIDE IN THIS SUBDIRECTORY
|   240x320b.jpg                          | Using the appropriate command the LCDs will
|   240x320c.jpg                          | momentarily display a set of six 240x320 jpg
|   240x320d.jpg                          --+ images.

```


Note: the **bold underlined** files are in the shared GitHub Repository, the remaining files are in the clock repository.

## 2 Photographs of Hardware Components


### 2.1 Photographs of Prototype Unit



Photograph 1 - Prototype Front View



Photograph 2 - Prototype Back View 1



Photograph 3 - Prototype Back View 2




## 2.2 Photographs of Production Unit



Photograph 4 - Production Front View



Photograph 5 - Production Back View 1



Photograph 6 - Production Back View 2

### 3 Wiring Diagrams

The RPi talks to the LCDs over an SPI interface. An introduction to SPI can be found here:

[https://en.wikipedia.org/wiki/Serial\\_Peripheral\\_Interface](https://en.wikipedia.org/wiki/Serial_Peripheral_Interface)

Each LCD has eight connection points. Seven connection points are common to all LCDs. For example, pin 19 on the RPi (the Data In pin) is connected to all eight LCDs. So, when the RPi is pumping out data on pin 19 it is going to ALL LCDs. That said, the only LCD that is “listening” is that LCD whose Chip Select pin (CS) is “low”. The CS points are NOT all common. The RPi will only drive one of the six LCD Chip Select signals low at a time.

Functional and Physical wiring diagrams are provided in Figures 1 and 2, respectively.




Figure 1. Functional Wiring Diagram






Figure 2. Physical Wiring Diagram

## 4 Software Operational Overview

Conceptually, there are two programs running on the RPi – a “server” and a “clock”. The server can accept commands from a “client” (running on a different, remote device – a PC or a phone) over a “socket” that exists either over a Local Wireless LAN or over the internet. Control of the clock is accomplished by running the client. The client will/can send commands to the server who, in turn, forwards it to the clock. Information on this client/server implementation can be found in Appendix 1.

### 4.1 Software Processes and Communication Queues

The clock runs on three separate cores, one core runs the server (Main Process), another runs the clock counter (Clock Process) and the third controls the displays (LCD Process). These processes communicate using four multiprocessing-communication-queues. Two queues for are for sending commands and two are for receiving responses. A simplified communication diagram (for the ‘stop’ command) is presented in Figure 3.




Figure 3. Communication Queues

## 4.2 Configuration File Setup

For the client and server to communicate they must share information - IP address, port numbers, etc. Users must determine this information and enter it into the file named `cfg.cfg`.

### 4.2.1 Accessing the RPi Desktop and Connecting to a Wi-Fi Network

The file `cfg.cfg` resides on the Solid-State Drive on the RPi. To edit the file the RPi Desktop must be accessed.

Connect an HDMI display and a wireless (or wired) keyboard/mouse to the RPi. The connection points are designated in Figure 4. Once these connections are made, apply power to the RPi.




Figure 4.

Raspberry Pi Connection Points

Once the RPi has booted the desktop shown in Figure 5 will be displayed.




Figure 5. Raspberry Desktop

Click the Wi-Fi icon, designated in the above Figure by a single arrow. whereby an opportunity to select the Wi-Fi network will be provided. Select the desired network and enter the password. Henceforth the RPi will automatically connect to this network whenever it is available.

#### 4.2.2 Accessing the RPi Terminal Window

After connecting to the LAN, open a terminal by clicking on the icon, designated above by the double arrow, and enter the command **ifconfig**. An example output of the **ifconfig** command is shown in Figure 6. Take note of the inet address as it will be added to **cfg.cfg**.

```
wlan0: flags=4163<UP,BROADCAST,RUNNING,MULTICAST> mtu 1500
  inet 192.168.1.130 netmask 255.255.255.0 broadcast 192.168.1.255
  inet6 fe80::a19c:e9b6:d091:97c3 prefixlen 64 scopeid 0x20<link>
  ether 88:a2:9e:00:f3:b6 txqueuelen 1000 (Ethernet)
  RX packets 1647 bytes 475854 (464.7 KiB)
  RX errors 0 dropped 0 overruns 0 frame 0
  TX packets 706 bytes 93394 (91.2 KiB)
  TX errors 0 dropped 0 overruns 0 carrier 0 collisions 0
```

Figure 6. ifconfig Command Output Screenshot

### 4.2.3 Editing the Configuration File with the Built-In Nano Editor.

In the terminal window, enter the following command to navigate to the RPi directory:

```
cd python/spiClock
```

Enter the following command to open the file in the nano editor:

```
nano -e cfg.cfg
```

An example `cfg.cfg` is provided in Figure 7.

Nano is a simple editor. The mouse doesn't work so use the arrow keys

Edit an existing line or add a new line. The RPi name will be entered when starting the server (on the RPi) and when starting the client (on a remote machine, either a PC or a phone).

Enter a port number. Ports between 8000 and 9000 are safe to use. Enter the Lan address obtained by the `ifconfig` command. Enter your router's IP address. The router IP address can be obtained via website [www.whatismyip.com](http://www.whatismyip.com). Choose an enter your desired password.

Note that the password contained in the `cfg.cfg` file is the password that the client will send to the server when attempting to establish a connection. It is not the "user" password for the RPi itself. The RPi password for the RPi itself is used when, for example attempting to establish an SSH connection to the RPi.

Save the file by entering the following commands:

```
ctrl-x      # To begin the editor exiting process.
Y           # Answer to the "save-file" prompt.
<RETURN>    # Answer to the "save as cfg.cfg" (default) prompt.
```




Figure 7.

Example `cfg.cfg` File Screenshot

### 4.2.4 Copying Files from the RPi to a Flash Drive.

As mentioned in section 1.3, there are six files that need to be placed on the machine that will run the client. Insert a Flash Drive into a USB Port on the RPi and, using the RPi File Explorer (click on the File Explorer Icon designated by the dotted arrow in Figure 5. Raspberry Desktop), copy the following files to it:

```
client.py, clientCustomize, gui.py, cfg.py, cfg.cfg
```



## 4.3 Starting the Server

Start the Server ...

## 4.4 Starting the Command Line Client

Start the command line client with the following command:

`python client.py <id>` Replace <id> as appropriate, see Section “Configuration File”, below

Once the server accepts the connection a prompt is presented. Enter ‘m’ at the prompt to get a list of available commands. A screen shot of this is provided below.

```
PS C:\01-home\14-python\gitTrackedCode\spiClock> python .\client.py clk2
same, lan, internet (s,l,i) -> l
sndBufSize 65536
rcvBufSize 65536

Accepted connection from: ('192.168.1.110', 65386)

Choice (m=menu, close) -> m

=== GET  COMMANDS ===
gas - Get Active Style
gds - Get Day Style
gns - Get Night Style
gAs - Get ALL Styles
gdt - Get Day Time
gnt - Get Night Time
gat - Get Active Threads
gvn - Get Version Number

=== SET  COMMANDS ===
sas - Set Active Style
sds - Set Day Style
sns - Set Night Style
sdt - Set Day Time
snt - Set Night Time

=== FILE  COMMANDS ===
ral - Read App Log File
rsl - Read Srvr Log File
rse - Read Srvr Exc File
cal - Clr App Log File
csl - Clr Srvr Log File
cse - Clr Srvr Except File

=== OTHER COMMANDS ===
sc - Start Clock
pc - Stop Clock
mus - Make User Style
dus - Delete User Style
dp - Display Pics
up - Upload Pic
rp - Remove Pic
us - Update SW
hlp - Help
close - Disconnect
ks - Kill Server
rb - Reboor RPi

=== TEST  COMMANDS ===
rtl - Run Test 1
rt2 - Run Test 2
rh - Reset LCD HW Test
rs - Reset LCD SW Test
sb - LCD Backlight Test
lc - List Commands Test

Choice (m=menu, close) ->
```

Figure 8.

Command Line Client Screenshot

## 4.5 Starting the GUI Client

Start the GUI client with the following command: `python gui.py`. Then, when the following screen is displayed click on the appropriate UUT (this is the equivalent of the `<id>` parameter specified when starting the Command Line Client).




Figure 9.

GUI Client Screenshot 1




Figure 10.

GUI Client Screenshot 2

Once the server accepts the connection a

When the GUI client is started and a connection is accepted by the server the 'm' command is automatically issued. The response is used to populate the GUIs buttons (GUI is 'built' at run time). A screen shot of the GUI is provided below.

The 'build at run time' architecture is what allows the sprinkler and clock applications to use the same GUI.





Figure 11. GUI Client Screenshot 3



## 4.6 Starting the Server Automatically at Boot Time

Df



```
pi@rasp3: ~  
GNU nano 7.2 /tmp/crontab.rw73F9/crontab  
# Edit this file to introduce tasks to be run by cron.  
#  
# Each task to run has to be defined through a single line  
# indicating with different fields when the task will be run  
# and what command to run for the task  
#  
# To define the time you can provide concrete values for  
# minute (m), hour (h), day of month (dom), month (mon),  
# and day of week (dow) or use '*' in these fields (for 'any').  
#  
# Notice that tasks will be started based on the cron's system  
# daemon's notion of time and timezones.  
#  
# Output of the crontab jobs (including errors) is sent through  
# email to the user the crontab file belongs to (unless redirected).  
#  
# For example, you can run a backup of all your user accounts  
# at 5 a.m every week with:  
# 0 5 * * 1 tar -zcf /var/backups/home.tgz /home/  
#  
# For more information see the manual pages of crontab(5) and cron(8)  
#  
# m h dom mon dow  command  
@reboot /bin/sleep 30; cd /home/pi/python/spiClock && python3 server.py clk2 >>serverLog.txt 2>>serverException.txt
```

Figure 12.

Crontab Screenshot

## 4.7 Memory Utilization

The Amazon Link provided earlier for the RPi earlier is a link to a 4GB (RAM) version of the RPi. However, the application can run on a 1GB version. Below is a screen capture of the output of four issuances of the `free --mega` Linux command. The first command was issued right after boot where only the OS is running, the second after the server was started, the third after a client was connected and the fourth after the clock was started.

The data shows that after everything is up and running there is still over 76MB of free RAM. Plenty for dozens of more clients to connect.

```
pi@rasp3:~ $ free --mega    # After Boot
```

	total	used	free	shared	buff/cache	available
Mem:	<u>950</u>	359	<u>152</u>	24	520	591
Swap:	536	0	536			

```
pi@rasp3:~ $ free --mega    # After Starting Server
```

	total	used	free	shared	buff/cache	available
Mem:	950	389	<u>100</u>	24	542	560
Swap:	536	0	536			

```
pi@rasp3:~ $ free --mega    # After Connecting Client
```

	total	used	free	shared	buff/cache	available
Mem:	950	387	<u>102</u>	24	542	562
Swap:	536	0	536			

```
pi@rasp3:~ $ free --mega    # After Starting Clock
```

	total	used	free	shared	buff/cache	available
Mem:	950	410	<u>76</u>	24	545	539
Swap:	536	0	536			

```
pi@rasp3:~ $
```

## 5 Appendix 1. A Python Based Client-Server Architecture

### 5.1 Introduction

This document describes a client-server architecture written in the Python programming language. A client-server architecture is a structure where multiple clients request services from a centralized server and separates user interaction from data processing.

To start the server type "python server.py <device>" on the command line.

To connect a command line client to the server type "python client.py <device>" on the command line.

To connect a GUI client to the server type "python gui.py <device>" on the command line.

A client can be run on the same machine as the server (in a different command window) or on a different machine entirely.

### 5.2 A Well-Known Client Server

Servers are things that respond to requests. Clients are things that make requests.

A web browser is a type of client that can connect to servers that "serve" web pages - like the Google server.

When a web browser (a client) connects to the Google Server and sends it a request (e.g., send me a web page containing a bunch of links related to "I'm searching this") the Google Server will respond to the request by sending back a web page.

Requests are sent in "packets" over connections called "sockets". Included in the request is the IP address of the client making it - that's how the server knows where to send the response back to. A given machine has one IP address, so if more than one instance of a web browser is open on a single machine how is it that the response ends up in the "right" web browser and not the other browser? Port number.

### 5.3 Closing a Client and Stopping the Server

Every client has a unique (IP, port) tuple. The server tracks every client by (IP, port). The server maintains a list of (IP, port) for all active clients.

Each client has two unique things associated with it - (1) a socket and (2) an instance (a thread) running the client's handling function

When a client issues a "close" command, its (IP, port) is removed from the list and as a result the handleClient's infinite loop is exited thereby causing its socket to be closed and its thread to terminate.

When a client issues a "ks" (kill server) command, not only does that client terminate but all other clients terminate as well. Furthermore the "ks" command causes the server itself (it's still waiting for other clients to possibly connect) to terminate.

The worker functions associated with all commands are contained within file `cmdWorkers.py` with the exceptions of the `close` and `ks` commands. The work associated with the `close` and `ks` commands is performed in file `server.py` directly.

Upon receipt of the `ks` command the server (1) sends a message to all clients (including the one sent the command) indicating that the server is shutting down so that the client will exit gracefully, (2) terminates all clients and then finally (3) the server itself exits.

Additional details related to client connection types and to function calling sequences are provided in figures 1 and 2.

## 5.4 Server's Handling of Unexpected Events

If a user clicks the red X in the client window (closes the window) that client unexpectedly (from the server's viewpoint) terminates. This contrasts with the client issuing the `close` or `ks` command where the server is explicitly notified of the client's termination. An unexpected termination results in a sort of unattached thread and socket that may continue to exist even when the server exits. This situation is rectified by two `try/except` blocks in function `handleClient`. Two are needed because it was empirically determined the Windows and Linux systems seem to block (waiting for a command from the associated client) in different places.

## 5.5 Some Assembly Required

In file `client.py` on approximately lines 60 and 61 the following two lines of code are present:

```
connectDict={'s':'localhost','l':'00.00.00.00','i':'00.00.00.00'}  
PORT =
```

Likewise in file `server.py` on approximately line 164 the following line of code is present:

```
port =
```

For all connection types (refer to Figure 1) a port number needs to be specified. The number used must be the same in both the client and the server files. Use a number greater than 1024 – between 5,000 and 50,000 is safe.

For connection type 2, in addition to the port number, the IP of the server needs to be entered (value for key `'l'`) needs to be entered. The address can be found via the `ifconfig` command in a command window open on the machine that will be running the server.

For connection type 3, in addition to the port number, the external IP of the router needs to be entered (value for the key `'i'`) needs to be entered. The router's external IP address can be found using by going to the following web page on a browser.

<https://whatismyipaddress.com/>

The use of connection type 3 also requires port forwarding to be set up on the router. An example is shown below. The example shows forwarding port 1234 (substitute 1234 with whatever port number you entered `client.py` and `server.py`) to port 1234 for IP address 192.168.1.10. Substitute 192.168.1.10 with whatever the IP address of the machine running the server is. Again, this address can be obtained via use of the `ipconfig` command. Since only one port number needs to be forwarded the start and end port numbers are the same.

It seems weird that a port number needs to be forwarded to that same number, but it does.

Service Name	External Start Port	External End Port	Internal Start Port	Internal End Port	Internal IP address
My Service Name	1234	1234	1234	1234	192.168.1.10




## 5.6 A Potential Pitfall – Firewall


The above was all initially done with the server running on a Raspberry Pi. The Raspberry Pi runs Linux and by default its firewall is disabled. As such, all connection types worked only by performing the "SOME ASSEMBLY REQUIRED" steps outlined above.

On windows to get all connection types working, specifically connection type 3, the Windows firewall will need to be changed to allow incoming python TCP connections.


These are the basic steps:

**Control Panel\System and Security\Windows Defender Firewall ---> Advanced settings ---> Connection Security Rules ---> Inbound Rules**






Right click on the Incoming Rule for Python TCP Protocol, select the General Tab and change to Allow the connection.



## 5.7 Explanatory Figures

Figures 1 and 2 illustrate the various connection types and the functional call tree, respectively.



Last update: 31-Oct-2025

Computers 1 & 2 & the router are all on the same Local Area Network (LAN). Computer 3 is not on the same LAN but is connected to the Internet (an Interconnected set of Local Area networks).

When a client is started it prompts for the desired connection type and offers 3 choices: 's', 'l', 'i'.  
 s = same machine = type 1. l = same lan = type 2. i = internet = type 3.


Computer 1 is running both the server and the client so the obvious connection type is type 1, as shown. However, computer 1 could also connect over the LAN or over the internet (neither shown).

Computer 2 is running only the client but is on the same LAN as the computer running the server so the obvious connection type is type 2, as shown. However, computer 2 could also connect over internet (not shown). Computer 2 can not connect to the server via a type 1 connection.

Computer 3 can only connect to the server via a type 3 connection.

The server can handle multiple connections of type 1,2 and 3 simultaneously.

Figure n.      Connection Types



Computers 1 & 2 & the router are all on the same Local Area Network (LAN). Computer 3 is not on the same LAN but is connected to the Internet (an Interconnected set of Local Area networks).

When a client is started it prompts for the desired connection type and offers 3 choices: 's', 'l', 'i'.  
s = same machine = type 1. l = same lan = type 2. i = internet = type 3.

Computer 1 is running both the server and the client so the obvious connection type is type 1, as shown. However, computer 1 could also connect over the LAN or over the internet (neither shown).

Computer 2 is running only the client but is on the same LAN as the computer running the server so the obvious connection type is type 2, as shown. However, computer 2 could also connect over internet (not shown). Computer 2 can not connect to the server via a type 1 connection.

Computer 3 can only connect to the server via a type 3 connection.

The server can handle multiple connections of type 1,2 and 3 simultaneously.

Figure n. Functional Call Tree