

Chapter 1 LCD1602

In this chapter, we will learn about the LCD1602 Display Screen.

Project 1.1 LCD1602

In this section we learn how to use LCD1602 to display something.



Component knowledge

I2C communication



I2C (Inter-Integrated Circuit) is a two-wire serial communication mode, which can be used for the connection of micro controllers and their peripheral equipment. Devices using I2C communication must be connected to the serial data (SDA) line, and serial clock (SCL) line (called I2C bus). Each device has a unique address and can be used as a transmitter or receiver to communicate with devices connected to the bus.

LCD1602 communication

The LCD1602 display screen can display 2 lines of characters in 16 columns. It is capable of displaying numbers, letters, symbols, ASCII code and so on. As shown below is a monochrome LCD1602 display screen along with its circuit pin diagram.




I2C LCD1602 display screen integrates a I2C interface, which connects the serial-input & parallel-output module to the LCD1602 display screen. This allows us to only use 4 lines to operate the LCD1602.




The serial-to-parallel IC chip used in this module is PCF8574T (PCF8574AT), and its default I2C address is 0x27(0x3F).

Below is the PCF8574 pin schematic diagram and the block pin diagram:




PCF8574 module pin and LCD1602 pin are corresponding to each other and connected with each other:




So we only need 4 pins to control the 16 pins of the LCD1602 display screen through the I2C interface. In this project, we will use the I2C LCD1602 to display some static characters and dynamic variables.

Circuit

Schematic diagram



Hardware connection. If you need any support, please feel free to contact us via: support@freenove.com




Sketch

Before writing code, we need to import the library needed.

How to install the library

We use the third party library LiquidCrystal I2C. If you haven't installed it yet, please do so before learning. The steps to add third-party Libraries are as follows: open arduino->Sketch->Include library-> Manage libraries. Enter " LiquidCrystal I2C" in the search bar and select " LiquidCrystal I2C " for installation.




There is another way you can install libraries.


Click "Add .ZIP Library..." and then find **LiquidCrystal_I2C.zip** in libraries folder (this folder is in the folder unzipped from the ZIP file we provided). This library can facilitate our operation of I2C LCD1602.

Use I2C LCD 1602 to display characters and variables.


Before uploading the code, click "Tools", "Board" and select "NodeMCU 1.0 (ESP-12E Module)".




Select the serial port.



Note: For macOS users, if the uploading fails, please set the baud rate to 115200 before clicking "Upload Using Programmer".



Sketch_1.1_Display_the_string_on_LCD1602



```
Sketch_1.1_Display_the_string_on_LCD1602 | Arduino 1.8.19
File Edit Sketch Tools Help
Sketch_1.1_Display_the_string_on_LCD1602
11 //Define SCL pins
12 //Define SCL pins
13 /*
14  * note:If lcd1602 uses PCF8574T, IIC's address is 0x27,
15  *       or lcd1602 uses PCF8574AT, IIC's address is 0x3F.
16  */
17 LiquidCrystal_I2C lcd(0x27,16,2);
18 void setup() {
19   Wire.begin(SDA, SCL);           // attach the IIC pin
20   lcd.init();                     // LCD driver initialization
21   lcd.backlight();                // Open the backlight
22   lcd.setCursor(0,0);             // Move the cursor to row 0, column 0
23   lcd.print("hello, world!");     // The print content is displayed on the LCD
24 }
25
26 void loop() {
27   lcd.setCursor(0,1);             // Move the cursor to row 1, column 0
28   lcd.print("Counter:");          // The count is displayed every second
29   lcd.print(millis() / 1000);
30   delay(1000);
31 }
```

Done uploading.

Leaving...

Hard resetting via RTS pin...

11 ESP32 Wrover Module, Default 4MB with spiffs (1.2MB APP/1.5MB SPIFFS), QIO, 80MHz, 115200, None on COM4

Compile and upload the code to ESP8266 and the LCD1602 displays characters.



So far, at this writing, we have two types of LCD1602 on sale. One needs to adjust the backlight, and the other does not.

The LCD1602 that does not need to adjust the backlight is shown in the figure below.



If the LCD1602 you received is the following one, and you cannot see anything on the display or the display is not clear, try rotating the white knob on back of LCD1602 slowly, which adjusts the contrast, until the screen can display clearly.



The following is the program code:

```

1  #include <LiquidCrystal_I2C.h>
2  #include <Wire.h>
3
4  #define SDA 13           //Define SDA pins
5  #define SCL 14          //Define SCL pins
6
7  /*
8   * note: If lcd1602 uses PCF8574T, IIC's address is 0x27,
9   *       or lcd1602 uses PCF8574AT, IIC's address is 0x3F.
10  */
11  LiquidCrystal_I2C lcd(0x27, 16, 2);
12
13  void setup() {
14      Wire.begin(SDA, SCL);           // attach the IIC pin
15      if (!i2cAddrTest(0x27)) {
16          lcd = LiquidCrystal_I2C(0x3F, 16, 2);
17      }
18      lcd.init();                     // LCD driver initialization
19      lcd.backlight();                // Turn on the backlight

```

```


20  lcd.setCursor(0,0);           // Move the cursor to row 0, column 0
21  lcd.print("hello, world! ");  // The print content is displayed on the LCD
22  }
23
24  void loop() {
25      lcd.setCursor(0,1);       // Move the cursor to row 1, column 0
26      lcd.print("Counter:");    // The count is displayed every second
27      lcd.print(millis() / 1000);
28      delay(1000);
29  }
30  bool i2CAddrTest(uint8_t addr) {
31      Wire.begin();
32      Wire.beginTransmission(addr);
33      if (Wire.endTransmission() == 0) {
34          return true;
35      }
36      return false;
37  }

```

The Arduino IDE code usually contains two basic functions: void setup() and void loop().

After the board is reset, the setup() function will be executed firstly, and then the loop() function.

setup() function is generally used to write code to initialize the hardware. And loop() function is used to write code to achieve certain functions. loop() function is executed repeatedly. When the execution reaches the end of loop(), it will jump to the beginning of loop() to run again.



Include header file of Liquid Crystal Display (LCD)1602 and I2C.

```

1  #include <LiquidCrystal_I2C.h>
2  #include <Wire.h>

```

Instantiate the I2C LCD1602 screen. It should be noted here that if your LCD driver chip uses PCF8574T, set the I2C address to 0x27, and if uses PCF8574AT, set the I2C address to 0x3F.

```

11 LiquidCrystal_I2C lcd(0x27, 16, 2);

```

Initialize I2C and set its pins as 13,14. And then initialize LCD1602 and turn on the backlight of LCD.

```

14 Wire.begin(SDA, SCL);           // attach the IIC pin
15 if (!i2CAddrTest(0x27)) {
16     lcd = LiquidCrystal_I2C(0x3F, 16, 2);

```



```

17 }
18 lcd.init();           // LCD driver initialization
19 lcd.backlight();      // Turn on the backlight

```

Move the cursor to the first row, first column, and then display the character.

```

20 lcd.setCursor(0,0);   // Move the cursor to row 0, column 0
21 lcd.print("hello, world! "); // The print content is displayed on the LCD

```

Print the number on the second line of LCD1602.

```

24 void loop() {
25     lcd.setCursor(0,1); // Move the cursor to row 1, column 0
26     lcd.print("Counter:"); // The count is displayed every second
27     lcd.print(millis() / 1000);
28     delay(1000);
29 }

```

Check whether the I2C address exists.

```

30 bool i2CAddrTest(uint8_t addr) {
31     Wire.begin();
32     Wire.beginTransmission(addr);
33     if (Wire.endTransmission() == 0) {
34         return true;
35     }
36     return false;
37 }

```

Reference

class LiquidCrystal

The LiquidCrystal class can manipulate common LCD screens. The first step is defining an object of LiquidCrystal, for example:

```
LiquidCrystal_I2C lcd(0x27, 16, 2);
```

Instantiate the Lcd1602 and set the I2C address to 0x27, with 16 columns per row and 2 rows per column.

```
init();
```

Initializes the Lcd1602's device

```
backlight();
```

Turn on Lcd1602's backlight.

```
setCursor(column, row);
```

Sets the screen's column and row.

column: The range is 0 to 15.

row: The range is 0 to 1.

```
print(String);
```

Print the character string on Lcd1602

Chapter 2 LCD2004

In the previous chapter, we studied the LCD1602 display. In order to display more content, In this chapter, we will learn about the LCD2004 Display Screen.

Project 2.1 LCD2004

In this section we learn how to use LCD2004 to display something.



Component knowledge

I2C communication



I2C (Inter-Integrated Circuit) is a two-wire serial communication mode, which can be used for the connection of micro controllers and their peripheral equipment. Devices using I2C communication must be connected to the serial data (SDA) line, and serial clock (SCL) line (called I2C bus). Each device has a unique address and can be used as a transmitter or receiver to communicate with devices connected to the bus.

LCD2004 communication

The LCD2004 display screen can display 4 lines of characters in 20 columns. It is capable of displaying numbers, letters, symbols, ASCII code and so on. As shown below is a monochrome LCD2004 display screen along with its circuit pin diagram.




I2C LCD2004 display screen integrates a I2C interface, which connects the serial-input & parallel-output module to the LCD2004 display screen. This allows us to only use 4 lines to the operate the LCD2004.




The serial-to-parallel IC chip used in this module is PCF8574T (PCF8574AT), and its default I2C address is 0x27(0x3F).

Below is the PCF8574 pin schematic diagram and the block pin diagram:




PCF8574 module pin and LCD2004 pin are corresponding to each other and connected with each other:




So we only need 4 pins to control the 16 pins of the LCD2004 display screen through the I2C interface. In this project, we will use the I2C LCD2004 to display some static characters and dynamic variables.

Circuit

Schematic diagram



Hardware connection. If you need any support, please feel free to contact us via: support@freenove.com




Sketch

Before writing code, we need to import the library needed. Skip this section if you have already installed it, or proceed if you haven't.

How to install the library

We use the third party library **LiquidCrystal I2C**. If you haven't installed it yet, please do so before learning. The steps to add third-party Libraries are as follows: open arduino->Sketch->Include library-> Manage libraries. Enter " LiquidCrystal I2C" in the search bar and select " LiquidCrystal I2C " for installation.



There is another way you can install libraries.

Click "Add .ZIP Library..." and then find **LiquidCrystal_I2C.zip** in libraries folder (this folder is in the folder unzipped from the ZIP file we provided). This library can facilitate our operation of I2C LCD2004.

Use I2C LCD 2004 to display characters and variables.

Sketch_2.1_Display_the_string_on_LCD2004



```
Sketch_2.1_Display_the_string_on_LCD2004 | Arduino 1.8.19
File Edit Sketch Tools Help

Sketch_2.1_Display_the_string_on_LCD2004

17 LiquidCrystal_I2C lcd(0x27,20,4);
18 void setup() {
19   Wire.begin(SDA, SCL);           // attach the IIC pin
20   lcd.init();                     // LCD driver initialization
21   lcd.backlight();                // Open the backlight
22   // (note: line 1 is the second row, since counting begins with 0):
23   lcd.setCursor(0, 0); // set the cursor to column 0, line 0
24   // print the number of seconds since reset:
25   lcd.print("FREENOVE");
26   lcd.setCursor(0, 1); // set the cursor to column 0, line 1
27   // print the number of seconds since reset:
28   lcd.print("www.freenove.com");
29   lcd.setCursor(0, 2); // set the cursor to column 0, line 2
30   lcd.print("hello, world!"); // Print a message to the LCD
31 }
32
33 void loop() {
34   lcd.setCursor(0,3);             // Move the cursor to row 1, column 0
35   lcd.print("Counter:");          // The count is displayed every second
36   lcd.print(millis() / 1000);
37   delay(1000);
38 }
```

Done uploading.

Leaving...
Hard resetting via RTS pin...

14 ESP32 Wrover Module, Default 4MB with spiiffs (1.2MB APP/1.5MB SPIFFS), QIO, 80MHz, 115200, None on COM4

Compile and upload the code to ESP8266 and the LCD2004 displays characters.



If you cannot see anything on the display or the display is not clear, try rotating the white knob on back of LCD2004 slowly, which adjusts the contrast, until the screen can display clearly.



The following is the program code:

```

1  #include <LiquidCrystal_I2C.h>
2  #include <Wire.h>
3
4  #define SDA 13                //Define SDA pins
5  #define SCL 14               //Define SCL pins
6
7  /*
8   * note: If lcd2004 uses PCF8574T, IIC's address is 0x27,
9   *       or lcd2004 uses PCF8574AT, IIC's address is 0x3F.
10  */
11  LiquidCrystal_I2C lcd(0x27, 20, 4);
12
13  void setup() {
14      Wire.begin(SDA, SCL);      // attach the IIC pin
15      lcd.init();               // LCD driver initialization
16      lcd.backlight();          // Turn on the backlight
17      // (note: line 1 is the second row, since counting begins with 0):
18      lcd.setCursor(0, 0); // set the cursor to column 0, line 0
19      // print the number of seconds since reset:
20      lcd.print("FREENOVE");
21      lcd.setCursor(0, 1); // set the cursor to column 0, line 1
22      // print the number of seconds since reset:
23      lcd.print("www.freenove.com");
24      lcd.setCursor(0, 2); // set the cursor to column 0, line 2
25      lcd.print("hello, world!"); // Print a message to the LCD
26
27  }
28
29  void loop() {
30      lcd.setCursor(0, 3);      // Move the cursor to column 0, row 3
31      lcd.print("Counter:");    // The count is displayed every second
32      lcd.print(millis() / 1000);

```

```

33     delay(1000);
34 }

```

Include header file of Liquid Crystal Display (LCD)2004 and I2C.

```

1  #include <LiquidCrystal_I2C.h>
2  #include <Wire.h>

```

Instantiate the I2C LCD2004 screen. It should be noted here that if your LCD driver chip uses PCF8574T, set the I2C address to 0x27, and if uses PCF8574AT, set the I2C address to 0x3F.

```

11 LiquidCrystal_I2C lcd(0x27, 20, 4);

```

Initialize I2C and set its pins as 13,14. And then initialize LCD2004 and turn on the backlight of LCD.

```

14 Wire.begin(SDA, SCL);           // attach the IIC pin
15 lcd.init();                     // LCD driver initialization
16 lcd.backlight();                // Turn on the backlight

```

Move the cursor to the third row, first column, and then display the character.

```

24 lcd.setCursor(0, 2);            // Move the cursor to row 2, column 0
25 lcd.print("hello, world! ");    // The print content is displayed on the LCD

```

Print the number on the fourth line of LCD2004.

```

29 void loop() {
30     lcd.setCursor(0, 3);         // Move the cursor to column 0, row 3
31     lcd.print("Counter:");       // The count is displayed every second
32     lcd.print(millis() / 1000);
33     delay(1000);
34 }

```

Reference

class LiquidCrystal

The LiquidCrystal class can manipulate common LCD screens. The first step is defining an object of LiquidCrystal, for example:

```
LiquidCrystal_I2C lcd(0x27, 20, 4);
```

Instantiate the Lcd2004 and set the I2C address to 0x27, with 20 columns per row and 4 rows per column.

```
init();
```

Initializes the Lcd2004's device

```
backlight();
```

Turn on Lcd2004's backlight.

```
setCursor(column, row);
```

Sets the screen's column and row.

column: The range is 0 to 19.

row: The range is 0 to 3.

```
print(String);
```

Print the character string on Lcd2004.