



# SMARTBALL v1.x/v2

DATAGRAM SPECIFICATIONS V0.4

last update – 16/10/2022

---

## INTRODUCTION

Smartballs send and receive specific UDP Datagrams, this choice has been made over OSC, Artnet or other kind of existing protocol to save bandwidth as much as possible. This protocol is still in active development and will likely to evolve during the alpha and beta test phase.

This document is compatible with the following release:

- hardware v1.x : <https://github.com/siteswapjuggler/smartball-hardware/tree/v1.2>
- firmware dev branch : <https://github.com/siteswapjuggler/smartball-firmware/tree/dev>
- externals v0.3 beta 1 : <https://github.com/siteswapjuggler/smartball-externals/tree/v0.3-beta.1> (apart GSC)

---

## VERSION NOTE

Structure change:

- Packet format updated to take advantage of UDP packet informations

Command updates:

- Stream now has a flag to describe the data content of the stream
- IMU flag has new bits for Fusion algorithm feedback

New commands:

- Set config settings
- Save config settings

Removed commands:

- DeepSleep

---

## SUMMARY

INTRODUCTION.....	1
VERSION NOTE.....	1
DATAGRAM STRUCTURE.....	3
UPSTREAM PACKETS.....	3
DOWNSTREAM PACKETS .....	3
UPSTREAM COMMANDS .....	4
PING .....	4
REBOOT.....	4
FACTORY SETTINGS.....	4
SAVE FACTORY SETTINGS.....	4
GENERAL SETTINGS.....	4
SAVE GENERAL SETTINGS .....	5
COLOUR (FOREGROUND).....	5
COLOUR (BACKGROUND).....	5
STREAM.....	5
IMU SETTINGS.....	6
ACCELEROMETER RANGE.....	6
GYROSCOPE RANGE .....	7
SAVE IMU SETTINGS.....	7
INFRARED.....	7
MOTOR .....	7
STROBE .....	8
MASTER.....	8
DOWNSTREAM COMMANDS.....	9
PONG .....	9
BATTERY VALUE .....	9
IMU VALUES.....	9

---

## DATAGRAM STRUCTURE

### UPSTREAM PACKETS .....

Upstream datagram are made as described below:

- Command                1 byte
- Data                    (optional)

#### CMD – Command

Commands byte is unique to every message.

#### DATA (optional)

Data depends on each command and is optional. See command description below for further information.

### DOWNSTREAM PACKETS .....

Downstream datagram are made as described below:

- Id number               2 bytes
- Serial number          2 bytes
- Command               1 byte
- Data                    depending on length

#### ID – ID Number

Two bytes uint16 serial number.

#### SN – Serial Number

Two bytes uint16 serial number.

#### CMD – Command

Commands byte is unique to every message.

#### DATA (optional)

Data depends on each command and is optional. See command description below for further information.

---

## UPSTREAM COMMANDS

### PING .....

Ping command trigger a pong answer.

CMD
0x01

### REBOOT .....

Reboot command trigger the reboot of the ball (*does not work on first boot after firmware update*).

CMD
0x02

### FACTORY SETTINGS .....

Factory settings command sets new factory settings value. Factory settings includes a serial number, a device flag and an adc scaling factor.

CMD	DATA
0x10	5 bytes

DATA STRUCTURE:

- serial number: uint16 value from 0 to 65535
- device flag: 16 bits flag describing available devices
- adc scaling factor: unsigned Q15.1 value from 0.0 to 6553.5

SN_MSB	SN_LSB	FLAG_MSB	FLAG_LSB	SCL_MSB	SCL_LSB
--------	--------	----------	----------	---------	---------

DEVICE FLAG STRUCTURE:

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
-	-	-	-	-	-	-	-	-	-	-	BUZ	MOT	IRL	IMU	RGB

### SAVE FACTORY SETTINGS .....

Save factory command trigger EEPROM writing of the factory settings.

CMD
0x11

### GENERAL SETTINGS .....

General settings command sets new general settings value. General settings includes the id number.

CMD	DATA
0x12	1 bytes

#### DATA STRUCTURE:

- id number: uint8 value from 0 to 255

ID
----

#### SAVE GENERAL SETTINGS .....

Save general settings command trigger EEPROM writing of the general settings.

CMD
0x13

#### COLOUR (FOREGROUND) .....

Colour command change current colours according to the number of RGB values sent. To be clearer data length will implicitly tell the ball which colour mode to apply, see options below:

- 3 values: 1 colour mode
- 6 values: 2 colours mode (1 per hemisphere)
- 9 values: 3 colours mode (3 pairs of opposite leds)
- 18 values: 6 colours mode (6 individual leds)

CMD	DATA
0x20	variable

#### DATA STRUCTURE:

- Colour 1 Red value : uint8 value from 0 to 255
- Colour 1 Green value : uint8 value from 0 to 255
- Colour 1 Blue value : uint8 value from 0 to 255
- (optional) colour 2/3/4/5/6 RGB values

R1	G1	B1	(R2)	(G2)	(B2)	and so on...
----	----	----	------	------	------	--------------

#### COLOUR (BACKGROUND) .....

Background colour command change the current background colours according to the number of RGB values sent. Background colour is the second colour of the stroboscopic effect. Data structures and options are the as the foreground colour command.

CMD	DATA
0x22	variable

#### STREAM .....

Stream command act almost the same way as colour command apart that you can address multiple balls at one time. Doing this you need to add one extra data byte to precise the number of colours sent for each ball. Balls will change colours according to its id numbers modulo the number of channels sent in the stream.

CMD	DATA
0x21	variable

#### DATA STRUCTURE:

- Flag : describe the data sent in the stream
- Offset : id offset of the stream
- Series of data 1
- (optional) Series of data 2, etc...

#### STREAM FLAG STRUCTURE:

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
LOOP	-	-	-	-	GSC	MOT	IRL	STB	MST	N_COL2			N_COL1		

#### DATA STRUCTURE EXAMPLE:

Even serial number balls goes red & blue while odd serial number balls goes black & white:

FLAG	OFFSET	RGB1.1	RGB1.2	RGB2.1	RGB 2.2
0x00 0x02	0x00	0xFF 0x00 0x00	0x00 0x00 0xFF	0xFF 0xFF 0xFF	0x00 0x00 0x00

This command has been design for the first 30 balls during the alpha tests. Future firmware will use customisable id values instead of serial numbers.

## IMU SETTINGS .....

IMU settings command will change current IMU feedback settings.

CMD	FLAG
0x30	variable

#### DATA STRUCTURE:

- IMU flag: 8 bits flag describing available feedbacks.

#### DEVICE FLAG STRUCTURE:

7	6	5	4	3	2	1	0
STA	WLD	QUA	VEC	TMP	MAG	GYR	ACC

## ACCELEROMETER RANGE .....

Accelerometer range command will change current accelerometer full-scale range settings.

CMD	PAR
0x32	variable

#### DATA STRUCTURE:

- Full-scale parameter: 8 bits parameter.

#### PARAMETER VALUES:

- 0x00: -2g / +2g.
- 0x01: -4g / +4g.
- 0x02: -8g / +8g.
- 0x03: -16g / +16g (default).

## GYROSCOPE RANGE .....

Gyroscope range command will change current gyroscope full-scale range settings.

CMD	PAR
0x33	variable

DATA STRUCTURE:

- Full-scale parameter: 8 bits parameter.

PARAMETER VALUES:

- 0x00: -250dps / +250dps.
- 0x01: -500dps / +500dps.
- 0x02: -1000dps / +1000dps.
- 0x03: -2000dps / +2000dps (default).

## SAVE IMU SETTINGS .....

Save IMU command trigger EEPROM writing of the IMU settings.

CMD
0x031

## INFRARED .....

Infrared command change the current value of the infrared channel PWM.

CMD	DATA
0x40	2 bytes

DATA STRUCTURE:

- value : uint16 value from 0 to 1023

VAL_MSB	VAL_LSB
---------	---------

## MOTOR .....

Motor command change the current value of the motor channel PWM.

CMD	DATA
0x50	2 bytes

DATA STRUCTURE:

- value : uint16 value from 0 to 1023

MSB	LSB
-----	-----

## STROBE .....

Strobe command change the current interval of the inner stroboscopic effect. Using this effect switch between foreground and background colour every  $n$  milliseconds. Values are stored as 10  $\mu$ s per less significant bit.

CMD	DATA
0x60	2 bytes

DATA STRUCTURE:

- interval (ms) : value from 0. to 500.

## MASTER .....

Master command is a global dimmer for every colour channel. The dimmer value does not affect the colours memory it only change the amount of colours forwarded to the RGB Leds. Values are stored as 1/100<sup>th</sup> unit per less significant bit.

CMD	DATA
0x70	2 bytes

DATA STRUCTURE:

- dimmer: value from 0. to 100.



---

## DOWNSTREAM COMMANDS

### PONG .....

Pong is answering the ping command.

ID		SN		CMD
MSB	LSB	MSB	LSB	0x01

### BATTERY VALUE .....

Battery feedback transmit  $V_{share}$  voltage value stored as 1/100<sup>th</sup> Volts per LSB.

ID		SN		CMD	DATA
MSB	LSB	MSB	LSB	0x00	2 bytes

DATA STRUCTURE:

- value: value from 0 to 5.2V, this value is adjusted by the adc scaling factory setting.

VAL_MSB	VAL_LSB
---------	---------

### IMU VALUES .....

IMU feedback transmit IMU values according to the current IMU flag.

ID		SN		CMD	DATA
MSB	LSB	MSB	LSB	0x30	variable

DATA STRUCTURE:

- IMU flag: 8 bits flag describing available feedbacks (see IMU settings for description)
- (optional) accelerometer: 6 bytes containing the XYZ values of the accelerometer
- (optional) gyroscope: 6 bytes containing the XYZ 1/100 values of the gyroscope
- (optional) magnetometer: 6 bytes containing the XYZ values of the magnetometer
- (optional) temperature: temperature value
- (optional) magnitude: 6 bytes containing values of the acc, gyr & mag magnitude
- (optional) quaternion: 8 bytes containing the WXYZ values of the quaternion
- (optional) world: 6 bytes containing the XYZ values of the real world acceleration
- (optional) special states: 1 byte flag for filter state detection (work in progress)

1/100<sup>th</sup> m.s<sup>-2</sup>

1/100<sup>th</sup> d.s<sup>-1</sup>

1/100<sup>th</sup>.μT

1/100<sup>th</sup> °C

1/100<sup>th</sup>

1/10000<sup>th</sup>

1/100<sup>th</sup> m.s<sup>-2</sup>

DATA STRUCTURE EXAMPLE:

Optional data stacks after directly after the flag depending on enable bits order.

FLAG	GYR_XYZ	TEMP
0x0A	6 bytes	2 bytes

DOCUMENT VERSION	
v1.0	Initial release
v1.1	Loop bit correction in stream flag
v1.2	IMU Flag correction in IMU Settings, fixed point value correction, summary correction
v1.3	GSC bit in the stream flag