

## 8086 INTERRUPTS

- An interrupt is a special condition that arises during the working of a  $\mu P$ .
- The  $\mu P$  services it by executing a subroutine called Interrupt Service Routine (ISR).
- There are 3 sources of interrupts for 8086:

### External Signal (Hardware Interrupts):

These interrupts occur as signals on the external pins of the  $\mu P$ .  
8086 has two pins to accept hardware interrupts, NMI and INTR.

### Special instructions (Software Interrupts):

These interrupts are caused by writing the software interrupt instruction  $INTn$  where "n" can be any value from 0 to 255 (00H to FFH).  
Hence all 256 interrupts can be invoked by software.

### Condition Produced by the Program (Internally Generated Interrupts):

8086 is interrupted when some special conditions occur while executing certain instructions in the program.  
Eg: **An error in division** automatically causes the INT 0 interrupt.

### INTERRUPT VECTOR TABLE (IVT) {10M --- IMPORTANT }

The **IVT contains ISR address** for the 256 interrupts.

**Each ISR address** is stored as **CS and IP**.

As each ISR address is of 4 bytes (2-CS and 2-IP), each ISR address requires 4 locations to be stored.

There are **256 interrupts**: INT 0 ... INT 255  $\therefore$  the **total size of the IVT** is  $256 \times 4 = 1KB$ .

The first 1KB of memory, address 00000 H ... 003FF H, are reserved for the IVT.

Whenever an interrupt **INT N** occurs,  $\mu P$  does  $N \times 4$  to get values of **IP and CS** from the IVT and hence perform the ISR.



1 KB (256 \* 4)

00000 H	IP Lower	<b>INT 0 --- Divide error</b>
00001 H	IP Higher	
00002 H	CS Lower	
00003 H	CS Higher	
00004 H		<b>INT 1 --- Single Stepping</b>
.		
.		
00007 H		
00008 H		<b>INT 2 --- NMI</b>
.		
.		
0000B H		
0000C H		<b>INT 3 --- Breakpoint</b>
.		
.		
0000F H		
00010 H		<b>INT 4 --- Interrupt on Overflow</b>
.		
.		
00013 H		
00014 H		<b>INT 5</b>
.		
.		
.		
0007F H		<b>INT 31</b>
00080 H		
.		
.		
003FF H		<b>INT 32</b>
		<b>INT 255</b>

--- Reserved

--- User  
Defined

Dedicated Interrupts

## **DEDICATED INTERRUPTS (INT 0 ... INT 4)**

### **1) INT 0 (Divide Error)**

This interrupt occurs whenever there is **division error**

i.e. when the result of a division is too large to be stored.

This condition normally occurs when the divisor is very small as compared to the dividend or the divisor is zero. #Refer example from Bharat Sir's lecture notes...

Its ISR address is stored at location  $0 \times 4 = 00000H$  in the IVT.

### **2) INT 1 (Single Step)**

The  $\mu P$  executes this interrupt **after every instruction if the TF is set.**

It puts  $\mu P$  in **Single Stepping** Mode i.e. the  $\mu P$  pauses after executing every instruction.

This is very useful during **debugging**. #Refer example from Bharat Sir's lecture notes...

Its ISR generally displays contents of all registers.

Its ISR address is stored at location  $1 \times 4 = 00004H$  in the IVT.

### **3) INT 2 (Non Maskable Interrupt)**

The  $\mu P$  executes this ISR in **response to** an interrupt on the **NMI** line.

Its ISR address is stored at location  $2 \times 4 = 00008H$  in the IVT.

### **4) INT 3 (Breakpoint Interrupt)**

This interrupt is used to cause **Breakpoints** in the program.

It is caused by writing the instruction INT 03H or simply INT.

It is useful in **debugging large programs** where Single Stepping is inefficient.

Its ISR is used to **display the contents of all registers** on the screen.

Its ISR address is stored at location  $3 \times 4 = 0000CH$  in the IVT.

### **5) INT 4 (Overflow Interrupt)**

This interrupt occurs if the **Overflow Flag is set AND** the  $\mu P$  executes the **INTO** instruction (Interrupt on overflow). #Show example from Bharat Sir's lecture notes...

It is used to detect overflow error in **signed arithmetic** operations.

Its ISR address is stored at location  $4 \times 4 = 00010H$  in the IVT.

Please Note: INT 0 ... INT 4 are called as dedicated interrupts as these interrupts are dedicated for the above-mentioned special conditions.



## **RESERVED INTERRUPTS**

### **INT 5 ... INT 31**

These levels are **reserved** by INTEL to be used in higher processors like 80386, Pentium etc. They are **not available** to the user.

## **User defined Interrupts**

### **INT 32 ... INT 255**

These are **user defined, software** interrupts.

ISRs for these interrupts are written by the users to service various user defined conditions.

These interrupts are invoked by writing the instruction INT n.

Its ISR address is obtained by the  $\mu P$  from location  $n \times 4$  in the IVT.

## **HARDWARE INTERRUPTS**

### **1) NMI (Non Maskable Interrupt)**

This is a **non-maskable, edge** triggered, **high priority** interrupt.

On receiving an interrupt on NMI line, the  $\mu P$  executes **INT 2**.

$\mu P$  obtains the ISR address from location  $2 \times 4 = 00008H$  from the IVT.

It reads 4 locations starting from this address to get the values for IP and CS, to execute the ISR.

☺ For doubts contact Bharat Sir on 98204 08217

### **2) INTR**

This is a **maskable, level** triggered, **low priority** interrupt.

On receiving an interrupt on INTR line, the  $\mu P$  executes **2 INTA** pulses.

**1st INTA** pulse --- the interrupting device **calculates** (prepares to send) the **vector number**.

**2nd INTA** pulse --- the interrupting device **sends** the **vector number "N"** to the  $\mu P$ .

Now  $\mu P$  multiplies  $N \times 4$  and goes to the corresponding location in the IVT to obtain the ISR address.

INTR is a maskable interrupt.

It is masked by making  $IF = 0$  by software through **CLI** instruction.

It is unmasked by making  $IF = 1$  by software through **STI** instruction.



## **Response to any interrupt --- INT N**

- i) The  $\mu P$  will **PUSH Flag** register into the Stack.  
 $SS:[SP-1], SS:[SP-2] \leftarrow \text{Flag}$   
 $SP \leftarrow SP - 2$
- ii) **Clear IF and TF** in the Flag register and thus disables INTR interrupt.  
 $IF \leftarrow 0, TF \leftarrow 0$
- iii) **PUSH CS** into the Stack.  
 $SS:[SP-1], SS:[SP-2] \leftarrow CS$   
 $SP \leftarrow SP - 2$
- iv) **PUSH IP** into the Stack.  
 $SS:[SP-1], SS:[SP-2] \leftarrow IP$   
 $SP \leftarrow SP - 2$
- v) **Load new IP** from the IVT  
 $IP \leftarrow [N \times 4], [N \times 4 + 1]$
- vi) **Load new CS** from the IVT  
 $IP \leftarrow [N \times 4 + 2], [N \times 4 + 3]$

Since CS and IP get new values, control shifts to the address of the ISR and the ISR thus begins. At the end of the ISR the  $\mu P$  encounters the IRET instruction and returns to the main program in the following steps.

## **Response to IRET instruction**

- i) The  $\mu P$  will **restore IP from the stack**  
 $IP \leftarrow SS:[SP], SS:[SP+1]$   
 $SP \leftarrow SP + 2$
- ii) The  $\mu P$  will **restore CS from the stack**  
 $CS \leftarrow SS:[SP], SS:[SP+1]$   
 $SP \leftarrow SP + 2$
- iii) The  $\mu P$  will **restore FLAG register from the stack**  
 $\text{Flag} \leftarrow SS:[SP], SS:[SP+1]$   
 $SP \leftarrow SP + 2$



## Interrupt Priorities

Interrupt	Priority	
	(Simultaneous occurrence)	(To interrupt another ISR)
Divide Error, INT n, INTO	1 (Highest)	Can interrupt any ISR
NMI	2	
INTR	3	Cannot interrupt an ISR (IF, TF $\leftarrow$ 0)
Single Stepping	4 (Lowest)	

Priority in 8086 interrupts is of two types:

### 1. Simultaneous Occurrence:

When more than one interrupts occur simultaneously then, **all s/w interrupts except single stepping**, get the **highest priority**.

This is followed by **NMI**. Next is **INTR**. Finally, the **lowest priority** is of the **single stepping** interrupt.

**Eg:** Assume the  $\mu P$  is executing a **DIV** instruction that causes a **division error** and **simultaneously INTR** occurs.

Here **INT 0** (Division error) will be **served first** i.e. its ISR will be executed, as it has higher priority, and **then INTR** will be **served**. #Please refer Bharat Sir's Lecture Notes for this ...

### 2. Ability to interrupt another ISR:

Since software interrupts (**INT N**) are **non-maskable**, they **can interrupt** any ISR.

**NMI** is also **non-maskable** hence it **can** also **interrupt** any ISR.

But **INTR** and **Single stepping** **cannot interrupt** another ISR **as** both are **disabled** before  $\mu P$  enters an ISR by **IF  $\leftarrow$  0** and **TF  $\leftarrow$  0**.

**Eg:** Assume the  $\mu P$  executes DIV instruction that causes a **division error**. So  $\mu P$  gets the **INT 0** interrupt and now  **$\mu P$  enters the ISR for INT 0**. **During** the execution of **this ISR**, **NMI** and **INTR** occur.

Here  **$\mu P$  will branch out** from the ISR of INT 0 and **service NMI** (as **NMI is non-maskable**).

After completing the ISR of NMI  **$\mu P$  will return to the ISR for INT 0**.

**INTR** is **still pending** but the  **$\mu P$  will not service INTR** during the ISR of INT 0 (as **IF  $\leftarrow$  0**).

$\mu P$  will first **finish the INT 0 ISR** and **only then service INTR**.

Thus INTR and Single stepping cannot interrupt an existing ISR.