

# **Formality® Tool Commands**

---

Version T-2022.03-SP4, September 2022

**SYNOPSYS®**

## Copyright Notice and Proprietary Information

© 2022 Synopsys, Inc. All rights reserved. This Synopsys software and all associated documentation are proprietary to Synopsys, Inc. and may only be used pursuant to the terms and conditions of a written license agreement with Synopsys, Inc. All other use, reproduction, or distribution of the Synopsys software or the associated documentation is strictly prohibited.

### Destination Control Statement

All technical data contained in this publication is subject to the export control laws of the United States of America. Disclosure to nationals of other countries contrary to United States law is prohibited. It is the reader's responsibility to determine the applicable regulations and to comply with them.

### Disclaimer

SYNOPSYS, INC., AND ITS LICENSORS MAKE NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

### Trademarks

Synopsys and certain Synopsys product names are trademarks of Synopsys, as set forth at <http://www.synopsys.com/company/legal/trademarks-brands.html>.

All other product or company names may be trademarks of their respective owners.

### Free and Open-Source Software Licensing Notices

If applicable, Free and Open-Source Software (FOSS) licensing notices are available in the product installation.

### Third-Party Links

Any links to third-party websites included in this document are for your convenience only. Synopsys does not endorse and is not responsible for such websites and their practices, including privacy practices, availability, and content.

[www.synopsys.com](http://www.synopsys.com)

---

## Contents

---

SEQGEN . . . . .	13
add_command_hook . . . . .	15
add_to_collection . . . . .	17
alias . . . . .	19
all_connected . . . . .	21
all_fanin . . . . .	23
all_fanout . . . . .	25
all_inputs . . . . .	27
all_outputs . . . . .	28
all_registers . . . . .	29
analyze_cones . . . . .	31
analyze_designs . . . . .	35
analyze_points . . . . .	36
analyze_upf . . . . .	39
annotate_trace . . . . .	41
append_eco_data . . . . .	43
append_to_collection . . . . .	45
apply_edits . . . . .	47
apropos . . . . .	48
change_link . . . . .	50
check_dpx_options . . . . .	52
check_license . . . . .	54
check_script . . . . .	56
collections . . . . .	60
commit_edits . . . . .	64
compare_collections . . . . .	65
compare_edits . . . . .	67
compare_lp . . . . .	69
connect_net . . . . .	71
connect_pin . . . . .	73
constrain_low_power_intent . . . . .	75
copy_collection . . . . .	76
cputime . . . . .	78
create_cell . . . . .	79
create_command_group . . . . .	81
create_constraint_type . . . . .	83
create_container . . . . .	85
create_cutpoint_blackbox . . . . .	87
create_eco_patch . . . . .	89
create_net . . . . .	91

create_port . . . . .	93
create_power_model . . . . .	95
create_primitive . . . . .	96
current_container . . . . .	99
current_design . . . . .	101
current_instance . . . . .	103
current_prefix . . . . .	106
date . . . . .	108
debug_library_cell . . . . .	109
debug_script . . . . .	110
define_design_lib . . . . .	112
define_primitive_pg_pins . . . . .	114
define_proc_attributes . . . . .	116
diagnose . . . . .	120
discard_edits . . . . .	123
disconnect_net . . . . .	124
echo . . . . .	126
edit_design . . . . .	128
elaborate_library_cells . . . . .	130
elapsed_time . . . . .	131
end_alterate_strategies . . . . .	132
error_info . . . . .	134
exit . . . . .	135
filter_collection . . . . .	136
find_cells . . . . .	138
find_compare_points . . . . .	140
find_cutpoint_pins . . . . .	143
find_designs . . . . .	146
find_drivers . . . . .	148
find_equivalent_nets . . . . .	150
find_nets . . . . .	153
find_pins . . . . .	155
find_ports . . . . .	157
find_receivers . . . . .	159
find_references . . . . .	161
find_region_of_nets . . . . .	163
find_segments . . . . .	165
find_svf_operation . . . . .	167
foreach_in_collection . . . . .	170
generate_eco_map_file . . . . .	172
get_app_var . . . . .	174
get_attribute . . . . .	177
get_cells . . . . .	179
get_command_hooks . . . . .	181
get_command_option_values . . . . .	182

get_current_hook_command . . . . .	184
get_defined_commands . . . . .	185
get_designs . . . . .	188
get_dpx_workers . . . . .	190
get_lib_cells . . . . .	191
get_lib_pins . . . . .	193
get_libs . . . . .	195
get_license . . . . .	197
get_message_ids . . . . .	199
get_message_info . . . . .	200
get_nets . . . . .	202
get_pins . . . . .	204
get_ports . . . . .	206
get_trace_option . . . . .	208
get_unix_variable . . . . .	210
getenv . . . . .	212
group . . . . .	214
guide . . . . .	216
guide_architecture_db . . . . .	218
guide_architecture_netlist . . . . .	220
guide_boundary . . . . .	222
guide_boundary_netlist . . . . .	224
guide_breakpoint . . . . .	226
guide_change_names . . . . .	228
guide_checkpoint . . . . .	230
guide_clkgate_removal . . . . .	232
guide_constant . . . . .	233
guide_constraints . . . . .	235
guide_datapath . . . . .	237
guide_datapath_end . . . . .	239
guide_divider_netlist . . . . .	240
guide_dont_verify_scan . . . . .	242
guide_dont_verify_scan_input . . . . .	244
guide_eco_change . . . . .	246
guide_eco_map . . . . .	248
guide_environment . . . . .	250
guide_eqop . . . . .	252
guide_file_info . . . . .	254
guide_fsm_reencoding . . . . .	256
guide_group . . . . .	258
guide_group_function . . . . .	260
guide_hier_map . . . . .	262
guide_implementation . . . . .	264
guide_info . . . . .	266
guide_instance_map . . . . .	268

guide_instance_merging . . . . .	270
guide_inv_push . . . . .	272
guide_invert . . . . .	273
guide_iso_duplication . . . . .	275
guide_iso_merging . . . . .	276
guide_mark . . . . .	277
guide_mc . . . . .	278
guide_merge . . . . .	280
guide_multibit . . . . .	282
guide_multiplier . . . . .	284
guide_port_constant . . . . .	286
guide_private . . . . .	288
guide_reg_constant . . . . .	290
guide_reg_duplication . . . . .	292
guide_reg_encoding . . . . .	294
guide_reg_eqop . . . . .	296
guide_reg_merging . . . . .	298
guide_reg_removal . . . . .	300
guide_reg_split . . . . .	302
guide_rename_design . . . . .	304
guide_replace . . . . .	306
guide_retiming . . . . .	309
guide_retiming_class . . . . .	311
guide_retiming_cross . . . . .	313
guide_retiming_decompose . . . . .	315
guide_retiming_eq_nets . . . . .	317
guide_retiming_finished . . . . .	319
guide_retiming_move . . . . .	320
guide_retiming_multibit . . . . .	322
guide_retiming_pinmap . . . . .	324
guide_retiming_seqmap . . . . .	326
guide_retiming_unmap . . . . .	328
guide_rewire . . . . .	330
guide_safety_error_code . . . . .	332
guide_safety_error_propagate . . . . .	334
guide_safety_fsm . . . . .	336
guide_safety_reg_group . . . . .	338
guide_scan_input . . . . .	340
guide_sequential_cg_fanin . . . . .	342
guide_set_rounding . . . . .	343
guide_share . . . . .	345
guide_split_constant . . . . .	347
guide_time_begin . . . . .	349
guide_time_end . . . . .	350
guide_transformation . . . . .	351

guide_ungroup . . . . .	354
guide_uniquify . . . . .	356
guide_ununiquify . . . . .	358
help . . . . .	360
help_attributes . . . . .	362
history . . . . .	364
index_collection . . . . .	367
insert_inversion . . . . .	369
invert_pin . . . . .	371
is_false . . . . .	373
is_true . . . . .	375
library_verification . . . . .	377
license_users . . . . .	379
list_attributes . . . . .	381
list_key_bindings . . . . .	383
list_libraries . . . . .	384
list_licenses . . . . .	385
lminus . . . . .	387
load_breakpoint_data . . . . .	389
load_ssf . . . . .	390
load_upf . . . . .	392
log_trace . . . . .	395
ls . . . . .	397
man . . . . .	398
match . . . . .	399
match_eco_regions . . . . .	401
memory . . . . .	403
parse_proc_arguments . . . . .	405
preverify . . . . .	407
preview . . . . .	409
print_message_info . . . . .	411
print_proc_new_vars . . . . .	413
print_suppressed_messages . . . . .	415
printenv . . . . .	416
printvar . . . . .	417
proc_args . . . . .	419
proc_body . . . . .	421
query_objects . . . . .	422
quit . . . . .	424
read_container . . . . .	425
read_db . . . . .	427
read_ddc . . . . .	431
read_fsm_states . . . . .	434
read_ndm . . . . .	436
read_power_model . . . . .	438

read_sverilog . . . . .	440
read_verilog . . . . .	444
read_vhdl . . . . .	448
record_edits . . . . .	451
redirect . . . . .	452
remodel . . . . .	455
remove_black_box . . . . .	457
remove_cell . . . . .	459
remove_cell_type . . . . .	461
remove_checkpoint_report_commands . . . . .	463
remove_checkpoint_setup_commands . . . . .	465
remove_clock . . . . .	467
remove_command_hook . . . . .	469
remove_compare_rules . . . . .	471
remove_constant . . . . .	473
remove_constraint . . . . .	475
remove_constraint_type . . . . .	476
remove_container . . . . .	478
remove_cutpoint . . . . .	480
remove_design . . . . .	482
remove_design_library . . . . .	484
remove_dont_cut . . . . .	486
remove_dont_match_points . . . . .	488
remove_dont_reverse . . . . .	490
remove_dont_verify_points . . . . .	492
remove_dp_int_round . . . . .	494
remove_dpx_options . . . . .	495
remove_factor_point . . . . .	496
remove_from_collection . . . . .	498
remove_guidance . . . . .	500
remove_init_toggle_assumption . . . . .	501
remove_input_value_range . . . . .	503
remove_inv_push . . . . .	505
remove_inversion . . . . .	507
remove_library . . . . .	509
remove_license . . . . .	511
remove_mismatch_message_filter . . . . .	513
remove_net . . . . .	516
remove_net_resolution . . . . .	518
remove_object . . . . .	520
remove_parameters . . . . .	522
remove_port . . . . .	524
remove_probe_points . . . . .	526
remove_resistive_drivers . . . . .	528
remove_simulation_setup_file . . . . .	530



remove_user_match . . . . .	531
remove_verify_points . . . . .	533
rename . . . . .	535
rename_object . . . . .	537
replicate_safety_register . . . . .	539
report_aborted_points . . . . .	541
report_alternate_strategies . . . . .	544
report_always_on_cells . . . . .	546
report_analysis_results . . . . .	548
report_app_var . . . . .	549
report_architecture . . . . .	551
report_black_boxes . . . . .	553
report_cell_list . . . . .	558
report_cell_type . . . . .	561
report_checkpoint_report_commands . . . . .	563
report_checkpoint_setup_commands . . . . .	565
report_checksum . . . . .	567
report_clocks . . . . .	569
report_compare_rules . . . . .	570
report_constant_sources . . . . .	572
report_constants . . . . .	574
report_constraint . . . . .	576
report_constraint_type . . . . .	578
report_containers . . . . .	580
report_cutpoints . . . . .	581
report_derived_isolation_constraints . . . . .	583
report_design_libraries . . . . .	584
report_designs . . . . .	586
report_diagnosed_matching_regions . . . . .	589
report_dont_cuts . . . . .	591
report_dont_match_points . . . . .	592
report_dont_reverse . . . . .	593
report_dont_verify_points . . . . .	594
report_dp_int_round . . . . .	596
report_dpx_options . . . . .	597
report_eco_data . . . . .	599
report_eco_impact . . . . .	600
report_edits . . . . .	603
report_electrical_checks . . . . .	604
report_error_candidates . . . . .	607
report_factor_points . . . . .	610
report_failing_points . . . . .	611
report_feedthrough_points . . . . .	615
report_feedthrough_status . . . . .	617
report_fsm . . . . .	619

report_guidance	621
report_hdlin_mismatches	624
report_hierarchy	626
report_host_options	629
report_init_toggle_assumption	630
report_init_toggle_objects	632
report_input_value_range	634
report_inv_push	636
report_inversion	638
report_libraries	639
report_loops	642
report_lp	645
report_matched_points	646
report_mismatch_message_filters	652
report_multidrivens_nets	654
report_net_resolution	656
report_not_compared_points	658
report_parameters	663
report_passing_points	665
report_potentially_constant_registers	669
report_power_model	671
report_probe_points	674
report_probe_status	676
report_related_supplies	678
report_remodel	680
report_remove_objects	682
report_safety_status	683
report_setup_status	685
report_source_path	687
report_status	690
report_svf	693
report_svf_operation	694
report_trace	698
report_truth_table	701
report_undriven_nets	704
report_unmatched_inputs	706
report_unmatched_points	707
report_unread_endpoints	712
report_unverified_points	715
report_upf	719
report_user_matches	722
report_verify_points	724
report_vhdl	725
restore_session	727
rewire_connection	729

run_alterate_strategies . . . . .	731
save_session . . . . .	734
select_cell_list . . . . .	736
set_app_var . . . . .	738
set_architecture . . . . .	740
set_black_box . . . . .	742
set_cell_type . . . . .	744
set_checkpoint_report_commands . . . . .	746
set_checkpoint_setup_commands . . . . .	748
set_clock . . . . .	750
set_command_option_value . . . . .	752
set_compare_rule . . . . .	754
set_constant . . . . .	757
set_constraint . . . . .	759
set_current_command_mode . . . . .	763
set_cutpoint . . . . .	765
set_direction . . . . .	767
set_dont_cut . . . . .	769
set_dont_match_points . . . . .	771
set_dont_reverse . . . . .	773
set_dont_verify_points . . . . .	775
set_dp_int_round . . . . .	777
set_dpx_options . . . . .	779
set_eco_data . . . . .	782
set_eco_implementation . . . . .	783
set_eco_reference . . . . .	784
set_factor_point . . . . .	785
set_feedthrough_points . . . . .	787
set_fsm_encoding . . . . .	789
set_fsm_state_vector . . . . .	791
set_host_options . . . . .	794
set_implementation_design . . . . .	796
set_init_toggle_assumption . . . . .	797
set_input_value_range . . . . .	799
set_inv_push . . . . .	801
set_message_info . . . . .	803
set_mismatch_message_filter . . . . .	805
set_net_resolution . . . . .	808
set_orig_implementation . . . . .	810
set_orig_reference . . . . .	811
set_parameters . . . . .	812
set_probe_points . . . . .	815
set_reference_design . . . . .	817
set_run_alterate_strategies_options . . . . .	818
set_simulation_setup_file . . . . .	820

set_svf . . . . .	822
set_top . . . . .	824
set_trace_option . . . . .	828
set_unix_variable . . . . .	830
set_user_match . . . . .	832
set_vclp_setup_commands . . . . .	834
set_verify_points . . . . .	835
set_vsdc . . . . .	837
setenv . . . . .	839
setup . . . . .	841
sh . . . . .	842
shell_is_fmeco_shell . . . . .	843
sizeof_collection . . . . .	844
sort_collection . . . . .	845
source . . . . .	847
start_dpx_workers . . . . .	849
start_gui . . . . .	851
stop_dpx_workers . . . . .	852
stop_gui . . . . .	853
suppress_message . . . . .	854
test_compare_rule . . . . .	856
translate_instance_pathname . . . . .	859
unalias . . . . .	861
undo_edits . . . . .	862
undo_match . . . . .	863
ungroup . . . . .	864
uniquify . . . . .	866
unread_analysis . . . . .	868
unsetenv . . . . .	870
unsuppress_message . . . . .	872
vclp_start_gui . . . . .	873
verify . . . . .	874
verify_edits . . . . .	877
view_named_objects . . . . .	878
which . . . . .	880
write_app_var . . . . .	882
write_container . . . . .	884
write_eco_regions . . . . .	886
write_edits . . . . .	888
write_functional_matches . . . . .	890
write_hierarchical_verification_script . . . . .	892
write_library_debug_scripts . . . . .	896
write_power_model . . . . .	898
write_register_mapping . . . . .	900

---

## SEQGEN

Sets Formality's SEQGEN generic register primitive.

---

## SYNTAX

**SEQGEN**

---

## ARGUMENTS

This command has no arguments.

---

## DESCRIPTION

This man page describes how to use SEQGEN. You can use SEQGEN to set Formality's generic register primitive. A SEQGEN has up to 10 inputs, up to 2 outputs, and up to 3 attributes.

This command has the following inputs:

- AC : asynchronous clear (clear)
- AS : asynchronous set (preset)
- AL : asynchronous load (enable)
- AD : asynchronous data (data\_in)
- SC : synchronous clear (synch\_clear)
- SS : synchronous set (synch\_preset)
- ST : synchronous toggle (synch\_toggle)
- SL : synchronous load (synch\_enable)
- SD : synchronous data (next\_state)
- CLK : clock (clocked\_on)

This command has the following outputs:

- Q : state output (Q)
- QN : inverted state output (QN)

This command has the following attributes:

- AC\_AS\_Q : value of Q when both AC and AS are asserted (clear\_prset\_var1)
- AC\_AS\_QN : value of QN when both AC and AS are asserted (clear\_prset\_var2)
- SC\_SS\_Q : value of Q when both SC and SS are asserted (synch\_clear\_prset\_var1)

CLK does not exist if the SEQGEN represents a latch. Otherwise, the SEQGEN represents a flip-flop and CLK connects to a non-ground net, which is the clock signal. Any pin type that is not present on the SEQGEN is assumed to be zero.

It is assumed that every asynchronous operation has priority over all synchronous operations. For example, if both AC and SS have value 1 when the clock transits from 0 to 1, Q has value 0. It is also assumed that both AC and AS have priority over AL. That is, when both AC and AL have value 1, Q has value 0 regardless of AD's value. Similarly, SC and SS have priority over SL and ST. There is no precedence relation between ST and SL. In practice, you need not define a precedence relation between ST and SL, because when a SEQGEN is inferred from an HDL description, its ST and SL are one-hot (meaning they cannot be 1 at the same time).

---

## EXAMPLES

This example shows how the behavior of a SEQGEN can be modeled by the following function. Change of AC, AS, AL, AD, or 0-to-1 transition of CLK causes activation of the function.

```
SEQGEN(AC, AS, AL, AD, SC, SS, ST, SL, SD, CLK, Q, QN, AC_AS_Q,\
AC_AS_QN, SC_SS_Q)
```

```
input AC, AS, AL, AD, SC, SS, ST, SL, SD, CLK;
inout Q, QN;
parameter AC_AS_Q, AC_AS_QN, SC_SS_Q;
```

```
{
variable temp;
if (AC && AS) {
  Q=AC_AS_Q; QN=AC_AS_QN;
} else if (AC) {
  Q=0; QN=1;
} else if (AS) {
  Q=1; QN=0;
} else if (AL) {
  Q=AD; QN=!AD;
} else if (posedge CLK) {
  if (SC && SS) {
    Q=SC_SS_Q; QN=!SC_SS_Q;
  } else if (SC) {
    Q=0; QN=1;
  } else if (SS) {
    Q=1; QN=0;
  } else if (ST && SL) {
    error;
  } else if (SL) {
    Q=SD; QN=!SD;
  } else if (ST) {
    temp=Q; Q=QN; QN=temp;
  }
}
```

---

## SEE ALSO

---

## add\_command\_hook

Add hook into command execution

---

### SYNTAX

```
string add_command_hook -before script
      -after script
      -replace script
      [-name name]
      commandName
```

```
string script
string script
string script
string name
string commandName
```

---

### ARGUMENTS

**-before *script***

Hook runs before command.

**-after *script***

Hook runs after command.

**-replace *script***

Hook runs in place of command.

**-name *name***

Name of hook. If no name is specified a name is automatically generated.

***commandName***

Command to update.

---

### DESCRIPTION

The **add\_command\_hook** adds a customization point into the execution of an application command. For example, these hooks can be used to either run a report or gather statistics before and after an application command is run.

Within the body of any hook the `get_current_hook_command` can be used to query the command and its arguments. For example, a before and after hook may use this information if the hook actions should only happen when specific options are specified. In a replace hook the hook can run the replaced command possibly updating the command options.

This command returns the name of the hook which can be used to remove the hook from the command if desired.

---

## EXAMPLES

Arrange for report timing to be executed every time place\_opt is run.

```
prompt> add_command_hook place_opt -before report_timing  
before0
```

Force all report\_timing calls to use the -nosplit option.

```
prompt> add_command_hook report_timing -replace {eval [get_current_hook_command] -nosplit}  
replace0
```

---

## SEE ALSO

```
get_command_hooks(2)  
remove_command_hook(2)  
get_current_hook_command(2)
```



---

## add\_to\_collection

Adds objects to a collection, resulting in a new collection. The base collection remains unchanged.

---

### SYNTAX

```
collection add_to_collection
[-unique]
collection1
object_spec
```

#### Data Types

<i>collection1</i>	collection
<i>object_spec</i>	list

---

### ARGUMENTS

#### -unique

Removes duplicate objects from the resulting collection. By default, duplicate objects are not removed.

#### *collection1*

Specifies the base collection to which objects are to be added. This collection is copied to the result collection, and objects matching *object\_spec* are added to the result collection. The *collection1* option can be the empty collection (empty string), subject to some constraints, as explained in the DESCRIPTION section.

#### *object\_spec*

Specifies a list of named objects or collections to add.

If the base collection is heterogeneous, only collections can be added to it.

If the base collection is homogeneous, the object class of each element in this list must be the same as in the base collection. If it is not the same class, it is ignored. From heterogeneous collections in the *object\_spec*, only objects of the same class of the base collection are added. If the name matches an existing collection, the collection is used. Otherwise, the objects are searched for in the database using the object class of the base collection.

The *object\_spec* has some special rules when the base collection is empty, as explained in the DESCRIPTION section.

---

### DESCRIPTION

The **add\_to\_collection** command allows you to add elements to a collection. The result is a new collection representing the objects in the *object\_spec* added to the objects in the base collection.

Elements that exist in both the base collection and the *object\_spec*, are duplicated in the resulting collection. Duplicates are not removed unless you use the *-unique* option. If the *object\_spec* is empty, the result is a copy of the base collection.

If the base collection is homogeneous, the command searches in the database for any elements of the *object\_spec* that are not collections, using the object class of the base collection. If the base collection is heterogeneous, all implicit elements of the

*object\_spec* are ignored.

When the *collection1* argument is the empty collection, some special rules apply to the *object\_spec*. If the *object\_spec* is non-empty, there must be at least one collection somewhere in the *object\_spec* list (its position in the list does not matter). The first homogeneous collection in the *object\_spec* list becomes the base collection and sets the object class for the function. The examples show the different errors and warnings that can be generated.

The **append\_to\_collection** command has similar semantics as the **add\_to\_collection** command; however, the **append\_to\_collection** command can be much more efficient in some cases. For more information about the command, see the man page.

For background on collections and querying of objects, see the **collections** man page.

---

## EXAMPLES

The following example uses the **get\_ports** command to get all of the ports beginning with 'mode' and then adds the "CLOCK" port.

```
prompt> set xports [get_ports mode*]
{r:/WORK/top/mode[0] r:/WORK/top/mode[1] r:/WORK/top/mode[2]}
prompt> add_to_collection $xports [get_ports CLOCK]
{r:/WORK/top/mode[0] r:/WORK/top/mode[1] r:/WORK/top/mode[2] r:/WORK/top/CLOCK}
```

The following example adds the cell u1 to a collection containing the SCANOUT port.

```
prompt> set so [get_ports SCANOUT]
{r:/WORK/top/SCANOUT}
prompt> set u1 [get_cells u1]
{r:/WORK/top/u1}
prompt> set het [add_to_collection $so $u1]
{r:/WORK/top/SCANOUT r:/WORK/top/u1}
prompt> query_objects -verbose $het
{{port r:/WORK/top/SCANOUT} {cell r:/WORK/top/u1}}
```

The following examples show how the **add\_to\_collection** command behaves when the base collection is empty. Adding two empty collections yields the empty collection. Adding an implicit list of only strings to the empty collection generates an error message, because no collections are present in the *object\_spec* list. Finally, as long as one collection is present in the *object\_spec* list, the command succeeds, even though a warning message is generated. The example uses the variable settings from the previous example.

```
prompt> sizeof_collection [add_to_collection "" ""]
0

prompt> set A [add_to_collection "" [list a c]]
Error: At least one collection required for argument 'object_spec'
to add_to_collection when the 'collection' argument is empty (SEL-014)

prompt> add_to_collection "" [list a $het $so]
Warning: Ignored all implicit elements in argument 'object_spec'
to add_to_collection because the class of the base collection
could not be determined (SEL-015)
{r:/WORK/top/SCANOUT r:/WORK/top/u1 r:/WORK/top/SCANOUT}
```

---

## SEE ALSO

append\_to\_collection(2)  
collections(2)  
query\_objects(2)  
remove\_from\_collection(2)  
sizeof\_collection(2)

---

## alias

Creates a pseudocommand that expands to a longer command with more words, or lists the current alias definitions.

---

### SYNTAX

**alias**  
[*name*]  
[*def*]

#### Data Types

*name* string  
*def* string

---

### ARGUMENTS

#### *name*

Specifies the name of the alias. The name must begin with a letter, and can contain letters, underscores, and numbers.

#### *def*

Specifies the expansion of the alias. That is, it specifies the replacement text, for the *name* argument.

---

### DESCRIPTION

This command defines or displays command aliases.

When you don't specify any arguments, it displays the currently defined aliases and their expansions. With a single argument, the **alias** command displays the expansion for the given *name*. With more than one argument, an alias is created that is named by the first argument and expanded to the remaining arguments.

You cannot create an alias by using the name of any existing command or procedure. Thus, you cannot use the **alias** command to redefine existing commands.

An alias can refer to another alias.

An alias is expanded only when it is the first word in a command.

---

### EXAMPLES

Although you can abbreviate commands, there could be a conflict with another command. The following example shows how to use an alias to prevent the conflict.

```
prompt> alias q quit  
prompt>
```

The following example shows how to use the **alias** command to create a shortcut for commonly used command invocations.

```
prompt> alias include {source -echo -verbose}  
prompt>
```

After the previous commands, the **include script.Tcl** is replaced with **source -echo -verbose script.Tcl** before the command is interpreted. The following examples show how to display the alias by using the **alias** command. Note that the displayed aliases are in alphabetical order.

```
prompt> alias  
include      source -echo -verbose  
q            quit  
prompt>
```

---

## SEE ALSO

[unalias\(2\)](#)

---

## all\_connected

Returns the objects connected to a net, port, or pin.

---

### SYNTAX

collection **all\_connected**  
[-leaf]  
[-type *type*]  
[*objects*]

#### Data Types

<i>type</i>	string
<i>objects</i>	list

---

### ARGUMENTS

#### -leaf

Specifies that only leaf pins are returned for a hierarchical net. For non-hierarchical nets, there is no difference in output.

#### -type *type*

The type of the *objects*. The type can be net, pin, or port.

#### *objects*

Specified the objects whose connections are returns. The objects must be nets, port, or pins. Objects of other types are ignored.

---

### DESCRIPTION

The **all\_connected** command returns a collection of objects connected to the specified nets, ports, and pins.

If the *-leaf* option is sued, a collection of leaf pins and ports of the nets is returned.

To connect nets to ports or pins, use the **connect\_net** command. TO break connections, use the **disconnect\_net** command.

---

### EXAMPLES

The following example uses **all\_connected** to return the objects connected to **MY\_NET**:

```
prompt> all_connected MY_NET
```

```
# Connecting net 'MY_NET' to port 'OUT3'.
```

```
prompt> connect_net MY_NET OUT3
```

```
# Connecting net 'MY_NET' to pin 'U65/Z'.
```

```
prompt> connect_net MY_NET U65/Z  
  
prompt> all_connected MY_NET  
{r:/WORK/top/OUT3 r:/WORK/top/U65/Z}  
  
prompt> all_connected OUT  
{r:/WORK/top/MY_NET}  
  
prompt> all_connected U65/Z  
{r:/WORK/top/MY_NET}
```

---

## SEE ALSO

- all\_inputs(2)
- all\_outputs(2)
- connect\_net(2)
- create\_net(2)
- current\_design(2)
- disconnect\_net(2)
- remove\_net(2)

---

## all\_fanin

Returns a collection of pins, ports, or cells in the fanin of the specified sinks.

---

### SYNTAX

```
collection all_fanin  
[-type type]  
[-to objects]  
[-only_cells]  
[-flat]
```

#### Data Types

<i>type</i>	string
<i>objects</i>	list

---

### ARGUMENTS

#### -type *type*

The type of the *objects*. The type can be net, pin, port, or cell.

#### -to *objects*

Returns a collection of sink pins and port in the design.

#### -only\_cells

Returns a collection of all cells in the fanin of *objects*, rather than a collection of pins and ports.

#### -flat

Specifies to function in the flat mode of operation. The two major modes in which **all\_fanin** functions are hierarchical (the default) and flat. When in hierarchical mode, only objects from the same hierarchy levels as *objects* are returned.

---

### DESCRIPTION

The **all\_fanin** command returns a collection of the fanin of specified sink objects in the design. The command stops at inputs to logic cones: For example, registers, cut-points, and black-box output pins.

---

### EXAMPLES

The following examples show the fanin of a port in the design. The design comprises three inverters in a chain name *iv1*, *iv2*, and *iv3*. The *iv1* and *iv2* inverters are hierarchically combined in a larger cell named *ii2*.

To make it easier to read, we have omitted the *container:/library/design* from the output below.

```
prompt> all_fanin -to tout  
{tin ii2/hin ii2/hout iv3/in iv3/out tout}
```

```
prompt> all_fanin -to tout -flat  
{tin ii2/iv1/U1/a ii2/iv1/U1/z ii2/iv2/U1/z ii2/iv2/U1/a iv3/U1/a iv3/U1/z tout}
```

---

## SEE ALSO

`all_fanout(2)`



---

## all\_fanout

Returns a collection of pins, ports, or cells in the fanout of the specified sources.

---

### SYNTAX

collection **all\_fanout**  
[-type *type*]  
[-from *objects*]  
[-only\_cells]  
[-flat]

#### Data Types

<i>type</i>	string
<i>objects</i>	list

---

### ARGUMENTS

#### -type *type*

The type of the *objects*. The type can be net, pin, port, or cell.

#### -from *objects*

Returns a collection of source pins and port in the design.

#### -only\_cells

Returns a collection of all cells in the fanout of *objects*, rather than a collection of pins and ports.

#### -flat

Specifies to function in the flat mode of operation. The two major modes in which **all\_fanout** functions are hierarchical (the default) and flat. When in hierarchical mode, only objects from the same hierarchy levels as *objects* are returned.

---

### DESCRIPTION

The **all\_fanout** command returns a collection of the fanout of specified source objects in the design. The command stops at outputs of logic cones: For example, registers, cut-points, and black-box input pins.

---

### EXAMPLES

The following examples show the fanout of a port in the design. The design comprises three inverters in a chain name *iv1*, *iv2*, and *iv3*. The *iv1* and *iv2* inverters are hierarchically combined in a larger cell named *ii2*.

To make it easier to read, we have omitted the *container:/library/design* from the output below.

```
prompt> all_fanout -from tin  
{tin ii2/hin ii2/hout iv3/in iv3/out tout}
```

```
prompt> all_fanout -from tin -flat  
{tin ii2/iv1/U1/a ii2/iv1/U1/z ii2/iv2/U1/z ii2/iv2/U1/a iv3/U1/a iv3/U1/z tout}
```

---

## SEE ALSO

[all\\_fanin\(2\)](#)

---

## all\_inputs

Creates a collection of all input ports in the current design. You can assign these ports to a variable or pass them into another command.

---

### SYNTAX

collection **all\_inputs**

---

### DESCRIPTION

The **all\_inputs** command creates a collection of all input or inout ports in the current design.

If you want only certain ports, use the **get\_ports** command to create a collection of ports matching a specific pattern and optionally passing filter criteria.

When issued from the command prompt, the **all\_inputs** command behaves as though the **query\_objects** command had been called to display the objects in the collection. By default, a maximum of 100 objects is displayed. You can change the number of objects the command displays by using the **collection\_result\_display\_limit** variable.

For information about collections and the querying of objects, see the **collections** man page.

---

### EXAMPLES

The following example sets constant value 0 on all input ports of the current design.

```
prompt> set_constant [all_inputs] 0
Set 'r:/WORK/top/A' to constant 0
Set 'r:/WORK/top/B' to constant 0
Set 'r:/WORK/top/C' to constant 0
```

---

### SEE ALSO

collections(2)  
get\_ports(2)  
query\_objects(2)  
set\_constant(2)  
collection\_result\_display\_limit(3)

---

## all\_outputs

Creates a collection of all output ports in the current design. You can assign these ports to a variable or pass them into another command.

---

### SYNTAX

collection **all\_outputs**

---

### DESCRIPTION

The **all\_outputs** command creates a collection of all output or inout ports in the current design.

If you want only certain ports, use **get\_ports** to create a collection of ports matching a specific pattern and optionally passing filter criteria.

When issued from the command prompt, **all\_outputs** behaves as though **query\_objects** had been called to display the objects in the collection. By default, a maximum of 100 objects is displayed; you can change this maximum using the variable **collection\_result\_display\_limit**.

For information about collections and the querying of objects, see the **collections** man page.

---

### EXAMPLES

The following example sets all output ports of the current design as verify points.

```
prompt> set_verify_points [all_outputs]
Set verify point 'r:/WORK/bot/Z1'
Set verify point 'r:/WORK/bot/Z2'
Set verify point 'r:/WORK/bot/Z3'
```

---

### SEE ALSO

collections(2)  
get\_ports(2)  
query\_objects(2)  
set\_verify\_points(2)  
collection\_result\_display\_limit(3)

---

## all\_registers

Creates a collection of register cells or pins from the current design, relative to the current instance. You can assign the resulting collection to a variable or pass it into another command.

---

### SYNTAX

```
collection all_registers
  [-cells]
  [-data_pins]
  [-clock_pins]
  [-output_pins]
  [-no_hierarchy]
```

---

### ARGUMENTS

#### **-cells**

Creates a collection of register cells (default).

#### **-data\_pins**

Creates a collection of register data pins.

#### **-clock\_pins**

Creates a collection of register clock pins.

#### **-output\_pins**

Creates a collection of register output pins.

#### **-no\_hierarchy**

Only searches the current instance; does not descend the hierarchy.

---

### DESCRIPTION

The **all\_registers** command creates a collection of pins or cells related to registers in the current design, relative to the current instance. The collection contains objects according to the specified content control arguments (**-cells**, **-data\_pins**, etc.).

When issued from the command prompt, **all\_registers** behaves as though **query\_objects** had been called to display the objects in the collection. By default, a maximum of 100 objects is displayed; you can change this maximum using the variable **collection\_result\_display\_limit**.

For information about collections and the querying of objects, see the **collections** man page.

---

## EXAMPLES

This example gets all the register cells in the current design, descending the hierarchy.

```
prompt> current_design top  
prompt> all_registers  
{r:/WORK/top/U1 r:/WORK/top/U2 r:/WORK/top/M1/moltuae_reg r:/WORK/top/M1/B1/R1}
```

This example gets all data pins of all registers in the current design, not descending the hierarchy.

```
prompt> all_registers -data_pins -no_hierarchy  
{r:/WORK/top/U1/Din r:/WORK/top/U1/Enable r:/WORK/top/U2/data r:/WORK/top/U2/load}
```

This example gets all nets connected to all register outputs starting from the current instance.

```
prompt> current_instance M1  
prompt> get_nets -of_objects [all_registers -output_pins]  
{r:/WORK/top/M1/N42 r:/WORK/top/M1/N43 r:/WORK/top/M1/B1/out}
```

---

## SEE ALSO

```
collections(2)  
current_design(2)  
current_instance(2)  
get_cells(2)  
get_nets(2)  
collection_result_display_limit(3)
```

---

## analyze\_cones

Analyze fan-in cones for the specified points.

---

### SYNTAX

```
int analyze_cones  
  [-type type]  
  objects gP | -unverified | -aborted | -failing  
  [-r | -i]  
  [-substring substring]  
  [-max_objects max_objects]  
  [-reduction_factor reduction_factor]  
  [-start_object start_object]  
  -filter filter  
  [-size size]  
  [-percent percent]  
  [-level level]  
  [-depth depth]  
  [-multicone | -summary]  
  [-instance instance]  
  [-path]
```

#### Data Types

```
type string  
substring string  
max_points integer  
reduction_factor integer  
start_seed integer  
filter string  
size integer  
percent integer  
level integer  
instance string
```

---

### ENABLED SHELL MODES

Match Verify

---

### ARGUMENTS

#### -type *ID\_type*

Specifies the object type being analyzed:

- cell
- net
- pin

- port

### **objects**

Analyze the specified list of objects. These can be any design objects and are not restricted to compare points. Specify the list of objects as follows:

{obj1 obj2 ...}

Use wildcard characters to match multiple objects.

### **-unverified**

Analyzes the unverified points reported in the previous verification.

### **-aborted**

Analyzes the aborted points reported in the previous verification.

### **-failing**

Analyzes the failing points reported in the previous verification.

### **-r**

Analyzes the reference design objects. This option can only be used with the **-unverified**, **-aborted**, and **-failing** options.

### **-i**

Analyzes the implementation design objects. This option can only be used with the **-unverified**, **-aborted**, and **-failing** options.

### **-substring *substring***

Analyzes only those objects containing the specified *substring*. This option can only be used with the **-unverified**, **-aborted**, and **-failing** options.

### **-max\_objects *max\_objects***

Stop analysis after *max\_objects* objects are analysed.

### **-reduction\_factor *reduction\_factor***

Analyze only one out of the *reduction\_factor* objects. This option can be used if there are a large number of unverified, aborted, or failing points.

### **-start\_object *start\_object***

Skip the first *start\_object* objects. The option **-reduction\_factor** always selects the same set of objects to analyze. This option can be used to skip the first few objects and hence analyze a different set of objects.

### **-filter *filter***

Specify the subtype of the report generated. Valid *filter* values are:

- datapath
- dontcare
- logic
- pin
- powerdomain
- ungroup

Examples of each of these reports are shown in the examples section.



**-size *size***

Cutoff size for instances in the fan-in cone.

**-percent *percent***

Cutoff percentage for instances in the fanin cone. This option is similar to the **-size** option. The percentage is computed by comparing the instance size to the fan-in cone size.

**-level *level***

Cutoff level for instances in the fan-in cone.

**-depth *depth***

Report only the filter subtype with depth greater than or equal to the specified value.

**-multicone**

Generate a combined report for all the specified objects. This option is only valid for the datapath, dontcare, logic, and pin filters.

**-summary**

Prints out only the cone size of the specified objects. The list of objects are sorted based on the cone size.

**-instance *instance***

Specifies the *instance* whose pins are to be reported. This option is only valid for the filters pin.

**-path**

Prints the complete instance path in the reports.

---

## DESCRIPTION

This command generates statistical information about the fan-in cone of objects in the design. Running this command on hard compare points can give some insight into the logic driving the point. Generating multicone reports can give an idea about the shared logic between hard compare points.

Verification can become hard because of a combination of factors. This command can help identify the following potential causes of hard verification:

- Datapath instances
- Dontcare sources
- Large XOR trees
- Non-isolated powerdomain crossings
- Ungrouped design instances and datapath instances

Many of these hard verifications can be resolved by adding cuts. One of the best places to add cuts is on pins of design instances. The filter pin helps identify pins of design instances in the fan-in cone of a given object.

---

## EXAMPLES

The following example shows a filter logic report:

```
fm_shell (match)> analyze_cones -filter logic
```

```

-percent 20 r:/WORK/bit_coin/bit_secure_9/slice_0/piso_bit/dout_reg
*****
Report      : cone_analysis
            -filter logic
            -percent 20
            r:/WORK/bit_coin/bit_secure_9/slice_0/piso_bit/dout_reg

Reference   : r:/WORK/bit_coin
Implementation : i:/WORK/bit_coin
Version     : N-2017.09
Date       : Tue Jul 18 14:50:42 2017
*****
Analyzing r:/WORK/bit_coin/bit_secure_9/slice_0/piso_bit/dout_reg
Logic  XOR  SEQ  SIZE Percent  Level Instance (Design)
  39    0    5   44 100.00%    1 bit_coin (bit_coin)
  35    0    5   40  90.91%    2 bit_secure_9 (bit_top)
  33    0    5   38  86.36%    3 slice_0 (bit_slice)
  29    0    3   32  72.73%    4 piso_bit (piso)
  14    0    2   16  36.36%    5 dout_reg (UPF_RET_SEQ_AACC_0_0_0_1...)
*****
Analysis Completed

```

The following example shows a multicone filter logic report:

```

fm_shell (match)> analyze_cones -filter logic -size 12
-multicone r:/WORK/bit_coin/bit_secure_1/slice_3*/piso_bit/dout_reg
*****
Report      : cone_analysis
            -filter logic
            -size 12
            -multicone
            r:/WORK/bit_coin/bit_secure_1/slice_3*/piso_bit/dout_reg

Reference   : r:/WORK/bit_coin
Implementation : i:/WORK/bit_coin
Version     : N-2017.09
Date       : Tue Jul 18 14:53:17 2017
*****
Analyzing r:/WORK/bit_coin/bit_secure_1/slice_3/piso_bit/dout_reg
Analyzing r:/WORK/bit_coin/bit_secure_1/slice_30/piso_bit/dout_reg
Analyzing r:/WORK/bit_coin/bit_secure_1/slice_31/piso_bit/dout_reg
Analyzed 3 points
#Points Percent  Level Instance (Design)
  3 100.00%    1 bit_coin (bit_coin)
  3 100.00%    2 bit_secure_1 (bit_top)
  1  33.33%    3 slice_3 (bit_slice)
  1  33.33%    4 piso_bit (piso)
  1  33.33%    5 dout_reg (UPF_RET_SEQ_AACC_0_0_0_1...)
  1  33.33%    3 slice_30 (bit_slice)
  1  33.33%    4 piso_bit (piso)
  1  33.33%    5 dout_reg (UPF_RET_SEQ_AACC_0_0_0_1...)
  1  33.33%    3 slice_31 (bit_slice)
  1  33.33%    4 piso_bit (piso)
  1  33.33%    5 dout_reg (UPF_RET_SEQ_AACC_0_0_0_1...)
*****
Analysis Completed

```

The following example shows a summary report:

```

fm_shell (match)> analyze_cones -filter logic
-summary r:/WORK/bit_coin/bit_secure_1/slice_3*/piso_bit/dout_reg
44 r:/WORK/bit_coin/bit_secure_1/slice_3/piso_bit/dout_reg
44 r:/WORK/bit_coin/bit_secure_1/slice_30/piso_bit/dout_reg
44 r:/WORK/bit_coin/bit_secure_1/slice_31/piso_bit/dout_reg

```

---

## SEE ALSO

`analyze_points(2)`

---

## analyze\_designs

Analyze impl design for specific issues.

---

### SYNTAX

```
int analyze_designs  
-multi_match_feedback do multi_match_feedback analysis on impl design
```

Data Types

---

### ENABLED SHELL MODES

Match Verify

---

### ARGUMENTS

**-multi\_match\_feedback** *specified analysis*

Do multi\_match\_feedback analysis on the IMPL design.

---

### DESCRIPTION

This command does the specified analysis on the IMPL design and produces warning messages if a questionable structure is detected. The analysis types are specified by arguments to this command. Currently the only available analysis is multi\_match\_feedback.

---

### EXAMPLES

```
analyze_designs -multi_match_feedback
```

FM-SG-001: (warning) Formality detected a potential initialization problem on register <reg1> due to its dependence on register <reg2>.

---

### SEE ALSO

FM-SG-001

---

## analyze\_points

Analyzes the previous failed or incomplete verification.

---

### SYNTAX

```
int analyze_points  
  failing_aborted_or_unverified_compare_points |  
  -failing | -aborted | -unverified | -all  
  [-last]  
  [-effort high / low]  
  [-limit limit]  
  [-no_operator_svp]
```

#### Data Types

*failing\_aborted\_or\_unverified\_compare\_points* string  
*limit* integer

---

### ENABLED SHELL MODES

Verify

---

### ARGUMENTS

#### *failing\_aborted\_or\_unverified\_compare\_points*

Analyzes the specified list of failing, aborted, or unverified compare points. Specify the list of compare points as follows:

{cp1 cp2 ...}

Use wildcard characters to match multiple points.

#### **-failing**

Analyzes the failing points reported in the previous verification.

#### **-aborted**

Analyzes the aborted points reported in the previous verification.

#### **-unverified**

Analyzes the unverified points reported in the previous verification.

#### **-all**

Analyzes failing, aborted, and unverified points reported in the previous verification.

#### **-last**

Restricts the analysis to only the points considered in the previous partial verification. A verification is partial when only the compare points specified using the **set\_verify\_points** command are verified. If the previous verification is not a partial verification, this option has no effect.

**-limit *limit***

Specifies the number of failing points to be analyzed. The default is 500. A value of 0 implies no limit.

**-effort *low* / *high***

Specifies the effort level for the analysis engine. The default is *high*.

**-no\_operator\_svp**

Recommends using the Design Compiler **set\_verification\_priority** command with an unquified instance. If an unquified instance is not available, this option recommends using the command on a design, instead of datapath operators.

---

## DESCRIPTION

This command runs a set of heuristic analyses on the previous verification to determine if there are potential causes for failing or hard verification other than logical differences. In the case of a hard verification, the **analyze\_points** command might report a message that recommends using the **set\_verification\_priority** command in Design Compiler to obtain a verifiable result. By default, the **analyze\_points** command recommends using the **set\_verification\_priority** command with datapath operators.

To run the **analyze\_points** command automatically at the end of verification, set the **verification\_run\_analyze\_points** variable to **true**.

To review the results of the most recent analysis, use the **report\_analysis\_results** command. Note that this analysis is not cumulative. The **analyze\_points** command replaces all previous results.

Interrupting the **analyze\_points** command stops processing but retains the partial results that are generated.

---

## EXAMPLES

The following example shows the results of analysis on a design with missing retention behavior in the implementation design.

```
fm_shell (verify)> analyze_points -all
***** Analysis Results *****
Found 1 Undriven Reference Signal
-----
An undriven signal in the reference design may be caused by either
a legitimate 'don't care' condition or an error in the RTL.
If an examination of the RTL finds no unexpected undriven signals
try 'set verification_set_undriven_signals 0:X'
to match synthesis.
-----
r:/WORK/top/b
Undriven in the reference cones for 2 compare point(s):
  r:/WORK/top/U0/R2_reg
  r:/WORK/top/U1/R2_reg
-----
*****
Analysis Completed
```

---

## SEE ALSO

```
report_analysis_results(2)
set_verify_points(2)
verification_run_analyze_points(3)
```

---

## analyze\_upf

Analyze the UPF inserted into the designs using the **load\_upf** command and provide diagnosis report on supply nets and power states

---

### SYNTAX

```
status analyze_upf  
  [-r]  
  [-i]  
  [-container container_name]
```

#### Data Types

*container\_name* string

#### Enabled Shell Modes

Setup  
Match  
Verify

---

### ARGUMENTS

**-r**

Analyze the UPF information of the reference container.

**-i**

Analyze UPF information of the implementation container.

**-container *container\_name***

Analyze UPF information of the specified container.

---

### DESCRIPTION

This command analyzes the UPF information on all containers. It provides information on the following issues in the UPF.

1. Never-On Supplies: Supplies that can never be turned on.
2. Never-true power-state constraints: Power state constraints that can never be true.
3. Mutually exclusive PSTs: Reports when power states cannot be all turned on simultaneously.

---

## EXAMPLES

The following example reports UPF summary information on the reference container.

```
analyze_upf -r
Container: r
-----
Found 1 Supply Net(s) that can never be turned ON
-----
Supply Net r:/WORK/top/VDDA can never be 1 (ON value)
  Set verification_force_upf_supplies_on to false
  Use "verify -constant1 r:/WORK/top/VDDA " to see a failing logic cone for the supply net.
-----

*****
Analysis Completed
1
```

---

## SEE ALSO

load\_upf(2)  
report\_upf(2)



---

## annotate\_trace

Control annotation of traced command execution to the shell output.

---

### SYNTAX

```
annotate_trace [-start|-stop]
                [-profile profile_annotation_type]
                [-log log_string]
                [-quiet]
```

*string log\_string*  
*string profile\_annotation\_type*

---

### ARGUMENTS

#### **-start**

This option is mutually exclusive with -stop. The option starts the annotation of traced command execution to the shell output. Each executed command string is annotated to the output prepended with ";;# ".

#### **-stop**

This option is mutually exclusive with -start. This option stops annotation of traced command execution to the shell output.

#### **-profile *profile\_annotation\_type***

This option selects the profile data output behavior for command annotation. This option is only meaningful when given with the -start option. The argument is one of: on, with\_start, off. The /flon/fP value starts annotation with profile data output enabled in the default mode which is to output the data only at the end of a command invocation. The data is output only if the delta values from the beginning of the command invocation meet or exceed the thresholds set for each of the reported metrics. The /flwith\_start/fP value starts annotation with profile data output both at the beginning and at the end of a command invocation. The profile data is output at the beginning regardless of any thresholds since delta values cannot be calculated at the beginning of the invocation. The profile data output at the end of command invocation is controlled by thresholds. The /floff/fP value disables profile data output. If profile data annotation is enabled but profile metric gathering has not been enabled with set\_trace\_option, all profile metrics are auto-enabled. If omitted, annotation is started without profile data output.

#### **-log *log\_string***

This option outputs the given log\_string to the shell output prepended with ";;# ". If the given string contains newline characters, each line is prepended with ";;# ".

#### **-quiet**

If given, this option causes the command to ignore error conditions such as an attempt to log a comment string before annotation is started. The command will exit quietly when it encounters an error condition.

---

### DESCRIPTION

The **annotate\_trace** command performs operations related to annotating traced command execution to the shell output. If the

application creates an output log, the annotation is made also to the output log. The command strings which are annotated to the output are those that are traced for creating a traced command replay log.

The **annotate\_trace** with no options will report on the current status of annotation: on or off.

---

## EXAMPLES

The following example starts annotation of executed commands to the output. Then the command is invoked again with no options to report on the status.

```
prompt> annoate_trace -start
prompt> annoate_trace
on
```

The following example configures profile metrids, then starts annotation of executed commands to the output along with the profile data.

```
prompt> set_trace_topion -profile all
prompt> set_trace_topion -memory_threshold 10
prompt> set_trace_topion -cpu_threshold 0
prompt> annotate_trace -start -profile with_start
```

---

## SEE ALSO

set\_trace\_option(2)  
get\_trace\_option(2)  
log\_trace(2)

---

## append\_eco\_data

Adds manual ECO SVF file to the ECO database.

---

### SYNTAX

```
status append_eco_data
  -svf file ]
  [ -name name ]
  [ -replace ]
  [ frd_name ]
```

#### Data Types

*file* string  
*name* string  
*frd\_name* string

---

### ARGUMENTS

#### **-svf *file***

SVF file to package.

#### **-name *name***

Specifies an optional name for the ECO. The default name is "ECO<n>".

#### **-replace**

Overwrites output files if they already exist.

#### ***frd\_name***

If not specified, the generated output FRD file follow the naming convention set via match\_eco\_regions. If the specified name is a valid directory then the output file will be saved inside the specified directory. Otherwise the specified name will be used to generate the output FRD file.

#### Enabled Shell Modes

Verify

---

### LICENSE

This command is available when the "Formality-LogicECO" license key is used.

---

## DESCRIPTION

This command adds the manual ECO SVF file to the FM-ECO database. This command can be issued only in verify mode after confirming the successful verification of manual ECO patch in Formality. It's an error to run this command without setting previous incremental ECO database. The newly created ECO database(FRD file) includes the previous ECO database files and the manual ECO SVF file.

---

## SEE ALSO

set\_eco\_data  
report\_eco\_data  
write\_eco\_regions

---

## append\_to\_collection

Adds objects to a collection and modifies a variable.

---

### SYNTAX

```
collection append_to_collection
[-unique]
var_name
object_spec
```

#### Data Types

<i>var_name</i>	collection
<i>object_spec</i>	list

---

### ARGUMENTS

#### -unique

Indicates that duplicate objects are to be removed from the resulting collection. By default, duplicate objects are not removed.

#### *var\_name*

Specifies a variable name. The objects matching *object\_spec* are added into the collection referenced by this variable.

#### *object\_spec*

Specifies a list of named objects or collections to add.

---

### DESCRIPTION

The **append\_to\_collection** command allows you to add elements to a collection. This command treats the variable name given by the *var\_name* option as a collection, and it appends all of the elements in *object\_spec* to that collection. If the variable does not exist, it is created as a collection with elements from the *object\_spec* as its value. If the variable does exist and it does not contain a collection, it is an error.

The result of the command is the collection that was initially referenced by the *var\_name* option, or the collection created if the variable did not exist.

The **append\_to\_collection** command provides the same semantics as the common use of the **add\_to\_collection** command; however, this command shows significant improvements in performance.

An example of replacing the **add\_to\_collection** command with the **append\_to\_collection** command is provided below. For example,

```
set var_name [add_to_collection $var_name $objs]
```

Using the **append\_to\_collection** command, the command becomes:

```
append_to_collection var_name $objs
```

The **append\_to\_collection** command can be much more efficient than the **add\_to\_collection** command if you are building up a collection in a loop. The arguments of the command have the same restrictions as the **add\_to\_collection** command. For more information about these restrictions, see the **add\_to\_collection** man page.

---

## EXAMPLES

The following example shows how a collection can be built up using the **append\_to\_collection** command:

```
prompt> set xports
Error: can't read "xports": no such variable
      Use error_info for more info. (CMD-013)
prompt> append_to_collection xports [get_ports in*]
{r:/WORK/top/in0 r:/WORK/top/in1 r:/WORK/top/in2}
prompt> append_to_collection xports CLOCK
{r:/WORK/top/in0 r:/WORK/top/in1 r:/WORK/top/in2 r:/WORK/top/CLOCK}
```

---

## SEE ALSO

`add_to_collection(2)`  
`foreach_in_collection(2)`  
`index_collection(2)`  
`remove_from_collection(2)`  
`sizeof_collection(2)`

---

## apply\_edits

Copies the edited designs back to the original designs.

---

### SYNTAX

**apply\_edits**

**Enabled Shell Modes**

Setup

---

### DESCRIPTION

This command copies all the edited designs created by the **edit\_design** command back to the original designs.

The **verify\_edits** command implicitly applies the edits. While **apply\_edits** can only be used in setup mode, the **verify\_edits** commands can be used in match or verify modes.

---

### EXAMPLES

Edit a design while in verify mode, revert to setup mode, and copy the changes back:

```
fm_shell (verify)> edit_design i:/WORK/bot
fm_shell (verify)> create_net ECO_NET_1
fm_shell (verify)> setup
fm_shell (setup)> apply_edits
```

---

### SEE ALSO

create\_net(2)  
discard\_edits(2)  
edit\_designs(2)  
verify\_edits(2)

---

## apropos

Searches the command database for a pattern.

---

### SYNTAX

```
string apropos
  [-symbols_only]
  pattern
```

#### Data Types

*pattern*    string

---

### ARGUMENTS

#### -symbols\_only

Searches only command and option names.

#### *pattern*

Searches for the specified *pattern*.

---

### DESCRIPTION

The **apropos** command searches the command and option database for all commands that contain the specified *pattern*. The *pattern* argument can include the wildcard characters asterisk (\*) and question mark (?). The search is case-sensitive. For each command that matches the search criteria, the command help is printed as though **help -verbose** was used with the command.

Whereas **help** looks only at command names, **apropos** looks at command names, the command one-line description, option names, and option value-help strings. The search can be restricted to only command and option names with the **-symbols\_only** option.

When searching for dash options, do not include the leading dash. Search only for the name.

---

### EXAMPLES

In the following example, assume that the **get\_cells** and **get\_designs** commands have the **-exact** option. Note that without the **-symbols\_only** option, the first search picks up commands which have the string "exact" in the one-line description.

```
prompt> apropos exact
get_cells      # Create a collection of cells
[-exact]      (Wildcards are considered as plain characters)
patterns      (Match cell names against patterns)

get_designs    # Create a collection of designs
[-exact]      (Wildcards are considered as plain characters)
patterns      (Match design names against patterns)
```



```
real_time      # Return the exact time of day

prompt> apropos exact -symbols_only
get_cells      # Create a collection of cells
[-exact]       (Wildcards are considered as plain characters)
patterns       (Match cell names against patterns)

get_designs     # Create a collection of designs
[-exact]       (Wildcards are considered as plain characters)
patterns       (Match design names against patterns)
```

---

## SEE ALSO

help(2)

---

## change\_link

Changes the design to which a cell is linked.

---

### SYNTAX

```
status change_link  
  cell_list  
  design_name  
  [ -force ]  
  [ -pin_map pin_map_list ]
```

#### Data Types

*cell\_list* list

*design\_name* string

*pin\_map\_list* list

---

### RETURN VALUE

The **change\_link** command returns a status of 1 if it was successful and 0 if it failed.

---

### ARGUMENTS

#### ***cell\_list***

Specifies the cells for which the link is to be changed. You can specify either object IDs or instance-based paths. The specified cells must belong to the same container.

#### ***design\_name***

Specifies the name of the design to link to the cells specified using the *cell\_list*. You can specify an objectID or just a design name. In the latter case, the libraries in the container of the *cell\_list* cells are searched, and if a unique design is found, it will be used.

#### ***-force***

Relaxes the restriction that the new design must have exactly the same ports (same name and direction) as the pins on the cells. With this option, the new design is allowed to have extra ports.

#### ***-pin\_map pin\_map\_list***

Specifies the pin mapping used to map old pin names to new pin names. The old names must match the current pin names of the cell. The new names must match the current port names of the new design for the cell.

To specify the pin mapping, use the following syntax:

```
{{old_pin1 new_pin1}} ... {{old_pin_n new_pin_n}}
```

New pins maintain the same net connections as the corresponding old pins.

---

## DESCRIPTION

This command changes the design to which cells are linked. The new design must be compatible with the cells by having the same number of ports with the same name and direction as the pins on the cells.

Outside of Setup mode, this command only works on edit designs created using the **edit\_design** command.

---

## EXAMPLES

The following example shows how to change the design linked to be cell b1 in the design r:/WORK/mid to r:/WORK/alt\_bot.

```
fm_shell (setup)> current_design r:/WORK/mid  
fm_shell (setup)> change_link b1 r:/WORK/alt_bot
```

If the new design name is unique across all libraries, you do not have to specify a container and a library.

```
fm_shell (setup)> current_instance i:/WORK/tile1/cpu2/core3  
fm_shell (setup)> change_link cell1 AND2S4
```

A cell has pins 'a', 'b', and 'z'. To change the underlying design of the cell to one with ports named 'A', 'B', and 'Z', use the following command:

```
fm_shell (setup)> change_link r:/WORK/top/and2 r:/GTECH/GTECH_AND2 -pin_map {{a A} {b B} {z Z}}
```

---

## SEE ALSO

[current\\_design\(2\)](#)  
[current\\_instance\(2\)](#)  
[edit\\_design\(2\)](#)

---

## check\_dpx\_options

Checks `set_dpx_options` is working properly in your environment.

---

### SYNTAX

status **check\_dpx\_options**

---

### LICENSE

This command is available when the "Formality-DPX" license key is used.

---

### DESCRIPTION

This command tests that the options to the `set_dpx_options` command are set properly for your specific environment such that DPX workers can be successfully obtained.

The command launches a single worker process utilizing options user has specified for the `set_dpx_options` command. This worker process only informs the manager process (the `fm_shell` the user interacts with) that it is alive and then exits.

You should use this command to test your `set_dpx_options` settings whenever performing a distributed processing run for the first time in new environment. If this command does not complete successfully, do not use the given `set_dpx_option` options to attempt a full distributed verification run for it will not work. In this case, determine the reason for the failure and adjust the options specified for `set_dpx_options`, or run without distributed processing enabled.

---

### EXAMPLES

The following examples illustrate the command after the `set_dpx_options` command has been issued:

```
fm_shell (setup)> set_dpx_options -protocol SH -submit_command sh -max_workers 4 -max_cores 2
fm_shell (setup)> check_dpx_options
Error: Failed to procure license for DPX verification
fm_shell (setup)>
```

```
fm_shell (setup)> set_dpx_options -protocol SGE -submit_command "qsub -invalidOpt -P batch -pe mt 4 -l mem_free=150G" -max_workers 2 -max_cores 4
fm_shell (setup)> check_dpx_options
Info: License check for DPX verification successful.
Adding Host "SGE"
Info: Starting 1 worker. Each worker can process 4 tasks at a time.
Starting DPX worker: /path/FM_DPX_WORK/crew/C1
Checking for live worker...
Error: Failed to submit command on grid.
From file 'master.fmintel13.28821.err':
qsub: ERROR! invalid option argument "-invalidOpt"
.
fm_shell (setup)>
```

```
fm_shell (setup)> set_dpx_options -protocol SGE -submit_command "qsub -P batch -pe mt 4 -l mem_free=150G" -max_workers 2 -max_cores 4
fm_shell (setup)> check_dpx_options
Info: License check for DPX verification successful.
Adding Host "SGE"
Info: Starting 1 worker. Each worker can process 4 tasks at a time.
Starting DPX worker: /path/FM_DPX_WORK/crew/C2
Checking for live worker...
.....
No live worker seen in the past 2 minutes
.....
No live worker seen in the past 4 minutes
.....
Info: 1 live worker detected.
Stopping DPX worker
set_dpx_options is working properly in your environment
fm_shell (setup)>
```

---

## SEE ALSO

```
set_dpx_options(2)
report_dpx_options(2)
remove_dpx_options(2)
```

---

## check\_license

Checks the availability of a license for a feature.

---

### SYNTAX

status **check\_license**  
*feature\_list*

#### Data Types

*feature\_list* list

---

### ARGUMENTS

#### *feature\_list*

Specifies the list of features to be checked. The *feature\_list* argument might consist of a single value or a space-delimited list of values enclosed within braces ({}).

By looking at your key file, you can determine all of the features licensed at your site.

---

### RETURN VALUE

The **check\_license** command returns a status of 1 if it was successful and 0 if it failed.

---

### DESCRIPTION

This command checks on a license for each of the specified features. It checks on the authorization (existence) of a license, however, it does not check out any licenses.

The list\_licenses command provides a list of the features that you are currently using.

---

### EXAMPLES

The following example checks on a Formality license:

```
fm_shell (setup)> check_license { Formality }
```

---

## SEE ALSO

license\_users(2)  
list\_licenses(2)  
get\_license(2)  
remove\_license(2)

---

## check\_script

Statically check a script using the a static Tcl syntax checker based on TclPro Procheck and the Synopsys checking extensions for this tool.

---

### SYNTAX

```
string snpsTclPro::check_script [-no_tclchecker_warning]
    [-quiet]
    [-onepass]
    [-verbose]
    [-suppress messageID]
    [-application appName]
    [-W1]
    [-W2]
    [-W3]
    [-Wall]
    filePattern

string messageID
string appName
string filePattern
```

---

### ARGUMENTS

#### **-no\_tclchecker\_warning**

Don't warn that TclDevKit cannot be found

#### **-quiet**

prints minimal error information

#### **-onepass**

perform a single pass without checking proc args

#### **-verbose**

prints summary information

#### **-suppress *messageIDs***

prevent given messageIDs from being printed

#### **-application *appName***

Check script against application other than this one

#### **-W1**

print only error messages

#### **-W2**

print only error and usage warnings



**-W3**

print all errors and warnings

**-Wall**

print all types of messages (same as W3)

***filePattern***

file(s) to be checked

---

## USING THE PACKAGE

The **check\_script** command is in the snpsTclPro Tcl package, and all of the commands in this package are defined in the namespace snpsTclPro. The way to use this command is to load the package, which will import the commands it exports into the global namespace. This is shown below.

```
shell> package require snpsTclPro
1.0
```

These commands can be added to the .synopsys setup file for the system, user, or current directory, or the commands can be typed when the package is needed.

---

## DESCRIPTION

The **check\_script** command simplifies running the TclDevKit tclchecker program. This application is available for purchase from ActiveState (<http://www.activestate.com>). If the TclDevKit is not available then there is a limited Synopsys Tcl syntax checker that is used by this command. The Synopsys version of this code does not understand Tcl8.4 constructs, and some other checking is limited.

These checkers will check builtin Tcl commands, as well as the Synopsys extension commands which are found in the script. **check\_script** will locate the Synopsys checking extensions for the application and will then invoke the checker. The limited checker does not require any external license. It is part of the Synopsys installation.

The **check\_script** command will raise a Tcl error if the checker detects errors in the scripts being checked.

The **check\_script** command is provided as a convenience to streamline the use of the syntax checker within Synopsys applications. The checker can also be called directly on scripts, without requiring a license for the Synopsys application whose script is being checked. This checker script is available in the auxx/tcllib/bin/check\_script in the installation directory of your application. When run standalone the -application option must be specified.

### Synopsys Checker Extensions

The Synopsys extensions to the TclPro checker define a number of new warnings and errors. These messages are listed below, along with a short explanation of them.

Error **MisVal**

An option to a command which requires a value is missing its value.

Error **MisReq**

A required option or argument was not specified.

Error **Excl**

Two options which are mutually exclusive were both specified.

Error **ExtraPos**

An extra positional argument was specified to a command.

Error **BadRange**

The value specified for a given argument was outside of the legal range.

Error **UnkCmd**

The command specified is not known by the application.

Error **UnkOpt**

The specified option is not legal for the command.

Error **AmbOpt**

The option specified is not complete and matches 2 or more options for the command.

Warning **NotLit**

This warning indicates that the argument specified to an option was not a literal and therefore could not be checked. This message is suppressed by default. It can be enabled by setting the environment variable SNPS\_TCL\_NOLITERALWAN to true.

Warning **DupIgn**

An option was specified multiple times to the command, and the first value specified will be the one used. The other values will be ignored.

Warning **DupOver**

An option was specified multiple times to the command, and the last value specified will be the one used. The other values will be ignored.

---

## EXAMPLES

```
shell> check_script myscript.tcl

Loading snps_tcl.pcx...
Loading coreConsultant.pcx...
scanning: /u/user1/myscript.tcl
checking: /u/user1/myscript.tcl
test.tcl:3 (warnVarRef) variable reference used where variable name expected
set $a $b
^
test.tcl:5 (SnpsE-MisReq) Missing required positional options for foreach_in_collection: body
foreach_in_collection x {
}
^
test.tcl:9 (SnpsE-BadRange) Value -1 for 'index_collection index' must be >= 0
index_collection $a -1
child process exited abnormally
Error: Errors found in script.
    Use error_info for more info. (CMD-013)

shell> check_script -Wall anotherScript.tcl

Loading snps_tcl.pcx...
scanning: /u/user1/anotherScript.tcl
checking: /u/user1/anotherScript.tcl
```

---

## CAVEATS

The Synopsys extension messages cannot be suppressed.

Aliases and abbreviated commands will be flagged as undefined procedures.

---

## SEE ALSO

`debug_script(2)`  
`package(2)`  
`namespace(2)`

---

## collections

Describes the methodology for creating collections of objects and querying objects in the database.

---

### DESCRIPTION

Synopsys applications build an internal database of objects and attributes applied to them. These databases consist of several classes of objects, including libraries, lib\_cells, lib\_pins, designs, ports, cells, pins, and nets. Most commands operate on these objects.

By definition:

A collection is a group of objects exported to the Tcl user interface.

Collections have an internal representation (the objects) and, sometimes, a string representation. The string representation is generally used only for error messages.

A set of commands to create and manipulate collections is provided as an integral part of the user interface. The collection commands encompass two categories: those that create collections of objects for use by another command, and one that queries objects for viewing. The result of a command that creates a collection is a Tcl object that can be passed along to another command. For a query command, although the visible output looks like a list of objects (a list of object names is displayed), the result is an empty string.

An empty string "" is equivalent to the empty collection, that is, a collection with zero elements.

To illustrate the usage of the common collection commands, the man pages have examples.

#### Homogeneous and Heterogeneous Collections

A homogeneous collection contains only one type of object. A heterogeneous collection can contain more than one type of object. Commands that accept collections as arguments can accept either type of collection.

#### Lifetime of a Collection

Collections are active only as long as they are referenced. Typically, a collection is referenced when a variable is set to the result of a command that creates it or when it is passed as an argument to a command or a procedure. For example, you can save a collection of design ports by setting a variable to the result of the **get\_ports** command:

```
prompt> set ports [get_ports *]
```

Next, either of the following two commands deletes the collection referenced by the *ports* variable:

```
prompt> unset ports
prompt> set ports "value"
```

Collections can be implicitly deleted when they go out of scope. Collections go out of scope for various reasons. An example would be when the parent (or other antecedent) of the objects within the collection is deleted. For example, if our collection of ports is owned by a design, it is implicitly deleted when the design that owns the ports is deleted. When a collection is implicitly deleted, the variable that referenced the collection still holds a string representation of the collection. However, this value is useless because the collection is gone, as illustrated in the following example:

```
prompt> current_design
r:/WORK/top
```

```
prompt> set ports [get_ports in*]
{r:/WORK/top/in0 r:/WORK/top/in1}
```

```
prompt> remove_design top
Removing design top
```

```
prompt> query_objects $ports
```

Error: No such collection '\_sel26' (SEL-001)

## Iteration

To iterate over the objects in a collection, use the **foreach\_in\_collection** command. You cannot use the Tcl-supplied **foreach** iterator to iterate over the objects in a collection, because the **foreach** command requires a list, and a collection is not a list. In fact, if you use the **foreach** command on a collection, it destroys the collection.

The arguments of the **foreach\_in\_collection** command are similar to those of **foreach**: an iterator variable, the collection over which to iterate, and the script to apply at each iteration. Note that unlike the **foreach** command, the **foreach\_in\_collection** command does not accept a list of iterator variables.

The following example is an iterative way to perform a query. For more information, see the **foreach\_in\_collection** man page.

```
prompt> \
foreach_in_collection s1 $collection {
  echo [get_attribute $s1 name]
}
```

## Manipulating Collections

A variety of commands are provided to manipulate collections. In some cases, a particular command might not operate on a collection of a specific type. This is application-specific. Consult the man pages from your application.

- **add\_to\_collection** - This command creates a new collection by adding a list of element names or collections to a base collection. The base collection can be the empty collection. The result is a new collection. In addition, the **add\_to\_collection** command allows you to remove duplicate objects from the collection by using the *-unique* option.
- **append\_to\_collection** - This command appends a set of objects (specified by name or collection) to an existing collection. The base collection is passed in through a variable name, and the base collection is modified directly. It is similar in function to the **add\_to\_collection** command, except that it modifies the collection in place; therefore, it is much faster than the **add\_to\_collection** command when appending.
- **remove\_from\_collection** - This command removes a list of element names or collections from an existing collection. The second argument is the specification of the objects to remove and the first argument is the collection to have them removed from. The result of the command is a new collection. For example:

```
prompt> set dports [remove_from_collection [all_inputs] CLK]
{r:/WORK/top/in1 r:/WORK/top/in2 r:/WORK/top/in3}
```

- **compare\_collections** - This command verifies that two collections contain the same objects (optionally, in the same order). The result is "0" on success.
- **copy\_collection** - This command creates a new collection containing the same objects in the same order as a given collection. Not all collections can be copied.
- **index\_collection** - This command extracts a single object from a collection and creates a new collection containing that object. The index operation is done in constant time - it is independent of the number of elements in the collection, or the specific index. Not all collections can be indexed.
- **sizeof\_collection** - This command returns the number of objects in a collection.

## Filtering

In some applications, you can filter any collection by using the **filter\_collection** command. This command takes a base collection and creates a new collection that includes only those objects that match an expression.

Some applications provide a *-filter* option for their commands that create collections. This allows objects to be filtered out before they are ever included in the collection. Frequently this is more efficient than filtering after the they are included in the collection. The following examples from Formality list all techlib cells:

```
prompt> filter_collection \
[get_cells -hierarchical] {is_techlib == true}
{r:/WORK/top/U1 r:/WORK/top/M1/U2}
prompt> get_cells -hierarchical -filter {is_techlib==true}
{r:/WORK/top/U1 r:/WORK/top/M1/U2}
```

The basic form of a filter expression is a series of relations joined together with AND and OR operators. Parentheses are also supported. The basic relation contrasts an attribute name with a value through a relational operator. In the previous example,

*is\_hierarchical* is the attribute, *==* is the relational operator, and *true* is the value.

The relational operators are

```

== Equal
!= Not equal
> Greater than
< Less than
>= Greater than or equal to
<= Less than or equal to
~= Matches pattern
!~ Does not match pattern

```

The basic relational rules are

- String attributes can be compared with any operator.
- Numeric attributes cannot be compared with pattern match operators.
- Boolean attributes can be compared only with *==* and *!=*. The value can be only true or false.

Additionally, existence relations determine if an attribute is defined or not defined, for the object. For example, in PrimeTime:

```
(sense == setup_clk_rise) and defined(sdf_cond)
```

The existence operators are

```

defined
undefined

```

These operators apply to any attribute as long as it is valid for the object class. See the appropriate man pages for complete details.

## Sorting Collections

In some applications, you can sort a collection by using the **sort\_collection** command. It takes a base collection and a list of attributes as sort keys. The result is a copy of the base collection sorted by the given keys. Sorting is ascending, by default, or descending when you specify the *-descending* option. In the following example, the command sorts the ports by direction and then by full name.

```

prompt> sort_collection [get_ports *] \
{direction full_name}
{r:/WORK/top/in1 r:/WORK/top/in2 r:/WORK/top/out1 r:/WORK/top/out2}

```

## Implicit Query of Collections

In many applications, commands that create collections implicitly query the collection when the command is used at the command line. Consider the following examples:

```

prompt> set_constant [get_ports scan_en*] 0
Set 'r:/WORK/top/scan_en' to constant 0
Set 'r:/WORK/top/scan_en_1' to constant 0
Set 'r:/WORK/top/scan_en_2' to constant 0
prompt> get_ports in*
{r:/WORK/top/in0 r:/WORK/top/in1 r:/WORK/top/in2}
prompt> query_objects -verbose [get_ports in*]
{{port r:/WORK/top/in0} {port r:/WORK/top/in1} {port r:/WORK/top/in2}}
prompt> set_inports [get_ports in*]
{r:/WORK/top/in0 r:/WORK/top/in1 r:/WORK/top/in2}

```

In the first example, the **get\_ports** command creates a collection of ports that is passed to the **set\_constant** command. This collection is not the result of the primary command (**set\_constant**), and as soon as the primary command completes, the collection is destroyed. The second example shows how a command that creates a collection automatically queries the collection when that command is used as a primary command. The third example shows the verbose feature of the **query\_objects** command, which is not available with an implicit query. Finally, the fourth example sets the variable **inports** to the result of the **get\_ports** command. Only in the final example does the collection persist to future commands until **inports** is overwritten, unset, or goes out of scope.

---

## SEE ALSO

`add_to_collection(2)`  
`append_to_collection(2)`  
`compare_collections(2)`  
`copy_collection(2)`  
`filter_collection(2)`  
`foreach_in_collection(2)`  
`get_attribute(2)`  
`index_collection(2)`  
`query_objects(2)`  
`remove_from_collection(2)`  
`sizeof_collection(2)`  
`sort_collection(2)`

---

## commit\_edits

Commits the changes made by edit commands in the current session.

---

### SYNTAX

status **commit\_edits**

---

### DESCRIPTION

This command commits the changes made to the circuit by edit commands. It also removes the backup libraries containing the unedited designs.

A design is edited when you run the edit commands. Committing the edits does not change the functionality of the circuit. However, committing the edits sets a check-point for future **undo\_edits** commands.

By default, the tool commits edits before performing operations that make changes to the circuit. An example of this is processing SVF.

Before committing the edits, you can review them using the **compare\_edits** command. You can also highlight the edits in the GUI by selecting the **Color Edits** option in the **ECO** menu. For more information about editing a design, see the *Formality User Guide*.

---

### EXAMPLES

The following example creates a new net N1 in design r:/WORK/mid, commits the edit, creates a new N2, and reverts the change again.

```
fm_shell (setup)> current_design r:/WORK/mid
fm_shell (setup)> create_net N1
fm_shell (setup)> commit_edits
fm_shell (setup)> create_net N2
fm_shell (setup)> undo_edits
```

---

### SEE ALSO

[create\\_net\(2\)](#)  
[current\\_design\(2\)](#)  
[edit\\_design\(2\)](#)  
[undo\\_edits\(2\)](#)



---

## compare\_collections

Compares the contents of two collections. If the same objects are in both collections, the result is "0" (like string compare). If they are different, the result is nonzero. The order of the objects can optionally be considered.

---

### SYNTAX

```
int compare_collections  
  [-order_dependent]  
  collection1  
  collection2
```

#### Data Types

<i>collection1</i>	collection
<i>collection2</i>	collection

---

### ARGUMENTS

#### -order\_dependent

Indicates that the order of the objects is to be considered; that is, the collections are considered to be different if the objects are ordered differently.

#### *collection1*

Specifies the base collection for the comparison. The empty string (the empty collection) is a legal value for the *collection1* argument.

#### *collection2*

Specifies the collection with which to compare to *collection1*. The empty string (the empty collection) is a legal value for the *collection2* argument.

---

### DESCRIPTION

The **compare\_collections** command is used to compare the contents of two collections. By default, the order of the objects does not matter, so that a collection of cells u1 and u2 is the same as a collection of the cells u2 and u1. By using the **-order\_dependent** option, the order of the objects is considered.

Either or both of the collections can be the empty string (the empty collection). If two empty collections are compared, the comparison succeeds (that is, **compare\_collections** considers them identical), and the result is "0".

---

### EXAMPLES

The following example shows a variety of comparisons. Note that a result of "0" from **compare\_collections** indicates success. Any

other result indicates failure.

```
prompt> compare_collections [get_cells *] [get_cells *]
0
prompt> set c1 [get_cells {u1 u2}]
{r:/WORK/top/u1 r:/WORK/top/u2}
prompt> set c2 [get_cells {u2 u1}]
{r:/WORK/top/u2 r:/WORK/top/u1}
prompt> set c3 [get_cells {u2 u4 u6}]
{r:/WORK/top/u2 r:/WORK/top/u4 r:/WORK/top/u6}
prompt> compare_collections $c1 $c2
0
prompt> compare_collections $c1 $c2 -order_dependent
-1
prompt> compare_collections $c1 $c3
-1
```

The following example builds on the previous example by showing how empty collections are compared.

```
prompt> set c4 ""
prompt> compare_collections $c1 $c4
-1
prompt> compare_collections $c4 $c4
0
```

---

## SEE ALSO

[collections\(2\)](#)

---

## compare\_edits

Identifies the edits to a design and compares them with the backup copy of the design.

---

### SYNTAX

```
status compare_edits  
[ -list ]
```

#### Enabled Shell Modes

Setup  
Match  
Verify

---

### ARGUMENTS

***-list***

Reports the edits as a Tcl list. You can use this list in further Tcl processing.

---

### RETURN VALUE

By default, the **compare\_edits** command returns a status of 1.

When you specify the *-list* option, the command returns a Tcl list. At the outermost level, the list contains alternating keys and values. The keys are the strings "added", "removed", and "changed". The corresponding values are lists encoding the added, removed, and changed objects. These value are lists on the form of alternating keys and values. Here the keys are element types ("pin", "port", "net", and "cell"), and the associated values are lists of elements of those types.

When the lists of elements are empty, the following is the Tcl list that the command returns:

```
added {pin {} port {} net {} cell {}}  
removed {pin {} port {} net {} cell {}}  
changed {pin {} port {} net {} cell {}}
```

---

### DESCRIPTION

This command is used to determine the parts of a netlist that are affected by edit commands such as **create\_net** and **disconnect\_net**.

The **compare\_edits** command considers uncommitted edits; edits that are not yet committed using \ the **commit\_edits** command.

The **compare\_edits** command reports the pins, ports, nets, and cells that are either added, removed, or changed. Added elements

are reported as objects in the design libraries (normally WORK). Removed elements are reported as objects in the backup libraries (normally FM\_BACKUP\_WORK). Changed elements are reported as objects from both types of libraries.

You can also use the **compare\_edits** functionality in the GUI from the **ECO** menu.

---

## EXAMPLES

The following example shows how to use the **compare\_edits** command.

```
fm_shell (setup)> compare_edits
ADDED elements:
  NETS
    i:/WORK/bot/new

REMOVED elements:
  PINS
    i:/FM_BACKUP_WORK/mid/b1/bo1
    i:/FM_BACKUP_WORK/mid/b2/bo1

  PORTS
    i:/FM_BACKUP_WORK/bot/bo1

CHANGED elements:
  NETS
    i:/FM_BACKUP_WORK/bot/bo1
    i:/FM_BACKUP_WORK/mid/mo1
    i:/FM_BACKUP_WORK/mid/mo2
    i:/WORK/bot/bo1
    i:/WORK/mid/mo1
    i:/WORK/mid/mo2

  CELLS
    i:/FM_BACKUP_WORK/mid/b1
    i:/FM_BACKUP_WORK/mid/b2
    i:/WORK/mid/b1
    i:/WORK/mid/b2
```

When you use the **-list** option, the are reported in a Tcl list.

```
fm_shell (setup)> compare_edits -list
added {pin {} port {} net { i:/WORK/bot/new } cell { }}
removed {pin { i:/FM_BACKUP_WORK/mid/b1/bo1 i:/FM_BACKUP_WORK/mid/b2/bo1 }
  port { i:/FM_BACKUP_WORK/bot/bo1 } net {} cell { }}
changed {pin {} port {}
  net { i:/FM_BACKUP_WORK/bot/bo1 i:/FM_BACKUP_WORK/mid/mo1 i:/FM_BACKUP_WORK/mid/mo2
    i:/WORK/bot/bo1 i:/WORK/mid/mo1 i:/WORK/mid/mo2 }
  cell { i:/FM_BACKUP_WORK/mid/b1 i:/FM_BACKUP_WORK/mid/b2 i:/WORK/mid/b1 i:/WORK/mid/b2 }}
```

---

## SEE ALSO

create\_net(2)  
 disconnect\_net(2)  
 commit\_edits(2)

## compare\_lp

Perform static low power comparison checks between the reference and implementation designs.

### SYNTAX

status **compare\_lp**

### DESCRIPTION

This command can be run after the **match** command when variable **verification\_static\_low\_power\_compare** was set to true before any design data is read.

It will run the static low power comparison checks between the reference and implementation and report any differences as UPF DIFF violations. These violation will be added to a VCLP violations database and can be reported and debugged using the VCLP GUI or using the **report\_lp** command in either Formality or VCLP. It is not required to run this command separately because when the variable **verification\_static\_low\_power\_compare** is *true* it will be run automatically at the beginning of the **verify** command.

### EXAMPLES

Example output of the **compare\_lp** results which shows the Supply Connection Check Summary and the Management and Tree Summary. The Management Summary and the Tree Summary includes the DIFF violations for the MACRO and sequential (register/latch) supply connection checks.

#### Supply Connection Check Summary

Result	SEQs	MACROs
Passed	45	0
Failed	1	1
UnMatched	17	0
Total	62	1

Status: Compare LP...  
vc\_static\_shell>

#### Management Summary

Stage	Family	Errors	Warnings	Infos
UPF	UpfDiff	0	5	0
Total		0	5	0

#### Tree Summary

Severity	Stage	Tag	Count
----------	-------	-----	-------

warning	UPF	DIFF_ISO_APPLIES	1
warning	UPF	DIFF_ISO_ELEMENT	1
warning	UPF	DIFF_MACRO_SUPPLY	1
warning	UPF	DIFF_REGISER_SUPPLY	1
warning	UPF	DIFF_NET_EXIST	1
warning	UPF	DIFF_PORT_EXIST	1
-----			
Total			6

---

## SEE ALSO

report\_lp(2)  
verification\_static\_low\_power\_compare(3)

---

## connect\_net

Connects a net to one or more pins.

---

### SYNTAX

```
status connect_net  
  net_name  
  pin_list
```

#### Data Types

*net\_name* string  
*pin\_list* list

---

### ARGUMENTS

#### *net\_name*

Specifies the name of the net to connect. You can specify either an object ID or an instance-based path.

The command connects nets in a design and the changes are visible to all instances of that design. To connect a specific instance-based path, unify the instance of the design before connecting it.

#### *pin\_list*

Specifies the pins to which the net is to be connected. You can specify either object IDs or instance-based paths.

---

### RETURN VALUE

The **connect\_net** command returns a status of 1 if it was successful and 0 if it failed.

---

### DESCRIPTION

This command connects a net to the specified pins. If the net is not in the same hierarchy level as the pins, the tool punches ports and creates new net segments to enable the connection.

You can connect a net to many pins. However, you cannot connect a pin to more than one net. If you connect a net to a pin that already has an existing net connection, the existing net is disconnected.

To disconnect pins from a net, use the **disconnect\_net** command.

Outside of Setup mode, this command only works on edit designs created using the **edit\_design** command.

---

## EXAMPLES

The following example shows how to connect net net3 to two pins, r:/WORK/top/m1/i1 and r:/WORK/top/m1/b1/bi1.

```
fm_shell (setup)> current_instance r:/WORK/top/m1
fm_shell (setup)> connect_net net3 {i1 b1/bi1}
```

---

## SEE ALSO

current\_design(2)  
current\_instance(2)  
disconnect\_net(2)  
edit\_design(2)



---

## connect\_pin

Connects pins or ports at any level of hierarchy.

---

### SYNTAX

status **connect\_pin**  
-from *from\_object*  
-to *to\_list*

#### Data Types

*from\_object* string  
*to\_list* list

---

### ARGUMENTS

#### -from *from\_object*

Specifies the pin or port from which to make the connection. You can specify either an object ID or an instance-based path.

#### -to *to\_list*

Specifies the pins and ports to which to make the connection. The pins and ports can be at any level of the hierarchy. You can specify either object IDs or instance-based paths.

---

### RETURN VALUE

The **connect\_pin** command returns a status of 1 if it was successful and 0 if it failed.

---

### DESCRIPTION

This command performs global connections between the source object specified in the **-from** option and the objects specified in the **-to** option. The specified pins and ports can be at any level of hierarchy.

Outside of Setup mode, this command only works on edit designs created using the **edit\_design** command.

---

### EXAMPLES

The following example shows how to connect pin U1/Z to two pins, r:/WORK/top/m1/i1 and r:/WORK/top/m1/b1/bi1.

```
fm_shell (setup)> current_instance r:/WORK/top/m1
```

```
fm_shell (setup)> connect_pin -from U1/Z -to {i1 b1/bi1}
```

---

## SEE ALSO

current\_design(2)  
current\_instance(2)  
connect\_net(2)  
edit\_design(2)

---

## constrain\_low\_power\_intent

Constrains isolation and retention cells in a given design.

---

### SYNTAX

**constrain\_low\_power\_intent**  
*designID*

#### Data Types

*designID* string

---

### ENABLED SHELL MODES

Setup

---

### ARGUMENTS

#### **designID**

Specifies the design where isolation and retention cells will be constrained.

---

### DESCRIPTION

Use this command to constrain the low power behavior for isolation and retention for a specified design. Isolation cells are constrained to the always on state. Retention cells are constrained to always save, behaving like a regular register.

**constrain\_low\_power\_intent** is meant to allow the verification between a reference design where no UPF was loaded against an implementation where low power elements were inserted. This requires that **verification\_force\_upf\_supplies\_on** be set to true (default). It should be noticed that **constrain\_low\_power\_intent** only affects isolation and retention cells, other structures that may be implemented by the UPF file are not addressed by this command.

---

### SEE ALSO

---

## copy\_collection

Duplicates the contents of a collection, resulting in a new collection. The base collection remains unchanged.

---

### SYNTAX

```
collection copy_collection  
collection1
```

#### Data Types

```
collection1    collection
```

---

### ARGUMENTS

#### *collection1*

Specifies the collection to be copied. If an empty string is used for the *collection1* argument, the command returns the empty string (a copy of the empty collection is an empty collection).

---

### DESCRIPTION

The **copy\_collection** command is an efficient mechanism for creating a duplicate of an existing collection. It is more efficient and almost always sufficient to simply have more than one variable referencing the same collection. For example, if you create a collection of ports and save a reference to it in a **c1** variable, assigning the value of the **c1** variable to another **c2** variable creates a second reference to the same collection:

```
prompt> set c1 [get_cells U1*]  
{r:/WORK/top/U1 r:/WORK/top/U10 r:/WORK/top/U11 r:/WORK/top/U12}  
prompt> set c2 $c1  
{r:/WORK/top/U1 r:/WORK/top/U10 r:/WORK/top/U11 r:/WORK/top/U12}
```

This has not copied the collection. There are now two references to the same collection. If you change the *c1* variable, the *c2* variable continues to reference the same collection:

```
prompt> set c1 [get_cells block1]  
{r:/WORK/top/block1}  
prompt> query_objects $c2  
{r:/WORK/top/U1 r:/WORK/top/U10 r:/WORK/top/U11 r:/WORK/top/U12}
```

There might be instances when you really do need a copy. In those cases, the **copy\_collection** command is used to create a new collection that is a duplicate of the original.

---

### EXAMPLES

The following example shows the result of copying a collection. Functionally, it is not much different that having multiple references to the same collection.

```
prompt> set c1 [get_cells U1*]  
{r:/WORK/top/U1 r:/WORK/top/U10 r:/WORK/top/U11 r:/WORK/top/U12}  
prompt> set c2 [copy_collection $c1]  
{r:/WORK/top/U1 r:/WORK/top/U10 r:/WORK/top/U11 r:/WORK/top/U12}  
prompt> unset c1  
prompt> query_objects $c2  
{r:/WORK/top/U1 r:/WORK/top/U10 r:/WORK/top/U11 r:/WORK/top/U12}
```

---

## SEE ALSO

[collections\(2\)](#)

---

## cputime

Returns the CPU time used by the tool's shell.

---

### SYNTAX

**cputime**

---

### ARGUMENTS

none

---

### DESCRIPTION

This command returns the CPU time used by the tool's shell. The time is rounded off to the nearest one hundredth of a second.

---

### EXAMPLES

The following example shows the output produced by the **cputime** command.

```
fm_shell (setup)> cputime  
3.73  
fm_shell (setup)>
```

---

## create\_cell

Creates new cells.

---

### SYNTAX

```
cell_list create_cell
[cell_list]
reference_name
[ -connections pin_connection_list ]
```

#### Data Types

```
cell_list list
reference_name string
pin_connection_list list
```

---

### RETURN VALUE

The **create\_cell** command returns a list of the cells it created.

---

### ARGUMENTS

#### ***cell\_list***

Specifies the names of cells to create. You can specify either object IDs or instance-based paths. Each cell name must be unique within the design.

Cells are created in designs and are visible to all instances of that design. If you want to only affect a particular instance-based path, you must uniquify that instance of the design first.

If you do not specify this argument, the tool creates a single new cell and generates a name. The name is of the form *<prefix>\_CELL\_<number>*, where *<prefix>* is controlled by the **current\_prefix** command, and *<number>* is an integer to make the name unique.

Use the *cell\_list* argument before using the *reference\_name* argument.

#### ***reference\_name***

Specifies the design or library cell that the new cells reference. Ports on the reference determine the name, number, and direction of pins on the new cell.

#### ***pin\_connection\_list***

Specifies the pin connections for the new cell as a list of "*<pin>=<net>*" elements. Note that there are no spaces before or after the equal sign.

When the nets are in a different level of hierarchy than the newly created cell, the command creates ports and extra nets to make the connection.

---

## DESCRIPTION

This command creates new cells based on the *cell\_list* argument. New cells are the instantiation of an existing design or library cell.

To remove cells from the current design, use the **remove\_cell** command.

Outside of Setup mode, this command only works on edit designs created using the **edit\_design** command.

---

## EXAMPLES

The following example creates two new cells in design *r:/WORK/mid*. The new cells are called *box1* and *box2*, and they are both instantiations of design *r:/WORK/bot*.

```
fm_shell (setup)> current_design r:/WORK/mid  
fm_shell (setup)> create_cell {box1 box2} r:/WORK/bot
```

If the design name is unique across all libraries, you do not have to specify a container and a library:

```
fm_shell (setup)> current_design i:/WORK/cpu  
fm_shell (setup)> create_cell {cell1 cell2} AND2S4
```

You can use instance-based paths to create a cell and connect it up to four nets. Note that the four nets are specified relative to the the current instance (pins A and B), via the return value of a call to **create\_net** (pin C), or by a full instance-base path (pin Z):

```
fm_shell (setup)> current_instance i:/WORK/top/m1/b1  
fm_shell (setup)> create_cell AND3  
-connections [list A=../net1 B=cell3/net2 C=[create_net] Z=i:/WORK/top/m2/net3]
```

---

## SEE ALSO

[create\\_net\(2\)](#)  
[current\\_design\(2\)](#)  
[current\\_instance\(2\)](#)  
[current\\_prefix\(2\)](#)  
[edit\\_design\(2\)](#)  
[remove\\_cell\(2\)](#)



---

## create\_command\_group

Creates a new command group.

---

### SYNTAX

```
string create_command_group [-info info_text]  
group_name
```

---

### ARGUMENTS

**-info *info\_text***

Help string for the group

***group\_name***

Specifies the name of the new group.

---

### DESCRIPTION

The **create\_command\_group** command is used to create a new command group, which you can use to separate related user-defined procedures into functional units for the online help facility. When a procedure is created, it is placed in the "Procedures" command group. With the **define\_proc\_attributes** command, you can move the procedure into the group you created.

The *group\_name* can contain any characters, including spaces, as long as it is appropriately quoted. If *group\_name* already exists, **create\_command\_group** quietly ignores the command. The result of **create\_command\_group** is always an empty string.

---

### EXAMPLES

The following example demonstrates the use of the **create\_command\_group** command:

```
prompt> create_command_group {My Procedures} -info "Useful utilities"
```

```
prompt> proc plus {a b} { return [expr $a + $b] }
```

```
prompt> define_proc_attributes plus -command_group "My Procedures"
```

```
prompt> help  
My Procedures:  
plus
```

```
...
```

---

## SEE ALSO

`define_proc_attributes(2)`  
`help(2)`  
`proc(2)`

---

## create\_constraint\_type

Generates a user-defined constraint type.

---

### SYNTAX

status **create\_constraint\_type**  
*type\_name*  
*designID*

#### Data Types

*type\_name* string  
*designID* string

---

### ARGUMENTS

#### *type\_name*

Specifies the name of the constraint type.

#### *designID*

Specifies the name of the design that defines the constraint.

---

### DESCRIPTION

This command creates a user-defined constraint type from the specified design. You can then use the constraint type can with the **set\_constraint** command to constrain control points in the verification. For more information, see the **set\_constraint** command man page.

The following rules apply when you specify the constraint module using the *designID* argument:

- One or more inputs
- Only one output
- Output state is logic 1 if the inputs to the module satisfy the constraint (the control points are in a legal state). Output state is logic 0 if the inputs to the module do not satisfy the constraint (the control points are not in a legal state).
- No inouts
- No sequential logic
- No cycles
- No three-state logic
- No black boxes

The *type\_name* argument defines the name used to reference this constraint type using the **set\_constraint** command. The

*type\_name* argument must be unique from the set of predefined and user-defined type names.

The constraint module is automatically elaborated when you run the **create\_constraint\_type** command.

---

## EXAMPLES

The following example reads a design that is used to create a user-defined constraint type. The constraint module file `my_2hot.v` allows only two inputs to be 1 at the same time.

```
module my_2hot(in1, in2, in3 out);
input in1, in2, in3;
output out;
reg out;
```

```
always @*
case ({in1, in2, in3})
3'b110 : out = 1'b1;
3'b011 : out = 1'b1;
3'b101 : out = 1'b1;
default: out = 1'b0;
endcase
```

```
endmodule
```

```
fm_shell> read_verilog -container ctype my_2hot.v
No target library specified, default is WORK
Loading verilog file 'my_2hot.v'
Created container 'ctype'
Current container set to 'ctype'
1
fm_shell> create_constraint_type 2hot ctype:/WORK/my_2hot
1
```

---

## SEE ALSO

```
remove_constraint(2)
remove_constraint_type(2)
report_constraint(2)
report_constraint_type(2)
set_constraint(2)
```

---

## create\_container

Creates a new container.

---

### SYNTAX

**create\_container**  
*containerID*

#### Data Types

*containerID* string

---

### ARGUMENTS

***containerID***

Specifies the name of the container to create.

---

### DESCRIPTION

This command creates an empty container and establishes it as the current container. If a container with the specified name already exists, the tool reports an error.

When you create a container, the command loads the GTECH technology library, and any other shared technology libraries, into the new container.

For more information about containers, see the *Formality User Guide*.

The **create\_container** command returns one of the following:

- 0 to indicate failure
- 1 to indicate success

---

### EXAMPLES

This example creates a new container, ref, and establishes it as the current container.

```
fm_shell> create_container ref
Created container 'ref'
Current container set to 'ref'
1
fm_shell>
```

## SEE ALSO

current\_container(2)  
report\_containers(2)

---

## create\_cutpoint\_blackbox

Creates a single-input, single-output black box.

---

### SYNTAX

#### **create\_cutpoint\_blackbox**

*blackbox\_name*

*objectID*

*[-type objectID\_type]*

*[-invert]*

#### **Data Types**

*blackbox\_name* string

*objectID* string

*objectID\_type* string

---

### ENABLED SHELL MODES

Setup

---

### ARGUMENTS

#### ***blackbox\_name***

Specifies the name of the black box to insert.

#### ***objectID***

Specifies the design object into which the command inserts the black box.

#### ***-type objectID\_type***

Specifies the type of the object that is specified by the *objectID* argument. Use this option if the name of the specified design object is associated with more than one type of design object within the same design. Specify one of the following for the *objectID\_type* argument:

- *net* for a net type
- *pin* for a pin type
- *port* for a port type

#### ***-invert***

Specifies that the inserted cutpoint is inversed.

## DESCRIPTION

This command inserts a single-input, single-output black box on the specified net, or the net of the specified pin or port.

The black box input pin is named *In* and the output pin is named *Out*. The inserted black box is a cutpoint that effectively breaks the net on which it is inserted. If you specify a net object, then the net is disconnected from its drivers and connected to the black box output pin instead. A new net is then created that connects all drivers of the specified net to the black box input pin.

Similarly, the net connected to a specified pin or port is cut. The existing net connects to the black box input pin, and a new net is generated to connect the black box output pin to the specified pin or port.

This command does not work with bidirectional pins or ports, or nets connected to bidirectional pins or ports. This command forces the creation of a compare point and inserts a new primary input at the specified net or the net of the specified pin or port, because the tool creates compare points at black box input pins by default.

---

## EXAMPLES

```
fm_shell (setup)> create_cut myblackbox ref:/WORK/scanner/updn -type net
Created cutpoint black box 'ref:/WORK/scanner/myblackbox' with input pin 'In' and output pin 'Out'.
Net connected to input pin: 'ref:/WORK/scanner/N0'
Net connected to output pin: 'ref:/WORK/scanner/updn'
1
fm_shell (setup)>
```

---

## SEE ALSO

```
set_cutpoint(2)
remove_cutpoint(2)
report_cutpoints(2)
```



---

## create\_eco\_patch

Creates an ECO change list (ECO patch).

---

### SYNTAX

```
status create_eco_patch
[ -prefix name ]
[ -work_directory name ]
[ -inverter_lib_cell_name name ]
[ -buffer_lib_cell_name name ]
[ -use_name_pattern pattern ]
[ -dont_use_name_pattern pattern ]
[ -replace ]
[ name ]
```

#### Data Types

*name* string  
*pattern* string

#### Enabled Shell Modes

Match  
Verify

---

### LICENSE

This command is available when the "Formality-LogicECO" license key is used.

---

### ARGUMENTS

#### **-prefix *name***

Specifies a name that will be used as the basis for naming all new nets/cells/ports. The default is "ECO\_".

#### **-work\_directory *name***

Specifies an optional directory path name for all FM-ECO output. If the directory does not exist it will be created. If no directory is specified all FM-ECO output will be written in the current directory.

#### **-inverter\_lib\_cell\_name *name***

Specifies the technology library inverter cell to instantiate when necessary. The expected name format is "*/<library\_name>/<cell\_name>*".

#### **-buffer\_lib\_cell\_name *name***

Specifies the technology library buffer cell to instantiate when necessary. The expected name format is "`<library_name>/<cell_name>`".

**-use\_name\_pattern *pattern***

Specifies the name pattern to use when searching technology libraries for simple combinational gates (BUF, INV, AND, NAND, OR, NOR, XOR, XNOR). Only technology library cells with names that match the given pattern will be considered. If this option is not used, all technology library cells are considered in the search. The pattern should be in TCL glob-style pattern matching form.

**-dont\_use\_name\_pattern *pattern***

Specifies the name pattern to use when searching technology libraries for simple combinational gates (BUF, INV, AND, NAND, OR, NOR, XOR, XNOR). Any technology library cells with names that match the given pattern will not be considered. If this option is not used, no technology library cells are excluded from the search. The pattern should be in TCL glob-style pattern matching form.

**-replace**

Overwrites output file if it already exists.

***name***

If not specified, the generated output files follow the naming convention set via `match_eco_regions`. If the specified name is a valid directory then the output files will be saved inside the specified directory. Otherwise the specified name will be used as the basis for naming all generated output files.

---

## DESCRIPTION

This command can only be issued in match or verify mode. You must first specify the original implementation, the ECO reference, the ECO implementation and source the ECO regions data file that was generated during a `match_eco_regions` session. This command will then create the netlist edit commands that when applied to the original implementation will make it functionally equivalent to the ECO reference.

---

## EXAMPLES

The following example creates an ECO patch.

```
fm_shell (match)> create_eco_patch -replace
```

---

## SEE ALSO

`match_eco_regions`  
`write_eco_regions`  
`set_orig_reference`  
`set_orig_implementation`  
`set_eco_reference`  
`set_eco_implementation`

---

## create\_net

Creates new nets.

---

### SYNTAX

```
net_list create_net  
[ net_list ]  
[ -power | -ground | -tie_high | -tie_low ]  
[ -pins pin_list ]
```

#### Data Types

```
net_list list  
pin_list list
```

---

### RETURN VALUE

The **create\_net** command returns a list of the nets it created.

---

### ARGUMENTS

#### *net\_list*

Specifies the names of the nets to create. You can specify either object IDs or instance-based paths. Each net name must be unique in the design.

Nets are created in designs and are visible to all instances of that design. If you want to only affect a particular instance-based path, you must uniquely identify the instance of the design first.

If you do not specify this argument, the tool creates a single new net and generates a name. The name is of the form *<prefix>\_NET\_<number>*, where *<prefix>* is controlled by the **current\_prefix** command, and *<number>* is an integer to make the name unique.

#### **-power**

Creates a power net. By default, the tool creates a signal net.

The *-power*, *-ground*, *-tie\_high*, and *-tie\_low* options are mutually exclusive.

#### **-ground**

Creates a ground net. By default, the tool creates a signal net.

The *-power*, *-ground*, *-tie\_high*, and *-tie\_low* options are mutually exclusive.

#### **-tie\_high**

Creates a constant 1 net. By default, the tool creates a signal net.

The *-power*, *-ground*, *-tie\_high*, and *-tie\_low* options are mutually exclusive.

#### ***-tie\_low***

Creates a constant 0 net. By default, the tool creates a signal net.

The *-power*, *-ground*, *-tie\_high*, and *-tie\_low* options are mutually exclusive.

#### ***pin\_list***

Specifies the pins to which the new net is connected. This option is only allowed when creating a single net.

When the pins are in a different level of hierarchy than the newly created net, the command creates ports and extra nets to make the connection.

Pins that already are connected to a net are disconnected before they are connected to the newly created net.

---

## DESCRIPTION

This command creates new net objects based on the *net\_list* argument. The **create\_net** command creates only scalar (single bit) nets.

Use the *-pins* option to connect nets to pins, or use the **connect\_net** command. To remove nets, use the **remove\_net** command.

Outside of Setup mode, this command only works on edit designs created using the **edit\_design** command.

Logically, the *-ground* and *-tie\_low* options, and the *-power* and *-tie\_high* options are equivalent.

---

## EXAMPLES

The following example shows how to create two new nets in design *r:/WORK/mid*. The new cells are named *net1* and *net2*.

```
fm_shell (setup)> current_design r:/WORK/mid
fm_shell (setup)> create_net {net1 net2}
```

Assuming *r:/WORK/top/m1* is an instance of *r:/WORK/mid*, use instance-based paths to create a new net in *r:/WORK/mid*:

```
fm_shell (setup)> current_instance r:/WORK/top/m1
fm_shell (setup)> create_net net3 -pins {../m2/IN1 IN2 and _gate_cell/Z}
```

---

## SEE ALSO

connect\_net(2)  
create\_cell(2)  
current\_design(2)  
current\_instance(2)  
current\_prefix(2)  
disconnect\_net(2)  
edit\_design(2)  
remove\_net(2)

---

## create\_port

Creates ports.

---

### SYNTAX

```
port_list create_port
[ port_list ]
[ -direction dir ]
```

#### Data Types

```
port_list list
dir string
```

---

### RETURN VALUE

The **create\_port** command returns a list of the ports it created.

---

### ARGUMENTS

#### *port\_list*

Specifies the names of ports to create. You can use either object IDs or instance-based paths. Each port name must be unique within the current design.

Ports are created in designs and are visible to all instances of that design. If you want to only affect a particular instance-based path, you must uniquify that instance of the design first.

If you do not specify this argument, the tool creates a single new port and generates a name. The name is of the form *<prefix>\_PORT\_<number>*, where *<prefix>* is controlled by the **current\_prefix** command, and *<number>* is an integer to make the name unique.

#### *-direction dir*

Specifies the signal flow of the created port. Specify one of the following:

- **in** - Default.
- **out**
- **inout**

## DESCRIPTION

This command creates new port objects based on the *port\_list* argument.

Ports are the external connection points on a design. To connect ports to nets inside a design, use the **connect\_net** or **create\_net** commands.

Use the **remove\_port** command to remove ports.

Outside of Setup mode, this command only works on edit designs created using the **edit\_design** command.

---

## EXAMPLES

The following example shows how to create two new ports on design *r:/WORK/mid*. The new ports are named *new\_in* and *new\_out*.

```
fm_shell (setup)> current_design r:/WORK/mid
fm_shell (setup)> create_port new_in -dir in
fm_shell (setup)> create_port new_out -dir out
```

This example shows how to create a new port and connect it to a new net:

```
fm_shell (setup)> current_instance r:/WORK/top/m1/b1
fm_shell (setup)> create_net -pins [create_port]
```

---

## SEE ALSO

- connect\_net(2)
- create\_cell(2)
- current\_design(2)
- current\_instance(2)
- current\_prefix(2)
- edit\_design(2)
- remove\_port(2)

---

## create\_power\_model

Creates a Formality power model for an instance in memory.

---

### SYNTAX

```
status create_power_model  
  object_name
```

#### Data Types

*object\_name* string

---

### ARGUMENTS

*object\_name*

Specifies an instance to be modelled.

---

### DESCRIPTION

The **create\_power\_model** command creates the power model for an instance in memory.

The power model is similar in many ways to a black box with UPF, but since it is derived from the actual design all of the UPF semantics (including receiver/driver supplies) are reflected in the model and there is no need to reapply the subblock UPF to the model during top-level verification verification in UPF context.

---

### EXAMPLES

The following example creates the power model for a design in current container.

```
fm_shell> create_power_model r:/WORK/top/add2  
1
```

---

### SEE ALSO

write\_power\_model(2)  
read\_power\_model(2)

---

## create\_primitive

Creates primitive cells.

---

### SYNTAX

```
cell_list create_primitive
[cell_list]
cell_type
[ -size size_val ]
[ -connections pin_connection_list ]
```

#### Data Types

```
cell_list list
cell_type string
size_val integer
pin_connection_list list
```

---

### RETURN VALUE

The **create\_primitive** command returns a list of the cells it created.

---

### ARGUMENTS

#### *cell\_list*

Specifies the names of cells to create. You can use either object IDs or instance-based paths. Each cell name must be unique within its enclosing design.

Cells are created in designs and are visible to all instances of the design. To affect a specific instance-based path, uniquify the instance of the design first.

If you do not specify this argument, the tool creates a single new cell and generates a name. The name is of the form *<prefix>\_CELL\_<number>*, where *<prefix>* is controlled by the **current\_prefix** command, and *<number>* is an integer to make the name unique.

Use the *cell\_list* argument before using the *cell\_type* argument.

#### *cell\_type*

Specifies the type of primitive cells to create. The type must be one of the following:

- AND - to create combinational logic gate cells
- OR - to create combinational logic gate cells



- XOR - to create combinational logic gate cells
- NAND - to create combinational logic gate cells
- NOR - to create combinational logic gate cells
- XNOR - to create combinational logic gate cells
- BUF - to create buffer cells
- INV - to create inverter cells
- DC - to create dont-care cells
- TRI - to create tri-state cells
- SEQ - to create register cells

***size\_val***

Specifies the number of input pins of the gates being created. The size argument is ignored for BUF, INV, DC, TRI, and SEQ cell types. The size must be 2 or larger for XOR and XNOR. The size must be 0 or larger for AND, OR, NAND, and NOR. The default is 2.

***pin\_connection\_list***

Specifies the pin connections for the new cell as a list of "<pin>=<net>" elements. Note that there are no spaces before or after the equal sign.

When the nets are in a different level of hierarchy than the newly created cell, the command creates ports and extra nets to make the connection.

---

## DESCRIPTION

This command creates new primitive cells.

Use the **invert\_pin** command to invert pins on primitive cells.

The output pins on non-SEQ primitive cells are always called *OUT*. SEQs have two output pins: *Q* and *QN*.

The input pins on combinational logic primitive gates are called *IN1*, *IN2*, etc.

The input pins on dont\_care cells are called *DC* and *F*.

The input pins on TRI cells are called *D* and *EN*.

The input pins on SEQ cells are called *CLK*, *SL*, *SD*, *SS*, *SC*, *ST*, *AL*, *AD*, *AS*, and *AC*.

To create cells that are instantiations of a design, use the **create\_cell** command.

To remove cells from the current design, use the **remove\_cell** command.

Outside of Setup mode, this command only works on edit designs created using the **edit\_design** command.

This command is specific to Formality. It is not supported by other Synopsys tools. Formality will warn about this the first time the command is used.

---

## EXAMPLES

The following example creates a new 3-input AND cell in the design *r:/WORK/mid*. The new cell is named *MY\_AND\_GATE*.

```
fm_shell (setup)> current_design r:/WORK/mid
fm_shell (setup)> create_primitive MY_AND_GATE AND -size 3
```

This example creates a new 2-input XOR cell in the design of instance `r:/WORK/top/m1/b1`. The new cell is called `MY_XOR_GATE`.

```
fm_shell (setup)> current_instance r:/WORK/top/m1/b1
fm_shell (setup)> create_primitive MY_XOR_GATE XOR
```

This is the previous example without the use of **current\_instance**.

```
fm_shell (setup)> create_primitive r:/WORK/top/m1/b1/MY_XOR_GATE XOR
```

This example creates a new 3-input AND cell in the design of instance `r:/WORK/top/m1`. The new cell is called `MY_AND_GATE`. Pins IN1, IN2, and IN3 of `MY_AND_GATE` are connected to nets `m1` of `mi2`, `i3` of `top`, and `i4` of `top`, respectively. Since no absolute instance paths were used, all nets are referenced relative to the **current\_instance** top.

```
fm_shell (setup)> current_instance r:/WORK/top
fm_shell (setup)> create_primitive m1/MY_AND_GATE and -size 3
                  -connect {IN1=m1/mi2 IN2=i3 IN3=i4 OUT=m1/b1/bo2}
```

This example uses auto-naming to create a new SEQ in the **current\_instance** top.

```
fm_shell (setup)> current_instance r:/WORK/top
fm_shell (setup)> set name [create_primitive seq]
fm_shell (setup)> puts "Name: $name."
Name: r:/WORK/top/FM_CELL_1.
```

---

## SEE ALSO

```
create_cell(2)
current_design(2)
current_instance(2)
edit_design(2)
invert_pin(2)
remove_cell(2)
```

---

## current\_container

Sets or reports the current container.

---

### SYNTAX

status **current\_container**  
[ *containerID* ]

#### Data Types

*containerID* string

---

### ARGUMENTS

#### *containerID*

Specifies the name of the container to establish as the current container.

---

### DESCRIPTION

This command establishes or reports the current container.

If the specified container ID does not exist, the tool reports the following error:

Error: container *name* could not be found.

To report the current container, enter the command without specifying a container ID. If the specified container is not set, the tool reports the following error:

The current container is not set  
0

The current container remains current until you issue a subsequent **current\_container** command or create a new container. For conceptual information about containers, see the *Formality User Guide*.

The **current\_container** command returns one of the following:

- 0 to indicate failure
- A string containing the name of the current container

---

### EXAMPLES

The following example creates three containers `ref`, `impl`, and `temp`, establishes the container named `temp` as the current container, and then reports the current container.

```
fm_shell> create_container ref  
Created container 'ref'  
Current container set to 'ref'  
1  
fm_shell> create_container impl  
Created container 'impl'  
Current container set to 'impl'  
1  
fm_shell> create_container temp  
Created container 'temp'  
Current container set to 'temp'  
1  
fm_shell> current_container temp  
impl  
fm_shell> current_container  
impl  
fm_shell>
```

---

## SEE ALSO

`create_container(2)`  
`report_containers(2)`

---

## current\_design

Sets or reports the current design.

---

### SYNTAX

**current\_design**  
[ *designID* ]

#### Data Types

*designID* string

---

### ARGUMENTS

#### *designID*

Specifies the name of the design to establish as the current design. For information about design IDs, see the *Formality User Guide*.

---

### DESCRIPTION

This command sets or reports the current design.

To establish a current design, specify the *designID* argument. If the specified design does not exist, the tool reports one of the following two error messages:

Error: DesignID *name* is invalid  
Error: A design named *name* could not be found in *container*

**Note:** Reading in a design does not establish it as the current design.

To report the current design, run the command without specifying the *designID* argument. If a current design is not set, the tool reports the following error:

The current design is not set  
0

The current design remains current until you issue the subsequent **current\_design** command.

---

### EXAMPLES

The following example establishes and reports the current design.

```
fm_shell> create_container ref
Created container 'ref'
Current container set to 'ref'
1
```

```
fm_shell> read_db mapped_gate_lca500k.db
Loading db file 'mapped_gate_lca500k.db'
No target library specified, default is WORK
1
fm_shell> current_design /WORK/CORE
ref:/WORK/CORE
fm_shell> current_design
ref:/WORK/CORE
fm_shell>
```

---

## SEE ALSO

[current\\_instance\(2\)](#)

---

## current\_instance

Sets or reports the current instance.

---

### SYNTAX

**current\_instance**  
[ *instancePath* ]

#### Data Types

*instancePath* string

---

### RETURN VALUE

The **current\_instance** command returns the absolute path of the current instance.

---

### ARGUMENTS

#### *instancePath*

Specifies the working cell.

---

### DESCRIPTION

The **current\_instance** command sets the working instance, and enables you to traverse the design hierarchy. The instance specified by the **current\_instance** command is a cell embedded in the hierarchy of a design. You can use the current instance as the hierarchical reference point in many Formality commands to specify the hierarchy in which design objects such as nets, pins, and ports are found.

The **current\_instance** command always operates relative to the value of the **current\_design** command. It may be identical to the **current\_design** command, or below the **current\_design** in the hierarchy. If the current instance is not set, the command assumes the value of the **current\_design** command.

The **current\_instance** command can take either no argument, or an instance path:

- If no argument is specified, it returns the value of the **current\_design** command.
- If the **current\_instance** command is set to an absolute or fully qualified instance path, the specified cell becomes the current cell, and the **current\_design** command is set to the top-level design of the path.
- If the **current\_instance** command is set to a relative instance path, the specified cell becomes the current cell, and only the **current\_instance** command is affected; the **current\_instance** command is defined relative to the **current\_design** command.

An instance path is relative if it does not fully specify the path (container, library, instance path) to the cell:

- A "." signifies current directory.

- A ".." moves one level up the design hierarchy. Note that ".." directive may also be either nested or embedded, or both, in complex instance instantiations, as shown in the following examples.
- If a valid cell at the current level of hierarchy is specified, the **current\_instance** command is moved down to that level of hierarchy.

The current instance remains current until either the subsequent **current\_instance** or **current\_design** command.

---

## EXAMPLES

The following examples shows the interplay between **current\_instance** and **current\_design**.

```
fm_shell> current_instance
The current instance is not set
0
fm_shell> current_design
The current design is not set
0
fm_shell> current_instance r:/WORK/top
r:/WORK/top

## no args echoes current_instance

fm_shell> current_instance
r:/WORK/top

fm_shell> current_design
r:/WORK/top

## invalid current_instance un-sets current_design

fm_shell> current_instance ../
Error: Unknown name: '../' (FM-036)
Information: Current design is no longer set (FM-072)
0
fm_shell> current_instance
The current instance is not set
0
## Setting current_instance full path sets current_design to top

fm_shell> current_instance r:/WORK/top/m1
r:/WORK/top/m1

fm_shell> current_design
r:/WORK/top

## Relative cell reference

fm_shell> current_instance b1
r:/WORK/top/m1/b1

## Another relative cell reference

fm_shell> current_instance ../b2
r:/WORK/top/m1/b2

## Re-setting current_design un-sets current_instance

fm_shell> current_design r:/WORK/mid
r:/WORK/mid
fm_shell> current_instance
The current instance is not set
0
fm_shell>
```



---

## SEE ALSO

current\_prefix(2)  
current\_design(2)  
create\_net(2)  
create\_port(2)  
create\_cell(2)  
connect\_net(2)  
remove\_net(2)  
remove\_port(2)  
remove\_cell(2)  
change\_link(2)  
record\_edits(2)  
undo\_edits(2)  
write\_edits(2)

---

## current\_prefix

Sets or reports the prefix used by automatic name generation in high-level ECO editing.

---

### SYNTAX

**current\_prefix**  
[ *prefix* ]

#### Data Types

*prefix* string

---

### RETURN VALUE

The **current\_prefix** command returns the name of the current prefix.

---

### ARGUMENTS

#### *prefix*

Appends the specified prefix to design objects created using the auto-name-generation feature of the high level editing ECO command set.

---

### DESCRIPTION

The **current\_prefix** command appends the specified prefix to objects created by the automatic name-generation feature of the following high level editing ECO commands:

**create\_net**  
**create\_port**  
**create\_cell**

The auto-naming format for the three commands is <prefix>\_<type>\_<integer>, where:

<prefix> is **current\_prefix**  
<type> is NET, PORT OR CELL, respectively  
<integer> is the lowest available integer to guarantee uniqueness of the name

The default of **current\_prefix** is "FM" .

---

### EXAMPLES

The following example creates a net using the default value of **current\_prefix** and connects it to the specified pin.

```
fm_shell (setup)> create_net -pins ../register/U133/zn  
i:/WORK/mR4000/cntrl/FM_NET_1
```

The following example overrides the default value of **current\_prefix** and connects it to a given pin.

```
fm_shell (setup)> current_prefix ECO7  
fm_shell (setup)> create_net -pins ../register/U131/zn  
i:/WORK/mR4000/cntrl/ECO7_NET_1
```

---

## SEE ALSO

- current\_instance(2)
- create\_net(2)
- create\_port(2)
- create\_cell(2)

---

## date

Returns a string containing the current date and time.

---

## SYNTAX

string **date**

---

## DESCRIPTION

The **date** command generates a string containing the current date and time, and returns that string as the result of the command. The format is fixed as follows:

ddd mmm nn hh:mm:ss yyyy

Where:

ddd is an abbreviation for the day  
mmm is an abbreviation for the month  
nn is the day number  
hh is the hour number (24 hour system)  
mm is the minute number  
ss is the second number  
yyyy is the year

The **date** command is useful because it is native. It does not fork a process. On some operating systems, when the process becomes large, no further processes can be forked from it. With it, there is no need to call the operating system with **exec** to ask for the date and time.

---

## EXAMPLES

The following command prints the date.

```
prompt> echo "Date and time: [date]"
Date and time: Thu Dec 9 17:29:51 1999
```

---

## SEE ALSO

exec(2)

---

## debug\_library\_cell

Debugs the specified library cell. This command is available only in the library verification mode.

---

### SYNTAX

**debug\_library\_cell**  
[ *cellName* ]

#### Data Types

*cellName* string

---

### ARGUMENTS

***cellName***

Specifies the name of cell that is to be debugged.

---

### DESCRIPTION

Use this command to debug a library cell that has failed or aborted verification to obtain more information and analyze the problem. This command reverifies the specified library cell directly from the reference and implementation containers.

Use this command only after all cells are verified. It keeps the session in the *library\_verify* mode.

---

### SEE ALSO

verify(2)  
select\_cell\_list(2)  
report\_cell\_list(2)

---

## debug\_script

Debug a script using the TclDevKit Tcl debugger.

---

### SYNTAX

string **debug\_script** script [*port*] [*hostname*]

---

### ARGUMENTS

#### *script*

This specifies the Tcl script(s) to be debugged. This script will be sourced and instrumented for debugging.

#### *port*

Specifies the port number that the debugger is listening on for a remote debugging application. By default the debugger will be launched on an available port.

#### *hostname*

Specifies the host where Prodebug is already running. This is used to connect to an existing remote Prodebug session.

#### **::env(SNPS\_TCLPRO\_HOME)**

This Tcl variable is used to specify the root of the TclPro installation. It is initialized from the environment variable SNPS\_TCLPRO\_HOME in the user's environment.

---

### USING THE PACKAGE

The **debug\_script** command is in the snpsTclPro Tcl package, and all of the commands in this package are defined in the namespace snpsTclPro. The way to use this command is to load the package, which will import the commands it exports into the global namespace. This is shown below.

```
shell> package require snpsTclPro
1.0
```

These commands can be added to the .synopsys setup file for the system, user, or current directory, or the commands can be typed when the package is needed.

---

### DESCRIPTION

The **debug\_script** command simplifies the use of the TclDevKit Tcl debugger available from ActiveState (<http://www.activestate.com>). First it ensures a connection to the Prodebug debugger either by connecting to a running debug session (given a *hostname* and *port*), or by launching the debugger on *localhost* using an available port, and then connecting to it. If there is already an active connection to

the debugger then that debugger will simply be used.

Once the connection to the debugger is set up, the specified script will be sourced and debugged. The default behavior for the debugger is to stop at the first line of the source'd script.

The debugger must be run using a "remote" debugging project if you want to connect the Synopsys tools to a running prodebug session. The port number in use by the debugger can be viewed via the Application tab of the "File->Project" Settings dialog.

---

## EXAMPLES

```
# Launch the debugger and then debug the script myscript.tcl.
shell> debug_script myscript.tcl
Selected port 2576 on host localhost
launching prodebug

# now debug another script using the same session
shell> debug_script anotherScript.tcl

# debug myscript.tcl, connecting to the specified debugger session or
# creating one if the connection fails.
shell> debug_script myscript.tcl 2576 localhost
```

---

## CAVEATS

The debugger currently kills the process that started the debugger when you exit, despite the preferences being set differently in the debugger.

When the Synopsys tool has spawned a debugger, that debugger must be exited before the Synopsys tool can exit. If this is not the case then the Synopsys tool will hang on exit, until the debugger is exited.

The **debug\_script** command waits for the debug process to start up, before it tries to connect to the debugger. If **debug\_script** times out before the debugger is started due to machine or network loading, simply close the debugger that was launched, and then increase the timeout setting with the command **set\_debugger\_start\_timeout**, and then re-run the debugger. The **set\_debugger\_start\_timeout** command takes a single argument which is the value of the timeout in milliseconds, and the default value for the timeout is 10000.

---

## SEE ALSO

check\_script(2)  
package(2)  
namespace(2)

---

## define\_design\_lib

Defines the library mapping information.

---

### SYNTAX

```
status define_design_lib  
[ -container containerID | -r | -i ]  
logical_library_name  
-path physical_library_name
```

#### Data Types

```
containerID string  
logical_library_name string  
physical_library_name string
```

---

### ARGUMENTS

#### **-container** *containerID*

Specifies the container from which the mapping is to be used. If you don't specify a container name, by default the current container is used.

#### **-r**

Specifies that the mapping in the default reference container is to be used.

#### **-i**

Specifies that the mapping in the default implementation container is to be used.

#### ***logical\_library\_name***

Specifies the name of the logical library name.

#### **-path** *physical\_library\_name*

Specifies the name of the physical library including the path.

---

### DESCRIPTION

You can use this command multiple times, once for each logical library name that is to be mapped to a physical library. You can run the commands at any time, but they are valid only before the first read into that logical library.

When multiple logical libraries point to the same physical library specified by using the *physical\_library\_name* argument, the tool uses the first logical library name that is defined. The path specified by using the **-path** option is used for proper mapping. All logical libraries that point to the same path, must share the same physical library.

A logical library cannot be mapped to two physical libraries in the same container. But they can be mapped to two physical libraries in different containers.



The **define\_design\_lib** command returns one of the following:

- 0 to indicate failure
- 1 to indicate success

---

## EXAMPLES

The following example maps logical libraries lib1 and lib2 to physical library lib1 in container r.

```
fm_shell> define_design_lib -r lib1 -path s
1
fm_shell> define_design_lib -r lib2 -path s
1
fm_shell>
```

The following example reports an error when a container is not available.

```
fm_shell> define_design_lib lib1 -path s
The current container is not set
0
fm_shell>
```

The following example reports an error when the same logical library is mapped to different physical libraries in the same container.

```
fm_shell> define_design_lib -r lib1 -path s
1
fm_shell> define_design_lib -r lib1 -path p
Warning: For current container r, the logical library LIB1 is already mapped to
the physical library LIB1.
Skipping current mapping information. (FM-518)
0
fm_shell>
```

---

## SEE ALSO

read\_vhdl(2)  
current\_container(2)

---

## define\_primitive\_pg\_pins

Defines the power and ground pins or power-down-function pin of User Defined Primitive(UDP) cells.

---

### SYNTAX

```
status define_primitive_pg_pins
[-power power_pin_names
-ground ground_pin_names]
[-power_down power_down_function_pin_name]
primitive_list
```

#### Data Types

```
power_pin_names list
ground_pin_names list
power_down_function_pin_name string
primitive_list list
```

---

### ARGUMENTS

#### **-power *power\_pin\_names***

Specifies the power pin list of given list of User Defined Primitive(UDP) cells.

#### **-ground *ground\_pin\_names***

Specifies the ground pin list of given list of User Defined Primitive(UDP) cells.

#### **-power\_down *power\_down\_function\_pin\_name***

Specifies the power-down-function pin of given list of User Defined Primitive(UDP) cells.

#### ***primitive\_list***

Specifies the list of power aware User Defined Primitive(UDP) cells. This can accept values which are in TCL glob-style pattern matching form.

---

### DESCRIPTION

You can use this command to provide information on the power and ground pins or power-down-function pin of given list of User Defined Primitive(UDP) cells. This information assist the tool in identifying the power-down-function logic of these User Defined Primitive(UDP) cells.

- 0 to indicate failure
- 1 to indicate success

## EXAMPLES

The following examples show the usage of **define\_primitive\_pg\_pins** command.

```
fm_shell> define_primitive_pg_pins -power VDD -ground VSS "udp_cell_1* udp_cell_2*"
1
fm_shell> define_primitive_pg_pins -power {VDD VDD1} -ground "VSS VSS1" "udp_cell*"
1
fm_shell> define_primitive_pg_pins -power_down PDF "udp_cell_3* udp_cell_4*"
1
fm_shell>
```

---

## SEE ALSO

---

## define\_proc\_attributes

Defines attributes of a Tcl procedure, including an information string for help, a command group, a set of argument descriptions for help, and so on. The command returns the empty string.

---

### SYNTAX

```
string define_proc_attributes
    proc_name
    [-info info_text]
    [-define_args arg_defs]
    [-define_arg_groups group_defs]
    [-command_group group_name]
    [-return type_name]
    [-hide_body]
    [-hidden]
    [-dont_abbrev]
    [-permanent]
```

#### Data Types

```
proc_name    string
info_text    string
arg_defs     list
group_defs   list
group_name   string
type_name    string
```

---

### ARGUMENTS

#### *proc\_name*

Specifies the name of the existing procedure.

#### **-info** *info\_text*

Provides a help string for the procedure. This is printed by the **help** command when you request help for the procedure. If you do not specify *info\_text*, the default is "Procedure".

#### **-define\_args** *arg\_defs*

Defines each possible procedure argument for use with **help -verbose**. This is a list of lists where each list element defines one argument.

#### **-define\_arg\_groups** *group\_defs*

Defines argument checking groups. These groups are checked for you in `parse_proc_arguments`. each list element defines one group

#### **-command\_group** *group\_name*

Defines the command group for the procedure. By default, procedures are placed in the "Procedures" command group.

#### **-return** *type\_name*

Specifies the type of value returned by this proc. Any value may be specified. Some applications use this information for automatically generated dialogs etc. Please see the `type_name` option attribute described below.

**-hide\_body**

Hides the body of the procedure from **info body**.

**-hidden**

Hides the procedure from **help** and **info proc**.

**-dont\_abbrev**

Specifies that the procedure can never be abbreviated. By default, procedures can be abbreviated, subject to the value of the **sh\_command\_abbrev\_mode** variable.

**-permanent**

Defines the procedure as permanent. You cannot modify permanent procedures in any way, so use this option carefully.

**-deprecated**

Defines the procedure as deprecated i.e. it should no longer be called but is still available.

**-obsolete**

Defines the procedure as obsolete i.e. it used to exist but can no longer be called.

---

## DESCRIPTION

The **define\_proc\_attributes** command associates attributes with a Tcl procedure. These attributes are used to define help for the procedure, locate it in a particular command group, and protect it.

When a procedure is created with the **proc** command, it is placed in the Procedures command group. There is no help text for its arguments. You can view the body of the procedure with **info body**, and you can modify the procedure and its attributes. The **define\_proc\_attributes** command allows you to change these aspects of a procedure.

Note that the arguments to Tcl procedures are all named, positional arguments. They can be programmed with default values, and there can be optional arguments by using the special argument name *args*. The **define\_proc\_attributes** command does not relate the information that you enter for argument definitions with **-define\_args** to the actual argument names. If you are describing anything other than positional arguments, it is expected that you are also using **parse\_proc\_arguments** to validate and extract your arguments.

The *info\_text* is displayed when you use the **help** command on the procedure.

Use **-define\_args** to define help text and constraints for individual arguments. This makes the help text for the procedure look like the help for an application command. The value for **-define\_args** is a list of lists. Each element has the following format:

```
arg_name option_help value_help data_type attributes
```

The elements specify the following information:

- *arg\_name* is the name of the argument.
- *option\_help* is a short description of the argument.
- *value\_help* is the argument name for positional arguments, or a one word description for dash options. It has no meaning for a Boolean option.
- *data\_type* is optional and is used for option validation. The *data\_type* can be any of: string, list, boolean, int, float, or one\_of\_string. The default is string.
- *attributes* is optional and is used for option validation. The *attributes* is a list that can have any of the following entries:
  - "required" - This argument must be specified. This attribute is mutually exclusive with optional.
  - "optional" - Specifying this argument is optional. This attribute is mutually exclusive with "required."

- "value\_help" - Indicates that the valid values for a one\_of\_string argument should be listed whenever argument help is shown.
- "values {<list of allowable values>}" - If the argument type is one\_of\_string, you must specify the "values" attribute.
- "type\_name <name>" - Give a descriptive name to the type that this argument supports. Some applications may use this information to provide features for automatically generated dialogs, etc. Please see product documentation for details. This attribute is not supported on boolean options.
- "merge\_duplicates" - When this option appears more than once in a command, its values are concatenated into a list of values. The default behavior is that the right-most value for the option specified is used.
- "remainder" - Specifies that any additional positional arguments should be returned in this option. This option is only valid for string option types, and by default the option is optional. You can require at least one item to be specified by also including the required option.
- "deprecated" - Specifying this option is deprecated i.e. it should no longer be used but is still available. A warning will be output if this option is specified. This attribute cannot be combined with obsolete or required.
- "obsolete" - Specifying this option is obsolete i.e. it used to exist but can no longer be used. A warning will be output if this option is specified. This attribute cannot be combined with deprecated or required.
- "min\_value" <value> - Specify the minimum value for this option. This attribute is only valid for integer and float types.
- "max\_value" <value> - Specify the maximum value for this option. This attribute is only valid for integer and float types.
- "default" <value> - Specify the default value for this option. This attribute is only valid for string, integer and float option types. If the user does not specify this option when invoking the command this default value will be automatically passed to the associated tcl procedure.

The default for *attributes* is "required."

Use the **-define\_arg\_groups** to define argument checking groups. The format of this option is a list where each element in the list defines an option group. Each element has the following format:

```
{<type> {<opt1> <opt2> ...} [<attributes>]}
```

The types of groups are

- *"exclusive"* Only one option in an exclusive group is allowed. All the options in the group must have the same required/optional status. This group can contain any number of options.
- *"together"* If the first option in the group is specified then the second argument is also required. This type of group can contain at most two options.
- *"related"* These options are related to each other. An automatic dialog builder for this command may try to group these options together.

The supported attributes are:

- *"label" <text>* An optional label text to identify this group. The label may be used by an application to automatically build a grouping in a generated dialog.
- *"bidirectional"* This is only valid for a together group. It means that both options must be specified together.

Change the command group of the procedure using the **-command\_group** command. Protect the contents of the procedure from being viewed by using **-hide\_body**. Prevent further modifications to the procedure by using **-permanent**. Prevent abbreviation of the procedure by using **-dont\_abbrev**.

---

## EXAMPLES

The following procedure adds two numbers together and returns the sum. For demonstration purposes, unused arguments are defined.

```

prompt> proc plus {a b} { return [expr $a + $b]}

prompt> define_proc_attributes plus -info "Add two numbers" \
? -define_args {
  {a "first addend" a string required}
  {b "second addend" b string required}
  {"-verbose" "issue a message" "" boolean optional}}

prompt> help -verbose plus
Usage: plus  # Add two numbers
[-verbose]   (issue a message)
a            (first addend)
b            (second addend)

prompt> plus 5 6
11

```

In the following example, the `argHandler` procedure accepts an optional argument of each type supported by **`define_proc_attributes`**, then displays the options and values received. Note the only one of `-Int`, `-Float`, or `-Bool` may be specified to the command:

```

proc argHandler {args} {
  parse_proc_arguments -args $args results
  foreach argname [array names results] {
    echo $argname = $results($argname)
  }
}

define_proc_attributes argHandler \
-info "Arguments processor" \
-define_args {
  {-Oos "oos help" AnOos one_of_string
   {required value_help {values {a b}}}}
  {-Int "int help" AnInt int optional}
  {-Float "float help" AFloat float optional}
  {-Bool "bool help" "" boolean optional}
  {-String "string help" AString string optional}
  {-List "list help" AList list optional}
  {-IDup "int dup help" AIDup int {optional merge_duplicates}}
} \
-define_arg_groups {
  {exclusive {-Int -Float -Bool}}
}

```

---

## SEE ALSO

```

help(2)
info(2)
parse_proc_arguments(2)
proc(2)
sh_command_abbrev_mode(3)

```

---

## diagnose

Runs diagnosis on the most recent verification that failed. By default, this command diagnoses the implementation design.

---

### SYNTAX

```
integer diagnose  
  [failing_compare_points]  
  [-pattern_limit limit]  
  [-effort_level low | medium | high]  
  [-r]  
  [-all]
```

#### Data Types

```
failing_compare_points string  
limit integer
```

---

### ENABLED SHELL MODES

Verify

---

### ARGUMENTS

#### *failing\_compare\_points*

Specifies a list of failing compare points to be diagnosed in the following form:

```
{cp1 cp2 ...}
```

Use wildcard characters to match multiple points. By default, this command considers all compare points.

#### **-pattern\_limit** *limit*

Specifies the maximum number of failing patterns to consider during diagnosis. The limit must be an integer. The default for the *limit* argument is 256 patterns. For more information about failing patterns, see the *Formality User Guide*.

#### **-effort\_level** low | medium | high

Specifies the effort level for the diagnosis engine. The default effort level is **medium**.

#### **-r**

Diagnoses the reference design. By default, the command diagnoses the implementation design.

#### **-all**

Diagnoses all failing compare points.

---



## DESCRIPTION

This command runs diagnosis on the most recent verification that failed.

If you run the **diagnose** command before performing verification, the tool reports the following error:

Error: You must perform verification before diagnosis

Use the list of error candidates that the command identifies to isolate problem areas in a failing design. A successful diagnosis identifies error candidates with single or multiple errors. Use the **report\_error\_candidates** command to view error candidates. For conceptual information about error candidates, see the *Formality User Guide*.

The **diagnose** command also identifies the corresponding matching regions in the matched design. For example, if you diagnosed an implementation design, matching regions are identified in the reference design. Set the *diagnosis\_enable\_find\_matching\_regions* Tcl variable to **false** to turn off matching regions.

Interrupting the **diagnose** command stops processing and any diagnosis results are lost. The tool does not retain partial diagnosis results.

During diagnosis, the tool uses a maximum of 256 failing patterns, by default, that apply to the failing compare points. Use the **pattern\_limit** option to use a maximum failing pattern limit other than the default or the value set by using the **diagnosis\_pattern\_limit** Tcl variable.

For best error resolution, diagnose the whole design without specifying any arguments. This might sometimes fail to return any potential errors, such as the FM-417 or FM-420 errors. In such cases, to diagnose a group of failing compare points, specify a list of compare points. If this also fails, diagnose a single compare point. For single compare points, the command diagnoses only the logic cone that defines the specified compare point.

---

## EXAMPLES

The following example shows a failed verification and the subsequent diagnosis. The transcript notes the associated designs and provides a verification and diagnosis progress report. The number of failing patterns applied over the entire design is the maximum of 256.

```
prompt> verify
Reference design is 'r:/WORK/chkblk'
Implementation design is 'i:/WORK/chkblk'

***** Matching Results *****

353 Compare points matched by name
.br
0 Compare points matched by signature analysis
.br
0 Compare points matched by topology
.br
173 Matched primary inputs, black box outputs
.br
0(0) Unmatched reference(implementation) compare points
.br
0(0) Unmatched reference(implementation) primary inputs, black box outputs
.br
*****

Status: Verifying...

Compare point bd_gop_hdr_exist_reg failed (is not equivalent)

Compare point bd_au_count_reg_0_ failed (is not equivalent)
```

Compare point bd\_au\_count\_reg\_1\_ failed (is not equivalent)

Compare point bd\_au\_count\_reg\_2\_ failed (is not equivalent)

Compare point bd\_au\_count\_reg\_3\_ failed (is not equivalent)

Compare point bd\_au\_count\_reg\_4\_ failed (is not equivalent)

Compare point bd\_au\_count\_reg\_5\_ failed (is not equivalent)

\*\*\*\*\* Verification Results \*\*\*\*\*

Verification FAILED

ATTENTION: RTL interpretation messages were produced during link of reference design.

Verification results may disagree with a logic simulator.

-----  
Reference design: r:/WORK/chkblk  
Implementation design: i:/WORK/chkblk  
346 Passing compare points  
7 Failing compare points  
0 Aborted compare points  
-----

Matched Compare Points BBPin Loop BBNet Cut Port DFF LAT TOTAL

-----  
Passing (equivalent) 0 0 0 0 137 209 0 346  
Failing (not equivalent) 0 0 0 0 0 7 0 7  
Not Compared  
Constant reg 3 0 3  
-----

\*\*\*\*\*

prompt> **diagnose**

Status: Diagnosing i:/WORK/chkblk vs r:/WORK/chkblk...

Status: Diagnosis initializing...

Status: Analyzing patterns...

Single error detected in implementation.

Single error detected in implementation design.

Number of error candidates: 3

Analysis completed

Status: Finding matching regions in reference design...

Single matching region detected in reference design.

Diagnosis completed

1

fm\_shell (verify)>

---

## SEE ALSO

report\_diagnosed\_matching\_regions(2)  
report\_error\_candidates(2)  
report\_failing\_points(2)  
report\_passing\_points(2)

---

## discard\_edits

Removes all design copies created by **edit\_design**.

---

### SYNTAX

**discard\_edits**

#### Enabled Shell Modes

Setup  
Match  
Verify

---

### DESCRIPTION

This command removes all the edited designs created by the **edit\_design** command. Any edits done are lost unless they have previously been applied using the **apply\_edits** or **verify\_edits** commands.

---

### EXAMPLES

Edit a design and then discard the edits:

```
fm_shell (verify)> edit_design i:/WORK/bot  
fm_shell (verify)> create_net ECO_NET_1  
fm_shell (verify)> discard_edits
```

---

### SEE ALSO

[apply\\_edits\(2\)](#)  
[create\\_net\(2\)](#)  
[edit\\_designs\(2\)](#)  
[verify\\_edits\(2\)](#)

---

## disconnect\_net

Disconnects a net from one or more pins.

---

### SYNTAX

```
status disconnect_net  
  net_name  
  pin_list  
  -all
```

#### Data Types

```
net_name string  
pin_list list
```

---

### RETURN VALUE

The **disconnect\_net** command returns a status of 1 if it was successful and 0 if it failed.

---

### ARGUMENTS

#### *net\_name*

Disconnects the specific net. You can specify either an object ID or an instance-based path.

The command disconnects nets in a design and the changes are visible to all instances of the design. To only affect a specific instance-based path, unify the instance of the design before running this command.

#### *pin\_list*

Disconnects the specified pins from the net. You can specify either object IDs or instance-based paths. You must specify either the *pin\_list* or the *-all* option.

#### *-all*

Disconnects all pins from a net. You must specify either the *pin\_list* or the *-all* option.

---

### DESCRIPTION

This command removes the connections between a net and one or more pins. The net and pins are not removed.

You can specify pins that are directly on the given net segment itself or pins that are connected to other segments of the net.

The *-all* option removes the pins directly connected to the given net without considering any other segments of the net.

To connect pins to a net, use the **connect\_net** command.

Outside of Setup mode, this command only works on edit designs created using the **edit\_design** command.

---

## EXAMPLES

The following example shows how to disconnect all pins from net i1 and two pins from net i2.

```
fm_shell (setup)> current_instance r:/WORK/top/m1
fm_shell (setup)> disconnect_net i1 -all
fm_shell (setup)> disconnect_net i2 {b1/in1 b2/out1}
```

---

## SEE ALSO

`connect_net(2)`  
`current_design(2)`  
`current_instance(2)`  
`edit_design(2)`

---

## echo

Displays the values of the specified arguments.

---

### SYNTAX

**echo**

*[-n] [argument]*

**Data Types**

*argument* string

---

### ARGUMENTS

**-n**

Suppresses the default new-line behavior.

***argument***

Specifies the arguments to be displayed.

---

### DESCRIPTION

This command returns the values of the given arguments. Use the **echo** command to display the value of variables, expressions, and text strings. When you specify a list of arguments, separate them with a space.

By default, each value appears on a new line. When you use the **-n** switch, multiple values are printed in the same line. To redirect the output, use the ">" and ">>" operators.

---

### EXAMPLES

```
fm_shell> echo "Running version" $sh_product_version
Running version v3.0a
fm_shell> echo -n "Printing to" [expr (3 - 2)] > foo
fm_shell> echo " line." >> foo
fm_shell> sh cat foo
Printing to 1 line.
```

---

### SEE ALSO

sh(2)

---

## edit\_design

Edit a copy of the specified design.

---

### SYNTAX

```
edit_design
  design
  [ -hierarchy ]
```

#### Data Types

*design* string

#### Enabled Shell Modes

Setup  
Match  
Verify

---

### ARGUMENTS

#### *design*

Specifies the name of the design to edit.

#### *-hierarchy*

Make editable copies of all the designs instantiated by "*design*" recursively down the hierarchy.

---

### DESCRIPTION

This command creates a copy of the specified design. The copy will be placed in a separate library meant for modifications via edit commands (such as **create\_net** and **disconnect\_net**). The design is only copied if it has not already been copied for edit.

This command sets the **current\_design** to the editable design.

When it returns to setup mode, Formality will either apply the edits to the original designs, or discard the edited designs. See the man page for the **setup** command for details.

---

### EXAMPLES

Edit a design:



```
fm_shell (verify)> edit_design i:/WORK/bot  
fm_shell (verify)> create_net ECO_NET_1
```

---

## SEE ALSO

`create_net(2)`  
`disconnect_net(2)`  
`setup(2)`

---

## elaborate\_library\_cells

Resolves cell references before verifying the library. This command is available only in the library verification mode.

---

### SYNTAX

**elaborate\_library\_cells**

---

### DESCRIPTION

Use this command to link cell instances after reading in both libraries. Apply verification constraints after this command has completed. If constraints are not necessary, use the **verify** command to complete the verification of the libraries after they both are read in.

---

### EXAMPLES

This example elaborates cells in both libraries.

```
fm_shell> elaborate_library_cells
```

---

### SEE ALSO

[verify\(2\)](#)

---

## elapsed\_time

Returns the number of seconds of wall clock time elapsed since Formality started.

---

### SYNTAX

**elapsed\_time**

---

### ARGUMENTS

none

---

### DESCRIPTION

This command returns the amount of wall clock time, in seconds, elapsed since Formality started.

---

### EXAMPLES

The following example shows the output produced by the **elapsed\_time** command.

```
fm_shell (match)> elapsed_time
1342
fm_shell (match)>
```

---

## end\_alterate\_strategies

End alternate strategies runs.

---

### SYNTAX

**end\_alterate\_strategies**  
-directory *pathname*  
[ -strategies *strategies\_list* ]

#### Data Types

*pathname* string  
*strategies\_list* string

---

### ARGUMENTS

#### -directory *pathname*

Specifies the directory where the strategies are being run.

#### -strategies *strategies\_list*

Specifies the list of strategies to be stopped.

---

### DESCRIPTION

This command provides a way of stopping some or all of the alternate strategies that were run using the **run\_alterate\_strategies** command.

The option -directory is required to identify the run that is being stopped.

If option -strategies is not specified, all the strategies are stopped.

---

### EXAMPLES

The following example ends all alternate strategies runs in directory ras.

```
fm_shell> end_alterate_strategies -directory ras
```

## SEE ALSO

`run_alternate_strategies(2)`

---

## error\_info

Displays detailed information on errors that are reported by the previous command.

---

### SYNTAX

**error\_info**

---

### DESCRIPTION

This command displays detailed information about errors reported by the previous command. When an error occurs, the **error\_info** command helps you identify the exact line in the block that caused the error.

---

### EXAMPLES

In this example, the iterator variable "s" is not dereferenced in the 'if' statement. It should be "\$s == "a" ".

```
fm_shell> foreach s $my_list {  
?   if { s == "a" } {  
?     echo "Found 'a!'"  
?   }  
? }  
Error: syntax error in expression " s == "a" "  
      Use error_info for more info. (CMD-013)  
fm_shell> error_info  
Extended error info:  
syntax error in expression " s == "a" "  
while executing  
"if { s == a } {  
  echo "Found 'a'"  
}"  
("foreach" body line 2)  
invoked from within  
"foreach s [list a b c] {  
  if { s == a } {  
    echo "Found 'a'"  
  }  
}"  
-- End Extended Error Info
```

---

## exit

Terminates the application.

---

### SYNTAX

integer **exit**  
[*exit\_code*]

#### Data Types

*exit\_code*    integer

---

### ARGUMENTS

*exit\_code*

Specifies the return code to the operating system. The default value is 0.

---

### DESCRIPTION

This command exits from the application. You have the option to specify a code to return to the operating system.

---

### EXAMPLES

The following example exits the current session and returns the code 5 to the operating system. At a UNIX operating system prompt, verify (**echo**) the return code as shown.

```
prompt> exit 5

% echo $status
5
```

---

### SEE ALSO

quit(2)

---

## filter\_collection

Filters an existing collection, resulting in a new collection. The base collection remains unchanged.

---

### SYNTAX

```
collection filter_collection
  [-regex]
  [-nocase]
  collection1
  expression
```

#### Data Types

<i>collection1</i>	collection
<i>expression</i>	string

---

### ARGUMENTS

#### -regex

Specifies that the =~ and !~ filter operators will use real regular expressions. By default, the =~ and !~ filter operators use simple wildcard pattern matching with the \* and ? wildcards.

#### -nocase

Makes the pattern match case-insensitive.

#### *collection1*

Specifies the base collection to be filtered. This collection is copied to the result collection. Objects are removed from the result collection if they are evaluated as **false** by the conditional *expression* value. Substitute the collection you want for *collection1*.

#### *expression*

Specifies an expression with which to filter *collection1*. Substitute the string you want for *expression*.

---

### DESCRIPTION

Filters an existing collection, resulting in a new collection. The base collection remains unchanged.

In many cases, application commands that create collections support a *-filter* option that filters as part of the collection process, rather than after the collection has been made. This type of filtering is almost always more efficient than using the **filter\_collection** command after a collection has been formed. The **filter\_collection** command is most useful if you plan to filter the same large collection many times using different criteria.

The **filter\_collection** command results in either a new collection or an empty string. A resulting new collection contains the subset of the objects in the input *collection1*. A resulting empty string (the empty collection) indicates that the *expression* filtered out all elements of the input *collection1*.

The basic form of the conditional expression is a series of relations joined together with AND and OR operators. Parentheses () are



also supported. The basic relation contrasts an attribute name with a value through a relational operator. For example,

```
is_inverted == true and direction == in
```

The value side of a relation can be a simple string, quoted string, or an attribute name prefixed with "@". For example:

```
input_delay<=@output_delay
input_delay<=0.24
name=="@literal_name"
```

The relational operators are

```
== Equal
!= Not equal
> Greater than
< Less than
>= Greater than or equal to
<= Less than or equal to
=~ Matches pattern
!~ Does not match pattern
```

The basic relational rules are

- String attributes can be compared with any operator.
- Numeric attributes cannot be compared with pattern match operators.
- Boolean attributes can be compared only with == and !=. The value can be only either *true* or *false*.

The **filter\_collection** command has a *-regexp* option that uses regular expressions when matching for string attributes. Regular expression matching is done in the same way as in the Tcl **regexp** command. When using the *-regexp* option, take care in the way you quote the filter *expression*. Using rigid quoting with curly braces around regular expressions is recommended.

Regular expressions are always anchored; that is, the expression is assumed to begin matching at the beginning of an object name and end matching at the end of an object name. You can widen the search simply by adding "." to the beginning or end of the expressions as needed. You can make the regular expression search case-insensitive by using the *-nocase* option.

---

## EXAMPLES

The following example from Formality creates a collection of only techlib cells.

```
prompt> set a [filter_collection \
? [get_cells *] "is_techlib == true"]
{r:/WORK/top/U1 r:/WORK/top/U2}
```

The following example from Formality does the same as above, but using the *-filter* option of the **get\_cells** command.

```
prompt> set a [get_cells * -filter "is_techlib == true"]
{r:/WORK/top/U1 r:/WORK/top/U2}
```

The following shows how to use the *-filter* option of the **get\_cells** command to only return the AND gates.

```
prompt> get_cells $ref/* -filter {@cell_type == "AND"}
{r:/WORK/top/C1 r:/WORK/top/C2}
```

---

## SEE ALSO

```
collections(2)
get_cells(2)
regexp(2)
```

---

## find\_cells

Lists cells in the current design.

---

### SYNTAX

```
collection find_cells
  [-of_objectID objectID]
  [-library_cells | -nolibrary_cells]
  [-type ID_type]
  [cellID_list]
```

#### Data Types

```
objectID string
ID_type string
cellID_list string
```

---

### ARGUMENTS

#### **-of\_objectID *objectID***

Specifies a pin to which returned cells are connected or specifies the design in which the returned cells are located.

#### **-library\_cells**

Include cells referenced from technology library cells in the cell list.

#### **-nolibrary\_cells**

Includes the cells that are not referenced from technology library cells in the cell list.

#### **-type *ID\_type***

Resolves conflicts between design objects specified by using the **-of\_object** option that are of different types but have the same name. Specify one of the following ID types:

- *pin* for a pin type
- *design* for a design

#### ***cellID\_list***

Lists object IDs in the current design. Each object ID must resolve to an object of type *cell*.

---

### DESCRIPTION

This command lists cells in the current design.

If you use this command without specifying a list of cell names or object IDs, the command lists all the cells in the current design by default.

The tool returns the following string if you have not established a current design:

Error: The current design is not set. A design must be specified.

To return a list of cells, specify a list of object IDs that are defined as cell types. To list cells that are connected to specific object IDs, use the **-of\_objectID** option. For example, to list cells attached to a specific pin:

```
find_cells -of_objectID objectID
```

To limit the list of cells that are reported by this command to those referenced or not referenced from a technology library, use the **-library\_cells** switch or the **-nolibrary\_cells** switch, respectively.

If you use the **find\_cells** command with the **-of\_objectID** option and specify a design ID argument, the tool returns a list of cells in the current design that are instantiated from the specified design ID.

If you use the **-of\_objectID** option and you know that naming conflicts exist for the specified *objectID*, you can use the **-type** option to resolve those objects.

The **find\_cells** command returns a list of cell names.

---

## EXAMPLES

The following examples demonstrate how to use the **find\_cells** command to obtain information about cells in the current design. In these examples the current design is named */WORK/mR4000*.

The following example returns a list of all cells.

```
prompt> find_cells {ref:/WORK/mR4000/Instruction_reg[0]}  
ref:/WORK/mR4000/register
```

The following example lists cells that are instantiations of a design named **mA1u**.

```
prompt> find_cells -of_objectID ref:/*/mA1u  
ref:/WORK/mR4000/alu
```

The following example lists cells in a design named **mA1u**.

```
prompt> find_cells ref:/*/mA1u/*/  
ref:/WORK/mA1u/U403 ... ref:/WORK/mA1u/r23
```

The following example lists cells that are not references of technology library cells.

```
prompt> find_cells -nolibrary_cells  
ref:/WORK/mR4000/alu ... ref:/WORK/mR4000/register
```

---

## SEE ALSO

- current\_design(2)
- find\_nets(2)
- find\_pins(2)
- find\_ports(2)
- find\_references(2)
- list\_libraries(2)

---

## find\_compare\_points

Returns a list of compare points affected by the specified design objects.

---

### SYNTAX

```
find_compare_points  
  -edits | objectID_list | -edits objectID_list  
  [ -list | -collection ]  
  [ -type ID_type ]  
  [ -status status_type ]
```

#### Data Types

*ID\_type* string  
*status\_type* string  
*objectID* string

---

### ARGUMENTS

#### -edits

Identifies fan out compare points from edits that are made using editing commands such as **create\_cell** and **connect\_net**. When combined with an *objectID\_list* the compare point fan out is determined from edits in designs specified by the *objectID\_list* argument. You cannot use the *-type* option with the **-edits** option.

#### *objectID\_list*

Specifies design objects from which to start looking for compare points when the *-edits* option is not specified. If you specify a name consisting of a wildcard expression that resolves to more than one object, the operation is applied to all the matching objects. However, if the name resolves to multiple objects with identical names and you do not specify the object type, only one of these objects is used in the following precedence: pin, port, net, cell.

#### -list

Reports compare points as a Tcl list. You can use this list in further Tcl processing.

#### -collection

Reports compare points as a collection. You can use this collection in further Tcl processing.

#### -type *ID\_type*

Specifies the type of the objects to use from the *objectID\_list*. Use this option if the name of the specified design object is associated with more than one object type in the same design. Specify one of the following object types:

- *pin* - to specify pin type
- *port* - to specify port type
- *net* - to specify net type
- *cell* - to specify cell type

#### -status *status\_type*

Limits the compare points to those with a specific status. Specify one of the following:

- *passing* - to specify passing compare points
- *failing* - to specify failing compare points
- *aborted* - to specify aborted compare points
- *unverified* - to specify unverified compare points
- *unmatched* - to specify unmatched compare points
- *not\_compared* - to specify disabled compare points

---

## DESCRIPTION

This command returns a report of the compare points which are in the fan out of the specified ObjectIDs or edits. By default, the command returns a report with one compare point per line. This command is useful for ECO modifications, where a change to one or more design objects is made and you want to find the affected compare points. You can then verify the affected points using multiple point verification with the **set\_verify\_points** command.

If the **-list** option is specified, the command returns a Tcl list of compare points.

By default, the **find\_compare\_points** command returns compare points regardless of their status. However, you can limit the search to only compare points with certain statuses using one or more **-status** options.

---

## EXAMPLES

The following example returns all the compare points that structurally depend on a given design object.

```
fm_shell> find_compare_points r:/WORK/top/n123
(DFF)  r:/WORK/top/mult1/mult2/prod_preiso_reg[7]
(DFF)  r:/WORK/top/mult1/mult2/prod_preiso_reg[8]
(DFF)  r:/WORK/top/mult1/mult2/prod_preiso_reg[9]
(Port)  r:/WORK/top/prod[0]
(Port)  r:/WORK/top/prod[10]
```

This example shows how to obtain a Tcl list of all compare points affected by edits.

```
fm_shell> find_compare_points -edits -list
{i:/WORK/top/sum[11]} {i:/WORK/top/sum[12]} {i:/WORK/top/sum[13]}
{i:/WORK/top/sum[14]} {i:/WORK/top/sum[15]}
```

This example shows how to report all compare points affected by edits in the design i:/WORK/block142.

```
fm_shell> find_compare_points -edits i:/WORK/block142
(DFF)  i:/WORK/block142/prod[0]
(DFF)  i:/WORK/block142/prod[1]
(Port)  i:/WORK/block142/early[0]
(Port)  i:/WORK/block142/early[1]
```

This example shows how to obtain a Tcl list of all failing and unverified compare points affected by edits.

```
fm_shell> find_compare_points -edits -list -status failing -status unverified
{i:/WORK/top/sum[13]} {i:/WORK/top/sum[14]} {i:/WORK/top/sum[15]} {i:/WORK/top/carry1}
```

---

## SEE ALSO

```
set_verify_points(2)  
verify_edits(2)
```

---

## find\_cutpoint\_pins

Finds potential cutpoints on the specified instance.

---

### SYNTAX

```
int find_cutpoint_pins  
  object gP  
  [-in_fanin_of instance]  
  [-type type]  
  [-exclude exclude_list]  
  [-filter filter_list]
```

#### Data Types

```
instance string  
type string  
exclude_list list  
filter_list list
```

---

### ENABLED SHELL MODES

Match Verify

---

### ARGUMENTS

#### ***object***

Find potential cutpoints on all pins matching the specified object in reference and implementation. Use wildcard characters to match multiple objects.

#### ***-type type***

Used to specify the object type of the compare point when using '*-in\_fanin\_of*'. This can be one of:

- cell
- net
- pin
- port

#### ***-exclude exclude\_list***

Exclude the specified list of pins. Specify the list of pins to be exclude as follows:

```
{pin1 pin2 ...}
```

#### ***-filter filter\_list***

Filter based on specified list of conditions. Options are as follows:

- filter {direction <input | output | both>}
- filter {instance\_logic\_size <logic\_size>}
- filter {pin\_fanin\_logic\_size <logic\_size>}
- filter {pin\_fanin\_dontcare\_size}

Examples of these filters and their usage are shown in the examples section.

---

## DESCRIPTION

This command generates a potential list of cutpoints that can be inserted on the matching pins of the specified instance. Furthermore, cutpoints can be filtered based on a specified compare point, pin direction, pin fan-in logic/dont care size. The exclude option helps exclude pins on which cutpoints need not be inserted.

Verification can become hard because of a combination of factors such as:

- Datapath instances
- Dontcare sources
- Large XOR trees
- Un-isolated powerdomain crossings
- Ungrouped design instances

Running this command can be a debugging aid when dealing with such hard verifications. Many of these hard verifications can be resolved by adding cuts. One of the best places to add cuts is on pins of design instances. This command serves this purpose by generating potential cuts on pins of the specified instances. The filter option helps refine the cutpoints further based on size, direction, fanin logic etc.

---

## EXAMPLES

The following examples shows the usage of the command:

```
fm_shell (match)> find_cutpoint_pins *add1*
Analyzing Object : r:/WORK/top/add1
set_cutpoint -type pin r:/WORK/top/add1/clock
set_cutpoint -type pin i:/WORK/top/add1/clock
set_cutpoint -type pin r:/WORK/top/add1/data1[0]
set_cutpoint -type pin i:/WORK/top/add1/data1[0]
set_cutpoint -type pin r:/WORK/top/add1/data1[1]
set_cutpoint -type pin i:/WORK/top/add1/data1[1]
set_cutpoint -type pin r:/WORK/top/add1/data1[2]
set_cutpoint -type pin r:/WORK/top/add1/reset
set_cutpoint -type pin i:/WORK/top/add1/reset
set_cutpoint -type pin r:/WORK/top/add1/sum1[0]
set_cutpoint -type pin i:/WORK/top/add1/sum1[0]
```

The following example shows usage of filters such as the exclude and direction. Cuts on pin : clk, reset are excluded because of the exclude filter. Cuts on pin : sum1 is excluded because the direction filter was specified.

```
fm_shell (match)> find_cutpoint_pins *add1* -exclude {*clk*,*reset*} -filter {direction input}
set_cutpoint -type pin r:/WORK/top/add1/data1[0]
set_cutpoint -type pin i:/WORK/top/add1/data1[0]
set_cutpoint -type pin r:/WORK/top/add1/data1[1]
set_cutpoint -type pin i:/WORK/top/add1/data1[1]
set_cutpoint -type pin r:/WORK/top/add1/data1[2]
set_cutpoint -type pin i:/WORK/top/add1/data1[2]
```

The following example demonstrates how multiple filters can be used to refine cutpoints. Cuts on pin : clk, reset are excluded because



of the exclude filter. Cuts on input pins are excluded because the direction filter was specified. Cuts are generated only on pins that are in the fan-in of instance : r:/WORK/top/sum1[7], whose object type is port. Cuts are generated only on the pins of the instance that have a fan-in logic greater than the specified number.

```
fm_shell (match)> find_cutpoint_pins *add1* -exclude {*clk*,*reset*} -filter {direction output} -filter {pin_fanin_logic_size 1} -in_fanin_of r:/WORK/top/sum1[7] -type  
set_cutpoint -type pin r:/WORK/top/add1/sum1[7]  
set_cutpoint -type pin i:/WORK/top/add1/sum1[7]
```

---

## SEE ALSO

[analyze\\_cones\(2\)](#)

---

## find\_designs

Returns a list of designs in the current design.

---

### SYNTAX

collection **find\_designs**  
[*object\_list*]  
[-passing]  
[-failing]  
[-aborted]  
[-not\_verified]

#### Data Types

*object\_list* string

---

### ARGUMENTS

#### *object\_list*

Specifies objects in the current workspace.

#### **-passing**

Specifies designs that have passed the most recent verification.

#### **-failing**

Specifies designs that have failed the most recent verification.

#### **-aborted**

Specifies designs that have aborted during the most recent verification.

#### **-not\_verified**

Specifies designs that are not verified during the most recent verification.

---

### DESCRIPTION

This command returns a list of designs when you specify an object list. If you do not specify a list of designs or object IDs, the tool lists all the designs that are loaded.

To list designs with a specific verification status, specify the appropriate switch. The verification status is based on the most recent verification. If verification is not performed, the verification status of all designs is "not verified."

The **-passing**, **-failing**, and **-aborted** switches are applicable only to implementation designs because the tool verifies implementation designs. The **-not\_verified** switch is applicable to all designs.

If a matching design is not found, the command does not return anything. Otherwise, the command returns one of the following:

- 0 to indicate failure
- List of designs names for success

---

## EXAMPLES

The following example lists all designs currently loaded. Due to the large number of designs, this example shows only a partial listing.

```
prompt> find_designs -failing  
impl:/WORK/impl impl:/WORK/myor2 impl:/WORK/myor2_reg
```

```
prompt> find_designs -passing  
impl:/WORK/myopt2 impl:/WORK/myreg
```

```
prompt> find_designs -not_verified  
impl:/WORK/myand2 impl:/WORK/myand2_reg ...
```

```
prompt> find_designs -passing impl:/*opt*  
impl:/WORK/myopt2
```

...

```
prompt>
```

---

## SEE ALSO

```
find_cells(2)  
find_pins(2)  
find_ports(2)  
find_references(2)  
list_libraries(2)  
report_designs(2)
```

---

## find\_drivers

Returns a list of drivers of the specified net.

---

### SYNTAX

```
status find_drivers  
[-hier]  
net_name
```

#### Data Types

*net\_name* string

---

### RETURN VALUE

The **find\_drivers** command returns a list of drivers, each specified by absolute path, of the given net, or 0 if it failed.

---

### ARGUMENTS

#### **-hier**

Lists drivers across the specified hierarchy.

#### **net\_name**

Lists the drivers of the specified net. The net must be specified as either an absolute or relative to (**current\_instance**) the instance-based path.

---

### DESCRIPTION

The command finds and returns a list of all drivers of the net. All technology library cell output pins or top-level input ports of the net segment (or across hierarchy, if "-hier" is specified) are returned. Note that if the **-hier** option is not specified, cellpins are returned.

---

### EXAMPLES

The following example shows how to find all local drivers of net r:/WORK/top/M1/B1/o1.

```
fm_shell > find_drivers r:/WORK/top/M1/n1  
r:/WORK/top/M1/B1/o1
```

The following example shows how to drivers across hierarchy for the same net

```
fm_shell > find_drivers -hier r:/WORK/top/M1/n1  
r:/WORK/top/M1/B1/C1/Z
```

Note that the same results could be obtained using **current\_instance** and relative paths:

```
fm_shell > current_instance r:/WORK/top  
fm_shell > find_drivers M1/n1  
r:/WORK/top/M1/B1/o1
```

---

## SEE ALSO

```
find_receivers(2)  
current_instance(2)  
create_net(2)  
connect_net(2)
```

---

## find\_equivalent\_nets

Finds nets in the implementation design that are equivalent to the specified nets.

---

### SYNTAX

```
status find_equivalent_nets  
[ -nets candidateNet_list ]  
[ -list ]  
[ -fanin ]  
[ inputNet_list ]
```

#### Data Types

*candidateNet\_list* list  
*inputNet\_list* list

#### Enabled Shell Modes

Match  
Verify

---

### ARGUMENTS

#### ***-nets candidateNet\_list***

Restricts the search for equivalent nets to the specified list of nets. The candidate nets must be from the implementation design. Any other net in this list is ignored. If this option is not specified, the command finds all equivalent nets in the implementation design.

#### ***-list***

Reports equivalent nets as a Tcl list. You can use this list in further Tcl processing.

#### ***-fanin***

Look up-stream for nets with equivalences, if no equivalences are found.

#### ***inputNet\_list***

Specifies a list of nets whose equivalences are to be found. This list of nets can be any combination of reference and implementation nets.

---

### DESCRIPTION

This command finds nets in the implementation design that are equivalent to the specified nets. The input net can be either a reference or implementation net. An equivalent net can either be positively (identical) or negatively (inverse) equivalent to the input net.

By default, the command searches the entire implementation design for all instances of nets that are equivalent to the input net. You can restrict the search to specific nets using the **-nets** option. The list of nets must be implementation design nets. Any other net in the candidate list is ignored. The **find\_region\_of\_nets** command can be used to build lists of candidate nets.

The default output of the command is a report that lists each input net followed by its equivalences. The input net together with its equivalences form an equivalence class. The **-list** option produces a Tcl list output of equivalence classes which is amenable for further processing in a Tcl script.

The format of an equivalence class is as follows:

```
<input_net> <class_type> { <equiv_net1> <polarity> <equiv_net2> <polarity> ... }
```

<input\_net> is the input net whose equivalences were found

The <class\_type> field is one of the following values:

- +**  
Normal equivalence class
- ?**  
The equivalence class timed out or was interrupted by the user. All equivalences may not be listed. A timeout value for **find\_equivalent\_nets** is set using the **equivalent\_nets\_timeout\_limit** variable.
- 0**  
The input net of this class is a constant 0
- 1**  
The input net of this class is a constant 1
- X**  
The input net of this class is a constant X
- The list following <class\_type> consists of pairs of equivalent nets and its polarity with respect to the input net.  
The <polarity> field can be one of the following:
  - +**  
The equivalent net function is identical to the input net function.
  - The equivalent net function is the inverse of the input net function.
  - ?**  
The equivalent net and the input net are highly similar, but Formality could not conclusively prove equivalence.

---

## EXAMPLES

The following examples show how to use the **find\_equivalent\_nets** command.

```
fm_shell (match)> find_equivalent_nets -list r:/WORK/m1/b1/r1
{ r:/WORK/m1/b1/r1 + { r:/WORK/m1/b1/r2 + i:/WORK/m1/b1/r1 - } }

fm_shell (match)> find_equivalent_nets -list r:/WORK/m1/b1/r1
{ r:/WORK/m1/b1/r1 ? { r:/WORK/m1/b1/r2 + r:/WORK/m1/b2/r3 - i:/WORK/m1/b1/r1 ? } }
```

The following example shows a report of nets that are equivalent to *r:/WORK/rt11/PORTB[1]*:

```
fm_shell (verify)> find_equivalent_nets r:/WORK/rtl1/PORTB[1]
--- Equivalent Nets:
  Ref Net + r:/WORK/rtl1/PORTB[1]
  Impl Net + i:/WORK/rtl1/U27/B
  Impl Net + i:/WORK/rtl1/U11/A
  Impl Net + i:/WORK/rtl1/U7/A
  Impl Net + i:/WORK/rtl1/U36/B
  Impl Net + i:/WORK/rtl1/PORTB[1]
```

The following example shows how to use the `-nets` option to constrain the search space of candidate equivalent nets to implementation nets in failing cones:

```
fm_shell (verify)> set region [find_region_of_nets -implementation -failing]
fm_shell (verify)> find_equivalent_nets -nets $region r:/WORK/rtl1/PORTB[1]
--- Equivalent Nets:
  Ref Net + r:/WORK/rtl1/PORTB[1]
  Impl Net + i:/WORK/rtl1/U27/B
  Impl Net + i:/WORK/rtl1/U11/A
```

---

## SEE ALSO

```
equivalent_nets_timeout_limit(3)
find_region_of_nets(2)
```



---

## find\_nets

Returns a list of nets in the current design.

---

### SYNTAX

```
find_nets  
  object_list  
  [ -hierarchy ]  
  -of_objectID objectID  
  -type ID_type
```

#### Data Types

```
object_list string  
objectID string  
ID_type string
```

---

### ARGUMENTS

#### ***object\_list***

Specifies one or more object IDs in the current design. For information on how to specify an object ID, see the *Formality User Guide*.

#### **-hierarchy**

Includes nets instantiated below the specified designs.

#### **-of\_objectID *object\_ID***

Includes the nets connected to the specified pin or port. For information on how to specify an object ID, see the *Formality User Guide*.

#### **-type *ID\_type***

Resolves conflicts between design objects referenced with the *-of\_object* option that are of different types but share the same name. Specify one of the following values for the *ID\_type* argument:

- *pin* for a pin type
- *port* for a port type

---

### DESCRIPTION

This command returns a list of nets.

To list nets connected to specific object IDs, specify the *-of\_object* option. For example, to list nets attached to a specific pin, use the following command:

```
find_nets -of_objectID objectID
```

When you use the `-of_objectID objectID` option, to resolve naming conflicts in the design, use the `-type` option.

When you don't specify a list of nets or object IDs, the command lists all nets by default.

The tool reports the following error if a current design is not established:

Error: The current design is not set. A design must be specified.

Otherwise, the **find\_nets** command returns one of the following:

- 0 to indicate failure
- List of net names

---

## EXAMPLES

The following example lists the nets in the current design. Due to the large number of nets, this example shows a partial listing.

```
fm_shell> find_nets
ref:/WORK/CORE/CC
ref:/WORK/CORE/CCEN
ref:/WORK/CORE/CIN
...
ref:/WORK/CORE/Y_9
ref:/WORK/CORE/ZERO
fm_shell>
```

---

## SEE ALSO

```
find_cells(2)
find_pins(2)
find_ports(2)
find_references(2)
list_libraries(2)
```

---

## find\_pins

Returns a list of pins in the current design.

---

### SYNTAX

```
find_pins  
[ -of_objectID objectID ]  
[ -in ]  
[ -out ]  
[ -inout ]  
[ -hierarchy ]  
[ -type type ]  
[pinID_list]
```

#### Data Types

```
objectID string  
object_list string  
type string
```

---

### ARGUMENTS

#### **-of\_objectID *objectID***

Specifies a cell or net connected to the pins. For information on how to specify an object ID, see the *Formality User Guide*.

#### **-in**

Includes the input pins in the pin list.

#### **-out**

Includes the output pins in the pin list.

#### **-inout**

Includes the bidirectional pins in the pin list.

#### **-hierarchy**

Includes pins that are connected at all levels of the hierarchy in the pin list.

#### **-type *type***

Resolves conflicts between design objects referenced in the *-of\_object* option that are of different types but have the same name. Specify one of the following values for the *ID\_type* argument:

- *cell* for a cell type
- *net* for a net type

#### **pinID\_list**

Specifies a list of pin names.

---

## DESCRIPTION

This command returns a list of pins.

To find pins connected to a specific net or cell, use the *-of\_object* option:

**find\_pins** *-of\_objectID objectID*

If you use the *-of\_objectID* option, and you know that naming conflicts exist for the specified *objectID*, use the *-type* option to resolve the conflicts.

Filter the list for pins of a certain type by specifying the *-in*, *-out*, or *-inout* options.

Use the *-hierarchy* switch to return a list of pins that crosses hierarchical bounds. This allows you to see every pin connected in a hierarchical design.

The tool lists all the pins when you use the **find\_pins** command without specifying a list of pins or without using the *-of\_objectID* option.

The tool reports the following error if a current design is not established:

Error: The current design is not set. A design must be specified.

Otherwise, the **find\_pins** command returns one of the following:

- 0 to indicate failure
- List of pin names

---

## EXAMPLES

The following example lists all pins in the current design. Due to the large number of pins, this example shows a partial listing.

```
fm_shell> find_pins
ref:/WORK/CORE/CC
ref:/WORK/CORE/CCEN
ref:/WORK/CORE/CIN
...
ref:/WORK/CORE/Y_7
ref:/WORK/CORE/Y_8
ref:/WORK/CORE/Y_9
fm_shell>
```

---

## SEE ALSO

find\_cells(2)  
find\_nets(2)  
find\_ports(2)  
find\_references(2)  
list\_libraries(2)

---

## find\_ports

Returns a list of ports in the current design.

---

### SYNTAX

**find\_ports**  
[ -of\_objectID *ID* ]  
[ -in ]  
[ -out ]  
[ -inout ]  
[ -type *type* ]  
[portID\_list]

#### Data Types

*objectID* string  
*object\_list* string  
*ID\_type* string

---

### ARGUMENTS

#### -of\_objectID *ID*

Specifies a net or design connected to the returned ports. For information on how to specify an object ID, see the *Formality User Guide*.

#### -in

Includes input ports in the list of ports.

#### -out

Includes output ports in the list of ports.

#### -inout

Includes bidirectional ports in the list of ports

#### -type *type*

Resolves conflicts between design objects referenced with the *-of\_objectID* option that are of different types but have the same name. Specify one of the following values for the type ID:

- *net* for a net type
- *design* for a design

#### portID\_list

Specifies a list of port names.

---

## DESCRIPTION

This command returns a list of ports in the current design.

To find ports that are connected to a specific net or design, specify the *-of\_objectID* option:

**find\_ports** *-of\_objectID objectID*

If you use the *-of\_objectID* option, and you know that naming conflicts exist for the specified *objectID*, use the *-type* option to help you resolve the conflicts.

Filter the list for pins of a certain type by specifying the *-in*, *-out*, or *-inout* switches.

When you use the **find\_ports** command without specifying a list of ports or without using the *-of\_objectID* option, it reports all the ports by default.

The tool reports the following error if the current design is not established:

Error: The current design is not set. A design must be specified.

Otherwise, the **find\_ports** command returns one of the following:

- 0 to indicate failure
- List of port names for success

---

## EXAMPLES

The following example lists all ports in the current design. Due to the large number of ports, this example shows a partial listing.

```
fm_shell> find_ports
ref:/WORK/CORE/CC
ref:/WORK/CORE/CCEN
ref:/WORK/CORE/CIN
...
ref:/WORK/CORE/Y_7
ref:/WORK/CORE/Y_8
ref:/WORK/CORE/Y_9
fm_shell>
```

---

## SEE ALSO

find\_cells(2)  
find\_nets(2)  
find\_pins(2)  
find\_references(2)  
list\_libraries(2)

---

## find\_receivers

Returns a list of all receivers for the given net.

---

### SYNTAX

```
status find_receivers  
[-hier]  
net_name
```

#### Data Types

*net\_name* string

---

### RETURN VALUE

The **find\_receivers** command returns a list of receivers, each specified by absolute path, of the given net, or 0 if it failed.

---

### ARGUMENTS

#### **-hier**

Lists receivers across the specified hierarchy.

#### **net\_name**

Lists receivers of the specified net. This net must be specified as either an absolute or relative to instance-based path.

---

### DESCRIPTION

This command lists receivers of the specified net. Technology library cell input pins or top-level output ports of the net segment (or across the specified hierarchy) are returned. Note that if the **-hier** option is not specified, the command lists cell pins.

---

### EXAMPLES

The following example shows how to find all local receivers of net r:/WORK/top/M1/B1/o1.

```
fm_shell > find_receivers r:/WORK/top/M1/B1/o1  
r:/WORK/top/M1/B1/o1
```

The following example shows how to receivers across hierarchy for the same net  
fm\_shell > **find\_receivers** -hier r:/WORK/top/M1/B1/o1

```
r:/WORK/top/M1/C1/A
```

Note that the same results could be obtained using the **current\_instance** command and relative paths:

```
fm_shell > current_instance r:/WORK/top  
fm_shell > find_receivers M1/B1/o1  
r:/WORK/top/M1/B1/o1
```

---

## SEE ALSO

```
find_drivers(2)  
current_instance(2)  
create_net(2)  
connect_net(2)
```



---

## find\_references

Returns a list of designs instantiated within the current design.

---

### SYNTAX

#### **find\_references**

[ -of\_objectID *cellID* ]  
[ -hierarchy ]  
[ -black\_box ]  
[designID\_list]

#### Data Types

*objectID* string  
*design\_list* string

---

### ARGUMENTS

#### ***designID\_list***

Specifies one or more design IDs from which to generate a list of instantiated designs. For information on how to specify a design ID, see the *Formality User Guide*.

#### **-of\_objectID *cellID***

Specifies the cell whose design name is returned. Each *objectID* must resolve to an object defined as a cell type.

#### **-hierarchy**

Includes all designs that are instantiated below the specified designs.

#### **-black\_box**

Includes black boxes and unlinked devices.

#### **designID\_list**

Specifies a list of design within which the tool will look for design references.

---

### DESCRIPTION

This command returns a list of designs instantiated within the specified designs or within the current design.

When you use the **find\_references** command without specifying a list of *designIDs* or a particular cell's *objectID*, it reports all the designs within the current design, by default.

The command reports the following error if you have not established a current design:

Error: The current design is not set. A design must be specified.

The **find\_references** command returns one of the following:

- 0 to indicate failure
- List of designs for success

---

## EXAMPLES

The following examples first set the current design and then generate a list of designs located within the current design. In these examples, the current design is /WORK/mR4000.

```
fm_shell> current_design ref:*/mR4000
ref:/WORK/mR4000
fm_shell> find_references
ao4a2 ao7a1 ... oa1f0 oa1f1
```

The following example returns the designs instantiated within design mR4000.

```
fm_shell> find_references ref:*/mA1u
and3b1 and8a1 ... or3b1 or4b1
```

The following example returns the designs referenced by cell mR4000/U160.

```
fm_shell> find_references -of_objectID ref:*/mR4000/U160
buf1a4
```

The following example returns all design references at all levels of hierarchy. In this case, the instantiated designs within the current design are listed because the current design was not linked.

```
fm_shell> find_references -hierarchy
ao4a2 ao7a1 ... oa1f0 oa1f1
```

The following example lists design references that are unlinked or are black boxes.

```
fm_shell> find_references -hierarchy
ao4a2 ao7a1 ... oa1f0 oa1f1
```

In the preceding example, the instantiated designs within the current design are listed because the current design was not linked. If the current design was linked, the list would appear like this:

```
ref:/CBA_CORE/and2b1 ... ref:/WORK/mRegister
```

---

## SEE ALSO

```
find_cells(2)
find_nets(2)
find_pins(2)
find_ports(2)
list_libraries(2)
```

---

## find\_region\_of\_nets

Lists nets that define a region in the design.

---

### SYNTAX

```
status find_region_of_nets  
[ -cells <cells_list> | -recursive ]  
[ -reference ]  
[ -implementation ]  
[ -failing ]  
[ comparePoint_list ]
```

#### Data Types

*cells\_list* list  
*comparePoint\_list* list

#### Enabled Shell Modes

Match  
Verify

---

### ARGUMENTS

#### *comparePoint\_list*

Returns a collection of nets in the cones of the specified compare points. Matching compare points are implicitly included in this list.

#### *-cells <cells\_list>*

Returns a collection of nets contained in the specified cells.

#### *-recursive*

Includes nets in cells contained within the specified cells when this option is specified with the *-cells* option.

#### *-failing*

Includes nets in the fan-in cones of the failing compare points.

#### *-reference*

Includes only reference nets.

#### *-implementation*

Includes only implementation nets.

## DESCRIPTION

This command generates a collection of nets. The collection can be stored in Tcl variables and passed to other Formality commands such as **find\_equivalent\_nets**, for example to limit the search space to a particular region of the design.

Collections of nets can be computed in the following ways:

### Using a List of Compare Points

When you specify a list of compare points using the **find\_region\_of\_nets** command, it returns a collection of nets in the fan-in cone of each compare-point. The command also implicitly includes nets from the matching compare-point cones.

### From Cells

When you specify a list of cell names using the **-cells** option, the command returns a list of nets within the specified cells. Nets from sub-cells can be included by recursively descending down the hierarchy using the **-recursive** option.

### From Failing Compare Points

You can list nets from the fan-in cone of all failing compare points using the **-failing** option. You can use the **-reference** and **-implementation** options to include only reference or implementation nets respectively.

---

## EXAMPLES

The following example finds nets in the fan-in cones of two compare points,

```
fm_shell (match)> find_region_of_nets {r:/WORK/m1/b1/r1 r:/WORK/m1/b2/r1}
```

The following example finds nets in the top level reference design:

```
fm_shell (match)> find_region_of_nets -cells $ref
```

The following example finds implementation nets in the fan-in cones of failing points:

```
fm_shell (match)> find_region_of_nets -failing -implementation
```

---

## SEE ALSO

`find_equivalent_nets(2)`

---

## find\_segments

Returns a list of all segments, across the hierarchy of the design, for the given net.

---

### SYNTAX

status **find\_segments**  
*net\_name*

#### Data Types

*net\_name* string

#### Enabled Shell Modes

Setup

---

### RETURN VALUE

The **find\_segments** command returns a list of segments, each specified by absolute path, of the given net, or 0 if it failed.

---

### ARGUMENTS

*net\_name*

Lists segments of the specified net. Specify this must be specified as either an absolute or relative (to **current\_instance**) instance-based path.

---

### DESCRIPTION

This command returns a list of segments for the specified net, each specified as an absolute path.

---

### EXAMPLES

The following example shows how to find the net segments of the net: r:/WORK/top/M1/B1/o1 using an absolute path to o1.

```
fm_shell (setup)> find_segments r:/WORK/top/M1/B1/o1  
r:/WORK/top/M1/B1/o1 r:/WORK/top/M1/n1
```

The following example shows how to find the same segments using the **current\_instance** command.

```
fm_shell (setup)> current_instance r:/WORK/top/M1/B1  
fm_shell (setup)> find_segments o1
```

r:/WORK/top/M1/B1/o1 r:/WORK/top/M1/n1

---

## SEE ALSO

current\_instance(2)  
create\_net(2)  
connect\_net(2)

---

## find\_svf\_operation

Finds automated setup (SVF) operation ID numbers based on either command name or operation status, or both.

---

### SYNTAX

```
find_svf_operation  
[ -command command_name ]  
[ -status status_name ]  
[ compare_points_list ]
```

#### Data Types

```
command_name string  
status_name string  
compare_points_list string
```

---

### ARGUMENTS

#### **-command *command\_name***

Specifies the name of the guide command to search for. You need not specify the **guide\_** prefix of the command name. Repeat this option to search for multiple commands. Use the following **guide\_transformation** sub-types:

- *map*
- *merge*
- *share*
- *tree*

#### **-status *status\_name***

Specifies the name of a status to search for. The list returned includes only ID numbers for commands that have the specified status. The option might be repeated to search for multiple statuses. Specify one of the following values for the *status\_name* argument:

- *unprocessed* - The operation is read but not yet processed.
- *accepted* - The operation has successfully processed and is applied.
- *rejected* - The processing of the operation failed and the operation is not applied.
- *unsupported* - The tool does not support the operation.
- *unaccepted* - Any status other than accepted.

#### **compare\_points\_list**

Specifies a compare point or a list of compare points. The command searches the fanin of the specified compare points and finds all automated setup (SVF) operations that match by cell name. Use regular expressions to specify points.

## DESCRIPTION

Use this command to generate a Tcl list of automated setup (SVF) operation IDs. You can use the list as the argument with the **report\_svf\_operation** command.

You can optionally specify a list of points and find SVF operations in their fanin cone.

## EXAMPLES

```
fm_shell (match)> find_svf_operation -status rejected
3 9 10 11 12
```

```
fm_shell (setup)> find_svf_operation -command map
4 5 6 7
```

```
fm_shell (setup)> find_svf_operation $ref/U1/point1
5 8
```

```
fm_shell (setup)> find_svf_operation -command transformation
3 4 5 6 7
```

```
fm_shell (setup)> find_svf_operation -command uniquify
2 8
```

```
fm_shell (verify)> report_svf_operation -summary [find_svf_operation -status rejected]
```

Operation	Line	Command	Status
3	22	transformation_tree	rejected
9	95	change_names	rejected
10	114	change_names	rejected
11	133	change_names	rejected
12	153	change_names	rejected

```
1
```

```
fm_shell (verify)> report_svf_operation [ find_svf_operation -status rejected -command tree ]
```

SVF Operation 3 (Line: 22) - transformation\_tree. Status: rejected

## Operation Id: 3

```
guide_transformation \
-design { test } \
-type { tree } \
-input { 16 src1 } \
-input { 16 src2 } \
-input { 16 src4 } \
-input { 16 src6 } \
-input { 16 src8 } \
-output { 18 O1 } \
-pre_resource { { 17 } add_5 = UADD { { src1 ZERO 17 } { src2 ZERO 17 } } } \
-pre_resource { { 18 } add_5_2 = UADD { { add_5 ZERO 18 } { src4 ZERO 18 } } } \
-pre_resource { { 18 } add_5_3 = UADD { { add_5_2 } { src6 ZERO 18 } } } \
-pre_resource { { 18 } sub_5 = USUB { { add_5_3 } { src8 ZERO 18 } } } \
-pre_assign { O1 = { sub_5 } } \
-post_resource { { 18 } add_3_root_sub_5 = UADD { { src1 ZERO 18 } { src2 ZERO 18 } } } \
-post_resource { { 18 } add_2_root_sub_5 = UADD { { src4 ZERO 18 } { src6 ZERO 18 } } } \
-post_resource { { 18 } add_1_root_sub_5 = UADD { { add_3_root_sub_5 } { add_2_root_sub_5 } } } \
-post_resource { { 18 } sub_0_root_sub_5 = USUB { { add_1_root_sub_5 } { src8 ZERO 18 } } } \
-post_assign { O1 = { sub_0_root_sub_5 } }
```

Info: guide\_transformation 3 (Line: 22) Could not find pre\_resource 'sub\_5' in design 'test'.

```
1
```

```
fm_shell (setup)> find_svf_operation -command datapath -status rejected $ref/U1/HardPoints*
14 24 31
```



## SEE ALSO

- `remove_guidance(2)`
- `report_svf_operation(2)`
- `report_guidance(2)`
- `set_svf(2)`

---

## foreach\_in\_collection

Iterates over the elements of a collection.

---

### SYNTAX

```
string foreach_in_collection  
    itr_var  
    collections  
    body
```

#### Data Types

<i>itr_var</i>	string
<i>collections</i>	list
<i>body</i>	string

---

### ARGUMENTS

#### *itr\_var*

Specifies the name of the iterator variable.

#### *collections*

Specifies a list of collections over which to iterate.

#### *body*

Specifies a script to execute per iteration.

---

### DESCRIPTION

The **foreach\_in\_collection** command is used to iterate over each element in a collection. You cannot use the Tcl-supplied **foreach** command to iterate over collections because the **foreach** command requires a list, and a collection is not a list.

The arguments for the **foreach\_in\_collection** command parallel those of the **foreach** command: an iterator variable, the collections over which to iterate, and the script to apply at each iteration. All arguments are required.

Note: The **foreach\_in\_collection** command does not allow a list of iterator variables.

During each iteration, the *itr\_var* option is set to a collection of exactly one object. Any command that accepts *collections* as an argument also accepts *itr\_var* because they are of the same data type (collection).

You can nest the **foreach\_in\_collection** command within other control structures, including another **foreach\_in\_collection** command.

Note that if the body of the iteration is modifying the netlist, it is possible that all or part of the collection involved in the iteration will be deleted. The **foreach\_in\_collection** command is safe for such operations. If a command in the body causes the collection to be removed, at the next iteration, the iteration ends with a message indicating that the iteration ended prematurely.

An alternative to collection iteration is to use complex filtering to create a collection that includes only the desired elements, then apply one or more commands to that collection. If the order of operations does not matter, the following are equivalent. The first is an example without iterators.

```
set s [get_cells {U1/*}]
command1 $s
command2 $s
unset s
```

The following is a similar approach using the **foreach\_in\_collection** command:

```
foreach_in_collection itr [get_cells {U1/*}] {
  command1 $itr
  command2 $itr
}
```

For collections with large numbers of objects, the non-iterator version is more efficient, though both produce the same results if the commands are order-independent.

---

## EXAMPLES

The following example from Formality sets constants on the output ports of the current instance by using a filter with the **get\_ports** command.

```
prompt> set op [get_ports -filter {direction == "out"}]
prompt> set_constant $op 0
Set 'r:/WORK/top/M1/o1' to constant 0
Set 'r:/WORK/top/M1/o2' to constant 0
```

The following example from Formality does the same as above, but using iteration and the Tcl **if** command to do the filtering.

```
prompt> foreach_in_collection itr [get_ports] {
?   if {[get_attribute $itr direction] == "out"} {
?     set_constant $itr 0
?   }
? }
Set 'r:/WORK/top/M1/o1' to constant 0
Set 'r:/WORK/top/M1/o2' to constant 0
```

---

## SEE ALSO

```
collections(2)
foreach(2)
get_ports(2)
set_constant(2)
```

---

## generate\_eco\_map\_file

Generates *guide\_eco\_change* commands for an RTL that has been modified for ECO.

---

### SYNTAX

```
generate_eco_map_file  
[ -replace ] file  
[ -uncomment_single_operator_mappings ]
```

#### Data Types

*file* string

---

### ARGUMENTS

#### -replace

Specifies that the file specified by the *file* argument replaces an existing ECO map file.

#### -uncomment\_single\_operator\_mappings

Automatically map operators when only a single mapping option is available.

#### *file*

Specifies the name of the file in which to save the ECO map information. Supply the full pathname or only the file name. If you do not specify the directory information, the tool writes information to the current working directory.

---

### DESCRIPTION

Use this command to generate *guide\_eco\_map* commands for an ECO modification.

Before issuing this command, you must load the original design as the reference, the ECO-modified design as the implementation, and both the original automated setup file (SVF) from synthesis and the *guide\_eco\_change* automated setup commands that are generated by using the *fm\_eco\_to\_svf* script.

You must manually inspect the resulting SVF file and uncomment the correct mappings. In the case of *-uncomment\_single\_operator\_mappings*, Formality automatically uncomments mappings if there is only one mapping choice. You should still validate that this is the desired behavior. It is possible for an operator to not be mapped to anything.

Map the operators if they perform the same function, have the same type, and have the same size inputs and outputs.

---

### EXAMPLES

The following example writes the ECO map information to the file named *eco\_map.svf* in the current working directory.

```
fm_shell> generate_eco_map_file -replace eco_map.svf  
Info: wrote file 'eco_map.svf'
```

---

## SEE ALSO

`guide_eco_map(2)`  
`guide_eco_change(2)`

---

## get\_app\_var

Gets the value of an application variable.

---

### SYNTAX

```
string get_app_var  
  [-default | -details | -list]  
  [-only_changed_vars]  
  var
```

#### Data Types

*var*    string

---

### ARGUMENTS

#### -default

Gets the default value.

#### -details

Gets additional variable information.

#### -list

Returns a list of variables matching the pattern. When this option is used, then the *var* argument is interpreted as a pattern instead of a variable name.

#### -only\_changed\_vars

Returns only the variables matching the pattern that are not set to their default values, when specified with **-list**.

#### *var*

Specifies the application variable to get.

---

### DESCRIPTION

The **get\_app\_var** command returns the value of an application variable.

There are four legal forms for this command:

- **get\_app\_var <var>**  
Returns the current value of the variable.
- **get\_app\_var <var> -default**  
Returns the default value of the variable.

- `get_app_var <var> -details`

Returns more detailed information about the variable. See below for details.

- `get_app_var -list [-only_changed_vars] <pattern>`

Returns a list of variables matching the pattern. If *-only\_changed\_vars* is specified, then only variables that are changed from their default values are returned.

In all cases, if the specified variable is not an application variable, then a Tcl error is returned, unless the application variable **sh\_allow\_tcl\_with\_set\_app\_var** is set to true. See the **sh\_allow\_tcl\_with\_set\_app\_var** man page for details.

When **-details** is specified, the return value is a Tcl list that is suitable as input to the Tcl **array set** command. The returned value is a list with an even number of arguments. Each odd-numbered element in the list is a key, and each even-numbered element in the list is the value of the previous key.

The supported keys are as follows:

*name*

This key contains the name of the variable. This key is always present.

*value*

This key contains the current value of the variable. This key is always present.

*default*

This key contains the default value of the variable. This key is always present.

*help*

This key contains the help string for the variable. This key is always present, but sometimes the value is empty.

*type*

This key contains the type of the application variable. Legal values of for this key are: string, bool, int, real. This key is always present.

*constraint*

This key describes additional constraints placed on this variable. Legal values for this key are: none, list, range. This key is always present.

*min*

This key contains the min value of the application variable. This key is present if the constraint is range. The value of this key may be the empty string, in which case the variable only has a max value constraint.

*max*

This key contains the max value of the application variable. This key is present if the constraint is "range". The value of this key may be the empty string, in which case the variable only has a min value constraint.

*list*

This key contains the list of legal values for the application variable. This key is present if the constraint is "list".

---

## EXAMPLES

The following are examples of the **get\_app\_var** command:

```
prompt> get_app_var sh_enable_page_mode
1

prompt> get_app_var sh_enable_page_mode -default
false

foreach {key val} [get_app_var sh_enable_page_mode -details] { echo "$key: $val"
}
=>  name: sh_enable_page_mode
    value: 1
    default: false
    help: Displays long reports one page at a time
    type: bool
    constraint: none

prompt> get_app_var -list sh_*message
sh_new_variable_message
```

---

## SEE ALSO

```
report_app_var(2)
set_app_var(2)
write_app_var(2)
```



---

## get\_attribute

Retrieves the value of an attribute on an object or on a collection of objects.

---

### SYNTAX

```
string get_attribute
  [-class class_name]
  [-quiet]
  [-value_list]
  object_spec
  attr_name
```

#### Data Types

<i>class_name</i>	string
<i>object_spec</i>	string or collection
<i>attr_name</i>	string

---

### ARGUMENTS

#### **-class *class\_name***

Specifies the class name of the *object\_spec* option, provided the *object\_spec* option is a name. The valid values for the *class\_name* option are *lib*, *lib\_cell*, *lib\_pin*, *design*, *port*, *cell*, *pin*, and *net*.

#### **-quiet**

Indicates that any error and warning messages are not reported.

#### **-value\_list**

Indicates that the return value should be a list, even if there is only a single object specified to retrieve the attribute. Normally, the return value of the **get\_attribute** command is a string if there is only a single object, and a list if multiple objects are specified.

#### ***object\_spec***

Specifies an object from which to retrieve the attribute value. The *object\_spec* option must be either a collection of one or more objects, or a name which is combined with the *class\_name* option to find the object. If the *object\_spec* option is a name, you must also use the *-class* option.

#### ***attr\_name***

Specifies the name of the attribute where the value is retrieved.

---

### DESCRIPTION

Retrieves the value of an attribute on an object or on a collection of objects. The object is either a string name of exactly one object, or a collection of one or more objects. If it is a name, the *-class* option is required. The return value is a string or a list of strings if multiple objects are specified to retrieve an attribute.

---

## EXAMPLES

The following example gets the value of the *direction* attribute for all ports whose names begin with OUT:

```
prompt> get_attribute [get_ports OUT*] direction
out out inout out
```

The following example gets all registers, and for each register prints the register's *full\_name* attribute and then gets the register's lib cell and prints the lib cell's *library\_name* attribute.

```
prompt> foreach_in_collection sel [all_registers] {
?   echo -n "lib cell of '[get_attribute $sel full_name]' "
?   echo "is in library [get_attribute [get_lib_cell -of_object $sel] library_name]"
? }
lib cell of 'r:/WORK/top/hold_reg' is in library cmos_slow
lib cell of 'r:/WORK/top/M1/frst_reg' is in library cmos_fast
lib cell of 'r:/WORK/top/M1/scnd_reg' is in library cmos_fast
```

---

## SEE ALSO

all\_registers(2)  
collections(2)  
foreach\_in\_collection(2)  
get\_lib\_cell(2)  
get\_ports(2)  
help\_attributes(2)  
list\_attributes(2)

---

## get\_cells

Creates a collection of cells from the current design relative to the current instance. You can assign these cells to a variable or pass them into another command.

---

### SYNTAX

```
collection get_cells
[-exact]
[-hierarchical]
[-quiet]
[-filter expression]
[patterns | -of_objects objects]
```

#### Data Types

<i>expression</i>	string
<i>objects</i>	list
<i>patterns</i>	list

---

### ARGUMENTS

#### -exact

Considers wildcards to be plain characters, and does not interpret their meaning as wildcards.

#### -hierarchical

Searches for cells level-by-level relative to the current instance. The full name of the object at a particular level must match the patterns. The search is similar to the UNIX **find** command. For example, if there is a cell block1/adder, a hierarchical search finds it using "adder".

#### -quiet

Suppresses warning and error messages if no objects match. Syntax error messages are not suppressed.

#### -filter *expression*

Filters the collection with the *expression* value. For any cells that match *patterns* or *objects*, the expression is evaluated based on the cell's attributes. If the expression evaluates to true, the cell is included in the result.

#### -of\_objects *objects*

Creates a collection of cells connected to the specified objects. In this case, each object is either a named pin, a pin collection, a named net or a net collection. The *-of\_objects* and *patterns* options are mutually exclusive; you can specify only one. In addition, you cannot use the *-hierarchical* option with the *-of\_objects* option.

#### *patterns*

Matches cell names against patterns. Patterns can include the wildcard characters "\*" and "?". Patterns can also include collections of type cell. The *patterns* and *-of\_objects* options are mutually exclusive; you can specify only one.

If you do not specify a pattern, the command uses \* (asterisk) as the default pattern.

---

## DESCRIPTION

This command creates a collection of cells in the current design, relative to the current instance, that match certain criteria. The command returns a collection if any cells match the *patterns* or *objects* option and passes the filter (if specified). If no objects match the criteria, an empty string is returned.

You can use the **get\_cells** command at the command prompt, or you can nest it as an argument to another command. For example, you can use it in the **query\_objects** command. In addition, you can assign the **get\_cells** result to a variable.

When issued from the command prompt, the **get\_cells** command behaves as though the **query\_objects** command had been called to display the objects in the collection. By default, a maximum of 100 objects is displayed; you can change this maximum using the **collection\_result\_display\_limit** variable.

The "implicit query" property of the **get\_cells** command provides a fast, simple way to display cells in a collection. However, if you want the flexibility provided by the **query\_objects** command (for example, if you want to display the object class), use the **get\_cells** command as an argument to the **query\_objects** command.

For information about collections and querying of objects, see the **collections** man page.

---

## EXAMPLES

The following example queries the cells that begin with "o" and reference an FD2 library cell. Although the output looks like a list, it is not. The output is just a display.

```
prompt> get_cells "o*" -filter "ref_name == FD2"
{r:/WORK/top/o_reg1 r:/WORK/top/o_reg2 r:/WORK/top/o_reg3 r:/WORK/top/o_reg4}
```

The following example shows that, given a collection of pins, you can query the cells connected to those pins.

```
prompt> set pinset [get_pins o*/CP]
{r:/WORK/top/o_reg1/CP r:/WORK/top/o_reg2/CP}

prompt> query_objects [get_cells -of_objects $pinset]
{r:/WORK/top/o_reg1 r:/WORK/top/o_reg2}
```

The following example shows that, given a collection of cells, you can set those cells as verify points.

```
prompt> set_verify_points [get_cells R*]
Set verify point 'r:/WORK/bot/R0_reg'
Set verify point 'r:/WORK/bot/R1_reg'
```

---

## SEE ALSO

collections(2)  
filter\_collection(2)  
get\_pins(2)  
query\_objects(2)  
set\_verify\_points(2)  
collection\_result\_display\_limit(3)

---

## get\_command\_hooks

Get registered hooks for this command

---

### SYNTAX

string **get\_command\_hooks** *commandName*

string *commandName*

---

### ARGUMENTS

*commandName*

Command to query

---

### DESCRIPTION

The **get\_command\_hooks** command returns information about any hooks registered on the specified command. The data returned is in Tcl dict format and may be queried using that command.

---

### EXAMPLES

When a command has both before and after hooks registered the data will look like this

```
prompt> get_command_hooks place_opt
before {before0 report_timing}
after {after0 {echo "Done with placement"}}
```

---

### SEE ALSO

add\_command\_hook(2)  
remove\_command\_hook(2)  
get\_current\_hook\_command(2)  
dict(2)

---

## get\_command\_option\_values

Queries current or default option values.

---

### SYNTAX

**get\_command\_option\_values**  
[-default | -current]

-command *command\_name*

#### Data Types

*command\_name*    string

---

### ARGUMENTS

#### -default

Gets the default option values, if available.

#### -current

Gets the current option values, if available.

#### -command *command\_name*

Gets the option values for this command.

---

### DESCRIPTION

This command attempts to query a default or current value for each option (of the command) that has default and/or current-value-tracking enabled. Details of how the option value is queried depend on whether one of the **-current** or **-default** options is specified (see below).

A "Tcl array set compatible" (possibly empty) list of option names and values is returned as the Tcl result. The even-numbered entries in the list are the names of options that were enabled for default-value-tracking or current-value-tracking and had at least one of these values set to a not-undefined value). Each odd-numbered entry in the list is the default or current value of the option name preceding it in the list.

Any options that were not enabled for either default-value-tracking nor current-value-tracking are omitted from the output list. Similarly, options that were enabled for default-value-tracking or current-value-tracking, but for which no (not-undefined) default or current value is set, are omitted from the result list.

If neither **-current** nor **-default** is specified, then for each command option that has either default-value-tracking or current-value-tracking (or both) enabled, the value returned is as follows:

- The current value is returned if current-value-tracking is enabled and a (not-undefined) current value has been set;

- Otherwise the default value is returned if default-value-tracking is enabled and a (not-undefined) default value has been set;
- Otherwise the name and value pair for the option is not included in the result list.

If **-current** is specified, the value returned for an option is the current value if current-value-tracking is enabled, and a (not-undefined) current value has been set; otherwise the name and value pair for the option is omitted from the result list.

If **-default** is specified, the value returned for an option is the default value if default-value-tracking is enabled, and a (not-undefined) default value has been set; otherwise the name and value pair for the option is omitted from the result list.

The result list from **get\_command\_option\_values** includes option values of both dash options and positional options (assuming that both kinds of options of a command have been enabled for value-tracking).

The command issues a Tcl error in a variety of situations, such as if an invalid command name was passed in with **-command**.

---

## EXAMPLES

The following example shows the use of **get\_command\_option\_values**:

```
prompt> test -opt1 10 -opt2 20
1
```

```
prompt> get_command_option_values -command test
-bar1 10 -bar2 20
```

---

## SEE ALSO

preview(2)  
set\_command\_option\_value(2)

---

## get\_current\_hook\_command

Get the currently running command string

---

### SYNTAX

string **get\_current\_hook\_command**

---

### ARGUMENTS

---

### DESCRIPTION

The **get\_current\_hook\_command** command may only be run from within a command hook. The command returns the command string used to invoke the command.

Note that option values may have been abbreviated when the hooked command was executed. In that case the information returned will also include abbreviated option values.

---

### SEE ALSO

[add\\_command\\_hook\(2\)](#)  
[remove\\_command\\_hook\(2\)](#)  
[get\\_command\\_hooks\(2\)](#)



---

## get\_defined\_commands

Get information on defined commands and groups.

---

### SYNTAX

```
string get_defined_commands [-details]  
    [-groups]  
    [pattern]  
  
string pattern
```

---

### ARGUMENTS

#### **-details**

Get detailed information on specific command or group.

#### **-groups**

Search groups rather than commands

#### ***pattern***

Return commands or groups matching pattern. The default value of this argument is "".

---

### DESCRIPTION

The **get\_defined\_commands** gets information about defined commands and command groups. By default the command returns a list of commands that match the specified pattern.

When **-details** is specified, the return value is a list that is suitable as input to the **array set** command. The returned value is a list with an even number of arguments. Each odd-numbered element in the list is a key name, and each even-numbered element in the list is the value of the previous key. The **-details** option is only legal if the pattern matches exactly one command or group.

When **-group** is specified with **-details**, the supported keys are as follows:

#### *name*

This key contains the name of the group.

#### *info*

This key contains the short help for the group.

#### *commands*

This key contains the commands in the group

When **-details** is used with a command, the supported keys are as follows:

*name*

This key contains the name of the command.

*info*

This key contains the short help for the command.

*groups*

This key contains the group names that this command belongs to.

*options*

This key contains the options defined for the command. The value is a list.

*return*

This key contains the return type for the command.

Each element in the *options* list also follows the key value pattern. The set of available keys for options are as follows:

*name*

This key contains the name of the option.

*info*

This key contains the short help for the option.

*value\_info*

This key contains the short help string for the value

*type*

The type of the option.

*required*

The value will be 0 or 1 depending if the option is optional or required.

*is\_list*

Will be 1 if the option requires a list.

*list\_length*

If a list contains the list length constraint. One of any, even, odd, non\_empty or a number of elements.

*allowed\_values*

The allowed values if the option has specified allowed values.

*min\_value*

The minimum allowed value if the option has specified one.

*max\_value*

The maximum allowed value if the option has specified one.

---

## EXAMPLES

```
prompt> get_defined_commands *collection
```

```
add_to_collection append_to_collection copy_collection filter_collection
foreach_in_collection index_collection sort_collection
prompt> get_defined_commands -details sort_collection
name sort_collection info {Create a sorted copy of the collection}
groups {} options {{name -descending info {Sort in descending order}
value_info {} type boolean required 1 is_list 0} {name -dictionary info
{Sort strings dictionary order.} value_info {} type boolean required 1
is_list 0} {name collection info {Collection to sort} value_info
collection type string required 0 is_list 0} {name criteria info {Sort
criteria - list of attributes} value_info criteria type list required 0
is_list 1 list_length non_empty}}
```

---

## SEE ALSO

help(2)  
man(2)

---

## get\_designs

Creates a collection of designs. You can assign these designs to a variable or pass them into another command.

---

### SYNTAX

collection **get\_designs**  
[-exact]  
[-hierarchical]  
[-quiet]  
[-filter *expression*]  
*patterns*

#### Data Types

<i>expression</i>	string
<i>patterns</i>	list

---

### ARGUMENTS

#### -exact

Considers wildcards to be plain characters, and does not interpret their meaning as wildcards.

#### -hierarchical

Searches for designs inferred by the design hierarchy relative to the current instance. The full name of the object at a particular level must match the patterns.

#### -quiet

Suppresses warning and error messages if no objects match. Syntax error messages are not suppressed.

#### -filter *expression*

Filters the collection with the *expression* value. For any designs that match *patterns*, the expression is evaluated based on the design's attributes. If the expression evaluates to true, the design is included in the result.

#### *patterns*

Matches design names against patterns. Patterns can include the wildcard characters "\*" and "?". Patterns can also include collections of type design.

If you do not specify a pattern, the command uses \* (asterisk) as the default pattern.

---

### DESCRIPTION

This command creates a collection of designs that match certain criteria. The command returns a collection if any designs match the *patterns* option and pass the filter, if specified. If no objects matched your criteria, an empty string is returned.

You can use the **get\_designs** command at the command prompt, or you can nest it as an argument to another command. For example, you can use it in the **query\_objects** command. In addition, you can assign the **get\_designs** result to a variable.

When issued from the command prompt, the **get\_designs** command behaves as though the **query\_objects** command had been called to display the objects in the collection. By default, a maximum of 100 objects is displayed; you can change this maximum using the **collection\_result\_display\_limit** variable .

The "implicit query" property of the **get\_designs** command provides a fast, simple way to display designs in a collection. However, if you want the flexibility provided by the **query\_objects** command (for example, if you want to display the object class), use the **get\_designs** command as an argument to the **query\_objects** command.

For information about collections and the querying of objects, see the **collections** man page.

---

## EXAMPLES

The following example queries the designs that begin with 'mpu.' Although the output looks like a list, it is just a display.

```
prompt> get_designs mpu*
{/WORK/top/mpu_0_0 r:/WORK/top/mpu_0_1 r:/WORK/top/mpu_1_0 r:/WORK/top/mpu_1_1}
```

The following example shows that, given a collection of designs, you can mark those designs as black boxes.

```
prompt> set_black_box [get_designs mpu*]
Set black box on 'r:/WORK/mpu_0_0'
Set black box on 'r:/WORK/mpu_0_1'
Set black box on 'r:/WORK/mpu_1_0'
Set black box on 'r:/WORK/mpu_1_1'
```

---

## SEE ALSO

collections(2)  
filter\_collection(2)  
query\_objects(2)  
set\_black\_box(2)  
collection\_result\_display\_limit(3)

---

## get\_dpx\_workers

Returns a list of the currently available workers.

---

### SYNTAX

`get_dpx_workers`

---

### DESCRIPTION

The **get\_dpx\_workers** command returns a Tcl list of the distributed processing workers that have been started and are ready to accept tasks. Each worker in the list is identified by `<hostname>:<cores>`, where `<hostname>` is the name of compute host on which the worker is running, and `<cores>` are the number of cores that the worker will run on.

This command is typically used to determine the number of workers available for distributed processing before executing a command that distributes to them. Under certain circumstances, you might want to hold off on performing distributed verification until a minimum number of workers are available.

---

### EXAMPLES

The following example returns the list of all the available distributed processing workers that have been started and are ready to accept tasks:

```
fm_shell (setup)> get_dpx_workers
rock367:4 crest-598-293:4 crest-598-315:4 yellow073:4
```

---

### SEE ALSO

`set_dpx_options(2)`  
`remove_dpx_options(2)`  
`report_dpx_options(2)`  
`start_dpx_workers(2)`  
`stop_dpx_workers(2)`  
`dpx_enable_checkpoint_verification(3)`  
`dpx_keep_workers_alive(3)`  
`dpx_verification_strategies(3)`  
`dpx_worker_acquisition_timeout(3)`

---

## get\_lib\_cells

Creates a collection of library cells. You can assign these library cells to a variable or pass them into another command.

---

### SYNTAX

```
collection get_lib_cells
  [-exact]
  [-quiet]
  [-filter expression]
  patterns | -of_objects objects
```

#### Data Types

<i>expression</i>	string
<i>objects</i>	list
<i>patterns</i>	list

---

### ARGUMENTS

#### -exact

Considers wildcards to be plain characters, and does not interpret their meaning as wildcards.

#### -quiet

Suppresses warning and error messages if no objects match. Syntax error messages are not suppressed.

#### -filter *expression*

Filters the collection with the *expression* value. For any library cells that match the *patterns* or *objects* argument, the expression is evaluated based on the library cell's attributes. If the expression evaluates to true, the library cell is included in the result.

#### -of\_objects *objects*

Creates a collection of library cells that are referenced by the specified cells or own the specified library pins. In this case, each object is either a named library pin or netlist cell, or a library pin collection or a netlist cell collection. The *-of\_objects* and *patterns* options are mutually exclusive; you must specify one, but not both.

#### *patterns*

Matches library cell names against patterns. Patterns can include the wildcard characters "\*" and "?". Patterns can also include collections of type lib\_cell. The *patterns* and *-of\_objects* options are mutually exclusive; you must specify one, but not both.

If you do not specify a pattern, the command uses \* (asterisk) as the default pattern.

---

### DESCRIPTION

This command creates a collection of library cells that match certain criteria. The command returns a collection if any library cells match the *patterns* or *objects* option and pass the filter, if specified. If no objects match the criteria, an empty string is returned.

You can use the **get\_lib\_cells** command at the command prompt, or you can nest it as an argument to another command. For

example, you can use it in the **query\_objects** command. In addition, you can assign the **get\_lib\_cells** command result to a variable.

When issued from the command prompt, the **get\_lib\_cells** command behaves as though the **query\_objects** command had been called to display the objects in the collection. By default, a maximum of 100 objects is displayed; you can change this maximum using the **collection\_result\_display\_limit** variable.

The "implicit query" property of the **get\_lib\_cells** command provides a fast, simple way to display cells in a collection. However, if you want the flexibility provided by the **query\_objects** command (for example, if you want to display the object class), use the **get\_lib\_cells** command as an argument to the **query\_objects** command.

For information about collections and the querying of objects, see the **collections** man page.

---

## EXAMPLES

The following example queries all library cells that are in the misc\_cmos library and begin with AN2. Although the output looks like a list, it is just a display.

```
prompt> get_lib_cells /misc_cmos/AN2*  
{/misc_cmos/AN2 /misc_cmos/AN2P}
```

The following example shows one way to find out the library cell used by a particular cell.

```
prompt> get_lib_cells -of_objects [get_cells o_reg1]  
{r:/misc_cmos/FD2}
```

---

## SEE ALSO

collections(2)  
filter\_collection(2)  
get\_cells(2)  
query\_objects(2)  
collection\_result\_display\_limit(3)



---

## get\_lib\_pins

Creates a collection of library cell pins. You can assign these library cell pins to a variable or pass them into another command.

---

### SYNTAX

```
collection get_lib_pins
[-exact]
[-quiet]
[-filter expression]
patterns | -of_objects objects
```

#### Data Types

<i>expression</i>	string
<i>objects</i>	list
<i>patterns</i>	list

---

### ARGUMENTS

#### -exact

Considers wildcards to be plain characters, and does not interpret their meaning as wildcards.

#### -quiet

Suppresses warning and error messages if no objects match. Syntax error messages are not suppressed.

#### -filter *expression*

Filters the collection with the *expression* option. For any library cell pins that match the *patterns* option (or the *objects* option), the expression is evaluated based on the library cell pin's attributes. If the expression evaluates to true, the library pin is included in the result.

#### -of\_objects *objects*

Creates a collection of library cell pins referenced by the specified netlist pins or owned by the specified library cells. In this case, each object is either a named library cell or netlist pin, or a library cell collection or netlist pin collection. The *-of\_objects* and *patterns* options are mutually exclusive; you must specify one, but not both.

#### *patterns*

Matches library cell pin names against patterns. The *patterns* option can include the wildcard characters "\*" and "?". The *patterns* option can also include collections of type **lib\_pin**. The *patterns* and *-of\_objects* options are mutually exclusive; you must specify one, but not both.

If you do not specify a pattern, the command uses \* (asterisk) as the default pattern.

---

### DESCRIPTION

The **get\_lib\_pins** command creates a collection of library cell pins that match certain criteria. The command returns a collection if any

library cell pins match the *patterns* or *objects* options and pass the filter (if specified). If no objects matched the criteria, the empty string is returned.

You can use the **get\_lib\_pins** command at the command prompt, or you can nest it as an argument to another command (for example, the **query\_objects** command). In addition, you can assign the **get\_lib\_pins** command result to a variable.

When issued from the command prompt, the **get\_lib\_pins** command behaves as though the **query\_objects** command had been called to display the objects in the collection. By default, a maximum of 100 objects is displayed; you can change this maximum using the **collection\_result\_display\_limit** variable.

The "implicit query" property of the **get\_lib\_pins** command provides a fast, simple way to display cells in a collection. However, if you want the flexibility provided by the **query\_objects** command, use the **get\_lib\_pins** command as an argument to the **query\_objects** command. For example, use this if you want to display the object class.

For information about collections and the querying of objects, see the **collections** man page.

---

## EXAMPLES

The following example queries all pins of the AN2 library cell in the misc\_cmos library. Although the output looks like a list, it is just a display.

```
prompt> get_lib_pins /misc_cmos/AN2/*  
{/misc_cmos/AN2/A /misc_cmos/AN2/B /misc_cmos/AN2/Z}
```

The following example shows one way to find out how the library pin is used by a particular pin in the netlist.

```
prompt> get_lib_pins -of_objects o_reg1/Q  
{r:/misc_cmos/FD2/Q}
```

---

## SEE ALSO

collections(2)  
filter\_collection(2)  
get\_libs(2)  
get\_lib\_cells(2)  
query\_objects(2)  
collection\_result\_display\_limit(3)

---

## get\_libs

Creates a collection of libraries. You can assign these libraries to a variable or pass them into another command.

---

### SYNTAX

```
collection get_libs
  [-exact]
  [-quiet]
  [-filter expression]
  [patterns | -of_objects objects]
```

#### Data Types

<i>expression</i>	string
<i>objects</i>	list
<i>patterns</i>	list

---

### ARGUMENTS

#### -exact

Considers wildcards to be plain characters, and does not interpret their meaning as wildcards.

#### -quiet

Suppresses warning and error messages if no objects match. Syntax error messages are not suppressed.

#### -filter *expression*

Filters the collection with the *expression* option. For any libraries that match *patterns* (or *objects*), the expression is evaluated based on the library's attributes. If the expression evaluates to true, the library is included in the result.

#### -of\_objects *objects*

Creates a collection of libraries that contain the specified objects. In this case, each object is either a named library cell or a library cell collection. the *-of\_objects* and *patterns* options are mutually exclusive; you can specify only one.

#### *patterns*

Matches library names against patterns. Patterns can include the wildcard characters "\*" and "?". Patterns can also include collections of type lib. The *patterns* and *-of\_objects* options are mutually exclusive; you can specify only one.

If you do not specify a pattern, the command uses \* (asterisk) as the default pattern.

---

### DESCRIPTION

The **get\_libs** command creates a collection of libraries that match certain criteria. The command returns a collection if any libraries match the *patterns* option and pass the filter (if specified). If no objects match the criteria, the empty string is returned.

You can use the **get\_libs** command at the command prompt, or you can nest it as an argument to another command (for example, the **query\_objects** command). In addition, you can assign the **get\_libs** command result to a variable.

When issued from the command prompt, the **get\_libs** command behaves as though the **query\_objects** command had been called to display the objects in the collection. By default, a maximum of 100 objects is displayed; you can change this maximum using the **collection\_result\_display\_limit** variable.

The "implicit query" property of the **get\_libs** command provides a fast, simple way to display cells in a collection. However, if you want the flexibility provided by the **query\_objects** command, use the **get\_libs** command as an argument to the **query\_objects** command. For example, use this if you want to display the object class.

For information about collections and the querying of objects, see the **collections** man page.

---

## EXAMPLES

The following example queries all loaded libraries. Although the output looks like a list, it is just a display.

```
prompt> get_libs
{r/misc_cmos r/misc_cmos_io}
```

The following example shows that given a library collection, you can remove those libraries. Note that you cannot remove libraries if they are referenced by a design.

```
pt_shell> remove_library [get_libs misc*]
Removed technology library 'misc_cmos' from container 'r'
Removed technology library 'misc_cmos_io' from container 'r'
```

---

## SEE ALSO

collections(2)  
filter\_collection(2)  
query\_objects(2)  
remove\_library(2)  
collection\_result\_display\_limit(3)

---

## get\_license

Obtains a license for the specified Formality feature(s).

---

### SYNTAX

status **get\_license**  
*feature\_list*

#### Data Types

*feature\_list* list

---

### ARGUMENTS

#### *feature\_list*

Specifies the list of Formality features to be obtained. The *feature\_list* argument might consist of a single value or a space-delimited list of values enclosed within braces ({}).

By looking at your key file, you can determine all of the features licensed at your site.

---

### RETURN VALUE

The **get\_license** command returns a status of 1 if it was successful and 0 if it failed.

---

### DESCRIPTION

This command obtains a license for the specified feature(s). These features are checked out by the current user until the **remove\_license** command is used or until the program exits.

When **fm\_shell** is invoked, Formality will automatically checkout the base Formality license. If this license is unavailable, and the user has set environment variable **FM\_WAIT\_LICENSE** to 1, then the Formality run will be queued to start as soon as the license becomes available. If **fm\_shell -checkout Formality-ECO** is invoked, Formality will checkout a Formality-ECO license, or wait for it if **FM\_WAIT\_LICENSE** is set to 1.

The **list\_licenses** command provides a list of the features that you are currently using.

The **license\_users** command provides a list of all features checked out by all users.

---

## EXAMPLES

The following example obtains a Formality-ECO license from within **fm\_shell**:

```
fm_shell (setup)> get_license Formality-ECO
```

---

## SEE ALSO

- `check_license(2)`
- `license_users(2)`
- `list_licenses(2)`
- `remove_license(2)`

---

## get\_message\_ids

Get application message ids

---

### SYNTAX

```
string get_message_ids [-type severity]  
[pattern]
```

```
string severity  
string pattern
```

---

### ARGUMENTS

**-type *severity***

Filter ids based on type (Values: Info, Warning, Error, Severe, Fatal)

***pattern***

Get IDs matching pattern (default: \*)

---

### DESCRIPTION

The **get\_message\_ids** command retrieves the error, warning and informational messages used by the application. The result of this command is a Tcl formatted list of all message ids. Information about the id can be queried with the **get\_message\_info** command.

---

### EXAMPLES

The following code finds all error messages and makes the application stop script execution when one of these messages is encountered.

```
foreach id [get_message_ids -type Error] {  
    set_message_info -stop_on -id $id  
}
```

---

### SEE ALSO

```
print_message_info(2)  
set_message_info(2)  
suppress_message(2)
```

---

## get\_message\_info

Returns information about diagnostic messages.

---

### SYNTAX

integer **get\_message\_info**  
[-error\_count | -warning\_count | -info\_count  
| -limit *l\_id* | -occurrences *o\_id* | -suppressed *s\_id* | -id *i\_id*]

#### Data Types

<i>l_id</i>	string
<i>o_id</i>	string
<i>s_id</i>	string
<i>i_id</i>	string

---

### ARGUMENTS

#### -error\_count

Returns the number of error messages issued so far.

#### -warning\_count

Returns the number of warning messages issued so far.

#### -info\_count

Returns the number of informational messages issued so far.

#### -limit *l\_id*

Returns the current user-specified limit for a given message ID. The limit was set with the **set\_message\_info** command.

#### -occurrences *o\_id*

Returns the number of occurrences of a given message ID.

#### -suppressed *s\_id*

Returns the number of times a message was suppressed either using **suppress\_message** or due to exceeding a user-specified limit.

#### -id *i\_id*

Returns information about the specified message. The information is returned as a Tcl list compatible with the array set command.

---

### DESCRIPTION

The **get\_message\_info** command retrieves information about error, warning, and informational messages. For example, if the following message is generated, information about it is recorded:



Error: unknown command 'wrong\_command' (CMD-005)

It is useful to be able to retrieve recorded information about generated diagnostic messages. For example, you can stop a script after a certain number of errors have occurred, or monitor the number of messages issued by a single command.

You can also find out how many times a specific message has occurred, or how many times it has been suppressed. Also, you can find out if a limit has been set for a particular message ID.

---

## EXAMPLES

The following example uses the **get\_message\_info** command to count the number of errors that occurred during execution of a specific command, and to return from the procedure if the error count exceeds a given amount:

```
prompt> proc \  
do_command {limit} {  
  set current_errors [get_message_info -error_count]  
  command  
  set new_errors [get_message_info -error_count]  
  if {[expr $new_errors - $current_errors] > $limit} {  
    return -code error "Too many errors"  
  }  
  ...  
}
```

The following example uses the **get\_message\_info** command to retrieve information on the CMD-014 message:

```
prompt> get_message_info -id CMD-014  
id CMD-014 severity Error limit 0 occurrences 0 suppressed 0 message  
{Invalid %s value '%s' in list.}
```

---

## SEE ALSO

```
print_message_info(2)  
set_message_info(2)  
suppress_message(2)  
get_message_ids(2)
```

---

## get\_nets

Creates a collection of nets from the current design relative to the current instance. You can assign these nets to a variable or pass them into another command.

---

### SYNTAX

```
collection get_nets
  [-boundary_type upper | lower | both]
  [-exact]
  [-hierarchical]
  [-quiet]
  [-filter expression]
  [patterns | -of_objects objects]
```

#### Data Types

<i>expression</i>	string
<i>objects</i>	list
<i>patterns</i>	list

---

### ARGUMENTS

#### -boundary\_type upper | lower | both

Specifies what to do when getting nets of boundary pins and ports.

You must specify one of the following values:

- *upper* - Get the net outside the hierarchical block.
- *lower* - Get the net inside the hierarchical block.
- *both* - Get the nets both inside and outside the hierarchical block.

If the *-of\_objects* argument is a pin collection or a name that can be either a pin or a port, *upper* is the default value. Otherwise, if *-of\_objects* argument is a port collection, *lower* is the default value.

This option can be used only with the *-of\_objects* option. In addition, the specified object must be a pin or a port. This option has no meaning for cells.

#### -exact

Considers wildcards to be plain characters, and does not interpret their meaning as wildcards.

#### -hierarchical

Searches for nets level-by-level relative to the current instance. The full name of the object at a particular level must match the patterns. The search is similar to the UNIX **find** command. For example, if there is a net block1/muxsel, a hierarchical search would find it using "muxsel." You cannot use the *-hierarchical* option with the *-of\_objects* option.

#### -quiet

Suppresses warning and error messages if no objects match. Syntax error messages are not suppressed.

#### -filter *expression*

Filters the collection with *expression*. For any nets that match *patterns* (or *objects*), the expression is evaluated based on the cell's attributes. If the expression evaluates to true, the net is included in the result.

### **-of\_objects** *objects*

Creates a collection of nets connected to the specified objects. Each object is either a named pin, a pin collection, a port, a port collection, a named cell or cell collection. The *-of\_objects* and *patterns* options are mutually exclusive; you can specify only one. In addition, you cannot use the *-hierarchical* option with the *-of\_objects* option.

### **patterns**

Matches net names against patterns. Patterns can include the wildcard characters "\*" and "?". Patterns can also include collections of type net. The *patterns* and *-of\_objects* options are mutually exclusive; you can specify only one.

If you do not specify a pattern, the command uses \* (asterisk) as the default pattern.

---

## DESCRIPTION

The **get\_nets** command creates a collection of nets in the current design, relative to the current instance that match certain criteria. The command returns a collection if any nets match the *patterns* or *objects* and pass the filter (if specified). If no objects matched the criteria, the empty collection is returned.

You can use the **get\_nets** command at the command prompt, or you can nest it as an argument to another command (for example, **query\_objects**). In addition, you can assign the **get\_nets** result to a variable.

When issued from the command prompt, the **get\_nets** command behaves as though **query\_objects** had been called to display the objects in the collection. By default, a maximum of 100 objects is displayed; you can change this maximum using the **collection\_result\_display\_limit** variable.

The "implicit query" property of **get\_nets** provides a fast, simple way to display cells in a collection. However, if you want the flexibility provided by the **query\_objects** options (for example, if you want to display the object class), use **get\_nets** as an argument to **query\_objects**.

For information about collections and the querying of objects, see the **collections** man page.

---

## EXAMPLES

The following example queries the nets that begin with 'NET' in block 'block1'. Although the output looks like a list, it is just a display.

```
prompt> get_nets block1/NET*
{r:/WORK/block1/NET1QNX r:/WORK/block1/NET2QNX}
```

The following example shows that with a collection of pins, you can query the nets connected to those pins.

```
prompt> set pinset [get_pins {o_reg1/QN o_reg2/QN}]
{r:/WORK/block1/o_reg1/QN r:/WORK/block1/o_reg2/QN}
prompt> query_objects [get_nets -of_objects $pinset]
{r:/WORK/block1/NET1QNX r:/WORK/block1/NET2QNX}
```

---

## SEE ALSO

collections(2)  
 filter\_collection(2)  
 get\_pins(2)  
 query\_objects(2)  
 collection\_result\_display\_limit(3)

---

## get\_pins

Creates a collection of pins from the current design relative to the current instance. You can assign these pins to a variable or pass them into another command.

---

### SYNTAX

```
collection get_pins
[-exact]
[-hierarchical]
[-quiet]
[-filter expression]
[patterns | -of_objects objects]
```

#### Data Types

<i>expression</i>	string
<i>objects</i>	list
<i>patterns</i>	list

---

### ARGUMENTS

#### -exact

Considers wildcards to be plain characters, and does not interpret their meaning as wildcards.

#### -hierarchical

Searches for pins level-by-level relative to the current instance. The full name of the object at a particular level must match the patterns. The search is similar to the **find** UNIX command. For example, if there is a pin block1/adder/D[0], a hierarchical search finds it using "adder/D[0]". You cannot use the *-hierarchical* option with the *-of\_objects* option.

#### -quiet

Suppresses warning and error messages if no objects match. Syntax error messages are not suppressed.

#### -filter *expression*

Filters the collection with the *expression*. For any pins that match *patterns* (or *objects*), the expression is evaluated based on the pin's attributes. If the expression evaluates to true, the pin is included in the result.

#### -of\_objects *objects*

Creates a collection of pins connected to the specified objects. Each object is a named cell or net, or cell collection or pin collection. The *-of\_objects* and *patterns* options are mutually exclusive; you can specify only one. In addition, you cannot use the *-hierarchical* option with the *-of\_objects* option.

#### *patterns*

Matches pin names against patterns. The *patterns* option can include the wildcard characters "\*" and "?". The *patterns* option can also include collections of type pin. The *patterns* and *-of\_objects* options are mutually exclusive; you can specify only one.

If you do not specify a pattern, the command uses \* (asterisk, treated as \*/\*) as the default pattern.

---

## DESCRIPTION

The **get\_pins** command creates a collection of pins in the current design, relative to the current instance, that match certain criteria. The command returns a collection if any pins match the *patterns* or *objects* options and pass the filter (if specified). If no objects match the criteria, the empty string is returned.

When used with the *-of\_objects* option, the **get\_pins** command searches for pins connected to any cells or nets specified in the *objects*.

You can use the **get\_pins** command at the command prompt, or you can nest it as an argument to another command (for example, the **query\_objects** command). In addition, you can assign the **get\_pins** command result to a variable.

When issued from the command prompt, the **get\_pins** command behaves as though the **query\_objects** command had been called to display the objects in the collection. By default, a maximum of 100 objects is displayed; you can change this maximum using the **collection\_result\_display\_limit** variable.

The "implicit query" property of the **get\_pins** command provides a fast, simple way to display cells in a collection. However, if you want the flexibility provided by the **query\_objects** command, use the **get\_pins** command as an argument to the **query\_objects** command. For example, use this to display the object class.

For information about collections and the querying of objects, see the **collections** man page.

---

## EXAMPLES

The following example queries the 'CP' pins of cells that begin with 'o'. Although the output looks like a list, it is just a display.

```
prompt> get_pins o*/CP
{r:/WORK/top/o_reg1/CP r:/WORK/top/o_reg2/CP r:/WORK/top/o_reg3/CP
r:/WORK/top/o_reg4/CP}
```

The following example shows that given a collection of cells, you can query the pins connected to those cells.

```
prompt> set csel [get_cells o_reg1]
{r:/WORK/top/o_reg1}
prompt> query_objects [get_pins -of_objects $csel]
{r:/WORK/top/o_reg1/D r:/WORK/top/o_reg1/CP r:/WORK/top/o_reg1/CD
r:/WORK/top/o_reg1/Q r:/WORK/top/o_reg1/QN}
```

---

## SEE ALSO

collections(2)  
filter\_collection(2)  
get\_cells(2)  
query\_objects(2)  
collection\_result\_display\_limit(3)

---

## get\_ports

Creates a collection of ports from the current design relative to the current instance. You can assign these ports to a variable or pass them into another command.

---

### SYNTAX

```
collection get_ports
  [-exact]
  [-quiet]
  [-filter expression]
  patterns | -of_objects objects
```

#### Data Types

<i>expression</i>	string
<i>objects</i>	list
<i>patterns</i>	list

---

### ARGUMENTS

#### -exact

Considers wildcards to be plain characters, and does not interpret their meaning as wildcards.

#### -quiet

Suppresses warning and error messages if no objects match. Syntax error messages are not suppressed.

#### -filter *expression*

Filters the collection with the *expression* option. For any ports that match the *patterns* option, the expression is evaluated based on the port's attributes. If the expression evaluates to true, the cell is included in the result.

#### -of\_objects *objects*

Creates a collection of ports connected to the specified objects. Each object is a named net or a net collection. The *-of\_objects* and *patterns* options are mutually exclusive; you can specify only one.

#### *patterns*

Matches port names against patterns. Patterns can include the wildcard characters "\*" and "?". Patterns can also include collections of type port. The *patterns* and *-of\_objects* options are mutually exclusive; you can specify only one.

If you do not specify a pattern, the command uses \* (asterisk) as the default pattern.

---

### DESCRIPTION

The **get\_ports** command creates a collection of ports in the current design or instance that match certain criteria. The command returns a collection if any ports match the *patterns* option and pass the filter (if specified). If no objects match the criteria, the empty string is returned.

You can use the **get\_ports** command at the command prompt, or you can nest it as an argument to another command (for example, the **query\_objects** command). In addition, you can assign the **get\_ports** command result to a variable.

When issued from the command prompt, the **get\_ports** command behaves as though the **query\_objects** command had been called to display the objects in the collection. By default, a maximum of 100 objects is displayed; you can change this maximum using the **collection\_result\_display\_limit** variable.

The "implicit query" property of the **get\_ports** command provides a fast, simple way to display cells in a collection. However, if you want the flexibility provided by the **query\_objects** command, use the **get\_ports** command as an argument to the **query\_objects** command. For example, use this to display the object class.

For information about collections and the querying of objects, see the **collections** man page. In addition, refer to the **all\_inputs** and **all\_outputs** man pages, which also create collections of ports.

---

## EXAMPLES

The following example queries all input ports beginning with 'mode'. Although the output looks like a list, it is just a display.

```
prompt> get_ports "mode*" -filter {direction == in}
{r:/WORK/mid/mode[0] r:/WORK/mid/mode[1] r:/WORK/mid/mode[2]}
```

The following example sets constant value 0 on ports beginning with "scan\_en".

```
prompt> set_constant [get_ports scan_en*] 0
Set 'r:/WORK/top/scan_en' to constant 0
Set 'r:/WORK/top/scan_en_1' to constant 0
Set 'r:/WORK/top/scan_en_2' to constant 0
```

---

## SEE ALSO

all\_inputs(2)  
all\_outputs(2)  
collections(2)  
filter\_collection(2)  
query\_objects(2)  
set\_constant(2)  
collection\_result\_display\_limit(3)

---

## get\_trace\_option

Get the current option value controlling behavior of command tracing and output annotation..

---

### SYNTAX

```
get_trace_option [-command name
                  |-profile
                  |-memory_threshold
                  |-cpu_threshold
                  |-time_threshold]
                  [-annotate | -is_traced]

string name
```

---

### ARGUMENTS

#### **-command *name***

This option is mutually exclusive with -profile, -memory\_threshold, -cpu\_threshold, and -time\_threshold. The option identifies the command for which tracing or annotation option is returned.

#### **-annotate**

If this option is given, then the *annotate* setting for the given command is returned. This option is mutually exclusive with -is\_traced and is meaningful only in combination with the -command option.

#### **-is\_traced**

If this option is given, then returns 1 if the given command is traced and logged, 0 otherwise. This option is mutually exclusive with -annotate and is meaningful only in combination with the -command option.

#### **-profile**

This option is mutually exclusive with all others. The option returns a list of the currently enabled profile metrics, or "all" if all metrics are enabled.

#### **-memory\_threshold**

This option is mutually exclusive with all others. The option returns the currently set memory profile threshold, if any, in kilobytes. If no threshold is set, then it returns the string "unset".

#### **-cpu\_threshold**

This option is mutually exclusive with all others. The option returns the currently set cpu profile threshold, if any, in seconds. If no threshold is set, then it returns the string "unset".

#### **-time\_threshold**

This option is mutually exclusive with all others. The option returns the currently set wall clock time profile threshold, if any, in kilobytes. If no threshold is set, then it returns the string "unset".



## DESCRIPTION

The command is used to query the current setting for the command annotation option that is set with the `set_trace_option` command, or profile metric settings.

---

## EXAMPLES

The following example sets the annoation type of the `get_attribute` command.

```
prompt> get_trace_option -command get_attribute -annotate
annotate
```

The following example sets, then gets, the currently enabled profile metrics.

```
prompt> set_trace_topion -profile {cpu time}
prompt> get_trace_topion -profile
cpu time
```

The following example gets the threshold for memory profile metric before one has been set.

```
prompt> get_trace_option -memory_threshold
unset
```

The following example will list the commands in the Builtins command group that are not traced and logged.

```
prompt> foreach cmd [dict get [get_defined_commands -details -groups Builtins] commands] {
? if {[get_trace_option -command $cmd -is_traced]}
? {echo $cmd}
? }
```

---

## SEE ALSO

`log_trace(2)`  
`annotate_trace(2)`  
`set_trace_option(2)`

---

## get\_unix\_variable

Returns the value of a UNIX environment variable.

---

### SYNTAX

**get\_unix\_variable**  
*variable\_name*

#### Data Types

*variable\_name* string

---

### ARGUMENTS

***variable\_name***

Specifies the name of a UNIX environment variable.

---

### DESCRIPTION

This command returns the value of a UNIX environment variable.

The command searches the UNIX environment variable list for the specified variable and returns its value. The command returns the empty string "" if the variable is not defined for the current session.

The fm\_shell displays the value inherited from the UNIX shell from which you invoked the tool. If you set the variable to a new value by using the **set\_unix\_variable** command, you see the new value within the application and any new processes you initiate from the application. However, if you use the UNIX **setenv** command to set the value of the variable and then run the **get\_unix\_variable** command within the application, you do not see the new value. Also, if you use the **setenv** UNIX command to set a UNIX variable within a shell you invoke by using the **sh** command, you do not see the variable's value in the application.

---

### EXAMPLES

In the following example, the **get\_unix\_variable** command returns you to the home directory.

```
fm_shell> set home [get_unix_variable "HOME"]
/users/disk1/bill

fm_shell> cd $home
fm_shell> pwd
/users/disk1/bill
```

In the following example, the **set\_unix\_variable** command changes the value of an environment variable.

```
fm_shell> get_unix_variable "PRINTER"
laser1
```

```
fm_shell> set_unix_variable "PRINTER" "laser3"  
laser3
```

```
fm_shell> get_unix_variable "PRINTER"  
laser3
```

In the following example, the environment variable requested was not previously defined.

```
fm_shell> get_unix_variable "UNDEFINED"  
Error: can't read "env(UNDEFINED)": no such element in array  
Use error_info for more info. (CMD-013)
```

---

## SEE ALSO

[printenv\(2\)](#)  
[printvar\(2\)](#)  
[sh\(2\)](#)  
[set\\_unix\\_variable\(2\)](#)

---

## getenv

Returns the value of a system environment variable.

---

### SYNTAX

```
string getenv  
    variable_name
```

#### Data Types

```
variable_name    string
```

---

### ARGUMENTS

***variable\_name***

Specifies the name of the environment variable to be retrieved.

---

### DESCRIPTION

The **getenv** command searches the system environment for the specified *variable\_name* and sets the result of the command to the value of the environment variable. If the variable is not defined in the environment, the command returns a Tcl error. The command is catchable.

Environment variables are stored in the **env** Tcl array variable. The **getenv**, **setenv**, and **printenv** environment commands are convenience functions to interact with this array.

The application you are running inherited the initial values for environment variables from its parent process (that is, the shell from which you invoked the application). If you set the variable to a new value using the **setenv** command, you see the new value within the application and within any new child processes you initiate from the application using the **exec** command. However, these new values are not exported to the parent process. Further, if you set an environment variable using the appropriate system command in a shell you invoke using the **exec** command, that value is not reflected in the current application.

See the **set**, **unset**, and **printvar** commands for information about working with non-environment variables.

---

### EXAMPLES

In the following example, **getenv** returns you to your home directory:

```
prompt> set home [getenv "HOME"]  
/users/disk1/bill
```

```
prompt> cd $home
```

```
prompt> pwd  
/users/disk1/bill
```

In the following example, **setenv** changes the value of an environment variable:

```
prompt> getenv PRINTER
laser1

prompt> setenv PRINTER "laser3"
laser3

prompt> getenv PRINTER
laser3
```

In the following example, the requested environment variable is not defined. The error message shows that the Tcl variable **env** was indexed with the value UNDEFINED, which resulted in an error. In the second command, **catch** is used to suppress the message.

```
prompt> getenv "UNDEFINED"
Error: can't read "env(UNDEFINED)": no such element in array
Use error_info for more info. (CMD-013)

prompt> if {[catch {getenv "UNDEFINED"} msg]} {
    setenv UNDEFINED 1
}
```

---

## SEE ALSO

- catch(2)
- exec(2)
- printenv(2)
- printvar(2)
- set(2)
- setenv(2)
- unsetenv(2)
- unset(2)

---

## group

Creates a new level of hierarchy.

---

### SYNTAX

```
group  
  cell_list  
  -design_name design_name  
  [-cell_name cell_name]
```

#### Data Types

```
cell_list string  
design_name string  
cell_name string
```

---

### ENABLED SHELL MODES

Setup

---

### ARGUMENTS

#### *cell\_list*

Specifies a list of cells in the current design to group into a new level of hierarchy. To specify more than one cell, enclose them in braces { }.

#### **-design\_name** *design\_name*

Specifies the name of the design containing the new level of hierarchy. The design name must not exist in the library in which it is to be created.

#### **-cell\_name** *cell\_name*

Specifies the name of the instance of the new design. If this option is not specified, a unique cell name is generated.

---

### DESCRIPTION

This command groups any number of cells or instances in the current design into a new design, creating a new level of hierarchy. The new design name must be defined by using the *-design\_name* option. A new cell is created in the current design which references the new design.

Specify the instance name of the new design by using the *-cell\_name* option. By default, the following naming style is used:

```
cell{integer}
```

where *integer* is an integer value that ensures a unique name.

Ports in the new design and the nets they are connected to in the current design are similarly named. The direction of each port in the new design is determined for pins on the net according to the following table:

Inside pins    Outside pins    Resulting port direction

-----	-----	-----
IN	OUT	IN
OUT	IN	OUT
IN & OUT	OUT	IN
IN & OUT	IN	OUT
IN	IN & OUT	IN
OUT	IN & OUT	OUT
IN & OUT	IN & OUT	INOUT (bidirectional)

Constants (power, ground) that are directly connected to inside pins are included in the new hierarchy. Truncated and undriven inside pins are not represented by a port of the new design. Equivalent inside pins are represented by just one resulting port.

---

## EXAMPLES

This example groups a specified list of cells and creates a new design with the given design name and generates a unique name for its instance.

```
fm_shell (setup)> group -design_name design_name {u1 u2 u3}
```

---

## SEE ALSO

current\_design(2)

---

## guide

Changes the mode to the guide mode.

---

### SYNTAX

**guide**  
[ -append ]

---

### ENABLED SHELL MODES

Guide  
Setup

---

### ARGUMENTS

**-append**

Specifies to append to current svf file.

---

### DESCRIPTION

When you use this command, the tool changes to the guide mode and enables all guide commands. When invoked, the tool is in the setup mode. After executing the **guide** command, it switches to the guide mode.

Use automated setup mode (SVF) commands only when the tool is in the guide mode. The tool cannot change to the guide mode after any design information (other than technology libraries) is read. If the design is read, it must be removed before the tool can change to the guide mode.

The prompt changes to indicate the current mode:

```
fm_shell (guide)>
fm_shell (setup)>
fm_shell (match)>
fm_shell (verify)>
```

The **setup** command returns one of the following:

- 0 to indicate failure
- 1 to indicate success



---

## EXAMPLES

```
fm_shell (setup)> guide  
1  
fm_shell (guide)>
```

---

## SEE ALSO

```
setup(2)  
match(2)  
verify(2)  
undo_match(2)
```

---

## guide\_architecture\_db

Associates a file with in the .db format with an architectural implementation.

---

### SYNTAX

```
guide_architecture_db  
[ -file filename ]  
[ libraries ]
```

#### Data Types

```
filename string  
libraries string
```

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

#### **-file *filename***

Specifies the name of a file in the .db format that contains the associated architecture.

#### ***libraries***

Specifies files in the .db format that are referenced in the architectural implementation.

---

### DESCRIPTION

Use this guide mode command to associate a file in the .db format with an architecture.

---

### EXAMPLES

```
fm_shell (guide)> guide_architecture_db -file arch.db { gtech }  
1
```

---

### SEE ALSO

guide(2)  
guide\_architecture\_netlist(2)

---

## guide\_architecture\_netlist

Associate a netlist with an architectural implementation.

---

### SYNTAX

#### **guide\_architecture\_netlist**

[ -file *filename* ]

[ *libraries* ]

#### **Data Types**

*filename* string

*libraries* string

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

#### **-file *filename***

Specifies the name of the netlist containing the associated architecture. If the specified *filename* is a directory, then the directory contains a netlist for each design.

#### **libraries**

Specifies files in .db file format that are referenced in the architectural implementation.

---

### DESCRIPTION

Use this guide mode command to associate a netlist format implementation for an architecture.

---

### EXAMPLES

```
fm_shell (guide)> guide_architecture_netlist -file arch.net gtech.db  
1
```

---

## SEE ALSO

[guide\(2\)](#)  
[guide\\_architecture\\_db\(2\)](#)

---

## guide\_boundary

Specifies boundaries of individual arithmetic operators within complex datapath netlists.

---

### SYNTAX

```
guide_boundary
{ -body bodyName }
{ -operand operandList }
{ -column columnList }
{ -resource resourceList }
```

#### Data Types

```
bodyName string
operandList string
columnList string
resourceList string
```

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

#### **-body *bodyName***

Specifies the name of the netlist implementing the arithmetic block.

#### **-operand *operandList***

Specifies a list of intermediate results of arithmetic operators.

#### **-column *columnList***

Specifies a list of column specifications for each intermediate operand.

#### **-resource *resourceList***

Specifies a list of arithmetic operators in the block.

---

### DESCRIPTION

Use this guide mode command to specify boundaries of individual arithmetic operators within complex datapath netlists.

## EXAMPLES

```
fm_shell (guide)> guide_boundary \  
-body { dp_sub_9_DP_OP_258_5050_0 } \  
-operand { I1 bin 2 } \  
-operand { I2 bin 2 } \  
-operand { I3 bin 2 } \  
-operand { OP3.out.1 bin 4 } \  
-column { I1 0 { I1[0] } } \  
-column { I1 1 { I1[1] } } \  
-column { I2 0 { I2[0] } } \  
-column { I2 1 { I2[1] } } \  
-column { I3 0 { I3[0] } } \  
-column { I3 1 { I3[1] } } \  
-column { OP3.out.1 0 { O1[0] } } \  
-column { OP3.out.1 1 { O1[1] } } \  
-column { OP3.out.1 2 { O1[2] } } \  
-column { OP3.out.1 3 { O1[3] } } \  
-resource { OP3 { I2 I1 I3 } { OP3.out.1 } }  
1
```

---

## SEE ALSO

guide(2)

---

## guide\_boundary\_netlist

Associates a netlist with implementations of compound arithmetic blocks.

---

### SYNTAX

```
guide_boundary_netlist
{ -file filename }
{ libraries }
```

#### Data Types

*filename* string  
*libraries* string

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

#### **-file *filename***

Specifies the name of the netlist containing the associated architecture. If the specified *filename* is a directory, then the directory contains a netlist for each *design*. The name of the file is `\design.b.e\`.

#### ***libraries***

Specifies files in .db format that are referenced in the architectural implementation.

---

### DESCRIPTION

Use this guide mode command to associate a netlist implementation for implementations of compound arithmetic blocks.

---

### EXAMPLES

```
fm_shell (guide)> guide_boundary_netlist -file arch.net { gtech.db }
1
```



---

## SEE ALSO

[guide\(2\)](#)

---

## guide\_breakpoint

Identifies a breakpoint design.

---

### SYNTAX

integer **guide\_breakpoint**  
-type *breakpointID*  
-cksum *alignmentString*

#### Data Types

*breakpointID* string  
*alignmentString* string

---

### ENABLED SHELL MODES

guide

---

### ARGUMENTS

#### -type *breakpointID*

Specifies an identifier tag for a breakpoint. If a breakpoint-data file is generated as a result of this guidance, it will include this string in the breakpoint data file name.

#### -cksum *alignmentString*

Specifies the string that is aligned with the implementation design.

---

### DESCRIPTION

This guide command causes a breakpoint-data file to be written when the breakpoint flow is enabled and the guidance aligns with the implementation.

---

### EXAMPLES

The following example identifies an initial\_opto breakpoint.

```
prompt> guide_breakpoint \  
-type { initial_opto } \  
-cksum { UniqueDesignIdentifierForAlignment }
```

1

---

## SEE ALSO

[guide\(2\)](#)

---

## guide\_change\_names

Changes the name of design objects.

---

### SYNTAX

**guide\_change\_names**  
-design *designName*  
[ -instance *instanceName* ]  
[ *changeBlock* ]

#### Data Types

*designName* string  
*instanceName* string  
*changeBlock* string

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

**-design *designName***

Specifies the name of the design containing the names.

**-instance *instanceName***

Specifies the name of the instance containing the names.

***changeBlock***

Specifies a space separated list specifying the object type, old, and new names.

---

### DESCRIPTION

Use this guide mode command to change object names.

---

### EXAMPLES

```
fm_shell (guide)> guide_change_names -design test \  
  { { cell U1 mycell3 } }
```

```
{ cell U2 mycell2 } \
{ cell U3 mycell1 } \
  { port data myd } \
{ port clock myck } \
{ port q myq } }
```

1

---

## SEE ALSO

[guide\(2\)](#)

---

## guide\_checkpoint

Identifies a checkpoint design.

---

### SYNTAX

```
integer guide_checkpoint  
-type checkpointId  
-file fileName  
[ -design designName ]  
[ -root rootName ]
```

#### Data Types

```
checkpointId string  
fileName string  
designName string  
rootName string
```

---

### ENABLED SHELL MODES

guide

---

### ARGUMENTS

#### **-type *checkpointId***

Specifies an identifier tag for a checkpoint.

#### **-file *fileName***

Specifies the name of the sub-directory inside the SVF that contains the checkpoint files.

#### **-root *rootName***

This option is added by Formality when the SVF is written out using **report\_guidance** command.

#### **-design *designName***

The name of the design to checkpoint. If omitted, Formality will assume the design is the top design in the reference container.

---

### DESCRIPTION

This guide command identifies a checkpoint.

## EXAMPLES

The following example identifies a retiming checkpoint

```
prompt> guide_checkpoint \  
-type { retiming-1 } \  
-file { cp-1 }
```

1

---

## SEE ALSO

`guide(2)`

---

## guide\_clkgate\_removal

This is a private guide.

---

### SYNTAX

**guide\_clkgate\_removal**  
-private *privateData*

#### Data Types

*privateData* string

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

-private *privateData*

Specifies the private data for the guide.

---

### DESCRIPTION

This is a private guide.

---

### EXAMPLES

```
fm_shell (guide)> guide_clkgate_removal \  
-private { privateData }
```

1

---

### SEE ALSO

guide(2)



---

## guide\_constant

Asserts that a design object can never reach any known value different from a specified constant value.

---

### SYNTAX

#### **guide\_constant**

```
-design { designName }  
-verify_scope { scopeDesignName }  
-constant0 | -constant1 { designObject }
```

#### **Data Types**

```
designName string  
scopeDesignName string  
designObject string
```

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

#### **-design { *designName* }**

Specifies the name of the design containing the design object. Specify only the design name, and not the workspace and container names. This design is rewired once the constant guidance is verified and accepted.

#### **-verify\_scope { *scopeDesignName* }**

Specifies the name of the scope design within which the constant is verifiable.

#### **-constant0 | -constant1 { *designObject* }**

Specifies the constant value and the object which can only reach that constant value.

---

### DESCRIPTION

This command asserts that a design object can never reach any known value different from a specified constant value. Formality will verify that the object can in fact load no other value. If that verification succeeds, Formality will drive all loads of the design object with the specified constant.

---

### EXAMPLES

To specify that input port *in0* inside design *test* has been replaced with a constant 0 for all instances of *test* within the scope of top design *top*:

```
fm_shell (guide)> guide_constant -design { test } -verify_scope  
{ top } -constant0 { svfObjectPort in0 }
```

To specify that the pin *out0* of instance *I1* is constant 0 in design *test* within the same scope:

```
fm_shell (guide)> guide_constant -design { test } -verify_scope  
{ test } -constant0 { svfObjectPin I1 out0 }
```

---

## SEE ALSO

[guide\(2\)](#)

---

## guide\_constraints

Identifies equivalent and constant block pins.

---

### SYNTAX

```
guide_constraints  
-body bodyName  
[ -const0 { list } ]  
[ -const1 { list } ]  
[ -equivalent { list } ]
```

#### Data Types

```
bodyName string  
list string
```

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

#### -body *bodyName*

Specifies the name of the body tag. This is linked to the instance of the next **guide\_datapath** or **guide\_multiplier** command with the same *bodyName*. This is a required option.

#### -const0 *list*

Wires all pins that are set to a constant 0 if verification against 0 reference succeeds. You can use this option multiple times in the same instance of the command.

#### -const1 *list*

Wires all pins that are set to a constant 1 if verification against 1 in reference succeeds. You can use this option multiple times in the same instance of the command.

#### -equivalent *list*

Proves all the specified pins are equivalent or complementary. The proven equivalences are applied to the design. Inverted equivalences are specified with "~" preceding the inverted pin name. You can use this option multiple times in the same instance of the command.

---

### DESCRIPTION

Use this guide mode command to identify arithmetic cell input equivalences and constants to increase the success rate of the

arithmetic solver.

---

## EXAMPLES

To set  $I1[2]$  as equivalent to inverted  $I1[3]$  in the design *dp* instance *add\_22\_DP\_OP\_258\_595\_1*

```
fm_shell(guide)> guide_constraints -body { dp_add_22_DP_OP_258_595_0 }  
  -equivalent { I1[2] ~ I1[3] }  
fm_shell(guide)> guide_datapath \  
  -design { dp }  
  -datapath { add_22_DP_OP_258_595_1 } \  
  -body { dp_add_22_DP_OP_258_595_0 }
```

---

## SEE ALSO

guide(2)

---

## guide\_datapath

Identifies a datapath subdesign.

---

### SYNTAX

```
integer guide_datapath  
-design designName  
[-instance instanceName]  
-body datapathBody  
[-enable enablePort]  
[-odc_body odcBody]  
[-logic_input { {odcPort} {odcAnchorPoint} }]
```

#### Data Types

```
designName string  
instanceName string  
datapathBody string  
enablePort string  
odcBody string  
odcPort string  
odcAnchorPoint string
```

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

#### **-design *designName***

Specifies the name of the design containing the datapath.

#### **-instance *instanceName***

Specifies the name of the instance containing the datapath.

#### **-body *datapathBody***

Specifies the name of the file containing the datapath description (.db file or netlist format).

#### **-enable *enablePort***

Specifies the name of the enable port in *datapathBody* specified datapath description.

#### **-odc\_body *odcBody***

Specifies the name of the file containing the odc datapath description (netlist format).

#### **-logic\_input *odcPort odcAnchorPoint***

Specifies pair of data, first name of the odc port in *odcBody* netlist second name of respective concordant object

---

## DESCRIPTION

This guide mode command identifies a datapath.

---

## EXAMPLES

The following example identifies the datapath for a design named *test* using the datapath description in the file named *dpath.db*.

```
prompt> guide_datapath \  
-design { dp } \  
-datapath { add_22_DP_OP_258_595_1 } \  
-body { dp_add_22_DP_OP_258_595_0 } \  
-enable { DG_ctrl } \  
-odc_body { dp_add_22_DP_OP_258_595_0_odc } \  
-logic_input { { DG_I1 } { top/fifo/controller/pipe_reg[31]/Q } } \  
-logic_input { { DG_I2 } { top/fifo/controller/enable } } \  
-logic_input { { DG_I3 } { top/fifo/sub_controller/sub_465.out.1_31 } }
```

1

---

## SEE ALSO

[guide\(2\)](#)

---

## guide\_datapath\_end

This is a private guide.

---

### SYNTAX

integer **guide\_datapath\_end**  
-private *privateData*

#### Data Types

*privateData* string

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

-private *privateData*

Specifies the private data for the guide.

---

### DESCRIPTION

This is a private guide.

---

### EXAMPLES

```
fm_shell (guide)> guide_datapath_end \  
-private { privateData }
```

1

---

### SEE ALSO

---

## guide\_divider\_netlist

Provides a divider netlist.

---

### SYNTAX

```
guide_divider_netlist
{ -design designName }
{ -instance instanceName }
{ -verilog VerilogFileName }
```

#### Data Types

```
designName string
instanceName string
VerilogFileName string
```

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

#### **-design *designName***

Specifies the name of the design containing the divider.

#### **-instance *instanceName***

Specifies the name of the instance of the divider.

#### **-verilog *VerilogFileName***

Specifies the Verilog file containing the divider netlist.

---

### DESCRIPTION

Use this guide mode command to provide a divider netlist.

---

### EXAMPLES

```
fm_shell (guide)> guide_divider_netlist \
  -design { test } \
```



```
-instance { div_12 } \  
-verilog { netlists/dw-1/DW_div_uns_a_width12_b_width8.d.v }  
1
```

---

## SEE ALSO

[guide\(2\)](#)

---

## guide\_dont\_verify\_scan

Identifies a compare point that should be disabled due to scan insertion.

---

### SYNTAX

#### **guide\_dont\_verify\_scan**

```
-ports { port_name ... }  
-pins { pin_name ... }  
-propagate svfTrue
```

#### Data Types

```
port_name string  
pin_name string
```

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

#### **-ports**

Specifies a Tcl list of black box input ports or primary output ports that should not be verified. The format is **design\_name/port\_name**.

#### **-pins**

Specifies a Tcl list of black box input pin names that should not be verified. The format is **design\_name/cell\_name/.../pin\_name**.

#### **-propagate svfTrue**

Specifies that upstream compare points that do not fanout to other compare points should not be verified. This argument is optional.

---

### DESCRIPTION

This command specifies compare points that should not be verified. This is used when scan circuitry is inserted or scan chains are reordered. This command is ignored if either the **synopsys\_auto\_setup** or **svf\_scan** variables are not set to *true*.

---

### EXAMPLES

To disable the black box pin top/bbox/in1:

```
fm_shell (guide)> guide_dont_verify_scan -pins { top/bbox/in1 }
```

To disable the primary output port top/out1 and propagate dont\_verify backward to points that don't fanout elsewhere:

```
fm_shell (guide)> guide_dont_verify_scan -ports { top/out1 } -propagate svfTrue
```

---

## SEE ALSO

- guide(2)
- guide\_scan\_output(2)
- guide\_scan\_input(2)
- synopsys\_auto\_setup(3)
- svf\_scan(3)

---

## guide\_dont\_verify\_scan\_input

Identifies a compare point that should be disabled due to scan insertion.

---

### SYNTAX

#### **guide\_dont\_verify\_scan\_input**

```
-ports { port_name ... }  
-pins { pin_name ... }  
-propagate svfTrue
```

#### **Data Types**

```
port_name string  
pin_name string
```

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

#### **-ports**

Specifies a Tcl list of black box input ports or primary output ports that should not be verified. The format is **design\_name/port\_name**.

#### **-pins**

Specifies a Tcl list of black box input pin names that should not be verified. The format is **design\_name/cell\_name/.../pin\_name**.

#### **-propagate svfTrue**

Specifies that upstream compare points that do not fanout to other compare points should not be verified. This argument is optional.

---

### DESCRIPTION

This command specifies compare points that should not be verified. This is used when scan circuitry is inserted or scan chains are reordered. This command is ignored if either the **synopsys\_auto\_setup** or **svf\_scan** variables are not set to *true*. This command is a synonym for **guide\_dont\_verify\_scan**. The two commands do exactly the same thing.

---

### EXAMPLES

guide\_dont\_verify\_scan\_input

To disable the black box pin top/bbox/in1:

```
fm_shell (guide)> guide_dont_verify_scan_input -pins { top/bbox/in1 }
```

To disable the primary output port top/out1 and propagate dont\_verify backward to points that don't fanout elsewhere:

```
fm_shell (guide)> guide_dont_verify_scan_input -ports { top/out1 } -propagate svfTrue
```

---

## SEE ALSO

- guide(2)
- guide\_scan\_output(2)
- guide\_scan\_input(2)
- guide\_dont\_verify\_scan(2)
- synopsys\_auto\_setup(3)
- svf\_scan(3)

---

## guide\_eco\_change

Describes changes to lines that are caused by an ECO.

---

### SYNTAX

#### **guide\_eco\_change**

```
-file_orig { nameOfOriginalFile }  
-file_eco { nameOfEcoFile }  
-type { typeName }  
-original { lineNumber [ lineNumber ] }  
-eco { lineNumber [ lineNumber ] }
```

#### Data Types

```
nameOfOriginalFile string  
nameOfEcoFile string  
typeName string  
lineNumber integer
```

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

#### **-file\_orig { *nameOfOriginalFile* }**

Specifies the name of the original RTL file.

#### **-file\_eco { *nameOfEcoFile* }**

Specifies the name of the ECO-modified RTL file.

#### **-type { *typeName* }**

Specifies the type of operation that was performed on the specified line number. Specify one of the following values for the *typeName* argument:

- *insert* for lines added by the ECO-modification.
- *replace* for lines modified by the ECO-modification.
- *delete* for lines removed by the ECO-modification.

#### **-original { *lineNumber lineNumber* }**

Specifies the line number or range of line numbers in the original file.

#### **-eco { *lineNumber lineNumber* }**

Specifies the line number or range of line numbers in the ECO-modified file.

---

## DESCRIPTION

Use this command to specify which lines were either inserted, replaced, or deleted as a result of an ECO modification.

Use the *fm\_eco\_to\_svf* script to generate the *guide\_eco\_change* automated setup commands.

---

## EXAMPLES

```
fm_shell (guide)> guide_eco_change \  
-file_orig { original/rtl/foo.v } \  
-file_eco { eco/rtl/foo.v } \  
-type { insert } \  
-original { 0 } -eco { 1 }
```

```
fm_shell (guide)> guide_eco_change \  
-file_orig { original/rtl/foo.v } \  
-file_eco { eco/rtl/foo.v } \  
-type { replace } \  
-original { 4 } -eco { 5 }
```

```
fm_shell (guide)> guide_eco_change \  
-file_orig { original/rtl/foo.v } \  
-file_eco { eco/rtl/foo.v } \  
-type { delete } \  
-original { 6 9 } -eco { 6 }
```

```
$ cat original/rtl/foo.v  
module dummy(A,B,Z1,Z2);  
  input [1:0] A,B;  
  output [2:0] Z1,Z2;  
  assign Z1 = A + B;  
  assign Z2 = A - B;  
  // Blank  
  // Blank  
  // Blank  
  // Blank  
endmodule;
```

```
$ cat eco/rtl/foo.v  
// This is the ECO version  
module dummy(A,B,Z1,Z2);  
  input [1:0] A,B;  
  output [2:0] Z1,Z2;  
  assign Z1 = A + B + 1;  
  assign Z2 = A - B;  
endmodule;
```

---

## SEE ALSO

[guide\(2\)](#)  
[guide\\_eco\\_map\(2\)](#)  
[generate\\_eco\\_map\\_file\(2\)](#)

---

## guide\_eco\_map

Describes the changes to names of arithmetic operators that are caused by an ECO.

---

### SYNTAX

```
guide_eco_map  
-design { designName }  
-from { cellName }  
-to { cellName }
```

#### Data Types

```
designName string  
cellName string
```

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

**-design { *designName* }**

Specifies the name of the design.

**-from { *cellName* }**

Specifies the name of arithmetic operator when reading the original RTL file.

**-to { *cellName* }**

Specifies the name of arithmetic operator when reading the ECO-modified RTL file.

---

### DESCRIPTION

Use this guide mode command to specify changed to cell names for lines changed by an ECO modification.

Use the *generate\_eco\_map\_file* command to generate the *guide\_eco\_map* automated setup commands.

---

### EXAMPLES



```
fm_shell (guide)> guide_eco_map \  
-design { dummy } \  
-from { add_4 } \  
-to { add_5 }
```

```
$ cat original/rtl/foo.v  
module dummy(A,B,Z1,Z2);  
  input  [1:0] A,B;  
  output [2:0] Z1,Z2;  
  assign  Z1 = A + B;  
  assign  Z2 = A - B;  
  // Blank  
  // Blank  
  // Blank  
  // Blank  
endmodule;
```

```
$ cat eco/rtl/foo.v  
// This is the ECO version  
module dummy(A,B,Z1,Z2);  
  input  [1:0] A,B;  
  output [2:0] Z1,Z2;  
  assign  Z1 = A + B + 1;  
  assign  Z2 = A - B;  
endmodule;
```

---

## SEE ALSO

```
guide(2)  
guide_eco_change(2)  
generate_eco_map_file(2)
```

---

## guide\_environment

Sets the environment variables.

---

### SYNTAX

```
guide_environment
{
  { name_1 value_1 }
  { name_2 value_2 }
  { name_n value_n }
}
```

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

{ *name value* }

Specifies a list of variable names and values.

---

### DESCRIPTION

Use this guide mode command to set global environment variables.

---

### EXAMPLES

```
fm_shell (guide)> guide_environment { \
    { bus_dimension_separator_style [] } \
    { bus_extraction_style %s[%d:%d] } \
    { bus_naming_style %s[%d] } \
    { bus_range_separator_style : } \
    { hdlin_while_loop_iterations 1000 } }
1
```

---

### SEE ALSO

guide(2)

---

## guide\_eqop

Combines readers from one object to another specified constant value.

---

### SYNTAX

#### **guide\_eqop**

```
-design <name>
-verify_scope <name>
-rewire <value>
-object { net <name> | port <name> | pin <cell> <pin-name> }
-equal | -opposite { net <name> | port <name> | pin <cell> <pin-name> }
```

#### **Data Types**

```
designName string
scopeDesignName string
designObject string
rewireType svfTrue or svfFalse
```

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

#### **-design { *designName* }**

Specifies the name of the design containing the design object. Specify only the design name, and not the workspace and container names. This design is rewired once the eqop guidance is verified and accepted.

#### **-verify\_scope { *scopeDesignName* }**

Specifies the name of the scope design within which the eqops are verifiable.

#### **-rewire { *rewireType* }**

Specifies if we will apply the rewire or not. svfFalse is not currently supported.

#### **-equal { *designObject* }**

Specifies the constant value and the object which can only reach that constant value.

#### **-opposite { *designObject* }**

---

### DESCRIPTION

This command connects the readers of the equal and opposite objects to the -object object. This guide will be rejected if the specified

equal and opposite objects being rewired are not logically correct, or do not have consistent X spaces. It is required that there is no input condition where the -object object can be X while the equal or opposite objects are not X, since that would be expanding the X space in the reference.

---

## EXAMPLES

To specify that input port *in2* inside design *test* has its reader rewired to *in2* for all instances of *test* within the scope of top design *top*:

```
fm_shell (guide)> guide_eqop -design { test }  
                  -verify_scope { top }  
                  -rewire { svfTrue }  
                  -object { svfObjectPort in0 }  
                  -equal { svfObjectPort in2 }
```

---

## SEE ALSO

[guide\(2\)](#)  
[guide\\_constant\(2\)](#)

---

## guide\_file\_info

Specifies a set of information corresponding to an RTL file included in the design.

---

### SYNTAX

```
guide_file_info  
[ -file { fileName } ]  
[ -language { language } ]  
[ -nameID { fileID } ]  
[ -cksum { checksum } ]  
[ -cksum_file { fileName } ]  
[ -version { version } ]
```

#### Data Types

```
fileName string  
language string  
checksum string  
fileID string
```

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

#### **-file *fileName***

Specifies the name of an RTL file that is part of the design.

#### **-language { ( *svfFileInfoLangVerilog* | *svfFileInfoLangVHDL* ) }**

Specifies language of the RTL file. Possible values are: *svfFileInfoLangVerilog* *svfFileInfoLangVHDL*

#### **-nameID *fileName***

The File Identifier value for the RTL file.

#### **-cksum *checksum***

The checksum derived from the full contents of the RTL file. Some removal of comments and excess whitespace may be performed before computing the checksum.

#### **-cksum\_file *fileName***

Name of a special file stored within the SVF data. Each line of this file is a checksum of the corresponding line of the RTL file. Each line may have comments and/or excess whitespace removed before computing the checksum.

#### **-version *version***

Specifies the version of Design Compiler that is used to create the automated setup file that is specified by using the *-file* option.

---

## DESCRIPTION

Specifies a set of information corresponding to an RTL file included in the design. This is used mainly by the "SVF Reuse" flow, which compares the stored checksum files vs. similar files generated from the corresponding current RTL files, and adjust conformant naming to accomodate any differences in line numbering.

The version arg gives the version of Design Compiler that is used to generate the automated setup file. This information is used to control the way the tool names datapath operators.

---

## EXAMPLES

```
fm_shell (guide)> guide_file_info \  
-file { ./test.v } \  
-cksum_file { checksums/23817_6a0e3c56f55bb9977de7125c22b6d6b0.cksum } \  
-language { svfFileInfoLangVerilog } \  
-nameID { 23817 } \  
-cksum { 6a0e3c56f55bb9977de7125c22b6d6b0 } \  
-version { 19.272 }
```

---

## SEE ALSO

---

## guide\_fsm\_reencoding

Changes the finite state machine (FSM) encoding.

---

### SYNTAX

```
integer guide_fsm_reencoding  
-design design_name  
-previous_state_vector prev_list  
-current_state_vector curr_list  
-state_reencoding state_list
```

#### Data Types

```
design_name string  
prev_list string  
curr_list string  
state_list string
```

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

#### **-design *design\_name***

Specifies the name of the design containing the FSM.

#### **-previous\_state\_vector *prev\_list***

Specifies a list of register bits before re-encoding.

#### **-current\_state\_vector *curr\_list***

Specifies a list of post re-encoding register bits.

#### **-state\_reencoding *state\_list***

Specifies a list of state re-encodings.

---

### DESCRIPTION

This guide mode command changes the FSM encoding.



## EXAMPLES

```
prompt> guide_fsm_reencoding \  
-design myfsm_0 \  
-previous_state_vector { out1_reg out0_reg } \  
-current_state_vector { Q4 Q3 Q2 Q1 } \  
-state_reencoding { { begin 2#00 2#0001 } \  
{ ok 2#01 2#0010 } \  
{ nok 2#10 2#0100 } \  
{ end 2#11 2#1000 } } \  
1
```

---

## SEE ALSO

[guide\(2\)](#)

---

## guide\_group

Creates hierarchy around design objects.

---

### SYNTAX

```
integer guide_group  
-design design_name  
[ -instance instance_name ]  
[ -cells cell_list ]  
-new_design new_design_name  
-new_instance new_instance_name  
[group_block]
```

#### Data Types

```
design_name string  
instance_name string  
cell_list string  
new_design_name string  
new_instance_name string  
group_block string
```

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

#### **-design *design\_name***

Specifies the name of the design containing the objects.

#### **-instance *instance\_name***

Specifies the name of the instance containing the objects.

#### **-cells *cell\_list***

Specifies a list of the cells being grouped.

#### **-new\_design *new\_design\_name***

Specifies the name of the new design being created.

#### **-new\_instance *new\_instance\_name***

Specifies the name of the instance of the new design being created.

#### ***group\_block***

Specifies a space separated list of old-cell and new-cell names.

---

## DESCRIPTION

This guide mode command creates a hierarchy around design objects.

---

## EXAMPLES

```
prompt> guide_group \  
-cells { shift4_i_1 \  
shift4_i_2 \  
shift_4_i_2 \  
shift_4_i_3 } \  
-design shift8 \  
-new_design foo \  
-new_instance foo_i_1 \  
{ { shift4_i_1 foo_i_1/shift4_i_1 } \  
{ shift4_i_2 foo_i_1/shift4_i_2 } }  
1
```

---

## SEE ALSO

`guide(2)`

---

## guide\_group\_function

Instructs HDL readers to create a level of hierarchy around specified function call.

---

### SYNTAX

```
guide_group_function
{ -file file_number }
{ -fcall function_call }
{ -new_design new_design_name }
{ -new_instance new_instance_name }
{ -output_name output_port_name }
```

#### Data Types

```
file_number number
function_call string
new_design_name string
new_instance_name string
output_port_name string
```

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

#### **-file *file\_number***

Specifies the file which includes the function call. File number is assigned in `guid_info` commands.

#### **-fcall *function\_call***

Specifies which function call should be grouped. Naming convention similar to operators.

#### **-new\_design *new\_design\_name***

Specifies the name to call the design representing the function.

#### **-new\_instance *new\_instance\_name***

Specifies the name to call the design representing the function.

#### **-output\_name *output\_signal\_name***

Specifies the name of the output port of the design created for the grouped function.

---

### DESCRIPTION

Use this guide mode command to instruct hdl readers to leave a function call grouped in its own level of hierarchy. This is usefull in isolating XOR trees from surrounding logic.

---

## EXAMPLES

```
fm_shell (guide)> guide_group_function -file 1138 -call func_10_C20  
-new_design foo -new_instance u0 -output_name fee  
1
```

---

## SEE ALSO

[guide\(2\)](#)

---

## guide\_hier\_map

Synchroniezs design names between synthesis and verification.

---

### SYNTAX

```
guide_hier_map  
-change_link { svfTrue }  
-design { designName }  
-cells { listOfCellNames }  
-linked { designName }  
-library { libraryName }  
-pin_names { listOfCellNames }
```

#### Data Types

```
designName string  
listOfCellNames list of strings  
libraryName string  
listOfPinNames list of oldPinName newPinName strings
```

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

#### **-change\_link *svfTrue***

True if the linked design has a different port list than the original.

#### **-design *designName***

Specifies the design containing the cells.

#### **-cells *listOfCellNames***

Lists all cells in the specified design which are instances of the linked design.

#### **-linked *designName***

Specifies the new target name of the listed cells.

#### **-library *libraryName***

Specifies the library containing the linked design.

#### **-pin\_names *listOfPinNames***

Lists the mapping from old pin names to new pin names with -change\_link

---

## DESCRIPTION

The down-design of the specified cell(s) within the given design are changed (if possible) to match the linked design.

---

## EXAMPLES

```
fm_shell (guide)> guide_hier_map \  
-design { topDesign } \  
-cells { inst1 inst2 } \  
-linked { paramDesign_P1_P2 }
```

---

## SEE ALSO

`guide_hier_map(2)`

---

## guide\_implementation

Identifies the architecture of a DesignWare component.

---

### SYNTAX

**guide\_implementation**  
-design *designName*  
-instance *instanceName*  
-arch *arch*

#### Data Types

*designName* string  
*instanceName* string  
*arch* string

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

**-design *designName***

Specifies the name of the design containing the DesignWare component.

**-instance *instanceName***

Specifies the name of the instance of the DesignWare component.

**-arch *arch***

Specifies the architecture of the DesignWare component. For example *rtl* or *str* for a DW\_fp\_mult floating point multiplier.

---

### DESCRIPTION

Use this guide mode command to identify the architecture of a DesignWare component.

---

### EXAMPLES

```
fm_shell (guide)> guide_implementation \  
-design { fp_mul } \  
-
```



```
1      -instance { dw_fp_mul } \  
      -arch { str }
```

---

## SEE ALSO

[guide\(2\)](#)

---

## guide\_info

Specifies the version of Design Compiler that is used to generate the automated setup file for verification (SVF).

---

### SYNTAX

```
guide_info
[ -file fileName ]
[ -version { version } ]
```

#### Data Types

```
fileName string
version string
```

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

#### **-file *fileName***

Specifies the name of the automated setup file for verification (SVF).

#### **-version *version***

Specifies the version of Design Compiler that is used to create the automated setup file that is specified by using the *-file* option.

---

### DESCRIPTION

Specifies the version of Design Compiler that is used to generate the automated setup file. This information is used to control the way the tool names datapath operators.

---

### EXAMPLES

```
fm_shell (guide)> guide_info -version { rtl.v 6.346 }
```

---

### SEE ALSO



---

## guide\_instance\_map

Specifies a new design name for specially named designs.

---

### SYNTAX

```
guide_instance_map  
-design { designName }  
[ -instance { instanceName } ]  
-linked { designName }
```

#### Data Types

*designName* string  
*instanceName* string

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

#### **-design *designName***

Specifies the design containing the instance.

#### **-instance *instanceName***

Specifies the hierarchical path from the specified design to an instance of a parameterized, or a specially named, design.

#### **-linked *designName***

Specifies the new target name of the instance design.

---

### DESCRIPTION

Specifies a new design name for specially named designs.

---

### EXAMPLES

```
fm_shell (guide)> guide_instance_map \  
-design { paramDesign } \  
-instance { inst1 } \  

```

-linked { *paramDesign\_P1\_P2* }

---

## SEE ALSO

---

## guide\_instance\_merging

Identifies merged instances.

---

### SYNTAX

#### **guide\_instance\_merging**

-design *designName*  
-from *fromList*  
-to *toInstance*

#### **Data Types**

*designName* string  
*fromList* string  
*toInstance* string

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

#### **-design *designName***

Specifies the name of the design that contains the merged instances.

#### **-from *fromList***

Lists the merged instances.

#### **-to *toReg***

Specifies the final instance.

---

### DESCRIPTION

Use this guide mode command to identify merged instances.

---

### EXAMPLES

```
fm_shell (guide)> guide_instance_merging \  
-design top \
```

```
1      -from { inst3 inst2 } \  
      -to inst1
```

---

## SEE ALSO

[guide\(2\)](#)

---

## guide\_inv\_push

---

### SYNTAX

```
guide_inv_push  
-design { designName }  
-register { registerName }
```

#### Data Types

```
designName string  
registerName string
```

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

**-design** *designName*

Specifies the name of the design that contains the phase inverted (inversion pushed) register.

**-register** *registerName*

Specifies the name of the phase inverted register.

---

### DESCRIPTION

Use this guide mode command to indicate the named register is phase inverted (inversion pushed).

---

### EXAMPLES

```
fm_shell (guide)> guide_inv_push -design test -register q1_reg[0]  
1
```

---

### SEE ALSO

svf\_inv\_push(3)



---

## guide\_invert

Use this guide mode command to indicate that the named object is inverted.

---

### SYNTAX

**guide\_invert**  
-design { *designName* }  
-object { *designObject* }

#### Data Types

*designName* string  
*designObject* string

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

**-design { *designName* }**

Specifies the name of the design containing the design object. Specify only the design name, and not the workspace and container names.

**-object { *designObject* }**

Specifies the name of the object which is inverted.

---

### DESCRIPTION

Formality will insert an inverter in the design and all its up cells at the design object interface. For an input port object that translates to inserting an inverter on the net that drives the input port in all the up cells and inserting an inverter on the net that is driven by the input port inside the design. For an output port, an inverter is inserted on the net that drives the output port and also on all upcell nets driven by the output port.

---

### EXAMPLES

To specify that input port *in0* inside design *test* has been inverted for all instances of *test* within the scope of top design *top*:

```
fm_shell (guide)> guide_invert -design { test } -object { svfObjectPort in0 }
```

---

## SEE ALSO

`guide(2)`

---

## guide\_iso\_duplication

This is a private guide.

---

### SYNTAX

**guide\_iso\_duplication**  
-private *privateData*

#### Data Types

*privateData* string

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

-private *privateData*

Specifies the private data for the guide.

---

### DESCRIPTION

This is a private guide.

---

### EXAMPLES

```
fm_shell (guide)> guide_iso_duplication \  
-private { privateData }
```

1

---

### SEE ALSO

guide(2)  
load\_upf(2)

---

## guide\_iso\_merging

This is a private guide.

---

### SYNTAX

**guide\_iso\_merging**  
-private *privateData*

#### Data Types

*privateData* string

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

-private *privateData*

Specifies the private data for the guide.

---

### DESCRIPTION

This is a private guide.

---

### EXAMPLES

```
fm_shell (guide)> guide_iso_merging \  
-private { privateData }
```

1

---

### SEE ALSO

guide(2)  
load\_upf(2)

---

## guide\_mark

---

### SYNTAX

**guide\_mark**  
*type*  
*phase*

#### Data Types

*type* string  
*phase* string

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

*type*  
*phase*

---

### DESCRIPTION

This command is for internal use only.

---

## guide\_mc

Identifies a subdesign generated by Module Compiler.

---

### SYNTAX

```
status guide_mc
  -design designName
  [mcBlock]
```

#### Data Types

*designName* string

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

**-design *designName***

Specifies the name of the design.

***mcBlock***

Specifies a list of old-name new-name pairs.

---

### DESCRIPTION

This command identifies a subdesign generated by Module Compiler.

---

### EXAMPLES

This example shows how to use the **guide\_mc** command.

```
fm_shell (guide)> guide_mc -design top { {from to} {old new} }
1
```

---

## SEE ALSO

[guide\(2\)](#)

---

## guide\_merge

Groups arithmetic operators together.

---

### SYNTAX

```
guide_merge
{ -design designName }
{ -datapath datapathName }
{ -input inputList }
{ -output outputList }
{ -pre_resource preResourceList }
{ -pre_assign preAssignList }
```

#### Data Types

```
designName string
datapathName string
inputList string
outputList string
preResourceList string
preAssignList string
```

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

#### **-design *designName***

Specifies the name of the design to be transformed.

#### **-datapath *datapathName***

Specifies the name of the datapath block.

#### **-input *inputList***

Specifies a list of block inputs.

#### **-output *outputList***

Specifies a list of block outputs.

#### **-pre\_resource *preResourceList***

Specifies a list of resources in the arithmetic block pre-graph.

#### **-pre\_assign *preAssignList***

Specifies a list of assignments in the arithmetic block pre-graph.



---

## DESCRIPTION

Use this guide mode command to group arithmetic operators together into a new datapath block.

---

## EXAMPLES

```
fm_shell (guide)> guide_merge \
  -design { sig_calc } \
  -datapath { sub_113_DP_OP_284_7544_12 } \
  -input { 36 I1 } \
  -input { 15 I2 } \
  -input { 12 I3 } \
  -input { 5 I4 } \
  -input { 1 I5 } \
  -output { 36 O6 } \
  -output { 24 O4 } \
  -pre_resource { { 27 } mult_113 = MULT { { I2 } { I3 } } } \
  -pre_resource { { 36 } sub_113 = SUB { { I1 } { mult_113 SIGN 36 } } } \
  -pre_resource { { 24 } srl_125 = \
    SHIFT { { sub_113 35 12 } { I4 } { U'b0 } { U'b0 } { U'b0 } { U'b0 } } } \
  -pre_resource { { 24 } add_125 = ADD { { srl_125 } { I5 ZERO 24 } } } \
  -pre_assign { O6 = { sub_113 } } \
  -pre_assign { O4 = { add_125 } }
```

1

---

## SEE ALSO

[guide\(2\)](#)

---

## guide\_multibit

Support name-matching of multibit banked registers.

---

### SYNTAX

```
status guide_multibit
  -design designName
  -type [ svfMultibitTypeBank | svfMultibitTypeSplit | svfMultibitTypeSyncBank | svfMultibitTypeSyncSplit ]
  -groups { { cellList } ... }
```

#### Data Types

*designName* string  
*cellList* string

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

#### -design *designName*

Specifies the name of the design containing the objects.

#### -type *svfMultibitTypeBank* | *svfMultibitTypeSplit* | *svfMultibitTypeSyncBank* | *svfMultibitTypeSyncSplit*

Specifies whether this is a banking operation or split operation

#### -groups { {*cellList*} ... }

For a banking operation (-type *svfMultibitTypeBank* | -type *svfMultibitTypeSyncBank*), -groups specifies a list of *cellList*s that represent registers that are mapped into a bank. Each *cellList* in the group contains a list of register names and sizes, the last two elements specify the name of the banked register instance and its size.

For a split operation (-type *svfMultibitTypeSplit* | -type *svfMultibitTypeSyncSplit*), -groups specifies a list of *cellList*s that represent registers that are split into sub-banks. For each *cellList*, the first element specifies a banked register name followed by its size and the remaining elements specify the list of sub-bank register instance names and sizes.

---

### DESCRIPTION

Use this guide mode command to enable Formality to name-match registers in the reference to the corresponding banked/split registers in the implementation.

## EXAMPLES

```
fm_shell (guide)> guide_multibit \
  -design myDesign \
  -type svfMultibitTypeBank \
  -groups \
  { { i_reg[7:0] 8 j_reg[2:0] 3 k_reg 1 i_reg_7_0_j_reg_2_0_k_reg_bank_reg 12 } \
    { d_reg[12:0] 13 d_reg_12_0_bank_reg 13 } }
```

1

```
fm_shell (guide)> guide_multibit \
  -design myDesign \
  -type svfMultibitTypeSplit \
  -groups \
  { { i_reg_7_0_j_reg_2_0_k_reg_bank_reg 12 \
    i_reg_7_0_j_reg_2_0_k_reg_bank_reg_bank[6_0] 7 \
    i_reg_7_0_j_reg_2_0_k_reg_bank_reg_bank[7] 1 \
    i_reg_7_0_j_reg_2_0_k_reg_bank_reg_bank[11_8] 4 } \
    { d_reg_12_0_bank_reg 13 \
    d_reg_12_0_bank_reg_bank[5_0] 6 \
    d_reg_12_0_bank_reg_bank[12_6] 7 } }
```

1

## SEE ALSO

guide\_change\_names(2)  
guide\_group(2)

---

## guide\_multiplier

Identifies a subdesign as a multiplier with a specific architecture.

---

### SYNTAX

#### **guide\_multiplier**

```
-design designName
[ -instance instanceName ]
-arch arch
-body fileName
[ -rounding { ExtPos [ IntPos ] } ]
[-enable enablePort]
[-odc_body odcBody]
[-logic_input { {odcPort} {odcAnchorPoint} }]
```

#### **Data Types**

```
designName string
instanceName string
arch string
fileName string
ExtPos int
IntPos int
enablePort string
odcBody string
odcPort string
odcAnchorPoint string
```

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

#### **-design *designName***

Specifies the name of the design containing the multiplier.

#### **-instance *instanceName***

Specifies the name of the instance containing the multiplier.

#### **-arch *arch***

Specifies the architecture of the multiplier: *csa*, *pparch*, or *apparch*.

#### **-body *fileName***

Specifies the file containing the multiplier description, either a .db file or a netlist.

#### **-rounding { *ExtPos* *IntPos* }**

Specifies the external and internal rounding positions, if any.

**-enable *enablePort***

Specifies the name of the enable port in *datapathBody* specified datapath description.

**-odc\_body *odcBody***

Specifies the name of the file containing the odc datapath description (netlist format).

**-logic\_input *odcPort odcAnchorPoint***

Specifies pair of data, first name of the odc port in *odcBody* netlist second name of respective concordant object

---

## DESCRIPTION

Use this guide mode command to identify a subdesign as a multiplier with a specific architecture.

---

## EXAMPLES

```
fm_shell (guide)> guide_multiplier \
    -design { fei_int } \
    -instance { mul_24/mult/mult } \
    -arch { csa } \
    -body { fei_int_DW02_mult_8_8_0 } \
    -rounding { 8 6 } \
    -enable { DG_ctrl } \
    -odc_body { fei_int_DW02_mult_8_8_0_odc } \
    -logic_input { { DG_l2 } { enable } }
```

1

---

## SEE ALSO

guide(2)

---

## guide\_port\_constant

Identifies an input port or pin that is tied to a constant.

---

### SYNTAX

```
guide_port_constant  
-design design_name  
-value 0 | 1 | X  
-ports { port_name ... }  
-pins { pin_name ... }
```

#### Data Types

```
design_name string  
port_name string  
pin_name string
```

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

#### **-design** *design\_name*

Specifies the name of the design whose ports/pins are tied to a constant.

#### **-value** 0 | 1 | X

Specifies a value (0,1,X) that is applied to the input port as a constant.

#### **-ports** *port\_name*

Specifies a Tcl list of input port names that is tied to the value specified by the **-value** option.

#### **-pins** *pin\_name*

Specifies a Tcl list of input pin names that is tied to the value specified by the **-value** option.

---

### DESCRIPTION

Use the **guide\_port\_constant** command to specify the input ports or pins that are held constant. The tool ignores this command if either the **synopsys\_auto\_setup** variable or the **svf\_port\_constant** variable is not set to *true*.

---

## EXAMPLES

To set the port `en` of design `top` to 1:

```
fm_shell (guide)> guide_port_constant -design top -value 1 -ports { en }
```

---

## SEE ALSO

[guide\(2\)](#)  
[synopsys\\_auto\\_setup\(3\)](#)  
[svf\\_port\\_constant\(3\)](#)

---

## guide\_private

Instructs svf processing to obtain and execute the next guidance from an associated private file.

---

### SYNTAX

**guide\_private**  
[ -root *dir\_path* ]  
[ -skip ]

#### Data Types

*dir\_path* string

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

#### **-root *dir\_path***

Specifies the path to the private file containing the private guidance

#### **-skip**

Instructs svf processing to skip, or not process, the private svf guide (in the associated private file) corresponding to this `guide_private`.

---

### DESCRIPTION

Use this guide mode command to direct svf processing to access and execute the next available guidance command to be found in a private file associated with the (public) svf in which this `guide_private` command was found.

---

### EXAMPLES

```
fm_shell (guide)> guide_private
```

```
fm_shell (guide)> guide_private -skip
```

```
fm_shell (guide)> guide_private -root private_svf_2/private
```

1



---

## SEE ALSO

[guide\(2\)](#)

---

## guide\_reg\_constant

Asserts that a register can never reach any known value different from a specified constant value.

---

### SYNTAX

```
guide_reg_constant  
[ -design designName ]  
[ -replaced svfTrue | svfFalse ]  
instanceName  
constantVal
```

#### Data Types

```
designName string  
instanceName string  
constantVal integer
```

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

#### **-design *designName***

Specifies the name of the design containing the register. Specify only the design name, and not the workspace and container names.

#### **-replaced svfTrue | svfFalse | svfRewireLoads**

Specifies whether the register has been replaced, in the implementation, with the constant. The value "svfFalse" specifies the register and its reader connections are preserved, and we annotate the register as constant. The value "svfRewireLoads" specifies that the register is preserved but it's loads are rewired to the specified value. The value "svfTrue" specifies that the register will be optimized away and it's loads connected to the specified value.

#### ***instanceName***

Specifies the hierarchical path from the specified design to the target register.

#### ***constantVal***

Specifies the constant value.

---

### DESCRIPTION

This command asserts that a register can never reach any known value different from a specified constant value, and to inform

Formality whether or not the register has been replaced, in the implementation, with that constant. Formality will verify that the register can in fact load no other value. If that verification succeeds and "-replaced" is "svfTrue", Formality will replace the register with the specified constant. If that verification succeeds and "-replaced" is "svfFalse", Formality will not replace the register but will use the verified constant value as a constraint for subsequent verification. For example, if the constant value is 0, Formality will allow only the values 0 and X, not 1, as previous states for the register in subsequent verification. If "-replaced" is "svfRewireLoads", the register will remain and become unread, but its loads will be connected to the constant so they cannot be driven by X.

If "-replaced" is not specified, Formality will assume the register has not been replaced, unless/until a subsequent SVFpre-verification depending on the register fails, at which point it will re-attempt the verification with the assumption that the register has been replaced. This results in nonoptimal run time, and can eventually lead to false differences if the register has not in fact been replaced. Therefore, though -replaced is optional for backward-compatibility, it is recommended to always specify it.

---

## EXAMPLES

To specify that the instance *U1* inside design *test* has been replaced with a constant 1:

```
fm_shell (guide)> guide_reg_constant -design test U1 1 -replaced svfTrue
```

To specify that the instance *r:WORK/top/mid\_inst\_0/bot\_inst\_0/state[0]* can only load constant 0, but has not been replaced with a constant 0:

```
fm_shell (guide)> guide_reg_constant -design top mid_inst_0/bot_inst_0/state[0] 0 -replaced svfFalse
```

---

## SEE ALSO

guide(2)

---

## guide\_reg\_duplication

Identifies duplicated registers.

---

### SYNTAX

**guide\_reg\_duplication**  
[-design *designName*]  
-from *fromReg*  
-to *toList*

#### Data Types

*designName* string  
*fromReg* string  
*toList* string

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

#### -design *designName*

Specifies the name of the design containing the duplicate registers. By default, the command operates on all designs.

#### -from *fromReg*

Specifies the name of the original register.

#### -to *toList*

Specifies a list of duplicated registers.

---

### DESCRIPTION

This guide mode command identifies duplicated registers.

---

### EXAMPLES

The following example shows the registers that are duplicates of the register named *UI* in a design named *test*.

```
prompt> guide_reg_duplication \  
-design test \  
-from U1 \  
-to { U1 U2 U3 }  
1
```

---

## SEE ALSO

`guide(2)`

---

## guide\_reg\_encoding

Identifies registers whose encoding has changed, usually from binary to carry-save.

---

### SYNTAX

```
integer guide_reg_encoding  
-design designName  
-from fromStyle  
-to toStyle  
{bit bit [ bit*]}
```

#### Data Types

```
designName string  
fromStyle string  
toStyle string  
bit String
```

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

#### **-design *designName***

Specifies the name of the design containing the encoded register.

#### **-from *fromStyle***

Specifies the original style of the register.

#### **-to *toStyle***

Specifies the new style of the register.

#### ***bit***

Specifies the register bits.

---

### DESCRIPTION

This guide mode command identifies bits of registers that are re-encoded. For a binary to carry-save encoding, the first bit on each line represents the binary value, and the remaining bits represent the carry-save encoding.

---

## EXAMPLES

The following example shows how to identify registers whose encoding has changed from binary to CS2 for a design named *test*.

```
prompt> guide_reg_encoding \  
-design test \  
-from binary \  
-to CS2 \  
{ R[0] R_sum[0] R_carry[0] } \  
{ R[1] R_sum[1] R_carry[1] }  
1
```

---

## SEE ALSO

[guide\(2\)](#)

---

## guide\_reg\_eqop

Identifies registers that are equal and opposite. These registers are needed to verify the **guide\_reg\_constant** and **guide\_reg\_merging** commands.

---

### SYNTAX

```
status guide_reg_eqop
[ -design designName ]
  -from FromList
  -to ToReg
```

#### Data Types

```
designName string
FromList string
ToReg string
```

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

#### -design *designName*

Specifies the name of the design containing the registers that are merged according to the automated setup file.

#### -from *FromList*

Specifies a list of the equal or opposite registers. Use the "~" symbol to indicate opposite functionality.

#### -to *ToReg*

Specifies the register to which the pins are merged for preverification.

---

### DESCRIPTION

Use this command to identify registers with equivalent functionality that are used to verify the **guide\_reg\_merging**, and **guide\_reg\_constant** commands. This command does not modify the reference design. After the related **guide\_reg\_merging** and **guide\_reg\_constant** commands are processed, the tool ignores this command.

---

### EXAMPLES



```
fm_shell (guide)> guide_reg_eqop \  
-design top \  
-to { Q2 }\  
-from { Q2 Q3 ~Q4 } \  
1
```

---

## SEE ALSO

[guide\(2\)](#)  
[guide\\_reg\\_merging\(2\)](#)  
[guide\\_reg\\_constant\(2\)](#)

---

## guide\_reg\_merging

Identifies merged registers.

---

### SYNTAX

**guide\_reg\_merging**  
-design *designName*  
-from *fromList*  
-to *toReg*  
[ -replaced svfRewireLoads ]

#### Data Types

*designName* string  
*fromList* string  
*toReg* string

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

#### **-design *designName***

Specifies the name of the design that contains the merged registers.

#### **-replaced svfRewireLoads**

Specifies if the from registers are left in the design unread. Normally the -from registers are removed.

#### **-from *fromList***

Lists the merged registers.

#### **-to *toReg***

Specifies the final register.

---

### DESCRIPTION

This command is used to rewire the loads of the -from registers to the -to register, and removes the now unread-from registers. Formality will first verify that the merge is valid, by confirming that the logic driving each from register is consistent with the logic driving the -to register. To be considered valid, the X space of the -to register has to be a subset of each of the -from registers, to avoid increasing the X space of the reference. An inverted merge is specified by "~" before the inverted merge register in the from list.

---

## EXAMPLES

```
fm_shell (guide)> guide_reg_merging \  
-design top \  
-from { Q3 } \  
-to Q2
```

1

To specify that the Q3 loads be transferred to Q2.

---

## SEE ALSO

[guide\(2\)](#)

---

## guide\_reg\_removal

Identifies registers that been removed during synthesis.

---

### SYNTAX

**guide\_reg\_removal**  
-design *designName*  
-cells *cellList*

#### Data Types

*designName* string  
*cellList* string

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

**-design *designName***

Specifies the name of the design containing the removed registers.

**-cells *fromList***

Specifies a list of removed registers.

---

### DESCRIPTION

Use this guide mode command to identify registers which have been removed. NOTE: This automated setup file is for information only and is not to be used or verified by Formality.

---

### EXAMPLES

```
fm_shell (guide)> guide_reg_removal \  
-design top \  
-cells { reg1 reg2 }  
1
```

---

## SEE ALSO

---

## guide\_reg\_split

Describes how to split loads of a given register onto its many duplicate copies.

---

### SYNTAX

#### **guide\_reg\_split**

-design {*designName*}  
-from {*RegName*}  
-to {*RegName:Pin LoadList*}

#### Data Types

*designName* string  
*RegName* string  
*Pin* string  
*LoadList* TCL list of cell:pin pairs

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

#### **-design *designName***

Specifies the name of the design that contains the registers.

#### **-from *RegName***

Specifies the original register.

#### **-to *RegName:Pin LoadList***

Specifies the final registers and their load connections. Multiple occurrences of this option are legal.

---

### DESCRIPTION

Use this guide mode command to specify split registers.

---

### EXAMPLES

```
fm_shell (guide)> guide_reg_split \
```

```
1  -design { top } \  
    -from { reg1 } \  
    -to { reg11:Q { { C1:A } { C2:B } } } \  
    -to { reg12:Q { { C3:A } } }
```

---

## SEE ALSO

[guide\\_reg\\_merging\(2\)](#)

---

## guide\_rename\_design

Renames a design.

---

### SYNTAX

```
guide_rename_design  
-design oldName  
-new_design newName
```

#### Data Types

```
oldName string  
newName string
```

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

**-design *oldName***

Specifies the current name of the design.

**-new\_design *newName***

Specifies the new name of the design.

---

### DESCRIPTION

Use this guide mode command to rename a design.

---

### EXAMPLES

```
fm_shell (guide)> guide_rename_design \  
-design oldName \  
-new_design newName
```

1



## SEE ALSO

[guide\(2\)](#)

---

## guide\_replace

Describes high-level arithmetic optimizations.

---

### SYNTAX

#### **guide\_replace**

```
-origin { originName }  
[ -type { typeName } ]  
-design { designName } | -body { bodyName }  
-input { inputList }  
-output { outputList }  
-pre_resource { preResourceList }  
-pre_assign { preAssignList }  
-post_resource { postResourceList }  
-post_assign { postAssignList }
```

#### Data Types

```
originName string  
typeName string  
designName wstring  
bodyName string  
inputList string  
outputList string  
preResourceList string  
preAssignList string  
postResourceList string  
postAssignList string
```

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

#### **-origin { *originName* }**

Specifies the origin of the optimization.

#### **-type { *typeName* }**

Specifies the need for special case processing.

#### **-design { *designName* }**

Specifies the design in which the optimization takes place, if it is a design-based optimization.

#### **-body { *bodyName* }**

Specifies the netlist implementing the arithmetic block, if it is a block-based optimization.

#### **-input { *inputList* }**

Lists the optimization inputs.

**-output { *outputList* }**

Lists the optimization outputs.

**-pre\_resource { *preResourceList* }**

Lists the resources in the optimization pre-graph.

**-pre\_assign { *preAssignList* }**

Lists the assignments in the optimization pre-graph.

**-post\_resource { *postResourceList* }**

Lists the resources in the optimization post graph.

**-post\_assign { *postAssignList* }**

Lists the assignments in the optimization post graph.

---

## DESCRIPTION

Use this guide mode command to specify high-level arithmetic optimizations in a design or on a datapath block.

---

## EXAMPLES

```
fm_shell (guide)> guide_replace \
-origin { Gensh } \
-body { dp_sub_9_DP_OP_258_5050_0 } \
-input { unsigned 2 I1 } \
-input { unsigned 2 I2 } \
-input { unsigned 2 I3 } \
-output { unsigned 4 O1 } \
-pre_resource { { 4 } OP0 = MULT { { I1 ZERO 4 } { I1 ZERO 4 } } } \
-pre_resource { { 4 } OP1 = MULT { { I2 ZERO 4 } { I2 ZERO 4 } } } \
-pre_resource { { 4 } OP2 = ADD { { OP0.out.1 ZERO 4 } { OP1.out.1 ZERO 4 } } } \
-pre_resource { { 4 } OP3 = SUB { { OP2.out.1 ZERO 4 } { I3 ZERO 4 } } } \
-pre_assign { O1 = { OP3.out.1 ZERO 4 } } \
-post_resource { { 4 } OP3 = SOP { { { I2 ZERO 4 } { I2 ZERO 4 } } { { I1 ZERO 4 } { I1 ZERO 4 } } { { - I3 ZERO 4 } } } } \
-post_assign { O1 = { OP3.out.1 ZERO 4 } }
```

```
fm_shell (guide)> guide_replace \
-origin { Presto_aco } \
-type { svfReplacePrestoConditionalAccumulation } \
-design { digit_package } \
-input { 1 src_1 } \
-input { 1 src_2 } \
-input { 10 src_3 } \
-input { 10 src_4 } \
-output { 10 aco_out } \
-pre_resource { { { 10 } add_837 = ADD { { src_3 ZERO 10 } { src_4 ZERO 10 } } } } \
-pre_resource { { { 10 } C921 = SELECT { { src_1 } { src_2 } { add_837 ZERO 10 } { src_3 ZERO 10 } } } } \
-pre_assign { aco_out = { C921 ZERO 10 } } \
-post_resource { { { 10 } mult_add_837_aco = MULT { { src_4 ZERO 10 } { src_1 ZERO 10 } } } } \
-post_resource { { { 10 } add_837_aco = ADD { { src_3 ZERO 10 } { mult_add_837_aco ZERO 10 } } } } \
-post_assign { aco_out = { add_837_aco ZERO 10 } }
```

1

---

## SEE ALSO

[guide\(2\)](#)

---

## guide\_retiming

Describes a basic register retiming move over a library cell or net fork.

---

### SYNTAX

```
integer guide_retiming  
-design {designName}  
-direction {direction}  
-libCell {cellName}  
-input {cellInput}  
-output {cellOutput}  
[-resetStateDontCare]
```

#### Data Types

```
designName string  
direction string  
cellName string  
cellInput string  
cellOutput string
```

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

#### **-design** *designName*

Specifies the name of the design that contains retimed logic.

#### **-direction** *direction*

Specifies the direction that the given register has moved, forward or backward.

#### **-libCell** *cellName*

Specifies the name of the library cell across which the register has moved or **FM\_FORK** for a net fork.

#### **-input** *cellInput*

Specifies the input to the cell across which the register has moved, in the format *PinName:RegisterName*. Multiple occurrences of this option are legal.

#### **-output** *cellOutput*

Specifies the output of the cell across which the register has moved, in the format *PinName:RegisterName*. Multiple occurrences of this option are legal.

#### **-resetStateDontCare**

Indicates whether the reset state of the register changed during the retiming move.

---

## DESCRIPTION

This guide mode command describes a basic register retiming move over a library cell or net fork.

---

## EXAMPLES

The following example shows the command used with a design named *test* in a *forward* direction on a library cell named *NAND2* with multiple inputs and output as shown.

```
prompt> guide_retiming \  
-design {test} \  
-direction {forward} \  
-libCell {NAND2} \  
-input {A:q1_reg} \  
-input {B:q2_reg} \  
-output {Y:__tmp__name__0}  
1
```

---

## SEE ALSO

[guide\\_retiming\\_decompose\(2\)](#)  
[guide\\_retiming\\_finished\(2\)](#)  
[guide\\_retiming\\_multibit\(2\)](#)  
[svf\\_retiming\(3\)](#)

---

## guide\_retiming\_class

Identifies a given SEQ as the leader of the named retiming Class.

---

### SYNTAX

**guide\_retiming\_class**  
-design {*designName*}  
-name {*ClassName*}  
-leader {*RegName*}

#### Data Types

*designName* string  
*ClassName* string  
*RegName* string

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

**-design *designName***

Specifies the name of the design that contains the cell in -leader.

**-name *ClassName***

Specifies the name of the retiming class.

**-leader *RegName***

Specifies the name of the SEQ that is chosen to be the leader of the named retiming class.

---

### DESCRIPTION

This guide mode command identifies a given SEQ as the leader of the named retiming Class. Class is determined by SL, SC, SS, AL, AC, AS, CLK nets of a given SEQ. Two SEQs Reg1 and Reg2 are in the same class if their SL1=SL2, CLK1=CLK2, AL1=AL2, SC1|SS1=SC2|SS2, and AC1|AS1=AC2|AS2.

---

### EXAMPLES

The following example shows the command used with a design named *test* and on register instance "reg1" which is a multibit (4 bit) register.

```
prompt> guide_retiming_class \  
-design {test} \  
-name {Class_1} \  
-leader {REG_0}
```

---

## SEE ALSO

```
guide_retiming_pinmap(2)  
guide_retiming_unmap(2)  
guide_retiming_seqmap(2)  
guide_retiming_cross(2)  
guide_retiming_move(2)
```



---

## guide\_retiming\_cross

Describes a register moving across a hierarchy.

---

### SYNTAX

#### **guide\_retiming\_cross**

-design {*designName*}  
-direction {*Direction*}  
-class {*ClassName*}  
-from {*RegName*}  
-to {*RegName*}

#### **Data Types**

*designName* string  
*Direction* string, either svfForward or svfBackward  
*ClassName* string  
*RegName* string, hierarchical register name relative to -design

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

#### **-design *designName***

Specifies a register move crossing hierarchy.

#### **-direction *Direction***

Specifies the move direction (forward or backward)

#### **-class *ClassName***

Specifies the name of the retiming class.

#### **-from *RegName***

Specifies the name of the existing register (SEQ) before the move. RegName can be hierarchical relative to -design.

#### **-to *RegName***

Specifies the name of the new register (SEQ) after the move. RegName can be hierarchical relative to -design.

---

### DESCRIPTION

This guide mode command specifies a register move across design hierarch.

---

## EXAMPLES

The following example shows the command used with a design named *test* to move *REG\_O* across design hierarchy *U1*.

```
prompt> guide_retiming_cross \  
-design {test} \  
-direction {svfForward} \  
-class {Class_1} \  
-from {REG_0} \  
-to {U1/REG_10}
```

---

## SEE ALSO

```
guide_retiming_pinmap(2)  
guide_retiming_unmap(2)  
guide_retiming_seqmap(2)  
guide_retiming_class(2)  
guide_retiming_move(2)
```

---

## guide\_retiming\_decompose

Indicates that a synchronous enable register is decomposed - changed to a D flip-flop with a feedback MUX.

---

### SYNTAX

```
integer guide_retiming_decompose  
-design {designName}  
-preName {previousName}  
-postName {changedName}  
[ -classChanged ]
```

#### Data Types

```
designName string  
previousName string  
changedName string
```

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

#### **-design** *designName*

Specifies the name of the design that contains the decomposed register.

#### **-preName** *previousName*

Specifies the name of the register before decomposition.

#### **-postName** *changedName*

Specifies the name of the register after decomposition. If the name is not changed, then the postName is the same as the preName.

#### **-classChanged**

Indicates whether the class of the register has changed or not.

---

### DESCRIPTION

Use this guide mode command to indicate that a synchronous enable register has changed to a D flip-flop with a feedback MUX, or decomposed.

---

## EXAMPLES

```
prompt> guide_retiming_decompose \  
-design {test} \  
-preName {q1_reg[0]} \  
-postName {q1_reg[0]} \  
-classChanged  
1
```

---

## SEE ALSO

```
guide_retiming(2)  
guide_retiming_finished(2)  
guide_retiming_multibit(2)  
svf_retiming(3)
```

---

## guide\_retiming\_eq\_nets

Specifies that in a given context (-design) the listed nets can be shown to be either logically equivalent (-nets) or gated equivalent (-gated\_nets). And this equivalence shall be later needed in a retiming guide for the -target\_instance.

---

### SYNTAX

```
guide_retiming_eq_nets  
-design {designName}  
-target_instance {cellName}  
-gated_nets {listOfNets}  
-nets {listOfNets}
```

#### Data Types

*designName* string  
*cellName* string  
*listOfNets* list of list of hierarchical net names

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

#### **-design** *designName*

Specifies the name of the design in which the listed equivalences can be proven.

#### **-target\_instance** *cellName*

Specifies the name of the cell instance that equivalences need to be propagated.

#### **-gated\_nets** *listOfNets*

Lists the name of the nets arranged in equivalence class sets. Specifies that equivalence is in the sense of gated clock equivalence.

#### **-nets** *listOfNets*

Lists the name of the nets arranged in equivalence class sets. Specifies that the equivalence is in the sense of logical equivalence.

---

### DESCRIPTION

This guide mode command specifies that certain nets are equivalent in the given contest and needs to be recognized in another context target\_instance. The equivalence can be gated equivalence and/or logical equivalence.

---

## EXAMPLES

The following example shows that "U1/en1" and "U1/en2" are logically equivalent also "U1/clk1" and "U1/clk2" are logically equivalent outside of U1 and needs to be recognized inside U1. The equivalence can be proven in the design *test*.

```
prompt> guide_retiming_eq_nets \  
-design { test } \  
-target_instance { U1 } \  
-nets { { U/en1 U1/en2 } { U1/clk1 U1/clk2 } }
```

---

## SEE ALSO

```
guide_retiming_pinmap(2)  
guide_retiming_unmap(2)  
guide_retiming_seqmap(2)  
guide_retiming_class(2)  
guide_retiming_cross(2)  
guide_retiming_move(2)
```

---

## guide\_retiming\_finished

Indicates that the group of automated setup (SVF) retiming commands for this design is finished.

---

### SYNTAX

status **guide\_retiming\_finished**

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

None

---

### DESCRIPTION

This guide mode command indicates that the group of automated setup (SVF) retiming commands for this design is finished.

---

### EXAMPLES

The following example shows that the group of automated setup (SVF) retiming commands for this design is finished.

```
prompt> guide_retiming_finished
1
```

---

### SEE ALSO

guide\_retiming(2)  
guide\_retiming\_decompose(2)  
guide\_retiming\_multibit(2)  
svf\_retiming(3)

---

## guide\_retiming\_move

Describes how registers are moved (retimed) across a given gate instance.

---

### SYNTAX

**guide\_retiming\_move**  
-design {*designName*}  
-direction {*moveDirection*}  
-class {*className*}  
-cell {*cellName*}  
-input {*Pin:regName:AsyncState:SyncState*}  
-output {*Pin:regName:AsyncState:SyncState*}

#### Data Types

*designName* string  
*moveDirection* string (either svfForward or svfBackward)  
*className* string  
*cellName* string  
*Pin* string  
*regName* string  
*AsyncState* integer (between 0 and 7), or nothing if no async clear/set on this register  
*SyncState* integer (between 0 and 7), or nothing if no sync clear/set on this register

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

#### -design *designName*

Specifies the name of the design that contains the cell in -cell.

#### -direction *moveDirection*

Specifies the direction of the register move across the given cell (forward or backward).

#### -class *className*

Specifies the retiming class to which the moving registers belong.

#### -cell *cellName*

Specifies the name of the cell instance over which registers move.

#### -input *Pin:regName:AsyncState:SyncState*

For forward direction, this specifies the existing register *regName* that drives the input pin *Pin* of the cell *cellName*. For backward direction, this specifies the new after move register with the name *regName* that will drive the input pin *Pin* of the cell *cellName*. *AsyncState* (number between 0 and 7) specifies the async reset state (connections to its AC, AS pins) of this particular register



relative to Class leader. SyncState (number between 0 and 7) specifies the sync reset state (connections to its SC, SS pins) of this particular register relative to Class leader. Multiple occurrences of this option are legal.

**-output *Pin:regName:AsyncState:SyncState***

For forward direction, this specifies the new after move register with the name regName that will be driven by the output pin Pin of the cell cellName. For backward direction, this specifies the existing register regName that is driven by the output pin Pin of the cell cellName. AsyncState (number between 0 and 7) specifies the async reset state (connections to its AC, AS pins) of this particular register relative to Class leader. SyncState (number between 0 and 7) specifies the sync reset state (connections to its SC, SS pins) of this particular register relative to Class leader. Multiple occurrences of this option are legal.

---

## DESCRIPTION

This guide mode command describes how registers move over a given logic cell instance and the reset state of these registers before and after the move. For example, if one register is moving over an inverter, then its clear connection has to move to set. Otherwise, this move introduces a difference.

---

## EXAMPLES

The following example shows a forward move across NAND gate instance *C1* in design named *test* of registers *Reg1* and *Reg2* with class *Class\_1* (lets assume this class has async clear/set and no sync clear/set).

```
prompt> guide_retiming_move \
-design {test} \
-direction {svfForward}
-class {Class_1} \
-cell {C1} \
-input {A:Reg1:2;} \
-input {A:Reg2:2;} \
-output {Z:NewReg1:4;}
```

---

## SEE ALSO

```
guide_retiming_pinmap(2)
guide_retiming_unmap(2)
guide_retiming_seqmap(2)
guide_retiming_class(2)
guide_retiming_cross(2)
```

---

## guide\_retiming\_multibit

Indicates if a multibit register is split into one-bit registers.

---

### SYNTAX

```
guide_retiming_multibit
-design { designName }
-multiName { previousName }
-splitNames { newNames }
```

#### Data Types

```
designName string
previousName string
newNames string
```

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

**-design** *designName*

Specifies the name of the design that contains the multibit register.

**-multiName** *previousName*

Specifies the name of the multibit register before being split.

**-splitNames** *changedName*

Specifies the name of the registers after being split.

---

### DESCRIPTION

Use this guide mode command to indicate that a multibit register is split into one-bit registers.

---

### EXAMPLES

```
fm_shell (guide)> guide_retiming_multibit \
-design { test } \
```

```
-multiName { example_reg[0:3] } \
-splitNames { Q3:example_reg[0:3]_Q3 } \
-splitNames { Q2:example_reg[0:3]_Q2 } \
-splitNames { Q1:example_reg[0:3]_Q1 } \
-splitNames { Q0:example_reg[0:3]_Q0 }
1

fm_shell (guide)> guide_retiming_multibit \
-design { test } \
-multiName { my_reg[0:2] } \
-splitNames { Q2:my_reg2 Q1:my_reg1 Q0:my_reg0 }
1
```

---

## SEE ALSO

svf\_retiming(3)  
guide\_retiming(2)  
guide\_retiming\_decompose(2)  
guide\_retiming\_finished(2)

---

## guide\_retiming\_pinmap

Describes a mapping between pins of a techcell register and its internal SEQ pins.

---

### SYNTAX

#### **guide\_retiming\_pinmap**

```
-design {designName}
-cell {cellName}
-pinmap {Bit TechCellPin SEQpin Inversion}
or
-pinmap {Bit TechCellPin Constant NA}
```

#### **Data Types**

```
designName string
cellName string
Bit integer
TechCellPin string
SEQpin string
Inversion either svfTrue or svfFalse
Constant either svfZero or svfOne for inputs, svfNC for outputs meaning No Connection
NA string which is ignored
```

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

#### **-design *designName***

Specifies the name of the design that contains the cell in -cell.

#### **-cell *cellName***

Specifies the name of the cell instance of the techcell. We are only interested in the techcell not the instance. The linked design of the instance is our techcell.

#### **-pinmap *Bit TechCellPin SEQpin Inversion***

Specifies, for the bitnumber Bit for multibit, how is the techcell pin named TechCellPin connects to the internal SEQ pin. If the connection has inversion, then svfTrue is given for the Inversion. One important thing to note here is that if both AC and AS is used on this register, then one needs to specify the contention (AC=AS=1) state. In such a case, instead of just AC as SEQpin we use ACL meaning L (low, 0) state for the contention, and we use ACH meaning H (high, 1) state for the contention. Also, AS needs to be given as ASL or ASH. Something applies to sync SC SS contention (SCL/SCH for SC, and SSL/SSH for SS). If the TechCellPin is supposed to connect to a constant, then the second form of -pinmap is used. Multiple occurrences of this option are legal.

#### **-pinmap *Bit TechCellPin Constant NA***

Specifies if the techcell register pin TechCellPin is a constant (svfZero or svfOne) for inputs, or No Connection (svfNC) for outputs. Multiple occurrences of this option are legal.

---

## DESCRIPTION

This guide mode command describes the semantics of each techcell register pin in terms of its connection or "equivalent" connection to its internal SEQ pin. For multibit techcell register internal SEQs are indicated by their bit number. For single bit registers Bit is given as 0.

---

## EXAMPLES

The following example shows the command used with a design named *test* on a techcell instance *reg1*.

```
prompt> guide_retiming_pinmap \  
-design {test} \  
-cell {reg1} \  
-pinmap {0 DT SD svfFalse} \  
-pinmap {0 Q Q svfFalse} \  
-pinmap {0 RN AC svfTrue} \  
-pinmap {0 SET AS svfFalse} \  
-pinmap {0 EN SL svfFalse} \  
-pinmap {0 CK CLK svfFalse} \  
-pinmap {0 SE svfZero NA} \  
-pinmap {0 SI svfZero NA}
```

---

## SEE ALSO

[guide\\_retiming\\_unmap\(2\)](#)  
[guide\\_retiming\\_seqmap\(2\)](#)  
[guide\\_retiming\\_class\(2\)](#)  
[guide\\_retiming\\_cross\(2\)](#)  
[guide\\_retiming\\_move\(2\)](#)

---

## guide\_retiming\_seqmap

Describes a mapping between pins of external logic around the SEQ and the function of an unused pin of the SEQ, such that the extra logic can be removed and the pin is used instead. For example, Sync Clear is implemented via an external logic to pull the data line to 0 when clear is active, and we want to remove the extra logic and use SC pin instead.

---

### SYNTAX

```
guide_retiming_seqmap
-design {designName}
-cell {cellName}
-seqmap {Cell:Pin SEQpin Inversion}
or
-seqmap {Cell:Pin Constant NA}
```

#### Data Types

```
designName string
cellName string
Cell string
Pin string
SEQpin string
Inversion either svfTrue or svfFalse
Constant either svfZero or svfOne
NA string which is ignored
```

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

#### **-design *designName***

Specifies the name of the design that contains the cell in -cell.

#### **-cell *cellName***

Specifies the name of the SEQ that is created by guide\_retiming\_unmap.

#### **-seqmap *Cell:Pin SEQpin Inversion***

Specifies that the pin given by Cell:Pin pair implements the SEQpin functionality. It might have inverted relation indicated by svfTrue on the Inversion entry. One important thing to note here is that if both AC and AS is used on this register, then one needs to specify the contention (AC=AS=1) state. In such a case, instead of just AC as SEQpin we use ACL meaning L (low, 0) state for the contention, and we use ACH meaning H (high, 1) state for the contention. Also, AS needs to be given as ASL or ASH. Something applies to sync SC SS contention (SCL/SCH for SC, and SSL/SSH for SS). If the Cell:Pin is supposed to connect to a constant, then the second form of -seqmap is used. Multiple occurrences of this option are legal.

#### **-seqmap *Cell:Pin Constant NA***

Specifies if the pin Cell:Pin is driven by a constant (svfZero or svfOne). Multiple occurrences of this option are legal.

---

## DESCRIPTION

This guide mode command describes the pin and function correspondence of extra logic around a SEQ and unused pins of that SEQ. Such that we can remove the extra logic and utilize the unused SEQ pins instead.

---

## EXAMPLES

The following example shows the command used with a design named *test* and SEQ *reg1*, in order to pull-in the reset logic.

```
prompt> guide_retiming_seqmap \  
-design {test} \  
-cell {reg1} \  
-seqmap {U1:S SC svfFalse} \  
-seqmap {U1:A svfZero NA} \  
-seqmap {U1:B SD svfFalse}
```

---

## SEE ALSO

[guide\\_retiming\\_pinmap\(2\)](#)  
[guide\\_retiming\\_unmap\(2\)](#)  
[guide\\_retiming\\_class\(2\)](#)  
[guide\\_retiming\\_cross\(2\)](#)  
[guide\\_retiming\\_move\(2\)](#)

---

## guide\_retiming\_unmap

Describes how we actually apply the pinmap description on the given register instance.

---

### SYNTAX

**guide\_retiming\_unmap**  
-design {*designName*}  
-cell {*cellName*}  
-namemap {*Bit RegName*}

#### Data Types

*designName* string  
*cellName* string  
*Bit* integer  
*RegName* string

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

#### -design *designName*

Specifies the name of the design that contains the cell in -cell.

#### -cell *cellName*

Specifies the name of the cell instance of the techcell.

#### -namemap *Bit RegName*

Specifies the name of the SEQ that comes out of the pinmap conversion of this instance -cell. For multibit registers the Bit number is given. For single-bit registers Bit is given as 0. Multiple occurrences of this option are legal.

---

### DESCRIPTION

This guide mode command describes the names of the SEQs created by application of guide\_retiming\_pinmap description. For multibit registers the Bit number is given. For single-bit registers Bit is given as 0.

---

### EXAMPLES



The following example shows the command used with a design named *test* and on register instance "reg1" which is a multibit (4 bit) register.

```
prompt> guide_retiming_unmap \  
-design {test} \  
-cell {reg1} \  
-namemap {0 REG_0} \  
-namemap {1 REG_1} \  
-namemap {2 REG_2} \  
-namemap {3 REG_3}
```

---

## SEE ALSO

`guide_retiming_pinmap(2)`  
`guide_retiming_seqmap(2)`  
`guide_retiming_class(2)`  
`guide_retiming_cross(2)`  
`guide_retiming_move(2)`

---

## guide\_rewire

Identifies registers or pins that are merged.

---

### SYNTAX

```
status guide_rewire
[ -design designName ]
  -from fromList
  -to toReg
```

#### Data Types

```
designName string
fromList string
toReg string
```

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

**-design *designName***

Specifies the name of the design containing the merged registers.

**-from *fromList***

Specifies a list of the merged registers or pins.

**-to *toReg***

Specifies the final register or pin.

---

### DESCRIPTION

Use the **guide\_rewire** command to identify registers or pins that are merged. This command is similar to the **guide\_reg\_merging** command, but has the additional functionality of allowing registers at different levels of the hierarchy to be merged. Only pins that are directly driven by registers are allowed to be merged. This command is a superset of the **guide\_reg\_merging** command.

---

### EXAMPLES

```
fm_shell (guide)> guide_rewire \  
-design top \  
-from { Q1 Q3 } \  
-to Q2
```

1

---

## SEE ALSO

guide(2)  
guide\_reg\_merging(2)  
guide\_reg\_eqop(2)

---

## guide\_safety\_error\_code

This is a private guide.

---

### SYNTAX

**guide\_safety\_error\_code**  
-private *privateData*

#### Data Types

*privateData* string

---

### ENABLED SHELL MODES

Guide

---

### LICENSE

This command is available when the "Formality-FuSa" license key is used.

---

### ARGUMENTS

-private *privateData*

---

### DESCRIPTION

This is a private guide.

---

### EXAMPLES

```
guide_safety_error_code \  
-private { privateData }  
1
```

**SEE ALSO**

---

## guide\_safety\_error\_propagate

This is a private guide.

---

### SYNTAX

**guide\_safety\_error\_propagate**  
-private *privateData*

#### Data Types

*privateData* string

---

### ENABLED SHELL MODES

Guide

---

### LICENSE

This command is available when the "Formality-FuSa" license key is used.

---

### ARGUMENTS

-private *privateData*

---

### DESCRIPTION

This is a private guide.

---

### EXAMPLES

```
guide_safety_error_propagate \  
-private { privateData }  
1
```

## SEE ALSO

---

## guide\_safety\_fsm

This is a private guide.

---

### SYNTAX

**guide\_safety\_fsm**  
-private *privateData*

#### Data Types

*privateData* string

---

### ENABLED SHELL MODES

Guide

---

### LICENSE

This command is available when the "Formality-FuSa" license key is used.

---

### ARGUMENTS

-private *privateData*

---

### DESCRIPTION

This is a private guide.

---

### EXAMPLES

```
guide_safety_fsm \  
-private { privateData }  
1
```



## SEE ALSO

---

## guide\_safety\_reg\_group

This is a private guide.

---

### SYNTAX

**guide\_safety\_reg\_group**  
-private *privateData*

#### Data Types

*privateData* string

---

### ENABLED SHELL MODES

Guide

---

### LICENSE

This command is available when the "Formality-FuSa" license key is used.

---

### ARGUMENTS

-private *privateData*

---

### DESCRIPTION

This is a private guide.

---

### EXAMPLES

```
guide_safety_reg_group \  
-private { privateData }  
1
```

**SEE ALSO**

---

## guide\_scan\_input

Identifies a port or black box pin that should be tied to a constant to disable scan.

---

### SYNTAX

```
guide_scan_input  
-design design_name  
-disable_value 0 | 1  
-ports { port_name ... }  
-pins { pin_name ... }
```

#### Data Types

```
design_name string  
port_name string  
pin_name string
```

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

#### -design

Specifies the name of the design whose ports or pins should be tied to a constant.

#### -disable\_value

Specifies the constant value (0 or 1) that should be applied to the input port or BBOX output pin in order to disable scan circuitry that is inserted.

#### -ports

Specifies a Tcl list of input port names that should be tied to the value specified by using the *-disable\_value* option.

#### -pins

Specifies a Tcl list of BBOX pin names that should be tied to the value specified by using the *-disable\_value* option.

---

### DESCRIPTION

Use this guide mode command to specify that some inputs should be held constant in order to disable scan circuitry. This is used when scan circuitry is inserted or scan chains are reordered. This command is ignored if either the **synopsys\_auto\_setup** or **svf\_scan** variables are not set to *true*.

---

## EXAMPLES

To set the port test\_se of design top, to 0:

```
fm_shell (guide)> guide_scan_input -design top -disable_value 0 -ports { test_se }
```

---

## SEE ALSO

guide(2)  
guide\_scan\_output(2)  
synopsys\_auto\_setup(3)

---

## guide\_sequential\_cg\_fanin

This is a private guide.

---

### SYNTAX

**guide\_sequential\_cg\_fanin**  
-private *privateData*

#### Data Types

*privateData* string

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

-private *privateData*

Specifies the private data for the guide.

---

### DESCRIPTION

This is a private guide.

---

### EXAMPLES

```
guide_sequential_cg_fanin \  
-private { privateData } \  

```

---

### SEE ALSO

---

## guide\_set\_rounding

Specifies the initial rounding information for multipliers.

---

### SYNTAX

**guide\_set\_rounding**  
-design *designName*  
-cells *cellName*  
-rounding { *ExtPos* [ *IntPos* ] }

#### Data Types

*designName* string  
*cellName* string  
*ExtPos* int  
*intPos* int

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

**-design *designName***

Specifies the name of the design containing the multiplier.

**-cells *cellName***

Specifies the name of the multiplier cell.

**-rounding { *ExtPos* *IntPos* }**

Specifies the external and internal rounding positions.

---

### DESCRIPTION

Use this guide mode command to specify the internal and external rounding modifications applied to a multiplier.

---

### EXAMPLES

```
fm_shell (guide)> guide_set_rounding \
```

```
1  -design { top } \  
    -cells { mult_123 } \  
    -rounding { 12 4 }
```

---

## SEE ALSO

guide(2)  
set\_dp\_int\_round(2)



---

## guide\_share

Describes high-level resource sharing optimizations.

---

### SYNTAX

```
guide_share
{ -origin originName }
{ -design designName }
{ -input inputList }
{ -output outputList }
{ -control controlList }
{ -pre_resource preResourceList }
{ -pre_assign preAssignList }
{ -post_resource postResourceList }
{ -post_assign postAssignList }
```

#### Data Types

```
originName string
designName string
inputList string
outputList string
controlList string
preResourceList string
preAssignList string
postResourceList string
postAssignList string
```

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

#### **-origin *originName***

Specifies the name indicating where the optimization came from.

#### **-design *designName***

Specifies the name of the design in which the optimization takes place.

#### **-input *inputList***

Lists graph inputs.

#### **-output *outputList***

Lists graph outputs.

#### **-control *controlList***

Lists control inputs.

**-pre\_resource *preResourceList***

Lists resources in the optimization pre-graph.

**-pre\_assign *preAssignList***

Lists assignments in the optimization pre-graph.

**-post\_resource *postResourceList***

Lists resources in the optimization post graph.

**-post\_assign *postAssignList***

Lists assignments in the optimization post graph.

---

## DESCRIPTION

Use this guide mode command to specify high-level resource sharing optimizations.

---

## EXAMPLES

```
fm_shell (guide)> guide_share \
-origin { ExTra_mutex } \
-design { dp } \
-input { 8 I1 } \
-input { 8 I2 } \
-output { 8 O1 } \
-output { 8 O2 } \
-control { C1 = add_10 } \
-control { C2 = sub_10 } \
-pre_resource { { 8 } add_10 = ADD { { I1 ZERO 8 } { I2 ZERO 8 } } } \
-pre_resource { { 8 } sub_10 = SUB { { I1 ZERO 8 } { I2 ZERO 8 } } } \
-pre_assign { O1 = { add_10 ZERO 8 } } \
-pre_assign { O2 = { sub_10 ZERO 8 } } \
-post_resource { { 8 } addsub_10_addsub = ADDSUB { { addsub_10_sel_1 ZERO 8 }
  { addsub_10_sel_2 ZERO 8 } { addsub_10_sel_3 } } } \
-post_resource { { 8 } addsub_10_sel_1 = SELECT { { C1 } { C2 } { I1 ZERO 8 }
  { I1 ZERO 8 } } } \
-post_resource { { 8 } addsub_10_sel_2 = SELECT { { C1 } { C2 } { I2 ZERO 8 }
  { I2 ZERO 8 } } } \
-post_resource { { 1 } addsub_10_sel_3 = SELECT { { C1 } { C2 } { `b0 }
  { `b1 } } } \
-post_assign { O1 = { addsub_10_addsub ZERO 8 } } \
-post_assign { O2 = { addsub_10_addsub ZERO 8 } }
1
```

---

## SEE ALSO

guide(2)

---

## guide\_split\_constant

Describes high-level implementation of a constant.

---

### SYNTAX

```
guide_split_constant  
-output { outputList }  
-pre_assign { preAssignList }  
-post_resource { postResourceList }  
-post_assign { postAssignList }
```

#### Data Types

```
outputList string  
preAssignList string  
postResourceList string  
postAssignList string
```

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

**-output { *outputList* }**

Lists the optimization outputs.

**-pre\_assign { *preAssignList* }**

Lists the constant that is being implemented.

**-post\_resource { *postResourceList* }**

Lists the resources in the optimization post graph.

**-post\_assign { *postAssignList* }**

Lists the assignments in the optimization post graph.

---

### DESCRIPTION

Use this guide mode command to specify how a constant is implemented.

## EXAMPLES

```
fm_shell (guide)> guide_split_constant \
-output { 12 out } \
-pre_assign { out = { S`b100100100100 } } \
-post_resource { { 12 } T0 = SHIFT { { U`b1 ZERO 12 } { U`b11 } { U`b0 } { U`b0 } { U`b1 } { U`b0 } } } \
-post_resource { { { 12 } T1 = ADD { { T0 ZERO 12 } { - U`b1 ZERO 12 } } } } \
-post_resource { { { 12 } T2 = ADD { { U`b1 ZERO 12 } { T0 ZERO 12 } } } } \
-post_resource { { { 12 } T3 = SHIFT { { T1 ZERO 12 } { U`b110 } { U`b0 } { U`b0 } { U`b1 } { U`b0 } } } } \
-post_resource { { { 12 } T4 = ADD { { T3 ZERO 12 } { - T2 ZERO 12 } } } } \
-post_resource { { { 12 } T5 = SHIFT { { T4 ZERO 12 } { U`b10 } { U`b0 } { U`b0 } { U`b1 } { U`b0 } } } } \
-post_resource { { { 12 } T6 = ADD { { S`b000000000000 SIGN 12 } { - T5 SIGN 12 } } } } \
-post_assign { out = { T6.out.1 ZERO 12 } }
```

1

---

## SEE ALSO

guide(2)

---

## guide\_time\_begin

---

### SYNTAX

**guide\_time\_begin**  
*"datetime"*

#### Data Types

*datetime* integer

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

*datetime*

Specifies the date and time.

---

### DESCRIPTION

This command is for internal use only.

---

## guide\_time\_end

---

### SYNTAX

`guide_time_end`

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

None.

---

### DESCRIPTION

This command is for internal use only.

---

### EXAMPLES

N/A

---

## guide\_transformation

Describes design transformations.

---

### SYNTAX

#### **guide\_transformation**

```
-design designName
-type type
-input inputList
-output outputList
[ -control controlList ]
[ -virtual virtualList ]
[ -pre_resource preResourceList ]
[ -pre_assign preAssignList ]
[ -post_resource postResourceList ]
[ -post_assign postAssignList ]
[ -datapath datapathList ]
```

#### **Data Types**

```
designName string
type string
inputList string
outputList string
controlList string
virtualList string
preResourceList string
preAssignList string
postResourceList string
postAssignList string
datapathList string
```

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

#### **-design *designName***

Specifies the name of the design to be transformed.

#### **-type *type***

Specifies the type of transformation: share, tree, map, or merge.

#### **-input *inputList***

Lists transformation inputs.

#### **-output *outputList***

Lists transformation outputs.

**-control *controlList***

Lists transformation control signals.

**-virtual *virtualList***

Lists transformation virtual signals.

**-pre\_resource *preResourceList***

Lists resources in the transformation pre-graph.

**-pre\_assign *preAssignList***

Lists assignments in the transformation pre-graph.

**-post\_resource *postResourceList***

Lists resources in the transformation post graph.

**-post\_assign *postAssignList***

Lists assignments in the transformation post graph.

**-datapath *datapathList***

Lists datapath elements in the transformation.

---

## DESCRIPTION

Use this guide mode command to describe high-level design transformations.

---

## EXAMPLES

```
fm_shell (guide)> guide_transformation \
    -design general_tree \
    -type tree \
    -input { 4 src1 4 src2 4 src4 } \
    -output { 6 O1 } \
    -control { ctrl1 = cond ctrl2 } \
    -pre_resource { { 5 5 } add_7 = DIV { { src1 2 4 }
{ src2 2 3 ZERO 3 } } } \
    -pre_resource { { { 5 5 } add_8 = DIV { { src1 2 4 }
{ src2 2 4 ZERO 5 } } } } \
    -pre_resource { { { 5 5 } add_9 = DIV { { src1 ZERO 5 }
{ src2 ZERO 5 } } } } \
    -pre_resource { { { 6 4 4 } sub_9 = USUB { { add_9 ZERO 6 }
{ src4 ZERO 6 } } } } \
    -pre_assign { O1 = { sub_9 } } \
    -post_resource { { 6 7 4 3 } sub_1_root_sub_9 = USUB {
{ src1 ZERO 6 } { src4 ZERO 6 } } } \
    -post_resource { { { 6 7 3 2 5 } add_0_root_sub_9 = UADD {
{ src2 ZERO 6 } { sub_1_root_sub_9 } } } } \
    -post_assign { O1 = { add_0_root_sub_9 } }
```

1



---

## SEE ALSO

[guide\(2\)](#)

---

## guide\_ungroup

Removes hierarchy from design objects.

---

### SYNTAX

**guide\_ungroup**  
-design *designName*  
-cells *cellList*  
[ *renameBlock* ]

#### Data Types

*designName* string  
*cellList* string  
*renameBlock* string

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

**-design *designName***

Specifies the name of the design containing the objects.

**-cells *cellList***

Lists the cells being ungrouped.

***renameBlock***

Specifies a space separated list of old-cell new-name pairs.

---

### DESCRIPTION

Use this guide mode command to remove hierarchy from design objects.

---

### EXAMPLES

```
fm_shell (guide)> guide_ungroup \  
-design shift8 \
```

```
-cells { foo } \  
{ { shift8/shift4_i_1/shift2_i_1/dout_reg dout_reg } \  
  { shift8/shift4_i_1/shift2_i_1/state1_reg state1_reg } \  
  { shift8/shift4_i_1/shift2_i_2/dout_reg dout_reg1 } \  
  { shift8/shift4_i_1/shift2_i_2/state1_reg state1_reg1 } \  
  { shift8/shift4_i_2/shift2_i_2/state1_reg state1_reg3 } }
```

1

---

## SEE ALSO

[guide\(2\)](#)

---

## guide\_uniquify

Creates unique instances for design objects.

---

### SYNTAX

**guide\_uniquify**  
-design *designName*  
[ *uniquifyBlock* ]

#### Data Types

*designName* string  
*uniquifyBlock* string

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

**-design *designName***

Specifies the name of the design containing the objects being uniquified.

***uniquifyBlock***

Specifies a space separated list of old-cell new-design pairs.

---

### DESCRIPTION

Use this guide mode command to create unique instances for design objects.

---

### EXAMPLES

```
fm_shell (guide)> guide_uniquify -design shift4 \  
                  { { shift2_i_1 shift2_0 } { shift2_i_2 shift2_1 } }  
1
```

---

## SEE ALSO

[guide\(2\)](#)

---

## guide\_ununiquify

Folds ununiquified instances back to their original designs.

---

### SYNTAX

```
guide_ununiquify  
-design designName  
[ ununiquifyBlock ]
```

#### Data Types

```
designName string  
ununiquifyBlock string
```

---

### ENABLED SHELL MODES

Guide

---

### ARGUMENTS

**-design *designName***

Specifies the name of the design containing the objects being folded.

***ununiquifyBlock***

Specifies a space separated list of old-cell new-design pairs.

---

### DESCRIPTION

Use this guide mode command to fold ununiquified instances back to their original designs.

---

### EXAMPLES

```
fm_shell (guide)> guide_ununiquify \  
-design top \  
{ { U2 mid } \  
{ U1 mid } \  
{ U2/U3 bot } \  
{ U1/U3 bot } }
```

1

---

## SEE ALSO

[guide\(2\)](#)

---

## help

Returns information about Formality shell commands.

---

## SYNTAX

**help**  
[ *-verbose* ]  
[ *-groups* ]  
[ *pattern* ]

### Data Types

*pattern* string

---

## ARGUMENTS

### **-verbose**

Displays all the **help** command options and detailed messages.

### **-groups**

Displays command groups only.

### ***pattern***

Specifies a Formality shell *command*.

---

## DESCRIPTION

Use this command to see the help information for a Formality shell command.

This command does not return syntax information about `fm_shell` commands. To display syntax information about a command, use:

*command* -help

To display information about a particular command, specify the name of the *command* as the argument. When you don't specify a command name, Formality displays an alphabetical list of all available Formality shell commands.

---

## EXAMPLES

This example displays the help information for the **read\_db** command:

```
fm_shell> help read_db
read_db -- Read one or more db files
```

This example displays syntax and help information for the **read\_db** command:



```
fm_shell> read_db -help
Usage: read_db  # Read one or more db files
[-container container_name]  (Read into named container)
[-libname libname]  (Library or design library name)
file_names          (List of files to read)
```

---

## SEE ALSO

man(2)

---

## help\_attributes

Display help for attributes and object types.

---

### SYNTAX

```
string help_attributes [-verbose]
      [class_name]
      [attr_pattern]
```

#### Data Types

```
string class_name
string attr_pattern
```

---

### ARGUMENTS

#### -verbose

Display attribute properties.

#### class\_name

Object class to retrieve help for. Valid classes are *lib*, *lib\_cell*, *lib\_pin*, *design*, *port*, *cell*, *pin*, and *net*.

#### attr\_pattern

Show attributes matching pattern.

---

### DESCRIPTION

The **help\_attributes** command is used to get quick help for the set of available attributes. When this command is run with no arguments a brief informational message is printed followed by the available object classes.

---

### EXAMPLES

The following example lists net attributes ending with "name".

```
prompt> help_attributes net *name
Available net attributes:
container_name    # string
full_name         # string
library_name      # string
name              # string
parent_name       # string
path_name         # string
```

---

## SEE ALSO

`get_attribute(2)`  
`list_attributes(2)`

---

## history

Displays or modifies the commands recorded in the history list.

---

### SYNTAX

#### **history**

**[-h]**

**[-r]**

**[args]**

#### **Data Types**

*args* string

---

### ARGUMENTS

#### **-h**

Displays the history list without the leading numbers. Use this switch to create scripts from the existing history. You can then source the script by using the **source** command. You can use this switch only with a single numeric argument. Note that this switch is not a standard extension to Tcl.

#### **-r**

Reverses the order of the output. The most recent entries are displayed first rather than the oldest entries first. You can use this switch only with a single numeric argument. Note that this switch is not a standard extension to Tcl.

#### **args**

Specifies additional arguments to the **history** command.

---

### DESCRIPTION

Use this command to perform several operations related to the recently executed commands that are recorded in the history list.

Each of the recorded commands is referred to as an *event*. The most commonly used forms of the command are illustrated in the following section. You can combine each with either the **-h** or **-r** switches, but not both. When you don't use any argument, the **history** command returns a formatted string, intended for you to read, giving the event number and contents for each of the events in the history list.

If a single, integer argument count is specified, only the most recent count events are returned. Note that this option is not a standard extension to Tcl.

By default, 20 events are retained in the history list. You can change the length of the history list by using the following command:

```
fm_shell> history keep integer
```

Tcl supports several additional forms of the **history** command. See the History Revision section.

## EXAMPLES

The following examples illustrate the basic use of the **history** command.

To limit the number of events by using a single numeric argument:

```
fm_shell> history 3
7 set base_name "my_file"
8 set fname [format "%s.db" $base_name]
9 history 3
```

To view the history list in reverse order:

```
fm_shell> history -r 3
9 history -r 3
8 set fname [format "%s.db" $base_name]
7 set base_name "my_file"
```

To remove the leading numbers from each line in the history:

```
fm_shell> history -h 3
set base_name "my_file"
set fname [format "%s.db" $base_name]
history -h 3
```

### Advanced Tcl History

The **history** command has many advanced features. The recently executed commands are recorded in a history list. Each of these recorded commands are referred to as an event. You can specify an event by using any of the following forms:

- A number: A positive integer refers to the event associated with the number. All events are numbered starting at 1. A negative integer selects an event relative to the current event. For example, specifying *-1* refers to the previous event and *-2* to the one before that.
- A string: Selects the most recent event that matches the string. An event matches the string either if the string is the same as the first characters of the event or if the string matches the event in the sense of the **string match** command.

The **history** command can take any of the following forms:

- **history**  
Same as "**history** info", described later in this man page.
- **history** add <command> [exec]  
Adds the "command" argument to the **history** list as a new event. If you specify (or abbreviate) **exec**, the command also executes and its result is returned. If you do not specify **exec**, the command returns an empty string.
- **history** change <newValue> [event]  
Replaces the value recorded for an event with the *newValue*. The *event* argument specifies the event to replace and defaults to the current event (not event -1). This intention of the command is for your use with commands that implement new forms of history substitution to replace the current event (which invokes the substitution) with the command created through substitution. The return value is an empty string.
- **history** event <event>  
Returns the value of the event specified by using the *event* argument. The default value of the *event* argument is -1. This command revises the history. See the Advanced Tcl History section for details.
- **history** info [count]  
Returns a formatted string (intended for you to read) giving the event number and contents for each of the events in the history list except the current event. If you specify *count*, only the most recent *count* number of events are returned.
- **history** keep <count>  
You can use this command to change the size of the history list to a number of events specified by using the *count* argument. By default, 20 events are retained in the history list. This command returns an empty string.
- **history** nextid  
Returns the number of the next event to record in the **history** list. Use this for things like printing the event number in

command-line prompts.

- **history** redo [*event*]  
Re-executes the command indicated by the *event* argument and returns its result. By default the *event* argument is set to -1. This command results in history revision. See History Revision for details.
- **history** substitute <old> <new> <event>  
Retrieves the command specified by using the *event* argument. By default the *event* argument is set to -1 and replaces any occurrences of "old" or "new" in the command. Only simple character equality is supported, wild cards are not supported. This use also executes the resulting command, and returns the result. This command results in **history** revision. See History Revision for details.
- **history** words <selector> <event>  
Retrieves history from the command specified by the *event* argument and the words specified by using the *selector* argument. This command returns the words in a string separated by spaces. The *selector* argument has three forms. If it is a single number, it selects the word given by that number (0 for the command name, 1 for its first argument, and so on). If it consists of two numbers separated by a dash, it selects all the arguments between the two specified numbers. Otherwise the *selector* is treated as a pattern; all words matching that pattern (in the sense of "string match") are returned. In the numeric forms you can use \$ to select the last word of a command.

For example, suppose the most recent command in the **history** list is

```
format {%s is %d years old} Alice [expr $ageInMonths/12]
```

The following are some **history** commands and the results they would produce.

```
history words $      [expr $ageInMonths/12]
history words 1-2    {%s is %d years old} Alice
history words *a*o*  {%s is %d years old} [expr $ageInMonths/12]
```

History words results in **history** revision.

- **History Revision:**  
The **history** options "event", "redo", "substitute, and "words" result in **history** revision". When you invoke one of these options, the current event is modified to eliminate the **history** command and replaced with the result of the **history** command. For example, suppose that the most recent command in the **history** list is:

```
set a [expr $b+2]
```

and that the next command invoked is one from the left side of the following table. The command actually recorded in the **history** event is the corresponding one on the right side of the table.

```
history redo      set a [expr $b+2]
history s a b     set b [expr $b+2]
set c [history w 2] set c [expr $b+2]
```

History revision is needed because event specifiers like -1 are only valid at a particular time; after more events are added to the **history** list, a different event specifier is needed.

History revision occurs even when you invoke **history** indirectly from the current event (such as, you type a command that invokes a Tcl procedure that invokes history): the top-level command whose execution eventually results in a **history** command is replaced.

To invoke commands like "**history** words" without **history** revision, you can use '**history** event' to save the current **history** event then use "**history** change" to restore it later.

---

## SEE ALSO

---

## index\_collection

Given a collection and an index into it, if the index is in range, create a new collection containing only the single object at the index in the base collection. The base collection remains unchanged.

---

### SYNTAX

```
collection index_collection
  collection1
  index
```

#### Data Types

<i>collection1</i>	collection
<i>index</i>	int

---

### ARGUMENTS

#### *collection1*

Specifies the collection to be searched.

#### *index*

Specifies the index into the collection. Allowed values are integers from 0 to **sizeof\_collection** - 1.

---

### DESCRIPTION

You can use the **index\_collection** command to extract a single object from a collection. The result is a new collection containing only that object. The index operation is done in constant time - it is independent of the number of elements in the collection, or the specific index.

The range of indices is from 0 to one less than the size of the collection. If the specified index is outside that range, an error message is generated.

Commands that create a collection of objects do not impose a specific order on the collection, but they do generate the objects in the same, predictable order each time. Applications that support the sorting of collections allow you to impose a specific order on a collection.

You can use the empty string for the *collection1* argument. However, by definition, any index into the empty collection is invalid. Therefore, using the **index\_collection** command with the empty collection always generates the empty collection as a result and generates an error message.

Note that not all collections can be indexed.

---

### EXAMPLES

The following example uses the **index\_collection** command to extract the first object of a collection.

```
prompt> set c1 [get_cells {u1 u2}]  
{r:/WORK/top/u1 r:/WORK/top/u2}  
prompt> query_objects [index_collection $c1 0]  
{r:/WORK/top/u1}
```

---

## SEE ALSO

collections(2)  
query\_objects(2)  
sizeof\_collection(2)



---

## insert\_inversion

Creates an inversion at the specified net, pin, or port.

---

### SYNTAX

status **insert\_inversion**  
[-type *ID\_type*]  
*objectID*

#### Data Types

*ID\_type* string  
*objectID* string

---

### ENABLED SHELL MODES

Setup

---

### ARGUMENTS

#### -type *ID\_type*

Specifies the object type. Use this option if the name of the specified design object is associated with more than one object type in the same design. Specify one of the following object types:

- *pin*
- *port*
- *net*

#### *objectID*

Specifies the design object where you want to insert inversion. You can specify a primary port, pin, or net unless they are bidirectional. If the name you specify resolves to multiple objects with identical names, and if you do not specify the **-type** option, the command searches for the specified object in the following order: pin, port, and net.

---

## DESCRIPTION

This command inserts inversion at the specific object. You must specify the object as a folded design path. Inversion can be inserted on ports, pins, and nets. Inversion cannot be inserted on bidirectional ports or pins. If there is a bidirectional pin connected to a specified net, the command reports an error and exits. Note that if a specified net has multiple fanout, they are all inverted. Specify a primary port or pin if you do not want to invert all the fanouts or fanins of a net.

The **insert\_inversion** command is available from the GUI in the "Setup" menu of the logic cone schematics. You must select a net, pin, or port before clicking "Insert inversion" on the "Setup menu". Note that you can select the diamond shaped hierarchy separator to make a pin selection for the **insert\_inversion** command. The GUI queues the command, because the **insert\_inversion** command must be executed in the setup mode.

NOTE that the **insert\_inversion** command is made on the actual design, so the inversion is inserted in all instantiations of the design. A warning message is reported if the inversion is inserted in more places than the selected net, pin, or port. No warning will be given from the command line. The GUI default for net selection crosses the hierarchy separators making it possible to select multiple nets segments. This can be turned off by editing the GUI preferences, and setting "Skip Hierarchical Crossings" to "false". If multiple net segments are selected across the hierarchy, then the driving net is chosen by the GUI for the **insert\_inversion** command.

Use the **report\_inversion** command to view a list of inversion objects.

---

## EXAMPLES

The following example shows how to insert inversion on a primary output port out1.

```
fm_shell (setup)> insert_inversion i:/WORK/top/out1 -type port
Inversion created at 'i:/WORK/top/out1_FM_INV'
1
```

The following example inserts inversion on an input pin i1.

```
fm_shell (setup)> insert_inversion i:/WORK/top/bot1/i1 -type pin
Inversion created at 'i:/WORK/top/i1_FM_INV'
1
```

The following example inserts inversion on a net in2.

```
fm_shell (setup)> insert_inversion i:/WORK/top/in2 -type net
Inversion created at 'i:/WORK/top/in2_FM_INV'
1
```

---

## SEE ALSO

remove\_inversion(2)  
report\_inversion(2)

---

## invert\_pin

Inverts one or more pins on a primitive cell.

---

### SYNTAX

```
status invert_pin  
  pin_list
```

#### Data Types

*pin\_list* list

---

### RETURN VALUE

The **invert\_pin** command returns a status of 1 if it succeed and 0 if it failed.

---

### ARGUMENTS

*pin\_list*

Inverts the specified pins. You can specify either object IDs or instance-based paths.

Inversion of a pin is visible to all instances of that pin. To affect a specific instance-based path, uniquify that instance of the design before you run this command.

---

### DESCRIPTION

This command inverts the specified pins on primitive cells. Only pins on non-SEQ primitive cells are inverted.

Outside of Setup mode, this command only works on edit designs created using the **edit\_design** command.

This command is specific to Formality. It is not supported by other Synopsys tools. Formality will warn about this the first time the command is used.

---

### EXAMPLES

The following example shows how to create a new AND cell in design r:/WORK/mid and inverts the output pin effectively making it a

NAND gate.

```
fm_shell (setup)> current_design r:/WORK/mid  
fm_shell (setup)> create_primitive my_gate AND  
fm_shell (setup)> invert_pin my_gate/OUT
```

This example shows how to create a new XOR cell in design i:/WORK/top/m1/b1 and inverts the output pin effectively making it a XNOR gate. If the instance-based path i:/WORK/top/m1/b1 is not unique, all instances are affected.

```
fm_shell (setup)> current_instance r:/WORK/top/m1/b1  
fm_shell (setup)> create_primitive my_xnor XOR  
fm_shell (setup)> invert_pin my_xnor/OUT
```

---

## SEE ALSO

```
create_primitive(2)  
current_design(2)  
current_instance(2)  
edit_design(2)
```

---

## is\_false

Tests the value of a specified variable, and returns 1 if the value is 0 or the case-insensitive string **false**; returns 0 if the value is 1 or the case-insensitive string **true**.

---

### SYNTAX

```
status is_false  
value
```

#### Data Types

value    string

---

### ARGUMENTS

*value*

Specifies the name of the variable whose value is to be tested.

---

### DESCRIPTION

This command tests the value of a specified variable, and returns 1 if the value is either 0 or the case-insensitive string **false**. The command returns 0 if the value is either 1 or the case-insensitive string **true**. Any value other than 1, 0, **true**, or **false** generates a Tcl error message.

The **is\_false** command is used in writing scripts that test Boolean variables that can be set to 1, 0, or the case-insensitive strings **true** or **false**. When such variables are set to **true** or **false**, they cannot be tested in the negative in an **if** statement by simple variable substitution, because they do not constitute a true or false condition. The following example is not legal Tcl:

```
set x FALSE  
if { !$x } {  
    set y TRUE  
}
```

This results in a Tcl error message, indicating that you cannot use a non-numeric string as the operand of "!". So, although you can test the positive condition, **is\_false** allows you to test both conditions safely.

---

### EXAMPLES

The following example shows the use of the **is\_false** command:

```
prompt> set x TRUE  
TRUE  
  
prompt> if { ![is_false $x] } {  
?     set y TRUE  
?     }
```

TRUE

prompt>

---

## SEE ALSO

[expr\(2\)](#)

[if\(2\)](#)

[is\\_true\(2\)](#)

---

## is\_true

Tests the value of a specified variable, and returns 1 if the value is 1 or the case-insensitive string **true**; returns 0 if the value is 0 or the case-insensitive string **false**.

---

### SYNTAX

```
status is_true  
  value
```

#### Data Types

*value*    string

---

### ARGUMENTS

*value*

Specifies the name of the variable whose value is to be tested.

---

### DESCRIPTION

This command tests the value of a specified variable, and returns 1 if the value is either 1 or the case-insensitive string **true**. The command returns 0 if the value is either 0 or the case-insensitive string **false**. Any value other than 1, 0, **true**, or **false** generates a Tcl error message.

The **is\_true** command is used in writing scripts that test Boolean variables that can be set to 1, 0, or the case-insensitive strings **true** or **false**. When such variables are set to **true** or **false**, they cannot be tested in the negative in an **if** statement by simple variable substitution, because they do not constitute a true or false condition. The following example is not legal Tcl:

```
set x TRUE  
if { !$x } {  
  set y FALSE  
}
```

This results in a Tcl error message, indicating that you cannot use a non-numeric string as the operand of "!". So, although you can test the positive condition, **is\_true** allows you to test both conditions safely.

---

### EXAMPLES

The following example shows the use of the **is\_true** command:

```
prompt> set x FALSE  
FALSE  
  
prompt> if { ![is_true $x] } {  
?   set y FALSE  
?   }
```

FALSE

prompt>

---

## SEE ALSO

expr(2)  
if(2)  
is\_false(2)



---

## library\_verification

Starts the library verification mode.

---

### SYNTAX

**library\_verification**  
[ *mode* ]

#### Data Types

*mode* string

---

### ARGUMENTS

#### *mode*

Specifies the library verification mode. Specify one of the following values for the *mode* argument:

- VERILOG\_VERILOG - verifies two versions of a Verilog simulation library
- VERILOG\_DB - verifies a Verilog simulation library against a library in .db file format
- VERILOG\_PWRDB - verifies Verilog cells in the reference library against the power version of the cells in the implementation library that is the in .db file format
- DB\_DB - verifies two versions of a .db file format library
- DB\_VERILOG - verifies a .db format library against a Verilog simulation library
- PWRDB\_VERILOG - verifies the power version of cells in the reference library in .db file format against the Verilog cells in the implementation library
- NONE - exits the library verification mode

---

### DESCRIPTION

This command starts the library verification mode to read and verify library cells.

To restart the fm\_shell design environment, use the *NONE* mode. When the *NONE* mode is specified, the tool removes all containers containing the library cells and exits the library verification mode.

The following commands are available in the library verification mode:

- **read\_verilog** - reads Verilog library cells
- **read\_sverilog** - reads SystemVerilog library cells
- **read\_db** - reads the .db file format libraries
- **report\_cell\_list** - reports cells

- **select\_cell\_list** - selects cells
- **verify** - verifies all library cells
- **report\_status** - reports the status of verification
- **debug\_library\_cell** - debugs failing cell in library verification mode
- **write\_library\_debug\_scripts** - debugs failing cells in the formal verification mode

For more information on these commands, see the man pages of each command.

---

## EXAMPLES

---

## SEE ALSO

debug\_library\_cell(2)  
read\_db(2)  
read\_verilog(2)  
read\_sverilog(2)  
report\_status(2)  
select\_cell\_list(2)  
verify(2)  
write\_library\_debug\_scripts(2)

---

## license\_users

Lists the current users of the Synopsys licensed features.

---

### SYNTAX

status **license\_users**  
[*feature\_list*]

#### Data Types

*feature\_list* list

---

### ARGUMENTS

#### *feature\_list*

Lists the licensed features for which to obtain the information. The *feature\_list* argument might consist of a single value or a space-delimited list of values enclosed within braces ({}).

See the Synopsys Installation Guide: UNIX-Based Platforms for a list of features supported by the current release, or determine from your key file all of the features licensed at your site.

---

### RETURN VALUE

The **license\_users** command returns a status of 1 if it was successful and 0 if it failed.

---

### DESCRIPTION

This command displays information about all of the licenses, related users, and host names currently in use. If a feature list is specified, only information about those features is displayed.

The **license\_users** command is valid only when Network Licensing is enabled.

---

### EXAMPLES

In the following example, all users of Synopsys features are displayed:

```
fm_shell (setup)> license_users  
carlson@node1      Formality
```

frodo@node3

Design-Compiler, DC-Expert

---

## SEE ALSO

check\_license(2)  
list\_licenses(2)  
get\_license(2)  
remove\_license(2)

---

## list\_attributes

Lists currently defined attributes.

---

### SYNTAX

```
string list_attributes  
  [-application]  
  [-class class_name]  
  [-nosplit]
```

#### Data Types

<i>class_name</i>	string
-------------------	--------

---

### ARGUMENTS

#### -application

Lists application attributes as well as user-defined attributes (see DESCRIPTION).

#### -class *class\_name*

Limit the listing to attributes of a single class. Valid classes are *lib*, *lib\_cell*, *lib\_pin*, *design*, *port*, *cell*, *pin*, and *net*.

#### -nosplit

Prevents line-splitting and facilitates writing software to extract information from the report output. Most of the design information is listed in fixed-width columns. If the information in a given field exceeds the column width, the next field begins on a new line, starting in the correct column.

---

### DESCRIPTION

The **list\_attributes** command displays an alphabetically sorted list of currently defined attributes. There are two categories of attributes: application-defined and user-defined. Formality only has application-defined attributes; user-defined attributes are not supported. By default, the **list\_attributes** command lists user-defined attributes. This is useful for other tools, but for Formality the **-application** option must be used to obtain any useful output.

Using the **-application** option adds all application attributes to the listing. Note that there are many application attributes. It is often useful to limit the listing to a specific object class using the *class\_name* option.

---

### EXAMPLES

The following example lists all net attributes.

```
prompt> list_attributes -application -class net
```

\*\*\*\*\*  
Report : List of Attribute Definitions  
Version: ...  
Date : ...  
\*\*\*\*\*

Properties:  
A - Application-defined  
S - Settable  
B - Subscripted

Attribute Name	Object	Type	Properties	Constraints
-----				
container_name	net	string	A	
full_name	net	string	A	
library_name	net	string	A	
name	net	string	A	
object_class	net	string	A	
parent_name	net	string	A	
path_name	net	string	A	
type	net	string	A	

---

SEE ALSO

get\_attribute(2)  
help\_attributes(2)

---

## list\_key\_bindings

Lists the key bindings in the current editing mode

---

### SYNTAX

**list\_key\_bindings**  
[ -nosplit ]

---

### ARGUMENTS

**-nosplit**

Displays column text without splitting them.

---

### DESCRIPTION

The **list\_key\_bindings** command displays the current key bindings in the current edit mode. To change the edit mode, use the **sh\_line\_editing\_mode** variable in either the .synopsys\_fm.setup file or in the fm\_shell.

The text CTRL+K is read as `Control+K` and describes the character produced when the K key is pressed while the Control key is pressed.

The text META+K is read as `Meta+K` and describes the character produced when the k key is pressed while the Meta key is pressed. The Meta key is labeled ALT on many keyboards. On keyboards with two keys labeled ALT (usually to either side of the space bar), the ALT on the left side is generally set as the Meta key. The ALT key on the right might also be configured to work as a Meta key or configured as some other modifier, such as a Compose key for typing accented characters.

If you do not have a Meta or ALT key, or another key working as a Meta key, the identical keystroke can be generated by typing ESC first, and then typing k. Either process is known as metafying the k key.

Alternative key bindings work only in the VI alternate (command) mode.

---

### SEE ALSO

sh\_enable\_line\_editing(3)  
sh\_line\_editing\_mode(3)

---

## list\_libraries

Lists technology libraries that are currently loaded.

---

### SYNTAX

**list\_libraries**

---

### DESCRIPTION

Use this command to list the technology libraries that are currently loaded. Shared libraries are listed first.

The **list\_libraries** command returns one of the following:

- 0 to indicate failure
- List of library names

For more information about libraries and shared libraries, see the *Formality User Guide*.

---

### EXAMPLES

This example assumes an environment that contains two containers, reference and implementation, and three libraries - *gtech*, *lca10k*, and *attlib*. In the example, *gtech* is a shared library because it is loaded into both reference and implementation containers. The other libraries, *lca10k* and *attlib*, are not shared libraries because they are loaded into individual containers.

```
fm_shell> list_libraries
gtech implementation:/lca500k ref:/lca500k
fm_shell>
```

---

### SEE ALSO

remove\_library(2)  
report\_containers(2)  
report\_libraries(2)



---

## list\_licenses

Displays a list of licenses currently checked out by the user.

---

### SYNTAX

status **list\_licenses**  
*feature\_list*

#### Data Types

*feature\_list* list

---

### ARGUMENTS

The **list\_licenses** command has no arguments.

---

### RETURN VALUE

The **list\_licenses** command returns a status of 1 if it was successful and 0 if it failed.

---

### DESCRIPTION

This command lists the licenses you currently have checked out. If more than one copy of a license key is checked out, the number of keys checked out is shown in parentheses following the license name.

---

### EXAMPLES

The following example illustrates the use of **list\_licenses**:

```
fm_shell (setup)> list_licenses
Licenses in use:
  Design-Compiler
  Formality
```

---

### SEE ALSO

check\_license(2)  
license\_users(2)  
remove\_license(2)  
get\_license(2)

---

## Iminus

Removes one or more named elements from a list and returns a new list.

---

### SYNTAX

```
list Iminus
[-exact]
original_list
elements
```

#### Data Types

<i>original_list</i>	list
<i>elements</i>	list

---

### ARGUMENTS

#### **-exact**

Specifies that the exact pattern is to be matched. By default, **Iminus** uses the default match mode of **Isearch**, the **-glob** mode.

#### *original\_list*

Specifies the list to copy and modify.

#### *elements*

Specifies a list of elements to remove from *original\_list*.

---

### DESCRIPTION

The **Iminus** command removes elements from a list by using the element itself, rather than the index of the element in the list (as in **Ireplace**). The **Iminus** command uses the **Isearch** and **Ireplace** commands to find the elements and replace them with nothing.

If none of the elements are found, a copy of *original\_list* is returned.

The **Iminus** command is often used in the translation of Design Compiler scripts that use the subtraction operator (-) to remove elements from a list.

---

### EXAMPLES

The following example shows the use of the **Iminus** command. Notice that no error message is issued if a specified element is not in the list.

```
prompt> set l1 {a b c}
```

```
a b c
```

```
prompt> set I2 [lminus $I1 {a b d}]  
c
```

```
prompt> set I3 [lminus $I1 d]  
a b c
```

The following example illustrates the use of **lminus** with the **-exact** option:

```
prompt> set I1 {a a[1] a* b[1] b c}  
a a[1] a* b[1] b c
```

```
prompt> set I2 [lminus $I1 a*]  
{b[1]} b c
```

```
prompt> set I3 [lminus -exact $I1 a*]  
a {a[1]} {b[1]} b c
```

```
prompt> set I4 [lminus -exact $I1 {a[1] b[1]} ]  
a a* b c
```

---

## SEE ALSO

[lreplace\(2\)](#)  
[lsearch\(2\)](#)

---

## load\_breakpoint\_data

Loads the specified breakpoint data file.

---

### SYNTAX

**load\_breakpoint\_data**  
*file\_name*

#### Data Types

*file\_name* string

---

### ENABLED SHELL MODES

Setup

---

### ARGUMENTS

*file\_name*

Specifies the name of the breakpoint data file to load.

---

### DESCRIPTION

Use this command to load the breakpoint data file when performing a verification with a breakpoint design as the reference. It provides the necessary data required to successfully process SVF which occurs after the breakpoint is generated. This command must be used before the set\_svf command.

---

### EXAMPLES

```
fm_shell (setup)> load_breakpoint_data formality_bkpt_RTLToinitial_map.bdf
1
fm_shell (setup)>
```

---

### SEE ALSO

*"guide\_breakpoint"*

---

## load\_ssf

Loads the specified SSF (Safety Specification Format) file.

---

### SYNTAX

```
load_ssf  
[ -container container_name | -r ]  
[ -version version_string ]  
file_name
```

#### Data Types

```
container_name string  
version_string string  
file_name string
```

---

### ENABLED SHELL MODES

Setup

---

### ARGUMENTS

#### -container *container\_name*

Load the SSF file to the specified container.

#### -r

Load the SSF file to the reference container.

#### -version *version\_string*

Specifies the version of the SSF file that is being loaded. The version can also be specified in the SSF file using the **ssf\_version** command.

#### *file\_name*

Specifies the name of the SSF file to load.

---

### DESCRIPTION

Use this command to load a file containing SSF commands and apply them to the specified container. If a container is not specified, the command applies the SSF commands to the default container. The command reports an error if a container is not specified and there is no default container. To run this command, ensure that the tool is in the setup mode, and the top design in the container is set. **load\_ssf** must be issued before **load\_upf** to allow proper low power constraints to be added to any design elements implemented by the ssf.

If an SSF command reports an error, the tool stops processing the rest of the SSF file, unless the **sh\_continue\_on\_error** variable is set to *true*.

Formality receives safety guidance from the implementation tool in the SVF file. During **preverify** the tool implements safety logic for equivalence checking based on that guidance in the svf file. The tool uses the SSF commands from **load\_ssf** to do consistency checks between the ssf and the svf guidance. Implementation tools can meet user specified safety targets by implementing more or less logic than is specified in the SSF file. The tool supports the SSF commands necessary to perform consistency checks between the SSF and the SVF using the Synopsys Safety Specification design flow and will give a summary of any issues at the end of the **preverify** command. In addition to the consistency checks, during verification the tool will report failing compare points if safety logic was implemented incorrectly in the implementation design.

Formality supports **load\_ssf** on the reference design to perform the consistency checks with safety guidance in the SVF.

The **load\_ssf** command returns one of the following:

- 0 to indicate failure
- 1 to indicate success

---

## EXAMPLES

```
fm_shell (setup)> load_ssf -r adder.ssf
Loading ssf file '/disk/projects/SSF/adder/adder.ssf'
1
fm_shell (setup)>
```

---

## SEE ALSO

*report\_safety\_status*

---

## load\_upf

Loads the specified UPF (Unified Power Format) file.

---

### SYNTAX

```
load_upf
[ -container container_name | -r | -i ]
[ -scope instance_path ]
[ -version version_string ]
[ -force ]
[ -strict_check true|false ]
[ -supplemental supplemental_upf_file_name ]
[ -target target_type ]
file_name
```

#### Data Types

```
container_name string
instance_path string
version_string string
strict_check Boolean
supplemental_upf_file_name string
target_type string
file_name string
```

---

### ENABLED SHELL MODES

Setup

---

### ARGUMENTS

#### **-container** *container\_name*

Loads the UPF file to the specified container.

#### **-r**

Loads the UPF file to the reference container.

#### **-i**

Loads the UPF file to the implementation container.

#### **-scope** *instance\_path*

Sets the initial scope for the UPF to the named instance.

#### **-version** *version\_string*

Specifies the version of the UPF file that is being loaded. If the version specified by using the **upf\_version** command in the UPF file does not match the version specified by using the *version\_string* argument, the command issues a warning.



**-force**

Loads the UPF file into a container that was previously modified by UPF or the automated setup file for verification (SVF). Using this option is neither safe nor recommended, and is normally not allowed, because previous UPF or automated setup modifications might have invalidated design object name references in the UPF.

**-strict\_check true|false**

Default is **true**. When **false** (as for "Golden UPF" application to a netlist):

- The **upf\_name\_map\_file** variable or **upf\_name\_map** pragmas in the target design (if any) are used to source map files.
- Missing object errors are suppressed. (If **golden\_upf\_report\_missing\_objects** is true, informational messages are reported.)
- **\*\_logic\_\*** commands are ignored.

**-supplemental supplemental\_upf\_file\_name**

Specifies a supplemental UPF file to be loaded after the primary one. During the supplemental UPF load (after the primary UPF load), **strict\_check false** is ignored, and any name maps or rules used in the primary UPF load are discarded.

**-target target\_type**

Specifies the origin of the target design:

- **automatic**: default interpretation, based on **upf\_implementation\_based\_on\_file\_headers** and/or **upf\_implemented\_constructs**.
- **rtl**: standard interpretation: no part of the UPF is assumed to be already implemented in the incoming target design. Formality must implement all UPF constructs. **upf\_implementation\_based\_on\_file\_headers** and **upf\_implemented\_constructs** are ignored.
- **dc\_netlist**: specifies that repeater, isolation, and retention strategies are already implemented in the incoming target netlist, but resulting cells are not connected to their supplies. **upf\_implementation\_based\_on\_file\_headers** and **upf\_implemented\_constructs** are ignored.
- **icc\_netlist**: specifies that repeater, isolation, and retention strategies and power switches are already implemented in the incoming target netlist, and resulting cells are explicitly connected to their supplies via **connect\_supply\_net** commands in the incoming UPF. **upf\_implementation\_based\_on\_file\_headers** and **upf\_implemented\_constructs** are ignored.
- **dc\_pg\_netlist**: as for **dc\_netlist**, but also specifies that supplies are already implemented and explicitly connected in the incoming target netlist:

1. an automatic **-reuse** is applied to **create\_supply\_\*** commands;
2. **connect\_supply\_net** commands are ignored;
3. no automatic supply net connection occurs.
4. **upf\_implementation\_based\_on\_file\_headers** and **upf\_implemented\_constructs** are ignored.

- **pg\_netlist**: as for **dc\_pg\_netlist**, but also specifies that power switches may have a partial implementation and supplies may have Verilog **supply1/supply0** constants in the incoming target netlist:

1. an automatic **-reuse** is applied to **create\_supply\_\*** commands.
2. **connect\_supply\_net** commands will either connect or reconnect supplies.
3. no automatic supply net connection occurs.
4. as with **strict\_check** set to false, missings elements in lists will be allowed.
5. partial or full implementation of power switches will be handled.
6. Verilog **supply1/supply0** constants will be removed from any supply where a **create\_supply\_net** command is encountered in the UPF. Note: **hdl\_error\_on\_supply\_type\_port** must be set to false for the netlist or Verilog reader when **supply1/supply0** wire types are present in the netlist.
7. **upf\_implementation\_based\_on\_file\_headers** and **upf\_implemented\_constructs** are ignored.

- **final\_pg\_netlist**: associates the UPF file with the netlist to enable static checks. **No modifications are made to the netlist.**

**file\_name**

Specifies the name of the UPF file to load.

---

## DESCRIPTION

Use this command to load and execute the UPF commands in the specified UPF file, and apply them to the specified container. If a container is not specified, the command applies the UPF commands to the default container. The command reports an error if a container is not specified and there is no default container. To run this command, ensure that the tool is in the setup mode, and the top design in the container is set.

If a UPF command reports an error, the tool stops processing the rest of the UPF file, unless the **sh\_continue\_on\_error** variable is set to **true**.

The tool supports the UPF commands necessary to complete low power design by using the Synopsys low power design flow.

See the Synopsys low power flow documentation and Synopsys SolvNet for more details on the IEEE 1801, also known as Unified Power Format (UPF), commands supported in the Synopsys flow.

The **load\_upf** command returns one of the following:

- 0 to indicate failure
- 1 to indicate success

---

## EXAMPLES

```
fm_shell (setup)> load_upf myfile.upf
1
fm_shell (setup)>
```

---

## SEE ALSO

*"IEEE Std 1801"*

---

## log\_trace

Control creation of a replay log of traced commands.

---

### SYNTAX

string **log\_trace** [-start file\_name]-stop|-pause|-resume] [-log log\_string] [-quiet]

string *file\_name*

string *log\_string*

---

### ARGUMENTS

#### **-start file-Name**

This option is mutually exclusive with -stop, -pause, and -resume. The argument is the pathname of the file to which the replay trace log is output. The option opens a file for output and begins logging command execution strings and application variable changes. Note that if the file already exists, the command overwrites the existing file. There can only be a single replay trace log output at any time.

#### **-stop**

This option is mutually exclusive with -start, -pause, and -resume. This option stops replay trace log output and closes the log file. Once stopped, the replay log cannot be reopened for appending.

#### **-pause**

This option is mutually exclusive with -start, -stop, and -resume. This option pauses replay trace log output. Execution of all commands and application variable settings are ignored and omitted from the log until output is resumed with -resume.

Note that pausing replay log output may render the resulting log unable to replay or incapable of replicating tool results.

#### **-resume**

This option is mutually exclusive with -start, -stop, and -pause. This option resumes replay trace log output.

#### **-log log\_string**

This option outputs the given log\_string, verbatim, to the replay trace log. The option may be used to explicitly log a command invocation or a comment. If the string is a comment, it must start with the Tcl comment character '#'.

#### **-quiet**

If given, this option causes the command to ignore error conditions such as an attempt to pause the trace log output before it is started. The command will exit quietly when it encounters an error condition.

---

### DESCRIPTION

The **log\_trace** command performs operations related to creating a flat replay log of traced command execution and application variable changes. All options are optional. Upon successful completion, the command returns the pathname of the trace log file, if any,

or an error message if the command fails.

Trace log output contains a comment header with the tool name and version, and the date and time when trace log output was started.

The resulting replay log is not 100% guaranteed to be able to replay or to reproduce tool results. One reason is that the tool execution environment may be different. If any operations are performed during log creation that would further compromise the ability to replay the resulting log or to replicate tool results, a warning message is appended to the log. Such operations including pausing log output.

Invoking the **log\_trace** with no options will report the current status of logging: on, paused, or off, followed by the currently open log file name, if any.

---

## EXAMPLES

The following example shows reporting of the log status before starting trace logging.

```
prompt> log_trace
off
```

The following example starts trace log creation.

```
prompt> log_trace -start ./tracelog.tcl
/an/absolute/path/.tracelog.tcl
prompt> log_trace
on: /an/absolute/path/.tracelog.tcl
```

The following example pauses, then resumes log creation.

```
prompt> log_trace -pause
/an/absolute/path/.tracelog.tcl
prompt> log_trace
paused: /an/absolute/path/.tracelog.tcl
prompt> log_trace -resume
/an/absolute/path/.tracelog.tcl
prompt> log_trace
on: /an/absolute/path/.tracelog.tcl
```

---

## SEE ALSO

set\_trace\_option(2)  
get\_trace\_option(2)  
annotate\_trace(2)

---

# ls

Lists the contents of a directory.

---

## SYNTAX

string **ls** [*filename* ...]

string *filename*

---

## ARGUMENTS

*filename*

Provides the name of a directory or filename, or a pattern which matches files or directories.

---

## DESCRIPTION

If no argument is specified, the contents of the current directory are listed. For each *filename* matching a directory, **ls** lists the contents of that directory. If *filename* matches a file name, the file name is listed.

---

## EXAMPLES

```
shell> ls *.db *.pt
```

```
test1.pt    c1.db      c3.db      c5.db
```

```
test2.pt    c2.db      c4.db      c6.db
```

---

## SEE ALSO

cd(2)  
pwd(2)

---

## man

Displays the manual pages for Formality shell commands.

---

### SYNTAX

str **man**  
[ *command* ]

#### Data Types

*command* string

---

### ARGUMENTS

*command*

Specifies a Formality shell command.

---

### DESCRIPTION

Use this command to display the manual page for any Formality shell command.

---

### EXAMPLES

This example displays the man page for the **read\_db** command:

```
fm_shell> man read_db
```

---

### SEE ALSO

help(2)

---

## match

Matches the implementation design against the reference design based on compare points.

---

## SYNTAX

status **match**

---

## DESCRIPTION

When you run the **match** command the tool changes to the match mode and matches the compare points in the implementation design against the compare points in the reference design. After matching is complete, the command reports the results of the match.

You can perform compare point matching incrementally. This is useful when automatic matching fails because of differences in the name and the structure between the reference and implementation designs. If you interrupt a match process, the tool retains the partial matching results. Run the **match** command again to resume matching.

You can issue commands that control matching, such as the **set\_compare\_rule** or **set\_user\_match** commands, if unmatched points remain in the reference design when matching completes. Run the **match** command again until all compare points in the reference design are matched. The **verify** command does not match previously matched compare points.

It is not necessary to execute this command before the **verify** command. If matching was not performed, the tool matches the compare points before verification automatically.

Use the **undo\_match** command to undo the matched results from the most recent match. Run the **undo\_match** command to undo the previous batch of matches.

The **match** command prints a summary of matching results and moves all matched compare points to the unverified state. Use the **report\_unmatched\_points** and **report\_matched\_points** commands to generate detailed reports.

Unmatched compare points do not cause errors. However, unmatched or incorrectly matched reference compare points might result in a failed verification.

---

## EXAMPLES

The following example shows all matched reference compare points.

```
fm_shell (setup)> match
Reference design is 'ref:/FMLIB/mif_top'
Implementation design is 'impl:/FMLIB/mif_top'
Status: Checking designs...
Warning: Constraint 'CON2' is disabled for contexts above 'ref:/FMLIB/m_adr'
        because it constrains hierarchical design ports. (FM-143)
Warning: Constraint 'CON1' is disabled for contexts above 'ref:/FMLIB/m_cmd'
        because it constrains hierarchical design ports. (FM-143)
Status: Building verification models...
Status: Matching...

*****Matching Results*****

288 Compare points matched by name
```

```

30 Compare points matched by signature analysis
0 Compare points matched by topology
0(31) Unmatched reference(implementation) compare points
0(0) Unmatched reference(implementation) primary inputs, black box outputs
-----

```

Unmatched Objects	REF	IMPL
-----		
Registers	0	31
Clock-gate LAT	0	31

```

*****

```

The following example shows some remaining unmatched compare points.

```

fm_shell (match)> match
Reference design is 'ref:/WORK/sequenceur'
Implementation design is 'imp:/WORK/SEQUENCEUR'
Status: Checking designs...
Info: 0 (4) multiply-driven nets found in reference (implementation) design;
see formality.log for list.
Status: Building verification models...
Status: Matching...

```

```

*****Matching Results*****

```

```

35 Compare points matched by name
44 Compare points matched by signature analysis
0 Compare points matched by topology
9(9) Unmatched reference(implementation) compare points
0(0) Unmatched reference(implementation) primary inputs, black box outputs
-----

```

Unmatched Objects	REF	IMPL
-----		
Registers	9	9
DFF	9	9

```

*****

```

---

## SEE ALSO

```

report_unverified_points(2)
report_matched_points(2)
report_unmatched_points(2)
remove_user_match(2)
report_user_matches(2)
set_user_match(2)
setup(2)
undo_match(2)
verify(2)

```



---

## match\_eco\_regions

Identifies and matches ECO regions.

---

### SYNTAX

```
status match_eco_regions
[ -name name ]
[ -work_directory name ]
[ -save_session value ]
[ -include_unread_compare_points value ]
[ -include_directly_undriven_outputs value ]
```

#### Data Types

*name* string  
*value* string

#### Enabled Shell Modes

Preverify  
Match  
Verify

---

### ARGUMENTS

#### **-name *name***

Specifies an optional name for the ECO. The default name is "ECO". All output files generated by the `write_eco_regions` and `create_eco_patch` commands will follow a naming convention that is based on the supplied name. You must use this option if you are planning to do multiple incremental ECOs.

#### **-work\_directory *name***

Specifies an optional directory path name for all FM-ECO output. If the directory does not exist it will be created. If no directory is specified all FM-ECO output will be written in the current directory.

#### **-save\_session *value***

Specifies whether to save a formality session file from the ECO reference to original reference verification context. Specify one of the following for the value argument:

- *on*
- *off (default)*

#### **-include\_unread\_compare\_points *value***

Specifies whether to include unread compare points when comparing the ECO reference to the original reference designs. Use this option if the RTL change has an impact on existing matched unread compare points or introduces new unread compare points in the design. You must also enable verification of unread compare points or matched unread compare points when using this option,

and the default setting will be set accordingly. Specify one of the following for the value argument:

- *all*
- *matched*
- *none*

**-include\_directly\_undriven\_outputs *value***

Specifies whether to consider ECOs that involve directly undriven output ports. Use this option if the ECO resulted in an existing directly undriven primary output port to become driven or an existing driven primary output port to become directly undriven. Specify one of the following for the value argument:

- *on (default)*
- *off*

---

## LICENSE

This command is available when the "Formality-LogicECO" license key is used.

---

## DESCRIPTION

This command can be issued in preverify, match or verify mode. You must first specify the original reference, original implementation, and the ECO reference. The command will identify ECO regions in the ECO reference and their matching boundaries in the original implementation.

---

## SEE ALSO

write\_eco\_regions  
create\_eco\_patch  
set\_orig\_reference  
set\_orig\_implementation  
set\_eco\_reference  
set\_eco\_implementation

---

## memory

Reports **memory** used by the Formality shell.

---

### SYNTAX

```
int memory
  [-format]
  [-units]
  [-tag]
  [-now]
  [-sub]
```

---

### ARGUMENTS

#### **-format**

Formats output with appropriate units.

#### **-units kB | mB | gB**

Specify which units to use. The default is kB.

#### **-tag**

Reports which parallel section, if any, set the high-water mark.

#### **-now**

Reports memory used by the current main process, ignoring child processes that are no longer active and that may have set a higher highwater mark.

#### **-sub**

Reports maximum memory used by any subprocess.

---

### DESCRIPTION

Use this command to report memory used by the Formality shell. When using multi-core (set\_host\_options -max\_cores <n>, n > 1), this command reports an upper bound on the maximum high watermark of memory over the life of the Formality session, including child processes, which may be more than the current memory in use. By default the memory is rounded to the nearest kilobyte.

Note that the Linux tools, such as ps, top, lsf, generally do not distinguish private vs. shared memory in a multi-core environment, so they erroneously report memory usage that is higher than actual use, and higher than the numbers reported by Formality.

## EXAMPLES

The following example returns memory used by the Formality shell.

```
fm_shell> memory  
4880
```

---

## SEE ALSO

---

## parse\_proc\_arguments

Parses the arguments passed into a Tcl procedure.

---

### SYNTAX

```
string parse_proc_arguments -args arg_list  
result_array
```

```
list arg_list  
string result_array
```

---

### ARGUMENTS

**-args *arg\_list***

Specified the list of arguments passed in to the Tcl procedure.

***result\_array***

Specifies the name of the array into which the parsed arguments should be stored.

---

### DESCRIPTION

The **parse\_proc\_arguments** command is used within a Tcl procedure to enable use of the -help option, and to support argument validation. It should typically be the first command called within a procedure. Procedures that use **parse\_proc\_arguments** will validate the semantics of the procedure arguments and generate the same syntax and semantic error messages as any application command (see the examples that follow).

When a procedure that uses **parse\_proc\_arguments** is invoked with the -help option, **parse\_proc\_arguments** will print help information (in the same style as using **help -verbose**) and will then cause the calling procedure to return. Similarly, if there was any type of error with the arguments (missing required arguments, invalid value, and so on), **parse\_proc\_arguments** will return a Tcl error and the calling procedure will terminate and return.

If you didn't specify -help, and the specified arguments were valid, the array variable *result\_array* will contain each of the argument values, subscripted with the argument name. Note that the argument name here is NOT the names of the arguments in the procedure definition, but rather the names of the arguments as defined using the **define\_proc\_attributes** command.

The **parse\_proc\_arguments** command cannot be used outside of a procedure.

---

### EXAMPLES

The following procedure shows how **parse\_proc\_arguments** is typically used. The argHandler procedure parses the arguments it receives. If the parse is successful, argHandler prints the options or values actually received.

```
proc argHandler args {
```

```

parse_proc_arguments -args $args results
foreach argname [array names results] {
    echo " $argname = $results($argname)"
}
}
define_proc_attributes argHandler -info "argument processor" \
-define_args \
{{-Oos "oos help" AnOos one_of_string {required value_help {values {a b}}}}
{-Int "int help" AnInt int optional}
{-Float "float help" AFloat float optional}
{-Bool "bool help" "" boolean optional}
{-String "string help" AString string optional}
{-List "list help" AList list optional}}
{-IDup int dup AIDup int {optional merge_duplicates}}

```

Invoking argHandler with the -help option generates the following:

```

prompt> argHandler -help
Usage: argHandler # argument processor
-Oos AnOos (oos help:
            Values: a, b)
[-Int AnInt] (int help)
[-Float AFloat] (float help)
[-Bool] (bool help)
[-String AString] (string help)
[-List AList] (list help)

```

Invoking argHandler with an invalid option causes the following output (and a Tcl error):

```

prompt> argHandler -Int z
Error: value 'z' for option '-Int' not of type 'integer' (CMD-009)
Error: Required argument '-Oos' was not found (CMD-007)

```

Invoking argHandler with valid arguments generates the following:

```

prompt> argHandler -Int 6 -Oos a
-Oos = a
-Int = 6

```

---

## SEE ALSO

```

define_proc_attributes(2)
help(2)
proc(2)

```

---

## preverify

Causes Formality to process SVF and enter Preverify mode.

---

### SYNTAX

status **preverify**

#### Enabled Shell Modes

Setup  
Match  
Verify

---

### DESCRIPTION

This command causes Formality to process SVF and enter Preverify mode. Existing matching and verification results are discarded.

Preverify mode can be used to perform setup operations on post-SVF modified design objects. However, only setup operations that do not modify the design database can be performed in Preverify mode.

For example, SVF processing may change the name of a register object. If a constant is to be set on this register, its post-SVF processed name must be guessed in Setup mode. Preverify mode alleviates this problem by giving you access to the post-SVF processed register name.

In Preverify mode, executing the **match** command causes Formality to perform compare point matching and switches to Match mode. Executing the **verify** command will cause Formality to switch to Verify mode. Executing **setup** will switch Formality back to Setup mode.

The prompt changes to reflect the current mode, as follows:

```
fm_shell (guide)>
fm_shell (setup)>
fm_shell (preverify)>
fm_shell (match)>
fm_shell (verify)>
```

---

### EXAMPLES

The following example illustrates entering Preverify mode from Setup mode.

```
fm_shell (setup)> preverify
Reference design is 'r:/WORK/top'
Implementation design is 'i:/WORK/top'
Status: Checking designs...
Status: Building verification models...
      Status: Creating views...
```

```
MILESTONE: SVF; 171 MB; 26.7964 s; A:1; R:0;
Status: Defining RTL constraints...
```

Arch    Source    Object ID  
No multipliers match these criteria.

Status: Propagating constraints...  
Status: Starting vtopo managers...  
Status: Initializing cpoint manager...  
Status: Identifying black-box resolved nets and marking unread objects...  
Status: Verification models complete.

***** Guidance Summary *****						
Status						
Command		Accepted	Rejected	Unsupported	Unprocessed	Total
-----						
uniquify	:	1	0	0	0	1
1						
fm_shell (preverify)>						

---

SEE ALSO

- collections(2)
- setup(2)
- guide(2)
- match(2)
- verify(2)



---

## preview

Evaluates its arg list without actually executing it, but option values are "stored through" if option value-tracking is enabled.

---

## SYNTAX

**preview** *arg* ...

---

## ARGUMENTS

*arg*

The arg list will be evaluated without being executed.

---

## DESCRIPTION

The preview command (like the built-in Tcl command eval) takes one or more arguments, which together comprise a Tcl script containing one or more commands. The preview command concatenates all its arguments together (like eval), and passes the concatenated string to the CCI/Tcl interpreter recursively.

The preview command passes its concatenated command string to the CCI/Tcl command evaluator as usual, but the special feature of the preview command is that the command will not actually be executed by preview. Instead only the early stages of CCI argument/option checking will happen for the command string. Specifically, standard CCI checking of option arguments is performed, as is "store through" of new current option values for options with current-value-tracking enabled (if option checking succeeded). The preview command thus provides a way to update current values of a command's options (which have current-value-tracking enabled) without actually executing the command.

Conceptually, the CCI preview command is in the same "family" as the Tcl built-in command eval - the difference is that eval executes its concatenated command string, while preview does not, but preview does implement CCI option checking and "store through" for current values of options (which have current-value-tracking enabled).

The advantage of the preview command (compared with a command for turning on and off preview mode) is that a preview command is guaranteed to finish/exit (thus guaranteeing that the preview behavior in the CCI command evaluator will get turned off as soon as the preview command exits). If instead it was necessary to have matching commands for turning on and off "preview mode", bugs in Tcl script code might cause the "turn off preview mode" call to be skipped - then the interpreter would be stuck in "preview mode" indefinitely (and we do not want to take the risk of such a serious bug happening). By having preview as a command, we greatly reduce the risk that the interpreter could get "stuck in preview mode".

Note that the preview command itself does not implement any additional echoing to output of its concatenated command.

About preview and mutually exclusive options: preview performs all option checking for the previewed command as if it was to be executed (even though the command will not be executed). Thus the simultaneous presence of multiple mutually exclusive options will generate an error under preview (and "store through" of current option values will be aborted). This can be regarded as both a feature (it's consistent with normal command execution) and a limitation (it makes it impossible to set current values for mutually exclusive options of a command from a single run of preview). To workaround this limitation, we also provide the `set_command_option_value` command (which does not do checks such as the mutual exclusion check) - see the man page for `set_command_option_value`.

A possible power user application: power users could put preview commands in their home directory Tcl startup files for their favorite

dialogs/commands to "seed" initial current values for these dialogs. This may lower the need for automatically saving replay scripts (of preview commands for each command/dialog) on exit from the application. Note: the `set_command_option_value` command may be easier to use than `preview` for this purpose.

---

## EXAMPLES

Consider a command named `foo` with two integer options, `-bar1` and `-bar2`, that have current-value-tracking enabled. In the following example, the "current values" being tracked for the `-bar1` and `-bar2` options are updated to 10 and 20 respectively:

```
prompt> preview foo -bar1 10 -bar2 20
prompt> get_command_option_values -current -command foo
-bar1 10 -bar2 20
```

Note that `foo` command is not actually executed in this example.

---

## SEE ALSO

`get_command_option_values(2)`  
`set_command_option_value(2)`

---

## print\_message\_info

Prints information about diagnostic messages that have occurred or have been limited.

---

### SYNTAX

```
string print_message_info  
  [-ids id_list]  
  [-summary]
```

#### Data Types

*id\_list* list

---

### ARGUMENTS

#### -ids *id\_list*

Specifies a list of message identifiers to report. Each entry can be a specific message or a glob-style pattern that matches one or more messages. If this option is omitted and no other options are given, then all messages that have occurred or have been limited are reported.

#### -summary

Generates a summary of error, warning, and informational messages that have occurred so far.

---

### DESCRIPTION

The **print\_message\_info** command enables you to print summary information about error, warning, and informational messages that have occurred or have been limited with the **set\_message\_info** command. For example, if the following message is generated, information about it is recorded:

```
Error: unknown command 'wrong_command' (CMD-005)
```

It is useful to be able to summarize all recorded information about generated diagnostic messages. Much of this can be done using the **get\_message\_info** command, but you need to know a specific message ID. By default, **print\_message\_info** summarizes all of the information. It provides a single line for each message that has occurred or has been limited, and one summary line that shows the total number of errors, warnings, and informational messages that have occurred so far. If an *id\_list* is given, then only messages matching those patterns are displayed. If **-summary** is given, then a summary is displayed.

Using a pattern in the *id\_list* is intended to show a specific message prefix, for example, "CMD\*". Note that this does not show all messages with that prefix. It shows only the messages that have occurred or have been limited.

---

### EXAMPLES

The following example uses **print\_message\_info** to show a few specific messages:

```
prompt> print_message_info -ids [list "CMD*" APP-99]
```

Id	Limit	Occurrences	Suppressed
CMD-005	0	7	2
APP-99	1	0	0

At the end of the session, you might want to generate some information about a set of interesting messages, such as how many times each occurred (which includes suppressions), how many times each was suppressed, and whether a limit was set for any of them. The following example uses **print\_message\_info** to get this information:

```
prompt> print_message_info
```

Id	Limit	Occurrences	Suppressed
CMD-005	0	12	0
APP-027	100	150	50
APP-99	0	1	0

Diagnostics summary: 12 errors, 150 warnings, 1 informational

Note that the suppressed count is not necessarily the difference between the limit and the occurrences, since the limit can be dynamically changed with the **set\_message\_info** command.

---

## SEE ALSO

`get_message_info(2)`  
`set_message_info(2)`  
`suppress_message(2)`

---

## print\_proc\_new\_vars

Checks for new variables created within a Tcl procedure.

---

### SYNTAX

string **print\_proc\_new\_vars**

---

### ARGUMENTS

The **print\_proc\_new\_vars** command has no arguments.

---

### DESCRIPTION

The **print\_proc\_new\_vars** command is used in a Tcl procedure to show new variables created up to that point in the procedure. If the **sh\_new\_variable\_message\_in\_proc** and **sh\_new\_variable\_message** variables are both set to **true**, this command is enabled. If either variable is **false**, the command does nothing. The result of the command is always an empty string.

When enabled, the command issues a CMD-041 message for each variable created in the scope of the procedure so far. Arguments to the procedure are excluded.

For procedures that are in a namespace (that is, not in the global scope), **print\_proc\_new\_vars** also requires that you have defined some aspect of the procedure using the **define\_proc\_attributes** command.

Important: This feature has a significant negative impact on CPU performance. This should be used only when developing scripts or in interactive use. When you turn on the feature, the application issues a message (CMD-042) to warn you about the usage of this feature.

---

### EXAMPLES

Assuming that the appropriate control variables are set to **true**, the following commands show new variables created within procedures:

```
prompt> proc new_proc {a} {  
    set x $a  
    set y $x  
    unset x  
    print_proc_new_vars  
}
```

```
prompt> new_proc 67  
=New variable report for new_proc:  
Information: Defining new variable 'y'. (CMD-041)  
=END=
```

```
prompt>
```

```
prompt> proc ns::p2 {a} {  
        set x $a  
        print_proc_new_vars  
    }  
  
prompt> define_proc_attributes ns::p2  
  
prompt> ns::p2 67  
=New variable report for ns::p2:  
Information: Defining new variable 'x'. (CMD-041)  
=END=
```

---

## SEE ALSO

[define\\_proc\\_attributes\(2\)](#)  
[sh\\_new\\_variable\\_message\(3\)](#)  
[sh\\_new\\_variable\\_message\\_in\\_proc\(3\)](#)

---

## print\_suppressed\_messages

Displays an alphabetical list of message IDs that are currently suppressed.

---

### SYNTAX

string **print\_suppressed\_messages**

---

### ARGUMENTS

The **print\_suppressed\_messages** command has no arguments.

---

### DESCRIPTION

The **print\_suppressed\_messages** command displays all messages that you suppressed using the **suppress\_message** command. The messages are listed in alphabetical order. You only can suppress informational and warning messages. The result of **print\_suppressed\_messages** is always the empty string.

---

### EXAMPLES

The following example shows the output from the **print\_suppressed\_messages** command:

```
prompt> print_suppressed_messages  
No messages are suppressed
```

```
prompt> suppress_message {XYZ-001 CMD-029 UI-1}
```

```
prompt> print_suppressed_messages  
The following 3 messages are suppressed:  
CMD-029, UI-1, XYZ-001
```

---

### SEE ALSO

[suppress\\_message\(2\)](#)  
[unsuppress\\_message\(2\)](#)

---

## printenv

Prints the value of each environment variable.

---

### SYNTAX

**printenv**  
[*pattern*]

#### Data Types

*pattern* string

---

### ARGUMENTS

*pattern*

Specifies a single variable to print.

---

### DESCRIPTION

Use this command to print the values of the environment variables inherited from the parent process or set in the tool by using the **set\_unix\_variable** command. Unless a variable is specified, the command prints the values of all environment variables.

To retrieve the value of a single environment variable, you can also use the **get\_unix\_variable** command.

---

### EXAMPLES

These examples show the output of the **printenv** command.

```
fm_shell> printenv SHELL
/bin/csh
fm_shell> printenv EDITOR
emacs
```

---

### SEE ALSO

get\_unix\_variable(2)  
set\_unix\_variable(2)



---

## printvar

Prints the values of one or more variables.

---

### SYNTAX

**printvar**  
[ -application ]  
[ -user\_defined ]  
[ *pattern* ]

#### Data Types

*pattern*

---

### ARGUMENTS

#### -application

Prints the values of the application variables.

#### -user\_defined

Prints the values of the user-defined variables.

#### *pattern*

Prints the value of the specified *pattern* (variable).

---

### DESCRIPTION

Use this command to print the values of one or more patterns.

If a *pattern* is not specified, the command prints out the values of all the variables, both Formality and user-defined.

---

### EXAMPLES

This example prints the values of all the variables.

```
fm_shell> printvar
```

This example prints the values of all the variables that start with sh\*.

```
fm_shell> printvar sh*
sh_arch           ="sparc"
sh_continue_on_error  = "0"
sh_enable_page_mode   = "false"
sh_product_version   = "1997.01-development"
```

```
sh_source_uses_search_path = "false"
```

This example prints the value of the variable `search_path`.

```
fm_shell> printvar search_path  
search_path = ". /designs/newcpu/v1.6 /lib/cmos"
```

---

## SEE ALSO

---

## proc\_args

Displays the formal parameters of a procedure.

---

### SYNTAX

```
str proc_args  
  <proc_name>
```

#### Data Types

<proc\_name> string

---

### ARGUMENTS

*proc\_name*

Specifies the name of the procedure.

---

### DESCRIPTION

This command displays the names of the formal parameters of a user defined procedure.

This command is essentially a synonym for the Tcl builtin command **info** with the **args** argument.

---

### EXAMPLES

This example shows the output of **proc\_args** for a simple procedure.

```
fm_shell> proc plus {a b} { return [expr $a + $b] }  
fm_shell> proc_args plus  
a b  
fm_shell> info args plus  
a b
```

---

### SEE ALSO

info(2)  
proc(2)

proc\_body(2)

---

## proc\_body

Displays the body of a procedure.

---

### SYNTAX

**proc\_body**  
*proc\_name*

#### Data Types

*proc\_name* string

---

### ARGUMENTS

*proc\_name*

Specifies the name of the procedure.

---

### DESCRIPTION

This command displays the contents of a user-defined procedure.

This command is essentially a synonym for the Tcl builtin command **info** with the **body** argument.

---

### EXAMPLES

This example shows the output of **proc\_body** for a simple procedure.

```
fm_shell> proc plus {a b} { return [expr $a + $b] }
fm_shell> proc_body plus
return [expr $a + $b]
```

---

### SEE ALSO

info(2)  
proc(2)  
proc\_args(2)

---

## query\_objects

Searches for and displays objects in the database.

---

### SYNTAX

```
string query_objects  
  [-verbose]  
  [-truncate elem_count]  
  [-class class_name]  
  object_spec
```

#### Data Types

<i>class_name</i>	string
<i>elem_count</i>	int
<i>object_spec</i>	list

---

### ARGUMENTS

#### -verbose

Displays the class of each object found. By default, only the name of each object is listed. With this option, each object name is preceded by its class (see the EXAMPLES).

#### -truncate *elem\_count*

Truncates display to *elem\_count* elements. By default, up to 100 elements display. To see more or less elements, use this option. To see all elements, set the *elem\_count* value to 0.

#### -class *class\_name*

For elements in the *object\_spec* that are not collections, this is the class used when searching the database for objects which match the element. Valid classes are application-specific.

#### *object\_spec*

Provides a list of objects to find and display. Each element in the list is either a collection or a pattern which will match some objects in the database. Patterns are explicitly searched for in the database with class *class\_name*.

---

### DESCRIPTION

The **query\_objects** command finds and displays objects in the application's runtime database. The command does not have a meaningful return value; it displays the objects found and returns an empty string.

The *object\_spec* is a list containing collections and/or object names. For elements of the *object\_spec* that are collections, **query\_objects** simply displays the contents of the collection.

For elements of the *object\_spec* that are names (or contain wildcard patterns), the **query\_objects** command searches the database for objects of the class specified by the *class\_name* option. Note: The **query\_objects** command does not have a predefined implicit order of classes for which searches are initiated. If you do not specify the *class\_name* option, only those elements that are collections

are displayed. Messages are displayed for the other elements (see EXAMPLES).

To control the number of elements displayed, use the *-truncate* option. If the display is truncated, you see the ellipsis (...) as the last element. Note that if the default truncation occurs, a message displays showing the total number of elements that would have displayed (see EXAMPLES).

NOTE: The output from the **query\_objects** command looks similar to the output from any command that creates a collection; however, the result of the **query\_objects** command is always an empty string.

---

## EXAMPLES

These following examples show the basic usage of the **query\_objects** command.

```
prompt> query_objects [get_cells o*]
{r:/WORK/top/or1 r:/WORK/top/or2 r:/WORK/top/or3}
prompt> query_objects -class cell U*
{r:/WORK/top/U1 r:/WORK/top/U2}
prompt> query_objects -verbose -class cell [list U* [get_nets n1]]
{{cell r:/WORK/top/U1} {cell r:/WORK/top/U2} {net r:/WORK/top/n1}}
```

When you omit the **-class** option, only those elements of the *object\_spec* that are collections generate output. The other elements generate error messages.

```
prompt> query_objects [list U* [get_nets n1] n*]
Error: No such collection 'U*' (SEL-001)
Error: No such collection 'n*' (SEL-001)
{r:/WORK/top/n1}
```

When the output is truncated, you get the ellipsis at the end of the display. For the following example, assume the default truncation is 5 (it is actually 100).

```
prompt> query_objects [get_cells o*] -truncate 2
{r:/WORK/top/or1 r:/WORK/top/or2 ...}
prompt> query_objects [get_cells *]
{r:/WORK/top/or1 r:/WORK/top/or2 r:/WORK/top/or3 r:/WORK/top/U1 r:/WORK/top/U2 ...}
Output truncated (total objects 126)
```

---

## SEE ALSO

```
collections(2)
get_cells(2)
get_clocks(2)
get_designs(2)
get_generated_clocks(2)
get_lib_cells(2)
get_lib_pins(2)
get_libs(2)
get_nets(2)
get_path_groups(2)
get_pins(2)
get_ports(2)
get_qtm_ports(2)
get_timing_paths(2)
```

---

## quit

Exits the Formality shell.

---

### SYNTAX

**quit**

---

### DESCRIPTION

This command exits the Formality shell and closes the current Formality session.

---

### EXAMPLES

The following example exits the Formality shell.

```
fm_shell> quit
```

---

### SEE ALSO

[exit\(2\)](#)



---

## read\_container

Reads a container into the Formality environment.

---

### SYNTAX

```
read_container  
[ -container container_name | -r | -i ]  
[ -replace ]  
file_name
```

#### Data Types

```
container_name string  
file_name string
```

---

### ARGUMENTS

#### **-container *container\_name***

Specifies the container into which files are read.

#### **-r**

Reads container data into the current reference container.

#### **-i**

Reads container data into the current implementation container.

#### **-replace**

Overwrites an existing container. This option is required if the current container is not empty.

#### ***file\_name***

Specifies the name of the file containing the saved container.

---

### DESCRIPTION

This command reads a container into the Formality environment. The file that is read in must be written by Formality.

If the container being read in and the current container have the same name, the command reports an error and does not load the container. If the two containers do not have the same name, the command creates the container, reads the information into it, and establishes it as the current container.

To specify a unique container name, use the **-container** option. The *-replace* option replaces the contents of the existing container with the contents of the new container.

Containers that are read from files, written without using the **l-pre\_set\_top** option, marked "read-only," and operations that could modify their contents are not allowed.

You cannot run the following commands on a read-only container, or on objects within a read-only container:

- **set\_top**
- **read\_db**
- **read\_verilog**
- **read\_vhdl**
- **remove\_design**
- **remove\_design\_library**
- **remove\_library**
- **remove\_object**
- **rename\_object**
- **set\_direction**
- **uniquify**

The **read\_container** command returns one of the following:

- 0 to indicate failure
- 1 to indicate success

---

## EXAMPLES

The following example creates a new container named `spec_2`.

```
fm_shell> read_container -container spec_2 ref.fsc
Loading container file '/u/formality/spec_2.fsc'
Created container 'spec_2'
Current container set to 'spec_2'
1
fm_shell>
```

The following example reads the information from a previously saved container back into an existing container.

```
fm_shell> read_container -replace ref.fsc
Loading container file '/u/formality/ref.fsc'
Reference design is no longer set
1
fm_shell>
```

---

## SEE ALSO

`report_containers(2)`  
`write_container(2)`

---

## read\_db

Reads technology libraries or designs in the .db format.

---

### SYNTAX

```
read_db  
[ -container container_name | -r | -i ]  
[ -libname libname ]  
[ -technology_library ]  
[ -merge ]  
[ -replace_black_box ]  
file_names
```

#### Data Types

```
container_name string  
libname string  
file_names string
```

---

### ARGUMENTS

#### **-container *container\_name***

Specifies the container into which the data is read and sets it as the current container.

#### **-r**

Reads data into the default reference container and sets it as the current container.

#### **-i**

Reads data into the default implementation container and sets it as the current container.

#### **-technology\_library**

Specifies that the file is a technology library.

#### **-libname *libname***

Specifies the design library or the technology library into which the designs or cells are read.

#### **-merge**

Replaces black box cells and test cells in the specified library with those that are read in from the .db format library. This option also adds cells if there are no corresponding cells already in the specified existing library.

#### **-replace\_black\_box**

Replaces black box cells and test cells in the specified library with those that are read in from the .db format library.

#### ***file\_names***

Specifies one or more files to read. Specify Synopsys database files.

## DESCRIPTION

Use this command to read one or more Synopsys internal database (.db) designs or technology libraries into a container. The **read\_db** command recognizes whether a file represents a design or a technology library. The command overwrites existing designs in the container with the designs that are read. Designs linked to the overwritten files are unlinked.

Unless you specify the name of the design or technology library, the command uses the default design library named *WORK* or the default technology library named *TECH\_WORK*.

To merge the specified existing library and the .db format library being read in, use the *-merge* option. Merging replaces black box and test cells in the existing library with those read in from the database. Merging also adds cells if there are no corresponding cells in the existing library.

To replace black box and test cells in the specified existing library with those read in from the database without merging the two libraries, use the *-replace\_black\_box* option.

The following list describes how to use the **read\_db** command.

- **Reading designs in .db format into the current container** - To read a design library in .db format into the current container, use the **read\_db** command. Do not use the *-container* option. If you use the *-container* option and you have not established a current container, the command reports an error. Use the following command:

```
read_db file
```

- **Reading a design library in .db format into a specific container** - To read a design library in the .db format into a specific container, use the *-container* option. If you use the *-container* option and the container does not exist, the command creates the container and establishes it as the current container. Use the following command:

```
read_db -container c_name file
```

- **Reading shared database technology libraries** - To read a shared database technology library, use the **read\_db** command. Do not use the *-container* option, which reads the library into all currently open containers and all subsequently opened containers. Use the following command:

```
read_db file
```

- **Reading unshared database technology libraries** - To read a database technology library into a specific container, use the *-container* option. If you use the *-container* option and the container does not exist, the command creates the container and establishes it as the current container. Use the following command:

```
read_db -container c_name file
```

- **Renaming a design library** - To rename a design library, specify the *-libname* option. By default, designs are read into the default design library called *WORK*. Use the following command:

```
read_db -libname my_design_lib file
```

- **Renaming a technology library** - To rename a technology library, specify the *-libname* option. By default, cells are read into the default technology library called *TECH\_WORK*.

```
read_db -libname my_tech_lib file
```

The **read\_db** command returns one of the following:

- 0 to indicate failure
- 1 to indicate success

### Special Behavior in the Library Verification Mode

In the library verification mode, use the **read\_db** command to read all libraries in .db format into a specified container. The container library names are handled internally by the tool. The only options that remain valid in the library verification mode are *-r* and *-i*.

```
fm_shell> read_db -r mylib.db
```

```

Loading db file 'mylib.db'
Current container set to 'r'
Total cells found: 2
1

```

---

## EXAMPLES

This example reads a design library in .db format. In this case, the command creates the container by using the *-container* option. Note the design files are read into a default design library named *WORK* and the newly created container is established as the current container.

```

fm_shell> read_db -c ref post_scan.db
Loading db file 'post_scan.db'
No target library specified, default is WORK
Created container 'ref'
Current container set to 'ref'
1
fm_shell>

```

This example reads a design library in .db format into the current container. Here, the *-libname* option is used to rename the design library to *my\_lib*.

```

fm_shell> create_container ref
Created container 'ref'
Current container set to 'ref'
1
fm_shell> read_db -libname my_lib post_scan.db
Loading db file 'post_scan.db'
1
fm_shell> report_design_libraries

```

```

Number of
Designs   Design Library
-----
      10   ref:/my_lib
1

```

This example merges the contents of the specified library in .db format into the shared technology library *my\_lib*, replacing black box and test cells that are already in the library *my\_lib*.

```

fm_shell> read_db -libname my_lib -replace_black_box resolve.db
Loading db file 'resolve.db'
Loading new version of design 'LS1P' into shared technology library 'my_lib'
Loading new version of design 'LS1' into shared technology library 'my_lib'
1
fm_shell>

```

This example merges the contents of the specified library in .db format into the technology library *new\_lib* that is not shared, replacing black box and test cells and adding cells when there is no corresponding cell already in the library *new\_lib*.

```

fm_shell> read_db -c ref -libname new_lib -merge new_versions.db
Loading db file 'new_versions.db'
1
fm_shell>

```

This example reads a shared technology library (all containers get the library). Note that when you create subsequent containers, the command loads the technology library automatically into the new container.

```

fm_shell> read_db lca500k.db
Loading db file 'lca500k.db'
1
fm_shell>

```

---

## SEE ALSO

```
report_designs(2)  
report_design_libraries(2)  
report_libraries(2)
```

---

## read\_ddc

Reads Synopsys logical database in the .ddc format.

---

### SYNTAX

```
status read_ddc
[ -container container_name | -r | -i]
[ -libname libname]
[ -technology_library]
[ -merge]
[ -replace_black_box]
[ -block_abstraction block_names]
file_names
```

#### Data Types

```
container_name string
libname string
file_names string
block_names string
```

---

### ARGUMENTS

#### **-container *container\_name***

Specifies the container into which the file is to be read and sets it as the current container.

#### **-r**

Reads the file into the default reference container and sets it as the current container.

#### **-i**

Reads the file into the default implementation container and sets it as the current container.

#### **-technology\_library**

Indicates that the specified file as a technology library.

#### **-libname *libname***

Specifies the design library or the technology library into which the designs in .ddc format or cells are read.

#### **-merge**

Replaces black box cells and test cells in the existing library with those read in from the designs or cells. This option adds cells if there are no corresponding cells already in the existing library.

#### **-replace\_black\_box**

Replaces black box cells and test cells in the specified existing library with those read in from the designs or cells.

#### ***block\_names***

Specifies a list of block abstraction module or design names.

***file\_names***

Specifies one or more files to read. Specify one or more Synopsys designs in .ddc format.

---

**DESCRIPTION**

This command reads one or more design files that are in .ddc format into the specified container. When existing designs are present in the destination container, the tool overwrites existing designs with the designs that are read. Designs linked to the overwritten files are unlinked.

By default, the tool names the design library *WORK*, or *TECH\_WORK* if it is a technology library.

If you specify the **-merge** option for a .ddc format design,

- The contents of the file are merged into the specified existing library
- Black box and test cells in the existing library are replaced with those read in from the database
- Cells are added even if there are no corresponding cells in the existing library.

The **-replace\_black\_box** option only replaces black box and test cells in the named existing library with those read in from the database.

The **-block\_abstraction** switch allows list of designs to be read as interface logic for Transparent Interface Optimization(TIO) flow.

The following list describes the use of the **read\_ddc** command:

- **Reading .ddc format designs into the current container**- To read designs in .ddc format into the current container, use the **read\_ddc** command. Do not use the **-container** option. The syntax to read .ddc format designs into the current directory is:

```
read_ddc file_list
```

- **Reading .ddc format designs into a specific container**- To read .ddc format designs into a specific container, use the **container** option. If you use the **-container** option and the container does not exist, the tool creates the container and establishes it as the current container. The syntax to read .ddc format designs into a specific directory is:

```
read_ddc -container container_name
```

- **Renaming a design library** - To rename a design library, use the **-libname** option. By default, designs are read into the default design library named *WORK*. The command syntax to rename a design library is:

```
read_ddc -libname libname
```

---

**EXAMPLES**

The following example reads a .ddc format design. The command creates a container by using the **-container** option. Note that the design files are read into a default design library named *WORK* and the newly created container is established as the current container.

```
prompt> read_ddc -c ref post_scan.ddc
Loading ddc file 'post_scan.ddc'
Loaded 22 designs.
< ... list of designs omitted ... >
No target library specified, default is WORK
Created container 'ref'
Current container set to 'ref'
1
```

This example reads a .ddc format design into the current container. The **-libname** option is used to rename the design library to *my\_lib*.



```
prompt> create_container ref
Created container 'ref'
Current container set to 'ref'
1
prompt> read_ddc -libname my_lib \
post_scan.ddc
Loading ddc file 'post_scan.ddc'
Loaded 22 designs.
< ... list of designs omitted ... >
1
prompt> report_design_libraries
Number of
Designs   Design Library
-----
      22   ref:/my_lib
1
```

---

## SEE ALSO

report\_designs(2)  
report\_design\_libraries(2)  
report\_libraries(2)

---

## read\_fsm\_states

Reads finite state machine (FSM) states into the Formality environment.

---

### SYNTAX

**read\_fsm\_states**

*file*  
[ *designID* ]

#### Data Types

*designID* string

---

### ARGUMENTS

#### *file*

Specifies the file containing the FSM states.

#### *designID*

Specifies the design with FSM states you are defining.

---

### DESCRIPTION

This command reads FSM information, enabling the tool to correctly process FSM designs that have different state encodings. For the tool to verify one FSM against another, the FSM designs must use the same state names.

The specified file must be generated by using the **report\_fsm** command in Design Compiler or be a text file that follows these rules:

- Must contain one-word directives that start with the period (.) character.
- Single-line comments must start with the pound character (#). White space must precede the pound character. The newline character is considered white space.
- The file must contain the ".state\_vector" directive followed by a single or multiline list of FSM flip-flop names. This list defines the FSM state vectors.
- The file must contain the ".encoding" directive followed by a list of state names and their binary encodings. For example, the directive could be followed by this line:

```
RESET_STATE 2#100 FINAL_STATE 2#011;
```

For each state name and encoding pair, the number and order of binary digits must match the number and order of flip-flops in the state vectors. You can separate binary digits with an underscore character "\_". You can specify the number base as binary, octal, decimal, or hexadecimal.

The following example specifies FSM states. It names two flip-flops that hold states and defines four state names and their encodings. Notice the various methods by which you can specify the numbering system.

```
CURRENT_STATE_reg[1]
CURRENT_STATE_reg[0]
```

```
SO ^B0_0
S1 16#2
S2 ^O1
S3 8#3
```

You can specify the design into which states are read by specifying the *designID* argument. If you do not specify a design ID, the command reads the states into the current design. If the command cannot match the FSM state information in the file to the design, it reports the following error, where *name* is the flip-flop that could not be found:

Error: No Flip-Flop *name* in the design.

The **read\_fsm\_states** command returns one of the following:

- 0 to indicate failure
- 1 to indicate success

---

## EXAMPLES

The following example reads FSM states into the current design. The states are located in a file named *state\_info* in the current working directory.

```
fm_shell> read_fsm_states state_info
1
fm_shell>
```

The following example reads FSM states into the design *ref:/WORK/CORE/FSM*. The states are located in a file named *state\_info*.

```
fm_shell> read_fsm_states $HOME/misc/state_info \
ref:/WORK/CORE/FSM
1
```

---

## SEE ALSO

```
report_fsm(2)
set_fsm_encoding(2)
set_fsm_state_vector(2)
```

---

## read\_ndm

Reads Synopsys logical database in the NDM format.

---

### SYNTAX

```
status read_ndm
[ -container container_name | -r | -i ]
[ -libname libname ]
[ -format netlist_format ]
[ -abstraction_block block_names ]
[ -preserve_supply_constants ]
[ -no_upf ]
-block block_name
library_name
```

#### Data Types

```
container_name string
libname string
netlist_format string
block_name string
library_name string
```

---

### ARGUMENTS

#### **-container *container\_name***

Specifies the container into which the library is to be read and sets it as the current container.

#### **-r**

Reads the file into the default reference container and sets it as the current container.

#### **-i**

Reads the file into the default implementation container and sets it as the current container.

#### **-libname *libname***

Specifies the design library into which the designs or cells in NDM format are read.

#### **-format *netlist\_format***

Specifies the netlist format. Valid values are as follows:

- *pg\_netlist* - All netlist cells have pg\_pins and connections
- *non\_pg\_netlist* - The netlist does not contain any cells with pg\_pins
- *partial\_pg\_netlist* - The netlist uses pg\_pin cells only for instances with pg\_pin connections in the netlist

#### **-preserve\_supply\_constants**

Preserves power or ground (including analog power or ground) supply constant nets.

#### **-no\_upf**

Ignores UPF in the NDM library.

When this option is not specified, Formality extracts the NDM library UPF and automatically loads it during the *set\_top* command.

**-block *block\_name***

Specifies already existing blocks to be read in the *designName[/labelName]* format.

**-abstraction\_block *block\_names***

Specifies a list of block abstraction block names.

***library\_name***

The name of the pre-existing NDM library.

Note: As the library name is a directory name, it cannot contain the slash ("/") or colon (":") character.

---

## DESCRIPTION

This command reads libraries in the NDM format into the specified container. The library name can be given as a full path name, a relative path name, or a single name. In case of relative path name and single name scenarios, the *search\_path* variable is used to determine the complete path to the library.

Based on the *block\_name* specified, the existing block is opened for reading with the default design view. This block contains designs that are loaded into the library.

By default, the tool names the design library as WORK. To change the library name, use the *-libname* option. Existing libraries with same name are not overwritten.

---

## EXAMPLES

The following example reads an NDM format library. The command creates a container using the **-container** option. The newly created container is established as the current container.

```
prompt> read_ndm -c ref -block my_top_block_name my_ndm_design_lib
Created container 'ref'
Current container set to 'ref'
1
```

This example reads an NDM format design into the current container.

```
prompt> create_container ref
Created container 'ref'
Current container set to 'ref'
1
prompt> read_ndm -block my_top_block_name my_ndm_design_lib
1
```

---

## SEE ALSO

*set\_top*(2)  
*report\_designs*(2)  
*report\_design\_libraries*(2)  
*report\_libraries*(2)

---

## read\_power\_model

Reads Formality power model files.

---

### SYNTAX

```
read_power_model  
[ -container container_name | -r | -i]  
[ -libname libname]  
file_names
```

#### Data Types

```
container_name string  
libname string  
file_names string
```

---

### ARGUMENTS

#### **-container *container\_name***

Specifies the container into which the file is to be read and sets it as the current container.

#### **-r**

Reads the file into the default reference container and sets it as the current container.

#### **-i**

Reads the file into the default implementation container and sets it as the current container.

#### **-libname *libname***

Specifies the design library into which the designs in power model format are read.

#### ***file\_names***

Specifies one or more files to read.

---

### DESCRIPTION

The **read\_power\_model** command reads one or more design files that are in the Formality power model format into the specified container. Existing designs in the destination container are overwritten and designs linked to the overwritten files are unlinked.

The following list describes the use of the **read\_power\_model** command:

- **Reading .fpm format designs into the current container-** To read designs in the .fpm format into the current container, use the **read\_power\_model** command. Do not use the **-container** option. The syntax to read .fpm format designs into the current container is,

```
read_power_model file_list
```

- **Reading .fpm format designs into a specific container**- To read designs in the .fpm format into a specific container, use the **-container** option. If you use the **-container** option and the specified container does not exist, the tool creates the container and sets it as the current container. The syntax to read .fpm format designs into a specific directory is:

```
read_power_model -container container_name file_list
```

- **Specifying a design library** - To specify a design library, use the **-libname** option. The command syntax to read power models into a specified a design library is:

```
read_power_model -libname libname file_list
```

---

## EXAMPLES

The following example shows how to read in a Formality power model. The command creates a container using the **-container** option. Note that the design files are read into a default power model library and the newly created container is set as the current container.

```
fm_shell> read_power_model -container ref sub.fpm
Created container 'ref'
Current container set to 'ref'
Info: Loaded model for design 'sub'.
1
```

The following example shows how to read a Formality power model into the current container. The **-libname** option is used to specify a design library named *my\_lib*.

```
fm_shell> create_container ref
Created container 'ref'
Current container set to 'ref'
1
fm_shell> read_power_model -libname my_lib sub.fpm
Info: Loaded model for design 'sub'.
1
```

---

## SEE ALSO

[write\\_power\\_model\(2\)](#)

---

## read\_sverilog

Reads one or more SystemVerilog files.

---

### SYNTAX

```
status read_sverilog
[ -container container_name | -r | -i ]
[ -libname libname ]
[ -work_library libname ]
[ -uses design_libs_list ]
[ -L design_libs_list ]
[ -technology_library ]
[ -f VCS_option_file ]
[ -F VCS_option_file ]
[ -vcs "VCS_options" ]
[ -define define ]
[ -3.1a | -05 | -09 | -12 ]
[ -extra_library_cells cell_list ]
[ filenames ]
```

#### Data Types

```
container_name string
libname string
VCS_option_file string
"VCS_options" string
define string
design_list string
filenames string
```

---

### ARGUMENTS

#### **-container *container\_name***

Specifies the container into which the SystemVerilog designs or cell descriptions are read. The specified container is set as the current container.

#### **-r**

Sets the default reference container as the current container and reads the SystemVerilog designs or cell descriptions into it.

#### **-i**

Sets the default implementation container as the current container and reads the SystemVerilog designs or cell descriptions into it.

#### **-libname *libname***

Names the design library or technology library into which SystemVerilog designs or cell descriptions are read. You can specify any alphanumeric string for the *libname* argument.

#### **-work\_library *library\_name***

Same behavior as the *-libname* option.

#### **-technology\_library**



Specifies that the file that is read in is a technology library. When you use this option, specify a container by using the *-r*, *-i*, or *-container* option.

#### **-uses *design\_libs\_list***

The list of libraries used to find the references if Formality could not resolve the reference from working library. Libraries from *-uses liblist* are used only if parent library doesn't have searched design. If the design is not found in library list of **-uses**, search is continued using default search order.

#### **-L *design\_libs\_list***

The list of libraries used to find the references. Libraries from *-L liblist* are used even if parent library does have design/interface. If the reference is not found in library list of **-L**, search is canceled and error message is issued.

#### **-f *VCS\_option\_file***

Specifies that the file is a VCS option file, which contains VCS options or Verilog files.

#### **-F *VCS\_option\_file***

Same as the *-f* option but allows you to specify a path to the file and the source files listed in the file do not have to be absolute pathnames.

#### **-vcs *VCS options***

Specifies that the string enclosed within quotation marks is VCS options or Verilog files.

#### **-define *define***

Sets the define option before reading the first SystemVerilog file. The *define* argument might consist of a single value or a space-delimited list of values enclosed within braces.

#### **-3.1a | -05 | -09 | -12**

Specifies the standard to use for language interpretation. The default is *-12*, which specifies the IEEE Standard 1800-2012. Note that setting the *hdlin\_sv\_packages* variable to "none" specifies the "3.1a" standard.

#### **-extra\_library\_cells *cell\_list***

Specifies the list of design names(may be unused) to be elaborated. If called before *set\_top*, the cells in *cell\_list* will be elaborated during the subsequent *set\_top* command even if they are not included in the top design hierarchy. This is in addition to the normal behavior of *read\_verilog*. If the cells in *cell\_list* already exist then they will be overwritten, which is the current behavior of *read\_sverilog*. If called after *set\_top* in setup mode, or anytime in match or verify mode, the cells in *cell\_list* (and only those designs) will be elaborated as part of the *read\_sverilog* command. If the library already exists, it will only be possible to add designs to it; that is, it will only be possible to elaborate designs that have not previously been elaborated. It will not be possible to overwrite any existing design. Attempting to overwrite an existing design will result in an error message.

#### ***file\_list***

Specifies one or more SystemVerilog files to read.

---

## DESCRIPTION

Use this command to read one or more SystemVerilog files. Designs are read into design libraries, and Verilog library cell descriptions are read in as technology libraries. By default, the tool places designs into the default design library named *WORK*, and cell descriptions into the default technology library named *TECH\_WORK*. The command, by default, detects if files are in compressed gzip format and reads them.

If a specified library does not exist, the tool creates it. If the library exists, it overwrites the existing designs or cell descriptions with the designs or cell descriptions that are read. Designs linked to any overwritten designs are unlinked.

The following list describes how to use the **read\_sverilog** command.

- **Reading designs into a specific container** - To read designs into a specific container, do not use the *-technology\_library* option. Instead use the *-r*, *-i*, or *-container* options. If the specified container does not exist, the tool creates the container and sets it as the current container. The syntax to use the command is:

```
read_sverilog -container c_name file
```

- **Reading unshared technology libraries** - To read a technology library into a specific container, use the *-technology\_library* option and the *-r*, *-i*, or *-container* options. If the specified container does not exist, the tool creates the container and sets it as the current container. The syntax to use the command is:

```
read_sverilog -technology_library -container c_name tech_file
```

- **Renaming a technology library** - To rename a technology library, specify the *-libname*, or the *-work\_library*, and *-technology\_library* options along with the *-r*, *-i*, or *-container* options. By default, the command reads cell descriptions into the default technology library named *TECH\_WORK*. The syntax to use the command is:

```
read_sverilog -technology_library -r -libname my_tech_lib tech_lib
```

- **Renaming a design library** - To rename a design library, specify the *-libname* or *-work\_library* option and do not use the *-technology\_library* option. By default, the command reads designs into the default design library named *WORK*. The syntax to use the command is:

```
read_sverilog -libname my_design_lib file
```

- **VCS options** - The **read\_sverilog** command supports some VCS options: *-v*, *-y*, *-f*, *-liblist* (Only with simulation setup file), *+define*, *+libext* and *+incdir*. Some VCS options are irrelevant, therefore recognized but ignored: *-P* and all the other '+' options. The syntax of the command is:

```
read_sverilog -vcs "VCS options"
read_sverilog -f VCS_option_file
read_sverilog -F VCS_option_file
```

#### Special Behavior in the Library Verification Mode:

The *library\_verification* command preprocesses all Verilog library cells into specified container. The container library names are handled internally by the tool. The only options that are valid in the library verification mode are *-r*, *-i*, and *-technology\_library*.

```
fm_shell> read_sverilog -r vlg_cells.v
Loading verilog file 'vlg_cells.v'
Preprocessing library 'vlg_cells.v' ...
Total cells found: 5
1
```

---

## EXAMPLES

This example reads a SystemVerilog design into the Formality environment. In this case, the *-container* option creates the container *ref*. The design files are read into a default design library named *WORK*, and the newly created container is established as the current container.

```
fm_shell> read_sverilog -c ref p0.sv
Loading verilog file '/u/formality/designs/p0.sv'
No target library specified, default is WORK
Created container 'ref'
Current container set to 'ref'
1
fm_shell> report_design_libraries

Number of
Designs   Design Library
-----
1         ref:/WORK
1
fm_shell>
```

This example reads a SystemVerilog design into the current container. Here, the *-libname* option renames the design library to *my\_lib*.

```
fm_shell> read_sverilog -libname my_lib p0.sv
Loading verilog file '/u/formality/designs/p0.sv'
1
fm_shell> report_design_libraries -short
Number of
Designs    Design Library
-----
1          ref:/my_lib
1
fm_shell>
```

This example reads a technology library into container 'ref'.

```
fm_shell (setup)> read_sverilog -technology_library -container ref lib.v
Loading verilog file '/u/formality/libraries/lib.v '
No target library specified, default is TECH_WORK
Created container 'ref'
Current container set to 'ref'
1
fm_shell (setup)> report_libraries -short

Number of
Cells    Shared    Technology Library
-----
83       Yes     GTECH

83       Yes     i:/GTECH

83       Yes     r:/GTECH

83       Yes     ref:/GTECH
1        No     ref:/TECH_WORK

1

fm_shell> create_container impl
Created container 'impl'
Current container set to 'impl'
1
fm_shell> report_libraries -short
Number of
Cells    Shared    Technology Library
-----
1        Yes     TECH_WORK
79       Yes     gtech

1        Yes     impl:/TECH_WORK
79       Yes     impl:/gtech
1        Yes     ref:/TECH_WORK
79       Yes     ref:/gtech
1
fm_shell>
```

---

## SEE ALSO

```
read_verilog(2)
report_designs(2)
report_design_libraries(2)
report_libraries(2)
set_simulation_setup_file(2)
```

---

## read\_verilog

Reads one or more Verilog files.

---

### SYNTAX

```
status read_verilog
[ -container container_name | -r | -i ]
[ -libname libname ]
[ -work_library libname ]
[ -netlist ]
[ -uses design_libs_list ]
[ -L design_libs_list ]
[ -technology_library ]
[ -f VCS_option_file ]
[ -F VCS_option_file ]
[ -vcs "VCS options" ]
[ -define define ]
[ -95 | -01 | -05 ]
[ -extra_library_cells cell_list ]
[ filenames ]
```

#### Data Types

```
container_name string
libname string
VCS_option_file string
"VCS options" string
define string
design_list string
filenames string
```

---

### ARGUMENTS

#### **-container *container\_name***

Specifies the container into which the Verilog designs or cell descriptions are read. The specified container is set as the current container.

#### **-r**

Sets the default reference container as the current container and reads the Verilog designs or cell descriptions into it.

#### **-i**

Sets the default implementation container as the current container and reads the Verilog designs or cell descriptions into it.

#### **-libname *libname***

Names the design library or technology library into which Verilog designs or cell descriptions are read. You can specify any alphanumeric string for the *libname* argument.

#### **-work\_library *library\_name***

Same behavior as the *-libname* option.

#### **-netlist**

Identifies the file as a Verilog structural netlist. This option can reduce the time required to read the file. Use the -95 or the -01 options to select the IEEE Standard Verilog.

#### **-uses *design\_libs\_list***

The list of libraries used to find the references if Formality could not resolve the reference from working library. Libraries from -uses liblist are used only if parent library doesn't have searched design. If the design is not found in library list of **-uses**, search is continued using default search order.

#### **-L *design\_libs\_list***

The list of libraries used to find the references. Libraries from -L liblist are used even if parent library does have design/interface. If the reference is not found in library list of **-L**, search is canceled and error message is issued.

#### **-technology *library***

Specifies that the file that is read in is a technology library. When you use this option, specify a container by using the *-r*, *-i*, or *-container* options.

#### **-f *VCS\_option\_file***

Specifies that the file is a VCS option file, which contains VCS options or Verilog files.

#### **-F *VCS\_option\_file***

Same as the -f option but allows you to specify a path to the file and the source files listed in the file do not have to be absolute pathnames.

#### **-vcs *VCS options***

Specifies that the string enclosed within quotation marks is VCS options or Verilog files.

#### **-define *define***

Sets the define option before reading the first Verilog file. The *define* argument might consist of a single value or a space-delimited list of values enclosed within braces.

#### **-95 | -01 | -05**

Specifies the IEEE standard to use for language interpretation. The default is -05, which specifies the IEEE 1364-2005. Use only the -95 and -01 options with the *-netlist* option. You can set the **hdlin\_vrlg\_std** variable to 1995, 2001, or 2005 to establish the Verilog language interpretation.

#### **-extra\_library\_cells *cell\_list***

Specifies the list of design names (may be unused) to be elaborated. If called before *set\_top*, the cells in *cell\_list* will be elaborated during the subsequent *set\_top* command even if they are not included in the top design hierarchy. This is in addition to the normal behavior of *read\_verilog*. If the cells in *cell\_list* already exist then they will be overwritten, which is the current behavior of *read\_verilog*. If called after *set\_top* in setup mode, or anytime in match or verify mode, the cells in *cell\_list* (and only those designs) will be elaborated as part of the *read\_verilog* command. If the library already exists, it will only be possible to add designs to it; that is, it will only be possible to elaborate designs that have not previously been elaborated. It will not be possible to overwrite any existing design. Attempting to overwrite an existing design will result in an error message.

#### ***file\_list***

Specifies one or more Verilog files to read.

---

## DESCRIPTION

Use this command to read one or more Verilog files. Designs are read into design libraries, and Verilog library cell descriptions are read in as technology libraries. By default, the tool places designs into the default design library named *WORK*, and cell descriptions into the default technology library named *TECH\_WORK*. The command, by default, detects if files are in compressed gzip format and reads them.

If a specified library does not exist, the tool creates it. If the library exists, it overwrites the existing designs or cell descriptions with the designs or cell descriptions that are read. Designs linked to any overwritten designs are unlinked.

If a Verilog file contains a structural netlist without the RTL source, use the `-netlist` option, which identifies the file as a Verilog structural netlist. This reduces the time required to read the file.

The following list describes how to use the **read\_verilog** command.

- **Reading designs into a specific container** To read designs into a specific container, use the **read\_verilog** command. Do not use the `-technology_library` option, instead use the `-r`, `-i`, or `-container` options. If the specified container does not exist, the tool creates the container and sets it as the current container. The syntax to use the command is:

```
read_verilog -container c_name file
```

- **Reading designs in Verilog structural netlist format** To read designs in Verilog structural netlist format, use the `-netlist` option. If the specified container does not exist, the tool reports an error. The syntax to use the command is:

```
read_verilog -netlist
```

- **Reading unshared technology libraries** To read a technology library into a specific container, use the `-technology_library` option and the `-r`, `-i`, or `-container` options. If the specified container does not exist, the tool creates the container and sets it as the current container. The syntax to use the command is:

```
read_verilog -technology_library -container c_name cells.v
```

- **Renaming a technology library** To rename a technology library, specify the `-libname`, or the `-work_library`, and `-technology_library` options along with the `-r`, `-i`, or `-container` options. By default, the command reads cell descriptions into the default technology library named `TECH_WORK`. The syntax to use the command is:

```
read_verilog -technology_library -r -libname my_tech_lib cells.v
```

- **Renaming a design library** To rename a design library, specify the `-libname` or `-work_library` option and do not use the `-technology_library` option. By default, the command reads designs into the default design library named `WORK`. The syntax to use the command is:

```
read_verilog -libname my_design_lib file
```

- **VCS options** The **read\_verilog** command supports some VCS options: `-v`, `-y`, `-f`, `-liblist` (Only with simulation setup file), `+define`, `+libext` and `+incdir`. Some VCS options are irrelevant, therefore recognized but ignored: `-P` and all the other '+' options. The syntax of the command is:

```
read_verilog -vcs "VCS options"
read_verilog -f VCS_option_file
read_verilog -F VCS_option_file
```

#### Special Behavior in the Library Verification Mode:

The `library_verification` command preprocesses all Verilog library cells into specified container. The container library names are handled internally by the tool. The only options that are valid in the library verification mode are `-r`, `-i`, and `-technology_library`.

```
fm_shell> read_verilog -r vlg_cells.v
Loading verilog file 'vlg_cells.v'
Preprocessing library 'vlg_cells.v' ...
Total cells found: 5
1
```

## EXAMPLES

This example reads a Verilog design into the Formality environment. In this case, the `-container` option creates the container `ref`. The design files are read into a default design library named `WORK`, and the newly created container is established as the current container.

```
fm_shell> read_verilog -container ref p0.v
Loading verilog file '/u/formality/designs/p0.v'
No target library specified, default is WORK
```

```
Created container 'ref'
Current container set to 'ref'
1
fm_shell> report_design_libraries

Number of
Designs   Design Library
-----
1         ref:/WORK
1
fm_shell>
```

This example reads a Verilog design into the current container. Here, the *-libname* option renames the design library to *my\_lib*.

```
fm_shell> read_verilog -libname my_lib p0.v
Loading verilog file '/u/formality/designs/p0.v'
1
fm_shell> report_design_libraries -short
Number of
Designs   Design Library
-----
1         ref:/my_lib
1
fm_shell>
```

This example reads a technology library into container 'ref'.

```
fm_shell (setup)> read_verilog -technology_library -container ref lib.v
Loading verilog file '/u/formality/libraries/lib.v'
No target library specified, default is TECH_WORK
Created container 'ref'
Current container set to 'ref'
1
fm_shell (setup)> report_libraries -short

Number of
Cells   Shared   Technology Library
-----
83      Yes     GTECH

83      Yes     i:/GTECH

83      Yes     r:/GTECH

83      Yes     ref:/GTECH
1       No     ref:/TECH_WORK
1
```

```
This example reads a design and libraries using the -vcs option.
fm_shell (setup)> read_verilog -i ./netlist/design.v -vcs "-v newDFF.v
-y ./libs/lib1 -y ./libs/lib2 +libext+.v"
Loading verilog file '/u/formality/netlist/design.v'
No target library specified, default is WORK
Current container set to 'i'
1
```

SEE ALSO

- read\_sverilog(2)
- report\_designs(2)
- report\_design\_libraries(2)
- report\_libraries(2)
- set\_simulation\_setup\_file(2)

---

## read\_vhdl

Reads one or more VHDL files into the Formality environment.

---

### SYNTAX

```
read_vhdl  
[ -container container_name | -r | -i ]  
[ -libname libname ]  
[ -work_library libname ]  
[ -technology_library ]  
[ -87 | -93 | -2008 ]  
file_names
```

#### Data Types

```
container_name string  
libname string  
file_names string
```

---

### ARGUMENTS

#### **-container *container\_name***

Specifies the container into which VHDL designs or cell descriptions are read.

#### **-r**

Reads VHDL designs or cell descriptions into the default reference container.

#### **-i**

Reads VHDL designs or cell descriptions into the default implementation container.

#### **-libname *libname***

Specifies the design library or technology library into which VHDL designs or cell descriptions are read.

#### **-work\_library *libname***

Same behavior as the *-libname* option.

#### **-technology\_library**

Identifies the file as a technology library. This option must be used with the *-r*, *-i*, or *-container* options.

#### **-87 | -93 | -2008**

Specifies the IEEE standard to use for language interpretation. The *hdlin\_vhdl\_std* variable defines the current default.

#### ***file\_list***

Specifies one or more VHDL files.



## DESCRIPTION

This command reads one or more VHDL files into a container and sets the container as the current container. Designs are read into design libraries and library cell descriptions are read into technology libraries. If you do not specify the design or technology library, the command by default names the design library *WORK* and the default technology library *TECH\_WORK*.

If the specified library name does not exist, the command creates a new library. If the specified library exists in the destination container, the command overwrites existing designs or cell descriptions. Designs linked to any overwritten designs become unlinked.

The following list shows how to use the command.

- Reading designs into a specific container To read designs into a specific container, use the *-r*, *-i*, or *-container* options. Do not specify the *-technology\_library* option. If you use the *-container* option and the container does not exist, the command creates the container and establishes it as the current container. The syntax to use the command is:

```
read_vhdl -container c_name file
```

- Reading unshared technology libraries To read a technology library into a specific container, use the *-technology\_library* option and the *-r*, *-i*, or *-container* options. If the container does not exist, the command creates the container and establishes it as the current container. The syntax to use the command is:

```
read_vhdl -technology_library tech_file -container c_name tech_file
```

- Renaming a technology library To rename a technology library, specify the *-libname*, or *-work\_library*, and the *-technology\_library* options along with the *-r*, *-i*, or *-container* option. By default, the command reads into the default *TECH\_WORK* technology library. The syntax to use the command is:

```
read_vhdl -technology_library tech_file -r -libname my_tech_lib tech_file
```

- Renaming a design library To rename a design library, use the *-libname*, or *-work\_library*, option and omit the *-technology\_library* option. By default, the command reads designs into the default *WORK* design library. The syntax to use the command is:

```
read_vhdl -libname my_design_lib file
```

- Reading a design with VHDL-87 or VHDL-93 By default the command reads VHDL files as specified by the **hdlin\_vhdl\_std** variable. The default for this variable is *2008*. You can override the current variable setting by using the **read\_vhdl** *-87* or *-93* command.

The **read\_vhdl** command returns one of the following:

- 0 to indicate failure
- 1 to indicate success

---

## EXAMPLES

The following example reads a VHDL design into the Formality environment. The *-container* option creates a container names *ref*. The tool reads the design files into the *WORK* design library and establishes the new container as the current container.

```
fm_shell> read_vhdl -container ref des_1.vhd
Loading vhd file '/u/designs/des_1.vhd'
No target library specified, default is WORK
1
fm_shell>
```

The following example reads a VHDL design into the current container. The *-libname* option renames the design library *my\_lib*.

```
fm_shell> read_vhdl -libname my_lib des_1.vhd
Loading vhd file '/u/designs/des_1.vhd'
1
fm_shell>
```

The following example reads a shared technology library into all containers. The technology library is automatically loaded into

subsequent new containers.

```
fm_shell> read_vhdl -technology_library des_lib.vhd  
Loading vhdI file '/u/designs/des_lib.vhd'  
No target library specified, default is TECH_WORK  
1  
fm_shell>
```

---

## SEE ALSO

report\_designs(2)  
report\_design\_libraries(2)  
report\_libraries(2)  
hdlin\_vhdl\_std(3)

---

## record\_edits

Records edit commands.

---

### SYNTAX

**record\_edits**  
[ *-on* | *-off* ]

#### Enabled Shell Modes

Setup  
Match  
Verify

---

### ARGUMENTS

#### ***-on***

Turns recording of edit commands on.

#### ***-off***

Turns recording of edits commands off.

---

### DESCRIPTION

This command is used to control the recording of edit commands (**create\_net**, **disconnect\_net**, ...). Recording is on by default when Formality starts.

Called without an argument, the command turns recording on.

Use the **write\_edits** command to write the recorded edit commands to a file.

---

### SEE ALSO

create\_net(2)  
disconnect\_net(2)  
report\_edits(2)  
write\_edits(2)

---

## redirect

Redirects the output of a command to a file.

---

### SYNTAX

```
string redirect  
  [-append]  
  [-tee]  
  [-file | -variable]  
  target  
  { command_string }
```

#### Data Types

*target*  
*command\_string*

---

### ARGUMENTS

#### -append

Appends the output to the specified target file.

#### -tee

Like the unix command of the same name, sends output to the current output channel as well as to the *target*.

#### -file

Indicates that *target* is a file name, and redirection is to that file. This is the default. It is exclusive of *-variable*.

#### -variable

Indicates that *target* is a variable name, and redirection is to that Tcl variable. It is exclusive of *-file*.

#### *target*

Indicates the target of the output redirection. If redirecting to a file, this is the file name. If redirecting to a Tcl variable, this is the variable name.

#### *command\_string*

The command to execute. Intermediate output from this command, as well as the result of the command, will be redirected to *target*. The *command\_string* should be rigidly quoted with curly braces.

---

### DESCRIPTION

This command performs the same function as the traditional unix-style redirection operators `>` and `>>`. The *command\_string* must be rigidly quoted (that is, enclosed in curly braces) in order for the operation to succeed. It must not be constructed as a nested command.

Output is redirected to a file by default. Output can be redirected to a Tcl variable by using the *-variable* option.

Output can be channeled to the current output device as well as the redirect target by using the *-tee* option. See the examples section for an example.

The result of a **redirect** command which does not generate a Tcl error is the empty string. Screen output occurs only if errors occurred during execution of the *command\_string* (other than opening the redirect file). When errors occur, a summary message is output. See the examples.

Although the result of a successful **redirect** command is the empty string, it is still possible to get and use the result of the command that you redirected. Construct a **set** command in which you set a variable to the result of your command. Then, redirect the **set** command. The variable holds the result of your command. See the examples.

The **redirect** command is much more flexible than traditional unix redirection operators. With **redirect**, you can redirect multiple commands or an entire script. See the examples for an example of how to construct such a command.

Note that the builtin Tcl command **puts** does not respond to output redirection of any kind. Use the builtin **echo** command instead.

---

## EXAMPLES

In the following example, the output of the plus procedure is redirected. The echoed string and the result of the plus operation is in the output file. Notice that the result was not echoed to the screen.

```
prompt> proc plus {a b} {echo "In plus" ; return [expr $a + $b]}
prompt> redirect p.out {plus 12 13}
prompt> exec cat p.out
In plus
25
```

In this example, a typo in the command created an error condition. The error message indicates that you can use **error\_info** to trace the error, but you should first check the output file.

```
prompt> redirect p.out {plus2 12 13}
Error: Errors detected during redirect
      Use error_info for more info. (CMD-013)
prompt> exec cat p.out
Error: unknown command 'plus2' (CMD-005)
```

In this example, we explore the usage of results from redirected commands. Since the result of **redirect** for a command which does not generate a Tcl error is the empty string, use the **set** command to trap the result of the command. For example, assume that there is a command to read a file which has a result of "1" if it succeeds, and "0" if it fails. If you redirect only the command, there is no way to know if it succeeded.

```
redirect p.out { read_a_file "a.txt" }
# Now what? How can I redirect and use the result?
```

But if you set a variable to the result, then it is possible to use that result in a conditional expression, etc.

```
redirect p.out { set rres [read_a_file "a.txt"] }
if { $rres == 1 } {
  echo "Read ok!"
}
```

The **redirect** command is not limited to redirection of a single command. You can redirect entire blocks of a script with a single **redirect** command. This simple example with **echo** demonstrates this feature:

```
prompt> redirect p.out {  
?   echo -n "Hello "  
?   echo "world"  
?   }  
prompt> exec cat p.out  
Hello world  
prompt>
```

The **redirect** command allows you to tee output to the previous output device and also to redirect output to a variable. This simple example with **echo** demonstrates these features:

```
prompt> set y "This is "  
This is  
prompt> redirect -tee x.out {  
    echo XXX  
    redirect -variable y -append {  
        echo YYY  
        redirect -tee -variable z {  
            echo ZZZ  
        }  
    }  
}  
XXX  
prompt> exec cat x.out  
XXX  
prompt> echo $y  
This is YYY  
ZZZ  
  
prompt> echo $z  
ZZZ
```

---

## SEE ALSO

[echo\(2\)](#)  
[error\\_info\(2\)](#)  
[set\(2\)](#)

---

## remodel

Modify the contents of techlib cells referred to by given cells.

---

### SYNTAX

```
remodel  
-type remodel_type  
[-mbit_separator mbit_separator]  
[-mbit_pattern mbit_pattern]  
cell_ID
```

---

### ENABLED SHELL MODES

Setup

---

### ARGUMENTS

**-type *remodel\_type***

The type of remodeling to perform: **seq2buffer** or **inv2buffer**.

**-mbit\_separator *mbit\_separator***

A string specifying the separator that appears between bit names in a multibit bank cell name.

**-mbit\_pattern *mbit\_pattern***

A glob-style pattern that matches portions of a multibit bank cell name, so as to specify which bits of a multibit bank cell are to be modified.

***cell\_ID***

A collection of cells, or a glob-style pattern specifying the cells to change. The cells must refer to tech lib cells.

---

### DESCRIPTION

This command makes modified copies of techlib cells referred to by given cells. The modification either replaces a SEQ with a buffer (**-type seq2buffer**), or replaces an inverter with a buffer (**-type inv2buffer**). Specifically: The techlib cell referred to by the cell is copied (where the copied techlib cell has the same name as the original, plus a postfix), the copied techlib cell is modified, and the cell is linked to the copied techlib cell. If another cell is remodeled and the cell refers to the same original techlib cell, the existing copied techlib cell is reused.

For **-type seq2buffer** the modification consists of replacing the single SEQ in the techlib cell with a buffer. For **-type inv2buffer** the modification consists of replacing the single inverter in the techlib cell with a buffer.

Multibit bank cells can be modified with **-type seq2buffer** using the **-mbit\_separator** and **-mbit\_pattern** options. These are used together to specify which bits of a bank cell are to be modified. The **cell-ID** is still used to specify which cells are to be modified. Then, for each such cell, the full cell name is split into bit names using the **-mbit\_separator** string, and then for each bit name that matches the **-mbit\_pattern**, that bit in the copied techlib cell is modified.

When a register is modified using **-type seq2buffer**, any scan logic associated with the register is disabled and removed in the modified techlib cell.

---

## EXAMPLES

This example shows seq2buffer remodeling for all cells named U\* in design top:

```
fm_shell (setup)> remodel -type seq2buffer i:/WORK/top/U*  
Remodeled 5 instances, using 2 remodeled techlib cells
```

This example shows seq2buffer remodeling for two bits of multibit bank cells named R\* in the current design, where cell names are formed with bits named "R<digit>" separated by "\_X\_" (e.g., "R0\_X\_R1\_X\_R2\_X\_R3", for which **-mbit\_pattern R{0,2}** matches "R0" and "R2"):

```
fm_shell (setup)> remodel -type seq2buffer -mbit_separator _X_ -mbit_pattern R{0,2} R*  
Remodeled 1 instances, using 1 remodeled techlib cells
```

This example shows inv2buffer remodeling for all cells whose name matches INV\* in any design in the WORK library:

```
fm_shell (setup)> remodel -type inv2buffer i:/WORK/*/INV*  
Remodeled 100 instances, using 5 remodeled techlib cells
```

---

## SEE ALSO

report\_remodel(2)



---

## remove\_black\_box

Removes user-defined black boxes.

---

### SYNTAX

```
remove_black_box  
[ object_list ]  
[ -attribute attribute_name ]  
-all
```

#### Data Types

```
object_list string  
attribute_name string
```

---

### ENABLED SHELL MODES

Setup

---

### ARGUMENTS

#### *object\_list*

Removes black boxes from the specified designs or cells.

#### -all

Removes black boxes from all designs and cells in the Formality environment.

#### -attribute *attribute\_name*

Removes black boxes from all designs that have the specified attribute.

---

### DESCRIPTION

This command removes black boxes that are set by using the **set\_black\_box** command.

You can remove black boxes from all designs or cells from individual designs and cells. To remove black boxes from all designs and cells, use the *-all* option or do not specify any arguments. For specific designs, use one or more object lists.

The **remove\_black\_box** command returns one of the following:

- 0 to indicate failure
- 1 to indicate success

---

## EXAMPLES

The first example removes a black box from the design named *lower*. The second example removes a black box from the cell named *inst1* in the top module *top*.

```
fm_shell (setup)> remove_black_box rtl:/WORK/lower
Removed user-defined black box on 'rtl:/WORK/lower'
1
fm_shell (setup)> remove_black_box rtl:/WORK/top/inst1
Removed user-defined black box on 'rtl:/WORK/top/inst1'
1
fm_shell (setup)>
```

The following example removes all user-defined black boxes from all designs and cells in the Formality environment.

```
fm_shell (setup)> remove_black_box -all
Removed all user-defined black boxes
1
fm_shell (setup)>
```

---

## SEE ALSO

```
report_black_box(2)
set_black_box(2)
```

---

## remove\_cell

Removes cells.

---

### SYNTAX

```
status remove_cell  
  cell_list  
  -all
```

#### Data Types

*cell\_list* list

---

### RETURN VALUE

The **remove\_cell** command returns a status of 1 if it was successful and 0 if it failed.

---

### ARGUMENTS

#### *cell\_list*

Specifies the names of cells to remove. You can use either object IDs or instance-based paths.

Cells are removed from all instances of a design. If you want to only affect a particular instance-based path, you must uniquify that instance of the design first.

You must specify either the *cell\_list* or *-all*.

#### *-all*

Removes all cells in the current design or instance.

You must specify either the *cell\_list* or *-all*.

---

### DESCRIPTION

This command removes the cells that are specified using the *cell\_list* argument, or all cells in the current design or instance if the *-all* option is used.

This command disconnects nets that are connected to pins on the cells that are removed.

You can create cells using the **create\_cell** and **create\_primitive** commands.

Outside of Setup mode, this command only works on edit designs created using the **edit\_design** command.

---

## EXAMPLES

The following example removes two cells *box1* and *box2* in the design *r:/WORK/mid*.

```
fm_shell (setup)> current_design r:/WORK/mid  
fm_shell (setup)> remove_cell {box1 box2}
```

The following example removes cell *box3* from all instances of the design of *r:/WORK/top/m1/b1*.

```
fm_shell (setup)> current_instance r:/WORK/top/m1/b1  
fm_shell (setup)> remove_cell box3
```

---

## SEE ALSO

- `create_cell(2)`
- `create_primitive(2)`
- `current_design(2)`
- `current_instance(2)`
- `edit_design(2)`

---

## remove\_cell\_type

Removes the cell type that was set on a technology library cell or collection of cells

---

### SYNTAX

```
remove_cell_type  
[ design_list ]  
-all
```

#### Data Types

*design\_list* string

---

### ENABLED SHELL MODES

Setup

---

### ARGUMENTS

#### *object\_list*

Specifies a tech-lib cell whose cell-type value needs to be removed. It is the string name of exactly onetech-lib cell or a collection of one or more cells.

#### -all

Removes the cell-type from all user specified cell-types in tech-lib cells

---

### DESCRIPTION

Removes the cell type associated with the technology library cell or a collection of one or more cells.

---

### EXAMPLES

The first example removes the cell-type lssd from the design \fr:/LIBNAME/lower.

```
fm_shell (setup)> remove_cell_type r:/LIBNAME/cellname  
r:/LIBNAME/cellname: Removed as LSSD  
1  
fm_shell (setup)>
```

The first example removes the cell-type retention from the design \fr:/LIBNAME/lower.

```
fm_shell (setup)> remove_cell_type r:/LIBNAME/cellname  
r:/LIBNAME/cellname: Removed as RETENTION  
1  
fm_shell (setup)>
```

The following example removes all user-defined cell-types from the tech-lib cells .

```
fm_shell (setup)> remove_cell_type -all  
1  
fm_shell (setup)>
```

---

## SEE ALSO

```
report_cell_type(2)  
set_cell_type(2)
```

---

## remove\_checkpoint\_report\_commands

Removes reports associated with a specific checkpoint.

---

### SYNTAX

```
remove_checkpoint_report_commands  
[ID]  
[-all]
```

#### Data Types

ID string

---

### ARGUMENTS

#### ID

Identifies the target checkpoint with reports.

#### -all

Causes all setup to be removed.

---

### DESCRIPTION

Removes any reports to be executed after a specific checkpoint finishes verification.

If -all is specified, reports are removed for all checkpoints.

---

### EXAMPLES

Checkpoints may be identified with their guide number, their checkpoint number or their name. For example, assume that SVF guide #123 is a logic\_opt checkpoint, and is the first logic\_opt and second overall checkpoint in the SVF. The possible IDs for this checkpoint are

```
123          (Guide number)  
ckpt2        (Checkpoint number)  
ckpt_logic_opt (Checkpoint name)
```

This example removes the reports for the first checkpoint  
fm\_shell (setup)> **remove\_checkpoint\_report\_commands ckpt1**  
Info: Checkpoint reports for ckpt\_pre\_map have been removed.

1

This example removes the reports for all checkpoints

```
fm_shell (setup)> remove_checkpoint_report_commands -all
```

Info: All checkpoint reports have been removed.

1

---

## SEE ALSO

`report_checkpoint_report_commands(2)`

`set_checkpoint_report_commands(2)`



---

## remove\_checkpoint\_setup\_commands

Removes commands associated with a specific checkpoint.

---

### SYNTAX

```
remove_checkpoint_setup_commands  
[ID]  
[-all]
```

#### Data Types

ID string

---

### ARGUMENTS

#### ID

Identifies the target checkpoint needing setup.

#### -all

Causes all setup to be removed.

---

### DESCRIPTION

Removes any commands to be executed before a specific checkpoint begins preverification.

If -all is specified, setup is removed for all IDs.

---

### EXAMPLES

Checkpoints may be identified with their guide number, their checkpoint number or their name. For example, assume that SVF guide #123 is a logic\_opt checkpoint, and is the first logic\_opt and second overall checkpoint in the SVF. The possible IDs for this checkpoint are

```
123          (Guide number)  
ckpt2        (Checkpoint number)  
ckpt_logic_opt (Checkpoint name)
```

This example removes the setup for the first checkpoint  
fm\_shell (setup)> **remove\_checkpoint\_setup\_commands ckpt1**  
Info: Checkpoint setup for ckpt\_pre\_map has been removed.

1

This example removes the setup for all checkpoints

```
fm_shell (setup)> remove_checkpoint_setup_commands -all
```

Info: All checkpoint setup has been removed.

1

---

## SEE ALSO

`set_checkpoint_setup_commands(2)`

`report_checkpoint_setup_commands(2)`

---

## remove\_clock

Removes clocks that are created by using the **set\_clock** command.

---

### SYNTAX

**remove\_clock**  
*netID* | -all

#### Data Types

*netID* string

---

### ENABLED SHELL MODES

Setup

---

### ARGUMENTS

*netID*

Specifies a list of clocks to remove. If you specify a name consisting of a regular expression that resolves to more than one net, the operation is applied to the matching nets.

**-all**

Removes all clocks from the current design.

---

### DESCRIPTION

This command removes user-specified clocks that are created by using the **set\_clock** command.

Specify either a clock name or the *-all* option.

---

### EXAMPLES

```
fm_shell (setup)> remove_clock HDL:/WORK/CORE/SCLK
Removed clock from 'HDL:/WORK/CORE/SCLK'
1
fm_shell (setup)> remove_clock -all
Removed all user-defined clocks
1
```

---

## SEE ALSO

`report_clocks(2)`  
`set_clock(2)`

---

## remove\_command\_hook

Remove hook from command execution

---

### SYNTAX

```
string remove_command_hook -before name  
-after name  
-replace name  
commandName
```

```
string name  
string commandName
```

---

### ARGUMENTS

#### **-before *name***

Remove the before hook named *name*

#### **-after *name***

Remove the after hook named *name*

#### **-replace *name***

Remove the replace hook named *name*

#### ***commandName***

Command to update

---

### DESCRIPTION

The **remove\_command\_hook** removes a hook previously added to a command. When a hook is created via the **add\_command\_hook** the name of the hook is returned. Use that name to remove the hook. The `get_command_hooks` command can also be used to determine the name of each registered hook.

---

### EXAMPLES

```
prompt> remove_command_hook place_opt -before before0
```

---

### SEE ALSO

```
add_command_hook(2)
get_current_hook_command(2)
get_command_hooks(2)
```

---

## remove\_compare\_rules

Removes all user-defined compare rules.

---

### SYNTAX

**remove\_compare\_rules**  
[ *designID* ]

#### Data Types

*designID* string

---

### ARGUMENTS

#### *designID*

Specifies the design from which to remove the user-defined compare rules.

---

### DESCRIPTION

Use this command to remove all previously defined name matching rules, or compare rules, from a specified design. For more information about compare rules, see the *Formality User Guide*.

If you do not specify a value for the *designID* argument, the command removes compare rules from the current design. If you specify a design ID that has no compare rules, the command issues a warning message.

The **remove\_compare\_rules** command returns one of the following:

- 0 to indicate failure
- 1 to indicate success

---

### EXAMPLES

This example removes all compare rules in the ff.async.reset design, in the current container.

```
fm_shell> remove_compare_rules ff.async.reset
1
fm_shell>
```

This example removes all compare rules in the current design.

```
fm_shell> remove_compare_rules
1
fm_shell>
```

---

## SEE ALSO

`report_compare_rules(2)`  
`set_compare_rule(2)`



---

## remove\_constant

Removes the user-defined constants specified by the **set\_constants** command.

---

### SYNTAX

#### **remove\_constant**

-all | *objectID*  
[-type *type*]

#### Data Types

*objectID* string  
*type* string

#### Enabled Shell Modes

Setup

---

### ARGUMENTS

#### **-all**

Removes all user-defined constants from designs in the Formality environment.

#### ***objectID***

Specifies the design object constant you want to remove. If you specify a name consisting of a regular expression that resolves to more than one object, the operation is applied to all matching objects, if the name resolves to multiple objects with identical names and you do not specify the object type, only one of these objects is affected. The order of precedence is pin, port, net, cell.

#### **-type *type***

Specifies the object type of the specified object ID. Use this option if the name of the specified design object is associated with more than one object type within the same design. Specify one of the following values for the *type* argument:

- *pin* specifies pin type
  - *port* specifies port type
  - *net* specifies net type
  - *cell* specifies cell type
- 

### DESCRIPTION

This command removes the specified constants that are specified by the **set\_constant** command.

To remove a constant from a specific design object, specify the *objectID*. If the design object is located in the current design and container, you do not have to specify the container and design information.

When design objects of different types have the same name within a design, use the **-type** option.

Use the **report\_constants** command to report the ports and nets that are defined as constants.

The **remove\_constant** command returns one of the following:

- 0 to indicate failure
- 1 to indicate success

---

## EXAMPLES

The following example removes the constant previously set at port CC. The design object is located in the implementation container, the WORK library, and the CORE design.

```
fm_shell (setup)> remove_constant impl:/WORK/CORE/CC
```

```
1
```

```
fm_shell (setup)>
```

The following example removes the constant previously set at net B7. The design also contains a port with the same name, so you must specify the **-type** option. The net is located in the current design.

```
fm_shell (setup)> remove_constant -type net B7
```

```
1
```

```
fm_shell (setup)>
```

---

## SEE ALSO

report\_constants(2)  
set\_constant(2)

---

## remove\_constraint

Removes external constraints from the control points of a design.

---

### SYNTAX

status **remove\_constraint**  
*constraint\_name*

#### Data Types

*constraint\_name* string

---

### ARGUMENTS

*constraint\_name*

Specifies the name of the constraint to remove set by the **set\_constraint** command.

---

### DESCRIPTION

Use this command to remove a specified constraint from the Formality session. Use the **report\_constraint** command to report a list of constraints.

---

### EXAMPLES

This example removes a constraint.

```
fm_shell> set_constraint 0hot {IN1 IN2 IN3 IN4} FM_CONSTRAINT_0
fm_shell> remove_constraint FM_CONSTRAINT_0
1
```

---

### SEE ALSO

create\_constraint\_type(2)  
remove\_constraint\_type(2)  
report\_constraint(2)  
report\_constraint\_type(2)  
set\_constraint(2)

---

## remove\_constraint\_type

Removes the specified external constraint type that is created by using the **create\_constraint\_type** command.

---

### SYNTAX

```
remove_constraint_type  
type_name
```

#### Data Types

*type\_name* string

---

### ARGUMENTS

*type\_name*

Specifies the type of user-specified constraint to remove.

---

### DESCRIPTION

Use this command to remove user-defined external constraint types created by using the **create\_constraint\_type** command. Constraints that are of the removed type are also removed.

Do not use this command to remove predefined constraint types. See the **set\_constraint** command man page for a list of predefined types.

The **remove\_constraint** command returns one of the following:

- 0 to indicate failure
- 1 to indicate success

---

### EXAMPLES

This example removes a constraint type that is used by an existing constraint.

```
fm_shell> set_constraint parity {IN1 IN2 IN3} -map \  
{A=IN1 B=IN2 C=IN3} $ref FM_CONSTRAINT_0
```

```
fm_shell> remove_constraint_type parity  
Information: Constraint 'FM_CONSTRAINT_0' uses type  
'parity' and is being removed. (FM-087)  
1
```

**SEE ALSO**

`create_constraint_type(2)`  
`remove_constraint(2)`  
`report_constraint(2)`  
`report_constraint_type(2)`  
`set_constraint(2)`

---

## remove\_container

Removes the specified container(s) from the Formality environment.

---

### SYNTAX

**remove\_container**  
*container\_list* | -all

#### Data Types

*container\_list* string

---

### ARGUMENTS

#### *container\_list*

Specifies the containers to remove. You can specify one or more containers to remove.

#### -all

Removes all containers in the current session and their contents.

---

### DESCRIPTION

Use this command to remove a specific or all containers.

This command removes all design libraries, technology libraries, and the container. Unsaved information in the container, such as user-defined constants, is also removed. To save the contents of a container use the **write\_container** command.

The **remove\_container** command returns one of the following:

- 0 to indicate failure
- 1 to indicate success

---

### EXAMPLES

The following example removes all the containers in the Formality environment:

```
fm_shell> remove_container -all
Removed container 'impl'
Current design is no longer set
Implementation design is no longer set
Removed container 'ref'
Reference design is no longer set
1
fm_shell> report_containers
```

```
containers:  None
1
fm_shell>
```

---

## SEE ALSO

```
report_containers(2)
report_design_libraries(2)
report_designs(2)
report_hierarchy(2)
report_libraries(2)
```

---

## remove\_cutpoint

Removes cutpoints that are specified by the **set\_cutpoint** command or created by the **create\_cutpoint\_blackbox** command.

---

### SYNTAX

#### **remove\_cutpoint**

*objectID* | -all  
[-type *type*]

#### Data Types

*objectID* string  
*type* string

#### Enabled Shell Modes

Setup

---

### ARGUMENTS

#### ***objectID***

Specifies a list of cutpoints to remove. If you specify a name consisting of a regular expression that resolves to more than one object, the operation is applied to all the matching objects. If the specified name resolves to multiple objects (with identical names and unspecified object type), only one of these objects is affected. The precedence is pin then net.

#### **-all**

Removes all the cutpoints from the current design.

#### **-type *type***

Specifies the object type. Use this option if the name of the specified design object is associated with more than one object type in the same design. Specify one of the following values for the *ID\_type* argument:

- *pin* to specify the pin type
- *net* to specify the net type
- *cell* to specify the cell type

---

### DESCRIPTION

This command removes user-specified cutpoints that are specified by using the **set\_cutpoint** command or created by using the **create\_cutpoint\_blackbox** command.

Specify either a specific cutpoint with the *objectID* argument or use the **-all** option to remove all cutpoints in the current design.



---

## EXAMPLES

```
fm_shell (setup)> remove_cutpoint HDL:/WORK/CORE/MUX_OUT_BLK/UPC_DATA[9]
Removed cutpoint from 'HDL:/WORK/CORE/MUX_OUT_BLK/UPC_DATA[9]'
1
fm_shell (setup)> remove_cutpoint -all
Removed all user-defined cutpoints
1
```

---

## SEE ALSO

```
set_cutpoint(2)
report_cutpoints(2)
create_cutpoint_blackbox(2)
```

---

## remove\_design

Removes the specified designs from the Formality environment.

---

### SYNTAX

#### **remove\_design**

*[-hierarchy]  
[-shared\_lib]  
designID\_list*

#### **Data Types**

*designID\_list* string

#### **Enabled Shell Modes**

Setup

---

### ARGUMENTS

#### **-hierarchy**

Removes all files recursively from hierarchical designs.

#### **-shared\_lib**

Removes designs in the technology libraries.

#### ***designID\_list***

Removes one or more designs from the current container.

---

### DESCRIPTION

This command removes designs from the Formality environment. By default, the tool removes the design from the current container unless you specify a container name as part of the *designID* argument.

You can recursively remove all files in a design's hierarchy by using the *-hierarchy* option. However, this option does not remove designs in the technology libraries.

NOTE: After you successfully run the **set\_top** command on a container, its design can no longer be removed. Use the **set\_black\_box** command instead.

The **remove\_design** command returns one of the following:

- 0 to indicate failure
- 1 to indicate success

---

## EXAMPLES

The following example removes the UPC design from the container named "ref" but does not remove the hierarchical files in it.

```
fm_shell (setup)> remove_design /WORK/UPC
Removed design '/WORK/UPC' from container 'ref'
1
fm_shell (setup)>
```

The following example removes the UPC design as in the preceding example. However, this command uses the *-hierarchy* option, which removes the UPC\_DW01\_add\_12\_0 design as well.

```
fm_shell (setup)> remove_design -hierarchy /WORK/UPC
Removed design '/WORK/UPC' from container 'ref'
Removed design '/WORK/UPC_DW01_add_12_0' from
container 'ref'
1
fm_shell (setup)>
```

---

## SEE ALSO

```
remove_black_box(2)
report_black_boxes(2)
report_designs(2)
set_black_box(2)
```

---

## remove\_design\_library

Removes one or more design libraries from the Formality environment.

---

### SYNTAX

**remove\_design\_library**  
*design\_libraryID\_list* | -all

#### Data Types

*design\_libraryID\_list* string

---

### ARGUMENTS

#### *design\_libraryID\_list*

Removes one or more design libraries from the current container.

#### -all

Removes all design libraries from the current container.

---

### DESCRIPTION

This command removes design libraries from the current container, unless you specify a container name as part of the *designID* argument.

You can remove all design libraries from the current container by using the **-all** option.

NOTE: Remove design libraries from containers before using the **set\_top** command. After you successfully run the **set\_top** command on a container, its design can no longer be removed.

The **remove\_design\_library** command returns one of the following:

- 0 to indicate failure
- 1 to indicate success

---

### EXAMPLES

The following example removes the WORK design library from the default implementation container.

```
fm_shell> remove_design_library WORK
Removed design library 'WORK' from container 'impl'
1
fm_shell>
```

---

## SEE ALSO

`remove_design(2)`  
`report_designs(2)`

---

## remove\_dont\_cut

Removes the dont-cutpoints that are specified using the **set\_dont\_cutpoint** command.

---

### SYNTAX

#### **remove\_dont\_cut**

*objectID* | -all  
[-type *type*]

#### Data Types

*objectID* string  
*type* string

#### Enabled Shell Modes

Setup

---

### ARGUMENTS

#### ***objectID***

Specifies a list of dont-cutpoints to remove. If you specify a name consisting of a regular expression that resolves to more than one object, the operation is applied to all the matching objects. If the specified name resolves to multiple objects with identical names and unspecified object type, only one of these objects is affected. The precedence is pin then net.

#### **-all**

Removes all the dont-cutpoints from the current design.

#### **-type *type***

Specifies the object type. Use this option if the name of the specified design object is associated with more than one object type in the same design. Specify one of the following object types:

- *pin* to specify the pin type
- *net* to specify the net type
- *cell* to specify the cell type

---

### DESCRIPTION

This command removes the dont-cutpoints that are specified using the **set\_dont\_cut** command.

Specify either a specific cutpoint using the **objectID** option or use the **-all** option to remove all cutpoints in the current design.

## EXAMPLES

```
fm_shell (setup)> remove_dont_cut $ref/block/IN  
Removed dont_cut from 'r:/WORK/top/block/IN'  
1  
fm_shell (setup)> remove_dont_cut -all  
Removed all user defined dont_cutpoints  
1
```

---

## SEE ALSO

```
set_dont_cut(2)  
report_dont_cuts(2)
```

---

## remove\_dont\_match\_points

Removes a list of user-specified dont-match points.

---

### SYNTAX

```
integer remove_dont_match_points  
[-type ID_type]  
objectID_list  
[-all]
```

#### Data Types

*ID\_type* string  
*objectID\_list* string

---

### ARGUMENTS

#### **-type *ID\_type***

Identifies the object type of the specified object. Use this option when the name of the specified design object is associated with more than one object type within the same design. Specify one of the following object types.

- **pin** - Specifies the pin type.
- **port** - Specifies the port type.
- **net** - Specifies the net type.
- **cell** - Specifies the cell type.

#### ***objectID\_list***

Removes the dont\_match attribute from the specified design objects. If the specified regular expression resolves to more than one object, the operation is applied to all of the objects. However, if the name resolves to multiple objects with identical names and you do not specify the object type, only one of these objects is affected in the following precedence, pin, port, net, cell.

#### **-all**

Removes the user-specified dont\_match attributes from objects.

---

### DESCRIPTION

This command removes the user-specified dont\_match attributes from specified objects. To enable matching of all user-specified dont-match points, use the **-all** option.

---

### EXAMPLES

remove\_dont\_match\_points



The following example removes a user-defined dont-match point. The port *A\_T33* is in the default implementation container, the *WORK* library, and the *CORE* design.

```
prompt> remove_dont_match_points \  
impl:/WORK/CORE/A_T33
```

The following example is similar to the preceding example except that the **-type** option differentiates the design object from other types having the same name.

```
prompt> remove_dont_match_points \  
-type cell \  
impl:/WORK/CORE/A_T33
```

---

## SEE ALSO

```
report_dont_match_points(2)  
report_matched_points(2)  
report_unmatched_points(2)  
set_dont_match_points(2)
```

---

## remove\_dont\_reverse

Removes the dont-reverse that are specified using the **set\_dont\_reverse** command.

---

### SYNTAX

**remove\_dont\_reverse**  
*objectID* | -all

#### Data Types

*objectID* string

#### Enabled Shell Modes

Setup

---

### ARGUMENTS

#### *objectID*

Specifies a list of dont-reverse cells to remove. If you specify a name consisting of a regular expression that resolves to more than one object, the operation is applied to all the matching objects.

#### **-all**

Removes all the dont-reverse cells from the current design.

---

### DESCRIPTION

This command removes the dont-reverse cells that are specified using the **set\_dont\_reverse** command.

Specify either a specific cell using the **objectID** option or use the **-all** option to remove all dont-reverse cells in the current design.

---

### EXAMPLES

```
fm_shell (setup)> remove_dont_reverse $ref/block/icg1
Removed dont_reverse from 'r:/WORK/top/block/icg1'
1
fm_shell (setup)> remove_dont_reverse -all
Removed all user defined dont_reverses
1
```

---

## SEE ALSO

set\_dont\_reverse(2)  
report\_dont\_reverse(2)  
verification\_clock\_gate\_reverse\_gating(3)

---

## remove\_dont\_verify\_points

Removes a specified list of user-defined dont-verify points.

---

### SYNTAX

```
integer remove_dont_verify_points  
  [-type ID_type]  
  objectID_list  
  [-all]  
  [-directly_undriven_output]
```

#### Data Types

*ID\_type* string *objectID\_list* string

---

### ENABLED SHELL MODES

Setup

---

### ARGUMENTS

#### **-type *ID\_type***

Identifies the object type of the specified object. Use this option when the name of the specified design object is associated with more than one object type within the same design. Specify one of the following object types:

- **pin** - Specifies the pin type.
- **port** - Specifies the port type.
- **net** - Specifies the net type.
- **cell** - Specifies the cell type.

#### ***objectID\_list***

Specifies one or more design objects to re-enable. If you specify a name consisting of a regular expression that resolves to more than one object, the operation applies to all of the matching objects. However, if the specified name resolves to multiple objects with identical names and you do not specify the object type, only one of these objects is affected in the precedence of pin, port, net, and cell.

#### **-all**

Removes all user-defined dont-verify points from the current design.

#### **-directly\_undriven\_output**

Specifies all top-level reference design output ports that either do not have connected nets, or that have connected nets but do not have driving pins.

---

## DESCRIPTION

This command removes the `dont_verify` attribute from the specified compare points. To remove the attribute from all user-specified don't-verify points, use the **-all** option.

Don't-verify points are not removed from the designs until you issue a subsequent **match** or **verify** command. To report the don't-verify points using the following commands:

```
report_matched_points -point_type dont_verify
```

```
report_unmatched_points -point_type dont_verify
```

---

## EXAMPLES

The following example removes the `dont_verify` attributes. Port `A_T33` is in the default implementation container, the *WORK* library, and the *CORE* design.

```
prompt> remove_dont_verify_points \  
impl:/WORK/CORE/A_T33
```

The following example is similar to the preceding example except that the **-type** option differentiates the design object from other types having the same name.

```
prompt> remove_dont_verify_points \  
-type cell \  
impl:/WORK/CORE/A_T33
```

---

## SEE ALSO

```
report_dont_verify_points(2)  
report_matched_points(2)  
report_unmatched_points(2)  
set_dont_verify_points(2)
```

---

## remove\_dp\_int\_round

Removes any rounding information for multipliers.

---

### SYNTAX

**remove\_dp\_int\_round**  
*objectID*

#### Data Types

*objectID* string

---

### ENABLED SHELL MODES

Setup

---

### ARGUMENTS

*objectID*

Removes any rounding information for the multiplier.

---

### DESCRIPTION

Use this command to remove the internal and external rounding modifications applied to a multiplier.

---

### EXAMPLES

```
fm_shell (guide)> remove_dp_int_round { mult_12* mult_34* }  
1
```

---

### SEE ALSO

set\_dp\_int\_round(2)  
report\_dp\_int\_round(2)

---

## remove\_dpx\_options

Removes DPX options.

---

### SYNTAX

status **remove\_dpx\_options**

---

### LICENSE

This command is available when the "Formality-DPX" license key is used.

---

### DESCRIPTION

This command removes all the user-specified options in set\_dpx\_options.

---

### EXAMPLES

The following example illustrates the command after the set\_dpx\_options command has been issued:

```
fm_shell (setup)> set_dpx_options -protocol SH -submit_command sh -max_cores 2 -max_workers 3
fm_shell (setup)> remove_dpx_options
fm_shell (setup)> report_dpx_options
*****
Report      : dpx_options

Reference   : <None>
Implementation : <None>
Version     : R-2020.09-SP3
Date       : Tue Oct 27 09:39:16 2020
*****
No options specified by user in set_dpx_options.
1
```

---

### SEE ALSO

set\_dpx\_options(2)  
report\_dpx\_options(2)

---

## remove\_factor\_point

Removes the design object as a factoring variable specified by the **set\_factor\_point** command.

---

### SYNTAX

#### **remove\_factor\_point**

*objectID* | -all  
[-type *type*]

#### Data Types

*objectID* string  
*type* string

#### Enabled Shell Modes

- Setup
- Match
- Verify

---

### ARGUMENTS

#### ***objectID***

Specifies a list of factoring variables to remove. If you specify a name consisting of a regular expression that resolves to more than one object, the operation is applied to all the matching objects. If the specified name resolves to multiple objects with identical names (and you do not specify the object type), only one of these objects is affected. In which case, the precedence is pin, port, net, and cell.

#### **-all**

Removes all factoring variables from the current design.

#### **-type *type***

Specifies the object type. Use this option if the name of the specified design object is associated with more than one object type in the same design. Specify one of the following values for the *objectID\_type* argument:

- *port* to specify port type
- *pin* to specify pin type
- *net* to specify net type
- *cell* to specify cell type

---

### DESCRIPTION



This command removes the given objects as factoring variables, which are specified by using the **set\_factor\_point** command. Specify either a list of objects with valid factoring variable names with the objectID or use the **-all** option. Use wildcard character (\*) to specify groups of objects.

---

## EXAMPLES

```
fm_shell (setup)> remove_factor_point $ref/M1/U1/state1_reg
Removed factoring variable from 'r:/WORK/top/M1/U1/state1_reg'
1
fm_shell (setup)> remove_factor_point -all
Removed all user-defined factoring variables
1
```

---

## SEE ALSO

```
set_factor_point(2)
report_factor_points(2)
```

---

## remove\_from\_collection

Removes objects from a collection, resulting in a new collection. The base collection remains unchanged.

---

### SYNTAX

```
collection remove_from_collection
[-intersect]
collection1
object_spec
```

#### Data Types

<i>collection1</i>	collection
<i>object_spec</i>	list

---

### ARGUMENTS

#### -intersect

Removes objects from *collection1* not found in *object\_spec*. Without this option, removes objects from *collection1* that are found in *object\_spec*.

#### *collection1*

Specifies the base collection to be copied to the result collection. Objects matching *object\_spec* are removed from the result collection.

#### *object\_spec*

Specifies a list of named objects or collections to remove. The object class of each element in this list must be the same as in the base collection. If the name matches an existing collection, the collection is used. Otherwise, the objects are searched for in the database using the object class of the base collection.

---

### DESCRIPTION

The **remove\_from\_collection** command removes elements from a collection, creating a new collection.

If the base collection is homogeneous, any element of the *object\_spec* that is not a collection is searched for in the database using the object class of the base collection. If the base collection is heterogeneous, any element of the *object\_spec* that is not a collection is ignored.

If the *-intersect* option is not specified, which is the default mode, and if nothing matches the *object\_spec*, the resulting collection is a copy of the base collection. If everything in the *collection1* option matches the *object\_spec*, the result is the empty collection. With the *-intersect* option the results are reversed.

For background on collections and querying of objects, see the **collections** man page.

## EXAMPLES

The following example gets all input ports except "CLOCK".

```
prompt> set cPorts [remove_from_collection [all_inputs] CLOCK]
{"in1", "in2"}
```

---

## SEE ALSO

`add_to_collection(2)`  
`collections(2)`

---

## remove\_guidance

Removes the current setup data specified by the **set\_svf** command

---

### SYNTAX

**remove\_guidance**

#### Enabled Shell Modes

- Setup
- Guide

---

### DESCRIPTION

This command removes the stored setup data, which is specified by the **set\_svf** command.

---

### EXAMPLES

```
fm_shell (setup)> remove_guidance
SVF is not set.
0
fm_shell (setup)> set_svf top.svf
SVF set to 'top.svf'.
1
fm_shell (setup)> remove_guidance
Removed SVF from 'top.svf'.
1
fm_shell (setup)>
```

---

### SEE ALSO

set\_svf(2)  
report\_guidance(2)

---

## remove\_init\_toggle\_assumption

Removes the initial toggle assumption on a controlling object(s).

---

### SYNTAX

```
remove_init_toggle_assumption  
[-type]  
[-all | object_list]
```

#### Data Types

*object\_list* string

#### Enabled Shell Modes

Setup

---

### ARGUMENTS

#### -type

Optional switch to specify the type of the object(s). The types are port, net or cell.

#### *object\_list*

Specifies the object(s) whose initial toggle assumptions need to be removed.

#### -all

Removes all the initial toggle assumptions.

---

### DESCRIPTION

Removes the initial toggle assumption on a controlling object(s) set by the set\_init\_toggle\_assumption command.

---

### EXAMPLES

The following example removes the initial toggle assumption from *i:/WORK/bit\_slice/hclk*.

```
fm_shell (setup)> remove_init_toggle_assumption i:/WORK/bit_slice/hclk  
Removing the initial toggle assumption of i:/WORK/bit_slice/hclk  
1
```

The following example removes all the initial toggle assumptions..

```
fm_shell (setup)> remove_init_toggle_assumption -all  
Removing the initial toggle assumption of i:/WORK/bit_slice/hclk  
Removing the initial toggle assumption of i:/WORK/bit_slice/lclk  
1
```

---

## SEE ALSO

```
set_init_toggle_assumption(2)  
report_init_toggle_assumption(2)
```

---

## remove\_input\_value\_range

Removes a specified or all input value ranges that are set by using the **set\_input\_value\_range** command.

---

### SYNTAX

**remove\_input\_value\_range**  
*objectID* | -all

#### Data Types

*objectID* string

#### Enabled Shell Modes

Setup

---

### ARGUMENTS

#### *objectID*

Removes input value range for the specified object ID.

#### **-all**

Removes all input value ranges.

---

### DESCRIPTION

This command removes the input value ranges that are set by the **set\_input\_value\_range** command. All primary inputs default to binary (0 or 1) value range.

The **remove\_input\_value\_range** command returns one of the following:

- 0 to indicate failure
- 1 to indicate success

---

### EXAMPLES

The following example removes the input value range for r:/WORK/top/PI1.

```
fm_shell (setup)> remove_input_value_range r:/WORK/top/PI1
Removed user-defined input range from 'r:/WORK/top/PI1'
1
```

The following example removes all the input value ranges.

```
fm_shell (setup)> remove_input_value_range -all  
Removed all user-defined input ranges  
1  
fm_shell (setup)>
```

---

## SEE ALSO

```
set_input_value_range(2)  
report_input_value_range(2)  
write_hierarchical_verification_script(2)
```



---

## remove\_inv\_push

Disables the move of inversions across the register boundaries.

---

### SYNTAX

```
remove_inv_push  
[-shared_lib]  
objectID_list | -all
```

#### Data Types

*objectID\_list*

#### Enabled Shell Modes

Setup

---

### ARGUMENTS

#### -shared\_lib

Disables the move of inversions across the register boundaries from the shared technology libraries.

#### objectID\_list

Specifies the objects where the inversion across the register boundaries are disabled.

#### -all

Disables all inversions across register boundaries.

---

### DESCRIPTION

This command disables the move of an inversion across the register boundary from an object. You can use this command only on:

- A sequential primitive in a design
- An instance referencing a technology library
- A design in a technology library
- A top-level, or primary output port
- An input pin on a black box

The **remove\_inv\_push** command returns one of the following:

- 0 to indicate failure
- 1 to indicate success

---

## EXAMPLES

The following example specifies the removal of the inversion across the reg\_A, register boundary.

```
fm_shell (setup)> remove_inv_push ref:/WORK/CORE/reg_A  
1
```

---

## SEE ALSO

```
report_inv_push(2)  
set_inv_push(2)
```

---

## remove\_inversion

Removes user-specified inversions.

---

### SYNTAX

status **remove\_inversion**  
*objectID* | -all

#### Data Types

*objectID* string

#### ENABLED SHELL MODES

Setup

---

### ARGUMENTS

#### *objectID*

Removes the specified inversion objects.

#### -all

Removes all the user-specified inversion objects from the current design.

---

### DESCRIPTION

This command removes the specified inversion object that is inserted using the **insert\_inversion** command.

To remove an inversion object from a specific design object, specify the *objectID* of the inversion object. To remove all user-inserted inversion from all workspaces, specify the **-all** option.

The **remove\_inversion** command is available from the GUI through the "Setup" menu of the logic cone schematics. You must select an inversion object before "Remove inversion" is enabled in the "Setup menu". The GUI queues the command, because the **remove\_inversion** command must be executed in the setup mode. NOTE that the **remove\_inversion** command is made on the actual design, so inversion is removed from all instantiations of the design. The tool reports a warning from the GUI if inversions are removed in more places than just the selection. No warning is reported from the command line.

To report the inversion objects that are inserted using the **insert\_inversion** command, use the **report\_inversion** command.

---

## EXAMPLES

The following example shows how to remove inversion objects.

```
fm_shell (setup)> remove_inversion i:/WORK/top/out2_FM_INV  
1
```

The following example removes all the inversion previously created with **insert\_inversion** commands.

```
fm_shell (setup)> remove_inversion -all  
1
```

---

## SEE ALSO

[report\\_inversion\(2\)](#)  
[insert\\_inversion\(2\)](#)

---

## remove\_library

Removes the specified technology libraries from the Formality environment.

---

### SYNTAX

**remove\_library**  
*libraryID\_list* | -all

#### Data Types

*libraryID\_list* string

---

### ARGUMENTS

#### *libraryID\_list*

Specifies the libraries to remove. You can specify the name of the library, or the library ID including the name of the container.

#### -all

Removes the technology libraries that are currently loaded in all containers.

---

### DESCRIPTION

This command removes the technology libraries from the Formality environment. You can either remove all libraries, including the GTECH libraries, or specific libraries. Libraries that are removed are not loaded (with the exception of GTECH) into subsequently created containers.

You can remove specific libraries by listing the library names. Do not specify the container or use the slash character as you would when specifying a library ID argument.

To remove unshared technology libraries, specify the *libraryID* argument.

Removing a shared technology library from a specific container does not prevent the tool from automatically loading that library into subsequently created containers.

The **remove\_library** command returns one of the following:

- 0 to indicate failure
- 1 to indicate success

---

### EXAMPLES

The following example removes the shared technology library named *my\_shared\_lib*. The report shows all the currently loaded libraries. After the tool removes *my\_shared\_lib*, it is not loaded into the newly created containers.

```
fm_shell> report_libraries -short

Number of
Cells    Shared  Technology Library
-----
1        Yes    my_shared_lib
79       Yes    gtech
1        Yes    ref:/my_shared_lib
79       Yes    ref:/gtech
1

fm_shell> remove_library my_shared_lib
Removed shared technology library 'my_shared_lib'
1

fm_shell> report_libraries -short
Number of
Cells    Shared  Technology Library
-----
79       Yes    gtech
79       Yes    ref:/gtech
1
fm_shell>
```

---

SEE ALSO

report\_libraries(2)

---

## remove\_license

Removes one or more licensed Formality features.

---

### SYNTAX

status **remove\_license**  
*feature\_list*

#### Data Types

*feature\_list* list

---

### ARGUMENTS

#### *feature\_list*

Specifies the list of Formality features to be removed. The *feature\_list* argument might consist of a single value or a space-delimited list of values enclosed within braces ({}).

By looking at your key file, you can determine all of the features licensed at your site.

---

### RETURN VALUE

The **remove\_license** command returns a status of 1 if it was successful and 0 if it failed.

---

### DESCRIPTION

This command removes the specified Formality license features from the features you are currently using.

The **list\_licenses** command provides a list of the features that you are currently using.

---

### EXAMPLES

The following example removes the Formality-ECO license:

```
fm_shell (setup)> remove_license Formality-ECO
```

## SEE ALSO

check\_license(2)  
license\_users(2)  
list\_licenses(2)  
get\_license(2)



---

## remove\_mismatch\_message\_filter

Removes warning or suppress filter on one or more simulation-synthesis mismatch messages.

---

### SYNTAX

```
status remove_mismatch_message_filter
  [-warn | -suppress]
  [-all]
  [-signal SignalName]
  [-block HierarchicalBlockName]
  [-file FileName]
  [-line LineNumber]
  [MismatchMessageIDList]
```

#### Data Types

<i>SignalName</i>	string
<i>HierarchicalBlockName</i>	string
<i>FileName</i>	string
<i>LineNumber</i>	integer
<i>MismatchMessageIDList</i>	list

---

### ARGUMENTS

#### -warn

Removes mismatch filter set with **-warn** option. This option can not be combined with **-suppress**.

#### -suppress

Removes mismatch message filter set with **-suppress** option. This option can not be combined with **-warn**.

#### -all

This option removes all filters. This option can be combined with **-warn** or **-suppress**. The option **-all** alone will remove all the filters set previously. It removes all warning filters if specified with **-warn** option and removes all suppress filters if specified with **-suppress** option.

#### -signal SignalName

Removes mismatch message filter based on the Signal or Variable Name. The SignalName can accept a string value in Tcl glob style pattern that should exactly match the **set\_mismatch\_message\_filter** input. This is an optional option.

#### -block HierarchicalBlockName

Removes mismatch message filter based on the hierarchical block name. The Hierarchical block name can accept a string value in Tcl glob style pattern that should exactly match the **set\_mismatch\_message\_filter** input. The block name can be module or entity-architecture name, always or process block name, generate block name, function name and procedure name. The expected format of hierarchical block name for always or process block and generate block are as follows:

```
<ModuleName>[/<BlockName>]*
```

The expected format of hierarchical block name for functions and procedures that defined inside a module or package is as follows:

```
<ModuleOrPackageName>/<FunctionOrProcedureName>
```

This is an optional option.

#### **-file FileName**

Removes mismatch message filter based on a file name. The file name can be a leaf level file name like `*/test.v` or full file path. This can accept values which are in Tcl glob-style pattern matching form that exactly matches `set_mismatch_message_filter` input. This is an optional option.

#### **-line LineNumber**

Removes mismatch message filter for a mismatch message that occurs at given line number of an RTL file. This option requires `-file` option. It cannot be used with `-signal` or `-block` options. This is an optional option

#### **MismatchMessageIDList**

Removes mismatch message filter for the list of mismatch message ids specified. This is an optional option. Below are the list of simulation mismatch error codes that this option accepts:

**FMR\_VHDL-274 FMR\_VHDL-1002 FMR\_VHDL-1004 FMR\_VHDL-1014 FMR\_VHDL-1025 FMR\_VHDL-1027 FMR\_VHDL-1036  
FMR\_VHDL-1140 FMR\_VHDL-1144 FMR\_VHDL-1145 FMR\_VLOG-079 FMR\_VLOG-081 FMR\_VLOG-083 FMR\_VLOG-087  
FMR\_VLOG-089 FMR\_VLOG-090 FMR\_VLOG-091 FMR\_VLOG-100 FMR\_VLOG-925 FMR\_VLOG-928 FMR\_VLOG-929  
FMR\_VLOG-933 FMR\_ELAB-034 FMR\_ELAB-058 FMR\_ELAB-059 FMR\_ELAB-100 FMR\_ELAB-115 FMR\_ELAB-116  
FMR\_ELAB-117 FMR\_ELAB-118 FMR\_ELAB-125 FMR\_ELAB-130 FMR\_ELAB-136 FMR\_ELAB-145 FMR\_ELAB-146  
FMR\_ELAB-147 FMR\_ELAB-149 FMR\_ELAB-150 FMR\_ELAB-151 FMR\_ELAB-153 FMR\_ELAB-154 FMR\_ELAB-261 FM\_SVF-  
001 FM\_SVF-002 FM\_SVF-003 FM\_SVF-004 FM\_SVF-005 FM\_SVF-006 FM\_SVF-007 FM\_SVF-008**

---

## DESCRIPTION

The command removes the warning or suppress filter that previously set on one or more simulation-synthesis mismatch messages. The command input should exactly match existing filter to remove.

The command returns status 1 on success and 0 on failure.

---

## EXAMPLES

To remove **-suppress** filter that set on `FMR_ELAB-117` for file `/vobs/data/rtl/test.sv` and line-number 57, use the command as shown below. Note that the remove command should match the set command to get removed.

```
fm_shell (setup)> set_mismatch_message_filter -suppress -file {/vobs/data/rtl/test.sv}
-line 57 FMR_ELAB-117
```

```
fm_shell (setup)> remove_mismatch_message_filter -suppress -file {/vobs/data/rtl/test.sv}
-line 57 FMR_ELAB-117
```

To remove all the **-suppress** filters set on `FMR_ELAB-117`, use the command as shown below:

```
fm_shell (setup)> remove_mismatch_message_filter -suppress FMR_ELAB-117
```

To remove all the **-warn** filters that set on mismatch message, use the command as shown below:

```
fm_shell (setup)> remove_mismatch_message_filter -warn -all
```

To remove suppress filter that set on `FMR_ELAB-146` that matches file-name `test*.v`, use the command as shown below:

```
fm_shell (setup)> remove_mismatch_message_filter -suppress -file {*/test*.v} FMR_ELAB-146
```

---

## SEE ALSO

`set_mismatch_message_filter(2)`  
`report_mismatch_message_filters(2)`

---

## remove\_net

Removes the specified nets.

---

### SYNTAX

```
status remove_net  
  [-hier]  
  net_list  
  -all
```

#### Data Types

*net\_list* list

---

### RETURN VALUE

The **remove\_net** command returns a status of 1 if it was successful and 0 if it failed.

---

### ARGUMENTS

#### **-hier**

Removes all segments (across hierarchy) of nets in the *net\_list*.

#### **net\_list**

Specifies the names of nets to remove. You can use either object IDs or instance-based paths.

Nets are removed from all instances of a design. If you want to only affect a particular instance-based path, you must uniquify that instance of the design first.

You must specify either the *net\_list* or *-all*.

#### **-all**

Removes all nets in the current design or instance.

You must specify either the *net\_list* or *-all*.

---

### DESCRIPTION

This command removes nets that are specified using the *net\_list* argument, or all nets in the current design or instance if the *-all*

option is used.

If a net is connected to a pin, the connection is removed.

If the **-hier** option is specified, the segments of the net (across hierarchy) are removed. Any ports now orphaned as a result of this are also removed.

The **-hier** and the **-all** options are mutually exclusive.

You can create nets using the **create\_net** command.

Outside of Setup mode, this command only works on edit designs created using the **edit\_design** command.

---

## EXAMPLES

The following example removes two nets *net1* and *net2* in design *r:/WORK/mid*.

```
fm_shell (setup)> current_design r:/WORK/mid  
fm_shell (setup)> remove_net {net1 net2}
```

The following example removes a net *net3* from all instances of the design of *r:/WORK/top/m1/b1*.

```
fm_shell (setup)> current_instance r:/WORK/top/m1/b1  
fm_shell (setup)> remove_net net3
```

---

## SEE ALSO

[create\\_net\(2\)](#)  
[current\\_design\(2\)](#)  
[current\\_instance\(2\)](#)  
[edit\\_design\(2\)](#)

---

## remove\_net\_resolution

Removes resolution function from the specified net.

---

### SYNTAX

```
status remove_net_resolution
[ -all ]
[ objectID ]
```

#### Data Types

*objectID*    string

#### Enabled Shell Modes

Setup

---

### ARGUMENTS

#### -all

Removes resolution function from all the nets. Causes Formality to select the default resolution function for all the multiply-driven nets.

#### *objectID*

Specifies the net from which the resolution function is to be removed. If you specify a name that resolves to more than one net, the resolution function is removed from all of the matching nets.

---

### DESCRIPTION

Use this command to remove the net resolution function of a net with multiple drivers.

One and only one of the two options -all and *objectID* should be specified. If the command is invoked with both or none of the options, the tool will report an error.

---

### EXAMPLES

The following examples remove the resolution function from the net VDD in the implementation design.

```
fm_shell (setup)> remove_net_resolution \
i:/WORK/dut/VDD
Removed resolution function from net 'i:/WORK/dut/VDD'
1
```

---

## SEE ALSO

`report_net_resolution(2)`  
`set_net_resolution(2)`

---

## remove\_object

Removes the specified pins, ports, or unlinked cells from a design.

---

### SYNTAX

```
remove_object  
objectID  
[-shared_lib]  
[-type object_type]
```

#### Data Types

*objectID* string  
*object\_type* string

#### Enabled Shell Modes

Setup

---

### ARGUMENTS

#### *objectID*

Specifies the pin, port, or unlinked cell to remove.

#### **-shared\_lib**

Removes the specified objects from the technology libraries.

#### **-type *object\_type***

Specifies the object type with the specific object ID. Use this option if the name of the specified design object is associated with more than one object type within a design. Specify one of the following values for the *object\_type* argument:

- *cell* for a cell type
- *port* for a port type
- *pin* for a pin type

---

### DESCRIPTION

This command removes the specified pin, port, or unlinked cell from a design.

For example, an implementation design uses black boxes that do not add functionality to the design compared to the reference design. A simple way to make sure the objects do not affect verification is to remove them.

The **remove\_object** command returns one of the following:

- 0 to indicate failure



- 1 to indicate success

---

## EXAMPLES

The following example removes a port in the implementation design.

```
fm_shell (setup)> remove_object impl:/WORK/CORE/BUS_KEEPER  
1  
fm_shell (setup)>
```

---

## SEE ALSO

`report_designs(2)`

---

## remove\_parameters

Removes specific parameters that are set by using the **set\_parameters** command.

---

### SYNTAX

status **remove\_parameters**

[-flatten]  
[-retimed]  
[-resolution]  
[-all\_designs]  
[-all\_parameters]  
[*designID\_list*]

#### Data Types

*designID\_list* string

#### Enabled Shell Modes

Setup (for the **-retimed**, **-resolution**, **-all\_parameters** parameters)

---

### ARGUMENTS

#### **-flatten**

Removes the flattened parameters.

#### **-retimed**

Removes the retimed parameters.

#### **-resolution**

Removes the resolution parameters.

#### **-all\_designs**

Removes parameters from all designs in the Formality environment.

#### **-all\_parameters**

Removes all three types of parameters.

#### ***designID\_list***

Removes the parameters in the specific design.

---

### DESCRIPTION

This command removes specific parameters that are set by using the **set\_parameters** command.

You can remove parameters from all designs, individual designs, or the current design. To remove parameters from all designs, use the *-all\_designs* option. To remove parameters from specific designs, specify the design IDs. By default, this command removes parameters from the current design.

Specify the parameters to remove by using any combination of the *-flatten*, *-retimed*, and *-resolution* options. To remove all the three types of parameters, use the *-all\_parameters* option.

You must specify at least one parameter type.

When a design is not associated with a flattened parameter, the command verifies hierarchical blocks within their isolated context during verification. If verification fails at this level, the command flattens the design and verifies it again. Remove the flattened parameter to perform block-level verification before flattening the design.

When a design is not associated with the retimed parameter, the command does not account for retiming before verification. For more information about how Formality treats retimed designs, see the *Formality User Guide*.

When a design is not associated with the resolution parameter, the tool determines a signal consensus at nets having multiple drivers where no ports or black boxes are driving the net. For more information about resolution setting, see the *Formality User Guide*.

---

## EXAMPLES

The following example shows how to remove the flattened parameters from the current design in the current container:

```
fm_shell> remove_parameters -flatten
1
fm_shell>
```

---

## SEE ALSO

report\_parameters(2)  
set\_parameters(2)

---

## remove\_port

Removes the specified ports.

---

### SYNTAX

```
status remove_port
      port_list
      -all
```

#### Data Types

*port\_list* list

---

### RETURN VALUE

The **remove\_port** command returns a status of 1 if it was successful and 0 if it failed.

---

### ARGUMENTS

#### *port\_list*

Specifies the names of ports to remove. You can use either object IDs or instance-based paths.

Ports are removed from all instances of a design. If you want to only affect a particular instance-based path, you must uniquify that instance of the design first.

You must specify either the *port\_list* or *-all*.

#### *-all*

Removes all ports in the current design or instance. You must specify either the *port\_list* or *-all*.

---

### DESCRIPTION

This command removes ports that are specified using the *port\_list* argument, or all ports on the current design or instance if the *-all* option is used.

This command also disconnects any nets that are connected to ports that are removed.

You can create ports using the **create\_port** command.

Outside of Setup mode, this command only works on edit designs created using the **edit\_design** command.

---

## EXAMPLES

The following example removes two ports *in1* and *in2* on design *r:/WORK/mid*.

```
fm_shell (setup)> current_design r:/WORK/mid  
fm_shell (setup)> remove_port {in1 in2}
```

The following example removes a port *in3* from all instances of the design of *r:/WORK/top/m1/b1*.

```
fm_shell (setup)> current_instance r:/WORK/top/m1/b1  
fm_shell (setup)> remove_port in3
```

---

## SEE ALSO

- `create_port(2)`
- `current_design(2)`
- `current_instance(2)`
- `edit_design(2)`

---

## remove\_probe\_points

Deselects the two nets in a logic cone set by the **set\_probe\_points** command.

---

### SYNTAX

**remove\_probe\_points**  
*objectID* | -all

#### Data Types

*objectID* string

#### Enabled Shell Modes

Setup  
Match  
Verify

---

### ARGUMENTS

#### *objectID*

Removes the specified object that is a part of a probe pair. The name should specify the absolute path to a unique net in the reference or implementation designs starting with the top design.

#### -all

Removes the set probe pairs.

---

### DESCRIPTION

This command removes the two nets set by using the **set\_probe\_points** command in either the reference or the implementation design. The net name should refer to a unique net.

---

### EXAMPLES

```
fm_shell (setup)> remove_probe_points $ref/U1/U2/net2
Removed probe for 'r:/WORK/top/U1/U2/net2'
1
fm_shell (setup)> remove_probe_points i:/WORK/top/n1
Removed probe for 'i:/WORK/top/n1'
1
```

## SEE ALSO

set\_probe\_points(2)  
report\_probe\_points(2)  
report\_probe\_status(2)

---

## remove\_resistive\_drivers

Removes all resistive drivers including pullups, pulldowns, and bus holders from the Formality environment.

---

### SYNTAX

**remove\_resistive\_drivers**

#### Enabled Shell Modes

Setup

---

### ARGUMENTS

This command has no arguments.

---

### DESCRIPTION

This command removes all resistive drivers, pullups, pulldowns, bus holders, and similar components from all open containers. These components represent the effects of driver-type attributes specified in the Synopsys libraries or resistive driver constructs in the Verilog libraries.

Use this command to exclude these drivers during subsequent verification.

The **remove\_resistive\_drivers** command returns one of the following:

- 0 to indicate failure
- 1 to indicate success

---

### EXAMPLES

```
fm_shell (setup)> remove_resistive_drivers
Removed object 'c:/TGC4000_3.3V_QLM_NOM.DB/IO001/C0'
Removed object 'c:/TGC4000_3.3V_QLM_NOM.DB/IO003/C0'
Removed object 'c:/TGC4000_3.3V_QLM_NOM.DB/PB110/C0'
Removed object 'c:/TGC4000_3.3V_QLM_NOM.DB/PD100/C0'
Removed object 'c:/TGC4000_3.3V_QLM_NOM.DB/PR010/C0'
Removed object 'c:/TGC4000_3.3V_QLM_NOM.DB/PR100/C0'
1
fm_shell (setup)>
```



---

## SEE ALSO

---

## remove\_simulation\_setup\_file

Removes Synopsys simulation setup file from Formality environment

---

### SYNTAX

status **remove\_simulation\_setup\_file**

---

### DESCRIPTION

Formality can read synopsys\_sim.setup file to configure its environment matching VCS using set\_simulation\_setup\_file command. However, if user wish to remove the setup for a container, then use this command to clear existing setup.

This command is allowed only after a successful set\_top or before read commands.

---

### EXAMPLES

```
fm_shell (setup)> remove_simulation_setup_file  
Removed Simulation setup successfully.
```

1

---

### SEE ALSO

set\_simulation\_setup\_file(2)

---

## remove\_user\_match

Removes user-specified matches from the current session.

---

### SYNTAX

```
remove_user_match  
[-type type] | -all  
objectID_list
```

#### Data Types

```
type string  
objectID_list string
```

---

### ARGUMENTS

#### -type *type*

Specifies the object type for the object. Use this option if the name of the specified design object is associated with more than one object type within the same design. Specify one of the following values for the *type* argument:

- *pin* to specify pin type
- *port* to specify port type
- *net* to specify net type
- *cell* to specify cell type

#### -all

Removes all user-defined matches.

#### *objectID\_list*

Specifies a list of design objects that are specified as one of the points in a user-defined match. If you specify a name consisting of a regular expression that resolves to more than one object, the tool reports an error. If the name resolves to multiple objects with identical names and you do not specify the object type, only one of these objects is affected. The precedence in this case is pin, port, net, and cell.

---

### DESCRIPTION

This command removes one or more user-defined matches from the current session.

**NOTE:** Newly created user-defined matches are not applied to designs until the subsequent *match* or *verify* command. Other related points might be matched as a result of a user-defined match. After a user-defined match is applied, you can only undo the match, but not remove it, by using the *undo\_match* or *setup* command. This allows you to avoid situations in which the matched and setup states are inconsistent.

The **remove\_user\_match** command returns one of the following:

- 0 to indicate failure
- 1 to indicate success

---

## EXAMPLES

The following example removes a user-specified match. The *A\_T33* port is located in the *impl* container, *WORK* library, and *CORE* design.

```
fm_shell> remove_user_match impl:/WORK/CORE/A_T33
```

The following example is the same as the preceding example except that the *-type* option differentiates the design object from other types having the same name.

```
fm_shell> remove_user_match -type cell impl:/WORK/CORE/A_T33
```

---

## SEE ALSO

`set_user_match(2)`  
`report_user_matches(2)`  
`undo_match(2)`

---

## remove\_verify\_points

Removes a list of user-defined verify points.

---

### SYNTAX

```
remove_verify_points  
[-type ID_type]  
objectID_list  
[-all]
```

---

### ENABLED SHELL MODES

Setup  
Match  
Verify

---

### ARGUMENTS

#### **-type *ID\_type***

Identifies the object type for the specified objects. Use this option when the name of the specified design object is associated with more than one object type within the same design. Specify one of the following object types,

- **pin** - To specify the pin type.
- **port** - To specify the port type.
- **net** - To specify the net type.
- **cell** - To specify the cell type.

#### ***objectID\_list***

Specifies design objects to remove from the set of verify points. If you specify a name consisting of a wildcard expression that resolves to more than one object, the operation applies to all the matching objects. If the name resolves to multiple objects with identical names, and you do not specify the object type, only one of these objects is affected. In this case, the precedence is pin, port, net, and cell.

#### **-all**

Removes all user-defined verify points.

---

### DESCRIPTION

This command removes compare points from the set of verify points. To remove all user-specified verify points, use the **-all** option.

Verify points affect the subsequent **match** and **verify** commands.

To report the current verify points, use the following command:

```
report_verify_points
```

---

## EXAMPLES

The following example shows how to remove a point from the set of verify points.

```
fm_shell> remove_verify_points i:/WORK/top/out
```

The following example is similar to the preceding example except that the **-type** option differentiates the design object from other types having the same name.

```
fm_shell> remove_verify_points -type pin i:/WORK/top/out
```

---

## SEE ALSO

```
report_verify_points(2)  
set_verify_points(2)
```

---

## rename

Renames or deletes a command.

---

### SYNTAX

```
string rename  
  old_name  
  new_name
```

---

### ARGUMENTS

*old\_name*

Specifies the current name of the command.

*new\_name*

Specifies the new name of the command.

---

### DESCRIPTION

Renames the *old\_name* command so that it is now called *new\_name*. If *new\_name* is an empty string, then *old\_name* is deleted. The *old\_name* and *new\_name* arguments may include namespace qualifiers (names of containing namespaces). If a command is renamed into a different namespace, future invocations of it will execute in the new namespace. The **rename** command returns an empty string as result.

Note that the **rename** command cannot be used on permanent procedures. Depending on the application, it can be used on all basic builtin commands. In some cases, the application will allow all commands to be renamed.

WARNING: **rename** can have serious consequences if not used correctly. When using **rename** on anything other than a user-defined Tcl procedure, you will be warned. The **rename** command is intended as a means to wrap other commands: that is, the command is replaced by a Tcl procedure which calls the original. Parts of the application are written as Tcl procedures, and these procedures can use any command. Commands like **puts**, **echo**, **open**, **close**, **source** and many others are often used within the application. Use **rename** with extreme care and at your own risk. Consider using **alias**, Tcl procedures, or a private namespace before using **rename**.

---

### EXAMPLES

This example renames `my_proc` to `my_proc2`:

```
prompt> proc my_proc {} {echo "Hello"}  
prompt> rename my_proc my_proc2  
prompt> my_proc2  
Hello  
prompt> my_proc  
Error: unknown command 'my_proc' (CMD-005).
```

---

## SEE ALSO

`define_proc_attributes(2)`



---

## rename\_object

Renames the specified objects in a design.

---

### SYNTAX

**rename\_object**  
-file *filename*  
[-type *object\_type*]  
[-shared\_lib]  
[-container *container\_name*]  
[-reverse]  
*objectID*  
[*new\_name*]

#### Data Types

*filename* string  
*object\_type* string  
*container\_name* string  
*objectID* string  
*new\_name* string

#### Enabled Shell Modes

Setup

---

### ARGUMENTS

#### -file *filename*

Specifies the file from which to read the rename directives. Each line in the specified file must follow the syntax:

`[[design_name] object_type] objectID new_name`

#### -type *object\_type*

Identifies the object type specified by the *objectID* argument. Use this option if the name of the specified design object is associated with more than one object type within the same design. Specify one of the following values for *object\_type*:

- *cell* for a cell type
- *port* for a port type

#### -shared\_lib

Renames shared library objects in technology libraries.

#### -container *container\_name*

Specifies the container to apply the rename directives defined by using the *-file* option. The tool examines every library in the container for name changes.

#### -reverse

Reverses the rename directives in the file.

***objectID***

Specifies the design object to rename.

***new\_name***

Specifies the new name for the object.

---

## DESCRIPTION

This command renames design objects in the current design. You can specify a single **rename\_object** directive or specify a file of directives.

To rename one design object, use the *-type* option. If you are specifying a file of directives, specify the *object\_type* argument and optionally a container.

The **rename\_object** command returns one of the following:

- 0 to indicate failure
- 1 to indicate success

---

## EXAMPLES

The following example changes port name *ICC* to *ICC\_port*.

```
fm_shell (setup)> rename_object -type port ref:/WORK/CORE/CC CC_port
Renamed object 'ref:/WORK/CORE/CC' to 'CC_port'
1
fm_shell (setup)>
```

---

## SEE ALSO

---

## replicate\_safety\_register

Performs triple modular redundancy (TMR) on one or more registers.

---

### SYNTAX

#### **replicate\_safety\_register**

-from *regexp*  
-to *patterns*  
*registers*

#### Data Types

*regexp* string  
*patterns* list  
*registers* list

#### Enabled Shell Modes

Setup  
Preverify

---

### LICENSE

This command is made available when you use the "Formality-FuSa" license key.

---

### ARGUMENTS

#### ***regexp***

Specifies the regular expression used to generate TMR register names.

#### ***patterns***

Specifies three patterns used to generate TMR names.

#### ***registers***

Specifies the register cells to operate on.

---

### DESCRIPTION

This command applies triple modular redundancy (TMR) to specified registers, to enable successful verification of pre-TMR and post-TMR netlists.

The listed *registers* are processed one by one. For each register, the cell name is matched against *regex*, and the list of *patterns* and the match results are used to generate names of TMR registers. Then the original register is replicated using the generated names, and voting logic is added (one voter per original register output).

You must specify exactly three *patterns* with the **-to** option. *patterns* (in conjunction with *regex*) generates three different names. The generated names must be different from existing registers in the design. Optionally, one name can be the original register name. In that case, the original register is kept and two new registers are created. Otherwise, the original register is removed and three new registers are created.

The new registers are created in the same design as the original register and have the same type as the original register. The input pins of the TMR registers are driven by the nets originally driving the corresponding input pins of the original register. The output pins of the TMR registers drive the voting logic (one copy of voting logic for each output pin of the original register; for example, two voters if the register has Q and QN output pins), and the voting logic drives the nets originally driven by the output pins of the original register.

---

## EXAMPLES

Replicate one register, **r:/WORK/top/run\_reg**:

```
fm_shell (setup)> replicate_safety_register \
  -from {\(*)_reg} -to { {\1_reg} {\1_Areg} {\1_Breg} } r:/WORK/top/run_reg
```

*regex* uses `\(\\)` syntax to capture part of the register cell name, and *patterns* uses `\1` to refer to that captured part of the name when generating names. In this case, the cell name is **run\_reg**, so the captured part is "run", and the three generated names are **run\_reg**, **run\_Areg**, and **run\_Breg**. Since the first name is the original register name, the original register is kept and two new registers are created (named using the other two generated names).

More than one capture group can appear in *regex*:

```
fm_shell (setup)> set regs [get_cells {r:/WORK/cpu/state_reg[*]}]
fm_shell (setup)> replicate_safety_register \
  -from {\(*)_reg\(*)} -to { {\1_A\2} {\1_B\2} {\1_C\2} } $regs
```

Consider that the first cell name is **state\_reg[0]**. In that case the first captured part is "state" and the second captured part is "[0]". Therefore, the generated names are **state\_A[0]**, **state\_B[0]**, and **state\_C[0]**. Since none of the names are the original register name, the original register is removed and three new registers are created (named using the generated names).

---

## SEE ALSO

```
get_cells(2)
verification_tmr_suppress_during_seu(3)
```

---

## report\_aborted\_points

Reports the compare points that Formality cannot prove either equivalent or not.

---

### SYNTAX

```
int report_aborted_points
  [-compare_rule]
  [-substring substring]
  [-point_type point_type]
  [-inputs input_type]
  [-status status]
  [-loop]
  [-hard]
  [-list]
  [-last]
  [-never_loads]
  [-always_reset]
```

#### Data Types

```
substring string
point_type string
input_type string
status string
```

#### Enabled Shell Modes

```
Verify
```

---

### ARGUMENTS

#### -compare\_rule

Reports mapped object names that result from the application of compare rules.

#### -substring *substring*

Reports points containing the specified substring.

#### -point\_type *point\_type*

Reports only the compare points that have characteristics which match the specified type or types. By default, all compare point types are reported. You can specify one or more *point\_type* values.

- **bbox\_pin** to report all black box pin compare points.
- **bbox\_input** to report black box input pin compare points.
- **bbox\_inout** to report black box bidirectional pin compare points.
- **loop** to report loop compare points.
- **bbox\_net** to report multiply-driven nets that are resolved using black boxes.
- *cut* to report cutpoints.

- **port** to report all port compare points.
- **output** to report output port compare points.
- **inout** to report bidirectional port compare points.
- *directly\_undriven\_output* to report output and bidirectional ports that do not have a connected net or that have a connected net but do not have a driving pin.
- **reg** to report all register compare points.
- **DFF** to report flip-flop register compare points.
- **LAT** to report latch register compare points.
- **trans** to report transparent latch register compare points.
- **PDCut** to report power domain pin compare points.
- **PGPin** to report power, ground, or power-down function compare points.

#### **-inputs *input\_type***

Reports only the compare points with input points that are undriven or unmatched, or both. You can specify the following *input\_type* values.

- **undriven** - Report compare points with undriven input points.
- **unmatched** - Report compare points with unmatched input points.

#### **-status *status***

Reports only the compare points that have the polarity specified by the *status* argument. By default, the command reports compare points of any polarity. Specify one or both *status* values.

- **inverted** to report compare points with inverted match polarity.
- **noninverted** to report compare points with noninverted match polarity.

#### **-loop**

Reports compare points that are aborted because they are driven by a potentially state-holding asynchronous loop.

#### **-hard**

Reports compare points that are aborted because they are hard verification points.

#### **-list**

Reports a list of point name pairs, which can be used in further Tcl processing, instead of a formatted table.

#### **-last**

Reports a list of point name pairs from the last verification.

#### **-never\_loads**

Filters the report to only include register compare point pairs that do not synchronously load.

#### **-always\_reset**

Filters the report to only include register compare point pairs that are constantly reset..

---

## DESCRIPTION

This command reports information about compare points that are aborted during the most recent verification. The tool aborts verification of a compare point when it cannot determine functional equivalence. Points that are located downstream from a potentially state-holding asynchronous loop are not verified and are considered aborted.

This command reports the total number of aborted compare points, followed by the design objects that represent the aborted compare point. For each design object, the report includes the container, the design object type, and the design ID of the design object.

---

## EXAMPLES

The following example reports the compare points that are aborted.

```
prompt> report_aborted_points
1 Aborted compare point:
  0 Loop (driven by a potentially state-holding asynchronous loop)
  1 Hard (too complex to solve)

Hard : Ref DFF  r:/LIB_DETECTOR/Detector/v_rCMag11_reg[0]
      Impl DFF i:/WORK/Detector/v_rCMag11_reg[0]

[BBNet: multiply-driven net
BBPin: black box pin
Cut: cut-point
DFF: non-constant DFF register
DFF0: constant 0 DFF register
DFF1: constant 1 DFF register
DFFX: constant X DFF register
DFF0X: constrained 0X DFF register
DFF1X: constrained 1X DFF register
LAT: non-constant latch register
LAT0: constant 0 latch register
LAT1: constant 1 latch register
LATX: constant X latch register
LAT0X: constrained 0X latch register
LAT1X: constrained 1X latch register
LATCG: clock-gating latch register
TLA: transparent latch register
TLA0X: transparent constrained 0X latch register
TLA1X: transparent constrained 1X latch register
Loop: cycle break point
Port: primary (top-level) port
Und: undriven signal cut-point]

1
```

---

## SEE ALSO

```
report_failing_points(2)
report_matched_points(2)
report_passing_points(2)
report_unmatched_points(2)
report_unverified_points(2)
report_not_compared_points(2)
```

---

## report\_alternate\_strategies

Reports alternate strategies.

---

### SYNTAX

```
status report_alternate_strategies
[-setup]
[-no_setup]
[-list]
```

#### Enabled Shell Modes

Setup Match Verify

---

### ARGUMENTS

#### -setup

Report strategies that require reverting to setup mode.

#### -no\_setup

Report strategies that can be specified without reverting to setup mode.

#### -list

Return a Tcl list of strategies.

---

### DESCRIPTION

This command reports all the alternate strategies in Formality.

---

### EXAMPLES

The following example illustrates the command with no options specified:

```
fm_shell (setup)> report_alternate_strategies
*****
Report      : alternate_strategies

Reference   : <None>
Implementation : <None>
Version     : P-2019.03-BETA-20190215
Date       : Fri Feb 15 10:15:46 2019
*****
s2 s3 s1 s6 o2 l1 l3 s8 s4 o4 o3 s5 k1 k2 s7 s9 o1 s10 l2
1
```



The following example illustrates the command with `-no_setup` and `-list` options specified: `nf`

```
fm_shell (setup)> report_alternate_strategies -no_setup -list
s2 s3 s1 o2 l1 l3 s8 s4 o4 o3 s7 s9 o1 s10 l2
```

The following example illustrates the command with `-setup` option:

```
fm_shell (setup)> report_alternate_strategies -setup
*****
Report      : alternate_strategies
             -setup

Reference   : <None>
Implementation : <None>
Version     : P-2019.03-BETA-20190215
Date       : Fri Feb 15 11:36:34 2019
*****
s6 s5 k1 k2
1
```

---

## SEE ALSO

```
run_alternate_strategies(2)
set_run_alternate_strategies_options(2)
```

---

## report\_always\_on\_cells

Reports implementation cells that are always on.

---

### SYNTAX

**report\_always\_on\_cells**  
[-domain *domain\_name*]  
[-allowed]  
[-disallowed]

#### Data Types

*domain\_name* string

---

### ARGUMENTS

#### **-domain *domain\_name***

Reports only the always-on cells within the specified UPF power domain.

#### **-allowed**

Reports the always-on cells that do not cause verification failure.

#### **-disallowed**

Reports always-on cells that cause verification failure. If you specify neither the *-allowed* nor the *-disallowed* options, by default the command reports disallowed always-on cells.

---

### DESCRIPTION

The **report\_always\_on\_cells** command reports the instance path and library/design reference of each allowed or disallowed always-on cell. This command is only available in the verify mode and will not be available without deprecated verification mode for power-off states.

Allowed always-on cells are those that are on the following paths:

- Specify paths that drive any primary or backup PG pins
- Logic paths that drive any ISO or SAVE pins
- Paths that connect primary input to primary output wires in the reference design
- The direct drivers of power domain boundaries that are driven by isolation cells in the reference design - cells that are expected to be isolation cells.

---

## EXAMPLES

```
fm_shell (verify)> report_always_on_cells
```

```
*****
```

```
Report      : always_on_cells
```

```
Reference   : r:/WORK/ChipTop
```

```
Implementation : i:/WORK/ChipTop
```

```
Version     : G-2012.06
```

```
Date       : Wed Jun 6 12:46:37 2012
```

```
*****
```

```
6700 Disallowed always-on cells:
```

```
Domain /GPRs/GPRS:
```

```
i:/WORK/ChipTop/GPRs/A_reg_reg_0_ (TCBN65LPHVTWC_CCS/SDFQD1HVT)
```

```
i:/WORK/ChipTop/GPRs/A_reg_reg_10_ (TCBN65LPHVTWC_CCS/SDFQD1HVT)
```

```
i:/WORK/ChipTop/GPRs/A_reg_reg_11_ (TCBN65LPHVTWC_CCS/SDFQD1HVT)
```

```
...
```

```
fm_shell (verify)> report_always_on_cells -allowed
```

```
*****
```

```
Report      : always_on_cells
```

```
Reference   : r:/WORK/ChipTop
```

```
Implementation : i:/WORK/ChipTop
```

```
Version     : G-2012.06
```

```
Date       : Wed Jun 6 12:50:30 2012
```

```
*****
```

```
6 Allowed always-on cells:
```

```
Domain /Multiplier/GENPP/GENPP:
```

```
i:/WORK/ChipTop/Multiplier/GENPP/U3 (TCBN65LPHVTCGWC/PTINVD4HVT)
```

```
i:/WORK/ChipTop/Multiplier/GENPP/U4 (TCBN65LPHVTCGWC/PTINVD4HVT)
```

```
i:/WORK/ChipTop/Multiplier/GENPP/U5 (TCBN65LPHVTCGWC/PTINVD4HVT)
```

```
i:/WORK/ChipTop/Multiplier/GENPP/U6 (TCBN65LPHVTCGWC/PTINVD4HVT)
```

```
i:/WORK/ChipTop/Multiplier/GENPP/U7 (TCBN65LPHVTCGWC/PTINVD4HVT)
```

```
i:/WORK/ChipTop/Multiplier/GENPP/U8 (TCBN65LPHVTCGWC/PTINVD4HVT)
```

---

## SEE ALSO

---

## report\_analysis\_results

Reports the results of the recent analysis.

---

### SYNTAX

**report\_analysis\_results**  
[-summary]

#### Enabled Shell Modes

Verify

---

### ARGUMENTS

**-summary**

Reports a summary of the analysis results.

---

### DESCRIPTION

Use this command to report the results of the recent analysis. This is useful after verification when the **verification\_run\_analyze\_points** variable is set to **true**. Also, use this command after restoring a saved session that includes analysis results.

Analysis information is only available in the current verify session. Any action that exits the verify mode removes the analysis results.

---

### SEE ALSO

analyze\_points(2)  
verification\_run\_analyze\_points(3)

---

## report\_app\_var

Shows the application variables.

---

### SYNTAX

```
string report_app_var  
  [-verbose]  
  [-only_changed_vars]  
  [pattern]
```

#### Data Types

*pattern*    string

---

### ARGUMENTS

#### **-verbose**

Shows detailed information.

#### **-only\_changed\_vars**

Reports only changed variables.

#### ***pattern***

Reports on variables matching the pattern. The default is "".

---

### DESCRIPTION

The **report\_app\_var** command prints information about application variables matching the supplied pattern. By default, all descriptive information for the variable is printed, except for the help text.

If no variables match the pattern, an error is returned. Otherwise, this command returns the empty string.

If the **-verbose** option is used, then the command also prints the help text for the variable. This text is printed after the variable name and all lines of the help text are prefixed with " #".

The Constraints column can take the following forms:

```
{val1 ...}
```

The valid values must belong to the displayed list.

```
val \<= a
```

The value must be less than or equal to "a".

```
val \>= b
```

The value must be greater than or equal to "b".

`b \<= val \<= a`

The value must be greater than or equal to "b", and less than or equal to "a".

---

## EXAMPLES

The following are examples of the **report\_app\_var** command:

```
prompt> report_app_var sh*
Variable      Value  Type  Default  Constraints
-----
sh_continue_on_error  false bool  false
sh_script_stop_severity none  string none  {none W E}
\\.\\.\\.
```

```
prompt> report_app_var sh* -verbose
Variable      Value  Type  Default  Constraints
-----
sh_continue_on_error  false bool  false
# Allows source to continue after an error
sh_script_stop_severity none  string none  {none W E}
# Indicates the error message severity level which would cause
# a script to stop executing before it completes
\\.\\.\\.
```

---

## SEE ALSO

get\_app\_var(2)  
 set\_app\_var(2)  
 write\_app\_var(2)

---

## report\_architecture

Display the architecture and source for each multiplier object ID under the reference design. This command is only available after setup mode.

---

### SYNTAX

```
report_architecture [ -set_architecture |  
-hdlin_multiplier_architecture | -fm_pragma |  
-all | object_ID ]
```

---

### ARGUMENTS

#### **-set\_architecture**

Display the architecture for multipliers selected via the **set\_architecture** command.

#### **-hdlin\_multiplier\_architecture**

Display the architecture for multipliers selected via the **hdlin\_multiplier\_architecture** TCL variable.

#### **-fm\_pragma**

Display the architecture for multipliers selected via the Formality source code pragma.

#### **-all**

Display the architecture for all multipliers in the reference design. This is the default behavior of the command.

#### ***object\_ID***

Display the architecture for the multiplier at this *object\_ID* only.

---

### DESCRIPTION

This command is used to display the architecture selected and the source used to make this selection for each multiplier in the reference design. By default, the architecture and source of all multipliers is displayed, but the command's options can be used to select specific multiplier object\_IDs to display based on the source as well as the *object ID*.

This command may only be run after leaving setup mode (i.e. after the **match** command).

---

### EXAMPLES

This example shows displaying the architecture for all multipliers in the design.

```
fm_shell (match)> report_architecture
```

Arch	Source	Instance Path
csa	set_arch	r:/WORK/test4/mul_28
nbw	hdlin	r:/WORK/test4/mul_30
csa	fm_pragma	r:/WORK/test4/mul_32
wall	fm_pragma	r:/WORK/test4/mul_34
wall	fm_pragma	r:/WORK/test4/mul_40
wall	fm_pragma	r:/WORK/test4/mul_42
nbw	fm_pragma	r:/WORK/test4/mul_44
wall	fm_pragma	r:/WORK/test4/mul_46

This example shows displaying the architecture for only multipliers where the `hdlin_multiplier_architecture` TCL variable was used to select the architecture. Note how the option to the command has been shortened.

```
fm_shell (match)> report_architecture -hdlin
```

Arch	Source	Instance Path
nbw	hdlin	r:/WORK/test4/mul_30

---

## SEE ALSO

- `set_architecture(2)`
- `enable_multiplier_generation(3)`
- `hdlin_multiplier_architecture(3)`
- `architecture_selection_precedence(3)`
- `dw_foundation_threshold(3)`



---

## report\_black\_boxes

Reports black boxes in the specified designs.

---

### SYNTAX

```
status report_black_boxes
  [-r]
  [-i]
  [-container container_name]
  [-all]
  [-unresolved]
  [-interface_only]
  [-f]
  [-m]
  [-empty]
  [-unread_tech_cell_pins]
  [-set_black_box]
  [designID_list]
  [-summary]
```

#### Data Types

```
container_name string
designID_list string
```

---

### ARGUMENTS

**-r**

Reports black boxes that are in the default reference container.

**-i**

Reports black boxes that are in the default implementation container.

**-container *container\_name***

Reports black boxes that are in the specified container.

**-all**

Reports all designs that contain black boxes. This is the default behavior of the command.

**-unresolved**

Reports designs that are referenced by the **read** command, but are not resolved.

**-interface\_only**

Reports designs that contain only the interface. To read in only the interface of a design use the *hdlin\_interface\_only* variable.

**-empty**

Reports designs that contain only port declarations.

**-f**

Reports Formality Power Modules.

**-m**

Reports Technology Macro cell (DB).

**-unread\_tech\_cell\_pins**

Reports designs from technology libraries whose input pins are unread.

**-set\_black\_box**

Reports designs that are marked as black boxes by the **set\_black\_box** command.

**designID\_list**

Specifies the list of designs to report.

**-summary**

Generates a summary report of black boxes in default reference and implementation container after set top. This option is not allowed with any of the options other than **designID\_list**.

DESCRIPTION

This command reports the black boxes that are within the specified designs or containers. By default, the command reports black boxes in the current reference and implementation containers.

To report specific designs, specify the *designID\_list* argument. To report designs from specific containers, specify the **-i**, **-r**, or **-container** options.

Each report includes information about:

- Black boxes
- Associated black box types
- Linked or unlinked status for empty designs
- Instance paths of the design inferred as black box

EXAMPLES

The following example shows reports about black boxes in two designs in the reference container. Both designs are in the WORK design library.

```
fm_shell (setup)> report_black_boxes ref:/WORK/lower ref:/WORK/empty
*****
Report      : black_boxes

Reference   : ref:/WORK/top
Implementation : impl:/WORK/top
Version     : G-2012.06
Date       : Wed Jun 6 12:46:37 2012
*****

|
| Legend: |
| Black Box Attributes |
| s = Set with set_black_box command |
| i = Module read with -interface_only |
```

```

|      u = Unresolved design module      |
|      e = Empty design module           |
|      * = Unlinked design module        |
|      ut = Unread Tech cells pins       |
|      L = Linked to non-black box design |
|      f = Formality Power Model         |
|      m = Technology Macro cell (.db)    |
|_____|

```

```

#####
####  DESIGN LIBRARY - ref:/WORK
#####
Type Design Name
-----

```

```
s  lower
```

```

Instances : 1 of 1
-----
ref:/WORK/top/inst1

```

```
e  empty
```

```

Instances : 1 of 1
-----
ref:/WORK/top/inst2

```

```
1
fm_shell>
```

The following example shows reports about all the black box design modules in the implementation and reference containers. Each design is located in the WORK design library.

```
fm_shell (setup)> report_black_boxes
```

```
*****
```

```
Report      : black_boxes
```

```
Reference   : ref:/WORK/top
```

```
Implementation : impl:/WORK/top
```

```
Version     : G-2012.06
```

```
Date       : Wed Jun 6 12:46:37 2012
```

```
*****
```

```
Information: Reporting black boxes for current reference and implementation designs. (FM-184)
```

```

|_____|
| Legend: |
| Black Box Attributes |
| s = Set with set_black_box command |
| i = Module read with -interface_only |
| u = Unresolved design module |
| e = Empty design module |
| * = Unlinked design module |
| ut = Unread Tech cells pins |
| L = Linked to non-black box design |
| f = Formality Power Model |
| m = Technology Macro cell (.db) |
|_____|

```

```

#####
####  DESIGN LIBRARY - impl:/WORK
#####
Type Design Name
-----

```

```
s  lower
```

```

Instances : 1 of 1
-----
impl:/WORK/top/inst1

```

```

#####
####  DESIGN LIBRARY - ref:/WORK
#####
Type Design Name
-----

```

```

-----
s  lower

Instances : 1 of 1
-----
ref:/WORK/top/inst1

e  empty

Instances : 1 of 1
-----
ref:/WORK/top/inst2

1
fm_shell>

```

The following example shows summary about all the black box design modules in the implementation and reference containers. Each design is located in the WORK design library.

```
fm_shell (setup)> report_black_boxes -summary
```

```

*****
Report      : black_boxes
              -summary

Reference   : r:/WORK/top
Implementation : i:/WORK/top
Version     : P-2019.03-VAL-20190403
Date       : Wed Apr 3 05:19:39 2019
*****

```

```

-----
| Legend:                                     |
| Black Box Attributes                       |
| s = Set with set_black_box command       |
| i = Module read with -interface_only     |
| u = Unresolved design module             |
| e = Empty design module                  |
| * = Unlinked design module              |
| ut = Unread tech cells pins             |
| L = Linked to non-black box design      |
| f = Formality Power Model               |
| m = Technology Macro cell (.db)         |
|-----|

```

Design Name	Ref. Type	Inst. Count	Impl. Type	Inst. Count	Mismatch (Yes/No)
bot1	e	1	e	1	N
bot2	e	1	e	2	Y
bot3	e	1	s	1	Y

```
1
```

Another example showing summary about all the black box design modules in the implementation and reference containers. Each design is located in the WORK design library.

```
fm_shell (setup)> report_black_boxes -summary
```

```

*****
Report      : black_boxes
              -summary

Reference   : r:/WORK/top
Implementation : i:/WORK/top
Version     : P-2019.03-VAL-20190403
Date       : Wed Apr 3 05:19:39 2019
*****

```

```

-----
| Legend:                                     |
| Black Box Attributes                       |
| s = Set with set_black_box command       |
| i = Module read with -interface_only     |
|-----|

```

	u = Unresolved design module	
	e = Empty design module	
	* = Unlinked design module	
	ut = Unread tech cells pins	
	L = Linked to non-black box design	
	f = Formality Power Model	
	m = Technology Macro cell (.db)	

Design Name	Ref. Type	Inst. Count	Impl. Type	Inst. Count	Mismatch (Yes/No)	
SUB#PWR_UPF_FM_BBOX		m	1	m	1	N
add2_FM_BBOX	f	1	f	1	N	

fm\_shell>

SEE ALSO

remove\_black\_box(2)  
set\_black\_box(2)  
hdlin\_interface\_only(3)

---

## report\_cell\_list

Reports library cells. This command is available only in the library verification mode.

---

### SYNTAX

```
status report_cell_list
  [-verify]
  [-r | -i]
  [-matched]
  [-unmatched]
  [-passing]
  [-failing]
  [-aborting]
  [-filter wildcard_pattern]
```

#### Data Types

*wildcard\_pattern* string

---

### ARGUMENTS

#### -verify

Reports cells that match in the reference and implementation containers when this option is used before selecting the cells. After you select the cells, this option reports the cells that you selected for verification that matched in both containers. The *-verify* option displays the names of all cells that are selected for verification.

#### -r

Reports cells that are read into the reference container.

#### -i

Reports cells that are read into the implementation container.

#### -matched

Reports cells that are matched in reference and implementation containers.

#### -unmatched

Reports cells that did not match when you specify this option before you select the cells. After you select the cells, this option reports cells that you tried to select but were not selected for verification because they did not match.

#### -passing

Reports cells that passed verification.

#### -failing

Reports cells that failed verification.

#### -aborting

Reports cells for which the verification was aborted.

**-filter *wildcard\_pattern***

Specifies a wildcard pattern as a filter. Only the cell names that match the specified pattern are reported.

---

**DESCRIPTION**

This command reports library cells that are read by the tool.

- To report cells that are read into the reference container, use the following syntax:

```
report_cell_list -r
```

- To report cells that are selected for verification, use the following syntax:

```
report_cell_list -v
```

Use the **-r** or the **-i** options to report all the cell names that are read after using a **read\_\*** command.

Use the **-unmatched** and **-verify** options along with the **select\_cell\_list** command to report cells that are selected for verification.

Use the **-passing**, **-failing**, and **-aborting** options after performing verification to report the cells.

---

**EXAMPLES**

This example shows a report about cells in the reference or implementation containers and those that are selected for verification.

```
fm_shell> report_cell_list -r
*****
Report      : cell_list

Reference   : ref:/WORK/top
Implementation : impl:/WORK/top
Version     : G-2012.06
Date       : Wed Jun 6 12:46:37 2012
*****

#####
####  Cells in reference container
#####
Myincand
Myand
Mynand
Myor
Mynor

Total cells found: 5

fm_shell> report_cell_list -i
*****
Report      : cell_list

Reference   : ref:/WORK/top
Implementation : impl:/WORK/top
Version     : G-2012.06
Date       : Wed Jun 6 12:46:37 2012
*****

#####
####  Cells in implementation container
#####
Myincand
Myand
Mynand
```

Total cells found: 3

fm\_shell> **report\_cell\_list -v**

\*\*\*\*\*

Report : cell\_list

Reference : ref:/WORK/top

Implementation : impl:/WORK/top

Version : G-2012.06

Date : Wed Jun 6 12:46:37 2012

\*\*\*\*\*

#####

#### Cells selected for verification

#####

Myincand

Myand

Mynand

Total cells found: 3

fm\_shell>

---

## SEE ALSO

[select\\_cell\\_list\(2\)](#)

[debug\\_library\\_cell\(2\)](#)



---

## report\_cell\_type

Reports the cell type that was set on a technology library cell.

---

### SYNTAX

```
status report_cell_type
[-all]
[designID_list]
```

#### Data Types

*designID\_list* string

---

### ARGUMENTS

#### -all

Reports cell-type set by user on all thetech-lib cells.

#### *designID\_list*

Specifies the list of designs to report.

---

### DESCRIPTION

Reports the cell type associated with the technology library cell or a collection of one or more cells. The types that can be reported are lssd: Level-Sensitive Scan Design retention: Retention register synchronizer: Synchronizer cell multibit: Banked register or Multi-bit register.

---

### EXAMPLES

The following example shows reports about a tech-lib cell with cell-type LSSD.

```
fm_shell (setup)> report_cell_type ref:/WORK/lower
ref:/WORK/lower: SET as LSSD
1
fm_shell>
```

The following example shows reports about a tech-lib cell with cell-type RETENTION.

```
fm_shell (setup)> report_cell_type ref:/WORK/lower
ref:/WORK/lower: SET as RETENTION
1
fm_shell>
```

---

## SEE ALSO

`remove_cell_type(2)`  
`set_cell_type(2)`

---

## report\_checkpoint\_report\_commands

Reports commands associated with reporting for a specific checkpoint.

---

### SYNTAX

```
report_checkpoint_report_commands  
[ID]
```

#### Data Types

*ID* string

---

### ARGUMENTS

#### ID

Identifies the target checkpoint needing reporting commands.

---

### DESCRIPTION

Reports any commands to be executed after a specific checkpoint finishes verification.

If no checkpoint ID is specified, report if generated for all checkpoints.

---

### EXAMPLES

Checkpoints may be identified with their guide number, their checkpoint number or their name. For example, assume that SVF guide #123 is a logic\_opt checkpoint, and is the first logic\_opt and second overall checkpoint in the SVF. The possible IDs for this checkpoint are

```
123          (Guide number)  
ckpt2        (Checkpoint number)  
ckpt_logic_opt (Checkpoint name)
```

This example shows the reports for the first checkpoint

```
fm_shell (setup)> set_checkpoint_report_commands ckpt1 {  
  report_failing_points  
}  
1  
fm_shell (setup)> set_checkpoint_report_commands ckpt2 {  
  reported_aborted_points  
}
```

```

1
fm_shell (setup)> report_checkpoint_report_commands ckpt1
*****
Report      : checkpoint_report_commands
              ckpt1

Reference    : <None>
Implementation : <None>
Version      : P-2019.03
*****
ckpt1 {
    report_failing_points
}

```

This example shows the reports for all checkpoints

```

fm_shell (setup)> report_checkpoint_report_commands
*****

```

```

Report      : checkpoint_report_commands

Reference    : <None>
Implementation : <None>
Version      : P-2019.03
*****
ckpt1 {
    report_failing_points
}
ckpt2 {
    report_aborted_points
}

```

---

## SEE ALSO

```

remove_checkpoint_report_commands(2)
set_checkpoint_report_commands(2)

```

---

## report\_checkpoint\_setup\_commands

Reports commands associated with a specific checkpoint.

---

### SYNTAX

```
report_checkpoint_setup_commands  
[ID]
```

#### Data Types

*ID* string

---

### ARGUMENTS

#### ID

Identifies the target checkpoint needing setup.

---

### DESCRIPTION

Reports any commands to be executed before a specific checkpoint begins preverification.

If no checkpoint ID is specified, setup is reported for all IDs.

Setup is reported in the order it was entered.

---

### EXAMPLES

Checkpoints may be identified with their guide number, their checkpoint number or their name. For example, assume that SVF guide #123 is a logic\_opt checkpoint, and is the first logic\_opt and second overall checkpoint in the SVF. The possible IDs for this checkpoint are

```
123          (Guide number)  
ckpt2        (Checkpoint number)  
ckpt_logic_opt (Checkpoint name)
```

This example reports the setup for the first checkpoint

```
fm_shell (setup)> set_checkpoint_setup_commands ckpt1 {  
  echo "Setup for checkpoint 1"  
}  
1  
fm_shell (setup)> set_checkpoint_setup_commands ckpt2 {
```

```

    echo "Setup for checkpoint 2"
}
1
fm_shell (setup)> report_checkpoint_setup_commands ckpt1
*****
Report      : checkpoint_setup_commands
              ckpt1

Reference    : <None>
Implementation : <None>
Version      : P-2019.03
*****
ckpt1 {
    echo "Setup for checkpoint 1"
}

This example reports the setup for all checkpoints
fm_shell (setup)> set_checkpoint_setup_commands ckpt1 {
    echo "Setup for checkpoint 1"
}
1
fm_shell (setup)> set_checkpoint_setup_commands ckpt2 {
    echo "Setup for checkpoint 2"
}
1
fm_shell (setup)> report_checkpoint_setup_commands
*****
Report      : checkpoint_setup_commands

Reference    : <None>
Implementation : <None>
Version      : P-2019.03
*****
ckpt1 {
    echo "Setup for checkpoint 1"
}
ckpt2 {
    echo "Setup for checkpoint 2"
}

```

---

## SEE ALSO

```

set_checkpoint_setup_commands(2)
remove_checkpoint_setup_commands(2)

```

---

## report\_checksum

Reports the checksum value of elaborated top design of a container.

---

### SYNTAX

```
int report_checksum  
[ -container container_name | -r | -i ]
```

#### Data Types

*container\_name* string

---

### ARGUMENTS

#### **-container** *container\_name*

Reports the checksum value of elaborated top design of specified container.

#### **-r**

Reports the checksum value of elaborated top design of reference container.

#### **-i**

Reports the checksum value of elaborated top design of implementation container.

---

### DESCRIPTION

Use this command to retrieve the checksum value of elaborated top design of specified linked container. This command generates the checksum by looking at only the elaborated design and library data that is used to define the function to be verified. It can be used on a linked container at any time during the flow to capture the current view of the design and library data. If the checksum value difference is detected between two runs of Formality, it indicates that one or more source data has changed.

If none of the command options are supplied, it generates the checksum of elaborated top design of current container.

---

### EXAMPLES

The following example shows sample checksum report.

```
fm_shell> report_checksum -r  
*****  
Report      : Checksum  
Reference   : r:/WORK/top  
Implementation : <None>  
Version     : <FM_Version>  
Date        : <Date>  
*****
```

```
The total checksum of the top design r:/WORK/top is -1992367182
1
fm_shell>
```

---

## SEE ALSO



---

## report\_clocks

Reports user-specified clocks.

---

### SYNTAX

**report\_clocks**

---

### ARGUMENTS

This command has no arguments

---

### DESCRIPTION

This command reports all user-specified clocks.

---

### EXAMPLES

```
fm_shell (setup)> report_clocks
*****
Report      : clocks

Reference   : ref:/WORK/CORE
Implementation : impl:/WORK/CORE
Version     : G-2012.06
Date       : Wed Jun 6 12:46:37 2012
*****
Net Name
-----
HDL:/WORK/CORE/SCLK
1
```

---

### SEE ALSO

set\_clock(2)  
remove\_clock(2)

---

## report\_compare\_rules

Reports user-defined compare rules.

---

### SYNTAX

**report\_compare\_rules**  
[*designID*]

#### Data Types

*designID* string

---

### ARGUMENTS

#### *designID*

Specifies the design containing the compare rules.

---

### DESCRIPTION

This command reports compare rules that are defined by using the **set\_compare\_rule** command.

You can report compare rules added for a specific design by specifying a value for the *designID* argument. If you do not specify a design ID argument, the tool reports user-defined compare rules in the current design by default.

The **report\_compare\_rules** command reports one line of information for each compare rule. Each line presents the "from" expression followed by the "to" expression. Because many similar compare rules can exist, the tool limits its display to 100 rules. After reporting 100 compare rules, it displays the following message:

List of compare rules truncated after 100 compare rules

The **report\_compare\_rules** command returns one of the following:

- 0 to indicate failure
- 1 to indicate success

---

### EXAMPLES

The following example sets a compare rule and then reports the rules. Each line of output represents a single rule:

```
fm_shell> set_compare_rule ref:/WORK/CORE -from "C" -to "B"
Set compare rules for 'ref:/WORK/CORE'
1
fm_shell> report_compare_rules
*****
Report      : compare_rules
```

```
Reference    : ref:/WORK/CORE
Implementation : impl:/WORK/CORE
Version      : G-2012.06
Date        : Wed Jun 6 12:46:37 2012
*****
'C' -> 'B'
1
fm_shell>
```

---

## SEE ALSO

[set\\_compare\\_rule\(2\)](#)

---

## report\_constant\_sources

Reports information about the origin of constants on a specified net.

---

### SYNTAX

```
report_constant_sources  
[ netID ... ]
```

---

### ARGUMENTS

*netID*

Specifies the design net for which you want a report.

---

### DESCRIPTION

This command reports information about the originating source of constants on the specified *netIDs*. It traces through the fanin cone of the net until it reaches a constant LOGIC0 or LOGIC1 source, or a net with a user-specified constant on it.

The **report\_constant\_sources** command produces one line of output for each constant source. The line includes the value, the full object ID, and the object type - net or cell.

The **report\_constant\_sources** command returns one of the following:

- 0 to indicate failure
- 1 to indicate success

---

### EXAMPLES

The following example reports on all user-defined constants.

```
fm_shell> report_constant_sources ref:/WORK/UPC/scan_en  
Constant Object  
Value   Type   Object Name  
-----  
0       cell   ref:/WORK/UPC/LOGIC0  
1  
fm_shell
```

---

### SEE ALSO

report\_constants(2)

remove\_constant(2)  
set\_constant(2)

---

## report\_constants

Reports user-defined constants.

---

### SYNTAX

**report\_constants**  
[*objectID\_list*]

#### Data Types

*objectID\_list* string

---

### ARGUMENTS

#### *objectID\_list*

Specifies the design objects (net or port) to report.

---

### DESCRIPTION

This command reports constants that are defined by using the **set\_constant** command. By default, the tool returns a list of all user-specified constants.

The **report\_constants** command generates one line of output for each constant. The line includes the value, the object ID, and the object type, either net or port.

The **report\_constants** command returns one of the following:

- 0 to indicate failure
- 1 to indicate success

---

### EXAMPLES

The following example reports all user-defined constants.

```
fm_shell> report_constants
*****
Report      : constants

Reference   : ref:/WORK/UPC
Implementation : impl:/WORK/UPC
Version     : G-2012.06
Date       : Wed Jun 6 12:46:37 2012
*****
Constant   Object
Value      Type   Object Name
```

```
-----
0      port  impl:/WORK/UPC/UPC_DATA_11
1      port  ref:/WORK/UPC/UPC_DATA_11
1
fm_shell>
```

---

## SEE ALSO

[remove\\_constant\(2\)](#)  
[set\\_constant\(2\)](#)

---

## report\_constraint

Reports constraints.

---

### SYNTAX

**report\_constraint**  
[-long]  
[*constraint\_name*]

#### Data Types

*constraint\_name* string

---

### ARGUMENTS

#### -long

Reports detailed information on all the currently defined constraints.

#### *constraint\_name*

Specifies the constraint to report.

---

### DESCRIPTION

This command reports the specified constraint. By default, the tool returns information about all constraint types.

When you specify the **-long** option, the tool generates a detailed report on all defined constraints. The tool reports an error when you specify a named constraint.

The report contains the constraint name, type, design, and associated control points on which the constraint is applied. For user-defined constraints, the tool reports the constraint module mappings.

The **report\_constraint** command returns one of the following:

- 0 to indicate failure
- 1 to indicate success

---

### EXAMPLES

The following example generates a list of the currently defined constraints.

```
fm_shell> report_constraint
FM_CONSTRAINT_0
FM_CONSTRAINT_1
```



CPOINT0  
CPOINT1

The following example returns detailed information about a specific constraint that uses a predefined type.

```
fm_shell> report_constraint FM_CONSTRAINT_0
*****
Report      : constraint

Reference   : ref:/WORK/testcase
Implementation : impl:/WORK/testcase
Version     : G-2012.06
Date       : Wed Jun 6 12:46:37 2012
*****

Constraint: FM_CONSTRAINT_0
Type:      1hot_init0
Design:    ref:/WORK/testcase
Constrained Points...
(reg) Q_reg[0]
(port) PortData[1]
(reg) Q_reg[2]
(reg) Q_reg[3]
```

The following example returns detailed information about a specific constraint that uses a user-defined type.

```
fm_shell> report_constraint CPOINT0
*****
Report      : constraint

Reference   : ref:/WORK/testcase
Implementation : impl:/WORK/testcase
Version     : G-2012.06
Date       : Wed Jun 6 12:46:37 2012
*****

Constraint: CPOINT0
Type:      odd_parity
Design:    ref:/WORK/testcase
Constrained Points...
(reg) Q_reg[0]
(reg) Q_reg[1]
(reg) Q_reg[2]
(reg) Q_reg[3]
Constraint Module Port Map...
type:/WORK/my_1hot_4/a <-> ref:/WORK/testcase/Q_reg[0]
type:/WORK/my_1hot_4/b <-> ref:/WORK/testcase/Q_reg[1]
type:/WORK/my_1hot_4/c <-> ref:/WORK/testcase/Q_reg[2]
type:/WORK/my_1hot_4/d <-> ref:/WORK/testcase/Q_reg[3]
1
```

---

## SEE ALSO

create\_constraint\_type(2)  
remove\_constraint(2)  
remove\_constraint\_type(2)  
report\_constraint\_type(2)  
set\_constraint(2)

---

## report\_constraint\_type

Reports the constraint types set in a design.

---

### SYNTAX

**report\_constraint\_type**

[-long]

[*type\_name*]

#### Data Types

*type\_name* string

---

### ARGUMENTS

#### -long

Generates a detailed report for all the currently defined constraint types.

#### *type\_name*

Specifies the constraint types to report.

---

### DESCRIPTION

This command reports constraint types, including predefined, external and user-defined, constraint types. See the **set\_constraint** command man page for a list of predefined and user-defined types created by using the **create\_constraint\_type** command.

By default, the tool provides a list of all constraint types in the design. Specify the *type\_name* argument to report information about a specific constraint type.

Use the **-long** option to generate a detailed report for all defined constraint types. If you specify a named constraint type with this option, the tool reports an error.

The report includes the names, constraint modules, and constraints that currently reference the constraint types.

The **report\_constraint\_type** command returns the following:

- 0 to indicate failure
- 1 to indicate success

---

### EXAMPLES

The following example generates a list of defined constraint types.

```
fm_shell> report_constraint_type
*****
Report      : constraint_type

Reference   : ref:/WORK/CORE
Implementation : impl:/WORK/CORE
Version     : G-2012.06
Date       : Wed Jun 6 12:46:37 2012
*****

0hot
0hot_init0
0hot_init1
1hot
1hot_init0
1hot_init1
coupled
mutex
my_2hot
```

The following example provides detailed information about a predefined constraint type used by a number of constraints.

```
fm_shell> set_constraint 0hot {IN1 IN2 IN3 IN4} $ref
FM_CONSTRAINT_0
fm_shell> set_constraint 0hot {INA INB INC IND} $ref
FM_CONSTRAINT_1
fm_shell> report_constraint_type 0hot
*****
Report      : constraint_type

Reference   : ref:/WORK/CORE
Implementation : impl:/WORK/CORE
Version     : G-2012.06
Date       : Wed Jun 6 12:46:37 2012
*****

Type: 0hot (predefined)
Constraints...
  FM_CONSTRAINT_0
  FM_CONSTRAINT_1
1
```

The following example provides detailed information about a user-defined constraint type used by a number of constraints.

```
fm_shell> set_constraint parity {IN1 IN2 IN3 IN4} \
  -map {A=IN1 B=IN2 C=IN3 D=IN4} -name CPOINT0 $ref
fm_shell> report_constraint_type parity
*****
Report      : constraint_type

Reference   : ref:/WORK/parity
Implementation : impl:/WORK/parity
Version     : G-2012.06
Date       : Wed Jun 6 12:46:37 2012
*****

Type: parity (custom)
Design: type:/WORK/parity
Constraints...
  CPOINT0
1
```

---

## SEE ALSO

```
create_constraint_type(2)
remove_constraint(2)
remove_constraint_type(2)
report_constraint(2)
set_constraint(2)
```

---

## report\_containers

Reports containers in the current Formality environment.

---

### SYNTAX

status **report\_containers**  
[-list]

---

### ARGUMENTS

**-list**

Returns a list of container names which can be used in further Tcl processing.

---

### DESCRIPTION

This command reports a list of containers in the current Formality environment.

---

### EXAMPLES

The following example creates a report about all containers in the Formality environment.

```
fm_shell> report_containers
*****
Report      : compare_rules

Reference   : ref:/
Implementation : impl:/
Version     : G-2012.06
Date        : Wed Jun 6 12:46:37 2012
*****
Containers:
impl
ref
1
fm_shell>
```

---

### SEE ALSO

create\_container(2)  
current\_container(2)  
read\_container(2)

---

## report\_cutpoints

Reports the cutpoints that are set by using the **set\_cutpoint** command.

---

### SYNTAX

status **report\_cutpoints**

---

### ARGUMENTS

This command has no arguments.

---

### DESCRIPTION

This command reports the user-specified cutpoints in the current design.

---

### EXAMPLES

```
fm_shell (setup)> report_cutpoints
*****
Report      : cutpoints

Reference   : ref:/WORK/CORE
Implementation : impl:/WORK/CORE
Version     : G-2012.06
Date       : Wed Jun 6 12:46:37 2012
*****

Object
Type   Object Name
-----
pin    HDL:/WORK/CORE/MUX_OUT_BLK/DATA[10]
pin    HDL:/WORK/CORE/MUX_OUT_BLK/DATA[11]
pin    HDL:/WORK/CORE/MUX_OUT_BLK/DATA[12]
pin    HDL:/WORK/CORE/MUX_OUT_BLK/DATA[1]
pin    HDL:/WORK/CORE/MUX_OUT_BLK/DATA[2]
pin    HDL:/WORK/CORE/MUX_OUT_BLK/DATA_OUT[1]
pin    HDL:/WORK/CORE/MUX_OUT_BLK/DATA_OUT[2]
pin    HDL:/WORK/CORE/MUX_OUT_BLK/DATA_OUT[3]
pin    HDL:/WORK/CORE/MUX_OUT_BLK/ENABLE
pin    HDL:/WORK/CORE/MUX_OUT_BLK/MUX_OUT[1]
pin    HDL:/WORK/CORE/MUX_OUT_BLK/MUX_OUT[2]
pin    HDL:/WORK/CORE/MUX_OUT_BLK/REG_DATA[1]
pin    HDL:/WORK/CORE/MUX_OUT_BLK/REG_DATA[2]
pin    HDL:/WORK/CORE/MUX_OUT_BLK/REG_DATA[3]
pin    HDL:/WORK/CORE/MUX_OUT_BLK/SEL[0]
pin    HDL:/WORK/CORE/MUX_OUT_BLK/SEL[1]
pin    HDL:/WORK/CORE/MUX_OUT_BLK/STK_DATA[1]
pin    HDL:/WORK/CORE/MUX_OUT_BLK/STK_DATA[2]
```

```
pin    HDL:/WORK/CORE/MUX_OUT_BLK/STK_DATA[3]
pin    HDL:/WORK/CORE/MUX_OUT_BLK/STK_DATA[4]
pin    HDL:/WORK/CORE/MUX_OUT_BLK/UPC_DATA[1]
pin    HDL:/WORK/CORE/MUX_OUT_BLK/UPC_DATA[2]
net    OPT:/WORK/CORE/PC[1]
1
```

---

## SEE ALSO

```
set_cutpoint(2)
remove_cutpoint(2)
create_cutpoint_blackbox(2)
```

---

## report\_derived\_isolation\_constraints

Reports any derived isolation constraints added to the design.

---

### SYNTAX

```
status report_derived_isolation_constraints  
  [-r]  
  [-i]  
  [-container container_name]  
  [-verbose]
```

#### Data Types

*container\_name* string

---

### ARGUMENTS

#### -r default

Reports all the derived isolation constraints that were inserted into the default reference container.

#### -i

Reports all the derived isolation constraints that were inserted into the default implementation container.

#### -container *container\_name*

Reports all the derived isolation constraints that were inserted into the the specified container.

#### -verbose

Adds a detailed list of the constraints to the report.

---

### DESCRIPTION

The **report\_derived\_isolation\_constraints** command reports how many derived isolation constraints were inserted into a container.

The report breaks down the constraints into those derived from isolation strategies and those that are derived from "is\_isolated" ports of macros. When "-verbose" is added, each individual constraint is listed in each group.

---

### SEE ALSO

`upf_derive_isolation_constraints(3)`

---

## report\_design\_libraries

Reports design libraries in the current Formality environment.

---

### SYNTAX

status **report\_design\_libraries**  
[*item\_list*]

#### Data Types

*item\_list* string

---

### ARGUMENTS

#### *item\_list*

Specifies the containers and design libraries to report. The list can have:

- *container\_name*: Specifies the container name. Do not use the colon character (:). The **report\_design\_libraries** command does not support the current container.
- *libraryID*: Specifies a design library name. You can use the (\*) wildcard character.

---

### DESCRIPTION

This command reports design libraries in the Formality environment. The report does not include information about technology libraries.

You can report information about specific design libraries and containers by specifying *item\_list* arguments. By default, the tool reports information about the design libraries in the current Formality environment.

Each line of the report contains the number of designs in the design library and their names.

---

### EXAMPLES

The following example reports information about all the design libraries loaded in the Formality environment.

```
fm_shell> report_design_libraries
*****
Report      : design_libraries

Reference   : ref:/WORK
Implementation : impl:/my_lib
Version     : G-2012.06
Date       : Wed Jun 6 12:46:37 2012
*****
```



```
Number of
Designs   Design Library
-----
    10    impl:/my_lib
    10    ref:/WORK
1
fm_shell>
```

The following example reports on the design library named WORK loaded in the reference container.

```
fm_shell> report_design_libraries ref:/WORK
*****
Report      : design_libraries

Reference   : ref:/WORK
Implementation : impl:/my_lib
Version     : G-2012.06
Date       : Wed Jun 6 12:46:37 2012
*****

Number of
Designs   Design Library
-----
    10    ref:/WORK
1
fm_shell>
```

---

SEE ALSO

report\_containers(2)  
report\_designs(2)  
report\_libraries(2)

---

## report\_designs

Reports information on designs.

---

### SYNTAX

status **report\_designs**  
[*item\_list*]

#### Data Types

*item\_list* string

---

### ARGUMENTS

#### *item\_list*

Specifies the containers, libraries, and designs to report. The list can have:

- *container\_name* - specifies a container name. Do not use the colon character (:).
- *libraryID* - specifies a design library. You can use the wildcard character (\*).
- *designID* - specifies a design. You can use the wildcard character (\*).

---

### DESCRIPTION

Use this command to report information about the designs in the Formality environment. You can specify container names, library IDs, and design IDs.

The report includes the following information:

- Number of cells (linked and unlinked)
- Number of ports
- Number of nets
- Resolution type
- Setting for the flatten parameter
- Setting for the retimed parameter

---

### EXAMPLES

The following example shows how to report information about the designs in the container *spec*.

```
fm_shell> report_designs spec
*****
Report      : designs

Reference   : ref:/WORK
Implementation : spec:/WORK
Version     : G-2012.06
Date       : Wed Jun 6 12:46:37 2012
*****
```

```

|-----|
| Legend:                               |
| Statistics      Attributes            |
| c = number of cells      c = CONSENSUS resolution type |
|   linked(unlinked)      x = BLACKBOX resolution type |
| p = number of ports      a = AND resolution type      |
| n = number of nets       o = OR resolution type       |
|                          f = flatten                  |
|                          r = retimed                   |
|-----|
#####
#### DESIGN LIBRARY - spec:/WORK
#####
Design Name      Statistics      Attributes      Verification status
-----
impl             c0(0) p0 n0      c
myand2           c1(0) p3 n3      c
myand2_reg       c7(0) p4 n10      c
myopt1           c6(0) p3 n8      c
myopt2           c0(0) p0 n0      c
myor2            c0(0) p0 n0      c
myor2_reg        c0(0) p0 n0      c
myreg            c7(0) p3 n9      c
spec             c8(0) p4 n11      c
1
fm_shell>
```

This example shows how to report information about the design library *WORK* in the container *impl*. The example also reports on the designs in the container *spec*.

```
fm_shell> report_designs {impl:/WORK/myopt2 spec}
*****
Report      : design_libraries

Reference   : ref:/WORK
Implementation : spec:/my_lib
Version     : G-2012.06
Date       : Wed Jun 6 12:46:37 2012
*****
```

```

|-----|
| Legend:                               |
| Statistics      Attributes            |
| c = number of cells      c = CONSENSUS resolution type |
|   linked(unlinked)      x = BLACKBOX resolution type |
| p = number of ports      a = AND resolution type      |
| n = number of nets       o = OR resolution type       |
|                          f = flatten                  |
|                          r = retimed                   |
|-----|
#####
#### DESIGN LIBRARY - impl:/WORK
#####
Design Name      Statistics      Attributes      Verification status
-----
myopt2           c7(0) p4 n9      c      Passing
#####
#### DESIGN LIBRARY - spec:/WORK
#####
Design Name      Statistics      Attributes      Verification status
-----
impl             c0(0) p0 n0      c
myand2           c1(0) p3 n3      c
myand2_reg       c7(0) p4 n10      c
```

```
myopt1      c6(0) p3 n8      c
myopt2      c0(0) p0 n0      c
myor2       c0(0) p0 n0      c
myor2_reg   c0(0) p0 n0      c
myreg       c7(0) p3 n9      c
spec        c8(0) p4 n11     c
1
fm_shell>
```

---

SEE ALSO

```
report_containers(2)
report_design_libraries(2)
report_libraries(2)
find_designs(2)
```

---

## report\_diagnosed\_matching\_regions

Reports matching regions for the previous diagnosis.

---

### SYNTAX

```
int report_diagnosed_matching_regions  
  [-expand mode]
```

#### Data Types

*mode* string

#### Enabled Shell Modes

Verify

---

### ARGUMENTS

#### -expand *mode*

Reports information about the technology library and DesignWare components.

The *mode* argument specifies the technology library cell expansion mode.

- **auto** - Includes details of the cells containing multiple sequential elements, feedback loops, or other logic that can modify the output of the cell. This is the default mode.
- **true** - Includes details of only the technology library and DesignWare component cells. Only the elements that are part of the diagnosed region are listed.
- **false** - Excludes details of the technology library and DesignWare component cells.

---

### DESCRIPTION

This command reports matching regions for the previous diagnosis. Matching regions are drivers in the matched design and are identified in the undiagnosed design. For example, if you diagnosed the implementation design, matching regions are identified in the reference design.

The report includes recommended and alternative matching regions, and the type of driver.

---

### EXAMPLES

The following example shows a list of matching regions for a diagnosis with three matching regions:

```
fm_shell> report_diagnosed_matching_regions  
*****
```

Report : diagnosed\_matching\_regions

Reference : ref:/WORK

Implementation : impl:/my\_lib

Version : G-2012.06

Date : Wed Jun 6 12:46:37 2012

\*\*\*\*\*

3 distinct matching regions detected in reference.

Recommended matching region:

Prim fm\_m1876/C1

Prim C782

Port e\_cd\_en

Alternate matching regions:

Prim fm\_m171f/C1

Prim fm\_m1876/C1

Port e\_cd\_en

---

## SEE ALSO

diagnose(2)

---

## report\_dont\_cuts

Reports the dont-cut points that are set using the **set\_dont\_cut** command.

---

### SYNTAX

status **report\_dont\_cut**

---

### ARGUMENTS

This command has no arguments.

---

### DESCRIPTION

This command reports the user-specified dont-cut points in the current design.

---

### EXAMPLES

```
fm_shell (setup)> report_dont_cut
*****
Report      : dont_cut

Reference   : r:/WORK/top
Implementation : i:/WORK/top
Version     : G-2012.06-Beta4
Date       : Mon Apr 23 16:43:04 2012
*****

Object
Type   Object Name
-----
pin    r:/WORK/top/block/IN

1
```

---

### SEE ALSO

set\_dont\_cut(2)  
remove\_dont\_cut(2)

---

## report\_dont\_match\_points

Reports the dont\_match points that are set using the **set\_dont\_match\_point** command.

---

### SYNTAX

status **report\_dont\_match\_points**

---

### ARGUMENTS

This command has no arguments.

---

### DESCRIPTION

The **report\_dont\_match\_points** command reports the objects that are defined as dont\_match using the **set\_dont\_match\_point** command.

---

### EXAMPLES

The following example shows a report of three dont\_match points.

```
fm_shell (setup)> report_dont_match_points
*****
```

```
Report      : dont_match_points
```

```
Reference   : ref:/mp_gt
```

```
Implementation : impl:/mp_gt
```

```
Version     : H-2013.03
```

```
Date       : Mon Mar 11 12:46:37 2013
```

```
*****
```

Don't match points:

```
(Port) impl:/mp_gt/IBM_CMOS_GApwr.db/CORE/mydesign
```

```
(Port) ref:/mp_gt/IBM_CMOS_GApwr.db/CORE/mydesign
```

```
(Reg) impl:/mp_gt/IBM_CMOS_GApwr.db/CORE/STATE_2
```

---

### SEE ALSO

remove\_dont\_match\_points(2)

set\_dont\_match\_points(2)

report\_matched\_points(2)

report\_unmatched\_points(2)



---

## report\_dont\_reverse

Reports the dont-reverse points that are set using the **set\_dont\_reverse** command.

---

### SYNTAX

status **report\_dont\_reverse**

---

### ARGUMENTS

This command has no arguments.

---

### DESCRIPTION

This command reports the user-specified dont-reverse points in the current design.

---

### EXAMPLES

```
fm_shell (setup)> report_dont_reverse
*****
Report      : dont_reverse

Reference   : r:/WORK/top
Implementation : i:/WORK/top
Version     : G-2012.06-Beta4
Date        : Mon Apr 23 16:43:04 2012
*****

Object
Type   Object Name
-----
cell   r:/WORK/top/block/icg1

1
```

---

### SEE ALSO

set\_dont\_reverse(2)  
 remove\_dont\_reverse(2)  
 verification\_clock\_gate\_reverse\_gating(3)

---

## report\_dont\_verify\_points

Reports dont\_verify points that are set by using the **set\_dont\_verify\_point** command.

---

### SYNTAX

status **report\_dont\_verify\_points**

---

### ARGUMENTS

This command has no arguments.

---

### DESCRIPTION

This command reports the compare points that are defined as dont\_verify by using the **set\_dont\_verify\_point** command.

The dont\_verify points are not applied to the designs until you run the **match** or the **verify** commands. After using the commands, use the **report\_matched\_points -point\_type dont\_verify** and **report\_unmatched\_points -point\_type dont\_verify** commands to see which compare points are marked as dont\_verify.

---

### EXAMPLES

The following example shows a report of three dont\_verify points.

```
fm_shell (setup)> report_dont_verify_points
*****
Report      : dont_verify_points

Reference   : ref:/mp_gt
Implementation : impl:/mp_gt
Version     : G-2012.06
Date       : Wed Jun 6 12:46:37 2012
*****

Dont verify points:

(Port) impl:/mp_gt/IBM_CMOS_GApwr.db/CORE/mydesign
(Port) ref:/mp_gt/IBM_CMOS_GApwr.db/CORE/mydesign
(Reg)  impl:/mp_gt/IBM_CMOS_GApwr.db/CORE/STATE_2

fm_shell (setup)>
```

---

### SEE ALSO

```
remove_dont_verify_points(2)  
report_matched_points(2)  
report_unmatched_points(2)  
set_dont_verify_points(2)
```

---

## report\_dp\_int\_round

Reports any rounding information for multipliers and how it was applied.

---

### SYNTAX

**report\_dp\_int\_round**

---

### ENABLED SHELL MODES

Setup

---

### DESCRIPTION

Reports any rounding information associated with multipliers and how it was applied.

---

### EXAMPLES

```
fm_shell (guide)> report_dp_int_round  
report_dp_int_round
```

Instances with rounding information  
(\* if rounding was not used)

```
-----  
16 14 r:/WORK/top/U1/mult_x_2  
1
```

---

### SEE ALSO

set\_dp\_int\_round(2)  
remove\_dp\_int\_round(2)

---

## report\_dpx\_options

Reports DPX options.

---

### SYNTAX

status **report\_dpx\_options**

---

### LICENSE

This command is available when the "Formality-DPX" license key is used.

---

### DESCRIPTION

This command reports all the user-specified DPX options within Formality.

---

### EXAMPLES

The following example illustrates the command when `set_dpx_options` has not been specified by the user:

```
fm_shell (setup)> report_dpx_options
*****
Report      : dpx_options

Reference   : <None>
Implementation : <None>
Version     : R-2020.09-SP1
Date        : Tue Sep 29 07:46:14 2020
*****
No options specified by user in set_dpx_options.
1
```

The following example illustrates the command after the `set_dpx_options` command has been issued with options `-protocol SH`, `-submit_command sh`, `-max_cores 2`, and `-max_workers 3`:

```
fm_shell (setup)> report_dpx_options
*****
Report      : dpx_options

Reference   : <None>
Implementation : <None>
Version     : R-2020.09-SP1
Date        : Tue Sep 29 12:42:30 2020
*****
Communication protocol or grid type : SH
Worker submit command               : sh
Max concurrent workers              : 3
Max cores available per worker      : 2
```

1

---

## SEE ALSO

set\_dpx\_options(2)  
remove\_dpx\_options(2)

---

## report\_eco\_data

Reports the ECO names from the database file.

---

### SYNTAX

status **report\_eco\_data** <file>

---

### LICENSE

This command is available when the "Formality-LogicECO" license key is used.

---

### DESCRIPTION

For the given database this command reports all the ECO names in the executed order.

---

### EXAMPLE

```
fm_shell(setup) > report_eco_data fm_eco.frd
*****
Report      : report_eco_data

Version     : <version>
Date        : <date & time>
*****
ECO database includes 2 ECOs, implemented in the following order:
eco1
ECO2
```

---

### SEE ALSO

set\_eco\_data  
write\_eco\_regions

---

## report\_eco\_impact

Reports the impact of the ECO on the original netlist.

---

### SYNTAX

```
integer report_eco_impact  
  [-scan str]  
  [-unread]  
  [-size]  
  [-all]  
  [-cell designId_list]
```

#### Data Types

*str* string  
*designId\_list* string

#### Enabled Shell Modes

Match Verify

---

### LICENSE

This command is available when the "Formality-LogicECO" license key is used.

---

### ARGUMENTS

#### -scan *str*

Reports the impact the ECO has had on the scan chain. New registers introduced by the ECO are excluded from the scan chain. Replacements for banked register bits are also excluded from the scan chain, however the original banked bit remains on the scan chain but is unread on the functional path. ECO's performed on scan-shift registers result in a broken scan chain.

Specify one of the following values for the *str* argument:

- *new* - Report newly introduced registers.
- *multibit* - Report patched multibit registers.
- *shift* - Report shift registers.
- *all* - Report all of the above.

#### -unread

Reports registers that are left with no readers after the ECO.

#### -size

Reports the ECO patch size.



**-all**

Produces all of the above reports (-scan all, -unread and -size)

**-cell *designId\_list***

Reports which cells among the passed list of cells were either made unused or impacted by the ECO. A cell is considered to be impacted by the ECO if any net in the fanin or fanout cone of that cell was ECO'd.

---

## DESCRIPTION

The **report\_eco\_impact** command reports on the impact that the ECO patch has on the original netlist.

It should be run in **match** or **verify** modes after successfully generating an ECO patch.

An ECO patch can cause the addition (removal) of new (existing) registers, which can impact the scan chain of the design because it hasn't been rewired to accommodate the additional (removed) register. The **-scan** option of this command can be used to summarize the scan chain impacts of the ECO patch.

Registers that are left without any readers after the ECO can be obtained using the **-unread** option.

Use the **-size** option for a summary of the total number of cells/nets/ports added and removed.

---

## EXAMPLES

The following command produces all of the ECO impact reports:

```
verify> report_eco_impact -all
*****
Report      : report_eco_impact
            -all

Version     : Q-2019.12
Date       : Thu Jan 23 10:18:19 2020
*****
```

The following registers were introduced by the ECO and are not on the scan chain:

New DFF onet:/WORK/test/IECO\_region1\_R4\_reg

The following registers were patched by the ECO and are no longer shift-registers.  
As a result the scan chain is broken:

Shift DFF onet:/WORK/test/R2\_reg

ECO patch (fm\_eco\_region.patch.tcl) introduces 6 cells, 6 nets, 0 ports and  
removes 3 cells, 2 nets.

The following commands reports the names of special cells that were removed or impacted by the ECO:

```
verify> report_eco_impact -cell [get_cell -h *LS*]
*****
Report      : report_eco_impact

Version     : Q-2019.12
Date       : Thu Jan 23 11:13:49 2020
*****
```

ECO patch (fm\_eco\_region.patch.tcl) introduces 3 cells, 0 nets, 0 ports and removes 6 cells, 3 nets.

The following special cells are currently unused:

Unused cell : i:/WORK/top/LSDOWN1 (LSDOWNX1\_HVT)

Unused cell : i:/WORK/top/LSDOWN2 (LSDOWNX1\_HVT)

The following special cells fanout was potentially impacted by the ECO patch:

Impacted cell : i:/WORK/top/LSUP (LSUPX1\_HVT)

1

---

## SEE ALSO

---

## report\_edits

Reports the recorded edit commands.

---

### SYNTAX

**report\_edits**

#### Enabled Shell Modes

Setup  
Match  
Verify

---

### DESCRIPTION

This command reports the recorded edit commands (such as **create\_net** and **disconnect\_net**). The edit commands shown are the ones that can be used by Design Compiler or IC Compiler to replicate the edits performed in Formality.

Use the command **record\_edits** to enable and disable recording.

All edit commands are shown except ones that occurred while recording was turned off and ones that are reverted using the **undo\_edits** command.

---

### SEE ALSO

create\_net(2)  
disconnect\_net(2)  
record\_edits(2)  
remove\_net(2)  
write\_edits(2)

---

## report\_electrical\_checks

Checks the connectivity of the circuit.

---

### SYNTAX

```
report_electrical_checks  
[ -unconnected_ports ]  
[ -unconnected_pins ]  
[ -output_pins_tied_to_constants ]  
[ -multiply_driven_pins ]  
[ -multiply_driven_ports ]  
[ -unread_nets ]  
[ -undriven_nets ]  
[ -unreachable_cells ]  
[ -uninstantiated_designs ]  
[ -list ]  
[ -edits ]  
[ design_list ]
```

#### Data Types

*design\_list* list of strings

---

### ARGUMENTS

#### **-unconnected\_pins**

Checks for pins that are not connected. All pins are checks on primitive gates and tech cells. Only IN and IN/OUT pins are checks on other cells.

#### **-unconnected\_ports**

Checks for ports that are not connected.

#### **-output\_pins\_tied\_to\_constants**

Checks for OUT and IN/OUT pins that are tied directly to a constant net.

#### **-multiply\_driven\_pins**

Checks for pins driven by multiple sources.

#### **-multiply\_driven\_ports**

Checks for ports driven by multiple sources.

#### **-unread\_nets**

Checks for nets without a receiver.

#### **-undriven\_nets**

Checks for nets without a driver.

#### **-unreachable\_cells**

Checks for cells that cannot be reached from cell inputs or constant nets.

### **-uninstantiated\_designs**

Checks for designs that are not instantiated by at least one cell.

### **-list**

Report the results of the checks as a Tcl list. You can use this list in further Tcl processing.

### **-edits**

Perform the checks in the designs affected by edit commands like **create\_net** and **connect\_net**.

### **design\_list**

Performs the checks in these designs.

This option can be combined with the \fi-edits option. If neither options are use, the command checks all implementation designs.

---

## DESCRIPTION

This command performs a number of checks of the connectivity of the circuit. The format is either a report of the objects that failed the checks, or, if the **-list** option is used, a Tcl list.

The Tcl output is a list of alternating keys and values. The values are lists of objects.

```
UNCONNECTED_PINS <PINS>
UNCONNECTED_PORTS <PORTS>
MULTIPLY_DRIVEN_PINS <PORTS>
MULTIPLY_DRIVEN_PORTS <PORTS>
OUTPUT_PINS_TIED_TO_CONSTANT <PINS>
UNREAD_NETS <NETS>
UNDRIVEN_NETS <NETS>
UNREACHABLE_CELLS <CELLS>
UNINSTANTIATED_DESIGNES <DESIGNS>
```

By default, the **report\_electrical\_checks** command performs all the checks on all implementation designs. However, you can limit the checks it performs via the command options, and you can specify the designs you want to check.

---

## EXAMPLES

The following example performs all checks on all implemenetation designs:

```
fm_shell> report_electrical_checks
Processing design: i:/WORK/M_RTL_ADD_UN_4

Processing design: i:/WORK/alt_bot1
Design not instantiated: i:/WORK/alt_bot1

Processing design: i:/WORK/alt_bot2

Processing design: i:/WORK/bot
Output pins tied to constants in design: i:/WORK/bot
out i:/WORK/bot/C0/OUT
Unread nets in design: i:/WORK/bot
i:/WORK/bot/fm_N7[10]
i:/WORK/bot/fm_N7[11]
i:/WORK/bot/fm_N7[8]
i:/WORK/bot/fm_N7[9]
Undriven nets in design: i:/WORK/bot
i:/WORK/bot/fm_N7[4]
```

```
i:/WORK/bot/fm_N7[5]  
i:/WORK/bot/fm_N7[6]
```

```
Processing design: i:/WORK/mid  
Unconnected ports on design: i:/WORK/mid  
in i:/WORK/mid/mck  
Unconnected pins on cells in design: i:/WORK/mid  
in i:/WORK/mid/MY_PRIM/IN1  
in i:/WORK/mid/MY_PRIM/IN2  
out i:/WORK/mid/MY_PRIM/OUT  
Undriven nets in design: i:/WORK/mid  
i:/WORK/mid/mck  
Unreachable cells in design: i:/WORK/mid  
i:/WORK/mid/MY_PRIM
```

```
Processing design: i:/WORK/top  
Unread nets in design: i:/WORK/top  
i:/WORK/top/i5  
Undriven nets in design: i:/WORK/top  
i:/WORK/top/o5
```

---

## SEE ALSO

```
create_net(2)  
connect_net(2)
```

---

## report\_error\_candidates

Reports error candidates for the previous diagnosis.

---

### SYNTAX

```
status report_error_candidates
  [-compare_point compare_point]
  [-design design]
  [-percentage percentage]
  [-techlib]
  [-expand type]
```

#### Data Types

```
compare_point string
design string
percentage integer
type string
```

---

### Enabled Shell Modes

Verify

---

### ARGUMENTS

#### **-compare\_point *compare\_point***

This option is obsolete.

#### **-design *design***

This option is obsolete.

#### **-percentage *percentage***

Reports error candidates that are above a specific percentage. Specify a value between 0 to 100.

#### **-techlib**

This option is obsolete.

#### **-expand *type***

Reports detailed information on the technology library and DesignWare components. Specify one of the following values for the *type* argument:

- **false** - Excludes details of technology library and DesignWare component cells from the report.
- **auto** - Includes details of only the cells containing multiple sequential elements, feedback loops, or other logic that can modify the output value of the cell in the report. This is the default mode.

- **true** - Includes details of only the technology library and DesignWare component cells in the report. Only the elements that are part of the error candidate are listed.

---

## DESCRIPTION

This command reports error candidates for the previous diagnosis. Error candidates are driver objects in the design whose state during verification might fail the verification.

If the design has multiple errors, diagnosis might identify error candidates that are comprised of multiple error drivers. The **report\_error\_candidates** command reports the number of distinct errors and error candidates. Diagnosis might find close alternative error candidates that can also be used to correct the failures, in addition to the recommended candidate.

The report contains a recommended candidate, an optional list of alternative candidates, and the type of the driver.

---

## EXAMPLES

The following example shows a list of error candidates for a single error diagnosis. The command reports two error candidates, each of type cell:

```
fm_shell (verify)> report_error_candidates
*****
Report      : error_candidates

Reference   : ref:/WORK
Implementation : impl:/my_lib
Version     : G-2012.06
Date       : Wed Jun 6 12:46:37 2012
*****
```

Single error detected in implementation.

Recommended error candidate:

Cell U4072

Alternate error candidates:

1. Cell U4071

1

The following example shows a list of four error candidates, with two drivers each.

```
fm_shell (verify)> report_error_candidates
*****
Report      : error_candidates

Reference   : ref:/WORK
Implementation : impl:/my_lib
Version     : G-2012.06
Date       : Wed Jun 6 12:46:37 2012
*****
```

2 distinct errors detected in implementation.

Recommended error candidate:

U5036  
U4652

Alternate error candidates:

1. bd\_cpu\_end\_reg  
U4652

2. U5036  
bd\_underflow\_prev\_reg



```
3. bd_cpu_end_reg  
   bd_underflow_prev_reg
```

```
1
```

---

## SEE ALSO

```
diagnose(2)  
report_diagnosed_matching_regions(2)
```

---

## report\_factor\_points

Reports factoring variables that are set by using the **set\_factor\_point** command.

---

### SYNTAX

status **report\_factor\_points**

---

### ARGUMENTS

This command has no arguments.

---

### DESCRIPTION

This command reports factoring variables that are set by using the **set\_factor\_point** command.

---

### EXAMPLES

```
fm_shell (setup)> report_factor_points
*****
Report      : factor_points

Reference   : r:/WORK/top
Implementation : i:/WORK/top
Version     : G-2012.06
Date       : Wed Jun 6 12:46:37 2012
*****

Object
Type   Object Name
-----
port   r:/WORK/top/data1
port   r:/WORK/top/data2
port   r:/WORK/top/data3

1
```

---

### SEE ALSO

set\_factor\_point(2)  
remove\_factor\_point(2)

---

## report\_failing\_points

Reports compare points that fail verification.

---

### SYNTAX

```
int report_failing_points
  [-compare_rule]
  [-substring substring]
  [-point_type point_type]
  [-matched]
  [-unmatched]
  [-status status]
  [-inputs input_type]
  [-list]
  [-last]
  [-never_loads]
  [-always_reset]
```

#### Data Types

```
substring string
point_type string
status string
input_type string
```

---

### Enabled Shell Modes

```
Match
Verify
```

---

### ARGUMENTS

#### -compare\_rule

Reports object names that are mapped because of the application of compare rules.

#### -substring *substring*

Reports the compare points that contain the specified substring.

#### -point\_type *point\_type*

Reports the compare points with characteristics that match the specified types. By default, all compare point types are included. Specify the following point types:

- *bbox\_pin* - Reports black box pin compare points
- *bbox\_input* - Reports black box input pin compare points
- *bbox\_inout* - Reports black box bidirectional pin compare points

- *loop* - Reports loop compare points
- *bbox\_net* - Reports multiply-driven nets that are resolved using black boxes
- *cut* - Reports cutpoints
- *port* - Reports port compare points
- *output* - Reports output port compare points
- *inout* - Reports bidirectional port compare points
- *directly\_undriven\_output* - Reports output and bidirectional ports that do not have a connected net, or have a connected net but do not have a driving pin
- *reg* - Reports register compare points
- *DFF* - Reports flip-flop register compare points
- *LAT* - Reports latch register compare points
- *trans* - Reports transparent latch register compare points
- *PDCut* - Reports power domain pin compare points
- *PGPin* - Reports power, ground, or power-down function compare points

**-matched**

Reports the matched design objects.

**-unmatched**

Reports the unmatched design objects.

**-status *status***

Reports only the compare points that have the specified polarity. By default, the command reports compare points of any polarity. Specify one or both of the following *status* values:

- *inverted* - to report compare point pairs with inverted polarity.
- *noninverted* - to report compare point pair with noninverted polarity.

**-inputs *input\_type***

Reports only the compare points with undriven or unmatched input points. Specify one or both of the following input types.

- *undriven* - to report compare points with undriven input points.
- *unmatched* - to report compare points with unmatched input points.

**-list**

Reports a list of compare point pairs.

**-last**

Reports a list of compare point pairs from the previous verification.

**-never\_loads**

Filters the report to only include register compare point pairs that do not synchronously load.

**-always\_reset**

Filters the report to only include register compare point pairs that are constantly reset.

## DESCRIPTION

This command reports compare points that failed the previous verification. A failing compare point consists of two design objects that are not equivalent or a compare point having an unmatched design object.

The command lists the number of failing compare points followed by paired design objects for each failing compare point. Each item in the report lists the design object, the design that contains the failing compare point (implementation or reference design), the design object type, and the design ID. When you use the **-unmatched** option, the number of failing compare points is followed by the unpaired design objects.

## EXAMPLES

The following example shows a failing point report.

```
fm_shell> report_failing_points
*****
Report      : failing_points

Reference   : OPT:/WORK/CORE
Implementation : SCAN:/WORK/CORE
Version     : G-2012.06
Date       : Wed Jun 6 12:46:37 2012
*****

20 Failing compare points (20 matched, 0 unmatched):

Ref DFF     OPT:/WORK/CORE/REG_BLK/INT_REG_reg[10]
Impl DFF     SCAN:/WORK/CORE/REG_BLK/INT_REG_reg[10]

Ref DFF     OPT:/WORK/CORE/REG_BLK/INT_REG_reg[11]
Impl DFF     (-) SCAN:/WORK/CORE/REG_BLK/INT_REG_reg[11]

Ref DFF     OPT:/WORK/CORE/REG_BLK/INT_REG_reg[12]
Impl DFF     (-) SCAN:/WORK/CORE/REG_BLK/INT_REG_reg[12]

Ref DFF     OPT:/WORK/CORE/STACK_BLK/MEM_reg[2][10]
Impl DFF     (-) SCAN:/WORK/CORE/STACK_BLK/MEM_reg[2][10]

Ref DFF     OPT:/WORK/CORE/STACK_BLK/MEM_reg[2][11]
Impl DFF     (-) SCAN:/WORK/CORE/STACK_BLK/MEM_reg[2][11]

Ref DFF     OPT:/WORK/CORE/STACK_BLK/MEM_reg[2][12]
Impl DFF     (-) SCAN:/WORK/CORE/STACK_BLK/MEM_reg[2][12]

Ref DFF     OPT:/WORK/CORE/STACK_BLK/MEM_reg[2][1]
Impl DFF     SCAN:/WORK/CORE/STACK_BLK/MEM_reg[2][1]

Ref DFF     OPT:/WORK/CORE/STACK_BLK/MEM_reg[2][3]
Impl DFF     SCAN:/WORK/CORE/STACK_BLK/MEM_reg[2][3]

Ref DFF     OPT:/WORK/CORE/STACK_BLK/MEM_reg[2][4]
Impl DFF     SCAN:/WORK/CORE/STACK_BLK/MEM_reg[2][4]

Ref DFF     OPT:/WORK/CORE/STACK_BLK/MEM_reg[2][5]
Impl DFF     SCAN:/WORK/CORE/STACK_BLK/MEM_reg[2][5]

Ref DFF     OPT:/WORK/CORE/STACK_BLK/MEM_reg[2][6]
Impl DFF     SCAN:/WORK/CORE/STACK_BLK/MEM_reg[2][6]

Ref DFF     OPT:/WORK/CORE/STACK_BLK/MEM_reg[2][7]
Impl DFF     SCAN:/WORK/CORE/STACK_BLK/MEM_reg[2][7]

Ref DFF     OPT:/WORK/CORE/STACK_BLK/MEM_reg[2][8]
Impl DFF     SCAN:/WORK/CORE/STACK_BLK/MEM_reg[2][8]
```

Ref DFF	OPT:/WORK/CORE/STACK_BLK/MEM_reg[2][9]
Impl DFF	SCAN:/WORK/CORE/STACK_BLK/MEM_reg[2][9]
Ref DFF	OPT:/WORK/CORE/STACK_BLK/MEM_reg[4][10]
Impl DFF	SCAN:/WORK/CORE/STACK_BLK/MEM_reg[4][10]
Ref DFF	OPT:/WORK/CORE/STACK_BLK/MEM_reg[4][11]
Impl DFF	SCAN:/WORK/CORE/STACK_BLK/MEM_reg[4][11]
Ref DFF	OPT:/WORK/CORE/STACK_BLK/MEM_reg[4][12]
Impl DFF	SCAN:/WORK/CORE/STACK_BLK/MEM_reg[4][12]
Ref DFF	OPT:/WORK/CORE/STACK_BLK/MEM_reg[4][1]
Impl DFF	SCAN:/WORK/CORE/STACK_BLK/MEM_reg[4][1]
Ref DFF	OPT:/WORK/CORE/STACK_BLK/MEM_reg[4][3]
Impl DFF	SCAN:/WORK/CORE/STACK_BLK/MEM_reg[4][3]
Ref DFF	OPT:/WORK/CORE/STACK_BLK/MEM_reg[4][4]
Impl DFF	SCAN:/WORK/CORE/STACK_BLK/MEM_reg[4][4]

[BBNet: multiply-driven net

BBPin: black box pin

Cut: cut-point

DFF: non-constant DFF register

DFF0: constant 0 DFF register

DFF1: constant 1 DFF register

DFFX: constant X DFF register

DFF0X: constrained 0X DFF register

DFF1X: constrained 1X DFF register

LAT: non-constant latch register

LAT0: constant 0 latch register

LAT1: constant 1 latch register

LATX: constant X latch register

LAT0X: constrained 0X latch register

LAT1X: constrained 1X latch register

LATCG: clock-gating latch register

TLA: transparent latch register

TLA0X: transparent constrained 0X latch register

TLA1X: transparent constrained 1X latch register

Loop: cycle break point

Port: primary (top-level) port

Und: undriven signal cut-point]

1

---

## SEE ALSO

report\_aborted\_points(2)  
 report\_matched\_points(2)  
 report\_passing\_points(2)  
 report\_unmatched\_points(2)  
 report\_unverified\_points(2)  
 report\_not\_compared\_points(2)

---

## report\_feedthrough\_points

Reports the feedthrough commands applied to this verification. Feedthrough commands are specified via the `set_feedthrough_points` command.

---

### SYNTAX

status **report\_feedthrough\_points**

#### Enabled Shell Modes

Setup  
preverify  
match  
verify

---

### ARGUMENTS

This command has no arguments.

---

### DESCRIPTION

This command reports all the feedthrough commands applied to the current Formality verification.

---

### EXAMPLES

The following example creates a report about all the feedthrough commands applied to this Formality verification.

```
fm_shell> report_feedthrough_points
```

```
*****  
Report      : feedthrough_points  
Reference   : r:/WORK/TOP  
Implementation : i:/WORK/TOP  
*****
```

4 Feedthrough Specifications:

```
Design: i:/WORK/A  
Input: clock__FEEDTHRU_0  
Output: clock__FEEDTHRU_1
```

```
Design: i:/WORK/A  
Input: Constant 0  
Output: z[2]
```

```
Design: i:/WORK/C
Input: clock__FEEDTHRU_0
Output: clock__FEEDTHRU_1 (inverted)
```

```
Design: i:/WORK/A
Equivalent: clock clock__FEEDTHRU_0
1
fm_shell>
```

---

## SEE ALSO

```
set_feedthrough_points(2)
report_feedthrough_status(2)
```



---

## report\_feedthrough\_status

Reports the verification status of the feedthrough commands applied to this verification. Feedthrough commands are specified via the `set_feedthrough_points` command.

---

### SYNTAX

status **report\_feedthrough\_status**

#### Enabled Shell Modes

```
setup
preverify
match
verify
```

---

### ARGUMENTS

This command has no arguments.

---

### DESCRIPTION

This command reports the verification status of all the feedthrough commands applied to the current Formality verification.

---

### EXAMPLES

The following example creates a report about all the feedthrough commands applied to this Formality verification and their status. A status of NOT RUN indicates that the feedthrough command specified for those points has not yet been verified and its verification status is unknown.

```
fm_shell> report_feedthrough_status
```

```
*****
Report      : feedthrough_status
Reference   : r:/WORK/TOP
Implementation : i:/WORK/TOP
*****
```

Input	Output	Status
i:/WORK/A/clock	i:/WORK/A/clock__FEEDTHRU_2	NOT RUN
i:/WORK/A/clock__FEEDTHRU_0	i:/WORK/A/clock__FEEDTHRU_1	NOT RUN
i:/WORK/C/clock__FEEDTHRU_0	i:/WORK/C/clock__FEEDTHRU_1	NOT RUN

Equivalent Input Feedthroughs

```
-----  
i:/WORK/A/clock i:/WORK/A/clock__FEEDTHRU_0      PASS  
  
1  
fm_shell>
```

---

## SEE ALSO

set\_feedthrough\_points(2)  
report\_feedthrough\_points(2)

---

## report\_fsm

Reports information on finite state machines (FSM) in a design.

---

### SYNTAX

status **report\_fsm**  
 [-name *FSM\_name* | *designID*]

#### Data Types

*FSM\_name* string  
*designID* string

---

### ARGUMENTS

#### -name *FSM\_name*

Reports state information of the specific FSM.

#### *designID*

Specifies the design for which FSM information is reported. By default, the command reports FSM information in the current design.

---

### DESCRIPTION

This command reports FSM state information in the current design by default, or in a specific design. The report includes the FSM name, state vector flip-flop names and ordering, and the encodings.

---

### EXAMPLES

The following example reports the state encodings for the design impl:/WORK/CORE/FSM.

```
fm_shell> report_fsm impl:/WORK/CORE/FSM
*****
Report      : fsm

Reference   : ref:/WORK
Implementation : impl:/WORK
Version     : G-2012.06
Date       : Wed Jun 6 12:46:37 2012
*****
FM_FSM_0
State Vector:
CURRENT_STATE_reg[1]
CURRENT_STATE_reg[0]
State Encodings:
```

```
S1
10
S2
01
S3
11
SO
00
1
fm_shell>
```

The following example is the same as the preceding example except that it uses the *-name* option to specify the FSM name.

```
fm_shell> report_fsm -name FM_FSM_0
*****
Report      : fsm

Reference   : ref:/WORK
Implementation : impl:/WORK
Version     : G-2012.06
Date       : Wed Jun 6 12:46:37 2012
*****
FM_FSM_0
State Vector:
CURRENT_STATE_reg[1]
CURRENT_STATE_reg[0]
State Encodings:
S1
10
S2
01
S3
11
SO
00
1
fm_shell>
```

---

## SEE ALSO

```
read_fsm_states(2)
set_fsm_encoding(2)
set_fsm_state_vector(2)
```

---

## report\_guidance

Reports the name and the summary of contents of the current automated Setup Verification for Formality (SVF) file(s).

---

### SYNTAX

**report\_guidance**

[*-to filename*]  
[*-pack*]  
[*-datapath*]  
[*-long*]  
[*-short*]  
[*-source*]  
[*-summary*]

**Data Types**

*filename* string

---

### ARGUMENTS

**-to *filename***

Specifies the name of the output file. If an intermediate automated setup file for verification netlist is referenced in the automated setup file, the command stores the unencrypted versions of the referenced netlists in a directory prefixed with fmsvf.

**-pack**

Creates a compressed file containing the output of the **report\_guidance** command. Use this option with the **-to** option.

**-datapath**

Reports a summary of the status of datapath transformations.

**-long**

Reports detailed information on the status of datapath transformations. Use this option with the **-datapath** option.

**-short**

Skip individual guide summary in report

**-source**

Returns the source of the most recently loaded SVF file

**-summary**

Reports a summary of the automated setup file. This option is the default behavior.

---

### DESCRIPTION

This command reports the name and the summary of the contents of the current Setup Verification for Formality (SVF) files. The command overwrites any existing file with the file specified by the **-to** option.

## EXAMPLES

```
fm_shell (setup)> report_guidance
*****
```

```
Report      : guidance
```

```
Reference   : ref:/WORK
Implementation : impl:/WORK
Version     : G-2012.06
Date       : Wed Jun 6 12:46:37 2012
*****
```

```
SVF is not set.
1
```

```
fm_shell (setup)> set_svf myfile.svf
SVF set to 'myfile.svf'.
1
```

```
fm_shell (setup)> report_guidance -to mynewfile.svf
*****
```

```
Report      : guidance
```

```
Reference   : ref:/WORK
Implementation : impl:/WORK
Version     : G-2012.06
Date       : Wed Jun 6 12:46:37 2012
*****
```

```
SVF files read:
myfile.svf
```

```
SVF files produced:
mynewfile.svf/
svf.txt
d1/
```

Note that if there are references to intermediate encrypted netlists in the automated setup file for verification such as

```
guide_architecture_netlist -file { dwsvf_7839-0/dwarchs_0.v.e } { lsi_10k }
```

then the decrypted automated setup file for verification has new references to the decrypted netlists such as **guide\_architecture\_netlist -file { fmsvf\_7839-0/dwarchs\_0.v } { lsi\_10k }**

```
fm_shell (setup)> report_guidance -summary
*****
```

```
Report      : guidance
```

```
Reference   : ref:/WORK
Implementation : impl:/WORK
Version     : G-2012.06
Date       : Wed Jun 6 12:46:37 2012
*****
```

Command	Status				
	Accepted	Rejected	Unsupported	Unprocessed	Total
architecture_netlist:	1	0	0	0	1
change_names :	1	37	0	0	38
datapath :	0	2	0	0	2
inv_push :	19	0	0	0	19
reg_constant :	1	0	0	0	1
transformation					
map :	66	0	0	0	66
merge :	2	0	0	0	2
share :	8	0	0	0	8

Note: If verification succeeds you can safely ignore unaccepted guidance commands.

SVF files read:  
myfile.svf

SVF files produced:  
formality\_svf/  
svf.txt  
d1/

---

## SEE ALSO

set\_svf(2)  
remove\_guidance(2)  
find\_svf\_operation(2)  
report\_svf\_operation(2)

---

## report\_hdlin\_mismatches

Reports the RTL simulation or synthesis mismatches that occurred during design linking.

---

### SYNTAX

**report\_hdlin\_mismatches**  
[-summary | -verbose]  
[-reference]  
[-implementation]  
[-container *containerName*]

#### Data Types

*containerName* string

#### Enabled Shell Modes

Verify

---

### ARGUMENTS

#### -summary

Reports a summary of mismatches.

#### -verbose

Reports detailed information about mismatches, including a list of all locations. This is the default behavior.

#### -reference

Reports mismatches in the current reference container.

#### -implementation

Reports mismatches in the current implementation container.

#### -container *containerName*

Reports mismatches in the specified container.

---

### DESCRIPTION

This command reports information about simulation or synthesis mismatches that occur during the setup of the specified containers.

---

### EXAMPLES



```
fm_shell (verify)> report_hdlin_mismatches
```

[Verbose report of the current container]

```
fm_shell (verify)> report_hdlin_mismatches -r -i -s
```

[Summary report of both the reference and implementation container]

```
fm_shell (verify)> report_hdlin_mismatches -s -c myContainer
```

[Summary report of the named container]

---

## report\_hierarchy

Reports the hierarchy of a design.

---

### SYNTAX

status **report\_hierarchy**  
[*designID*]  
[-level *integer*]

#### Data Types

*designID* string  
*integer* integer

---

### ARGUMENTS

#### *designID*

Specifies a design. By default, the command reports the hierarchy of the current design.

#### **-level** *integer*

Report only the designs at or above this level (top level design is level 0). The specified integer must be greater than or equal to zero.

---

### DESCRIPTION

This command reports the hierarchy of a design. The report does not include the hierarchy of a technology library component.

To report the hierarchy of a specific design, use the *designID* argument. If you do not specify a design, the tool reports the current design by default.

By default, the entire design hierarchy is displayed. By using the **-level** option, you can print up to a level. Note that the numbering starts from 0 for the top level design and continues down the hierarchy.

Each report has a banner that includes the design name, optional level specification, followed by the number of unresolved references in the design.

---

### EXAMPLES

This example shows part of the report for a large design:

```
fm_shell> report_hierarchy i:/bentle.db
*****
Report      : hierarchy
```

```

Reference    : r:/bentle
Implementation : i:/bentle
Version      : G-2012.06
Date        : Wed Jun 6 12:46:37 2012
*****
*****

Report : hierarchy
Design : bentle
*****

Warning: 50 unresolved references are not included in
this report. (RPT-2)
bentle
FD1AH      cg51_convex
ITCUH      cg51_io_convex
IntCtrl
.
.
.
IntCtrl_go
AF1L (24)  cg51_convex
AN4L cg51_convex
AN223L
AN224L (unlinked)
fm_shell>

```

This example shows the usage of -level option:

```

fm_shell> report_hierarchy -level 3
*****

Report      : hierarchy
              -level 3

Reference    : r:/WORK/top
Implementation : <None>
Version      : L-2016.03
Date        : Tue Dec 8 02:23:08 2015
*****

Design: top

top          WORK
Formality Primitives (2)
midA         WORK
Formality Primitives (2)
botA         WORK
Formality Primitives (2)
botB         WORK
midB         WORK
Formality Primitives (2)
botB         WORK
Formality Primitives (2)
dff          WORK
1

```

```

fm_shell> report_hierarchy -level 1
*****

Report      : hierarchy
              -level 1

Reference    : r:/WORK/top
Implementation : <None>
Version      : L-2016.03
Date        : Tue Dec 8 02:23:08 2015
*****

Design: top

top          WORK
Formality Primitives (2)
midA         WORK
midB         WORK
1

```

---

## SEE ALSO

[report\\_designs\(2\)](#)

---

## report\_host\_options

Reports the options that set using the **set\_host\_options** command.

---

### SYNTAX

status **report\_host\_options**

---

### DESCRIPTION

This command reports the options that are set using the **set\_host\_options** command.

---

### EXAMPLES

This example shows how to use the **report\_host\_options** command.

```
fm_shell (setup)> report_host_options  
max_cores: 4  
1
```

---

### SEE ALSO

set\_host\_options(2)

---

## report\_init\_toggle\_assumption

Reports the initial toggle assumption on a controlling object(s).

---

### SYNTAX

**report\_init\_toggle\_assumption**  
[-all | *object\_list*]

#### Data Types

*object\_list* string

#### Enabled Shell Modes

All modes

---

### ARGUMENTS

#### *object\_list*

Specifies the object(s) whose initial toggle assumptions need to be reported.

#### -all

Reports all the initial toggle assumptions.

---

### DESCRIPTION

Reports the initial toggle assumption on a controlling object(s) set by the `set_init_toggle_assumption` command.

---

### EXAMPLES

The following example reports the initial toggle assumption on *i:/WORK/bit\_slice/hclk*.

```
fm_shell (setup)> report_init_toggle_assumption i:/WORK/bit_slice/hclk
Object i:/WORK/bit_slice/hclk has been assumed to not toggle during initialization
1
```

The following example reports all the initial toggle assumptions..

```
fm_shell (setup)> report_init_toggle_assumption -all
Object i:/WORK/bit_slice/hclk has been assumed to not toggle during initialization
Object i:/WORK/bit_slice/lclk has been assumed to not toggle during initialization
1
```

---

## SEE ALSO

`set_init_toggle_assumption(2)`  
`remove_init_toggle_assumption(2)`

---

## report\_init\_toggle\_objects

Reports all objects that are assumed to toggle and not toggle that can initialize potentially constant registers. Includes objects identified by the initialization mode and those set by user.

---

### SYNTAX

```
report_init_toggle_objects
[-toggle_objects]
[-no_toggle_objects]
```

---

### ARGUMENTS

#### -toggle\_objectsP

Report only the objects assumed to toggle that initialize potentially constant registers

#### -no\_toggle\_objects

Report only the objects assumed to not toggle that can initialize potentially constant registers

#### Enabled Shell Modes

Match  
Verify

---

### DESCRIPTION

This command reports all objects assumed to toggle and not toggle that can initialize potentially constant registers. Includes objects identified by the initialization mode and those set by user.

---

### EXAMPLES

The following example reports all objects assumed to toggle and not toggle.

```
fm_shell (verify)> report_init_toggle_objects
*****
Report      : init_toggle_objects

Reference   : r:/WORK/bit_slice
Implementation : i:/WORK/bit_slice
Version     : O-2018.06-BETA-20180520
Date        : Mon May 21 07:13:16 2018
*****
No-Toggle Objects:
  -i:/WORK/bit_slice/badclk
1
```



---

## SEE ALSO

report\_potentially\_constant\_registers(2)  
set\_init\_toggle\_assumption(2)  
report\_init\_toggle\_assumption(2)  
remove\_init\_toggle\_assumption(2)

---

# report\_input\_value\_range

Reports the input value ranges set by the **set\_input\_value\_range** command.

---

## SYNTAX

```
status report_input_value_range
      [objectID_list]
```

### Data Types

*objectID\_list* string

### Enabled Shell Modes

Setup

---

## ARGUMENTS

*objectID\_list*

Reports the input value range of the specified design objects.

---

## DESCRIPTION

This command reports the input value ranges set by the **set\_input\_value\_range** command.

---

## EXAMPLES

The following example report input value range for all design objects.

```
fm_shell (setup)> report_input_value_range
*****
Report      : input_value_range

Reference   : r:/WORK/top
Implementation : i:/WORK/top
Version     : G-2012.06
Date       : Wed Jun 6 12:46:37 2012
*****
Input      Object
Range      Type  Object Name
-----
-----
```

```
01X    port  r:/WORK/top/d
1X     port  r:/WORK/top/rst
1
```

The following example report input value range for the r:/WORK/top/PI1 object.

```
fm_shell (setup)> report_input_value_range r:/WORK/top/PI1
*****
Report      : input_value_range

Reference   : r:/WORK/top
Implementation : i:/WORK/top
Version     : G-2012.06
Date       : Wed Jun 6 12:46:37 2012
*****

Input      Object
Range      Type   Object Name
-----
0X         port   r:/WORK/top/PI1
1
```

---

SEE ALSO

- set\_input\_value\_range(2)
- remove\_input\_value\_range(2)
- write\_hierarchical\_verification\_script(2)

---

## report\_inv\_push

Reports the inversions moved across register boundaries that are specified by the **set\_inv\_push** command, or via SVF inversion push guidance.

---

### SYNTAX

```
status report_inv_push
      [designID]
      [-svf]
      [-diff]
      [-script]
```

#### Data Types

*designID* string

---

### ARGUMENTS

#### *designID*

Reports the inversions moved across register boundaries in the specified design.

#### **-svf**

Reports the inversions moved across register boundaries via SVF inversion push guidance.

#### **-diff**

Implies -svf; reports the differences in SVF inversion push guidance between reference and implementation designs.

#### **-script**

Sames as -diff but the differences are reported in script format.

---

### DESCRIPTION

This command reports the inversions moved across register boundaries that are specified by the **set\_inv\_push** command or via SVF inversion push guidance.

To list inversion push points that are defined for a specific design, specify the *designID* argument. If you do not specify the *designID* argument, the command reports all user- and SVF- defined inversion push points.

To list inversion push specified only via SVF inversion push guidance, specify the **-svf** argument. To limit the report to inversion push differences between reference and implementation, specify the **-diff** argument. If you specify the **-script** argument, the differences will be reported as a series of "set\_user\_match -inverted" commands.

---

## EXAMPLES

This example sets a inversion push point and then reports it.

```
fm_shell> report_inv_push ref:/WORK/CORE
```

```
*****
```

```
Report      : inv_push
```

```
Reference   : ref:/WORK/CORE
```

```
Implementation : impl:/WORK/CORE
```

```
Version     : G-2012.06
```

```
Date       : Wed Jun 6 12:46:37 2012
```

```
*****
```

```
User Defined Inversion Push:
```

```
Object
```

```
Type      Object Name
```

```
-----
```

```
cell      ref:/WORK/CORE/reg_A
```

```
SVF Defined Inversion Push:  None
```

```
1
```

---

## SEE ALSO

```
set_inv_push(2)
```

```
remove_inv_push(2)
```

---

## report\_inversion

Reports information about the user-inserted inversions created using the **insert\_inversion** command.

---

### SYNTAX

status **report\_inversion**

---

### ARGUMENTS

This command has no arguments.

---

### DESCRIPTION

The **report\_inversion** command reports information about inversion inserted using the **insert\_inversion** command. The command reports the total number of user-inserted inversion followed by the list of inversion objects.

---

### EXAMPLES

The following example shows how to use the **report\_inversion** command.

```
fm_shell> report_inversion
User Inserted Inversion:  2

i:/WORK/top/out2_FM_INV
i:/WORK/top/i1_FM_INV
1
```

---

### SEE ALSO

remove\_inversion(2)  
insert\_inversion(2)

---

## report\_libraries

Reports information about the current technology libraries.

---

### SYNTAX

status **report\_libraries**  
[-short]  
[-defects errors | all]  
[-merged\_sequential\_cells]  
[-unused\_cells]  
[libraryID\_list]

#### Data Types

*libraryID\_list* string

---

### ARGUMENTS

#### -short

Reports a summary of the technology libraries. Short, or summary, reports contain just the number of cells, the library name, and indicates whether the library is shared or not.

#### -defects errors | all

Reports information about defects or errors in the technology libraries.

#### -merged\_sequential\_cells

Reports information about merged registers in the technology libraries.

#### -unused\_cells

Reports information about unused cells in the technology libraries. This option can not be used with '-defects errors' and '-merged\_sequential\_cells'.

#### *library\_list*

Reports information about the specified technology libraries. Specify one of the following values for the *library\_list* argument:

- *library\_name* - Specifies the name of a shared technology library. Do not use a preceding slash character (/) as used when specifying a library ID.
- *libraryID* - Specifies a technology library in a specific container. You can use the wildcard character (\*) as part of the design library name.

DESCRIPTION

This command reports information about technology libraries.

Detailed reports include a legend that helps in identifying the type of cell (sequential or black box). In these reports, the list of cells appears after the legend. For each library, the report identifies whether the library is shared or not. For technology libraries that are not shared, the report header includes the container name.

EXAMPLES

This example creates a short report about all technology libraries in the Formality environment. For each library, the report lists cells and their attributes.

```
fm_shell> report_libraries -short

Number of
Cells   Shared   Technology Library
-----
79      Yes     gtech
79      Yes     impl:/gtech
79      Yes     ref:/gtech
1
fm_shell>
```

This example generates a long report about the shared technology library *gtech*. For brevity, the example omits most cell listings. Long reports have an attribute legend at the beginning of the report.

```
fm_shell> report_libraries gtech
*****
Report      : libraries

Reference   : r:/TECH_WORK
Implementation : i:/TECH_WORK
Version     : G-2012.06
Date       : Wed Jun 6 12:46:37 2012
*****

Legend:
Attributes
s = sequential cell
t = tristate
b = BLACKBOX

#####
SHARED TECH LIB - gtech
#####
Library Cell      Attributes
-----
GTECH_ZERO
GTECH_ONE
GTECH_BUF
.
.
.
GTECH_ADD_ABC
GTECH_OUTBUF      t
GTECH_INOUTBUF    t
GTECH_INBUF
GTECH_TBUF        t
GTECH_FD1         b
GTECH_FD14        s
GTECH_FD18        s
.
```



```
.
.
GTECH_LD3          b
GTECH_LD4          b
GTECH_LSR0         b
1
fm_shell>
```

This example creates a report about all the merged registers in technology libraries in the Formality environment.

```
fm_shell>report_libraries -merged_sequential_cells
*****
Report      : libraries

Reference   : r:/TECH_WORK
Implementation : i:/TECH_WORK
Version     : G-2012.06
Date       : Wed Jun 6 12:46:37 2012
*****
#####
####  TECH LIB - r:/TECH_WORK
#####
Library Cell      Merged Register  Original Cells      Q      QN
-----
Simple_Cell      *dff.00.Q*      UDP_DFFA, UDP_DFFB      Q      QX
1
```

This example generates a short report about unused cells in technology libraries in the Formality environment.

```
fm_shell>report_libraries -unused -short
*****
Report      : libraries
            -short
            -unused_cells

Reference   : r:/WORK/top
Implementation : <None>
Version     : L-2016.03
Date       : Tue Jan 5 20:24:08 2016
*****

Unused
Cells  Shared  Technology Library
-----
89     Yes    GTECH
1      Yes    TECH_WORK

89     Yes    i:/GTECH
1      Yes    i:/TECH_WORK

89     Yes    r:/GTECH
1
```

SEE ALSO

```
list_libraries(2)
```

---

## report\_loops

Reports the nets and pins of loops or portions of loops.

---

### SYNTAX

```
int report_loops  
  [-ref | -impl]  
  [-limit n]  
  [-unfold]
```

#### Data Types

*n* integer

#### Enabled Shell Modes

Match Verify

---

### ARGUMENTS

#### -ref

Reports information about the nets and pins of loops in the reference design. By default, the command reports information about loops in both the reference and implementation designs.

#### -impl

Reports information about the net and pins of loops in the implementation design. By default, the command reports information about loops in both the reference and implementation designs.

#### -limit *n*

Limits the report to the number of specified loops. By default, the tool reports 10 loops per design and 100 objects per loop. If you set the limit to 0, the tool reports all nets and pins in all loops of the specified design.

#### -unfold

Reports information about loops in overlapping (or embedded) loops as separate loops. By default, subloops are not reported. The report size might increase exponentially because of the number of subloops.

---

### DESCRIPTION

This command reports information about the nets and pins of loops in the reference and implementation design.

Use this command either before or after the **verify** command. This command does not require verification results. The command reports all loops even if the loops are broken during verification.

## EXAMPLES

The following example shows a report that does not contain subloops. The reported objects are instance path names.

```
prompt> report_loops -impl
*****
Report      : loops

Reference   : SPEC:/WORK
Implementation : i:/WORK
Version     : G-2012.06
Date       : Wed Jun 6 12:46:37 2012
*****
There is(are) 1 loop(s) found in the implementation design :

Loop 1 :
(Pin) IMPL:/LIB/testImpl/D0/OUT
(Net) IMPL:/LIB/testImpl/net_x1
(Pin) IMPL:/LIB/testImpl/C0/IN1
(Pin) IMPL:/LIB/testImpl/C0/OUT
(Net) IMPL:/LIB/testImpl/net_b
(Pin) IMPL:/LIB/testImpl/D0/F
1
```

The following example shows a report that contains subloops, without specifying the **-unfold** option.

```
prompt> report_loops -ref
*****
Report      : libraries

Reference   : SPEC:/WORK
Implementation : i:/WORK
Version     : G-2012.06
Date       : Wed Jun 6 12:46:37 2012
*****
There is(are) 1 loop(s) found in the reference design :

Loop 1 :
(Pin) SPEC:/WORK/testSpec/C0/OUT
==> (Net) SPEC:/WORK/testSpec/w1
(Net) SPEC:/WORK/testSpec/w1
==> (Pin) SPEC:/WORK/testSpec/C1/IN2
(Pin) SPEC:/WORK/testSpec/C1/IN2
==> (Pin) SPEC:/WORK/testSpec/C1/OUT
(Pin) SPEC:/WORK/testSpec/C1/OUT
==> (Net) SPEC:/WORK/testSpec/c
(Net) SPEC:/WORK/testSpec/c
==> (Pin) SPEC:/WORK/testSpec/C0/IN2
==> (Pin) SPEC:/WORK/testSpec/C2/IN2
(Pin) SPEC:/WORK/testSpec/C0/IN2
==> (Pin) SPEC:/WORK/testSpec/C0/OUT
(Pin) SPEC:/WORK/testSpec/C2/IN2
==> (Pin) SPEC:/WORK/testSpec/C2/OUT
(Pin) SPEC:/WORK/testSpec/C2/OUT
==> (Net) SPEC:/WORK/testSpec/w1
1
```

The following example shows a report using the **-unfold** option on a design with subloops.

```
prompt> report_loops -ref -unfold
*****
Report      : libraries

Reference   : SPEC:/WORK
Implementation : i:/TECH_WORK
Version     : G-2012.06
Date       : Wed Jun 6 12:46:37 2012
*****
There is(are) 1 loop(s) found in the reference design :
```

Loop 1 :

(Sub-loop 1)

(Pin) SPEC:/WORK/testSpec/C0/OUT

(Net) SPEC:/WORK/testSpec/w1

(Pin) SPEC:/WORK/testSpec/C1/IN2

(Pin) SPEC:/WORK/testSpec/C1/OUT

(Net) SPEC:/WORK/testSpec/c

(Pin) SPEC:/WORK/testSpec/C0/IN2

(Sub-loop 2)

(Net) SPEC:/WORK/testSpec/w1

(Pin) SPEC:/WORK/testSpec/C1/IN2

(Pin) SPEC:/WORK/testSpec/C1/OUT

(Net) SPEC:/WORK/testSpec/c

(Pin) SPEC:/WORK/testSpec/C2/IN2

(Pin) SPEC:/WORK/testSpec/C2/OUT

1

---

## SEE ALSO

remove\_cutpoint(2)

report\_cutpoints(2)

set\_cutpoint(2)

---

## report\_lp

Report violations found during static low power comparison.

---

### SYNTAX

status **report\_lp**

---

### DESCRIPTION

This command is used to report any static low power comparison violations. found during the **compare\_lp** command. By default it lists the summary of violations. The command and its arguments are passed directly to the current VCLP session which is running in the background. For a complete list of arguments and options see the VCLP man page for the **report\_lp** command.

---

### EXAMPLES

Example report from a design with several **compare\_lp** violations.

```
fm_shell (setup)> report_lp
```

```
-----
Management Summary
```

```
-----
Stage Family      Errors Warnings  Infos
-----
UPF  UpfDiff       0      5      0
-----
Total              0      5      0
-----
```

```
-----
Tree Summary
```

```
-----
Severity Stage Tag          Count
-----
warning UPF  DIFF_ISO_APPLIES      1
warning UPF  DIFF_ISO_ELEMENT      1
warning UPF  DIFF_MACRO_SUPPLY      1
warning UPF  DIFF_NET_EXIST      1
warning UPF  DIFF_PORT_EXIST      1
-----
Total              5
-----
```

---

### SEE ALSO

**compare\_lp**(2)  
**verification\_static\_low\_power\_compare**(3)

---

## report\_matched\_points

Reports information about the matched compare points.

---

### SYNTAX

```
integer report_matched_points
  [-compare_rule]
  [-substring substring]
  [-point_type point_type]
  [-inputs input_type]
  [-status status]
  [-except_status except_status]
  [-method matching_method]
  [-last]
  [-type ID_type]
  [-datapath]
  [-not_compared]
  [-list]
  [-never_loads]
  [-always_reset]
  [objectID]
```

#### Data Types

```
substring string
point_type string
input_type string
status string
except_status string
matching_method string
ID_type string
objectID string
```

#### Enabled Shell Modes

Match Verify

---

### ARGUMENTS

#### -compare\_rule

Reports mapped object names resulting from the application of compare rules.

#### -datapath

Reports only matched datapath blocks.

#### -substring *substring*

Reports only the points that contain the specified substring.

#### -point\_type *point\_type*

Reports only the points that match the specified type or types. By default, matchable input points and matchable compare points are reported. All point types are included in the report except blocks, block pins, and PGPins.

Specify one of the following values for the *point\_type* argument:

- *all* - Report all object types.
- *bbox* - Report black boxes.
- *bbox\_pin* - Report all black box pins.
- *bbox\_input* - Report black box input pins.
- *bbox\_output* - Report black box output pins.
- *bbox\_inout* - Report black box bidirectional pins.
- *block* - Report hierarchical blocks.
- *block\_pin* - Report hierarchical block pins.
- *block\_input* - Report hierarchical block input pins.
- *block\_output* - Report hierarchical block output pins.
- *block\_inout* - Report hierarchical block bidirectional pins.
- *loop* - Report loop points.
- *net* - Report net points.
- *cut* - Report cutpoints.
- *bbox\_net* - Report black box-resolved, multiply-driven nets.
- *port* - Report all ports.
- *input* - Report input ports.
- *output* - Report output ports.
- *inout* - Report bidirectional ports.
- *directly\_undriven\_output* - Report output and bidirectional ports that do not have connected nets or that have connected nets but do not have a driving pin.
- *reg* - Report all registers.
- *DFF* - Report flip-flop registers.
- *LAT* - Report latch registers.
- *PDCut* - Report power domain pin compare points.
- *PGPin* - Report power/ground/power-down function compare points.

#### **-status *status***

Reports only the compare points that match the specified type or types. If both **-status** and **-point\_type** arguments are specified, the compare points that are included must pass both filters.

By default, if neither the **-status** nor the **-except\_status** options are used, the report includes points with any status except:

- Points where one or both objects are *unread*
- *dont\_verify* points with a matched status that is not necessary for subsequent verification success

To exclude all *dont\_verify* points from the report, use the **-except\_status *dont\_verify*** option. Multiple occurrences of this option are legal and values are additive. Specify one of the following values for the *status* argument:

- *none* - Report all except these special types.

- *trans* - Report transparent latch registers.
- *const* - Report all constant registers.
- *const0* - Report constant 0 registers.
- *const1* - Report constant 1 registers.
- *constX* - Report constant X registers.
- *const0X* - Report constrained 0X registers.
- *const1X* - Report constrained 1X registers.
- *clock\_gate* - Report clock-gate latches.
- *dont\_verify* - Report *dont\_verify* points.
- *unread* - Report unread points.
- *undriven* - Report undriven points.
- *inverted* - Report points matched inverted.
- *noninverted* - Report points matched noninverted.
- *targeted* - Report points targeted for verification.
- *not\_targeted* - Report points not targeted for verification.

#### **-except\_status *except\_status***

Excludes points that match the specified status from the report. Multiple occurrences of this option are legal and values are additive. By default, the report includes *dont\_verify* points with a matched status that could be necessary for downstream verification success. Specify one of the following values for the *except\_status* argument:

- *trans* - Exclude transparent latch registers.
- *const* - Exclude all constant registers.
- *const0* - Exclude constant 0 registers.
- *const1* - Exclude constant 1 registers.
- *constX* - Exclude constant X registers.
- *const0X* - Exclude constrained 0X registers.
- *const1X* - Exclude constrained 1X registers.
- *clock\_gate* - Exclude clock-gate latches.
- *dont\_verify* - Exclude *dont\_verify* points.
- *unread* - Exclude unread points.
- *undriven* - Exclude undriven points.
- *inverted* - Exclude points matched inverted.
- *noninverted* - Exclude points matched noninverted.
- *targeted* - Exclude points targeted for verification.
- *not\_targeted* - Exclude points not targeted for verification.

#### **-method *matching\_method***

Reports only the points that match the specified method.



Specify one of the following values for the *matching\_method* argument:

- *user* - Report points matched by the **set\_user\_match** command.
- *name* - Report points matched by name.
- *topology* - Report points matched by topology.
- *function* - Report points matched by function.

#### **-last**

Includes points matched during the most recent **match** or **verify** command.

#### **-not\_compared**

Reports only points that are reported as "Not Compared" in the verification results summary.

#### **-list**

Returns a list of pairs of point names which can be used in further Tcl processing. By default, the command prints a formatted table.

#### **-never\_loads**

Filters the report to only include register compare point pairs that do not synchronously load.

#### **-always\_reset**

Filters the report to only include register compare point pairs that are constantly reset.

#### **objectID -type ID\_type**

Reports points (matched cone inputs) in the compare point fanin specified by the *objectID* argument. Use the **-type ID\_type** option to specify the type of the compare point if its name is ambiguous. These arguments are optional, but the **-type ID\_type** option is only valid when used with the *objectID* argument.

---

## DESCRIPTION

The **report\_matched\_points** command reports on design objects that are matched.

The tool generates a report that includes the total number of matched points followed by each pair of matched design objects. For each design object, the report lists the matching method, whether the match occurred in the most recent matching operation, the container, the design object type, and the design object's design ID.

---

## EXAMPLES

The following command reports on all of the matched design objects:

```
prompt> report_matched_points
*****
Report      : matched_points

Reference   : HDL:/WORK/CORE
Implementation : OPT:/WORK/CORE
Version     : G-2012.06
Date       : Wed Jun 6 12:46:37 2012
*****

12 Matched points (substring 'INT_UPC_reg'):
```

Ref DFF	Name(Last) HDL:/WORK/CORE/UPC_BLK/INT_UPC_reg[10]
Impl DFF	Name(Last) OPT:/WORK/CORE/UPC_BLK/INT_UPC_reg[10]
Ref DFF	Name(Last) HDL:/WORK/CORE/UPC_BLK/INT_UPC_reg[11]
Impl DFF	Name(Last) OPT:/WORK/CORE/UPC_BLK/INT_UPC_reg[11]
Ref DFF	Name(Last) HDL:/WORK/CORE/UPC_BLK/INT_UPC_reg[12]
Impl DFF	Name(Last) OPT:/WORK/CORE/UPC_BLK/INT_UPC_reg[12]
Ref DFF	Name(Last) HDL:/WORK/CORE/UPC_BLK/INT_UPC_reg[1]
Impl DFF	(-) Name(Last) OPT:/WORK/CORE/UPC_BLK/INT_UPC_reg[1]
Ref DFF	Name(Last) HDL:/WORK/CORE/UPC_BLK/INT_UPC_reg[2]
Impl DFF	(-) Name(Last) OPT:/WORK/CORE/UPC_BLK/INT_UPC_reg[2]
Ref DFF	Name(Last) HDL:/WORK/CORE/UPC_BLK/INT_UPC_reg[3]
Impl DFF	(-) Name(Last) OPT:/WORK/CORE/UPC_BLK/INT_UPC_reg[3]
Ref DFF	Name(Last) HDL:/WORK/CORE/UPC_BLK/INT_UPC_reg[4]
Impl DFF	Name(Last) OPT:/WORK/CORE/UPC_BLK/INT_UPC_reg[4]
Ref DFF	Name(Last) HDL:/WORK/CORE/UPC_BLK/INT_UPC_reg[5]
Impl DFF	Name(Last) OPT:/WORK/CORE/UPC_BLK/INT_UPC_reg[5]
Ref DFF	Name(Last) HDL:/WORK/CORE/UPC_BLK/INT_UPC_reg[6]
Impl DFF	Name(Last) OPT:/WORK/CORE/UPC_BLK/INT_UPC_reg[6]
Ref DFF	Name(Last) HDL:/WORK/CORE/UPC_BLK/INT_UPC_reg[7]
Impl DFF	Name(Last) OPT:/WORK/CORE/UPC_BLK/INT_UPC_reg[7]
Ref DFF	Name(Last) HDL:/WORK/CORE/UPC_BLK/INT_UPC_reg[8]
Impl DFF	Name(Last) OPT:/WORK/CORE/UPC_BLK/INT_UPC_reg[8]
Ref DFF	Name(Last) HDL:/WORK/CORE/UPC_BLK/INT_UPC_reg[9]
Impl DFF	Name(Last) OPT:/WORK/CORE/UPC_BLK/INT_UPC_reg[9]

[BBNet: multiply-driven net

BBox: black box

BBPin: black box pin

Block: hierarchical block

BIPin: hierarchical block pin

Cut: cut-point

DFF: non-constant DFF register

DFF0: constant 0 DFF register

DFF1: constant 1 DFF register

DFFX: constant X DFF register

DFF0X: constrained 0X DFF register

DFF1X: constrained 1X DFF register

LAT: non-constant latch register

LAT0: constant 0 latch register

LAT1: constant 1 latch register

LATX: constant X latch register

LAT0X: constrained 0X latch register

LAT1X: constrained 1X latch register

LATCG: clock-gating latch register

TLA: transparent latch register

TLA0X: transparent constrained 0X latch register

TLA1X: transparent constrained 1X latch register

Loop: cycle break point

Net: matchable net

Port: primary (top-level) port

Und: undriven signal cut-point

Func: matched by function

Name: matched by name

Topo: matched by topology

User: matched by user

Last: matched during most recent matching]

## SEE ALSO

report\_aborted\_points(2)  
report\_failing\_points(2)  
report\_passing\_points(2)  
report\_unmatched\_points(2)  
report\_unverified\_points(2)  
report\_not\_compared\_points(2)

---

## report\_mismatch\_message\_filters

Reports all the simulation-synthesis mismatch filters currently set on one or more simulation-synthesis mismatch messages.

---

### SYNTAX

```
status report_mismatch_message_filters
      [-unmatched]
      [MismatchMessageIDList]
```

#### Data Types

*MismatchMessageIDList*    list

---

### ARGUMENTS

#### -unmatched

Reports the mismatch filters those are not executed by any of the mismatch-messages produced during the run. This is an optional option. By default, the report command will display all the filters.

#### MismatchMessageIDList

Reports mismatch message filter for the list of mismatch message ids specified. This is an optional option. Below are the list of simulation mismatch error codes that this option accepts:

```
FMR_VHDL-274 FMR_VHDL-1002 FMR_VHDL-1004 FMR_VHDL-1014 FMR_VHDL-1025 FMR_VHDL-1027 FMR_VHDL-1036
FMR_VHDL-1140 FMR_VHDL-1144 FMR_VHDL-1145 FMR_VLOG-079 FMR_VLOG-081 FMR_VLOG-083 FMR_VLOG-087
FMR_VLOG-089 FMR_VLOG-090 FMR_VLOG-091 FMR_VLOG-100 FMR_VLOG-925 FMR_VLOG-928 FMR_VLOG-929
FMR_VLOG-933 FMR_ELAB-034 FMR_ELAB-058 FMR_ELAB-059 FMR_ELAB-100 FMR_ELAB-115 FMR_ELAB-116
FMR_ELAB-117 FMR_ELAB-118 FMR_ELAB-125 FMR_ELAB-130 FMR_ELAB-136 FMR_ELAB-145 FMR_ELAB-146
FMR_ELAB-147 FMR_ELAB-149 FMR_ELAB-150 FMR_ELAB-151 FMR_ELAB-153 FMR_ELAB-154 FMR_ELAB-261 FM_SVF-
001 FM_SVF-002 FM_SVF-003 FM_SVF-004 FM_SVF-005 FM_SVF-006 FM_SVF-007 FM_SVF-008
```

---

### DESCRIPTION

The command reports all the filters set in the order of priority. The first displayed filter for a specific message will have highest priority than the next in the report.

The command returns status 1 on success and 0 on failure.

---

### EXAMPLES

Assume below filters set in a session:

```
set_mismatch_message_filter -warn -block bot_sizeA1_size0/gen0/alwaysb FMR_ELAB-117
set_mismatch_message_filter -suppress -file /vobs/data/rtl/test.sv -line 57 FMR_ELAB-117
```

```
set_mismatch_message_filter -warn
```

Then the report command reports the filters as below

```
fm_shell (setup)> report_mismatch_message_filters
*****
Report      : report_mismatch_message_filters

Reference   : <None>
Implementation : <None>
Version     : J-2014.09
Date        : Wed Jul 15 01:58:10 2014
*****

FMR_ELAB-117 -suppress -file /vobs/data/rtl/test.sv -line 57
FMR_ELAB-117 -warn -block bot_sizeA1_size0/gen0/alwaysblock
FMR_ELAB-117 -warn

-warn
```

In above report, the first three filters for mismatch message ID FMR\_ELAB-117 and the last filter is for all other mismatch message IDs. The third line corresponds to implicit filter that set on FMR\_ELAB-117 because of set\_mismatch\_message\_filter -warn.

If there are many filters set, and you want to report the filter set on particular message ID, then use the below shown command:

```
fm_shell (setup)> report_mismatch_message_filters FMR_ELAB-117
*****
Report      : report_mismatch_message_filters
              FMR_ELAB-117
Reference    : <None>
Implementation : <None>
Version      : J-2014.09
Date         : Wed Jul 16 03:21:55 2014
*****

FMR_ELAB-117 -suppress -file /vobs/data/rtl/test.sv -line 57
FMR_ELAB-117 -suppress -signal data1
FMR_ELAB-117 -warn -block bot_sizeA1_size0/gen0/alwaysblock
FMR_ELAB-117 -suppress
```

If you want to check the filters that are not matched by any of the mismatch message, use the command as shown below:

```
fm_shell (setup)> report_mismatch_message_filters FMR_ELAB-117 -unmatched
*****
Report      : report_mismatch_message_filters
              FMR_ELAB-117
              -unmatched
Reference    : r:/WORK/small_test
Implementation : <None>
Version      : J-2014.09-Beta2
Date         : Wed Jul 16 03:32:30 2014
*****

FMR_ELAB-117 -warn -block bot_sizeA1_size0/gen0/alwaysblock
FMR_ELAB-117 -suppress
```

Please note that, **-unmatched** will report those filters that are not hit by any of the mismatch messages. It does not display implicit filter(a filter set without MismatchMessageIDList) on specific message ID like normal report.

---

## SEE ALSO

```
set_mismatch_message_filter(2)
remove_mismatch_message_filter(2)
```

---

## report\_multidrivens\_nets

Reports information about multiply-driven nets after match.

---

### SYNTAX

#### **report\_multidrivens\_nets**

[-substring *substring*]

[-reference]

[-implementation]

#### **Data Types**

*substring* string

#### **Enabled Shell Modes**

Match

Verify

---

### ARGUMENTS

#### **-substring *substring***

Reports information about only the nets that contain the specified substring.

#### **-reference**

Reports information about only the multiply-driven nets in the reference design. By default, the command reports multiply-driven nets in both the reference and implementation designs.

#### **-implementation**

Reports information about only the multiply-driven nets in the implementation design. By default, the command reports multiply-driven nets in both the reference and implementation designs.

---

### DESCRIPTION

This command reports information about the multiply-driven nets after match. The report includes the total number of multiply-driven nets, followed by each multiply-driven net and the list of drivers. The nets and drivers include the full instance path names. The resolution or wire type is shown for each net if it is not of consensus type. The cell and library names are displayed for each driver if they exist.

## EXAMPLES

The following example shows a report generated by the **report\_multidrivn\_nets** command.

```
prompt> report_multidrivn_nets
*****
Report      : multidrivn_nets

Reference   : r:/WORK
Implementation : i:/WORK
Version     : G-2012.06
Date       : Wed Jun 6 12:46:37 2012
*****

report_multidrivn_nets

2 Multiply driven nets:

Net  r:/WORK/top/Z
Drivers (3)
  r:/WORK/and_multi/C1/OUT
  r:/WORK/top/mid/out  (inv) (TECH_WORK)
  r:/WORK/and_multi/C0/OUT

Net  i:/WORK/top/Z
Drivers (3)
  i:/WORK/and_multi/C1/OUT
  i:/WORK/top/mid/out  (inv) (TECH_WORK)
  i:/WORK/and_multi/C0/OUT

1
```

---

## SEE ALSO

report\_undrivn\_nets(2)

---

## report\_net\_resolution

Reports resolution function for the specified net.

---

### SYNTAX

```
status report_net_resolution
[ objectID ]
```

#### Data Types

*objectID*    string

#### Enabled Shell Modes

Setup

---

### ARGUMENTS

#### *objectID*

Specifies the net for which the resolution function is to be reported. If you specify a name that resolves to more than one net, the resolution function is reported for all of the matching nets.

---

### DESCRIPTION

Use this command to report the resolution function for a net. If a resolution function has not been specified for the net, the default resolution function will be reported.

If the command is invoked with no arguments, all the nets with user specified resolution function are reported.

---

### EXAMPLES

The following examples reports the resolution function for the net VDD in the implementation design.

```
fm_shell (setup)> report_net_resolution \
i:/WORK/dut/VDD
*****
Report      : net_resolution_functions

Reference   : r:/WORK/dut
Implementation : i:/WORK/dut
Version     : O-2018.06
Date       : Wed Feb 21 09:37:45 2018
*****
Resolution Function Net Name
=====
```



```
parallel      i:/WORK/dut/VDD  
1
```

---

## SEE ALSO

```
remove_net_resolution(2)  
set_net_resolution(2)
```

---

## report\_not\_compared\_points

Reports compare points that it was unnecessary to compare.

---

### SYNTAX

```
int report_not_compared_points
  [-compare_rule]
  [-substring substring]
  [-point_type point_type]
  [-status status]
  [-except_status except_status]
  [-list]
```

#### Data Types

```
substring string
point_type string
status string
except_status string
```

#### Enabled Shell Modes

```
Match
Verify
```

---

### ARGUMENTS

#### -compare\_rule

Reports mapped object names resulting from the application of compare rules.

#### -substring *substring*

Reports only the points containing the specified *substring*.

#### -point\_type *point\_type*

Filters the report to include only the compare points with characteristics that match the specified type or types. By default, all compare point types are included. Specify one or more *point\_type* values on which to report.

The valid *point\_type* values are as follows:

- **bbox\_pin** - Report all black-box pin compare points.
- **bbox\_input** - Report black-box input pin compare points.
- **bbox\_inout** - Report black-box bidirectional pin compare points.
- **loop** - Report loop compare points.
- **bbox\_net** - Report black-box-resolved multiply-driven nets.

- **cut** - Report cut-points.
- **port** - Report all port compare points.
- **output** - Report output port compare points.
- **inout** - Report bidirectional port compare points.
- **directly\_undriven\_output** - Report output and bidirectional ports that do not have a connected net, or that have a connected net but do not have a driving pin.
- **reg** - Report all register compare points.
- **DFF** - Report flip-flop register compare points.
- **LAT** - Report latch register compare points.
- **trans** - Report transparent latch register compare points.
- **PDCut** - Report power domain pin compare points.
- **PGPin** - Report power/ground/power-down function compare points.

### **-status *status***

Reports only the points that match the specified type or types. If both **-status** and **-point\_type** are specified, included points must pass both filters.

The valid *status* values are as follows:

- **none** - Report all except these special types.
- **trans** - Report transparent latch registers.
- **const** - Report all constant registers.
- **const0** - Report constant 0 registers.
- **const1** - Report constant 1 registers.
- **constX** - Report constant X registers.
- **const0X** - Report constrained 0X registers.
- **const1X** - Report constrained 1X registers.
- **clock\_gate** - Report clock-gate latches.
- **dont\_verify** - Report *dont\_verify* points.
- **unread** - Report unread points.
- **undriven** - Report undriven points.
- **inverted** - Report points matched inverted.
- **noninverted** - Report points matched noninverted.
- **targeted** - Report points targeted for verification.
- **not\_targeted** - Report points not targeted for verification.

### **-except\_status *except\_status***

Filters the report to exclude points that match the specified type. Multiple occurrences of this switch are legal and values are additive. The valid *except\_status* values are as follows:

- **trans** - Exclude transparent latch registers.
- **const** - Exclude all constant registers.
- **const0** - Exclude constant 0 registers.
- **const1** - Exclude constant 1 registers.
- **constX** - Exclude constant X registers.
- **const0X** - Exclude constrained 0X registers.
- **const1X** - Exclude constrained 1X registers.
- **clock\_gate** - Exclude clock-gate latches.
- **dont\_verify** - Exclude *dont\_verify* points.
- **unread** - Exclude unread points.
- **undriven** - Exclude undriven points.
- **inverted** - Exclude points matched inverted.
- **noninverted** - Exclude points matched noninverted.
- **targeted** - Exclude points targeted for verification.

- *not\_targeted* - Exclude points not targeted for verification.

### -list

Reports the not compared points as a list. You can use this list for further Tcl processing.

---

## DESCRIPTION

The **report\_not\_compared\_points** command reports points that it was not necessary to compare because they were either unread, constant, marked dont\_verify, or clock-gating latches.

Formality produces a report that includes the total number of points reported followed by each pair of matched design objects. For each design object, the report lists the matching method, whether the match occurred in the most recent matching operation, the container, the design object type, and the design object's *designID*.

---

## EXAMPLES

The following example reports on all of the not compared design objects:

```
prompt> report_not_compared_points
```

```
27 Not compared points:
```

```
Ref LATCG    Name(Last) ref:/LAPLACE_LIB/laplace/emif0/emif_clocks0/clkgate_inp_sb
Impl LATCG    Name(Last) der:/LAPLACE_LIB/laplace/emif0/emif_clocks0/clkgate_inp_sb

Ref LATCG    Name(Last) ref:/LAPLACE_LIB/laplace/emif0/emif_clocks0/clkgate_inp_sd
Impl LATCG    Name(Last) der:/LAPLACE_LIB/laplace/emif0/emif_clocks0/clkgate_inp_sd

Ref LAT      Name(Last) ref:/LAPLACE_LIB/laplace/emif0/emif_clocks0/clkgate_inp_tck
Impl LAT      Name(Last) der:/LAPLACE_LIB/laplace/emif0/emif_clocks0/clkgate_inp_tck

Ref LATCG    Name(Last) ref:/LAPLACE_LIB/laplace/emif0/emif_clocks0/reset_cntr_reg/cg0
Impl LATCG    Name(Last) der:/LAPLACE_LIB/laplace/emif0/emif_clocks0/reset_cntr_reg/cg0

Ref LATCG    Name(Last) ref:/LAPLACE_LIB/laplace/emif1/emif_clocks0/clkgate_inp_sb
Impl LATCG    Name(Last) der:/LAPLACE_LIB/laplace/emif1/emif_clocks0/clkgate_inp_sb

Ref LATCG    Name(Last) ref:/LAPLACE_LIB/laplace/emif1/emif_clocks0/clkgate_inp_sd
Impl LATCG    Name(Last) der:/LAPLACE_LIB/laplace/emif1/emif_clocks0/clkgate_inp_sd

Ref LAT      Name(Last) ref:/LAPLACE_LIB/laplace/emif1/emif_clocks0/clkgate_inp_tck
Impl LAT      Name(Last) der:/LAPLACE_LIB/laplace/emif1/emif_clocks0/clkgate_inp_tck

Ref LATCG    Name(Last) ref:/LAPLACE_LIB/laplace/emif1/emif_clocks0/reset_cntr_reg/cg0
Impl LATCG    Name(Last) der:/LAPLACE_LIB/laplace/emif1/emif_clocks0/reset_cntr_reg/cg0

Ref LATCG    Name(Last) ref:/LAPLACE_LIB/laplace/padf0/pfmisc0/bea_reg0/cg0
Impl LATCG    Name(Last) der:/LAPLACE_LIB/laplace/padf0/pfmisc0/bea_reg0/cg0

Ref DFFX     Name(Last) ref:/LAPLACE_LIB/laplace/test_str0/rring_osc_0/nscanreg0/u0
Impl DFFX     Name(Last) der:/LAPLACE_LIB/laplace/test_str0/rring_osc_0/nscanreg0/u0

Ref DFFX     Name(Last) ref:/LAPLACE_LIB/laplace/test_str0/rring_osc_0/nscanreg1/u0
Impl DFFX     Name(Last) der:/LAPLACE_LIB/laplace/test_str0/rring_osc_0/nscanreg1/u0

Ref DFFX     Name(Last) ref:/LAPLACE_LIB/laplace/test_str0/rring_osc_0/nscanreg2/u0
Impl DFFX     Name(Last) der:/LAPLACE_LIB/laplace/test_str0/rring_osc_0/nscanreg2/u0

Ref DFFX     Name(Last) ref:/LAPLACE_LIB/laplace/test_str0/rring_osc_0/nscanreg3/u0
Impl DFFX     Name(Last) der:/LAPLACE_LIB/laplace/test_str0/rring_osc_0/nscanreg3/u0

Ref DFFX     Name(Last) ref:/LAPLACE_LIB/laplace/test_str0/rring_osc_0/nscanreg4/u0
Impl DFFX     Name(Last) der:/LAPLACE_LIB/laplace/test_str0/rring_osc_0/nscanreg4/u0
```

Ref DFFX	Name(Last) ref:/LAPLACE_LIB/laplace/test_str0/rring_osc_0/nscanreg5/u0
Impl DFFX	Name(Last) der:/LAPLACE_LIB/laplace/test_str0/rring_osc_0/nscanreg5/u0
Ref DFFX	Name(Last) ref:/LAPLACE_LIB/laplace/test_str0/rring_osc_0/nscanreg6/u0
Impl DFFX	Name(Last) der:/LAPLACE_LIB/laplace/test_str0/rring_osc_0/nscanreg6/u0
Ref DFFX	Name(Last) ref:/LAPLACE_LIB/laplace/test_str0/rring_osc_0/nscanreg7/u0
Impl DFFX	Name(Last) der:/LAPLACE_LIB/laplace/test_str0/rring_osc_0/nscanreg7/u0
Ref DFFX	Name(Last) ref:/LAPLACE_LIB/laplace/test_str0/rring_osc_0/nscanreg8/u0
Impl DFFX	Name(Last) der:/LAPLACE_LIB/laplace/test_str0/rring_osc_0/nscanreg8/u0
Ref DFFX	Name(Last) ref:/LAPLACE_LIB/laplace/test_str0/rring_osc_1/nscanreg0/u0
Impl DFFX	Name(Last) der:/LAPLACE_LIB/laplace/test_str0/rring_osc_1/nscanreg0/u0
Ref DFFX	Name(Last) ref:/LAPLACE_LIB/laplace/test_str0/rring_osc_1/nscanreg1/u0
Impl DFFX	Name(Last) der:/LAPLACE_LIB/laplace/test_str0/rring_osc_1/nscanreg1/u0
Ref DFFX	Name(Last) ref:/LAPLACE_LIB/laplace/test_str0/rring_osc_1/nscanreg2/u0
Impl DFFX	Name(Last) der:/LAPLACE_LIB/laplace/test_str0/rring_osc_1/nscanreg2/u0
Ref DFFX	Name(Last) ref:/LAPLACE_LIB/laplace/test_str0/rring_osc_1/nscanreg3/u0
Impl DFFX	Name(Last) der:/LAPLACE_LIB/laplace/test_str0/rring_osc_1/nscanreg3/u0
Ref DFFX	Name(Last) ref:/LAPLACE_LIB/laplace/test_str0/rring_osc_1/nscanreg4/u0
Impl DFFX	Name(Last) der:/LAPLACE_LIB/laplace/test_str0/rring_osc_1/nscanreg4/u0
Ref DFFX	Name(Last) ref:/LAPLACE_LIB/laplace/test_str0/rring_osc_1/nscanreg5/u0
Impl DFFX	Name(Last) der:/LAPLACE_LIB/laplace/test_str0/rring_osc_1/nscanreg5/u0
Ref DFFX	Name(Last) ref:/LAPLACE_LIB/laplace/test_str0/rring_osc_1/nscanreg6/u0
Impl DFFX	Name(Last) der:/LAPLACE_LIB/laplace/test_str0/rring_osc_1/nscanreg6/u0
Ref DFFX	Name(Last) ref:/LAPLACE_LIB/laplace/test_str0/rring_osc_1/nscanreg7/u0
Impl DFFX	Name(Last) der:/LAPLACE_LIB/laplace/test_str0/rring_osc_1/nscanreg7/u0
Ref DFFX	Name(Last) ref:/LAPLACE_LIB/laplace/test_str0/rring_osc_1/nscanreg8/u0
Impl DFFX	Name(Last) der:/LAPLACE_LIB/laplace/test_str0/rring_osc_1/nscanreg8/u0

[BBNet: multiply-driven net

BBox: black-box

BBPin: black-box pin

Block: hierarchical block

BiPin: hierarchical block pin

Cut: cut-point

DFF: non-constant DFF register

DFF0: constant 0 DFF register

DFF1: constant 1 DFF register

DFFX: constant X DFF register

DFF0X: constrained 0X DFF register

DFF1X: constrained 1X DFF register

LAT: non-constant latch register

LAT0: constant 0 latch register

LAT1: constant 1 latch register

LATX: constant X latch register

LAT0X: constrained 0X latch register

LAT1X: constrained 1X latch register

LATCG: clock-gating latch register

TLA: transparent latch register

TLA0X: transparent constrained 0X latch register

TLA1X: transparent constrained 1X latch register

Loop: cycle break point

Net: matchable net

Port: primary (top-level) port

Und: undriven signal cut-point

Func: matched by function

Name: matched by name

Topo: matched by topology

User: matched by user

Last: matched during most recent matching]

---

## SEE ALSO

report\_aborted\_points(2)  
report\_failing\_points(2)  
report\_matched\_points(2)  
report\_passing\_points(2)  
report\_unverified\_points(2)

---

## report\_parameters

Reports information about parameters that are set by the **set\_parameters** command.

---

### SYNTAX

status **report\_parameters**  
[*designID\_list*]

#### Data Types

*designID\_list* string

---

### ARGUMENTS

*designID\_list*

Reports parameters in the specified designs. By default, the command reports information about parameters in the current design.

---

### DESCRIPTION

This command reports information about the user-defined parameters for the specified designs or the current design.

The report includes the following design information:

- Number of cells (linked and unlinked)
- Number of ports
- Number of nets
- Net resolution type
- Attributes of the flatten parameter
- Attributes of the retimed parameter

---

### EXAMPLES

This example creates a report about parameters in the implementation and reference designs. One design is in the *impl* container, and another is in the *ref* container. The designs are in the WORK design library.

```
fm_shell> report_parameters {ref:/WORK/CORE impl:/WORK/CORE}
```

```
*****
Report      : parameters

Reference   : ref:/WORK/CORE
Implementation : impl:/WORK/CORE
Version     : G-2012.06
Date       : Wed Jun 6 12:46:37 2012
*****
```

Legend:	
Statistics	Attributes
c = number of cells	c = CONSENSUS resolution type
linked(unlinked)	x = BLACKBOX resolution type
p = number of ports	a = AND resolution type
n = number of nets	o = OR resolution type
f = flatten	
r = retimed	

```
#####
DESIGN LIBRARY - impl:/WORK
#####
Design Name      Statistics      Attributes
-----
CORE             c10(0) p39 n102      c
#####
#### DESIGN LIBRARY - ref:/WORK
#####
Design Name      Statistics      Attributes
-----
CORE             c10(0) p38 n102      c
1
```

SEE ALSO

```
remove_parameters(2)
set_parameters(2)
```



---

## report\_passing\_points

Reports information about compare points that passed verification.

---

### SYNTAX

```
int report_passing_points
  [-compare_rule]
  [-substring substring]
  [-point_type point_type]
  [-status status]
  [-inputs input_type]
  [-list]
  [-last]
  [-never_loads]
  [-always_reset]
```

#### Data Types

```
substring string
point_type string
status string
input_type string
```

#### Enabled Shell Modes

Verify

---

### ARGUMENTS

#### -compare\_rule

Reports the mapped object names resulting from the application of compare rules.

#### -substring *substring*

Reports information about the points that contain the specific substring.

#### -point\_type *point\_type*

Reports information about the compare points with characteristics that match the specified types. By default, all compare point types except PGPin are included.

Specify one of the following values for the *point\_type* argument:

- *bbox\_pin* - to report all black box pin compare points.
- *bbox\_input* - to report black box input pin compare points.
- *bbox\_inout* - to report black box bidirectional pin compare points.
- *loop* - to report loop compare points.

- *bbox\_net* - to report black box-resolved multiply-driven nets.
- *cut* - to report cutpoints.
- *port* - to report all port compare points.
- *output* - to report output port compare points.
- *inout* - to report bidirectional port compare points.
- *directly\_undriven\_output* - to report output and bidirectional ports that do not have a connected net, or that have a connected net but do not have a driving pin.
- *reg* - to report all register compare points.
- *DFF* - to report flip-flop register compare points.
- *LAT* - to report latch register compare points.
- *trans* - to report transparent latch register compare points.
- *PDCut* - to report power domain pin compare points.
- *PGPin* - to report power/ground/power-down function compare points.

**-status *status***

Reports information about the compare points with the specified polarity. By default, compare points of both polarities are included in the report.

Specify one of the following values for the *status* argument:

- *inverted* - to report compare points with inverted match polarity.
- *noninverted* - to report compare points with noninverted match polarity.

**-inputs *input\_type***

Reports information about the compare points with input points that are either undriven or unmatched, or both. Specify one or both *input\_type* values on which to report.

- *undriven* - to report compare points with undriven input points.
- *unmatched* - to report compare points with unmatched input points.

**-list**

Reports a list of compare point pairs. You can use this list in further Tcl processing.

**-last**

Reports information about compare point pairs from the previous verification.

**-never\_loads**

Filters the report to only include register compare point pairs that do not synchronously load.

**-always\_reset**

Filters the report to only include register compare point pairs that are constantly reset.

---

**DESCRIPTION**

This command reports information about the compare points that passed verification. The report includes the total number of passing

compare points, followed by each pair of design objects that passed verification. Information for each design object includes the container in which the design is, the design object type, and the design object's design ID.

## EXAMPLES

The following example shows how to use the **report\_passing\_points** command:

```
prompt> report_passing_points
*****
Report      : passing_points

Reference   : OPT:/WORK/CORE
Implementation : SCAN:/WORK/CORE
Version      : G-2012.06
Date        : Wed Jun 6 12:46:37 2012
*****
```

16 Passing compare points:

```
Ref Port    OPT:/WORK/CORE/FULL
Impl Port    SCAN:/WORK/CORE/FULL

Ref Port    OPT:/WORK/CORE/PL
Impl Port    SCAN:/WORK/CORE/PL

Ref Port    OPT:/WORK/CORE/PROM
Impl Port    SCAN:/WORK/CORE/PROM

Ref Port    OPT:/WORK/CORE/VECT
Impl Port    SCAN:/WORK/CORE/VECT

Ref Port    OPT:/WORK/CORE/Y[10]
Impl Port    SCAN:/WORK/CORE/Y[10]

Ref Port    OPT:/WORK/CORE/Y[11]
Impl Port    SCAN:/WORK/CORE/Y[11]

Ref Port    OPT:/WORK/CORE/Y[12]
Impl Port    SCAN:/WORK/CORE/Y[12]

Ref Port    OPT:/WORK/CORE/Y[1]
Impl Port    SCAN:/WORK/CORE/Y[1]

Ref Port    OPT:/WORK/CORE/Y[2]
Impl Port    SCAN:/WORK/CORE/Y[2]

Ref Port    OPT:/WORK/CORE/Y[3]
Impl Port    SCAN:/WORK/CORE/Y[3]

Ref Port    OPT:/WORK/CORE/Y[4]
Impl Port    SCAN:/WORK/CORE/Y[4]

Ref Port    OPT:/WORK/CORE/Y[5]
Impl Port    SCAN:/WORK/CORE/Y[5]

Ref Port    OPT:/WORK/CORE/Y[6]
Impl Port    SCAN:/WORK/CORE/Y[6]

Ref Port    OPT:/WORK/CORE/Y[7]
Impl Port    SCAN:/WORK/CORE/Y[7]

Ref Port    OPT:/WORK/CORE/Y[8]
Impl Port    SCAN:/WORK/CORE/Y[8]

Ref Port    OPT:/WORK/CORE/Y[9]
Impl Port    SCAN:/WORK/CORE/Y[9]
```

[BBNet: multiply-driven net  
BBPin: black box pin]

Cut: cut-point  
DFF: non-constant DFF register  
DFF0: constant 0 DFF register  
DFF1: constant 1 DFF register  
DFFX: constant X DFF register  
DFF0X: constrained 0X DFF register  
DFF1X: constrained 1X DFF register  
LAT: non-constant latch register  
LAT0: constant 0 latch register  
LAT1: constant 1 latch register  
LATX: constant X latch register  
LAT0X: constrained 0X latch register  
LAT1X: constrained 1X latch register  
LATCG: clock-gating latch register  
TLA: transparent latch register  
TLA0X: transparent constrained 0X latch register  
TLA1X: transparent constrained 1X latch register  
Loop: cycle break point  
Port: primary (top-level) port  
Und: undriven signal cut-point]

1

---

## SEE ALSO

report\_aborted\_points(2)  
report\_failing\_points(2)  
report\_matched\_points(2)  
report\_unmatched\_points(2)  
report\_unverified\_points(2)  
report\_not\_compared\_points(2)

---

## report\_potentially\_constant\_registers

Reports information on the potentially constant registers.

---

### SYNTAX

```
report_potentially_constant_registers
[-info]
[-fanout_of ObjectList]
[-assumed_no_toggle]
```

---

### ARGUMENTS

#### **-fanout\_of *ObjectList***

Reports only potentially constant registers in the fanout of the specified object. If the objectID was not the cause of initialization of any registers, the report will be empty (not an error) the objectID\_list can be a list {a b c } of objects that are the possible toggling objects

#### **-assumed\_no\_toggle**

Reports only the potentially constant registers that were not found constant because some signal was assumed to \*not\* toggle (due to automatched mode, or user specified set\_init\_toggle\_assumption -no\_toggle)

#### **-info**

Provides additional information on why the constant registers were found to be constant or not.

#### **Enabled Shell Modes**

Match  
Verify

---

### DESCRIPTION

This command reports information about constant registers that were found to be constant based on toggle signal(s), and potentially constant registers that were not found constant because some signal was assumed to \*not\* toggle.

---

### EXAMPLES

The following example reports on all potentially constant registers.

```
fm_shell> report_potentially_constant_registers
```

```
*****
Report      : potentially_constant_registers
```

```
Reference   : r:/WORK/bit_slice
```

```
Implementation : i:/WORK/bit_slice
Version       : O-2018.06-ALPHA-20180328
Date         : Wed Mar 28 10:56:55 2018
*****
```

```
(LAT0) i:/WORK/bit_slice/my_latch1
1
```

The following example gives additional info  
 fm\_shell> **report\_potentially\_constant\_registers -info**  
 \*\*\*\*\*

```
Report       : potentially_constant_registers
              -info
```

```
Reference    : r:/WORK/bit_slice
Implementation : i:/WORK/bit_slice
Version      : O-2018.06-ALPHA-20180328
Date        : Wed Mar 28 10:56:55 2018
*****
```

```
(LAT0) i:/WORK/bit_slice/my_latch1
- Data pin (AD) is constrained to 0
- Enable pin (AL) can controlled by i:/WORK/bit_slice/hclk
1
```

The following example reports on all potentially constant registers that can be initialized by an object.  
 fm\_shell> **report\_potentially\_constant\_registers -fanout\_of i:/WORK/bit\_slice/hclk**  
 \*\*\*\*\*

```
Report       : potentially_constant_registers
              -fanout_of i:/WORK/bit_slice/hclk
Reference    : r:/WORK/bit_slice
Implementation : i:/WORK/bit_slice
Version      : O-2018.06-ALPHA-20180328
Date        : Wed Mar 28 10:56:55 2018
*****
```

```
(LAT0) i:/WORK/bit_slice/my_latch1
1
```

The following example reports on all potentially constant registers whose control signals have been assumed to not toggle.  
 fm\_shell (verify)> **report\_potentially\_constant\_registers -assumed\_no\_toggle**  
 \*\*\*\*\*

```
Report       : potentially_constant_registers
              -assumed_no_toggle
```

```
Reference    : r:/WORK/bit_slice
Implementation : i:/WORK/bit_slice
Version      : O-2018.06-BETA-20180520
Date        : Mon May 21 07:14:24 2018
*****
```

```
(LAT0X) i:/WORK/bit_slice/my_latch1
1
```

---

## SEE ALSO

```
report_init_toggle_objects(2)
set_init_toggle_assumption(2)
report_init_toggle_assumption(2)
remove_init_toggle_assumption(2)
```

---

## report\_power\_model

Reports Formality power models.

---

### SYNTAX

```
status report_power_model  
  [-r]  
  [-i]  
  [-container container_name]  
  [-summary]
```

#### Data Types

*container\_name* string

---

### ARGUMENTS

**-r**

Reports Formality Power models that are in the default reference container.

**-i**

Reports Formality Power models that are in the default implementation container.

**-container *container\_name***

Reports Formality Power models that are in the specified container.

**-summary**

Generates a summary report of Formality Power models in the session.

---

### DESCRIPTION

The **report\_power\_model** command reports the power models present in all the available Formality containers.

The power model is similar in many ways to a black box with UPF, but since it is derived from the actual design all of the UPF semantics (including receiver/driver supplies) are reflected in the model and there is no need to reapply the subblock UPF to the model during top-level verification verification in UPF context.

---

### EXAMPLES

The following example reports the power model in default reference container.

```
fm_shell> report_power_model -r
```

```

*****
Report      : power model
-r

Reference   : r:/WORK/tc
Implementation : i:/WORK/tc
Version     : S-2021.06-BETA-20210506
Date       : Thu May 6 13:41:39 2021
*****

-----
r:/FM_MLIB_0/blk
-----
Checksum      : aef58b8c-e50c-5283-a36b-479ac3df0883
Formality Version : S-2021.06-BETA-20210506
SVF Applied    : Yes
Original Container : r
Verify State   : SUCCEEDED (verification_force_upf_supplies_on == true)
Formality Script : report_power_model/test.tcl
UPF           : -
Output Constraints : o[2] 0

1

```

The following example reports the power models in all the containers.

```

fm_shell> report_power_model
*****
Report      : power model

Reference   : r:/WORK/tc
Implementation : i:/WORK/tc
Version     : S-2021.06-BETA-20210506
Date       : Thu May 6 13:43:52 2021
*****

-----
r:/FM_MLIB_0/blk
-----
Checksum      : aef58b8c-e50c-5283-a36b-479ac3df0883
Formality Version : S-2021.06-BETA-20210506
SVF Applied    : Yes
Original Container : r
Verify State   : SUCCEEDED (verification_force_upf_supplies_on == true)
Formality Script : report_power_model/test.tcl
UPF           : -
Output Constraints : o[2] 0

-----
i:/FM_MLIB_0/blk
-----
Checksum      : aef58b8c-e50c-5283-a36b-479ac3df0883
Formality Version : S-2021.06-BETA-20210506
SVF Applied    : No
Original Container : i
Verify State   : SUCCEEDED (verification_force_upf_supplies_on == true)
Formality Script : report_power_model/test.tcl
UPF           : -
Output Constraints : o[2] 0

1

```

The following example reports a summary of power models in all the containers.

```

fm_shell> report_power_model -summary
*****
Report      : power model
            -summary

Reference   : r:/WORK/tc
Implementation : i:/WORK/tc
Version     : S-2021.06-BETA-20210506
Date       : Thu May 6 13:45:52 2021

```



\*\*\*\*\*

Power Model	Checksum	Original Container	SVF Applied	SVF Status	Verify Supplies	Forced ON
r:/FM_MLIB_0/blk	aef58b8c-e50c-5283-a36b-479ac3df0883	r		Yes	SUCCEEDED	TRUE
i:/FM_MLIB_0/blk	aef58b8c-e50c-5283-a36b-479ac3df0883	i		No	SUCCEEDED	TRUE

1

SEE ALSO

write\_power\_model(2)  
create\_power\_model(2)  
read\_power\_model(2)

---

## report\_probe\_points

Reports the probe net pairs set by the **set\_probe\_points** command.

---

### SYNTAX

**report\_probe\_points**

#### Enabled Shell Modes

Setup  
Match  
Verify

---

### ARGUMENTS

This command has no arguments.

---

### DESCRIPTION

This command reports the debug probe pairs set by the **set\_probe\_points** command. The probe pair consists of a reference net and an implementation net.

---

### EXAMPLES

```
fm_shell (setup)> report_probe_points
*****
Report      : probe_points

Reference   : r:/WORK/top
Implementation : i:/WORK/top
Version     : G-2012.06
Date        : Wed Jun 6 12:46:37 2012
*****

r:/WORK/top/data
i:/WORK/top/data

r:/WORK/top/U2/Z[0]
i:/WORK/top/U3/m3/net4

r:/WORK/top/M1/x
i:/WORK/top/x
1
```

## SEE ALSO

set\_probe\_points(2)  
remove\_probe\_points(2)  
report\_probe\_status(2)

---

## report\_probe\_status

Reports verification status information about probe net pairs that are set by the **set\_probe\_points** command.

---

### SYNTAX

**report\_probe\_status**  
[-status pass | fail | abort | notrun]

#### Enabled Shell Modes

Verify

---

### ARGUMENTS

#### -status

Reports information about probe net pairs with the specified status. Specify one of the following values:

- *pass*
- *fail*
- *abort*
- *notrun*

---

### DESCRIPTION

This command reports information about the verification status of debug probe pairs that are set by the **set\_probe\_points** command.

---

### EXAMPLES

This example shows a report with all the probe net pairs and their verification status.

```
fm_shell (setup)> report_probe_status
*****
Report      : probe_status

Reference   : r:/WORK/top
Implementation : i:/WORK/top
Version     : G-2012.06
Date       : Wed Jun 6 12:46:37 2012
*****

Ref FAIL    r:/WORK/top/data
Impl FAIL   i:/WORK/top/data
```

```
Ref PASS    r:/WORK/top/U1/U3/net4
Impl PASS   i:/WORK/top/U4/net9
```

```
Ref FAIL    r:/WORK/top/M1/M2/Z[0]
Impl FAIL   i:/WORK/top/Z_0_
```

1

This example shows a report with the probe net pairs that have passed verification.

```
fm_shell (setup)> report_probe_status -status pass
```

```
*****
```

```
Report      : probe_status
```

```
Reference   : r:/WORK/top
```

```
Implementation : i:/WORK/top
```

```
Version     : G-2012.06
```

```
Date       : Wed Jun 6 12:46:37 2012
```

```
*****
```

```
Ref PASS    r:/WORK/top/U1/U3/net4
```

```
Impl PASS   i:/WORK/top/U4/net9
```

1

---

## SEE ALSO

```
set_probe_points(2)
remove_probe_points(2)
report_probe_points(2)
verify(2)
```

---

## report\_related\_supplies

Reports the driver and receiver supply nets and those that exist for the specified port or net.

---

### SYNTAX

#### **report\_related\_supplies**

*ObjectPath*

[-drivers]

[-receivers]

[-type]

#### **Data Types**

*ObjectPath* string

#### **Enabled Shell Modes**

Match

Verify

---

### ARGUMENTS

#### **-drivers**

Reports the UPF driver supply information of the specified port or net.

#### **-receivers**

Reports the UPF receiver supply information of the specified port or net.

#### **-type *type***

Specifies the object type. Use this option if the name of the specified design object is associated with more than one object type in the design. Specify one of the following values for the *type* argument:

- *port*
- *net*

---

### DESCRIPTION

This command reports the driver and receiver supply nets and supply sets of the specified port or net. If the specified regular expression resolves to more than one object, then all of those objects will be reported. However, if the name resolves to multiple objects with identical names and you do not specify the object type, only one of these objects is affected in the following precedence: port, net. By default, the command reports the full path name of the specified object, the drivers and the receivers.

Use only either the **-drivers** or the **-receivers** option to report only drivers or receivers respectively.

---

## EXAMPLES

The following example shows how to report the UPF related supply information.

```
fm_shell> report_related_supplies r:/WORK/simple/n4[3]

*****
Report      : upf_related_supplies
             r:/WORK/simple/n4[3]

Reference   : r:/WORK/simple
Implementation : i:/WORK/simple
Version     : G-2012.06-SP1-2
Date       : Thu Aug 2 14:52:23 2012
*****

Net: r:/WORK/simple/n4[3]
Driver:
  r:/WORK/simple/u4/out1[3]
  Supplies: r:/WORK/simple/VDD1 r:/WORK/simple/VSS1
  Supply Set(s): /PD_TOP.primary /PD_A.iso_A1.isolation_supply_set
Receiver:
  r:/WORK/simple/in1[3]_UPF_ISO/IN
  Supplies: r:/WORK/simple/VDD3 r:/WORK/simple/VSS2
  Supply Set(s): /PD_B.primary /PD_B.iso_B1.isolation_supply_set
1
```

---

## SEE ALSO

load\_upf(2)  
report\_upf(2)

---

## report\_remodel

Reports the instances that have been modified by the **remodel** command.

---

### SYNTAX

```
report_remodel  
[-type remodel_type]
```

---

### ENABLED SHELL MODES

Setup

---

### ARGUMENTS

**-type remodel\_type**

Limit the report to one type of remodeling: **seq2buffer** or **inv2buffer**.

---

### DESCRIPTION

This command reports all instances in the reference and implementation that have been modified by the **remodel** command.

By default all types of remodeling are reported. To limit the report to one type of remodeling, use the **-type** option.

---

### EXAMPLES

```
fm_shell (setup)> report_remodel
```

```
Seq2Buffer Instances
```

```
-----  
i:/WORK/top/Rst_reg  
i:/WORK/bot/Rst_reg
```

```
Inv2Buffer Instances
```

```
-----  
i:/WORK/mid/INV_U4
```

```
fm_shell (setup)> report_remodel -type seq2buffer
```

```
Seq2Buffer Instances
```

```
-----  
i:/WORK/top/Rst_reg
```



i:/WORK/bot/Rst\_reg

---

**SEE ALSO**

remodel(2)

---

## report\_remove\_objects

Reports the objects that are removed by using the **remove\_object** command.

---

### SYNTAX

status **report\_remove\_objects**

---

### ARGUMENTS

This command has no arguments.

---

### DESCRIPTION

This command reports the objects removed by the user using the \fremove\_object command.

---

### EXAMPLES

```
fm_shell (setup)> report_remove_objects
*****
Report      : remove_objects

Reference   : <None>
Implementation : <None>
Version     : J-2014.09-Alpha
Date       : Fri May 16 12:01:16 2014
*****
```

Removed Objects:

```
(Port) impl:/mapped_gate_IBM_CMOS5S_GApower.db/CORE/PL
(Block) impl:/mapped_gate_IBM_CMOS5S_GApower.db/CORE/CNTL_BLK
(Net) impl:/mapped_gate_IBM_CMOS5S_GApower.db/MUX_OUT/DATA_1
(Block) impl:/mapped_gate_IBM_CMOS5S_GApower.db/MUX_OUT/MUX_BLK
```

1

---

### SEE ALSO

remove\_object(2)

---

## report\_safety\_status

Reports consistency check information on the SSF objects that are inserted into the designs based on SVF guidance and safety commands using the **load\_ssf** command.

---

### SYNTAX

```
status report_safety_status
[-r]
[-container container_name]
```

#### Data Types

*container\_name* string

#### Enabled Shell Modes

Setup  
Match  
Verify

---

### ARGUMENTS

By default, the **report\_safety\_status** command reports information on containers where **load\_ssf** was issued.

**-r**

Reports the SSF consistency check information of the reference container.

**-container *container\_name***

Specifies a container to report.

---

### DESCRIPTION

This command reports all SSF consistency check warnings followed by a summary of SSF information for the container. The report is available after preverification.

---

### EXAMPLES

The following example reports SSF summary when the implementation SVF guidance is consistent with **load\_ssf**

```
prompt> report_safety_status
```

```
***** SSF Consistency Checking Summary *****  
Implementation Safety Error Code consistent with Safety Specification Format
```

Please refer to the Formality log file for more details,  
or execute report\_safety\_status

```
SSF file loaded:  
test.ssf  
*****
```

This example reports a consistency check difference

```
prompt> report_safety_status  
Warning: Safety Register type inconsistency for B1/R1. Type: TMR found in implementation and type: DMR found in the Safety Specification Rule: rule_name2  
set_safety_register_rule File: /disk/testcase/reg2.ssf, Line 43  
create_safety_register_rule File: /disk/testcase/reg2.ssf, Line 25 (FM-SSF-003)
```

```
***** SSF Consistency Checking Summary *****  
1 FM-SSF-003 conflicting safety register in implementation
```

Please refer to the Formality log file for more details,  
or execute report\_safety\_status

```
SSF file(s) loaded:  
/disk/testcase/reg2.ssf  
*****
```

---

## SEE ALSO

load\_ssf(2)

---

## report\_setup\_status

Reports information about the design statistics and warning messages that are issued by the tool during design read and user-specified setup.

---

### SYNTAX

```
status report_setup_status
  [-design_info]
  [-hdl_read_messages]
  [-all]
  [-commands]
```

---

### ARGUMENTS

#### **-design\_info**

Reports information about the design.

#### **-hdl\_read\_messages**

Reports information about the warning messages that are issued by the tool when the design is read.

#### **-all**

Reports info across all containers.

#### **-commands**

Reports user-specified setup commands.

---

### DESCRIPTION

This command reports the design statistics and warning messages. This report enables you to check for and complete any missing design setup information before proceeding with the **match** and **verify** commands.

Any changes that are performed using the **synopsys\_auto\_setup** variable or the automated setup file for verification are not included in the report. Also, the reported statistics might differ from the statistics reported after **match** and **verify** commands.

The **report\_setup\_status** command can be run only after reading and linking both reference and implementation containers. The statistics reported in the user-specified setup section are the number of objects that a specific command addresses in a container.

---

### EXAMPLES

This example shows a setup status report.

```
fm_shell (setup)> report_setup_status
*****
Report      : setup_status

Reference   : r:/WORK/top
Implementation : i:/WORK/top
Version     : G-2012.06
Date       : Wed Jun 6 12:46:37 2012
*****

#### Design Information ####
# Design Settings #
set_top reference design: r:/WORK/top
set_top implementation design: i:/WORK/top
set_reference_design: r:/WORK/reference
set_implementation_design: i:/WORK/implementation

# Design Statistics Ref (Imp) #
Ports:      1200 (1203)
Registers:  2300 (2351)
Black boxes: 8 (8)
  - Unresolved modules: 1 (1)
  - User specified:    2 (2)
Undriven nets: 41 (41)
Multiply-driven nets: 5 (5)

#### HDL Read Message Summary ####
Message ID:   Occurrences: Ref(Imp)
-----
FMR_VLOG-069      1 (0)

#### User Specified Setup ####
Command Name:   Result: Ref(Imp)
-----
set_black_box   : 3( 11)
set_clock       : 2( 1)
set_compare_rule : 2( 0)
set_constant    : 4( 2)
set_constraint  : 5( 5)
set_cutpoint    : 0( 6)
set_dont_cut    : 0( 0)
set_dont_match_points : 0( 0)
set_dont_verify_point : 8( 8)
set_factor_point : 0( 0)
set_inv_push    : 11( 11)
set_user_match  : 13( 13)
set_verify_points : 0( 0)
change_link     : 0( 0)
create_cell     : 0( 0)
create_net      : 0( 0)
create_port     : 0( 0)
create_primitive : 0( 0)
connect_net     : 0( 0)
disconnect_net  : 0( 0)
invert_pin      : 0( 0)
remove_cell     : 0( 0)
remove_net      : 0( 0)
remove_port     : 0( 0)
rewire_connection : 0( 0)
```

1

---

## SEE ALSO

---

## report\_source\_path

Reports source path information of designs or instances.

---

### SYNTAX

```
status report_source_path
  [-r]
  [-i]
  [-container container_name]
  [-tech]
  [ObjectID_list]
```

#### Data Types

*ObjectID\_list* string/collection

---

### ARGUMENTS

**-r**

Reports designs referenced in Reference container.

**-i**

Reports designs referenced in Implementation container.

**-c container\_name**

Reports designs referenced in given container.

**-tech**

Reports objects in the technology libraries.

***ObjectID\_list***

Reports information about the specified Designs or Instances. If the ObjectID is an instance, it reports source path of the design being referenced. ObjectID\_list is mutually exclusive to -i, -r and -c . ObjectID list can contain wild cards or a collection.

---

### DESCRIPTION

This command reports source path information about one or more designs or instances.

Detailed reports include source file path, library name and container name of given design. If user has not specified any options, it reports the source path information about designs in all available containers.

## EXAMPLES

This example creates a report about all technology libraries in the Formality environment.

```
fm_shell> report_source_path -tech
*****
Report      : source_path
            -tech

Reference   : r:/WORK/top
Implementation : i:/WORK/top
Version     : M-2016.12-SP3
Date        : Thu Mar 16 03:56:32 2017
*****
#-----
#   Container : i
#-----

Design: i:/ME_TOP_LIB/me_top
Library: ME_TOP_LIB
Source: /remote/client/db_files/me_top_lib.db

#-----
#   Container : r
#-----

Design: r:/ME_TOP_LIB/me_top
Library: ME_TOP_LIB
Source: /remote/client/db_files/me_top_lib.db

1

fm_shell>
```

This example generates a report about all the cells referenced in Implementation container.

```
fm_shell> report_source_path -i
*****
Report      : source_path
            -i

Reference   : r:/WORK/top
Implementation : i:/WORK/top
Version     : M-2016.12-SP2-VAL-170316
Date        : Thu Mar 16 03:56:32 2017
*****
#-----
#   Container : i
#-----

Design: i:/ME_TOP_LIB/me_top
Library: ME_TOP_LIB
Source: /remote/client/db_files/me_top_lib.db

Design: i:/WORK/top
Library: WORK
Source: /remote/client/rtl_out/design.out.v

1

fm_shell>
```

This example creates a report about designs or instances matched by ObjectID list.

```
fm_shell>report_source_path r:/WORK/top/forloop_me\[0*
*****
Report      : source_path
```



```
r:/WORK/top/forloop_me[0]*
```

```
Reference      : r:/WORK/top
Implementation : i:/WORK/top
Version       : M-2016.12-SP3
Date          : Thu Mar 16 03:56:32 2017
*****
```

```
r:/WORK/top/forloop_me[0].me_inst
Design: r:/ME_TOP_LIB/me_top
Library: ME_TOP_LIB
Source: /remote/client/db_files/me_top_lib.db
```

```
1
fm_shell>
```

This example creates a report about designs or instances matched by ObjectID list.

```
fm_shell>current_design r:/WORK/top
fm_shell>report_source_path [get_cells]
*****
```

```
Report      : source_path
            _sel1
```

```
Reference      : r:/WORK/top
Implementation : i:/WORK/top
Version       : M-2016.12-SP3
Date          : Thu Mar 16 03:56:32 2017
*****
```

```
r:/WORK/top/forloop_me[0].me_inst
Design: r:/ME_TOP_LIB/me_top
Library: ME_TOP_LIB
Source: /remote/client/db_files/me_top_lib.db
```

```
r:/WORK/top/forloop_me[1].me_inst
Design: r:/ME_TOP_LIB/me_top
Library: ME_TOP_LIB
Source: /remote/client/db_files/me_top_lib.db
```

```
1
fm_shell>
```

---

## SEE ALSO

```
get_cells(2)
get_designs(2)
```

---

## report\_status

Reports information about the current status of the verification. This command reports the status of the library cells when used in the library verification mode.

---

### SYNTAX

```
status report_status
  [-pass]
  [-fail]
  [-abort]
  [-last]
  [-short]
```

---

### ARGUMENTS

#### **-pass**

Reports information about the library cells that passed the verification. This option is available only in the library verification mode.

#### **-fail**

Reports information about the library cells that failed the verification. This option is available only in the library verification mode.

#### **-abort**

Reports information about the library cells for which the verification was aborted. This option is available only in the library verification mode.

#### **-last**

Reports the status information about the compare points verified during the most recent verification.

#### **-short**

Use a short report format.

---

### DESCRIPTION

This command reports the status of the verification. The report includes information on the current reference and implementation designs, the result of the recent verification including the number of failing compare points, the status of the recent diagnosis including the number of error candidates, and user-specified setup information.

Use the -short option to get a report that shows the totals of the number of compare points in the major categories. This option gives a report that is compatible with the report\_status command in versions earlier than H-2013.03.

Information about the recent verification and diagnosis is cleared when

- The current reference or implementation designs are changed by the **set\_reference** or **set\_implementation** commands.
- The reference or implementation design container is removed.

In the library verification mode, if no options are specified, the command reports the status of library verification. The report includes the number of cells that are verified, passed, failed and cells that are aborted during verification.

## EXAMPLES

This example shows a verification status report.

```
fm_shell> report_status
*****
Report      : status

Reference   : RTL:/WORK/top
Implementation : NET:/WORK/top
Version     : H-2013.03
Date       : Tue Feb 19 16:28:12 2013
*****

***** Verification Results *****
Verification SUCCEEDED
-----
Reference design: RTL:/WORK/top
Implementation design: NET:/WORK/top
5578 Passing compare points
-----
Matched Compare Points  BBPin  Loop  BBNet  Cut  Port  DFF  LAT  TOTAL
-----
Passing (equivalent)    0    0    0    0  834  4744  0  5578
Failing (not equivalent) 0    0    0    0    0    0    0
Not Compared
Unread                  0    0    0    0    4    0    4
*****
1
```

This is the -short version of the same report

```
fm_shell (verify)> report_status -short
*****
Report      : status
            -short

Reference   : r:/WORK/top
Implementation : i:/WORK/top
Version     : H-2013.03
Date       : Tue Feb 19 16:28:12 2013
*****

Reference Design:  RTL:/WORK/top
Implementation Design: NET:/WORK/top
Verification
Status:           SUCCEEDED
Passing Points:   5578
Failing Points:   0
Aborted Points:   0
Unverified Points: 0
Diagnosis
Status:           Not Run
Error Candidates: 0
User Defined Setup
Equivalences:     0
Compare Points:   0
Constants:        0
1
```

This example shows a library verification status status report when the **report\_status** command is used in library verification mode.

```
fm_shell (library_verify)> report_status
*****
Report      : status

Reference   : r:/WORK/reference
Implementation : i:/WORK/implementation
Version     : G-2012.06
Date        : Wed Jun 6 12:46:37 2012
*****
```

```
***** Library Verification Results *****
Total Cells verified   : 1
Number of Passing Cells : 0
Number of Failing Cells : 1
Number of Aborting Cells : 0
```

```
fm_shell (library_verify)>
fm_shell (library_verify)> report_status -f
*****
Report      : status

Reference   : r:/WORK/reference
Implementation : i:/WORK/implementation
Version     : G-2012.06
Date        : Wed Jun 6 12:46:37 2012
*****
```

```
#####
###   Failing Cells
#####
bad_cell

Total cells found: 1
```

---

## SEE ALSO

```
diagnose(2)
set_compare_point(2)
set_constant(2)
set_equivalence(2)
set_reference_design(2)
set_implementation_design(2)
verify(2)
```

---

## report\_svf

This command is obsolete and is replaced by the **report\_guidance** command.

---

## SEE ALSO

report\_guidance(2)

---

## report\_svf\_operation

Reports information about automated setup (SVF) operations. You can also report operations in specified compare point's fan-in.

---

### SYNTAX

```
report_svf_operation
[ -command command_name ]
[ -except_command command_name ]
[ -status status_name ]
[ -guide ]
[ -message ]
[ -summary ]
id_list | compare_points_list
```

---

### ARGUMENTS

#### **-command *command\_name***

Specifies the guide command to search for. Do not specify the "guide\_" prefix of the command name. The option may be repeated to search for multiple commands. The guide\_transformation sub-types may be used: map, merge, share, tree.

#### **-except\_command *command\_name***

Specifies the guide command to skip during searches. Do not specify the "guide\_" prefix of the command name. The option may be repeated to search for multiple commands. The guide\_transformation sub-types may be used: map, merge, share, tree.

#### **-status *status\_name***

Specifies the status to search for. The list returned includes only ID numbers for commands that have the specified status. The option may be repeated to search for multiple statuses. Statuses are:

- \* unprocessed - The operation has been read but not yet processed.
- \* accepted - The operation has been successfully processed and applied.
- \* rejected - The processing of the operation failed and the operation was not applied.
- \* unsupported - The operation is no longer or not yet supported by this release of Formality.
- \* unaccepted - Any status other than accepted.

#### **-guide**

Reports only the text of the commands.

#### **-message**

Reports only the warning messages associated with the operations.

#### **-summary**

Reports a tabular summary of operations with each id number, line number, command name, and status.

*id\_list* | *compare\_points\_list*

Specifies a list of ID numbers of the operations to be reported or list of compare points whose fan-in will be searched to find SVF operations. Use **find\_svf\_operation**, q.v., to generate a list of id numbers of selected operations.

---

## DESCRIPTION

Use this command to print information about SVF operations.

You can optionally specify a list of compare points and report SVF operations in their fan-in cone.

---

## EXAMPLES

```
fm_shell (verify)> report_svf_operation -summary -status rejected
```

Operation	Line	Command	Status
3	22	transformation_tree	rejected
9	95	change_names	rejected
10	114	change_names	rejected
11	133	change_names	rejected
12	153	change_names	rejected

1

```
fm_shell (verify)> report_svf_operation -summary -status rejected
-except_command change_names
```

Operation	Line	Command	Status
3	22	transformation_tree	rejected

1

```
fm_shell (verify)> report_svf_operation -status rejected -command tree
```

```
SVF Operation 3 (Line: 22) - transformation_tree. Status: rejected
## Operation Id: 3
guide_transformation \
  -design { test } \
  -type { tree } \
  -input { 16 src1 } \
  -input { 16 src2 } \
  -input { 16 src4 } \
  -input { 16 src6 } \
  -input { 16 src8 } \
  -output { 18 O1 } \
  -pre_resource { { 17 } add_5 = UADD { { src1 ZERO 17 } { src2 ZERO 17 } } } \
  -pre_resource { { 18 } add_5_2 = UADD { { add_5 ZERO 18 } { src4 ZERO 18 } } } \
  -pre_resource { { 18 } add_5_3 = UADD { { add_5_2 } { src6 ZERO 18 } } } \
  -pre_resource { { 18 } sub_5 = USUB { { add_5_3 } { src8 ZERO 18 } } } \
  -pre_assign { O1 = { sub_5 } } \
  -post_resource { { 18 } add_3_root_sub_5 = UADD { { src1 ZERO 18 }
    { src2 ZERO 18 } } } \
  -post_resource { { 18 } add_2_root_sub_5 = UADD { { src4 ZERO 18 }
    { src6 ZERO 18 } } } \
  -post_resource { { 18 } add_1_root_sub_5 = UADD { { add_3_root_sub_5 }
    { add_2_root_sub_5 } } } \
  -post_resource { { 18 } sub_0_root_sub_5 = USUB { { add_1_root_sub_5 }
    { src8 ZERO 18 } } } \
  -post_assign { O1 = { sub_0_root_sub_5 } }
```

```
Info: guide_transformation 3 (Line: 22) Could not find pre_resource 'sub_5' in design 'test'.
```

1

```
fm_shell (verify)> report_svf_operation -message -status rejected -command tree
```

```
Info: guide_transformation 3 (Line: 22) Could not find pre_resource 'sub_5' in design 'test'.
```

1

```
fm_shell (verify)> report_svf_operation -guide -status rejected -command tree
```

```
SVF Operation 3 (Line: 22) - transformation_tree. Status: rejected
```

```
## Operation Id: 3
```

```
guide_transformation \
-design { test } \
-type { tree } \
-input { 16 src1 } \
-input { 16 src2 } \
-input { 16 src4 } \
-input { 16 src6 } \
-input { 16 src8 } \
-output { 18 O1 } \
-pre_resource { { 17 } add_5 = UADD { { src1 ZERO 17 } { src2 ZERO 17 } } } \
-pre_resource { { { 18 } add_5_2 = UADD { { add_5 ZERO 18 } { src4 ZERO 18 } } } } \
-pre_resource { { { 18 } add_5_3 = UADD { { add_5_2 } { src6 ZERO 18 } } } } \
-pre_resource { { { 18 } sub_5 = USUB { { add_5_3 } { src8 ZERO 18 } } } } \
-pre_assign { O1 = { sub_5 } } \
-post_resource { { 18 } add_3_root_sub_5 = UADD { { src1 ZERO 18 } { src2 ZERO 18 } } } \
-post_resource { { { 18 } add_2_root_sub_5 = UADD { { src4 ZERO 18 } { src6 ZERO 18 } } } } \
-post_resource { { { 18 } add_1_root_sub_5 = UADD { { add_3_root_sub_5 } { add_2_root_sub_5 } } } } \
-post_resource { { { 18 } sub_0_root_sub_5 = USUB { { add_1_root_sub_5 } { src8 ZERO 18 } } } } \
-post_assign { O1 = { sub_0_root_sub_5 } }
```

1

```
fm_shell (verify)> report_svf_operation {r:/WORK/dp/O3[1] r:/WORK/dp/O3[4]}
-command merge
```

```
## SVF Operation 5 (Line: 47) - transformation_merge. Status: rejected
```

```
## Operation Id: 5
```

```
guide_transformation \
-design { dp } \
-type { merge } \
-input { 4 I1 } \
-input { 4 I2 } \
-input { 4 I3 } \
-input { 4 I4 } \
-output { 8 O1 } \
-pre_resource { { 8 } mult_12 = MULT_TC { { I1 } { I2 } { 0 } } } \
-pre_resource { { { 8 } mult_12_2 = MULT_TC { { I3 } { I4 } { 0 } } } } \
-pre_resource { { { 8 } add_12 = ADD { { mult_12 } { mult_12_2 } } } } \
-pre_assign { O1 = { add_12 } } \
-datapath add_12_DP_OP_258_7518_1
```

```
Info: guide_transformation 5 (Line: 47) Retrying with unread processing enabled.
```

```
Info: guide_transformation 5 (Line: 47) Could not find pre_resource 'mult_12' in design 'dp'.
```

```
Info: guide_transformation 5 (Line: 47) Could not find pre_resource 'mult_12_2' in design 'dp'.
```

```
Info: guide_transformation 5 (Line: 47) Could not find pre_resource 'add_12' in design 'dp'.
```

1

```
fm_shell (verify)> report_svf_operation r:/WORK/dp/O* -status rejected -command datapath
```

```
## SVF Operation 10 (Line: 116) - datapath. Status: rejected
```

```
## Operation Id: 10
```

```
guide_datapath \
-design { dp } \
-datapath { add_12_DP_OP_258_7518_1 } \
-body { dp_add_12_DP_OP_258_7518_0 }
```

```
Info: guide_datapath 10 (Line: 116) Pre-verification of
r:/WORK/dp/add_12_DP_OP_258_7518_1 INCONCLUSIVE.
```

1



---

## SEE ALSO

find\_svf\_operation(2)  
set\_svf(2)  
report\_guidance(2)  
remove\_guidance(2)

---

## report\_trace

Produce a report of performance profile metrics collected for traced commands.

---

### SYNTAX

```
report_trace [-start|-stop|resume]
               [-profile profile_type]
               [-command command_name]
               [-cumulative count]
               [-top count]
               [-quiet]
```

```
string profile_type
string command_name
int count
```

---

### ARGUMENTS

#### **-start**

This option is mutually exclusive with -stop, -resume, -profile, -top, -cumulative, -command. The option starts the collection of performance profile statics for each traced command invocation. If metric collection had previously been stopped with -stop, then previously collected data are deleted before collection starts.

#### **-stop**

This option is mutually exclusive with -start, -resume, -profile, -top, -cumulative, -command. The option stops the collection of performance profile statics for traced command invocations.

#### **-resume**

This option is mutually exclusive with -start, -stop, -profile, -top, -cumulative, -command. The option resume the collection of performance profile statics for traced command invocations. Previous gathered statics remain and newly collected metrics are added to pre-existing data. This option may be used after -stop to resume data collection without deleting previously collected data.

#### **-profile *profile\_type***

This option is mutually exclusive with -start, -stop, and -resume. This option selects the profile metrics that are included in the report. Allowed valuesA valid value is a list of permitted values {memory, cpu, time, count}, or the value all to select all metrics. If -profile is given, then the report output contains performance profile data of given types only. If the option is omitted, then it defaults to all.

#### **-cumulative *count***

This optional option is mutually exclusive with -start, -stop, -resume, and -command. This option limits the number of commands reported for the top resource consumer accumulated over all invocations. However, all commands that share the same usage metric as the minimum consumer included in the count will be shown. If the option is omitted, the report output contains the top 10 consumers.

#### **-top *count***

This optional option is mutually exclusive with -start, -stop, -resume and -command. This option limits the number of commands reported for the top resource consumer per single invocation. However, all commands that share the same usage metric as the

minimum consumer included in the count will be shown. If the option is omitted, the report output contains the top 10 consumers.

#### **-command *command\_name***

This option is mutually exclusive with -start, -stop, -resume, -top and -cumulative. This option causes a performance profile report to be displayed for the given command. Cumulative and top single invocation metrics are shown. If the command was not invoked, then a message with this information is displayed instead of a report.

#### **-quiet**

If given, this option causes the command to ignore error conditions such as an attempt to start profile gathering when it has already been started or reporting on a non-existent command. The command will exit quietly when it encounters an error condition.

---

## DESCRIPTION

The **report\_trace** command collects performance profile metrics on all traced command invocations since the last -start. Stopping the gathering is not necessary to produce a report. When performance profile collection is started with report\_trace -start, each traced command will be measured for the available performance metrics: memory, CPU, wallclock time, and call count. The accumulated profile data can be reported at any time by calling this command

Stopping the metric gathering with -stop freezes the gathered metrics until the next -start. When gathering is restarted, all previously gathered metrics are deleted. Alternatively, metric collection may be restarted without deleting previously collected data using -resume.

The **report\_trace** with no options will report the top 10 consumers in both cumulative and single call metrics for all profile types collected thus far.

---

## EXAMPLES

The following example starts the collection of performance profile metrics.

```
prompt> report_trace -start
on
```

The following example produces a report of top 10 commands with most usage for all profile types for both cumulative and individual call consumption. 10 is the default number reported for -top and -cumulative when these options are omitted.

```
prompt> report_trace
on
```

The following example produces a report of cumulative and the single most expensive invocation for each profile type for the command update\_timing.

```
prompt> report_trace -command update_timing
on
```

The following example produces a report of top 20 consumers for cumulative and single invocation collected thus far.

```
prompt> report_trace -top 20 -cumulative 20
on
```

The following example produces a report of top 5 cumulative consumption of memory.

```
prompt> report_trace -profile memory -cumulative 5
on
```

The following example produces a report of top 15 commands with most invocations.

```
prompt> report_trace -profile count -cumulative 15
on
```

The following example produces a report of top 10 commands with most cpu and wallclock time usage for both cumulative and individual call consumption. 10 is the default number reported for -top and -cumulative when these options are omitted.

```
prompt> report_trace -profile {cpu time}  
on
```

---

## SEE ALSO

- set\_trace\_option(2)
- get\_trace\_option(2)
- log\_trace(2)
- annotate\_trace(2)

---

## report\_truth\_table

Generate and print truth table for given signal.

---

### SYNTAX

```
report_truth_table [ signalId ]  
  [ -display_fanin ]  
  [ -fanin { list of signals }  ]  
  [ -constraint {signal=[0/1]}+  ]  
  [ -nb_lines int ]  
  [ -max_line int ]  
  [ -max_fanin int ]
```

---

### ARGUMENTS

#### ***signalId***

Name of signal(port/net/pin) for which to generate the truth table. Name must be valid Formality signal Id.

#### ***-display\_fanin***

This option is used to view only the fanin for given signal. No truth table is generated.

#### ***-fanin {signal signal ...}***

This option is used to view the truth table for a given signal in terms of the specified fanin signals. This option can be used to change the default order of the fanin printed in the truth table. The other use of this option is to limit the truth table to only those fanins that may be of interest to the user. In this case, the output will be expressed as a logical equation in terms of the unspecified fanin signals.

#### ***-constraint {signal=0/1 signal=0/1 ...}***

This option allows the user to constraint fanin signals to either 0 or 1. This will help in reducing the size of the truth table.

#### ***-nb\_lines integer***

This option sets maximum size of truth table row. This is used to limit the size of logical expression for specified signal. Default value for this size is 4096.

#### ***-max\_line integer***

This option sets maximum number of lines that can be printed for the truth table. Default value is 512.

#### ***-max\_line integer***

This option sets maximum fanin size that can be printed for the truth table. Default value is 25.

---

### DESCRIPTION

This command is used to view the truth table for given signal. It enhances the debug environment in Formality and can be used

specially for smaller cones or library cells. This feature provides user the ability to view truth table for failing points in terms of desired signal fanin. There is also an option to analyze the output value by constraining fanin signals to 1 or 0.

The **report\_truth\_table** command returns the following:

- \* 0 for failure
- \* 1 for success

---

## EXAMPLES

- \* View truth table for a two-input and cell

```
(fm_shell) report_truth_table r:/WORK/my_and/out
Truth table for signal : "out"
-----
in1
| in2
||
0 . | 0
1 0 | 0
1 1 | 1

***** End truth table *****
```

- \* View truth table for D-flip flop

```
(fm_shell) report_truth_table r:/WORK/dff/q
Truth table for signal : "q"
-----
clk<1>
| clk
| | d
| | |
0 0 . | q<1>
0 1 0 | 0
0 1 1 | 1
1 . . | q<1>

***** End truth table *****
```

- \* View truth table for 4-input and gate in terms of chosen fanin

```
(fm_shell) report_truth_table -fanin { a b } r:/WORK/my_and/out
Truth table for signal : "out"
-----
a
| b
| |
0 . | 0
1 0 | 0
1 1 | c & d

***** End truth table *****
```

- \* View truth table for 2-input xor by constraining one signal

```
(fm_shell) report_truth_table -constraint {y=1} r:/WORK/my_xor/out
Truth table for signal : "out"
-----
y = 1
z
|
0 | 1
1 | 0

***** End truth table *****
```

---

## SEE ALSO

---

## report\_undriven\_nets

Reports the nets that are undriven after match.

---

### SYNTAX

**report\_undriven\_nets**  
[-substring *substring*]  
[-reference]  
[-implementation]

#### Data Types

*substring* string

#### Enabled Shell Modes

Match  
Verify

---

### ARGUMENTS

#### -substring *substring*

Reports only the nets containing the specified substring.

#### -reference

Reports the undriven nets in the reference design.

#### -implementation

Reports the undriven nets in the implementation design.

---

### DESCRIPTION

This command reports the nets that are undriven after the most recent match. The report includes the total number of undriven nets, followed by a list of undriven nets.

---

### EXAMPLES

The following example is a report generated by the **report\_undriven\_nets** command.

```
prompt> report_undriven_nets
*****
```



```
Report      : undriven_nets

Reference   : r:/WORK/top
Implementation : i:/WORK/top
Version     : G-2012.06
Date       : Wed Jun 6 12:46:37 2012
*****
```

4 Undriven nets:

```
r:/WORK/top/out_or
r:/WORK/top/or_one.a
i:/WORK/top/and_zero.b
i:/WORK/top/out_or
1
```

---

## SEE ALSO

report\_multidriven\_nets(2)

---

## report\_unmatched\_inputs

Reports unmatched inputs from the most recent verification - OBSOLETE.

---

### DESCRIPTION

This command has been replaced by the **report\_unmatched\_points** command.

---

### EXAMPLES

---

### SEE ALSO

report\_unmatched\_points(2)  
report\_matched\_points(2)  
report\_failing\_points(2)  
report\_passing\_points(2)  
report\_aborted\_points(2)

---

## report\_unmatched\_points

Reports the unmatched design objects after using the **match** command.

---

### SYNTAX

```
int report_unmatched_points
  [-compare_rule]
  [-substring substring]
  [-point_type point_type]
  [-inputs input_type]
  [-status status]
  [-except_status except_status]
  [-reference]
  [-implementation]
  [-datapath]
  [-list]
  [-never_loads]
  [-always_reset]
  [object_list [-type type]]
```

#### Data Types

```
substring string
point_type string
input_type string
status string
except_status string
object_list string
type string
```

#### Enabled Shell Modes

```
Match
Verify
```

---

### ARGUMENTS

#### -compare\_rule

Reports mapped object names using the compare rules.

#### -substring *substring*

Reports compare points with the specified substring.

#### -point\_type *point\_type*

Reports the specified types of compare points. By default, input points and compare points of all types are included in the report. You need to specify one of the following point types:

- *all* - Reports all object types.
- *bbox* - Reports black boxes.

- *bbox\_pin* - Reports all black-box pins.
- *bbox\_input* - Reports black-box input pins.
- *bbox\_output* - Reports black box output pins.
- *bbox\_inout* - Reports black box bidirectional pins.
- *block* - Reports hierarchical blocks.
- *block\_pin* - Reports hierarchical block pins.
- *block\_input* - Reports hierarchical block input pins.
- *block\_output* - Reports hierarchical block output pins.
- *block\_inout* - Reports hierarchical block bidirectional pins.
- *loop* - Reports loop points.
- *net* - Reports net points.
- *cut* - Reports cut points. Includes Und and Unk cone inputs.
- *bbox\_net* - Reports resolved black box and multiply-driven nets.
- *port* - Reports all ports.
- *input* - Reports input ports.
- *output* - Reports output ports.
- *inout* - Reports bidirectional ports.
- *directly\_undriven\_output* - Reports output and bidirectional ports without connected nets or with connected nets but without a driving pin.
- *reg* - Reports all registers.
- *DFF* - Reports flip-flop registers.
- *LAT* - Reports latch registers.
- *PDCut* - Reports power domain pin compare points.
- *PGPin* - Reports power, ground, or power-down function compare points.

#### **-inputs *input\_type***

Reports points with undriven or unmatched inputs.

#### **-status *status***

Reports the points that match the specified status. If both the **-status** and **-point\_type** options are specified, the reported points must pass both filters.

By default, the **report\_unmatched\_points** command does not report the points with the *unread* status. The command also does not report the unmatched *dont\_verify* points resulting in verification failure. To suppress the reporting of all *dont\_verify* points, use the **-except\_status dont\_verify** option.

The **-status** option can have one of the following arguments:

- *none* - Reports all except these special types.
- *trans* - Reports transparent latch registers.
- *const* - Reports all constant registers.
- *const0* - Reports constant 0 registers.

- *const1* - Reports constant 1 registers.
- *constX* - Reports constant X registers.
- *const0X* - Reports constrained 0X registers.
- *const1X* - Reports constrained 1X registers.
- *clock\_gate* - Reports clock-gate latches.
- *dont\_verify* - Reports dont\_verify points.
- *unread* - Reports unread points.
- *undriven* - Reports undriven points.
- *targeted* - Reports points targeted for verification.
- *not\_targeted* - Reports points that are not targeted for verification.
- *removed* - Reports points that are removed from reference design.

#### **-except\_status except\_status**

Excludes points that match the specified type from the report.

You need to specify one of the following values for the *except\_status* argument:

- *trans* - Excludes transparent latch registers.
- *const* - Excludes all constant registers.
- *const0* - Excludes constant 0 registers.
- *const1* - Excludes constant 1 registers.
- *constX* - Excludes constant X registers.
- *const0X* - Excludes constrained 0X registers.
- *const1X* - Excludes constrained 1X registers.
- *clock\_gate* - Excludes clock-gate latches.
- *dont\_verify* - Excludes all *dont\_verify* points. By default, the report includes unmatched dont\_verify points that might result in verification failure.
- *unread* - Excludes unread points.
- *undriven* - Excludes undriven points.
- *targeted* - Excludes points targeted for verification.
- *not\_targeted* - Excludes points not targeted for verification.
- *passing\_feedthrough\_points* - Excludes points that have a passing feedthrough verification status. This is only available after verify.

#### **-reference**

Reports compare points in the reference design. By default, the **report\_unmatched\_points** command reports compare points in both the reference and the implementation designs.

#### **-implementation**

Reports compare points in the implementation design. By default, the **report\_unmatched\_points** command reports compare points in both the reference and the implementation designs.

#### **-datapath**

Reports datapath blocks in the reference design.

#### **-list**

Returns a list of point names which can be used in further Tcl processing.

#### **-never\_loads**

Filters the report to only include register compare points that do not synchronously load.

#### **-always\_reset**

Filters the report to only include register compare points that are constantly reset.

#### ***object\_list* -type *type***

Reports unmatched cone inputs in the fanin of the compare point specified by the *object\_list* option. Use the **-type** *ID\_type* option to specify the type of the compare point if its name is ambiguous. The **-type** *ID\_type* option is valid only when you use the *objectID* argument.

---

## DESCRIPTION

This command reports the design objects that are not matched. The report includes the total number of unmatched points followed by a list of unmatched design objects.

---

## EXAMPLES

The following command reports the unmatched design objects in both the reference and the implementation designs.

```
fm_shell> report_unmatched_points
*****
Report      : unmatched_points

Reference   : HDL:/WORK/CORE
Implementation : SCAN:/WORK/CORE
Version     : G-2012.06
Date       : Wed Jun 6 12:46:37 2012
*****

3 Unmatched points (0 reference, 3 implementation):

Impl Port SCAN:/WORK/CORE/test_se

Impl Port SCAN:/WORK/CORE/test_si

Impl Port SCAN:/WORK/CORE/test_so

[BBNet: multiply-driven net
BBox: black box
BBPin: black box pin
Block: hierarchical block
BIPin: hierarchical block pin
Cut: cut-point
DFF: non-constant DFF register
DFF0: constant 0 DFF register
TLA: transparent latch register
TLA0X: transparent constrained 0X latch register
TLA1X: transparent constrained 1X latch register
Loop: cycle break point
Net: matchable net
Port: primary (top-level) port
Und: undriven signal cut-point]
1
```

---

## SEE ALSO

report\_aborted\_points(2)  
report\_failing\_points(2)  
report\_matched\_points(2)  
report\_passing\_points(2)  
report\_unverified\_points(2)  
report\_feedthrough\_status(2)

---

## report\_unread\_endpoints

Reports the end objects that cause points to become unread.

---

### SYNTAX

```
int report_unread_endpoints
  [-all]
  [-point_type point_type]
  [-cause cause]
  [unread_points_list]
```

#### Data Types

*point\_type* string  
*cause* string  
*unread\_points\_list* string

#### Enabled Shell Modes

Match  
Verify

---

### ARGUMENTS

#### -all

Reports all unread points in the design.

#### -point\_type *point\_type*

Reports the unread points of the specified point type argument. By default, unread input points and compare points of all types except block and block pin are included.

Specify one of the following arguments for the **point\_type** argument:

- *bbox\_pin* - Reports unread black box pins.
- *bbox\_input* - Reports unread black box input pins.
- *bbox\_output* - Reports unread black box output pins.
- *bbox\_inout* - Reports unread black box bidirectional pins.
- *loop* - Reports unread loop points.
- *cut* - Reports unread cutpoints.
- *bbox\_net* - Reports unread black-box resolved and multiply-driven nets.
- *port* - Reports all unread ports.
- *input* - Reports unread input ports.



- *inout* - Reports unread bidirectional ports.
- *reg* - Reports all unread registers.
- *DFF* - Reports unread flip-flop registers.
- *LAT* - Reports unread latch registers.

**-cause cause**

Reports the end points that match the specified cause argument.

Specify one of the following **cause** arguments for the option:

- *no\_reader* - Reports end points due to no reader.
- *constant* - Reports end points due to blocking constant.

**unread\_points\_list**

Reports the specified unread points. The format of the list is {cp1 cp2}. Use wildcard characters to match multiple points.

---

## DESCRIPTION

This command reports unread end points. It reports end objects which cause points to become unread. The report lists each end point, its type, and the cause for being a path terminating object.

---

## EXAMPLES

The following example reports a specific unread register.

```
fm_shell> report_unread_endpoints r:/WORK/top/q3_reg
*****
Report      : unread_endpoints

Reference   : r:/WORK/top
Implementation : i:/WORK/top
Version     : G-2012.06
Date        : Wed Jun 6 12:46:37 2012
*****
```

Following 2 blocking objects identified in the fanout:

```
(Net ) r:/WORK/top/fm_m21/andOut0[1] (blocked by constant)
(Net ) r:/WORK/top/q2n (no reader)
```

The following example reports all unread registers in the design.

```
fm_shell> report_unread_endpoints -all -point_type reg
*****
Report      : unread_endpoints

Reference   : r:/WORK/top
Implementation : i:/WORK/top
Version     : G-2012.06
Date        : Wed Jun 6 12:46:37 2012
*****
```

Following 5 blocking objects identified in the fanout:

```
(Cell) r:/WORK/top/q5_reg (no reader)
```

(Net ) r:/WORK/top/fm\_m13/andOut0[0] (blocked by constant)  
(Net ) r:/WORK/top/fm\_m21/andOut0[1] (blocked by constant)  
(Net ) r:/WORK/top/q2n (no reader)  
(Net ) i:/WORK/top/fm\_m10/andOut0[0] (blocked by constant)

---

## SEE ALSO

report\_matched\_points(2)  
report\_unmatched\_points(2)  
diagnose(2)

---

## report\_unverified\_points

Reports the compare points that must be verified again.

---

### SYNTAX

```
status report_unverified_points
  [-compare_rule]
  [-substring string]
  [-point_type point_type]
  [-inputs input_type]
  [-status status]
  [-cause cause]
  [-list]
  [-last]
  [-never_loads]
  [-always_reset]
```

#### Data Types

```
string string
point_type string
input_type string
status string
cause string
```

#### Enabled Shell Modes

```
Match
Verify
```

---

### ARGUMENTS

#### -compare\_rule

Reports objects that are mapped using compare rules.

#### -substring *string*

Reports compare points containing the specified string argument.

#### -point\_type *point\_type*

Reports the compare points that are of the specified point type argument. By default, all compare point types are included.

Specify one or more of the following point types:

- *bbox\_pin* - Reports all black-box pin compare points.
- *bbox\_input* - Reports black-box input pin compare points.
- *bbox\_inout* - Reports black-box bidirectional pin compare points.
- *loop* - Reports loop compare points.

- *bbox\_net* - Reports black-box resolved and multiply-driven nets.
- *cut* - Reports cutpoints.
- *port* - Reports all port compare points.
- *output* - Reports output port compare points.
- *inout* - Reports bidirectional port compare points.
- *directly\_undriven\_output* - Reports output and bidirectional ports that do not have a connected net, or that have a connected net but do not have a driving pin.
- *reg* - Reports all register compare points.
- *DFF* - Reports flip-flop register compare points.
- *LAT* - Reports latch register compare points.
- *trans* - Reports transparent latch register compare points.
- *PDCut* - Reports power domain pin compare points.
- *PGPin* - Reports power, ground, or power-down function compare points.

**-inputs *input\_type***

Reports compare points with input points that are undriven or unmatched.

Specify one of the following input type arguments for the option:

- *undriven* - Reports compare points with undriven input points
- *unmatched* - Reports compare points with unmatched input points

**-status *status***

Reports compare points with the specified polarity arguments. By default, compare points with either polarities are reported.

Specify one of the following polarities:

- *inverted* - Reports compare points with inverted match polarity
- *noninverted* - Reports compare points with noninverted match polarity

**-cause *cause***

Reports the compare points whose unverified status is due to the specified cause. Specify one of the following values for the *cause* argument:

- *interrupt* - Reports compare points that are unverified due to an interrupt (^C) or timeout.
- *fail\_limit* - Reports compare points that are unverified because failing point limit was reached.
- *matching* - Reports compare points that are unverified because of matching changes.

**-list**

Reports a list of pairs of point names that can be used in further Tcl processing.

**-last**

Reports the points that are unverified in the previous verification.

**-never\_loads**

Filters the report to only include register compare point pairs that do not synchronously load.

**-always\_reset**

Filters the report to only include register compare point pairs that are constantly reset.

---

## DESCRIPTION

This command reports compare points that are not verified.

The reports includes the total number of unverified compare points in each of the categories, followed by the design objects that represent the unverified compare point.

---

## EXAMPLES

```
fm_shell> report_unverified_points
*****
Report      : unverified_points

Reference   : r:/WORK/reference
Implementation : i:/WORK/implementation
Version     : G-2012.06
Date        : Wed Jun 6 12:46:37 2012
*****

7 Unverified compare points:
  0 unverified because of interrupt or timeout
  7 unverified because failing point limit reached
  0 affected by matching changes

Ref DFF     r:/WORK/reference/ffA/q_reg[0]
Impl DFF     i:/WORK/implementation/ffA/q_reg[0]

Ref DFF     r:/WORK/reference/ffB/q_reg[0]
Impl DFF     i:/WORK/implementation/ffB/q_reg[0]

Ref DFF     r:/WORK/reference/ffB/q_reg[1]
Impl DFF     i:/WORK/implementation/ffB/q_reg[1]

Ref DFF     r:/WORK/reference/ffC/q_reg[0]
Impl DFF     i:/WORK/implementation/ffC/q_reg[0]

Ref DFF     r:/WORK/reference/ffC/q_reg[1]
Impl DFF     i:/WORK/implementation/ffC/q_reg[1]

Ref DFF     r:/WORK/reference/ffC/q_reg[2]
Impl DFF     i:/WORK/implementation/ffC/q_reg[2]

Ref DFF     r:/WORK/reference/ffC/q_reg[3]
Impl DFF     i:/WORK/implementation/ffC/q_reg[3]

[BBNet: multiply-driven net
BBPin: black box pin
Cut: cut-point
DFF: non-constant DFF register
DFF0: constant 0 DFF register
DFF1: constant 1 DFF register
DFFX: constant X DFF register
DFF0X: constrained 0X DFF register
DFF1X: constrained 1X DFF register
TLA: transparent latch register
TLA0X: transparent constrained 0X latch register
TLA1X: transparent constrained 1X latch register
Loop: cycle break point
Port: primary (top-level) port
Und: undriven signal cut-point]
```

1

---

## SEE ALSO

report\_failing\_points(2)  
report\_passing\_points(2)  
report\_aborted\_points(2)  
report\_matched\_points(2)  
report\_unmatched\_points(2)  
report\_not\_compared\_points(2)

---

## report\_upf

Reports information on the UPF objects that are inserted into the designs using the **load\_upf** command.

---

### SYNTAX

```
status report_upf
  [-r]
  [-i]
  [-container container_name]
  [-verbose]
  [-domain]
  [-isolation]
  [-retention]
  [-power_switch]
  [-pst]
  [-instance_paths]
```

#### Data Types

*container\_name* string

#### Enabled Shell Modes

Setup  
Match  
Verify

---

### ARGUMENTS

**-r**

Reports the UPF information of the reference container. By default, the **report\_upf** command reports information on all containers.

**-i**

Reports UPF information of the implementation container. By default, the **report\_upf** command reports information on all containers.

**-container** *container\_name*

Specifies a container to report.

**-verbose**

Reports detailed information about the loaded files, the number of cells inserted, and the implemented power-state tables. Specifying the following options at the same time is the same as using the *-verbose* option: **-retention**, **-isolation**, **-power\_switch**, **-pst**.

**-domain**

Reports all the power domains that are defined in the loaded UPF files, their primary supplies, and the root elements for each

domain.

#### **-isolation**

Reports all the isolation cells that are inserted by each power domain and the isolation strategy they came from.

#### **-retention**

Reports all the retention cells that are inserted by Formality by each power domain and the retention strategy they came from.

#### **-power\_switch**

Reports the power switch cells that are inserted into the design along with their power domain name and output supply net.

#### **-pst**

Reports summary information for loaded power-state tables. This option reports the total number of supplies and states for each table.

#### **-instance\_paths**

Reports the instance path names for cells in addition to the folded design path names which are the default. This option will affect the **-verbose**, **-domain**, **-isolation**, **-retention**, and **-power\_switch** options. The **-instance\_paths** option is only available after match.

---

## DESCRIPTION

This command reports a summary of UPF information of all containers. When data is reported for a container, it begins with the list of UPF files that were loaded followed by the setting of the **upf\_implementation\_based\_on\_file\_headers** variable and file comments. Totals are reported for the number of defined domains, inserted isolation cells, retention cells, power switch cells, and power-state tables created.

When **-isolation**, **-retention**, **-power\_switch**, or **-pst** options are specified, the inferred cells or UPF objects are grouped and listed after each UPF file they originated from. The UPF file line number of the creation command is reported for each object. Isolation and retention cells have a heading with the total number of cells inserted for the specified upf file. Then it has a sub-heading for each strategy, which displays the UPF file line number, power domain name, strategy name, and total cells inserted for this strategy. That will be followed by the folded design path name to each inferred cell for the given strategy. UPF power switch cells have a heading with the total number of switch cells inserted for the specified UPF file. Then a sub-heading containing the UPF file line number, domain name, and switch name is displayed. This is followed by the folded design path to the UPF switch cell, a sub-heading: Output supply net, and then the path name to the switch output supply net.

The **-instance\_paths** option is available after matching. When this option is specified, the command reports the instance pathnames of all three cell types in addition to the folded design path names. Power state tables are displayed with a heading indicating the total number of tables created for the UPF file. A sub-heading for each power state table displays the UPF file line number of the creation command, and power state table name. This will be followed by the total number of supplies and states for each power state table.

---

## EXAMPLES

The following example reports UPF summary information on the default reference and implementation containers.

Container: r

UPF file loaded and file control variable value:

```
-----
/slowfs/dept5138v/sscherr/work/upf/report/domain_merge/top_u5.upf
upf_implementation_based_on_file_headers: true
```

Power State Tables created: 0

Isolation cells inserted: 0



Retention cells inserted: 0

UPF power switch cells inserted: 0

UPF file loaded and file control variable value:

-----  
/slowfs/dept5138v/sscherr/work/upf/report/domain\_merge/u51.upf  
upf\_implementation\_based\_on\_file\_headers: true

Power State Tables created: 1

Isolation cells inserted: 0

Retention cells inserted: 1

UPF power switch cells inserted: 1

UPF file loaded and file control variable value:

-----  
/slowfs/dept5138v/sscherr/work/upf/report/domain\_merge/top\_only1.upf  
upf\_implementation\_based\_on\_file\_headers: true

Power State Tables created: 2

Isolation cells inserted: 24

Retention cells inserted: 7

UPF power switch cells inserted: 5

load\_upf has not been run on container: i.  
1

---

## SEE ALSO

load\_upf(2)  
upf\_implementation\_based\_on\_file\_headers(3)

---

## report\_user\_matches

Reports the user-defined matched points.

---

### SYNTAX

status **report\_user\_matches**  
[-inverted | -noninverted | -unknown]

---

### ARGUMENTS

#### -inverted

Reports the user-defined matches that have an inverted polarity. This option is mutually exclusive to the *-noninverted* and *-unknown* options.

#### -noninverted

Reports the user-defined matches that have the regular polarity. This option is mutually exclusive to the *-inverted* and *-unknown* options.

#### -unknown

Reports the user-defined matches that have an unknown polarity. This option is mutually exclusive to the *-inverted* and *-noninverted* options.

---

### DESCRIPTION

This command reports compare points that match when the **set\_user\_match** command is specified and returns a list of user-defined matched compare point pairs.

User-defined matches are not applied to the designs until the *match* or *verify* commands are run. Other related points are matched as a result of a user-defined match. After a user-defined match is applied, you can report on the affected points with the *report\_matched\_points -method user* command.

---

### EXAMPLES

The following example reports the user-defined matched points.

```
fm_shell (setup)> report_user_matches
*****
Report      : user_matches

Reference   : spec:/WORK
Implementation : impl:/WORK
Version     : G-2012.06
```

Date : Wed Jun 6 12:46:37 2012  
\*\*\*\*\*

User matched points:

(Port) impl:/WORK/UPC/UPC\_DATA[4]  
(Port) spec:/WORK/UPC/UPC\_DATA[5]

(Port) spec:/WORK/UPC/UPC\_DATA[4]  
(Port) (-) impl:/WORK/UPC/UPC\_DATA[5]

(BBPin) impl:/WORK/UPC/INT\_UPC\_reg[3]  
(BBPin) (?) spec:/WORK/UPC/INT\_UPC\_reg[3]

---

## SEE ALSO

remove\_compare\_point(2)  
report\_matched\_points(2)  
set\_user\_match(2)

---

## report\_verify\_points

Reports information about the user-defined verify points.

---

### SYNTAX

status **report\_verify\_points**

---

### DESCRIPTION

This command reports the points that are defined as verify points using the *set\_verify\_points* command.

The command also lists the current verification status, if known, of each point.

---

### EXAMPLES

The following example shows how to use the command. Each line represents a design object.

```
fm_shell (verify)> report_verify_points
Verify points:
(PASSED) (Port) r:/WORK/top/o3
(PASSED) (Port) r:/WORK/top/o4
```

---

### SEE ALSO

[remove\\_verify\\_points\(2\)](#)  
[set\\_verify\\_points\(2\)](#)

---

## report\_vhdl

Reports a list of VHDL configurations, entities, architectures, and associated generics.

---

### SYNTAX

```
status report_vhdl
[-configuration]
[-entity]
[-package]
```

---

### ARGUMENTS

#### **-configuration**

Reports the top-level entities and the associated architectures.

#### **-entity**

Reports the entities, including their architectures and generics with their default values.

#### **-package**

Reports the packages that are loaded in the current design.

---

### DESCRIPTION

This command reports a list of VHDL configurations, entities, generics and architectures in the Formality environment.

---

### EXAMPLES

The following example reports all VHDL objects in the Formality environment.

```
fm_shell> report_vhdl
*****
Report      : vhdl

Reference   : ref:/WORK
Implementation : impl:/WORK
Version     : G-2012.06
Date       : Wed Jun 6 12:46:37 2012
*****

***** Container ref *****
loaded entities:
-----
ref:/WORK/FULL_ADDER
Generics:
```

```
None
Architectures:
NEW_FULL_ADDER
REGULAR_FULL_ADDER
ref:/WORK/HALF_ADDER
Generics:
None
Architectures:
REGULAR_HALF_ADDER
NEW_HALF_ADDER
ref:/WORK/generic2
Generics:
n = No Default
Architectures:
GENERIC2
loaded configurations:
-----
ref:/WORK/ConfigAdd
FULL_ADDER
Regular_Full_Adder
ref:/WORK/ConfigHalf
HALF_ADDER
New_Half_Adder
loaded packages:
-----
ref:/WORK/PACK_PACK100
```

1

---

## SEE ALSO

---

## restore\_session

Restores a saved Formality session.

---

### SYNTAX

status **restore\_session**  
*file*

#### Data Types

*file* string

---

### ARGUMENTS

*file\_name*

Specifies a file that is previously saved by the **save\_session** command or using the Formality GUI.

---

### DESCRIPTION

This command restores a previously saved Formality session. When you restore a session, all information in the current Formality session is lost, unless the current session is already saved.

Restored information includes design and technology libraries, current reference and implementation designs, design and environment parameters, and verification and diagnosis status.

---

### EXAMPLES

The following example restores information from a session file named *synth\_test*, in which verification succeeded.

```
fm_shell> restore_session synth_test.fss  
Session restored.  
Last Verification Status:  
reference design : s:/WORK/CORE  
implementation design: i:/WORK/CORE  
Verification SUCCEEDED  
Diagnosis - N/A
```

The following example restores information from a session file named *synth\_test\_2*, in which the implementation and reference containers are not established.

```
fm_shell> restore_session synth_test_2.fss  
Session restored.  
Last Verification Status: Verification not run.
```

---

## SEE ALSO

`save_session(2)`



---

## rewire\_connection

Rewires the input pins driven by one object so that they are driven by another object.

---

### SYNTAX

```
status rewire_connection  
  [-type ID_type_list]  
  [-invert]  
  -from ID1 -to ID2
```

#### Data Types

```
ID_type_list string  
ID1 string  
ID2 string
```

---

### ARGUMENTS

#### -type *ID\_type\_list*

Specifies the type of the specified objects. Use this option if the design contains more than one type of object with the specified name. Specify one of the following object types:

- *port* - Specifies that both objects are ports
- *pin* - Specifies that both objects are pins
- *net* - Specifies that both objects are nets
- *{pin net}* - Specifies that the first object is a pin and the second is a net
- *{port net}* - Specifies that the first object is a port and the second is a net
- *{net pin}* - Specifies that the first object is a net and the second is a pin
- *{net port}* - Specifies that the first object is a net and the second is a port
- *{port pin}* - Specifies that the first object is a port and the second is a pin
- *{pin port}* - Specifies that the first object is a pin and the second is a port

#### -invert

Inverts the connections.

#### -from *ID1*

Specifies the design object that drives the input pins that will be reconnected to the object specified by the -to *ID2* argument. The object specified by the -from *ID1* argument must be one of the following:

- input or inout port
- output or inout pin
- net

**-to ID2**

Specifies the new driver of the input pins driven by the object specified by the *-from ID1* argument. The object specified by the *-to ID2* argument must be one of the following:

- input or inout port
- output or inout pin
- net

---

**DESCRIPTION**

This command rewires the design that contains the specified objects. The specified objects must belong to the same design and must be one of the following:

- input or inout port
- output or inout pin
- net

The input pins driven by the object specified with the *-from ID1* argument are disconnected from their net and reconnected to the net driven by the object specified with the *-to ID2* argument.

---

**EXAMPLES**

This example shows how to reconnect the input pins driven by port P2 to be driven by port P1 instead. In this case, the *-type* argument differentiates the port from a similarly named net.

```
fm_shell> rewire_connection -type port -from ref:/WORK/CORE/P2 -to ref:/WORK/CORE/P1  
Rewired port 'P1' and port 'P2'  
1
```

---

**SEE ALSO**

---

## run\_alterate\_strategies

Runs alternate strategies in parallel.

---

### SYNTAX

```
status run_alterate_strategies
  [-directory pathname]
  [-replace]
  [-session session_file]
  [-tclfile tcl_file]
  [-strategies strategies_list]
  [-run_all]
```

#### Data Types

```
pathname      string
session_file  string
tcl_file      string
strategies_list string
integer       integer
```

---

### ARGUMENTS

#### **-directory *pathname***

Specifies the directory containing data for all the runs.

#### **-replace**

Replaces the existing directory.

#### **-session *session\_file***

Specifies the session file containing the designs.

#### **-tclfile *tcl\_file***

Specifies the Tcl file with scripts to read the designs.

#### **-strategies *strategies\_list***

Specifies the list of strategies to run.

#### **-run\_all**

Runs all specified strategies to completion even if one strategy is successful.

---

### DESCRIPTION

This command automates the process of running alternate strategies in parallel. If one of the alternate strategy successfully completes verification, all other strategy runs are terminated.

All log files and run information is generated within the directory specified using the **-directory** option. If this option is not specified, a unique directory starting with the prefix `formality_alterate_strategy` is created.

Either a session file or a Tcl file must be specified. If the Tcl file is specified, it must contain the **verify** command.

You can specify the list of strategies to be run using the **-strategies** option. The list of currently supported strategies is stored in the **verification\_alterate\_strategy\_names** variable. If the **-strategies** option is not specified, all the supported strategies are run, except for the default strategy *none*. This is because the command assumes that you have used the default strategy, and the results were inconclusive.

**set\_run\_alterate\_strategies\_options** must be issued prior to **run\_alterate\_strategies** command.

`set_run_alterate_strategies_options` command specifies the compute farm configuration necessary to start alternate strategies in parallel.

By default, when one of the alternate strategies successfully completes verification, remaining running strategies are killed. Strategies that are pending in the queue are not started. You can use the **-run\_all** option to override this behavior. With this option, you can complete running all strategies. This option can also be used to identify a strategy that takes the least amount of resources to verify the design.

By default, alternate strategy master and workers communicate using IPv4 protocol. IPv6 protocol can be enabled through an environment variable `CDPL_IPV6`.

To enable IPv6 through this variable: `setenv CDPL_IPV6`

To disable IPv6 or to use IPv4 protocol: `unsetenv CDPL_IPV6`

Following protocols are supported for launchig jobs on remote machines:

```
LSF
SGE
PBS
RTDA
NB
CUSTOM (users can specify job submit script)
```

---

## EXAMPLES

The following examples illustrate the command usage for running alternate strategies in parallel in different farm environments.

### 1. SGE farm - 16 workers each using 4 cores

```
fm_shell> set_run_alterate_strategies_options -max_cores 4 -protocol SGE
-submit_command "qsub -V -P bnormal -cwd
-l arch=glinux,os_bit=64,mem_free=10G -pe mt 4" -num_processes 16
fm_shell> run_alterate_strategies -session post_match.fss
```

### 2. SGE farm - custom script for 16 workers each using 4 cores

```
fm_shell> set_run_alterate_strategies_options -max_cores 4 -protocol SGE
-submit_command custom.scr -num_processes 16
fm_shell> run_alterate_strategies -session post_match.fss
```

```
custom.scr
#!/bin/csh -f
qsub -V -P bnormal -cwd -l arch=glinux,os_bit=64,mem_free=10G -pe mt 4 $*
```

### 3. SGE farm - 16 workers each using 4 cores with -tclfile option

```
fm_shell> set_run_alterate_strategies_options -max_cores 4 -protocol SGE
-submit_command "qsub -V -P bnormal -cwd
-l arch=glinux,os_bit=64,mem_free=10G -pe mt 4" -num_processes 16
fm_shell> run_alterate_strategies -tclfile fm.tcl
```

```
fm.tcl
set_svf default.svf
read_container -r ref.fsc
```

```
read_container -i impl.fsc  
verify  
quit
```

#### 4. LSF farm - 8 workers each using 4 cores

```
fm_shell> set_run_alterate_strategies_options -max_cores 4 -protocol LSF  
-submit_command "bsub -n 4 -R \"qscm\" -R \"rusage\\[mem=32000]\\\"  
-R \"span\\[hosts=1\\]\" -num_processes 8  
fm_shell> run_alterate_strategies -session post_match.fss
```

---

## SEE ALSO

```
set_run_alterate_strategies_options(2)
```

---

## save\_session

Saves the current Formality session.

---

### SYNTAX

status **save\_session**  
[-replace]  
*file*

#### Data Types

*file* string

---

### ARGUMENTS

#### -replace

Replaces an existing file with the file being saved.

#### *file*

Specifies the name of the file in which the Formality session is saved. You can specify the full path name or only the file name. If you do not specify the path, the tool saves the file in the current working directory.

---

### DESCRIPTION

This command saves the current Formality session to a specified .fss file.

The session information includes all open containers and environment parameters, verification results, and diagnosis status. You must have successfully run the **set\_top** command on the containers before the session can be saved.

Note: Backward compatibility is not guaranteed for Formality session files. New versions of the tool might not support session files generated from earlier versions.

---

### EXAMPLES

The following example writes the Formality session information to the file named *regression\_out* in the \$TEST directory.

```
fm_shell> save_session $TEST/regression_out  
Info: wrote file '/d/atg2/test/regression_out.fss'
```

## SEE ALSO

`restore_session(2)`

---

## select\_cell\_list

Selects library cells depending on the option specified. This command is available only in the library verification mode.

---

### SYNTAX

```
status select_cell_list
  [-add cell_names ]
  [-remove cell_names ]
  [-clear]
  [-file file_name]
  [cell_names]
```

#### Data Types

*cell\_names* string  
*file\_name* string

---

### ARGUMENTS

#### **-add *cell\_names***

Adds the specified cells to the list of cells that are selected for verification. You can use wildcard characters to specify a range of cells.

#### **-remove *cell\_names***

Removes the specified cells from the list of cells that are selected for verification. You can use wildcard characters to specify a range of cells.

#### **-clear**

Clears cells from the list of cells that are selected for verification.

#### **-file *file\_name***

Adds cells from the specified file to the list of cells that are selected for verification. The file must contain cell names that are separated by spaces. You can use wildcard characters to specify the file name.

#### ***cell\_names***

Specifies cells for verification. You can use wildcard characters to specify a range of cells. This option clears the existing list of cells that are selected for verification.

---

### DESCRIPTION

This command manages the list of cells that are selected for verification. By default, Formality verifies only the cells that match in the reference and implementation containers. Use this command only after the implementation cells are read.



---

## EXAMPLES

This example clears the existing list of cells and selects the specified cell list for verification.

```
fm_shell> select_cell_list My*  
Adding cell "Myincand" for verification  
Adding cell "Myand" for verification  
Adding cell "Mynand" for verification  
Adding cell "Myor" for verification  
Adding cell "Mynor" for verification
```

This example removes the specified cell list from the list of cells selected for verification.

```
fm_shell> select_cell_list -remove Mynand  
Removing cell "Mynand" from verification
```

This example adds the specified cell list to the list of cells selected for verification.

```
fm_shell> select_cell_list -add Mynand  
Adding cell "Mynand" for verification
```

---

## SEE ALSO

```
report_cell_list(2)  
debug_library_cell(2)
```

---

## set\_app\_var

Sets the value of an application variable.

---

### SYNTAX

```
string set_app_var  
-default  
var  
value
```

#### Data Types

var	string
value	string

---

### ARGUMENTS

#### -default

Resets the variable to its default value.

#### var

Specifies the application variable to set.

#### value

Specifies the value to which the variable is to be set.

---

### DESCRIPTION

The **set\_app\_var** command sets the specified application variable. This command sets the variable to its default value or to a new value you specify.

This command returns the new value of the variable if setting the variable was successful. If the application variable could not be set, then an error is returned indicating the reason for the failure.

Reasons for failure include:

- The specified variable name is not an application variable, unless the application variable **sh\_allow\_tcl\_with\_set\_app\_var** is set to true See the **sh\_allow\_tcl\_with\_set\_app\_var** man page for details.
- The specified application variable is read only.
- The value specified is not a legal value for this application variable

---

## EXAMPLES

The following example attempts to set a read-only application variable:

```
prompt> set_app_var synopsis_root /tmp  
Error: can't set "synopsys_root": variable is read-only  
Use error_info for more info. (CMD-013)
```

In this example, the application variable name is entered incorrectly, which generates an error message:

```
prompt> set_app_var sh_enabel_page_mode 1  
Error: "sh_enabel_page_mode" is not an application variable  
Use error_info for more info. (CMD-013)
```

This example shows the variable name entered correctly:

```
prompt> set_app_var sh_enable_page_mode 1  
1
```

This example resets the variable to its default value:

```
prompt> set_app_var sh_enable_page_mode -default  
0
```

---

## SEE ALSO

```
get_app_var(2)  
report_app_var(2)  
write_app_var(2)
```

---

## set\_architecture

Sets the architecture for a specific type of multiplier or a DesignWare multiplier instance.

---

### SYNTAX

```
int set_architecture  
  object_ID  
  architecture_type
```

#### Data Types

*object\_ID* string  
*architecture\_type* string

#### Enabled Shell Modes

Setup

---

### ARGUMENTS

#### *object\_ID*

Specifies the object ID of the multiplier.

#### *architecture\_type*

Specifies the type of architecture to use for the multiplier. Select one of the following architecture types - carry-save array, non-Booth Wallace tree, or Booth-encoded Wallace tree for the architecture type argument:

- **csa** - Specifies carry-save array
  - **nbw** - Specifies non-Booth Wallace tree
  - **wall** - Specifies Booth-encoded Wallace tree
- 

### DESCRIPTION

This command sets the architecture for a specific type of multiplier when the multiplier architecture generation is enabled by setting the **enable\_multiplier\_generation** variable to *true*. The architectures correspond to the **csa**, **nbw** and **wall** multiplier architectures. The architecture types are carry-save array, non-Booth Wallace tree, and Booth-encoded Wallace tree, respectively.

---

### EXAMPLES

The following command sets the carry-save array architecture for the multiplier identified by **r:WORK/test/mult28**

```
fm_shell> set_architecture r:/WORK/test4/mul_28 csa
```

---

## SEE ALSO

- `report_architecture(2)`
- `architecture_selection_precedence(3)`
- `dw_foundation_threshold(3)`
- `enable_multiplier_generation(3)`
- `hdlin_multiplier_architecture(3)`

---

## set\_black\_box

Marks the specified designs as black boxes.

---

### SYNTAX

```
status set_black_box
  [-attribute attribute_string]
  [designId_list]
```

#### Data Types

*attribute\_string* string  
*designId\_list* string

#### Enabled Shell Modes

Setup

---

### ARGUMENTS

#### -attribute *attribute\_string*

Marks the designs that have the specified attribute as a black box.

#### *designId\_list*

Marks the specific designs or instance cells as a black box.

---

### DESCRIPTION

This command marks specific designs or instance cells as black boxes, which affects the verification of those designs. The black boxes are persistent during the current session.

To generate a black box for a specific design or cell, specify the *designID\_list* option.

---

### EXAMPLES

The following example marks the design *lower* as a black box.

```
fm_shell (setup)> set_black_box ref:/WORK/lower
Set black box on 'ref:/WORK/lower'
1
```

The following example marks the cell *inst1* of top module *top* as a black box.

```
fm_shell (setup)> set_black_box ref:/WORK/top/inst1  
Set black box on 'ref:/WORK/top/inst1'  
1
```

---

## SEE ALSO

```
remove_black_box(2)  
report_black_boxes(2)
```

---

## set\_cell\_type

Sets a cell type value on a technology library cell or a collection of tech-lib cells.

---

### SYNTAX

```
status set_cell_type
  [-value value_string]
  [designId_list]
  [-map { retention_cell_name [list_of_pin_name_pairs] } ]
```

#### Data Types

*value\_string* string  
*designId\_list* string  
*list\_of\_pin\_name\_pairs* list of list pairs

#### Enabled Shell Modes

Setup

---

### ARGUMENTS

#### **-value *value\_string***

Specifies the value of the cell type that needs to be added.

#### ***designId\_list***

Specifies a tech-lib cell on which the value of the cell type needs to be added. It is the string name of exactly one tech-lib cell or a collection of one or more cells.

#### **-map {*retention\_cell\_name* [*list\_of\_pin\_mappings*] }**

Only valid and required for **-value retention\_equivalent**. Specifies the mapping to a retention cell replacement during **load\_upf** for sequential cells. To invert the sense of any pin, the SystemVerilog bit-wise negation operator ~ can be specified before the retention register pin name. Extra pins are allowed on the retention cell such as test but must be mapped to constant **1** or **0**. Save/restore and pg pins will be automatically mapped.

---

### DESCRIPTION

Sets the cell type on a technology library cell. You can specify the string name of exactly one tech-lib cell or a collection of one or more cells. The types that can be added are

lssd: Level-Sensitive Scan Design  
 retention: Retention register  
 retention\_equivalent: Retention register mapping for sequention cells  
 synchronizer: Synchronizer cell  
 multibit: Banked register or Multi-bit register.



---

## EXAMPLES

The following example sets the design *lower* with cell-type value LSSD.

```
fm_shell (setup)> set_cell_type -value lssd ref:/WORK/lower
LSSD is set on r:/WORK/lower
1
```

The following example sets the design *lower* with cell-type value RETENTION.

```
fm_shell (setup)> set_cell_type -value retention ref:/WORK/lower
RETENTION is set on r:/WORK/lower
1
```

The following example sets the synchronizer design *SYNC\_CELL* with cell-type value RETENTION\_EQUIVALENT and specifies the mapping to a complex retention cell.

```
fm_shell (setup)> set_cell_type -value retention_equivalent r:/TCB_SYN/SYNCH_CELL -map {RVSN_RETENTION {{CP CP} {D D} {CD ~CDN} {0 SE} {0 SI} {0
RETENTION_EQUIVALENT is set on r:/TCB_SYN/SYNCH_CELL
1
```

---

## SEE ALSO

```
remove_cell_type(2)
report_cell_type(2)
load_upf(2)
upf_infer_complex_retention_cells(3)
upf_use_library_cells_for_retention(3)
```

---

## set\_checkpoint\_report\_commands

Specifies reporting commands to be executed after a specific checkpoint finishes verification.

---

### SYNTAX

#### set\_checkpoint\_report\_commands

IDs  
Block

#### Data Types

*IDs* a single string or a tcl list of strings  
*Block* string block

#### Enabled Shell Modes

Setup

---

### ARGUMENTS

#### IDs

Identifies one or more target checkpoints for reporting.

#### Block

Specifies reporting commands to execute after checkpoint verification ends.

---

### DESCRIPTION

Use this command to set commands to be executed after a specific checkpoint finishes verification. This allows users to apply commands that are typically used for reporting after a checkpoint verification has finished.

If the same checkpoint is specified more than once, only the last block is saved.

---

### EXAMPLES

Checkpoints can be identified with their guide number, checkpoint number or name. For example, consider that SVF guide #123 is a logic\_opt checkpoint, and is the first logic\_opt and second overall checkpoint in the SVF. The possible IDs for this checkpoint are as follows:

123            (Guide number)  
ckpt2        (Checkpoint number)  
ckpt\_logic\_opt    (Checkpoint name)  
ckpt\_logic\_opt2   (Checkpoint index)

Formality searches for the possible names in the above order. The first possibility that exists is the only one that is executed for this checkpoint.

This example specifies the reports for the ckpt\_pre\_retime argument:

```
fm_shell (setup)> set_checkpoint_report_commands ckpt_pre_retime {  
  report_failing_points  
}  
1
```

This example specifies the reports for the first checkpoint encountered:

```
fm_shell (setup)> set_checkpoint_report_commands ckpt1 {  
  report_unmatched_points  
}  
1
```

---

## SEE ALSO

remove\_checkpoint\_report\_commands(2)  
report\_checkpoint\_report\_commands(2)

---

## set\_checkpoint\_setup\_commands

Specifies the commands to be executed with a specific checkpoint.

---

### SYNTAX

**set\_checkpoint\_setup\_commands**

IDs  
Block

#### Data Types

*IDs* a single string or a tcl list of strings  
*Block* string block

#### Enabled Shell Modes

Setup

---

### ARGUMENTS

#### IDs

Identifies one or more target checkpoints needing setup.

#### Block

Specifies commands to execute before checkpoint verification begins.

---

### DESCRIPTION

Use this command to set commands to be executed before a specific checkpoint begins preverification. The command is intended to be used to apply commands that are typically used to set up for verification (commands prior to and not including the preverify, match, and verify commands).

If the same checkpoint is specified more than once, only the last block is saved.

---

### EXAMPLES

Checkpoints can be identified with their guide number, checkpoint number or name. For example, consider that SVF guide #123 is a logic\_opt checkpoint, and is the first logic\_opt and second overall checkpoint in the SVF. The possible IDs for this checkpoint are as follows:

123            (Guide number)  
ckpt2        (Checkpoint number)  
ckpt\_logic\_opt    (Checkpoint name)  
ckpt\_logic\_opt2   (Checkpoint index)

The Formality tool searches for the possible names in the above order. The first possibility that exists is the only one that is executed for this checkpoint.

This example specifies the setup for the ckpt\_pre\_retime argument:

```
fm_shell (setup)> set_checkpoint_setup_commands ckpt_pre_retime {  
  set_dont_verify $ref/A_reg  
  set_dont_verify $impl/A_reg  
}  
1
```

This example specifies the setup for the first checkpoint encountered:

```
fm_shell (setup)> set_checkpoint_setup_commands ckpt1 {  
  set_verification_alterate_strategy o2  
}  
1
```

---

## SEE ALSO

report\_checkpoint\_setup\_commands(2)  
remove\_checkpoint\_setup\_commands(2)

---

## set\_clock

Sets the specified net as a clock.

---

### SYNTAX

**set\_clock**  
*netID*

#### Data Types

*netID* string

#### Enabled Shell Modes

Setup

---

### ARGUMENTS

*netID*

Sets the specified design net as a clock. If you specify a name consisting of a regular expression that resolves to more than one net, the operation is applied to all the matching nets.

---

### DESCRIPTION

This command sets the specified net as a clock. Use this command to identify clock-gate latches in the fanin of compare points that the tool cannot identify as clocks (primary output ports and black box input pins), when the **verification\_clock\_gate\_hold\_mode** variable is set to *collapse\_all\_cg\_cells*.

---

### EXAMPLES

The following example sets the net **\$impl/SCLK** as a clock.

```
fm_shell (setup)> set_clock $impl/SCLK
Set clock at 'OPT:/WORK/CORE/SCLK'
1
```

---

### SEE ALSO

[remove\\_clock\(2\)](#)

report\_clocks(2)

---

## set\_command\_option\_value

Set a command option default or current value.

---

### SYNTAX

string **set\_command\_option\_value**

-default | -current

-command *command\_name*

-option *option\_name* | -position *positional\_option\_position*

-value *value* | -undefined

---

### ARGUMENTS

#### -default

Set the default option value.

#### -current

Set the current option value.

#### -command *command\_name*

Set the option value for an option of this command.

#### -option *option\_name*

Set the option value for this option of the command.

#### -position *positional\_option\_position*

Set the option value for this positional option of the command.

#### -value *value*

Set the option value to this value.

#### -undefined

Set the option value to the "undefined value".

---

### DESCRIPTION

Sets the current or default value of a command option.



Either `-default` must be specified (to specify setting the default value of the option), or `-current` must be specified (to specify setting the current value of the option). Unlike for `get_command_option_values`, one of `-current` or `-default` must be specified for `set_command_option_value`.

An option of a command must be specified (for value setting) by passing a command name via `-command` and either an option name (for an option of the command) via `-option`, or the position of a positional option via `-position`. The *option\_name* passed via `-option` (for a dash option) must not have its leading dash character omitted. An option name passed via `-option` may be either the name of a dash option or the name of a positional option. A positional option may be specified either via `-option` or via `-position`. Positional option positions of a command are numbered 0, 1, 2, ... (N-1), where N is the number of positional options of the command.

To set the (current or default) value of the option, a string value should be passed via `-value`. Alternatively, you can pass `-undefined` to reset the option to have the "undefined value". (CAVEAT: For some "set value implementations" for numeric options, `-undefined` does not really "undefine" the value - instead the value is set to 0.)

Processing of the `-value` value does not include any CCI option checking of the value (such as checking whether the option value has correct syntax for its type).

The command "throws" a Tcl error for various conditions:

- \* the command does not exist
- \* the command exists but no such option of the command exists
- \* the set operation failed (could be due to a failed conversion for one of the "set value" implementations which does a conversion from string to one of integer, double, etc.)

The `-undefined` option is a mutually exclusive alternative to the `-value` option. `-undefined` has the effect of resetting the option value to the "undefined value".

A possible power user application: power users could put `set_command_option_value` commands in their home directory Tcl startup files for their favorite dialogs/commands to "seed" initial current values for these dialogs. This may lower the need for automatically saving replay scripts (of `set_command_option_value` commands for each command/dialog option/field) on exit from the application.

---

## EXAMPLES

The following example sets the current value for the `-bar` option of the `foo` command to a value of `abc`.

```
prompt> set_command_option_value -current -command foo \  
-option "-bar" -value abc
```

The following example sets the current value for the first positional argument of the `foo` command to a value of `xyz`.

```
prompt> set_command_option_value -current -command foo \  
-position 1 -value xyz
```

---

## SEE ALSO

`get_command_option_values(2)`  
`preview(2)`

---

## set\_compare\_rule

Defines a name matching rule that Formality applies to a design to create compare points.

---

### SYNTAX

```
status set_compare_rule
  [-type type]
  [-from expression]
  [-to string]
  [-file file_name]
  [designID]
```

#### Data Types

```
type string
expression string
string string
file_name string
designID string
```

---

### ARGUMENTS

#### -type *type*

Specifies the design object type. Specify one of the following object types:

- *port*
- *net*
- *cell*

#### -from *expression*

Specifies the pattern to search for when setting the compare points.

#### -to *string*

Specifies the replacement pattern to use after successfully finding the search pattern. Arithmetic expressions can be specified in the replacement pattern delimited by `\{(` and `\)}`.

#### -file *file\_name*

Specifies a file containing one or more name matching rules.

#### *designID*

Specifies the design affected by the name matching rule.

---

## DESCRIPTION

Use this command to define name translation rules. Formality uses these rules when creating compare points. This command is useful when similar design object names in two design use different naming formats. For example, the reference design uses a naming scheme where an underscore character is part of the register name:

```
reg_1
reg_2
reg_3
```

The implementation design uses a naming scheme where the bit numbers follow the bus name:

```
reg[1]
reg[2]
reg[3]
```

Use the **set\_compare\_rule** command to define a name translation rule from one format to another. Formality applies this rule when creating the compare points.

Compare rules are based on a regular expression syntax similar to those supported by the UNIX **sed** command. Arithmetic expressions are supported in the replacement pattern to handle vector name transformations introduced by bit-reversal, bit-renumbering, and partitioning. Operators + - \* / and % are supported in arithmetic expressions. You can use the **test\_compare\_rule** command to ensure that your compare rules behave as required.

To apply several rules at the same time, use the *-file* option and specify a file that contains the rules. The contents of the file must include a single *search\_pattern* and a single *replace\_pattern* per line. Specify the *from* pattern first and then the *to* pattern followed by an optional *type*. Separate the patterns with a space. Formality reads the rules and applies each during the compare point creation process.

Compare rules remain in effect for the particular design until you remove the rule. To remove the rule, use the **remove\_compare\_rules** command.

If you do not specify a design ID, the tool applies the rules to the current design. If you do not specify a container name when specifying the design ID, Formality applies the compare rule to the design in the current container.

You can specify a particular design object type to be affected by specifying the **-type** *type* option. If you do not specify the *type* argument with the *-type* option, the tool applies the rules to all design objects.

---

## EXAMPLES

This example defines a compare rule for the *async.reset.db* design. Primary output ports driven by a bus in this design use a *bus\_reg[bit]* format. However, the design that is being verified uses the *A\_bus\_reg\_bit* format for the same output ports. Before creating compare points, the tool applies the command rules and transforms the *bus\_reg[bit]* name format to the *A\_bus\_reg\_bit* name format.

```
fm_shell> set_compare_rule async.reset.db -from {\.*_reg)\_([0-9]*)} -to {A\_1\_2}
```

This example defines several rules using the file *my\_rules*. This example affects the default design in the current container.

```
fm_shell> set_compare_rule -file my_rules
```

The following example defines a compare rule with arithmetic operators. The rule is expected to transform the following name formats:

```
out0  -> out_1_reg
out1  -> out_2_reg
out2  -> out_3_reg
out3  -> out_4_reg
```

```
fm_shell> set_compare_rule r:/WORK/topxor -from {out\[0-9]+\)} -to {out_\(1+1)\_reg}
```

---

## SEE ALSO

`remove_compare_rules(2)`  
`report_compare_rules(2)`  
`test_compare_rule(2)`

---

## set\_constant

Sets a net, port, cell, or pin to a constant state of 0 or 1.

---

### SYNTAX

```
status set_constant  
[-type type]  
[-undriven_only]  
objectID  
constant_value
```

#### Data Types

```
type string  
objectID string  
constant_value string
```

#### Enabled Shell Modes

Setup

---

### ARGUMENTS

#### -type *type*

Specifies the type of the design object. Use this option if the name of the specified design object is associated with more than one object type in the same design. Specify one of the following object types:

- *pin* - Specify a pin that is not a primitive input pin.
- *port*
- *net*
- *cell* - Specify a cell that is a register.

#### -undriven\_only

Specifies that the constant value will be applied to undriven object only. The object is undriven if no real driver is connected to the object.

#### *objectID*

Specifies the design object. If you specify a name that resolves to more than one object, the name is applied to all of the matching objects. If the name resolves to multiple objects with identical names and you do not specify the object type, only one of these objects are affected in the following precedence: pin, port, net, cell. The exception is, if the design object, you are assigning the constant to, is a port connected to a net of the same name.

#### *constant\_value*

Specifies the logic state:

- 0: A constant whose value is 0

- 1: A constant whose value is 1

---

## DESCRIPTION

This command applies the logic 0 or 1 value to the specified design objects. Applying the constants to a circuit is helpful when problem areas exist in a circuit and you want to isolate the area by disabling an area of logic. For example, when your implementation design has scan logic and you want to exclude it from the verification process, you can assign a constant to the scan-enable input port to disable the scan logic from the verification process. If you assign a constant to a net with a driver, the tool issues a warning message. Use `-undriven_only` option to set constant to specified object, only when no real driver is found.

Use the **report\_constants** command to list the user-specified constants.

---

## EXAMPLES

The following example sets port CC to a logical 1 state.

```
fm_shell (setup)> set_constant ref:/WORK/CORE/CC 1 -type port
Set 'ref:/WORK/CORE/CC' to constant 1
1
```

---

## SEE ALSO

`remove_constant(2)`  
`report_constants(2)`

---

## set\_constraint

Creates an external constraint on a design or hierarchal design.

---

### SYNTAX

```
set_constraint
[-name constraint_name]
[-map mapping_list]
constraint_type
control_point_list
[designID]
```

#### Data Types

```
constraint_name string
mapping_list string
constraint_type string
control_point_list string
designID string
```

---

### ARGUMENTS

#### *constraint\_type*

Specifies the constraint type. Specify one of the following values:

- *0hot* - Specifies a zero-hot constraint. Elements in the *control\_point\_list* are constrained so that all valid vectors have one of the control point elements at a logic 0 state with the remainder of the control points at logic 1.
- *0hot\_init0* - Same as 0hot except that the control point elements are allowed to be in the all-logic 0 state.
- *0hot\_init1* - Same as 0hot except that the control point elements are allowed to be in the all-logic 1 state.
- *1hot* - Specifies a one-hot constraint. Elements in the *control\_point\_list* are constrained so that all valid vectors have one of the control point elements at a logic 1 state with the remainder in the all-logic 0 state.
- *1hot\_init0* - Same as 1hot except that the control point elements are allowed to be in the all-logic 0 state.
- *1hot\_init1* - Same as 1hot except that the control point elements are allowed to be in the all logic 1 state.
- *coupled* - Specifies a coupled constraint. The elements in the *control\_point\_list* are always in the same binary state.
- *mutex* - Specifies a mutually exclusive constraint. The elements in the *control\_point\_list* are always in opposite binary states. The *control\_point\_list* must contain two elements for this type.
- *user\_defined\_type\_name* - Specifies a user-defined constraint that is created by the **create\_constraint\_type** command. Use the name referenced by **create\_constraint\_type**.

#### *control\_point\_list*

Lists control points (primary inputs, registers, nets) in the constrained design or hierarchy to which to apply the constraint. When specifying the *control\_point\_list*, use the following syntax:

```
[ { name [name] }
```

Where the *name* argument names a state holding flip-flop, port, pin or net in the constrained design or hierarchy. If name is not a full path name then it is relative to the given design or the current design if the design is not given. Use { } when the list contains more than one name.

### ***designID***

Specifies the design to which the tool resolves relative control point names.

### **-name *constraint\_name***

Specifies the constraint's name.

### **-map *mapping\_list***

Lists port names in the constraint module and the corresponding flip-flop, port, or net (control point) names in the constrained design. If you don't specify a mapping list, the tool implies mapping in which the names of the constraint module ports are assumed to be the same as the names of the corresponding control points in the constrained design. This option is only used in conjunction with a user-defined constraint type. You only need to specify a map for those constraint module ports that will not match by name. When specifying the mapping list, use the following syntax:

```
[ { [ cm_name=name ] [cm_name=name] [ ] ]
```

Where:

- The *cm\_name* argument specifies the name of an input port of the constraint module specified when the constraint module is created.
- The *name* argument specifies the leaf/simple name of a state-holding flip-flop, port, or net control point. As a shorthand, a control point can be referenced by position in the control point list using the syntax '\$n' where n is the position in the list. For example \$1 refers to the first control point.

Use the outer braces { } when the list contains more than one set of mapped names or the \$n shorthand reference is used.

---

## **DESCRIPTION**

This command applies an external constraint to the listed flip-flops, ports, pins and nets in the specified design or hierarchy.

The *type\_name* argument specifies how the control points are to be constrained. If you don't specify a design, relative names are resolved to the current design. The type name can be either a predefined constraint type or a constraint type that you create using the **create\_constraint\_type** command. The predefined constraint types are:

- *0hot*
- *0hot\_init0*
- *0hot\_init1*
- *1hot*
- *1hot\_init0*
- *1hot\_init1*



- *coupled*
- *mutex*

When a constraint is applied to a design or hierarchy, all subsequent verifications verify equivalence only for conditions (vectors) that are legal according to the constraint. For example, if a 1hot constraint is applied to a set of ports, the tool does not check for equivalence in cases where the ports are not in a valid one-hot state.

If all control points are found in a single design, then all instances of that design within the verification have the same constraint. If the constraints are applied to the reference design, they are also implicitly applied to the comparable design in the implementation design, and vice versa.

Link the constrained container before executing this command. The tool reports an error if you apply a constraint on a flip-flop cell that is currently a black box because it is still unlinked or unsuccessfully linked.

When you execute this command, the tool assigns a unique name to the constraint, either automatically or explicitly using the *-name constraint\_name* option. The **remove\_constraint** and **report\_constraint** commands require the unique constraint name.

Defining a constraint on a design input port is meaningful only for the top-level design because the instantiating design defines the constraints for lower-level designs. A warning occurs during verification if you apply a constraint to an input port of a design that is not the top-level design. In this case, the constraint is disabled for the higher-level verifications. In addition, the tool reports an error if you define a constraint for an output port of a design that is not a black box.

The **set\_constraint** command returns one of the following:

- 0 to indicate failure
- 1 to indicate success

---

## EXAMPLES

The following example assigns a 1hot constraint to a set of registers in a design.

```
fm_shell> set_constraint 1hot {Q_reg[0] Q_reg[1] Q_reg[2]} ref:/WORK/testcase
FM_CONSTRAINT_0
```

The following example assigns a user-defined constraint to a mixed set of registers and ports in the reference design. The ports of the constraint module are explicitly mapped to control points in the constrained design hierarchy.

```
fm_shell> set_reference ref:/WORK/testcase
Reference design set to 'ref:/WORK/testcase'
1
fm_shell> create_constraint_type 2hot type:/WORK/my_2hot
1
fm_shell> set_constraint 2hot {PortData[0] U0/QR_reg[0] PortData[1] U1/QR_reg[0]}
-map {IN1=PortData[0] IN2=$2 IN3=PortData[1] IN4=$4} \
-name MY2HOT ${ref}
MY2HOT
```

---

## SEE ALSO

```
create_constraint_type(2)
remove_constraint(2)
remove_constraint_type(2)
```

```
report_constraint(2)  
report_constraint_type(2)
```

---

## set\_current\_command\_mode

---

### SYNTAX

string **set\_current\_command\_mode**

**-mode** *command\_mode* | **-command** *command*

string *command\_mode*

string *command*

---

### ARGUMENTS

#### **-mode** *command\_mode*

Specifies the name of the new command mode to be made current. **-mode** and **-command** are mutually exclusive; you must specify one, but not both.

#### **-command** *command*

Specifies the name of the command whose associated command mode is to be made current. **-mode** and **-command** are mutually exclusive; you must specify one, but not both.

---

### DESCRIPTION

The **set\_current\_command\_mode** sets the current command mode. If there is a current mode in effect, the current mode is first canceled, causing the associated clean up to be executed. The initialization for the new command mode is then executed as it is made current.

If the name of the given command mode is empty, the current command mode is cancelled and no new command mode is made current.

A current command mode stays in effect until it is displaced by a new command mode or until it is cleared by an empty command mode.

If the command completes successfully, the new current command mode name is returned. On failure, the command returns the previous command mode name which will remain current and prints an error message unless error messages are suppressed.

---

### EXAMPLES

The following example sets the current command mode to a mode called "mode\_1"

```
shell> set_current_command_mode -mode mode_1
```

The following example clears the current command mode without setting a new mode.

```
shell> set_current_command_mode -mode ""
```

The following example sets the current command mode to the mode associated with the command "modal\_command"

```
shell> set_current_command_mode -command modal_command
```

---

## set\_cutpoint

Specifies a hierarchical pin or net as a hard cutpoint.

---

### SYNTAX

```
set_cutpoint  
[-type type]  
[-primary_input]  
objectID
```

#### Data Types

*type* string  
*objectID* string

#### Enabled Shell Modes

Setup

---

### ARGUMENTS

#### -type *type*

Specifies the object type when using the *objectID* argument. Use this option if the name of the specified design object is associated with more than one object type in the same design. Specify one of the following for the type argument:

- *pin*
- *net*

#### -primary\_input

Specifies that the cutpoint is treated like a primary input. Constraints are not propagated through the cutpoint and it is constrained to 0 or 1 for verification.

#### *objectID*

Sets the design object as a cutpoint. If you specify a name that resolves to more than one object, the operation is applied to all matching objects. However, if the name resolves to multiple objects with identical names and you do not specify the object type, either pins or nets with the specified name are set as cutpoints.

---

### DESCRIPTION

This command sets the specified hierarchical pin or net as a hard cutpoint. They are verified independently and are used as a free variable for verification of downstream compare points.

## EXAMPLES

The following example uses the **-type net** option to set net \$impl/PC[1], as a cutpoint.

```
fm_shell (setup)> set_cutpoint -type net $impl/PC[1]
Set cutpoint at 'OPT:/WORK/CORE/PC[1]'
1
```

The following example sets all of the pins on a block as cutpoints using the **-type pin** option.

```
fm_shell (setup)> set_cutpoint -type pin HDL:/WORK/CORE/MUX_OUT_BLK/*
Set cutpoint at 'HDL:/WORK/CORE/MUX_OUT_BLK/DATA[10]'
Set cutpoint at 'HDL:/WORK/CORE/MUX_OUT_BLK/DATA[11]'
Set cutpoint at 'HDL:/WORK/CORE/MUX_OUT_BLK/DATA[12]'
Set cutpoint at 'HDL:/WORK/CORE/MUX_OUT_BLK/STK_DATA[1]'
Set cutpoint at 'HDL:/WORK/CORE/MUX_OUT_BLK/STK_DATA[2]'
Set cutpoint at 'HDL:/WORK/CORE/MUX_OUT_BLK/STK_DATA[3]'
Set cutpoint at 'HDL:/WORK/CORE/MUX_OUT_BLK/STK_DATA[4]'
Set cutpoint at 'HDL:/WORK/CORE/MUX_OUT_BLK/UPC_DATA[1]'
Set cutpoint at 'HDL:/WORK/CORE/MUX_OUT_BLK/UPC_DATA[2]'
Set cutpoint at 'HDL:/WORK/CORE/MUX_OUT_BLK/UPC_DATA[3]'
Set cutpoint at 'HDL:/WORK/CORE/MUX_OUT_BLK/UPC_DATA[4]'
Set cutpoint at 'HDL:/WORK/CORE/MUX_OUT_BLK/UPC_DATA[5]'
1
```

---

## SEE ALSO

```
remove_cutpoint(2)
report_cutpoints(2)
set_dont_cut(2)
create_cutpoint_blackbox(2)
```

---

## set\_direction

Sets the direction of ports and pins.

---

### SYNTAX

```
status set_direction
  [-type object_type]
  [-shared_lib]
  objectID
  new_direction
```

#### Data Types

```
object_type string
objectID string
new_direction string
```

#### Enabled Shell Modes

Setup

---

### ARGUMENTS

#### **-type *object\_type***

Specifies the type for the *object\_type* argument. Use this option if the name of the specified design object is associated with more than one type of design object in the same design. If you specify a design object that has the same name as other design objects of different types, use the *-type* option to differentiate it from the other objects.

Specify one of the following values for the *object\_type* argument:

- *port* to specify a port type
- *pin* to specify a pin type

#### **-shared\_lib**

Redirects objects from technology libraries.

#### ***objectID***

Specifies a design object. You can specify any unlinked port or pin.

#### ***new\_direction***

Specifies the port or pin direction. Specify one of the following directions:

- *in*
- *out*
- *inout*

---

## DESCRIPTION

This command sets the direction on a specified unlinked port or pin.

Defining the direction of a pin or port helps determine equivalence more accurately during verification. For example, designs that use black boxes to hold the most recent value from a bus (bus-holder or bus-keeper) might not compare to designs that do not use comparable black boxes. For example, if the pin connecting the bus-holder to the bus is bidirectional, the bus might have an external driver.

---

## EXAMPLES

In the following example, the direction of the pin connecting the black box to the bus is bidirectional. The following command redefines the pin's direction as input only. In this case, redefining the direction eliminates an extraneous driver from the bus.

```
fm_shell (setup)> set_direction impl:/WORK/CORE/CC in  
Set 'ref:/WORK/CORE/CC' to direction in  
1
```

---

## SEE ALSO



---

## set\_dont\_cut

Specifies an object that should not be used as a cutpoint.

---

### SYNTAX

```
set_dont_cut  
  objectID  
  [-type objectID_type]
```

#### Data Types

```
objectID string  
objectID_type string
```

#### Enabled Shell Modes

Setup

---

### ARGUMENTS

#### -type *objectID\_type*

Specifies the type of the specified object. Use this option if the name of the specified design object is associated with more than one object type in the same design. Specify one of the following object types:

- *pin*
- *net*

#### *objectID*

Specifies the design object that is not to be used as a cutpoint. If you specify a name consisting of a regular expression that resolves to more than one object, the operation is applied to all the matching objects. If the name specified resolves to multiple objects with identical names, and you do not specify the object type, only one of these objects will be affected. The precedence in this case is pin, net. Wildcards may be used to specify objects.

---

### DESCRIPTION

This command specifies a hierarchical pin or net that should not be a cutpoint. The specified object is not verified independently and is not used as a free variable for the verification of compare points.

The Formality tool does not insert automatic cutpoints at user-specified dont\_cut points. The **set\_dont\_cut** command overrides the **set\_cutpoint** command. Use this command if automatically inserted cutpoints (type PDCut) appear to be causing failing points.

## EXAMPLES

The following example shows how to use the **set\_dont\_cut** command.

```
fm_shell (setup)> set_dont_cut $ref/block/pin  
Set dont_cut at 'r:/WORK/top/block/pin'  
1
```

---

## SEE ALSO

```
remove_dont_cut(2)  
report_dont_cuts(2)  
set_cutpoint(2)  
verification_insert_upf_isolation_cutpoints(3)
```

---

## set\_dont\_match\_points

Specifies a list of compare points to exclude from match.

---

### SYNTAX

```
status set_dont_match_points  
[-type type]  
objectID_list
```

#### Data Types

```
type string  
objectID_list string
```

---

### ARGUMENTS

#### -type *type*

Specifies the object type. Use this option if the name of the specified design object is associated with more than one object type in the design. Specify one of the following values for the *type* argument:

- *pin*
- *port*
- *net*
- *cell*

#### *objectIDlist*

Specifies a list of objects to exclude from matching. The *dont\_match* attribute is set on the specified objects. If the specified regular expression resolves to more than one object, the attribute is applied to all the objects. However, if the name resolves to multiple objects with identical names and you do not specify the object type, only one of these objects is affected in the following precedence: pin, port, net, cell.

---

### DESCRIPTION

This command applies the *dont\_match* attribute on the specified objects. All objects with the *dont\_match* attribute are excluded from matching.

The specified objects are excluded from matching during the subsequent *match* or *verify* command. To report the objects that have the *dont\_match* attribute, use the **report\_dont\_match\_points** command.

---

## EXAMPLES

The following example shows how to prevent matching an object in the current design.

```
fm_shell (setup)> set_dont_match_points buffer_test
```

The following example shows how to prevent matching the specified test ports in the reference design named top.

```
fm_shell (setup)> set_dont_match_points {r:/WORK/top/test_so1 r:/WORK/top/test_so2  
r:/WORK/top/test_so3}
```

The following example shows how to use a wildcard character to prevent matching of test input ports on a black box.

```
fm_shell (setup)> set_dont_match_points {r:/WORK/top/ram32x20m/test_si*}
```

---

## SEE ALSO

```
remove_dont_match_points(2)  
report_dont_match_points(2)  
report_matched_points(2)  
report_unmatched_points(2)
```

---

## set\_dont\_reverse

Specifies a clock gating latch cell that should not be reversed by reverse clock gating.

---

### SYNTAX

**set\_dont\_reverse**  
*objectID*

#### Data Types

*objectID* string

#### Enabled Shell Modes

Setup

---

### ARGUMENTS

*objectID*

Specifies the design cell that is not to be reversed by reverse clock gating. If you specify a name consisting of a regular expression that resolves to more than one cell, the operation is applied to all the matching cells. Wildcards may be used to specify cells.

---

### DESCRIPTION

This command specifies a cell that should not be reversed by reverse clock gating. This may be applied either to the SEQ latch primitive, or to the tech cell. When reverse clock gating is enabled, this latch will be treated as a LAT instead of a LATCG, and will not be reversed. This should be applied to both the reference and implementation cells, which must be matched for a successful verification.

---

### EXAMPLES

The following example shows how to use the **set\_dont\_reverse** command.

```
fm_shell (setup)> set_dont_reverse $ref/block/icg1
Set dont_reverse at 'r:/WORK/top/block/icg1'
1
```

**SEE ALSO**

`remove_dont_reverse(2)`  
`report_dont_reverse(2)`  
`verification_clock_gate_reverse_gating(3)`

---

## set\_dont\_verify\_points

Prevents design equivalence verification between two objects that constitute a matched compare point.

---

### SYNTAX

```
status set_dont_verify_points  
  [-type type]  
  -directly_undriven_output  
  [-propagate]  
  objectID_list
```

#### Data Types

```
type string  
objectID_list string
```

---

### ARGUMENTS

#### -type *type*

Specifies the object type argument for the option. Use this option if the name of the specified design object is associated with more than one object type in the design. Specify one of the following values for the *type* argument:

- *pin*
- *port*
- *net*
- *cell*

The only compare points of type *pin* are those at black box input pins. Therefore, when you specify type *pin*, the tool disables the specified compare points at black box input pins.

#### -directly\_undriven\_output

Sets the *dont\_verify* attribute on the top-level reference design output ports that do not have connected nets and on the connected nets that have no driving pins.

#### -propagate

Sets the *dont\_verify* attribute on upstream compare points that are not read by other compare points. Use this option on primary output ports that are driven by test inserted lockup latches and cause failures on the ports.

#### *objectIDlist*

Sets the *dont\_verify* attribute on design objects that are associated with the specified compare point. If the specified regular expression resolves to more than one object, the operation is applied to all of the matching objects. However, if the name resolves to multiple objects with identical names and you do not specify the object type, only one of these objects is affected in the following precedence: *pin*, *port*, *net*, *cell*. Use this option to disable an unmatched compare point.

---

## DESCRIPTION

This command applies the `dont_verify` attribute on the specified compare points. Compare points with the `dont_verify` attribute are excluded from verification.

The `dont_verify` points are not applied to the designs until you run the `match` or `verify` command. To report the compare points that have the `dont_verify` attribute, use the **report\_matched\_points** *-point\_type* and the **report\_unmatched\_points** *-point\_type dont\_verify* commands.

---

## EXAMPLES

The following example disables verification of an unmatched compare point in the current design.

```
fm_shell (setup)> set_dont_verify_points buffer_test
```

The following example disables the test ports in the reference design named top.

```
fm_shell (setup)> set_dont_verify_points {r:/WORK/top/test_so1  
r:/WORK/top/test_so2 r:/WORK/top/test_so3}
```

The following example uses a wildcard character to disable all of the test input ports on a black box cell because scan reordering has occurred in the implementation and the function at those inputs is known to be different from the reference.

```
fm_shell (setup)> set_dont_verify_points {r:/WORK/top/ram32x20m/test_si*}
```

---

## SEE ALSO

```
remove_dont_verify_points(2)  
report_aborted_points(2)  
report_dont_verify_points(2)  
report_failing_points(2)  
report_matched_points(2)  
report_passing_points(2)  
report_unmatched_points(2)
```



---

## set\_dp\_int\_round

Specifies the initial rounding information for multipliers.

---

### SYNTAX

```
set_dp_int_round  
  objectID  
  ExtPos [ IntPos ]
```

#### Data Types

```
objectID string  
ExtPos int  
intPos int
```

---

### ENABLED SHELL MODES

Setup

---

### ARGUMENTS

#### *objectID*

Specifies the design multiplier to be rounded.

#### *ExtPos IntPos*

Specifies the external and internal rounding positions.

---

### DESCRIPTION

Use this command to specify the internal and external rounding modifications applied to a multiplier.

---

### EXAMPLES

```
fm_shell (guide)> set_dp_int_round { mult_12* mult_34* } 12 4  
1
```

---

## SEE ALSO

`guide_set_rounding(2)`  
`remove_dp_int_round(2)`  
`report_dp_int_round(2)`

---

## set\_dpx\_options

Sets configuration options for Formality distributed processing (DPX) using the Synopsys Common Distributed Processing Library (CDPL) framework for parallel computing.

---

### SYNTAX

```
status set_dpx_options
[-hosts host_file]
[-protocol RSH | SH | SSH | SGE | UGE | LSF | PBS | RTDA | NB | SLURM | AWSBATCH | CUSTOM ]
[-submit_command submit_command]
[-max_workers worker_count]
[-max_cores cores_per_worker]
[-max_memory mem_in_GB]
[-work_dir working_directory]
```

---

### DATA TYPES

```
host_file string
submit_command string
worker_count string
cores_per_worker string
mem_in_GB number
working_directory string
```

---

### ARGUMENTS

#### **-hosts host\_file**

Specifies an optional configuration file for setting up the distributed verification environment. This file uses the CDPL host information file format.

#### **-protocol RSH | SH | SSH | SGE | UGE | LSF | PBS | RTDA | NB | SLURM | AWSBATCH | CUSTOM**

Defines the protocol for launching worker processes on remote or local machines. The protocol corresponds to the type of compute farm manager you are submitting to or, when not using a compute farm manager, to the method used to access the compute hosts.

Valid values include the following:

```
RSH [Remote Shell]
SSH [Secure Shell]
SH [shell process on the local host]
SGE/UGE [Originally Sun Grid Engine, lately Univa Grid Engine]
LSF [Load Sharing Facility, from Platform Computing]
PBS [Portable Batch System]
RTDA [Runtime Design Automation NetworkComputer]
NB [Intel Netbatch Compute Farm]
SLURM [Simple Linux Utility for Resource Management]
AWSBATCH [Amazon's AWS Batch Farm]
CUSTOM [Customer farm type unknown to CDPL]
```

#### **-submit\_command submit\_command**

Defines the command used to submit jobs to the compute hosts. For compute farm managers, this command is specific to the local network setup and typically includes required resource requests. The submit command for the RSH, SSH and SH protocols are "rsh", "ssh" and "sh", respectively. If the submit command includes embedded spaces or command options, then the entire command should be a quoted string.

**-max\_workers worker\_count**

Specifies the maximum number of workers requested for processing distributed tasks. The default is 8 workers.

**-max\_cores cores\_per\_worker**

Specifies the maximum number of compute cores per worker assumed to be available for processing distributed tasks. The default is 1 core per worker.

**-max\_memory mem\_in\_GB**

Specifies the maximum amount of RAM in GB for each worker machine. This is the combined amount of RAM for all tasks processed in parallel by the worker. Shared memory is only counted once.

If the memory limit is hit, the DPX worker will attempt to stop tasks to bring the memory consumption down below the limit.

A negative value indicates no maximum memory limit. This is the default behavior.

**-work\_dir working\_directory**

Specifies the working directory to be used for the files generated and used by distributed processing. If not specified, the DPX working directory FM\_DPX\_WORK[n] is created in current shell working directory. Otherwise it is created under the specified directory.

---

## LICENSE

This command becomes available when you use the Formality-DPX license key.

---

## DESCRIPTION

The `set_dpx_options` command is used to configure Formality DPX distributed processing. The distributed processing features in Formality are based on the Common Distributed Processing Library (CDPL) framework used by many Synopsys applications. The configurations options available within Formality are similar to the other CDPL-based applications.

When this command is successfully executed, the Formality tool is configured to run some stages of the session using distributed processing. With distributed processing the verification problem is divided into discrete tasks that run on workers.

A worker is a separate process that communicates with the manager process, receiving instructions on what tasks to perform and providing the results of those tasks back to the manager. Workers might be running on the local machine with the manager, or on another machine in the network or a compute farm, depending on how the distributed environment is configured. Each worker can optionally run multiple tasks in parallel. The number of parallel tasks allowed for each worker is configured using the `-max_cores` option. The number of workers is specified using the `-max_workers` option. The total number of tasks that can be run in parallel is (`worker_count X cores_per_worker`).

The `-protocol` and `-submit_command` options together define where and how workers are created. The protocol specifies whether workers are created on compute farms, such as LSF or SGE, or on local machines without going through a farm manager. The `submit_command` is the command string used to start up processes on the target environment. The command string is highly specific to your environment when using a compute farm protocol. Consult with your local farm manager administrators for information on how to submit to your farm.

The `-hosts` option provides an alternative configuration file-based mechanism for configuring the distributed verification environment. This option cannot be used together with the `-protocol` or `-submit_command` options. There are multiple places in the verification flow

that can be distributed, including SVF checkpoint preverification, the verify command, and so on. By default, workers are not requested and started up until they are needed for the verification step and, once that step is completed, the workers are released. In some farm environments, it can take a considerable amount of time from the point where workers are requested to the time that they are provided, which can create dead zones in the verification process while the Formality tool waits for workers. To prevent workers from being released at the end of a verification step (such as at the end of SVF preverification), set the `dpx_keep_workers_alive` command to true. This keeps the workers until they are explicitly released using the `stop_dpx_workers` command, or the session ends. To ensure that workers are available when they are initially needed, use the `start_dpx_workers` command to request workers before verification begins.

Note: Your farm environment can have rules for whether this is allowed, since the workers might be idle for some time before they are required. DPX licenses are not reserved until tasks are deployed onto the workers. With compute farm environments, it is very common that not all workers are made available at the same time. It is not unusual that the farm provides only a subset of the requested workers, and those workers trickle in over time. Once a worker is acquired and ready for use, Formality DPX distributes `max_cores` parallel tasks to the worker.

Each worker has a full copy of the designs that are loaded into the manager process. When requesting farm resources, it is best to assume that each worker requires the same amount of memory that is needed to perform the same non-DPX verification. If you expect a 4-core serial Formality run to use 100GB, then expect to use 100GB for each DPX worker when performing that same run. `max_cores` set to 4. If you set `max_cores` to be higher, then expect more memory to be required, consistent with what you expect when not running DPX.

---

## EXAMPLES

The following example sets 4 workers and 4 cores per worker on the SGE grid, allocating 100G:

```
fm_shell > set_dpx_options -protocol SGE -submit_command "qsub -P bnormal -l mem_free=100G" -max_workers 4 -max_cores 4
```

The following example sets 1 worker and 32 cores per worker on the local machine:

```
fm_shell > set_dpx_options -protocol SH -submit_command sh -max_workers 1 -max_cores 32
```

---

## SEE ALSO

```
remove_dpx_options(2)
report_dpx_options(2)
start_dpx_workers(2)
stop_dpx_workers(2)
get_dpx_workers(2)
dpx_enable_checkpoint_verification(3)
dpx_keep_workers_alive(3)
dpx_verification_strategies(3)
dpx_worker_acquisition_timeout(3)
```

---

## set\_eco\_data

Sets the ECO database file.

---

### SYNTAX

status **set\_eco\_data** <file>

---

### LICENSE

This command is available when the "Formality-LogicECO" license key is used.

---

### DESCRIPTION

This command sets the ECO database file specified in the llib(FRD) file format. The command reads the file and extracts all the ECO information into the new directory named 'fm\_eco\_frd' inside the \$fm\_work\_path. In case 'fm\_eco\_frd' already exist, overwrites the directory. All the ECO nodes from the file are extracted and same named sub-directories are created inside 'fm\_eco\_frd'. Each extracted ECO node will have the following files,

- fm\_<eco\_name>\_region.group.tcl
- fm\_<eco\_name>\_region.data.tcl
- fm\_<eco\_name>\_region.svf
- fm\_<eco\_name>\_region.patch.tcl (ascii)
- fm\_<eco\_name>\_region.confirm\_setup.tcl (ascii)
- fm\_<eco\_name>\_region.netlist\_flow\_setup.tcl (ascii)

This command must be set before set\_svf command, otherwise its an error.

---

### SEE ALSO

report\_eco\_data  
match\_eco\_regions  
write\_eco\_regions  
create\_eco\_patch

---

## set\_eco\_implementation

Specifies the ECO implementation container or design ID.

---

### SYNTAX

status **set\_eco\_implementation**

#### Enabled Shell Modes

Setup  
Match  
Verify

---

### LICENSE

This command is available when the "Formality-LogicECO" license key is used.

---

### DESCRIPTION

This command specifies the ECO implementation container or design ID. If a container name is given, the top design in that container will be used.

---

### SEE ALSO

match\_eco\_regions  
write\_eco\_regions  
create\_eco\_patch  
set\_orig\_reference  
set\_orig\_implementation  
set\_eco\_reference

---

## set\_eco\_reference

Specifies the ECO reference container or design ID.

---

### SYNTAX

status **set\_eco\_reference**

#### Enabled Shell Modes

Setup  
Match  
Verify

---

### LICENSE

This command is available when the "Formality-LogicECO" license key is used.

---

### DESCRIPTION

This command specifies the ECO reference container or design ID. If a container name is given, the top design in that container will be used.

---

### SEE ALSO

match\_eco\_regions  
write\_eco\_regions  
create\_eco\_patch  
set\_orig\_reference  
set\_orig\_implementation  
set\_eco\_implementation



---

## set\_factor\_point

Specifies that the given object is a factoring variable.

---

### SYNTAX

**set\_factor\_point**  
[-type *type*]  
*objectID\_list*

#### Data Types

*type* string  
*objectID\_list* string

#### Enabled Shell Modes

Setup  
Match  
Verify

---

### ARGUMENTS

#### -type *type*

Specifies the type of the object. Use this option if the name of the specified design object is associated with more than one object type in the same design. Specify one of the following for the type argument:

- *port*
- *pin*
- *net*
- *cell*

#### *objectID\_list*

Specifies a list of design objects to be designated as factoring variables. If you specify a name consisting that resolves to more than one object, the operation is applied to all the matching objects. However, if the name resolves to multiple objects with identical names and you do not specify the object type, only one of these objects is affected in the following precedence: pin, port, net, cell.

---

### DESCRIPTION

This command specifies that the list of given objects are factoring variables. Each object must be a primary input port, black box output pin, register cell or previously set cutpoint, and should be matched and binary constrained. Use wildcard characters to specify groups of objects.

User-specified factoring variables are not used until the *match* or *verify* commands. Any factoring variable that is not matched and

binary constrained at the beginning of the subsequent verification is ignored. The tool performs factored verification using any remaining valid factoring variables. If no valid factoring variables are specified, then the tool performs unfactored verification as usual.

---

## EXAMPLES

The following example sets the factors point on a design object state1\_reg.

```
fm_shell (setup)> set_factor_point $ref/M1/U1/state1_reg  
Set factoring variable at 'r:/WORK/top/M1/U1/state1_reg'  
1
```

---

## SEE ALSO

`remove_factor_point(2)`  
`report_factor_points(2)`

---

## set\_feedthrough\_points

Specifies the feedthrough ports of a particular design.

---

### SYNTAX

```
set_feedthrough_points  
-design designID  
[-input port_name]  
[-tie_low]  
[-tie_high]  
[-output port_name]  
[-equiv port_name port_name]  
[-invert]
```

#### Data Types

*designID* string  
*port\_name* string

#### Enabled Shell Modes

Setup

---

### ARGUMENTS

#### -design *designID*

Specifies the design on which the feedthrough point is specified.

#### -input *port\_name*

Specifies the input port (if any) for the feedthrough point.

#### -tie\_low

Specifies whether the feedthrough point is a tie low (constant 0).

#### -tie\_high

Specifies whether the feedthrough point is a tie high (constant 1).

#### -output *port\_name*

Specifies the output feedthrough point. The options -input/-tie\_low/-tie\_high must be used with the -output option.

#### -equiv *port\_name port\_name*

Specifies names of feedthrough points that are equivalent to each other. The ports must have the same direction. Only one of -equiv or -output may be specified.

#### -invert

Specifies whether the feedthrough points have an inverted relationship. -invert may not be used with -tie\_low or -tie\_high.

---

## DESCRIPTION

This command allows the user to specify feedthrough relationships between ports of designs. During verification, `set_feedthrough_points` on top level designs are verified independently on both the reference and implementation designs. When the feedthrough points are specified on the ports of a `black_box` design which is not the current design being verified, the feedthrough points will be used as a constraint on that black box.

Use this command to allow accurate verification of a design that has feedthroughs without having to load the entire design hierarchy. It is up to the user to ensure the `set_feedthrough_points` on black box designs are accurate by running the block level verification of the sub-design (which is black boxed at the parent level verification) with the same `set_feedthrough_points` specifications.

Feedthrough verification results are available in the verification results summary and can also be reported with command *`report_feedthrough_status`*

---

## EXAMPLES

Feedthrough command where output port `o` is directly driven by input port `i` of design `D`. The feedthrough is verified when design `D` is verified. If design `D` is blackboxed, the feedthrough is added as a constraint around that black box.

```
fm_shell (setup)> set_feedthrough_point -design D -input i -output o
```

Feedthrough command where input port `p1` and `p2` in design `A` are equivalent. The feedthrough gets verified when the top-level verification occurs. If the design `A` is black-boxed, the feedthrough is added as a constraint around that black-box.

```
fm_shell (setup)> set_feedthrough_point -design A -equiv { p1 p2 }
```

---

## SEE ALSO

`report_feedthrough_points(2)`  
`report_feedthrough_status(2)`

---

## set\_fsm\_encoding

Specifies the bit encodings for states in the specified design.

---

### SYNTAX

```
status set_fsm_encoding
  [-name fsm_name]
  encoding_list
  [designID]
```

#### Data Types

```
fsm_name string
encoding_list string
designID string
```

#### Enabled Shell Modes

Setup

---

### ARGUMENTS

#### -name *fsm\_name*

Specifies the name of the FSM to which the tool applies the encoding. If a design has multiple FSMs, specify a FSM using the -name *fsm\_name* option.

#### *encoding\_list*

Specifies a list of all states in the FSM paired with assigned bit encodings. The syntax to specify the encoding list is:

```
[[name=[number_base]code [name=[number_base]code] {}]
```

Use braces around the entire list when the list has more than one name-state pairs, or when you include spaces within a pair. If you include spaces as part of a name-state pair, enclose the pair in double quotation marks for an established FSM state vector flip-flop name or an optional number base. You can use two forms to specify the number base:

- 2# | 8# | 16# - Specifies binary, octal, or hexadecimal number bases, respectively. The decimal base is not supported.
- ^B | ^O | ^H - Specifies binary, octal, or hexadecimal number bases, respectively. The decimal base is not supported. This is the encoding associated with the FSM state vector flip-flop. Specify a string of digits in the base you specify.

#### *designID*

Specifies the design to which the tool applies the encoding.

---

### DESCRIPTION

This command defines encodings for established FSM state vector flip-flops. Use this command to define encodings when you have just a few states to define. For FSMs with many states, use the **read\_fsm\_states** command.

You cannot use this command until you have established the FSM state vector flip-flop names. You can establish these names using the **set\_fsm\_state\_vector** command.

If a design has only one FSM, you can define encodings in a specific design by specifying a design. Alternatively, you can let the tool assign encodings to the current design by not specifying the design.

If the tool cannot find the design, it returns the following error message,

Design ID *name* is invalid

---

## EXAMPLES

The following example declares four states for two previously named flip-flops. In this example, the encodings are applied to the current design. Encodings are specified in the binary numbering system.

```
fm_shell (setup)> set_fsm_encoding { S0=2#00 S1=2#01 S2=2#10 S3=2#11 }  
1
```

The following example accomplishes the same result as the previous example. However, states are supplied in the hexadecimal numbering system.

```
fm_shell (setup)> set_fsm_encoding { S0=16#0 S1=16#1 S2=16#2 S3=16#3 }  
1
```

The following example defines encodings for a FSM design named *ref:/WORK/CORE/FSM*. This example specifies the state using the octal numbering system. All state encodings are enclosed in double quotation marks. In this example, spaces around the equal sign are not allowed.

```
fm_shell (setup)> set_fsm_encoding "STATE_1=8#1 STATE_2=8#2"  
1
```

---

## SEE ALSO

read\_fsm\_states(2)  
report\_fsm(2)  
set\_fsm\_state\_vector(2)

---

## set\_fsm\_state\_vector

Names state vector flip-flops in an FSM.

---

### SYNTAX

```
string set_fsm_state_vector  
  flip-flop_list  
  [ designID ]  
  [ -name FSM_name ]  
  [ -match matching_fsm_name ]
```

#### Data Types

*flip-flop\_list* string  
*designID* string  
*FSM\_name* string  
*matching\_fsm\_name* string

#### Enabled Shell Modes

Setup

---

### ARGUMENTS

#### *flip-flop\_list*

Specified the ordered list of flip-flops in the FSM used to store the state vector. Use the following syntax to specify the flip-flop list:

```
[ { } name [ name... ] { } ]
```

Use the [ ] when the list has more than one flip-flop. The *name* argument specifies the instance name of a state-holding flip-flop in the FSM.

#### *designID*

The design to which Formality applies the names.

#### **-name** *FSM\_name*

Specifies the name of the FSM to which the state vector belongs.

#### **-match** *matching\_fsm\_name*

Specifies the FSM name mapping between the reference and implementation designs. This option is only needed when there are more than 1 re-encoded FSMs within the same level of hierarchy.

## DESCRIPTION

This command names and establishes the order of each flip-flop used to store a state vector in an FSM. The number of flip-flops in the list also determines the length of the state encodings used to represent each state.

The list of state vector names you supply should map directly to the encodings for all states. The first element in the instance list stores the left-most bit (most significant bit) of each state encoding; the second element in the list stores the next bit of each state encoding; and so on. It is an error to have the same flip-flop in two FSMs.

For example, to encode four states using two bits with flip-flops named ff1 and ff0, specify the following command:

```
fm_shell (setup)> set_fsm_state_vector { ff0 ff1 }
```

In this case, the set of all state encodings in binary is:

```
00
01
10
11
```

Instance ff0 stores the left column for the state encodings, and ff1 stores the right column. After you name the flip-flops, you can define their encodings by using the **set\_fsm\_encoding** command.

You can name and order flip-flops in a specific FSM by supplying a *designID*. You can also let Formality apply the list to the current design by omitting a *designID*.

If Formality cannot find a listed flip-flop in the design, it returns the following error message, where *name* is the flip-flop name you specified and *container* is the container:

```
Error: A cell named name could not be found in container container.
```

When you execute this command, Formality assigns a unique name to the FSM, either automatically or explicitly using the **-name** *FSM\_name* option. This name is reported by **report\_fsm**.

If there are multiple re-encoded FSMs within a single level of hierarchy, you need to use the **-match** option to map the reference and implementation FSM names to each other. First, use the **set\_fsm\_state\_vector -name** command to specify the FSM names for the multiple FSMs that reside within the same level of hierarchy in the reference design. Then, when specifying the state vectors for the matching FSMs in the implementation design, use the **-match** option to map each FSM to the appropriate FSM name in the reference design.

## EXAMPLES

The following example names and orders three flip-flops in the current design. Because of the ordered nature of the list, subsequent encodings are applied such that FF\_0 stores the first (left-most) bit, FF\_1 stores the middle bit, and FF\_2 stores the last (right-most) bit.

```
fm_shell (setup)> set_fsm_state_vector { FF_0 FF_1 FF_2 }
1
```

The following example names and orders the same list in an FSM design named *ref:/WORK/CORE/FSM\_BEHAVIOR*. Since no *FSM\_name* is provided, Formality creates a unique name for this FSM and returns the name.

```
fm_shell (setup)> set_fsm_state_vector { FF_0 FF_1 FF_2 } ref:/WORK/CORE/FSM_BEHAVIOR
FM_FSM_0
```

In the following example, the *FSM\_name* is provided.

```
fm_shell (setup)> set_fsm_state_vector { FF_0 FF_1 FF_2 } ref:/WORK/CORE/FSM_BEHAVIOR -name my_fsm
my_fsm
```



---

## SEE ALSO

`read_fsm_states(2)`  
`report_fsm(2)`  
`set_fsm_encoding(2)`

---

## set\_host\_options

Sets resource options.

---

### SYNTAX

```
status set_host_options
[ -max_cores num_cores ]
[ -max_memory mem_in_GB ]
[ -local_process ]
```

#### Data Types

*num\_cores* string

*mem\_in\_GB* number

---

### ARGUMENTS

#### **-max\_cores** *num\_cores*

Specifies the number of processes on the local machine to use in parallel. The default is one core. The maximum number of cores you can specify is eight. A second Formality license is consumed if you specify more than four cores. The second licensed is not released until Formality exits.

#### **-max\_memory** *mem\_in\_GB*

Specifies the amount of physical memory (RAM) in GB that Formality may use.

For a multi-core run, the limit is the sum of all the physical memory used by all the processes. Shared memory is only counted once.

The Formality tool will periodically check the amount of memory it is using against this limit. If the limit is reached, the tool will stop the current command and return to the prompt.

Setting a negative limit disables the memory use checks. This is the default behavior.

#### **-local\_process**

Specifies that **-max\_cores** applies to the local process. This is always true for now and may always be omitted.

---

### DESCRIPTION

This command sets options for parallel processing.

---

## EXAMPLES

This example specifies that up to 4 processes may be used on the local machine in parallel.

```
fm_shell> set_host_options -max_cores 4
```

---

## SEE ALSO

---

## set\_implementation\_design

Sets the implementation design.

---

### SYNTAX

status **set\_implementation\_design**  
[*designID*]

#### Data Types

*designID* string

---

### ARGUMENTS

*designID*

Specifies the design you want to establish as the top-level implementation design.

---

### DESCRIPTION

This command establishes the implementation design. To establish a specific design as the implementation design, you must specify the *designID* argument. When you don't specify the *designID* argument, Formality sets the current design as the implementation design.

When you establish an implementation, it remains active until you issue a subsequent **set\_implementation\_design** command.

---

### EXAMPLES

The following example establishes the design CORE in the impl container as the top-level implementation design.

```
fm_shell> set_implementation_design impl:/WORK/CORE  
Implementation design set to 'impl:/WORK/CORE'  
1
```

---

### SEE ALSO

set\_reference\_design(2)

---

## set\_init\_toggle\_assumption

Sets an initial toggle assumption on a controlling object(s).

---

### SYNTAX

```
set_init_toggle_assumption  
[-toggle | -no_toggle]  
[-type]  
[object_list]
```

#### Data Types

*object\_list* string

#### Enabled Shell Modes

Setup

---

### ARGUMENTS

#### -toggle

Specifies that the object(s) should toggle during initialization.

#### -no\_toggle

Specifies that the object(s) should not toggle during initialization.

#### -type

Optional switch to specify the type of the object(s). The types are port, net or cell.

#### *object\_list*

Specifies the object(s) whose initial toggle assumptions need to be set.

---

### DESCRIPTION

Sets an initial toggle assumption on a controlling object(s).

---

### EXAMPLES

The following example sets the object *i:/WORK/bit\_slice/hclk* to toggle.

```
fm_shell (setup)> set_init_toggle_assumption -toggle i:/WORK/bit_slice/hclk  
1
```

The following example sets the object *i:/WORK/bit\_slice/hclk* to not toggle.

```
fm_shell (setup)> set_init_toggle_assumption -no_toggle i:/WORK/bit_slice/hclk  
1
```

---

## SEE ALSO

```
remove_init_toggle_assumption(2)  
report_init_toggle_assumption(2)
```

---

## set\_input\_value\_range

Overrides the default binary (0 or 1) value range for a primary input. You can set the allowed value range to any subset of {0, 1, X, Z}.

---

### SYNTAX

```
status set_input_value_range  
  objectID  
  value_range
```

#### Data Types

```
objectID string  
value_range string
```

#### Enabled Shell Modes

Setup

---

### ARGUMENTS

#### *objectID*

Specifies the design object whose value range you want to set. You can supply any PI port or pin. If you specify a name consisting of a regular expression that resolves to more than one object, the operation will be applied to all of the matching objects, with one exception: if the name you give resolves to multiple objects with identical names (and you do not specify the object type), only one of these objects will be affected; the precedence in this case is pin followed by port.

#### *value\_range*

Specifies the value range as a subset of the standard 4-valued logic set {0, 1, X, Z}:

- *01X* - A set of values {0, 1, X}
- *0X* - A set of values {0, X}
- *1* - A constant whose value is 1

---

## DESCRIPTION

This command sets the allowed value ranges for primary inputs. By default, all primary inputs are assumed to be binary (01), meaning they can take 0 or 1 value.

The **report\_input\_value\_range** command is mainly used during hierarchical verification. This happens automatically when you use **write\_hierarchical\_verification\_script** command. You may explicitly set value ranges if additional constraints are known for an input.

Formality tracks user-defined input value ranges. Use the **report\_input\_value\_range** command to view a list of these settings.

---

## EXAMPLES

The following example sets port PI1 to input value range of 0, 1 or X.

```
fm_shell (setup)> set_input_value_range r:/WORK/top/PI1 01X
Set 'r:/WORK/top/PI1' to input range 01X
1
```

---

## SEE ALSO

[remove\\_input\\_value\\_range\(2\)](#)  
[report\\_input\\_value\\_range\(2\)](#)  
[write\\_hierarchical\\_verification\\_script\(2\)](#)



---

## set\_inv\_push

Adds a sequential object, top-level port, or black-box input pin to the list of objects through which Formality transports inverters for verification.

---

### SYNTAX

```
status set_inv_push  
[ -shared_lib ]  
objectIDlist
```

#### Data Types

*objectIDlist* string

#### Enabled Shell Modes

Setup

---

### ARGUMENTS

#### -shared\_lib

Sets the inversion push on shared technology libraries.

#### *objectIDlist*

Specifies the list of objects to which you want to apply an inversion push. Use the following syntax when specifying the *objectID\_list* argument:

```
[ { } name [ name... ] { } ]
```

Use { } when the list has more than one object. The *name* argument specifies the name of an object in the design.

---

### DESCRIPTION

This command adds a sequential object, top-level output port or black-box input pin to the list of objects through which Formality transports inverters for successful verification.

You can only use this command on,

- Sequential primitives

- Instances that reference a technology library
- Designs in technology libraries
- Top-level (primary) output ports
- Black-box input pins

---

## EXAMPLES

The following example defines a cell in which to apply inversion push.

```
fm_shell (setup)> set_inv_push ref:/WORK/CORE/reg_A  
1
```

The following example defines a technology library in which to apply inversion push.

```
fm_shell (setup)> set_inv_push -shared_lib ref:/TECH_WORK/mydesign  
1
```

---

## SEE ALSO

`remove_inv_push(2)`  
`report_inv_push(2)`

---

## set\_message\_info

Set some information about diagnostic messages.

---

### SYNTAX

string **set\_message\_info** -id message\_id [-limit max\_limit|-stop\_on|-stop\_ff]

string *message\_id*  
integer *max\_limit*

---

### ARGUMENTS

#### **-id *message\_id***

Information is to be set for the given *message\_id*. The message must exist. Although different constraints allow different message types, no constraint allows severe or fatal messages.

#### **-limit *max\_limit***

Set the maximum number of occurrences for *message\_id*. This is an integer greater than or equal to zero. If you set it to zero, that means the number of occurrences of the message is unlimited. Messages which occur after a limit is reached are automatically suppressed.

#### **-stop\_on**

Force Tcl error if message is emitted.

#### **-stop\_off**

Turn off a previous -stop\_on directive

---

### DESCRIPTION

The **set\_message\_info** command sets constraints on diagnostic messages (typically error, warning, and informational messages).

Currently, you can set a upper limit for the number of occurrences of a message. You can set this to zero to indicate that there is no limit. You can retrieve the current limit for a message using the **get\_message\_info** command. *When the limit is exceeded, all future occurrences of the message are automatically suppressed. A count of total occurrences (including those suppressed) can be retrieved using get\_message\_info.*

---

### EXAMPLES

The following example uses **set\_message\_info** to set a limit on the number of APP-027 messages to 100. When the 101st APP-027 message is about to be issued, you will be warned that the limit has been exceeded, and that all future occurrences will be

suppressed.

```
prompt> set_message_info -id APP-027 -limit 100
prompt> do_command
Warning: can't find node U27.1 (APP-027)
Warning: can't find node U27.2 (APP-027)
Warning: can't find node U27.3 (APP-027)
...
Warning: can't find node U27.100 (APP-027)
Note - message 'APP-027' limit (100) exceeded. Remainder will be suppressed.
1
```

---

## SEE ALSO

`get_message_info(2)`  
`get_message_ids(2)`  
`print_message_info(2)`  
`suppress_message(2)`

---

## set\_mismatch\_message\_filter

Sets warning or suppress filter on one or more simulation-synthesis mismatch messages.

---

### SYNTAX

```
status set_mismatch_message_filter
-warn | -suppress
[-signal SignalName]
[-block HierarchicalBlockName]
[-file FileName]
[-line LineNumber]
[MismatchMessageIDList]
```

#### Data Types

<i>SignalName</i>	string
<i>HierarchicalBlockName</i>	string
<i>FileName</i>	string
<i>LineNumber</i>	integer
<i>MismatchMessageIDList</i>	list

---

### ARGUMENTS

#### -warn

Reduces the mismatch message severity to warning. This option can not be combined with **-suppress**.

#### -suppress

Suppresses the mismatch message. This option can not be combined with **-warn**.

#### -signal SignalName

Sets mismatch message filter based on the Signal or Variable Name. The SignalName can accept a string value in Tcl glob style pattern. This is an optional option.

#### -block HierarchicalBlockName

Sets mismatch message filter based on the hierarchical block name. The Hierarchical block name can accept a string value in Tcl glob style pattern. The block name can be module or entity-architecture name, always or process block name, generate block name, function name and procedure name. The expected format of hierarchical block name for always or process block and generate block are as follows:

```
<ModuleName>[/<BlockName>]*
```

The expected format of hierarchical block name for functions and procedures that defined inside a module or package is as follows:

```
<ModuleOrPackageName>/<FunctionOrProcedureName>
```

This is an optional option.

#### -file FileName

Sets mismatch message filter based on a file name. The file name can be a leaf level file name like \*/test.v or full file path. This can accept values which are in TCL glob-style pattern matching form. This is an optional option.

**-line LineNumber**

Sets mismatch message filter for a mismatch message that occurs at given line number of an RTL file. This option requires **-file** option. It cannot be used with **-signal** or **-block** options. This is an optional option

**MismatchMessageIDList**

Sets mismatch message filter for the list of mismatch message ids specified. This is an optional option. Below are the list of simulation mismatch error codes that this option accepts:

FMR\_VHDL-274 FMR\_VHDL-1002 FMR\_VHDL-1004 FMR\_VHDL-1014 FMR\_VHDL-1025 FMR\_VHDL-1027 FMR\_VHDL-1036  
 FMR\_VHDL-1140 FMR\_VHDL-1144 FMR\_VHDL-1145 FMR\_VLOG-079 FMR\_VLOG-081 FMR\_VLOG-083 FMR\_VLOG-087  
 FMR\_VLOG-089 FMR\_VLOG-090 FMR\_VLOG-091 FMR\_VLOG-100 FMR\_VLOG-925 FMR\_VLOG-928 FMR\_VLOG-929  
 FMR\_VLOG-933 FMR\_ELAB-034 FMR\_ELAB-058 FMR\_ELAB-059 FMR\_ELAB-100 FMR\_ELAB-115 FMR\_ELAB-116  
 FMR\_ELAB-117 FMR\_ELAB-118 FMR\_ELAB-125 FMR\_ELAB-130 FMR\_ELAB-136 FMR\_ELAB-145 FMR\_ELAB-146  
 FMR\_ELAB-147 FMR\_ELAB-149 FMR\_ELAB-150 FMR\_ELAB-151 FMR\_ELAB-153 FMR\_ELAB-154 FMR\_ELAB-261 FM\_SVF-  
 001 FM\_SVF-002 FM\_SVF-003 FM\_SVF-004 FM\_SVF-005 FM\_SVF-006 FM\_SVF-007 FM\_SVF-008

---

**DESCRIPTION**

The command sets the warning or suppress filter on one or more simulation-synthesis mismatch messages. This command can be used to either reduce the severity to warning or suppress the mismatch message based on the selection criteria given by the user. If suppressed, the message will not be displayed and does not report in the RTL Interpretation summary. Explicit filters are applicable only to those message ids specified. An Implicit filter(a filter set without MismatchMessageIDList) is applicable for all mismatch messages.

**Precedence of command options**

From a given set of commands that act on same set of mismatch messages, the commands with most specific filter will have higher precedence. List of various combinations of options in decreasing order of precedence is given below:

**-file + -line -file + -block + -signal -file + -signal -file + -block -block + -signal -signal -block -file**

If any two filters have same precedence as per above list, then the filter set with **-warn** will have higher priority over **-suppress** filter.

The command returns status 1 on success and 0 on failure.

---

**EXAMPLES**

To warn on all the mismatch messages, use the command

```
fm_shell (setup)> set_mismatch_message_filter -warn
```

To suppress all the FMR\_ELAB-117, use the command

```
fm_shell (setup)> set_mismatch_message_filter -suppress FMR_ELAB-117
```

To suppress all the FMR\_VLOG-079 that matches signal names start with set\_, use the command

```
fm_shell (setup)> set_mismatch_message_filter -suppress -signal {set_*} FMR_VLOG-079
```

To warn on all the FMR\_VLOG-079 in blocks under bot/gen0, use the command

```
fm_shell (setup)> set_mismatch_message_filter -warn -block {bot/gen0/*} FMR_VLOG-079
```

---

**SEE ALSO**

```
remove_mismatch_message_filter(2)  
report_mismatch_message_filters(2)
```

---

## set\_net\_resolution

Sets resolution function on the specified net.

---

### SYNTAX

```
status set_net_resolution  
  [-force]  
  function  
  objectID
```

#### Data Types

<i>function</i>	string
<i>objectID</i>	string

#### Enabled Shell Modes

Setup

---

### ARGUMENTS

#### **-force**

Prevents the specified net from being a BBNet when one of the dividers is a primary input.

#### **function**

Specifies the function Formality uses for a net if it have multiple drivers. The supported function types are:

- *consensus* - Causes Formality to use the following rules to define the value of a multiply-driven net. This is the default net resolution function.
  - If one or more drivers are on (for example, three state devices that have been enabled), and all these drivers have the same value, the net resolves to that value.
  - If one or more drivers are on, and all these drivers do not have the same value, the net resolves to a don't care state (X).
  - If none of the drivers are on, the net resolves to a high impedance state (Z).
- *blackbox* - Causes Formality to use an "unknown" function.
- *and* - Causes Formality to use a "wired-and" function. You should never use this resolution with CMOS technology. Furthermore, your design must support wired-and functionality before you should use this resolution.
- *or* - Causes Formality to use a "wired-or" function. You should never use this resolution with CMOS technology. Furthermore, your design must support wired-or functionality before you should use this resolution.
- *onehot* - This resolution function is meant to be used when the reference design has an associated UPF file and the implementation design is a post P&R netlist with the power and ground network instantiated. It causes Formality to use the following rules to define the value of a multiply-driven net.
  - If one and only one driver has value 1'b1 and all other drivers have value 1'b0, the net resolves to value 1'b1.
  - If more than one driver has value 1'b1 the net resolves to undetermined state (X).



- If all the drivers have value 1'b0, the net resolves to value 1'b0.
- If any of the drivers have a non-binary value (X or Z), the net resolves to undetermined state (X).
- *parallel* - This resolution function is meant to be used when the reference design has an associated UPF file and the implementation design is a post P&R netlist with the power and ground network instantiated. It causes Formality to use the following rules to define the value of a multiply-driven net.
  - If all the driver have value 1'b1, the net resolves to value 1'b1.
  - If all the drivers have value 1'b0, the net resolves to value 1'b0.
  - If some of the driver has value 1'b1 and others have value 1'b0, the net resolves to undetermined state (X).
  - If any of the drivers have a non-binary value (X or Z), the net resolves to undetermined state (X).
- *parallel\_onehot* - This resolution function is meant to be used when the reference design has an associated UPF file and the implementation design is a post P&R netlist with the power and ground network instantiated. Please refer to the UPF standard for more details.

***objectID***

Specifies the net on which the resolution function is to be applied. If you specify a name that resolves to more than one net, the resolution function is applied to all of the matching nets.

---

## DESCRIPTION

Use this command to change the net resolution function of a net with multiple drivers.

---

## EXAMPLES

The following examples sets parallel resolution function for the net VDD in the implementation design.

```
fm_shell (setup)> set_net_resolution \  
parallel \  
i:/WORK/dut/VDD  
Set resolution 'parallel' on net 'i:/WORK/dut/VDD'  
1
```

---

## SEE ALSO

remove\_net\_resolution(2)  
report\_net\_resolution(2)

---

## set\_orig\_implementation

Specifies the original implementation container or design ID.

---

### SYNTAX

status **set\_orig\_implementation**

#### Enabled Shell Modes

Setup  
Match  
Verify

---

### LICENSE

This command is available when the "Formality-LogicECO" license key is used.

---

### DESCRIPTION

This command specifies the original implementation container or design ID. If a container name is given, the top design in that container will be used.

---

### SEE ALSO

match\_eco\_regions  
write\_eco\_regions  
create\_eco\_patch  
set\_orig\_reference  
set\_eco\_reference  
set\_eco\_implementation

---

## set\_orig\_reference

Specifies the original reference container or design ID.

---

### SYNTAX

status **set\_orig\_reference**

#### Enabled Shell Modes

Setup  
Match  
Verify

---

### LICENSE

This command is available when the "Formality-LogicECO" license key is used.

---

### DESCRIPTION

This command specifies the original reference container or design ID. If a container name is given, the top design in that container will be used.

---

### SEE ALSO

match\_eco\_regions  
write\_eco\_regions  
create\_eco\_patch  
set\_orig\_implementation  
set\_eco\_reference  
set\_eco\_implementation

---

## set\_parameters

Sets the verification parameters for the specified design.

---

### SYNTAX

```
status set_parameters
[ -flatten ]
[ -resolution function ]
[ -retimed ]
[ designID ]
```

#### Data Types

*function* string  
*designID* string

#### Enabled Shell Modes

Setup (for the **-resolution** and **-retimed** options only)

---

### ARGUMENTS

#### -flatten

Ignores hierarchical design block boundaries during verification. By default, Formality considers hierarchical design block boundaries to be potential internal cutpoints in the network to be verified. Although this behavior is not explicitly visible, under certain conditions, for example if you know a significant amount of boundary optimization has occurred in your design, you may see improved verification run-times by setting this parameter. However, for most designs, setting this parameter will result in a degradation or no change in verification run-time.

#### -resolution *function*

Specifies the function Formality uses for nets that have multiple drivers in the design. Formality uses "consensus" by default. You must supply one of the following values for function:

- *consensus* - Causes Formality to use the following rules to define the value of multiply-driven nets. This is the default net resolution function.
  - If one or more drivers are on (for example, three state devices that have been enabled), and all these drivers have the same value, the net resolves to that value.
  - If one or more drivers are on, and all these drivers do not have the same value, the net resolves to a don't care state (X).
  - If none of the drivers are on, the net resolves to a high impedance state (Z).
- *blackbox* - Causes Formality to use an "unknown" function.
- *and* - Causes Formality to use a "wired-and" function. You should never use this resolution with CMOS technology. Furthermore, your design must support wired-and functionality before you should use this resolution.

- *or* - Causes Formality to use a "wired-or" function. You should never use this resolution with CMOS technology. Furthermore, your design must support wired-or functionality before you should use this resolution.

#### **-retimed**

Specifies that the design has been retimed, which means some registers inside the given design have been repositioned to meet a timing goal. As a result, Formality takes additional steps during verification to ensure successful compare point creation. This parameter is not to specify which register or registers have been repositioned, but to specify in which design there is at least one repositioned register. By default, Formality does not consider a design as having been retimed.

#### **designID**

Specifies the design for which you want to set parameters. For information about how to supply a *designID*, refer to the user guide.

---

## DESCRIPTION

Use this command to set parameters that affect the verification of a specific design or the current design. To set parameters on a specific design, supply a *designID*. To apply parameters to the current design, omit the *designID*.

On a design-by-design basis, you can control hierarchical boundary consideration, resolution of nets with more than one driver, and the handling of retimed designs.

- *Flattening* - Given a top-level design that consists of hierarchical blocks, Formality considers hierarchical design block boundaries to be potential internal cutpoints in the network to be verified. Although this behavior is not explicitly visible, under certain conditions, for example if you know a significant amount of boundary optimization has occurred in your design, you may see improved verification run-times by setting this parameter. However, for most designs, setting this parameter will result in a degradation or no change in verification run-time. Setting the parameter on a given design instructs Formality to ignore the boundary of that block and all of its internal blocks.
- *Resolution* - By default, Formality uses the consensus rules as described in the *-resolution* switch to represent nets that have multiple drivers. You can use the *-resolution* switch to also specify "unknown", "wired-and", or "wired-or" functions to represent these nets. Using "unknown" (specifying black box) requires that the individual nets be treated as fixed points in the design and matched in an attempt to create compare points. Using "wired-and" or "wired-or" functions does not require the nets to be matched between the two designs in an attempt to create compare points.
- *Retiming* - Retimed designs can contain registers that have been moved in an attempt to optimize space or timing. This relocation can cause difficulties when Formality is creating compare points when given a design and its retimed counterpart. To accommodate retimed designs, you can use the *-retimed* switch. When you set the retimed parameter on a design, Formality takes steps to account for certain types of retiming. By default, Formality treats a design as if it has not been retimed.

---

## EXAMPLES

The following example sets all three parameters on the CORE design. The command causes Formality to ignore hierarchical block boundaries in the hierarchical design. Formality also considers nets with multiple drivers as "wired-and" functions. By default, Formality applies a set of consensus rules to determine the nets functions. Finally, Formality takes steps to verify CORE against a retimed design.

```
fm_shell (setup)> set_parameters -flatten \
-resolution AND \
-retimed \
ref:/WORK/CORE
Set parameter 'flatten' on 'ref:/WORK/CORE'
Set parameter 'retimed' on 'ref:/WORK/CORE'
Set resolution mode of 'AND' on 'ref:/WORK/CORE'
1
```

## SEE ALSO

`remove_parameters(2)`  
`report_parameters(2)`

---

## set\_probe\_points

Sets a net pair between the reference and implementation designs for probe verification.

---

### SYNTAX

**set\_probe\_points**

[ -inverted ]

*ref\_netID*

*imp\_netID*

**Data Types**

*ref\_netID* string

*imp\_netID* string

---

### ENABLED SHELL MODES

Setup Match Verify

---

### ARGUMENTS

**-inverted**

Specifies that the reference and implementation net objects have an inverted relationship.

***ref\_netID***

Specifies the reference net object that is a part of a probe pair to be compared for debugging. The name should specify the absolute path to a unique net in the reference design starting with the top design.

***imp\_netID***

Specifies the implementation net object which is part of a probe pair to be compared for debugging. The name should specify the absolute path to a unique net in the implementation design starting with the top design.

---

### DESCRIPTION

This command sets a probe pair for debug comparison. The probe pair consists of a net in the reference design and a second net from the implementation design. Nets that are otherwise compare points (such as cutpoints) cannot be set as probes. The net name should refer to a unique net. Use multiple **set\_probe\_point** commands to set multiple probe pairs with the same reference net and different implementation nets. This allows more efficient verification and debugging when attempting to find equivalent nets in a logic cone.

## EXAMPLES

```
fm_shell (setup)> set_probe_points $ref/U1/U2/net2 $impl/U3/net4
Set user probe between 'r:/WORK/top/U1/U2/net2' and 'i:/WORK/top/U3/net4'
1
fm_shell (setup)> set_probe_points r:/WORK/top/M1/n1 i:/WORK/top/n1
Set user probe between 'r:/WORK/top/M1/n1' and 'i:/WORK/top/n1'
1
```

---

## SEE ALSO

```
remove_probe_points(2)
report_probe_points(2)
report_probe_status(2)
verify(2)
```



---

## set\_reference\_design

Sets the reference design.

---

### SYNTAX

status **set\_reference\_design**  
[ *designID* ]

#### Data Types

*designID* string

---

### ARGUMENTS

*designID*

Specifies the design to establish as the top-level reference design.

---

### DESCRIPTION

This command establishes the reference design. To establish a specific design as the reference design, specify the *designID* argument. When you don't specify the *designID* argument, Formality sets the current design as the reference design.

When you establish a reference design, it remains active until you issue the next **set\_reference\_design** command.

---

### EXAMPLES

The following example establishes the design CORE in the ref container as the top-level reference design.

```
fm_shell> set_reference_design ref:/WORK/CORE  
Reference design set to 'ref:/WORK/CORE'  
1
```

---

### SEE ALSO

set\_implementation\_design(2)

---

## set\_run\_alternate\_strategies\_options

Set alternate strategies job options.

---

### SYNTAX

```
status set_run_alternate_strategies_options
  [-max_cores integer]
  [-protocol LSF | SGE | RTDA | PBS | NB | CUSTOM]
  [-submit_command command]
  [-num_processes integer]
```

#### Data Types

<i>integer</i>	integer
<i>command</i>	string

---

### ARGUMENTS

#### **-max\_cores *integer***

Specifies the CPU core usage limit for alternate strategy workers.

#### **-protocol LSF | SGE | RTDA | PBS | NB | CUSTOM**

Specifies the communication protocol or farm type.

#### **-submit\_command *command***

Specifies the command for launching and submitting jobs to alternate strategy workers.

#### **-num\_processes *integer***

Specifies the maximum number of workers/strategies to start in parallel.

---

### DESCRIPTION

This command configures the Master for running alternate strategy workers in parallel, and must be issued prior to `run_alternate_strategies` command.

Master Formality license is shared by one other alternate strategy worker. All other workers check out their own licenses, as and when required.

With this command, the following setup variables are deprecated and have no effect:

```
alternate_strategy_job_env
alternate_strategy_job_options
alternate_strategy_monitor_env
alternate_strategy_monitor_options
```

## EXAMPLES

The following examples illustrate the command usage for configuring the master to run alternate strategies in parallel in different farm environments.

### 1. SGE farm - 16 workers each using 4 cores

```
fm_shell> set_run_alternate_strategies_options -max_cores 4 -protocol SGE
-submit_command "qsub -V -P bnormal -cwd
-l arch=glinux,os_bit=64,mem_free=10G -pe mt 4" -num_processes 16
```

### 2. SGE farm - custom script for 16 workers each using 4 cores

```
fm_shell> set_run_alternate_strategies_options -max_cores 4 -protocol SGE
-submit_command custom.scr -num_processes 16
```

```
custom.scr
#!/bin/csh -f
qsub -V -P bnormal -cwd -l arch=glinux,os_bit=64,mem_free=10G -pe mt 4 "$"
```

### 3. LSF farm - 8 workers each using 4 cores

```
fm_shell> set_run_alternate_strategies_options -max_cores 4 -protocol LSF
-submit_command "bsub -n 4 -R \"qscm\" -R \"rusage[mem=32000]\"
-R \"span[hosts=1]\" -num_processes 8
```

### 4. LSF farm - custom script for 8 workers each using 4 cores

```
fm_shell> set_run_alternate_strategies_options -max_cores 4 -protocol LSF
-submit_command custom.scr -num_processes 8
```

```
custom.scr
#!/bin/csh -f
bsub -n 4 -R "qscm" -R "rusage[mem=32000]" -R "span[hosts=1]" "$"
```

### 5. RTDA - 12 workers each using 4 cores

```
fm_shell> set_run_alternate_strategies_options -max_cores 4 -protocol RTDA
-submit_command "nc run -r+ RAM/32000 -r+ CPUS/4" -num_processes 12
```

### 6. CUSTOM farm - 4 workers each using 4 cores

```
fm_shell> set_run_alternate_strategies_options -max_cores 4 -protocol CUSTOM
-submit_command custom.scr -num_processes 4
```

```
custom.scr
#!/bin/csh -f
bsub -n 4 -R "qscm" -R "rusage[mem=32000]" -R "span[hosts=1]" "$"
```

## SEE ALSO

run\_alternate\_strategies(2)

---

## set\_simulation\_setup\_file

Sets Synopsys simulation setup file for read

---

### SYNTAX

status **set\_simulation\_setup\_file**  
[*file\_list*]

#### Data Types

*file\_list* list

#### Enabled Shell Modes

Setup

---

### ARGUMENTS

*file\_list*

List of simulation setup files to be read in Formality

---

### DESCRIPTION

Formality can read synopsys\_sim.setup file to configure its environment matching VCS. This file maps the logical libraries and sets the default library search order.

Formality ignores following from the simulation setup file: - physical path mapped to the logical library names - Simulation variables

User can read any number of simulation setup files to formality.

---

### EXAMPLES

```
fm_shell (setup)> set_simulation_setup_file {synopsys_sim.setup}  
set_simulation_setup_file ./synopsys_sim.setup  
Loading Synopsys simulation setup file '/global/test/synopsys_sim.setup'  
1
```

---

### SEE ALSO

```
remove_simulation_setup_file(2)
read_verilog(2)
read_sverilog(2)
set_top(2)
```

---

## set\_svf

Sets the automated setup file (.svf) for verification.

---

### SYNTAX

```
status set_svf  
[-append]  
[-ordered]  
[-extension name]  
[filedirnames]
```

#### Data Types

*name* string  
*filedirname*s string

#### Enabled Shell Modes

Setup  
Guide

---

### ARGUMENTS

#### -append

Appends the data to the current SVF information.

#### -ordered

Preserves the order of the file names when reading.

#### -extension *name*

Specifies the extension to be used when recursively searching directories for SVFs. The default is "svf".

#### *filedirname*s

Specifies the name of the SVF to read or directories to search. If nothing is specified, the SVF is reset.

---

### DESCRIPTION

Use this command to set the automated setup file (.svf) for verification. The SVF provides valuable information that can be used during compare point matching to facilitate aligning of compare points in the designs to be verified. If multiple files are specified, by default, the Formality tool reads the files in the order of the file timestamps before processing. If you use the **-ordered** option, the tool does not change the order while reading the .svf files.

If a directory name is specified, Formality recursively searches the directory and reads any file whose extension matches with the **-extension** option or "svf" if the **-extension** option is not specified. For each SVF file found, the contents are processed and all information is stored in memory for later use during the name-based compare point matching.

If file name is not specified, the SVF is reset. However, it is preferred to use the **remove\_guidance** command to delete the stored SVF data.

You can use the **set\_svf** command only before reading a design. The Formality tool applies SVF processing to a specified reference design only once and ignores any additionally applied SVF during verification of a reference design that has already been modified by SVF processing.

You can see the contents of a previously set SVF with the **report\_guidance -to filename** command.

---

## EXAMPLES

This example sets the automated setup file for verification.

```
fm_shell (setup)> set_svf myfile.svf  
SVF set to 'myfile.svf'.  
1
```

---

## SEE ALSO

report\_guidance(2)  
remove\_guidance(2)

---

## set\_top

Resolves cell references and elaborates the RTL designs.

---

### SYNTAX

```
status set_top
[ -vhdl_arch architecture_name ]
[ designID | -auto ]
[ -config configID ]
[ -parameter value ]
[ -liblist LibraryList ]
[ -liblist_work ]
[ -liblist_nocelldiff ]
```

#### Data Types

*architecture\_name* string  
*designID* string  
*configID* string  
*value* string  
*LibraryList* list

---

### ARGUMENTS

#### **-vhdl\_arch *architecture\_name***

Specifies a VHDL target architecture for elaboration. The architecture name you specify must be a valid VHDL architecture.

#### ***designID***

Specifies the non-VHDL design to link or elaborate.

#### **-auto**

Attempts to automatically detect the top-level design.

#### **-config *configID***

Specifies a Verilog Configuration for elaboration. The configID is the name of a valid Verilog configuration. If user has not specified a designID, Formality will pick first design in the design statement of the configuration. Formality will not accept -auto with -config option.

#### **-parameter *valueID***

Specifies a new value for design parameters. The parameter values may be integers or specified in the following format:

<param\_name> <hex value format> <base>'h<value>

For example:

```
fm_shell (setup)> set_top ref:/WORK/design \
```



**-param {w1 = 4'h5 }**

For proper usage, use the following rules:

- Single positional parameter: param\_value
- Multiple positional parameters:  
{ param\_value1, param\_value2, ... }
- Single name-based parameters:  
{ param\_name = param\_value }  
{ param\_name <= param\_value }
- Multiple name-based parameters:  
{ param\_name1 = param\_value1, param\_name2  
param\_value2, ... }  
{ param\_name1 <= param\_value1, param\_name2 <=  
param\_value2, ... }
- Mixed positional and name-based parameters:  
{ param\_value1, param\_value2, param\_name3 =  
param\_value3, param\_name4 = param\_value4, ... }  
{ param\_value1, param\_value2, param\_name3 <  
param\_value3, param\_name4 <= param\_value4, ... }

You cannot specify a name-based parameter before a positional parameter. This is consistent with Design Compiler.

You can pass parameters to SystemVerilog Interface type ports defined in top module. The parameter name should be in the form - <Port Name>.<Parameter Name>

Specify the base name the port if the port is an array of interface/modport.

The interface port parameters can be specified by name based only and it can be mixed with name based module parameters. You can mix interface port parameter with positional parameters however, all the positional parameters must be specified before name-based parameters.

### **-liblist *LibraryList***

It specifies the library search order for unresolved modules or entity instantiated in Verilog/SystemVerilog. This option is available only when simulation setup file is read. When -liblist is specified, Formality starts searching libraries in the order specified with -liblist. It neither honors the library order specified in the synopsys\_sim.setup file, nor look at the other libraries present in the synopsys\_sim.setup file.

### **-liblist\_work**

The -liblist\_work elaboration option enables Formality to first search in the parent work library when attempting to resolve a design cell. This option is relevant only when the Verilog configuration file is not used. This option is available only when simulation setup file is read.

### **-liblist\_nocellidiff**

The -liblist\_nocellidiff elaboration option disables the differentiation between design cell and library cell. You can use this option at elaboration time to override the default precedence order. This option is available only when simulation setup file is read.

## DESCRIPTION

This command resolves all name-based design references in a specific design.

When resolving references, Formality does not look outside the container in which the specified design resides. If you are linking a netlist, Formality attempts to resolve all named references. If you are linking an RTL or VHDL design, issuing the **set\_top** command causes Formality to first elaborate the design and then attempt to resolve all named references.

If you are elaborating VHDL and you have more than one architecture, you can use the **-vhdl\_arch** option to supply the target architecture.

If you do not specify the *designID* argument or specify the **-auto** option, Formality attempts to use the current design. If you specify the *designID* argument without the path prefix, the **set\_top** command attempts to find it in the default library in the current container.

During the linking process, Formality issues errors if it cannot resolve a named reference. Alternatively, if you set the **hdlin\_unresolved\_modules** variable to **black\_box**, Formality issues warnings and treats unresolved named references as black boxes.

You can also change the design parameter values by using the **-parameter value** option.

For the **-parameter** option, the parameter specification must be specially delimited. The parameter specification can be enclosed in double quotation marks ("), but this is not advised if the specification itself includes string values. Instead, use the special parameter-delimiter, which brackets the parameter specification syntax. The parameter-delimiter starts and ends with '#' (hash). Multi-line strings put backslashes (\) as the last character in the line. This is because "#" is properly recognized as a string constant.

Spaces can be inserted in the middle of the parameter string to make your script easier to read, but you must either enclose the parameter string in double quotation marks ("), or escape the spaces using back slashes (\).

NOTE: After successful completion of the **set\_top** command all shared libraries in the container are no longer shared.

---

## EXAMPLES

The following example loads a design and attempts to link it without the supporting library. Formality issues warning messages for each cell in the design whose name cannot be resolved. Formality then reloads with the required supporting library and issues the same **set\_top** command.

```
fm_shell> read_db mapped_gate_lca500k.db
Loading db file 'mapped_gate_lca500k.db'
No target library specified, default is WORK
1
fm_shell> set_top ref:/WORK/CORE
Warning: Cannot link cell 'OUTPUT_BUFFER/U11' to its
reference design 'IV'. (FE-LINK-2)
Warning: Cannot link cell 'MULTIPLEXOR/U15' to its
reference design 'IV'. (FE-LINK-2)
Warning: Cannot link cell 'MULTIPLEXOR/U16' to its
reference design 'IV'. (FE-LINK-2)
...
set_top of 'ref:/WORK/CORE' failed
fm_shell> read_db mapped_gate_lca500k.db
Loading db file 'mapped_gate_lca500k.db'
No target library specified, default is WORK
1
fm_shell> read_db lca500k.db
Loading db file 'lca500k.db'
1
fm_shell> link ref:/WORK/CORE
Set top 'ref:/WORK/CORE' completed successfully
1
```

The following example elaborates the design using a configuration specified with **set\_top** command

```
fm_shell> set_top r:/rtlLib3/top -config r:/cfgLib/cfg_top
Setting top design to 'r:/RTLlib3/top'
...
```

If user has not specified the designID, Formality will choose first design in the 'design statement' of configuration to elaborate.

```
fm_shell> set_top -config r:/cfgLib/cfg_top
Setting top design to 'r:/RTLlib/mid'
...
```

Following example elaborates the design 'top' using module parameters - 20, 3 and interface port parameters P1.VALUE=>2, P2.SIZE=>8, P2.VALUE=>3, P1.SIZE=>8

```
fm_shell> set_top top -param {10, 3, P1.VALUE=>2, P2.SIZE=>8, P2.VALUE=>3, P1.SIZE=>8}
Setting top design to 'i:/WORK/top'
...
```

Following example elaborates the design 'top' using module parameters - SIZE=>10, PARITY=>1 and applies the parameters "VALUE=>2, SIZE=>8" to array of ports named 'intf\_arr'

```
fm_shell> set_top top -param {SIZE=>10, PARITY=>1, intf_arr.VALUE=>2, intf_arr.SIZE=>8}
Setting top design to 'i:/WORK/top'
...
```

Following example elaborates the design 'top'. All the references in design hierarchy will be resolved using the liblist specified and there will not be any differentiation between design cell and library cell

```
fm_shell> set_simulation_setup_file synopsys_sim.setup
...
fm_shell> set_top top -liblist_nocelldiff -liblist {LIB1 LIB2 LIB3 LIB4}
Setting top design to 'i:/WORK/top'
...
```

---

## SEE ALSO

[verify\(2\)](#)  
[hdlin\\_unresolved\\_modules\(3\)](#)  
[set\\_simulation\\_setup\\_file\(2\)](#)

---

## set\_trace\_option

Set an option value controlling behavior of command tracing and output annotation..

---

### SYNTAX

```
set_trace_option [-command name
                  |-profile profile_metric_types
                  |-memory_threshold threshold
                  |-cpu_threshold threshold
                  |-time_threshold threshold ]
                  [-annotate annotate_type]
```

string *name*

string *annotate\_type*

list *profile\_metric\_types*

integer *threshold*

---

### ARGUMENTS

#### **-command *name***

This option is mutually exclusive with -profile, -memory\_threshold, -cpu\_threshold, and -time\_threshold. The option identifies the command for which annotation option is being set.

#### **-annotate *annotate\_type***

This option is meaningful only when given with the -command option. Set the annotation type of the given command with this option. The allowed values are {annotate, omit}.

The *annotate* option value causes the traced command execution to be annotated to the shell output. If the application supports an output log, the annotation is also output to the output log.

The *omit* option value causes the command execution string to be omitted from output annotation.

#### **-profile *profile\_metric\_types***

This option is mutually exclusive with all others. The option sets the currently enabled profile metrics, or "all" if all metrics are enabled. Allowed values are a list of: memory, cpu, time, or the value all to indicate enabling of all metrics, or the value none to indicate disabling of all metrics. If none is given in a list with any other value, it is ignored. The enabled profile metrics are reported with command annotations in the tool output to shell, and to the output log if supported by the tool.

#### **-memory\_threshold *threshold***

This option is mutually exclusive with all others. The option sets the threshold for gathering memory metrics. The profile data annotation will be output at the end of a command invocation only when the delta memory use for a command invocation matches or exceeds the threshold. The threshold has no effect on profile data output at the beginning of command invocation when this is enabled. The threshold is expressed in kilobytes. The special value -1 unsets the threshold.

#### **-cpu\_threshold *threshold***

This option is mutually exclusive with all others. The option sets the threshold for gathering CPU usage metrics. The profile data annotation will be output at the end of a command invocation only when the delta CPU usage for a command invocation matches or exceeds the threshold. The threshold has no effect on profile data output at the beginning of command invocation when this is

enabled. The threshold is expressed in seconds. The special value -1 unsets the threshold. If cpu threshold is unset, then the default threshold of 1 second is used. To effect no threshold, set the threshold to 0 (zero).

#### **-time\_threshold *threshold***

This option is mutually exclusive with all others. The option sets the threshold for gathering elapsed time metrics. The profile data annotation will be output at the end of a command invocation only when the elapsed time for a command invocation matches or exceeds the threshold. The threshold has no effect on profile data output at the beginning of command invocation when this is enabled. The threshold is expressed in seconds. The special value -1 unsets the threshold. If time threshold is unset, then the threshold for cpu is used.

---

## DESCRIPTION

If a command is given with -annotate option, then the **set\_trace\_option** command informs the tool on how to behave during command annotation output, which is started with the **annotate\_trace** command.

If profile, memory\_threshold, cpu\_threshold, or time\_threshold is given, the **set\_trace\_option** configures the behavior of performance profile gathering and the data reported in command annotations to the output.

---

## EXAMPLES

The following example sets profile configurations, turns annotation off for the command *get\_attribute*, then starts command annotations to the output.

```
prompt> set_trace_topion -profile all
prompt> set_trace_topion -memory_threshold 10
prompt> set_trace_topion -cpu_threshold 30
prompt> set_trace_topion -command get_attribute -annotate omit
prompt> annotate_trace -start -profile on
```

---

## SEE ALSO

log\_trace(2)  
annotate\_trace(2)  
get\_trace\_option(2)

---

## set\_unix\_variable

Sets the value of a UNIX environment variable.

---

### SYNTAX

**set\_unix\_variable**  
*variable\_name new\_value*

#### Data Types

*variable\_name* string  
*new\_value* string

---

### ARGUMENTS

#### *variable\_name*

Specifies the name of a UNIX environment variable.

#### *new\_value*

Specifies the new value for the specified UNIX environment variable.

---

### DESCRIPTION

This command sets the specified UNIX environment variable to the new value in the current application. The variable is created if is not already defined in the environment.

The **get\_unix\_variable** command returns the new value of the variable. To develop shell command scripts, use both the **get\_unix\_variable** and **set\_unix\_variable** commands.

Child processes initiated from the application, using the **sh** command, after running the **set\_unix\_variable** command inherit the new variable value. If you set a variable in the application using the **set\_unix\_variable** command, run the **get\_unix\_variable** command to see the new value. You also see the new value in any subsequent processes you initiate from within the application using the **sh** command. However, you do not see the new value in the parent UNIX shell from which you invoked the application.

If you use the UNIX command **setenv** to set a UNIX variable in a shell you previously invoked using the **sh** command, you do not see that value in the application.

---

### EXAMPLES

The following example changes the default printer.

```
fm_shell> get_unix_variable "PRINTER" laser1
```

```
fm_shell> set_unix_variable "PRINTER" "laser3" laser3
```

```
fm_shell> get_unix_variable "PRINTER" laser3
```

---

## SEE ALSO

[get\\_unix\\_variable\(2\)](#)

[rintenv\(2\)](#)

[sh\(2\)](#)

---

## set\_user\_match

Creates pairs of matched points when two or more comparable design objects are specified.

---

### SYNTAX

```
status set_user_match  
[ -type ID_type_list ]  
[ -inverted | -noninverted ]  
objectID_1 objectID_2
```

#### Data Types

*ID\_type\_list* string  
*objectID* string

---

### ARGUMENTS

#### **-type *ID\_type\_list***

Specifies the object type. You may use this option if the name of a specified design object is associated with more than one object type in the same design. Specify one of the following values for the *ID\_type* argument:

- *pin* - Specifies pin type
- *port* - Specifies port type
- *net* - Specifies net type
- *cell* - Specifies cell type
- *{pin net}* - Specifies that the first object is a pin and the second is a net
- *{net pin}* - Specifies that the first object is a net and the second is a pin

#### ***objectID\_1 objectID\_2***

Matches the design objects specified. The design objects must be comparable in type. Exactly one of the objects must be from the reference. The others must be from the implementation. If you specify a name consisting of a regular expression that resolves to more than one object, the tool reports an error. However, if the name resolves to multiple objects with identical names (and you do not specify the object type), only one of these objects will be affected. The precedence in this case is pin, port, net, cell.

#### **-inverted**

Specifies that the matched design objects have inverted relationship. Default is unknown relationship.

#### **-noninverted**

Specifies that the matched design objects have noninverted relationship. Default is unknown relationship.



---

## DESCRIPTION

This command matches two or more design objects. You can use this command to match points that Formality could not match during its matching process. For example, Formality does not automatically match primary output ports that differ in name but are otherwise comparable.

Specify the polarity of the match using the **-inverted** or the **-noninverted** options. If the **verification\_inversion\_push** variable is enabled, Formality determines the polarity for registers that have unspecified polarities. If the **verification\_inversion\_push** is not enabled, then all unknown polarities will default to noninverted. For I/O ports any unknown polarity is assumed noninverted.

User-defined matches are not applied to the designs until the next *match* or *verify* command. Many other related points may be matched as a result of a user-defined match. Once a user-defined match is applied, it cannot be removed unless you unapply it using the *undo\_match* or *setup* command. This prevents situations where the matched and setup states are inconsistent. You can determine the matches resulting from a *set\_user\_match* command by following it with the *match* and *report\_matched\_points -last* commands.

One reference design object may be matched with more than one implementation design object. In that case, each implementation object is verified against the reference object. A single implementation object may not match more than one reference object. One-to-many matches are not discovered automatically by Formality, but may only be specified by the user with **set\_user\_match**. Hierarchical blocks (linked cells) and their pins may not be multiply matched, except for black boxes and black box pins.

---

## EXAMPLES

This example creates a compare point using two ports: *FULL* and *A\_FULL*. The design containing the port *FULL* is the current design. The port *A\_FULL* is located in the impl container, the WORK design library, and the CORE design.

```
fm_shell> set_user_match impl:/WORK/CORE/A_FULL \  
FULL
```

This example matches registers with the same name as the ports in the previous example. Consequently, the **-type** option is required.

```
fm_shell> set_user_match -type cell \  
impl:/WORK/CORE/A_FULL \  
FULL
```

---

## SEE ALSO

```
match(2)  
undo_match(2)  
remove_user_match(2)  
report_matched_points(2)  
report_unmatched_points(2)
```

---

## set\_vclp\_setup\_commands

Use this command to specify a list of commands to pass to VCLP at startup when using the Static Low Power Compare functionality.

---

### SYNTAX

```
status set_vclp_setup_commands  
      vclp_command_list
```

---

### DESCRIPTION

When using the Static Low Power Compare functionality in Formality (see **verification\_static\_low\_power\_compare**), This command is used to specify a list of VCLP commands to execute at startup when VCLP is invoked by Formality. The list of commands will be given to both the reference and implementation VCLP runs and will be executed before any other VCLP commands.

---

### EXAMPLES

```
fm_shell (setup)> set_vclp_setup_commands {source "mysetupfile.vclp.tcl"}
```

---

### SEE ALSO

[verification\\_static\\_low\\_power\\_compare\(3\)](#)

---

## set\_verify\_points

Marks multiple compare points for verification.

---

### SYNTAX

```
status set_verify_points  
[ -type ID_type ]  
[ -file fileOfObjectIDs ]  
[ objectID_list ]
```

#### Data Types

```
ID_type string  
fileOfObjectIDs string  
objectID_list string
```

#### Enabled Shell Modes

```
Setup  
Match  
Verify
```

---

### ARGUMENTS

#### -type *ID\_type*

Specifies the type for the specified objects. Use this option if the name of the specified design object is associated with more than one object type in the same design. Specify one of the following object types:

- *pin* - To specify pin type
- *port* - To specify port type
- *net* - To specify net type
- *cell* - To specify cell type

#### -file *fileOfObjectIDs*

Specifies a file containing object IDs. See the *objectID\_list* argument description for details on object IDs.

#### *objectID\_list*

Specifies one or more design objects associated with the compare point to verify. If you specify a name that resolves to more than one object, the operation is applied to all of the matching objects.

---

## DESCRIPTION

This command marks multiple compare points for verification.

Verify points affect the subsequent **match** and **verify** commands. To view the current set of compare points marked for verification, use the **report\_verify\_points** command.

---

## EXAMPLES

The following example verifies only the specified ports in the reference design named top.

```
fm_shell (setup)> set_verify_points {r:/WORK/top/out1 r:/WORK/top/out2 r:/WORK/top/out3}
```

The following example uses a wildcard character to enable verification of all ports matching the expression:

```
fm_shell (setup)> set_verify_points -type port {r:/WORK/top/out*}
```

The following example writes a file of failing points and then later enables verification of only those points:

```
fm_shell (verify)> report_failing_points -list > fail.fpt  
[...later in a separate Formality run...]  
fm_shell (setup)> set_verify_points -file fail.fpt
```

---

## SEE ALSO

remove\_verify\_points(2)  
report\_verify\_points(2)  
report\_aborted\_points(2)  
report\_failing\_points(2)  
report\_unmatched\_points(2)

---

## set\_vsdc

Sets the VSDC.

---

### SYNTAX

status **set\_vsdc**  
[-append]  
[-ordered]  
[-extension *name*]  
[*filedirname*s]

#### Data Types

*name* string  
*filedirname*s string

#### Enabled Shell Modes

Setup  
Guide

---

### ARGUMENTS

#### -append

Appends the data to the current VSDC information.

#### -ordered

Preserves the ordering of the filenames when reading.

#### -extension *name*

Specifies the extension to be used when recursively searching directories for VSDC files. Default is "vsdc".

#### *filedirname*s

Specifies the name of the VSDC files to read or directories to search. If nothing is specified, the VSDC is reset.

---

### DESCRIPTION

This command sets the VSDC. The VSDC provides valuable information that is used during compare point matching to facilitate alignment of compare points in the designs to be verified. Unlike SVF, which contains information that is either dependent on Synopsys-specific technology or is only in limited customer availability, VSDC files are intended for all verification flows.

If multiple files are specified, Formality attempts to order the files before processing (unless -ordered is specified in which case Formality does not change the order). If a directory name is specified, Formality recursively searches the directory and reads any file

whose extension matches that specified using the **-extension** option or "vsvc" if no extension is specified. For each VSDC file found, the contents are processed and all information is stored in memory for later use during name-based compare point matching.

If a file name is not specified, the VSDC is reset. However, it is preferred to use the **remove\_guidance** command to delete the stored VSDC data.

You can see the contents of a previously set VSDC by using the **report\_guidance -to filename** command.

---

## EXAMPLES

The following example shows how to use the **set\_vsvc** command.

```
fm_shell (setup)> set_vsvc myfile.vsvc  
VSDC set to 'myfile.vsvc'.  
1
```

---

## SEE ALSO

set\_vvf(2)  
report\_guidance(2)  
remove\_guidance(2)

---

## setenv

Sets the value of a system environment variable.

---

### SYNTAX

string **setenv** *variable\_name* *new\_value*

string *variable\_name*

string *new\_value*

---

### ARGUMENTS

***variable\_name***

Names of the system environment variable to set.

***new\_value***

Specifies the new value for the system environment variable.

---

### DESCRIPTION

The **setenv** command sets the specified system environment *variable\_name* to the *new\_value* within the application. If the variable is not defined in the environment, the environment variable is created. The **setenv** command returns the new value of *variable\_name*. To develop scripts that interact with the invoking shell, use **getenv** and **setenv**.

Environment variables are stored in the Tcl array variable **env**. The environment commands **getenv**, **setenv**, and **printenv** are convenience functions to interact with this array.

The **setenv** command sets the value of a variable only within the process of your current application. Child processes initiated from the application using the **exec** command after a usage of **setenv** inherit the new variable value. However, these new values are not exported to the parent process. Further, if you set an environment variable using the appropriate system command in a shell you invoke using the **exec** command, that value is not reflected in the current application.

---

### EXAMPLES

The following example changes the default printer.

```
shell> getenv PRINTER
laser1
shell> setenv PRINTER "laser3"
laser3
shell> getenv PRINTER
```

laser3

---

## SEE ALSO

exec(2)  
getenv(2)  
unsetenv(2)  
printenv(2)  
printvar(2)  
set(2)  
sh(2)  
unset(2)



---

## setup

Causes Formality to revert to SETUP mode.

---

### SYNTAX

status **setup**

#### Enabled Shell Modes

Match  
Verify

---

### DESCRIPTION

This command changes the Formality mode to the Setup mode, discards any matching and verification results, and enables all setup commands.

Upon invocation, Formality starts in the Setup mode. After executing the **match** command, Formality switches to the Match mode. After executing the **verify** command, Formality switches to the Verify mode.

Many commands can be executed only in the Setup mode. Execute the **setup** command to return to the Setup mode, which re-enables all setup commands and discards all matching information resulting from the **match** and **verify** commands. . The prompt changes to reflect the current mode, as follows:

```
fm_shell (guide)>
fm_shell (setup)>
fm_shell (match)>
fm_shell (verify)>
```

---

### EXAMPLES

The following example illustrates returning to the Setup mode from the Match mode.

```
fm_shell (match)> setup
1
fm_shell (setup)>
```

---

### SEE ALSO

guide(2)  
match(2)  
verify(2)

---

## sh

Executes a command in a child process.

---

### SYNTAX

**sh**  
[*args*]

#### Data Types

*args* string

---

### ARGUMENTS

*args*

Command and arguments that you want to execute in the child process.

---

### DESCRIPTION

Use this command to execute a command in a child process. This is very similar to the UNIX **exec** command. However, file name expansion is performed on the arguments.

---

### EXAMPLES

This example shows how you can remove files using a wildcard.

```
fm_shell> ls aaa*  
aaa1  aaa2  aaa3  
fm_shell> sh rm aaa*  
fm_shell> ls aaa*  
Error: aaa*: No such file or directory Use error_info for more info. (CMD-013)
```

---

### SEE ALSO

---

## shell\_is\_fmeco\_shell

Determines if Formality ECO tool was invoked.

---

### SYNTAX

status **shell\_is\_fmeco\_shell**

---

### ARGUMENTS

None

#### Enabled Shell Modes

All

---

### DESCRIPTION

This command is used to check if the tool is running as fmeco\_shell. The command returns 1 if the shell is Formality ECO shell, or 0 otherwise.

---

### EXAMPLES

The following example shows how to check the shell in which the tool has been invoked:

```
prompt> if { [shell_is_fmeco_shell] } { \  
    echo "You invoked fmeco_shell" \  
} else { \  
    echo "You invoked normal fm_shell" \  
}
```

---

### SEE ALSO

fm\_shell(2)

---

## sizeof\_collection

Returns the number of objects in a collection.

---

### SYNTAX

```
int sizeof_collection  
    collection1
```

#### Data Types

*collection1*      collection

---

### ARGUMENTS

#### *collection1*

Specifies the collection for which to get the number of objects. If the empty collection (empty string) is used for the *collection1* argument, the command returns 0.

---

### DESCRIPTION

The **sizeof\_collection** command is an efficient mechanism for determining the number of objects in a collection.

---

### EXAMPLES

The following example from Formality shows a simple way to find out how many objects matched a particular pattern and filter in the **get\_cells** command.

```
prompt> echo "Number of techlib cells: \  
?      [sizeof_collection \  
?      [get_cells -hierarchical -filter is_techlib]]"  
Number of techlib cells: 10
```

---

### SEE ALSO

collections(2)  
get\_cells(2)

---

## sort\_collection

Sorts a collection based on one or more attributes, resulting in a new, sorted collection. The sort is ascending by default.

---

### SYNTAX

```
collection sort_collection
  [-descending]
  [-dictionary]
  collection
  criteria
```

#### Data Types

<i>collection</i>	collection
<i>criteria</i>	list

---

### ARGUMENTS

#### -descending

Indicates that the collection is to be sorted in reverse order. By default, the sort proceeds in ascending order.

#### -dictionary

Sort strings dictionary order. For example "a30" would come after "a4".

#### *collection*

Specifies the collection to be sorted.

#### *criteria*

Specifies a list of one or more application or user-defined attributes to use as sort keys.

---

### DESCRIPTION

You can use the **sort\_collection** command to order the objects in a collection based on one or more attributes. For example, to get a collection of non-techlib cells increasing alphabetically, followed by techlib cells increasing alphabetically, sort the collection of cells using the *is\_techlib* and *full\_name* attributes as *criteria*.

In an ascending sort, Boolean attributes are sorted with those objects first that have the attribute set to *false*, followed by the objects that have the attribute set to *true*. In the case of a sparse attribute, objects that have the attribute come first, followed by the objects that do not have the attribute.

Sorts are ascending by default. The *-descending* option reverses the order of the objects.

---

## EXAMPLES

The following example from Formality sorts a collection of cells based on the `is_techlib` attribute, and adds a second key to list them alphabetically. In this example, cells U1, U2 and U10 are techlib cells, and Z1 and Z2 are non-techlib cells. Because the *is\_techlib* attribute is Boolean, those objects with the attribute set to *false* are listed first in the sorted collection.

```
pt_shell> set zc [get_cells {Z2 U2 Z1 U1 U10}]
{r:/WORK/top/Z1 r:/WORK/top/U2 r:/WORK/top/Z1 r:/WORK/top/U1 r:/WORK/top/U10}
pt_shell> set zsort [sort_collection $zc {is_techlib full_name}]
{r:/WORK/top/Z1 r:/WORK/top/Z2 r:/WORK/top/U1 r:/WORK/top/U10 r:/WORK/top/U2}
pt_shell> set zsort [sort_collection -dictionary $zc {is_techlib full_name}]
{r:/WORK/top/Z1 r:/WORK/top/Z2 r:/WORK/top/U1 r:/WORK/top/U2 r:/WORK/top/U10}
```

---

## SEE ALSO

[collections\(2\)](#)

---

## source

Reads a file and evaluates it as a Tcl script.

---

## SYNTAX

```
source  
[-echo]  
[-verbose]  
file
```

### Data Types

*file* string

---

## ARGUMENTS

### -echo

Echoes each command as it is executed. Note that this option is a non-standard extension to Tcl.

### -verbose

Displays the result of each command executed. Note that error messages are always displayed. This option is a non-standard extension to Tcl.

### *file*

Specifies the script file to read.

---

## DESCRIPTION

This command reads a command from a file and then pass each one to the command interpreter. The result of the **source** command is the result of the last command executed from the file specified.

- If an error occurs in evaluating the contents of the file, the **source** command displays that error.
- If the **return** command is invoked from within the file, the remainder of that file is skipped and the **source** command returns normally with the result from the **return** command.

By default, the **source** command displays little information. It is possible to get intermediate information from the **source** command using the **-echo** and **-verbose** options. The **-echo** option echoes each command as it appears in the script. The **-verbose** option echoes the result of each command after execution. To emulate the behavior of the Design Compiler **include** command, use both these options.

The file name specified can be a fully expanded file name and can begin with a tilde. Under normal circumstances, this file is searched for based only on what you typed. However, if the system variable **sh\_source\_uses\_search\_path** is set to "true", the file is

searched for based on the path established with the **search\_path** variable.

---

## EXAMPLES

This example reads in a script of aliases.

```
fm_shell> source -echo aliases.tcl
alias q quit
alias hv {help -verbose}
alias include {source -echo -verbose}
```

---

## SEE ALSO

search\_path(3)  
sh\_source\_uses\_search\_path(3)



---

## start\_dpx\_workers

Starts distributed processing workers.

---

### SYNTAX

```
status start_dpx_workers
```

---

### DESCRIPTION

Use the **start\_dpx\_workers** command to create and initialize distributed processing workers specified by the **set\_dpx\_options** command. This command is non-blocking, meaning that it returns immediately after making the request to start the workers, but before the workers are ready to accept tasks. The **get\_dpx\_workers** command can be used to determine how many workers have started.

In a typical distributed processing flow, the workers are automatically started when the verification session enters a part of the flow that can be distributed. If the distribution is managed by a compute farm, it is not unusual to have significant latency between the request for workers and the provision of workers by the farm. It is also not unusual to have a significant delay between availability of the first and last worker, or for the job to never get the full complement of workers requested. Some of these delays can be mitigated by running the **start\_dpx\_workers** command early in the verification script, increasing the probability of workers to be ready to accept tasks when needed. However, this also means that workers remain idle until needed, which might violate your local compute farm policies.

When using the **start\_dpx\_workers** command, it is typical to also set the **dpx\_keep\_workers\_alive** variable to ensure that workers are not released until either the end of the session or explicitly using the **stop\_dpx\_workers** command.

---

### EXAMPLES

The following example shows how to set up and start four distributed processing workers, and keep them alive:

```
fm_shell (setup)> set_dpx_options -protocol SGE -submit_command "qsub -P bnormal -l mem_free=100G" -max_workers 4 -max_cores 4
```

```
fm_shell (setup)> start_dpx_workers
Info: Starting 4 workers. Each worker can process 4 tasks at a time.
Starting DPX workers: /some/path/FM_DPX_WORK/crew/C1
```

```
fm_shell (setup)> set_dpx_keep_workers_alive true
true
```

---

### SEE ALSO

```
set_dpx_options(2)
remove_dpx_options(2)
report_dpx_options(2)
stop_dpx_workers(2)
get_dpx_workers(2)
dpx_enable_checkpoint_verification(3)
dpx_keep_workers_alive(3)
```

dpx\_verification\_strategies(3)  
dpx\_worker\_acquisition\_timeout(3)

---

## start\_gui

Starts a Formality GUI session.

---

### SYNTAX

status **start\_gui**

---

### DESCRIPTION

This command starts a GUI session.

Once a GUI window has been created, subsequent **start\_gui** commands are ignored until after using the **stop\_gui** command. The GUI can be started and stopped any number of times during a single Formality session.

---

### SEE ALSO

stop\_gui(2)

---

## stop\_dpx\_workers

Stops and releases all currently distributed processing workers.

---

### SYNTAX

stop\_dpx\_workers

---

### DESCRIPTION

The **stop\_dpx\_workers** command shuts down and releases any distributed processing workers currently in use. It also cancels any requests for workers that are not yet fulfilled by the compute farm. This command directly controls the lifetime of the distributed processing workers.

If you execute a command for distributed processing workers later, before running the **start\_dpx\_workers** command, new workers can get automatically requested and started.

---

### EXAMPLES

The following example stops and releases all the currently distributed processing workers.

```
fm_shell (setup)> stop_dpx_workers
Stopping DPX workers
```

---

### SEE ALSO

set\_dpx\_options(2)  
remove\_dpx\_options(2)  
report\_dpx\_options(2)  
start\_dpx\_workers(2)  
get\_dpx\_workers(2)  
dpx\_enable\_checkpoint\_verification(3)  
dpx\_keep\_workers\_alive(3)  
dpx\_verification\_strategies(3)  
dpx\_worker\_acquisition\_timeout(3)

---

## stop\_gui

Closes the Formality GUI session.

---

### SYNTAX

status **stop\_gui**

---

### DESCRIPTION

This command closes the current Formality GUI session.

If the GUI window is not currently open, the **stop\_gui** command is ignored. The GUI can be started and stopped any number of times during a single Formality session.

---

### SEE ALSO

start\_gui(2)

---

## suppress\_message

Disables printing of one or more informational or warning messages.

---

### SYNTAX

```
string suppress_message [message_list]
```

```
list message_list
```

---

### ARGUMENTS

*message\_list*

A list of messages to suppress.

---

### DESCRIPTION

The **suppress\_message** command provides a mechanism to disable the printing of messages. You can suppress only informational and warning messages. The result of **suppress\_message** is always the empty string.

A given message can be suppressed more than once. So, a message must be unsuppressed (using **unsuppress\_message**) as many times as it was suppressed in order for it to be enabled. The **print\_suppressed\_messages** command displays the currently suppressed messages.

---

### EXAMPLES

When the argument to the **unalias** command does not match any existing aliases, the CMD-029 warning message displays. This example shows how to suppress the CMD-029 message:

```
prompt> unalias q*  
Warning: no aliases matched 'q*' (CMD-029)  
prompt> suppress_message CMD-029  
prompt> unalias q*  
prompt>
```

---

### SEE ALSO

```
print_suppressed_messages(2)  
unsuppress_message(2)  
get_message_ids(2)
```

set\_message\_info(2)

---

## test\_compare\_rule

Tests a name matching rule on current unmatched points or user-specified names.

---

### SYNTAX

```
status test_compare_rule  
[designID | -r | -i]  
-name name_list  
-from search_pattern  
-to replace_pattern  
[-substring string]  
[-type type]
```

#### Data Types

```
search_pattern string  
replace_pattern string  
string string  
type string  
name_list string
```

---

### ARGUMENTS

#### ***designID***

Specifies the design on which to test unmatched compare points by the name matching rule.

#### **-r**

Specifies the reference design for testing.

#### **-i**

Specifies the implementation design for testing.

#### **-name**

Specifies a list of arbitrary user-defined names for testing. No *designID* should be specified along with this option.

#### **-to *replace\_pattern***

Specifies the pattern Formality uses as a replacement after successfully finding the *search\_pattern* argument. Formality supports the same syntax for *replace\_pattern* as it does for regular expressions used by the UNIX **sed** command. Arithmetic expressions can be specified delimited by \{ and \}.

#### **-from *search\_pattern***

Specifies the pattern for which Formality searches during the compare point creation process. Formality supports the same syntax for *search\_pattern* as it does for regular expressions used by the UNIX **sed** command. Please make sure that only relative names are used in the pattern, excluding top level name.

#### **-substring *string***



Reports points containing the specified *string*.

### **-type *ID\_type***

Specifies the object type to be tested by the rule:

- cell
- port
- net

---

## DESCRIPTION

This command tests name translation rules. Note that this command just tests the rule. If the testing is successful, use the `set_compare_rule` command to set the compare rule. You can perform testing on current unmatched points or user specified arbitrary names. A report is printed with mapped and unmapped names.

Compare rules are based on a regular expression syntax identical to that supported by the UNIX **sed** facility. This command also supports arithmetic expressions in the replace pattern. You can use this command to check the syntactic correctness of your regular expressions and arithmetic expressions.

You can specify a particular design to be tested by supplying a *designID*. If you do not supply a *designID*, Formality tests the rule(s) on the current design. Also, you can omit the container portion of the *designID* to default to the current container.

---

## EXAMPLES

This example tests a compare rule for the design 'topxor'. The rule performs the following name transformations: out0 -> out\_1\_reg out1 -> out\_2\_reg out2 -> out\_3\_reg out3 -> out\_4\_reg

.nf

```
fm_shell> test_compare_rule r:/WORK/topxor \ -from {out\([0-9]+\)} -to {out_\(1+1\)_reg}
```

3 Mapped Point(s):

Port r:/WORK/topxor/out1 mapped to r:/WORK/topxor/out\_2\_reg

Port r:/WORK/topxor/out4 mapped to r:/WORK/topxor/out\_5\_reg

Port r:/WORK/topxor/out9 mapped to r:/WORK/topxor/out\_10\_reg

2 Unmapped Point(s):

Pin r:/WORK/topxor/clock

Net r:/WORK/topxor/wire0

Total: 5 (3 Mapped, 1 Unmapped) 1

This example tests the previous rule on arbitrary names.

```
fm_shell> test_compare_rule -name {out1 reg clk vcc out4} \
    -from {out\([0-9]+\)} -to {out_\(1+1\)_reg}
```

2 Mapped Point(s):

```
Name      r:/WORK/topxor/out1
mapped to  r:/WORK/topxor/out_2_reg
```

Name        r:/WORK/topxor/out4  
mapped to    r:/WORK/topxor/out\_5\_reg

2 Unmapped Point(s):

Name        r:/WORK/topxor/reg  
  
Name        r:/WORK/topxor/clk

Total: 4 (2 Mapped, 2 Unmapped)  
1

---

SEE ALSO

set\_compare\_rules(2)  
report\_unmatched\_points(2)

---

## translate\_instance\_pathname

Translates an instance-based pathname to a Formality design ID or object ID.

---

### SYNTAX

```
string translate_instance_pathname  
[ -type ID_type ] pathname
```

#### Data Types

*ID\_type* string  
*pathname* string

---

### ARGUMENTS

#### -type *ID\_type*

Specifies the object type for *pathname*'s leaf. Use this switch when the leaf portion of the instance-based pathname could resolve to more than one type of design object. Specify one of the following values for *ID\_type*:

- *cell*
- *net*
- *port*
- *pin*

#### *pathname*

Specifies the instance-based pathname of the design object you want to translate. Use the following syntax when supplying a value for *pathname*:

```
[[[container:]/des_lib/design/]inst_1[/ inst_n...]]cell_name  
[[[container:]/des_lib/design/]inst_1[/ inst_n...]]net_name  
[[[container:]/des_lib/design/]inst_1[/ inst_n...]]port_name  
[[[container:]/des_lib/design/]inst_1[/ inst_n...]]pin_name
```

---

### DESCRIPTION

This command translates an instance-based design object pathname into the equivalent Formality *designID* or *objectID*.

You can create objectIDs for cells, nets, ports, and pins. When specifying the instance-based pathname, Formality uses the current container if you do not include the container in the instance *pathname* but do supply design library and design names. If you omit the container, design library, and design, Formality uses the current design.

When translating an object that shares its name with another object of a different type, you must use the `-type` option to supply the object type. Otherwise, Formality resolves the conflict using the following order: cell, port, net, then pin.

---

## EXAMPLES

The following example returns the objectID for the port CC in the current design.

```
fm_shell> translate_instance_pathname -type port CC  
ref:/WORK/CORE/CC
```

---

## SEE ALSO

- `find_cells(2)`
- `find_nets(2)`
- `find_pins(2)`
- `find_ports(2)`

---

## unalias

Removes one or more aliases.

---

### SYNTAX

**unalias**  
*pattern*

#### Data Types

*pattern* string

---

### ARGUMENTS

*pattern*

Removes aliases matching the specified pattern. This argument can be repeated. Each is the name of a specific alias to remove, or a pattern containing the wildcard characters "\*" and "%" that match one or more aliases to be removed.

---

### DESCRIPTION

This command removes aliases created using the **alias** command.

---

### EXAMPLES

This command removes all aliases.

```
fm_shell> unalias *
```

This command removes all aliases beginning with f, and the alias *rt100*.

```
fm_shell> unalias f* rt100
```

---

### SEE ALSO

alias(2)

---

## undo\_edits

Reverts the changes made by edit commands.

---

### SYNTAX

status **undo\_edits**

---

### DESCRIPTION

This command reverts the changes made to the design using edit commands such as the **create\_net** command.

The design is reverted to its state after the last **commit\_edits** command. If no **commit\_edits** commands have been issued, the circuit is reverted back to its state before the edit commands were issued.

Outside of Setup mode, this command only works on edit designs created using the **edit\_design** command.

---

### EXAMPLES

The following example creates a new net in design r:/WORK/mid and reverts the change again.

```
fm_shell (setup)> current_design r:/WORK/mid
fm_shell (setup)> create_net N42
fm_shell (setup)> undo_edits
```

---

### SEE ALSO

[commit\\_edits\(2\)](#)  
[create\\_nets\(2\)](#)  
[current\\_design\(2\)](#)  
[edit\\_design\(2\)](#)

---

## undo\_match

Removes matches between design objects that are matched.

---

### SYNTAX

status **undo\_match**  
[ -all ]

#### Enabled Shell Modes

Match  
Verify

---

### ARGUMENTS

**-all**

Removes matches from all previously matched compare points.

---

### DESCRIPTION

This command removes matches made by the **match** command. Run the **undo\_match** command again to unmatch the next previous batch of matches. Use the **undo\_match -all** command to remove all matches by all previously issued the **match** commands.

After running the **undo\_match** command, Formality is still in the Match mode. To return to the Setup mode, run the **setup** command.

If you used the **set\_user\_match** command to establish matching directives, you must use the **remove\_user\_match** command to remove them. Otherwise, the next **match** or **verify** command will cause the objects to be matched again.

The **undo\_match** command is intended to help you debug matching problems. For example, you can set a compare rule, run **match**, view the results with **report\_matched\_points** and **report\_unmatched\_points** command, and if the compare rule caused some points to be incorrectly matched, run the **undo\_match** command and fix the compare rule.

---

### SEE ALSO

match(2)  
setup(2)  
report\_matched\_points(2)  
report\_unmatched\_points(2)  
set\_user\_match(2)  
remove\_user\_match(2)  
report\_user\_matches(2)  
verify(2)

---

## ungroup

Removes a level of hierarchy.

---

### SYNTAX

```
ungroup  
cell_list | -all  
[-prefix prefix_name]  
[-flatten] [-simple_names]
```

#### Data Types

*cell\_list* string  
*prefix\_name* string

#### Enabled Shell Modes

Setup

---

### ARGUMENTS

#### *cell\_list*

Specifies a list of cells in the current design that are to be ungrouped. The contents of these cells are brought up to the same level as the cells. You must specify either the *cell\_list* or the **-all** option, but not both.

#### **-all**

Indicates that all cells in the current\_design are to be ungrouped. You must specify either *cell\_list* or -all, but not both.

#### **-prefix *prefix\_name***

Specifies the prefix to use in naming ungrouped cells. The default naming style is:

*cell\_being\_ungrouped/old\_cell\_name*{number}

To provide a vestige of the former hierarchy, omit this option when the **-flatten** option is used.

#### **-flatten**

Removes the hierarchy of the specified cell and its subcells recursively until all levels of hierarchy are removed.

#### **-simple\_names**

Uses simple, non-hierarchical names for cells that are ungrouped. Unless this option is used, cells are given default hierarchical names. With this option, cells maintain their original names.



## DESCRIPTION

Removes a single level of hierarchy from the current design by exploding the contents of the specified cell in the current design.

New cell names are created by concatenating *prefix\_name* with original cell names. If the resulting name is not unique, the new unique name is:

*prefix\_name**cellnumber*

If you do not specify a prefix, the default is:

*cell\_being\_ungrouped/old\_cell\_name{number}*

---

## EXAMPLES

This example ungroups a specified list of cells.

```
fm_shell (setup)> ungroup {u1 u2 u3}
```

This example ungroups a specific cell and specifies the prefix to be used.

```
fm_shell (setup)> ungroup {u1} -prefix "U1:"
```

This example completely removes the hierarchy of two cells.

```
fm_shell (setup)> ungroup {u1 u2} -flatten
```

This example completely collapses the hierarchy of the current\_design.

```
fm_shell (setup)> ungroup -all -flatten
```

---

## SEE ALSO

`current_design(2)`

---

## uniquify

Creates unique design names for multiply-instantiated designs in hierarchical designs.

---

### SYNTAX

status **uniquify**  
[ *designID* ]

#### Data Types

*designID* string

#### Enabled Shell Modes

Setup

---

### ARGUMENTS

*designID\_1*

The design for which you want to create unique design name.

---

### DESCRIPTION

This command removes multiply-instantiated hierarchy in a design by creating a unique design for each cell instance. When you enter the command, Formality searches for designs referenced in the hierarchy of the design and generates new, uniquely named designs for all instances that have the same name.

Having unique design names is necessary any time you use a Formality command to specify a particular instance of a multiply instantiated design. For example, when creating a compare point, if the design object you want to use from the implementation design is instantiated several times in the top-level design. Specifying the design name does not differentiate between instances. Before you can create the compare point, you need to create unique design names in the implementation design. If you do not specify the *designID* argument with the command, Formality uses the current design.

---

### EXAMPLES

This example creates unique design names in the top-level design named *impl:/WORK/CORE*.

```
fm_shell (setup)> uniquify  
Uniquifying design 'impl:/WORK/CORE'  
Uniquify of 'impl:/WORK/CORE' completed successfully
```

---

## SEE ALSO

---

## unread\_analysis

The **unread\_analysis** command is used to determine whether any failing compare point is functionally unread. The command updates the verification status of any unread point, and returns 1 (success) if this causes the overall verification to pass.

---

### SYNTAX

```
unread_analysis  
[ -list ref_compare_point_list ]  
[ -level integer ]
```

---

### ARGUMENTS

#### **-list *ref\_compare\_point\_list***

Runs unread analysis on a list of failing reference compare points. If this option is not specified, unread analysis is run on all failing compare points.

#### **-level *integer***

Specifies how deep to look for observability. If a compare point is read by a downstream point, then that point needs to be analyzed to determine whether it is read by its downstream readers, and so forth. This variable determines the depth of this traversal.

---

### DESCRIPTION

**unread\_analysis** determines whether any given failing compare point(s) are unobservable. It does so by unmatching the compare point and verifying whether any downstream points subsequently fail verification. If no downstream points are affected by the unmatched point (i.e., successful verification while the compare point is unmatched), the compare point is declared UNREAD, and marked as such in the database.

If a downstream primary output port or black box input fails verification from an unmatched compare point, then the compare point is considered observable, and marked as READ.

If any other downstream compare points fail verification, they must subsequently be analyzed to determine if they are READ by their fanout. This traversal continues through *-levels* of compare points. If any remaining compare points still fail verification after the traversal has reached this limit, or if the verification of any point is inconclusive, the original point is considered UNKNOWN.

If any downstream compare point is encountered that was an failing point in the original verification, then its verification will continue to fail after the original compare point is unmatched. For this reason, the original point will be declared READ.

**unread\_analysis** will work on all failing points, unless a subset of these points is provided through the *-list* option.

Compare points that are determined to be UNREAD will be marked as such in the database. In particular, such points will no longer show up as failing points. If all failing points are determined to be UNREAD, the Verification Status of the entire verification will be successful, and the **unread\_analysis** command will return 1. Otherwise, there are still failing points and the command will return 0.

---

## EXAMPLE

This example shows the output of unread analysis for a READ compare point. In case of a READ or UNKNOWN result, Formality will provide the path of compare points it looked at.

```
fm_shell> unread_analysis
```

```
Analyzing unread compare point: r:/WORK/test/DFF1
```

```
READ r:/WORK/test/DFF1
```

```
Path:
```

1. r:/WORK/test/DFF1
2. r:/WORK/test/DFF2
3. r:/WORK/test/DFF4
4. r:/WORK/test/DFF7
5. r:/WORK/test/c

```
fm_shell>
```

This example shows the output of unread analysis for an UNREAD compare point. You can run **report\_status** afterward to see the effect on the overall verification status.

```
fm_shell> unread_analysis
```

```
Analyzing unread compare point: r:/WORK/test/DFF9
```

```
UNREAD r:/WORK/test/DFF9
```

```
fm_shell>
```

---

## SEE ALSO

verify  
report\_status

---

## unsetenv

Removes a system environment variable.

---

### SYNTAX

string **getenv**  
*variable\_name*

#### Data Types

*variable\_name*    string

---

### ARGUMENTS

*variable\_name*

Specifies the name of the environment variable to be unset.

---

### DESCRIPTION

The **unsetenv** command searches the system environment for the specified *variable\_name* and removes variable from the environment. If the variable is not defined in the environment, the command returns a Tcl error. The command is catchable.

Environment variables are stored in the **env** Tcl array variable. The **unsetenv**, commands is a convenience function to interact with this array. It is equivalent to 'unset ::env(*variable\_name*)'

The application you are running inherited the initial values for environment variables from its parent process (that is, the shell from which you invoked the application). If you unset the variable using the **unsetenv** command, you remove the variable value in the application and in any new child processes you initiate from the application using the **exec** command. However, the variable is still set in the parent process.

See the **set** and **unset** commands for information about working with non-environment variables.

---

### EXAMPLES

In the following example, **unsetenv** remove the DISPLAY variable from the environment:

```
prompt> getenv DISPLAY
host:0
prompt> unsetenv DISPLAY
prompt> getenv DISPLAY
Error: can't read "::env(DISPLAY)": no such variable
      Use error_info for more info. (CMD-013)
```

## SEE ALSO

catch(2)  
exec(2)  
printenv(2)  
set(2)  
unset(2)  
setenv(2)  
getenv(2)

---

## unsuppress\_message

Enables printing of one or more suppressed informational or suppressed warning messages.

---

### SYNTAX

string **unsuppress\_message** [*messages*]

list *messages*

---

### ARGUMENTS

*messages*

A list of messages to enable.

---

### DESCRIPTION

The **unsuppress\_message** command provides a mechanism to re-enable the printing of messages which have been suppressed using **suppress\_message**. You can suppress only informational and warning messages, so the **unsuppress\_message** command is only useful for informational and warning messages. The result of **unsuppress\_message** is always the empty string.

You can suppress a given message more than once. So, you must unsuppress a message as many times as it was suppressed in order to enable it. The **print\_suppressed\_messages** command displays currently suppressed messages.

---

### EXAMPLES

When the argument to the **unalias** command does not match any existing aliases, the CMD-029 warning message displays. This example shows how to re-enable the suppressed CMD-029 message. Assume that there are no aliases beginning with 'q'.

```
prompt> unalias q*
prompt> unsuppress_message CMD-029
prompt> unalias q*
Warning: no aliases matched 'q*' (CMD-029)
```

---

### SEE ALSO

print\_suppressed\_messages(2)  
suppress\_message(2)



---

## vcpl\_start\_gui

After **compare\_lp** command has finished, use this command to start the VCLP GUI to debug any static low power comparison violation.

---

### SYNTAX

status **vcpl\_start\_gui**

---

### DESCRIPTION

When using the Static Low Power Compare functionality in Formality (see **verification\_static\_low\_power\_compare**) after the **compare\_lp** command has finished, use this command to start the VCLP GUI to debug any violations. The VCLP GUI session will exit when the Formality run exits.

---

### EXAMPLES

```
fm_shell (verify)> vcpl_start_gui
```

---

### SEE ALSO

compare\_lp(2)  
fP(2)  
verification\_static\_low\_power\_compare(3)

---

## verify

Verifies the functional equivalence between the two specified designs or two comparable design objects.

---

### SYNTAX

```
status verify
  [ designID_1 designID_2 ] |
  [[ -inverted ]
   [ -type ID_type ]
   objectID_1 objectID_2 ] |
  [[ -constant0 | -constant1 ] [ -type ID_type ] objectID ] |
  [[ -type ID_type ] objectID [ -constant0 | -constant1 ] ] |
  [ -probe ] |
  [ -restart | -incremental ]
  [ -level integer ]
```

#### Data Types

```
ID_type string
objectID string
ID_type string
integer integer
```

---

### ARGUMENTS

#### *designID\_1*

Specifies the reference design. If you do not specify a design, Formality uses the current reference design.

#### *designID\_2*

Specifies the implementation design. If you do not specify a design, Formality uses the current implementation design.

#### **-inverted**

Verifies the inverse-equivalence of the two specified objects.

#### **-type *ID\_type***

Specifies an object type. You must use this option if the leaf portions of the instance-based pathnames of *objectID\_1* and *objectID\_2* resolve to more than one type of design object. Specify one of the following values for the *ID\_type* argument:

- **cell**
- **net**

- **port**

- **pin**

***objectID\_1***

Specifies a design object that is comparable to *objectID\_2* and is of the same type as *objectID\_2*.

***objectID\_2***

Specifies a design object that is comparable to *objectID\_1* and is of the same type as *objectID\_1*.

**-constant0**

Specifies a constant 0. This is used to check if the objectIDs are constant 0. If this switch is specified on the command line before the object ID, then the constant is considered the reference. If this switch is specified on the command line after the Object ID, then the constant is considered the implementation.

**-constant1**

Specifies a constant 1. This is used to check if the objectIDs are constant 1. If this switch is specified on the command line before the Object ID, then the constant is considered the reference. If this switch is specified on the command line after the Object ID, then the constant is considered the implementation.

**-probe**

Verifies only probes points. This is used to verify probe net pairs set using the **set\_probe\_points** command. This debug option is allowed only when main verification is partially or fully done and shell is in the Verify mode. Probe verification do not alter or destroy the current match or verify results.

**-restart**

Discards any verification results from previous verify commands; verify all compare points. Opposite of **-incremental**. The default behavior is **-incremental**, which indicates to Formality so save partial results from successive verifications.

**-incremental**

Opposite of **-restart**. The default behavior is **-incremental**, which indicates to preserve any results from previous verify commands and to verify only unverified points. If matching changes have been made since the last verify command, affected compare points will be moved to the unverified state before being verified. If verification effort level has been increased also verify compare points aborted due to complexity.

**-level *integer***

Assumes functional boundaries at blocks at or above this level only have been preserved, where top is level 0. The specified integer must be greater than or equal to zero. The default is no limit. If you know that the boundaries of blocks below a certain level have different functions in the reference and implementation designs, you can use this switch to improve verification performance. For example, if boundary optimization has occurred.

---

## DESCRIPTION

This command proves or disproves design equivalence using the current implementation and reference designs, the specified implementation and reference designs, a specific compare point or user defined probe pairs.

In library\_verification mode this command invokes verification on all the library cells that were selected for verification.

When you specify this command, Formality performs verification and reports its success. If you interrupt verification (Ctrl+C), Formality retains partial verification results. You can report these partial verification results.

Formality bases verification on the verification mode and applies all currently set environment parameters as well as any currently set design-specific parameters.

When verifying designs, Formality determines whether the designs are comparable and attempts to prove their functional equivalence. If all compare points prove equal when verifying two designs, Formality reports the designs as functionally equivalent (verification passes). However, should any compare point fail verification or abort during verification, Formality reports the two designs as functionally unequivalent (verification fails).

You can specify the implementation and reference designs, or let Formality use the current implementation and reference designs. Not supplying any design IDs causes Formality to use the current implementation and reference design for verification. Supplying two designIDs causes Formality to establish the first design as the current reference design and the second design as the current implementation design.

You must have successfully run the **set\_top** command on the reference and implementation designs (or the top-level designs within which they are contained) before performing verification.

When verifying compare points, Formality determines whether the design objects constituting the compare points are comparable. Verification success or failure hinges on that compare point only.

If you are verifying a single compare point, you must supply two objectIDs that are of the same type (cell, port, or net). If more than one objectID exists in either design that shares the same name but is of a different type, you must use the **-type** option to differentiate the objects. The objects can be in different designs.

Pin-to-pin single compare point verification is only allowed on black box pins.

You can use the **-probe** option to verify debug probe pairs set using the **set\_probe\_points** command.

If verification fails, you can view a list of failing compare points by using the **report\_failing\_points** command. You can then direct Formality to use this list to diagnose the differences between the implementation and reference designs.

---

## SEE ALSO

report\_unverified\_points(2)  
report\_aborted\_points(2)  
report\_failing\_points(2)  
report\_passing\_points(2)  
set\_probe\_points(2)  
report\_probe\_status(2)  
write\_hierarchical\_verification\_script(2)

---

## verify\_edits

Copies the edited designs back to the original designs and performs a verification.

---

### SYNTAX

```
status verify_edits  
[ -include_failures ]
```

#### Enabled Shell Modes

Setup  
Match  
Verify

---

### DESCRIPTION

This command copies all the edited designs created by the **edit\_design** command back to the original designs, and then verifies all compare points affected by the edits.

If the **-include\_failures** option is used, the verification will also include all failing points. This is useful if your edits do not address all failures. This way those points that are not addressed by the edits will continue to fail.

This command changes the set of points targeted for verification. You can use **report\_verify\_points** to inspect the set, or **remove\_verify\_points** to prune it in preparation for a new verification.

Use the command **apply\_edits** to copy the edited designs back to the original designs without doing a verification. This can only be done in setup mode, but **verify\_edits** can be done in any mode.

---

### EXAMPLES

Edit a design and verify the changes while in verify mode:

```
fm_shell (verify)> edit_design i:/WORK/bot  
fm_shell (verify)> create_net ECO_NET_1  
fm_shell (verify)> verify_edits
```

---

### SEE ALSO

**apply\_edits(2)**  
**create\_net(2)**  
**edit\_designs(2)**  
**remove\_verify\_points(2)**  
**report\_verify\_points(2)**

---

## view\_named\_objects

Loads a set of named objects for GUI display.

---

### SYNTAX

```
view_named_objects  
[ -file file_name ]  
objectID_list
```

#### Data Types

```
file_name string  
objectID_list string
```

---

### ENABLED SHELL MODES

Setup

---

### ARGUMENTS

#### -file *file\_name*

Reads in a list of objectIDs via specified file, one ID per line. Tcl glob-style matching supported.

#### *objectID\_list*

Specifies a list of objectIDs, bounded by {} if more than 1 entry. Tcl glob-style matching supported.

---

### DESCRIPTION

Use this command to send a list of objectIDs to the GUI for display, either through the argument *objectID\_list* or the *-file* option. Note these 2 methods cannot be mixed in a single command line. Also, the command must work when the GUI is active. In shell mode it silently returns without action.

The command results in a pop-up a window showing the list of objects found, so users can choose either cone or design schematics to view, via right-click menu items.

---

### EXAMPLES

```
fm_shell (setup)> view_named_objects obj_ID  
1  
fm_shell (setup)> view_named_objects {obj_ID1 obj_ID2* obj_ID3?}
```

```
1
fm_shell (setup)> view_named_objects -file objectID_file
1
```

where the objectID\_file in last example looks like:

```
obj_ID1
obj_ID2*
obj_ID3?
```

---

## SEE ALSO

---

## which

Locates a file and displays its pathname.

---

### SYNTAX

**which**  
*filename\_list*

#### Data Types

*filename\_list* string

---

### ARGUMENTS

*filename\_list*

Specifies a list of files to locate.

---

### DESCRIPTION

This command displays the location of the specified files. This command uses the **search\_path** variable to find the location of the files. This command can be a useful prelude to the **read\_db** or **link\_design** commands, because it shows how these commands expand filenames. The **which** command can be used to verify that a file exists in the system.

If an absolute pathname is given, the command searches for the file in the given path and returns the full pathname of the file.

---

### EXAMPLES

These examples are based on the following search\_path.

```
fm_shell> set search_path "/u/foo /u/foo/test"
```

This command searches for the file name foo1 in the search\_path.

```
fm_shell> which mydesign
/u/mypath/mydesign
```



---

## SEE ALSO

`search_path(3)`

---

## write\_app\_var

Writes a script to set the current variable values.

---

### SYNTAX

```
string write_app_var  
-output file  
[-all | -only_changed_vars]  
[pattern]
```

#### Data Types

<i>file</i>	string
<i>pattern</i>	string

---

### ARGUMENTS

#### -output *file*

Specifies the file to which to write the script.

#### -all

Writes the default values in addition to the current values of the variables.

#### -only\_changed\_vars

Writes only the changed variables. This is the default when no options are specified.

#### *pattern*

Writes the variables that match the specified *pattern*. The default is "".

---

### DESCRIPTION

The **write\_app\_var** command generates a Tcl script to set all application variables to their current values. By default, variables set to their default values are not included in the script. You can force the default values to be included by specifying the **-all** option.

---

### EXAMPLES

The following is an example of the **write\_app\_var** command:

```
prompt> write_app_var -output sh_settings.tcl sh*
```

## SEE ALSO

get\_app\_var(2)  
report\_app\_var(2)  
set\_app\_var(2)

---

## write\_container

Saves the information in the current or specified container to a file.

---

### SYNTAX

#### **write\_container**

```
[ -container container_name | -r | -i ]  
[ -quiet ]  
[ -replace ]  
[-pre_set_top]  
filename
```

#### **Data Types**

*container\_name* string  
*filename* string

---

### ARGUMENTS

#### **-container *containerID***

Specifies the container to save. For information about how to specify a container ID, see the *Formality User Guide*.

#### **-r**

Saves the default reference container.

#### **-i**

Saves the default implementation container.

#### **-replace**

Replaces an existing file.

#### **-quiet**

Suppresses information and warning messages when writing to read-only containers.

#### **-pre\_set\_top**

Writes a container before a successful **set\_top** command.

#### ***filename***

Specifies the file in which the tool saves container information.

---

### DESCRIPTION

This command saves a container to a single file.

When you write a container to a file, you save only the design data and not the setup parameters and verification results. The tool creates a file with the `.fsc` extension.

After you save a container, you can read it back in by using the **read\_container** command.

When you use the `-pre_set_top` option, the container is written to a file before successful execution of the **set\_top** command and stores intermediate data. These containers are not marked as read only.

Saved containers are marked as read-only when they are read into a session. All operations that would change the container contents are disallowed. For more information, see the **read\_container** command man page. Therefore, you should fully prepare the containers for verification, including setting the top-level design before executing the **write\_container** command.

The **write\_container** command returns one of the following:

- 0 to indicate failure
- 1 to indicate success

---

## EXAMPLES

The following example saves the design data for container *impl* into the file *impl\_container* in the current working directory:

```
fm_shell> write_container -container impl impl_container
Info: Wrote file 'impl_container.fsc'.
1
fm_shell>
```

---

## SEE ALSO

`read_container(2)`

---

## write\_eco\_regions

Writes the ECO region files.

---

### SYNTAX

```
status write_eco_regions  
[ -replace ]  
[ name ]
```

#### Data Types

*name* string

#### Enabled Shell Modes

Match  
Verify

---

### LICENSE

This command is available when the "Formality-LogicECO" license key is used.

---

### ARGUMENTS

#### -replace

Overwrites output files if they already exist.

#### *name*

If not specified, the generated output files follow the naming convention set via match\_eco\_regions. If the specified name is a valid directory then the output files will be saved inside the specified directory. Otherwise the specified name will be used as the basis for naming all generated output files.

---

### DESCRIPTION

This command can only be issued in match or verify mode. You must first issue the match\_eco\_regions command. The write\_eco\_regions command will then write the ECO region files. The group file contains the identified ECO regions and their boundaries in the ECO reference design. The data file contains the ECO region boundary matching information between ECO reference and original implementation.

---

## EXAMPLES

The following example will write the ECO region files.

```
fm_shell (match)> match_eco_regions  
fm_shell (match)> write_eco_regions -replace
```

---

## SEE ALSO

- match\_eco\_regions
- create\_eco\_patch
- set\_orig\_reference
- set\_orig\_implementation
- set\_eco\_reference
- set\_eco\_implementation

---

## write\_edits

Writes the recorded edit commands to the specified file.

---

### SYNTAX

```
write_edits  
  filename  
  [ -replace ]
```

#### Data Types

*filename* string

#### Enabled Shell Modes

Setup  
Match  
Verify

---

### ARGUMENTS

#### *filename*

Specifies the name of the Tcl script file to write.

#### **-replace**

Replaces an existing file.

---

### DESCRIPTION

This command writes the recorded edit commands (such as **create\_net** and **disconnect\_net**) to a Tcl file, which can then be used in Formality (R), Design Compiler (R), IC Compiler (TM), IC Compiler II (TM), or Fusion Compiler (TM) to replicate the edits.

Use the **record\_edits** command to enable and disable recording.

All edit commands are written to a file except those that occurred while recording was turned off and ones that are reverted using the **undo\_edits** command.

The Tcl script generated by this command contains sections with setup for each of the tools in which you can read in the script. There are sections for Formality (fm\_shell), Design Compiler (dc\_shell), IC Compiler (icc\_shell), IC Compiler II (icc2\_shell), and Fusion Compiler (fc\_shell).

The setup consists of Tcl variables, which are commented out by default. Uncomment them to change the setup. Just above each Tcl variable, there are comments describing their use.

If you do not write out the recorded edits, Formality will upon exit write them to a file named *default\_edits.tcl*.



---

## EXAMPLES

Write the edit script to disk:

```
fm_shell (setup)> write_edits edits.tcl
```

Read the edit script back into Formality:

```
fm_shell (setup)> source edits.tcl
```

---

## SEE ALSO

[create\\_net\(2\)](#)  
[disconnect\\_net\(2\)](#)  
[record\\_edits\(2\)](#)  
[remove\\_net\(2\)](#)  
[report\\_edits\(2\)](#)

---

## write\_functional\_matches

Writes functional matches as user-defined matches.

---

### SYNTAX

**write\_functional\_matches**  
[-filename]  
*file*

#### Data Types

*file* string

#### Enabled Shell Modes

Match Verify

---

### ARGUMENTS

#### -filename

Required argument for a file.

#### *file*

The output file to generate the user matches from functional matches.

---

### DESCRIPTION

This command writes the matches made by signature analysis (functional matches) as `set_user_matches` in the specified file.

The **write\_functional\_matches** command generates one line of output for each functional match. The line includes `set_user_match`, type, polarity, ref-name and impl-name.

---

### EXAMPLES

The following example for `write_functional_matches`.

```
fm_shell (match)> write_functional_matches -f user_matches
fm_shell (match)>
```

An example of the file "user\_matches" is as follows:

```
set_user_match -type cell -inverted \
RTL:/WORK/rs_j0b1regs/j0b1_10_change_reg/updata_i_reg[0] \
i:/WORK/rs_j0b1regs_f_p/j0b1_10_change_reg/updata_i_ff_b0
set_user_match -type cell -noninverted \
RTL:/WORK/rs_j0b1regs/j0b1_10_change_reg/updata_i_reg[1] \
```

i:/WORK/rs\_j0b1regs\_f\_p/j0b1\_10\_change\_reg\_updata\_i\_ff\_b1

---

## write\_hierarchical\_verification\_script

Writes a Tcl script that performs hierarchical verification on the current reference and implementation designs.

---

### SYNTAX

```
status write_hierarchical_verification_script
  [-replace]
  [-noconstant]
  [-noequivalence]
  [-match type]
  [-save_mode mode]
  [-save_directory pathname]
  [-save_file_limit integer]
  [-save_time_limit integer]
  [-level integer]
  [-path instance-specific-pathname(s)]
  [-block instance-specific-pathname(s)]
  [-dont_resolve_failures]
  [-top_level_only]
  filename
```

#### Data Types

```
type string
mode string
pathname string
integer integer
filename string
```

---

### ARGUMENTS

#### -replace

Replaces the existing script file.

#### -noconstant

Does not capture constant constraints at the boundary of hierarchical blocks verified in isolation.

#### -noequivalence

Does not capture equivalence constraints at the boundary of hierarchical blocks verified in isolation.

#### -match *type*

Writes matching commands for all objects, when *all* is specified, or only for objects matched by means other than name, when *auto* is specified. Specify one of the following for *type*:

- auto (default)
- all

**-save\_mode *mode***

Specifies the verification status for which a session file will be saved. In "auto" mode, Formality will save session files for inconclusive verifications only. If the "-dont\_resolve\_failures" switch is also specified Formality will save session files for failing and inconclusive verifications. Specify one of the following for *mode*:

- auto (default)
- not\_passed
- failed
- inconclusive

**-save\_directory *pathname***

Saves the session files to the directory named *pathname*. The default is ".".

**-save\_file\_limit *integer***

Specifies the maximum number of session files to save. The value must be greater than or equal to zero. The default is 1.

**-save\_time\_limit *integer***

Saves session files using at least the specified number of cpu seconds. The specified integer must be greater than or equal to zero. Default: 0.

**-level *integer***

Creates black boxes of the blocks only at or above this level, where top is level 0. This option also separately verifies the blocks unless used with the **-top\_level\_only** option. The specified integer must be greater than or equal to zero.

**-block *instance-specific-pathname(s)***

Creates black boxes of the specified blocks. This option also separately verifies the blocks unless used with the **-top\_level\_only** option.

**-path *instance-specific-pathname(s)***

Creates black boxes of the blocks along the specified instance specific path name. This option also separately verifies the blocks unless used with the **-top\_level\_only** option.

**-top\_level\_only**

Verifies only the top-level design with all blocks black boxed, except when used with the **-level**, **-block**, or **-path** options, in which case only the specified blocks are black boxed.

**-dont\_resolve\_failures**

Does not attempt to resolve failing lower-level hierarchical blocks.

***filename***

Specifies the script file name.

## DESCRIPTION

This command writes a Tcl script that you can source to perform a hierarchical (block-by-block) verification on the current reference and implementation designs, where matched blocks are explicitly verified in isolation from containing blocks and without considering the function of contained (underlying) matched blocks. By default, the tool performs hierarchical verification for all matched blocks. You can specify which blocks to perform hierarchical verification on, by using the **-level**, **-block**, **-path** options.

The generated Tcl script performs as follows for each specified matched block of the currently defined top-level reference and implementation designs:

- Black-boxes specified matched lower level blocks.
- Removes unused compare points.
- Optionally captures matching information.
- Optionally captures constants at block boundaries.
- Optionally captures equivalences at block boundaries.
- Verifies the target block as a top-level design.
- Saves the Formality session for failing/inconclusive verifications.

Each block is verified in isolation, but explicit setup commands are generated to capture top-level context. By default, the tool attempts to resolve failing hierarchical blocks by reverifying them as part of their parent block. You can turn off this behavior by using the **-dont\_resolve\_failures** option.

The script records the SUCCEEDED, FAILED, or INCONCLUSIVE results for each block in a text file named *fm\_script.log*. When the script terminates, the tool concatenates this file to the transcript.

The tool saves session files in a directory of your choice. You can control exactly which session files are saved by using the **-save\_mode** option.

If either valid matching or verification results, or both, are available when the command is issued, the tool reuses them. Otherwise, it creates them before generating the script.

---

## EXAMPLES

The following example writes a hierarchical verification script to a file named *my\_script.tcl* in the current directory, replacing the existing file if it exists, and including all matching commands for all object types.

```
fm_shell> write_hi -rep my_script -match all
Status: Checking designs...
Status: Building verification models...
Status: Matching...
```

```
*****Matching Results*****
144 Compare points matched by name
24 Compare points matched by signature analysis
0 Compare points matched by topology
0(0) Unmatched reference(implementation) compare points
0(0) Unmatched reference(implementation) primary inputs, black-box outputs
*****
```

Status: Writing hierarchical verification script to file my\_script.tcl...

---

## SEE ALSO

verify(2)  
set\_parameter(2)

---

## write\_library\_debug\_scripts

Debugs failing cells from library verification mode in the Formality environment.

---

### SYNTAX

**write\_library\_debug\_scripts**  
[ -dir *directory name* ]

#### Data Types

*directory name* string

---

### ARGUMENTS

**-dir *directory name***

Specifies the name of directory in which to save the Tcl scripts. Can be absolute or relative path. The default directory is \$(pwd)/DEBUG.

---

### DESCRIPTION

This command debugs a library cell that has failed/aborted verification in the standard Formality flow. The command generates Tcl scripts for failing cells. These run scripts can be invoked in a different Formality session and debugged using standard Formality diagnose commands.

---

### EXAMPLES

```
fm_shell> write_library_debug_scripts -dir ./my_debug
Writing tcl script "./my_debug/test_my_failing_cell.tcl"
Generated "./my_debug/test_<cell_name>.tcl" scripts for all failing cells
Run 'formality -f <tcl_file>' to debug failing cells
```

To debug my\_failing\_cell run:

```
<unix_shell>% formality -f ./my_debug/test_my_failing_cell.tcl
```

---

### SEE ALSO



```
verify(2)
select_cell_list(2)
report_cell_list(2)
```

---

## write\_power\_model

Creates a Formality power model for a container's top design and saves it to a file.

---

### SYNTAX

```
status write_power_model  
[ -container container_name | -r | -i ]  
[ -replace ]  
filename
```

#### Data Types

```
container_name string  
filename string
```

---

### ARGUMENTS

**-container** *containerID*

Specifies the container.

**-r**

Specifies the default reference container.

**-i**

Specifies the default implementation container.

**-replace**

Replaces an existing file.

***filename***

Specifies the file in which the tool saves the top level power model.

---

### DESCRIPTION

The **write\_power\_model** command creates and saves the power model for the top design to a file. You can read in the the power model using the **read\_power\_model** command.

---

## EXAMPLES

The following example creates and saves the power model for the top design in the container *impl* into the file *add2.fpm* in the current working directory.

```
fm_shell> write_power_model -container impl add2  
Info: Created and wrote model for top design 'add2'.  
1
```

---

## SEE ALSO

`read_power_model(2)`

---

## write\_register\_mapping

Create and populate register mapping information file

---

### SYNTAX

```
integer write_register_mapping  
  [-rtlname]  
  [-bbpin]  
  [-bbox_input]  
  [-bbox_output]  
  [-bbox_inout]  
  [-port]  
  [-port_input]  
  [-port_output]  
  [-port_inout]  
  [-unmatched_ref]  
  [-siloti]  
  [-prime_power]  
  [-replace]  
  file_name
```

#### Data Types

*file\_name* string

#### Enabled Shell Modes

Match Verify

---

### ARGUMENTS

#### -rtlname

Enable RTL name instead of inferred register name

#### -replace

Overwrites the existing file

#### -bbpin

Include blackbox pin mapping in output report

#### -bbox\_input

Include blackbox input pin mapping in output

#### -bbox\_output

Include blackbox output pin mapping in output

#### -bbox\_inout

Include blackbox inout pin mapping in output

#### -port

Include port mapping in output report

**-port\_input**

Include input port mapping in output

**-port\_output**

Include output port mapping in output

**-port\_inout**

Include inout port mapping in output

**-unmatched\_ref**

Include unmatched reference points in output

**-siloti**

Specify Siloti format for register mapping file

**-prime\_power**

Specify SAIF format for register mapping file

**file\_name**

Output File Name

---

## DESCRIPTION

The **write\_register\_mapping** command generates a report that maps registers, and optionally, ports and black-box pins in the reference design to the matching elements in the implementation design.

If the reference design is a RTL, the report is based on the original RTL names as the inferred register names might change because of SVF guidance related to register optimizations, such as merge, duplication, inv\_push, constant optimization, or change\_name. This makes it difficult to track inferred register names in the post SVF reference container. Therefore, this command generates the report by mapping the original register names to the matching registers in the implementation design.

The **-rtlname** switch enables Formality front end reader inferred register name to be replaced with RTL name. This is applicable to both reference and implementation container inferred register names.

The **-bbpin** switch enables including a list of all mapped black-box pins between the reference and implementation designs in the output report.

The **-bboxes\_input** switch enables including a list of all mapped black-box input pins between the reference and implementation designs in the output report.

The **-bboxes\_output** switch enables including a list of all mapped black-box output pins between the reference and implementation designs in the output report.

The **-bboxes\_inout** switch enables including a list of all mapped black-box inout pins between the reference and implementation designs in the output report.

The **-port** switch enables including a list of all mapped ports between the reference and implementation designs in the output report.

The **-port\_input** switch enables including a list of all mapped input ports between the reference and implementation designs in the output report.

The **-port\_output** switch enables including a list of all mapped output ports between the reference and implementation designs in the output report.

The **-port\_inout** switch enables including a list of all mapped inout ports between the reference and implementation designs in the

output report.

The **-unmatched\_ref** switch enables including a list of all unmatched reference points in the output report.

The **-siloti** switch specifies Siloti format for output register mapping file.

The **-prime\_power** switch specifies SAIF format for output register mapping file.

---

## EXAMPLES

The following command generates the report by mapping the original RTL registers names that are constant, optimized, or matched with the register names in the implementation design.

```
prompt> write_register_mapping Map.txt
```

Here are sample of what's written out for various optimizations:

Below mapping shows RTL *reg o1* inferred *o1\_reg* mapped to netlist libcell *o1\_reg* having functionally read *Q* and *QN* driver pins. Match polarity is positive for *Q* pin and negative for *QN*.

```
oref pos u1/o1_reg
impl pos u1/o1_reg/Q
impl neg u1/o1_reg/QN
```

Below mapping shows above scenario with *-rtlname* switch enabled.

```
oref pos u1/o1
impl pos u1/o1_reg/Q
impl neg u1/o1_reg/QN
```

Below mapping shows unaltered instantiated tech libcell *inst\_FD1* of tech library cell. *inst\_FD1/QN* is missing as its functionally unread.

```
oref pos inst_FD1/Q
impl pos inst_FD1/Q
```

Below mapping shows constant register optimization: *P\_ref* is const0 optimized and *R\_ref* is const1 optimized.

```
oref pos mid/bot/P_reg
impl c=0

oref pos mid/bot/R_reg
impl c=1
```

Below mapping shows register merge optimization: *o1\_reg* and *o2\_reg* are merged to *o1\_reg*. *Q* and *QN* both pins are functionally read points.

```
oref pos u3/o2_reg
impl pos u3/o1_reg/Q
impl neg u3/o1_reg/QN

oref pos u3/o1_reg
impl pos u3/o1_reg/Q
impl neg u3/o1_reg/QN
```

Below mapping shows register duplication along with inv push:

```
oref pos mid/bot/R_reg
impl pos mid/bot/R1_reg/Q
impl neg mid/bot/R2_reg/Q
impl pos mid/bot/R2_reg/QN
```

Below mapping shows banked registers of two registers inside mapping along with change name guidance:

```
oref pos mid/bot/q_reg[0]
impl pos mid/bot/q_reg_1_0_/Q0
```

```
oref pos mid/bot/q_reg[1]
impl pos mid/bot/q_reg_1_0_/Q1

oref pos mid/bot/q_reg[2]
impl pos mid/bot/q_reg_3_2_/Q0

oref pos mid/bot/q_reg[3]
impl pos mid/bot/q_reg_3_2_/Q1
```

Below mapping shows 1:N user matching for instantiated libcells:

```
oref pos FLOP2_reg/Q
oref neg FLOP2_reg/QN
impl pos FLOP2_reg/Q
impl neg FLOP2_reg/QN
impl pos FLOP3_reg/Q
impl neg FLOP3_reg/QN
```

Below mapping shows retention register mapping post change name guidance. For *data\_reg\_0\_/QN* is missing as its unread.

```
oref pos fr2/regout_reg[3]
impl pos fr2_regout_reg_3_/Q
impl neg fr2_regout_reg_3_/QN

oref pos data_reg_0_/Q
impl pos data_reg_0_/Q
```

Below mapping shows *g1/q* having different polarity path case:

```
oref ? g1/q
oref neg g1/qn
impl ? g1/q
impl neg g1/qn
```

Below mapping shows unsupported retimed registers:

```
# The following mapping is not supported
# oref pos u_fcpu/fm_ret_fwmc_1_1_158/R_17725
# impl pos fm_ret_fwmc_1_1_158/R_17725
```

Below mapping shows a list of black-box pins (-bbpin) and ports (-port):

```
#
# Blackbox Pins
#
oref pos m1/bb1/in1
impl pos m1/bb1/in1

oref pos m1/bb1/in2
impl pos m1/bb1/in2

#
# Ports
#
oref pos in1
impl pos in1

oref pos out
impl pos out

oref pos q
impl pos q
```

Below mapping shows a list of registers with -siloti option:

```
#
# Registers
#
u1_reg.Q ==> u1

u1_reg.QN ~> u1

u2_reg.Q ==> u2
```

```
u2_reg.QN ~> u2
```

Below mapping shows a list of black-box output pins (-bbox\_output) and input ports (-port\_input) with -siloti option:

```
#
# Blackbox Pins
#
ram16x2.Q[0] => uram16x2.Q[0]

ram16x2.Q[1] => uram16x2.Q[1]

#
# Ports
#
clk_t => clk_t

rst => rst

sel1 => sel1

sel2 => sel2
```

Below mapping shows a list of registers with -prime\_power option:

```
#
# Registers
#
set_rtl_to_gate_name -rtl ra_reg/Q -gate ra_reg/Q
set_rtl_to_gate_name -rtl ra_reg/Q -gate ra_reg/SO
set_rtl_to_gate_name -rtl rb -gate rb_reg/Q
set_rtl_to_gate_name -rtl rb -gate rb_reg/SO
set_rtl_to_gate_name -rtl rd[0] -gate rd_reg_0_/Q
set_rtl_to_gate_name -rtl rd[0] -gate rd_reg_0_/SO
```

---

## SEE ALSO

```
report_matched_points(2)
report_unmatched_points(2)
```