

RV-10

N720AK

Pilot's Operating Handbook

Revision 1.0

Insert aircraft photo here

`images/aircraft.jpg`

Constructed by:
Sam Ritchie
Serial number 41649
Construction: 2015 - 2025

Table of Contents

1	Introduction	5
2	General	6
2.1	Introduction	6
2.2	Exterior Dimensions	6
2.3	Interior Dimensions	6
2.4	General Specifications	6
2.5	Performance Specifications	7
2.6	Engine	7
2.7	Propeller	8
2.8	Fuel	8
2.9	Oil	8
2.10	Maximum Weights	8
2.11	Baggage Space	9
2.12	Specific Loadings	9
3	Operating Limitations	10
3.1	General	10
3.2	Airspeed Limitations	10
3.3	Power Plant Limitations	10
3.4	Power Plant EFIS Markings	11
3.5	Weight Limits	11
3.6	Center of Gravity Limits	12
3.7	Flight Maneuvering Load Factors	12
3.8	Types of Operations	12
3.9	Fuel Limitations	12
3.10	Placards	12
4	Additional Engine Information	13
4.1	General	13
5	Emergency Procedures	14
5.1	Engine Failures	14
5.2	Forced Landings	14
5.3	Fires	16
5.4	Icing	17
5.5	Electrical / Oil Malfunctions	18
5.6	Emergency Operation In Clouds	19
6	Abnormal Procedures	21
6.1	Takeoff And Climb	21
6.2	Landing	21
7	Normal Procedures	23
7.1	Preflight	23
7.2	In Flight	25
7.3	Postflight	27
8	Performance	28

8.1 Stall and Approach Speeds	28
8.2 Takeoff Performance	28
8.3 Climb Performance	28
8.4 Cruise Performance	28
8.5 Landing Performance	28
9 Weight and Balance	29
9.1 Airplane Weighing Procedure	29
9.2 Empty Weight and Balance Data	29
9.3 Allowable Weight and Balance Envelope	29
9.4 Sample Weight and Balance Calculation	29
10 System Descriptions	30
10.1 The Airplane	30
10.2 Engine and Components	30
10.3 Propeller	30
10.4 Landing Gear	30
10.5 Brake System	30
10.6 Flight Control System	30
10.7 Fuel System	30
10.8 Electrical System	30
10.9 Pitot-Static System	30
10.10 Instrument Panel	30
10.11 Heating, Ventilation and Defrosting	30
10.12 Cabin Features	30
10.13 Baggage Area	30
10.14 Exterior Lighting	30
11 Handling, Servicing and Maintenance	31
11.1 General	31
11.2 Ground Handling	31
11.3 Engine Air Filter	31
11.4 Brake Service	31
11.5 Landing Gear Service	31
11.6 Propeller Service	31
11.7 Oil System Service	32
11.8 Fuel System	32
11.9 Battery Service	32
11.10 Lubrication	32

1 Introduction

This Pilot's Operating Handbook contains the information necessary for the safe and efficient operation of the RV-10 aircraft N720AK.

This handbook is divided into sections for quick reference:

1. **General** - Aircraft specifications and descriptive data
2. **Limitations** - Operating limitations, placards, and markings
3. **Emergency Procedures** - Procedures for handling emergencies
4. **Normal Procedures** - Normal operating procedures
5. **Checklists** - Abbreviated checklists for normal and emergency operations
6. **Performance** - Performance charts and data
7. **Weight and Balance** - Weight and balance data and calculations
8. **System Descriptions** - Description of aircraft systems
9. **Handling, Servicing, and Maintenance** - Ground handling, servicing, and maintenance information

2 General

2.1 Introduction

The RV-10 is a four-place, single-engine aircraft powered by a [ENGINE MODEL] [CYLINDER COUNT]-cylinder reciprocating engine turning a [PROP TYPE] propeller. The aircraft is primarily constructed of alclad aluminum using flush rivets to the maximum extent possible.

2.2 Exterior Dimensions

Dimension	Value
Wing Span	32' 9"
Horizontal Stab Span	
Length	25'
Height	
Wheel Base	
Wing Area	147 sq. ft.

2.3 Interior Dimensions

2.4 General Specifications

Specification	Value
Wing Span	32' 9"
Length	25'
Height	
Wing Area	147 sq. ft.
Empty Weight	lbs
Gross Weight	2,700 lbs
Wing Loading – Gross	lbs/sq. ft.
Power Loading – Gross	lbs/HP
Engine	
Propeller	
Fuel Capacity	U.S. Gallons
Baggage Capacity	lbs

2.5 Performance Specifications

Performance	Light Weight	Gross Weight
Top Speed	KIAS	KIAS
Cruise (75% @ 8,000 ft)	KIAS	KIAS
Cruise (55% @ 8,000 ft)	KIAS	KIAS
Stall Speed	KIAS	KIAS
Rate of Climb	ft/min	ft/min
Ceiling	ft	ft
Takeoff Distance	ft	ft
Landing Distance	ft	ft
Range (75%)	SM	SM
Range (55%)	SM	SM

2.6 Engine

Parameter	Value
Manufacturer	
Model	
Serial Number	
Rated Horsepower	HP
Rated Speed	RPM
Bore	inches
Stroke	inches
Displacement	cubic inches
Compression Ratio	
Type	

2.7 Propeller

Parameter	Value
Manufacturer	
Model	
Serial Number	
Blades	
Low Pitch	degrees
High Pitch	degrees
Diameter (max)	inches
Diameter (min)	inches
Type	

2.8 Fuel

Parameter	Value
Fuel Capacity	U.S. gallons
Usable Fuel	U.S. gallons
Minimum Grade	100LL octane

2.9 Oil

Parameter	Value
Oil Capacity	quarts max, quarts min
Oil Specifications	
Oil Viscosity (All Temps)	SAE15W-50 or SAE20W-50

2.10 Maximum Weights

Weight	Value
Maximum Takeoff Weight	lbs
Maximum Ramp Weight	lbs
Maximum Landing Weight	lbs
Maximum Baggage Weight	lbs
Empty Weight	lbs
Gross Weight	lbs

2.11 Baggage Space

Dimension	Value
Entry Width	
Entry Height	
Volume	cubic feet

2.12 Specific Loadings

Loading	Value
Wing Loading	lbs/sq. ft.
Power Loading	lbs/HP

3 Operating Limitations

3.1 General

This section provides the operating limitations, instrument markings, color coding and basic placards necessary for the safe operation of the airplane and its systems.

3.2 Airspeed Limitations

Type	Description	KIAS
V_{S0}	Stall, Flaps Down	
V_{S1}	Stall, Flaps Up	
V_X	Best Angle of Climb	
V_Y	Best Rate of Climb	
V_G	Best Glide	
V_{FE}	Maximum Flap Extended	
V_{NO}	Maximum Structural Cruising	
V_A	Design Maneuvering	
V_{NE}	Never Exceed	

3.3 Power Plant Limitations

Parameter	Limit
Engine	
Maximum Horsepower	HP
Maximum Speed	RPM
Maximum Manifold Pressure	
Maximum CHT	°F
Maximum Oil Temperature	°F
Oil Pressure (Min)	PSI
Oil Pressure (Max)	PSI
Fuel Pressure (Min)	PSI
Fuel Pressure (Max)	PSI

3.4 Power Plant EFIS Markings

3.4.1 Tachometer

Arc	Range
Green Arc	0 – RPM
Red Line (Max)	RPM

3.4.2 Oil Temperature

Arc	Range
Green Arc	°F – °F
Yellow Arc	°F – °F
Red Line (Max)	°F

3.4.3 Oil Pressure

Arc	Range
Green Arc	– PSI
Yellow Arc	– PSI
Red Line (Min)	PSI
Red Line (Max)	PSI

3.4.4 Cylinder Head Temperature

Arc	Range
Green Arc	°F – °F
Yellow Arc	°F – °F
Red Line (Max)	°F

3.5 Weight Limits

Limit	Value
Maximum Takeoff Weight	lbs
Maximum Ramp Weight	lbs
Maximum Landing Weight	lbs
Maximum Baggage Weight	lbs

3.6 Center of Gravity Limits

Category	Range
Utility	" – " aft of datum

Note: Datum is located forward of the wing leading edge.

3.7 Flight Maneuvering Load Factors

Category	Positive	Negative
Utility	+G	-G

3.8 Types of Operations

The airplane is approved for the following operations when equipped in accordance with FAR 91:

- Day VFR
- Night VFR
- Day IFR
- Night IFR
- Non-Icing

3.9 Fuel Limitations

Parameter	Value
Fuel Capacity	U.S. gallons
Usable Fuel	U.S. gallons
Minimum Grade	100LL octane

3.10 Placards

Location	Placard
On baggage area	Maximum Baggage Capacity lbs
In view from entrance	EXPERIMENTAL
In view of occupants	PASSENGER WARNING: THIS AIRCRAFT IS AMATEUR BUILT AND DOES NOT COMPLY WITH FEDERAL SAFETY REGULATIONS FOR STANDARD AIRCRAFT.
At each fuel filler	100LL, XX Gal.

4 Additional Engine Information

4.1 General

Refer to your engine manufacturer's Operator's Manual for detailed performance charts and operating information.

4.1.1 Key Engine Data

Parameter	Value
Model	
Serial Number	
TBO	hours
Installed	
Hours at Installation	

5 Emergency Procedures

These procedures are derived from the efis-editor checklist file. Update the source JSON and regenerate to modify.

5.1 Engine Failures

5.1.1 Engine Failure During Takeoff Run

- Throttle ... **IDLE**
- Brakes ... **APPLY**
- Wing Flaps ... **RETRACT**
- Mixture ... **IDLE CUT-OFF**
- Ignition Switch ... **OFF**
- Master Switch ... **OFF**

5.1.2 Engine Failure Immediately After Takeoff

- Airspeed ... **75 KIAS (FLAPS UP)** 70 KIAS (flaps DOWN)
- Landing Area ... **WITHIN 30^o**
- Fuel Selector Valve ... **OFF**
- Mixture ... **IDLE CUT-OFF**
- Ignition Switch ... **OFF**
- Wing Flaps ... **AS REQUIRED** 40^o recommended
- Master Switch ... **OFF**

5.1.3 Engine Failure During Flight

- Airspeed ... **76 KIAS**
- Landing Area ... **LOCATE**
- Fuel Selector Valve ... **BOTH**
- Carburetor Heat ... **ON**
- Mixture ... **RICH**
- Ignition Switch ... **BOTH** or **START** if propeller is stopped
- Primer ... **IN AND LOCKED**
- Forced Landing ... **EXECUTE** as described in Emergency Landing Without Engine Power

5.2 Forced Landings

5.2.1 Emergency Landing Without Engine Power

- SQUAWK ... **7700**
- Airspeed ... **75 KIAS (FLAPS UP)** 70 KIAS (flaps DOWN)
- Fuel Selector Valve ... **OFF**

- Mixture ... **IDLE CUT-OFF**
- Ignition Switch ... **OFF**
- Wing Flaps ... **AS REQUIRED (40° RECOMMENDED)**
- Master Switch ... **OFF**
- Radio Call ... **MAYDAY 121.5** time permitting
- Doors ... **UNLATCH PRIOR TO TOUCHDOWN**
- Touchdown ... **SLIGHTLY TAIL LOW**
- Brakes ... **APPLY HEAVILY**

5.2.2 Precautionary Landing With Engine Power

- Airspeed ... **70 KIAS**
- Wing Flaps ... **20°**
- Selected Field ... **FLY OVER**
- Terrain And Obstructions ... **NOTE**
- Wing Flaps ... **RETRACT** at safe altitude and airspeed
- Electrical Switches ... **OFF**
- Wing Flaps (On Final) ... **40°**
- Airspeed ... **70 KIAS**
- Avionics Power and Master Switches ... **OFF**
- Doors ... **UNLATCH PRIOR TO TOUCHDOWN**
- Touchdown ... **SLIGHTLY TAIL LOW**
- Ignition Switch ... **OFF**
- Brakes ... **APPLY HEAVILY**

5.2.3 Ditching

- Transmit Mayday ... **121.5 MHZ, GIVING LOCATION**
- SQUAWK ... **7700**
- Heavy Objects ... **SECURE OR JETTISON**
- Flaps ... **20° - 40°**
- Power ... **SET** ESTABLISH 300 FT/MIN DESCENT at 60 KIAS High Winds, Heavy Seas – INTO THE WIND. Light Winds, Heavy Swells – PARALLEL TO SWELLS If no power is available, approach at 70 KIAS with flaps up or at 65 KIAS with 10° flaps.
- Cabin Doors ... **UNLATCH**
- Touchdown ... **LEVEL ATTITUDE AT ESTABLISHED DESCENT**
- Face ... **CUSHION AT TOUCHDOWN WITH FOLDED COAT**
- Airplane ... **EVACUATE**
- Life Vests and Raft ... **INFLATE**

5.2.4 Landing With A Flat Main Tire

- Approach ... **NORMAL**
- Wing Flaps ... **FULL DOWN**
- Touchdown ... **GOOD TIRE FIRST** hold airplane off flat tire as long as possible with aileron control

5.2.5 Landing Without Elevator Control

- Airspeed ... **80 KIAS**
- Elevator Trim ... **LEVEL FLIGHT**
- Elevator Trim ... **DO NOT CHANGE**
- Glide Angle ... **CONTROL** by adjusting power exclusively
- Elevator Trim ... **FULL NOSE UP**
- Power ... **ADJUST** so airplane will rotate to horizontal attitude for touchdown
- Throttle ... **CLOSE** at touchdown

5.3 *Fires*

5.3.1 Fire During Start On Ground

- Cranking ... **CONTINUE**
- Power ... **1700 RPM** for a few minutes
- Engine ... **SHUTDOWN**
- Throttle ... **FULL OPEN**
- Mixture ... **IDLE CUT-OFF**
- Cranking ... **CONTINUE** 2-3 min
- Fire Extinguisher ... **OBTAIN**
- Fuel Selector Valve ... **OFF**
- Master Switch ... **OFF**
- Ignition Switch ... **OFF**
- Fire ... **EXTINGUISH**
- Fire Damage ... **INSPECT**

5.3.2 Engine Fire In Flight

- Fuel Selector Valve ... **OFF**
- Mixture ... **IDLE CUT-OFF**
- Master Switch ... **OFF**
- Cabin Heat and Air ... **OFF** except overhead vents
- Airspeed ... **100 KIAS** If fire is not extinguished, increase glide speed to find an airspeed which will provide an incombustible mixture If fire goes out:
- Glide speed ... **76 KIAS**
- Landing Area ... **LOCATE**
- Forced Landing ... **EXECUTE** as described in Emergency Landing Without Engine Power

5.3.3 Electrical Fire In Flight

- Master Switch ... **OFF**
- Avionics Power Switch ... **OFF**
- All Other Switches ... **OFF** Except Ignition Switch
- Vents/Cabin Air/Heat ... **CLOSED**

- Fire Extinguisher ... **ACTIVATE** After discharging an extinguisher within a closed cabin, ventilate the cabin. and electrical power is necessary for continuance of flight:
- Master Switch ... **ON**

Note: monitor ammeter

- Circuit Breakers ... **CHECK** for faulty circuit, do not reset
- Radio Switches ... **OFF**
- Avionics Power Switch ... **ON**
- Radio/Electrical Switches ... **ON** one at a time, with delay after each until short circuit is localized
- Vents/Cabin Air/Heat ... **OPEN** when it is ascertained that fire is completely extinguished

5.3.4 Cabin Fire

- Master Switch ... **OFF**
- Vents/Cabin Air/Heat ... **CLOSED**
- Fire Extinguisher ... **ACTIVATE** After discharging an extinguisher within a closed cabin, ventilate the cabin
- Land ... **AS SOON AS POSSIBLE**
- Airplane ... **INSPECT FOR DAMAGE**

5.3.5 Wing Fire

- Navigation Light Switch ... **OFF**
- Strobe Light Switch ... **OFF**
- Pitot Heat Switch ... **OFF** Perform a sideslip to keep the flames away from the fuel tank and cabin, and land as soon as possible using flaps only as required for final approach and touchdown.

5.4 Icing

5.4.1 Inadvertent Icing Encounter

- Pitot Heat Switch ... **ON**
- Icing Conditions ... **EXIT** Turn back or change altitude to obtain an outside air temperature that is less conducive to icing
- Cabin Heat ... **ON**
- Defroster Control ... **MAX AIRFLOW**
- Engine Speed ... **INCREASE** to minimize build up on propeller blades
- Carb Heat ... **AS REQUIRED** Lean the mixture if carburetor heat is used continuously
- Land ... **NEAREST AIRPORT** With an extremely rapid ice build-up, select a suitable "off airport" landing site With an ice accumulation of 1/4 inch or more on the wing leading edges, be prepared for significantly higher stall speed

- Wing Flaps ... **LEAVE RETRACTED**
- Windshield Ice ... **REMOVE** Open left window and if practical scrape ice from a portion of the windshield for visibility in the landing approach
- Forward Slip ... **PERFORM** if necessary during landing approach, for improved visibility
- Approach ... **80 TO 90 KIAS** depending upon the amount of ice accumulation
- Land ... **AT LEVEL ATTITUDE**

5.4.2 Static Source Blockage

- Alternate Static Source Valve ... **PULL ON**
- Airspeed ... **REFERENCE** Consult appropriate table in Section 5
- Cruise ... **50 FT HIGHER THAN NORMAL**
- Approach ... **30 FT HIGHER THAN NORMAL**

5.4.3 Carburetor Icing

- Note RPM decrease ... **CHECK**
- Carburetor Heat ... **ON** monitor RPM for “decrease then increase” as carburetor ice melts
- Mixture ... **RE-LEAN**

5.5 *Electrical / Oil Malfunctions*

5.5.1 Ammeter Shows Excessive Rate Of Charge

- Alternator ... **OFF**
- Non-Essential Electrical Equipment ... **OFF**
- Flight ... **TERMINATE** as soon as practical

5.5.2 Ammeter Shows Discharge

- Avionics Power Switch ... **OFF**
- Master Switch ... **ALT OFF (LEFT)**
- Check ALT Breakers ... **RESET ONCE**
- Master Switch ... **ALT ON** attempt only one reset
- Master Switch ... **ALT OFF**
- Avionics Power Switch ... **ON**
- Electrical Equipment ... **MINIMIZE**
- Flight ... **TERMINATE** as soon as practical

5.5.3 Low-Voltage Light Illuminates During Flight

Illumination of the low-voltage light may occur during low RPM conditions with an electrical load on the system such as during a low RPM taxi. Under these conditions, the light will go out at higher RPM. The master switch need not be recycled since an over-voltage condition has not occurred to deactivate the alternator system.

- Avionics Power Switch ... **OFF**
- Master Switch ... **OFF (BOTH SIDES)**
- Master Switch ... **ON**

- Low-Voltage Light ... **CHECK OFF**
- Avionics Power Switch ... **ON**
- Alternator ... **OFF**
- Non-Essential Radio and Electrical Equipment ... **OFF**
- Flight ... **TERMINATE** as soon as practical

5.5.4 High Oil Temperature

- Mixture ... **ENRICH**
- If Climbing ... **STOP CLIMB**
- RPM ... **DECREASE**
- Airspeed ... **INCREASE**

5.6 *Emergency Operation In Clouds*

5.6.1 Executing A 180° Turn In Clouds

- Compass Heading ... **NOTE**
- Time ... **NOTE**
- Standard Rate Turn ... **INITIATE** maintain for 60 seconds
- Level Flight ... **MAINTAIN**
- Turn Accuracy ... **CHECK** compass heading should be the reciprocal of the original heading
- Heading ... **ADJUST AS NECESSARY** Using rudder
- Altitude and Airspeed ... **MAINTAIN**

5.6.2 Emergency Descent Through Clouds

- Heading ... **EAST OR WEST** to minimize compass card swings due to changing bank angles In addition, keep hands off the control wheel and steer a straight course with rudder control by monitoring the turn coordinator. Occasionally check the compass heading and make minor corrections to hold an approximate course.
- Mixture ... **FULL RICH**
- Carb Heat ... **FULL**
- Power ... **REDUCE** for 500 to 800 FPM descent
- Elevator and Rudder Trim ... **ADJUST** for stabilized descent at 80 KIAS
- Turn Coordinator ... **MONITOR** Make corrections by rudder alone
- Normal Cruising Flight ... **RESUME**

5.6.3 Recovery From A Spiral Dive

- Throttle ... **CLOSE**
- Turn ... **STOP** by using coordinated aileron and rudder control
- Elevator ... **APPLY BACK PRESSURE** cautiously to slowly reduce the indicated airspeed to 80 KIAS
- Elevator Trim ... **ADJUST** to maintain an 86 KIAS glide Keep hands off the control wheel, using rudder control to hold straight heading. Use rudder trim to relieve unbalanced rudder force, if present.

- Carb Heat ... **APPLY**
- Engine ... **CLEAR OCCASIONALLY**
- Normal Cruising Flight ... **RESUME**
- Throttle ... **IDLE**
- Ailerons ... **NEUTRAL**
- Rudder ... **FULL OPPOSITE DIRECTION OF ROTATION**
- Elevator Control ... **FORWARD** Briskly to break stall
- Control Inputs ... **HOLD** Until Rotation Stops
- Normal Flight ... **RESUME**

6 Abnormal Procedures

These procedures are derived from the efis-editor checklist file.

6.1 Takeoff And Climb

6.1.1 Short Field Takeoff

- Wing Flaps ... **20°**
- Carburetor Heat ... **COLD**
- Brakes ... **APPLY**
- Power ... **FULL THROTTLE AND 2600 RPM**
- Brakes ... **RELEASE**
- Elevator Control ... **SLIGHTLY TAIL LOW**
- Climb Speed ... **59 KIAS** until all obstacles are cleared
- Wing Flaps ... **RETRACT** slowly after reaching 70 KIAS

6.1.2 Maximum Performance Climb

- Airspeed ... **78 KIAS TO 72 KIAS**
- Power ... **FULL THROTTLE AND 2600 RPM**
- Fuel Selector Valve ... **BOTH**
- Mixture ... **FULL RICH** mixture may be leaned above 5000 feet
- Cowl Flaps ... **FULL OPEN**

6.2 Landing

6.2.1 Short Field Landing

- Airspeed ... **70-80 KIAS (FLAPS UP)**
- Wing Flaps ... **40°** below 95 KIAS
- Airspeed ... **MAINTAIN 60 KIAS**
- Trim ... **ADJUST**
- Power ... **REDUCE TO IDLE** as obstacle is cleared
- Touchdown ... **MAIN WHEELS FIRST**
- Brakes ... **APPLY HEAVILY**
- Wing Flaps ... **RETRACT**

6.2.2 Go Around

- Power ... **FULL THROTTLE AND 2600 RPM**
- Carburetor Heat ... **COLD**
- Wing Flaps ... **RETRACT TO 20°**
- Climb Speed ... **61 KIAS** positive rate of climb

- Wing Flaps ... **RETRACT TO 10°**
- Climb Speed ... **77 KIAS**
- Wing Flaps ... **RETRACT** after reaching safe altitude
- Cowl Flaps ... **OPEN**

7 Normal Procedures

These procedures are derived from the efis-editor checklist file. Update the source JSON and regenerate to modify.

7.1 Preflight

7.1.1 Preflight Inspection

- Pilot's Operating Handbook ... **AVAILABLE IN THE AIRPLANE**
- Keys ... **CLIP TO THROTTLE**
- Control Wheel Lock ... **REMOVE**
- Ignition Switch ... **OFF**
- Avionics Power Switch ... **OFF**
- Master Switch ... **ON**
- Fuel Quantity Indicators ... **CHECK**
- Master Switch ... **OFF**
- Alternate Static Source Valve ... **OFF**
- Fuel Selector Valve ... **BOTH**
- Baggage Door ... **CHECK**
- Rudder Gust Lock ... **REMOVE**
- Tail Tie-Down ... **DISCONNECT**
- Control Surfaces ... **CHECK**
- Aileron ... **CHECK**
- Wing Tie-Down ... **DISCONNECT**
- Fuel Tank Vent Opening ... **CHECK**
- Main Wheel Tire ... **CHECK**
- Fuel Tank Sump ... **CHECK**
- Fuel Quantity ... **CHECK VISUALLY**
- Fuel Filler Cap ... **SECURE** and vent unobstructed
- Static Source Openings ... **CHECK**
- Propeller and Spinner ... **CHECK** for nicks, security, and oil leaks
- Landing Lights ... **CHECK**
- Carburetor Air Filter ... **CHECK**
- Nose Wheel, Strut and Tire ... **CHECK**
- Nose Tie-Down ... **DISCONNECT**
- Engine Oil Level ... **CHECK** Do not operate with less than nine quarts. Fill to twelve quarts for extended flight.
- Fuel Strainer ... **CHECK**
- Main Wheel Tire ... **CHECK**
- Fuel Tank Sump ... **CHECK**
- Fuel Quantity ... **CHECK VISUALLY**

- Fuel Filler Cap ... **SECURE** and vent unobstructed
- Pitot Tube Cover ... **REMOVE**
- Fuel Tank Vent Opening ... **CHECK**
- Stall Warning Vane ... **CHECK**
- Wing Tie-Down ... **DISCONNECT**
- Aileron ... **CHECK**

7.1.2 Before Starting Engine

- Preflight Inspection ... **COMPLETE**
- Seats, Belts, Shoulder Harnesses ... **ADJUST AND LOCK**
- Fuel Selector Valve ... **BOTH**
- Cowl Flaps ... **OPEN**
- Avionics Power Switch ... **OFF**
- Electrical Equipment ... **OFF**
- Circuit Breakers ... **CHECK IN**
- Brakes ... **TEST AND SET**

7.1.3 Starting Engine

- Mixture ... **RICH**
- Propeller ... **HIGH RPM**
- Carburetor Heat ... **COLD**
- Throttle ... **OPEN 1/2 INCH**
- Prime ... **AS REQUIRED** 3-6 strokes (none if engine is warm). Check in and locked
- Master Switch ... **ON**
- Beacon Light ... **ON**
- Propeller Area ... **CLEAR**
- Ignition Switch ... **START** release after engine starts If engine has been overprimed (2x):
 - place mixture idle
 - start with throttle 1/4 to 1/2 open.
 - Mixture full rich when engine fires and throttle to idle promptly.
- RPM ... **ADJUST TO 1,000** reset to 1000 RPM as engine warms up
- Oil Pressure ... **CHECK IN GREEN**
- Mixture ... **LEAN FOR TAXI** at least 3/4"

7.1.4 Before Taxi

- Avionics Power Switch ... **ON**
- Wing Flaps ... **RETRACT, VERIFY UP**
- Radios ON ... **BDU AWOS 118.825** obtain AWOS/ATIS
- Altimeter ... **SET**
- Heading indicator ... **SET**
- Lights ... **AS REQUIRED**
- Brakes ... **TEST ON ROLL**

7.1.5 Before Takeoff

- Brakes ... **HOLD**
- Cabin Doors and Windows ... **CLOSED AND LOCKED**
- Elevator and Rudder Trim ... **TAKEOFF**
- Flight Controls ... **FREE AND CORRECT**
- Flight Instruments ... **SET**
- Fuel Selector Valve ... **BOTH**
- Cowl Flaps ... **OPEN**
- Propeller Control ... **HIGH RPM**
- Mixture ... **RICH**
- Throttle ... **1700 RPM**
- Mixture Control ... **SET** lean => RPM drop, enrich to peak RPM, three 1/2 turns rich
- Propeller ... **CYCLE 2X** RPM dip, then oil pressure dip
- Carburetor Heat ... **CHECK RPM DROP**
- Magnetos ... **CHECK** L, Both, R, Both: ≤ 150 RPM drop ≤ 50 RPM difference
- Engine Instruments (Oil Pressure, Temp) ... **CHECK**
- Fuel Gauge ... **CHECK QUANTITY**
- Ammeter ... **CHECK**
- Suction Gage ... **CHECK**
- Throttle ... **IDLE, THEN 1000 RPM**
- Radios, Navigation ... **SET** BDU CTAF 122.725
- Transponder ... **ALT, 1200**
- Flashing Beacon ... **AS REQUIRED**
- Navigation Lights ... **AS REQUIRED**
- Strobe Lights ... **AS REQUIRED**
- Pitot Heat ... **AS REQUIRED**
- Wing Flaps ... **SET FOR TAKEOFF**
- Throttle Friction Lock ... **ADJUST**
- Radio Call ... **BDU CTAF 122.725**

7.1.6 Normal Takeoff

- Wing Flaps ... **0° - 20°**
- Carburetor Heat ... **COLD**
- Power ... **FULL THROTTLE AND 2600 RPM**
- Elevator Control ... **LIFT NOSE WHEEL AT 50 KIAS**
- Climb Speed ... **70 KIAS (FLAPS 20°)** 80 KIAS (flaps UP)

7.2 In Flight

7.2.1 Normal Climb

- Airspeed ... **85-95 KIAS**
- Power ... **23" HG AND 2450 RPM**
- Fuel Selector Valve ... **BOTH**

- Mixture ... **SET** mixture may be leaned above 5000 feet
- Engine Gauges ... **CHECK**
- Cowl Flaps ... **OPEN** as required

7.2.2 Cruise

- Power ... **15-23" HG AND 2200-2450 RPM** no more than 75%
- Elevator and Rudder Trim ... **ADJUST**
- Mixture ... **LEAN**
- Engine Gauges ... **CHECK**
- Lights ... **AS REQUIRED**
- Cowl Flaps ... **CLOSED**

7.2.3 Pre-Maneuver

- Fuel Selector Valve ... **BOTH**
- Mixture Control ... **SET** as needed
- Carburetor Heat ... **AS REQUIRED**
- Cowl Flaps ... **AS REQUIRED**
- Lights ... **AS REQUIRED**
- Clearing Turns ... **PERFORM** 90° L - 90° R / 180° turn
- Power ... **AS DESIRED**

7.2.4 Descent

- Fuel Selector Valve ... **BOTH**
- Mixture ... **ENRICHEN** as required
- AWOS/ATIS ... **BDU AWOS 118.825**
- Power ... **AS DESIRED**
- Carburetor Heat ... **AS REQUIRED** to prevent carburetor icing
- Cowl Flaps ... **CLOSED**
- Wing Flaps ... **AS DESIRED** 0° to 10° below 140 KIAS, 10° to 40° below 95 KIAS
- Lights ... **AS REQUIRED**

7.2.5 Before Landing

- Radio Call ... **BDU CTAF 122.725**
- Carburetor Heat ... **ON** apply full heat before closing throttle
- Cowl Flaps ... **CLOSED**
- Fuel Selector Valve ... **BOTH**
- Mixture ... **RICH**
- Propeller ... **HIGH RPM**
- Seats, Belts, Harnesses ... **ADJUST AND LOCK**

7.2.6 Normal Landing

- Airspeed ... **70-80 KIAS (FLAPS UP)**
- Wing Flaps ... **AS DESIRED** 0° TO 10° below 140 KIAS, 10° TO 40° below 95 KIAS

- Airspeed ... **65-75 KIAS (FLAPS DOWN)**
- Trim ... **ADJUST**
- Touchdown ... **MAIN WHEELS FIRST**
- Landing Roll ... **LOWER NOSE WHEEL GENTLY**
- Braking ... **MINIMUM REQUIRED**

7.3 Postflight

7.3.1 After Landing

- Carburetor Heat ... **COLD**
- Cowl Flaps ... **OPEN**
- Wing Flaps ... **UP**
- Elevator and Rudder Trim ... **TAKEOFF**
- Lights ... **AS REQUIRED**
- Pitot Heat ... **AS REQUIRED**
- Transponder ... **ALT, 1200**
- Radio Call ... **BDU CTAF 122.725**

7.3.2 Securing Airplane

- Avionics Power Switch ... **OFF**
- Electrical Equipment ... **OFF**
- Ignition ... **GROUNDING CHECK** L, R, then OFF, back R
- Throttle ... **IDLE**
- Mixture ... **IDLE CUT-OFF**
- Lights ... **OFF** except beacon
- Ignition Switch ... **OFF**
- Master Switch ... **OFF**
- Fuel Selector Valve ... **RIGHT**
- Cowl Flaps ... **CLOSED**
- Control Lock ... **INSTALL**
- Hobbs + Tach Time ... **RECORD**

8 Performance

8.1 Stall and Approach Speeds

Speed	Weight	Flaps Up	Flaps Down
Stall	lbs	KIAS	KIAS
Approach ($1.3 \times V_S$)	lbs	KIAS	KIAS

8.2 Takeoff Performance

8.3 Climb Performance

8.4 Cruise Performance

8.5 Landing Performance

9 Weight and Balance

9.1 Airplane Weighing Procedure

The aircraft was weighed with the fuselage level. The aircraft was empty with the exception for oil located in the engine sump.

9.2 Empty Weight and Balance Data

The datum is located XX" forward of the wing leading edge.

Station	Weight (lbs)	Arm (inches)	Moment (lb-in)
Left Main			
Right Main			
Nose/Tail			
Total			
CG		"	

9.3 Allowable Weight and Balance Envelope

9.4 Sample Weight and Balance Calculation

Item	Weight (lbs)	Arm (in)	Moment (lb-in)
Empty Weight			
Pilot			
Front Passenger			
Rear Passengers			
Baggage			
Fuel (gal × 6.0)			
Total			

$CG = \text{Total Moment} / \text{Total Weight} = \text{" aft of datum}$

10 System Descriptions

10.1 The Airplane

The airplane is a single engine, low wing configuration with tricycle landing gear. The airframe is aluminum alloy construction except for some steel components comprising: engine mount, landing gear components, control surface bellcranks, and other miscellaneous items.

10.2 Engine and Components

10.3 Propeller

10.4 Landing Gear

10.5 Brake System

10.6 Flight Control System

10.7 Fuel System

10.8 Electrical System

10.9 Pitot-Static System

10.10 Instrument Panel

10.11 Heating, Ventilation and Defrosting

10.12 Cabin Features

10.13 Baggage Area

10.14 Exterior Lighting

11 Handling, Servicing and Maintenance

11.1 General

The airplane should be moved using a tow bar which connects to the nose wheel. The airplane may be pushed or pulled from the inboard portions of the prop blades. Do not push on the spinner!

11.2 Ground Handling

The airplane has three tie-down rings. The tie-down rings are removable and may be kept inside the baggage compartment area.

11.3 Engine Air Filter

11.4 Brake Service

Item	Specification
Brake Linings	
Brake Fluid	

11.5 Landing Gear Service

Item	Specification
Main Tire Pressure	PSI
Nose Tire Pressure	PSI

11.6 Propeller Service

The propeller must be lubricated at intervals not to exceed 100 hours or 12 calendar months, whichever occurs first.

Grease Type	
Interval	100 hrs / 12 months

11.7 Oil System Service

Item	Specification
Oil Filter	
Change Interval	hours

11.8 Fuel System***11.9 Battery Service***

Battery	Location	Type
Main		

11.10 Lubrication

Item	Lubricant	Interval
Wheel Bearings		Annual
Control Hinges		As needed