






# mixerli

LiPo powered 10 channel (4x2 + 1x2) stereo mixer featuring stereo input level control slider and stereo rotary aux send level control.



LiPo powered 10 channel (4x2 + 1x2) stereo mixer featuring stereo input level control slider and stereo rotary aux send level control.  
<https://github.com/stahlnow/mixerli>  
 MIT License - Copyright (c) 2017 stahl

**stahl**labs

Sheet: /  
 File: mixerli.kicad\_sch

**Title: mixerli**

Size: A4 Date: 2022-11-13

KiCad E.D.A. kicad (6.0.9)

**Rev: 2.0.0a**


Id: 1/8

Note: Dual mono configuration

The normally stereophonic input can be changed into a monophonic input where the signal is hardwired to both the left and the right channel resulting in a dual monophonic signal.

This change requires two changes:

- Ring pin of the jack must be removed
- JP solder pad must be closed (soldered)



Sheet: /Input 1/  
File: fader.kicad\_sch

**Title:**

Size: A4  
KiCad E.D.A. kicad (6.0.9)


Date:  
Rev:  
Id: 2/8

Note: Dual mono configuration

The normally stereophonic input can be changed into a monophonic input where the signal is hardwired to both the left and the right channel resulting in a dual monophonic signal.

This change requires two changes:

- Ring pin of the jack must be removed
- JP solder pad must be closed (soldered)



Sheet: /Input 2/  
File: fader.kicad\_sch

**Title:**

Size: A4  
KiCad E.D.A. kicad (6.0.9)


Date:  
Rev:  
Id: 3/8

Note: Dual mono configuration

The normally stereophonic input can be changed into a monophonic input where the signal is hardwired to both the left and the right channel resulting in a dual monophonic signal.

This change requires two changes:

- Ring pin of the jack must be removed
- JP solder pad must be closed (soldered)



Sheet: /Input 3/  
File: fader.kicad\_sch

**Title:**

Size: A4  
KiCad E.D.A. kicad (6.0.9)


Date:  
Id: 4/8

Note: Dual mono configuration

The normally stereophonic input can be changed into a monophonic input where the signal is hardwired to both the left and the right channel resulting in a dual monophonic signal.

This change requires two changes:

- Ring pin of the jack must be removed
- JP solder pad must be closed (soldered)



Sheet: /Input 4/  
File: fader.kicad\_sch

**Title:**

Size: A4  
KiCad E.D.A. kicad (6.0.9)


Date:  
Rev:  
Id: 5/8

Note: Dual mono configuration

The normally stereophonic input can be changed into a monophonic input where the signal is hardwired to both the left and the right channel resulting in a dual monophonic signal.

This change requires two changes:

- Ring pin of the jack must be removed
- JP solder pad must be closed (soldered)




Sheet: /Input 5/  
File: fader.kicad\_sch

**Title:**

Size: A4  
KiCad E.D.A. kicad (6.0.9)

Date:  
Id: 6/8



PANORAMA

not implemented

Sheet: /Pan/Send/  
File: pan\_send.kicad\_sch

**Title:**

Size: A4	Date:
KiCad E.D.A. kicad (6.0.9)	

Rev:
Id: 7/8

