



# Deep Micro Systems

.

## CONFIGURATION STEPS FOR RASPBIAN STRETCH LITE FOR ARTIFICIAL VISION

Ing. Álvaro Rubén Hurtado Maldonado

Oruro - 12 de febrero de 2018

<b>1. Installation Instructions</b>	<b>3</b>
1.1. Raspbian Image . . . . .	3
1.2. Pre configuration . . . . .	3
1.2.1. Wi-Fi configuration . . . . .	3
1.2.2. Enable SSH and auto login on startup . . . . .	4
1.3. Python 3 setup . . . . .	4
1.4. Install OpenCV . . . . .	5
<b>2. Otras configuraciones</b>	<b>5</b>
2.1. Remot3 configuration . . . . .	5

# 1. Installation Instructions

## 1.1. Raspbian Image

For this tutorial we are using a Raspberry Pi 3 and Raspbian Stretch Lite OS:

- Minimal image based on Debian Stretch
- Version: November 2017
- Release date: 2017-11-29
- Kernel version: 4.9

We will be using a 32 Gb Samsung SD Card with Read speed of 80 MB/s and write speed of 20 MB/s.

For the burning of the image to the SD card we advice to use Windows OS:

1. Download the Lite version image
2. Extract it using 7 zip
3. Burn the image using Win 32 Image Creator
4. Extract the sd card and plug to the Raspberry Pi 3

## 1.2. Pre configuration

### 1.2.1. Wi-Fi configuration

To stablish connection to a visible Wi-Fi Network we just add the following lines to the file: `/etc/network/interfaces`:

---

```
auto lo

iface lo inet loopback
iface eth0 inet dhcp

allow-hotplug wlan0
auto wlan0

iface wlan0 inet dhcp
    wpa-ssid "SSID"
    wpa-psk "PASSWORD"
```

---

### 1.2.2. Enable SSH and auto login on startup

In order to control the pi remotely without the need of a keyboard and screen monitor we allow SSH:

1. Type **raspi-config** to get into configuration
2. In the preferences menu enter the Interfaces menu
3. Enable SSH
4. Back to the main menu enter the Boot Options
5. Activate Autologin

Then to get the local IP for your raspberry pi just type: `ifconfig` in the terminal.

This is highly recommended that you change the Pi password to a secure one, this can also be achieved from the `raspi-config` menu.

## 1.3. Python 3 setup

---

```
$ sudo apt-get update && sudo apt-get upgrade
$ sudo apt-get install build-essential cmake pkg-config
$ sudo apt-get install libhdf5-dev
$ sudo apt-get install libjpeg-dev libtiff5-dev libjasper-dev libpng12-dev
$ sudo apt-get install libavcodec-dev libavformat-dev libswscale-dev libv4l-dev
$ sudo apt-get install libxvidcore-dev libx264-dev
$ sudo apt-get install libgtk2.0-dev libgtk-3-dev
$ sudo apt-get install libcanberra-gtk*
$ sudo apt-get install libatlas-base-dev gfortran
$ sudo apt-get install python2.7-dev python3-dev
```

---

Or we can try the joint commands:

---

```
$ sudo apt-get update && sudo apt-get upgrade -y && sudo apt-get install
  build-essential cmake pkg-config -y && sudo apt-get install libhdf5-dev -y
  && sudo apt-get install libjpeg-dev libtiff5-dev libjasper-dev
  libpng12-dev -y && sudo apt-get install libavcodec-dev libavformat-dev
  libswscale-dev libv4l-dev -y && sudo apt-get install libxvidcore-dev -y &&
  libx264-devsudo apt-get install libgtk2.0-dev libgtk-3-dev -y && sudo
  apt-get install libcanberra-gtk* -y && sudo apt-get install
  libatlas-base-dev gfortran -y && sudo apt-get install python2.7-dev
  python3-dev -y
```

---

## 1.4. Install OpenCV

First we download all necessary resources and unzip them:

---

```
$ cd ~
$ wget -O opencv.zip https://github.com/Itseez/opencv/archive/3.3.0.zip
$ unzip opencv.zip
$ wget -O opencv_contrib.zip
  https://github.com/Itseez/opencv_contrib/archive/3.3.0.zip
$ unzip opencv_contrib.zip

$ cd ~/opencv-3.3.0/
$ mkdir build
$ cd build
```

---

Now we compile:

---

```
$ cmake -D CMAKE_BUILD_TYPE=RELEASE \
  -D CMAKE_INSTALL_PREFIX=/usr/local \
  -D OPENCV_EXTRA_MODULES_PATH=~/opencv_contrib-3.3.0/modules \
  -D ENABLE_NEON=ON \
  -D ENABLE_VFPV3=ON \
  -D BUILD_TESTS=OFF \
  -D INSTALL_PYTHON_EXAMPLES=OFF \
  -D WITH_EIGEN=ON \
  -D BUILD_EXAMPLES=OFF ..
```

---

Now we shall increase the swap size to 1024 to compile using several cores, this can be done modifying the file: **sudo nano /etc/dphys-swapfile**

---

```
# CONF_SWAPSIZE=100 # Old
CONF_SWAPSIZE=1024
```

---

Now we restart the swap service:

---

```
$ sudo /etc/init.d/dphys-swapfile stop && sudo /etc/init.d/dphys-swapfile start
```

---

### 1.4.1. Install Background subtraction

To install Background subtraction we first need to install swig:

---

```
$ sudo apt-get install swig
```

---

Now we can get and build Background subtraction:

---

```
$ git clone https://github.com/sagi-z/BackgroundSubtractorCNT.git
--single-branch
$ cd BackgroundSubtractorCNT
$ mkdir build
$ cd build
```

---

## 2. Otras configuraciones

### 2.1. Remot3 configuration

#### Referencias

- [1] Adafruit's Raspberry Pi Lesson 3. Network Setup.
- [2] Remote Manage Networked Devices Anywhere, Remot3