

Home

Learn

- [Learn Home](#)
- ▶ [Propeller BOE Tutorials](#)
- ▶ [BOE Shield Tutorials](#)
- [Microcontroller KickStarts](#)
- [Reference](#)

BASIC Stamp Resources

[Download the BASIC Stamp Editor](#) ▶

[Connect & Test your Board](#) ▶

[Connection Troubleshooting](#) ▶

[PBASIC Language Reference](#) ▶

[Buy a BASIC Stamp kit](#) ▶

[What's a Microcontroller?](#) ▶

[Robotics with the Boe-Bot](#) ▶

Propeller BOE Resources

[Buy a Propeller Board of Education](#) ▶

[Download Propeller Tool Software](#) ▶

[Open the Propeller Q & A](#) ▶

BOE Shield Resources

[Buy a BOE Shield](#) ▶


[Download Arduino Software](#) ▶

[Open Arduino Reference](#) ▶

[Download ROBOTC for Arduino](#) ▶

Gyroscope Module 3-Axis L3G4200D

Submitted by Gordon McComb on Thu, 05/10/2012 - 13:46




Item code: 27911

What It Can Do

- Modular angular rate sensor tracks motion in three axes
- Three selectable measurement scales, with rates up to 2000° per second
- Built-in temperature sensor; can be used separately, or for temperature drift compensation

The 3-Axis Gyroscope module provides separate data values for yaw, pitch, and roll. Motion is indicated as a positive or negative value, depending on the direction of rotation. The sensor is useful in 3D simulation, virtual gaming input devices, robotics, and for remotely controlled or unpiloted aircraft and submersibles.



Gyroscopes are commonly used with multi-axis accelerometers, where the data from both sensors can provide useful information detailing speed and direction of travel. The [Memsic 2125 Dual-axis Accelerometer](#) and [MMA7455 3-Axis Accelerometer Module](#) are good companion accelerometers for the 3-Axis Gyroscope module.


Parts List

- 3-Axis Gyroscope module
- BASIC Stamp HomeWork Board, Propeller BOE, Propeller QuickStart, or Arduino Uno microcontroller (with breadboard, as needed)
- 22 gauge solid conductor hookup wire

Basic Wiring

Microcontroller KickStarts

- [Microcontroller KickStarts Home](#)
- [2-Axis Joystick](#)
- [2x16 Serial LCD \(Backlit\) with Speaker](#)
- [4-Directional Tilt Sensor](#)
- [5-Position Switch](#)
- [Altimeter Module](#)
- [Compass Module 3-Axis](#)
- [GPS Module PMB-648](#)
- [Gyroscope Module 3-Axis](#)
- [Memsic 2125 Dual-axis Accelerometer](#)
- [PING\)\)\) Ultrasonic Distance Sensor](#)
- [PIR Sensor](#)
- [Parallax Continuous Rotation Servo](#)
- [Parallax Standard Servo](#)
- [Polar Heart Rate Receiver](#)
- [QTI Sensor](#)
- [Sound Impact Sensor](#)
- [XBee Wireless Pack](#)
- [Using Arduino Object Libraries](#)
- [Using Propeller Objects](#)
- [Using the Parallax Serial Terminal](#)




- Power Requirements: 2.7 to 6.5 VDC
- Communication Interface: I2C (up to 400 kHz) or SPI (10 MHz; 4 & 3 wire)
- Dimensions: 0.85 X 0.80 in (2.16 X 2.03 cm)

Program KickStarts

The KickStart examples display raw data output for each of the three axes. Values are retrieved from the module using the I2C interface.

BASIC Stamp HomeWork Board



Download BASIC Stamp 2 code for the 3-Axis Gyroscope Module

```
' {$STAMP BS2}
' {$PBASIC 2.5}

SDA      PIN    0      ' SDA of gyro connected to P0
SCL      PIN    1      ' SCL of gyro connected to P1

WRITE_Data  CON    $D2  ' Request Write operation
READ_Data   CON    $D3  ' Request Read operation

' Control registers
CTRL_REG1  CON    $20
CTRL_REG2  CON    $21
CTRL_REG3  CON    $22
CTRL_REG4  CON    $23
STATUS_REG CON    $27
OUT_X_INC  CON    $A8

X          VAR    Word
Y          VAR    Word
Z          VAR    Word
rawl       VAR    Word
rawh       VAR    Word

' Variables for I2C communications
I2C_DATA   VAR    Byte
I2C_LSB    VAR    Bit
I2C_REG    VAR    Byte
I2C_VAL    VAR    Byte

PAUSE 100          ' Power up delay

' Set up data ready signal
I2C_REG = CTRL_REG3
I2C_VAL = $08
GOSUB I2C_Write_Reg

' Set up "block data update" mode
I2C_REG = CTRL_REG4
I2C_VAL = $80
GOSUB I2C_Write_Reg

' Send the get continuous output command
I2C_REG = CTRL_REG1
I2C_VAL = $1F
GOSUB I2C_Write_Reg
```

```

DO
  GOSUB Gyro_Get_Raw                                ' Get XYZ data

  ' Divide X Y Z, by 114 to reduce noise
  IF (X.BIT15) THEN
    X = (ABS X) / 114
    X = -X
  ELSE
    X = X / 114
  ENDIF
  IF (Y.BIT15) THEN
    Y = (ABS Y) / 114
    Y = -Y
  ELSE
    Y = Y / 114
  ENDIF
  IF (Z.BIT15) THEN
    Z = (ABS Z) / 114
    Z = -Z
  ELSE
    Z = Z / 114
  ENDIF

  DEBUG HOME, "RAW X = ",11, SDEC X, CR    ' Display data
  DEBUG "RAW Y = ",11, SDEC Y, CR
  DEBUG "RAW Z = ",11, SDEC Z, CR

  PAUSE 250

LOOP

Gyro_Get_Raw:
  GOSUB Wait_For_Data_Ready

  GOSUB I2C_Start

  I2C_DATA = WRITE_DATA
  GOSUB I2C_Write                                ' Read the data starting
  I2C_DATA = OUT_X_INC                            ' at pointer register
  GOSUB I2C_Write

  GOSUB I2C_Stop

  GOSUB I2C_Start
  I2C_DATA = READ_DATA
  GOSUB I2C_Write

  GOSUB I2C_Read
  rawL = I2C_DATA                                ' Read high byte
  GOSUB I2C_ACK

  GOSUB I2C_Read
  rawH = I2C_DATA                                ' Read low byte
  GOSUB I2C_ACK
  X = (rawH <&lt; 8) | rawL                        ' OR high and low into X

  ' Do the same for Y and Z:
  GOSUB I2C_Read
  rawL = I2C_DATA
  GOSUB I2C_ACK

  GOSUB I2C_Read
  rawH = I2C_DATA
  GOSUB I2C_ACK
  Y = (rawH <&lt; 8) | rawL

  GOSUB I2C_Read
  rawL = I2C_DATA
  GOSUB I2C_ACK

  GOSUB I2C_Read
  rawH = I2C_DATA
  GOSUB I2C_NACK
  Z = (rawH << 8) | rawL

  GOSUB I2C_Stop

RETURN

'-----I2C functions-----
' Read the status register until the ZYXDA bit is high
Wait_For_Data_Ready:
DO
  I2C_REG = STATUS_REG
  GOSUB I2C_Read_Reg
LOOP UNTIL ((I2C_DATA & $08) <> 0)
RETURN

' Set I2C_REG & I2C_VAL before calling this
I2C_Write_Reg:
  GOSUB I2C_Start
  I2C_DATA = WRITE_DATA
  GOSUB I2C_Write
  I2C_DATA = I2C_REG
  GOSUB I2C_Write
  I2C_DATA = I2C_VAL
  GOSUB I2C_Write

```

```

    GOSUB I2C_Stop
    RETURN

' Set I2C_REG before calling this, I2C_DATA will have result
I2C_Read_Reg:
    GOSUB I2C_Start
    I2C_DATA = WRITE_DATA
    GOSUB I2C_Write
    I2C_DATA = I2C_REG
    GOSUB I2C_Write
    GOSUB I2C_Stop
    GOSUB I2C_Start
    I2C_DATA = READ_DATA
    GOSUB I2C_Write
    GOSUB I2C_Read
    GOSUB I2C_NACK
    GOSUB I2C_Stop
    RETURN

I2C_Start:
    LOW SDA
    LOW SCL
    RETURN

I2C_Stop:
    LOW SDA
    INPUT SCL
    INPUT SDA
    RETURN

I2C_ACK:
    LOW SDA
    INPUT SCL
    LOW SCL
    INPUT SDA
    RETURN

I2C_NACK:
    INPUT SDA
    INPUT SCL
    LOW SCL
    RETURN


I2C_Read:
    SHIFTIN SDA, SCL, MSBPPE, [I2C_DATA]
    RETURN

I2C_Write:
    I2C_LSB = I2C_DATA.BIT0
    I2C_DATA = I2C_DATA / 2
    SHIFTOUT SDA, SCL, MSBFIRST, [I2C_DATA\7]
    IF I2C_LSB THEN INPUT SDA ELSE LOW SDA
    INPUT SCL
    LOW SCL
    INPUT SDA
    INPUT SCL
    LOW SCL
    RETURN


```

When this program is run the BASIC Stamp Debug Terminal will automatically open.

Propeller BOE and Propeller QuickStart



Propeller BOE Wiring Diagram



Propeller QuickStart Wiring Diagram

Download Propeller Spin code for the 3-Axis Gyroscope Module

```

OBJ

pst          : "FullDuplexSerial"

CON

_clkmode     = xtall + pll16x
_clkfreq     = 80_000_000

SDApin       = 0           ' SDA of gyro connected to P0
SCLpin       = 1           ' SCL of gyro connected to P1

WRITE        = $D2         ' Request Write operation
READ         = $D3         ' Request Read operation

' Control registers
CTRL_REG1    = $20
CTRL_REG2    = $21
CTRL_REG3    = $22
CTRL_REG4    = $23
STATUS_REG   = $27
OUT_X_INC    = $A8

x_idx = 0
y_idx = 1
z_idx = 2

VAR

long x
long y
long z

long cx
long cy
long cz

long ff_x
long ff_y
long ff_z

long multiBYTE[3]

PUB Go | last_ticks

pst.start(31, 30, 0, 115200)

' Set modes
Wrt_1B(CTRL_REG3, $08)           ' Data ready signal
Wrt_1B(CTRL_REG4, $80)           ' Block data update
Wrt_1B(CTRL_REG1, $1F)           ' Enable all axes

last_ticks := cnt

repeat
    pst.tx(1)                     ' Set Terminal data
    WaitForDataReady              ' at top of screen
    Read_MultiB(OUT_X_INC)        ' Read XYZ bytes

    ' Divide by 114 to reduce noise
    x := (x - cx) / 114
    y := (y - cy) / 114
    z := (z - cz) / 114

RawXYZ

```

```

        WaitCnt(ClkFreq / 4 + Cnt)                ' Delay before next loop

PUB RawXYZ
'Display Raw X,Y,Z data

pst.str(string("RAW X ",11))
pst.dec(x)

pst.str(string(13, "RAW Y ",11))
pst.dec(y)

pst.str(string(13, "RAW Z ",11))
pst.dec(z)

'' Below here routines to support I2C interfacing

PUB WaitForDataReady | status
repeat
    status := Read_1B(STATUS_REG)
    if (status & $08) == $08
        quit

PUB Wrt_1B(SUB1, data)
''Write single byte to Gyroscope.

    start
    send(WRITE)
    send(SUB1)
    send(data)
    stop

PUB Read_1B(SUB3) | rxd
''Read single byte from Gyroscope

    start
    send(WRITE)
    send(SUB3)
    stop

    start
    send(READ)
    rxd := receive(false)
    stop

    result := rxd

PUB Read_MultiB(SUB3)
''Read multiple bytes from Gyroscope

    start
    send(WRITE)
    send(SUB3)
    stop

    start
    send(READ)
    multiBYTE[x_idx] := (receive(true)) | (receive(true)) << 8
    multiBYTE[y_idx] := (receive(true)) | (receive(true)) << 8
    multiBYTE[z_idx] := (receive(true)) | (receive(false)) << 8
    stop

    x := ~multiBYTE[x_idx]
    y := ~multiBYTE[y_idx]
    z := ~multiBYTE[z_idx]

PRI send(value)

value := ((!value) >< 8)

repeat 8
    dira[SDApin]      := value
    dira[SCLpin]      := false
    dira[SCLpin]      := true
    value >= 1

    dira[SDApin]      := false
    dira[SCLpin]      := false
    result            := not(ina[SDApin])
    dira[SCLpin]      := true
    dira[SDApin]      := true

PRI receive(aknowledge)

dira[SDApin]          := false

repeat 8
    result <= 1
    dira[SCLpin]        := false
    result              |= ina[SDApin]
    dira[SCLpin]        := true

    dira[SDApin]        := (aknowledge)
    dira[SCLpin]        := false
    dira[SCLpin]        := true
    dira[SDApin]        := true

PRI start

```

```

outa[SDApin]      := false
outa[SCLpin]      := false
dira[SDApin]      := true
dira[SCLpin]      := true


PRI stop

dira[SCLpin]      := false
dira[SDApin]      := false

```

To view the results of the demonstration, after uploading is complete run the Parallax Serial Terminal from the Run menu, or press F12. Click the Enable button in the Terminal window, then momentarily depress the Reset button on the Propeller QuickStart board to restart the program.

Arduino Uno



[Download Arduino 1.0 Code for the 3-Axis Gyroscope Module](#)

[Download Arduino Pre-release Version Code for the 3-Axis Gyroscope Module](#)

```

#include <Wire.h>

#define CTRL_REG1 0x20
#define CTRL_REG2 0x21
#define CTRL_REG3 0x22
#define CTRL_REG4 0x23

int Addr = 105;          // I2C address of gyro
int x, y, z;

void setup(){
  Wire.begin();
  Serial.begin(9600);
  writeI2C(CTRL_REG1, 0x1F); // Turn on all axes, disable power down
  writeI2C(CTRL_REG3, 0x08); // Enable control ready signal
  writeI2C(CTRL_REG4, 0x80); // Set scale (500 deg/sec)
  delay(100);              // Wait to synchronize
}

void loop(){
  getGyroValues();         // Get new values
  // In following Dividing by 114 reduces noise
  Serial.print("Raw X:"); Serial.print(x / 114);
  Serial.print(" Raw Y:"); Serial.print(y / 114);
  Serial.print(" Raw Z:"); Serial.println(z / 114);
  delay(500);              // Short delay between reads
}

void getGyroValues () {
  byte MSB, LSB;

  MSB = readI2C(0x29);
  LSB = readI2C(0x28);
  x = ((MSB << 8) | LSB);

  MSB = readI2C(0x2B);
  LSB = readI2C(0x2A);
  y = ((MSB << 8) | LSB);

  MSB = readI2C(0x2D);
  LSB = readI2C(0x2C);
  z = ((MSB << 8) | LSB);
}

int readI2C (byte regAddr) {
  Wire.beginTransmission(Addr);
  Wire.write(regAddr);          // Register address to read

```

```
Wire.endTransmission();           // Terminate request
Wire.requestFrom(Addr, 1);        // Read a byte
while(!Wire.available()) { };      // Wait for receipt
return(Wire.read());               // Get result
}

void writeI2C (byte regAddr, byte val) {
  Wire.beginTransmission(Addr);
  Wire.write(regAddr);
  Wire.write(val);
  Wire.endTransmission();
}
```

To view the results of the demonstration, after uploading is complete click the Serial Monitor icon in the Arduino IDE. This displays the Serial Monitor window. Momentarily depress the Reset button on the Arduino board to restart the sketch.

For More Information

Useful links:

- [3-Axis Gyroscope data sheet](#)
- More information on gyroscopes and inertial navigation may be found on [Wikipedia: Gyroscope](#)

Copyright: Creative Commons 3.0 SA license

[Printer-friendly version](#)

Terms of Use ♦ Feedback: learn@parallax.com

Copyright©Parallax Inc. 2012 (unless otherwise noted)