

# **gputils 0.12.0**

**James Bowman and Craig Franklin**

**January**

# Contents

<b>1</b>	<b>Introduction</b>	<b>4</b>
1.1	Tool Flows	

2.8.2	Function . . . . .	13
2.9	Files . . . . .	13
2.9.1	Module . . . . .	13
2.9.2	Public . . . . .	13
2.9.3	With . . . . .	13
2.10	Code Generation . . . . .	13
2.10.1	Phases . . . . .	13
2.10.2	Expression Evaluation . . . . .	14
2.10.3	COFF sections . . . . .	14
2.10.4	Name mangling . . . . .	14
2.11	Coding Suggestions . . . . .	15

<i>CONTENTS</i>	3
<b>6 Utilities</b>	<b>40</b>
6.1 gpdasm . . . . .	40
6.1.1 Running gpdasm . . . . .	40
6.1.2 Comments	

# Chapter 1

## Introduction

gputils is a collection of tools for Microchip (TM) PIC microcontrollers. It includes gpal, gpasm, gplink, and gplib. Each tool is intended to be an open source replacement for a corresponding Microchip (TM) tool. This manual covers the basics of running the tools. For more details on a microcontroller, consult the manual for the specific PICmicro product that you are using.

This document is part of gputils.

gputils is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation; either version 2, or (at your option) any later version.

gputils is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY;



# Chapter 2

## gpal

### 2.1 Introduction

gpal is a compiler for Microchip

a PIC executable or gplib to produce an





2.5.2 Numbers

gpal uses decimal as its default radix. The following table

summarizes other supported num

base	general syntax	21 decimal written as
------	----------------	-----------------------

## 2.6 Statements

### 2.6.1 If

```
if <expression> then
  <statements>
[elsif <expression> then
  <statements>]*
[else
  <statements>]?
end if;
```

The statements in each block are executed if the expression is true. Here is an example:

```
if i < 10 then
  j = 5;
elsif
```













## Chapter 3

### **3.1.1 Using gpasm with “make”**

On most operating systems, you can build a project using the make utility.



base	general syntax	21 decimal written as

















**MACRO**

```
<label> MACRO [ <symbol> [ , <symbol> ]* ]
```

Declares a macro with name <label>. gpasm replaces any occurrences of <symbol> in the macro definition with the parameters given at macro invocation.

See also: LOCAL, ENDM

**MESSG**

```
MESSG <string>
```

Writes <string> to the list file, and to the standard error output.

See also: ERROR

**NOEXPAND**

```
NOEXPAND
```

Turn off macro expansion in the list file.

See also: EXPAND

**NOLIST**

```
NOLIST
```

Disables list file output.

See also: LIST

**ORG**

```
ORG <expression>
```

Sets the location at which instructions will be placed. If the source file does not specify an address with ORG, gpasm assumes an ORG of zero.

**PAGE**

```
PAGE
```

Causes the list file to advance to the next page.

See also: LIST

**PAGESEL**

```
PAGESEL <label>
```

```
GOTO <label>
```

the label is a Reselectingselecti(e)Tj 6.83391 0 Td

This directive will generate page selecting code to set the page bits to the page containing <label>

**PROCESSOR**

PROCESSOR <symbol>

Selects the target processor. See section ?? for more details.

See also: LIST

**RADIX**

RADIX <symbol>

Selects the default radix from “oct” for octal, “dec” “dec”

**UDATA\_ACS**

```
<label> UDATA_ACS <expression>
```

Only for relocatable mode. Creates a new uninitialized accessbank data section in the output object file. <label> specifies the name of the section. If <label> is not specified the default name “.udata\_acs” will be used. <expression> is optional and specifies the absolute address of the section.

See also: CODE, IDATA, UDATA

**UDATA\_OVR**

```
<label> UDATA_OVR <expression>
```

Only for relocatable mode. Creates a new uninitialized overlaid data section in the output object file. <label> specifies the name of the section. If <label> is not specified the default name “.udata\_ovr” will be used. <expression> is optional and specifies the absolute address of the section.

See also: CODE, IDATA, UDATA

**UDATA\_SHR**

```
<label> UDATA_SHR <expression>
```

Only for relocatable mode. Creates a new uninitialized sharebank data section in the output object file. <label> specifies the name of the section. If <label> is not specified the default name “.udata\_shr” will be used. <expression> is optional and specifies the absolute address of the section.

See also: CODE, IDATA, UDATA

**VARIABLE**

```
VARIABLE <label>[=<expression>, <label>[=<expression>]]*
```

Declares variable with the name <label>. The value of <label> may later be reassigned. The value of <label> does not have to be assigned at declaration.

See also: CONSTANT

**WHILE**

```
WHILE <expression>
```

Performs loop while <expression> is true.

See also: ENDW

**3.4 Instructions**

### 3.4.1 Instruction set summary

#### 12 bit Devices (PIC12C5XX)

Syntax	Description
ADDWF <f>,<dst>	Add W

## *CHAPTER 3.*



Spe

The s are:

SETZ	Set zero
MOVFW <f>	Move file to W
NEGF <f>	

**115 Duplicate Label**

Duplicate label or redefining a symbol that can not be redefined.

**124 Illegal Argument**

gpasm encountered an illegal argument in an expression.

**125 Illegal Condition**

An illegal condition like a missing ENDIF or ENDW has been encountered.

**126 Argument out of**

### **3.5.2 Warnings**

**201**

The ID locations value specified is too large.

**305** Using default destination of

# Chapter

If the user does not specify a linker script, gplink will

## **Chapter 5**

# **gplib**

gplib creates, modifies and extracts COFF archi





# Chapter 6

## Utilities

### 6.1 gpdasm

gpdasm is a disassembler for gputils. It converts hex files generated by gpasm and gplink into disassembled instructions.

#### 6.1.1 Running gpdasm

The general syntax for running gpdasm is

```
gpdasm [options] hex-file
```

Where options can be one of:

Option	Meaning
h	Display the help message.
i	Display hex file information
l	List supported processors.
m	Memory dump hex file.
p<processor>	Select processor
s	

--	--

## 6.2 gpvc

gpvc is cod file viewer for gputils. It provides an easy way to view the contents of the cod files generated by gpasm and gplink.

### 6.2.1 Running gpvc

The general syntax for running gpvc is

```
gpvc [options] cod-file
```

Where options can be one of:

Option	Meaning
a	Display all information
d	Display directory header
s	Display symbols
h	Show the help message.
r	Display ROM
l	Display source listing
m	Display debug message area
v	Print gpvc version information and exit.

| |

# Index

Archive format, 39  
ASCII, 19

BADRAM, 21  
BANKISEL, 22  
BANKSEL, 22  
bash, 17, 40, 41

case, 16  
CBLOCK, 22  
character, 19  
CODE, 23  
comments, 17  
CONFIG, 22  
CONSTANT

UDATA, 28  
UDATA ACS, 29  
UDATA OVR, 29  
UDATA SHR, 29  
  
VARIABLE, 29  
  
WHILE, 29