



Elektrobit



UDACITY

Technical Safety Concept Lane Assistance

Document Version: [Version]

Template Version 1.0, Released on 2017-06-21



Document history

| Date | Version | Editor | Description |
|------------|---------|--------------|------------------------|
| 06/13/2018 | 1.0 | Swapnil More | First Draft |
| 06/15/2018 | 1.1 | Swapnil More | Updates to First Draft |
| | | | |
| | | | |
| | | | |

Table of Contents

[Document history](#)

[Table of Contents](#)

[Purpose of the Technical Safety Concept](#)

[Inputs to the Technical Safety Concept](#)

[Functional Safety Requirements](#)

[Refined System Architecture from Functional Safety Concept](#)

[Functional overview of architecture elements](#)

[Technical Safety Concept](#)

[Technical Safety Requirements](#)

[Refinement of the System Architecture](#)

[Allocation of Technical Safety Requirements to Architecture Elements](#)

[Warning and Degradation Concept](#)

Purpose of the Technical Safety Concept


The purpose of the technical safety concept is to look at the item from a system-level perspective, refine the functional safety requirements as technical safety requirements. It is defined in the product development phase as it is more concrete and gets into the details of the item's technology. It assigns functions to specific sub-level of the systems according to ISO 26262.

Inputs to the Technical Safety Concept

Functional Safety Requirements

| ID | Functional Safety Requirement | ASIL | Fault Tolerant Time Interval | Safe State |
|-------------------------------------|--|------|------------------------------|--|
| Functional Safety Requirement 01-01 | The electronic power steering ECU shall ensure that the lane departure oscillating torque amplitude is below Max_Torque_Amplitude. | C | 50 ms | Vibration torque amplitude below Max_Torque_Amplitude. |
| Functional Safety Requirement 01-02 | The electronic power steering ECU shall ensure that the lane departure oscillating torque frequency is below Max_Torque_Frequency. | C | 50 ms | Vibration frequency is below Max_Torque_Frequency. |
| Functional Safety Requirement 02-01 | The electronic power steering ECU shall ensure that the Lane Keeping Assistance torque is applied only Max_Assist_Time | B | 500 ms | Assistance time is below Max_Assist_Time |

Refined System Architecture from Functional Safety Concept



Functional overview of architecture elements

| Element | Description |
|---|--|
| Camera Sensor | Capture images and send them to the Camera Sensor ECU |
| Camera Sensor ECU - Lane Sensing | Process Images to detect lane lines and calculate vehicle position w.r.t. the lane lines |
| Camera Sensor ECU - Torque request generator | Calculate the torque required to maintain vehicle in the lane. |
| Car Display | Display the Lane Departure Warning and status of the Lane Assistance System |
| Car Display ECU - Lane Assistance On/Off Status | Identify the status of the Lane Assistance System (ON/OFF) |
| Car Display ECU - Lane Assistant Active/Inactive | Identify the status of the Lane Assistance System (Active/Inactive) |
| Car Display ECU - Lane Assistance malfunction warning | Identify Lane Assistance Malfunction |

| | |
|--|---|
| Driver Steering Torque Sensor | Measure the torque applied to the steering wheel by the driver. |
| Electronic Power Steering (EPS) ECU - Driver Steering Torque | Software module receiving the driver's torque request from the steering wheel. |
| EPS ECU - Normal Lane Assistance Functionality | Software module receiving the Camera Sensor ECU torque request. |
| EPS ECU - Lane Departure Warning Safety Functionality | Software module ensuring the torque amplitude is below Max_Torque_Amplitude and torque frequency is below Max_Torque_Frequency. |
| EPS ECU - Lane Keeping Assistant Safety Functionality | Software module ensuring the Lane Keeping Assistance functionality application is not activate more than Max_Assist_Time time. |
| EPS ECU - Final Torque | Combine the torque request from the Lane Keeping and Lane Departure Warning functionalities and sends them to the Motor. |
| Motor | Applies the required torque to the steering wheel |

Technical Safety Concept

Technical Safety Requirements

Lane Departure Warning (LDW) Requirements:

Functional Safety Requirement 01-01 with its associated system elements
(derived in the functional safety concept)

| ID | Functional Safety Requirement | Electronic Power Steering ECU | Camera ECU | Car Display ECU |
|-------------------------------------|---|-------------------------------|------------|-----------------|
| Functional Safety Requirement 01-01 | The lane keeping item shall ensure that the lane departure oscillating torque amplitude is below Max_Torque_Amplitude | X | | |

Technical Safety Requirements related to Functional Safety Requirement 01-01 are:

| ID | Technical Safety Requirement | ASIL | Fault Tolerant Time Interval | Architecture Allocation | Safe State |
|---------------------------------------|--|------|------------------------------|-----------------------------------|---|
| Technical Safety Requirement 01-01-01 | The LDW safety component shall ensure that the amplitude of the 'LDW_Torque_Request' sent to the 'Final electronic power steering Torque' component is below 'Max_Torque_Amplitude.' | C | 50 ms | LDW Safety | Lane Departure Warning Torque Request Amplitude shall be set to zero. |
| Technical Safety Requirement 01-01-02 | When the LDW is deactivated, the 'LDW Safety' software module shall send a signal to the Car Display ECU to turn on a warning signal. | C | 50 ms | LDW Safety | Lane Departure Warning Torque Request Amplitude shall be set to zero. |
| Technical Safety Requirement 01-01-03 | When a failure is detected by the Lane Departure Warning functionality, it shall deactivate the Lane Departure Warning feature and set 'LDW_Torque_Request' to zero. | C | 50 ms | LDW Safety | Lane Departure Warning Torque Request Amplitude shall be set to zero. |
| Technical Safety Requirement 01-01-04 | The validity and integrity of the data transmission for 'LDW_Torque_Request' signal shall be ensured. | C | 50 ms | Data Transmission Integrity Check | Lane Departure Warning Torque Request Amplitude shall be set to zero. |
| Technical | Memory test shall be | A | Ignition | Memory Test | Lane |

| | | | | | |
|--------------------------------|--|--|-------|--|--|
| Safety Requirement 01-01-05 | conducted at startup of the EPS ECU to check for any memory problems | | cycle | | Departure Warning Torque Request Amplitude shall be set to zero. |
|--------------------------------|--|--|-------|--|--|

Functional Safety Requirement 01-02 with its associated system elements
(derived in the functional safety concept)

| ID | Functional Safety Requirement | Electronic Power Steering ECU | Camera ECU | Car Display ECU |
|-------------------------------------|---|-------------------------------|------------|-----------------|
| Functional Safety Requirement 01-02 | The lane keeping item shall ensure that the lane departure oscillating torque frequency is below Max_Torque_Frequency | X | | |

Technical Safety Requirements related to Functional Safety Requirement 01-02 are:

| ID | Technical Safety Requirement | ASIL | Fault Tolerant Time Interval | Architecture Allocation | Safe State |
|---------------------------------------|--|------|------------------------------|-------------------------|---|
| Technical Safety Requirement 01-02-01 | The Lane Departure Warning safety component shall ensure the frequency of the 'LDW_Torque_Request' sent to the 'Final electronic power steering Torque' component is below 'Max_Torque_Frequency.' | C | 50 ms | LDW Safety | Lane Departure Warning Torque Request Frequency shall be set to zero. |
| Technical Safety Requirement 01-02-02 | When the LDW is deactivated, the 'LDW Safety' software module | C | 50 ms | LDW Safety | Lane Departure Warning Torque |

| | | | | | |
|---------------------------------------|--|---|----------------|-----------------------------------|---|
| | shall send a signal to the Car Display ECU to turn on a warning signal. | | | | Request Frequency shall be set to zero. |
| Technical Safety Requirement 01-02-03 | When a failure is detected by the Lane Departure Warning functionality, it shall deactivate the Lane Departure Warning feature and set 'LDW_Torque_Request' to zero. | C | 50 ms | LDW Safety | Lane Departure Warning Torque Request Frequency shall be set to zero. |
| Technical Safety Requirement 01-02-04 | The validity and integrity of the data transmission for 'LDW_Torque_Request' signal shall be ensured. | C | 50 ms | Data Transmission Integrity Check | Lane Departure Warning Torque Request Frequency shall be set to zero. |
| Technical Safety Requirement 01-02-05 | Memory test shall be conducted at startup of the EPS ECU to check for any memory problems | A | Ignition cycle | Memory Test | Lane Departure Warning Torque Request Frequency shall be set to zero. |

Lane Departure Warning (LDW) Verification and Validation Acceptance Criteria:

| ID | Validation Acceptance Criteria and Method | Verification Acceptance Criteria and Method |
|---------------------------------------|--|--|
| Technical Safety Requirement 01-01-01 | Validate the Max_Torque_Amplitude is the chosen from the Lane Departure Warning Validation | Verify the Lane Departure Warning functionality is turned off. |
| Technical Safety | Validate the 'TORQUE_LIMITER' sends the | Verify the Car Display ECU displays the Lane Departure |

| | | |
|--|---|---|
| Requirement 01-01-02 | error_status_torque_limiter signal to the LDW_SAFETY_ACTIVATION. | Warning malfunction warning signal. |
| Technical Safety Requirement 01-01-03 | Validate the 'TORQUE_LIMITER' sends 'LDW_Torque_Request' with zero. | Verify the Final EPS Torque generator receives a LDW_Torque_Request of zero. |
| Technical Safety Requirement 01-01-04 | Validate the 'TORQUE_LIMITER' calculate and sends the correct cyclic redundancy check (CRC) and Alive counter for data transmission validity and integrity. | Verify the functionality is turn off if there is a CRC or Alive counter discrepancy. |
| Technical Safety Requirement 01-01-05 | Validate the Safety Startup Memory test to check memory faults catch memory faults. | Verify the Lane Departure Warning is turned off when the Safety Startup Memory fails. |
| Technical Safety Requirement 01-02-01 | Validate the Max_Torque_Frequency set is chosen from the Lane Departure Warning Acceptance Criteria. | Max_Torque_Request. |

Lane Keeping Assistance (LKA) Requirements:

Functional Safety Requirement 02-1 with its associated system elements
(derived in the functional safety concept)

| ID | Functional Safety Requirement | Electronic Power Steering ECU | Camera ECU | Car Display ECU |
|-------------------------------------|---|-------------------------------|------------|-----------------|
| Functional Safety Requirement 02-01 | The lane keeping item shall ensure that the lane keeping assistance torque is applied for only Max_Duration | X | | |

Technical Safety Requirements related to Functional Safety Requirement 02-01 are:

| ID | Technical Safety Requirement | A S | Fault Tolerant | Allocation to Architecture | Safe State |
|----|------------------------------|-----|----------------|----------------------------|------------|
|----|------------------------------|-----|----------------|----------------------------|------------|


| | | I L | Time Interval | | |
|--|--|--------|------------------|-----------------------------------|--|
| Technical Safety Requirement 02-01-01 | The Lane Keeping Assistance safety component shall ensure the duration of the lane keeping assistance torque is applied for less than Max_Duration | B | 500 ms | LKA Safety | Lane Keeping Assistance Torque shall be set to zero. |
| Technical Safety Requirement 02-01-02 | When the Lane Keeping Assistance function deactivates, the 'LKA Safety' shall send a signal to the Car Display ECU to turn on a warning light. | B | 500 ms | LKA Safety | Lane Keeping Assistance Torque shall be set to zero. |
| Technical Safety Requirement 02-01-03 | When a failure is detected, the Lane Keeping Assistance function shall deactivate and the 'LKA_Torque_Request' shall be zero. | B | 500 ms | LKA Safety | Lane Keeping Assistance Torque shall be set to zero. |
| Technical Safety Requirement 02-01-04 | The validity and integrity of the data transmission for 'LKA_Torque_Request' signal shall be ensured. | B | 500 ms | Data Transmission Integrity Check | Lane Keeping Assistance Torque shall be set to zero. |
| Technical Safety Requirement 02-01-05 | Memory test shall be conducted at startup of the EPS ECU to check for any memory problems | A | Ignition cycle | Memory Test | Lane Keeping Assistance Torque shall be set to zero. |

Lane Keeping Assistance (LKA) Verification and Validation Acceptance Criteria:

| ID | Validation Acceptance Criteria and Method | Verification Acceptance Criteria and Method |
|--|--|--|
| Technical Safety Requirement 02-01-01 | Validate the Max_Duration is set to the chosen value from LKA Validation Assistance Criteria | Verify the functionality is turned off after it is applied for Max_Duration. |
| Technical | Validate the 'TORQUE_LIMITER' | Verify the Car Display ECU displays |

| | | |
|---------------------------------------|---|--|
| Safety Requirement 02-01-02 | sends the error_status_torque_limiter signal to the LKA_SAFETY_ACTIVATION. | the Lane Keeping Assistance malfunction warning signal. |
| Technical Safety Requirement 02-01-03 | Validate the 'TORQUE_LIMITER' sends 'LKA_Torque_Request' with zero. | Verify the Final EPS Torque generator receives a LKA_Torque_Request of zero. |
| Technical Safety Requirement 02-01-04 | Validate the 'TORQUE_LIMITER' calculate and sends the correct cyclic redundancy check (CRC) and Alive counter for data transmission validity and integrity. | Verify the functionality is turn off if there is a CRC or Alive counter discrepancy. |
| Technical Safety Requirement 02-01-05 | Validate the Safety Startup Memory test to check memory faults catch memory faults. | Verify the Lane Keeping Assistance is turned off when the Safety Startup Memory fails. |

Refinement of the System Architecture



Allocation of Technical Safety Requirements to Architecture Elements

| ID | Technical Safety Requirement | Electronic Power Steering ECU | Camera ECU | Car Display ECU |
|---------------------------------------|---|-------------------------------|------------|-----------------|
| Technical Safety Requirement 01-01-01 | The Lane Departure Warning safety component shall ensure that the amplitude of the 'LDW_Torque_Request' sent to the 'Final electronic power steering Torque' component is below 'Max_Torque_Amplitude.' | X | | |
| Technical Safety Requirement 01-01-02 | When the Lane Departure Warning is deactivated, the 'LDW Safety' software module shall send a signal to the Car Display ECU to turn on a warning signal. | X | | |
| Technical Safety Requirement 01-01-03 | When a failure is detected by the Lane Departure Warning functionality, it shall deactivate the Lane Departure Warning feature and set 'LDW_Torque_Request' to zero. | X | | |
| Technical Safety Requirement 01-01-04 | The validity and integrity of the data transmission for 'LDW_Torque_Request' signal shall be ensured. | X | | |
| Technical Safety Requirement 01-01-05 | Memory test shall be conducted at startup of the EPS ECU to check for any memory problems | X | | |
| Technical Safety Requirement 01-02-01 | The Lane Departure Warning safety component shall ensure the frequency of the 'LDW_Torque_Reques' sent to the 'Final electronic power | X | | |

| | | | | |
|---------------------------------------|--|---|--|--|
| | steering Torque' component is below 'Max_Torque_Frequency.' | | | |
| Technical Safety Requirement 02-01-01 | The Lane Keeping Assistance safety component shall ensure the duration of the lane keeping assistance torque is applied for less than Max_Duration | X | | |
| Technical Safety Requirement 02-01-02 | When the Lane Keeping Assistance function deactivates, the 'LKA Safety' shall send a signal to the Car Display ECU to turn on a warning light. | X | | |
| Technical Safety Requirement 02-01-03 | When a failure is detected, the Lane Keeping Assistance function shall deactivate and the 'LKA_Torque_Request' shall be zero. | X | | |
| Technical Safety Requirement 02-01-04 | The validity and integrity of the data transmission for 'LKA_Torque_Request' signal shall be ensured. | X | | |
| Technical Safety Requirement 02-01-05 | Memory test shall be conducted at start up of the EPS ECU to check for any memory problems | X | | |

Warning and Degradation Concept

| ID | Degradation Mode | Trigger for Degradation Mode | Safe State invoked? | Driver Warning |
|--------|---|--|---------------------|--|
| WDC-01 | Turn off Lane Departure Warning functionality | Malfunction_01, Malfunction_02, Malfunction_05 | Yes | Lane Departure Warning Malfunction Warning on Car Display |
| WDC-02 | Turn off Lane Keeping | Malfunction_03, Malfunction_04 | Yes | Lane Keeping Assistance |

| | | | | |
|--|-----------------------------|--|--|--|
| | Assistance functionality | | | Malfunction Warning on Car Display |
|--|-----------------------------|--|--|--|