

Safe Watchdog Interface Safety Manual

| | |
|-------------------------|------------------------|
| Author: | TTTech Automotive GmbH |
| Security: | Company Confidential |
| Document number: | D-SAFEX-S-70-005 |
| Version: | 1.8.9 |
| Date: | 22.05.2014 |
| Status: | ALM_Published |
| MKS ID: | 232906 |

TTTech Automotive GmbH

Schoenbrunner Str. 7, A-1040 Vienna, Austria, Tel. + 43 1 585 34 34-0, Fax +43 1 585 34 34-90, office@tttech-automotive.com

No part of the document may be reproduced or transmitted in any form or by any means, electronic or mechanical, for any purpose, without the written permission of TTTech Automotive GmbH. Company or product names mentioned in this document may be trademarks or registered trademarks of their respective companies. TTTech Automotive GmbH undertakes no further obligation in relation to this document.

Revision History

30.05.2012 V1.0.0 Creation (based on MKS 185841)
27.06.2012 V1.1.0 Reviewed. Some information still open.
03.07.2012 V1.2.0 Added config generation and verification process
05.07.2012 V1.3.0 Added requirements from ETA and Check against System Specification
06.07.2012 V1.3.1 Ready for Release 1.8.2
13.08.2012 V1.3.2 Feedback from Hella-Audit, some texts more precise
10.09.2012 V1.3.3 Added chapter "S-WdgIf Generator - Verification".
13.09.2012 V1.3.4 Dissolved ETA section. Corrected review findings.
15.09.2012 V1.3.5 Safe Watchdog Interface ASIL Release
17.09.2012 V1.8.1 issue48784 (new version)
06.11.2012 V1.8.2 updated according to WdgIf_GetTickCount() (issue49948)
07.11.2012 V1.8.3 updated after review (issue49948)
03.04.2014 V1.8.4 Update after customer review, changes summarised in the issue52277
24.04.2014 V1.8.5 Updated parts related to AS driver compatibility (issue62032:msg467581, issue59785)
 Updated 240758: parameter WdgIfUseAutosarDrvApi
 Updated 260205: added vendor ID (WD driver function names)
 Added 555654: parameter WDGIF_USE_AUTOSAR_DRV_API
 Updated 289398: API differences (WDGIF_USE_AUTOSAR_DRV_API)
 Updated 234584, 235159, 283153: API compatibility (WDGIF_USE_AUTOSAR_DRV_API)
 Added 556326, changed 289394, 289398, 289412, 289455: Description of the <drv> shortcut
 Changed 233039, 234584, 235159, 283153: added *vendor-id* string
08.05.2014 V1.8.6 Updated according to the review remarks (issue62032:msg469458, issue62032:msg469460)
12.05.2014 V1.8.7 Updated according to the review remarks (issue62032:msg472152)
14.05.2014 V1.8.8 Updated according to the review remarks (issue62032:msg473209)
22.05.2014 V1.8.9 Language Review (issue63157)

Table of Contents

| | | |
|----------|--|----|
| 1 | Introduction | 6 |
| 1.1 | Purpose of this Document | 6 |
| 1.1.1 | Target Audience and Responsibilities | 6 |
| 1.1.2 | Structure of this Document | 7 |
| 2 | Terms | 9 |
| 3 | Notations | 10 |
| 4 | Abbreviations | 11 |
| 5 | Safe Watchdog Interface Overview | 12 |
| 6 | System Assumptions | 13 |
| 6.1 | Assumptions in this Document | 13 |
| 7 | S-WdgIf Function Requirements | 14 |
| 8 | S-WdgIf Configuration | 15 |
| 8.1 | Configuration Check-List | 15 |
| 8.1.1 | General Requirements | 15 |
| 8.1.2 | Compiler Settings | 16 |
| 8.1.3 | Post Build Configuration and Application Settings | 16 |
| 9 | S-WdgIf Configuration Generator | 18 |
| 9.1 | S-WdgIf Generator - Installation | 18 |
| 9.2 | S-WdgIf Generator - Application | 18 |
| 9.3 | S-WdgIf Generator - Verification | 19 |
| 9.3.1 | Check of WdgIf_Cfg_Features.h | 19 |
| 9.3.2 | Check of WdgIf_Lcfg.h | 20 |
| 9.3.3 | Check of WdgIf_Lcfg.c | 20 |
| 10 | Safe Watchdog Interface | 23 |
| 10.1 | API Specification | 23 |
| 10.1.1 | Expected Interface | 24 |
| 10.1.1.1 | Implementation of Wrapper Function Appl_Det_ReportError () | 25 |
| 10.1.2 | Imported Types and Definitions | 26 |
| 10.1.3 | Error Handling | 27 |
| 10.1.3.1 | DET Errors | 27 |
| 10.1.3.2 | Return Values | 28 |
| 10.2 | Functional Specification | 28 |
| 10.3 | S-WdgIf Configuration | 29 |
| 10.4 | File Structure | 29 |
| 10.5 | S-WdgIf Integration | 30 |
| 10.5.1 | Import from AUTOSAR Definitions into S-WdgIf | 30 |
| 10.5.2 | Memory Mapping | 32 |
| 10.5.3 | S-WdgIf Files | 33 |
| 10.5.4 | Compilation and Linkage | 33 |
| 10.5.5 | S-WdgM Stack Requirements | 34 |
| 10.6 | S-WdgIf Application | 35 |
| 10.6.1 | S-WdgIf API Functions | 36 |
| 10.6.2 | Memory Access | 37 |
| 10.6.3 | Concurrent Function Calls | 37 |
| 11 | Safety Lifecycle Tailoring | 39 |
| 12 | Qualification | 41 |
| 13 | Resource Requirements | 43 |
| 14 | Constraints and known Problems | 44 |
| 15 | References | 45 |
| 15.1 | Internal Documents | 47 |

| | | | | |
|--|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 552153 |
| <p>We Listen to Your Comments</p> <p>If there is any information in this document that is wrong, unclear or missing? Your feedback will help us to continuously improve the quality of this document. Please contact TTTech Automotive GmbH support if you have questions, change requests or suggestions for improvement related to the Safety Module or documentation. The TTTech Automotive GmbH support can be reached via the following e-mail address: support@tttech.com.</p> | | | | |

1 Introduction

1.1 Purpose of this Document

| | | | | |
|--|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 233001 |
| This document is the Software Safety Manual for the software component Safe Watchdog Interface (S-WdgIf). The S-WdgIf was developed by TTTech as an SEooC according to ISO 26262 (2011) for use in safety related items up to ASIL D (see [ISO26262]). This document contains the requirements that have to be satisfied to integrate and apply the S-WdgIf into a safety-related item. | | | | |
| Category: | Comment | Keywords: | ID: | 233003 |
| The S-WdgIf is a part of the S-WdgM Stack. It contains also a S-WdgIf Configuration Generator to generate configuration dependent S-WdgIf code. | | | | |
| Category: | Comment | Keywords: | ID: | 233005 |
| This document contains the requirements that have to be met to: <ul style="list-style-type: none">• install the S-WdgIf Generator,• generate the S-WdgIf code with the S-WdgIf Configuration Generator,• integrate the S-WdgIf code into an AUTOSAR system, and• to apply the S-WdgIf within an AUTOSAR system. | | | | |
| Category: | Comment | Keywords: | ID: | 233019 |
| Note: This document just describes requirements for the S-WdgIf. This document does not provide a full description of how to create a safe system. For example, this document is not concerned with hardware architectural metrics that may have an influence on software running on this hardware. These considerations are not specific to the S-WdgIf and are thus beyond the scope of this manual. | | | | |
| Category: | Comment | Keywords: | ID: | 559910 |
| The S-WdgIf was developed according to AUTOSAR version 3.1.4 [AS_WDGIF_SWS_3_1] and AUTOSAR version 4.0.1 [AS_WDGIF_SWS]. The S-WdgIf is compatible with both AUTOSAR versions but not fully compliant. For the deviations see [TT_WDGIF_UM]. | | | | |

1.1.1 Target Audience and Responsibilities

| | | | | |
|--|-------------|------------------|-----|--------|
| Category: | Comment | Keywords: | ID: | 233007 |
| The requirements are intended for the (system) integrator, who is responsible for the generation of the S-WdgIf configuration, the integration of the S-WdgIf in(to) a safety-related item and its application. | | | | |
| Category: | Requirement | Keywords: | ID: | 233009 |
| Label: | | Safety relevant: | | |
| Related To: | | Related To: | | |
| The integrator shall be an expert in the area of functional safety with deep knowledge of ISO 26262 (see [ISO26262]). Moreover, the integrator needs to know: <ul style="list-style-type: none">• the AUTOSAR architecture,• the ANSI C programming language, and• the S-WdgIf User Manual [TT_WDGIF_UM]). | | | | |

| | | | | |
|---|-------------|------------------|-----|--------|
| Category: | Comment | Keywords: | ID: | 233011 |
| The integrator shall ensure that all requirements defined in this Safety Manual are fulfilled in the integrated item. | | | | |
| Category: | Requirement | Keywords: | ID: | 233013 |
| Label: | | Safety relevant: | | |
| Related To: | | Related To: | | |
| <p>The integrator shall also follow the instructions in:</p> <ul style="list-style-type: none"> the Safety Manual for the S-WdgM (see [TT_WDGM_SM]) and the Safety Manual for the used S-Wdg drivers (see the driver specific Safety Manual. Examples can be found in section "References" at the end of this document) which describe the other parts of the S-WdgM Stack. | | | | |

1.1.2 Structure of this Document

| | | | | |
|---|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 233017 |
| Requirements are explicitly marked as "Requirement" in this document. All requirements described in this document shall be considered by the integrator. Explanatory text that does not represent an explicit requirement is marked as "Comment". | | | | |
| Category: | Comment | Keywords: | ID: | 554241 |
| Note: Document items of the type "Comment" do not represent explicit action items for the integrator, however, the integrator is advised to ensure that there are no contradictions between the comment and the intended S-Wdglf usage. | | | | |
| Category: | Comment | Keywords: | ID: | 554243 |
| Comments related to a requirement are placed below the related requirement. | | | | |
| Category: | Comment | Keywords: | ID: | 554242 |
| <p>Note: Requirements in this document shall be treated either as safety related or need not be treated as safety related, depending on the S-Wdglf use case:</p> <ul style="list-style-type: none"> If the S-Wdglf is used to monitor a safety related application then for each used S-Wdglf functionality all corresponding requirements shall be treated as safety related. If the S-Wdglf is used to monitor a QM application then the SM requirements need not be treated as safety related. <p>As a consequence, the field "Safety relevant" for each requirement is always empty.</p> | | | | |

| | | | | |
|--|---------|-------------------------------|-----|--------|
| Category: | Comment | Keywords: | ID: | 554244 |
| The list shows some keywords used in requirements and their explanation: | | | | |
| Key Word | | Description | | |
| must, shall, required, is responsible for, is the responsibility of | | Requirement is mandatory. | | |
| shall not | | Requirement is a prohibition. | | |
| table 1 | | | | |

2 Terms

| Category: | Comment | Keywords: | ID: | 260274 |
|---|---|-----------|-----|--------|
| Configuration Tool | A tool (like DaVinci Configurator Pro) that creates a Safe Watchdog Interface configuration. | | | |
| Error Escalation | The escalation of a detected fault to the Watchdog by a Watchdog reset or omittance of the Watchdog trigger. | | | |
| Safe Watchdog Driver | The lower and hardware dependent software layer of the S-WdgM Stack. It controls the Watchdog device. | | | |
| Safe Watchdog Interface | The middle and hardware independent software layer of the S-WdgM Stack. | | | |
| Safe Watchdog Interface Configuration | The part of the S-WdgIf code that is generated by the S-WdgIf Generator from an ECU description file. | | | |
| Safe Watchdog Interface Configuration Generator | A tool from TTTech that generates the S-WdgIf Configuration out of an ECU description file. In this document the name is abbreviated to "S-WdgIf Generator". The tool is part of the S-WdgIf package. | | | |
| Safe Watchdog Manager | The upper and hardware independent software layer of the S-WdgM Stack. It communicates with the application through RTE. | | | |
| Safe Watchdog Manager Stack | The stack comprises the S-WdgM, the Safe Watchdog Interface and the Safe Watchdog driver(s). | | | |
| System | A set of elements that relates at least a sensor, a controller and an actuator with one another (see [ISO26262], part1). In this document, the MCU is part of the system. | | | |
| Watchdog (device) | A Watchdog device is the hardware that provides the watchdog function. It can be an internal watchdog (on the MCU) or an external device. | | | |
| WD Mode | The "WD Mode" defines the period timeout. It is set with WdgIf_SetMode () and can be "slow", "fast" or "off" (WD disabled). Do not confuse with "WD Trigger Mode". | | | |
| WD Trigger Mode | The "WD Trigger Mode" defines the WD trigger window (start and length) together with the "WD Mode". It is set with WdgM_SetMode (). | | | |

table 2

3 Notations

| | | | | |
|-----------|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 233039 |
|-----------|---------|-----------|-----|--------|

| Notation | Description |
|--------------|---|
| <i>text</i> | Italic text is a placeholder for a name or text pattern. E.g.: In Wdg_ <i>infix</i> _Init (), the text <i>infix</i> is a placeholder for the actual name of the used WD driver. |
| <i>infix</i> | A placeholder with this name is interpreted as follows: <ul style="list-style-type: none">• In case of an AUTOSAR 3.1 environment, the placeholder <i>infix</i> stands for the name of the configured WD device.• In case of an AUTOSAR 4.0 environment, the placeholder <i>infix</i> stands for the pattern <i>vendor-id_device-name</i>, where <i>vendor-id</i> is the ID of the vendor of the WD driver and <i>device-name</i> is the name of the configured WD device. |

table 3

4 Abbreviations

| Category: | Comment | Keywords: | ID: | 233047 |
|--------------|--|-----------|-----|--------|
| API | Application Programming Interface | | | |
| ASIL | Automotive Safety Integrity Level | | | |
| AUTOSAR | Automotive Open System Architecture | | | |
| BSW | Basic Software (AUTOSAR term) | | | |
| DEM | Diagnostic Event Manager | | | |
| DET | Development Error Tracer | | | |
| ECU | Engine Control Unit | | | |
| ISO | International Organization for Standardization | | | |
| MCU | Microcontroller Unit | | | |
| MPU | Memory Protection Unit. Usually this is part of the Microcontroller. | | | |
| MemMap | Memory Mapping (for Memory Management) | | | |
| QM | Quality Managed (Software) | | | |
| SM | Safety Manual | | | |
| SPI | Serial Peripheral Interface (Module) | | | |
| S-Wdg | Safe Watchdog Driver (from TTTech) | | | |
| S-WdgM | Safe Watchdog Manager (from TTTech) | | | |
| S-WdgIf | Safe Watchdog Interface (from TTTech) | | | |
| S-WdgM Stack | The "S-WdgM Stack" comprises the S-WdgM, the S-WdgIf and the used Safe Watchdog driver(s). | | | |
| WD | Watchdog | | | |
| WdgM | Watchdog Manager according to the AUTOSAR 4.0 specification | | | |
| WdgIf | Watchdog Interface according to the AUTOSAR 4.0 specification | | | |

table 4

5 Safe Watchdog Interface Overview

| Category: | Comment | Keywords: | ID: | 233043 |
|--|---------|-----------|-----|--------|
| <p>For an overview of and more details about</p> <ul style="list-style-type: none">• the S-WdgIf,• the other S-WdgM Stack components, and• the S-WdgIf Generator <p>see the according user manuals and Safety Manuals:</p> <ul style="list-style-type: none">• for the S-WdgM: [TT_WDGM_UM], [TT_WDGM_SM],• for the S-WdgIf: [TT_WDGIF_UM] and this document, or• for the S-Wdg drivers: the according Safety Manual. <p>See section "References" at the end of this document.</p> | | | | |

6 System Assumptions

| | | | | |
|--|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 270643 |
| The system assumptions are a subset of the S-WdgM system assumptions (see [TT_WDGM_SM]). | | | | |

| | | | | |
|---|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 559912 |
| The S-WdgIf is designed for integration into an AUTOSAR 3.1.4 and 4.0.1 system. However, it is not restricted to these AUTOSAR versions. The software module can also be integrated into other versions of AUTOSAR and other system SW architectures, provided that the integration related requirements listed in the Safety Manual are met. | | | | |

6.1 Assumptions in this Document

| | | | | |
|--|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 282959 |
| The following requirements and comments are placed in the according context in this document. They may be interpreted as system assumptions or not - depending on the circumstances the system is developed and applied: | | | | |

| Requirement | Description |
|--------------------------------|---|
| 260213, 234568, 235165, 237306 | Quality level degradation by external interfaces to 3rd party modules. *1). |
| 260213 | Quality level degradation by external interfaces to S-WdgM Stack modules *2). |
| 236022 | S-WdgIf functionality affected by other SW. |
| 260197, 260217, 236258, 236382 | WD driver and WD device. |
| 236356 | Memory sections, access rights. |
| 236044, 237369, 236430, 236434 | Memory corruption. |
| 260205 | External Interfaces. |

table 5

*1) The 3rd party modules are not part of the S-WdgM Stack.

*2) The external interfaces between S-WdgM, S-WdgIf and S-Wdg do not have to be verified if:

- the modules are part of the same S-WdgM Stack release,
- the modules are not altered by the integrator, and
- the modules are integration tested by TTTech.

7 S-WdgM Function Requirements

| | | | | | |
|--|---------|-----------|--|-----|--------|
| Category: | Comment | Keywords: | | ID: | 270650 |
| For the system requirements that the S-WdgM Stack fulfills, see[TT_WDGM_SM]. | | | | | |

8 S-WdgIf Configuration

| | | | | |
|---|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 233053 |
| <p>The S-WdgIf Configuration is the part of the S-WdgIf code that is generated with the S-WdgIf Generator out of a given ECU description file.</p> <p>This section lists the safety requirements for the creation of a S-WdgIf Configuration.</p> | | | | |

| | | | | |
|---|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 233055 |
| <p>For a description of</p> <ul style="list-style-type: none">the configuration fields in the ECU description file andhow to create S-WdgIf code out of the ECU description file <p>see [TT_WDGIF_UM].</p> | | | | |

8.1 Configuration Check-List

| | | | | |
|--|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 233059 |
| <p>The S-WdgIf Generator performs basic checks on the ECU description file when it generates the S-WdgIf Configuration.</p> <p>The following list provides instructions for manual checks of safety relevant configuration values that cannot be performed by the S-WdgIf Generator.</p> | | | | |

8.1.1 General Requirements

| | | | | |
|--|-------------|------------------|-----|--------|
| Category: | Requirement | Keywords: | ID: | 234105 |
| Label: | | Safety relevant: | | |
| Related To: | | Related To: | | |
| <p>The integrator shall set the configuration parameters according to the project specification.</p> | | | | |

| | | | | |
|--|-------------|------------------|-----|--------|
| Category: | Requirement | Keywords: | ID: | 552162 |
| Label: | | Safety relevant: | | |
| Related To: | | Related To: | | |
| <p>The ECU description file that serves as input for the generation of the S-WdgIf Configuration files shall comply to the AUTOSAR schema defined in comment 559910 above.</p> | | | | |

| | | | | |
|---|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 554249 |
| <p>Note: These are the AUTOSAR versions for which the S-WdgIf was developed and tested.</p> | | | | |

| | | | | |
|--|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 554878 |
| <p>The AUTOSAR version used for S-WdgIf integration tests is defined in [TT_WDGS_ITR].</p> | | | | |

8.1.2 Compiler Settings

| | | | | |
|-------------|-------------|------------------|---|--------|
| Category: | Requirement | Keywords: | ID: | 240758 |
| Label: | | Safety relevant: | | |
| Related To: | | Related To: | __MKSID__264807,__MKSID__264811,__MKSID__552843 | |

The following fields in the ECU description file shall be "true" if the according feature shall be enabled, otherwise "false":

| Field | Feature |
|-----------------------|--|
| WdgIfVersionInfoApi | Enable Version API. |
| WdgIfDevErrorDetect | Enable Development error detection. |
| WdgIfUseAutosarDrvApi | Enable AUTOSAR compatible WD driver API. |

table 6

| | | | | |
|-------------|-------------|------------------|-----|--------|
| Category: | Requirement | Keywords: | ID: | 240769 |
| Label: | | Safety relevant: | | |
| Related To: | | Related To: | | |

If an internal HW tick counter is used, then the field WdgIfInternalTickCounterRef shall be defined such that it refers to a WD driver, otherwise the field WdgIfInternalTickCounterRef is omitted.

| | | | | |
|-----------|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 240773 |
|-----------|---------|-----------|-----|--------|

If WdgIfInternalTickCounterRef is a S-WdgIf information and refers to a WD driver, the driver must

- support an internal tick counter and
- its parameter WdgIfInternalTickCounter must be "true".

This is checked automatically by the S-WdgIf Configuration Generator.

8.1.3 Post Build Configuration and Application Settings

| | | | | |
|-----------|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 240764 |
|-----------|---------|-----------|-----|--------|

This section provides a check list for the various aspects and configuration fields that must be considered for post build configuration of the S-WdgIf.

| | | | | |
|-----------|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 240766 |
|-----------|---------|-----------|-----|--------|

For further information on configuration fields see [TT_WDGIF_UM].

| | | | | |
|-------------|-------------|------------------|-----|--------|
| Category: | Requirement | Keywords: | ID: | 260197 |
| Label: | | Safety relevant: | | |
| Related To: | | Related To: | | |

The integrator shall make sure that the configuration has

- only one WD driver and
- only one WD device for the driver defined.

| | | | | |
|--|-------------|------------------|-----|--------|
| Category: | Comment | Keywords: | ID: | 242221 |
| The current implementation of the S-WdgM Stack supports only one WD device per WD driver. If configured so, the S-WdgIf Generator yields an error message. | | | | |
| Category: | Comment | Keywords: | ID: | 260225 |
| As a consequence, the device index that is passed to the WD driver functions is always 0. | | | | |
| Category: | Requirement | Keywords: | ID: | 260199 |
| Label: | | Safety relevant: | | |
| Related To: | | Related To: | | |
| The integrator shall ensure that the names of the WD driver functions in the generated S-WdgIf configuration match the actual names of the functions in the WD driver. | | | | |
| Category: | Requirement | Keywords: | ID: | 260205 |
| Label: | | Safety relevant: | | |
| Related To: | | Related To: | | |
| In case a Watchdog Driver is used that is not implemented by TTTech, the integrator shall make sure that the WD driver supports the following functions: <ul style="list-style-type: none"> • Wdg_infix_SetMode () and • Wdg_infix_SetTriggerWindow () or Wdg_infix_SetTriggerCondition (). | | | | |
| Category: | Comment | Keywords: | ID: | 260201 |
| The S-WdgIf Generator fills the placeholder (<i>infix</i>) automatically. | | | | |
| Category: | Requirement | Keywords: | ID: | 260217 |
| Label: | | Safety relevant: | | |
| Related To: | | Related To: | | |
| If an internal HW tick counter is configured (i.e. WdgIfInternalTickCounterRef is defined), then the integrator shall make sure that the WD driver supports the function Wdg_infix_GetTickCount (). | | | | |
| Category: | Requirement | Keywords: | ID: | 260213 |
| Label: | | Safety relevant: | | |
| Related To: | | Related To: | | |
| In case a Watchdog Driver is used that is not implemented by TTTech, the integrator shall verify that the functions that are offered by the WD driver (listed in section "Expected Interface", Comment 234584) and called from the S-WdgIf do not degrade the quality level of the S-WdgIf below the required quality level. | | | | |

9 S-WdgIf Configuration Generator

| | | | | |
|--|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 234331 |
| This section lists the safety requirements for the installation and application of the S-WdgIf Generator. | | | | |
| Category: | Comment | Keywords: | ID: | 234333 |
| For information on how to use the S-WdgIf Generator, see [TT_WDGIF_UM]. | | | | |
| Category: | Comment | Keywords: | ID: | 234335 |
| Note: the S-WdgIf Generator is not ASIL-D and its output cannot be trusted. The generated files must be verified manually as described in "S-WdgIf Generator - Verification". | | | | |

9.1 S-WdgIf Generator - Installation

| | | | | |
|--|-------------|------------------|-----|--------|
| Category: | Requirement | Keywords: | ID: | 234339 |
| Label: | | Safety relevant: | | |
| Related To: | | Related To: | | |
| If the S-WdgIf Generator is installed and used on a different OS than Windows 7 with Service Pack 1, the integrator is responsible for ensuring that the change of the underlying OS does not affect the behavior and output of the S-WdgIf Generator. | | | | |
| Category: | Comment | Keywords: | ID: | 234341 |
| The S-WdgIf Generator has been tested on Windows 7 with Service Pack 1. | | | | |

9.2 S-WdgIf Generator - Application

| | | | | |
|---|-------------|------------------|-----|--------|
| Category: | Requirement | Keywords: | ID: | 234345 |
| Label: | | Safety relevant: | | |
| Related To: | | Related To: | | |
| The selected output path for the generated S-WdgIf code (runtime argument "OUTPUT-DIRECTORY") shall be empty before the S-WdgIf Generator is started. | | | | |
| Category: | Comment | Keywords: | ID: | 234347 |
| If the output path is not empty, code from previous generation runs may be accidentally integrated into the AUTOSAR system. | | | | |
| Category: | Comment | Keywords: | ID: | 263318 |
| The names of the generated files are listed on standard error (stdout). | | | | |
| Category: | Requirement | Keywords: | ID: | 234349 |
| Label: | | Safety relevant: | | |
| Related To: | | Related To: | | |
| If the S-WdgIf Generator aborts the generation process with an error, the (partially) generated output files shall not be used in an AUTOSAR system. | | | | |

| | | | | |
|--|-------------|------------------|-----|--------|
| Category: | Comment | Keywords: | ID: | 234351 |
| Error messages start with "Error" and they are displayed on standard error (stderr). If successful, the S-WdgIf Generator returns error level 0, otherwise an error level higher than 0 is returned. | | | | |
| Category: | Requirement | Keywords: | ID: | 234353 |
| Label: | | Safety relevant: | | |
| Related To: | | Related To: | | |
| If the S-WdgIf Generator displays a warning message, the integrator shall ensure that the cause of the warning does not invalidate the generated S-WdgIf Configuration. | | | | |
| Category: | Comment | Keywords: | ID: | 234355 |
| Warning messages start with "Warning" and are displayed on standard error (stderr). If successful (although with a warning), the S-WdgIf Generator returns error level 0, otherwise an error level higher than 0 is returned. | | | | |
| Category: | Comment | Keywords: | ID: | 234359 |
| TTTech provides a sample demonstration configuration with four supervised entities. The files may be used by the integrator, but they are intended for demonstration only. | | | | |
| Category: | Comment | Keywords: | ID: | 234361 |
| The S-WdgIf Generator is not configurable. The S-WdgIf Generator process is controlled by the input arguments only. | | | | |

9.3 S-WdgIf Generator - Verification

| | | | | | |
|--|---------|-----------|--|-----|--------|
| Category: | Comment | Keywords: | | ID: | 289334 |
| This section describes how to verify the generated files manually. | | | | | |

| | | | | | |
|---|-------------|------------------|-----------------|-----|--------|
| Category: | Requirement | Keywords: | | ID: | 289342 |
| Label: | | Safety relevant: | | | |
| Related To: | | Related To': | __MKSID__297368 | | |
| Check that the set of generated files is complete. It consists of: | | | | | |
| <ul style="list-style-type: none">• WdgIf_Cfg_Features.h,• WdgIf_Lcfg.h, and• WdgIf_Lcfg.c. | | | | | |

9.3.1 Check of WdgIf_Cfg_Features.h

| | | | | |
|---|-------------|------------------|-----------------|--------|
| Category: | Requirement | Keywords: | ID: | 289346 |
| Label: | | Safety relevant: | | |
| Related To: | | Related To: | __MKSID__264811 | |
| If - and only if - WdgIfVersionInfoApi in the ECU Description file is "true", then WDGIF_VERSION_INFO_API shall be set STD_ON, otherwise STD_OFF. | | | | |

Project Name: Safe Watchdog Interface
Doc. Name: Safety Manual

Version: 1.8.9
Doc. No: D-SAFEX-S-70-005

Page 20

| | | | | | |
|--|-----------------|------------------|--|-----|--------|
| Category: | Requirement | Keywords: | | ID: | 555654 |
| Label: | | Safety relevant: | | | |
| Related To: | __MKSID__552843 | Related To: | | | |
| If - and only if - WdgIfUseAutosarDrvApi in the ECU Description file is "true", then WDGIF_USE_AUTOSAR_DRV_API shall be set STD_ON, otherwise STD_OFF. | | | | | |
| Category: | Requirement | Keywords: | | ID: | 289352 |

| | | | | | |
|--|-------------|------------------|----------------|-----|--------|
| Category: | Requirement | Keywords: | | ID: | 289394 |
| Label: | | Safety relevant: | | | |
| Related To: | | Related To': | __MKSID__58842 | | |
| The following structures shall be defined: | | | | | |
| <ul style="list-style-type: none">• "WdgIf_InterfaceFunctionsType <i>infix_functions</i>",• "WdgIf_InterfaceFunctionsPerWdgDeviceType WdgIf_FunctionsPerWdg [WDGIF_NUMBER_OF_WATCHDOGS]" (an array of structures), and• "WdgIf_InterfaceType WdgIf_Interface". | | | | | |

| | | | | | |
|--|-------------|------------------|--|-----|--------|
| Category: | Requirement | Keywords: | | ID: | 289406 |
| Label: | | Safety relevant: | | | |
| Related To: | | Related To': | | | |
| The structures listed in 289394 above shall be memory mapped to WDGIF_START_SEC_CONST_UNSPECIFIED. | | | | | |

| | | | | | |
|--|-------------|------------------|-------------------------------|-----|--------|
| Category: | Requirement | Keywords: | | ID: | 289398 |
| Label: | | Safety relevant: | | | |
| Related To: | | Related To': | __MKSID__55578,__MKSID__55580 | | |
| The structure " <i>infix_functions</i> " shall contain the following field values (and in this order): | | | | | |
| <ul style="list-style-type: none">• "Wdg_infix_SetMode" and• "Wdg_infix_SetTriggerWindow" if WDGIF_USE_AUTOSAR_DRV_API is set to STD_OFF and "Wdg_infix_SetTriggerCondition" if WDGIF_USE_AUTOSAR_DRV_API is set to STD_ON. | | | | | |

| | | | | | |
|--|---------|-----------|--|-----|--------|
| Category: | Comment | Keywords: | | ID: | 289410 |
| The fields refer to the functions of the used WD driver to set the WD trigger. | | | | | |

| | | | | | |
|--|-------------|------------------|---------------------------------|-----|--------|
| Category: | Requirement | Keywords: | | ID: | 289412 |
| Label: | | Safety relevant: | | | |
| Related To: | | Related To': | __MKSID__297362,__MKSID__297324 | | |
| The array WdgIf_FunctionsPerWdg shall contain a single array item with the following field values (in this order): | | | | | |
| <ul style="list-style-type: none">• "&<i>infix_functions</i>" and• "0". | | | | | |

| | | | | | |
|---|---------|-----------|--|-----|--------|
| Category: | Comment | Keywords: | | ID: | 289414 |
| The value 0 refers to the position of each WD (starting with 0) assigned to the WD driver referred to by <i>infix</i> . There is only one WD configurable for a driver. | | | | | |

| | | | | | |
|--|-------------|------------------|--|-----|--------|
| Category: | Requirement | Keywords: | | ID: | 289455 |
| Label: | | Safety relevant: | | | |
| Related To: | | Related To': | __MKSID__55582,__MKSID__297312,__MKSID__239282 | | |
| The structure WdgIf_Interface shall contain the following field values: | | | | | |
| <ul style="list-style-type: none">• "WDGIF_NUMBER_OF_WATCHDOGS". | | | | | |

- "WdgIf_FunctionsPerWdg", and
- "Wdg_infix_GetTickCount" if - and only if - WDGIF_INTERNAL_TICK_COUNTER is set to STD_ON.

10 Safe Watchdog Interface

| | | | | |
|---|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 234556 |
| This section lists the safety requirements for the integration and application of the S-WdgIf code in/into an AUTOSAR system. | | | | |

10.1 API Specification

| | | | | |
|---|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 234560 |
| This section describes the imported types and definitions and the expected interface. It also describes safety related aspects of types, definitions and functions implemented in the S-WdgIf. Some types, definitions and interfaces depend on the used S-WdgIf Configuration. | | | | |

| | | | | |
|---|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 234562 |
| For more information see [TT_WDGIF_UM]. For more information about types, definitions and functions implemented in the S-Wdg drivers, see the Safety Manuals of the drivers. Safety Manuals and User Manuals of the drivers tested by TTTech can be found in section "References" at the end of this document. | | | | |

| | | | | |
|--|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 234564 |
| For further requirements related to imported types, definitions and interfaces, see section "S-WdgIf Integration" below. | | | | |

| | | | | |
|--|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 234566 |
| The integrator is responsible for the correct import of the types and definitions that are listed in section "Imported Types and Definitions" below. | | | | |

| | | | | |
|---|-------------|------------------|-----|--------|
| Category: | Requirement | Keywords: | ID: | 234570 |
| Label: | | Safety relevant: | | |
| Related To: | | Related To: | | |
| The integrator is responsible for the correct application of the interface functions. | | | | |

| | | | | |
|--|-------------|------------------|-----|--------|
| Category: | Requirement | Keywords: | ID: | 234572 |
| Label: | | Safety relevant: | | |
| Related To: | | Related To: | | |
| The integrator is responsible for ensuring that all external functions that are called from within the S-WdgIf code are imported from the correct versions of AUTOSAR. | | | | |

| | | | | |
|---|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 559643 |
| For the supported AUTOSAR versions, see comment 559910 above. | | | | |

| | | | | |
|---|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 546265 |
| The external functions are defined in section "Expected Interface" below. | | | | |

| | | | | |
|--|-------------|------------------|-----|--------|
| Category: | Requirement | Keywords: | ID: | 234574 |
| Label: | | Safety relevant: | | |
| Related To: | | Related To: | | |
| The inclusion of AUTOSAR files or any other files different from S-WdgIf files shall not redefine any identifier that is defined in the S-WdgIf code. E.g., redefinitions with #define macros. | | | | |

| | | | | |
|--|-------------|------------------|-----|--------|
| Category: | Requirement | Keywords: | ID: | 234568 |
| Label: | | Safety relevant: | | |
| Related To: | | Related To: | | |
| The integrator shall verify that no external interface of the S-WdgIf listed in this section degrades the quality level of the S-WdgIf below the required quality level. | | | | |

| | | | | |
|--|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 559038 |
| The external interfaces are defined in section "Expected Interface" below. | | | | |

| | | | | |
|--|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 234576 |
| For example, if an external function of quality level ASIL C is called by the S-WdgIf, it degrades the quality level of the S-WdgIf to ASIL C (if no precautions were taken), although the required quality level is ASIL D. | | | | |

10.1.1 Expected Interface

| | | | | |
|---|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 234580 |
| This section lists the external functions that are called by the S-WdgIf. | | | | |

| | | | | |
|--|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 234582 |
| For an overview of functions that are called by the S-WdgIf see [TT_WDGIF_UM]. | | | | |

| | | | | |
|---|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 234584 |
| The following functions of the WD driver in the lower layer are called: | | | | |

| Function | Module |
|--|-----------|
| Wdg_infix_SetMode () *) | WD Driver |
| Wdg_infix_SetTriggerWindow () or Wdg_infix_SetTriggerCondition() **) ***) | WD Driver |

table 7

*) If the function WdgIf_SetMode () is called with parameter DeviceIndex=*i*, then it calls the function that is configured for the *i*-th WD - referred to by *infix* - in the S-WdgIf configuration for the configuration field Wdg_infix_SetMode.

**) If the function WdgIf_SetTriggerWindow () or WdgIf_SetTriggerCondition () is called with parameter DeviceIndex=*i*, then it calls the function that is configured for the *i*-th WD - referred to by *infix* - in the S-WdgIf configuration for the configuration field Wdg_infix_SetTriggerWindow.

***) If the configuration parameter WdgIfUseAutosarApi is set to "true", then the S-WdgIf expects the WD driver to provide the function Wdg_infix_SetTriggerWindow () (which is the AUTOSAR API compatibility mode). Otherwise, the S-WdgIf expects the WD driver to provide the function

Wdg_infix_SetTriggerCondition () (which is the TTTech API compatibility mode).

| | | | | |
|-----------|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 235159 |
|-----------|---------|-----------|-----|--------|

Some functions are called by the S-WdgIf depending on the compiler switches as listed here:

| Compiler Switch | Function | Module |
|--|---|-----------|
| WDGIF_DEV_ERROR_DETECT is set to STD_ON | Appl_Det_ReportError () *) | DET |
| WDGIF_INTERNAL_TICK_COUNTER is set to STD_ON | Wdg_infix_GetTickCounter () **) | WD Driver |
| WDGIF_USE_AUTOSAR_DRV_API | If set to STD_ON, then Wdg_infix_SetTriggerWindow () is called, otherwise Wdg_infix_SetTriggerCondition () is called ***) | WD Driver |

table 8

*) This is a wrapper function. See section "Implementation of Wrapper Function Appl_Det_ReportError ()" below for information.

**) If the function WdgIf_GetTickCounter () is called with WDGIF_INTERNAL_TICK_COUNTER set to STD_ON, then it calls the function that is configured in the S-WdgIf configuration for the configuration field Wdg_infix_GetTickCounter.

***) WDGIF_USE_AUTOSAR_DRV_API is set to STD_ON for the AUTOSAR compatibility mode and set to STD_OFF for the TTTech compatibility mode.

10.1.1.1 Implementation of Wrapper Function Appl_Det_ReportError ()

| | | | | |
|-----------|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 238269 |
|-----------|---------|-----------|-----|--------|

The function Det_ReportError () may not meet the required quality level and need to be wrapped so that freedom from interference with the S-WdgIf is guaranteed. The according wrapper function is called Appl_Dem_ReportError (). The S-WdgIf calls the function Appl_Dem_ReportError () instead of Det_ReportError ().

| | | | | |
|-----------|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 260666 |
|-----------|---------|-----------|-----|--------|

Note: Det_ReportError () is only called if WDGIF_DEV_ERROR_DETECT is set to STD_ON.

| | | | | |
|-----------|-------------|-----------|-----|--------|
| Category: | Requirement | Keywords: | ID: | 260664 |
|-----------|-------------|-----------|-----|--------|

| | |
|--------|------------------|
| Label: | Safety relevant: |
|--------|------------------|

| | |
|-------------|-------------|
| Related To: | Related To: |
|-------------|-------------|

The wrapper function Appl_Det_ReportError () shall be declared in a separate header-file named Appl_Det.h. This header file shall include Det.h for the wrapped AUTOSAR function.

| | | | | |
|-----------|-------------|-----------|-----|--------|
| Category: | Requirement | Keywords: | ID: | 235165 |
|-----------|-------------|-----------|-----|--------|

| | |
|--------|------------------|
| Label: | Safety relevant: |
|--------|------------------|

| | |
|-------------|-------------|
| Related To: | Related To: |
|-------------|-------------|

The integrator shall verify that a call of this function does not degrade the S-WdgIf below the required quality level.

| | | | | |
|--|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 235862 |
| For this reason, the integrator is advised to revise the necessity of the expected interfaces. | | | | |

10.1.2 Imported Types and Definitions

| | | | | |
|--|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 235866 |
| This section lists the types and definitions that are imported by the S-Wdglf. | | | | |

| | | | | |
|--|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 235886 |
| The following types and definitions are imported from Platform_Types.h and used: Types: uint8 uint16 uint32 | | | | |

| | | | | |
|---|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 235888 |
| The following types and definitions are imported from Std_Types.h and used: Types: Std_VersionInfoType (only if WDGIF_VERSION_INFO_API is set to STD_ON) Std_ReturnType Definitions: STD_ON STD_OFF | | | | |

| | | | | |
|---|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 235890 |
| The following definitions are imported from "Compiler.h" and used: Definitions: AUTOMATIC FUNC NULL_PTR P2CONST P2FUNC P2VAR VAR | | | | |

| | | | | |
|---|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 235892 |
| The following definitions are imported from "Compiler_Cfg.h" and used: WDGIF_APPL_DATA WDGIF_CODE WDGIF_CONST WDGIF_APPL_CONST WDGIF_VAR | | | | |

| | | | | |
|---|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 235894 |
| The following definitions are imported from "MemMap.h" and used: In Wdglf.c: WDGIF_START_SEC_CODE | | | | |

WDGIF_STOP_SEC_CODE
In WdgIf_Lcfg.c:
WDGIF_START_SEC_CONST_UNSPECIFIED
WDGIF_STOP_SEC_CONST_UNSPECIFIED

10.1.3 Error Handling

| | | | | |
|---|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 235916 |
| This section describes the error codes that are set by the S-WdgIf (using the DET mechanism) and the return values from S-WdgIf API functions.. | | | | |

10.1.3.1 DET Errors

| | | | | |
|--|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 235920 |
| DET Errors are intended to support the development of an application. During software development, the compiler directive WDGIF_DEV_ERROR_DETECT is usually set to STD_ON. Once the software is safe enough so that no further DET error can occur, the option is deactivated. For safety reasons the DET errors that are returned by the S-WdgIf are listed here. | | | | |

| | | | | |
|-----------|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 235896 |
|-----------|---------|-----------|-----|--------|

If the compiler switch WDGIF_DEV_ERROR_DETECT is set to STD_ON, then the S-WdgIf reports the following development errors using the function Appl_Det_ReportError ():

| DET Error | Code | Description |
|----------------------|------|--|
| WDGIF_E_PARAM_DEVICE | 0x01 | A WD device is referenced that is not defined in the S-WdgIf configuration. *) |
| WDGIF_E_PARAM_PTR | 0x02 | WdgIf_GetVersionInfo () is called with NULL-pointer as parameter. |

table 9

*) Possible reasons are:

- the pointer to the WdgIf configuration is NULL,
- the device index is higher than the number of WDs in the WdgIf configuration, and
- the pointer to the referenced WD function is NULL.

The DET errors are defined in WdgIf.h.

| | | | | |
|---|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 235868 |
| The definition WDGIF_E_PARAM_DEVICE is an AUTOSAR definition (see [AS_WDGIF_SWS]). The definition WDGIF_E_PARAM_PTR is TTTech specific. | | | | |

| | | | | |
|--|-------------|------------------|-----|--------|
| Category: | Requirement | Keywords: | ID: | 235932 |
| Label: | | Safety relevant: | | |
| Related To: | | Related To: | | |
| The integrator is responsible for making sure that - once the compiler switch WDGIF_DEV_ERROR_DETECT is set to STD_OFF - no error relevant to DET can occur. | | | | |

10.1.3.2 Return Values

| Category: | Comment | Keywords: | ID: | 235936 | | | | | | | | |
|--|--|-----------|-----|--------|----------|---------|------------------|---|------------------------------|--|---------------------------|--|
| The following functions return E_NOT_OK in case an error occurred: | | | | | | | | | | | | |
| <table><tr><th>Function</th><th>Comment</th></tr><tr><td>WdgIf_SetMode ()</td><td>DET error WDGIF_E_PARAM_DEVICE was reported or the called function Wdg_infix_SetMode () of the WD driver returned E_NOT_OK.</td></tr><tr><td>WdgIf_SetTriggerCondition ()</td><td>DET error WDGIF_E_PARAM_DEVICE was reported or the called function Wdg_infix_SetTriggerWindow () of the WD driver returned E_NOT_OK.</td></tr><tr><td>WdgIf_SetTriggerWindow ()</td><td>DET error WDGIF_E_PARAM_DEVICE was reported or the called function Wdg_infix_SetTriggerWindow () of the WD driver returned E_NOT_OK.</td></tr></table> | | | | | Function | Comment | WdgIf_SetMode () | DET error WDGIF_E_PARAM_DEVICE was reported or the called function Wdg_infix_SetMode () of the WD driver returned E_NOT_OK. | WdgIf_SetTriggerCondition () | DET error WDGIF_E_PARAM_DEVICE was reported or the called function Wdg_infix_SetTriggerWindow () of the WD driver returned E_NOT_OK. | WdgIf_SetTriggerWindow () | DET error WDGIF_E_PARAM_DEVICE was reported or the called function Wdg_infix_SetTriggerWindow () of the WD driver returned E_NOT_OK. |
| Function | Comment | | | | | | | | | | | |
| WdgIf_SetMode () | DET error WDGIF_E_PARAM_DEVICE was reported or the called function Wdg_infix_SetMode () of the WD driver returned E_NOT_OK. | | | | | | | | | | | |
| WdgIf_SetTriggerCondition () | DET error WDGIF_E_PARAM_DEVICE was reported or the called function Wdg_infix_SetTriggerWindow () of the WD driver returned E_NOT_OK. | | | | | | | | | | | |
| WdgIf_SetTriggerWindow () | DET error WDGIF_E_PARAM_DEVICE was reported or the called function Wdg_infix_SetTriggerWindow () of the WD driver returned E_NOT_OK. | | | | | | | | | | | |
| table 10 | | | | | | | | | | | | |

| | | | | |
|---|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 235938 |
| The return codes are handled by the S-WdgIf function that calls one of the functions above. | | | | |

10.2 Functional Specification

| | | | | |
|---|-------------|------------------|-----|--------|
| Category: | Comment | Keywords: | ID: | 283401 |
| A detailed functional specification of the S-WdgIf module is provided in [TT_WDGIF_UDD]. | | | | |
| Category: | Requirement | Keywords: | ID: | 236022 |
| Label: | | Safety relevant: | | |
| Related To: | | Related To: | | |
| The integrator is responsible for ensuring that the S-WdgIf functionality is not unintentionally affected by other software (especially the AUTOSAR SW). This is, e.g., manipulation of local variables of S-WdgIf functions. | | | | |
| Category: | Comment | Keywords: | ID: | 287742 |
| This includes: <ul style="list-style-type: none">memory corruption (see section "S-WdgIf Application" below),source code modifications, andAPI function calls with wrong parameters. | | | | |

10.3 S-WdgIf Configuration

| | | | | | |
|---|---------|-----------|--|-----|--------|
| Category: | Comment | Keywords: | | ID: | 236026 |
| <p>The S-WdgIf has two kinds of configuration:</p> <ul style="list-style-type: none"> • pre-processor options and • link-time configuration data. | | | | | |

| | | | | | |
|--|---------|-----------|--|-----|--------|
| Category: | Comment | Keywords: | | ID: | 236032 |
| <p>The pre-processor options are generated out of an ECU configuration using the S-WdgIf Generator (coded in the generated file WdgIf_Cfg_Features.h). They activate or deactivate certain S-WdgIf features and cannot be altered during runtime. See section "S-WdgIf Configuration Generator" in this document for details on the S-WdgIf Generator and its application. See [TT_WDGIF_UM] for details on the pre-processor options.</p> | | | | | |

| | | | | | |
|--|---------|-----------|--|-----|--------|
| Category: | Comment | Keywords: | | ID: | 236034 |
| <p>The link-time configuration data is also generated out of the ECU configuration using the S-WdgIf Generator (coded in the generated files WdgIf_Lcfg.h and WdgIf_Lcfg.c). The link-time configuration defines the used WD devices with links to the device specific functions and cannot be altered during runtime. See section "S-WdgIf Configuration Generator" above for details on the S-WdgIf Generator and its application. See [TT_WDGIF_UM] for more information about on the link-time configuration data.</p> | | | | | |

| | | | | | |
|--|---------|-----------|--|-----|--------|
| Category: | Comment | Keywords: | | ID: | 236042 |
| <p>The integrator is responsible for generation and verification of configuration data as depicted in section "S-WdgIf Configuration Generator" above.</p> | | | | | |

| | | | | | |
|--|-------------|------------------|--|-----|--------|
| Category: | Requirement | Keywords: | | ID: | 236044 |
| Label: | | Safety relevant: | | | |
| Related To: | | Related To: | | | |
| <p>The integrator shall guarantee that the configuration data is not altered, e.g. through erroneous HW.</p> | | | | | |

| | | | | | |
|--|---------|-----------|--|-----|--------|
| Category: | Comment | Keywords: | | ID: | 236046 |
| <p>This can be realized - for example - with ECC ROM/FLASH checks, cyclical ROM/FLASH checks, and start up ROM/FLASH checks.</p> | | | | | |

10.4 File Structure

| | | | | | |
|--|---------|-----------|--|-----|--------|
| Category: | Comment | Keywords: | | ID: | 236055 |
| <p>For information about the S-WdgIf file structure see [TT_WDGIF_UM].</p> | | | | | |

| | | | | | |
|---|---------|-----------|--|-----|--------|
| Category: | Comment | Keywords: | | ID: | 236057 |
| <p>The following table shows the files that are only included when the according compiler directive is set to STD_ON:</p> | | | | | |

| Include File | Compiler Directive |
|--------------|------------------------|
| Det.h | WDGIF_DEV_ERROR_DETECT |

table 11

| | | | | |
|-----------|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 236061 |
|-----------|---------|-----------|-----|--------|

See also the requirement 234574 for File inclusion.

10.5 S-WdgIf Integration

| | | | | |
|-----------|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 236065 |
|-----------|---------|-----------|-----|--------|

This section describes how to integrate the S-WdgIf into a safety-relevant system.

| | | | | |
|-------------|-------------|------------------|-----|--------|
| Category: | Requirement | Keywords: | ID: | 236240 |
| Label: | | Safety relevant: | | |
| Related To: | | Related To: | | |

It is the responsibility of the integrator to demonstrate that the generated S-WdgIf configuration is sufficient for the considered system.

| | | | | |
|-------------|-------------|------------------|-----|--------|
| Category: | Requirement | Keywords: | ID: | 236256 |
| Label: | | Safety relevant: | | |
| Related To: | | Related To: | | |

The integrator is responsible for a correct integration of the S-WdgIf code on the system level as described in this section.

| | | | | |
|-------------|-------------|------------------|-----|--------|
| Category: | Requirement | Keywords: | ID: | 236258 |
| Label: | | Safety relevant: | | |
| Related To: | | Related To: | | |

The integrator shall verify that the chosen WD device(s), which is internal or external, meets the system's safety requirements.

| | | | | |
|-----------|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 236260 |
|-----------|---------|-----------|-----|--------|

For single oscillator MCU's (where the watchdog clock is derived from the CPU main clock) it is recommended to use an external watchdog device with its own oscillator as well.

10.5.1 Import from AUTOSAR Definitions into S-WdgIf

| | | | | |
|-------------|-------------|------------------|-----|--------|
| Category: | Requirement | Keywords: | ID: | 236264 |
| Label: | | Safety relevant: | | |
| Related To: | | Related To: | | |

The integrator is responsible for the correct implementation of all types and definitions that are imported from AUTOSAR header files and used by the S-WdgIf code according to AUTOSAR specifications.

| | | | | |
|--|-------------|------------------|-----|--------|
| Category: | Comment | Keywords: | ID: | 554231 |
| See also section "Imported Types and Definitions" above. | | | | |
| Category: | Requirement | Keywords: | ID: | 236266 |
| Label: | | Safety relevant: | | |
| Related To: | | Related To: | | |
| The integrator is responsible for providing the AUTOSAR header files for the import of the AUTOSAR types and definitions. | | | | |
| Category: | Comment | Keywords: | ID: | 236268 |
| For a list of imported AUTOSAR types and definitions and the related header files, see section "Imported Types and Definitions" above. | | | | |
| Category: | Requirement | Keywords: | ID: | 236270 |
| Label: | | Safety relevant: | | |
| Related To: | | Related To: | | |
| The inclusion of AUTOSAR header files into the S-Wdglf code shall not redefine any identifier that is defined within the S-Wdglf code. This prohibits, for example, redefinitions with #define macros. | | | | |
| Category: | Requirement | Keywords: | ID: | 236272 |
| Label: | | Safety relevant: | | |
| Related To: | | Related To: | | |
| The integrator is responsible for providing the correct code of used AUTOSAR functions. That is, correct in version and functionality. | | | | |
| Category: | Comment | Keywords: | ID: | 236274 |
| For a list of used AUTOSAR functions, see section "Expected Interface" above. | | | | |
| Category: | Requirement | Keywords: | ID: | 236276 |
| Label: | | Safety relevant: | | |
| Related To: | | Related To: | | |
| It is the responsibility of the integrator to provide a file Std_Types.h according to the comments in section "Imported Types and Definitions" above. | | | | |
| Category: | Requirement | Keywords: | ID: | 236278 |
| Label: | | Safety relevant: | | |
| Related To: | | Related To: | | |
| It is the responsibility of the integrator to provide a file Platform_Types.h according to the comments in section "Imported Types and Definitions" above. | | | | |
| Category: | Requirement | Keywords: | ID: | 236280 |
| Label: | | Safety relevant: | | |
| Related To: | | Related To: | | |
| It is the responsibility of the integrator to provide a file Compiler.h and a file Compiler_Cfg.h according to the comments in section "Imported Types and Definitions" above. | | | | |

| | | | | |
|--|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 236282 |
| Note: Some other integrated products provide their own contents for Compiler_Cfg.h. They need to be merged into the file Compiler_Cfg.h of the system. | | | | |

| | | | | |
|--|-------------|------------------|-----|--------|
| Category: | Requirement | Keywords: | ID: | 236284 |
| Label: | | Safety relevant: | | |
| Related To: | | Related To: | | |
| It is the responsibility of the integrator to provide a file MemMap.h according to the AUTOSAR specifications. | | | | |

| | | | | |
|--|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 236600 |
| In contrast to the S-WdgM, there is no configuration dependent memory management. All memory management definitions for the S-WdgIf are located in MemMap.h. | | | | |

| | | | | |
|--|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 236286 |
| Note: Some other integrated products provide their own contents for MemMap.h. They need to be merged into the file Memmap.h file for the system. | | | | |

| | | | | |
|---|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 236290 |
| TTTech provides example files for <ul style="list-style-type: none"> MemMap.h (which includes the files WdgM_MemMap.h or WdgM_OSMemMap.h, and Wdg_MemMap.h) and demo_MemMap.h (with the memory mapping definitions of the complete S-WdgM Stack). | | | | |

| | | | | |
|--|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 561554 |
| The file WdgM_MemMap.h is used in AUTOSAR 3.1 environments. The file WdgM_OSMemMap.h is used in AUTOSAR 4.0 environments. | | | | |

10.5.2 Memory Mapping

| | | | | |
|---|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 236350 |
| This section lists the requirements for the memory mapping of the S-WdgIf data and code (including the generated S-WdgIf code). | | | | |

| | | | | |
|---|-------------|------------------|-----|--------|
| Category: | Requirement | Keywords: | ID: | 236762 |
| Label: | | Safety relevant: | | |
| Related To: | | Related To: | | |
| The integrator is responsible for the inclusion of the correct MemMap.h file into the S-WdgIf code. | | | | |

| | | | | |
|---|-------------|------------------|-----|--------|
| Category: | Requirement | Keywords: | ID: | 236356 |
| Label: | | Safety relevant: | | |
| Related To: | | Related To: | | |
| The integrator is responsible for the correct assignment of S-WdgIf data and code (including the generated S-WdgIf code) to the various memory sections according to the memory mapping keywords provided by the S-WdgIf. | | | | |

| | | | | |
|---|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 236612 |
| For the memory sections that are supported by the S-WdgIf see comment 235894 in section "Imported Types and Definitions" above. | | | | |

10.5.3 S-WdgIf Files

| | | | | |
|---|-------------|------------------|-----------------|--------|
| Category: | Requirement | Keywords: | ID: | 236360 |
| Label: | | Safety relevant: | | |
| Related To: | | Related To': | __MKSID__297368 | |
| <p>The integrator shall ensure that only</p> <ul style="list-style-type: none">files of a single delivered package andfiles generated with tools of this package <p>are installed.</p> <p>These are the files:</p> <ul style="list-style-type: none">WdgIf_Cfg_Features.h (generated),WdgIf_Lcfg.h (generated),WdgIf_Lcfg.c (generated),WdgIf_Cfg.h,WdgIf_Types.h,WdgIf.h, andWdgIf.c. | | | | |

10.5.4 Compilation and Linkage

| | | | | |
|--|-------------|------------------|-----|--------|
| Category: | Requirement | Keywords: | ID: | 236366 |
| Label: | | Safety relevant: | | |
| Related To: | | Related To: | | |
| The integrator is responsible for compilation of the S-WdgIf code with a compiler that is compliant to ANSI ISO/IEC 9899:1990. | | | | |

| | | | | |
|--|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 236370 |
| The generated code is compliant to ANSI ISO/IEC 9899:1990. It is also known as "ANSI C (C89)" and "ISO C (C90)". | | | | |

| | | | | |
|--|-------------|------------------|-----|--------|
| Category: | Requirement | Keywords: | ID: | 236374 |
| Label: | | Safety relevant: | | |
| Related To: | | Related To: | | |
| The integrator is responsible for compilation and linkage of the S-WdgIf into the AUTOSAR system in accordance with the system requirements. | | | | |

| | | | | |
|---|-------------|------------------|-----|--------|
| Category: | Requirement | Keywords: | ID: | 236378 |
| Label: | | Safety relevant: | | |
| Related To: | | Related To: | | |
| The integrator shall guarantee that the compiled and linked target binary is correctly loaded into the target system. | | | | |

10.5.5 S-WdgM Stack Requirements

| | | | | |
|---|-------------|------------------|-----|--------|
| Category: | Comment | Keywords: | ID: | 555505 |
| This section lists the requirements for the S-WdgM Stack that must be met for safe functioning of the S-WdgIf. | | | | |
| Category: | Requirement | Keywords: | ID: | 236382 |
| Label: | | Safety relevant: | | |
| Related To: | | Related To: | | |
| The integrator shall make sure that the S-WdgIf communicates with <ul style="list-style-type: none">an internal WD device (MCU inside) oran external WD device. | | | | |
| Category: | Comment | Keywords: | ID: | 558045 |
| The communication between the S-WdgIf and the WD driver can be tested with negative integration tests. | | | | |
| Category: | Comment | Keywords: | ID: | 236384 |
| For ASIL C and D systems, it is recommended to use an external WD device with independent time based clock, reset circuit and power path. | | | | |
| Category: | Comment | Keywords: | ID: | 236386 |
| See <ul style="list-style-type: none">ISO 26262 (see [ISO26262], part 6, section 7.4.14, table 4/1d) andMicrocontroller manufacturer recommendation(see e.g. [TI_SPNU511_UM] section 5.3.6). | | | | |
| Category: | Requirement | Keywords: | ID: | 237306 |
| Label: | | Safety relevant: | | |
| Related To: | | Related To: | | |
| The integrator shall verify that the communication path to the external WD does not degrade the quality level below the required quality level. | | | | |
| Category: | Comment | Keywords: | ID: | 554234 |
| The requirement 237306 above is only relevant when an external WD is used. Note: The communication path to the external WD could be e.g. a SPI driver. | | | | |
| Category: | Requirement | Keywords: | ID: | 237369 |
| Label: | | Safety relevant: | | |
| Related To: | | Related To: | | |
| The integrator shall guarantee that the S-WdgIf program code - including configuration code - can not be corrupted. | | | | |
| Category: | Comment | Keywords: | ID: | 554832 |
| This can be realized - for example - with ECC ROM/FLASH checks, cyclical ROM/FLASH checks, and start up ROM/FLASH checks. | | | | |

10.6 S-WdgIf Application

| | | | | |
|---|-------------|------------------|-----|--------|
| Category: | Comment | Keywords: | ID: | 236760 |
| In contrast to the S-WdgM, the S-WdgIf API functions are not called from application level. Except WdgIf_GetVersionInfo (), all S-WdgIf functions are called by the S-WdgM. However, there are a few requirements to be considered on system level. | | | | |
| Category: | Comment | Keywords: | ID: | 261300 |
| The S-WdgIf does not alter data that is passed through from or to the S-WdgM. Only the contents of the variable whose address is passed as parameter to WdgIf_GetVersionInfo () is altered. | | | | |
| Category: | Requirement | Keywords: | ID: | 236428 |
| Label: | | Safety relevant: | | |
| Related To: | | Related To: | | |
| The integrator is responsible for correct handling and escalation of errors detected by the S-WdgIf code via DET monitoring. | | | | |
| Category: | Comment | Keywords: | ID: | 236756 |
| Returned error codes are handled by the caller of the function that returns a DET error. | | | | |
| Category: | Requirement | Keywords: | ID: | 236430 |
| Label: | | Safety relevant: | | |
| Related To: | | Related To: | | |
| The data that is used by the S-WdgIf, especially the S-WdgIf Configuration data, shall not be modified by any other SW of the system. | | | | |
| Category: | Requirement | Keywords: | ID: | 236432 |
| Label: | | Safety relevant: | | |
| Related To: | | Related To: | | |
| It shall be considered that the S-WdgIf code has no mechanism for detecting and/or correcting the following errors: <ul style="list-style-type: none"> • corruption of the S-WdgIf memory for constants, • corruption of the S-WdgIf code memory, and • corruption of the S-WdgIf local RAM memory (i.e. the local variables placed on the stack). | | | | |
| Category: | Requirement | Keywords: | ID: | 236434 |
| Label: | | Safety relevant: | | |
| Related To: | | Related To: | | |
| The integrator shall guarantee that the address spaces that are listed in the requirement above and for which the S-WdgIf offers no mechanism for error detection and error correction can not be corrupted. | | | | |
| Category: | Comment | Keywords: | ID: | 236438 |
| If a mechanism for detecting/correcting of such manipulations is implemented in the application level or system level, then it should also cover the S-WdgIf code. | | | | |

10.6.1 S-WdgIf API Functions

| | | | | |
|---|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 262246 |
| There are no function specific requirements for the S-WdgIf API functions, except WdgIf_GetVersionInfo (). However, some requirements concern all functions need to be met. | | | | |

| | | | | |
|---|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 262301 |
| The considered API functions/macros are: <ul style="list-style-type: none">• WdgIf_Setmode (),• WdgIf_SetTriggerCondition (),• WdgIf_SetTriggerWindow (),• WdgIf_GetTickCounter (), and• WdgIf_GetVersionInfo () (macro). | | | | |

| | | | | |
|---|-------------|------------------|-----|--------|
| Category: | Requirement | Keywords: | ID: | 262242 |
| Label: | | Safety relevant: | | |
| Related To: | | Related To: | | |
| It is the responsibility of the integrator to verify the correctness of parameters passed to the S-WdgIf API functions. Especially, that parameters are not modified when passed from S-WdgM API functions to S-WdgIf API functions . | | | | |

| | | | | |
|--|-------------|------------------|-----|--------|
| Category: | Requirement | Keywords: | ID: | 262243 |
| Label: | | Safety relevant: | | |
| Related To: | | Related To: | | |
| Some S-WdgIf API functions have a pointer to data as argument. The integrator is responsible that this data is not modified by code other than the S-WdgM. | | | | |

| | | | | |
|--|-----------------|------------------|-----|--------|
| Category: | Requirement | Keywords: | ID: | 265954 |
| Label: | | Safety relevant: | | |
| Related To: | __MKSID__263878 | Related To: | | |
| WdgIf_GetVersionInfo () shall be called with a correct pointer (e.g. use a pointer of type Std_VersionInfoType without a type cast). | | | | |

10.6.2 Memory Access

| | | | | |
|--|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 236784 |
| The S-WdgIf does not access the hardware registers directly. The hardware could be accessed by calls of the S-Wdg driver functions. The access of registers by the S-Wdg driver is platform and implementation dependent and "supervisor" or "privileged" MCU mode may be necessary. | | | | |

10.6.3 Concurrent Function Calls

| | | | | | |
|---|------------------|------------------------------|---------------------------|-------------------------|-------------------------|
| Category: | Comment | Keywords: | ID: | 283153 | |
| The following table shows which functions may run concurrently: | | | | | |
| The function below is interrupted by the function on the right side | WdgIf_SetMode () | WdgIf_SetTriggerCondition () | WdgIf_SetTriggerWindow () | WdgIf_GetVersionInfo () | WdgIf_GetTickCounter () |
| WdgIf_SetMode () | HW | HW | HW | Y | Y (reg) |
| WdgIf_SetTriggerCondition () | HW | HW | HW | Y | Y (reg) |
| WdgIf_SetTriggerWindow () | HW | HW | HW | Y | Y (reg) |
| WdgIf_GetVersionInfo () | Y | Y | Y | Y (ptr) | Y |
| WdgIf_GetTickCounter () | Y (reg) | Y (reg) | Y (reg) | Y | Y |

figure 1

| | |
|----|---|
| HW | The interruption is HW dependent and only allowed if interruption of the corresponding WD driver function is allowed. The corresponding function is: <ul style="list-style-type: none"> for WdgIf_SetMode (): Wdg_infix_SetMode (), for WdgIf_SetTriggerCondition (): Wdg_infix_SetTriggerWindow () or Wdg_infix_SetTriggerCondition () (depending on the AUTOSAR version) for WdgIf_SetTriggerWindow (): Wdg_infix_SetTriggerWindow () or Wdg_infix_SetTriggerCondition () (depending on the AUTOSAR version) for WdgIf_GetTickCounter (): Wdg_infix_GetTickCounter () |
| Y | Interruption is allowed |

| | |
|--------|---|
| Y(ptr) | Interruption is allowed only if the pointers, given as an output parameter to the function, are different |
| Y(reg) | Interruption is allowed only if the function <code>Wdg_infix_GetTickCount()</code> is implemented as a pure HW register read. |

table 12

11 Safety Lifecycle Tailoring

| | | | | |
|--|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 234297 |
| This section describes which phases of the S-WdgIf product safety lifecycle according to [ISO26262] were executed by TTTech during the development and which phases have to be executed by the integrator. | | | | |
| Category: | Comment | Keywords: | ID: | 234299 |
| The S-WdgIf is a software unit representing a safety element out of context (SEooC) according to [ISO26262], part 10. The SW requirements of the S-WdgIf are based on [AS_WDGIF_SWS] and [TT_WDGIF_SRD] with deviations listed in [TT_WDGIF_UM]. The architectural design is documented in [TT_WDGIF_UDD]. | | | | |
| Category: | Comment | Keywords: | ID: | 234301 |

software architecture through traceability

| | | | | | |
|-------------|-------------|------------------|--|-----|--------|
| Category: | Requirement | Keywords: | | ID: | 234315 |
| Label: | | Safety relevant: | | | |
| Related To: | | Related To: | | | |

The integrator is responsible for the execution of ISO/DIS 26262 phase 6-10 (SW integration and testing) to verify that S-WdgIf code is correctly integrated into the system.

| | | | | | |
|-------------|-------------|------------------|--|-----|--------|
| Category: | Requirement | Keywords: | | ID: | 234319 |
| Label: | | Safety relevant: | | | |
| Related To: | | Related To: | | | |

The integrator is responsible for the execution of phase ISO/DIS 26262 6-11 (Verification of SW safety requirements) to verify the safety requirements that are related to the S-WdgIf code.

12 Qualification

| | | | | |
|---|-------------|------------------|-----|--------|
| Category: | Comment | Keywords: | ID: | 234207 |
| The S-WdgIf has been developed according to the requirements in [ISO26262] as specified in section "Safety Lifecycle Tailoring" above. It can be integrated in systems up to ASIL D, provided that all requirements in this document are fulfilled. | | | | |
| Category: | Comment | Keywords: | ID: | 234209 |
| The hardware dependent qualification data for the S-WdgIf for each platform can be found in the S-Wdg drivers' Safety Manuals. | | | | |
| Category: | Comment | Keywords: | ID: | 234211 |
| The S-WdgM Stack Safety Case [TT_WDGS_SC] lists all S-WdgIf qualification documents. | | | | |
| Category: | Comment | Keywords: | ID: | 234213 |
| The S-WdgIf unit tests are specified in [TT_WDGIF_UTS]. The S-WdgIf tests of the unit test framework are specified in [TT_WDGS_UTS]. The integration tests of the S-WdgM Stack are specified in [TT_WDGS_ITS]. | | | | |
| Category: | Comment | Keywords: | ID: | 260894 |
| The environments and S-WdgIf Configurations of integration tests that have been conducted by TTTech can be found in the Safety Manual of the various S-Wdg drivers (e.g. [TT_WDGDR_platform_SM], where <i>platform</i> is the used platform. See also section "References" at the end of the document). | | | | |
| Category: | Requirement | Keywords: | ID: | 234215 |
| Label: | | Safety relevant: | | |
| Related To: | | Related To: | | |
| The integrator is responsible for the qualification of the S-WdgIf code for the used environment. This means that the S-WdgIf code must be integration tested against this environment. The environment comprises: <ul style="list-style-type: none">• the target CPU,• the compiler and linker,• the compiler and linker settings,• S-WdgIf pre-compile configurations, and• the used WDs and WD drivers. | | | | |
| Category: | Requirement | Keywords: | ID: | 234217 |
| Label: | | Safety relevant: | | |
| Related To: | | Related To: | | |
| If the S-WdgIf is used in an environment that differs in any way from the environment it has been tested with (according to [TT_WDGS_ITS] and [TT_WDGIF_UTS]), then the integrator shall analyze the consequences of the differences and conduct corresponding tests (see [ISO26262] part 6, clause 9, in particular [ISO26262] clause 9.4.6). | | | | |

| | | | | |
|--|---|------------------|-----|--------|
| Category: | Comment | Keywords: | ID: | 234219 |
| TTTech offers qualification of the S-WdgIf for customer-specific configurations. | | | | |
| Category: | Requirement | Keywords: | ID: | 265956 |
| Label: | | Safety relevant: | | |
| Related To: | __MKSID__263827, __MKSID__263846, __MKSID__263860 | Related To: | | |
| The integrator shall run integration tests with the generated configurations for S-WdgM and S-WdgIf. | | | | |

13 Resource Requirements

| | | | | | |
|--|---------|-----------|--|-----|--------|
| Category: | Comment | Keywords: | | ID: | 234197 |
| <p>The memory consumption and runtime consumption of the S-WdgIf depends on the chosen HW, which itself is chosen by the used S-Wdg driver.</p> <p>The resource requirements of the complete S-WdgM Stack can be found in the Safety Manual of the according S-Wdg driver.</p> | | | | | |

14 Constraints and known Problems

| | | | | |
|--|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 290609 |
| For known problems see the Release Notes document delivered with this software module. | | | | |

15 References

| | | | | |
|--|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 234117 |
| [ISO26262] ISO26262, Internation Standard, Road vehicles- Functional safety, First edition 2011-11-15 | | | | |
| Category: | Comment | Keywords: | ID: | 234119 |
| [TT_WDGM_SM] TTTech Automotive GmbH, Safe Watchdog Manager - Safety Manual, D-SAFEX-S-70-001 | | | | |
| Category: | Comment | Keywords: | ID: | 234121 |
| [TT_WDGDR_MPC56xx_SM] TTTech Automotive GmbH, Safe Watchdog Driver for MPC56xx - Safety Manual, D-MSP-M-70-022 | | | | |
| Category: | Comment | Keywords: | ID: | 554844 |
| [TT_WDGDR_SAFETCORE_SM] TTTech Automotive GmbH, Safe Watchdog Driver for TriCore and SafeTcore - Safety Manual, D-SAFEX-S-70-013 | | | | |
| Category: | Comment | Keywords: | ID: | 234125 |
| [TT_WDGDR_TMS570LS3x_SM] TTTech Automotive GmbH, Safe Watchdog Driver for TMS570LS3x - Safety Manual, D-SAFEX-S-70-015 | | | | |
| Category: | Comment | Keywords: | ID: | 234123 |
| [TT_WDGDR_V850E2PJ4_SM] TTTech Automotive GmbH, Safe Watchdog Driver for V850E2PJ4 - Safety Manual, D-SAFEX-S-70-029 | | | | |
| Category: | Comment | Keywords: | ID: | 554842 |
| [TT_WDGDR_TMS570LS_TPS65381_SM] TTTech Automotive GmbH, Safe Watchdog Driver for TMS570LS_TPS65381 - Safety Manual, D-SAFEX-S-70-038 | | | | |
| Category: | Comment | Keywords: | ID: | 554840 |
| [TT_WDGDR_MPC5643L_ATA5021_SM] TTTech Automotive GmbH, Safe Watchdog Driver for MPC5643L_ATA5021 - Safety Manual, D-SAFEX-S-70-049 | | | | |
| Category: | Comment | Keywords: | ID: | 234127 |
| [TT_WDGS_SC] TTTech Automotive GmbH, Safe Watchdog Manager Stack - Safety Case, D-SAFEX-IN-70-001 | | | | |
| Category: | Comment | Keywords: | ID: | 234129 |
| [TT_WDGM_UM] TTTech Automotive GmbH, Safe Watchdog Manager - User Manual, D-MSP-M-70-001 | | | | |
| Category: | Comment | Keywords: | ID: | 234131 |
| [TT_WDGIF_UM] TTTech Automotive GmbH, Safe Watchdog Interface - User Manual, D-MSP-M-70-006 | | | | |

| | | | | |
|---|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 234133 |
| [TT_WDGDR_MPC56xx_UM] TTTech Automotive Gmbh, Safe Watchdog Driver (MPC56xx) - User Manual, D-MSP-M-70-008 | | | | |
| Category: | Comment | Keywords: | ID: | 234135 |
| [TT_WDGDR_SAFETCORE_UM] Safe Watchdog Driver (SafeTcore) - User Manual, D-MSP-M-70-007 | | | | |
| Category: | Comment | Keywords: | ID: | 234137 |
| [TT_WDGDR_TMS570LS3x_UM] TTTech Automotive GbmH, Safe Watchdog Driver (TMS570LS3x) - User Manual, D-MSP-M-70-010 | | | | |
| Category: | Comment | Keywords: | ID: | 234143 |
| [AS_WDGM_SWS] AUTOSAR, Specification of Watchdog Manager, Version 2.0.0, Release 4.0, Revision 1 | | | | |
| Category: | Comment | Keywords: | ID: | 234145 |
| [AS_WDGIF_SWS] AUTOSAR, Specification of Watchdog Interface, Version 2.3.0, Release 4.0, Revision 1 | | | | |
| Category: | Comment | Keywords: | ID: | 559938 |
| [AS_WDGIF_SWS_3_1] AUTOSAR, Specification of Watchdog Interface, Version 2.2.2, Release 3.1, Revision 1 | | | | |
| Category: | Comment | Keywords: | ID: | 234147 |
| [AS_WDGDR_SWS] AUTOSAR, Specification of Watchdog Driver, Version 2.3.0, Release 4.0, Revision 1 | | | | |
| Category: | Comment | Keywords: | ID: | 237766 |
| [AS_RTE_SWS] AUTOSAR, Specification of RTE, Version 3.0.0, Release 4.0, Revision 1 | | | | |
| Category: | Comment | Keywords: | ID: | 234149 |
| [AS_STDTYP_SWS] AUTOSAR, Specification of Standard Types, Version 1.3.0, Release 4.0, Revision 1 | | | | |
| Category: | Comment | Keywords: | ID: | 234151 |
| [AS_COMABS_SWS] AUTOSAR, Specification of Compiler Abstraction, Version 3.0.0, Release 4.0, Revision 1 | | | | |
| Category: | Comment | Keywords: | ID: | 234153 |
| [AS_PLTFM_SWS] AUTOSAR, Specification of Platform Types, Version 2.3.0, Release 4.0, Revision 1 | | | | |
| Category: | Comment | Keywords: | ID: | 234155 |
| [AS_MEM_SWS] AUTOSAR, Specification of Memory Mapping, Version 1.2.0, Release 4.0, Revision 1 | | | | |
| Category: | Comment | Keywords: | ID: | 234177 |
| [TI_SPNU511_UM] Texas Instruments, Safety Manual for TMS570LS31x/21x and RM48x Hercules™ ARM® Safety Critical Microcontrollers - User's Guide, Literature Number: SPNU511A, February 2012 | | | | |

15.1 Internal Documents

| | | | | |
|---|---------|-----------|-----|--------|
| Category: | Comment | Keywords: | ID: | 283409 |
| The following referenced documents are internal TTTech Automotive GmbH document. For inspection, please contact TTTech Automotive GmbH: | | | | |
| Category: | Comment | Keywords: | ID: | 283417 |
| [TT_WDGIF_ETA] TTTech Automotive GmbH, Safe Watchdog Interface - Event Tree Analysis, D-SAFEX-S-70-012 | | | | |
| Category: | Comment | Keywords: | ID: | 283419 |
| [TT_WDGIF_SRD]] TTTech Automotive GmbH, Safe Watchdog Interface - Software Requirements Document, D-SAFEX-S-70-002 | | | | |
| Category: | Comment | Keywords: | ID: | 283421 |
| [TT_WDGIF_UDD] TTTech Automotive GmbH, Safe Watchdog Interface - Unit Design Document, D-SAFEX-D-70-001 | | | | |
| Category: | Comment | Keywords: | ID: | 283423 |
| [TT_WDGIF_UTS] TTTech Automotive GmbH, Safe Watchdog Interface - Unit Test Specification, D-SAFEX-V-70-002 | | | | |
| Category: | Comment | Keywords: | ID: | 283427 |
| [TT_WDGS_UTS] TTTech Automotive GmbH, Safe Watchdog Manager Stack - Unit Test Specification - Test Framework, D-SAFEX-V-70-008 | | | | |
| Category: | Comment | Keywords: | ID: | 283425 |
| [TT_WDGS_ITS] TTTech Automotive GmbH, Safe Watchdog Manager Stack - Integration Test Specification, D-SAFEX-V-01-001 | | | | |
| Category: | Comment | Keywords: | ID: | 554880 |
| [TT_WDGS_ITR] TTTech Automotive GmbH, Safe Watchdog Manager Stack - Integration Test Report, D-SAFEX-V-01-002 | | | | |