

EL 9000 T/DT register list for devices with KE firmware from V3.06 (check the installed version in your device's MENU in item INFO HW, SW)													
ModBus address (dec)	ModBus address (hex)	Read coils (0x01)	Read holding registers (0x03)	Write single coil (0x05)	Write single register (0x06)	Write multiple registers (0x10)	Description	Access	Data type	Data length in bytes	Number of registers	Data	Example or description
0	0x0000	x					Device class	R	uint(16)	2	1		44 = EL 9000 DT series, 51 = EL 9000 T series
1	0x0001	x					Device type	RW	uint(16)	2	1	20 ASCII	EL 9080-60 DT
21	0x0015	x					Manufacturer	R	char	40	20	ASCII	
41	0x0029	x					Manufacturer address	R	char	40	20	ASCII	
61	0x003D	x					Manufacturer ZIP code	R	char	40	20	ASCII	
81	0x0051	x					Manufacturer phone number	R	char	40	20	ASCII	
101	0x0065	x					Manufacturer website	R	char	40	20	ASCII	
121	0x0079	x					Nominal voltage	R	float	4	2	Floating point number IEEE754	80
123	0x007B	x					Nominal current	R	float	4	2	Floating point number IEEE754	60
125	0x007D	x					Nominal power	R	float	4	2	Floating point number IEEE754	1200
127	0x007F	x					Max. Internal resistance	R	float	4	2	Floating point number IEEE754	30
129	0x0081	x					Min. Internal resistance	R	float	4	2	Floating point number IEEE754	0.09
131	0x0083	x					Article no.	R	char	40	20	ASCII	33210506
151	0x0097	x					Serial no.	R	char	40	20	ASCII	1234567890
171	0x00AB	x			x		User text	RW	char	40	20	ASCII	
191	0x00BF	x					Firmware version (KE)	R	char	40	20	ASCII	V3.02 16.08.2016
211	0x00D3	x					Firmware version (HMI)	R	char	40	20	ASCII	V2.08 22.09.2016
231	0x00E7	x					Firmware version (DR)	R	char	40	20	ASCII	V1.0.4.1 30.06.2016
402	0x0192	x		x			Remote mode	RW	uint(16)	2	1	Coils : Remote	0x0000 = off; 0xFF00 = on
405	0x0195	x		x			DC input	RW	uint(16)	2	1	Coils : Output/Input	0x0000 = off; 0xFF00 = on
407	0x0197	x		x			Condition of DC input after PF alarm	RW	uint(16)	2	1	Coils : Condition	0x0000 = off; 0xFF00 = auto
408	0x0198		x		x		Condition of DC input after power ON	RW	uint(16)	2	1	Reg : Condition	0xFFFF = off; 0xFFFE = Restore
409	0x0199	x		x			Operation mode (UIP/UIR)	RW	uint(16)	2	1	Coils : Operation mode	0x0000 = UIP; 0xFF00 = UIR
410	0x019A	x		x			Restart of the device (warm start)	W	uint(16)	2	1	Coils : Restart	0xFF00 = execute
411	0x019B	x		x			Acknowledge alarms	W	uint(16)	2	1	Coils : Alarms	0xFF00 = acknowledge
416	0x01A0	x		x			Analog interface: Reference voltage (pin VREF)	RW	uint(16)	2	1	Coils : VREF	0x0000 = 10V; 0xFF00 = 5V
417	0x01A1	x		x			Analog interface: REM-SB level	RW	uint(16)	2	1	Coils : REM-SB Level	0x0000 = normal; 0xFF00 = inverted
418	0x01A2	x		x			Analog interface: REM-SB action	RW	uint(16)	2	1	Coils : REM-SB Action	0x0000 = DC off; 0xFF00 = DC on/off
422	0x01A6	x		x			Speed of internal voltage controller	RW	uint(16)	2	1	Coils : Controller speed	0x0000 = Slow; 0xFF00 = Fast
425	0x01A9	x		x			Condition of DC input after leaving remote	RW	uint(16)	2	1	Coils : Condition	0x0000 = off; 0xFF00 = auto
440	0x01B8		x		x		Analog interface: Pin 14 configuration	RW	uint(16)	2	1	Reg: Alarms 1	0x0000 = OVP (default); 0x0001 = OCP; 0x0002 = OPP; 0x0003 = OVP + OCP; 0x0004 = OVP + OPP; 0x0005 = OCP + OPP; 0x0006 = OVP + OCP + OPP
441	0x01B9		x		x		Analog interface: Pin 6 configuration	RW	uint(16)	2	1	Reg: Alarms 2	0x0000 = OT + PF (default); 0x0001 = OT; 0x0002 = PF
442	0x01BA		x		x		Analog interface: Pin 15 configuration	RW	uint(16)	2	1	Reg: Status DC	0x0000 = CV; 0x0001 = DC on/off
500	0x01F4	x		x			Set voltage value	RW	uint(16)	2	1	0x0000 - 0xD0E5 (0 - 102%)	Voltage value (for translation see programming guide)
501	0x01F5	x		x			Set current value	RW	uint(16)	2	1	0x0000 - 0xD0E5 (0 - 102%)	Current value (for translation see programming guide)
502	0x01F6	x		x			Set power value	RW	uint(16)	2	1	0x0000 - 0xD0E5 (0 - 102%)	Power value (for translation see programming guide)
503	0x01F7	x		x			Set resistance value	RW	uint(16)	2	1	minimum - 0xD0E5 (x - 102%)	Resistance value (the minimum value varies from model to model and can be calculated from the technical specification in the manual)
505	0x01F9	x					Device state	R	uint(32)	4	2	Bit 0 - 4: Control location  Bit 7 : DC input state Bit 9-10 : Regulation mode Bit 11 : Remote Bit 13 : Function generator Bit 14 : Remote sensing Bit 15 : Alarms Bit 16 : OVP Bit 17 : OCP Bit 18 : OPP Bit 19 : OT Bit 21 : Power fail Bit 22 : Power fail Bit 23 : Power fail Bit 24 : UVD Bit 25 : OVD Bit 26 : UCD Bit 27 : OCD Bit 28 : OPD Bit 30 : REM-SB	0x00 = free; 0x01 = local; 0x02 = remote; 0x03 = USB; 0x04 = analog; 0x06 = Ethernet 0 = off; 1 = on 00 = CV; 01 = CR; 10 = CC; 11 = CP 0 = off; 1 = on 0 = stopped ; 1 = running 0 = off; 1 = on 0 = none; 1 = active 0 = none; 1 = active 0 = none; 1 = active 0 = none; 1 = active 0 = none; 1 = active 0 = none; 1 = active 0 = none; 1 = active 0 = none; 1 = active 0 = none; 1 = active 0 = none; 1 = active 0 = none; 1 = active 0 = none; 1 = active 0 = DC enabled; 1 = REM-SB disables DC output/input
507	0x01FB	x					Actual voltage	R	uint(16)	2	1	0x0000 - 0xFFFF (0 - 125%)	Actual voltage (for translation see programming guide)
508	0x01FC	x					Actual current	R	uint(16)	2	1	0x0000 - 0xFFFF (0 - 125%)	Actual current (for translation see programming guide)
509	0x01FD	x					Actual power	R	uint(16)	2	1	0x0000 - 0xFFFF (0 - 125%)	Actual power (for translation see programming guide)
520	0x0208	x					Count of OV alarms since power up	R	uint(16)	2	1	0x0000 - 0xFFFF	Count
521	0x0209	x					Count of OC alarms since power up	R	uint(16)	2	1	0x0000 - 0xFFFF	Count
522	0x020A	x					Count of OP alarms since power up	R	uint(16)	2	1	0x0000 - 0xFFFF	Count
523	0x020B	x					Count of OT alarms since power up	R	uint(16)	2	1	0x0000 - 0xFFFF	Count
524	0x020C	x					Count of PF alarms since power up	R	uint(16)	2	1	0x0000 - 0xFFFF	Count
550	0x0226	x		x			Overvoltage protection threshold (OVP)	RW	uint(16)	2	1	0x0000 - 0xE147 (0 - 110%)	OVP threshold (for translation see programming guide)
553	0x0229	x		x			Overcurrent protection threshold (OCP)	RW	uint(16)	2	1	0x0000 - 0xE147 (0 - 110%)	OCP threshold (for translation see programming guide)
556	0x022C	x		x			Overpower protection threshold (OPP)	RW	uint(16)	2	1	0x0000 - 0xE147 (0 - 110%)	OPP threshold (for translation see programming guide)
559	0x022F	x		x			Undervoltage detection (UVD)	RW	uint(16)	2	1	0x0000 - 0xD0E5 (0 - 102%)	UVD threshold (for translation see programming guide)
560	0x0230	x		x			Adjustable UVD notification	RW	uint(16)	2	1	Reg : Adjustable UVD notification	0x0000 = nothing; 0x0001 = signal; 0x0002 = warning; 0x0003 = alarm
561	0x0231	x		x			Overvoltage detection (OVD)	RW	uint(16)	2	1	0x0000 - 0xD0E5 (0 - 102%)	OVD threshold (for translation see programming guide)
562	0x0232	x		x			Adjustable OVD notification	RW	uint(16)	2	1	Reg : Adjustable OVD notification	0x0000 = nothing; 0x0001 = signal; 0x0002 = warning; 0x0003 = alarm
563	0x0233	x		x			Undercurrent detection (UCD)	RW	uint(16)	2	1	0x0000 - 0xD0E5 (0 - 102%)	UCD threshold (for translation see programming guide)
564	0												