






Power switch uses a relay to provide power to the rest of the circuitry beyond the power section itself. This bypasses the kind of dodgy switches, as well as making an exciting clicking sound. Solder in the bypass jumper to skip installing relay, but you'll need to unplug the cable to turn it off.







JP7 is intended as a way of enabling
 "one" of the two modes when a front
 panel has not been installed, jumpering
 it will override the switches on the panel.

Front panel connector as well as circuitry for switches and LEDs.
 LED resistor values are suggested safe values, but need to be adjusted for LEDs used.


Sheet: /Front Panel/
 File: front_panel.kicad_sch

Title: BulkyModem Module (Front Panel)

Size: A4
 KiCad E.D.A. 8.0.2

Date:

Rev:
 Id: 5/6



Mounting spot for an audio module that does not exist.

Sheet: /Audio Panel/ File: audio_panel.kicad_sch		
Title: BulkyModem Module (Audio Panel)		
Size: A4	Date:	Rev:
KiCad E.D.A. 8.0.2	Id: 6/6	