

## Philips Airfryer HD928X — User Guide (Text-only)

### 1. Important Safety Information

#### Danger

- Only place food inside the basket. Do not allow food to touch the heating elements.
- Do not cover air inlets/outlets.
- Never fill the pan with oil or liquid.
- Do not immerse the appliance in water.
- Prevent liquids from entering the appliance to avoid electric shock.
- Do not exceed the maximum food level in the basket.
- Do not touch interior surfaces while operating.
- Ensure the heating element is always clean and unobstructed.

#### Warning

- Verify that the voltage matches local mains supply.
- Do not use the appliance or cord if damaged.
- Keep the appliance and cord away from children under 8 years old.
- Only connect to an earthed socket.
- Leave 10 cm free space around the appliance.
- Steam and hot air exit from top/rear openings—keep distance.
- Hot surfaces—handle the pan and basket with care.
- Do not place the appliance near heat sources.
- Do not operate unattended.
- Unplug immediately if dark smoke appears.
- Store potatoes above 6°C to minimize acrylamide.
- Only operate at temperatures between 5°C and 40°C.

#### Caution

- Household use only.
- Allow appliance to cool for 30 minutes before cleaning.
- Ensure food cooks to a golden-yellow color.
- Be cautious with remote cooking or delayed start.
- Fatty foods may cause smoke.

#### Automatic Shut-off

The appliance switches off automatically after 20 minutes of inactivity.

### 2. Introduction

The Philips HD928X Airfryer uses Rapid Air Technology to fry, grill, roast, and bake with little to no oil.

### 3. General Description

Includes control panel, preset buttons, indicators, pan, basket, air inlet/outlet.

### 4. Wi-Fi Indicator Status

Off: Not connected.

On: Connected.

Blinking: Setup or reconnecting.

Blinking with pauses: Wi-Fi defect.

### 5. Before First Use

Remove packaging and clean all parts.

### 6. NutriU App

Instructions for pairing, remote cooking, and voice control.

### 7. Preparing for Use

Place on stable, heat-resistant surface and keep airflow unobstructed.

### 8. Using the Appliance

Airfry by setting temperature and time. Shake food when required.

### 9. Keep Warm Mode

Keeps food warm for 30 minutes at 80°C.

### 10. Using Presets

Includes presets for frozen snacks, fries, meat, fish, vegetables, cake, and keep warm.

11. Recipes from NutriU App

Select and start recipes directly from the App.

12. Homemade Fries

Steps: cut, soak 30 minutes, dry, coat with oil, airfry and shake.

13. Cleaning

Cool before cleaning. Pan and basket are dishwasher-safe.

14. Storage

Ensure appliance is cool and dry before storing.

15. Recycling

Dispose according to electronic waste regulations.

16. Firmware Updates

App and firmware update automatically when connected.

17. Factory Reset

Hold temp up + time up for 10 seconds.

18. Troubleshooting

Includes solutions for heating, Wi-Fi, smoke, error codes, etc.