



Replacing a shelf nondisruptively in a stretch MetroCluster configuration

ONTAP MetroCluster

netapp-ivanad, ntap-bmegan
April 21, 2021

This PDF was generated from https://docs.netapp.com/us-en/ontap-metrocluster/maintain/task_replace_a_shelf_nondisruptively_in_a_stretch_mcc_configuration.html on April 28, 2021. Always check docs.netapp.com for the latest.

Table of Contents

Replacing a shelf nondisruptively in a stretch MetroCluster configuration. 1

Replacing a shelf nondisruptively in a stretch MetroCluster configuration

You can replace disk shelves without disruption in a stretch MetroCluster configuration with a fully populated disk shelf or a disk shelf chassis and transfer components from the shelf you are removing.


The disk shelf model you are installing must meet the storage system requirements specified in the [Hardware Universe](#), which includes supported shelf models, supported disk drive types, the maximum number of disk shelves in a stack, and supported ONTAP versions.

Steps

1. Properly ground yourself.
2. Identify all aggregates and volumes that have disks from the loop that contains the shelf you are replacing and make note of the affected plex name.

Either node might contain disks from the loop of the affected shelf and host aggregates or host volumes.

3. Choose one of the following two options based on the replacement scenario you are planning.
 - If you are replacing a complete disk shelf, including the shelf chassis, disks, and I/O modules (IOM), take the corresponding action as described in the table below:

Scenario	Action
The affected plex contains fewer disks from the affected shelf.	Replace the disks one-by-one on the affected shelf with spares from another shelf. <div> You can take the plex offline after completing the disk replacement.</div>
The affected plex contains more disks than are in the affected shelf.	Move the plex offline and then delete the plex.
The affected plex has any disk from the affected shelf.	Move the plex offline but do not delete it.

- If you are replacing only the disk shelf chassis and no other components, perform the following steps:
 - a. Offline the affected plexes from the controller where they are hosted:
aggregate offline
 - b. Verify that the plexes are offline:

aggregate status -r

4. Identify the controller SAS ports to which the affected shelf loop is connected and disable the SAS ports on both site controllers:

storage port disable -node node_name -port SAS_port

The affected shelf loop is connected to both sites.

5. Wait for ONTAP to recognize that the disk is missing. You can use the following commands to verify that the disk is missing: **sysconfig -a** or **sysconfig -r**.
6. Turn off the power switch on the disk shelf.
7. Unplug all power cords from the disk shelf.
8. Make a record of the ports from which you unplug the cables so that you can cable the new disk shelf in the same way.
9. Unplug and remove the cables connecting the disk shelf to the other disk shelves or the storage system.
10. Remove the disk shelf from the rack.

To make the disk shelf lighter and easier to maneuver, remove the power supplies and IOM. If you will be installing a disk shelf chassis, also remove the disk drives or carriers. Otherwise, avoid removing disk drives or carriers if possible because excessive handling can cause internal drive damage.

11. Install and secure the replacement disk shelf onto the support brackets and rack.
12. If you installed a disk shelf chassis, reinstall power supplies and IOM.
13. Reconfigure the stack of disk shelves by connecting all cables to the replacement disk shelf ports exactly as they were configured on the disk shelf that you removed.
14. Turn on the power to the replacement disk shelf and wait for the disk drives to spin up.
15. Change the disk shelf ID to a unique ID from 0 through 98.
16. Enable any SAS ports that you previously disabled and then wait for ONTAP to recognize that the disks are inserted.

You can use the following commands to verify that the disks are inserted: **sysconfig -a** or **sysconfig -r**.

17. If you are replacing the complete disk shelf (disk shelf chassis, disks, IOM), perform the following steps:



If you are replacing only the disk shelf chassis and no other components, go to Step 19.

- a. Use the **storage disk option modify -autoassign** command to determine whether disk auto assignment is enabled (on).

Disk assignment will occur automatically.

- b. If disk auto assignment is not enabled, assign disk ownership manually.

18. Move the plexes back online: **aggregate online plex name**
19. Recreate any plexes that were deleted by mirroring the aggregate.
20. Monitor the plexes as they begin resynchronizing:

aggregate status -r <aggregate name>

21. Verify that the storage system is functioning as expected:

system health alert show

Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system- without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.